infusion™

OcnOS® Open Compute Network Operating System for Service Providers Version 6.5.2

Carrier Ethernet Guide August 2024

IP Infusion Inc. Proprietary

© 2024 IP Infusion Inc. All Rights Reserved.

This documentation is subject to change without notice. The software described in this document and this documentation are furnished under a license agreement or nondisclosure agreement. The software and documentation may be used or copied only in accordance with the terms of the applicable agreement. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or any means electronic or mechanical, including photocopying and recording for any purpose other than the purchaser's internal use without the written permission of IP Infusion Inc.

IP Infusion Inc. 3965 Freedom Circle, Suite 200 Santa Clara, CA 95054 +1 408-400-1900 http://www.ipinfusion.com/

For support, questions, or comments via E-mail, contact:

support@ipinfusion.com

Trademarks:

IP Infusion and OcNOS are trademarks or registered trademarks of IP Infusion. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Use of certain software included in this equipment is subject to the IP Infusion, Inc. End User License Agreement at http://www.ipinfusion.com/license. By using the equipment, you accept the terms of the End User License Agreement.

Contents

Preface	10
IP Maestro Support	10
Audience	10
Conventions	10
Chapter Organization	10
Related Documentation	10
Feature Availability	11
Migration Guide	11
Support	11
Comments	11
Command Line Interface	12
Overview	12
Command Line Interface Help	12
Command Completion	13
Command Abbreviations	13
Command Line Errors	13
Command Negation	14
Syntax Conventions	14
Variable Placeholders	15
Command Description Format	16
Keyboard Operations.	16
Show Command Modifiers	17
String Parameters	20
Command Modes	20
Transaction-based Command-line Interface	22
Carrier Ethernet Configuration	22
	25
CHAPTER 1 Ethernet CFM Configurations	24
Continuity Check Message (CCM)	24
EVPN-ELINE CFM Sub-Interface on Multi-Homing	35
VPWS-CFM and Y1731 over Sub-Interface	48
CHAPTER 2 Y.1731 Performance Monitoring Configurations	59
Synthetic Loss Measurement (SLM) over L2 Bridge.	59
EVPN-ELINE (Y1731) Sub-Interface on Single Homing	108
CHAPTER 3 V1731 and CEM Over Cross-connect Sub-interface	125
Prereguisites	125
Configuration	126
Implementation Examples	133
Glossary	133

CHAPTER 4 Overview Prerequisites . Configuration. Implementation Glossary	Y.1731 and CFM Over EVPN ELINE Single Home 13 13 13 13 13 14 14 Y.1731 and CEM Over EVPN-ELINE Multi-home 14	445557
Overview	Y.1731 and CFM Over EVPN-ELINE Multi-nome 14	7
CHAPTER 6 Overview Prerequisites . Configuration Implementation Glossary	Y.1731 and CFM Over VPWS Sub-interface	0 0 0 9 9
CHAPTER 7 Overview Prerequisites . Configuration Implementation Glossary	Y.1731 and CFM Over EVPN ELAN Single Home	1 1 1 2 2
CHAPTER 8 Overview	Y.1731 and CFM Over EVPN-ELAN Multi-home	4 4
CHAPTER 9 Overview Prerequisites . Configuration Implementation Glossary	Y.1731 and CFM Over VPLS Sub-Interface	5 5 5 3 4
CHAPTER 10	Ethernet Linear Protection Switching Configuration 20	5
CHAPTER 11 Topology Validation Sub-ring with Sub-ring with ERPS Manag	G.8032 ERPS Version 2	1 0 3 5 4
CHAPTER 12 Overview Prerequisites . Major Ring Co Sub-ring with Sub-ring with Implementatio New CLI Com	ERPS with CFM Down-MEP over Bridge-Domain 28 .28 .28 onfiguration .28 Virtual Channel Configuration .30 out Virtual Channel Configuration .31 on Examples .31 mands .31	8 8 9 8 5 7 8

Revised CLI Commands Troubleshooting Abbreviations Glossary	
CHAPTER 13 Ethernet in the First Mile Configuration	
CHAPTER 14 Ethernet Test Signal Lock Configuration Topology ETH-TST Configuration ETH-LCK Configuration	
CHAPTER 15 Ethernet Bandwidth Notification Configuration	
Carrier Ethernet Command Reference	338
CHAPTER 1 CFM and Y.1731 Commands	
abort loss-measurement	3/3
abort test-signal domain	344
adaptive bandwidth disable	345
ais interval	
ais status	
bins-per-fd-interval	
bins-per-ifdv-interval	
bin-type	
bn receive	351
bw-mapped-interface	352
cc interval	353
cc multicast	
cfm snmp restart	355
clear ethernet cfm delay-measurement history	356
clear ethernet cfm dm history	357
clear ethernet cfm lm history	358
clear ethernet cfm loss-measurement history	359
clear ethernet cfm maintenance-point remote	360
clear ethernet cfm statistics	361
clear ethernet cfm statistics bn	362
clear ethernet cfm statistics lck	363
clear ethernet cfm statistics test-signal	
clear ethernet cfm traceroute-cache	365
csf receive	366
debug ethernet cfm	367
delay-measurement type on-demand	
delay-measurement type proactive	
ethernet cfm delay-measurement profile-name	
ethernet cfm delay-measurement reply.	371

ethernet cfm domain-type	372
ethernet cfm loss-measurement profile-name	373
ethernet cfm loss-measurement reply	374
ethernet cfm mep	375
ethernet cfm mip.	377
ethernet cfm statistics csf	378
ethernet cfm test-signal profile-name	379
evpn	.380
ethernet cfm traceroute cache	381
exit-ether-ma-mep-mode	382
exit-ether-ma-mode	383
frame priority	384
hardware-profile filter cfm-domain-name-str	.385
	386
	387
	388
link-level	389
mep crosscheck	
message neriod	397
min creation	200
intervals_stored	400
neer-port-id	400
ning ethernet mac	/02
rmen auto-discoverv	403
service ma-type	404
show ethernet cfm ais reception-status	405
show ethernet cfm bn	406
show ethernet cfm bn mep	.407
show ethernet cfm csf	.408
show ethernet cfm csf mep	.409
show ethernet cfm delay-measurement mep	.410
show ethernet cfm delay-measurement profile	.413
show ethernet cfm dm sessions.	. 415
show ethernet cfm errors	
show ethernet cfm eth-bn status	417
show ethernet cfm frame-Im session	418
show ethernet cfm lck details domain	
show ethernet cfm lck statistics	420
show ethernet cfm loss-measurement mep	421
show ethernet cfm loss-measurement profile	.423
show ethernet cfm ma status	424

	show ethernet cfm maintenance-points count	.426
	show ethernet cfm maintenance-points local mep	.427
	show ethernet cfm maintenance-points local mip	.429
	show ethernet cfm maintenance-points remote	.430
	show ethernet cfm statistics	.431
	show ethernet cfm statistics bn	.433
	show ethernet cfm statistics csf	.434
	show ethernet cfm test-signal domain	.435
	show ethernet cfm test-signal profile	.436
	show ethernet cfm test-signal sessions	.437
	show ethernet cfm traceroute-cache	.438
	show running-config cfm	.439
	test-signal frame-size	.440
	test-signal mode	.441
	test-signal pattern-type	.442
	test-signal start-time	443
	test-signal test-type	445
	traceroute ethernet.	.446
	vlan	.447
	vpws	.448
	wait-to-restore-timer <0-86400>.	.449
С	HAPTER 2 G8031 ELPS Commands	450
	aps-channel level	.451
	васкир	.452
		.453
		.454
		.455
	debug g8031	.456
	eps-protection-group	.457
		.458
	force-switch	.459
	g8031-eps	.460
	g8031 eps-instance	.461
	g8031 eps-protection group	.462
	g8031 profile	.463
	local-freeze	.464
	local-lockout	.465
	lockout	.466
	manual-switch-protection	.467
	manual-switch-working	.468
	mode	.469
	protection-port	.470
	show g8031 eps-instance	.471
	show g8031 eps-instance <eps_id></eps_id>	.472
	show hsl g8031 debug	.474
	switching mode	.475

timer hold-off-time	476
timer wait-to-restore	477
working-port	478
CHAPTER 3 G.8032 ERPS Version 2 Commands	479
aps-channel level	
aps-channel vlan	481
clear g8032 erp-instance	482
data vlan	483
debug g8032	484
east-interface	485
enable-tcn-propagation	486
erps-instance	487
a8032 erp-instance	488
a8032 erp-instance force-switch	489
d8032 erp-instance manual-switch	490
a8032 ring	401
g0002 mg	102
g0002-profile	402
	495
nng	
ring-ia	
ring-type	497
rpl role	498
show g8032 erp-instance	499
show g8032 profile	502
show g8032 ring	503
switching mode	504
tcn-to-instance	505
timer	506
virtual-channel	507
west-interface	508
CHAPTER 4 EFM OAM Commands	509
clear ethernet oam statistics interface	510
debug ethernet oam	511
ethernet oam enable	512
ethernet oam link-monitor event-log-size	513
ethernet oam link-monitor on	514
ethernet oam link-monitor supported	515
ethernet oam max-rate	516
ethernet oam min-rate	517
ethernet oam mode	518
ethernet oam remote-failure	
ethernet oam remote-loopback (startistop)	
ethernet oam remote-loopback (supported)timeout	521
ethernet oam timeout	522
show ethernet cam	502

show ethernet oam discovery	525
show ethernet oam eventlog	526
show ethernet oam statistics	527
show ethernet oam status	528
show ethernet oam discovery brief	529
lades	520
Index	530

Preface

This guide describes how to configure OcNOS.

IP Maestro Support

Monitor devices running OcNOS Release 6.3.4-70 and above using IP Maestro software.

Audience

This guide is intended for network administrators and other engineering professionals who configure OcNOS.

Conventions

Table P-1 shows the conventions used in this guide.

Table P-1: Conventions

Convention	Description
Italics	Emphasized terms; titles of books
Note:	Special instructions, suggestions, or warnings
monospaced type	Code elements such as commands, parameters, files, and directories

Chapter Organization

The chapters in command references are organized as described in Command Description Format.

The chapters in configuration guides are organized into these major sections:

- An overview that explains a configuration in words
- · Topology with a diagram that shows the devices and connections used in the configuration
- Configuration steps in a table for each device where the left-hand side shows the commands you enter and the right-hand side explains the actions that the commands perform
- · Validation which shows commands and their output that verify the configuration

Related Documentation

For information about installing OcNOS, see the Installation Guide for your platform.

Feature Availability

The features described in this document that are available depend upon the OcNOS SKU that you purchased. See the *Feature Matrix* for a description of the OcNOS SKUs.

Migration Guide

Check the Migration Guide for configuration changes to make when migrating from one version of OcNOS to another.

Support

For support-related questions, contact support@ipinfusion.com.

Comments

If you have comments, or need to report a problem with the content, contact techpubs@ipinfusion.com.

Command Line Interface

This chapter introduces the OcNOS Command Line Interface (CLI) and how to use its features.

Overview

You use the CLI to configure, monitor, and maintain OcNOS devices. The CLI is text-based and each command is usually associated with a specific task.

You can give the commands described in this manual locally from the console of a device running OcNOS or remotely from a terminal emulator such as putty or xterm. You can also use the commands in scripts to automate configuration tasks.

Command Line Interface Help

You access the CLI help by entering a full or partial command string and a question mark "?". The CLI displays the command keywords or parameters along with a short description. For example, at the CLI command prompt, type:

> show ?

-1---- 0

The CLI displays this keyword list with short descriptions for each keyword:

SHOW :	
application-priority	Application Priority
arp	Internet Protocol (IP)
bfd	Bidirectional Forwarding Detection (BFD)
pdb	Border Gateway Protocol (BGP)
bi-lsp	Bi-directional lsp status and configuration
bridge	Bridge group commands
ce-vlan	COS Preservation for Customer Edge VLAN
class-map	Class map entry
cli	Show CLI tree of current mode
clns	Connectionless-Mode Network Service (CLNS)
control-adjacency	Control Adjacency status and configuration
control-channel	Control Channel status and configuration
cspf	CSPF Information
customer	Display Customer spanning-tree
cvlan	Display CVLAN information
debugging	Debugging functions (see also 'undebug')
etherchannel	LACP etherchannel
ethernet	Layer-2
	_

If you type the ? in the middle of a keyword, the CLI displays help for that keyword only.

> show de? debugging Debugging functions (see also 'undebug')

If you type the ? in the middle of a keyword, but the incomplete keyword matches several other keywords, OcNOS displays help for all matching keywords.

```
> show i? (CLI does not display the question mark).
interface Interface status and configuration
ip IP information
isis ISIS information
```

Command Completion

The CLI can complete the spelling of a command or a parameter. Begin typing the command or parameter and then press the tab key. For example, at the CLI command prompt type sh:

> sh

Press the tab key. The CLI displays:

```
> show
```

If the spelling of a command or parameter is ambiguous, the CLI displays the choices that match the abbreviation. Type show i and press the tab key. The CLI displays:

```
> show i
    interface ip ipv6 isis
> show i
```

The CLI displays the interface and ip keywords. Type n to select interface and press the tab key. The CLI displays:

```
> show in
> show interface
```

Type ? and the CLI displays the list of parameters for the show interface command.

```
> show interface
IFNAME Interface name
| Output modifiers
> Output redirection
<cr>>
```

The CLI displays the only parameter associated with this command, the IFNAME parameter.

Command Abbreviations

The CLI accepts abbreviations that uniquely identify a keyword in commands. For example:

```
> sh int xe0
```

is an abbreviation for:

```
> show interface xe0
```

Command Line Errors

Any unknown spelling causes the CLI to display the error Unrecognized command in response to the ?. The CLI displays the command again as last entered.

```
> show dd?
% Unrecognized command
> show dd
```

When you press the Enter key after typing an invalid command, the CLI displays:

(config) #router ospf here

```
% Invalid input detected at '^' marker.
```

where the ^ points to the first character in error in the command.

If a command is incomplete, the CLI displays the following message:

> show
% Incomplete command.

Some commands are too long for the display line and can wrap mid-parameter or mid-keyword, as shown below. This does *not* cause an error and the command performs as expected:

```
area 10.10.0.18 virtual-link 10.10.0.19 authent ication-key 57393
```

Command Negation

Many commands have a no form that resets a feature to its default value or disables the feature. For example:

- The ip address command assigns an IPv4 address to an interface
- The no ip address command removes an IPv4 address from an interface

Syntax Conventions

Table P-2 describes the conventions used to represent command syntax in this reference.

Convention	Description	Example
monospaced font	Command strings entered on a command line	show ip ospf
lowercase	Keywords that you enter exactly as shown in the command syntax.	show ip ospf
UPPERCASE	See Variable Placeholders	IFNAME
()	Optional parameters, from which you must select one. Vertical bars delimit the selections. Do not enter the parentheses or vertical bars as part of the command.	(A.B.C.D <0-4294967295>)
()	Optional parameters, from which you select one or none. Vertical bars delimit the selections. Do not enter the parentheses or vertical bars as part of the command.	(A.B.C.D <0-4294967295>)
()	Optional parameter which you can specify or omit. Do not enter the parentheses or vertical bar as part of the command.	(IFNAME)
{}	Optional parameters, from which you must select one or more. Vertical bars delimit the selections. Do not enter the braces or vertical bars as part of the command.	{intra-area <1-255> inter-area <1-255> external <1-255>}

Table P-2: Syntax conventions

Convention	Description	Example
[]	Optional parameters, from which you select zero or more. Vertical bars delimit the selections. Do not enter the brackets or vertical bars as part of the command.	<pre>[<1-65535> AA:NN internet local-AS no-advertise no-export]</pre>
?	Nonrepeatable parameter. The parameter that follows a question mark can only appear once in a command string. Do not enter the question mark as part of the command.	?route-map WORD
•	Repeatable parameter. The parameter that follows a period can be repeated more than once. Do not enter the period as part of the command.	set as-path prepend .<1-65535>

Table P-2: Syntax conventions (Continued)

Variable Placeholders

Table P-3 shows the tokens used in command syntax use to represent variables for which you supply a value.

Token	Description
WORD	A contiguous text string (excluding spaces)
LINE	A text string, including spaces; no other parameters can follow this parameter
IFNAME	Interface name whose format varies depending on the platform; examples are: eth0, Ethernet0, ethernet0, xe0
A.B.C.D	IPv4 address
A.B.C.D/M	IPv4 address and mask/prefix
X:X::X:X	IPv6 address
X:X::X:X/M	IPv6 address and mask/prefix
HH:MM:SS	Time format
AA:NN	BGP community value
XX:XX:XX:XX:XX	MAC address
<1-5> <1-65535> <0-2147483647> <0-4294967295>	Numeric range

Table P-3: Variable placeholders

Command Description Format

Table P-4 explains the sections used to describe each command in this reference.

Section	Description
Command Name	The name of the command, followed by what the command does and when should it be used
Command Syntax	The syntax of the command
Parameters	Parameters and options for the command
Default	The state before the command is executed
Command Mode	The mode in which the command runs; see Command Modes
Example	An example of the command being executed

Table P-4: Command descriptions

Keyboard Operations

Table P-5 lists the operations you can perform from the keyboard.

Table I	P-5: Ke	yboard	operations
		-	

Key combination	Operation
Left arrow or Ctrl+b	Moves one character to the left. When a command extends beyond a single line, you can press left arrow or Ctrl+b repeatedly to scroll toward the beginning of the line, or you can press Ctrl+a to go directly to the beginning of the line.
Right arrow or Ctrl-f	Moves one character to the right. When a command extends beyond a single line, you can press right arrow or Ctrl+f repeatedly to scroll toward the end of the line, or you can press Ctrl+e to go directly to the end of the line.
Esc, b	Moves back one word
Esc, f	Moves forward one word
Ctrl+e	Moves to end of the line
Ctrl+a	Moves to the beginning of the line
Ctrl+u	Deletes the line
Ctrl+w	Deletes from the cursor to the previous whitespace
Alt+d	Deletes the current word
Ctrl+k	Deletes from the cursor to the end of line
Ctrl+y	Pastes text previously deleted with Ctrl+k, Alt+d, Ctrl+w, or Ctrl+u at the cursor

Key combination	Operation
Ctrl+t	Transposes the current character with the previous character
Ctrl+c	Ignores the current line and redisplays the command prompt
Ctrl+z	Ends configuration mode and returns to exec mode
Ctrl+l	Clears the screen
Up Arrow or Ctrl+p	Scroll backward through command history
Down Arrow or Ctrl+n	Scroll forward through command history

Table P-5: Keyboard operations (Continued)

Show Command Modifiers

You can use two tokens to modify the output of a show command. Enter a question mark to display these tokens:

```
# show users ?
```

- | Output modifiers
- > Output redirection

You can type the | (vertical bar character) to use output modifiers. For example:

```
> show rsvp | ?
begin Begin with the line that matches
exclude Exclude lines that match
include Include lines that match
last Last few lines
redirect Redirect output
```

Begin Modifier

The begin modifier displays the output beginning with the first line that contains the input string (everything typed after the begin keyword). For example:

```
# show running-config | begin xe1
...skipping
interface xe1
ipv6 address fe80::204:75ff:fee6:5393/64
!
interface xe2
ipv6 address fe80::20d:56ff:fe96:725a/64
!
line con 0
login
!
end
```

You can specify a regular expression after the begin keyword, This example begins the output at a line with either "xe2" or "xe4":

```
# show running-config | begin xe[2-4]
```

```
...skipping
```

```
interface xe2
 shutdown
L
interface xe4
 shutdown
Т
interface svlan0.1
no shutdown
1
route-map myroute permit 2
route-map mymap1 permit 10
route-map rmap1 permit 2
1
line con 0
login
line vty 0 4
 login
Т
end
```

Include Modifier

The include modifier includes only those lines of output that contain the input string. In the output below, all lines containing the word "input" are included:

```
# show interface xe1 | include input
input packets 80434552, bytes 2147483647, dropped 0, multicast packets 0
input errors 0, length 0, overrun 0, CRC 0, frame 0, fifo 1, missed 0
```

You can specify a regular expression after the include keyword. This examples includes all lines with "input" or "output":

```
#show interface xe0 | include (in|out)put
input packets 597058, bytes 338081476, dropped 0, multicast packets 0
input errors 0, length 0, overrun 0, CRC 0, frame 0, fifo 0, missed 0
output packets 613147, bytes 126055987, dropped 0
output errors 0, aborted 0, carrier 0, fifo 0, heartbeat 0, window 0
```

Exclude Modifier

The exclude modifier excludes all lines of output that contain the input string. In the following output example, all lines containing the word "input" are excluded:

```
# show interface xe1 | exclude input
Interface xe1
Scope: both
Hardware is Ethernet, address is 0004.75e6.5393
index 3 metric 1 mtu 1500 <UP,BROADCAST,RUNNING,MULTICAST>
VRF Binding: Not bound
Administrative Group(s): None
DSTE Bandwidth Constraint Mode is MAM
inet6 fe80::204:75ff:fee6:5393/64
output packets 4438, bytes 394940, dropped 0
output errors 0, aborted 0, carrier 0, fifo 0, heartbeat 0, window 0
collisions 0
```

You can specify a regular expression after the exclude keyword. This example excludes lines with "output" or "input":

```
# show interface xe0 | exclude (in|out)put
Interface xe0
Scope: both
Hardware is Ethernet Current HW addr: 001b.2139.6c4a
Physical:001b.2139.6c4a Logical:(not set)
index 2 metric 1 mtu 1500 duplex-full arp ageing timeout 3000
<UP,BROADCAST,RUNNING,MULTICAST>
VRF Binding: Not bound
Bandwidth 100m
DHCP client is disabled.
inet 10.1.2.173/24 broadcast 10.1.2.255
VRRP Master of : VRRP is not configured on this interface.
inet6 fe80::21b:21ff:fe39:6c4a/64
collisions 0
```

Redirect Modifier

The redirect modifier writes the output into a file. The output is not displayed.

show cli history | redirect /var/frame.txt

The output redirection token (>) does the same thing:

show cli history >/var/frame.txt

Last Modifier

The last modifier displays the output of last few number of lines (As per the user input). The last number ranges from 1 to 9999.

For example:

```
#show running-config | last 10
```

String Parameters

The restrictions in Table P-6 apply for all string parameters used in OcNOS commands, unless some other restrictions are noted for a particular command.

Restriction	Description
Input length	1965 characters or less
Restricted special characters	"?", ",", ">", " ", and "="
	The " " character is allowed only for the description command in interface mode.

Table P-6: String parameter restrictions

Command Modes

Commands are grouped into modes arranged in a hierarchy. Each mode has its own set of commands. Table P-7 lists the command modes common to all protocols.

Name	Description
Executive mode	Also called <i>view</i> mode, this is the first mode to appear after you start the CLI. It is a base mode from where you can perform basic commands such as show, exit, quit, help, and enable.
Privileged executive mode	Also called <i>enable</i> mode, in this mode you can run additional basic commands such as debug, write, and show.
Configure mode	Also called <i>configure terminal</i> mode, in this mode you can run configuration commands and go into other modes such as interface, router, route map, key chain, and address family.
	Configure mode is single user. Only one user at a time can be in configure mode.
Interface mode	In this mode you can configure protocol-specific settings for a particular interface. Any setting you configure in this mode overrides a setting configured in router mode.
Router mode	This mode is used to configure router-specific settings for a protocol such as BGP or OSPF.

Table P-7: Common command modes

Command Mode Tree

The diagram below shows the common command mode hierarchy.



Figure P-1: Common command modes

To change modes:

- 1. Enter privileged executive mode by entering enable in Executive mode.
- 2. Enter configure mode by entering configure terminal in Privileged Executive mode.

The example below shows moving from executive mode to privileged executive mode to configure mode and finally to router mode:

```
> enable mypassword
# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
(config)# router ospf
(config-router)#
```

Note: Each protocol can have modes in addition to the common command modes. See the command reference for the respective protocol for details.

Transaction-based Command-line Interface

The OcNOS command line interface is transaction based:

- Any changes done in configure mode are stored in a separate *candidate* configuration that you can view with the show transaction current command.
- When a configuration is complete, apply the candidate configuration to the running configuration with the commit command.
- If a commit fails, no configuration is applied as the entire transaction is considered failed. You can continue to change the candidate configuration and then retry the commit.
- Discard the candidate configuration with the abort transaction command.
- Check the last aborted transaction with the show transaction last-aborted command.
- Multiple configurations cannot be removed with a single commit. You must remove each configuration followed by a commit.
- Note: All commands MUST be executed only in the default CML shell (cmlsh). If you log in as root and start imish, then the system configurations will go out of sync. The imish shell is not supported and should not be started manually.

Carrier Ethernet Configuration

CHAPTER 1 Ethernet CFM Configurations

This chapter discusses Ethernet Operations, Administration and Management (OAM) configuration using the Connectivity Fault Management (CFM) protocol.

CFM detects, verifies, isolates and notifies connectivity failures on a Virtual Bridged LAN (B- VLAN) based on the protocol standard specified in IEEE 802.1ag 2007. It provides discovery and verification of paths through 802.1 bridges and LANs and is part of the OAM module. CFM is transparent to customer data being transported by a network and is capable of providing maximum fault management.



Prerequisite

Configure below hardware-profile commands related to CFM in configuration mode and reboot the nodes.

```
hardware-profile filter cfm-domain-name-str enable hardware-profile statistics cfm-ccm enable
```

SW1#configure terminal	Enter configure mode.
SW1(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW1(config)#vlan database	Entering vlan database
SW1(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.

SW1(config-vlan)#exit	Exit vlan database
SW1(config)#interface ce49	Configure interface ce49.
SW1(config-if)#switchport	Configure the interface as switch port.
SW1(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW1(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW1(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.
SW1(config-if)#exit	Exit config mode.
SW1(config)#ethernet cfm domain-type character-string domain-name mdnam level 7 mip-creation default	Create cfm domain with type as character string and set mip creation criteria to default.
SW1(config-ether-cfm)#service ma-type string ma-name testtm	Create ma type as string and configure the ma
SW1(config-ether-cfm-ma)#vlan 25 bridge 1	Configure vlan-id to associate the vlan to the MA
SW1(config-ether-cfm-ma)#mip-creation default	Set the mip creation criteria to default for the MA
SW1(config-ether-cfm-ma)#ethernet cfm mep down mpid 2 active true ce49	Create down mep on ce49.
SW1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast.
SW1(config-ether-cfm-ma-mep)#exit-ether-ma- mep-mode	Exit CFM MEP configuration mode.
SW1(config-ether-cfm-ma)#mep crosscheck mpid	Configure crosscheck to remote MEP in VLAN 512.
SW1(config-ether-cfm-ma)#cc interval 10ms	Enable cc interval for 10 millisecond.
SW1(config-ether-cfm-ma)#exit-ether-ma-mode	Exit CFM MA configuration mode.
SW1(config-ether-cfm)#exit	Exit ethernet CFM mode.
SW1(config)#commit	Commit the configuration
SW1(config)#exit	Exit the configure terminal mode

SW2#configure terminal	Enter configure mode.
SW2(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW2(config)#vlan database	Entering vlan database
SW2(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW2(config-vlan)#exit	Exit vlan database
SW2(config)#interface ce0	Configure interface ce0.
SW2(config-if)#switchport	Configure the interface as switch port.
SW2(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW2(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW2(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce0.
SW2(config-if)#exit	Exit config mode.

SW2(config)#interface xe0	Configure interface xe0.
SW2(config-if)#switchport	Configure the interface as switch port.
SW2(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW2(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW2(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe1.
SW2(config-if)#exit	Exit the interface mode
SW2(config)#commit	Commit the configuration
SW2(config)#exit	Exit the configure terminal mode

SW3#configure terminal	Enter configure mode.
SW3(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW3(config)#vlan database	Entering vlan database
SW3(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW3(config-vlan)#exit	Exit vlan database
SW3(config)#interface xel7	Configure interface xe17
SW3(config-if)#switchport	Configure the interface as switch port.
SW3(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW3(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW3(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe17.
SW3(config-if)#exit	Exit config mode.
SW3(config)#interface xel	Configure interface xe1.
SW3(config-if)#switchport	Configure the interface as switch port.
SW3(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW3(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW3(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe1.
SW3(config-if)#exit	Exit the interface mode
SW3(config)#commit	Commit the configuration
SW3(config)#exit	Exit the configure terminal mode

SW4#configure terminal	Enter configure mode.
SW4(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW4(config)#vlan database	Entering vlan database
SW4(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.

Exit vlan database
Configure interface xe1.
Configure the interface as switch port.
Configure interface in bridge group 1.
Configure interface mode as trunk.
Allow all VLANs on interface xe1.
Exit config mode.
Configure interface xe9.
Configure the interface as switch port.
Configure interface in bridge group 1.
Configure interface mode as trunk.
Allow all VLANs on interface xe9.
Exit the interface mode
Commit the configuration
Exit the configure terminal mode

SW5#configure terminal	Enter configure mode.
SW5(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW5(config)#vlan database	Entering vlan database
SW5(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW5(config-vlan)#exit	Exit vlan database
SW5(config)#interface xe9	Configure interface xe9.
SW5(config-if)#switchport	Configure the interface as switch port.
SW5(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW5(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW5(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe9.
SW5(config-if)#exit	Exit config mode.
SW5(config)#ethernet cfm domain-type character-string domain-name mdnam level 7 mip-creation default	Create cfm domain with type as character string and set mip creation criteria to default.
SW5(config-ether-cfm)#service ma-type string ma-name testtm	Create ma type as string and set mip creation criteria to default.
SW5(config-ether-cfm-ma)#vlan 25 bridge 1	Configure vlan-id to associate the vlan to the MA
SW5(config-ether-cfm-ma)#mip-creation default	Set the mip creation criteria to default for the MA
SW5(config-ether-cfm-ma)#ethernet cfm mep down mpid 1 active true xe9	Create down mep on xe9.

Enable cc multicast.
Exit CFM MEP configuration mode
Configure crosscheck to remote MEP in VLAN 512.
Enable cc interval for 10 millisecond.
Exit CFM MA configuration mode.
Exit ethernet CFM mode.
Commit the configuration
Exit the configure terminal mode

Validation

SW1#ping ethernet mac 3c2c.9926.e683 unicast source 2 domain mdnam

```
SW1#traceroute ethernet 3c2c.9926.e683 mepid 2 domain mdnam
MP Mac Hops Relay-action Ingress/Egress Ingress/Egress action
3c2c.9926.e683 1 RlyHit Ingress IngOK
SW1#show ethernet cfm statistics
Continuity Check Messages
CCM Sent : 184876
CCM Received : 21651
Loop Back Messages
LBM Sent : 10
LBR Received (Valid) : 10
LBR Received (Bad msdu) : 0
LBR Received (Out-of-Seq): 0
Link Trace Messages
LTM Sent
        : 1
LTR Sent
         : 0
LTR Received (Valid) : 1
LTR Received (unexpected): 0
SW1#show ethernet cfm maintenance-points local mep domain mdnam
MPID Dir Lvl VLAN CC-Stat HW-Status CC-Intvl MAC-Address Def Port MD Name
_____
___
   Dn 7 512 Enable Installed 10 ms 6cb9.c567.721d F ce49
2
mdnam
SW1#show ethernet cfm maintenance-points remote domain mdnam
MEPID RMEPID LEVEL LAN Rx CCM RDI PEER-MAC TYPE
_____
-2 1 7 512 Yes False
                                   3c2c.9926.e683 Configured
```

Continuity Check Message (CCM) Over VPWS

Note: The MEP should not be created on a network interface with L3 component (support is only for UpMep on VPWS).

SW1

SW1#configure terminal	Enter configure mode.
SW1(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW1(config)#vlan database	Entering VLAN database.
SW1(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW1(config-vlan)#exit	Exit config mode.
SW1(config)#interface ce49	Configure interface ce49.
SW1(config-if)#switchport	Configure the interface as switch port.
SW1(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW1(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW1(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.
SW1(config-if)#exit	Exit interface mode.
SW1(config)#commit	Commit the configuration
SW1(config)#exit	Exit the configure terminal mode

SW2#configure terminal	Enter configure mode.
SW2(config)#interface ce0	Configure interface ce0.
SW2(config-if)#switchport	Configure interface as a switch port.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#interface xe0	Configure interface xe0.
SW2(config-if)#no switchport	Configure interface as router port.
SW2(config-if)#ip address 10.0.0.1/24	Assign IP address to router port xe0
SW2(config-if)#no shutdown	Making the interface up
SW2(config-if)#exit	Exit interface mode.
SW2(config)#interface lo	Configure interface lo
SW2(config-if)#ip address 1.1.1.1/32 secondary	Configure secondary IP address to loopback interface .

SW2(config-if)#exit	Exit interface mode.
SW2(config)#router ospf 100	Configure ospf
SW2(config-router)#network 10.0.0/24 area 0	Advertising 10 network
SW2(config-router)#network 1.1.1.1/32 area 0	Advertising loopback IP
SW2(config-router)#exit	Exit router mode.
SW2(config)#router rsvp	Configuring rsvp
SW2(config-router)#hello-receipt	Configuring hello reception
SW2(config-router)#no php	Configuring device as not a PHP
SW2(config-router)#revert-timer 10	Configuring reversion time of RSVP
SW2(config-router)#exit	Exit router mode.
SW2(config)#rsvp-trunk to-1 ipv4	Configuring RSVP path
SW2(config-trunk)#to 2.2.2.2	Configuring first hop
SW2(config-trunk)#to 3.3.3.3	Configuring second hop
SW2(config-trunk)#exit	Exit trunk mode.
SW2(config)#interface xe0	Configuring interface
SW2(config-if)#enable-rsvp	Enabling RSVP in interface
SW2(config-if)#label-switching	Enabling MPLS labeling
SW2(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW2(config-if)#exit	Exit interface mode.
SW2(config)#router ldp	Configuring LDP
SW2(config-router)#targeted-peer ipv4 3.3.3.3	Configuring LDP target peer for PW
SW2(config-router-targeted-peer)#exit- targeted-peer-mode	Exit target peer mode
SW2(config-router)#no multicast-hellos	Disabling LDP multicast
SW2(config-router)#exit	Exit router mode.
SW2(config)#mpls l2-circuit ETH-2001 1 3.3.3.3	Creating VPWS PW
(config-pseudowire) #exit	Exit pseudowire config mode.
SW2(config)#service-template ETH-2001	Configuring service template profile for PW
SW2(config-svc)#match outer-vlan 200	Configuring match condition
SW2(config-svc)# rewrite ingress push 2000	Configuring action for match
SW2(config-svc)#exit	Exit service template mode
SW2(config)#interface ce0	Configuring interface
SW2(config-if)#mpls-l2-circuit ETH-2001 service-template ETH-2001	Mapping VPWS in AC
SW2(config-if)#exit	Exit interface mode.
SW2(config)#hardware-profile filter cfm- domain-name-str enable	Enabling HW filter for character string domain name
SW2(config)#ethernet cfm domain-type character-string domain-name 12345 level 7 mip-creation none	Configuring CFM domain over VPWS

SW2(config-ether-cfm-mpls-md)#service ma- type string ma-name 43981 mip-creation none	Creating MA for domain
SW2(config-ether-cfm-mpls-md-ma)#cc interval 100ms	Configuring CFM interval
SW2(config-ether-cfm-mpls-md-ma)#mep crosscheck mpid 1	Configuring remote mep
SW2(config-ether-cfm-mpls-md-ma)#ethernet cfm mep up mpid 4001 active true vpws ETH- 2001	Configuring local mep and mapping the same with vpws ser- vice
SW2(config-ether-cfm-mpls-ma-mep)#cc multicast state enable	Enabling the CFM multicast
SW2(config-ether-cfm-mpls-ma-mep)#exit- ether-ma-mep-mode	Exit CFM MEP configuration mode
SW2(config-ether-cfm-mpls-md-ma)# exit- ether-ma-mode	Exit Ethernet CFM MD configuration mode
SW2(config-ether-cfm-mpls-md)# exit	Configuring LM profile
SW2(config)#ethernet cfm loss-measurement profile-name lmm	Configuring LM profile
SW2(config-cfm-lm)#measurement-type lmm	Configuring measurement type as LMM
SW2(config-cfm-lm)#message-period 3	Configuring message period
SW2(config-cfm-lm)#measurement-interval 1	Configuring measurement interval
SW2(config-cfm-lm)#intervals-stored 3	Configuring number of interval to be stored
SW2(config-cfm-lm)#exit	Exit cfm loss measurement mode
SW2(config)#commit	Commit the configuration
SW2(config)#exit	Exit the configure terminal mode

SW3#configure terminal	Enter configure mode.
SW3(config)#interface xel	Configure interface
SW3(config-if)#no switchport	Configure interface as router port.
SW3(config-if)#ip address 20.0.0.1/24	Assign IP address to router port
SW3(config-if)#no shutdown	Making the interface up
SW3(config-if)#exit	Exit interface mode.
SW3(config)#interface xe17	Configure interface
SW3(config-if)#no switchport	Configure interface as router port.
SW3(config-if)#ip address 10.0.0.2/24	Assign IP address to router port
SW3(config-if)#no shutdown	Making the interface up
SW3(config-if)#exit	Exit interface mode.
SW3(config)#interface lo	Configure interface lo
SW3(config-if)#ip address 2.2.2.2/32 secondary	Configure secondary IP address to loopback interface .
SW3(config-if)#exit	Exit interface mode.
SW3(config)#router ospf 100	Configure ospf

SW3(config-router)#network 10.0.0.0/24 area 0	Advertising 10 network
SW3(config-router)#network 20.0.0.0/24 area 0	Advertising 10 network
SW3(config-router)#network 2.2.2.2/32 area 0	Advertising loopback IP
SW3(config-router)#exit	Exit router mode.
SW3(config)#router rsvp	Configuring rsvp
SW3(config-router)#hello-receipt	Configuring hello reception
SW3(config-router)#no php	Configuring device as not a PHP
SW3(config-router)#revert-timer 10	Configuring reversion time of RSVP
SW3(config-router)#exit	Exit router mode.
SW3(config)#interface xel	Configuring interface
SW3(config-if)#enable-rsvp	Enabling RSVP in interface
SW3(config-if)#label-switching	Enabling MPLS labeling
SW3(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW3(config-if)#exit	Exit interface mode.
SW3(config)#interface xe17	Configuring interface
SW3(config-if)#enable-rsvp	Enabling RSVP in interface
SW3(config-if)#label-switching	Enabling MPLS labeling
SW3(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW3(config-if)#exit	Exit interface mode.
SW3(config)#commit	Commit the configuration
SW3(config)#exit	Exit configure terminal mode

SW4#configure terminal	Enter configure mode.
SW4(config)#interface xe9	Configure interface
SW4(config-if)#switchport	Configure interface as switch port.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#interface xel	Configure interface
SW4(config-if)#no switchport	Configure interface as router port.
SW4(config-if)#ip address 20.0.0.2/24	Assign IP address to router port
SW4(config-if)#no shutdown	Making the interface up
SW4(config-if)#exit	Exit interface mode.
SW4(config)#interface lo	Configure interface lo
SW4(config-if)#ip address 3.3.3.3/32 secondary	Configure secondary IP address to loopback interface .
SW4(config-if)#exit	Exit interface mode.
SW4(config)#router ospf 100	Configure ospf
SW4(config-router)#network 20.0.0/24 area 0	Advertising 10 network
SW4(config-router)#network 3.3.3.3/32 area 0	Advertising loopback IP

SW4(config-router)#exit	Exit router mode.
SW4(config)#router rsvp	Configuring rsvp
SW4(config-router)#hello-receipt	Configuring hello reception
SW4(config-router)#no php	Configuring device as not a PHP
SW4(config-router)#revert-timer 10	Configuring reversion time of RSVP
SW4(config-router)#exit	Exit router mode.
SW4(config)#rsvp-trunk to-1 ipv4	Configuring RSVP path
SW4(config-trunk)#to 2.2.2.2	Configuring first hop
SW4(config-trunk)#to 1.1.1.1	Configuring second hop
SW4(config-trunk)#exit	Exit trunk mode.
SW4(config)#interface xel	Configuring interface
SW4(config-if)#enable-rsvp	Enabling RSVP in interface
SW4(config-if)#label-switching	Enabling MPLS labeling
SW4(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW4(config-if)#exit	Exit interface mode.
SW4(config)#router ldp	Configuring LDP
SW4(config-router)#targeted-peer ipv4 1.1.1.1	Configuring LDP target peer for PW
SW4(config-router-targeted-peer)#exit- targeted-peer-mode	Exit target peer mode
SW4(config-router)#no multicast-hellos	Disabling LDP multicast
SW4(config-router)#exit	Exit router mode.
SW4(config)#mpls l2-circuit ETH-2001 1 1.1.1.1	Creating VPWS PW
(config-pseudowire) #exit	Exit pseudowire config mode.
SW4(config)#service-template ETH-2001	Configuring service template profile for PW
SW4(config-svc)# match outer-vlan 200	Configuring match condition
SW4(config-svc)# rewrite ingress push 2000	Configuring action for match
SW4(config-svc)#exit	Exit service template mode
SW4(config)#interface xe9	Configuring interface
SW4(config-if)#mpls-l2-circuit ETH-2001 service-template ETH-2001	Mapping VPWS in AC
SW4(config-if)#exit	Exit interface mode.
SW4(config)#hardware-profile filter cfm- domain-name-str enable	Enabling HW filter for character string domain name
SW4(config)#ethernet cfm domain-type character-string domain-name 12345 level 7 mip-creation none	Configuring CFM domain over VPWS
SW4(config-ether-cfm-mpls-md)#service ma- type string ma-name 43981 mip-creation none	Creating MA for domain
SW4(config-ether-cfm-mpls-md-ma)#cc interval 100ms	Configuring CFM interval
SW4(config-ether-cfm-mpls-md-ma)#mep crosscheck mpid 4001	Configuring remote mep

SW4(config-ether-cfm-mpls-md-ma)#ethernet cfm mep up mpid 1 active true vpws ETH-2001	Configuring local mep and mapping the same with vpws ser- vice
SW4(config-ether-cfm-mpls-ma-mep)#cc multicast state enable	Enabling the CFM multicast
SW4(config-ether-cfm-mpls-ma-mep)#ethernet cfm loss-measurement reply lmm	Configuring LMR
SW4(config-ether-cfm-mpls-ma-mep)#exit- ether-ma-mep-mode	Exit CFM MEP configuration mode
SW4(config-ether-cfm-mpls-md-ma)#exit- ether-ma-mode	Exit CFM MA configuration mode
SW4(config-ether-cfm-mpls-md)#exit	Exit Ethernet CFM MD configuration mode
SW4(config)#commit	Commit the configuration
SW4(config)#exit	Exit configure terminal mode

SW5#configure terminal	Enter configure mode.
SW5(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW5(config)#vlan database	Entering VLAN database.
SW5(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW5(config-vlan)#exit	Exit config mode.
SW5(config)#interface xe9	Configure interface ce49.
SW5(config-if)#switchport	Configure the interface as switch port.
SW5(config-if)#bridge-group 1	Configure interface in bridge group 1
SW5(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW5(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.
SW5(config-if)#exit	Exit interface mode.
SW5(config)#commit	Commit the configuration
SW5(config)#exit	Exit configure terminal mode

Validation

SW1#show MEPID	ethernet RMEPID	cfm r I	maintenanc LEVEL	ce-point Rx CCM	s remote RDI	domain 12345 PEER-MAC	TYPE
200	100	 -	7	Yes	False	b86a.97d2.27d0	Configured
SW1#show MA NAME	ethernet	cfm r	ma status STATUS	domain	12345		
43981			Active				

EVPN-ELINE CFM Sub-Interface on Multi-Homing

The Connectivity Fault Management (CFM) feature enhances the product offering for the Ethernet LINE (ELINE) services in multi- homing scenarios. To route the traffic between two routers, create two sub interfaces within the physical interface, assign each sub interface an IP address within each subnet and then route the data between two subnets.

CFM multi-homing allows customer edge (CE) device to connect more than one provider edge (PE) device. Multihoming ensures redundant connectivity. The redundant PE device ensures that there is no traffic disruption when there is a network failure.

The following topology, configurations and validation section describe EVPN-ELINE CFM Sub-Interface on Multi Homing devices.

Topology

The following topology consists of customer edge routers CE1 and CE2 with IPv2 Provider Edge routers PE1 and PE2. These are interconnected through the core router P in the IPv4 MPLS provider networks.



Figure 1-2: CFM Sub-Interface on Multi Homing

Configuration

The following sessions displays the detailed information about configurations, and validations for CFM over subinterface.

PE1: Loopback Interface

Configure Loopback Interface on PE1

PE1(#configure terminal	Enter the configure mode
PE1(config)#interface lo	Enter the Interface mode for the loopback interface
PE1(config-if)#ip address 1.1.1.1/32 secondary	Configure IP address on loop-back interface
PE1(config-if)#exit	Exit the interface mode
PE1(config-if)#commit	Commit the transaction

PE1: Global LDP

Configure Global LDP on PE1

PE1(config)#router ldp	Enter the Router LDP mode
PE1(config-router) #router-id 1.1.1.1	Set the router ID to IP address 1.1.1.1
PE1(config-router)#targeted-peer ipv4 7.7.7.7	Configure targeted peer
PE1(config-router)#targeted-peer ipv4 8.8.8.8	Configure targeted peer
PE1(config-router-targeted-peer)#exit	Exit targeted-peer-mode
PE1(config-router)#exit	Exit from router target peer and LDP mode
PE1(config-router)#commit	Commit the transaction

PE1: Global EVPN MPLS Command

Configure Global EVPN MPLS Command on PE1

PE1(config) #evpn mpls enable	Enable EVPN MPLS
PE1(config)#commit	Commit candidate configuration to be running configuration
<pre>PE1(config)#evpn mpls vtep-ip-global1.1.1.1</pre>	Configure VTEP global IP to loopback IP

PE1: Interface Configuration Network Side

Configure Interface Network Side on PE1.

PE1(config)#interface xe33	Enter the Interface mode for xe33
PE1(config-if)#ip address 10.1.0.1/16	Configure IP address on the interface
PE1(config-if)#enable-ldp ipv4	Enable LDP on the physical interface
PE1(config-if)#label-switching	Enable label switching on the interface
PE1(config-if)#exit	Exit interface mode
PE1(config-if)#commit	Commit the transaction

PE1: OSPF Configuration

Configure OSPF on PE1

PE1(config)#router ospf 1	Enter the Router OSPF mode
PE1(config-router)#ospf router-id 1.1.1.1	Router-ID configurations
PE1(config-router)#network 1.1.1.1/32 area 0.0.0.0	Advertise the loopback address in the OSPF
PE1(config-router)#network 10.1.0.0/16 area 0.0.0.0	Advertise the network address in the OSPF
PE1(config-router)#exit	Exit router OSPF mode and return to Configure mode
PE1(config)#commit	Commit the transaction

PE1: BGP Configuration

Configure BGP on PE1.
PE1(config)#router bgp 1	Enter the Router BGP mode, ASN: 1
PE1(config-router)#neighbor 7.7.7.7 remote-	Configure neighbor as iBGP neighbor
as 1	
PE1(config-router)#neighbor 7.7.7.7 update- source lo	Source of routing updates as loop-back
PE1(config-router) #neighbor 8.8.8.8 remote-	Configure Neighbor as iBGP neighbor
as 1	
PE1(config-router)#neighbor 8.8.8.8 update- source lo	Source of routing updates as loop-back
PE1(config-router)#address-family l2vpn evpn	Enter into address family mode as EVPN
PE1(config-router-af)#neighbor 7.7.7.7 activate	Enable the EVPN Address family for neighbor
PE1(config-router-af)#neighbor 8.8.8.8 activate	Enable the EVPN Address family for neighbor
PE1(config-router-af)#exit	Exit the Address family mode
PE1(config-router)#exit	Exit the router Address
PE1(config)#commit	Commit the transaction
PE1(config-router)#commit	Commit the transaction

PE1: MAC VRF Configuration

Configure MAC VRF on PE1

PE1(config) #mac vrf vrf2	Enter VRF mode
PE1(config-vrf)#rd 1.1.1.1:2	Configure route-distinguisher value 1.1.1.1:2
PE1(config-vrf)#route-target both 2:2	Configure import and export value as 2:2
PE1(config-vrf)#exit	Exit VRF Mode
PE1(config-router)#commit	Commit the transaction

PE1: EVPN and VRF Mapping

Configure EVPN and VRF Mapping on PE1

PE1(config)#evpn mpls id 52 xconnect target- mpls-id 2	Configure the EVPN-VPWS identifier with source identifier2 and target identifier 2
PE1(config-evpn-mpls)#host-reachability- protocol evpn-bgp vrf2	Map VRF "VRF2" to EVPN-VPWS identifier

PE1: Access Port Configuration

Configure Access Port on PE1.

PE1(config)#interface xe33	Enter the Interface mode for xe33
PE1(config-if)#interface xe33.2 switchport	Create L2 sub interface of physical interface xe33
PE1(config-if)#description access-side-int	Provide the interface description
PE1(config-if)#encapsulation dot1q 2	Set encapsulation to dot1q with VLAN ID 2
PE1(config-if)#access-if-evpn	Enter the access mode for EVPN MPLS ID configuration

PE1(config-access-if)#map vpn-id 52	Map VPN-id 52 to interface xe33.2 (VPWS)
PE1(config-access-if)#exit	Exit out of access interface mode
PE1(config)#exit	Commit the transaction

P: Loop-back Interface

Configure Loopback Interface P.

P(#configure terminal	Enter configure mode
P(config)#interface lo	Enter the Interface mode for the loop-back interface
P(config-if)#ip address 2.2.2.2/32secondary	Configure IP address on loop-back interface
P(config-if) #exit	Exit interface mode
P(config)#commit	Commit the transaction

P: Global LDP

Configure Global LDP on P.

P(config) #router ldp	Enter the Router LDP mode
P(config-router) #router-id 2.2.2.2	Set the router ID to IP address 2.2.2.2
P(config-router)#exit	Exit from router target peer and LDP mode
P(config-router)#commit	Commit the transaction

P: Interface Configuration

Configure Interface on P.

P(config)#interface xe6	Enter the Interface mode for xe6
P(config-if)#ip address 10.1.0.2/16	Configure IP address on the interface
P(config-if)#enable-ldp ipv4	Enable LDP on the physical interface
P(config-if)#label-switching	Enable label switching on the interface
P(config-if) #exit	Exit interface mode
P(config)#interface xe21	Enter the Interface mode for xe21
P(config-if)#ip address 123.1.1.1/24	Configure IP address on the interface
P(config-if)#enable-ldp ipv4	Enable LDP on the physical interface
P(config-if)#label-switching	Enable label switching on the interface
P(config-if) #exit	Exit interface mode
P(config)#interface xe20	Enter the Interface mode for xe20
P(config-if)#ip address 124.1.1.1/24	Configure IP address on the interface
P(config-if)#enable-ldp ipv4	Enable LDP on the physical interface
P(config-if)#label-switching	Enable label switching on the interface
P(config-if) #exit	Exit the interface mode
P(config)#commit	Commit the transaction

P: OSPF Configuration

Configure OSPF on P.

P(config)#router ospf 1	Enter the router OSPF mode
P(config-router)#ospf router-id 2.2.2.2	Set the router ID as loop-back IP
P(config-router)#network 2.2.2.2/32 area0	Advertise loop-back address in OSPF
P(config-router)#network 10.1.0.0/16 area 0.0.0	Advertise xe3 network address in the OSPF that comes under same subnet
P(config-router)#network 123.1.1.0/24 area 0.0.0.0	Advertise the network address in the OSPF that comes under same subnet
P(config-router)#network 124.1.1.0/24 area 0.0.0.0	Advertise the network address in the OSPF that comes under same subnet
P(config-router)#exit	Exit the router OSPF mode and return to configure mode
POcNOS (config) #commit	Commit the candidate configuration to the running configuration

PE2: Loopback Interface

Configure Loopback Interface on PE2.

PE2#configure terminal	Enter the configure mode
PE2(config)#interface lo	Enter the Interface mode for the loopback interface
PE2(config-if)#ip address 7.7.7.7/32 secondary	Configure IP address on loopback interface.
PE2(config-if)#exit	Exit interface mode
PE2(config)#commit	Commit the transaction

PE2: Global LDP

Configure Global LDP on PE2.

PE2(config)#router ldp	Enter the router LDP mode
PE2(config-router) #router-id 7.7.7.7	Set the router ID to IP address 7.7.7.7
PE2(config-router)#targeted-peer ipv4 1.1.1.1	Configure the targeted peer
PE2(config-router-targeted-peer)# targeted- peer ipv4 8.8.8.8	Configure the targeted peer
PE2(config-router-targeted-peer)#exit	Exit targeted-peer-mode
PE2 (config-router) #exit	Exit from router target peer and LDP mode
PE2(config)#commit	Commit the transaction

PE2: Global EVPN MPLS Command

Configure Global MPLS Command on PE2.

PE2(config)#evpn mpls enable	Enable EVPN MPLS
	Note: Reload is required after Enabling or Disabling EVPN MPLS
PE2(config)#evpn mpls vtep-ip-global 7.7.7.7	Configure VTEP global IP to loop-back IP
PE2(config)#hardware-profile filter evpn- mpls-mh enable	Enable hardware-profile filter EVPN-MPLS-MH
PE2(config)#evpn mpls multihoming enable	Enable Multi homing
PE2(config)#commit	Commit the transaction Reboot the system to bring up the ILM installation in hardware

PE2: Interface Configuration Network Side

Configure Interface Configuration Network Side on PE2.

PE2(config)#interface xe21	Enter the isnterface mode for xe21
PE2(config-if)#ip address 123.1.1.2/24	Configure IP address on the interface
PE2(config-if)#enable-ldp ipv4	Enable LDP on the physical interface
PE2(config-if)#label-switching	Enable label switching on the interface
PE2(config-if)#exit	Exit the interface mode
PE2(config)#commit	Commit the transaction

PE2: OSPF Configuration

Configure OSPF on PE2.

PE2(config)#router ospf 1	Enter the Router OSPF mode
PE2(config-router)#ospf router-id 7.7.7.7	Router-ID configurations
PE2(config-router)#network 7.7.7.7/32 area 0.0.0	Advertise the loop-back address in OSPF
PE2(config-router) #network 123.1.1.0/24 area 0.0.0.0	Advertise the network address in OSPF
PE2(config-router)#exit	Exit the router OSPF mode and return to configure mode
PE2(config)#commit	Commit the candidate configuration to the running configuration

PE2: BGP Configuration

Configure BGP on PE2.

PE2(config)#router bgp 1	Enter the Router BGP mode, ASN: 1
PE2(config-router)#neighbor 1.1.1.1 remote- as 1	Configure Neighbor as iBGP neighbor
PE2(config-router)#neighbor 1.1.1.1 update- source lo	Source of routing updates as loop-back
PE2(config-router)#neighbor 8.8.8.8 remote- as 1	Configure Neighbor as iBGP neighbor

PE2(config-router)#neighbor 8.8.8.8 update- source lo	Source of routing updates as loop-back
PE2(config-router)#address-family l2vpn evpn	Enter the address family mode as EVPN
PE2(config-router-af)#neighbor 1.1.1.1 activate	Enable EVPN Address family for neighbor
PE2(config-router-af)#neighbor 8.8.8.8 activate	Enable EVPN Address family for neighbor
PE2(config-router-af)#exit	Exit the Address family mode
PE2(config)#commit	Commit the transaction

PE2: MAC VRF Configuration

Configure MAC VRF on PE2.

PE2(config)#mac vrf vrf2	Enter VRF mode
PE2(config-vrf)#rd 7.7.7.7:2	Configure Route-Distinguisher value 7.7.7.7:2
<pre>PE2(config-vrf)#route-target both 2:2</pre>	Configure import and export value as 2:2 Support: route-target export route-target import
PE2(config-vrf)#exit	Exit the VRF Mode

PE2: Access Port Configuration

Configure on Access Port PE2.

PE2(config)#interface po1	Enter the Interface mode for po1
PE2(config-if)#load-interval 30	Load interval setting
PE2(config-if)#evpn multi-homed system-mac 0000.aaaa.bbbc	Configure ESI on a link on which Multi homed CE isconnected
PE2(config-if)#interface pol.2 switchport	Create L2 sub interface of Dynamic LAG PO1
PE2(config-if)#encapsulation dot1q 2	Set Encapsulation to dot1q with VLAN ID 2 Supported Encapsulation: dot1ad, dot1q, untagged, default
PE2(config-if)#access-if-evpn	Enter Access mode for EVPN MPLS ID configuration
PE2(config-access-if)#map vpn-id 2	Map VPN-id 2 to interface xe2.2 (VPWS)
PE2(config-access-if)#exit	Exit out of access interface mode

PE2: Interface Configuration Acess Side

Configure Interface Configuration Acess Side on PE2

PE2(config-if)#interface xe5	Enter the Interface mode for xe5
PE2(config-if)#channel-group 1 mode active	Move the interface to Dynamic LAG 1
PE2(config)#commit	Commit the transaction

PE3: Loopback Interface

Configure Loopback Interface on PE3.

PE3#configure terminal	Enter the configure mode
PE3(config)#interface lo	Enter the Interface mode for the loop-back interface
PE3(config-if)#ip address 8.8.8.8/32 secondary	Configure the IP address on loop-back interface
PE3(config-if)#exit	Exit interface mode
PE3(config)#commit	Commit the transaction

PE3: Global LDP

Configure Global LDP on PE3.

PE3(config)#router ldp	Enter the Router LDP mode
PE3(config-router) #router-id 8.8.8.8	Set the router ID to IP address 8.8.8.8
PE3(config-router)#targeted-peer ipv4 1.1.1.1	Configure the targeted peer
PE3(config-router-targeted-peer)# targeted- peer ipv4 7.7.7.7	Configure the targeted peer
PE3(config-router-targeted-peer)#exit	Exit targeted-peer-mode
PE3(config-router)#exit	Exit from router LDP mode
PE3(config)#commit	Commit the transaction

PE3: Global EVPN MPLS Command

Configure Global EVPN MPLS Command on PE3.

PE3(config)#evpn mpls enable	Enable EVPN MPLS
PE3(config)#commit	Commit candidate configuration to be running configuration
PE3(config) #evpn mpls vtep-ip-global8.8.8.8	Configure VTEP global IP to loopback IP
PE3(config)#hardware-profile filter evpn- mpls-mh enable	Enable hardware-profile filter EVPN-MPLS-MH
PE3(config) #evpn mpls multihoming enable	Enable Multi homing
PE3(config)#commit	Commit the transaction
	Note: Reboot the system to bring up the ILM installation in hardware

PE3: Interface Configuration Network Side

Configure Interface Configuration Network Side on PE3

PE3(config)#interface xe5	Enter the Interface mode for xe5
PE3(config-if)#ip address 124.1.1.2/24	Configure IP address on the interface
PE3(config-if)#enable-ldp ipv4	Enable LDP on the physical interface
PE3(config-if)#label-switching	Enable label switching on the interface
PE3(config-if) #exit	Exit interface mode
PE3(config-if)#interface xe4	Enter the Interface mode for xe4

PE3(config-if)#channel-group 1 mode active

PE3(config)#commit

Move the Interface to Dynamic LAG 1 Commit the transaction

PE3: Interface Configuration Access Side

Configure Interface Access Side on PE3.

PE2(config-if)#interface xe4	Enter the Interface mode for xe4
PE2(config-if)#channel-group 1 mode active	Move the Interface to Dynamic LAG 1
PE2(config)#commit	Commit the transaction

PE3: OSPF Configuration

Configure OSPF on PE3.

PE3(config)#router ospf 1	Enter the Router OSPF mode
PE3(config-router)#ospf router-id 8.8.8.8	Router-ID configurations
PE3(config-router)#network 8.8.8.8/32 area 0.0.0	Advertise loopback address in OSPF
PE3(config-router)#network 124.1.1.0/24 area 0.0.0.0	Advertise network address in OSPF
PE3(config-router)#exit	Exit the router OSPF mode and return to Configure mode.
PE3(config)#commit	Commit the transaction

PE3: BGP Configuration

Configure BGP on PE3.

PE3(config)#router bgp 1	Enter the Router BGP mode, ASN: 1
PE3(config-router)#neighbor 1.1.1.1 remote- as 1	Configure Neighbor as iBGP neighbor
PE3(config-router)#neighbor 1.1.1.1 update- source lo	Source of routing updates as loop-back
PE3(config-router)#neighbor 7.7.7.7 remote- as 1	Configure Neighbor as iBGP neighbor
PE3(config-router)#neighbor 7.7.7.7 update- source lo	Source of routing updates as loop-back
PE3(config-router)#address-family 12vpn evpn	Enter into address family mode as EVPN
PE3(config-router-af)#neighbor 1.1.1.1 activate	Enable the EVPN address family for neighbor
PE3(config-router-af)#neighbor 7.7.7.7 activate	Enable the EVPN address family for neighbor
PE3(config-router-af)#exit	Exit the address family mode
PE3(config)#commit	Commit the transaction

PE3: MAC VRF Configuration

Configure MAC VRF on PE3.

PE3(config)#mac vrf vrf2	Enter VRF mode
PE3(config-vrf)#rd 8.8.8.8:2	Configure Route-Distinguisher value 8.8.8.8:2
PE3(config-vrf)#route-target both 2:2	Configure import and export value as 2:2
PE3(config-vrf)#exit	Exit VRF mode

PE3: EVPN and MAC VRF Mapping

Configure EVPN and MAC VRF Mapping on PE3

PE3(config)#evpn mpls id 2 xconnect target- mpls-id 52	Configure the EVPN-VPWS identifier with source identifier 2 and target identifier 52
PE3(config-evpn-mpls)#host-reachability- protocol evpn-bgp vrf2	Map VRF "test" to EVPN-VPWS identifier

PE3: Access Port Configuration

Configure Access Port on PE3.

PE3(config)#interface po1	Enter the Interface mode for po1
PE3(config-if)#load-interval 30	Load interval setting
PE3(config-if)#evpn multi-homed system-mac 0000.aaaa.bbbc	Configure ESI on a link on which Multi homed CE is connected
PE3(config-if)#interface po1.2 switchport	Create L2 sub interface of Dynamic LAG po1
PE3(config-if)#encapsulation dot1q 2	Set the encapsulation to dot1q with VLAN ID 2 supported encapsulation: dot1ad, dot1q, untagged, default
PE3(config-if)#access-if-evpn	Enter the access mode for EVPN MPLS ID configuration
PE3(config-access-if)#map vpn-id 2	Map VPN-id 2 to dynamic LAG sub interface po1.2(VPWS)
PE3(config-access-if)#exit	Exit the access interface mode

CFM CONFIGURATION

Configure below hardware-profile commands related to CFM in configuration mode.

hardware-profile filter cfm-domain-name-str enable hardware-profile statistics cfm-ccm enable

PE1

Configure PE1.

<pre>PE1(config)# ethernet cfm domain-type character-string domain-name 12346 level 7 mip-creation none</pre>	Create CFM domain for EVPN ELINE with type as character string and set MIP creation to none
PE1(config-ether-cfm-mpls-md)# service ma- type string ma-name 124	Create MA type with string and set MIP creation to none

PE1(config-ether-cfm-mpls-ma)# ethernet cfm mep up mpid 10 active true xe33.2 vlan 2	Create up-MEP for local.		
PE1(config-ether-cfm-mpls-ma-mep)#cc multicaststate enable	Enable CC multicast		
PE1(config-ether-cfm-mpls-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet MA-MEP-mode		
<pre>PE1(config-ether-cfm-mpls-ma)# mep auto- discovery enable</pre>	Enable auto discovery for R-MEP		
PE1(config-ether-cfm-mpls-ma)#cc interval 100	Enable CC interval with value 2 that is 100 milliseconds		
PE1(config-ether-cfm-mpls-ma)#exit-ether- ma-mode	Exit the Ethernet MA mode		
PE1(config-ether-cfm-mpls)#exit	Exit the Ethernet CFM mode		
PE1(config)#exit	Exit the configure mode		
PE1(config)#commit	Commit the candidate configuration to the running configuration		

PE2/PE3 CFM CONFIG

Configure below hardware-profile commands related to CFM in configuration mode.

hardware-profile filter cfm-domain-name-str enable

hardware-profile statistics cfm-ccm enable

PE2(config)# ethernet cfm domain-type character-string domain-name 12346 level 7 mip-creation none	Create CFM domain for EVPN ELINE with type as character string and set MIP creation to none		
PE2(config-ether-cfm-mpls-md) # service ma- type string ma-name 124	Create MA type with string and set MIP creation to none		
PE2(config-ether-cfm-mpls-ma)# ethernet cfm mep up mpid 20 active true pol.2 vlan 2	Create up-MEP for local MEP for VLAN 2		
PE2(config-ether-cfm-mpls-ma-mep)#cc multicaststate enable	Enable CC multicast		
PE2(config-ether-cfm-mpls-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet MA-MEP-mode		
<pre>PE2(config-ether-cfm-mpls-ma)# mep auto- discovery enable</pre>	Enable mep auto-discovery		
PE2(config-ether-cfm-mpls-ma)#cc interval 100	Enable CC interval with value 2 that is 100 milliseconds		
PE2(config-ether-cfm-mpls-ma)#exit-ether- ma-mode	Exit ethernet MA mode		
PE2(config-ether-cfm-mpls)#exit	Exit ethernet CFM mode		
PE2(config)#exit	Exit from the configure mode		
PE2(config)#commit	Commit the candidate configuration to the running configuration		

PE3(config) # ethernet cfm domain-type character-string domain-name 12346 level 7 mip-creation none	Create CFM domain for EVPN ELINE with type as character string and set MIP creation to none
PE3(config-ether-cfm-mpls-md)# service ma- type string ma-name 124	Create MA type with string and set MIP creation to none
PE3(config-ether-cfm-mpls-ma)# ethernet cfm mep up mpid 30 active true pol.2 vlan 2	Create up-MEP for local MEP for VLAN 2
PE3(config-ether-cfm-mpls-ma-mep)#cc multicaststate enable	Enable CC multicast
PE3(config-ether-cfm-mpls-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet MA-MEP-mode
PE3(config-ether-cfm-mpls-ma)# mep auto- discovery enable	Enable mep auto-discovery
PE3(config-ether-cfm-mpls-ma)#cc interval 100	Enable CC interval with value 2 that is 100 milliseconds
PE3(config-ether-cfm-mpls-ma)#exit-ether- ma-mode	Exit ethernet MA mode
PE3(config-ether-cfm-mpls)#exit	Exit ethernet CFM mode
PE3(config)#exit	Exit from the configure mode
PE3(config)#commit	Commit the candidate configuration to the running configuration

Validation

The following are the validations for PE1 and PE2.

PE1

The following validation is for PE1.

Local		Remote	Connectio	n-Details
VPN-ID PE-IP	EVI-Name MTU Ty	MTU VPN-ID pe NW-Status	Source	Destination
52 7.7.7.7	 1500 AC	1500 2 -NW NW-SET	xe33.2	00:00:00:aa:aa:bb:bb:00:00

8.8.8.8 1500 ---- ----PE1#show ethernet cfm errors domain 12346

Domain Name Level MEPID Defects 12346 7 20

PE1-7011#show ethernet cfm maintenance-points remote domain 12346 ma-name 124MEPIDRMEPIDLEVELRx CCMRDIPEER-MACTYPE10207YesFalse00aa.bb00.0002 Learnt10307YesFalse00aa.dd00.0003 Learnt

PE1-7011#ping ethernet mac 00aa.bb00.0002 unicast source 10 domain 12346 ma 124
success rate is 100 (5/5)
PE1-7011#traceroute ethernet 00aa.bb00.0002 mepid 10 domain 12346 ma 124
MP Mac Hops Relay-action Ingress/Egress Ingress/Egress action
00aa.bb00.0002 1 RlyHit Ingress IngOK

PE1-7011#ping ethernet mac 00aa.dd00.0003 unicast source 10 domain 12346 ma 124 success rate is 100 (5/5) PE1-7011#traceroute ethernet 00aa.dd00.0003 mepid 10 domain 12346 ma 124 MP Mac Hops Relay-action Ingress/Egress Ingress/Egress action 00aa.dd00.0003 1 RlyHit Ingress IngOK

PE2/PE3

The following validations for PE2 and PE3.

Local			Remote	Connection-I	Details
	=========				
======================================	EVI-Name MTU	MTU MTU Type NW-S		Source	Destination

_____ ____ 1500 52 2 pol.2 --- Single Homed Port ---1500 AC-NW NW-SET 1.1.1.1 PE2#sh ethernet cfm errors domain 12346 Domain Name Level MEPID Defects _____ 12346 7 20 PE2#show ethernet cfm maintenance-points local mep domain 12346 ma-name 124 MPID Dir Lvl CC-Stat HW-Status CC-Intvl MAC-Address Def Port MD Name _____ Up 7 Enable Installed 100 ms 00aa.bb00.0002 F pol.2 12346 20 PE2#show ethernet cfm maintenance-points remote domain 12346 ma-name 124 Rx CCM MEPID RMEPID LEVEL RDI PEER-MAC TYPE _____ 7 20 10 Yes False 3417.ebe4.af22 Learnt PE2#ping ethernet mac 3417.ebe4.af22 unicast source 10 domain 12346 ma 124 success rate is 100 (5/5)PE2#traceroute ethernet 3417.ebe4.af22 mepid 10 domain 12346 ma 124 MP Mac Hops Relay-action Ingress/Egress Ingress/Egress action 3417.ebe4.af22 1 RlyHit Ingress IngOK

VPWS-CFM and Y1731 over Sub-Interface

To route traffic between two routers create a sub interfaces within the physical interface and assign each sub interface an IP address within each subnet and then route the data between two subnets. The Connectivity Fault Management (CFM) feature enhances Ethernet LINE (ELINE) services. CFM encompasses Continuity Check (CC) and Ping that help with network fault detection and isolation

Virtual Private Wire Service (VPWS) on EVPN-MPLS communicates between two customer points and establishes an EVPN instance between a pair of PEs in a sub interface. It forwards traffic from one network to another network without any Media Access Control (MAC) lookup.

Topology

The following topology consists of customer edge routers, CE1 and CE2 with Provider Edge routers PE1, PE2. They are all connected through the core router P in the IPv4 MPLS provider network.



Figure 1-3: VPWS-CFM and Y1731 over Sub-Interface

Configuration

Configure the following hardware-profile commands related to CFM in configuration mode and reboot the nodes.

hardware-profile filter cfm-domain-name-str enable hardware-profile statistics cfm-lm enable hardware-profile statistics cfm-ccm enable hardware-profile statistics cfm-slm enable

CE1

Configure CE1.

CE1#configure terminal	Enter the configure mode
CE1(config)#bridge 1 protocol ieee vlan- bridge	Configure an IEEE VLAN-aware bridge
CE1(config-if)#commit	Commit the transaction
CE1(config)#vlan database	Enter VLAN configure mode
CE1(config-vlan)#vlan 2001-3000 bridge 1 state enable	Configure a VLAN and add it to the bridge
CE1(config-vlan)#commit	Commit the transaction
CE1(config-vlan)#exit	Exit the VLAN configuration mode
CE1(config)#interface xel	Enter the interface mode for xe1
CE1(config-if)#switchport	Configure the interface as a layer 2 port
CE1(config-if)#bridge-group 1	Associate the interface to bridge-group 1
CE1(config-if)#switchport mode trunk	Configure the interface mode as trunk
CE1(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe1
CE1(config-if)#commit	Commit the transaction

CE2

Configure CE2.

Enter the configure mode
Configure an IEEE VLAN-aware bridge
Commit the transaction
Enter VLAN configure mode
Configure a VLAN and add it to the bridge
Commit the transaction
Exit the VLAN configuration mode
Enter the Interface mode for xe1
Configure the interface as a layer 2 port

CE2(config-if)#bridge-group 1	Associate the interface to bridge-group 1
CE2(config-if)#switchport mode trunk	Configure the interface mode as trunk
CE2(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe1
CE2(config-if)#commit	Commit the transaction

PE1

Configure PE1

PE1#configure terminal	Enter configure mode
PE1(config)#interface lo	Enter the interface mode for the loopback interface
<pre>PE1(config-if)#ip address 1.1.1.1/32 secondary</pre>	Configure IP address on loopback interface
PE1(config-if)#commit	Commit the transaction
PE1(config-if) #exit	Exit interface mode
PE1(config)#router ldp	Enter the router LDP mode
PE1(config-router)#targeted-peer ipv4 4.4.4	Configure the targeted peer
<pre>PE1(config-router-targeted-peer)#exit- targeted-peer-mode</pre>	Exit the targeted-peer-mode
PE1(config-router)#commit	Commit the transaction
PE1(config-router)exit	Exit the interface mode
PE1(config)#interface xe2	Enter the interface mode for xe2
PE1(config-if)# load-interval 30	Load interval setting
PE1(config-if)# ip address 192.168.10.1/24	Configure the IP address on the interface
<pre>PE1(config-if) # label-switching</pre>	Enable label switching on the interface
PE1(config-if)# enable-ldp ipv4	Enable LDP on the physical interface
PE1(config-if)#commit	Commit the transaction
PE1(config-if)#exit	Exit the interface mode
PE1(config) #router ospf 1	Enter the router OSPF mode
PE1(config-router) # ospf router-id 1.1.1.1	Configure the OSPF router-id
PE1(config-router)# bfd all-interfaces	Configure BFD
PE1(config-router) # network 1.1.1.1/32 area 0.0.0.0	Advertise the OSPF loopback address
PE1(config-router)# network 192.168.10.0/24 area 0.0.0.0	Advertise the OSPF network address
PE1(config-router)#commit	Commit the transaction
PE1(config-router) #exit	Exit the Interface mode
PE1(config)#mpls l2-circuit test1 2001 4.4.4.4	Configure the VC for PE2
PE1(config-pseudowire)#commit	Commit the pseudowire transaction
PE1(config-pseudowire)#exit	Exit pseudowire configure mode
PE1(config)#interface xe1.2001 switchport	Creating L2 sub interface of physical interface xe1

PE1(config-if)#encapsulation default	Configure encapsulation
PE1(config-if)#rewrite push dot1q 2028	Configure rewrite with push dot1q
PE1(config-if)#access-if-vpws	Create the VPWS access-port.
PE1(config-acc-if-vpws)#mpls-l2-circuit test1 primary	Add circuit-id on the sub-interface
PE1(config-acc-if-vpws)#commit	Commit the configuration
PE1(config-acc-if-vpws)#exit	Exit the configure mode
PE1(config)#ethernet cfm domain-type character-string domain-name 12346 level 7 mip-creation none	Create the CFM domain and set MIP creation to none
<pre>PE1(config-ether-cfm)#service ma-type string ma-name 124</pre>	Create MA type with string and set MIP creation to none
PE1(config-ether-cfm-ma)#vpws test1	Configure VPWS to associate to the MA
PE1(config-ether-cfm-ma)#ethernet cfm mep up mpid 20 active true vpws test1	Create MEP up on VPWS
<pre>PE1(config-ether-cfm-ma-mep)#cc multicast state enable</pre>	Enable CC multicast
<pre>PE1(config-ether-cfm-ma-mep)#exit-ether-ma- mep-mode</pre>	Exit Ethernet MA-MEP-mode
<pre>PE1(config-ether-cfm-ma)#mep crosscheck mpid 10</pre>	Configure cross check to remote MEP
PE1(config-ether-cfm-ma)#cc interval 10ms	Enable CC interval value 10 milliseconds
PE1(config-ether-cfm-ma)#exit-ether-ma-mode	Exit Ethernet MA-MEP-mode
PE1(config-ether-cfm)#commit	Commit the transaction
PE1(config-ether-cfm)exit	Exit the transaction
PE1(config)#ethernet cfm loss-measurement profile-name SLM	Configuring SLM profile
<pre>PE1(config-cfm-lm)# measurement-type slm</pre>	Configure measurement type as SLM
<pre>PE1(config-cfm-lm)# measurement-interval 1</pre>	Configure measurement interval
<pre>PE1(config-cfm-lm)# intervals-stored 3</pre>	Configure number of interval to be stored
<pre>PE1(config-cfm-lm)# message-period 1s</pre>	Specify message period interval time
PE1(config-cfm-lm)#exit	Exit the transaction from SLM
PE1(config)#ethernet cfm loss-measurement profile-name LM	Configure LM profile
PE1(config-cfm-lm)# measurement-type lmm	Configure measurement type as LMM
PE1(config-cfm-lm)# measurement-interval 1	Configure measurement interval
PE1(config-cfm-lm)# intervals-stored 3	Configure number of interval to be stored
<pre>PE1(config-cfm-lm)# message-period 1s</pre>	Specify message period interval time
PE1(config-cfm-lm)#exit	Exit the transaction from LM
PE1(config)#ethernet cfm delay-measurement profile-name DM	Configure the DM profile
<pre>PE1(config-cfm-dm) # measurement-interval 1</pre>	Specify the measurement-interval in minutes
PE1(config-cfm-dm)# intervals-stored 2	Set the number of completed measurement intervals to store
DE1(config of dw) # maccore nominal 1c	Specify message period interval time

PE2

Configure PE2.

PE2#config terminal	Enter configure mode
PE2(config)#interface lo	Enter the Interface mode for the loopback interface
PE2(config-if) #ip address 4.4.4.4/32 secondary	Configure IP address on loopback interface
PE2(config-if)#commit	Commit the transaction
PE2(config-if)#exit	Exit interface mode
PE2(config)#router ldp	Enter the router LDP mode
PE2(config-router)#targeted-peer ipv4 1.1.1.1	Configure targeted peer
PE2(config-router-targeted-peer)#exit- targeted-peer-mode	Exit the targeted peer
PE2(config-router)#commit	Commit the transaction
PE2(config-router)exit	Exit interface mode
PE2(config)#interface xe2	Enter the Interface mode for xe2
<pre>PE2(config-if) # load-interval 30</pre>	Load interval setting
PE2(config-if) # ip address 192.168.30.2/24	Configure IP address on the interface
<pre>PE2(config-if) # label-switching</pre>	Enable label switching on the interface
PE2(config-if)# enable-ldp ipv4	Enable LDP on the physical interface
PE2(config-if)#commit	Commit the configuration
PE2(config-if)#exit	Exit interface mode
PE2(config)#router ospf 1	Enter the Router OSPF mode.
PE2(config-router) # ospf router-id 4.4.4.4	Configure the OSPF router-id
PE2(config-router)# bfd all-interfaces	Configure BFD on the OSPF interfaces
PE2(config-router)# network 4.4.4.4/32 area 0.0.0.0	Advertise loopback address in OSPF
PE2(config-router)# network 192.168.30.0/24 area 0.0.0	Advertise the OSPF network address
PE2(config-router)#commit	Commit the transaction
PE2(config-router)#exit	Exit interface mode
PE2(config)#mpls l2-circuit test1 2001 1.1.1.1	Configure the VC for PE1
PE2(config-pseudowire)#commit	Commit the Pseudowire transaction
PE2(config-pseudowire)#exit	Exit the Pseudowire transaction mode
PE2(config)#interface xe1.2001 switchport	Create the L2 sub interface of physical interface xe1
PE2(config-if)# encapsulation default	Set the encapsulation to default
PE2(config-if) # rewrite push dot1q 2028	Configure rewrite with push dot1q
PE2(config-if)# access-if-vpws	Configure VPWS
PE2(config-acc-if-vpws)# mpls-l2-circuit test1 primary	Configure VPWS to bind an interface to a MPLS
PE2(config-acc-if-vpws)#commit	Commit the VPWS transaction

PE2(config-acc-if-vpws)#exit	Exit the VPWS transaction
PE2(config)#ethernet cfm domain-type character-string domain-name 12346 level 7 mip-creation none	Create CFM domain for MA type with string and set MIP creation to none
PE2(config-ether-cfm) # service ma-type string ma-name 124	Create the CFM MA type with string
PE2(config-ether-cfm-ma)#vpws test1	Configure VPWS to associate to the MA
PE2(config-ether-cfm-ma)#ethernet cfm mep up mpid 10 active true vpws test1	Create up-MEP for VPWS
PE2(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multi cast to enable
PE2(config-ether-cfm-ma-mep)#ethernet cfm delay-measurement reply dmm	Configure the DMR
PE2(config-ether-cfm-ma-mep)#ethernet cfm loss-measurement reply lmm	Configure the LMR
PE2(config-ether-cfm-ma-mep)#exit-ether-ma- mep-mode	Exit Ethernet MP mode
PE2(config-ether-cfm-ma) #mep crosscheck mpid 20	Configure cross check to remote MEP
PE2(config-ether-cfm-ma)#cc interval 10ms	Enable CC interval with value 10 milliseconds
PE2(config-ether-cfm-ma)#exit-ether-ma-mode	Exit Ethernet MA mode
PE2(config-ether-cfm)#commit	Commit the transaction
PE2(config-ether-cfm)exit	Exit the VPWS transaction

P1

Configure P1.

Pl#configure terminal	Enter configure mode
P1(config)#interface lo	Enter the Interface mode for the loopback interface
P1(config-if)#ip address 2.2.2.2/32 secondary	Commit the transaction
P1(config-if)#commit	Exit the Interface mode
P1(config-if)#exit	Configure IP address on loopback interface
P1(config)#router ldp	Enter the Router LDP mode
P1(config-router)#transport-address ipv4 2.2.2.2	Configure targeted peer
P1(config-router)#commit	Commit the transaction
P1(config-router)exit	Exit the transaction
P1(config)#interface xe2	Enter the Interface mode for xe2
P1(config-if)# ip address 192.168.10.2/24	Configure IP address on the interface
P1(config-if)# label-switching	Enable label switching on the interface
P1(config-if)# enable-ldp ipv4	Enable LDP on the physical interface
P1(config-if)#commit	Commit the transaction
P1(config-if)#exit	Exit the transaction
Pl(config)#interface xel	Enter the Interface mode for xe1

P1(config-if)# ip address 192.168.20.1/24	Configure IP address on the interface
P1(config-if)# label-switching	Enable label switching on the interface
P1(config-if)# enable-ldp ipv4	Enable LDP on the physical interface
P1(config-if)#commit	Commit the transaction
P1(config-if)#exit	Exit the transaction
P1(config)#router ospf 1	Enter the Router OSPF mode
P1(config-router) # ospf router-id 2.2.2.2	Configure the OSPF router-id
P1(config-router) # bfd all-interfaces	Configure the BFD
P1(config-router) # network 2.2.2.2/32 area 0.0.0.0	OSPF loopback address
P1(config-router) # network 192.168.20.0/24 area 0.0.0.0	Advertise OSPF network
P1(config-router)# network 192.168.10.0/24 area 0.0.0.0	Advertise OSPF network
P1(config-router)#commit	Commit the transaction

P2

Configure P2.

P2#configure terminal	Enter configure mode
P2(config)#interface lo	Enter the Interface mode for the loopback interface
P2(config-if)#ip address 3.3.3.3/32 secondary	Configure IP address on loopback interface
P2(config-if)#commit	Commit the transaction
P2(config-if)#exit	Exit the Interface mode
P2(config)#router ldp	Enter the Router LDP mode
P2(config-router)#transport-address ipv4 3.3.3.3	Configure targeted peer
P2(config-router)#commit	Commit the transaction
P2(config-router)exit	Exit the Interface mode
P2(config)#interface xel	Enter the Interface mode for xe1
P2(config-if)# ip address 192.168.20.2/24	Configure IP address on the interface
P2(config-if)# label-switching	Enable label switching on the interface
P2(config-if)# enable-ldp ipv4	Enable LDP on the physical interface
P2(config-if)#commit	Commit the transaction
P2(config-if)#exit	Exit interface mode
P2(config)#interface xe2	Enter the Interface mode for xe2
P2(config-if)# ip address 192.168.30.1/24	Configure IP address on the interface
P2(config-if)# label-switching	Enable label switching on the interface

Enable LDP on the physical interface
Commit the transaction
Exit interface mode
Enter the Router OSPF mode
Configure the OSPF router-id
Advertise loopback address in OSPF
Advertise OSPF network address
Advertise OSPF network address
Commit the transaction

Validation

CFM

PE1#show ethernet cfm errors domain 12346

Domain	Name	Level	MEPID	Defects
12346		7	20	

defRDICCM
 defMACstatus
 defRemoteCCM
 defErrorCCM
 defXconCCM

PE1#show ethernet cfm ma status domain 12346 ma-name 124 MA NAME STATUS 124 Active

Ping

PE1#ping ethernet mac e8c5.7ae3.37ee unicast source 20 domain 12346 ma 124
 success rate is 100 (5/5)
PE1#

Traceroute

PE1#traceroute ethernete8c5.7ae3.37eemepid20domain12346ma124MP MacHopsRelay-actionIngress/EgressIngress/Egressactione8c5.7ae3.37ee1RlyHitIngressIngOK

Checking VC Status

PE1#show mpls vc-table

(m) - Service mapped over multipath transport(e) - Service mapped over LDP ECMP

VC-ID Vlan-ID Inner-Vlan-ID Access-Intf Network-Intf Out Label Tunnel-Label Nexthop Status UpTime 2001 N/A xe12001 xe2 26240 25601 N/A 4.4.4.4 Active 00:38:0

Delay-measurement

PE1#delay-measurement type proactive profile-name DM rmep 10 mep 20 domain 12346 ma 124 PE1#2023 Oct 12 04:11:56.696 : PE1 : ONMD : INFO : [CFM PM_SESSION_INFO_5]: CFM Frame Delay Measurement session started for MEP Id 20 and RMEP Id 10

PE1#show ethernet cfm delay-measurement mep 20 domain 12346 ma-name 124 MD : 12346 MA : 124 MEP : 20

VC Name	: test3
Peer MAC Address	: e8c5.7ae3.37ee

CURRENT:

RMEP ID : 10				
Measurement ID : 1				
Measurement Type	:	DMM		
Elapsed time(sec)	:	2		
Start Time	:	2023 Oct	: 12	04:11:56
Suspect Flag	:	FALSE		
Min Frame Delay(usec)	:	40		
Max Frame Delay(usec)	:	74		
Avg Frame Delay(usec)	:	57		
Min Inter FD Variation(usec)	:	34		
Max Inter FD Variation(usec)	:	34		
Avg Inter FD Variation(usec)	:	34		

	FRAME DE	LAY BINS				
Bin	Number Bin	Threshold	(us	sec)	Bin	Counter
1	0	-	<	4999	2	
2	50	00 -	<	9999	0	
3	10	000 -	<	14999	0	
4	15	- 000	<	4294967295	0	

	INTER-	FRAME	DELAY BINS		
Bin	Number	Bin	Threshold(usec)	Bin	Counter
1		0	- < 4999	1	

2	5000	-	<	9999	0
3	10000	_	<	4294967295	0

Loss-measurement

PE1#loss-measurement type proactive profile-name LM rmep 10 mep 20 domain 12346 ma 124 2023 Oct 12 04:18:43.667 : PE1 : ONMD : INFO : [CFM_DEFECT_INFO_5]: CFM Frame Loss Measurement started for MEP:20 MA:124 MD:12346 PE1#show ethernet cfm loss-measurement mep 20 domain 12346 ma-name 124

```
MEP: 20 MA: 124
CURRENT:
 Measurement ID : 1
                             : False
  Suspect
                             : lmm
  Measurement Type
  Elapsed time(sec)
                             : 10
  Start Time
                             : 2023 Oct 12 04:18:43
  Near End loss
                             : 0
  Far End loss
                             : 0
  Near End accumulated loss : 0
  Far End accumulated loss : 0
  Near End frame loss ratio : 0
  Far End frame loss ratio : 0
```

Synthetic Loss Measurement

PE1#loss-measurement type proactive profile-name SLM rmep 10 mep 20 domain 12346 ma 124 PE1#2023 Sep 30 07:07:57.166 : PE1 : ONMD : INFO : [CFM_DEFECT_INFO_5]: CFM Frame Loss Measurement started for MEP:20 MA:124 MD:12346

```
PE1#show ethernet cfm loss-measurement mep 20 domain 12346 ma-name 124
MEP: 20 MA: 124
CURRENT:
 Measurement ID : 2
                             : False
  Suspect
  Measurement Type
                             : slm
  Elapsed time(sec)
                             : 10
  Start Time
                             : 2023 Sep 30 07:08:56
  Near End loss
                             : 0
  Far End loss
                             : 0
  Near End accumulated loss : 0
  Far End accumulated loss
                             : 0
  Near End frame loss ratio : 0
  Far End frame loss ratio : 0
HISTORY:
 Measurement ID : 1
  Suspect
                             : False
```

```
Measurement Type
                            : slm
 Elapsed time(sec)
                            : 60
 End Time
                            : 2023 Sep 30 07:08:56
 Near End loss
                            : 0
 Far End loss
                            : 0
 Near End accumulated loss : 0
 Far End accumulated loss
                            : 0
 Near End frame loss ratio : 0
 Far End frame loss ratio
                            : 0
 Near End frame loss ratio min : 0
 Far End frame loss ratio min : 0
 Near End frame loss ratio max : 0
 Far End frame loss ratio max : 0
PE1#
PE1#show ethernet cfm maintenance-points count
Total No of MIPs
                                : 0
Total No of MEPs
                                : 2
Total No of UP MEPs
                                : 2
Total No of Down MEPs
                                : 0
Total No of Active CCM sessions : 2
Total No of UP CCM sessions
                           : 2
Total No of Active LM sessions : 2
Total No of Active DM sessions : 1
```

CHAPTER 2 Y.1731 Performance Monitoring Configurations

ITU-T Y.1731 supports Performance Monitoring feature for Ethernet. Loss and Delay measurement can be achieved which can be significantly used to identify network problems before they impact. SLM is used to calculate the frame loss between endpoints using synthetic frames. Transmit and received counters at endpoints for received vs dropped are used to measure frame loss. CCM and LMM are used to calculate the frame loss of data traffic between endpoints. On CCM, loss measurement is encapsulated as part of CFM packets and it's dual ended. For LMM, separate loss measurement message and reply is shared on configured interval between endpoints to calculate the data frame loss. CCM and LMM service frames will have the counters which maintain a count of transmitted and received data frames between a pair of MEPs.Ethernet frame delay measurement provides fine control to operators for triggering delay measurement on a given service and can be used to monitor SLAs. Ethernet frame delay measurement also collects other useful information, such as worst and best case delays, average delay, and aver-age delay variation.

Topology SW4 SW2 SW3 SW5 SW1 -----..... CeO Xe9 Customer MD level 7 SW2 SW4 SW3 SW5 SW1 Xe0 Ce49 Xe1 Xe9 Ce0 Xe17 Xe1 Xe9

Synthetic Loss Measurement (SLM) over L2 Bridge



Prerequisite

Configure below hardware-profile commands related to CFM in configuration mode and reboot the nodes.

Up MEP over VPWS

hardware-profile filter cfm-domain-name-str enable hardware-profile statistics cfm-ccm enable

Synthetic Loss Measurement (SLM) over L2 Bridge

SW1#configure terminal	Enter configure mode.
SW1(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.

SW1(config)#vlan database	Entering VLAN database.
SW1(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW1(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW1(config-vlan)#exit	Exit config mode.
SW1(config)#int ce49	Configure interface ce49.
SW1(config-if)#switchport	Configure the interface as switch port.
SW1(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW1(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW1(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.
SW1(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW1(config-if)#exit	Exit config mode.
SW1(config)#ethernet cfm domain-type character-string domain-name mdnam level 7 mip-creation default	Create cfm domain with type as character string and set mip creation criteria to default.
SW1(config-ether-cfm)#service ma-type string ma-name testtm	Create ma type as string and set mip creation criteria to de- fault.
SW1(config-ether-cfm-ma)#vlan 512 bridge 1	Configure primary VLAN ID
SW1(config-ether-cfm-ma)#mip-creation default	Configure MIP creation permission
SW1(config-ether-cfm-ma)#ethernet cfm mep down mpid 2 active true ce49	Create down mep for local-vid on ce49.
SW1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast.
SW1(config-ether-cfm-ma-mep)#exit-ether-ma- mep-mode	Exit ethernet cfm ma-mep mode.
SW1(config-ether-cfm-ma) #mep crosscheck mpid	Configure crosscheck to remote MEP in VLAN 512.
SW1(config-ether-cfm-ma)#cc interval 10ms	Enable cc interval for 10 millisecond.
SW1(config-ether-cfm-ma)#exit-ether-ma-mode	Exit ethernet ma mode.
SW1(config-ether-cfm)#commit	Commit the candidate configuration to the running configuration.
SW1(config-ether-cfm)#exit	Exit ethernet CFM mode.
SW1(config)#ethernet cfm loss-measurement profile-name SLM	Creating loss-measurement profile for SLM
SW1(config-cfm-lm)#measurement-interval 1	Specify the measurement-interval in minutes
SW1(config)#intervals-stored 3	Specify the number of history interval to be stored
SW1(config)# message-period 1	Specify message period interval time
SW1(config)#commit	Commit the candidate configuration to the running configuration.

SW2#configure terminal	Enter configure mode.
SW2(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW2(config)#vlan database	Entering VLAN database.
SW2(config-vlan)#vlan 512 type customer bridge 1 state enable	Create VLAN 512 for customer bridge.
SW2(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW2(config-vlan)#exit	Exit config mode.
SW2(config)#interface ce0	Configure interface ce0.
SW2(config)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#switchport	Configure interface as a switch port.
SW2(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW2(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW2(config-if)#switchport trunk allowed vlan all	Allow all customer VLANs on interface ce0.
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#int xe0	Configure interface xe0
SW2(config-if)#switchport	Configure interface as switch port.
SW2(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW2(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW2(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe1
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2 (config-if) #exit	Exit config mode.

SW3#configure terminal	Enter configure mode.
SW3(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW3(config)#vlan database	Entering VLAN database.
SW3(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW3(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW3(config-vlan)#exit	Exit config mode.
SW3(config)#int xe17	Configure interface xe17.
SW3(config-if)#switchport	Configure the interface as switch port.
SW3(config-if)#bridge-group 1	Configure interface in bridge group 1.

SW3(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW3(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe17.
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit config mode.
SW3(config)#int xel	Configure interface xe1.
SW3(config-if)#switchport	Configure the interface as switch port.
SW3(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW3(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW3(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe1.
SW3(config-if)#exit	Exit config mode.

SW4#configure terminal	Enter configure mode.
SW4(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW4(config)#vlan database	Entering VLAN database.
SW4(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW4(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW4(config-vlan)#exit	Exit config mode.
SW4(config)#int xel	Configure interface xe1.
SW4(config-if)#switchport	Configure the interface as switch port.
SW4(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW4(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW4(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe1.
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit config mode.
SW4(config)#int xe9	Configure interface xe9.
SW4(config-if)#switchport	Configure the interface as switch port.
SW4(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW4(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW4(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe9.
SW4(config-if)#exit	Exit config mode.

SW5#configure terminal	Enter configure mode.
SW5(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW5(config)#vlan database	Entering VLAN database.
SW5(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW5(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW5(config-vlan)#exit	Exit config mode.
SW5(config)#int xe9	Configure interface xe9.
SW5(config-if)#switchport	Configure the interface as switch port.
SW5(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW5(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW5(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe9.
SW5(config-if)#commit	Commit the candidate configuration to the running configuration.
SW5(config-if)#exit	Exit config mode.
SW5(config)#ethernet cfm domain-type character-string domain-name mdnam level 7 mip-creation default	Create cfm domain with type as character string and set mip creation criteria to default.
SW5(config-ether-cfm)#service ma-type string ma-name testtm	Create ma type as string and set mip creation criteria to default.
SW5(config-ether-cfm-ma)#vlan 512 bridge 1	Configure primary VLAN ID
SW5(config-ether-cfm-ma)#mip-creation default	Configure MIP creation permission
SW5(config-ether-cfm-ma)#ethernet cfm mep down mpid 1 active true xe9	Create down mep for local-vid on xe9
SW5(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast.
SW5(config-ether-cfm-ma-mep)#ethernet cfm loss-measurement reply slm	Generate and send SLR responses tacked
SW5(config-ether-cfm-ma-mep)#exit-ether-ma- mep-mode	Exit ethernet cfm ma-mep mode.
SW5(config-ether-cfm-ma)#mep crosscheck mpid 2	Configure crosscheck to remote MEP in VLAN 512.
SW5(config-ether-cfm-ma)#cc interval 10ms	Enable cc interval for 10 millisecond.
SW5(config-ether-cfm-ma)#exit-ether-ma-mode	Exit ethernet ma mode.
SW5(config-ether-cfm)#commit	Commit the candidate configuration to the running configuration.
SW5(config-ether-cfm)#exit	Exit ethernet CFM mode.

Commands to initiate/abort loss measurement

SW1#loss-measurement type proactive profile-name <WORD> rmep mac-address

<HHHH.HHHH.HHHH>mep <MEPID> domain < DOMAIN NAME> ma <MA NAME>

SW1#abort loss-measurement mep <MEPID> domain <DOMAIN NAME> MA <MA NAME>

Validation

SW1#ping ethernet mac 3c2c.9926.e683 unicast source 2 domain mdnam ma

SW1#traceroute	ethernet	3c2c.9926.e683	mepid 2 domain mdnam	ma testtm	
MP Mac	Hops	Relay-action	Ingress/Egress	Ingress/Egress ac-t	ion
3c2c.9926.e683	1	RlyHit	Ingress	IngOK	

SW1#loss-measurement type proactive profile-name SLM rmep mac-address 3c2c.9926.e683 mep 2 domain mdnam ma testtm

SW1#show ethernet cfm loss-	-measurement mep 2 domain mdnam ma testtm
MEP: 2 MA: testtm	
CURRENT:	
Measurement ID	:1
Suspect	:True
Measurement Type	:slm
Elapsed time(sec)	:7
Start Time	:2019 Apr 30 14:43:41
Near End loss	:0
Far End loss	:0
Near End accumulated loss	: 0
Far End accumulated loss	: 0
SW1# abort loss-measurement	z mep 2 domain mdnam

Synthetic Loss Measurement (SLM) Over VPWS



Figure 2-5: CFM Y.1731 SLM over VPWS Topology

SW1#configure terminal	Enter configure mode.
SW1(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW1(config)#vlan database	Entering VLAN database.
SW1(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.

SW1(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW1(config-vlan)#exit	Exit config mode.
SW1(config)#interface ce49	Configure interface ce49.
SW1(config-if)#switchport	Configure the interface as switch port.
SW1(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW1(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW1(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.
SW1(config-if)#commit	Commit the candidate configuration to the running configuration.
SW1(config-if)#exit	Exit config mode.

SW2#configure terminal	Enter configure mode.
SW2(config)#interface ce0	Configure interface ce0.
SW2(config-if)#switchport	Configure interface as a switch port.
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#interface xe0	Configure interface xe1.
SW2(config-if)#no switchport	Configure interface as router port.
SW2(config-if)#ip address 10.0.0.1/24	Assign IP address to router port xe0
SW2(config-if)#no shutdown	Making the interface up
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#interface lo	Configure interface lo
SW2(config-if)#ip address 1.1.1.1/32 secondary	Configure secondary IP address to loopback interface .
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#router ospf 100	Configure ospf
SW2(config-router)#network 10.0.0.0/24 area 0	Advertising 10 network
SW2(config-router)#network 1.1.1.1/32 area 0	Advertising loopback IP
SW2(config-router)#commit	Commit the candidate configuration to the running configuration.
SW2(config-router)#exit	Exit router mode.
SW2(config)#router rsvp	Configuring rsvp
SW2(config-router)#hello-receipt	Configuring hello reception
SW2(config-router)#no php	Configuring device as not a PHP
SW2(config-router)#revert-timer 10	Configuring reversion time of RSVP

SW2(config-router)#commit	Commit the candidate configuration to the running configuration.
SW2(config-router)#exit	Exit router mode.
SW2(config)#rsvp-trunk to-1 ipv4	Configuring RSVP path
SW2(config-trunk)#to 2.2.2.2	Configuring first hop
SW2(config-trunk)#to 3.3.3.3	Configuring second hop
SW2(config-trunk)#exit	Exit trunk mode.
SW2(config)#interface xe0	Configuring interface
SW2(config-if)#enable-rsvp	Enabling RSVP in interface
SW2(config-if)#label-switching	Enabling MPLS labeling
SW2(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#router ldp	Configuring LDP
SW2(config-router)#targeted-peer ipv4 3.3.3.3	Configuring LDP target peer for PW
SW2(config-router-targeted-peer)#exit- targeted-peer-mode	Exit target peer mode
SW2(config-router)#no multicast-hellos	Disabling LDP multicast
SW2(config-router)#commit	Commit the candidate configuration to the running configuration.
SW2(config-router)#exit	Exit router mode.
SW2(config)#mpls l2-circuit ETH-2001 1 3.3.3.3	Creating VPWS PW
SW2(config-pseudowire)#commit	Commit the candidate configuration to the running configuration.
SW2(config-pseudowire)#exit	Exit pseudowire config mode.
SW2(config)#service-template ETH-2001	Configuring service template profile for PW
SW2(config-svc)#match outer-vlan 10	Configuring match condition
SW2(config-svc)# rewrite ingress push 2000	Configuring action for match
SW2(config-svc)#commit	Commit the candidate configuration to the running configuration.
SW2(config-svc)#exit	Exit service template mode
SW2(config)#interface ce0	Configuring interface
SW2(config-if)#mpls-l2-circuit ETH-2001 ser- vice-template ETH-2001	Mapping VPWS in AC
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#hardware-profile filter cfm- domain-name-str enable	Enabling HW filter for character string domain name
SW2(config)#ethernet cfm domain-type character-string domain-name 12345 level 7 mip-creation none	Configuring CFM domain over VPWS

SW2(config-ether-cfm-mpls-md)#service ma- type string ma-name 43981 mip-creation none	Creating MA for domain
SW2(config-ether-cfm-mpls-md-ma)#cc interval 100ms	Configuring CFM interval
SW2(config-ether-cfm-mpls-md-ma)#mep cross- check mpid 1	Configuring remote mep
SW2(config-ether-cfm-mpls-md-ma)#ethernet cfm mep up mpid 4001 active true vpws ETH- 2001	Configuring local mep and mapping the same with vpws ser- vice
SW2(config-ether-cfm-mpls-ma-mep)#cc mul- ticast state enable	Enabling the CFM multicast
SW2(config-ether-cfm-mpls-ma-mep)#commit	Commit the candidate configuration to the running configuration.
SW2(config-ether-cfm-mpls-ma-mep)#exit	Exit CFM MEP configuration mode
SW2(config-ether-cfm-mpls-md-ma)#exit	Exit CFM MA configuration mode
SW2(config-ether-cfm-mpls-md)#exit	End current mode and down to previous mode
SW2(config)#ethernet cfm loss-measurement profile-name slm	Configuring LM profile
SW2(config-cfm-lm)#measurement-type slm	Configuring measurement type as SLM
SW2(config-cfm-lm)#message-period 3	Configuring message period
SW2(config-cfm-lm)#measurement-interval 1	Configuring measurement interval
SW2(config-cfm-lm)#intervals-stored 3	Configuring number of interval to be stored
SW2(config-cfm-lm)#commit	Commit the candidate configuration to the running configuration.
SW2(config-cfm-lm)#end	Exit config mode

SW3#configure terminal	Enter configure mode.
SW3(config)#interface xe17	Configure interface
SW3(config-if)#no switchport	Configure interface as router port.
SW3(config-if)#ip address 20.0.0.1/24	Assign IP address to router port
SW3(config-if)#no shutdown	Making the interface up
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#interface xel	Configure interface
SW3(config-if)#no switchport	Configure interface as router port.
SW3(config-if)#ip address 10.0.0.2/24	Assign IP address to router port
SW3(config-if)#no shutdown	Making the interface up
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#interface lo	Configure interface lo
SW3(config-if)#ip address 2.2.2.2/32 secondary	Configure secondary IP address to loopback interface .

SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#router ospf 100	Configure ospf
SW3(config-router)#network 10.0.0/24 area 0	Advertising 10 network
SW3(config-router)#network 20.0.0/24 area 0	Advertising 10 network
SW3(config-router)#network 2.2.2.2/32 area 0	Advertising loopback IP
SW3(config-router)#commit	Commit the candidate configuration to the running configuration.
SW3(config-router)#exit	Exit router mode.
SW3(config)#router rsvp	Configuring rsvp
SW3(config-router)#hello-receipt	Configuring hello reception
SW3(config-router)#no php	Configuring device as not a PHP
SW3(config-router)#revert-timer 10	Configuring reversion time of RSVP
SW3(config-router)#commit	Commit the candidate configuration to the running configuration.
SW3(config-router)#exit	Exit router mode.
SW3(config)#interface xel	Configuring interface
SW3(config-if)#enable-rsvp	Enabling RSVP in interface
SW3(config-if)#label-switching	Enabling MPLS labeling
SW3(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#interface xe17	Configuring interface
SW3(config-if)#enable-rsvp	Enabling RSVP in interface
SW3(config-if)#label-switching	Enabling MPLS labeling
SW3(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.

SW4#configure terminal	Enter configure mode.
SW4(config)#interface xe9	Configure interface
SW4(config-if)#switchport	Configure interface as switch port.
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#interface xel	Configure interface
SW4(config-if)#no switchport	Configure interface as router port.

SW4(config-if)#ip address 20.0.0.2/24	Assign IP address to router port
SW4(config-if)#no shutdown	Making the interface up
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#interface lo	Configure interface lo
SW4(config-if)#ip address 3.3.3.3/32 secondary	Configure secondary IP address to loopback interface .
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#router ospf 100	Configure ospf
SW4(config-router)#network 20.0.0/24 area 0	Advertising 10 network
SW4(config-router)#network 3.3.3.3/32 area 0	Advertising loopback IP
SW4(config-router)#commit	Commit the candidate configuration to the running configuration.
SW4(config-router)#exit	Exit router mode.
SW4(config)#router rsvp	Configuring rsvp
SW4(config-router)#hello-receipt	Configuring hello reception
SW4(config-router)#no php	Configuring device as not a PHP
SW4(config-router)#revert-timer 10	Configuring reversion time of RSVP
SW4(config-router)#commit	Commit the candidate configuration to the running configuration.
SW4(config-router)#exit	Exit router mode.
SW4(config)#rsvp-trunk to-1 ipv4	Configuring RSVP path
SW4(config-trunk)#to 2.2.2.2	Configuring first hop
SW4(config-trunk)#to 1.1.1.1	Configuring second hop
SW4(config-trunk)#commit	Commit the candidate configuration to the running configuration.
SW4(config-trunk)#exit	Exit trunk mode.
SW4(config)#interface xel	Configuring interface
SW4(config-if)#enable-rsvp	Enabling RSVP in interface
SW4(config-if)#label-switching	Enabling MPLS labeling
SW4(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#router ldp	Configuring LDP
SW4(config-router)#targeted-peer ipv4 1.1.1.1	Configuring LDP target peer for PW
SW4 (config-router-targeted-peer) #exit- targeted-peer-mode	Exit target peer mode
SW4(config-router)#no multicast-hellos	Disabling LDP multicast

SW4(config-router)#commit	Commit the candidate configuration to the running configuration.
SW4(config-router)#exit	Exit router mode.
SW4(config)#mpls l2-circuit ETH-2001 1 1.1.1.1	Creating VPWS PW
SW4(config-pseudowire)#commit	Commit the candidate configuration to the running configuration.
SW4(config-pseudowire)#exit	Exit pseudowire config mode.
SW4(config)#service-template ETH-2001	Configuring service template profile for PW
SW4(config-svc)# match outer-vlan 200	Configuring match condition
SW4(config-svc)# rewrite ingress push 2000	Configuring action for match
SW4(config-svc)#commit	Commit the candidate configuration to the running configuration.
SW4(config-svc)#exit	Exit service template mode
SW4(config)#interface xe9	Configuring interface
SW4(config-if)#mpls-l2-circuit ETH-2001 ser- vice-template ETH-2001	Mapping VPWS in AC
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#hardware-profile filter cfm- domain-name-str enable	Enabling HW filter for character string domain name
SW4(config)#ethernet cfm domain-type charac- ter-string domain-name 12345 level 7 mip- creation none	Configuring CFM domain over VPWS
SW4(config-ether-cfm-mpls-md)#service ma- type string ma-name 43981	Creating MA for domain
SW4(config-ether-cfm-ma)#mip-creation none	Configuring MIP creation permission
SW4(config-ether-cfm-mpls-md-ma)#cc interval 100ms	Configuring CFM interval
SW4(config-ether-cfm-mpls-md-ma)#cc interval 3	Configuring CFM interval
SW4(config-ether-cfm-mpls-md-ma)#mep cross- check mpid 4001	Configuring remote mep
SW4(config-ether-cfm-mpls-md-ma)#ethernet cfm mep up mpid 1 active true vpws ETH-2001	Configuring local mep and mapping the same with vpws ser- vice
SW4(config-ether-cfm-mpls-ma-mep)#cc mul- ticast state enable	Enabling the CFM multicast
SW4(config-ether-cfm-mpls-ma-mep)#ethernet cfm loss-measurement reply slm	Configuring SLR
SW4(config-ether-cfm-mpls-ma-mep)#commit	Commit the candidate configuration to the running configuration.
SW4(config-ether-cfm-mpls-ma-mep)#end	Exit config mode

SW5#configure terminal	Enter configure mode.
SW5(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW5(config)#vlan database	Entering VLAN database.
SW5(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW5(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW5(config-vlan)#exit	Exit config mode.
SW5(config)#interface xe9	Configure interface ce49.
SW5(config-if)#switchport	Configure the interface as switch port.
SW5(config-if)#bridge-group 1	Configure interface in bridge group 1
SW5(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW5(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.
SW5(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW5(config-if)#exit	Exit config mode.

Commands to initiate/abort loss measurement

SW2#loss-measurement type proactive profile-name <WORD> rmep mac-address <HHHH.HHHH.HHHH>mep <MEPID> domain < DOMAIN NAME>

SW2#abort loss-measurement mep <MEPID> domain <DOMAIN NAME>

Validation

SW2#loss-measurement type proactive profile-name slm rmep mac-address 3c2c.9926.e683 mep 1 domain 12345

```
SW2#show ethernet cfm loss-measurement mep 1 domain 12345
MEP: 2 MA: 43981
CURRENT:
Measurement ID
                          : 1
Suspect
                          : False
Measurement Type
                          : slm
                           : 7
Elapsed time(sec)
Start Time
                          : 2019 Apr 30 14:43:41
Near End loss
                          : 0
Far End loss
                          : 0
Near End accumulated loss : 0
Far End accumulated loss : 0
SW2# abort loss-measurement mep 1 domain 12345
```

Synthetic Loss Measurement (SLM) Over ELINE



Figure 2-6: CFM Y.1731 SLM over ELINE Topology

SW1

SW1#configure terminal	Enter configure mode.
SW1(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW1(config)#vlan database	Entering VLAN database.
SW1(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW1(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW1(config-vlan)#exit	Exit config mode.
SW1(config)#interface ce49	Configure interface ce49.
SW1(config-if)#switchport	Configure the interface as switch port.
SW1(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW1(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW1(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.
SW1(config-if)#commit	Commit the candidate configuration to the running configuration.
SW1(config-if)#exit	Exit config mode.

SW2#configure terminal	Enter configure mode.
SW2(config)#interface ce0	Configure interface ce0.
SW2(config-if)#switchport	Configure interface as a switch port.
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#interface xe0	Configure interface xe1.
SW2(config-if)#no switchport	Configure interface as router port.
SW2(config-if)#ip address 10.0.0.1/24	Assign IP address to router port xe0
SW2(config-if)#no shutdown	Making the interface up
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#interface lo	Configure interface lo
--	--
SW2(config-if)#ip address 1.1.1.1/32 secondary	Configure secondary IP address to loopback interface .
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#router ospf 100	Configure ospf
SW2(config-router)#network 10.0.0/24 area 0	Advertising 10 network
SW2(config-router)#network 1.1.1.1/32 area 0	Advertising loopback IP
SW2(config-router)#commit	Commit the candidate configuration to the running configuration.
SW2(config-router)#exit	Exit router mode.
SW2(config)#router rsvp	Configuring rsvp
SW2(config-router)#hello-receipt	Configuring hello reception
SW2(config-router)#no php	Configuring device as not a PHP
SW2(config-router)#revert-timer 10	Configuring reversion time of RSVP
SW2(config-router)#commit	Commit the candidate configuration to the running configuration.
SW2(config-router)#exit	Exit router mode.
SW2(config)#rsvp-trunk to-1 ipv4	Configuring RSVP path
SW2(config-trunk)#to 2.2.2.2	Configuring first hop
SW2(config-trunk)#to 3.3.3.3	Configuring second hop
SW2(config-trunk)#exit	Exit trunk mode.
SW2(config)#interface xe0	Configuring interface
SW2(config-if)#enable-rsvp	Enabling RSVP in interface
SW2(config-if)#label-switching	Enabling MPLS labeling
SW2(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#router ldp	Configuring LDP
SW2(config-router)#targeted-peer ipv4 3.3.3	Configuring LDP target peer for PW
SW2(config-router-targeted-peer)#exit- targeted-peer-mode	Exit target peer mode
SW2(config-router)#no multicast-hellos	Disabling LDP multicast
SW2(config-router)#commit	Commit the candidate configuration to the running configuration.
SW2(config-router)#exit	Exit router mode.
SW2(config)#mpls l2-circuit ETH-2001 1 3.3.3.3	Creating VPWS PW
SW2(config-pseudowire)#commit	Commit the candidate configuration to the running configuration.
SW2(config-pseudowire)#exit	Exit pseudowire config mode.

SW2(config)#service-template ETH-2001	Configuring service template profile for PW
SW2(config-svc)#match outer-vlan 10	Configuring match condition
SW2(config-svc)# rewrite ingress push 2000	Configuring action for match
SW2(config-svc)#commit	Commit the candidate configuration to the running configuration.
SW2(config-svc)#exit	Exit service template mode
SW2(config)#interface ce0	Configuring interface
SW2(config-if)#mpls-l2-circuit ETH-2001 ser- vice-template ETH-2001	Mapping VPWS in AC
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#hardware-profile filter cfm- domain-name-str enable	Enabling HW filter for character string domain name
SW2(config)#ethernet cfm domain-type character-string domain-name 12345 level 7 mip-creation none	Configuring CFM domain over VPWS
SW2(config-ether-cfm-mpls-md)#service ma- type string ma-name 43981 mip-creation none	Creating MA for domain
SW2(config-ether-cfm-mpls-md-ma)#cc interval 100ms	Configuring CFM interval
SW2(config-ether-cfm-mpls-md-ma)#mep cross- check mpid 1	Configuring remote mep
SW2(config-ether-cfm-mpls-md-ma)#ethernet cfm mep up mpid 4001 active true vpws ETH- 2001	Configuring local mep and mapping the same with vpws ser- vice
SW2(config-ether-cfm-mpls-ma-mep)#cc mul- ticast state enable	Enabling the CFM multicast
SW2(config-ether-cfm-mpls-ma-mep)#commit	Commit the candidate configuration to the running configuration.
SW2(config-ether-cfm-mpls-ma-mep)#exit	Exit CFM MEP configuration mode
SW2(config-ether-cfm-mpls-md-ma)#exit	Exit CFM MA configuration mode
SW2(config-ether-cfm-mpls-md)#exit	End current mode and down to previous mode
SW2(config)#ethernet cfm loss-measurement profile-name slm	Configuring LM profile
SW2(config-cfm-lm)#measurement-type slm	Configuring measurement type as SLM
SW2(config-cfm-lm)#message-period 3	Configuring message period
SW2(config-cfm-lm)#measurement-interval 1	Configuring measurement interval
SW2(config-cfm-lm)#intervals-stored 3	Configuring number of interval to be stored
SW2(config-cfm-lm)#commit	Commit the candidate configuration to the running configuration.
SW2(config-cfm-lm)#end	Exit config mode

SW3#configure terminal	Enter configure mode.
SW3(config)#interface xe17	Configure interface

SW3(config-if)#no switchport	Configure interface as router port.
SW3(config-if)#ip address 20.0.0.1/24	Assign IP address to router port
SW3(config-if)#no shutdown	Making the interface up
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#interface xe1	Configure interface
SW3(config-if)#no switchport	Configure interface as router port.
SW3(config-if)#ip address 10.0.0.2/24	Assign IP address to router port
SW3(config-if)#no shutdown	Making the interface up
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#interface lo	Configure interface lo
SW3(config-if)#ip address 2.2.2.2/32 secondary	Configure secondary IP address to loopback interface .
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#router ospf 100	Configure ospf
SW3(config-router)#network 10.0.0/24 area 0	Advertising 10 network
SW3(config-router)#network 20.0.0/24 area 0	Advertising 10 network
SW3(config-router)#network 2.2.2.2/32 area 0	Advertising loopback IP
SW3(config-router) #network 2.2.2.2/32 area 0 SW3(config-router) #commit	Advertising loopback IP Commit the candidate configuration to the running configuration.
SW3(config-router)#network 2.2.2.2/32 area 0 SW3(config-router)#commit SW3(config-router)#exit	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode.
SW3(config-router)#network 2.2.2.2/32 area 0 SW3(config-router)#commit SW3(config-router)#exit SW3(config)#router rsvp	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode. Configuring rsvp
SW3(config-router)#network 2.2.2.2/32 area 0 SW3(config-router)#commit SW3(config-router)#exit SW3(config)#router rsvp SW3(config-router)#hello-receipt	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode. Configuring rsvp Configuring hello reception
SW3 (config-router) #network 2.2.2.2/32 area 0 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config) #router rsvp SW3 (config-router) #hello-receipt SW3 (config-router) #no php	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode. Configuring rsvp Configuring hello reception Configuring device as not a PHP
SW3 (config-router) #network 2.2.2.2/32 area 0 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config) #router rsvp SW3 (config-router) #hello-receipt SW3 (config-router) #no php SW3 (config-router) #revert-timer 10	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode. Configuring rsvp Configuring hello reception Configuring device as not a PHP Configuring reversion time of RSVP
SW3 (config-router) #network 2.2.2.2/32 area 0 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config) #router rsvp SW3 (config-router) #hello-receipt SW3 (config-router) #no php SW3 (config-router) #revert-timer 10 SW3 (config-router) #commit	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode. Configuring rsvp Configuring hello reception Configuring device as not a PHP Configuring reversion time of RSVP Commit the candidate configuration to the running configuration.
SW3 (config-router) #network 2.2.2.2/32 area 0 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config) #router rsvp SW3 (config-router) #hello-receipt SW3 (config-router) #no php SW3 (config-router) #revert-timer 10 SW3 (config-router) #commit SW3 (config-router) #commit	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode. Configuring rsvp Configuring hello reception Configuring device as not a PHP Configuring reversion time of RSVP Commit the candidate configuration to the running configuration. Exit router mode.
SW3 (config-router) #network 2.2.2.2/32 area 0 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config) #router rsvp SW3 (config-router) #hello-receipt SW3 (config-router) #no php SW3 (config-router) #revert-timer 10 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config-router) #exit SW3 (config) #interface xel	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode. Configuring rsvp Configuring hello reception Configuring device as not a PHP Configuring reversion time of RSVP Commit the candidate configuration to the running configuration. Exit router mode. Configuring interface
SW3 (config-router) #network 2.2.2.2/32 area 0 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config) #router rsvp SW3 (config-router) #hello-receipt SW3 (config-router) #no php SW3 (config-router) #revert-timer 10 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config-router) #exit SW3 (config) #interface xel SW3 (config) #interface xel SW3 (config-if) #enable-rsvp	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode. Configuring rsvp Configuring hello reception Configuring device as not a PHP Configuring reversion time of RSVP Commit the candidate configuration to the running configuration. Exit router mode. Configuring interface Enabling RSVP in interface
SW3 (config-router) #network 2.2.2.2/32 area 0 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config) #router rsvp SW3 (config-router) #hello-receipt SW3 (config-router) #no php SW3 (config-router) #revert-timer 10 SW3 (config-router) #commit SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config-router) #exit SW3 (config) #interface xel SW3 (config-if) #enable-rsvp SW3 (config-if) #label-switching	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode. Configuring rsvp Configuring hello reception Configuring device as not a PHP Configuring reversion time of RSVP Commit the candidate configuration to the running configuration. Exit router mode. Configuring interface Enabling RSVP in interface Enabling MPLS labeling
SW3 (config-router) #network 2.2.2.2/32 area 0 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config) #router rsvp SW3 (config-router) #hello-receipt SW3 (config-router) #no php SW3 (config-router) #revert-timer 10 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config-router) #exit SW3 (config-router) #exit SW3 (config) #interface xel SW3 (config-if) #enable-rsvp SW3 (config-if) #label-switching SW3 (config-if) #enable-ldp ipv4	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode. Configuring rsvp Configuring hello reception Configuring device as not a PHP Configuring reversion time of RSVP Commit the candidate configuration to the running configuration. Exit router mode. Configuring interface Enabling RSVP in interface Enabling MPLS labeling Enabling Idp on interface
SW3 (config-router) #network 2.2.2.2/32 area 0 SW3 (config-router) #commit SW3 (config-router) #commit SW3 (config) #router rsvp SW3 (config-router) #hello-receipt SW3 (config-router) #no php SW3 (config-router) #revert-timer 10 SW3 (config-router) #commit SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config-router) #exit SW3 (config) #interface xe1 SW3 (config) #interface xe1 SW3 (config-if) #enable-rsvp SW3 (config-if) #label-switching SW3 (config-if) #enable-ldp ipv4 SW3 (config-if) #commit	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode. Configuring rsvp Configuring hello reception Configuring device as not a PHP Configuring reversion time of RSVP Commit the candidate configuration to the running configuration. Exit router mode. Configuring interface Enabling RSVP in interface Enabling MPLS labeling Enabling Idp on interface Commit the candidate configuration to the running configuration.
SW3 (config-router) #network 2.2.2.2/32 area 0 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config) #router rsvp SW3 (config-router) #hello-receipt SW3 (config-router) #no php SW3 (config-router) #revert-timer 10 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config-router) #exit SW3 (config) #interface xel SW3 (config) #interface xel SW3 (config-if) #enable-rsvp SW3 (config-if) #label-switching SW3 (config-if) #enable-ldp ipv4 SW3 (config-if) #commit SW3 (config-if) #exit	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode. Configuring rsvp Configuring hello reception Configuring device as not a PHP Configuring reversion time of RSVP Commit the candidate configuration to the running configuration. Exit router mode. Configuring interface Enabling RSVP in interface Enabling MPLS labeling Enabling Idp on interface Commit the candidate configuration to the running configuration. Exit interface mode.
SW3 (config-router) #network 2.2.2.2/32 area 0 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config-router) #hello-receipt SW3 (config-router) #no php SW3 (config-router) #revert-timer 10 SW3 (config-router) #commit SW3 (config-router) #exit SW3 (config-router) #exit SW3 (config) #interface xel SW3 (config) #interface xel SW3 (config-if) #enable-rsvp SW3 (config-if) #label-switching SW3 (config-if) #enable-ldp ipv4 SW3 (config-if) #commit SW3 (config-if) #exit SW3 (config-if) #exit SW3 (config-if) #exit	Advertising loopback IP Commit the candidate configuration to the running configuration. Exit router mode. Configuring rsvp Configuring hello reception Configuring device as not a PHP Configuring reversion time of RSVP Commit the candidate configuration to the running configuration. Exit router mode. Configuring interface Enabling RSVP in interface Enabling MPLS labeling Enabling Idp on interface Commit the candidate configuration to the running configuration. Exit interface Commit the candidate configuration to the running configuration. Exit interface mode. Configuration.

SW3(config-if)#label-switching	Enabling MPLS labeling
SW3(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.

SW4#configure terminal	Enter configure mode.
SW4(config)#interface xe9	Configure interface
SW4(config-if)#switchport	Configure interface as switch port.
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#interface xel	Configure interface
SW4(config-if)#no switchport	Configure interface as router port.
SW4(config-if)#ip address 20.0.0.2/24	Assign IP address to router port
SW4(config-if)#no shutdown	Making the interface up
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#interface lo	Configure interface lo
SW4(config-if)#ip address 3.3.3.3/32 secondary	Configure secondary IP address to loopback interface .
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#router ospf 100	Configure ospf
SW4(config-router)#network 20.0.0/24 area 0	Advertising 10 network
SW4(config-router)#network 3.3.3.3/32 area 0	Advertising loopback IP
SW4(config-router)#commit	Commit the candidate configuration to the running configuration.
SW4(config-router)#exit	Exit router mode.
SW4(config)#router rsvp	Configuring rsvp
SW4(config-router)#hello-receipt	Configuring hello reception
SW4(config-router)#no php	Configuring device as not a PHP
SW4(config-router)#revert-timer 10	Configuring reversion time of RSVP
SW4(config-router)#commit	Commit the candidate configuration to the running configuration.
SW4 (config-router) #exit	Exit router mode.
SW4(config)#rsvp-trunk to-1 ipv4	Configuring RSVP path
SW4(config-trunk)#to 2.2.2.2	Configuring first hop
SW4(config-trunk)#to 1.1.1.1	Configuring second hop

SW4(config-trunk)#commit	Commit the candidate configuration to the running configuration.
SW4(config-trunk)#exit	Exit trunk mode.
SW4(config)#interface xe1	Configuring interface
SW4(config-if)#enable-rsvp	Enabling RSVP in interface
SW4(config-if)#label-switching	Enabling MPLS labeling
SW4(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#router ldp	Configuring LDP
SW4(config-router)#targeted-peer ipv4 1.1.1.1	Configuring LDP target peer for PW
SW4(config-router-targeted-peer)#exit- targeted-peer-mode	Exit target peer mode
SW4(config-router)#no multicast-hellos	Disabling LDP multicast
SW4(config-router)#commit	Commit the candidate configuration to the running configuration.
SW4(config-router)#exit	Exit router mode.
SW4(config)#mpls l2-circuit ETH-2001 1 1.1.1.1	Creating VPWS PW
SW4(config-pseudowire)#commit	Commit the candidate configuration to the running configuration.
SW4(config-pseudowire)#exit	Exit pseudowire config mode.
SW4(config)#service-template ETH-2001	Configuring service template profile for PW
SW4(config-svc)# match outer-vlan 200	Configuring match condition
SW4(config-svc)# rewrite ingress push 2000	Configuring action for match
SW4(config-svc)#commit	Commit the candidate configuration to the running configuration.
SW4(config-svc)#exit	Exit service template mode
SW4(config)#interface xe9	Configuring interface
SW4(config-if)#mpls-l2-circuit ETH-2001 ser- vice-template ETH-2001	Mapping VPWS in AC
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#hardware-profile filter cfm- domain-name-str enable	Enabling HW filter for character string domain name
SW4(config)#ethernet cfm domain-type charac- ter-string domain-name 12345 level 7 mip- creation none	Configuring CFM domain over VPWS
SW4(config-ether-cfm-mpls-md)#service ma- type string ma-name 43981	Creating MA for domain
SW4(config-ether-cfm-ma)#mip-creation none	Configuring MIP creation permission
SW4(config-ether-cfm-mpls-md-ma)#cc interval 100ms	Configuring CFM interval

Configuring CFM interval
Configuring remote mep
Configuring local mep and mapping the same with vpws ser- vice
Enabling the CFM multicast
Configuring SLR
Commit the candidate configuration to the running configuration.
Exit config mode

SW5#configure terminal	Enter configure mode.
SW5(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW5(config)#vlan database	Entering VLAN database.
SW5(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW5(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW5(config-vlan)#exit	Exit config mode.
SW5(config)#interface xe9	Configure interface ce49.
SW5(config-if)#switchport	Configure the interface as switch port.
SW5(config-if)#bridge-group 1	Configure interface in bridge group 1
SW5(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW5(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.
SW5(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW5(config-if)#exit	Exit config mode.

Commands to initiate/abort loss measurement

SW2#loss-measurement type proactive profile-name <WORD> rmep mac-address <HHHH.HHHH.HHHH>mep <MEPID> domain < DOMAIN NAME>

SW2#abort loss-measurement mep <MEPID> domain <DOMAIN_NAME>

Validation

SW2#loss-measurement type proactive profile-name slm rmep mac-address 3c2c.9926.e683 mep 1 domain 12345

SW2#show ethernet cfm loss-measurement mep 1 domain 12345

```
MEP: 2 MA: 43981
CURRENT:
Measurement ID
                            : 1
                            : False
Suspect
Measurement Type
                            : slm
Elapsed time(sec)
                            : 7
Start Time
                            : 2019 Apr 30 14:43:41
Near End loss
                            : 0
Far End loss
                             : 0
Near End accumulated loss
                            : 0
Far End accumulated loss
                             : 0
```

SW2# abort loss-measurement mep 1 domain 12345



Loss Measurement Message(LMM) over L2 Bridge



Prerequisite

Configure below hardware-profile commands related to CFM in configuration mode and reboot the nodes.

```
hardware-profile filter cfm-domain-name-str enable
hardware-profile statistics cfm-lm enable
hardware-profile statistics cfm-ccm enable
```

SW1#configure terminal	Enter configure mode.
SW1(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW1(config)#vlan database	Entering vlan database

SW1(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW1(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW1(config-vlan)#exit	Exit vlan database
SW1(config)#int ce49	Configure interface ce49.
SW1(config-if)#switchport	Configure the interface as switch port.
SW1(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW1(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW1(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.
SW1(config-if)#commit	Commit the candidate configuration to the running configuration.
SW1(config-if)#exit	Exit config mode.
SW1(config)#ethernet cfm domain-type character-string domain-name mdnam level 7 mip-creation default	Create cfm domain with type as character string and set mip creation criteria to default.
SW1(config-ether-cfm)#service ma-type string ma-name testtm	Create ma type as string and set mip creation criteria to default.
SW1(config-ether-cfm)#vlan 512	Configure primary VLAN ID
SW1(config-ether-cfm-ma)#mip-creation default	Configure MIP creation permission
SW1(config-ether-cfm-ma)#ethernet cfm mep down mpid 2 active true local-vid 512 ce49	Create down mep for local-vid on ce49.
SW1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast.
SW1(config-ether-cfm-ma-mep)#exit-ether-ma- mep-mode	Exit ethernet cfm ma-mep mode.
SW1(config-ether-cfm-ma)#mep crosscheck mpid	Configure crosscheck to remote MEP in VLAN 512.
SW1(config-ether-cfm-ma)#cc interval 10ms	Enable cc interval for 10 millisecond.
SW1(config-ether-cfm-ma)#exit-ether-ma-mode	Exit ethernet ma mode.
SW1(config-ether-cfm)#commit	Commit the candidate configuration to the running configuration.
SW1(config-ether-cfm)#exit	Exit ethernet CFM mode.
SW1(config)# ethernet cfm loss-measurement profile-name LMM	Creating loss-measurement profile for LMM
SW1(config-cfm-lm)# measurement-type lmm	Specify the measurement type
SW1(config-cfm-lm)# measurement-interval 1	Specify the measurement-interval in minutes
SW1(config)# intervals-stored 3	Specify the number of history interval to be stored
SW1(config)# message-period 1s	Specify message period interval time
SW1(config)#commit	Commit the candidate configuration to the running configuration.

SW2#configure terminal	Enter configure mode.
SW2(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW2(config)#vlan database	Entering vlan database
SW2(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW2(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW2(config-vlan)#exit	Exit vlan database
SW2(config)#int ce0	Configure interface ce0.
SW2(config-if)#switchport	Configure the interface as switch port.
SW2(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW2(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW2(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce0.
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit config mode.
SW2(config)#int xe0	Configure interface xe0.
SW2(config-if)#switchport	Configure the interface as switch port.
SW2(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW2(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW2(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe1.
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit config mode.

SW3#configure terminal	Enter configure mode.
SW3(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW3(config)#vlan database	Entering vlan database
SW3(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW3(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW3(config-vlan)#exit	Exit vlan database
SW3(config)#int xe17	Configure interface xe17.
SW3(config-if)#switchport	Configure the interface as switch port.
SW3(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW3(config-if)#switchport mode trunk	Configure interface mode as trunk.

SW3(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe17.
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit config mode.
SW3(config)#int xel	Configure interface xe1.
SW3(config-if)#switchport	Configure the interface as switch port.
SW3(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW3(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW3(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe1.
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit config mode.

SW4#configure terminal	Enter configure mode.
SW4(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW4(config)#vlan database	Entering vlan database
SW4(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW4(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW4(config-vlan)#exit	Exit vlan database
SW4(config)#int xel	Configure interface xe1.
SW4(config-if)#switchport	Configure the interface as switch port.
SW4(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW4(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW4(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe1.
SW4 (config-if) #commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit config mode.
SW4(config)#int xe9	Configure interface xe9.
SW4(config-if)#switchport	Configure the interface as switch port.
SW4(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW4(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW4(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe9.
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit config mode.

SW5#configure terminal	Enter configure mode.
SW5(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW5(config)#vlan database	Entering vlan database
SW5(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW5(config-if)#commit	Commit the candidate configuration to the running configuration.
SW5(config-vlan)#exit	Exit vlan database
SW5(config)#int xe9	Configure interface xe9.
SW5(config-if)#switchport	Configure the interface as switch port.
SW5(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW5(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW5(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe9.
SW5(config-if)#commit	Commit the candidate configuration to the running configuration.
SW5(config-if)#exit	Exit config mode.
SW5(config)#ethernet cfm domain-type character-string domain-name mdnam level 7 mip-creation default	Create cfm domain with type as character string and set mip creation criteria to default.
SW5(config-ether-cfm)#service ma-type string ma-name testtm	Create ma type as string and set mip creation criteria to default.
SW5(config-ether-cfm-ma)#vlan 512 bridge 1	Configure primary VLAN ID
SW5(config-ether-cfm-ma)#mip-creation default	Configure MIP creation permission
SW5(config-ether-cfm-ma)#ethernet cfm mep down mpid 1 active true xe9	Create down mep for local-vid on xe9
SW5(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast.
SW5(config-ether-cfm-ma-mep)#ethernet cfm loss-measurement reply lmm	Generate and send LMR responses tacked
SW5(config-ether-cfm-ma-mep)#exit-ether-ma- mep-mode	Exit ethernet cfm ma-mep mode.
SW5(config-ether-cfm-ma)#mep crosscheck mpid 2	Configure crosscheck to remote MEP in VLAN 512.
SW5(config-ether-cfm-ma)#cc interval 10ms	Enable cc interval for 10 millisecond.
SW5(config-ether-cfm-ma)#exit-ether-ma-mode	Exit ethernet ma mode.
SW5(config-ether-cfm-ma)#commit	Commit the candidate configuration to the running configuration.
SW5(config-ether-cfm)#exit	Exit ethernet CFM mode.

Commands to initiate/abort loss measurement

loss-measurement type on-demand profile-name <WORD> rmep mac-address <HHHH.HHHH.HHHH>
start-time <immediate|relative|absolute> stop-time <none|absolute|relative> repetitionperiod <REP-TIME> mep <MEPID> domain < DOMAIN NAME> ma <MA NAME>

loss-measurement type proactive profile-name <WORD> rmep mac-address <HHHH.HHHH.HHHH>mep <MEPID> domain < DOMAIN NAME> ma <MA NAME>

abort loss-measurement mep <MEPID> domain <DOMAIN NAME> ma <MA NAME>

clear ethernet cfm loss-measurement mep <MEPID> domain <DOMAIN NAME> ma <MA NAME>

Validation

SW1#ping ethernet mac 3c2c.9926.e683 unicast source 2 domain mdnam ma

SW1#traceroute ethernet 3c2c.9926.e683 mepid 2 domain mdnam ma testtmMP MacHops Relay-actionIngress/Egress Ingress/Egress action3c2c.9926.e6831RlyHitIngressIngressIngressIngOK

SW1# loss-measurement type proactive profile-name LMM rmep mac-address 3c2c.9926.e683 mep 2 domain mdnam ma testtm

SW1# show ethernet cfr	n loss-measurement	mep 2	domain	mdnam	ma	testtm
MEP: 2 MA: testtm						
CURRENT:						
Measurement ID	: 1					
Suspect	: False					
Measurement Type	: lmm					
	0.4					

Elapsed time(sec)	: 24
Start Time	: 2019 Jul 21 00:10:3
Near End loss	: 0
Far End loss	: 0
Near End accumulated loss	: 0
Far End accumulated loss	: 0

SW1# abort loss-measurement mep 2 domain mdnam ma testtm

Loss Measurement Message (LMM) Over VPWS



Figure 2-8: CFM Y.1731 LMM over VPWS Topology

SW1#configure terminal	Enter configure mode.
SW1(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW1(config)#vlan database	Entering VLAN database.
SW1(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW1(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW1(config-vlan)#exit	Exit config mode.
SW1(config)#interface ce49	Configure interface ce49.
SW1(config-if)#switchport	Configure the interface as switch port.
SW1(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW1(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW1(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.
SW1(config-if)#commit	Commit the candidate configuration to the running configuration.
SW1(config-if)#exit	Exit config mode.

SW2#configure terminal	Enter configure mode.
SW2(config)#interface ce0	Configure interface ce0.
SW2(config-if)#switchport	Configure interface as a switch port.
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#interface xe0	Configure interface xe0.
SW2(config-if)#no switchport	Configure interface as router port.
SW2(config-if)#ip address 10.0.0.1/24	Assign IP address to router port xe0
SW2(config-if)#no shutdown	Making the interface up
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#interface lo	Configure interface lo
SW2(config-if)#ip address 1.1.1.1/32 secondary	Configure secondary IP address to loopback interface .
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#router ospf 100	Configure ospf
SW2(config-router)#network 10.0.0/24 area	Advertising 10 network

SW2(config-router)#network 1.1.1.1/32 area 0	Advertising loopback IP
SW2(config-router)#commit	Commit the candidate configuration to the running configuration.
SW2(config-router)#exit	Exit router mode.
SW2(config)#router rsvp	Configuring rsvp
SW2(config-router)#hello-receipt	Configuring hello reception
SW2(config-router)#no php	Configuring device as not a PHP
SW2(config-router)#revert-timer 10	Configuring reversion time of RSVP
SW2(config-router)#commit	Commit the candidate configuration to the running configuration.
SW2(config-router)#exit	Exit router mode.
SW2(config)#rsvp-trunk to-1 ipv4	Configuring RSVP path
SW2(config-trunk)#to 2.2.2.2	Configuring first hop
SW2(config-trunk)#to 3.3.3.3	Configuring second hop
SW2(config-trunk)#commit	Commit the candidate configuration to the running configuration.
SW2(config-trunk)#exit	Exit trunk mode.
SW2(config)#interface xe0	Configuring interface
SW2(config-if)#enable-rsvp	Enabling RSVP in interface
SW2(config-if)#label-switching	Enabling MPLS labeling
SW2(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#router ldp	Configuring LDP
SW2(config-router)#targeted-peer ipv4 3.3.3.3	Configuring LDP target peer for PW
SW2(config-router-targeted-peer)#exit- targeted-peer-mode	Exit target peer mode
SW2(config-router)#no multicast-hellos	Disabling LDP multicast
SW2(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW2(config-router)#exit	Exit router mode.
SW2(config)#mpls l2-circuit ETH-2001 1 3.3.3.3	Creating VPWS PW
SW2(config-pseudowire)#commit	Commit the candidate configuration to the running configuration.
SW2(config-pseudowire)#exit	Exit pseudowire config mode.
SW2(config)#service-template ETH-2001	Configuring service template profile for PW
SW2(config-svc)#match outer-vlan 200	Configuring match condition
SW2(config-svc)# rewrite ingress push 2000	Configuring action for match
SW2(config-svc)#commit	Commit the candidate configuration to the running configuration.
SW2(config-svc)#exit	Exit service template mode

SW2(config)#interface ce0	Configuring interface
SW2(config-if)#mpls-l2-circuit ETH-2001 ser- vice-template ETH-2001	Mapping VPWS in AC
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#hardware-profile filter cfm- domain-name-str enable	Enabling HW filter for character string domain name
SW2(config)#ethernet cfm domain-type character-string domain-name 12345 level 7 mip-creation none	Configuring CFM domain over VPWS
SW2(config-ether-cfm-mpls-md)#service ma- type string ma-name 43981 mip-creation none	Creating MA for domain
SW2(config-ether-cfm-mpls-md-ma)#cc interval 100ms	Configuring CFM interval
SW2(config-ether-cfm-mpls-md-ma)#mep cross- check mpid 1	Configuring remote mep
SW2(config-ether-cfm-mpls-md-ma)#ethernet cfm mep up mpid 4001 active true vpws ETH- 2001	Configuring local mep and mapping the same with vpws ser- vice
SW2(config-ether-cfm-mpls-ma-mep)#cc mul- ticast state enable	Enabling the CFM multicast
SW2(config-ether-cfm-mpls-ma-mep)#commit	Commit the candidate configuration to the running configuration.
SW2(config-ether-cfm-mpls-ma-mep)#exit	Exit CFM MEP configuration mode
SW2(config-ether-cfm-mpls-md-ma)#exit	Exit CFM MA configuration mode
SW2(config-ether-cfm-mpls-md)#exit	End current mode and down to previous mode
SW2(config)#ethernet cfm loss-measurement profile-name lmm	Configuring LM profile
SW2(config-cfm-lm)#measurement-type lmm	Configuring measurement type as LMM
SW2(config-cfm-lm)#message-period 3	Configuring message period
SW2(config-cfm-lm)#measurement-interval 1	Configuring measurement interval
SW2(config-cfm-lm)#intervals-stored 3	Configuring number of interval to be stored
SW2(config-cfm-lm)#commit	Commit the candidate configuration to the running configuration.
SW2(config-cfm-lm)#end	Exit config mode

SW3#configure terminal	Enter configure mode.
SW3(config)#interface xe17	Configure interface
SW3(config-if)#no switchport	Configure interface as router port.
SW3(config-if)#ip address 20.0.0.1/24	Assign IP address to router port
SW3(config-if)#no shutdown	Making the interface up
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.

SW3(config)#interface xel	Configure interface
SW3(config-if)#no switchport	Configure interface as router port.
SW3(config-if)#ip address 10.0.0.2/24	Assign IP address to router port
SW3(config-if)#no shutdown	Making the interface up
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#interface lo	Configure interface lo
SW3(config-if)#ip address 2.2.2.2/32 secondary	Configure secondary IP address to loopback interface.
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#router ospf 100	Configure ospf
SW3(config-router)#network 10.0.0/24 area 0	Advertising 10 network
SW3(config-router)#network 20.0.0/24 area 0	Advertising 10 network
SW3(config-router)#network 2.2.2.2/32 area 0	Advertising loopback IP
SW3(config-router)#commit	Commit the candidate configuration to the running configuration.
SW3(config-router)#exit	Exit router mode.
SW3(config)#router rsvp	Configuring rsvp
SW3(config-router)#hello-receipt	Configuring hello reception
SW3(config-router)#no php	Configuring device as not a PHP
SW3(config-router)#revert-timer 10	Configuring reversion time of RSVP
SW3(config-router)#commit	Commit the candidate configuration to the running configuration.
SW3(config-router)#exit	Exit router mode.
SW3(config)#interface xel	Configuring interface
SW3(config-if)#enable-rsvp	Enabling RSVP in interface
SW3(config-if)#label-switching	Enabling MPLS labeling
SW3(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#interface xe17	Configuring interface
SW3(config-if)#enable-rsvp	Enabling RSVP in interface
SW3(config-if)#label-switching	Enabling MPLS labeling
SW3(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.

SW4#configure terminal	Enter configure mode.
SW4(config)#interface xe9	Configure interface
SW4(config-if)#switchport	Configure interface as switch port.
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#interface xel	Configure interface
SW4(config-if)#no switchport	Configure interface as router port.
SW4(config-if)#ip address 20.0.0.2/24	Assign IP address to router port
SW4(config-if)#no shutdown	Making the interface up
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#interface lo	Configure interface lo
SW4(config-if)#ip address 3.3.3.3/32 secondary	Configure secondary IP address to loopback interface .
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#router ospf 100	Configure ospf
SW4(config-router)#network 20.0.0/24 area 0	Advertising 10 network
SW4(config-router)#network 3.3.3.3/32 area 0	Advertising loopback IP
SW4(config-router)#commit	Commit the candidate configuration to the running configuration.
SW4(config-router)#exit	Exit router mode.
SW4(config)#router rsvp	Configuring rsvp
SW4(config-router)#hello-receipt	Configuring hello reception
SW4(config-router)#no php	Configuring device as not a PHP
SW4(config-router)#revert-timer 10	Configuring reversion time of RSVP
SW4(config-router)#exit	Exit router mode.
SW4(config)#rsvp-trunk to-1 ipv4	Configuring RSVP path
SW4(config-trunk)#to 2.2.2.2	Configuring first hop
SW4(config-trunk)#to 1.1.1.1	Configuring second hop
SW4(config-trunk)#commit	Commit the candidate configuration to the running configuration.
SW4(config-trunk)#exit	Exit trunk mode.
SW4(config)#interface xel	Configuring interface
SW4(config-if)#enable-rsvp	Enabling RSVP in interface
SW4(config-if)#label-switching	Enabling MPLS labeling
SW4(config-if)#enable-ldp ipv4	Enabling ldp on interface

SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#router ldp	Configuring LDP
SW4(config-router)#targeted-peer ipv4 1.1.1.1	Configuring LDP target peer for PW
SW4(config-router-targeted-peer)#exit- targeted-peer-mode	Exit target peer mode
SW4(config-router)#no multicast-hellos	Disabling LDP multicast
SW4(config-router)#commit	Commit the candidate configuration to the running configuration.
SW4(config-router)#exit	Exit router mode.
SW4(config)#mpls l2-circuit ETH-2001 1 1.1.1.1	Creating VPWS PW
SW4(config-pseudowire)#commit	Commit the candidate configuration to the running configuration.
SW4(config-pseudowire)#exit	Exit pseudowire config mode.
SW4(config)#service-template ETH-2001	Configuring service template profile for PW
SW4(config-svc)# match outer-vlan 200	Configuring match condition
SW4(config-svc)# rewrite ingress push 2000	Configuring action for match
SW4(config-svc)#commit	Commit the candidate configuration to the running configuration.
SW4(config-svc)#exit	Exit service template mode
SW4(config)#interface xe9	Configuring interface
SW4(config-if)#mpls-l2-circuit ETH-2001 ser- vice-template ETH-2001	Mapping VPWS in AC
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#hardware-profile filter cfm- domain-name-str enable	Enabling HW filter for character string domain name
SW4(config)#ethernet cfm domain-type charac- ter-string domain-name 12345 level 7 mip- creation none	Configuring CFM domain over VPWS
SW4(config-ether-cfm-mpls-md)#service ma- type string ma-name 43981	Creating MA for domain
SW4(config-ether-cfm-ma)#mip-creation none	Configuring MIP creation permission
SW4(config-ether-cfm-mpls-md-ma)#cc interval 100ms	Configuring CFM interval
SW4(config-ether-cfm-mpls-md-ma)#mep cross- check mpid 4001	Configuring remote mep
SW4(config-ether-cfm-mpls-md-ma)#ethernet cfm mep up mpid 1 active true vpws ETH-2001	Configuring local mep and mapping the same with vpws ser- vice
SW4(config-ether-cfm-mpls-ma-mep)#cc mul- ticast state enable	Enabling the CFM multicast
SW4(config-ether-cfm-mpls-ma-mep)#ethernet cfm loss-measurement reply lmm	Configuring LMR

SW4(config-ether-cfm-mpls-ma-mep)#commit	Commit the candidate configuration to the running configuration.
SW4(config-ether-cfm-mpls-ma-mep)#end	Exit config mode

SW5#configure terminal	Enter configure mode.
SW5(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW5(config)#vlan database	Entering VLAN database.
SW5(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW5(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW5(config-vlan)#exit	Exit config mode.
SW5(config)#interface xe9	Configure interface ce49.
SW5(config-if)#switchport	Configure the interface as switch port.
SW5(config-if)#bridge-group 1	Configure interface in bridge group 1
SW5(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW5(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.
SW5(config-if)#commit	Commit the candidate configuration to the running configuration.
SW5(config-if)#exit	Exit config mode.

Commands to initiate/abort loss measurement

SW2#loss-measurement type proactive profile-name <WORD> rmep mac-address <HHHH.HHHH.HHHH>mep <MEPID> domain < DOMAIN NAME>

SW2#abort loss-measurement mep <MEPID> domain <DOMAIN NAME>

Validation

SW2#loss-measurement type proactive profile-name lmm rmep mac-address 3c2c.9926.e683 mep 1 domain 12345

SW2#show ethernet cfm loss-me	asurement mep 1 domain 12345
MEP: 2 MA: 43981	
CURRENT:	
Measurement ID	: 1
Suspect	: False
Measurement Type	: lmm
Elapsed time(sec)	: 7
Start Time	: 2019 Apr 30 14:43:41
Near End loss	: 0
Far End loss	: 0
Near End accumulatedloss	: 0

```
Far End accumulated loss : 0
SW2# abort loss-measurement mep 1 domain 12345
```

Delay Measurement (DM) over L2 Bridge





Prerequisite

Configure below hardware-profile commands related to CFM in configuration mode and reboot the nodes.

```
hardware-profile filter cfm-domain-name-str enable
hardware-profile statistics ingress-acl enable
hardware-profile statistics cfm-lm enable
hardware-profile statistics cfm-ccm enable
```

SW1#configure terminal	Enter configure mode.
SW1(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW1(config)#vlan database	Entering vlan database
SW1(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW1(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW1(config-vlan)#exit	Exit vlan database
SW1(config)#int ce49	Configure interface ce49.
SW1(config-if)#switchport	Configure the interface as switch port.
SW1(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW1(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW1(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.

SW1(config-if)#commit	Commit the candidate configuration to the running configuration.
SW1(config-if)#exit	Exit config mode.
SW1(config)#ethernet cfm domain-type character-string domain-name mdnam level 7 mip-creation default	Create cfm domain with type as character string and set mip creation criteria to default.
SW1(config-ether-cfm)#service ma-type string ma-name testtm	Create ma type as string and set mip creation criteria to default.
SW1(config-ether-cfm-ma)#vlan 512 bridge 1	Configure primary VLAN ID
SW1(config-ether-cfm-ma)#mip-creation default	Configure MIP creation permission
SW1(config-ether-cfm-ma)#ethernet cfm mep down mpid 2 active true ce49	Create down mep for local-vid on ce49.
SW1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast.
SW1(config-ether-cfm-ma-mep)#exit-ether-ma- mep-mode	Exit ethernet cfm ma-mep mode.
SW1(config-ether-cfm-ma)#mep crosscheck mpid 1	Configure crosscheck to remote MEP in VLAN 512.
SW1(config-ether-cfm-ma)#cc interval 10ms	Enable cc interval for 10 millisecond.
SW1(config-ether-cfm-ma)#exit-ether-ma-mode	Exit ethernet ma mode.
SW1(config-ether-cfm)#commit	Commit the candidate configuration to the running configuration.
SW1(config-ether-cfm)#exit	Exit ethernet CFM mode.
SW1(config)# ethernet cfm delay-measurement profile-name DM	Creating loss-measurement profile for DM
SW1(config-cfm-dm)# measurement-interval 1	Specify the measurement-interval in minutes
SW1(config-cfm-dm)# intervals-stored 3	Specify the number of history interval to be stored
SW1(config-cfm-dm)# message-period 1s	Specify message period interval time
SW1(config-cfm-dm)# bins-per-fd-interval 4	Specify the number of measurement bins per Measurement Interval for Frame Delay measurements.
SW1(config-cfm-dm) # bins-per-ifdv-interval 3	Specify the number of measurement bins per Measurement Interval for Inter-Frame Delay Variation measurements.
SW1(config-cfm-dm)#commit	Commit the candidate configuration to the running configuration.

SW2#configure terminal	Enter configure mode.
SW2(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW2(config)#vlan database	Entering vlan database
SW2(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW2(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW2(config-vlan)#exit	Exit vlan database
SW2(config)#int ce0	Configure interface ce0.

SW2(config-if)#switchport	Configure the interface as switch port.
SW2(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW2(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW2(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce0.
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit config mode.
SW2(config)#int xe0	Configure interface xe0.
SW2(config-if)#switchport	Configure the interface as switch port.
SW2(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW2(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW2(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe1.
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit config mode.

SW3#configure terminal	Enter configure mode.
SW3(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW3(config)#vlan database	Entering vlan database
SW3(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW3(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW3(config-vlan)#exit	Exit vlan database
SW3(config)#int xe17	Configure interface xe17.
SW3(config-if)#switchport	Configure the interface as switch port.
SW3(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW3(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW3(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe17.
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit config mode.
SW3(config)#int xel	Configure interface xe1.
SW3(config-if)#switchport	Configure the interface as switch port.
SW3(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW3(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW3(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe1.

SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit config mode.

SW4#configure terminal	Enter configure mode.
SW4(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW4(config)#vlan database	Entering vlan database
SW4(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW4(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW4(config-vlan)#exit	Exit vlan database
SW4(config)#int xel	Configure interface xe1.
SW4(config-if)#switchport	Configure the interface as switch port.
SW4(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW4(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW4(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe1.
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit config mode.
SW4(config)#int xe9	Configure interface xe9.
SW4(config-if)#switchport	Configure the interface as switch port.
SW4(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW4(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW4(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe9.
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit config mode.

SW5#configure terminal	Enter configure mode.
SW5(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW5(config)#vlan database	Entering vlan database
SW5(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW5(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW5(config-vlan)#exit	Exit vlan database
SW5(config)#int xe9	Configure interface xe9.

SW5(config-if)#switchport	Configure the interface as switch port.
SW5(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW5(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW5(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface xe9.
SW5(config-if)#commit	Commit the candidate configuration to the running configuration.
SW5(config-if)#exit	Exit config mode.
SW5(config)#ethernet cfm domain-type character-string domain-name mdnam level 7 mip-creation default	Create cfm domain with type as character string and set mip creation criteria to default.
SW5(config-ether-cfm)#service ma-type string ma-name testtm	Create ma type as string and set mip creation criteria to default.
SW5(config-ether-cfm)#vlan 512 bridge 1	Configure primary VLAN ID
SW5(config-ether-cfm-ma)#mip-creation default	Configure MIP creation permission
SW5(config-ether-cfm-ma)#ethernet cfm mep down mpid 1 active true xe9	Create down mep for local-vid on xe9
SW5(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast.
SW5(config-ether-cfm-ma-mep)# ethernet cfm delay-measurement reply dmm	Generate and send DMM responses tacked
SW5(config-ether-cfm-ma-mep)#exit-ether-ma- mep-mode	Exit ethernet cfm ma-mep mode.
SW5(config-ether-cfm-ma)#mep crosscheck mpid 2	Configure crosscheck to remote MEP in VLAN 512.
SW5(config-ether-cfm-ma)#cc interval 10ms	Enable cc interval for 10 millisecond.
SW5(config-ether-cfm-ma)#exit-ether-ma-mode	Exit ethernet ma mode.
SW5(config-ether-cfm)#commit	Commit the candidate configuration to the running configuration.
SW5(config-ether-cfm)#exit	Exit ethernet CFM mode.

Commands to initiate/abort on-demand delay measurement

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|RMEPID) starttime (immediate|relative HH:MM:SS|absolute HH:MM:SS <1-31> MONTH <1993-2035>) repetition-period <6000-4294967295> mep MEPID domain DOMAIN_NAME ma <MA_NAME>

abort delay-measurement mep <MEPID> domain <DOMAIN NAME> ma <MA NAME>

Validation

SW1#ping ethernet mac 3c2c.9926.e683 unicast source 2 domain mdnam ma

```
SW1#traceroute ethernet 3c2c.9926.e683 mepid 2 domain mdnam ma testtmMP MacHops Relay-actionIngress/Egress Ingress/Egress action3c2c.9926.e6831RlyHitIngressIngressIngressIngOK
```

SW1# delay-measurement type proactive profile-name DM rmep mac-address 3c2c.9926.e683 mep 2 domain mdnam ma testtm SW1#show ethernet cfm delay-measurement mep 2 domain mdnam ma testtm MEP : 2 MA : testtm VLAN ID : 512 Peer MAC Address : 3c2c.9926.e683 CURRENT: _____ RMEP ID : 1 Measurement ID : 12 Measurement Type : DMM Elapsed time(sec) : 24 Start Time : 2019 Aug 06 13:23:53 Suspect Flag : FALSE Min Frame Delay(usec) : 13 Max Frame Delay(usec) : 13 : 13 Avg Frame Delay(usec) Min Inter FD Variation(usec): 0 Max Inter FD Variation(usec): 0 Avg Inter FD Variation(usec): 0 FRAME DELAY BINS Bin Number Bin Threshold(usec) Bin Counter _____ - < 4999 1 0 3 5000 - < 9999 2 0 3 10000 - < 149990 4 15000 - < Inf 0 INTER-FRAME DELAY BINS Bin Number Bin Threshold(usec) Bin Counter _____ - < 1 0 4999 2 2 5000 - < 9999 0 10000 - < Inf 3 0 HISTORY STATISTICS _____ : mdnam MD : testtm MA MEP : 2 : 512 VLAN ID RMEP ID : 1 Measurement ID : 10 Measurement Type : DMM Elapsed time(sec) : 60

: 2019 Aug 06 13:22:52

End Time

Suspect Flag	: FALSE
Min Frame Delay(usec)	: 13
Max Frame Delay(usec)	: 13
Avg Frame Delay(usec)	: 13
Min Inter FD Variation(used	c): 0
Max Inter FD Variation (used	z) : 0
Ava Inter ED Variation (used	\mathbf{x}
nvg inter ib variation(uset	
דס אנזיים הפואע פוא	18
FRAME DELAI DI	NS R(usee) Din Counter
1 0 - <	1999 6
	4999 0
2 5000 - <	9999 0
3 10000 - <	14999 0
4 15000 - <	Int U
INTER-FRAME DELAY	(BINS
Bin Number Bin Threshold	d(usec) Bin Counter
1 ^ -	4000 5
	4999 5
2 5000 - <	9999 0
3 10000 - <	Inf O
RMEP ID : 1	
Measurement ID : 11	
Maaannaman 🖌 🔟 maaa	
Measurement Type	: DMM
Elapsed time(sec)	: DMM : 60
Elapsed time(sec) End Time	: DMM : 60 : 2019 Aug 06 13:23:52
Measurement Type Elapsed time(sec) End Time Suspect Flag	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec)	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec)	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec)	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter FD Variation(usec)	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 c): 0
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter FD Variation(used Max Inter FD Variation(used	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 :): 0 c): 0
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter FD Variation(usec) Max Inter FD Variation(usec) Avg Inter FD Variation(usec)	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 :): 0 c): 0 c): 0 c): 0
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter FD Variation(usec Avg Inter FD Variation(usec	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 : 13 : 0 :): 0 :): 0 :): 0
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter FD Variation(used Avg Inter FD Variation(used FRAME DELAY BIN	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 :): 0 :): 0 :): 0 :): 0 :): 0
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter FD Variation(usec Max Inter FD Variation(usec Avg Inter FD Variation(usec FRAME DELAY BIN Bin Number Bin Threshold	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 :): 0 c): 0 c): 0 NS d(usec) Bin Counter
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter FD Variation(usec Max Inter FD Variation(usec Avg Inter FD Variation(usec FRAME DELAY BIN Bin Number Bin Threshold	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 :): 0 c): 0 c): 0 S d(usec) Bin Counter
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter FD Variation(usec) Max Inter FD Variation(usec) Avg Inter FD Variation(usec) FRAME DELAY BIN Bin Number Bin Threshold 1 0 - <	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 :): 0 :): 0 :
Measurement TypeElapsed time (sec)End TimeSuspect FlagMin Frame Delay(usec)Max Frame Delay(usec)Avg Frame Delay(usec)Min Inter FD Variation(usec)Max Inter FD Variation(usec)Avg Inter FD Variation(usec)FRAME DELAY BINBin NumberBin Thresholo1025000	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 : 13 :): 0 :): 0 :): 0 :): 0 :S d(usec) Bin Counter
Measurement TypeElapsed time(sec)End TimeSuspect FlagMin Frame Delay(usec)Max Frame Delay(usec)Avg Frame Delay(usec)Min Inter FD Variation(usec)Max Inter FD Variation(usec)Avg Inter FD Variation(usec)FRAME DELAY BINBin NumberBin Threshold10250003	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 :): 0 c): 0 c): 0 NS d(usec) Bin Counter 4999 6 9999 0 14999 0
Measurement TypeElapsed time(sec)End TimeSuspect FlagMin Frame Delay(usec)Max Frame Delay(usec)Avg Frame Delay(usec)Min Inter FD Variation(usec)Max Inter FD Variation(usec)Avg Inter FD Variation(usec)FRAME DELAY BINBin NumberBin Threshold10250003100004	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 : 13 : 13 : 0 : 0 : 0 : 0 : 0 : 0 : 0 : 0
Measurement TypeElapsed time(sec)End TimeSuspect FlagMin Frame Delay(usec)Max Frame Delay(usec)Avg Frame Delay(usec)Min Inter FD Variation(usec)Max Inter FD Variation(usec)Avg Inter FD Variation(usec)FRAME DELAY BINBin NumberBin Threshold10250003100004	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 : 13 : 13 : 0 : 0 : 0 : 0 : 0 : 0 : 0 : 0
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter FD Variation(usec) Max Inter FD Variation(usec) Avg Inter FD Variation(usec) FRAME DELAY BIN Bin Number Bin Threshold 1 0 2 5000 3 10000 4 15000 INTER-FRAME DELAY	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 : 13 :): 0 2): 0 S d(usec) Bin Counter 4999 6 9999 0 14999 0 Inf 0 Z BINS
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter FD Variation(usec) Max Inter FD Variation(usec) Avg Inter FD Variation(usec) FRAME DELAY BIN Bin Number Bin Threshold 2 5000 - <	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 :): 0 c): 0 c): 0 S d(usec) Bin Counter 4999 6 9999 0 14999 0 Inf 0 S d(usec) Bin Counter
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter FD Variation(usec) Max Inter FD Variation(usec) Avg Inter FD Variation(usec) FRAME DELAY BIN Bin Number Bin Threshold 1 0 2 5000 3 10000 4 15000 INTER-FRAME DELAY Bin Number Bin Threshold	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 : 13 : 13 : 0 : 0 : 0 : 0 : 0 : 0 : 0 : 0
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter FD Variation(usec) Max Inter FD Variation(usec) Avg Inter FD Variation(usec) FRAME DELAY BIN Bin Number Bin Threshold ====================================	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 : 13 : 13 : 13 : 13 :): 0 2): 0 2): 0 S d(usec) Bin Counter 4999 6 9999 0 14999 0 Inf 0 S d(usec) Bin Counter 4999 5
Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter FD Variation(usec) Max Inter FD Variation(usec) Avg Inter FD Variation(usec) Avg Inter FD Variation(usec) Bin Number Bin Threshold 1 0 2 5000 3 10000 4 15000 1 0 1 0 2 5000	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 : 13 : 13 : 0 : 0 : 0 : 0 : 0 : 0 : 0 : 0
Measurement TypeElapsed time (sec)End TimeSuspect FlagMin Frame Delay(usec)Max Frame Delay(usec)Avg Frame Delay(usec)Min Inter FD Variation(usec)Max Inter FD Variation(usec)Avg Inter FD Variation(usec)Avg Inter FD Variation(usec)Bin NumberBin Threshold10250003100004150001025000310000450001025000310000	: DMM : 60 : 2019 Aug 06 13:23:52 : FALSE : 13 : 13 : 13 : 13 :): 0 2): 0 S d(usec) Bin Counter 4999 6 9999 0 14999 0 Inf 0 S d(usec) Bin Counter 4999 6 9999 0 Inf 0 S d(usec) Bin Counter

SW1# abort delay-measurement mep 2 domain mdnam ma testtm

Delay Measurement Message (DMM) Over VPWS



Figure 2-10: CFM Y.1731 DMM over VPWS Topology

SW1

SW1#configure terminal	Enter configure mode.
SW1(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW1(config)#vlan database	Entering VLAN database.
SW1(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW1(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW1(config-vlan)#exit	Exit config mode.
SW1(config)#interface ce49	Configure interface ce49.
SW1(config-if)#switchport	Configure the interface as switch port.
SW1(config-if)#bridge-group 1	Configure interface in bridge group 1.
SW1(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW1(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.
SW1(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW1(config-if)#exit	Exit config mode.

SW2#configure terminal	Enter configure mode.
SW2(config)#interface ce0	Configure interface ce0.
SW2(config-if)#switchport	Configure interface as a switch port.
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#interface xe0	Configure interface xe0.
SW2(config-if)#no switchport	Configure interface as router port.
SW2(config-if)#ip address 10.0.0.1/24	Assign IP address to router port xe0
SW2(config-if)#no shutdown	Making the interface up

SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#interface lo	Configure interface lo
SW2(config-if)#ip address 1.1.1.1/32 secondary	Configure secondary IP address to loopback interface.
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#router ospf 100	Configure ospf
SW2(config-router)#network 10.0.0/24 area 0	Advertising 10 network
SW2(config-router)#network 1.1.1.1/32 area 0	Advertising loopback IP
SW2(config-router)#commit	Commit the candidate configuration to the running configuration.
SW2(config-router)#exit	Exit router mode.
SW2(config)#router rsvp	Configuring rsvp
SW2(config-router)#hello-receipt	Configuring hello reception
SW2(config-router)#no php	Configuring device as not a PHP
SW2(config-router)#revert-timer 10	Configuring reversion time of RSVP
SW2(config-router)#commit	Commit the candidate configuration to the running configuration.
SW2(config-router)#exit	Exit router mode.
SW2(config)#rsvp-trunk to-1 ipv4	Configuring RSVP path
SW2(config-trunk)#to 2.2.2.2	Configuring first hop
SW2(config-trunk)#to 3.3.3.3	Configuring second hop
SW2(config-trunk)#commit	Commit the candidate configuration to the running configuration.
SW2(config-trunk)#exit	Exit trunk mode.
SW2(config)#interface xe0	Configuring interface
SW2(config-if)#enable-rsvp	Enabling RSVP in interface
SW2(config-if)#label-switching	Enabling MPLS labeling
SW2(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#router ldp	Configuring LDP
SW2(config-router)#targeted-peer ipv4 3.3.3.3	Configuring LDP target peer for PW
SW2(config-router-targeted-peer)#exit- targeted-peer-mode	Exit target peer mode
SW2(config-router)#no multicast-hellos	Disabling LDP multicast
SW2(config-router)#commit	Commit the candidate configuration to the running configuration.
SW2(config-router)#exit	Exit router mode.

SW2(config)#mpls l2-circuit ETH-2001 1 3.3.3.3	Creating VPWS PW
SW2(config-pseudowire)#commit	Commit the candidate configuration to the running configuration.
SW2(config-pseudowire)#exit	Exit pseudowire config mode.
SW2(config)#service-template ETH-2001	Configuring service template profile for PW
SW2(config-svc)#match outer-vlan 200	Configuring match condition
SW2(config-svc)# rewrite ingress push 2000	Configuring action for match
SW2(config-svc)#commit	Commit the candidate configuration to the running configuration.
SW2(config-svc)#exit	Exit service template mode
SW2(config)#interface ce0	Configuring interface
SW2(config-if)#mpls-l2-circuit ETH-2001 ser- vice-template ETH-2001	Mapping VPWS in AC
SW2(config-if)#commit	Commit the candidate configuration to the running configuration.
SW2(config-if)#exit	Exit interface mode.
SW2(config)#hardware-profile filter cfm- domain-name-str enable	Enabling HW filter for character string domain name
SW2(config)#ethernet cfm domain-type character-string domain-name 12345 level 7 mip-creation none	Configuring CFM domain over VPWS
SW2(config-ether-cfm-mpls-md)#service ma- type string ma-name 43981 mip-creation none	Creating MA for domain
SW2(config-ether-cfm-mpls-md-ma)#cc interval 100ms	Configuring CFM interval
SW2(config-ether-cfm-mpls-md-ma)#mep cross- check mpid 1	Configuring remote mep
SW2(config-ether-cfm-mpls-md-ma)#ethernet cfm mep up mpid 4001 active true vpws ETH- 2001	Configuring local mep and mapping the same with vpws ser- vice
SW2(config-ether-cfm-mpls-ma-mep)#cc mul- ticast state enable	Enabling the CFM multicast
SW2(config-ether-cfm-mpls-ma-mep)#commit	Commit the candidate configuration to the running configuration.
SW2(config-ether-cfm-mpls-ma-mep)#exit	Exit CFM MEP configuration mode
SW2(config-ether-cfm-mpls-md-ma)#exit	Exit CFM MA configuration mode
SW2(config-ether-cfm-mpls-md)#exit	End current mode and down to previous mode
SW2(config)#ethernet cfm delay-measurement profile-name DM	Configuring DM profile
SW2(config-cfm-dm)#measurement interval	Configuring measurement interval
SW2(config-cfm-dm)#intervals-stored 3	Configuring the number of history interval to be stored
SW2(config-cfm-dm)# message-period 1s	Configuring message period interval time
SW2(config-cfm-dm)# bins-per-fd-interval 4	Configuring the number of measurement bins per Meas- urement Interval for Frame Delay measurements.
SW2(config-cfm-dm) # bins-per-ifdv-interval 3	Configuring the number of measurement bins per Meas- urement Interval for Inter-Frame Delay Variation measure- ments.

SW2(config-cfm-dm)#commit	Commit the candidate configuration to the running configuration.
SW2(config-cfm-dm)#end	Exit config mode

SW3#configure terminal	Enter configure mode.
SW3(config)#interface xe17	Configure interface
SW3(config-if)#no switchport	Configure interface as router port.
SW3(config-if)#ip address 20.0.0.1/24	Assign IP address to router port
SW3(config-if)#no shutdown	Making the interface up
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#interface xel	Configure interface
SW3(config-if)#no switchport	Configure interface as router port.
SW3(config-if)#ip address 10.0.0.2/24	Assign IP address to router port
SW3(config-if)#no shutdown	Making the interface up
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#interface lo	Configure interface lo
SW3(config-if)#ip address 2.2.2.2/32 secondary	Configure secondary IP address to loopback interface .
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#router ospf 100	Configure ospf
SW3(config-router)#network 10.0.0/24 area 0	Advertising 10 network
SW3(config-router)#network 20.0.0.0/24 area 0	Advertising 10 network
SW3(config-router)#network 2.2.2.2/32 area 0	Advertising loopback IP
SW3(config-router)#exit	Exit router mode.
SW3(config)#router rsvp	Configuring rsvp
SW3(config-router)#hello-receipt	Configuring hello reception
SW3(config-router)#no php	Configuring device as not a PHP
SW3(config-router)#revert-timer 10	Configuring reversion time of RSVP
SW3(config-router)#commit	Commit the candidate configuration to the running configuration.
SW3(config-router)#exit	Exit router mode.
SW3(config)#interface xel	Configuring interface
SW3(config-if)#enable-rsvp	Enabling RSVP in interface
SW3(config-if)#label-switching	Enabling MPLS labeling

SW3(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.
SW3(config)#interface xe17	Configuring interface
SW3(config-if)#enable-rsvp	Enabling RSVP in interface
SW3(config-if)#label-switching	Enabling MPLS labeling
SW3(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW3(config-if)#commit	Commit the candidate configuration to the running configuration.
SW3(config-if)#exit	Exit interface mode.

SW4#configure terminal	Enter configure mode.
SW4(config)#interface xe9	Configure interface
SW4(config-if)#switchport	Configure interface as switch port.
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#interface xel	Configure interface
SW4(config-if)#no switchport	Configure interface as router port.
SW4(config-if)#ip address 20.0.0.2/24	Assign IP address to router port
SW4(config-if)#no shutdown	Making the interface up
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#interface lo	Configure interface lo
SW4(config-if)#ip address 3.3.3.3/32 secondary	Configure secondary IP address to loopback interface .
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#router ospf 100	Configure ospf
SW4(config-router)#network 20.0.0.0/24 area 0	Advertising 10 network
SW4(config-router)#network 3.3.3.3/32 area 0	Advertising loopback IP
SW4(config-router)#commit	Commit the candidate configuration to the running configuration.
SW4(config-router)#exit	Exit router mode.
SW4(config)#router rsvp	Configuring rsvp
SW4(config-router)#hello-receipt	Configuring hello reception
SW4(config-router)#no php	Configuring device as not a PHP
SW4(config-router)#revert-timer 10	Configuring reversion time of RSVP

SW4(config-router)#exit	Exit router mode.
SW4(config)#rsvp-trunk to-1 ipv4	Configuring RSVP path
SW4(config-trunk)#to 2.2.2.2	Configuring first hop
SW4(config-trunk)#to 1.1.1.1	Configuring second hop
SW4(config-trunk)#commit	Commit the candidate configuration to the running configuration.
SW4(config-trunk)#exit	Exit trunk mode.
SW4(config)#interface xel	Configuring interface
SW4(config-if)#enable-rsvp	Enabling RSVP in interface
SW4(config-if)#label-switching	Enabling MPLS labeling
SW4(config-if)#enable-ldp ipv4	Enabling ldp on interface
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#router ldp	Configuring LDP
SW4(config-router)#targeted-peer ipv4 1.1.1.1	Configuring LDP target peer for PW
SW4(config-router-targeted-peer)#exit- targeted-peer-mode	Exit target peer mode
SW4(config-router)#no multicast-hellos	Disabling LDP multicast
SW4(config-router)#commit	Commit the candidate configuration to the running configuration.
SW4(config-router)#exit	Exit router mode.
SW4(config)#mpls l2-circuit ETH-2001 1 1.1.1.1	Creating VPWS PW
SW4(config-pseudowire)#commit	Commit the candidate configuration to the running configuration.
SW4(config-pseudowire)#exit	Exit pseudowire config mode.
SW4(config)#service-template ETH-2001	Configuring service template profile for PW
SW4(config-svc)# match outer-vlan 200	Configuring match condition
SW4(config-svc)# rewrite ingress push 2000	Configuring action for match
SW4(config-svc)#commit	Commit the candidate configuration to the running configuration.
SW4(config-svc)#exit	Exit service template mode
SW4(config)#interface xe9	Configuring interface
SW4(config-if)#mpls-l2-circuit ETH-2001 ser- vice-template ETH-2001	Mapping VPWS in AC
SW4(config-if)#commit	Commit the candidate configuration to the running configuration.
SW4(config-if)#exit	Exit interface mode.
SW4(config)#hardware-profile filter cfm- domain-name-str enable	Enabling HW filter for character string domain name
SW4(config)#ethernet cfm domain-type charac- ter-string domain-name 12345 level 7 mip- creation none	Configuring CFM domain over VPWS

SW4(config-ether-cfm-mpls-md)#service ma- type string ma-name 43981	Creating MA for domain
SW4(config-ether-cfm-ma)#mip-creation none	Configuring MIP creation permission
SW4(config-ether-cfm-mpls-md-ma)#cc interval 100ms	Configuring CFM interval
SW4(config-ether-cfm-mpls-md-ma)#mep cross- check mpid 4001	Configuring remote mep
SW4(config-ether-cfm-mpls-md-ma)#ethernet cfm mep up mpid 1 active true vpws ETH-2001	Configuring local mep and mapping the same with vpws ser- vice
SW4(config-ether-cfm-mpls-ma-mep)#cc mul- ticast state enable	Enabling the CFM multicast
SW4(config-ether-cfm-mpls-ma-mep)#ethernet cfm delay-measurement reply dmm	Configuring DMR
SW4(config-ether-cfm-mpls-ma-mep)#commit	Commit the candidate configuration to the running configuration.
SW4(config-ether-cfm-mpls-ma-mep)#end	Exit config mode

SW5#configure terminal	Enter configure mode.
SW5(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
SW5(config)#vlan database	Entering VLAN database.
SW5(config-vlan)#vlan 512 bridge 1 state enable	Create VLAN 512 on bridge 1.
SW5(config-vlan)#commit	Commit the candidate configuration to the running configuration.
SW5(config-vlan)#exit	Exit config mode.
SW5(config)#interface xe9	Configure interface ce49.
SW5(config-if)#switchport	Configure the interface as switch port.
SW5(config-if)#bridge-group 1	Configure interface in bridge group 1
SW5(config-if)#switchport mode trunk	Configure interface mode as trunk.
SW5(config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.
SW5(config-if)#commit	Commit the candidate configuration to the running configuration.
SW5(config-if)#exit	Exit config mode.

Commands to initiate/abort delay measurement

delay-measurement type proactive profile-name WORD rmep (mac-address MAC|mep-id MEPID)
mep MEPID domain DOMAIN_NAME ma <MA_NAME>

abort delay-measurement mep MEPID domain DOMAIN_NAME ma <MA_NAME>

Validation

```
SW2# delay-measurement type proactive profile-name DM rmep mac-address 3c2c.9926.e683
mep 200 domain 12345
SW2# show ethernet cfm delay-measurement mep 200 domain 12345
MD : 12345
MA : 43981
MEP : 200
VLAN ID : 0
VC Name : ETH-2001
Peer MAC Address : b86a.97d2.27d0
CURRENT:
_____
RMEP ID
                        : 100
                        : 3
Measurement ID
                        : DMM
Measurement Type
Elapsed time(sec)
                        : 25
Start Time
                        : 2019 Nov 06 10:57:33
Suspect Flag
                           : TRUE
Min Frame Delay(usec)
                           : 37
Max Frame Delay(usec)
                           : 65
Avg Frame Delay(usec)
                           : 51
Min Inter FD Variation(usec): 13
Max Inter FD Variation (usec): 15
Avg Inter FD Variation(usec): 14
FRAME DELAY BINS
Bin Number Bin Threshold (usec) Bin Counter
_____
1 \quad 0 \quad - \quad < \quad 4999 \quad 3
25000 - < 9999 0
3 10000 - < 14999 0
4 \ 15000 \ - \ < \ Inf \ 0
INTER-FRAME DELAY BINS
Bin Number Bin Threshold(usec) Bin Counter
1 \quad 0 \quad - \quad < \quad 4999 \quad 2
25000 - < 9999 0
3 10000 - < Inf 0
HISTORY STATISTICS
_____
MD : 12345
MA : 43981
MEP : 200
VLAN ID : 0
VC Name : ETH-2001
RMEP ID : 100
Measurement ID : 1
Measurement Type : DMM
Elapsed time(sec) : 60
End Time : 2019 Nov 06 10:50:19
Suspect Flag : FALSE
```

```
Min Frame Delay(usec) : 14
Max Frame Delay(usec) : 75
Avg Frame Delay(usec) : 47
Min Inter FD Variation(usec): 53
Max Inter FD Variation(usec): 53
Avg Inter FD Variation (usec): 24
FRAME DELAY BINS
Bin Number Bin Threshold (usec) Bin Counter
_____
1 \ 0 \ - \ < \ 4999 \ 5
25000 - < 9999 0
3 10000 - < 14999 0
4 \ 15000 \ - \ < \ Inf \ 0
INTER-FRAME DELAY BINS
Bin Number Bin Threshold (usec) Bin Counter
_____
1 \ 0 \ - \ < \ 4999 \ 4
2 5000 - < 9999 0
3 10000 - < Inf 0
RMEP ID : 100
Measurement ID : 2
Measurement Type : DMM
Elapsed time(sec) : 60
End Time : 2019 Nov 06 10:51:20
Suspect Flag : FALSE
Min Frame Delay(usec) : 13
Max Frame Delay(usec) : 70
Avg Frame Delay(usec) : 37
Min Inter FD Variation(usec): 52
Max Inter FD Variation(usec): 52
Avg Inter FD Variation (usec): 21
FRAME DELAY BINS
Bin Number Bin Threshold (usec) Bin Counter
_____
1 \ 0 \ - \ < \ 4999 \ 6
25000 - < 9999 0
3 10000 - < 14999 0
4 \ 15000 \ - \ < \ Inf \ 0
INTER-FRAME DELAY BINS
Bin Number Bin Threshold (usec) Bin Counter
_____
1 \quad 0 \quad - \quad < \quad 4999 \quad 5
2 5000 - < 9999 0
3 10000 - < Inf 0
```

SW1# abort delay-measurement mep 2 domain mdnam

EVPN-ELINE (Y1731) Sub-Interface on Single Homing

To route traffic between two routers, create two sub interfaces within the physical interface, assign each sub interface an IP address within each subnet and then route the data between two subnets. Y.1731 is an enhancement of Connectivity Fault Management (CFM) and is used to monitor service performance. It provides a standard Ethernet ELINE function that includes Delay Measurement (DM) and Synthetic Loss Measurement (SLM).

As shown in the topology single-homing has a single ISP that provides static or dynamic routes to the customer edge router.

The following topology, configurations and validation section describe EVPN-ELINE Y1731 Sub-Interface on Single Homing devices.

Topology

This topology consists of customer edge routers. CE1 and CE2 with IPv2 Provider Edge routers PE1, PE2. These devices are all interconnected through the core router P in the IPv4 MPLS provider network.





Prerequisite

Configure the following hardware-profile commands related to CFM in configuration mode and reboot the nodes.

```
hardware-profile filter cfm-domain-name-str enable
```

hardware-profile statistics cfm-ccm enable

Configuration

The following content provides configuration and validation information on CFM over sub-interfaces.

PE1: Loopback Interface

Configure loopback Interface on PE1.

PE1#configure terminal	Enter the configure mode
PE1(config)#interface lo	Enter the interface mode for the loopback interface
PE1(config-if)#ip address 7.7.7.7/32 secondary	Configure IP address on loopback interface
PE1(config-if)#exit	Exit the interface mode
PE1(config)#commit	Commit the candidate configuration to the running configuration
PE1: Global EVPN MPLS Command

Configure Global EVPN MPLS command on PE1.

PE1#configure terminal	Enter the configuration mode
PE1(config)#evpn mpls enable	Enable EVPN MPLS
PE1(config-evpn-mpls)#evpn mpls vtep-ip- global 7.7.7.7	Configure the VTEP global IP to loopback IP
PE1(config)#commit	Commit candidate configuration to the running configuration.
	Note: Reload is required after enabling or disabling EVPN MPLS

PE1: Global LDP

Configure Global EVPN LDP on PE1.

PE1(config)#router ldp	Enter the Router LDP mode
PE1(config-router) #router-id 7.7.7.7	Set the router ID to IP address 7.7.7.7
PE1(config-router)#targeted-peer ipv4 8.8.8.8	Configure the targeted peer 8.8.8.8
PE1(config-router-targeted-peer)#exit	Exit the targeted peer
PE10cNOS (config-router) #exit	Exit from the LDP mode
PE1(config)#commit	Commit the candidate configuration to the running configuration

PE1: Interface Configuration Network Side

Configure the interface network side. on PE1.

PE1(config)#interface xe21	Enter the interface mode for xe21
PE1(config-if)#ip address 123.1.1.2/24	Configure the IP address on the interface
PE1(config-if)#enable-ldp ipv4	Enable LDP on the physical interface
PE1(config-if)#label-switching	Enable label switching on the interface
PE1(config-if)#exit	Exit the interface mode
PE1(config) #commit	Commit the candidate configuration to the running configuration

PE1: OSPF Configuration

Configure OSPF on PE1.

PE1(config) #router ospf 1	Enter the router OSPF mode
PE1(config-router) #ospf router-id 7.7.7.7	Configure the Router-ID
PE1(config-router)#network 7.7.7.7/32 area 0.0.0.0	Advertise the loopback address in OSPF
PE1(config-router) #network 123.1.1.0/24 area 0.0.0.0	Advertise xe21 network address in OSPF
PE1(config-router)#exit	Exit the router OSPF mode and return to Configure mode
PE1(config)#commit	Commit the candidate configuration to the running configuration

PE1: BGP Configuration

Configure BGP on PE1.

PE1(config)#router bgp 1	Enter the router BGP mode, AS number 1
PE1(config-router)#neighbor 8.8.8.8 remote- as 65010	Configure PE2 as iBGP neighbor using its loopback IP
PE1(config-router)#neighbor 8.8.8.8 update- source lo	Source of routing updates as loop-back
PE1(config-router)#address-family l2vpn evpn	Enter the address family mode as EVPN
PE1(config-router-af)#neighbor 8.8.8.8 activate	Enable the EVPN address family for the neighbor
PE1(config-router-af)#exit	Exit the address family mode
PE1(config-router)#commit	Commit the candidate configuration to the running configuration

PE1: MAC VRF Configuration

Configure MAC VRF on PE1.

PE1(config)#mac vrf vrf2	Enter the VRF mode
PE1(config-vrf)#rd 7.7.7.7:2	Configure the Route-Distinguisher (rd) value as 7.7.7.2
PE1(config-vrf)#route-target both 2:2	Configure the import and export value as 2:2
PE1(config-vrf)#exit	Exit the VRF mode
PE1(config)#commit	Commit the candidate configuration to the running configuration

PE1: EVPN and VRF Mapping

Configure EVPN and VRF Mapping on PE1.

PE1(config)#evpn mpls id 2 xconnect target- mpls-id 52	Configure the EVPN VPWS identifier with source identifier 2 and target identifier 52
PE1(config)#host-reachability-protocol evpn-bgp vrf2	Map VRF "VRF2" to the EVPN VPWS identifier
PE1(config)#commit	Commit candidate configuration to the running configuration

PE1: Access Port Configuration

Configure the Access Port Configuration on PE1.

PE1(config)#interface xe5	Enter the interface mode for xe5
PE1(config-if)#description access-side-int	Provide an Interface description
PE1(config-if)#interface xe5.2 switchport	Create the L2 subinterface for the physical interface xe6
PE1(config-if)#encapsulation dot1q 2	Set the encapsulation to dot1q with VLAN ID 2 Supported Encapsulation: dot1ad, dot1q, untagged, default
PE1(config-if)#access-if-evpn	Enter the access mode for EVPN MPLS ID configuration
PE1(config-access-if)#map vpn-id 2	Map VPN-id 252 to interface xe2.2 (VPWS)
PE1(config-access-if)#exit	Exit the access interface mode
PE1(config-if)#commit	Commit the candidate configuration to the running configuration

PE1: CFM Configuration

Configure CFM Configuration on PE1.

PE1(config)#hardware-profile filter cfm- domain-name-str enable	Configure the CFM-domain-name-SRR profile to enable CFM
PE1(config)#ethernet cfm domain-type character-string domain-name evpn1 level 7 mip-creation none	Create the CFM domain for EVPN ELINE with type as character string and set MIP creation to none
PE1(config-ether-cfm-mpls-md)#service ma- type string ma-name evp1	Create MA type with string and set MIP creation to none
PE1(config-ether-cfm-mpls-ma)# evpn2	Configure EVPN <evpn-id></evpn-id>
PE1(config-ether-cfm-mpls-ma)#ethernet cfm mep up mpid 10 active true evpn 2	Create up-MEP for local EVPN id 2
PE1(config-ether-cfm-mpls-ma-mep)#cc multicast state enable	Enable CC multicast
PE1(config-ether-cfm-mpls-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet MA-MEP-MEP-mode
PE1(config-ether-cfm-mpls-ma)#mep crosscheck mpid 20	Configure cross check remote MPID
PE1(config-ether-cfm-mpls-ma)#cc interval 100	Enable CC interval with value 2 that is 100 milliseconds
PE1(config-ether-cfm-mpls-ma)#exit-ether- ma-mode	Exit the Ethernet MA mode
PE1(config-ether-cfm-mpls-md)#exit	Exit the Ethernet CFM mode
PE1(config)#commit	Commit the candidate configuration to the running configuration

P1: Loopback nterface

Configure loopback interface on P1.

P1#configure terminal	Enter the configure mode
P1(config)#interface lo	Enter the interface mode for the loopback interface
P1(config-if)#ip address 2.2.2.2/32 secondary	Configure the IP address for the loopback interface
P1(config-if)#exit	Exit the interface mode
P1(config)#commit	Commit the candidate configuration to the running configuration

P1: Global LDP

Configure Global LDP on P1.

Pl(config)#router ldp	Enter the router LDP mode
P1(config-router) #router-id 2.2.2.2	Set the router ID to IP address 2.2.2.2
P1(config-router)#exit	Exit from the LDP mode
P1(config)#commit	Commit the candidate configuration to the running configuration

P1: Interface Configuration

Configure Interface Configuration on P1.

P1(config)#interface xe21	Enter the interface mode for xe21
P1(config-if)#ip address 123.1.1.1/24	Configure the IP address on the interface
P1(config-if)#enable-ldp ipv4	Enable LDP on the physical interface
P1(config-if)#label-switching	Enable label switching on the interface
P1(config-if)#exit	Exit the interface mode
P1(config)#interface Sel4	Enter the interface mode for xe14
P1(config-if)#ip address 100.1.0.1/30	Configure the IP address on the interface
P1(config-if)#enable-ldp ipv4	Enable LDP on the physical interface
P1(config-if)#label-switching	Enable label switching on the interface
P1(config-if)#exit	Exit the interface mode
P1(config)#commit	Commit the candidate configuration to the running configuration

P1: OSPF Configuration

Configure the OSPF Configuration on P1 for more information refer the Topology

P1(config)#router ospf 1	Enter the router OSPF mode
P1(config-router)#ospf router-id 2.2.2.2	Set the Router ID as the loopback IP
P1(config-router)#network 2.2.2.2/32 area 0.0.0.0	Advertise the loopback address in OSPF
P1(config-router)#network 100.1.0.0/16 area 0.0.0.0	Advertise the xe5 network address in OSPF
P1(config-router)#network 123.1.1.0/24 area 0.0.0.0	Advertise xe3 network address in OSPF
P1(config-router)#exit	Exit the router OSPF mode and return to configure mode
P1(config)#commit	Commit the candidate configuration to the running configuration

P2: Loop-back Interface

Configure the loop-back Interface P2.

P2#configure terminal	Enter configuration mode.
P2(config)#interface lo	Enter the interface mode for the loop-back interface
P2(config-if)#ip address 3.3.3.3/32 secondary	Configure the IP address on loop-back interface
P2(config-if)#exit	Exit interface mode
P2(config)#commit	Commit the candidate configuration to the running configuration

P2: Global LDP

Configure Global LDP on P2.

P2(config)#router ldp	Enter the router LDP mode
P2(config-router)#router-id 3.3.3.3	Set the router ID to IP address 10.143.73.3

P2(config-router)#exit	Exit from router target peer and LDP mode
P2(config)#commit	Commit the candidate configuration to the running
	configuration

P2: Interface Configuration

Configure Interface Configuration on P2.

P2(config)#interface xe2	Enter the Interface mode for xe2
P2(config-if)# ip address 100.1.0.1/30	Configure IP address on the interface
P2(config-if)#enable-ldp ipv4	Enable LDP on the physical interface
P2(config-if)#label-switching	Enable label switching on the interface
P2(config-if)#exit	Exit interface mode
P2(config)#interface xe22	Enter the Interface mode for xe22
P2(config-if)# ip address 124.1.1.1/24	Configure the IP address on the interface
P2(config-if)#enable-ldp ipv4	Enable LDP on the physical interface
P2(config-if)#label-switching	Enable label switching on the interface
P2(config-if)#exit	Exit the interface mode
P2(config)#commit	Commit the candidate configuration to the running configuration

P2: OSPF Configuration

Configure OSPF Configuration on P2.

P2(config)#router ospf 1	Enter the Router OSPF mode.
P2(config-router) #ospf router-id 3.3.3.3	Setting the Router ID as Loop-back IP
P2(config-router)#network 3.3.3.3/32 area 0.0.0.0	Advertise the loop-back address in OSPF
P2(config-router)#network 100.1.0.0/16 area 0.0.0.0	Advertise xe5 network address in OSPF
(config-router) #network 124.1.1.0/24 area 0.0.0.0	Advertise xe3 network address in OSPF
P2(config-router)#exit	Exit Router OSPF mode and return to Configure mode.
P2(config)#commit	Commit the candidate configuration to the running configuration

PE2: Loop-back Interface

Configure Loop-back Interface on PE2.

PE2#configure terminal	Enter the configuration mode
PE2(config)#interface lo	Enter the Interface mode for the loop-back interface
PE2(config-if)#ip address 8.8.8.8/32 secondary	Configure the IP address on loop-back interface
PE2(config-if)#exit	Exit the Interface mode
PE2(config)#commit	Commit the candidate configuration to the running configuration

PE2: Global LDP

Configure Global LDP on PE2.

PE2(config)#router ldp	Enter the Router LDP mode.
PE2(config-router) #router-id 8.8.8.8	Set the router ID to IP address 8.8.8.8
PE2(config-router)#targeted-peer ipv4 7.7.7.7	Configure targeted peer
PE2(config-router)#exit	Exit from the router target peer and LDP mode
PE2(config)#commit	Commit the candidate configuration to the running configuration

PE2: Global EVPN MPLS Command

Configure Global EVPN MPLS Command on PE2.

PE2(config)#evpn mpls enable	Enable EVPN MPLS
PE2(config)#commit	Commit the candidate configuration to the running configuration
	Note: Reload is required after Enabling or Disabling EVPN MPLS
PE2(config-evpn-mpls)#evpn mpls vtep-ip- global8.8.8	Configure the VTEP global IP to loop-back IP.'
PE2(config-evpn-mpls)#commit	Commit the candidate configuration to the running configuration

PE2: Interface Configuration Network Side

Configure Interface Network Side on PE2.

PE2(config)#interface xe18	Enter the interface mode for xe18
PE2(config-if)#enable-ldp ipv4	Configure IP address on the interface
PE2(config-if)#label-switching	Enable label switching on the interface
PE2(config-if) #exit	Exit the interface mode
PE2(config)#commit	Commit the candidate configuration to the running configuration

PE2: OPSF Configuration

Configure OSPF on PE2.

PE2(config)#router ospf 1	Enter the interface mode for xe2
PE2(config-router) #ospf router-id 8.8.8.8	Router-ID configurations
PE2(config-router)#network 8.8.8.8/32 area 0.0.0.0	Advertise loop-back address in OSPF.
PE2(config-router) #network 124.1.1.0/24 area 0.0.0.0	Advertise the xe5 network address in OSPF
PE2(config-router) #exit	Exit the router OSPF mode and return to configure mode
PE2(config)#commit	Commit the candidate configuration to the running configuration

PE2: BGP Configuration

Configure BGP on PE2.

PE2(config)#router bgp 1	Enter the router BGP mode, ASN: 65010
PE2(config-router)#neighbor 7.7.7.7 remote- as 65010	Configure PE1 as iBGP neighbor using it's loopback IP address
PE2(config-router)#neighbor 7.7.7.7 update- source lo	Source of routing updates as loop-back
PE2(config-router)#address-family l2vpn evpn	Enter the address family mode as EVPN
PE2(config-router-af)#neighbor 7.7.7.7 activate	Enable the EVPN Address family for neighbor
PE2(config-router-af)#exit	Exit the address family mode
PE2(config-router)#commit	Commit the candidate configuration to the running configuration

PE2: MAC VRF Configuration

Configure MAC VRF on PE2.

PE2(config)#mac vrf vrf2	Enter the VRF mode
PE2(config-vrf)#rd 8.8.8.8:2	Configure the rd value 8.8.8.8:2
PE2(config-vrf)#route-target both 2:2	Configure the import and export value as 2:2
PE2(config-vrf)#exit	Exit the VRF Mode
PE2(config)#commit	Commit the candidate configuration to the running configuration

PE2: EVPN and VRF Mapping

Configure EVPN and VRF Mapping PE2.

PE2(config)#evpn mpls id 52 xconnect target- mpls-id 2	Configure the EVPN-ELINE identifier with source identifier52 and target identifier 2
PE2(config-evpn-mpls)#host-reachability- protocol evpn-bgp vrf2	Map VFRF "VRF2" to EVPN-ELINE identifier
PE2(config-evpn-mpls)#commit	Commit the candidate configuration to the running configuration

PE2: Access Port Configuration

Configure Access Port on PE2.

PE2(config)#interface xe4	Enter the interface mode for xe4
PE2(config-if)#description access-side-int	Provide an interface description
PE2(config-if)#interface xe2 switchport	Create L2 subinterface of physical interface xe2
PE2(config-if)#encapsulation dot1q 2	Set encapsulation to dot1q with VLAN ID 2 Supported encapsulation is dot1ad, dot1q, untagged, default
PE2(config-if)#access-if-evpn	Enter the access mode for EVPN MPLS ID configuration
PE2(config-access-if)#map vpn-id 52	Map VPN-id 52 to interface xe2.2 (VPWS)

PE2(config-access-if)#exit	Exit out of the access interface mode
PE2(config-if)#commit	Commit the candidate configuration to the running configuration

PE2: CFM Configuration

Configure CFM on PE2 CFM.

PE2(config)#hardware-profile filter cfm- domain-name-str enable	Configure the CFM-domain-name-str profile to enable CFM
PE2(config)# ethernet cfm domain-type character-string domain-name evpn1 level 7 mip-creation none	Create CFM domain for EVPN ELINE with type as character string and set MIP creation to none
PE2(config-ether-cfm-mpls-md)# service ma- type string ma-name evp1	Create MA type with string and set MIP creation to none
PE2(config-ether-cfm-mpls-ma)# evpn 52	Configure EVPN <evpn-id></evpn-id>
PE2(config-ether-cfm-mpls-ma)# ethernet cfm mep up mpid 20 active true evpn 52	Create up-MEP for local EVPN id 52
PE2s(config-ether-cfm-mpls-ma-mep)#cc multicaststate enable	Enable CC multicast

Validation

The following is the validations for PE1 and PE2.

PE1

```
PE1#show evpn mpls xconnect id 2
EVPN-MPLS Xconnect Info
_____
AC-AC: Local-Cross-connect
AC-NW: Cross-connect to NetworkAC-UP: Access-port is up
AC-DN: Access-port is downNW-UP: Network is up
NW-DN: Network is down
NW-SET: Network and AC both are up
LocalRemoteConnection-Details
_____
VPN-IDEVI-NameMTUVPN-IDSourceDestinationPE-IPMTUTypeNW-Status
_____
 ----1500 52xe5.2--- Single Homed Port ---8.8.8.81500 AC-NW NW-SET
2
Total number of entries are 1
PE1#show ethernet cfm errors domain evpn1
Domain Name
         Level
               MEPID
                        Defects
_____
           2
                  10
evpn1
                          . . . . .
```

1. def defEri	ERDICCM	12. defMAC 5. defXc	Cstatus 3. conCCM	defRemot	eCCM			
PE1#sł	now eth	ernet cfn	n ma status	domain e	vpn1 ma-name	evpl		
MA NAN	1ESTATU	IS						
evr	plActiv	7e						
PE1#sł MPID I	now eth Dir Lvl	ernet cfm CC-Stat	n maintenanc HW-Status	ce-points CC-Intvl	local mep d MAC-Address	omain evp Def	on1 ma-r Port	name evpl MD Name
10	Up 2	Enable	Installed	100 ms	00aa.bb00.	0002 F	xe5.2	evpnl
PE1#sł	now eth	ernet cfn	n maintenanc	ce-points	remote doma	in evpnl	ma-name	e evpl
MEPID	RMEP 1	D LEVE	L RX CCI	M RDI	PEER-MAC	TYP	E 	
10	20	2	Yes	False	00cc.dd00.00)34 Conf	igured	

LMM

Loss Measurement Management (LMM) is a loss monitoring feature developed to monitor the loss and delay traffic measurement data on the router.

PE2(config)#ethernet cfm loss-measurement profile-name lmm	Configure LM profile
PE2(config-cfm-lm)#measurement-type lmm	Configure measurement type as LMM
PE2(config-cfm-lm)#measurement-interval 1	Configure measurement interval
PE2(config-cfm-lm)#intervals-stored 3	Configure number of interval to be stored
PE2(config-cfm-lm)#commit	Commit the candidate configuration to the running configuration.
PE2(config-cfm-lm)#end	Exit configure mode

PE2: CFM Responder Configuration

Configure CFM Responder on PE2.

Prerequisite

```
hardware-profile filter cfm-domain-name-str enable
hardware-profile statistics cfm-lm enable
hardware-profile statistics cfm-ccm enable
```

PE2(config)#hardware-profile filter cfm- domain-name-str enable	Configure the CFM-domain-name-STR profile to enable CFM
PE2(config)# ethernet cfm domain-type character-string domain-name evpn1 level 7 mip-creation none	Create the CFM domain for EVPN ELINE with type as characterstring and set MIP creation to none
PE2(config-ether-cfm-mpls-md) # service ma- type string ma-name evpl	Create the MA type with string and set MIP creation to none
PE2(config-ether-cfm-mpls-ma)# evpn 52	Configure EVPN <evpn-id></evpn-id>
PE2(config-ether-cfm-mpls-ma)# ethernet cfm mep up mpid 20 active true evpn 52	Create up-MEP for local EVPN id 52
PE2(config-ether-cfm-mpls-ma)# ethernet cfm loss-measurement reply lmm	Enable the LM responder
PE2(config-ether-cfm-mpls-ma-mep)#cc multicaststate enable	Enable CC multi cast

PE2(config-ether-cfm-mpls-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet MA-MEP-mode
PE2(config-ether-cfm-mpls-ma)# mep crosscheck mpid 10	Configure cross check to remote MEP for VLAN 2
PE2(config-ether-cfm-mpls-ma)#cc interval 100	Enable the CC interval with value 2 that is 10 milliseconds
PE2(config-ether-cfm-mpls-ma)#exit-ether- ma-mode	Exit the Ethernet MA mode
PE2(config-ether-cfm-mpls)#exit	Exit the Ethernet CFM mode
PE2(config)#exit	Exit the configure mode
PE2(config)#commit	Commit the candidate configuration to the running configuration

Commands to Initiate/Abort Loss Measurement

The following are the commands to initiate/abort loss measurement.

```
loss-measurement type on-demand profile-name <WORD> rmep mac-address <HHHH.HHHH.HHHH>
start-time <immediate|relative|absolute> stop-time <none|absolute|relative> repetition-
period <REP-TIME> mep <MEPID> domain < DOMAIN_NAME> ma <MA_NAME>
```

```
loss-measurement type proactive profile-name <WORD> rmep mac-address
<HHHH.HHHH.HHHH>mep <MEPID> domain < DOMAIN NAME> ma <MA NAME>
```

abort loss-measurement mep <MEPID> domain <DOMAIN NAME> ma <MA NAME>

clear ethernet cfm loss-measurement mep <MEPID> domain <DOMAIN NAME> ma <MA NAME>

Validation

The following are the validations for PE1.

```
PE1ping ethernet mac 00cc.dd00.0034 unicast source 10 domain evpn1 ma evp1
 success rate is 100 (5/5)
PE1#traceroute ethernet 00cc.dd00.0034 mepid 10 domain evpn1 ma evp1
MP Mac
                Hops Relay-action
                                           Ingress/Egress Ingress/Egress action
                       RlyHit
00cc.dd00.0034
                 1
                                             Ingress
                                                             IngOK
PE1# loss-measurement type proactive profile-name 1mm rmep 20 mep 10 domain evpn1 ma
evp1
PE1# show ethernet cfm loss-measurement mep 10 domain evpn1 ma-name evp1
MEP: 10 MA: evpl
CURRENT:
 Measurement ID : 48
                            : True
  Suspect
  Measurement Type
                             : lmm
  Elapsed time(sec)
                             : 14
  Start Time
                             : 2023 Oct 16 15:51:24
  Near End loss
                             : 0
  Far End loss
                             : 0
  Near End accumulated loss : 0
  Far End accumulated loss
                            : 0
  Near End frame loss ratio : 0
  Far End frame loss ratio : 0
HISTORY:
 Measurement ID : 45
  Suspect
                             : True
  Measurement Type
                             : lmm
  Elapsed time(sec)
                             : 60
  End Time
                             : 2023 Oct 16 15:49:24
  Near End loss
                             : 0
  Far End loss
                             : 0
  Near End accumulated loss : 0
  Far End accumulated loss
                             • 0
  Near End frame loss ratio : 0
  Far End frame loss ratio
                             : 0
  Near End frame loss ratio min : 0
  Far End frame loss ratio min : 0
  Near End frame loss ratio max : 0
  Far End frame loss ratio max : 0
PE1# abort loss-measurement mep 10 domain evpn1 ma evp1
PE1#ping ethernet mac 00cc.dd00.0034 unicast source 10 domain evpn1 ma evp1
       success rate is 100 (5/5)
```

```
PE1#traceroute ethernet 00cc.dd00.0034 mepid 10 domain evpn1 ma evp1
              Hops Relay-action
MP Mac
                                        Ingress/Egress Ingress/Egress action
00cc.dd00.0034 1
                    RlyHit
                                          Ingress
                                                         IngOK
PE1#sh ethernet cfm statistics mep 10 domain evpn1 ma-name evp1
CFM Statistics for MEP 10 of MD evpn1
 _____
Continuity Check Messages
  CCM Sent : 481375
CCM Received : 559371
Loop Back Messages
  LBM Sent
                         : 10
  LBR Received (Valid) : 10
  LBR Received(Bad msdu) : 0
  LBR Received (Out-of-Seq): 0
Link Trace Messages
  LTM Sent
                         : 2
  LTR Sent
                         : 0
  LTR Received(Valid)
                        : 2
  LTR Received (unexpected): 0
7023-mh1#
```

SLM

SLM is a software for managing the maintenance and repair products.

PE1: CFM Initiator Configuration

Configure SLM CFM Initiator on PE1.

PE2(config)#ethernet cfm loss-measurement profile-name slm	Configure the LM profile
PE2(config-cfm-lm)#measurement-type lmm	Configure measurement type as LMM
PE2(config-cfm-lm)#message-period 3	Configure the message period
PE2(config-cfm-lm)#measurement-interval 1	Configure the measurement interval
PE2(config-cfm-lm)#intervals-stored 3	Configure the number of interval to the stored
PE2(config-cfm-lm)#commit	Commit the candidate configuration to the running configuration
PE2(config-cfm-lm)#end	Exit the configure mode

PE2: CFM Responder Configuration

Configure SLM CFM Responder on PE2.

Prerequisite

Configure below hardware-profile commands related to CFM in configure mode and reboot the nodes.

```
hardware-profile filter cfm-domain-name-str enable hardware-profile statistics cfm-slm enable
```

hardware-profile statistics cfm-ccm enable

PE2(config)#hardware-profile filter cfm- domain-name-str enable	Configure CFM-domain-name-str profile to enable CFM	
PE2(config)# ethernet cfm domain-type character-string domain-name evpn1 level 7 mip-creation none	Create CFM domain for EVPN ELINE with type as character string and set MIP creation to none	
PE2(config-ether-cfm-mpls-md) # service ma- type string ma-name evp1	Create MA type with string and set MIP creation to none	
PE2(config-ether-cfm-mpls-ma)# evpn 52	Configure EVPN <evpn-id></evpn-id>	
PE2(config-ether-cfm-mpls-ma)# ethernet cfm mep up mpid 20 active true evpn 52	Create up-MEP for local EVPN id 52	
<pre>PE2(config-ether-cfm-mpls-ma)# ethernet cfm loss-measurement reply slm</pre>	Enable SLM responder	
PE2(config-ether-cfm-mpls-ma-mep)#cc multicaststate enable	Enable CC multi cast	
PE2(config-ether-cfm-mpls-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet MA-MEP-mode	
PE2(config-ether-cfm-mpls-ma)# mep crosscheck mpid 10	Configure cross check to remote MEP for VLAN 2	
PE2(config-ether-cfm-mpls-ma)#cc interval 100	Enable CC interval with value 2 that is 100 milliseconds	
PE2(config-ether-cfm-mpls-ma)#exit-ether- ma-mode	Exit the Ethernet MA mode	
PE2(config-ether-cfm-mpls)#exit	Exit the Ethernet CFM mode	
PE2(config)#exit	Exit from configure mode	
PE2(config)#commit	Commit the candidate configuration to the running configuration	

SLM Initiation/Abort

The following is the SLM Initiation/Abort.

```
_____
PE1#loss-measurement type proactive profile-name slm rmep 10 mep 20 domain evpn1
                                                                              ma
evp1
PE1#show ethernet cfm loss-measurement mep 20 domain evpn1 ma-name evp1
MEP: 20 MA: evpl
CURRENT:
Measurement ID : 2
Suspect : False
Measurement Type : slm
Elapsed time(sec) : 10
Start Time : 2023 Sep 30 07:08:56
Near End loss : 0
Far End loss : 0
Near End accumulated loss : 0
Far End accumulated loss : 0
```

```
Near End frame loss ratio : 0
Far End frame loss ratio : 0
HISTORY:
Measurement ID : 1
Suspect : False
Measurement Type : slm
Elapsed time(sec) : 60
End Time : 2023 Sep 30 07:08:56
Near End loss : 0
Far End loss : 0
Near End accumulated loss : 0
Far End accumulated loss : 0
Near End frame loss ratio : 0
Far End frame loss ratio : 0
Near End frame loss ratio min : 0
Far End frame loss ratio min : 0
Near End frame loss ratio max : 0
Far End frame loss ratio max : 0
PE1#
PE1# abort loss-measurement mep 10 domain evpn1 ma evp1
```

DMM

DMM) specifies solutions for IP networks, the traffic between mobile and correspondent nodes takes an optimal route. DMM aims for the transparency above the IP layer.

PE1: CFM Initiator Configuration

Configure DMM CFM Initiator on PE1.

<pre>PE1(config)# ethernet cfm delay-measurement profile-name dmm</pre>	Create the loss-measurement profile for DM
PE1(config-cfm-dm)# measurement-interval 1	Specify the measurement-interval in minutes
<pre>PE1(config-cfm-dm)# intervals-stored 3</pre>	Specify the number of history interval to be stored
PE1(config-cfm-dm)# message-period 1s	Specify the message period interval time
<pre>PE1(config-cfm-dm) # bins-per-fd-interval 4</pre>	Specify the number of measurement bins per Measurement Interval for Frame Delay measurements
<pre>PE1(config-cfm-dm) # bins-per-ifdv-interval 3</pre>	Specify the number of measurement bins per Measurement Interval for Inter-Frame Delay Variation measurements
PE1(config-cfm-dm)#commit	Commit the candidate configuration to the running configuration

PE2: CFM Responder Configuration

Prerequisite

Configure below hardware-profile commands related to CFM in configuration mode and reboot the nodes.

hardware-profile filter cfm-domain-name-str enable hardware-profile statistics cfm-ccm enable

PE2(config)#hardware-profile filter cfm- domain-name-str enable	Configure CFM-domain-name-str profile to enable CFM
PE2(config)# ethernet cfm domain-type character-string domain-name evpn1 level 7 mip-creation none	Create CFM domain for EVPN-ELINE with type as character string and set MIP creation to none
PE2(config-ether-cfm-mpls-md)# service ma- type string ma-name evp1	Create MA type with string and set MIP creation to none
PE2(config-ether-cfm-mpls-ma)# evpn 52	Configure EVPN <evpn-id></evpn-id>
PE2(config-ether-cfm-mpls-ma)# ethernet cfm mep up mpid 20 active true evpn 52	Create up-MEP for local EVPN id 52
PE2(config-ether-cfm-mpls-ma)# ethernet cfm delay-measurement reply dmm	Enable DMM responder
PE2(config-ether-cfm-mpls-ma-mep)#cc multicaststate enable	Enable the CC multicast
PE2(config-ether-cfm-mpls-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet MA-MEP-mode
PE2(config-ether-cfm-mpls-ma)# mep crosscheck mpid 10	Configure cross check to remote MEP for VLAN 2
PE2(config-ether-cfm-mpls-ma)#cc interval 100	Enable CC interval with value 2 that is 10 milliseconds
PE2(config-ether-cfm-mpls-ma)#exit-ether- ma-mode	Exit the Ethernet MA mode
PE2(config-ether-cfm-mpls)#exit	Exit the Ethernet CFM mode
PE2(config)#exit	Exit from the configure mode
PE2(config)#commit	Commit the candidate configuration to the running configuration

Validation

The following output validates the DMM configuration validations for PE1 and PE2.

```
PE1#delay-measurement type proactive profile-name dmm rmep 10 mep 20 domain evpn1 ma evp1
```

```
PE1#show ethernet cfm delay-measurement mep 20 domain evpn1 ma-name evp1
MD : evpn1
MA :
MEP : 20
VC Name :
Peer MAC Address : 00cc.dd00.0034
CURRENT:
RMEP ID : 10
Measurement ID : 1
Measurement Type : DMM
Elapsed time(sec) : 2
Start Time : 2023 Oct 12 04:11:56
Suspect Flag : FALSE
Min Frame Delay(usec) : 40
Max Frame Delay(usec) : 74
Avg Frame Delay(usec) : 57
Min Inter FD Variation(usec): 34
```

Max Inter FD Variation(usec): 34 Avg Inter FD Variation(usec): 34 FRAME DELAY BINS Bin Number Bin Threshold(usec) Bin Counter 1 0 - < 4999 2 2 5000 - < 9999 0 3 10000 - < 14999 0 4 15000 - < 4294967295 0 INTER-FRAME DELAY BINS Bin Number Bin Threshold(usec) Bin Counter 1 0 - < 4999 1 2 5000 - < 9999 0 3 10000 - < 4294967295 0

CHAPTER 3 Y.1731 and CFM Over Cross-connect Subinterface

Overview

The cross-connect feature establishes, manages, and optimizes communication paths within a network. It provides the infrastructure necessary for routing traffic, provisioning services, isolating faults, and improving network performance, ultimately contributing to the reliability and efficiency of the network infrastructure.

Y.1731 Connectivity Fault Management (CFM) over cross-connect interface allows for monitoring and managing the connectivity and performance of services across cross-connect interfaces within the network. This feature enables fault detection, performance monitoring, and fault management capabilities over cross-connect interfaces, enhancing network reliability and service quality.

Feature Characteristics

- Provides granular monitoring and management capabilities at the cross-connect interface level, allowing for detailed analysis of service performance.
- Allows customization of CFM parameters such as MEPs, MAs, and performance thresholds to meet specific network requirements and SLAs.
- Works seamlessly across different network topologies, including point-to-point, point-to-multipoint, and multipoint to-multipoint configurations.
- Scalable to large network deployments, accommodating growing traffic demands and network expansion.

Benefits

- Provides real-time monitoring and detection of faults within cross-connect interfaces, enabling quick identification and resolution of issues.
- Proactively identifies connectivity issues and performance degradation, ensuring high service availability and reliability.
- Enables efficient troubleshooting by providing detailed fault information, facilitating faster resolution of network issues.
- Monitors performance metrics such as delay, jitter, and packet loss across cross-connect interfaces, ensuring adherence to Service Level Agreements (SLAs).
- Supports automated fault management processes, including fault isolation, notification, and recovery, minimizing service downtime.

Prerequisites

Ensure that the network devices involved in the configuration support Y.1731 CFM and have the necessary software version installed. CFM functionality might not be available in all devices or software versions.

Configuration

The configurations involve defining VLANs, specifying interface roles, creating cross-connects between interfaces, and configuring ethernet CFM parameters for continuity checks and delay measurement.

Topology

This topology establishes a network with CFM enabled between CE1, PE1, PE2, and CE2. CFM allows for monitoring connectivity and detecting faults within the network. Each device is configured with CFM parameters, including MEPs, and cross-connects are established between devices to facilitate CFM message exchange. This setup enables comprehensive fault detection and management, enhancing the overall reliability and performance of the network.



Figure 3-12: Y.1731 CFM Over Cross-connect Interface

Perform the following configurations to set up sub-interfaces, establish cross-connects, and configure ethernet CFM domains on CE and PE nodes:

1. Configure sub interfaces on CE1 to set the load interval to 30 seconds, create sub-interface xe1.20, xe2.20 and configure it as a switchports, and specify the VLAN encapsulation as 802.10 with VLAN ID 20.

```
CE1(config)# interface xe1
CE1(config-if)# load-interval 30
CE1(config-if)# interface xe1.20 switchport
CE1(config-if)# encapsulation dot1q 20
CE1(config-if)# exit
CE1(config)# interface xe2
CE1(config-if)# load-interval 30
CE1(config-if)# interface xe2.20 switchport
CE1(config-if)# encapsulation dot1q 20
CE1(config-if)# exit
```

2. Set up cross-connect to define a cross-connect with the identifier VC1, specify interface xe1.20 as the primary interface for the cross-connect, and specify interface xe2.20 as the backup interface for the cross-connect:

```
CE1(config)# cross-connect VC1
CE1(config-xc)# interface xe1.20
CE1(config-bkp-xc)# interface xe2.20
CE1(config-bkp-xc)# commit
```

3. Configure ethernet CFM domain to specify the domain type as a character string with the domain name crcn1, the MA type as a string with the MA name ma1C, associate the MA with VLAN 20, configure a MEP with MEP ID 8001 as active on interface xe2.20, enable multicast state for continuity check, enable auto-discovery of RMEPs, and set the continuity check interval to 1 second:

```
CE1(config)# ethernet cfm domain-type character-string domain-name crcn1
level 7 mip-creation default
CE1(config-ether-cfm)# service ma-type string ma-name malC1
CE1(config-ether-cfm-ma)# vlan 20
CE1(config-ether-cfm-ma)# ethernet cfm mep down mpid 8001 active true xe2.20
CE1(config-ether-cfm-ma-mep)# cc multicast state enable
```

```
CE1(config-ether-cfm-ma) # rmep auto-discovery enable
CE1(config-ether-cfm-ma) # cc interval 1s
CE1(config-ether-cfm) # commit
```

4. Configure sub interfaces on PE1 to set the load interval to 30 seconds, create sub-interface xe2.20, xe3.20 and configure it as a switchports, and specify the VLAN encapsulation as 802.10 with VLAN ID 20:

```
PE1(config) # interface xe2
PE1(config-if) # load-interval 30
PE1(config-if) # interface xe2.20 switchport
PE1(config-if) # encapsulation dot1q 20
PE1(config-if) # exit
PE1(config) # interface xe3
PE1(config-if) # load-interval 30
PE1(config-if) # interface xe3.20 switchport
PE1(config-if) # encapsulation dot1q 20
PE1(config-if) # exit
```

5. Set up cross-connect on PE1 to define a cross-connect with the identifier VC2, specify interface xe2.20 as the primary interface for the cross-connect, and specify interface xe3.20 as the backup interface for the cross-connect:

```
PE1(config)# cross-connect VC2
PE1(config-xc)# interface xe2.20
PE1(config-bkp-xc)# interface xe3.20
PE1(config-bkp-xc)# commit
```

6. Configure Ethernet CFM on PE1 to specify the domain type as a character string with the domain name crcn1, the MA type as a string with the MA name ma1C, associate the MA with VLAN 20, configure a MEP with MEP ID 8002 as active on interface xe2.20, enable multicast state for continuity check, enable auto-discovery of RMEPs, and set the continuity check interval to 1 second:

```
PE1(config)# ethernet cfm domain-type character-string domain-name crcn1
level 7 mip-creation default
PE1(config-ether-cfm)# service ma-type string ma-name malC1
PE1(config-ether-cfm-ma)# vlan 20
PE1(config-ether-cfm-ma)# ethernet cfm mep down mpid 8002 active true xe2.20
PE1(config-ether-cfm-ma-mep)# cc multicast state enable
PE1(config-ether-cfm-ma)# rmep auto-discovery enable
PE1(config-ether-cfm-ma)# cc interval 1s
PE1(config-ether-cfm)# commit
```

7. Perform Delay measurement between CE1 and PE1, and configure Delay Management profile on PE1 and responder config on CE1:

```
PE1(config-cfm-lm)#ethernet cfm delay-measurement profile-name DM
PE1(config-cfm-dm)# measurement-interval 1
PE1(config-cfm-dm)# intervals-stored 2
PE1(config-cfm-dm)# message-period 1s
PE1(config-cfm-dm)#!
PE1(config-cfm-dm)#commit
CE1(config)#ethernet cfm domain-type character-string domain-name crcn1
level 7 mip-creation default
CE1(config-ether-cfm)# service ma-type string ma-name malC1
CE1(config-ether-cfm-ma)# ethernet cfm mep down mpid 8001 active true
```

- xe2.20 CE1(config-ether-cfm-ma-mep)#ethernet cfm delay-measurement reply dmm CE1(config-ether-cfm)#commit
- 8. Initiate the DM session on PE1:

PE1#delay-measurement type on-demand profile-name DM rmep 8001 start-time immediate stop-time none repetition-period 6000 mep 8002 domain crcn1 ma ma1C1

9. Perform SLM between CE1 and PE1, and configure SLM profile on PE1 and responder config on CE1:

```
CE1(config)#ethernet cfm domain-type character-string domain-name crcn1
level 7 mip-creation default
CE1(config-ether-cfm)#service ma-type string ma-name ma1C1
CE1(config-ether-cfm-ma)#ethernet cfm mep down mpid 8001 active true xe2.20
CE1(config-ether-cfm-ma-mep)#ethernet cfm loss-measurement reply slm
CE1(config-ether-cfm-ma-mep)#commit
PE1(config-cfm-lm)#ethernet cfm loss-measurement profile-name SLM
PE1(config-cfm-lm)# measurement-type slm
```

PE1(config-cfm-lm) # measurement-interval 1

- PE1(config-cfm-lm)# intervals-stored 3
- PE1(config-cfm-lm) # message-period 1s
- 10. Initiate the SLM session execute below on PE1:

```
PE1#loss-measurement type on-demand profile-name SLM rmep 8001 start-time immediate stop-time none repetition-period 6002 mep 8002 domain crcn1 ma malC1
```

Configuration Snapshot:

CE1

```
interface xel
 load-interval 30
1
interface xe1.20
 switchport
 encapsulation dot1q 20
L
interface xe2
 load-interval 30
T
interface xe2.20
 switchport
 encapsulation dot1q 20
ļ
cross-connect VC1
 interface xe1.20
 interface xe2.20
ethernet cfm domain-type character-string domain-name crcn1 level 7 mip-creation
default
 service ma-type string ma-name malC1
 vlan 20
 ethernet cfm mep down mpid 8001 active true xe2.20
   cc multicast state enable
  rmep auto-discovery enable
  cc interval 1s
```

```
interface xe2
 load-interval 30
!
interface xe2.20
 switchport
 encapsulation dot1q 20
!
interface xe3
 load-interval 30
!
interface xe3.20
 switchport
 encapsulation dot1q 20
1
cross-connect VC2
 interface xe2.20
 interface xe3.20
T
ethernet cfm domain-type character-string domain-name crcn1 level 7 mip-creation
default
 service ma-type string ma-name ma1C1
 vlan 20
  ethernet cfm mep down mpid 8002 active true xe2.20
   cc multicast state enable
  rmep auto-discovery enable
  cc interval 1s
!
ethernet cfm delay-measurement profile-name DM
 measurement-interval 1
 intervals-stored 2
 message-period 1s
```

Validation

Verify the configured cross-connect interfaces on the PE device.

CE1#sh	ow cross-connect					
cross-	connect status					
XC nam	le	Epl		Bkp-Ep1	Ep2	Bkp-
Ep2	Sp2 Status					
	+	+			+	-+
VC1 UP		xe1.20	-	xe2.20	. –	
	+				+	-+
AC cro	ss-connect summary	7				
Total	: 1					
Up	: 1					
Down	: 0					

Verify any errors related to the Ethernet CFM domain.

PE1#show ethernet cfm errors domain crcn1 Level VLAN MEPID Defects Domain Name MA Name _____ 7 20 8002 crcn1 malC1 1. defRDICCM 2. defMACstatus 3. defRemoteCCM 4. defErrorCCM 5. defXconCCM PE1#show ethernet cfm ma status domain crcn1 ma ma1C1 MA NAME STATUS _____ malC1 Active PE1#show ethernet cfm maintenance-points local mep domain crcn1 ma-name malC1 MPID Dir Lvl VLAN CC-Stat HW-Status CC-Intvl MAC-Address Def Port MD Name _____ 8002 Dn 7 20 Enable Installed 1 sec 5c07.5854.1a27 F xe2.20 crcn1 PE1#show ethernet cfm maintenance-points remote domain crcn1 ma-name malC1 TYPE RMEPID LEVEL Rx CCM RDI PEER-MAC MA NAME MEPID _____ 7 8002 8001 ma1C1 Yes False 9819.2c5e.930e Learnt PE1# PE1# PE1#ping ethernet mac 9819.2c5e.930e unicast source 8002 domain crcn1 ma ma1C1 success rate is 100 (5/5)PE1#traceroute ethernet 9819.2c5e.930e mepid 8002 domain crcn1 ma ma1C1 MP Mac Hops Relay-action Ingress/Egress Ingress/Egress action 9819.2c5e.930e 1 RlyHit Ingress IngOK CE2#show ethernet cfm errors domain crcn3 Domain Name MA Name Level VLAN MEPID Defects _____ ma1C3 0 NA 8007 crcn3 1. defRDICCM 2. defMACstatus 3. defRemoteCCM 4. defErrorCCM 5. defXconCCM CE2#show ethernet cfm ma status domain crcn3 ma ma1C3 MA NAME STATUS _____ malC3 Active PE2#show cross-connect cross-connect status XC name Bkp-Ep1 Ep2 Ep1 Bkp-Ep2 Status _____+ ____+ VC1 xe3.20 xe4.20 UP

AC cross-connect summary Total : 1 Up : 1 Down : 0

Verify the local Maintenance Points (MEPs) within the Ethernet CFM domain named associated with the Maintenance Association (MA)

```
PE1#show ethernet cfm delay-measurement mep 8002 domain crcn1 ma-name malC1
                   : crcn1
MD
MA
                   : malC1
                   : 8002
MEP
VLAN ID
                  : 0
                  : xe2.20
Interface
Peer MAC Address : 6821.5f1f.4e22
CURRENT:
_____
RMEP ID : 8001
Measurement ID : 3
                      : DMM
Measurement Type
Elapsed time(sec)
                      : 58
                      : 2024 Mar 28 18:52:12
Start Time
                       : FALSE
Suspect Flag
                      : 9
Min Frame Delay(usec)
Max Frame Delay(usec)
                      : 9
Avg Frame Delay(usec)
                       : 9
Min Inter FD Variation(usec): 0
Max Inter FD Variation(usec): 0
Avg Inter FD Variation(usec): 0
          FRAME DELAY BINS
           Bin Threshold(usec)
Bin Number
                                  Bin Counter
1
            0
                    - < 4999
                                    57
2
            5000
                    - < 9999
                                    0
3
            10000
                    - < 4294967295
                                   0
        INTER-FRAME DELAY BINS
Bin Number Bin Threshold(usec)
                                   Bin Counter
_____
           0
                    - < 4999
1
                                    56
2
            5000
                    - < 4294967295
                                   0
HISTORY STATISTICS
_____
MD
                   : crcn1
```

MA MEP VLAN ID Interface RMEP ID : 8001 Measurement ID Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec)	: malCl : 8002 : 0 : xe2.2 : 1 : DMM : 60 : 294967295 : FALSE : 9	
Avg Frame Delay(usec)	: 9	
Min Inter FD Variation	(usec): 0	
Max Inter FD Variation	(usec): 0	
Avg Inter FD Variation	(usec): 0	
FRAME DELAY	Y BINS	
Bin Number Bin Thres	shold(usec)	Bin Counter
1 0		=======================================
1 U 2 5000	- < 4999	59
3 10000	- < 4294967295	0
5 10000	< 1291907290	0
INTER-FRAME I	DELAY BINS	
Bin Number Bin Three	shold(usec)	Bin Counter
Bin Number Bin Three 1 0	shold(usec) 	Bin Counter ======= 58
Bin Number Bin Three 1 0 2 5000	shold(usec) 	Bin Counter ========= 58 0
Bin Number Bin Three 1 0 2 5000	shold(usec) 	Bin Counter ====== 58 0
Bin Number Bin Three 1 0 2 5000 RMEP ID : 8001 Mossurement ID	shold(usec) < 4999 - < 4294967295	Bin Counter ======= 58 0
Bin Number Bin Three I 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type	shold(usec) - < 4999 - < 4294967295 : 2 : DMM	Bin Counter ======= 58 0
Bin Number Bin Three 1 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type Elapsed time(sec)	shold(usec) - < 4999 - < 4294967295 : 2 : DMM : 60	Bin Counter ======= 58 0
Bin Number Bin Three I 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type Elapsed time(sec) End Time	shold(usec) - < 4999 - < 4294967295 : 2 : DMM : 60 : 2024 Mar 28	Bin Counter 58 0 18:52:12
Bin Number Bin Three 1 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type Elapsed time(sec) End Time Suspect Flag	<pre>shold(usec) - < 4999 - < 4294967295 : 2 : DMM : 60 : 2024 Mar 28 : FALSE</pre>	Bin Counter 58 0
Bin Number Bin Three I 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec)	<pre>shold(usec) - < 4999 - < 4294967295 : 2 : DMM : 60 : 2024 Mar 28 : FALSE : 9</pre>	Bin Counter 58 0
Bin Number Bin Three I 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec)	<pre>shold(usec) - < 4999 - < 4294967295 : 2 : DMM : 60 : 2024 Mar 28 : FALSE : 9 : 9 : 0</pre>	Bin Counter 58 0
Bin Number Bin Three Bin Three 1 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type Elapsed time (sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Avg Frame Delay(usec) Min Inter ED Variation	<pre>shold(usec) - < 4999 - < 4294967295 : 2 : DMM : 60 : 2024 Mar 28 : FALSE : 9 : 9 : 9 : 9 : 9 : 9 : 9 : 9 : 9 : 0</pre>	Bin Counter 58 0
Bin Number Bin Three Bin Number Bin Three 1 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Max Frame Delay(usec) Min Inter FD Variation Max Inter FD Variation	<pre>shold(usec) - < 4999 - < 4294967295 : 2 : DMM : 60 : 2024 Mar 28 : FALSE : 9 : 9 : 9 : 9 (usec): 0 (usec): 0</pre>	Bin Counter 58 0
Bin Number Bin Three I 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Max Frame Delay(usec) Min Inter FD Variation Max Inter FD Variation Avg Inter FD Variation	<pre>shold(usec) - < 4999 - < 4294967295 : 2 : DMM : 60 : 2024 Mar 28 : FALSE : 9 : 9 : 9 (usec): 0 (usec): 0 (usec): 0 (usec): 0</pre>	Bin Counter 58 0
Bin Number Bin Three Bin Three 1 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Max Frame Delay(usec) Min Inter FD Variation Max Inter FD Variation Avg Inter FD Variation	<pre>shold(usec) - < 4999 - < 4294967295 : 2 : DMM : 60 : 2024 Mar 28 : FALSE : 9 : 9 : 9 : 9 (usec): 0 (usec): 0 (usec): 0</pre>	Bin Counter 58 0
Bin Number Bin Three I 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type Elapsed time (sec) End Time Suspect Flag Min Frame Delay (usec) Max Frame Delay (usec) Max Frame Delay (usec) Min Inter FD Variation Max Inter FD Variation Avg Inter FD Variation Avg Inter FD Variation	<pre>shold(usec) - < 4999 - < 4294967295 : 2 : DMM : 60 : 2024 Mar 28 : FALSE : 9 : 9 : 9 (usec): 0 (usec): 0 (usec): 0 (usec): 0 Y BINS</pre>	Bin Counter 58 0 18:52:12
Bin Number Bin Three I 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Max Frame Delay(usec) Min Inter FD Variation Max Inter FD Variation Avg Inter FD Variation Avg Inter FD Variation FRAME DELAY Bin Number Bin Three	<pre>shold(usec) - < 4999 - < 4294967295 : 2 : DMM : 60 : 2024 Mar 28 : FALSE : 9 : 9 : 9 : 9 (usec): 0 (usec): 0 (usec): 0 (usec): 0 Y BINS shold(usec)</pre>	Bin Counter 58 0 18:52:12 Bin Counter
Bin Number Bin Three I 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Max Frame Delay(usec) Max Inter FD Variation Max Inter FD Variation	<pre>shold(usec) - < 4999 - < 4294967295 : 2 : DMM : 60 : 2024 Mar 28 : FALSE : 9 : 9 : 9 (usec): 0 (usec): 0 (usec): 0 Y BINS shold(usec) - < 4999</pre>	Bin Counter 58 0 18:52:12 Bin Counter 60
Bin Number Bin Three I 0 2 5000 RMEP ID : 8001 Measurement ID Measurement Type Elapsed time(sec) End Time Suspect Flag Min Frame Delay(usec) Max Frame Delay(usec) Max Frame Delay(usec) Min Inter FD Variation Max Inter FD Variation Max Inter FD Variation Max Inter FD Variation Avg Inter FD Variation Sumber Bin Three 1 0 2 5000	<pre>shold(usec) - < 4999 - < 4294967295 : 2 : DMM : 60 : 2024 Mar 28 : FALSE : 9 : 9 : 9 : 9 (usec): 0 (usec): 0 (usec): 0 (usec): 0 Y BINS shold(usec) - < 4999 - < 9999</pre>	Bin Counter 58 0 18:52:12 Bin Counter 60 0

INTER-FRAME DELAY BINS						
Bin Number	Bin Thresh	nold(usec)	Bin Counter			
==================	=======================================					
1	0	- < 4999	59			
2	5000	- < 4294967295	0			
1 2	0 5000	- < 4999 - < 4294967295	59 0			

Implementation Examples

UP MEP (User-Provided MEP):

- Scenario: To monitor the performance of Ethernet services between two customer locations.
- Use Case: Configure Y.1731 subinterface cross-connect with UP MEPs to monitor the performance of Ethernet services from the customer edge (CE) routers at each location. This allows the service provider to ensure service quality and troubleshoot any performance issues effectively.

Down MEP (Provider-Provided MEP):

- Scenario: To offer Ethernet services to multiple customers across its network infrastructure.
- Use Case: Configure Y.1731 subinterface cross-connect with Down MEPs on provider edge (PE) routers to monitor the performance of Ethernet services provided to individual customers. This allows the service provider to proactively detect and address any service degradation or faults, ensuring high service availability and customer satisfaction.

Default Untagged (Single-Tagged VLAN):

- Scenario: To offer Ethernet services over a single-tagged VLAN to simplify network configuration and management.
- Use Case: Configure Y.1731 subinterface cross-connect with default untagged settings on PE routers for Ethernet services provisioned over single-tagged VLANs. This enables the service provider to monitor the performance of Ethernet services efficiently while minimizing configuration complexity and overhead.

Glossary

The following provides definitions for key terms or abbreviations and their meanings used throughout this document:

Key Terms/Acronym	Description
Connectivity Fault Management (CFM)	CFM is a protocol used to detect, verify, and isolate connectivity faults in a network. It operates at the data link layer and is designed to monitor Ethernet networks.
Cross-connect Interface	A cross-connect interface is a network element or component responsible for forwarding traffic between different network segments or services. In the context of CFM, the cross-connect interface refers to the specific interfaces where CFM functionality is deployed and monitored.
Fault Detection	CFM over Cross-connect Interface enables the detection of faults such as link failures, excessive delay, or connectivity disruptions within the cross-connect infrastructure. By exchanging CFM messages and monitoring predefined parameters, network operators can identify and respond to faults promptly.
Fault Isolation and Diagnostics	Upon detecting a fault, CFM over Cross-connect Interface facilitates the isolation of the affected segment or service and provides diagnostic information to pinpoint the root cause of the issue. This information aids in troubleshooting and resolving network problems efficiently.

CHAPTER 4 Y.1731 and CFM Over EVPN ELINE Single Home

Overview

The Single Home EVPN ELINE Y.1731 CFM over Sub-interface feature enables the monitoring and management of Ethernet Virtual Private Network (EVPN) E-Line services using the Y.1731 Connectivity Fault Management (CFM) protocol over sub-interfaces. This feature enhances fault detection and performance monitoring capabilities for EVPN E-Line services, allowing network operators to ensure high availability and reliability of their networks. By extending Y.1731 CFM functionality to sub-interfaces in single home EVPN E-Line deployments, this feature provides comprehensive end-to-end visibility and control, enabling proactive fault detection, isolation, and troubleshooting.

Feature Characteristics

- Utilizes sub-interfaces to partition Ethernet traffic within the Single Home EVPN ELINE architecture, enabling efficient service delivery and management.
- Implements EVPN ELINE architecture with single-homing capabilities, facilitating the creation of Ethernet Virtual Private Networks with simplified configurations and reduced complexity.
- Provides robust fault detection mechanisms to identify connectivity issues, link failures, and service disruptions in Ethernet networks.

Benefits

- Provides detailed insights into Ethernet service performance, enabling proactive monitoring and optimization of network resources.
- Minimizes service downtime by promptly detecting and resolving faults, ensuring uninterrupted service delivery and customer satisfaction.
- Optimizes network resource utilization and bandwidth allocation by identifying and addressing connectivity issues in a timely manner.
- Facilitates rapid fault identification and isolation, accelerating troubleshooting processes and reducing mean time to repair (MTTR).
- Ensures compliance with Service Level Agreements (SLAs) by maintaining service quality metrics within defined thresholds and objectives.

Prerequisites

Ensure that the network devices (routers, switches) support Y.1731 CFM functionality and Single Home EVPN ELINE configuration.

Verify that the devices are running compatible software versions that include support for these features.

Configuration

Configure Single Home EVPN ELINE Y.1731 CFM over Sub-interface for enhanced fault management in EVPN networks.

Topology

The topology consists of two Customer Edge devices (CE1 and CE2) connected to Provider Edge devices (PE1 and PE2) through sub-interfaces. The Provider Edge devices are interconnected through Provider devices (P1 and P2). Y.1731 functionality is implemented over these sub-interfaces, allowing for fault detection and performance monitoring of Ethernet connectivity between the customer sites.



Figure 4-13: EVPN ELINE Over Sub-interface-Single Home

Perform the following configurations to configure Single Home EVPN ELINE Y.1731 CFM over Sub-interface:

1. On Customer Edge (CE) Nodes (CE1 and CE2), configure the interface xe1 and set it as a switchport with a load interval of (30 seconds):

```
CE1(config)#interface xe1
CE1(config-if)#switchport
CE1(config-if)#load-interval 30
CE1(config-if)#commit
```

CE1 (config-if) #exit

Note: Similarly follow the same steps to configure xe11(CE1) and xe12(CE2).

```
2. Create sub-interface (xe1.2001) adding the VLAN:
```

```
CE1(config)#interface xe1.2001 switchport
CE1(config-if)#encapsulation dot1q 2028
CE1(config-if)#commit
CE1(config-if)#exitCE1(config)#interface xe11.2001 switchport
CE1(config-if)#encapsulation dot1g 2028
```

```
CE1(config-if)#encapsulation dot1q 2028
CE1(config-if)#commit
CE1(config-if)#exit
```

3. Set up a cross-connect named (test100), specifying in and out interfaces:

```
CE1(config)#cross-connect test100
CE1(config-xc)#interface xe1.2001
CE1(config-xc)#interface xe11.2001
CE1(config-xc)#commit
```

- 4. Perform the following on PE1:
 - 1. Configure CFM related hardware profiles:

```
PE1(config)# hardware-profile filter cfm-domain-name-str enable
PE1(config)# hardware-profile statistics cfm-lm enable
PE1(config)# hardware-profile statistics cfm-ccm enable
PE1(config)#hardware-profile statistics cfm-slm enable
```

2. Configure the loopback interface with a secondary IP address(1.1.1.1/32):

```
PE1(config)#interface lo
PE1(config-if)#ip address 1.1.1.1/32 secondary
PE1(config-if)#commit
PE1(config-if)#exit
```

3. Configure LDP targeted peers:

```
PE1(config) #router ldp
PE1(config-router) #targeted-peer ipv4 4.4.4.4
PE1(config-router-targeted-peer) #exit-targeted-peer-mode
PE1(config-router) #commit
PE1(config-router) exit
```

4. Configure interface xe2 with an IP address (192.168.10.1/24) and enable LDP:

```
PE1(config)#interface xe2
PE1(config-if)#load-interval 30
PE1(config-if)#ip address 192.168.10.1/24
PE1(config-if)#label-switching
PE1(config-if)#enable-ldp ipv4
PE1(config-if)#commit
PE1(config-if)#exit
```

5. Configure OSPF routing, specify the OSPF router ID as (1.1.1.1), enable BFD on all interfaces, define the network (1.1.1.1/32) in area (0.0.0.0), and define the network (192.168.10.0/24) in area (0.0.0.0):

```
PE1(config) #router ospf 1
PE1(config-router) #ospf router-id 1.1.1.1
PE1(config-router) #bfd all-interfaces
PE1(config-router) #network 1.1.1.1/32 area 0.0.0.0
PE1(config-router) #network 192.168.10.0/24 area 0.0.0.0
PE1(config-router) #commit
PE1(config-router) #exit
```

6. Enable EVPN MPLS globally and configure VTEP IP:

```
PE1(config)# evpn mpls enable
PE1(config)# commit
PE1(config)# evpn mpls vtep-ip-global 1.1.1.1
PE1(config)# commit
```

7. Configure BGP with the remote PE devices and activate EVPN:

```
PE1(config) # router bgp 100
PE1(config-router) # neighbor 4.4.4.4 remote-as 100
PE1(config-router) # neighbor 4.4.4.4 update-source lo
PE1(config-router) # address-family l2vpn evpn
PE1(config-router-af) # neighbor 4.4.4.4 activate
PE1(config-router-af) # exit
PE1(config-router) # exit
PE1(config) # commit
```

8. Configure MAC VRF with the appropriate RD and RT:

```
PE1(config)# mac vrf vrf2
PE1(config-vrf)# rd 1.1.1.1:2
PE1(config-vrf)# route-target both 2:2
PE1(config-vrf)# exit
```

9. Map the EVPN instance and VRF, specifying the EVPN ID:

```
PE1(config) # evpn mpls id 2 xconnect target-mpls-id 52
PE1(config-evpn-mpls) # host-reachability-protocol evpn-bgp vrf2
```

```
PE1(config-evpn-mpls)# evi-name test2
PE1(config-evpn-mpls)# commit
PE1(config-router-af)# exit
```

10. Configure access ports on PE1:

```
PE1(config)# interface xe1.2001 switchport
PE1(config-if)# encapsulation dot1q 2028
PE1(config-if)# access-if-evpn
PE1(config-acc-if-evpn)# map vpn-id 2
PE1(config-acc-if-evpn)# commit
```

11. Configure CFM MEP on PE1, define the FCM domain (12346), create MA, configure MEP, and configure Remote MEP Auto-discovery,set CC Interval 10ms:

```
PE1(config) # ethernet cfm domain-type character-string domain-name12346
level 7 mip-creation default
PE1(config-ether-cfm) # service ma-type string ma-name 124
PE1(config-ether-cfm-ma) # ethernet cfm mep up mpid 20 active true
xe1.2001 vlan 2028
PE1(config-ether-cfm-ma-mep) # cc multicast state enable
PE1(config-ether-cfm-ma-mep) # exit-ether-ma-mep-mode
PE1(config-ether-cfm-ma) # rmep auto-discovery enable
PE1(config-ether-cfm-ma) # cc interval 10ms
PE1(config-ether-cfm-ma) # exit-ether-ma-mode
PE1(config-ether-cfm-ma) # exit-ether-ma-mode
PE1(config-ether-cfm-ma) # exit-ether-ma-mode
PE1(config-ether-cfm-ma) # commit
```

12. Provide CFM configuration, define a delay measurement profile named DM, set the measurement interval to 1 second, specify the number of intervals stored as 2, configure the message period as 1 second, define a loss measurement profile named LM, set the measurement type to LMM, set the measurement interval to 1 second, specify the number of intervals stored as 3, define a service level measurement profile named SLM, set the measurement type to SLM:

```
PE1(config) # ethernet cfm delay-measurement profile-name DM
PE1(config-cfm-dm) # measurement-interval 1
PE1(config-cfm-dm) # intervals-stored 2
PE1(config-cfm-dm) # message-period 1s
PE1(config-cfm-dm) # commit
PE1(config) # ethernet cfm loss-measurement profile-name LM
PE1(config-cfm-lm) # measurement-type lmm
PE1(config-cfm-lm) # measurement-interval 1
PE1(config-cfm-lm)# intervals-stored 3
PE1(config-cfm-lm) # message-period 1s
PE1(config-cfm-lm) # commit
PE1(config)# ethernet cfm loss-measurement profile-name SLM
PE1(config-cfm-lm) # measurement-type slm
PE1(config-cfm-lm) # measurement-interval 1
PE1(config-cfm-lm)# intervals-stored 3
PE1(config-cfm-lm) # message-period 1s
PE1(config-cfm-lm) # commit
```

Configuration Snapshot:

CE1:

```
interface xe1
switchport
load-interval 30
!
```

```
interface xe1.2001 switchport
encapsulation dot1q 2028
!
interface xe11.2001 switchport
encapsulation dot1q 2028
!
cross-connect test100
interface xe1.2001
interface xe11.2001
```

CE2:

```
interface xe1
switchport
load-interval 30
!
interface xe1.2001 switchport
encapsulation dot1q 2028
!
interface xe12.2001 switchport
encapsulation dot1q 2028
!
cross-connect test100
interface xe1.2001
interface xe12.2001
```

PE1:

```
interface lo
ip address 1.1.1.1/32 secondary
1
router ldp
targeted-peer ipv4 4.4.4.4
exit-targeted-peer-mode
1
interface xe2
load-interval 30
ip address 192.168.10.1/24
label-switching
enable-ldp ipv4
!
router ospf 1
ospf router-id 1.1.1.1
bfd all-interfaces
network 1.1.1/32 area 0.0.0.0
network 192.168.10.0/24 area 0.0.0.0
evpn mpls enable
evpn mpls vtep-ip-global 1.1.1.1
1
router bgp 100
neighbor 4.4.4.4 remote-as 100
neighbor 4.4.4.4 update-source lo
address-family 12vpn evpn
neighbor 4.4.4.4 activate
exit
!
```

```
mac vrf vrf2
    rd 1.1.1.1:2
    route-target both 2:2
    1
    evpn mpls id 2
    xconnect target-mpls-id 52
    host-reachability-protocol evpn-bgp vrf2
    evi-name test2
    interface xel
    switchport
    load-interval 30
    1
    interface xel.2001 switchport
     encapsulation dot1q 2028
     access-if-evpn
      map vpn-id 2
    ethernet cfm domain-type character-string domain-name 12346 level 7
    mipcreation none
      service ma-type string ma-name 124
        ethernet cfm mep up mpid 20 active true xe1.2001 vlan 2028
          cc multicast state enable
          exit-ether-ma-mep-mode
        rmep auto-discovery enable
        cc interval 10ms
        exit-ether-ma-mode
    ethernet cfm loss-measurement profile-name SLM
    measurement-type slm
    measurement-interval 1
    intervals-stored 3
    message-period 1s
    1
    ethernet cfm loss-measurement profile-name LM
    measurement-type lmm
    measurement-interval 1
    intervals-stored 3
    message-period 1s
    1
    ethernet cfm delay-measurement profile-name DM
    measurement-interval 1
    intervals-stored 2
    message-period 1s
PE2:
    interface lo
     ip address 4.4.4/32 secondary
    router ldp
     targeted-peer ipv4 1.1.1.1
    interface xe2
     load-interval 30
     ip address 192.168.30.2/24
     label-switching
     enable-ldp ipv4
    router ospf 1
```

```
bfd all-interfaces
 network 4.4.4.4/32 area 0.0.0.0
 network 192.168.30.0/24 area 0.0.0.0
evpn mpls enable
evpn mpls vtep-ip-global 4.4.4.4
1
router bgp 100
neighbor 1.1.1.1 remote-as 100
neighbor 1.1.1.1 update-source lo
address-family 12vpn evpn
neighbor 1.1.1.1 activate
exit
mac vrf vrf2
rd 4.4.4:2
route-target both 2:2
1
evpn mpls id 2 xconnect target-mpls-id 52
host-reachability-protocol evpn-bgp vrf2
evi-name test2
interface xel
switchport
load-interval 30
1
interface xel.2001 switchport
 encapsulation dot1q 2028
  access-if-evpn
   map vpn-id 52
ethernet cfm domain-type character-string domain-name 12346 level 7
mipcreation none
service ma-type string ma-name 124
  ethernet cfm mep up mpid 10 active true xe1.2001 vlan 2028
    cc multicast state enable
    ethernet cfm loss-measurement reply lmm
  ethernet cfm delay-measurement reply dmm
  exit-ether-ma-mep-mode
rmep auto-discovery enable
cc interval 10ms
exit-ether-ma-mode
interface lo
 ip address 2.2.2/32 secondary
router ldp
 transport-address ipv4 2.2.2.2
interface xe2
 ip address 192.168.10.2/24
 label-switching
 enable-ldp ipv4
interface xel
 ip address 192.168.20.1/24
 label-switching
```

P1:

enable-ldp ipv4

```
router ospf 1
ospf router-id 2.2.2.2
bfd all-interfaces
network 2.2.2.2/32 area 0.0.0.0
network 192.168.10.0/24 area 0.0.0.0
network 192.168.20.0/24 area 0.0.0.0
```

P2:

```
interface lo
  ip address 3.3.3.3/32 secondary
```

```
router ldp
transport-address ipv4 3.3.3.3
```

```
interface xe1
ip address 192.168.20.2/24
label-switching
enable-ldp ipv4
```

```
interface xe2
ip address 192.168.30.1/24
label-switching
enable-ldp ipv4
```

```
router ospf 1
ospf router-id 3.3.3.3
bfd all-interfaces
network 3.3.3.3/32 area 0.0.0.0
network 192.168.20.0/24 area 0.0.0.0
network 192.168.30.0/24 area 0.0.0.0
```

Validation

Verify the EVPN xconnect status.

```
PE1#show evpn mpls xconnect
EVPN Xconnect Info
_____
AC-AC: Local-Cross-connect
AC-NW: Cross-connect to Network
AC-UP: Access-port is up
AC-DN: Access-port is down
NW-UP: Network is up
NW-DN: Network is down
NW-SET: Network and AC both are up
Local
              Remote
                                    Connection-Details
_____
VPN-ID
        EVI-Name
                MTU VPN-ID
                           Source Destination
PE-IP
         MTU
               Type
                       NW-Status
_____
2 test2 1500 52 xe1.2001 --- Single Homed Port ---
4.4.4.4 1500 AC-NW NW-SET
```

Verify the CFM Errors:

Domain Name	MA Name	Level	VLAN	MEPID	Defects
12346	124	7	2028	20	

Verify the RMEP is learned or not.

PE1#show	ethernet	cfm mainte	nance-poir	nts remote	domair	12346	
MA_NAME	MEPID	RMEPID	LEVEL	Rx CCM	RDI	PEER-MAC	TYPE
124	20	10	7	Yes	False	e8c5.7ae3.37ee	Learnt

Verify the Ping:

PE1#ping ethernet mac e8c5.7ae3.37ee unicast source 20 domain 12346 ma 124 success rate is 100 (5/5)

Verify the local whether Local MEP is installed or not:

PE1#show ethernet cfm errors domain 12346

PE1#show ethernet cfm maintenance-points local mep domain 12346 ma-name 126 MPID Dir Lvl VLAN CC-Stat HW-Status CC-Intvl MAC-Address Def Port MD Name 124 Up 7 2028 Enable Installed 10 ms e8c5.7afe.fae9 F xe1.2001 12346

Verify the ethernet cfm ma status domain is active or not.

PE1#show ethernet cfm ma status domain 12346 ma-name 124 MA NAME STATUS 124 Active

Verify the Ping:

PE1#ping ethernet mac e8c5.7ae3.37ee unicast source 20 domain 12346 ma 124 success rate is 100 (5/5)

Verify the Traceroute:

PE1#traceroute ethernet e8c5.7ae3.37ee mepid 20 domain 12346 ma 124 MP Mac Hops Relay-action Ingress/Egress Ingress/Egress action e8c5.7ae3.37ee 1 RlyHit Ingress IngOK

Verify the Delay-measurement:

PE1#delay-measurement type proactive profile-name DM rmep 10 mep 20 domain 12346 ma 124 PE1#2024 Apr 10 13:35:37.236 : PE1: ONMD : INFO : [CFM_PM_SESSION_INFO_5]: CFM Frame Delay Measurement session started for MEP Id 20 and RMEP Id 10 PE2-7033#show ethernet cfm delay-measurement mep 20 domain 12346 ma-name 124 MD : 12346 MA : 124 MEP : 20 VLAN ID : 10

```
Interface : po1000.10
Peer MAC Address : 00cc.dd00.0000
CURRENT:
_____
RMEP ID : 10
Measurement ID : 1
Measurement Type : DMM
Elapsed time(sec) : 53
Start Time : 2024 Apr 10 13:35:37
Suspect Flag : FALSE
Min Frame Delay(usec) : 19
Max Frame Delay(usec) : 20
Avg Frame Delay(usec) : 19
Min Inter FD Variation(usec): 0
Max Inter FD Variation(usec): 1
Avg Inter FD Variation(usec): 0
FRAME DELAY BINS
Bin Number
                                    Bin Counter
             Bin Threshold(usec)
_____
             0 - < 4999
1
                                       52
2
             5000 - < 9999
                                       0
3
             10000 - < 4294967295
                                       0
INTER-FRAME DELAY BINS
Bin Number
              Bin Threshold(usec)
                                    Bin Counter
_____
               0 - < 4999
1
                                       51
               5000 - < 4294967295
2
                                       0
```

Verify the Loss-measurement:

PE1#loss-measurement type proactive profile-name LM rmep 10 mep 20 domain 12346 ma 124 PE1#2024 Apr 10 13:35:05.345 : PE1 : ONMD : INFO : [CFM_DEFECT_INFO_5]: CFM Frame Loss Measurement started for MEP:20 MA:124 MD:12346 PE1#show ethernet cfm loss-measurement mep 20 domain 12346 ma-name 124

```
MEP: 20 MA: 124
CURRENT:
 Measurement ID : 1
                            : False
  Suspect
  Measurement Type
                             : lmm
 Elapsed time(sec)
                            : 55
  Start Time
                            : 2024 Apr 10 13:37:05
  Near End loss
                            : 0
  Far End loss
                             : 0
  Near End accumulated loss : 0
  Far End accumulated loss : 0
  Near End frame loss ratio : 0
  Far End frame loss ratio : 0
Far End frame loss ratio : 0
HISTORY:
Measurement ID : 1
Suspect : FALSE
```

Measurement Type : 1mm Elapsed time(sec) : 60 End Time : 2024 Apr 10 13:36:05 Near End loss : 0 Far End loss : 0 Near End accumulated loss : 0 Far End frame loss ratio : 0 Far End frame loss ratio : 0 Near End frame loss ratio min : 0 Far End frame loss ratio min : 0 Far End frame loss ratio min : 0 Near End frame loss ratio max : 0 Far End frame loss ratio max : 0

Verify the Synthetic Loss Measurement:

Far End frame loss ratio max : 0

PE1#loss-measurement type proactive profile-name SLM rmep 10 mep 20 domain 12346 ma 124 PE1#2024 Apr 10 13:40:15.587 : PE1 : ONMD : INFO : [CFM DEFECT INFO 5]: CFM Frame Loss Measurement started for MEP:20 MA:124 MD:12346 PE1#show ethernet cfm loss-measurement mep 20 domain 12346 ma-name 124 MEP: 20 MA: 124 CURRENT: Measurement ID : 2 Suspect : False : slm Measurement Type Elapsed time(sec) : 17 Start Time : 2024 Apr 10 13:41:15 : 0 Near End loss Far End loss : 0 Near End accumulated loss : 0 Far End accumulated loss • 0 Near End frame loss ratio : 0 Far End frame loss ratio : 0 HISTORY: Measurement ID : 1 : False Suspect : slm Measurement Type Elapsed time(sec) : 60 End Time : 2024 Apr 10 13:41:15 Near End loss : 0 Far End loss • 0 Near End accumulated loss : 0 : 0 Far End accumulated loss Near End frame loss ratio : 0 Far End frame loss ratio : 0 Near End frame loss ratio min : 0 Far End frame loss ratio min : 0 Near End frame loss ratio max : 0
Implementation Examples

Enterprise Connectivity Monitoring:

Scenario: A large enterprise operates multiple branch offices connected via Ethernet services provided by a service provider network.

Use Case: Y.1731 CFM over sub-interface using Single Home EVPN ELINE enables the enterprise to monitor the connectivity and performance of its branch office connections. It facilitates proactive fault detection and management, ensuring reliable and uninterrupted communication between the headquarters and branch offices.

Service Provider Network Operations:

Scenario: A service provider manages a diverse range of Ethernet services for its enterprise customers, including VPNs, Internet access, and cloud connectivity.

Use Case: Y.1731 CFM over sub-interface using Single Home EVPN ELINE empowers the service provider to deliverhigh-quality Ethernet services with enhanced fault management capabilities. It enables the provider to quickly identify and resolve connectivity issues, minimize service downtime, and maintain customer satisfaction.

Glossary

The following provides definitions for key terms or abbreviations and their meanings used throughout this document:

Key Terms/Acronym	Description
Y.1731	A standard defined by the International Telecommunication Union Telecommunication Standardization Sector (ITU-T) that specifies performance monitoring and fault management for Ethernet-based networks.
Sub-interface	A logical division of a physical interface, typically used to separate traffic based on VLANs or other criteria. In this context, sub-interfaces are employed to establish distinct connections within the EVPN ELINE SH topology.
EVPN	Ethernet Virtual Private Network (VPN) is a technology that enables the creation of virtual private networks over an Ethernet-based infrastructure. It provides multi-tenancy and allows for the segmentation of traffic in service provider networks.
ELINE	ELINE is a type of EVPN service that provides point-to-point Ethernet connectivity between two sites.
Single Home (SH)	Refers to the configuration where a Customer Edge device (CE) is connected to only one Provider Edge device (PE) within an EVPN setup. It contrasts with the multi-homed configuration, where a CE may be connected to multiple PEs.
Maintenance End Point (MEP)	MEP is a CFM entity that resides at the edge of a CFM domain. It is responsible for generating and transmitting CFM protocol packets to detect faults and collect performance data.
Maintenance Domain (MD)	MD is a logical grouping of MEPs within a CFM network. MEPs within the same MD can communicate with each other to perform CFM functions such as fault detection and performance monitoring.
Maintenance Association(MA)	MA is a collection of MEPs associated with a specific service or set of services. It defines the scope of CFM operations within a maintenance domain.

Maintenance Point Identifier (MPID)	MPID is a unique identifier assigned to each MEP within a maintenance association. It is used to distinguish between different MEPs within the same MA.
Service Level Measurement (SLM)	SLM is a CFM function used to measure the loss characteristics of a network path. It collects data on packet loss, delay, and jitter to assess the quality of service provided by the network.
Loopback Message Generation (LMM)	LMM is a CFM function used to test end-to-end connectivity by generating loopback messages. These messages are transmitted from a MEP and looped back to the same MEP to verify bidirectional communication.
Delay Measurement Message (DMM)	DMM is a CFM function used to measure the one-way delay of packets transmitted across a network. It helps assess the performance of the network in terms of packet delivery time.
Continuity Check (CC)	CC is a CFM function used to verify the continuity of a service or network path by periodically sending continuity check messages between MEPs. It helps detect connectivity faults such as link failures or misconfigurations.

CHAPTER 5 Y.1731 and CFM Over EVPN-ELINE Multihome

Overview

The Multi Home EVPN ELINE Y.1731 CFM over Sub-interface feature enables the monitoring and management of Ethernet Virtual Private Network (EVPN) E-Line services using the Y.1731 Connectivity Fault Management (CFM) protocol over sub-interfaces. This feature enhances fault detection and performance monitoring capabilities for EVPN E-Line services, allowing network operators to ensure high availability and reliability of their networks. By extending Y.1731 CFM functionality to sub-interfaces in multi home EVPN E-Line deployments, this feature provides comprehensive end-to-end visibility and control, enabling proactive fault detection, isolation, and troubleshooting.

CFM multi-homing allows Customer Edge (CE) device to connect more than one Provider Edge (PE) device. Multihoming ensures redundant connectivity. The redundant PE device ensures that there is no traffic disruption when there is a network failure.

Feature Characteristics

- Utilizes sub-interfaces to partition Ethernet traffic within the Multi home EVPN ELINE architecture, enabling efficient service delivery and management.
- Implements EVPN ELINE architecture with multi-homing capabilities, facilitating the creation of Ethernet Virtual Private Networks with simplified configurations and reduced complexity.
- Provides robust fault detection mechanisms to identify connectivity issues, link failures, and service disruptions in Ethernet networks.

Benefits

- Provides detailed insights into Ethernet service performance, enabling proactive monitoring and optimization of network resources.
- Minimizes service downtime by promptly detecting and resolving faults, ensuring uninterrupted service delivery and customer satisfaction.
- Optimizes network resource utilization and bandwidth allocation by identifying and addressing connectivity issues in a timely manner.
- Facilitates rapid fault identification and isolation, accelerating troubleshooting processes and reducing mean time to repair (MTTR).

Ensures compliance with Service Level Agreements (SLAs) by maintaining service quality metrics within defined thresholds and objectives.

Configuration

Configure Multi Home EVPN ELINE Y.1731 CFM over Sub-interface for enhanced fault management in EVPN networks.

Topology

The following topology consists of customer edge routers CE1 and CE2 with IPv2 Provider Edge routers PE1 and PE2. These are interconnected through the core router P in the IPv4 MPLS provider networks.



Figure 5-14: EVPN ELINE Over CFM Sub-interface

The following sessions displays the detailed information about configurations, and validations for CFM over subinterface.

1. Configure Loopback Interface on PE1.

```
PE1(#configure terminal
PE1(config)#interface lo
PE1(config-if)#ip address 1.1.1.1/32
PE1(config-if)#exit
PE1(config-if)#commit
```

2. Configure Global LDP for distributing MPLS labels in the network.

```
PE1(config)# router ldp
PE1(config-router)# router-id 1.1.1.1
PE1(config-router)# targeted-peer ipv4 7.7.7.7
PE1(config-router)# targeted-peer ipv4 8.8.8.8
PE1(config-router-targeted-peer)#exit
PE1(config-router)# exit
PE1(config)# commit
```

3. Enable EVPN over MPLS and set a global VTEP IP.

```
PE1(config)# evpn mpls enable
PE1(config)# commit
PE1(config)# evpn mpls vtep-ip-global 1.1.1.1
PE1(config)# commit
```

4. Configure the interfaces connecting to the network, enabling LDP and MPLS label switching.

```
PE1(config)# interface xe6
PE1(config-if)# ip address 10.1.0.1/16
PE1(config-if)# enable-ldp ipv4
PE1(config-if)# label-switching
```

```
PE1(config-if) # exit
PE1(config) # commit
```

5. Set up OSPF for IP routing within the network.

```
PE1(config)# router ospf 1
PE1(config-router)# ospf router-id 1.1.1.1
PE1(config-router)# network 1.1.1.1/32 area 0
PE1(config-router)# network 10.1.0.0/16 area 0
PE1(config-router)# exit
PE1(config)# commit
```

6. Set up BGP for EVPN to exchange MAC and IP information.

```
PE1(config)# router bgp 1
PE1(config-router)# neighbor 7.7.7.7 remote-as 1
PE1(config-router)# neighbor 7.7.7.7 update-source lo
PE1(config-router)# neighbor 8.8.8.8 remote-as 1
PE1(config-router)# address-family 12vpn evpn
PE1(config-router-af)# neighbor 7.7.7.7 activate
PE1(config-router-af)# neighbor 8.8.8.8 activate
PE1(config-router-af)# exit
PE1(config-router)# exit
PE1(config-router)# exit
PE1(config-router)# exit
```

7. Configure MAC VRF.

```
PE1(config)# mac vrf vrf2
PE1(config-vrf)# rd 1.1.1.1:2
PE1(config-vrf)# route-target both 2:2
PE1(config-vrf)# exit
PE1(config)# commit
```

8. Configure EVPN and map VRF.

```
PE1(config)# evpn mpls id 52 xconnect target-mpls-id 2
PE1(config-evpn-mpls)# host-reachability-protocol evpn-bgp vrf2
PE1(config)# commit
```

9. Configure access port on interface xe33.2

```
PE1(config-if)# interface xe33.2 switchport
PE1(config-if)# description access-side-int
PE1(config-if)# encapsulation dot1q 2
PE1(config-if)# access-if-evpn
PE1(config-access-if)# map vpn-id 52
PE1(config-access-if)# exit
PE1(config)# commit
```

10. Set up CFM to monitor connectivity within the network.

```
PE1(config) #hardware-profile filter cfm-domain- name-str enable
PE1(config) # ethernet cfm domain-type character-string domain-name 12346 level 7
mip-creation none
PE1(config-ether-cfm-mpls-md) # service ma-type string ma-name 124
PE1(config-ether-cfm-mpls-ma) # ethernet cfm mep up mpid 10 active true xe33.2
vlan 2
PE1(config-ether-cfm-mpls-ma-mep) #cc multicast state enable
PE1(config-ether-cfm-mpls-ma-mep) #exit-ether- ma-mep-mode
PE1(config-ether-cfm-mpls-ma) # rmep auto-discovery enable
PE1(config-ether-cfm-mpls-ma) #cc interval 10ms
PE1(config-ether-cfm-mpls-ma) #exit-ether-ma- mode
```

```
PE1(config)#exit
PE1(config)#commit
```

Note: Similarly follow the same steps to configure respective cfm mep up and other CFM features for PE2 and PE3.

Configuration Snapshot:

PE1:

```
T
interface lo
ip address 1.1.1.1/32
router ldp
router-id 1.1.1.1
targeted-peer 7.7.7.7
targeted-peer 8.8.8.8
I.
router ospf 1
router-id 1.1.1.1
network 1.1.1.1/32 area 0
network 10.1.0.0/16 area 0
router bgp 1
bgp log-neighbor-changes
neighbor 7.7.7.7 remote-as 1
 neighbor 7.7.7.7 update-source lo
 neighbor 8.8.8.8 remote-as 1
 neighbor 8.8.8.8 update-source lo
 1
 address-family 12vpn evpn
neighbor 7.7.7.7 activate
neighbor 8.8.8.8 activate
exit-address-family
evpn mpls enable
evpn mpls vtep-ip-global 1.1.1.1
hardware-profile filter cfm-domain-name-str enable
hardware-profile statistics cfm-ccm enable
1
interface xe6
ip address 10.1.0.1/16
enable-ldp ipv4
label-switching
vrf definition vrf2
rd 1.1.1.1:2
route-target both 2:2
1
evpn mpls id 52 xconnect target-mpls-id 2
host-reachability-protocol evpn-bgp vrf2
!
interface xe33.2 switchport
description access-side-int
encapsulation dot1q 2
 access-if-evpn
```

```
map vpn-id 52
    !
    ethernet cfm domain-type character-string domain-name 12346 level 7 mip-
    creation none
     service ma-type string ma-name 124
      ethernet cfm mep up mpid 10 active true xe33.2 vlan 2
       cc multicast state enable
       exit-ether-ma- mode
       rmep auto-discovery enable
       cc interval 10ms
       exit-ether-ma- mode
    !
P:
    !
    interface lo
     ip address 2.2.2/32
    1
    interface xe6
    ip address 10.1.0.2/16
    enable-ldp ipv4
    label-switching
    1
    interface xe21
     ip address 123.1.1.1/24
     enable-ldp ipv4
    label-switching
    !
    interface xe20
     ip address 124.1.1.1/24
     enable-ldp ipv4
    label-switching
    1
    router ldp
     router-id 2.2.2.2
    1
    router ospf 1
     router-id 2.2.2.2
     network 2.2.2/32 area 0
     network 10.1.0.0/16 area 0
     network 123.1.1.0/24 area 0
     network 124.1.1.0/24 area 0
    PE2:
    T
    interface lo
     ip address 7.7.7.7/32
    1
    interface xe21
     ip address 123.1.1.2/24
     enable-ldp ipv4
    label-switching
    !
    router ldp
     router-id 7.7.7.7/32
     targeted-peer ipv4 1.1.1.1
```

```
targeted-peer ipv4 8.8.8.8
    T
    router ospf 1
     router-id 7.7.7.7
     network 7.7.7.7/32 area 0
     network 123.1.1.0/24 area 0
    !
    router bgp 1
     bgp log-neighbor-changes
     neighbor 1.1.1.1 remote-as 1
     neighbor 1.1.1.1 update-source lo
     neighbor 8.8.8.8 remote-as 1
     neighbor 8.8.8.8 update-source lo
     address-family 12vpn evpn
     neighbor 1.1.1.1 activate
     neighbor 8.8.8.8 activate
     exit-address-family
    1
    evpn mpls enable
    evpn mpls vtep-ip-global 7.7.7.7
    hardware-profile filter evpn-mpls-mh enable
    evpn mpls multihoming enable
    vrf definition vrf2
     rd 7.7.7.7:2
     route-target both 2:2
    1
    interface Pol
     load-interval 30
     evpn multi-homed system-mac 0000.aaaa.bbbc
    interface Pol.2 switchport
     encapsulation dot1q 2
     access-if-evpn
     map vpn-id 2
    L
    interface xe5
     channel-group 1 mode active
    1
    ethernet cfm domain-type character-string domain-name 12346 level 7 mip-
    creation none
     service ma-type string ma-name 124
      ethernet cfm mep up mpid 20 active true pol.2 vlan 2
       cc multicast state enable
        ethernet cfm loss-measurement reply slm
        ethernet cfm delay-measurement reply dmm
       exit-ether-ma- mode
       rmep auto-discovery enable
       cc interval 10ms
       exit-ether-ma- mode
    1
PE3:
    L
    interface lo
     ip address 8.8.8.8/32
    1
```

```
interface xe20
ip address 124.1.1.2/24
enable-ldp ipv4
label-switching
interface xe4
channel-group 1 mode active
!
router ldp
router-id 8.8.8.8
targeted-peer ipv4 1.1.1.1
targeted-peer ipv4 7.7.7.7
T
router ospf 1
router-id 8.8.8.8
network 8.8.8.8/32 area 0
network network 124.1.1.0/24 area 0
1
router bgp 1
bgp log-neighbor-changes
neighbor 1.1.1.1 remote-as 1
neighbor 1.1.1.1 update-source lo
neighbor 7.7.7.7 remote-as 1
neighbor 7.7.7.7 update-source lo
 address-family 12vpn evpn
neighbor 1.1.1.1 activate
neighbor 7.7.7.7 activate
exit-address-family
1
evpn mpls enable
evpn mpls vtep-ip-global 8.8.8.8
hardware-profile filter evpn-mpls-mh enable
evpn mpls multihoming enable
vrf definition vrf2
rd 8.8.8.8:2
route-target both 2:2
T
interface Pol
 load-interval 30
evpn multi-homed system-mac 0000.aaaa.bbbc
1
interface Pol.2 switchport
encapsulation dot1q 2
access-if-evpn
 map vpn-id 2
T
ethernet cfm domain-type character-string domain-name 12346 level 7 mip-
creation none
 service ma-type string ma-name 124
  ethernet cfm mep up mpid 30 active true pol.2 vlan 2
   cc multicast state enable
    ethernet cfm loss-measurement reply slm
    ethernet cfm delay-measurement reply dmm
   exit-ether-ma- mode
   rmep auto-discovery enable
   cc interval 10ms
```

```
exit-ether-ma- mode !
```

Validation

The following are the validations for PE1 and PE2.

PE1

The following validation is for PE1.

Local				Rem	ote C	onnection-De	tails
=========== VPN-ID PE-IP	======= EVI-1 M	===== Name TU	М МІ Туре	======== !U VPN- NW-Stat	-ID So us	urce D	estination
52 7.7.7.7	 1	===== 500	15 AC-NW	======== 00 2 NW-SET	xe3	33.2 00	:00:00:aa:aa:bb:bb:00:00:00
8.8.8.8 PE1#show	1 ethernet	500 cfm	 errors	 domain	12346		
Domain Na	ame	Le	evel	MEPID	Defects		
12346		7		20			
PE1#show MA NAME	ethernet	cfm	ma sta STA	tus doma TUS	in 12346 ma	-name 124	
124			Act	ive			
PE1#show MEPID	ethernet RMEPID	cfm	mainte: LEVEL	nance-po Rx C	ints remote CM RDI	domain 1234 PEER-MAC	6 ma-name 124 TYPE
10 10	20 30		7 7	Yes Yes	False False	00aa.bb00. 00aa.dd00.	0002 Learnt 0003 Learnt

PE1#show ethernet cfm maintenance-points local mep domain 12346 ma-name 124 MPID Dir Lvl CC-Stat HW-Status CC-Intvl MAC-Address Def Port MD Name -----

10 Up 7 Enable Installed 100 ms 3417.ebe4.af22 F xe33.2 12346

PE1#ping ethernet mac 00aa.bb00.0002 unicast source 10 domain 12346 ma 124 success rate is 100 (5/5)

PE1#tracerouteethernet00aa.bb00.0002mepid10domain12346ma124MP MacHopsRelay-actionIngress/EgressIngress/Egressaction00aa.bb00.00021RlyHitIngressIngOK

PE1#ping ethernet mac 00aa.dd00.0003 unicast source 10 domain 12346 ma 124
success rate is 100 (5/5)
PE1-7011#traceroute ethernet 00aa.dd00.0003 mepid 10 domain 12346 ma 124
MP Mac Hops Relay-action Ingress/Egress Ingress/Egress action
00aa.dd00.0003 1 RlyHit Ingress IngOK

Verify Delay Measurement:

PE1#delay-measurement type proactive profile-name DM rmep 20 mep 10 domain 12346 ma 124 PE1-7011#2019 Feb 14 10:34:53.935 : PE2-7033 : ONMD : INFO : [CFM PM SESSION_INFO_5]: CFM Frame Delay Measurement session started for MEP Id 10 and RMEP Id 20

PE1#show ethernet cfm delay-measurement mep 10 domain 12346 ma-name 124 MD : 12346 MA : 124 MEP : 10 VLAN ID : 2 Interface : xe33.2 Peer MAC Address : 00aa.bb00.0002

CURRENT:

RMEP ID	: 20						
Measurement ID	•)		5101				
Measurement Ty	pe	:	DMM				
Elapsed time(s	ec)	:	16				
Start Time		:	2019	Feb	14	10:36	5:53
Suspect Flag		:	FALSE	C			
Min Frame Dela	y(usec)	:	23				
Max Frame Dela	y(usec)	:	24				
Avg Frame Dela	y(usec)	:	23				
Min Inter FD V	ariation(us	ec):	0				
Max Inter FD V	ariation(us	ec):	1				
Avg Inter FD V	ariation(us	ec):	0				
FR	AME DELAY B	INS					
Bin Number	Bin Thresho	ld(u	sec)			Bin	Counter
1	_					=== = == 1 6	
1	0	- < '	4999			10	
2	5000	- <	9999			0	
3	10000	- <	429496	57295	5	0	

INT	'ER-FRAME	DELAY BINS	
Bin Number =============	Bin Thre	shold(usec) ====================================	Bin Counter
1	0	- < 4999	15
2	5000	- < 4294967295	0
HISTORY STATIS	STICS		
 MD		: 12346	
MA		: 124	
MEP		: 10	
VLAN ID		: 2	
Interface		: xe33.2	
RMEP ID	: 20	_	
Measurement 1	D	: 1	
Measurement 1	ype	: DMM : 60	
Erapsed time	sec)	: 00 • 2019 Ech 14	10.35.53
Suspect Flag		• FALSE	10.33.33
Min Frame Del	av(usec)	: 23	
Max Frame Del	av(usec)	: 24	
Avg Frame Del	ay(usec)	: 23	
Min Inter FD	Variation	(usec): 0	
Max Inter FD	Variation	(usec): 1	
Avg Inter FD	Variation	(usec): 0	
E Bin Number	'RAME DELA Bin Thre	Y BINS shold(usec)	Bin Counter
1	0	- < 4999	59
2	5000	- < 9999	0
3	10000	- < 429496/295	0
INI	'ER-FRAME	DELAY BINS	
Bin Number =============	Bin Thre	shold(usec) ====================================	Bin Counter
1	0	- < 4999	58
2	5000	- < 4294967295	0
RMEP ID	: 20		
Measurement I	D	: 2	
Measurement 1	'ype	: DMM	
Elapsed time	(sec)	: 60	
End Time		: 2019 Feb 14	10:36:53
Suspect Flag		: FALSE	
Min Frame Del	.ay(usec)	: 23	
Max Frame Del	.ay(usec)	: 24	
Avg Frame Del	.ay(usec)	: 23	

Min Inter FD Max Inter FD Avg Inter FD	Variation(u Variation(u Variation(u	sec): sec): sec):	: 0 : 1 : 0		
F Bin Number	RAME DELAY Bin Thresh	BINS old(1	1sec)	Bin	Counter
1	0	- <	4999	60	
2	5000	- <	9999	0	
3	10000	- <	4294967295	0	
INTER-FRAME DELAY BINS Bin Number Bin Threshold(usec) Bin Counter					
1	0	- <	4999	59	
2	5000	- <	4294967295	0	

Verify Synthetic Loss Measurement:

PE1#loss-measurement type proactive profile-name SLM rmep 20 mep 10 domain 12346 ma 124 PE1#2019 Feb 14 10:35:17.758 : PE2-7011 : ONMD : INFO : [CFM DEFECT INFO 5]: CFM Frame Loss Measurement started for MEP:10 MA:124 MD:12346 PE1-7011#show ethernet cfm loss-measurement mep 10 domain 12346 ma-name 124 MEP: 10 MA: 124 CURRENT: Measurement ID : 3 : False Suspect Measurement Type : slm Elapsed time(sec) : 19 Start Time : 2019 Feb 14 10:37:16 Near End loss : 0 Far End loss : 0 Near End accumulated loss : 0 Far End accumulated loss : 0 Near End frame loss ratio : 0 Far End frame loss ratio : 0 HISTORY: Measurement ID : 1 Suspect : False : slm Measurement Type Elapsed time(sec) : 60 End Time : 2019 Feb 14 10:36:16 Near End loss : 0 Far End loss : 0 Near End accumulated loss : 0 Far End accumulated loss : 0 Near End frame loss ratio : 0 Far End frame loss ratio : 0 Near End frame loss ratio min : 0

```
Far End frame loss ratio min : 0
 Near End frame loss ratio max : 0
 Far End frame loss ratio max : 0
Measurement ID : 2
 Suspect
                      : False
 Measurement Type
                      : slm
 Elapsed time(sec)
                      : 60
 End Time
                      : 2019 Feb 14 10:37:16
 Near End loss
                      : 0
 Far End loss
                       : 0
 Near End accumulated loss : 0
 Far End accumulated loss
                       : 0
 Near End frame loss ratio : 0
 Far End frame loss ratio : 0
 Near End frame loss ratio min : 0
 Far End frame loss ratio min : 0
 Near End frame loss ratio max : 0
 Far End frame loss ratio max : 0
PE2/PE3
The following validations for PE2 and PE3.
PE2#show evpn mpls xconnect
EVPN Xconnect Info
_____
AC-AC: Local-Cross-connect
AC-NW: Cross-connect to Network
AC-UP: Access-port is up
AC-DN: Access-port is down
NW-UP: Network is up
NW-DN: Network is down
NW-SET: Network and AC both are up
Local
                          Remote Connection-Details
______ ____
______
         EVI-Name MTU
VPN-ID
                         VPN-ID
                                   Source
                                             Destination
PE-IP
         MTU Type NW-Status
_____
                    1500 52
2
                                  pol.2 --- Single Homed Port ---
1.1.1.1 1500 AC-NW NW-SET
PE2#show ethernet cfm errors domain 12346
Domain Name
              Level
                      MEPID
                              Defects
_____
               7
                       20
12346
                                . . . . .
PE2#show ethernet cfm ma status domain 12346 ma-name 124
MA NAME
                  STATUS
_____
   124
                   Active
```

PE2#show MPID Dir	ethernet cfm Lvl CC-Stat B	maintenance-po HW-Status CC-I:	ints local mep domain 12346 ma-name 124 ntvl MAC-Address Def Port MD Name
20 Up PE2#show MEPID	7 Enable : ethernet cfm RMEPID	Installed 100 maintenance-po LEVEL Rx C	ns 00aa.bb00.0002 F pol.2 12346 ints remote domain 12346 ma-name 124 CM RDI PEER-MAC TYPE
20	10	7 Yes	False 3417.ebe4.af22 Learnt
PE2#ping success	ethernet mac rate is 100	3417.ebe4.af22 (5/5)	unicast source 10 domain 12346 ma 124
PE2#trace	eroute etnerne	et 341/.ebe4.ar	22 mepid 10 domain 12346 ma 124
MP Mac	Hops	Relay-action	Ingress/Egress Ingress/Egress action
3417.ebe	1.af22 1	RlyHit	Ingress IngOK

CHAPTER 6 Y.1731 and CFM Over VPWS Sub-interface

Overview

Y.1731 Connectivity Fault Management (CFM) over Layer 2 Virtual Private Wire Service (VPWS) is a protocol and technology combination used for fault management in Layer 2 VPN networks. It allows for the detection and management of faults, performance monitoring, and fault localization within a VPWS network.

Feature Characteristics

- Facilitates end-to-end fault management across the VPWS network, covering provider and customer edges.
- Supports multi-level fault management, allowing operators to define different levels of fault detection and management for different parts of the network.
- Y.1731 CFM includes performance monitoring capabilities, such as delay measurement and frame loss measurement, to monitor service quality parameters.
- The protocol supports loopback and link trace functions to identify and troubleshoot faults within the VPWS network.

Benefits

- Enables rapid detection and localization of faults within the VPWS network, minimizing downtime and service disruptions.
- Provides performance monitoring capabilities, allowing to track key performance indicators and ensure service quality.
- Enhances network visibility by providing detailed fault and performance monitoring data, aiding in network troubleshooting and maintenance.

Prerequisites

Ensure the network devices participating in the L2VPN VPWS setup support Y.1731 CFM functionality. This includes the Provider Edge (PE) and Customer Edge (CE) devices.

Configuration

Configure Y.1731 CFM over sub-interface using L2VPN VPWS by defining the CFM domain, configuring service MEPs and MAs, and setting up cross-connects between primary and backup interfaces.

Topology

The topology consists of two Customer Edge devices (CE1 and CE2) connected to two Provider Edge devices (PE1 and PE2) via sub-interfaces (xe11 and xe12). The Provider Edge devices are interconnected through Provider Devices (P1 and P2). Y.1731 ethernet CFM is configured over these sub-interfaces to monitor and manage ethernet connectivity between the CE devices, ensuring fault detection and performance monitoring across the service provider's network.



Figure 6-15: L2VPN VPWS Y1731 CFM Over Sub-interface

Perform the following configurations to configure Y.1731 CFM over sub-interface using L2VPN VPWS:

1. On Customer Edge (CE) Nodes (CE1 and CE2), configure the interface xe1 and set it as a switchport with a load interval of (30 seconds):

```
CE1(config)#interface xe1
CE1(config-if)#switchport
CE1(config-if)#load-interval 30
CE1(config-if)#commit
```

- CE1 (config-if) #exit
- Note: Similarly follow the same steps to configure xe11(CE1) and xe12(CE2).
- 2. Create sub-interface (xe1.2001) adding the VLAN:

```
CE1(config)#interface xe1.2001 switchport
CE1(config-if)#encapsulation dot1q 2028
CE1(config-if)#commit
CE1(config-if)#exit
CE1(config)#interface xe11.2001 switchport
CE1(config-if)#encapsulation dot1q 2028
CE1(config-if)#commit
CE1(config-if)#exit
```

3. Set up a cross-connect named (test100), specifying in and out interfaces:

```
CE1(config)#cross-connect test100
CE1(config-xc)#interface xe1.2001
CE1(config-xc)#interface xe11.2001
CE1(config-xc)#commit
```

- 4. Perform the following on PE1:
 - 1. Configure CFM related hardware profiles:

```
PE1(config)# hardware-profile filter cfm-domain-name-str enable
PE1(config)# hardware-profile statistics cfm-lm enable
PE1(config)# hardware-profile statistics cfm-ccm enable
PE1(config)#hardware-profile statistics cfm-slm enable
```

2. Configure the loopback interface with a secondary IP address(1.1.1.1/32):

```
PE1(config)#interface lo
PE1(config-if)#ip address 1.1.1.1/32 secondary
PE1(config-if)#commit
PE1(config-if)#exit
```

3. Configure LDP targeted peers:

```
PE1(config) #router ldp
PE1(config-router) #targeted-peer ipv4 4.4.4.4
PE1(config-router-targeted-peer) #exit-targeted-peer-mode
PE1(config-router) #commit
PE1(config-router) exit
```

4. Configure interface xe2 with an IP address (192.168.10.1/24) and enable LDP:

```
PE1(config)#interface xe2
PE1(config-if)#load-interval 30
PE1(config-if)#ip address 192.168.10.1/24
PE1(config-if)#label-switching
PE1(config-if)#enable-ldp ipv4
PE1(config-if)#commit
PE1(config-if)#exit
```

5. Configure OSPF routing, specify the OSPF router ID as (1.1.1.1), enable BFD on all interfaces, define the network (1.1.1.1/32) in area (0.0.0.0), and define the network (192.168.10.0/24) in area (0.0.0.0):

```
PE1(config) #router ospf 1
PE1(config-router) #ospf router-id 1.1.1.1
PE1(config-router) #bfd all-interfaces
PE1(config-router) #network 1.1.1.1/32 area 0.0.0.0
PE1(config-router) #network 192.168.10.0/24 area 0.0.0.0
PE1(config-router) #commit
PE1(config-router) #exit
```

```
6. Set up an L2VPN pseudowire (test1) between PE1 and PE2.
PE1(config) #mpls l2-circuit test1 2001 4.4.4.4
PE1(config-pseudowire) #commit
PE1(config-pseudowire) #exit
```

7. Configure sub-interface (xe1.2001) as an access interface for VPWS.

```
PE1(config)#interface xe1.2001 switchport
PE1(config-if)#encapsulation dot1q 2028
PE1(config-if)#access-if-vpws
PE1(config-acc-if-vpws)#mpls-12-circuit test1 primary
PE1(config-acc-if-vpws)#commit
PE1(config-acc-if-vpws)#exit
```

- 8. Configure Up-mep CFM domain:
 - Set the domain type as a character string with the domain name (12346) and (level 7)
 - Specify the MA type as a string with the MA name (124)
 - Associate the MA with (VLAN 2028)
 - Set up a MEP with MEP ID (20) as active on interface (xe1.2001)
 - Enable multicast state for continuity check, and auto-discovery of RMEPs
 - Set the continuity check interval to (10 milliseconds)

```
PE1(config) #ethernet cfm domain-type character-string domain-name
12346 level 7 mip-creation none
PE1(config-ether-cfm) # service ma-type string ma-name 124
PE1(config-ether-cfm-ma) #ethernet cfm mep up mpid 20 active true
xel.2001 vlan 2028
PE1(config-ether-cfm-ma-mep) #cc multicast state enable
PE1(config-ether-cfm-ma-mep) #exit-ether-ma-mep-mode
PE1(config-ether-cfm-ma) #rmep auto-discovery enable
PE1(config-ether-cfm-ma) #rmep auto-discovery enable
PE1(config-ether-cfm-ma) #cc interval 10ms
PE1(config-ether-cfm-ma) #exit-ether-ma-mode
PE1(config-ether-cfm) #commit
PE1(config-ether-cfm) #commit
```

• Create a loss measurement profile named SLM with measurement type SLM, measurement interval of 1, intervals stored of 3, and message period of (1) second.

```
PE1(config) #ethernet cfm loss-measurement profile-name SLM
PE1(config-cfm-lm) #measurement-type slm
PE1(config-cfm-lm) #measurement-interval 1
PE1(config-cfm-lm) #intervals-stored 3
PE1(config-cfm-lm) #message-period 1s
PE1(config-cfm-lm) #exit
```

• Create loss measurement profile named LM with measurement type LMM, measurement interval of (1), intervals stored of (3), and message period of (1 second),

```
PE1(config)#ethernet cfm loss-measurement profile-name LM
PE1(config-cfm-lm)#measurement-type lmm
PE1(config-cfm-lm)#measurement-interval 1
PE1(config-cfm-lm)#intervals-stored 3
PE1(config-cfm-lm)#message-period 1s
PE1(config-cfm-lm)#exit
```

Create a delay measurement profile named DM with a measurement interval of (1), intervals stored of (2), and message period of (1 second).
 PE1(config) #ethernet cfm delay-measurement profile-name DM

```
PE1 (config-cfm-dm) #measurement-interval 1
PE1 (config-cfm-dm) #intervals-stored 2
PE1 (config-cfm-dm) #message-period 1
```

Configuration Snapshot:

CE1:

```
interface xel
    switchport
     load-interval 30
    interface xe1.2001 switchport
     encapsulation dot1q 2028
    interface xell.2001 switchport
     encapsulation dot1q 2028
    cross-connect test100
     interface xel.2001
     interface xell.2001
CE2:
    interface xel
    switchport
     load-interval 30
    interface xe1.2001 switchport
     encapsulation dot1q 2028
    interface xe12.2001 switchport
     encapsulation dot1g 2028
    cross-connect test100
     interface xel.2001
     interface xe12.2001
PE1:
```

interface lo

```
ip address 1.1.1.1/32 secondary
    router ldp
     targeted-peer ipv4 4.4.4.4
    interface xe2
     load-interval 30
     ip address 192.168.10.1/24
     label-switching
     enable-ldp ipv4
    router ospf 1
     ospf router-id 1.1.1.1
     bfd all-interfaces
     network 1.1.1.1/32 area 0.0.0.0
     network 192.168.10.0/24 area 0.0.0.0
    mpls 12-circuit test1 2001 4.4.4.4
    interface xe1.2001 switchport
     encapsulation dot1q 2028
     access-if-vpws
     mpls-l2-circuit test1 primary
    ethernet cfm domain-type character-string domain-name 12346 level 7 mip-
    creation none
     service ma-type string ma-name 124
       ethernet cfm mep up mpid 20 active true xe1.2001 vlan 2028
         cc multicast state enable
         exit-ether-ma-mep-mode
       rmep auto-discovery enable
       cc interval 10ms
       exit-ether-ma-mode
    ethernet cfm loss-measurement profile-name SLM
     measurement-type slm
     measurement-interval 1
     intervals-stored 3
     message-period 1s
    ethernet cfm loss-measurement profile-name LM
     measurement-type lmm
     measurement-interval 1
     intervals-stored 3
     message-period 1s
    1
    ethernet cfm delay-measurement profile-name DM
     measurement-interval 1
     intervals-stored 2
     message-period 1s
PE2:
    interface lo
     ip address 4.4.4/32 secondary
    router ldp
```

targeted-peer ipv4 1.1.1.1

```
interface xe2
     load-interval 30
     ip address 192.168.30.2/24
     label-switching
     enable-ldp ipv4
    router ospf 1
    ospf router-id 4.4.4.4
     bfd all-interfaces
     network 4.4.4/32 area 0.0.0.0
     network 192.168.30.0/24 area 0.0.0.0
    mpls 12-circuit test1 2001 1.1.1.1
    interface xe1.2001 switchport
     encapsulation dot1q 2028
     access-if-vpws
     mpls-l2-circuit test1 primary
    ethernet cfm domain-type character-string domain-name 12346 level 7 mip-
    creation none
     service ma-type string ma-name 124
       ethernet cfm mep up mpid 10 active true xe1.2001 vlan 2028
         cc multicast state enable
         ethernet cfm loss-measurement reply lmm
         ethernet cfm delay-measurement reply dmm
         exit-ether-ma-mep-mode
       rmep auto-discovery enable
       cc interval 10ms
       exit-ether-ma-mode
P1:
    interface lo
     ip address 2.2.2/32 secondary
    router ldp
     transport-address ipv4 2.2.2.2
    interface xe2
     ip address 192.168.10.2/24
     label-switching
     enable-ldp ipv4
    interface xel
     ip address 192.168.20.1/24
     label-switching
     enable-ldp ipv4
    router ospf 1
     ospf router-id 2.2.2.2
     bfd all-interfaces
     network 2.2.2/32 area 0.0.0.0
     network 192.168.10.0/24 area 0.0.0.0
     network 192.168.20.0/24 area 0.0.0.0
```

```
interface lo
ip address 3.3.3.3/32 secondary
router ldp
transport-address ipv4 3.3.3.3
interface xel
 ip address 192.168.20.2/24
label-switching
enable-ldp ipv4
interface xe2
 ip address 192.168.30.1/24
label-switching
enable-ldp ipv4
router ospf 1
ospf router-id 3.3.3.3
bfd all-interfaces
network 3.3.3/32 area 0.0.0.0
network 192.168.20.0/24 area 0.0.0.0
network 192.168.30.0/24 area 0.0.0.0
```

Validation

Verify the RMEP is learned or not.

PE1#show	ethernet	cfm mainter	nance-points	remote	domain	12346	
MA_NAME	MEPID	RMEPID	LEVEL	Rx CCM	RDI	PEER-MAC	TYPE
124	20	10	7	Yes	Fal	Lse e8c5.7ae3.	.37ee Learnt

Verify the CFM Errors:

PE1#show ethernet cfm errors domain 12346

Domain	Name	Level	MEPID	Defects
12346		7	20	

defRDICCM
 defMACstatus
 defRemoteCCM
 defErrorCCM
 defXconCCM

Verify the CFM status:

PE1#show ethernet cfm ma status domain 12346 ma-name 124 MA NAME STATUS 124 Active

Verify the Ping:

PE1#ping ethernet mac e8c5.7ae3.37ee unicast source 20 domain 12346 ma 124 success rate is 100 (5/5)

Verify the Traceroute:

PE1#traceroute ethernete8c5.7ae3.37eemepid 20domain 12346ma 124MP MacHopsRelay-actionIngress/EgressIngress/Egress actione8c5.7ae3.37ee1RlyHitIngressIngOK

Verify the MPLS virtual circuit table, which contains information about MPLS label-switched paths (LSPs) and its associated virtual circuits in the network.

PE1#show mpls vc-table
(m) - Service mapped over multipath transport
(e) - Service mapped over LDP ECMP

VC-ID Nexthop	Vlan-ID Sta	Inner atus	-Vlan-ID UpTime	Access-Intf	Network-Intf	Out Label	Tunnel-Label
2001 4.4.4.4	N/A Act	N/A Live	00:38:0	xe1.2001 2	xe2	26240	25601

Verify the Delay-measurement:

PE1#delay-measurement type proactive profile-name DM rmep 10 mep 20 domain 12346 ma 124 PE1#2023 Oct 12 04:11:56.696 : PE1 : ONMD : INFO : [CFM PM_SESSION_INFO_5]: CFM Frame Delay Measurement session started for MEP Id 20 and RMEP Id 10

PE1#show ethernet cfm delay-measurement mep 20 domain 12346 ma-name 124

MD	: 12346
MA	: 124
MEP	: 20
VC Name	: test3
Peer MAC Address	: e8c5.7ae3.37ee

CURRENT:

RMEP ID : 10		
Measurement ID : 1		
Measurement Type	:	DMM
Elapsed time(sec)	:	2
Start Time	:	2023 Oct 12 04:11:56
Suspect Flag	:	FALSE
Min Frame Delay(usec)	:	40
Max Frame Delay(usec)	:	74
Avg Frame Delay(usec)	:	57
Min Inter FD Variation(usec)	:	34
Max Inter FD Variation(usec)	:	34
Avg Inter FD Variation (usec)	:	34

	FRAN	ME DELAY B	INS		
Bin	Number	Bin Thre	shold(usec)	Bin Cou	nter
1		0	- < 4999	2	
2		5000	- < 9999	0	

3	10000	- < 14999	С
4	15000	- < 4294967295	С

INTER-F	RAME DELAY I	BII	1S			
Number	Bin Threshold(usec)				Bin	Counter
	0	_	<	4999	1	
	5000	_	<	9999	0	
	10000	-	<	4294967295	0	
	INTER-F Number	INTER-FRAME DELAY Number Bin Thresho. 0 5000 10000	INTER-FRAME DELAY BIN Number Bin Threshold 0 - 5000 - 10000 -	INTER-FRAME DELAY BINS Number Bin Threshold(us 0 - < 5000 - < 10000 - <	INTER-FRAME DELAY BINS Number Bin Threshold(usec) 0 - < 4999 5000 - < 9999 10000 - < 4294967295	INTER-FRAME DELAY BINS Number Bin Threshold(usec) Bin 0 - < 4999 1 5000 - < 9999 0 10000 - < 4294967295 0

Verify the Loss-measurement:

PE1#loss-measurement type proactive profile-name LM rmep 10 mep 20 domain 12346 ma 124 2023 Oct 12 04:18:43.667 : PE1 : ONMD : INFO : [CFM_DEFECT_INFO_5]: CFM Frame Loss Measurement started for MEP:20 MA:124 MD:12346 PE1#show ethernet cfm loss-measurement mep 20 domain 12346 ma-name 124

```
MEP: 20 MA: 124
CURRENT:
 Measurement ID : 1
  Suspect
                             : False
                             : lmm
 Measurement Type
  Elapsed time(sec)
                             : 10
  Start Time
                             : 2023 Oct 12 04:18:43
  Near End loss
                             : 0
  Far End loss
                             : 0
  Near End accumulated loss : 0
  Far End accumulated loss
                             : 0
  Near End frame loss ratio : 0
  Far End frame loss ratio
                             : 0
```

Verify the Synthetic Loss Measurement:

```
PE1#loss-measurement type proactive profile-name SLM rmep 10 mep 20 domain 12346 ma 124
PE1#2024 Apr 10 13:40:15.587 : PE1 : ONMD : INFO : [CFM_DEFECT_INFO_5]: CFM Frame Loss
Measurement started for MEP:20 MA:124 MD:12346
PE1#show ethernet cfm loss-measurement mep 20 domain 12346 ma-name 124
MEP: 20 MA: 124
CURRENT:
 Measurement ID : 2
                             : False
  Suspect
  Measurement Type
                             : slm
  Elapsed time(sec)
                             : 17
  Start Time
                             : 2024 Apr 10 13:41:15
  Near End loss
                             : 0
  Far End loss
                             : 0
  Near End accumulated loss : 0
  Far End accumulated loss
                             : 0
  Near End frame loss ratio : 0
  Far End frame loss ratio
                             : 0
HISTORY:
```

```
Measurement ID : 1
 Suspect
                            : False
Measurement Type
                            : slm
Elapsed time(sec)
                            : 60
End Time
                            : 2024 Apr 10 13:41:15
Near End loss
                            : 0
 Far End loss
                            : 0
Near End accumulated loss : 0
 Far End accumulated loss
                            • 0
Near End frame loss ratio : 0
 Far End frame loss ratio
                           : 0
Near End frame loss ratio min : 0
 Far End frame loss ratio min : 0
Near End frame loss ratio max : 0
 Far End frame loss ratio max : 0
```

Verify the DM, LM, and SLM active sessions.

PE1#show ethernet cfm maintenance-points count

Total	No	of	MIPs	:	0
Total	No	of	MEPs	:	2
Total	No	of	UP MEPs	:	2
Total	No	of	Down MEPs	:	0
Total	No	of	Active CCM sessions	:	2
Total	No	of	UP CCM sessions	:	2
Total	No	of	Active LM sessions	:	2
Total	No	of	Active DM sessions	:	1

Implementation Examples

- To support a vast network infrastructure delivering VPWS to a multitude of enterprise clients, it is imperative to
 maintain uninterrupted connectivity and peak performance for these VPWS connections, all while minimizing the
 risk of downtime or disruptions.
- Understanding the role of fault detection, localization, and performance monitoring within the VPWS network, deploy Y.1731 CFM over Layer 2 VPN (VPWS) to enhance the network's resilience and operational efficiency.

Glossary

The following provides definitions for key terms or abbreviations and their meanings used throughout this document:

Key Terms/Acronym	Description
Connectivity Fault Management (CFM)	CFM is a protocol used to detect, verify, and isolate connectivity faults in a network. It operates at the data link layer and is designed to monitor ethernet networks.

Virtual Private Wire Service (VPWS)	VPWS is a Layer 2 VPN service that provides point-to-point connectivity between two sites over an MPLS network. It emulates a leased line or circuit between the customer premises equipment (CPE) devices.
Maintenance End Point (MEP)	MEP is a CFM entity that resides at the edge of a CFM domain. It is responsible for generating and transmitting CFM protocol packets to detect faults and collect performance data.
Maintenance Domain (MD)	MD is a logical grouping of MEPs within a CFM network. MEPs within the same MD can communicate with each other to perform CFM functions such as fault detection and performance monitoring.
Maintenance Association(MA)	MA is a collection of MEPs associated with a specific service or set of services. It defines the scope of CFM operations within a maintenance domain.
Maintenance Point Identifier (MPID)	MPID is a unique identifier assigned to each MEP within a maintenance association. It is used to distinguish between different MEPs within the same MA.
Service Level Measurement (SLM)	SLM is a CFM function used to measure the loss characteristics of a network path. It collects data on packet loss, delay, and jitter to assess the quality of service provided by the network.
Loopback Message Generation (LMM)	LMM is a CFM function used to test end-to-end connectivity by generating loopback messages. These messages are transmitted from a MEP and looped back to the same MEP to verify bidirectional communication.
Delay Measurement Message (DMM)	DMM is a CFM function used to measure the one-way delay of packets transmitted across a network. It helps assess the performance of the network in terms of packet delivery time.
Continuity Check (CC)	CC is a CFM function used to verify the continuity of a service or network path by periodically sending continuity check messages between MEPs. It helps detect connectivity faults such as link failures or misconfigurations.

CHAPTER 7 Y.1731 and CFM Over EVPN ELAN Single Home

Overview

The Single Home EVPN ELAN Y.1731 CFM over Sub-interface feature enables the monitoring and management ofEthernet Virtual Private Network (EVPN) Ethernet LAN services using the Y.1731 Connectivity Fault Management (CFM) protocol over sub-interfaces. This feature enhances fault detection and performance monitoring capabilities for EVPN E-LAN services, allowing network operators to ensure high availability and reliability of their networks. By extending Y.1731 CFM functionality to sub-interfaces in single home EVPN E-LAN deployments, this feature provides comprehensive end-to-end visibility and control, enabling proactive fault detection, isolation, and troubleshooting.

Feature Characteristics

- Utilizes sub-interfaces to partition Ethernet traffic within the Single Home EVPN ELAN architecture, enabling efficient service delivery and management.
- Implements EVPN ELAN architecture with single-homing capabilities, facilitating the creation of Ethernet Virtual Private Networks with simplified configurations and reduced complexity.
- Provides robust fault detection mechanisms to identify connectivity issues, link failures, and service disruptions in Ethernet networks.

Benefits

- Provides detailed insights into Ethernet service performance, enabling proactive monitoring and optimization of network resources.
- Minimizes service downtime by promptly detecting and resolving faults, ensuring uninterrupted service delivery and customer satisfaction.
- Optimizes network resource utilization and bandwidth allocation by identifying and addressing connectivity issues in a timely manner.
- Facilitates rapid fault identification and isolation, accelerating troubleshooting processes and reducing mean time to repair (MTTR).
- Ensures compliance with Service Level Agreements (SLAs) by maintaining service quality metrics within defined thresholds and objectives.

Prerequisites

Ensure that the network devices (routers, switches) support Y.1731 CFM functionality and Single Home EVPN ELAN configuration.

Verify that the devices are running compatible software versions that include support for these features.

Configuration

Configure Single Home EVPN ELAN Y.1731 CFM over Sub-interface for enhanced fault management in EVPN

networks.

Topology

The topology consists of three Customer Edge devices (CE1, CE2, and CE3) connected to Provider Edge devices (PE1,PE2, and PE3) through sub-interfaces. The Provider Edge devices are interconnected through Provider devices (P1 and P2).

Y.1731 functionality is implemented over these sub-interfaces, allowing for fault detection and performance monitoring of Ethernet connectivity between the customer sites.



Figure 7-16: EVPN ELAN Over Sub-interface-Single Home

Perform the following configurations to configure Single Home EVPN ELAN Y.1731 CFM over Sub-interface:

1. On Customer Edge (CE) Nodes (CE1, CE2, and CE3), configure the interface xe1 and set it as a switchport with a load interval of (30 seconds):

```
CE1(config)#interface xe1
CE1(config-if)#switchport
CE1(config-if)#load-interval 30
CE1(config-if)#commit
CE1(config-if)#exit
```

Note: Similarly follow the same steps to configure xe11(CE1), xe12(CE2), and xe13(CE3).

```
2. Create sub-interface (xe1.2001) adding the VLAN:
```

```
CE1(config)#interface xe1.2001 switchport
CE1(config-if)#encapsulation dot1q 2028
CE1(config-if)#commit
CE1(config-if)#exit
```

```
CE1(config)#interface xel1.2001 switchport
CE1(config-if)#encapsulation dot1q 2028
CE1(config-if)#commit
CE1(config-if)#exit
```

3. Set up a cross-connect named (test100), specifying in and out interfaces:

```
CE1(config)#cross-connect test100
CE1(config-xc)#interface xe1.2001
CE1(config-xc)#interface xe11.2001
CE1(config-xc)#commit
```

- 4. Perform the following on PE1:
 - 1. Configure CFM related hardware profiles:

```
PE1(config) # hardware-profile filter cfm-domain-name-str enable
PE1(config) # hardware-profile statistics cfm-lm enable
PE1(config) # hardware-profile statistics cfm-ccm enable
PE1(config) #hardware-profile statistics cfm-slm enable
```

2. Configure the loopback interface with a secondary IP address(1.1.1.1/32):

```
PE1(config)#interface lo
PE1(config-if)#ip address 1.1.1.1/32 secondary
PE1(config-if)#commit
PE1(config-if)#exit
```

3. Configure LDP targeted peers:

```
PE1(config) #router ldp
PE1(config-router) #targeted-peer ipv4 4.4.4.4
PE1(config-router-targeted-peer) #exit-targeted-peer-mode
PE1(config-router) #commit
PE1(config-router) exit
```

4. Configure interface xe2 with an IP address (192.168.10.1/24) and enable LDP:

```
PE1(config)#interface xe2
PE1(config-if)#load-interval 30
PE1(config-if)#ip address 192.168.10.1/24
PE1(config-if)#label-switching
PE1(config-if)#enable-ldp ipv4
PE1(config-if)#commit
PE1(config-if)#exit
```

5. Configure OSPF routing, specify the OSPF router ID as (1.1.1.1), enable BFD on all interfaces, define the network (1.1.1.1/32) in area (0.0.0.0), and define the network (192.168.10.0/24) in area (0.0.0.0):

```
PE1(config)#router ospf 1
PE1(config-router)#ospf router-id 1.1.1.1
PE1(config-router)#bfd all-interfaces
PE1(config-router)#network 1.1.1.1/32 area 0.0.0.0
PE1(config-router)#network 192.168.10.0/24 area 0.0.0.0
PE1(config-router)#commit
PE1(config-router)#exit
```

6. Enable EVPN MPLS globally and configure VTEP IP:

```
PE1(config) # evpn mpls enable
PE1(config) # commit
PE1(config) # evpn mpls vtep-ip-global 1.1.1.1
PE1(config) # commit
```

7. Configure BGP with the remote PE devices and activate EVPN:

```
PE1(config) # router bgp 100
PE1(config-router) # neighbor 4.4.4.4 remote-as 100
PE1(config-router) # neighbor 4.4.4.4 update-source lo
PE1(config-router) # address-family l2vpn evpn
PE1(config-router-af) # neighbor 4.4.4.4 activate
PE1(config-router-af) # exit
PE1(config-router) # exit
PE1(config) # commit
```

8. Configure MAC VRF with the appropriate RD and RT:

```
PE1(config)# mac vrf vrf2
PE1(config-vrf)# rd 1.1.1.1:2
PE1(config-vrf)# route-target both 2:2
PE1(config-vrf)# exit
```

9. Map the EVPN instance and VRF, specifying the EVPN ID:

```
PE1(config)#evpn mpls id 101
PE1(config-evpn-mpls)# host-reachability-protocol evpn-bgp vrf2
PE1(config-evpn-mpls)#commit
```

```
PE1(config-evpn-mpls)# commit
PE1(config-router-af)# exit
```

10. Configure access ports on PE1:

```
PE1(config)# interface xe1.2001 switchport
PE1(config-if)# encapsulation dot1q 2028
PE1(config-if)# access-if-evpn
PE1(config-acc-if-evpn)# map vpn-id 101
PE1(config-acc-if-evpn)# commit
```

11. Configure CFM MEP on PE1, define the FCM domain (12346), create MA, configure MEP, and configure Remote MEP Auto-discovery, set CC Interval 10ms:

```
PE1(config) # ethernet cfm domain-type character-string domain-name12346
level 7 mip-creation default
PE1(config-ether-cfm) # service ma-type string ma-name 124
PE1(config-ether-cfm-ma) # ethernet cfm mep up mpid 20 active true
xe1.2001 vlan 2028
PE1(config-ether-cfm-ma-mep) # cc multicast state enable
PE1(config-ether-cfm-ma-mep) # exit-ether-ma-mep-mode
PE1(config-ether-cfm-ma) # rmep auto-discovery enable
PE1(config-ether-cfm-ma) # cc interval 10ms
PE1(config-ether-cfm-ma) # exit-ether-ma-mode
PE1(config-ether-cfm-ma) # exit-ether-ma-mode
PE1(config-ether-cfm-ma) # exit-ether-ma-mode
PE1(config-ether-cfm-ma) # commit
```

12. Provide CFM configuration, define a delay measurement profile named DM, set the measurement interval to 1 second, specify the number of intervals stored as 2, configure the message period as 1 second, set the measurement type to LMM, set the measurement interval to 1 second, specify the number of intervals stored as 3, define a service level measurement profile named SLM, set the measurement type to SLM:

```
PE1(config)# ethernet cfm delay-measurement profile-name DM
PE1(config-cfm-dm)# measurement-interval 1
PE1(config-cfm-dm)# intervals-stored 2
PE1(config-cfm-dm)# message-period 1s
PE1(config-cfm-dm)# commit
PE1(config-cfm-lm)# measurement-type slm
PE1(config-cfm-lm)# measurement-interval 1
PE1(config-cfm-lm)# intervals-stored 3
PE1(config-cfm-lm)# message-period 1s
PE1(config-cfm-lm)# message-period 1s
```

Configuration Snapshot:

CE1:

```
interface xe1
switchport
load-interval 30
!
interface xe1.2001 switchport
encapsulation dot1q 2028
!
interface xe11.2001 switchport
encapsulation dot1q 2028
!
cross-connect test100
interface xe1.2001
```

interface xell.2001

CE2:

```
interface xe1
switchport
load-interval 30
!
interface xe1.2001 switchport
encapsulation dot1q 2028
!
interface xe12.2001 switchport
encapsulation dot1q 2028
!
cross-connect test100
interface xe1.2001
interface xe12.2001
```

PE1:

```
interface lo
 ip address 1.1.1.1/32 secondary
!
router ldp
targeted-peer ipv4 4.4.4.4
 exit-targeted-peer-mode
targeted-peer ipv4 5.5.5.5
  exit-targeted-peer-mode
transport-address ipv4 1.1.1.1
!
interface xe2
load-interval 30
ip address 192.168.10.1/24
label-switching
enable-ldp ipv4
1
router ospf 1
ospf router-id 1.1.1.1
bfd all-interfaces
network 1.1.1/32 area 0.0.0.0
network 192.168.10.0/24 area 0.0.0.0
!
evpn mpls enable
evpn mpls vtep-ip-global 1.1.1.1
1
router bgp 100
neighbor 4.4.4.4 remote-as 100
neighbor 4.4.4.4 update-source lo
neighbor 5.5.5.5 remote-as 100
neighbor 5.5.5.5 update-source lo
address-family 12vpn evpn
neighbor 4.4.4.4 activate
neighbor 5.5.5.5 activate
exit
!
mac vrf vrf2
rd 1.1.1.1:2
 route-target both 2:2
```

```
!
    evpn mpls id 101
     host-reachability-protocol evpn-bgp vrf2
    !
    interface xel
     switchport
     load-interval 30
    T
    interface xe1.2001 switchport
     encapsulation dot1q 2028
     access-if-evpn
     map vpn-id 101
    T
    ethernet cfm domain-type character-string domain-name 12346 level 7
    mipcreation none
     service ma-type string ma-name 124
     ethernet cfm mep up mpid 20 active true xe1.2001 vlan 2028
     cc multicast state enable
     exit-ether-ma-mep-mode
     rmep auto-discovery enable
     cc interval 10ms
     exit-ether-ma-mode
    1
    ethernet cfm loss-measurement profile-name SLM
     measurement-type slm
     measurement-interval 1
     intervals-stored 3
     message-period 1s
    1
    ethernet cfm delay-measurement profile-name DM
     measurement-interval 1
     intervals-stored 2
     message-period 1s
PE2:
    interface lo
     ip address 4.4.4/32 secondary
    router ldp
     targeted-peer ipv4 1.1.1.1
    exit-targeted-peer-mode
    targeted-peer ipv4 5.5.5.5
    exit-targeted-peer-mode
    transport-address ipv4 4.4.4.4
    1
    interface xe2
     load-interval 30
     ip address 192.168.30.2/24
     label-switching
     enable-ldp ipv4
    1
    router ospf 1
     ospf router-id 4.4.4.4
     bfd all-interfaces
     network 4.4.4/32 area 0.0.0.0
     network 192.168.30.0/24 area 0.0.0.0
    !
```

```
evpn mpls enable
    evpn mpls vtep-ip-global 4.4.4.4
    router bgp 100
     neighbor 1.1.1.1 remote-as 100
     neighbor 1.1.1.1 update-source lo
     neighbor 5.5.5.5 remote-as 100
     neighbor 5.5.5.5 update-source lo
     address-family 12vpn evpn
     neighbor 1.1.1.1 activate
     neighbor 5.5.5.5 activate
    exit
    mac vrf vrf2
     rd 4.4.4:2
     route-target both 2:2
    1
    evpn mpls id 101
     host-reachability-protocol evpn-bgp vrf2
    T
    interface xel
     switchport
     load-interval 30
    1
    interface xe1.2001 switchport
     encapsulation dot1q 2028
     access-if-evpn
    map vpn-id 101
    1
    ethernet cfm domain-type character-string domain-name 12346 level 7
    mipcreation none
     service ma-type string ma-name 124
     ethernet cfm mep up mpid 10 active true xe1.2001 vlan 2028
     cc multicast state enable
     ethernet cfm loss-measurement reply slm
     ethernet cfm delay-measurement reply dmm
     exit-ether-ma-mep-mode
     rmep auto-discovery enable
     cc interval 10ms
     exit-ether-ma-mode
    I
PE3:
    interface lo
     ip address 5.5.5/32 secondary
    !
    router ldp
     targeted-peer ipv4 1.1.1.1
    exit-targeted-peer-mode
    targeted-peer ipv4 4.4.4.4
    exit-targeted-peer-mode
    transport-address ipv4 5.5.5.5
    1
    interface xe3
```

```
label-switching
```

ip address 192.168.40.2/24

load-interval 30

```
enable-ldp ipv4
T
router ospf 1
ospf router-id
bfd all-interfaces
network 5.5.5.5/32 area 0.0.0.0
network 192.168.40.0/24 area 0.0.0.0
T
evpn mpls enable
evpn mpls vtep-ip-global 5.5.5.5
router bgp 100
neighbor 1.1.1.1 remote-as 100
neighbor 1.1.1.1 update-source lo
neighbor 4.4.4.4 remote-as 100
neighbor 4.4.4.4 update-source lo
address-family 12vpn evpn
neighbor 1.1.1.1 activate
neighbor 4.4.4.4 activate
exit
mac vrf vrf2
rd 5.5.5.5:2
route-target both 2:2
1
evpn mpls id 101
host-reachability-protocol evpn-bgp vrf2
!
interface xel
switchport
load-interval 30
interface xe1.2001 switchport
encapsulation dot1q 2028
access-if-evpn
 map vpn-id 101
ethernet cfm domain-type character-string domain-name 12346 level 7
mipcreation none
 service ma-type string ma-name 124
ethernet cfm mep up mpid 30 active true xe1.2001 vlan 2028
 cc multicast state enable
 ethernet cfm loss-measurement reply slm
ethernet cfm delay-measurement reply dmm
 exit-ether-ma-mep-mode
 rmep auto-discovery enable
cc interval 10ms
exit-ether-ma-mode
ļ
```

P1:

```
interface lo
  ip address 2.2.2/32 secondary
```

router ldp

```
transport-address ipv4 2.2.2.2
interface xe2
ip address 192.168.10.2/24
label-switching
enable-ldp ipv4
interface xel
ip address 192.168.20.1/24
label-switching
enable-ldp ipv4
router ospf 1
ospf router-id 2.2.2.2
bfd all-interfaces
network 2.2.2/32 area 0.0.0.0
network 192.168.10.0/24 area 0.0.0.0
network 192.168.20.0/24 area 0.0.0.0
interface lo
ip address 3.3.3/32 secondary
router ldp
transport-address ipv4 3.3.3.3
interface xel
ip address 192.168.20.2/24
```

```
ip address 192.168.20.2/2
label-switching
enable-ldp ipv4
```

```
interface xe2
ip address 192.168.30.1/24
label-switching
enable-ldp ipv4
```

```
router ospf 1
ospf router-id 3.3.3.3
bfd all-interfaces
network 3.3.3.3/32 area 0.0.0.0
network 192.168.20.0/24 area 0.0.0.0
network 192.168.30.0/24 area 0.0.0.0
```

CE3:

P2:

```
interface xe1
switchport
load-interval 30
!
interface xe1.2001 switchport
encapsulation dot1q 2028
!
interface xe13.2001 switchport
encapsulation dot1q 2028
!
cross-connect test100
interface xe1.2001
```

interface xel3.2001

Validation

Verify the EVPN MPLS status.

PE1#show evpn mpls EVPN-MPLS Information

> Codes: NW - Network Port AC - Access Port (u) - Untagged

```
VPN-IDEVI-Type Type Interface ESIVLANDF-Status Src-AddrDst-Addr
```

101		L2	NW			 -
101	1.1.1.1	L2	NW 5.5.5.5			 -
101			AC	xe1.2001	Single Homed Port	 -

Total number of entries are 4

Verify the RMEP is learned or not:

PE1#show ethernet cfm maintenance-points remote domain 12346 MA NAME MEPID RMEPID LEVEL RX CCM RDI PEER-MAC TYPE

124 20 10 7 Yes False e8c5.7ae3.37ee Learnt 124 20 30 7 Yes False e8c5.7ae3.38ee Learnt

Verify the Ping:

PE1#ping ethernet mac e8c5.7ae3.37ee unicast source 20 domain 12346 ma 124 success rate is 100 (5/5)

PE1#ping ethernet mac e8c5.7ae3.38ee unicast source 20 domain 12346 ma 124 success rate is 100 (5/5))

Verify the Traceroute:

PE1#traceroute ethernet e8c5.7ae3.37ee mepid 20 domain 12346 ma 124 MP Mac Hops Relay-action Ingress/Egress Ingress/Egress action e8c5.7ae3.37ee 1 RlyHit Ingress IngOK

PE1#traceroute ethernet e8c5.7ae3.38ee mepid 20 domain 12346 ma 124 MP Mac Hops Relay-action Ingress/Egress Ingress/Egress action e8c5.7ae3.38ee 1 RlyHit Ingress IngOK

Verify the Delay-measurement:
PE1#delay-measurement type proactive profile-name DM rmep 10 mep 20 domain 12346 ma 124 PE1#2024 Apr 10 13:35:37.236 : PE1: ONMD : INFO : [CFM PM SESSION INFO 5]: CFM Frame Delay Measurement session started for MEP Id 20 and RMEP Id 10 PE2-7033#show ethernet cfm delay-measurement mep 20 domain 12346 ma-name 124 MD : 12346 MA : 124 MEP : 20 VLAN ID : 10 Interface : po1000.10 Peer MAC Address : 00cc.dd00.0000 CURRENT: _____ RMEP ID : 10 Measurement ID : 1 Measurement Type : DMM Elapsed time(sec) : 53 Start Time : 2024 Apr 10 13:35:37 Suspect Flag : FALSE Min Frame Delay(usec) : 19 Max Frame Delay(usec) : 20 Avg Frame Delay(usec) : 19 Min Inter FD Variation(usec): 0 Max Inter FD Variation(usec): 1 Avg Inter FD Variation(usec): 0 FRAME DELAY BINS Bin Number Bin Threshold(usec) Bin Counter 1 0 - < 499952 2 5000 - < 9999Ο 3 10000 - < 42949672950 INTER-FRAME DELAY BINS Bin Number Bin Threshold(usec) Bin Counter 1 0 - < 499951 5000 - < 42949672952 0

Verify the Synthetic Loss Measurement:

PE1#loss-measurement type proactive profile-name SLM rmep 10 mep 20 domain 12346 ma 124 PE1#2024 Apr 10 13:40:15.587 : PE1 : ONMD : INFO : [CFM DEFECT INFO 5]: CFM Frame Loss Measurement started for MEP:20 MA:124 MD:12346 PE1#show ethernet cfm loss-measurement mep 20 domain 12346 ma-name 124 MEP: 20 MA: 124 CURRENT: Measurement ID : 2 : False Suspect : slm Measurement Type : 17 Elapsed time(sec) Start Time : 2024 Apr 10 13:41:15 Near End loss : 0 Far End loss : 0 Near End accumulated loss : 0

```
Far End accumulated loss
                            : 0
 Near End frame loss ratio : 0
 Far End frame loss ratio : 0
HISTORY:
Measurement ID : 1
                            : False
 Suspect
 Measurement Type
                            : slm
 Elapsed time(sec)
                            : 60
 End Time
                            : 2024 Apr 10 13:41:15
 Near End loss
                            : 0
 Far End loss
                            : 0
 Near End accumulated loss : 0
 Far End accumulated loss
                            : 0
 Near End frame loss ratio : 0
 Far End frame loss ratio : 0
 Near End frame loss ratio min : 0
 Far End frame loss ratio min : 0
 Near End frame loss ratio max : 0
 Far End frame loss ratio max : 0
```

Implementation Examples

Enterprise Connectivity Monitoring:

Scenario: A large enterprise operates multiple branch offices connected via Ethernet services provided by a service provider network.

Use Case: Y.1731 CFM over sub-interface using Single Home EVPN ELAN enables the enterprise to monitor the connectivity and performance of its branch office connections. It facilitates proactive fault detection and management, ensuring reliable and uninterrupted communication between the headquarters and branch offices.

Service Provider Network Operations:

Scenario: A service provider manages a diverse range of Ethernet services for its enterprise customers, including VPNs, Internet access, and cloud connectivity.

Use Case: Y.1731 CFM over sub-interface using Single Home EVPN ELAN empowers the service provider to deliverhigh-quality Ethernet services with enhanced fault management capabilities. It enables the provider to quickly identify and resolve connectivity issues, minimize service downtime, and maintain customer satisfaction.

Glossary

The following provides definitions for key terms or abbreviations and their meanings used throughout this document:

Key Terms/Acronym	Description
Y.1731	A standard defined by the International Telecommunication Union Telecommunication Standardization Sector (ITU-T) that specifies performance monitoring and fault management for Ethernet-based networks.

Sub-interface	A logical division of a physical interface, typically used to separate traffic based on VLANs or other criteria. In this context, sub-interfaces are employed to establish distinct connections within the EVPN ELAN SH topology.
EVPN	Ethernet Virtual Private Network (VPN) is a technology that enables the creation of virtual private networks over an Ethernet-based infrastructure. It provides multi-tenancy and allows for the segmentation of traffic in service provider networks.
ELAN	ELAN is a type of EVPN service that provides point-to-multi point Ethernet connectivity between two sites.
Single Home (SH)	Refers to the configuration where a Customer Edge device (CE) is connected to only one Provider Edge device (PE) within an EVPN setup. It contrasts with the multi-homed configuration, where a CE may be connected to multiple PEs.
Maintenance End Point (MEP)	MEP is a CFM entity that resides at the edge of a CFM domain. It is responsible for generating and transmitting CFM protocol packets to detect faults and collect performance data.
Maintenance Domain (MD)	MD is a logical grouping of MEPs within a CFM network. MEPs within the same MD can communicate with each other to perform CFM functions such as fault detection and performance monitoring.
Maintenance Association(MA)	MA is a collection of MEPs associated with a specific service or set of services. It defines the scope of CFM operations within a maintenance domain.
Maintenance Point Identifier (MPID)	MPID is a unique identifier assigned to each MEP within a maintenance association. It is used to distinguish between different MEPs within the same MA.
Service Level Measurement (SLM)	SLM is a CFM function used to measure the loss characteristics of a network path. It collects data on packet loss, delay, and jitter to assess the quality of service provided by the network.
Loopback Message Generation (LMM)	LMM is a CFM function used to test end-to-end connectivity by generating loopback messages. These messages are transmitted from a MEP and looped back to the same MEP to verify bidirectional communication.
Delay Measurement Message (DMM)	DMM is a CFM function used to measure the one-way delay of packets transmitted across a network. It helps assess the performance of the network in terms of packet delivery time.
Continuity Check (CC)	CC is a CFM function used to verify the continuity of a service or network path by periodically sending continuity check messages between MEPs. It helps detect connectivity faults such as link failures or misconfigurations.

CHAPTER 8 Y.1731 and CFM Over EVPN-ELAN Multi-home

Overview

The Multi Home EVPN ELAN Y.1731 CFM over Sub-interface feature enables the monitoring and management of Ethernet Virtual Private Network (EVPN) Ethernet-LAN services using the Y.1731 Connectivity Fault Management (CFM) protocol over sub-interfaces. This feature enhances fault detection and performance monitoring capabilities for EVPN E-LAN services, allowing network operators to ensure high availability and reliability of their networks. By extending Y.1731 CFM functionality to sub-interfaces in single home EVPN E-LAN deployments, this feature provides comprehensive end-to-end visibility and control, enabling proactive fault detection, isolation, and troubleshooting.

CFM multi-homing allows Customer Edge (CE) device to connect more than one Provider Edge (PE) device. Multihoming ensures redundant connectivity. The redundant PE device ensures that there is no traffic disruption when there is a network failure.

Feature Characteristics

- Utilizes sub-interfaces to partition Ethernet traffic within the Multi Home EVPN ELAN architecture, enabling efficient service delivery and management.
- Implements EVPN ELAN architecture with single-homing capabilities, facilitating the creation of Ethernet Virtual Private Networks with simplified configurations and reduced complexity.
- Provides robust fault detection mechanisms to identify connectivity issues, link failures, and service disruptions in Ethernet networks.

Benefits

- Provides detailed insights into Ethernet service performance, enabling proactive monitoring and optimization of network resources.
- Minimizes service downtime by promptly detecting and resolving faults, ensuring uninterrupted service delivery and customer satisfaction.
- Optimizes network resource utilization and bandwidth allocation by identifying and addressing connectivity issues in a timely manner.
- Facilitates rapid fault identification and isolation, accelerating troubleshooting processes and reducing mean time to repair (MTTR).

Ensures compliance with Service Level Agreements (SLAs) by maintaining service quality metrics within defined thresholds and objectives.

Configuration

Configure Multi Home EVPN ELAN Y.1731 CFM over Sub-interface for enhanced fault management in EVPN networks.

Topology

The following topology consists of Customer Edge routers CE1 and CE2 with IPv2 Provider Edge routers PE1, PE2, and PE3. These are interconnected through the core router P in the IPv4 MPLS provider networks.



Figure 8-17: EVPN ELAN Over CFM Sub-interface

The following sessions displays the detailed information about configurations, and validations for CFM over subinterface.

- 1. Configure Loopback Interface for router identification and BGP peering.
 - Enter global configuration mode, create the loopback interface. PE1#configure terminal PE1#interface lo
 - 2. Assign an IP address to the loopback interface, exit interface configuration mode, and commit the changes.

```
PE1(config) # interface lo
PE1(config-if) # ip address 1.1.1.1/32
PE1(config-if) # exit
PE1(config) # commit
```

- 2. Configure Global LDP for distributing MPLS labels in the network.
 - 1. Enter LDP configuration mode.
 - 2. Set Router ID and configure targeted peers.

```
PE1(config)# router ldp
PE1(config-router)# router-id 1.1.1.1
PE1(config-router)# targeted-peer ipv4 7.7.7.7
PE1(config-router)# targeted-peer ipv4 8.8.8.8
PE1(config-router-targeted-peer)#exit
PE1(config-router)# exit
PE1(config)# commit
```

3. Enable EVPN over MPLS and set a global VTEP IP.

```
PE1(config)# evpn mpls enable
PE1(config)# commit
PE1(config)# evpn mpls vtep-ip-global 1.1.1.1
PE1(config)# commit
```

4. Configure the interfaces connecting to the network, enabling LDP and MPLS label switching.

```
PE1(config)# interface xe33
PE1(config-if)# ip address 10.1.0.1/16
PE1(config-if)# enable-ldp ipv4
PE1(config-if)# label-switching
PE1(config-if)# exit
```

PE1(config) # commit

5. Set up OSPF for IP routing within the network.

```
PE1(config)# router ospf 1
PE1(config-router)# ospf router-id 1.1.1.1
PE1(config-router)# network 1.1.1.1/32 area 0.0.0.0
PE1(config-router)# network 10.1.0.0/16 area 0.0.0.0
PE1(config-router)# exit
PE1(config)# commit
```

6. Set up BGP for EVPN to exchange MAC and IP information.

```
PE1(config) # router bgp 1
PE1(config-router) # neighbor 7.7.7.7 remote-as 1
PE1(config-router) # neighbor 7.7.7.7 update-source lo
PE1(config-router) # neighbor 8.8.8.8 remote-as 1
PE1(config-router) # neighbor 8.8.8.8 update-source lo
PE1(config-router) # address-family 12vpn evpn
PE1(config-router-af) # neighbor 7.7.7.7 activate
PE1(config-router-af) # neighbor 8.8.8.8 activate
PE1(config-router-af) # exit
PE1(config-router) # exit
PE1(config) # commit
```

7. Configure MAC VRF.

```
PE1(config)# mac vrf vrf2
PE1(config-vrf)# rd 1.1.1.1:2
PE1(config-vrf)# route-target both 2:2
PE1(config-vrf)# exit
PE1(config)# commit
```

8. Configure EVPN and map VRF.

```
PE1(config)# evpn mpls id 101
PE1(config-evpn-mpls)# host-reachability-protocol evpn-bgp vrf2
PE1(config)# exit
PE1(config)# commit
```

9. Configure access port on interface xe33.

```
PE1(config)# interface xe33
PE1(config-if)# interface xe33.2 switchport
PE1(config-if)# description access-side-int
PE1(config-if)# encapsulation dot1q 2
PE1(config-if)# access-if-evpn
PE1(config-access-if)# map vpn-id 101
PE1(config-access-if)# exit
PE1(config)# commit
```

10. Configure Y1731 SLM and DM profile.

```
PE1(config)#ethernet cfm loss-measurement profile-name SLM
PE1(config-cfm-lm)# measurement-type slm
PE1(config-cfm-lm)# measurement-interval 1
PE1(config-cfm-lm)# intervals-stored 3
PE1(config-cfm-lm)# exit
PE1(config)# commit
PE1(config)# commit
PE1(config-cfm-lm)#ethernet cfm delay-measurement profile-name DM
PE1(config-cfm-dm)# measurement-interval 1
PE1(config-cfm-dm)# intervals-stored 2
PE1(config-cfm-dm)# message-period 1s
```

```
PE1(config-cfm-dm)#exit
PE1(config)# commit
```

Note: Similarly follow the same steps to configure respective cfm mep up and other CFM features for PE2 and PE3.

Configuration Snapshot:

PE1:

```
T
interface lo
ip address 1.1.1.1/32
!
router ldp
router-id 1.1.1.1
targeted-peer 7.7.7.7
targeted-peer 8.8.8.8
router ospf 1
router-id 1.1.1.1
network 1.1.1.1/32 area 0
network 10.1.0.0/16 area 0
!
router bgp 1
bgp log-neighbor-changes
neighbor 7.7.7.7 remote-as 1
neighbor 7.7.7.7 update-source lo
neighbor 8.8.8.8 remote-as 1
 neighbor 8.8.8.8 update-source lo
 1
 address-family 12vpn evpn
 neighbor 7.7.7.7 activate
 neighbor 8.8.8.8 activate
exit-address-family
1
evpn mpls enable
evpn mpls vtep-ip-global 1.1.1.1
hardware-profile filter cfm-domain-name-str enable
hardware-profile statistics cfm-ccm enable
1
evpn mpls id 101
host-reachability-protocol evpn-bgp vrf2
interface xe33
ip address 10.1.0.1/16
enable-ldp ipv4
label-switching
vrf definition vrf2
rd 1.1.1.1:2
route-target both 2:2
evpn mpls id 52 xconnect target-mpls-id 2
host-reachability-protocol evpn-bgp vrf2
Т
interface xe33.2
description access-side-int
encapsulation dot1q 2
```

```
access-if-evpn
      map vpn-id 101
    1
    ethernet cfm domain-type character-string domain-name 12346 level 7 mip-
    creation none
     service ma-type string ma-name 124
      ethernet cfm mep up mpid 10 active true xe33.2 vlan 2
       cc multicast state enable
       exit-ether-ma- mode
       mep auto-discovery enable
       cc interval 10ms
       exit-ether-ma- mode
    1
P:
    I.
    interface lo
     ip address 2.2.2/32
    I.
    interface xe6
     ip address 10.1.0.2/16
     mpls ip
    1
    interface xe21
     ip address 123.1.1.1/24
     enable-ldp ipv4
    label-switching
    !
    interface xe20
     ip address 124.1.1.1/24
     enable-ldp ipv4
    label-switching
    1
    router ldp
     router-id 2.2.2.2
    1
    router ospf 1
     router-id 2.2.2.2
     network 2.2.2/32 area 0
     network 10.1.0.0/16 area 0
     network 123.1.1.0/24 area 0
     network 124.1.1.0/24 area 0
    !
PE2:
    T
    interface lo
     ip address 7.7.7.7/32
    1
    interface xe21
     ip address 123.1.1.2
     enable-ldp ipv4
    label-switching
    !
    router ldp
     router-id 7.7.7.7/32
     targeted-peer ipv4 1.1.1.1
```

```
targeted-peer ipv4 8.8.8.8
    I.
    router ospf 1
     router-id 7.7.7.7
     network 7.7.7.7/32 area 0
     network 123.1.1.0/24 area 0
    !
    router bgp 1
     bgp log-neighbor-changes
     neighbor 1.1.1.1 remote-as 1
     neighbor 1.1.1.1 update-source lo
     neighbor 8.8.8.8 remote-as 1
     neighbor 8.8.8.8 update-source lo
     address-family 12vpn evpn
      neighbor 1.1.1.1 activate
      neighbor 8.8.8.8 activate
     exit-address-family
    1
    evpn mpls enable
    evpn mpls vtep-ip-global 7.7.7.7
    hardware-profile filter evpn-mpls-mh enable
    evpn mpls multihoming enable
    vrf definition vrf2
     rd 7.7.7.7:2
     route-target both 2:2
    1
    evpn mpls id 101
    host-reachability-protocol evpn-bgp vrf2
    1
    interface Pol
    load-interval 30
    evpn multi-homed system-mac 0000.aaaa.bbbc
    1
    interface Pol.2
    switchport
    encapsulation dot1q 2
    access-if-evpn
    map vpn-id 101
    interface xe5
     channel-group 1 mode active
    I.
    ethernet cfm domain-type character-string domain-name 12346 level 7 mip-
    creation none
     service ma-type string ma-name 124
      ethernet cfm mep up mpid 20 active true pol.2 vlan 2
       cc multicast state enable
       exit-ether-ma- mode
       mep auto-discovery enable
       cc interval 10ms
       exit-ether-ma- mode
    L
PE3:
    interface lo
```

```
ip address 8.8.8.8/32
1
interface xe5
 ip address 124.1.1.2/24
 enable-ldp ipv4
label-switching
interface xe4
 channel-group 1 mode active
I.
router ldp
 router-id 8.8.8.8
 targeted-peer ipv4 1.1.1.1
 targeted-peer ipv4 7.7.7.7
1
router ospf 1
 router-id 8.8.8.8
 network 8.8.8.8/32 area 0
network network 124.1.1.0/24 area 0
!
router bgp 1
 bgp log-neighbor-changes
 neighbor 1.1.1.1 remote-as 1
 neighbor 1.1.1.1 update-source lo
 neighbor 7.7.7.7 remote-as 1
 neighbor 7.7.7.7 update-source lo
 address-family 12vpn evpn
 neighbor 1.1.1.1 activate
 neighbor 7.7.7.7 activate
exit-address-family
evpn mpls enable
evpn mpls vtep-ip-global 8.8.8.8
hardware-profile filter evpn-mpls-mh enable
evpn mpls multihoming enable
1
vrf definition vrf2
 rd 8.8.8.8:2
 route-target both 2:2
evpn mpls id 101
host-reachability-protocol evpn-bgp vrf2
I.
interface Pol
load-interval 30
evpn multi-homed system-mac 0000.aaaa.bbbc
interface Pol.2
switchport
encapsulation dot1q 2
access-if-evpn
map vpn-id 101
ethernet cfm domain-type character-string domain-name 12346 level 7 mip-
creation none
 service ma-type string ma-name 124
  ethernet cfm mep up mpid 30 active true pol.2 vlan 2
```

```
cc multicast state enable
exit-ether-ma- mode
mep auto-discovery enable
cc interval 10ms
exit-ether-ma- mode
!
```

Validation

The following are the validations for PE1.

PE1

The following validation is for PE1.

PE1#show ethernet	cfm errors			
domain				
12346				
Domain Name	Level	MEPID	Defects	
12346	7	20		

PE1-7011#show	ethernet	cfm ma	intenan	ce-poi	nts remote o	domain 12346	ma-name	124
MEPID	RMEPID	LEVEL	Rx CCM	4 RDI	PEER-MAC	TYPE		
10	20	7	Yes	False	00aa.bb00.0	002 Learnt		
10	30	7	Yes Fa	alse	00aa.dd00.0	003 Learnt		

PE1-7011#show ethernet cfm maintenance-points local mep domain 12346 ma-name 124 MPID Dir Lvl CC-Stat HW-Status CC-Intvl MAC-AddressDef Port MD Name

10 Up 7Enable Installed 100 ms3417.ebe4.af22 Fxe33.2 12346

PE1-7011#ping ethernet mac 00aa.bb00.0002 unicast source 10 domain 12346 ma 124 success rate is 100 (5/5)

PE1-7011#traceroute ethernet 00aa.bb00.0002 mepid 10 domain 12346 ma 124 MP MacHops Relay-actionIngress/Egress Ingress/Egress action 00aa.bb00.00021RlyHit IngressIngOK

PE1-7011#ping ethernet mac 00aa.dd00.0003 unicast source 10 domain 12346 ma 124 success rate is 100 (5/5) PE1-7011#traceroute ethernet 00aa.dd00.0003 mepid 10 domain 12346 ma 124 MP MacHops Relay-actionIngress/Egress Ingress/Egress action 00aa.dd00.00031RlyHit IngressIngOK

Verify Synthetic Loss Measurement

PE1#loss-measurement type proactive profile-name SLM rmep 10 mep 20 domain 12346 ma 124 PE1#2023 Sep 30 07:07:57.166 : PE1 : ONMD : INFO : [CFM_DEFECT_INFO_5]: CFM Frame Loss Measurement started for MEP:20 MA:124 MD:12346 PE1#show ethernet cfm loss-measurement mep 20 domain 12346 ma-name 124

```
MEP: 20 MA: 124
CURRENT:
 Measurement ID : 2
 Suspect : False
 Measurement Type : slm
 Elapsed time(sec) : 10
 Start Time : 2023 Sep 30 07:08:56
 Near End loss : 0
 Far End loss : 0
 Near End accumulated loss : 0
 Far End accumulated loss : 0
 Near End frame loss ratio : 0
 Far End frame loss ratio : 0
HISTORY:
 Measurement ID : 1
 Suspect : False
 Measurement Type : slm
 Elapsed time(sec) : 60
 End Time : 2023 Sep 30 07:08:56
 Near End loss : 0
 Far End loss : 0
 Near End accumulated loss : 0
 Far End accumulated loss : 0
 Near End frame loss ratio : 0
 Far End frame loss ratio : 0
 Near End frame loss ratio min : 0
 Far End frame loss ratio min : 0
 Near End frame loss ratio max : 0
 Far End frame loss ratio max : 0
```

Verify Delay-measurement

PE1#delay-measurement type proactive profile-name DM rmep 10 mep 20 domain 12346 ma 124 PE1#2023 Oct 12 04:11:56.696 : PE1 : ONMD : INFO : [CFM PM SESSION INFO 5]: CFM Frame Delay Measurement session started for MEP Id 20 and RMEP Id 10 PE1#show ethernet cfm delay-measurement mep 20 domain 12346 ma-name 124 MD : 12346 MA : 124 MEP : 20 VC Name : test3 Peer MAC Address : e8c5.7ae3.37ee CURRENT: RMEP ID : 10 Measurement ID : 1 Measurement Type : DMM Elapsed time(sec) : 2 Start Time : 2023 Oct 12 04:11:56 Suspect Flag : FALSE Min Frame Delay(usec) : 40 Max Frame Delay(usec) : 74 Avg Frame Delay(usec) : 57

```
Min Inter FD Variation(usec): 34
Max Inter FD Variation(usec): 34
Avg Inter FD Variation(usec): 34
FRAME DELAY BINS
Bin Number Bin Threshold(usec) Bin Counter
1 0 - < 4999 2
2 5000 - < 9999 0
3 10000 - < 14999 0
4 15000 - < 4294967295 0
INTER-FRAME DELAY BINS
Bin Number Bin Threshold(usec) Bin Counter
1 0 - < 4999 1
2 5000 - < 9999 0
3 10000 - < 4294967295 0</pre>
```

PE2/PE3

The following validations for PE2 and PE3.

The following validations for PE2 and PE3.

PE2#sh EVPN-M	ow evpn mpls PLS Informati	on					
======	=======						
Code	es: NW - Netw	ork Port					
	AC - Acce	ss Port					
	(u) - Unta	gged					
VPN-ID Status	EVI-Name Src-Addr	EVI-T <u>)</u> Dst	ype Type -Addr	Interface	e ESI	VL	AN DF-
101	7.7.7.7	L2 1	NW .1.1.1				
101	 7.7.7.7	L2 8	NW .8.8.8				
101			AC	po1.2 00	:00:00:aa:aa:bb:b	ob:00:00:00	DF

Total number of entries are 4

Note: Refer sub-interface config for VLAN information.

PE3#

VPN-ID Status S	EVI-Name Src-Addr	EVI- D	-Type Type st-Addr	Interf	ace ESI	VLAN	DF-
101	8.8.8.8	L2	NW 1.1.1.1				-
101	 8.8.8.8	L2	NW 7.7.7.7				-
101 DF			AC	po1.2	00:00:00:aa:aa:bb:bb:00:00:	00	NON-
Total ni	umber of entr	ries a	re 4				
Note: Re PE3#	efer sub-inte	erface	config fo	or VLAN	information.		
PE2#sh @	ethernet cfm	error	s domain 1	2346			
Domain 1	NameLevelMEPI	DDefe	cts				
123467 2 PE2#shor CC-Stat	20 w ethernet cf HW-Status CC	m mair C-Intv	itenance-p 1 MAC-Addr	oints l cessDef	ocal mep domain 12346 ma-nam Port MD Name	e 124 MPID Dir	r Lvl
20 Up 7	Enable Insta	lled 1	00 ms00aa	.bb00.0	002 Fpo1.2 12346		
PE2#show MEPIDRMI 20 10 7 source 1 success PE2#trac MP MacHe Ingress	w ethernet cf EPIDLEVELRX (YesFalse (10 domain 123) rate is 100 ceroute ether ops Relay-act IngOK	Em mai CCMRDI 3417.e 346 ma (5/5) cnet 3 cionIn	ntenance-p PEER-MACTY be4.af22 1 124 417.ebe4.a gress/Egre	ooints : TPE Learnt 1f22 mej ess Ing:	remote domain 12346 ma-name PE2#ping ethernet mac 3417.e pid 10 domain 12346 ma 124 ress/Egress action 3417.ebe4	124 be4.af22 unic .af221RlyHit	cast

CHAPTER 9 Y.1731 and CFM Over VPLS Sub-Interface

Overview

Y.1731 Connectivity Fault Management (CFM) over Layer 2 Virtual Private LAN Service (VPLS) is a protocol and technology combination used for fault management in Layer 2 VPN networks. It allows for the detection and management of faults, performance monitoring, and fault localization within a VPLS network

Feature Characteristics

- Facilitates end-to-end fault management across the VPLS network, covering provider and customer edges.
- Supports multi-level fault management, allowing operators to define different levels of fault detection and management for different parts of the network.
- Y.1731 CFM includes performance monitoring capabilities, such as delay measurement and frame loss measurement, to monitor service quality parameters.
- The protocol supports loopback and link trace functions to identify and troubleshoot faults within the VPLS network.

Benefits

- Enables rapid detection and localization of faults within the VPLS network, minimizing downtime and service disruptions.
- Provides performance monitoring capabilities, allowing to track key performance indicators and ensure service quality.
- Enhances network visibility by providing detailed fault and performance monitoring data, aiding in network troubleshooting and maintenance.

Prerequisites

Ensure the network devices participating in the L2VPN VPLS setup support Y.1731 CFM functionality. This includes the Provider Edge (PE) and Customer Edge (CE) devices.

Configuration

Configure Y.1731 CFM over sub-interface using L2VPN VPLS by defining the CFM domain, configuring service MEPs and MAs, and setting up cross-connects between primary and backup interfaces.

Topology

The topology consists of three Customer Edge devices (CE1, CE2, and CE3) connected to three Provider Edge devices (PE1, PE2, and PE3) via sub-interfaces (xe1, xe12, and xe13). The Provider Edge devices are interconnected through Provider Devices (P1 and P2). Y.1731 ethernet CFM is configured over these sub-interfaces to monitor and manage ethernet connectivity between the CE devices, ensuring fault detection and performance monitoring across the service provider's network.



Figure 9-18: L2VPN VPLS Y1731 CFM Over Sub-interface

Perform the following configurations to configure Y.1731 CFM over sub-interface using L2VPN VPLS:

1. On Customer Edge (CE) Nodes (CE1, CE2, and CE3), configure the interface xe1 and set it as a switchport with a load interval of (30 seconds):

```
CE1(config)#interface xe1
CE1(config-if)#switchport
CE1(config-if)#load-interval 30
CE1(config-if)#commit
```

CE1(config-if)#exit

Note: Similarly follow the same steps to configure xe11(CE1), xe12(CE2), and xe13(CE3).

2. Create sub-interface (xe1.2001)adding the VLAN:

```
CE1(config)#interface xe1.2001 switchport
CE1(config-if)#encapsulation dot1q 2028
CE1(config-if)#commit
CE1(config-if)#exit
CE1(config)#interface xe11.2001 switchport
CE1(config-if)#encapsulation dot1q 2028
CE1(config-if)#commit
CE1(config-if)#exit
```

3. Set up a cross-connect named (test100), specifying in and out interfaces:

```
CE1(config)#cross-connect test100
CE1(config-xc)#interface xe1.2001
CE1(config-xc)#interface xe11.2001
CE1(config-xc)#commit
```

- 4. Perform the following on PE1:
 - 1. Configure CFM related hardware profiles:

```
PE1(config)# hardware-profile filter cfm-domain-name-str enable
PE1(config)# hardware-profile statistics cfm-lm enable
PE1(config)# hardware-profile statistics cfm-ccm enable
PE1(config)#hardware-profile statistics cfm-slm enable
```

2. Configure the loopback interface with a secondary IP address(1.1.1.1/32):

```
PE1(config)#interface lo
PE1(config-if)#ip address 1.1.1.1/32 secondary
PE1(config-if)#commit
PE1(config-if)#exit
```

3. Configure LDP targeted peers:

```
PE1(config) #router ldp
PE1(config-router) #targeted-peer ipv4 4.4.4.4
PE1(config-router-targeted-peer) #exit-targeted-peer-mode
PE1(config-router) #targeted-peer ipv4 5.5.5.5
PE1(config-router-targeted-peer) #exit-targeted-peer-mode
PE1(config-router) #transport-address ipv4 1.1.1.1
```

```
PE1(config-router)#commit
PE1(config-router)exit
```

4. Configure interface xe2 with an IP address (192.168.10.1/24) and enable LDP:

```
PE1(config)#interface xe2
PE1(config-if)#load-interval 30
PE1(config-if)#ip address 192.168.10.1/24
PE1(config-if)#label-switching
PE1(config-if)#enable-ldp ipv4
PE1(config-if)#commit
PE1(config-if)#exit
```

5. Configure OSPF routing, specify the OSPF router ID as (1.1.1.1), enable BFD on all interfaces, define the network (1.1.1.1/32) in area (0.0.0.0), and define the network (192.168.10.0/24) in area (0.0.0.0):

```
PE1(config) #router ospf 1
PE1(config-router) #ospf router-id 1.1.1.1
PE1(config-router) #bfd all-interfaces
PE1(config-router) #network 1.1.1.1/32 area 0.0.0.0
PE1(config-router) #network 192.168.10.0/24 area 0.0.0.0
PE1(config-router) #commit
PE1(config-router) #exit
```

6. Set up an L2VPN VPLS between PE1, PE2, and PE3.

```
PE1(config) #mpls vpls vpls-301 301
PE1(config-vpls) # signaling ldp
PE1(config-vpls-sig) # vpls-type vlan
PE1(config-vpls-sig) # vpls-peer 4.4.4.4
PE1(config-vpls-sig) # vpls-peer 5.5.5.5
PE1(config-vpls) # exit-signaling
PE1(config-vpls) # exit-vpls
PE1(config) #commit
PE1(config) #exit
```

7. Configure sub-interface (xe1.2001) as an access interface for VPLS.

```
PE1(config)#interface xe1.2001 switchport
PE1(config-if)#encapsulation dot1q 2028
PE1(config-if)# access-if-vpls
PE1(config-acc-if-vpls)#mpls-vpls vpls-301
PE1(config-acc-if-vpls)#commit
PE1(config-acc-if-vpls)#exit
```

- 8. Configure Up-mep CFM domain:
 - Set the domain type as a character string with the domain name (12346) and (level 7)
 - Specify the MA type as a string with the MA name (124)
 - Set up a MEP with MEP ID (20) as active on interface (xe1.2001) and Associate the vlan (VLAN 2028)
 - · Enable multicast state for continuity check, and auto-discovery of RMEPs
 - Set the continuity check interval to (10 milliseconds)

```
PE1(config)#ethernet cfm domain-type character-string domain-name
12346 level 7 mip-creation none
PE1(config-ether-cfm)# service ma-type string ma-name 124
PE1(config-ether-cfm-ma)#ethernet cfm mep up mpid 20 active true
xe1.2001 vlan 2028
PE1(config-ether-cfm-ma-mep)#cc multicast state enable
PE1(config-ether-cfm-ma-mep)#exit-ether-ma-mep-mode
```

```
PE1(config-ether-cfm-ma) #rmep auto-discovery enable
PE1(config-ether-cfm-ma) #cc interval 10ms
PE1(config-ether-cfm-ma) #exit-ether-ma-mode
PE1(config-ether-cfm) #commit
PE1(config-ether-cfm) exit
Create a loss measurement profile named SLM with measurement type SLM, measurement interval of
1, intervals stored of 3, and message period of (1) second.
PE1(config) #ethernet cfm loss-measurement profile-name SLM
PE1(config-cfm-lm) #measurement-type slm
PE1(config-cfm-lm) #measurement-interval 1
PE1(config-cfm-lm) #intervals-stored 3
PE1(config-cfm-lm) #message-period 1s
PE1(config-cfm-lm) #exit
```

• Create a delay measurement profile named DM with a measurement interval of (1), intervals stored of (2), and message period of (1 second).

```
PE1(config)#ethernet cfm delay-measurement profile-name DM
PE1(config-cfm-dm)#measurement-interval 1
PE1(config-cfm-dm)#intervals-stored 2
PE1(config-cfm-dm)#message-period 1
```

Configuration Snapshot:

PE1:

```
interface lo
 ip address 1.1.1.1/32 secondary
T
router ldp
 targeted-peer ipv4 4.4.4.4
  exit-targeted-peer-mode
 targeted-peer ipv4 5.5.5.5
  exit-targeted-peer-mode
transport-address ipv4 1.1.1.1
T.
mpls vpls vpls-301 301
 signaling ldp
  vpls-type vlan
  vpls-peer 4.4.4.4
  vpls-peer 5.5.5.5
  exit-signaling
 exit-vpls
I
interface xe2
 load-interval 30
 ip address 192.168.10.1/24
 label-switching
 enable-ldp ipv4
L
router ospf 1
 ospf router-id 1.1.1.1
 bfd all-interfaces
 network 1.1.1.1/32 area 0.0.0.0
 network 192.168.10.0/24 area 0.0.0.0
```

```
!
interface xel
 switchport
load-interval 30
!
interface xel.2001 switchport
encapsulation dot1q 2028
access-if-vpls
 mpls-vpls vpls-301
T.
ethernet cfm domain-type character-string domain-name 12346 level 7 mipcreation none
 service ma-type string ma-name 124
 ethernet cfm mep up mpid 20 active true xe1.2001 vlan 2028
 cc multicast state enable
 exit-ether-ma-mep-mode
 rmep auto-discovery enable
 cc interval 10ms
 exit-ether-ma-mode
T
ethernet cfm loss-measurement profile-name SLM
measurement-type slm
measurement-interval 1
 intervals-stored 3
message-period 1s
1
ethernet cfm delay-measurement profile-name DM
measurement-interval 1
 intervals-stored 2
message-period 1s
```

PE2:

```
interface lo
 ip address 4.4.4.4/32 secondary
!
router ldp
 targeted-peer ipv4 1.1.1.1
exit-targeted-peer-mode
targeted-peer ipv4 5.5.5.5
exit-targeted-peer-mode
transport-address ipv4 4.4.4.4
1
interface xe2
 load-interval 30
 ip address 192.168.30.2/24
 label-switching
 enable-ldp ipv4
!
router ospf 1
 ospf router-id 4.4.4.4
 bfd all-interfaces
```

```
network 4.4.4.4/32 area 0.0.0.0
 network 192.168.30.0/24 area 0.0.0.0
Т
mpls vpls vpls-301 301
 signaling ldp
  vpls-type vlan
 vpls-peer 1.1.1.1
  vpls-peer 5.5.5.5
  exit-signaling
 exit-vpls
Т
interface xel
 switchport
 load-interval 30
T
interface xe1.2001 switchport
 encapsulation dot1q 2028
 access-if-vpls
  mpls-vpls vpls-301
T
ethernet cfm domain-type character-string domain-name 12346 level 7 mipcreation none
 service ma-type string ma-name 124
 ethernet cfm mep up mpid 10 active true xe1.2001 vlan 2028
 cc multicast state enable
 ethernet cfm loss-measurement reply slm
 ethernet cfm delay-measurement reply dmm
 exit-ether-ma-mep-mode
 rmep auto-discovery enable
 cc interval 10ms
 exit-ether-ma-mode
Т
PE3:
interface lo
 ip address 5.5.5/32 secondary
T.
router ldp
 targeted-peer ipv4 1.1.1.1
exit-targeted-peer-mode
targeted-peer ipv4 4.4.4.4
exit-targeted-peer-mode
transport-address ipv4 5.5.5.5
!
interface xe3
 load-interval 30
 ip address 192.168.40.2/24
 label-switching
 enable-ldp ipv4
T
router ospf 1
 ospf router-id 5.5.5.5
```

```
bfd all-interfaces
 network 5.5.5.5/32 area 0.0.0.0
 network 192.168.40.0/24 area 0.0.0.0
Ţ
mpls vpls vpls-301 301
 signaling ldp
  vpls-type vlan
  vpls-peer 1.1.1.1
  vpls-peer 4.4.4.4
  exit-signaling
 exit-vpls
T
interface xel
 switchport
 load-interval 30
T
interface xel.2001 switchport
 encapsulation dot1q 2028
 access-if-vpls
  mpls-vpls vpls-301
T
ethernet cfm domain-type character-string domain-name 12346 level 7 mipcreation none
 service ma-type string ma-name 124
 ethernet cfm mep up mpid 30 active true xe1.2001 vlan 2028
 cc multicast state enable
  ethernet cfm loss-measurement reply slm
 ethernet cfm delay-measurement reply dmm
 exit-ether-ma-mep-mode
 rmep auto-discovery enable
 cc interval 10ms
 exit-ether-ma-mode
!
P2:
interface lo
 ip address 3.3.3.3/32 secondary
!
router ldp
 transport-address ipv4 3.3.3.3
T
interface xel
 ip address 192.168.20.2/24
 label-switching
 enable-ldp ipv4
Ţ.
interface xe2
 ip address 192.168.30.1/24
 label-switching
 enable-ldp ipv4
L
interface xe3
```

```
ip address 192.168.40.1/24
 label-switching
 enable-ldp ipv4
T
router ospf 1
ospf router-id 3.3.3.3
bfd all-interfaces
network 3.3.3/32 area 0.0.0.0
network 192.168.20.0/24 area 0.0.0.0
network 192.168.30.0/24 area 0.0.0.0
 network 192.168.40.0/24 area 0.0.0.0
CE3:
interface xel
switchport
load-interval 30
T
interface xel.2001 switchport
encapsulation dot1q 2028
T
interface xe13.2001 switchport
 encapsulation dot1q 2028
T
cross-connect test100
 interface xel.2001
 interface xe13.2001
CE1:
    interface xel
    switchport
     load-interval 30
    interface xe1.2001 switchport
     encapsulation dot1q 2028
    interface xell.2001 switchport
     encapsulation dot1q 2028
    cross-connect test100
     interface xel.2001
     interface xell.2001
CE2:
    interface xel
    switchport
     load-interval 30
    interface xe1.2001 switchport
     encapsulation dot1q 2028
    interface xe12.2001 switchport
     encapsulation dot1q 2028
    cross-connect test100
```

```
interface xe1.2001
interface xe12.2001
```

Validation

Verify the L2VPN VPLS status.

PE1# show mpls vpls mesh
(m) - Service mapped over multipath transport
(e) - Service mapped over LDP ECMP

VPLS-ID	Peer Addr	Tunnel·	-Label In-Label	Network-Intf	Out-Label	Lkps/St
PW-INDEX	SIG-Protocol	Status	UpTime			
301	4.4.4.4	52481	26240	xe2	28160	2/Up
2	LDP	Active	1d00h02m			
301	5.5.5.5	52497	26256	xe2	26256	2/Up
3	LDP	Active	1d00h57m			

PE1#

Verify the RMEP is learned or not.

PE1#show ethernet cfm maintenance-points remote domain 12346 MA_NAME MEPID RMEPID LEVEL Rx CCM RDI PEER-MAC TYPE

124 20 10 7 Yes False e8c5.7ae3.37ee Learnt 124 20 30 7 Yes False e8c5.7ae3.38ee Learnt

Verify the Ping:

PE1#ping ethernet mac e8c5.7ae3.37ee unicast source 20 domain 12346 ma 124 success rate is 100 (5/5)

PE1#ping ethernet mac e8c5.7ae3.38ee unicast source 20 domain 12346 ma 124 success rate is 100 (5/5)

Verify the Traceroute:

PE1#traceroute ethernet e8c5.7ae3.37ee mepid 20 domain 12346 ma 124 MP Mac Hops Relay-action Ingress/Egress Ingress/Egress action e8c5.7ae3.37ee 1 RlyHit Ingress IngOK

PE1#traceroute ethernet e8c5.7ae3.38ee mepid 20 domain 12346 ma 124 MP Mac Hops Relay-action Ingress/Egress Ingress/Egress action e8c5.7ae3.38ee 1 RlyHit Ingress IngOK

Implementation Examples

- To support a vast network infrastructure delivering VPLS to a multitude of enterprise clients, it is imperative to maintain uninterrupted connectivity and peak performance for these VPLS connections, all while minimizing the risk of downtime or disruptions.
- Understanding the role of fault detection, localization, and performance monitoring within the VPLS network, deploy Y.1731 CFM over Layer 2 VPN (VPLS) to enhance the network's resilience and operational efficiency.

Glossary

The following provides definitions for key terms or abbreviations and their meanings used throughout this document:

Key Terms/Acronym	Description
Virtual Private LAN Service (VPLS)	Allows multiple sites in different geographical locations to connect over a wide area network (WAN), creating the experience of being part of a single local area network (LAN).
Connectivity Fault Management (CFM)	CFM is a protocol used to detect, verify, and isolate connectivity faults in a network. It operates at the data link layer and is designed to monitor ethernet networks.
Virtual Private LAN Service (VPLS)	Allows multiple dispersed sites to connect over a wide area network (WAN), creating the experience of being part of a single local area network (LAN).
Maintenance End Point (MEP)	MEP is a CFM entity that resides at the edge of a CFM domain. It is responsible for generating and transmitting CFM protocol packets to detect faults and collect performance data.
Maintenance Domain (MD)	MD is a logical grouping of MEPs within a CFM network. MEPs within the same MD can communicate with each other to perform CFM functions such as fault detection and performance monitoring.
Maintenance Association(MA)	MA is a collection of MEPs associated with a specific service or set of services. It defines the scope of CFM operations within a maintenance domain.
Maintenance Point Identifier (MPID)	MPID is a unique identifier assigned to each MEP within a maintenance association. It is used to distinguish between different MEPs within the same MA.
Service Level Measurement (SLM)	SLM is a CFM function used to measure the loss characteristics of a network path. It collects data on packet loss, delay, and jitter to assess the quality of service provided by the network.
Loopback Message Generation (LMM)	LMM is a CFM function used to test end-to-end connectivity by generating loopback messages. These messages are transmitted from a MEP and looped back to the same MEP to verify bidirectional communication.
Delay Measurement Message (DMM)	DMM is a CFM function used to measure the one-way delay of packets transmitted across a network. It helps assess the performance of the network in terms of packet delivery time.
Continuity Check (CC)	CC is a CFM function used to verify the continuity of a service or network path by periodically sending continuity check messages between MEPs. It helps detect connectivity faults such as link failures or misconfigurations.

CHAPTER 10 Ethernet Linear Protection Switching Configuration

The feature Ethernet Linear Protection Switching (ELPS) adds a fast mechanism to switch from a failing Ethernet transport entity, thereby restoring node to node link up condition.

The objective of fast protection switching is achieved by integrating mature Ethernet operations, administration, and maintenance (OAM) functions and a simple automatic protection switching (APS) protocol for Ethernet linear networks. Since protection switching requires monitoring of both working and protection transport enti-ties, it is required that MEPs be activated for the purpose of monitoring the working and protection transport entities. Both transport entities are monitored individually by exchanging Continuity Check Messages (CCMs).

ELPS protocol is optimized to provide Protection Switching between two distinct endpoints on a point to point vlanbased Ethernet network. It can be used as an alternative to spanning tree protocol (STP) for fast transiting the port status without complex computation, provisioning overhead, and excessive information exchange, to thus achieve much faster (i.e., 50ms) protection switching. With ELPS, it is much convenient for network operator to grasp the status of network (eg. Active network topology) with protection switching than with other survivability mechanisms, such as STP.

Topology



Figure 10-19: ELPS Topology

Configuration

Prerequisite

Configure below hardware-profile commands related to CFM in configuration mode and reboot the nodes.

```
hardware-profile filter cfm-domain-name-str enable hardware-profile statistics cfm-ccm enable
```

Bridgel#configure terminal	Enter the configure mode
Bridge1(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge
Bridge1(config)#vlan 10-100 bridge 1 state enable	Create VLAN 10-100 on bridge 1
Bridgel(config)#commit	Commit the transaction
Bridgel(config)#interface xel	Configure interface xe1
Bridgel(config-if)# switchport	Configure xe1 as a layer 2 port
Bridge1(config-if)# bridge-group 1	Configure interface in bridge group 1

Bridgel(config-if)# switchport mode trunk	Configure port as trunk port
Bridgel(config-if)# switchport trunk allowed vlan add 10-100	Allow VLAN 10-100 on xe1 interface
Bridgel(config)#interface xe2	Configure interface xe2
Bridgel(config-if)# switchport	Configure xe2 as a layer 2 port
Bridge1(config-if)# bridge-group 1	Configure interface in bridge group 1
Bridge1(config-if)# switchport mode trunk	Configure port as trunk port
Bridgel(config-if)# switchport trunk allowed vlan add 10-100	Allow VLAN 10-100 on xe1 interface
Bridgel(config-if)#exit	Exit the interface mode
Bridgel(config)#commit	Commit the transaction
Bridgel(config)#ethernet cfm domain-type character-string domain-name 12345 level 5 mip-creation none	Create CFM domain with type as character string with name 12345 and set mip creation criteria to default with level 5 on bridge 1
Bridgel(config-ether-cfm)#service ma-type string ma-name 54321	Create MA type as string with name 54321
Bridge1(config-ether-cfm-ma)# vlan 10 bridge 1	Add VLAN 10
Bridge1(config-ether-cfm-ma)#mip-creation none	Set mip-creation creation criteria to none
Bridgel(config-ether-cfm-ma)#ethernet cfm mep down mpid 111 active true xe1	Create the down MEP 111 for ${\tt xe1}$ interface
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multi-cast
Bridge1(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit the Ethernet CFM MA-MEP mode
Bridge1(config-ether-cfm-ma)#mep crosscheck mpid 222	Configure crosscheck to remote MEP with value 222
Bridgel(config-ether-cfm-ma)#cc interval 3ms	Enable CC interval with 3ms
Bridge1(config-ether-cfm-ma)#exit-ether-ma- mode	Exit the Ethernet MA mode
Bridgel(config-ether-cfm)#exit	Exit the Ethernet CFM mode
Bridgel(config)#ethernet cfm domain-type character-string domain-name 56789 level 5 mip-creation none	Create CFM domain with type as character string with name 56789 and set MIP creation criteria to default with level 5 on bridge 1
Bridgel(config-ether-cfm)#service ma-type string ma-name 98765	Create MA type as string with name 98765.
Bridge1(config-ether-cfm-ma)# vlan 10 bridge 1	Add VLAN 10
Bridgel(config-ether-cfm-ma)#mip-creation none	Set MIP-creation creation criteria to none
Bridgel(config-ether-cfm-ma)#ethernet cfm mep down mpid 333 active true xe2	Create down MEP 333 for xe2 interface
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multi-cast
Bridgel(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit the Ethernet CFM MA-MEP mode

Bridgel(config-ether-cfm-ma)#mep crosscheck mpid 444	Configure crosscheck to remote MEP with value 444
Bridge1(config-ether-cfm-ma)#cc interval 3ms	Enable CC interval with 3ms
Bridge1(config-ether-cfm-ma)#exit-ether-ma- mode	Exit the Ethernet ma mode
Bridgel(config-ether-cfm)#exit	Exit the Ethernet CFM mode
Bridgel(config)#commit	Commit transaction
Bridgel(config)#g8031 eps-protection group eps1	Create g8031 protection group
Bridge1(g8031-config-protection)# working- port xe2	Associate $xe2$ interface as working port to g8031 protection group
Bridge1(g8031-config-protection)# protection-port xe1	Associate $xe1$ interface as protection port to g8031 protection group
Bridge1(g8031-config-protection)#g8031 profile eps1	Create g8031 profile
Bridge1(g8031-config-profile)# mode one-and- one-bidirectional	Associate g8031 mode one-and-one bidirectional
Bridge1(g8031-config-profile)# switching mode revertive	Set switchover type revertive mode
Bridge1(g8031-config-profile)# timer wait- to-restore 420	Set timer wait-to-restore
Bridge1(g8031-config-profile)#g8031 eps- instance eps1	Create g8031 instance
Bridge1(g8031-config-eps-instance)# eps- protection-group eps1	Associate g8031 protection group to instance
Bridge1(g8031-config-eps-instance)# g8031- profile eps1	Associate g8031 profile to instance
Bridge1(g8031-config-eps-instance)# aps- channel level 5	Add control VLAN 10
Bridge1(g8031-config-eps-instance)# control vlan 10	Commit the transaction
Bridge1(g8031-config-eps-instance)#data vlan 20,30	Add data VLAN 20,30
Bridge1(g8031-config-eps-instance)#exit	Exit the g8031 configuration mode
Bridgel(config)#commit	Commit the transaction
Bridgel(config)#end	Exit configuration terminal

Bridge2#configure terminal	Enter the configure mode
Bridge2(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge
Bridge2(config)#vlan 10-100 bridge 1 state enable	Create VLAN 10-100 on bridge 1
Bridge2(config)#commit	Commit the transaction
Bridge2(config)#interface xel	Configure interface xe1
Bridge2(config-if)# switchport	Configure xe1 as a layer 2 port

Bridge2(config-if)# bridge-group 1	Configure interface in bridge group 1
Bridge2(config-if)# switchport mode trunk	Configure port as trunk port
<pre>Bridge2(config-if)# switchport trunk allowed vlan add 10-100</pre>	Allow VLAN 10-100 on xe1 interface
Bridge2(config)#interface xe2	Configure interface xe2
Bridge2(config-if)# switchport	Configure xe2 as a layer 2 port
Bridge2(config-if)# bridge-group 1	Configure interface in bridge group 1
Bridge2(config-if)# switchport mode trunk	Configure port as trunk port
<pre>Bridge2(config-if)# switchport trunk allowed vlan add 10-100</pre>	Allow VLAN 10-100 on xe1 interface
Bridge2(config-if)#exit	Exit the interface mode
Bridge2(config)#commit	Commit the transaction
Bridge2(config)#g8031 eps-protection group eps1	Create g8031 protection group
<pre>Bridge2(g8031-config-protection)# working- port xe2</pre>	Associate $xe2$ interface as working port to g8031 protection group
Bridge2(g8031-config-protection)# protection-port xe1	Associate xel interface as protection port to g8031 protection group
Bridge2(g8031-config-protection)#g8031 profile eps1	Create g8031 profile
Bridge2(g8031-config-profile)# mode one-and- one-bidirectional	Associate g8031 mode one-and-one bidirectional
Bridge2(g8031-config-profile)# timer wait- to-restore 420	Set timer wait-to-restore
Bridge2(g8031-config-profile)#g8031 eps- instance eps1	Create g8031 instance
Bridge2(g8031-config-eps-instance)# eps- protection-group eps1	Associate g8031 protection group to instance
<pre>Bridge2(g8031-config-eps-instance)# g8031- profile eps1</pre>	Associate g8031 profile to instance
Bridge2(g8031-config-eps-instance)# aps- channel level 5	Associate CFM to PG
Bridge2(g8031-config-eps-instance)# control vlan 10	Add control VLAN 10
Bridge2(g8031-config-eps-instance)#data vlan 20,30	Add data VLAN 20,30
Bridge2 (g8031-config-eps-instance) #exit	Exit g8031 configuration mode
Bridge2(config)#commit	Commit the transaction
Bridge2 (config) #end	Exit the configuration terminal

Validation

1. Verify ELPS on Bridge1

Bridge1#show g8031 eps-instance

EPS-Name Id Mode Working-Path State Protection-Path State Control-VLAN CFM

```
_____
eps1 1 1:1,BI xe2 (A) Up xe1
                                              Up 10
                                                              Yes
Bridge1#show g8031 eps-instance eps1
Inst Name
           : eps1 (1), Profile (eps1), Protection Group (eps1)
Mode & Group : Bridge (1:1), Direction (Bi), Revertive (Yes)
             : Working port (xe2, Up) Protection port (xe1, Up)
Current State : No Request, Request signal (Null), Active-Path (Working)
              dFOP State - Not in defect mode
working cfm : mep id (111), cc-interval (3ms), Domain (12345), MA (54321)
Protection cfm : mep id (333), cc-interval (3ms), Domain (56789), MA (98765)
APS channel Info: vlan (10) Level (5)
Vlan
       : 20,30
APS Statistics : Tx - 2 Rx - 4
2. Verify ELPS on Bridge2
Bridge2#show g8031 eps-instance
EPS-Name Id Mode Working-Path State Protection-Path State Control-VLAN CFM
                        _____
_____
eps1 1 1:1,BI xe2 (A) Up xe1 Up 10
                                                              Yes
Bridge2#show g8031 eps-instance eps1
Inst Name
          : eps1 (1), Profile (eps1), Protection Group (eps1)
Mode & Group : Bridge (1:1), Direction (Bi), Revertive (Yes)
              : Working port (xe2, Up) Protection port (xe1, Up)
Current State : No Request, Request signal (Null), Active-Path (Working)
              dFOP State - Not in defect mode
working_cfm : mep_id (222), cc-interval (3ms), Domain (12345), MA (54321)
Protection cfm : mep id (444), cc-interval (3ms), Domain (56789), MA (98765)
APS channel Info: vlan (10) Level (5)
```

Vlan : 20,30

APS Statistics : Tx - 4 Rx - 2

CHAPTER 11 G.8032 ERPS Version 2

G.8032 is an International Telecommunication Union (ITU) standard for ERPS. It prevents loops on a per-VLAN basis with networks that are wired in a simple ring topology. The loops are prevented by blocking traffic on either a predetermined link or a failed link.

G.8032 Version 2 provides enhancements in support of multiple ring and ladder topologies. G.8032 offers a rapid detection and recovery time if a link or node.

This guide contains topologies and examples on how to configure g8032 ERPS configuration.

Topology

Figure 11-20 displays a sample Ring Protection topology on which protection switching is configured with four bridges. The Ring Protection Link (RPL) owner is the link between Bridge 3 and Bridge 4 (xe16), on which one side of the link is defined explicitly as RPL owner (Bridge 4) and RPL neighbor (Bridge 3). The rest of the bridges are explicitly configured RPL non owner to enable ERPS in the ring.



Figure 11-20: Major Ring Topology

Prerequisite

Configure below hardware-profile commands related to CFM in configuration mode and reboot the nodes.

hardware-profile filter cfm-domain-name-str enable hardware-profile statistics cfm-ccm enable

Bridgel#configure terminal	Enter configure mode
Bridgel(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.

Bridge1(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string
Bridgel(config)#vlan database	Configure VLAN database
Bridge1(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridgel(config-vlan)#interface xe6	Configure interface xe6
Bridge1(config-if)#switchport	Configure xe6 as a layer 2 port
Bridge1(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridgel(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridgel(config-if)#switchport mode trunk	Configure port as trunk port
Bridge1(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on xe6 interface
Bridgel(config-if)#interface xe8	Configure interface xe8
Bridge1(config-if)#switchport	Configure xe8 as a layer 2 port
Bridge1(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge1(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge1(config-if)#switchport mode trunk	Configure port as trunk port
Bridge1(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on xe8 interface
Bridgel(config-if)#ethernet cfm domain- type character-string domain-name nod12 level 7 mip-creation none	Create cfm domain with type as character string with name nod12 and set MIP creation criteria to default with level 7
Bridgel(config-ether-cfm)#service ma-type string ma-name 43982	Create MA type as string with name 43982
Bridge1(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridgel(config-ether-cfm-ma)# mip-creation none	Set MIP-creation criteria to none
Bridge1(config-ether-cfm-ma)#ethernet cfm mep down mpid 12 active true xe8	Create down MEP 12 for xe8 interface
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge1(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridgel(config-ether-cfm-ma)#mep crosscheck mpid 21	Configure crosscheck to remote MEP with value 21
Bridge1(config-ether-cfm-ma)#cc interval 100ms	Enable cc interval with 100ms
Bridgel(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet ma mode

Bridgel(config-ether-cfm)#ethernet cfm domain-type character-string domain-name nod41 level 7 mip-creation none	Create cfm domain with type as character string with name nod41 and set mip creation criteria to default with level 7
Bridgel(config-ether-cfm)#service ma-type string ma-name 43982	Create MA type as string with name 43982.
Bridge1(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
<pre>Bridge1(config-ether-cfm-ma) # mip-creation none</pre>	Set MIP-creation criteria to none
Bridge1(config-ether-cfm-ma)#ethernet cfm mep down mpid 14 active true xe6	Create down MEP 14 for xe6 interface
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridgel(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge1(config-ether-cfm-ma)#mep crosscheck mpid 41	Configure crosscheck to remote MEP with value 41
Bridge1(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridgel(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet ma mode
Bridge1(config-ether-cfm)#g8032 ring RING1	Create g8032 ring with name RING1
Bridge1(g8032-ring-config)#east-interface xe6	Associate xe6 interface as east-interface
Bridge1(g8032-ring-config)#west-interface xe8	Associate xe8 interface as west-interface
Bridge1(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge1(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge1(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge1(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge1(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge1(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge1(g8032-config-switch)#ring RING1	Associate ring RING1 to erp1 instance
Bridge1(g8032-config-switch) #rpl role non- owner	Configure the node as non-owner node
Bridgel(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance

Bridge1(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge1(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200
Bridge1(g8032-config-switch)#data vlan 201-205	Configure traffic vlan from 201-205
Bridge1(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge1(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge1(g8032-config-switch)#end	Exit g8032 erp instance mode

Bridge2#config terminal	Enter configure mode
Bridge2(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge2(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string
Bridge2(config)#vlan database	Configure VLAN database
Bridge2(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridge2(config-vlan)#interface xe3	Configure interface xe3
Bridge2(config-if)#switchport	Configure xe3 as a layer 2 port
Bridge2(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge2(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge2(config-if)#switchport mode trunk	Configure port as trunk port
Bridge2(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on xe3 interface
Bridge2(config-if)#interface xe8	Configure interface xe8
Bridge2(config-if)#switchport	Configure xe8 as a layer 2 port
Bridge2(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge2(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge2(config-if)#switchport mode trunk	Configure port as trunk port
Bridge2(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on xe8 interface
Bridge2(config-if)#ethernet cfm domain- type character-string domain-name nod23 level 7 mip-creation none	Create cfm domain with type as character string with name nod23 and set mip creation criteria to default with level 7
Bridge2(config-ether-cfm)#service ma-type string ma-name 43982	Create MA type as string with name 43982.
Bridge2(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge2(config-ether-cfm-ma) # mip-creation none	Set MIP-creation criteria to none

Bridge2(config-ether-cfm-ma)#ethernet cfm mep down mpid 23 active true local-vid 200 xe3	Create down MEP 23 with local VID 200 for xe3 interface
Bridge2(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge2(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge2(config-ether-cfm-ma)#mep crosscheck mpid 32	Configure crosscheck to remote MEP with value 32
Bridge2(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge2(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet MA mode
Bridge2(config-ether-cfm)#ethernet cfm domain-type character-string domain-name nod12 level 7 mip-creation none	Create CFM domain with type as character string with name nod12 and set mip creation criteria to default with level 7
Bridge2(config-ether-cfm)#service ma-type string ma-name 43982	Create MA type as string with name 43982.
Bridge2(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
<pre>Bridge2(config-ether-cfm-ma) # mip-creation none</pre>	Set MIP-creation criteria to none
Bridge2(config-ether-cfm-ma)#ethernet cfm mep down mpid 21 active true xe8	Create down MEP 21 for xe8 interface
Bridge2(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge2(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge2(config-ether-cfm-ma)#mep crosscheck mpid 12	Configure crosscheck to remote MEP with value 12
Bridge2(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge2(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet MA mode
Bridge2(config-ether-cfm)#g8032 ring RING1	Create g8032 ring with name RING1
Bridge2(g8032-ring-config)#east-interface xe8	Associate xe8 interface as east-interface
Bridge2(g8032-ring-config)#west-interface xe3	Associate xe3 interface as west-interface
Bridge2(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge2(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge2(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge2(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge2(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode

Bridge2(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge2(g8032-config-switch)#ring RING1	Associate ring RING1 to erp1 instance
Bridge2(g8032-config-switch)#rpl role non- owner	Configure the node as non-owner node
Bridge2(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance
Bridge2(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge2(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200
Bridge2(g8032-config-switch)#data vlan 201-205	Configure traffic vlan from 201-205
Bridge2(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge2(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge2(g8032-config-switch)#end	Exit g8032 erp instance mode

Bridge3#config terminal	Enter configure mode
Bridge3(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge3(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string
Bridge3(config)#vlan database	Configure VLAN database
Bridge3(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridge3(config-vlan)#interface xe3	Configure interface xe3
Bridge3(config-if)#switchport	Configure xe3 as a layer 2 port
Bridge3(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge3(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge3(config-if)#switchport mode trunk	Configure port as trunk port
Bridge3(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on xe3 interface
Bridge3(config-if)#interface xel6	Configure interface xe16
Bridge3(config-if)#switchport	Configure xe16 as a layer 2 port
Bridge3(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge3(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge3(config-if)#switchport mode trunk	Configure port as trunk port
Bridge3(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on xe16 interface
Bridge3(config-if)#ethernet cfm domain-type character-string domain-name nod23 level 7 mip-creation none	Create cfm domain with type as character string with name nod23 and set mip creation criteria to default with level 7
---	---
Bridge3(config-ether-cfm)#service ma-type string ma-name 43982	Create MA type as string with name 43982.
Bridge3(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge3(config-ether-cfm-ma)# mip-creation none	Set mip-creation criteria to none
Bridge3(config-ether-cfm-ma)#ethernet cfm mep down mpid 32 active true xe3	Create down MEP 32 for xe3 interface
Bridge3(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge3(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge3(config-ether-cfm-ma)#mep crosscheck mpid 23	Configure crosscheck to remote MEP with value 23
Bridge3(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge3(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridge3(config-ether-cfm)#ethernet cfm domain-type character-string domain-name nod34 level 7 mip-creation none	Create cfm domain with type as character string with name nod34 and set mip creation criteria to default with level 7
Bridge3(config-ether-cfm)#service ma-type string ma-name 43982	Create MA type as string with name 43982.
Bridge3(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge3(config-ether-cfm-ma)# mip-creation none	Set MIP-creation criteria to none
Bridge3(config-ether-cfm-ma)#ethernet cfm mep down mpid 34 active true xel6	Create down MEP 34 for xe16 interface
Bridge3(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge3(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge3(config-ether-cfm-ma)#mep crosscheck mpid 43	Configure crosscheck to remote MEP with value 43
Bridge3(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge3(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet MA mode
Bridge3(config-ether-cfm)#g8032 ring RING1	Create g8032 ring with name RING1
Bridge3(g8032-ring-config)#east-interface xe3	Associate xe3 interface as east-interface
Bridge3(g8032-ring-config)#west-interface xel6	Associate xe16 interface as west-interface
Bridge3(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1

Bridge3(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge3(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge3(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge3(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge3(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge3(g8032-config-switch)#ring RING1	Associate ring RING1 to erp1 instance
Bridge3(g8032-config-switch)#rpl role neighbor west-interface	Configure RPL node as neighbor node on west-interface
Bridge3(g8032-config-switch)#g8032-profile profile1	Associate profile profile1 to erp1 instance
Bridge3(g8032-config-switch)#aps-chanel level 7	Configure level as 7
Bridge3(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200
Bridge3(g8032-config-switch)#data vlan 201- 205	Configure traffic vlan from 201-205
Bridge3(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge3(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge3(g8032-config-switch)#end	Exit g8032 erp instance mode

Bridge4#config term	Enter configure mode
Bridge4(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge4(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string
Bridge4(config)#vlan database	Configure VLAN database
Bridge4(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridge4(config-vlan)#interface xe6	Configure interface xe6
Bridge4(config-if)#switchport	Configure xe6 as a layer 2 port
Bridge4(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge4(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge4(config-if)#switchport mode trunk	Configure port as trunk port
Bridge4(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on xe6 interface
Bridge4(config-if)#interface xel6	Configure interface xe16
Bridge4(config-if)#switchport	Configure xe16 as a layer 2 port

Bridge4(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge4(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge4(config-if)#switchport mode trunk	Configure port as trunk port
Bridge4(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on xe16 interface
Bridge4(config-if)#ethernet cfm domain-type character-string domain-name nod34 level 7 mip-creation none	Create cfm domain with type as character string with name nod34 and set mip creation criteria to default with level 7
Bridge4(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge4(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge4(config-ether-cfm-ma)# mip-creation none	Set mip-creation criteria to none
Bridge4(config-ether-cfm-ma)#ethernet cfm mep down mpid 43 active true xel6	Create down MEP 43 for xe16 interface
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge4(config-ether-cfm-ma)#mepcrosscheck mpid 34	Configure crosscheck to remote MEP with value 34
Bridge4(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge4(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet MA mode
Bridge4(config-ether-cfm)#ethernet cfm domain-type character-string domain-name nod41 level 7 mip-creation none	Create CFM domain with type as character string with name nod41 and set mip creation criteria to default with level 7
Bridge4(config-ether-cfm)#service ma-type string ma-name 43982	Create MA type as string with name 43982.
Bridge4(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge4(config-ether-cfm-ma)# mip-creation none	Set MIP-creation criteria to none
Bridge4(config-ether-cfm-ma)#ethernet cfm mep down mpid 41 active true xe6	Create down MEP 41 for xe6 interface
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge4(config-ether-cfm-ma)#mep crosscheck mpid 14	Configure crosscheck to remote MEP with value 14
Bridge4(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge4(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridge4(config-ether-cfm)#g8032 ring RING1	Create g8032 physical ring with name RING1

Bridge4(g8032-ring-config)#east-interface xel6	Associate xe16 interface as east-interface
Bridge4(g8032-ring-config)#west-interface xe6	Associate xe6 interface as west-interface
Bridge4(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge4(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge4(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge4(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge4(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge4(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge4(g8032-config-switch)#ring RING1	Associate ring RING1 to erp1 instance
Bridge4(g8032-config-switch)#rpl role owner east-interface	Configure the node as owner node on east-interface
Bridge4(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance
Bridge4(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge4(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200
Bridge4(g8032-config-switch)#data vlan 201- 205	Configure traffic vlan from 201-205
Bridge4(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge4(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge4(g8032-config-switch)#end	Exit g8032 erp instance mode

Validation

```
show g8032 profile profile1
Profile : profile1
========
Wait-To-Restore : 1 mins
Hold Off Timer : 0.00 secs
Guard Timer : 10 ms
Wait-To-Block : 5010 ms
Protection Type : Revertive
Bridge1:
show g8032 erp-instance erp1
        : erp7
Inst Name
Description
          :
State
          : G8032 ST IDLE
          : RING1
Phy Ring
          : MAJOR-RING
Ring Type
          : NON-OWNER
Role
           : 3c:2c:99:26:e6:80
Node ID
_____
            East Link
                          West Link
Interface : xe6 xe6
State : Unblocked Ur
Remote NodeId : 34:17:eb:e4:af:11 -
                           xe8
                           Unblocked
Remote BPR : 1
Endpoint Info
_____
Domain Name : nod41
MEP ID : 14
                           nod12
                           12
          : 43982
MA Name
                           43982
_____
_____
   Channel
(LEVEL, VLAN, RING ID) |
_____
 (7, 200, 1)
_____
DataTraffic vlan: 201-205
Profile : profile1
Bridge2:
show g8032 erp-instance erp1
        : erpl
Inst Name
Description
          :
          : G8032 ST IDLE
State
          : RING1
Phy Ring
Ring Type
          : MAJOR-RING
          : NON-OWNER
Role
Node ID
           : d8:9e:f3:5e:f8:29
_____
             East Link
                           West Link
```

Interface : xe8 State : Unblocked xe3 Unblocked Remote NodeId : 34:17:eb:e4:af:11 _ Remote BPR : 1 Endpoint Info _____ Domain Name : nod12 nod23 MEP ID : 21 MA Name : 43982 23 43982 _____ Channel (LEVEL, VLAN, RING ID) | _____ (7, 200, 1) _____ DataTraffic vlan: 201-205 Profile : profile1 sBridge3: show g8032 erp-instance erp1 Inst Name : erpl Description : Description State: G8032_ST_IPhy Ring: RING1Ring Type: MAJOR-RING State : G8032 ST IDLE : NEIGHBOR (WEST) Role : 3c:2c:99:1a:da:7d Node ID _____ East Link West Link _____ Interface : xe3 State : Unblocked xe16 Blocked Remote NodeId : 34:17:eb:e4:af:11 34:17:eb:e4:af:11 Remote BPR : 1 1 Endpoint Info _____ nod34 Domain Name : nod23 MEP ID : 22 : 43982 34 43982 ------Channel (LEVEL, VLAN, RING ID) | _____ (7, 200, 1) _____ DataTraffic vlan: 201-205 Profile : profile1 Bridge4: show g8032 erp-instance erp1 Inst Name : erp1 Description :

```
State: G8032_ST_IDLEPhy Ring: RING1Ring Type: MAJOR-RING
Role
          : OWNER (EAST)
     : 34:17:eb:e4:af:11
Node ID
_____
           East Link
                         West Link
_______
Interface : xel6
State : Blocked
                         xe6
                         Unblocked
Remote NodeId : -
Remote BPR : -
                          _
Endpoint Info
_____
Domain Name : nod34
                         nod41
MEP ID : 43
MA Name : 43982
                         41
                         43982
_____
   Channel
                 (LEVEL, VLAN, RING ID)
_____
(7, 200, 1)
_____
DataTraffic vlan: 201-205
Profile : profile1
```

Sub-ring with Virtual Channel

An ethernet ring that is connected to a Major Ring at the Interconnection Nodes. By itself, the Sub-Ring does not constitute a closed ring. A Sub-Ring is connected to the Interconnection nodes on only one port which is configured as east-interface.

Topology

Figure 11-21 displays a sample Ring Protection topology on which protection switching is configured with six bridges. This constitutes of one major ring (Bridge2, Bridge3, Bridge4 and Bridge 5) and one sub-ring (Bridge2, Bridge1, Bridge6 and Bridge5).

Major ring's RPL in enabled between Bridge 3(owner node) and Bridge 4(neighbor node) on xe4 and other devices are non-owner nodes for that ring. Sub-ring's RPL is enabled between bridge 1(owner node) and bridge 2 (neighbor node) on link xe2 and other devices on the non-owner nodes. Bridge 2 and Bridge 5 are called interconnected nodes since they are common node between major ring and subring. Virtual channel is enabled for this Subring on interconnected nodes on vlan 100 and tcn propagation is enabled.



Figure 11-21: Major ring and Sub-ring with Virtual Channel Topology

Configuration

Bridgel#config term	Enter configure mode
Bridgel(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridgel(config)#vlan database	Configure VLAN database
Bridge1(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridgel(config)#interface ce49	Configure interface ce49
Bridgel(config-if)#switchport	Configure ce49 as a layer 2 port
Bridgel(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge1(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridgel(config-if)#switchport mode trunk	Configure port as trunk port
Bridge1(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on ce49 interface
Bridge1(config-if)#interface xe2	Configure interface xe2
Bridgel(config-if)#switchport	Configure xe2 as a layer 2 port
Bridge1(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridgel(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridgel(config-if)#switchport mode trunk	Configure port as trunk port
Bridgel(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on xe2 interface

Bridge1(config-if)#ethernet cfm domain-type character-string domain-name 00061 level 7 mip-creation none	Create cfm domain with type as character string with name 00061 and set mip creation criteria to default with level 7
Bridgel(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982.
Bridge1(config-ether-cfm-ma)# vlan 201 bridge 1	Add VLAN 201
Bridge1(config-ether-cfm-ma)# mip-creation none	Set MIP-creation criteria to none
Bridgel(config-ether-cfm-ma)#ethernet cfm mep down mpid 16 active true ce49	Create down MEP 16 for ce49 interface
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge1(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridgel(config-ether-cfm-ma)#mep crosscheck mpid 61	Configure crosscheck to remote MEP with value 61
Bridge1(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridgel(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet MA mode
Bridgel(config-ether-cfm)#ethernet cfm domain-type character-string domain-name 00012 level 7 mip-creation none	Create CFM domain with type as character string with name 00012 and set mip creation criteria to default with level 7
Bridgel(config-ether-cfm)#service ma-type string ma-name 43982	Create MA type as string with name 43982
Bridge1(config-ether-cfm-ma)# vlan 201 bridge 1	Add VLAN 201
Bridgel(config-ether-cfm-ma)# mip-creation none	Set MIP-creation criteria to none
Bridgel(config-ether-cfm-ma)#ethernet cfm mep down mpid 12 active true xe2	Create down MEP 12 for xe2 interface
Bridgel(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridgel(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridgel(config-ether-cfm-ma)#mep crosscheck mpid 21	Configure crosscheck to remote MEP with value 21
Bridge1(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridgel(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridgel(config-ether-cfm)#g8032 ring subring	Create g8032 ring with name subring
Bridge1(g8032-ring-config)#east-interface ce49	Associate ce49 interface as east-interface
Bridge1(g8032-ring-config)#west-interface xe2	Associate xe2 interface as west-interface
Bridge1(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1

Bridge1(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge1(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge1(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge1(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge1(g8032-profile-config)#g8032 erp- instance erp2	Create g8032 erp instance erp2
Bridge1(g8032-config-switch)#ring-type sub- ring-vc	Configure ring type as subring virtual channel
Bridge1(g8032-config-switch)#ring subring	Associate ring subring to erp2 instance
Bridge1(g8032-config-switch)#rpl role owner west-interface	Configure the node as owner node on west-interface
Bridge1(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp2 instance
Bridge1(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridgel(g8032-config-switch)#aps-channel vlan 201	Configure RAPS channel vlan as 201
Bridge1(g8032-config-switch)#data vlan 202- 205	Configure traffic vlan from 202-205
Bridge1(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge1(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridgel(g8032-config-switch)#end	Exit g8032 erp instance mode

Bridge2#config term	Enter configure mode
Bridge2(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge1(config)#vlan database	Configure VLAN database
Bridge2(config-vlan)#vlan 100 bridge 1 state enable	Create VLAN 100 on bridge 1
Bridge2(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridge2(config)#interface xe2	Configure interface xe2
Bridge2(config-if)#switchport	Configure xe2 as a layer 2 port
Bridge2(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge2(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge2(config-if)#switchport mode trunk	Configure port as trunk port
Bridge2(config-if)#switchport trunk allowed vlan add 100,200-205	Allow vlan 100,200-205 on xe2 interface
Bridge2(config-if)#interface xe6	Configure interface xe6

Bridge2(config-if)#switchport	Configure xe6 as a layer 2 port
Bridge2(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge2(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge2(config-if)#switchport mode trunk	Configure port as trunk port
Bridge2(config-if)#switchport trunk allowed vlan add 100,200-205	Allow vlan 100,200-205 on xe6 interface
Bridge2(config-if)#interface xe8	Configure interface xe8
Bridge2(config-if)#switchport	Configure xe8 as a layer 2 port
Bridge2(config-if)#bridge-group 1	Configure interface in bridge group 1
<pre>Bridge2(config-if)#bridge-group 1 spanning- tree disable</pre>	Disable spanning tree for bridge group 1 on that interface
Bridge2(config-if)#switchport mode trunk	Configure port as trunk port
Bridge2(config-if)#switchport trunk allowed vlan add 100,200-205	Allow vlan 100,200-205 on xe8 interface
Bridge2(config-if)#ethernet cfm domain-type character-string domain-name 00012 level 7 mip-creation none	Create cfm domain with type as character string with name 00012 and set mip creation criteria to default with level 7
Bridge2(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge2(config-ether-cfm-ma)# vlan 201 bridge 1	Add VLAN 201
Bridge2(config-ether-cfm-ma)# mip-creation none	Set mip-creation criteria to none
Bridge2(config-ether-cfm-ma)#ethernet cfm mep down mpid 21 active true xe2	Create down MEP 21 for xe2 interface
Bridge2(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge2(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge2(config-ether-cfm-ma)#mep crosscheck mpid 12	Configure crosscheck to remote MEP with value 12
Bridge2(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge2(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridge2(config-ether-cfm)#ethernet cfm domain-type character-string domain-name 00052 level 7 mip-creation none	Create cfm domain with type as character string with name 00052 and set mip creation criteria to default with level 7
Bridge2(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge2(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
<pre>Bridge2(config-ether-cfm-ma)# mip-creation none</pre>	Set MIP-creation criteria to none
Bridge2(config-ether-cfm-ma)#ethernet cfm mep down mpid 25 active true xe6	Create down MEP 25 for xe6 interface
Bridge2(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast

Bridge2(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge2(config-ether-cfm-ma)#mep crosscheck mpid 52	Configure crosscheck to remote MEP with value 52
Bridge2(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge2(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridge2(config-ether-cfm)#ethernet cfm domain-type character-string domain-name 00023 level 7 mip-creation none	Create CFM domain with type as character string with name 00023 and set mip creation criteria to default with level 7
Bridge2(config-ether-cfm)#service ma-type string ma-name 43982	Create MA type as string with name 43982
Bridge2(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge2(config-ether-cfm-ma)# mip-creation none	Set MIP-creation criteria to none
Bridge2(config-ether-cfm-ma)#ethernet cfm mep down mpid 23 active true xe8	Create down MEP 23 for xe8 interface
Bridge2(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge2(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge2(config-ether-cfm-ma)#mep crosscheck mpid 32	Configure crosscheck to remote MEP with value 32
Bridge2(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge2(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet MA mode
Bridge2(config-ether-cfm)#g8032 ring ring	Create g8032 ring with name ring on bridge 1
Bridge2(g8032-ring-config)#east-interface xe6	Associate xe6 interface as east-interface
Bridge2(g8032-ring-config)#west-interface xe8	Associate xe8 interface as west-interface
Bridge2(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge2(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge2(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge2(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge2(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge2(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge2(g8032-config-switch)#ring ring	Associate ring RING1 to erp1 instance
Bridge2(g8032-config-switch)#ring-type major-ring	Configure ring-type as major ring

Bridge2(g8032-config-switch)#rpl role non- owner	Configure the node as non-owner node
Bridge2(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance
Bridge2(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge2(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200
Bridge2(g8032-config-switch)#data vlan 202- 205, 100	Configure traffic vlan from 202-205, 100
Bridge2(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge2(g8032-config-switch)#g8032 ring subring	Create g8032 ring with name subring
Bridge2(g8032-ring-config)#east-interface xe2	Associate xe2 interface as east-interface
Bridge2(g8032-ring-config)#g8032 erp- instance erp2	Create g8032 erp instance erp2
Bridge2(g8032-config-switch)#ring-type sub- ring-vc	Configure ring-type as sub-ring virtual channel
Bridge2(g8032-config-switch)#ring subring	Associate ring RING1 to erp2 instance
Bridge2(g8032-config-switch)#rpl role neighbor east-interface	Configure the node as neighbor node on east interface
Bridge2(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp2 instance
Bridge2(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge2(g8032-config-switch)#aps-channel vlan 201	Configure RAPS channel vlan as 201
Bridge2(g8032-config-switch)#data vlan 202- 205	Configure traffic vlan from 202-205
Bridge2(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge2(g8032-config-switch)#virtual- channel 100 attached-to-instance erp1	Configure virtual channel with vlan 100 and attach erp2 to erp1
Bridge1(g8032-config-switch)# enable-tcn- propagation	Enable tcn propagation
Bridge2(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge2(g8032-config-switch)#end	Exit g8032 erp instance mode

Bridge3#config term	Enter configure mode
Bridge3(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge3(config)#vlan database	Configure VLAN database
Bridge3(config-vlan)#vlan 100 bridge 1 state enable	Create VLAN 100 on bridge 1

Bridge3(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridge3(config)#interface xe8	Configure interface xe8
Bridge3(config-if)#switchport	Configure xe8 as a layer 2 port
Bridge3(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge3(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge3(config-if)#switchport mode trunk	Configure port as trunk port
Bridge3(config-if)#switchport trunk allowed vlan add 100,200-205	Allow vlan 100,200-205 on xe8 interface
Bridge3(config-if)#interface xe4	Configure interface xe4
Bridge3(config-if)#switchport	Configure xe4 as a layer 2 port
Bridge3(config-if)#bridge-group 1	Configure interface in bridge group 1
<pre>Bridge3(config-if)#bridge-group 1 spanning- tree disable</pre>	Disable spanning tree for bridge group 1 on that interface
Bridge3(config-if)#switchport mode trunk	Configure port as trunk port
Bridge3(config-if)#switchport trunk allowed vlan add 100,200-205	Allow VLAN 100,200-205 on xe4 interface
Bridge3(config-if)#ethernet cfm domain-type character-string domain-name 00023 level 7 mip-creation none	Create CFM domain with type as character string with name 00023 and set mip creation criteria to default with level 7
Bridge3(config-ether-cfm)#service ma-type string ma-name 43982	Create MA type as string with name 43982
Bridge3(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
<pre>Bridge3(config-ether-cfm-ma)# mip-creation none</pre>	Set MIP-creation criteria to none
Bridge3(config-ether-cfm-ma)#ethernet cfm mep down mpid 32 active true xe8	Create down MEP 32 for xe8 interface
Bridge3(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge3(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge3(config-ether-cfm-ma)#mep crosscheck mpid 23	Configure crosscheck to remote MEP with value 23
Bridge3(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge3(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet MA mode
Bridge3(config-ether-cfm)#ethernet cfm domain-type character-string domain-name 00034 level 7 mip-creation none	Create cfm domain with type as character string with name 00034 and set mip creation criteria to default with level 7
Bridge3(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge3(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
<pre>Bridge3(config-ether-cfm-ma) # mip-creation none</pre>	Set MIP-creation criteria to none

Bridge3(config-ether-cfm-ma)#ethernet cfm mep down mpid 34 active true xe4	Create down MEP 34 for xe4 interface
Bridge3(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge3(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge3(config-ether-cfm-ma)#mep crosscheck mpid 43	Configure crosscheck to remote MEP with value 43
Bridge3(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge3(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridge3(config-ether-cfm)#g8032 ring ring	Create g8032 ring with name ring
Bridge3(g8032-ring-config)#east-interface xe8	Associate xe8 interface as east-interface
Bridge3(g8032-ring-config)#west-interface xe4	Associate xe4 interface as west-interface
Bridge3(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge3(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge3(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge3(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge3(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge3(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge3(g8032-config-switch)#ring ring	Associate ring ring to erp1 instance
Bridge3(g8032-config-switch)#ring-type major-ring	Configure ring-type as major ring
Bridge3(g8032-config-switch)#rpl role owner west-interface	Configure the node as owner node on west interface
Bridge3(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance
Bridge3(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge3(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200
Bridge3(g8032-config-switch)#data vlan 202- 205,100	Configure traffic vlan from 202-205, 100
Bridge3(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge3(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge3 (g8032-config-switch) #end	Exit g8032 erp instance mode

Bridge4#config term	Enter configuration mode
Bridge4(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge4(config)#vlan database	Configure VLAN database
Bridge5(config-vlan)#vlan 100 bridge 1 state enable	Create VLAN 100 on bridge 1
Bridge4(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridge4(config)#interface xe4	Configure interface xe4
Bridge4(config-if)#switchport	Configure xe4 as a layer 2 port
Bridge4(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge4(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge4(config-if)#switchport mode trunk	Configure port as trunk port
Bridge4(config-if)#switchport trunk allowed vlan add 100,200-205	Allow vlan 100,200-205 on xe4 interface
Bridge4(config-if)#interface xel6	Configure interface xe16
Bridge4(config-if)#switchport	Configure xe4 as a layer 2 port
Bridge4(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge4(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge4(config-if)#switchport mode trunk	Configure port as trunk port
Bridge4(config-if)#switchport trunk allowed vlan add 100,200-205	Allow vlan 100,200-205 on xe16 interface
Bridge4(config-if)#ethernet cfm domain-type character-string domain-name 00034 level 7 mip-creation none	Create cfm domain with type as character string with name 00023 and set mip creation criteria to default with level 7
Bridge4(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge4(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
<pre>Bridge4(config-ether-cfm-ma)# mip-creation none</pre>	Set mip-creation criteria to none
Bridge4(config-ether-cfm-ma)#ethernet cfm mep down mpid 43 active true xe4	Create down MEP 43 for xe4 interface
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge4(config-ether-cfm-ma)#mep crosscheck mpid 34	Configure crosscheck to remote MEP with value 34
Bridge4(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge4(config-ether-cfm-ma) #exit-ether-ma- mode	Exit Ethernet ma mode

Bridge4(config-ether-cfm)#ethernet cfm domain-type character-string domain-name 00045 level 7 mip-creation none	Create cfm domain with type as character string with name 00045 and set mip creation criteria to default with level 7
Bridge4(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge4(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge4(config-ether-cfm-ma)# mip-creation none	Set mip-creation criteria to none
Bridge4(config-ether-cfm-ma)#ethernet cfm mep down mpid 45 active true xel6	Create down MEP 45 for xe16 interface
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge4(config-ether-cfm-ma)#mep crosscheck mpid 54	Configure crosscheck to remote MEP with value 54
Bridge4(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge4(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet MA mode
Bridge4(config-ether-cfm)#g8032 ring ring	Create g8032 ring with name ring
Bridge4(g8032-ring-config)#east-interface xe4	Associate xe4 interface as east-interface
Bridge4(g8032-ring-config)#west-interface xel6	Associate xe16 interface as west-interface
Bridge4(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge4(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge4(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge4(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge4(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge4(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge4(g8032-config-switch)#ring-type major-ring	Configure ring-type as major ring
Bridge4(g8032-config-switch)#ring ring	Associate ring ring to erp1 instance
Bridge4(g8032-config-switch)#rpl role neighbor east-interface	Configure the node as neighbor node on east interface
Bridge4(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance
Bridge4(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge4(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200

Bridge4(g8032-config-switch)#data vlan 202- 205, 100	Configure traffic vlan from 202-205, 100
Bridge4(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge4(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge4(g8032-config-switch)#end	Exit g8032 erp instance mode

Bridge5#config term	Enter configure mode
Bridge5(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridgel(config)#vlan database	Configure VLAN database
Bridge5(config-vlan)#vlan 100 bridge 1 state enable	Create VLAN 100 on bridge 1
Bridge5(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridge5(config)#interface xel6	Configure interface xe16
Bridge5(config-if)#switchport	Configure xe16 as a layer 2 port
Bridge5(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge5(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge5(config-if)#switchport mode trunk	Configure port as trunk port
Bridge5(config-if)#switchport trunk allowed vlan add 100,200-205	Allow vlan 100,200-205 on xe16 interface
Bridge5(config-if)#interface xe6	Configure interface xe6
Bridge5(config-if)#switchport	Configure xe6 as a layer 2 port
Bridge5(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge5(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge5(config-if)#switchport mode trunk	Configure port as trunk port
Bridge5(config-if)#switchport trunk allowed vlan add 100,200-205	Allow vlan 100,200-205 on xe6 interface
Bridge5(config-if)#interface xe17	Configure interface xe17
Bridge5(config-if)#switchport	Configure xe17 as a layer 2 port
Bridge5(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge5(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge5(config-if)#switchport mode trunk	Configure port as trunk port
Bridge5(config-if)#switchport trunk allowed vlan add 100,200-205	Allow vlan 100,200-205 on xe17 interface
Bridge5(config-if)#ethernet cfm domain- type character-string domain-name 00045 level 7 mip-creation none	Create cfm domain with type as character string with name 00045 and set mip creation criteria to default with level 7
Bridge5(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982

Bridge5(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge5(config-ether-cfm-ma)# mip- creation none	Set mip-creation criteria to none
Bridge5(config-ether-cfm-ma)#ethernet cfm mep down mpid 54 active true xel6	Create down MEP 54 for xe16 interface
Bridge5(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge5(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM ma-mep mode
Bridge5(config-ether-cfm-ma)#mep crosscheck mpid 45	Configure crosscheck to remote MEP with value 45
Bridge5(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge5(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet ma mode
Bridge5(config-ether-cfm)#ethernet cfm domain-type character-string domain-name 00052 level 7 mip-creation none	Create cfm domain with type as character string with name 00052 and set mip creation criteria to default with level 7
Bridge5(config-ether-cfm)#service ma-type string ma-name 43982	Create MA type as string with name 43982
Bridge5(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge5(config-ether-cfm-ma)# mip- creation none	Set mip-creation criteria to none
Bridge5(config-ether-cfm-ma)#ethernet cfm mep down mpid 52 active true xe6	Create down MEP 52 for xe6 interface
Bridge5(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge5(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge5(config-ether-cfm-ma)#mep crosscheck mpid 25	Configure crosscheck to remote MEP with value 25
Bridge5(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge5(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet ma mode
Bridge5(config-ether-cfm)#ethernet cfm domain-type character-string domain-name 00056 level 7 mip-creation none	Create cfm domain with type as character string with name 00056 and set mip creation criteria to default with level 7
Bridge5(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge5(config-ether-cfm-ma)# vlan 201 bridge 1	Add VLAN 201
Bridge5(config-ether-cfm-ma)# mip- creation none	Set mip-creation criteria to none
Bridge5(config-ether-cfm-ma)#ethernet cfm mep down mpid 56 active true xe17	Create down MEP 56 for xe17 interface
Bridge5(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast

Bridge5(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet cfm ma-mep mode
Bridge5(config-ether-cfm-ma)#mep crosscheck mpid 65	Configure crosscheck to remote MEP with value 65
Bridge5(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge5(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet ma mode
Bridge5(config-ether-cfm)#g8032 ring ring	Create g8032 ring with name ring
Bridge5(g8032-ring-config)#east-interface xel6	Associate xe16 interface as east-interface
Bridge5(g8032-ring-config)#west-interface xe6	Associate xe6 interface as west-interface
Bridge5(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge5(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge5(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge5(g8032-profile-config)#timer guard-timer 10	Configure guard-timer value as 10ms
Bridge5(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge5(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge5(g8032-config-switch)#ring ring	Associate ring ring to erp1 instance
Bridge5(g8032-config-switch)#ring-type major-ring	Configure ring-type as major ring
Bridge5(g8032-config-switch)#rpl role non-owner	Configure the node as non-owner node
Bridge5(g8032-config-switch)#g8032- profile profile1	Associate Profile profile1 to erp1 instance
Bridge5(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge5(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200
Bridge5(g8032-config-switch)#data vlan 202-205,100	Configure traffic vlan from 202-205, 100
Bridge5(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge5(g8032-config-switch)#g8032 ring subring	Create g8032 physical ring with name subring
Bridge5(g8032-ring-config)#east-interface xe17	Associate xe17 interface as east-interface
Bridge5(g8032-profile-config)#g8032 erp- instance erp2	Create g8032 erp instance erp2
Bridge5(g8032-config-switch)#ring-type sub-ring-vc	Configure ring-type as sub-ring virtual channel
Bridge5(g8032-config-switch)#ring subring	Associate ring subring to erp2 instance

Configure the node as non-owner node
Associate Profile profile1 to erp2 instance
Configure level as 7
Configure RAPS channel vlan as 201
Configure traffic vlan from 202-205
Configure ring-id as 1
Configure virtual channel with vlan 100 and attach erp2 to erp1
Enable tcn propagation
Commit the candidate configuration to the running configuration
Exit g8032 erp instance mode

Bridge6#config term	Enter configuration mode
Bridge6(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge1(config)#vlan database	Configure VLAN database
Bridge6(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridge6(config-vlan)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string
Bridge6(config)#interface xe0	Configure interface xe0
Bridge6(config-if)#switchport	Configure xe0 as a layer 2 port
Bridge6(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge6(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge6(config-if)#switchport mode trunk	Configure port as trunk port
Bridge6(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on xe0 interface
Bridge6(config-if)#interface ce0	Configure interface ce0
Bridge6(config-if)#switchport	Configure ce0 as a layer 2 port
Bridge6(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge6(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge6(config-if)#switchport mode trunk	Configure port as trunk port
Bridge6(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on ce0 interface

Bridge6(config-if)#ethernet cfm domain-type character-string domain-name 00056 level 7 mip-creation none	Create cfm domain with type as character string with name 00056 and set mip creation criteria to default with level 7
Bridge6(config-ether-cfm)#service ma-type string ma-name 43982	Create MA type as string with name 43982.
Bridge6(config-ether-cfm-ma)# vlan 201 bridge 1	Add VLAN 201
Bridge6(config-ether-cfm-ma)# mip-creation none	Set MIP-creation criteria to none
Bridge6(config-ether-cfm-ma)#ethernet cfm mep down mpid 65 active true xe0	Create down MEP 65 for xe0 interface
Bridge6(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge6(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet cfm ma-mep mode
Bridge6(config-ether-cfm-ma)#mep crosscheck mpid 56	Configure crosscheck to remote MEP with value 56
Bridge6(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge6(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridge6(config-ether-cfm)#ethernet cfm domain-type character-string domain-name 00061 level 7 mip-creation none	Create cfm domain with type as character string with name 00061 and set mip creation criteria to default with level 7
Bridge6(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge6(config-ether-cfm-ma)# vlan 201 bridge 1	Add VLAN 201
Bridge6(config-ether-cfm-ma)# mip-creation none	Set MIP-creation criteria to none
Bridge6(config-ether-cfm-ma)#ethernet cfm mep down mpid 61 active true ce0	Create down MEP 61 for ce0 interface
Bridge6(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge6(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet cfm ma-mep mode
Bridge6(config-ether-cfm-ma)#mep crosscheck mpid 16	Configure crosscheck to remote MEP with value 16
Bridge6(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge6(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridge6(config-ether-cfm)#g8032 ring subring	Create g8032 physical ring with name subring
Bridge6(g8032-ring-config)#east-interface xe0	Associate xe0 interface as east-interface
Bridge6(g8032-ring-config)#west-interface ce0	Associate ce0 interface as west-interface
Bridge6(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1

Bridge6(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge6(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge6(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge6(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge6(g8032-profile-config)#g8032 erp- instance erp2	Create g8032 erp instance erp2
Bridge6(g8032-config-switch)#ring-type sub- ring-vc	Configure ring type as subring virtual channel
Bridge6(g8032-config-switch)#ring subring	Associate ring subring to erp2 instance
Bridge6(g8032-config-switch)#rpl role non- owner	Configure the node as non-owner node
Bridge6(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp2 instance
Bridge6(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge6(g8032-config-switch)#aps-channel vlan 201	Configure RAPS channel vlan as 201
Bridge6(g8032-config-switch)#data-traffic- vlan 202-205	Configure traffic vlan from 202-205
Bridge6(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge6(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge6(g8032-config-switch)#end	Exit g8032 erp instance mode

Validation

Bridgel#show g80	32	erp-instance erp2	
Inst Name Description State Phy Ring Ring Type Role Node ID	: : : : : :	erp2 G8032_ST_IDLE subring SUB-RING (VIRTUAL) OWNER (WEST) 6c:b9:c5:67:72:1d	
		East Link	West Link
Interface State Remote NodeId Remote BPR Endpoint Info	:	ce49 Unblocked - -	xe2 Blocked - -
Domain Name MEP ID MA Name	:	00061 16 43982	00012 12 43982

Channel (LEVEL, VLAN, RING ID) | _____ (7, 201, 1) _____ DataTraffic vlan: 202-205 Profile : profile1 Bridge2#show g8032 erp-instance erp2 Description : erp2 State State : G8032_ST_IDLE Phy Ring : subring Ring Type : SUB-RING (VIRTUAL) Role : NEIGHBOR (EAST) Node ID : 3c:2c:99:26:e6:7c _____ East Link West Link Interface : xe2 State : Blocked Remote NodeId : 6c:b9:c5:67:72:1d -Remote BPR : 0 -Endpoint Info _____ Domain Name : 00012 MEP ID : 21 MA Name : 43982 TCN Propagation : Enabled Attached : -Attached To : erpl, Virtual ID : 100 : 1 _____ Channel (LEVEL, VLAN, RING ID) | _____ (7, 201, 1) _____ DataTraffic vlan: 202-205 Profile : profile1 Bridge2#show g8032 erp-instance erp1 : erpl Inst Name Description : State : G8032 ST IDLE Phy Ring : 1119 Ring Type : MAJOR-RING Pole : NON-OWNER Node ID : 3c:2c:99:26:e6:80 _____

	East Link	West Link
Interface State Remote NodeId Remote BPR Endpoint Info	: xe6 : Unblocked : - : -	xe8 Unblocked d8:9e:f3:5e:f8:29 0
Domain Name MEP ID MA Name	: 00052 : 25 : 43982	00023 23 43982
TCN Propagatic Attached Attached To Virtual ID	<pre>on : Disabled : erp2, : - : -:-</pre>	
Channel (LEVEL, VLAN,	RING ID)	
(7, 200,	1)	
DataTraffic vl	Lan: 202-205,100	
Profile : prof Bridge3#show g	g8032 erp-instance erp1	
Profile : prof Bridge3#show g Inst Name Description State Phy Ring Ring Type Role Node ID	<pre>g8032 erp-instance erp1 erp1 G8032_ST_IDLE ring MAJOR-RING OWNER (WEST) d8:9e:f3:5e:f8:29</pre>	
Profile : prof Bridge3#show g Inst Name Description State Phy Ring Ring Type Role Node ID	<pre>g8032 erp-instance erp1 erp1 G8032_ST_IDLE ring MAJOR-RING OWNER (WEST) d8:9e:f3:5e:f8:29 East Link</pre>	West Link
Profile : prof Bridge3#show c Inst Name Description State Phy Ring Ring Type Role Node ID 	<pre>state of the state of the</pre>	West Link xe4 Blocked - -
Profile : prof Bridge3#show c Inst Name Description State Phy Ring Ring Type Role Node ID 	<pre>state = 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1</pre>	West Link xe4 Blocked - - 00034 34 43982
Profile : prof Bridge3#show c Inst Name Description State Phy Ring Ring Type Role Node ID 	<pre>state of the second secon</pre>	West Link xe4 Blocked - - 00034 34 43982

DataTraffic vlan: 202-205,100

```
Profile : profile1
Bridge4#show g8032 erp-instance erp1
Inst Name : erp1
         :
: G8032_ST_IDLE
Description
State
Phy Ring : ring
Ring Type : MAJOR-RING
Role : NEIGHBOR (EAST)
      : 3c:2c:99:1a:da:7e
Node ID
_____
        East Link
                        West Link
Interface : xe4
                         xe16
         : Blocked
                        Unblocked
State
Remote BPR : 0
                         0
Endpoint Info
_____
Domain Name : 00034
MEP ID : 43
                         00045
                         45
      : 43982
MA Name
                         43982
_____
 _____
   Channel
(LEVEL, VLAN, RING ID) |
_____
(7, 200, 1)
_____
DataTraffic vlan: 202-205,100
Profile : profile1
Bridge5#show g8032 erp-instance erp2
Inst Name : erp2
Description
         :
State
         : G8032 ST IDLE
Phy Ring : subring
Ring Type : SUB-RING (VIRTUAL)
Role
         : NON-OWNER
Role
      : 34:17:eb:e4:af:12
Node ID
_____
          East Link
                        West Link
_____
Interface : xe17
State : Unblo
         : Unblocked
Remote NodeId : 6c:b9:c5:67:72:1d -
Remote BPR : 0
Endpoint Info
_____
Domain Name : 00056
MEPID : 56
MA Name : 43982
                         _
```

_____ TCN Propagation : Enabled Attached : -Attached To : erp1, Virtual ID : 100 : 1 _____ Channel (LEVEL, VLAN, RING ID) | _____ (7, 201, 1) _____ DataTraffic vlan: 202-205 Profile : profile1 Bridge5#show g8032 erp-instance erp1 : erpl Inst Name Inst Name Description : State : G8032_ST_IDLE Ring Type : MA TO Role : MAJOR-RING Role : NON-OWNER Node ID : 34:17:eb:e4:af:11 _____ _____ East Link West Link _____ Interface : xel6 State : Unblocked xe6 Unblocked Remote NodeId : -Remote BPR : d8:9e:f3:5e:f8:29 0 Endpoint Info _____ Domain Name : 00045 00052 MEP ID : 54 52 MA Name : 43982 43982 _____ TCN Propagation : Disabled Attached : erp2, Attached To : -: -:-Virtual ID _____ Channel 1 (LEVEL, VLAN, RING ID) | _____ (7, 200, 1) _____ DataTraffic vlan: 202-205,100 Profile : profile1 Bridge6#show g8032 erp-instance erp2 Inst Name : erp2 Description :

State Phy Ring Ring Type Role Node ID	: G8032_ST_IDLE : subring (VIRTUAL) : SUB-RING : NON-OWNER : b8:6a:97:d2:27:c6	
	East Link	West Link
Interface State Remote NodeId Remote BPR Endpoint Info	: xe0 : Unblocked : - : -	ce0 Unblocked 6c:b9:c5:67:72:1d 0
Domain Name MEP ID MA Name =======	: 00056 : 65 : 43982	00061 61 43982
Channel (LEVEL, VLAN,	RING ID)	
(7, 201,	1)	

DataTraffic vlan: 202-205 Profile : profile1

Sub-ring without Virtual Channel on a LAG interface

Figure 3 displays a sample Ring Protection topology on which protection switching is configured with 5 bridges on lag interfaces. The topology contains one major ring and one subring with non-virtual channel. The Ring Protection Link (RPL) for major ring is the link between Bridge 4 (owner) and Bridge 3 (neighbor) on lag interface po3. The subring is configured with no virtual channel and it's RPL link is configured between bridge 1 (neighbor) and bridge 5 (owner) on lag interface po6. The rest of the bridges are explicitly configured RPL non owner to enable ERPS in the ring in both major and subring.

Topology

Figure 11-22 displays a sample Ethernet Ring Protection Switching topology.



Figure 11-22: Major ring and sub-ring topology using LAG interface without a virtual channel

Configuration

Bridgel#config term	Enter configure mode
Bridge1(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge1(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string
Bridge1(config)#vlan database	Configure VLAN database
Bridge1(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridgel(config-vlan)#interface pol	Configure lag interface po1
Bridgel(config-if)#switchport	Configure po1 as a layer 2 port

Bridgel(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge1(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridgel(config-if)#switchport mode trunk	Configure port as trunk port
Bridgel(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on po1 interface
Bridgel(config-if)#interface po4	Configure lag interface po4
Bridgel(config-if)#switchport	Configure po4 as a layer 2 port
Bridgel(config-if)#bridge-group 1 spanning- tree disable	Configure interface in bridge group 1
Bridgel(config-if)#switchport mode trunk	Disable spanning tree for bridge group 1 on that interface
Bridge1(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on po4 interface
Bridgel(config-if)#interface po6	Configure lag interface po6
Bridgel(config-if)#switchport	Configure po6 as a layer 2 port
Bridgel(config-if)#bridge-group 1	Configure interface in bridge group 1
<pre>Bridge1(config-if)#bridge-group 1 spanning- tree disable</pre>	Disable spanning tree for bridge group 1 on that interface
Bridgel(config-if)#switchport mode trunk	Configure port as trunk port
Bridge1(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on po6 interface
Bridgel(config-if)#interface xel	Configure interface xe1
Bridgel(config-if)#channel-group 6 mode active	Configure xe1 as part of po6
Bridgel(config-if)#interface xe2	Configure interface xe2
Bridgel(config-if)#channel-group 6 mode active	Configure xe2 as part of po6
Bridgel(config-if)#interface xe6	Configure interface xe6
Bridgel(config-if)#channel-group 4 mode active	Configure xe6 as part of po4
Bridgel(config-if)#interface xe7	Configure interface xe7
Bridgel(config-if)#channel-group 4 mode active	Configure xe7 as part of po4
Bridgel(config-if)#interface xe8	Configure interface xe8
Bridgel(config-if)#channel-group 1 mode active	Configure xe8 as part of po1
Bridgel(config-if)#interface xe9	Configure interface xe9
Bridge1(config-if)#channel-group 1 mode active	Configure xe9 as part of po1
Bridgel(config-if)#ethernet cfm domain-type character-string domain-name nod12 level 7 mip-creation none	Create cfm domain with type as character string with name nod12 and set mip creation criteria to default with level 7
Bridgel(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge1(config-ether-cfm-ma)# vlan 200 bridge 1	Add vlan 200

Bridge1(config-ether-cfm-ma)#mip-creation none	Set mip-creation criteria to none
Bridge1(config-ether-cfm-ma)#ethernet cfm mep down mpid 12 active true pol	Create down mep 12 for po1 interface
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast
Bridge1(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet cfm ma-mep mode
Bridgel(config-ether-cfm-ma)#mep crosscheck mpid 21	Configure crosscheck to remote MEP with value 21
Bridge1(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge1(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridgel(config-ether-cfm)#ethernet cfm domain-type character-string domain-name nod41 level 7 mip-creation none	Create cfm domain with type as character string with name nod41 and set mip creation criteria to default with level 7
Bridgel(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge1(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge1(config-ether-cfm-ma)#mip-creation none	Set mip-creation criteria to none
Bridgel(config-ether-cfm-ma)#ethernet cfm mep down mpid 14 active true po4	Create down MEP 14 for po4 interface
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge1(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM ma-mep mode
Bridgel(config-ether-cfm-ma)#mep crosscheck mpid 41	Configure crosscheck to remote MEP with value 41
Bridge1(config-ether-cfm-ma)#cc interval 23ms	Enable CC interval with 100ms
Bridge1(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridgel(config-ether-cfm)#ethernet cfm domain-type character-string domain-name nod15 level 7 mip-creation none	Create cfm domain with type as character string with name nod15 and set mip creation criteria to default with level 7
Bridge1(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge1(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge1(config-ether-cfm-ma)#mip-creation none	Set mip-creation creation criteria to none
Bridgel(config-ether-cfm-ma)#ethernet cfm mep down mpid 51 active true po6	Create down mep 51 for po6 interface
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast
Bridgel(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet cfm ma-mep mode

Bridgel(config-ether-cfm-ma)#mepcrosscheck mpid 15	Configure crosscheck to remote MEP with value 15
Bridge1(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridgel(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridge1(config-ether-cfm)#g8032 ring lagring	Create g8032 ring with name lagring
Bridge1(g8032-ring-config)#east-interface po4	Associate po4 interface as east-interface
Bridge1(g8032-ring-config)#west-interface po1	Associate po1 interface as west-interface
Bridge1(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge1(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge1(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge1(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge1(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge1(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge1(g8032-config-switch)#ring lagring	Associate ring lagring to erp1 instance
Bridge1(g8032-config-switch)#rpl role non- owner	Configure the node as non-owner node
Bridge1(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance
Bridge1(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge1(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200
Bridge1(g8032-config-switch)#data vlan 201- 205	Configure traffic vlan from 201-205
Bridge1(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge1(g8032-config-switch)#g8032 ring lagsubring	Create g8032 ring with name lagsubring
Bridge1(g8032-ring-config)#east-interface po6	Associate po6 interface as east-interface
Bridge1(g8032-ring-config)#g8032 erp- instance erp2	Create g8032 erp instance erp2
Bridge1(g8032-config-switch)#ring-type sub- ring	Configure ring-type as sub-ring
Bridgel(g8032-config-switch)#ring lagsubring	Associate ring lagsubring to erp2 instance
Bridge1(g8032-config-switch)#rpl role neighbor east-interface	Configure the node as neighbor node on east interface
Bridge1(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp2 instance

Bridge1(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge1(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200
Bridge1(g8032-config-switch)#data vlan 201- 205	Configure traffic vlan from 201-205
Bridge1(g8032-config-switch)#ring-id 2	Configure ring-id as 2
Bridge1(g8032-config-switch)#non-virtual- channel	Enable Non Virtual Channel
Bridge1(g8032-config-switch)# enable-tcn- propagation	Enable tcn propagation
Bridge1(g8032-config-switch)# tcn-to- instance erp1	Attach erp1 instance to erp2 instance to notify any changes in subring to major ring
Bridge1(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge1(g8032-config-switch)#end	Exit g8032 erp instance mode

Bridge2#config term	Enter configure mode
Bridge2(config)#hardware-profile filter cfm-domain-name-str enable	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge2(config)#bridge 1 protocol rstp vlan-bridge	Enable CFM domain name as string
Bridgel(config)#vlan database	Configure VLAN database
Bridge2(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridge2(config-vlan)#interface pol	Configure lag interface po1
Bridge2(config-if)#switchport	Configure po1 as a layer 2 port
Bridge2(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge2(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge2(config-if)#switchport mode trunk	Configure port as trunk port
Bridge2(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on po1 interface
Bridge2(config-if)#interface po2	Configure lag interface po2
Bridge2(config-if)#switchport	Configure po2 as a layer 2 port
Bridge2(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge2(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge2(config-if)#switchport mode trunk	Configure port as trunk port
Bridge2(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on po2 interface
Bridge2(config-if)#interface xe8	Configure interface xe8
Bridge2(config-if)#channel-group 1 mode active	Configure xe8 as part of po1
Bridge2(config-if)#interface xe9	Configure interface xe9

Bridge2(config-if)#channel-group 1 mode active	Configure xe9 as part of po1
Bridge2(config-if)#interface xe3	Configure interface xe3
Bridge2(config-if)#channel-group 2 mode active	Configure xe3 as part of po2
Bridge2(config-if)#interface xe4	Configure interface xe4
Bridge2(config-if)#channel-group 2 mode active	Configure xe4 as part of po2
Bridge2(config-if)#ethernet cfm domain-type character-string domain-name nod12 level 7 mip-creation none	Create cfm domain with type as character string with name nod12 and set mip creation criteria to default with level 7
Bridge2(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge2(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge2(config-ether-cfm-ma)#mip-creation none	Set mip-creation creation criteria to none
Bridge2(config-ether-cfm-ma)#ethernet cfm mep down mpid 21 active true po1	Create down mep 21 for po1 interface
Bridge2(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast
Bridge2(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet cfm ma-mep mode
Bridge2(config-ether-cfm-ma)#mep crosscheck mpid 12	Configure crosscheck to remote MEP with value 12
Bridge2(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge2(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridge2(config-ether-cfm)#ethernet cfm domain-type character-string domain-name nod23 level 7 mip-creation none	Create cfm domain with type as character string with name nod23 and set mip creation criteria to default with level 7
Bridge2(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge2(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge2(config-ether-cfm-ma)#mip-creation none	Set mip-creation creation criteria to none
Bridge2(config-ether-cfm-ma)#ethernet cfm mep down mpid 23 active true po2	Create down mep 23 for po2 interface
Bridge2(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast
Bridge2(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet cfm ma-mep mode
Bridge2(config-ether-cfm-ma)#mep crosscheck mpid 32	Configure crosscheck to remote MEP with value 32
Bridge2(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge2(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode

Bridge2(config-ether-cfm)#g8032 ring lagring	Create g8032 ring with name lagring
Bridge2(g8032-ring-config)#east-interface pol	Associate po1 interface as east-interface
Bridge2(g8032-ring-config)#west-interface po2	Associate po2 interface as west-interface
Bridge2(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge2(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge2(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge2(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge2(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge2(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge2(g8032-config-switch)#ring lagring	Associate ring lagring to erp1 instance
Bridge2(g8032-config-switch) #rpl role non- owner	Configure the node as non-owner node
Bridge2(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance
Bridge2(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge2(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200
Bridge2(g8032-config-switch)#data van 201- 205	Configure traffic vlan from 201-205
Bridge2(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge2(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge2(g8032-config-switch)#end	Exit g8032 erp instance mode

	Enter configuration mode
Bridges#coniig term	
Bridge3(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge3(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string
Bridge1(config)#vlan database	Configure VLAN database
Bridge3(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridge3(config-vlan)#interface po2	Configure lag interface po2
Bridge3(config-if)#switchport	Configure po2 as a layer 2 port
Bridge3(config-if)#bridge-group 1	Configure interface in bridge group 1

Bridge3(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge3(config-if)#switchport mode trunk	Configure port as trunk port
Bridge3(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on po2 interface
Bridge3(config-if)#interface po3	Configure lag interface po3
Bridge3(config-if)#switchport	Configure po3 as a layer 2 port
Bridge3(config-if)#bridge-group 1	Configure interface in bridge group 1
<pre>Bridge3(config-if)#bridge-group 1 spanning- tree disable</pre>	Disable spanning tree for bridge group 1 on that interface
Bridge3(config-if)#switchport mode trunk	Configure port as trunk port
Bridge3(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on po3 interface
Bridge3(config-if)#interface xe3	Configure interface xe3
Bridge3(config-if)#channel-group 2 mode active	Configure xe3 as part of po2
Bridge3(config-if)#interface xe4	Configure interface xe4
Bridge3(config-if)#channel-group 2 mode active	Configure xe4 as part of po2
Bridge3(config-if)#interface xe15	Configure interface xe3
Bridge3(config-if)#channel-group 3 mode active	Configure xe3 as part of po3
Bridge3(config-if)#interface xel6	Configure interface xe16
Bridge3(config-if)#channel-group 3 mode active	Configure xe16 as part of po3
Bridge3(config-if)#ethernet cfm domain-type character-string domain-name nod23 level 7 mip-creation none	Create cfm domain with type as character string with name nod23 and set mip creation criteria to default with level 7
Bridge3(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge3(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge3(config-ether-cfm-ma)#mip-creation none	Set mip-creation creation criteria to none
Bridge3(config-ether-cfm-ma)#ethernet cfm mep down mpid 32 active true po2	Create down mep 32 for po2 interface
Bridge3(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast
Bridge3(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet cfm ma-mep mode
Bridge3(config-ether-cfm-ma)#mep crosscheck mpid 23	Configure crosscheck to remote MEP with value 23
Bridge3(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge3(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Create cfm domain with type as character string with name nod34 and set mip creation criteria to default with level 7	

Create ma type as string with name 43982	
Add VLAN 200	
Set mip-creation creation criteria to none	
Create down mep 34 for po3 interface	
Enable cc multicast	
Exit ethernet cfm ma-mep mode	
Configure crosscheck to remote MEP with value 43	
Enable CC interval with 100ms	
Exit Ethernet ma mode	
Create g8032 physical ring with name lagring	
Associate po2 interface as east-interface	
Associate po3 interface as west-interface	
Create g8032 profile with profile name profile1	
Configure wait to restore time as 1 min	
Configure hold-off timer value as 0	
Configure guard-timer value as 10ms	
Configure Switching mode as revertive Switching mode	
Create g8032 erp instance erp1	
Associate ring lagring to erp1 instance	
Configure the node as neighbor node on west interface	
Associate Profile profile1 to erp1 instance	
Configure level as 7	
Configure RAPS channel vlan as 200	
Configure traffic vlan from 201-205	

Bridge3(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge3(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge3(g8032-config-switch)#end	Exit g8032 erp instance mode

Bridge4#config term	Enter configure mode
Bridge4(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge4(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string
Bridgel(config)#vlan database	Configure VLAN database
Bridge4(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridge4(config-vlan)#interface po3	Configure lag interface po3
Bridge4(config-if)#switchport	Configure po3 as a layer 2 port
Bridge4(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge4(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge4(config-if)#switchport mode trunk	Configure port as trunk port
Bridge4(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on po3 interface
Bridge4(config-if)#interface po4	Configure lag interface po4
Bridge4(config-if)#switchport	Configure po4 as a layer 2 port
Bridge4(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge4(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge4(config-if)#switchport mode trunk	Configure port as trunk port
Bridge4(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on po4 interface
Bridge4(config-if)#interface po5	Configure lag interface po5
Bridge4(config-if)#switchport	Configure po5 as a layer 2 port
Bridge4(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge4(config-if)#bridge-group 1 spanning- tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge4(config-if)#switchport mode trunk	Configure port as trunk port
Bridge4(config-if)#switchport trunk allowed vlan add 200-205	Allow vlan 200-205 on po5 interface
Bridge4(config-if)#interface xe6	Configure interface xe6
Bridge4(config-if)#channel-group 4 mode active	Configure xe6 as part of po4
Bridge4(config-if)#interface xe7	Configure interface xe7
Bridge4(config-if)#channel-group 4 mode active	Configure xe7 as part of po4
Bridge4(config-if)#interface xel0	Configure interface xe10

Bridge4(config-if)#channel-group 5 mode active	Configure xe10 as part of po5
Bridge4(config-if)#interface xell	Configure interface xe11
Bridge4(config-if)#channel-group 5 mode active	Configure xe11 as part of po5
Bridge4(config-if)#interface xel5	Configure interface xe15
Bridge4(config-if)#channel-group 3 mode active	Configure xe15 as part of po3
Bridge4(config-if)#interface xel6	Configure interface xe16
Bridge4(config-if)#channel-group 3 mode active	Configure xe16 as part of po3
Bridge4(config-if)#ethernet cfm domain-type character-string domain-name nod34 level 7 mip-creation none	Create cfm domain with type as character string with name nod34 and set mip creation criteria to default with level 7
Bridge4(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge4(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge4(config-ether-cfm-ma)#mip-creation none	Set mip-creation creation criteria to none
Bridge4(config-ether-cfm-ma)#ethernet cfm mep down mpid 43 active true po3	Create down mep 43 for po3 interface
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet cfm ma-mep mode
Bridge4(config-ether-cfm-ma)#mepcrosscheck mpid 34	Configure crosscheck to remote MEP with value 34
Bridge4(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge4(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridge4(config-ether-cfm)#ethernet cfm domain-type character-string domain-name nod41 level 7 mip-creation none	Create cfm domain with type as character string with name nod41 and set mip creation criteria to default with level 7
Bridge4(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge4(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge4(config-ether-cfm-ma)#mip-creation none	Set mip-creation creation criteria to none
Bridge4(config-ether-cfm-ma)#ethernet cfm mep down mpid 41 active true po4	Create down mep 41 for po4 interface
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet cfm ma-mep mode
Bridge4(config-ether-cfm-ma)#mep crosscheck mpid 14	Configure crosscheck to remote MEP with value 14

Bridge4(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge4(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridge4(config-ether-cfm)#ethernet cfm domain-type character-string domain-name nod45 level 7 mip-creation none	Create cfm domain with type as character string with name nod45 and set mip creation criteria to default with level 7
Bridge4(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge4(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge4(config-ether-cfm-ma)#mip-creation none	Set mip-creation creation criteria to none
Bridge4(config-ether-cfm-ma)#ethernet cfm mep down mpid 54 active true po5	Create down mep 54 for po5 interface
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet cfm ma-mep mode
Bridge4(config-ether-cfm-ma)#mep crosscheck mpid 45	Configure crosscheck to remote MEP with value 45
Bridge4(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge4(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridge4(config-ether-cfm)#g8032 ring lagring	Create g8032 ring with name lagring
Bridge4(g8032-ring-config)#east-interface po3	Associate po3 interface as east-interface
Bridge4(g8032-ring-config)#west-interface po4	Associate po4 interface as west-interface
Bridge4(g8032-ring-config)#g8032 ring lagsubring	Create g8032 ring with name lagsubring
Bridge4(g8032-ring-config)#east-interface po5	Associate po5 interface as east-interface
Bridge4(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge4(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge4(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge4(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge4(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge4(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge4(g8032-config-switch)#ring lagring	Associate ring lagring to erp1 instance
Bridge4(g8032-config-switch)#rpl role owner east-interface	Configure the node as owner node on east interface

Bridge4(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance
Bridge4(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge4(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200
Bridge4(g8032-config-switch)#data vlan 201- 205	Configure traffic vlan from 201-205
Bridge4(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge4(g8032-config-switch)#g8032 erp- instance erp2	Create g8032 erp instance erp2
Bridge4(g8032-config-switch)#ring-type sub- ring	Configure ring-type as sub-ring
Bridge4(g8032-config-switch)#ring lagsubring	Associate ring lagsubring to erp2 instance
Bridge4(g8032-config-switch)#rpl role non- owner	Configure the node as neighbor node on east interface
Bridge4(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp2 instance
Bridge4(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge4(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200
Bridge4(g8032-config-switch)#data vlan 201- 205	Configure traffic vlan from 201-205
Bridge4(g8032-config-switch)#ring-id 2	Configure ring-id as 2
Bridge4(g8032-config-switch)#non-virtual- channel	Enable Non Virtual Channel
Bridge4(g8032-config-switch)# enable-tcn- propagation	Enable tcn propagation
Bridge4(g8032-config-switch)# tcn-to- instance erp1	Attach erp1 instance to erp2 instance to notify any changes in subring to major ring
Bridge4(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge4(g8032-config-switch)#end	Exit g8032 erp instance mode

Bridge5#config term	Enter config mode
Bridge5(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge5(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string
Bridge1(config)#vlan database	Configure VLAN database
Bridge5(config-vlan)#vlan 200-205 bridge 1 state enable	Create VLAN 200-205 on bridge 1
Bridge5(config-vlan)#interface po5	Configure lag interface po5
Bridge5(config-if)#switchport	Configure po5 as a layer 2 port

Disable spanning tree for bridge group 1 on that interface
Configure port as trunk port
Allow vlan 200-205 on po3 interface
Configure lag interface po3
Configure po3 as a layer 2 port
Configure interface in bridge group 1
Disable spanning tree for bridge group 1 on that interface
Configure port as trunk port
Allow vlan 200-205 on po3 interface
Configure interface xe1
Configure xe1 as part of po6
Configure interface xe2
Configure xe2 as part of po6
Configure interface xe10
Configure xe10 as part of po5
Configure interface xe11
Configure xe11 as part of po5
Create cfm domain with type as character string with name nod15 and set mip creation criteria to default with level 7
Create ma type as string with name 43982
Add VLAN 200
Set mip-creation creation criteria to none
Create down mep 15 for po6 interface
Enable cc multicast
Exit ethernet cfm ma-mep mode
Configure crosscheck to remote MEP with value 51
Enable CC interval with 100ms
Exit Ethernet ma mode

Bridge5(config-ether-cfm)#ethernet cfm domain-type character-string domain-name nod45 level 7 mip-creation none	Create cfm domain with type as character string with name nod45 and set mip creation criteria to default with level 7
Bridge5(config-ether-cfm)#service ma-type string ma-name 43982	Create ma type as string with name 43982
Bridge5(config-ether-cfm-ma)# vlan 200 bridge 1	Add VLAN 200
Bridge5(config-ether-cfm-ma)#mip-creation none	Set mip-creation criteria to none
Bridge5(config-ether-cfm-ma)#ethernet cfm mep down mpid 45 active true po5	Create down mep 45 for po5 interface
Bridge5(config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast
Bridge5(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet cfm ma-mep mode
Bridge5(config-ether-cfm-ma)#mep crosscheck mpid 54	Configure crosscheck to remote MEP with value 54
Bridge5(config-ether-cfm-ma)#cc interval 100ms	Enable CC interval with 100ms
Bridge5(config-ether-cfm-ma)#exit-ether-ma- mode	Exit Ethernet ma mode
Bridge5(config-ether-cfm)#g8032 ring lagsubring	Create g8032 ring with name lagsubring
Bridge5(g8032-ring-config)#east-interface po5	Associate po5 interface as east-interface
Bridge5(g8032-ring-config)#west-interface po6	Associate po6 interface as west-interface
Bridge5(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge5(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge5(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge5(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge5(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge5(g8032-profile-config)#g8032 erp- instance erp2	Create g8032 erp instance erp2
Bridge5(g8032-config-switch)#ring lagsubring	Associate Physical ring lagsubring to erp2 instance
Bridge5(g8032-config-switch)#ring-type sub- ring	Configure ring-type as subring
Bridge5(g8032-config-switch)#rpl role owner west-interface	Configure the node as owner node on west interface
Bridge5(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp2 instance
Bridge5(g8032-config-switch)#aps-channel level 7	Configure level as 7

Bridge5(g8032-config-switch)#aps-channel vlan 200	Configure RAPS channel vlan as 200
Bridge5(g8032-config-switch)#data vlan 201- 205	Configure traffic vlan from 201-205
Bridge5(g8032-config-switch)#ring-id 2	Configure ring-id as 2
Bridge5(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge5(g8032-config-switch)#end	Exit g8032 erp instance mode

Validation

Bridgel#show g80 Inst Name Description State Phy Ring Ring Type Role Node ID	032 erp-instance erp2 : erp2 : : G8032_ST_IDLE : lagsubring : SUB-RING (NON VIRTUA) : NEIGHBOR (EAST) : 3c:2c:99:26:e6:7b	L)
	East Link	West Link
Interface State Remote NodeId Remote BPR Endpoint Info	: po6 : Blocked : 6c:b9:c5:67:72:f6 : 0	
Domain Name MEP ID MA Name	: nod15 : 51 : 43982	- - -
TCN Propagation TCN Propagation Channel (LEVEL, VLAN, F	: Enabled List: erp1, RING ID)	
(7, 200, 2	2)	
Bridgel#show g80 Inst Name Description State Phy Ring Ring Type Role	<pre>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>></pre>	
Node ID	: 3c:2c:99:26:e6:80	
	East Link	West Link ====================================
Interface	: po4	pol

State : Unblocked Un Remote NodeId : 34:17:eb:e4:af:10 -Unblocked Remote BPR : 1 Endpoint Info _____ Domain Name : nod41 nod12 MEP ID : 14 Mame : 43982 12 43982 _____ _____ Channel (LEVEL, VLAN, RING ID) | _____ (7, 200, 1) | _____ DataTraffic vlan: 201-205 Profile : profile1 Bridge2#show g8032 erp-instance erp1 Description : State : G8032_ST_IDLE Phy Ring : lagring Ring Type : MAJOR-RING : NON-OWNER Role : d8:9e:f3:5e:f8:29 Node ID _____ East Link West Link ______ Interface : pol po State : Unblocked Ur Remote NodeId : 34:17:eb:e4:af:10 po2 Unblocked Remote BPR : 1 Endpoint Info _____ Domain Name : nod12 nod23 MEP ID : 21 23 · 43982 MA Name 43982 _____ Channel (LEVEL, VLAN, RING ID) _____ (7, 200, 1) _____ DataTraffic vlan: 201-205 Profile : profile1 Bridge3#show g8032 erp-instance erp1 : erpl Inst Name Inst Name Description : State : G8032_ST_IDLE Phy Ring : lagring Ring Type : MAJOR-RING

Role: NEIGHBOR (WEST)Node ID: 3c:2c:99:1a:da:7d _____ East Link West Link _____ Interface : po2 State : Unblocked po3 Blocked Remote NodeId : 34:17:eb:e4:af:10 34:17:eb:e4:af:10 : 1 1 Remote BPR Endpoint Info -----Domain Name : nod23 nod34 : 32 MEP ID 34 MEP ID : 32 MA Name : 43982 43982 Channel (LEVEL, VLAN, RING ID) _____ 200, 1) (7, _____ DataTraffic vlan: 201-205 Profile : profile1 Bridge4#show g8032 erp-instance erp2 : erp2 Inst Name Description : : G8032 ST IDLE State Phy Ring : lagsubring Ring Type : SUB-RING (NON VIRTUAL) Role : NON-OWNER : 34:17:eb:e4:af:0b Node ID _____ East Link West Link _____ Interface : po5 State : Unb : Unblocked Remote NodeId : 6c:b9:c5:67:72:f6 -Remote BPR : 0 Endpoint Info _____ Domain Name : nod45 MEP ID : 54 MA Name : 43982 _____ TCN Propagation : Enabled TCN Propagation List: erpl, Channel (LEVEL, VLAN, RING ID) _____ 200, 2) (7, _____ DataTraffic vlan: 201-205

Profile : profile1 Bridge4#show g8032 erp-instance erp1 : erpl Inst Name Description : State : G8032 ST IDLE Phy Ring: lagringRing Type: MAJOR-RINGRole: OWNER (EAST)Node ID: 34:17:eb:e4:af:10 _____ East Link West Link _____ Interface : po3 State : Blocked po4 : Blocked Unblocked Remote Nodeld : -_ Remote BPR : -Endpoint Info _____ Domain Name : nod34 MEP ID : 43 MA Name : 43982 nod41 41 43982 Channel (LEVEL, VLAN, RING ID) | _____ (7, 200, 1) _____ DataTraffic vlan: 201-205 Profile : profile1 Bridge5#show g8032 erp-instance erp2 Inst Name : erp2 Description : State : G8032 ST IDLE rny Ring Ring Type : lagsubring : SUB-RING : OWNER (WEST) Role Node ID : 6c:b9:c5:67:72:f6 _____ East Link West Link _____ Interface: po5po6State: UnblockedBlocked Remote Nodeld : -Remote BPR : -Endpoint Info _____ Domain Name : nod45 MEPID : 45 nod15 15 MA Name : 43982 43982 _____

```
Channel
 (LEVEL, VLAN, RING ID)
_____
 (7, 200, 2)
_____
DataTraffic vlan: 201-205
Profile : profile1
Bridge3#show g8032 erp-instance erp1
Inst Name : erpl
Description :
State: G8032_ST_IIPhy Ring: lagringRing Type: MAJOR-RING(1)(1)
          : G8032 ST IDLE
Role: NEIGHBOR (WEST)Node ID: 3c:2c:99:1a:da:7d
  _____
            East Link
                          West Link
______
Interface : po2
State : Unblocked
                          po3
                          Blocked
Remote NodeId : 34:17:eb:e4:af:10 34:17:eb:e4:af:10
Remote BPR : 1
                           1
Endpoint Info
_____
Domain Name : nod23
                           nod34
MEP ID : 32
MA Name : 43982
                           34
                           43982
_____
  ------
   Channel
 (LEVEL, VLAN, RING ID) |
_____
 (7, 200, 1) |
_____
DataTraffic vlan: 201-205
Profile : profile1
```

ERPS Managing Non-Data VLAN's

An Ethernet ring that is connected to a Major Ring at the Interconnection Nodes. Non-Bridged AC-VLAN's should follow the port state (block/forward) as ERPS data VLAN's.

User can give control for non-bridged AC_Vlans by configuring "erps-instance <id|none>". In sub-interface, user can add "erps-instance (NAME | none)" CLI. This will exclude the sub-intf/lif's to be processed by ERPS.

Erps-instance <name>, this sub-interface will follow specified erps-instance state for non-data vlan's.

This is useful in case of multiple instances, where one instance is in forward and another is block. So non-data vlan's has to follow specific instance configured by user. Default is lower instance id, if not configured.

Erps-instance none, this sub-interface will not managed by ERPS. (It will be always in forward state with ERPS not controlling it).

No command specified in sub-intf mode, this sub-intf/lif will be managed by ERPS and default erps-instance id will be used for LIF/sub-intf to follow the ERPS block/forward state. Default value is lower configured instance-id

Topology

displays a sample Ring Protection topology on which protection switching is configured with five bridges. This constitutes of one major ring (Bridge1, Bridge2, Bridge3, Bridge4 and Bridge 5) and MPLS/VPLS is running between Bridge4, Bridge5 and Bridge6)



Figure 11-23: Major ring running both ERPS and MPLS/VPLS between Bridge-4 and Bridge-5.

Bridge1#configure terminal	Enter configure mode
Bridge1(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridgel(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string
Bridgel(config)#vlan database	Configure VLAN database
Bridge1(config-vlan)# vlan 450 bridge 1 state enable	Create VLAN 450 on bridge 1
Bridge1(config-vlan)# vlan 900-1010 bridge 1 state enable	Create VLAN 900-1010 on bridge 1
Bridge1(config-vlan)#interface xe12	Configure interface xe12
Bridgel(config-if)#switchport	Configure xe12 as a layer 2 port
Bridge1(config-if)#bridge-group 1	Configure interface in bridge group 1

Bridge1(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridgel(config-if)#switchport mode trunk	Configure port as trunk port
Bridge1(config-if)#switchport trunk allowed vlan add 450,900-1010	Allow vlan 450,900-1010 on xe12 interface
Bridgel(config-if)#interface xe20	Configure interface xe20
Bridgel(config-if)#switchport	Configure xe20 as a layer 2 port
Bridge1(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridgel(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridgel(config-if)#switchport mode trunk	Configure port as trunk port
Bridge1(config-if)#switchport trunk allowed vlan add 450,900-1010	Allow vlan 450,900-1010 on xe20 interface
Bridgel(config-if)#interface xe24	Configure interface xe24
Bridgel(config-if)#switchport	Configure xe24 as a layer 2 port
Bridge1(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridgel(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridgel(config-if)#switchport mode trunk	Configure port as trunk port
Bridgel(config-if)#switchport trunk allowed vlan add 450,900-1010	Allow vlan 450,900-1010 on xe24 interface
Bridgel(config-if)# ethernet cfm domain- type character-string domain-name mdnal level 7 mip-creation default	Create cfm domain with type as character string with name mdna1 and set MIP creation criteria to default with level 7
Bridgel(config-ether-cfm)#service ma-type string ma-name n27	Create MA type as string with name n27
Bridge1(config-ether-cfm-ma)# vlan 900 bridge 1	Add VLAN 900
<pre>Bridge1(config-ether-cfm-ma)# mip-creation default</pre>	Set MIP-creation criteria to default
Bridge1(config-ether-cfm-ma)# ethernet cfm mep down mpid 2027 active true xel2	Create down MEP 2027 for xe12 interface
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridgel(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridgel(config-ether-cfm-ma)#mep crosscheck mpid 27	Configure crosscheck to remote MEP with value 27
Bridge1(config-ether-cfm-ma)#cc interval 10s	Enable cc interval with 10s

Bridge1(config-ether-cfm-ma)# exit-ether- ma-mode	Exit Ethernet ma mode
Bridgel(config-if)# ethernet cfm domain- type character-string domain-name mdna2 level 7 mip-creation default	Create cfm domain with type as character string with name mdna2 and set MIP creation criteria to default with level 7
Bridgel(config-ether-cfm)#service ma-type string ma-name n27	Create MA type as string with name n27
Bridge1(config-ether-cfm-ma)# vlan 900 bridge 1	Add VLAN 900
Bridge1(config-ether-cfm-ma)# mip-creation default	Set MIP-creation criteria to default
Bridgel(config-ether-cfm-ma)# ethernet cfm mep down mpid 3037 active true xe20	Create down MEP 3037 for xe20 interface
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge1(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge1(config-ether-cfm-ma)#mep crosscheck mpid 37	Configure crosscheck to remote MEP with value 37
Bridge1(config-ether-cfm-ma)#cc interval 10s	Enable cc interval with 10s
Bridge1(config-ether-cfm-ma)# exit-ether- ma-mode	Exit Ethernet ma mode
Bridge1(config-ether-cfm)#g8032 ring RING1	Create g8032 ring with name RING1
Bridge1(g8032-ring-config)#east-interface xe20	Associate xe20 interface as east-interface
Bridge1(g8032-ring-config)#west-interface xe12	Associate xe12 interface as west-interface
Bridge1(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge1(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge1(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge1(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge1(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge1(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge1(g8032-config-switch)#ring RING1	Associate ring RING1 to erp1 instance

Bridge1(g8032-config-switch)#rpl role non- owner	Configure the node as non-owner node
Bridge1(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance
Bridge1(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge1(g8032-config-switch)#aps-channel vlan 900	Configure RAPS channel vlan as 900
Bridge1(g8032-config-switch)#data vlan 950	Configure traffic vlan 950
Bridge1(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge1(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge1(g8032-config-switch)#end	Exit g8032 erp instance mode

Bridge2#configure terminal	Enter configure mode
Bridge2(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge2(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string
Bridge2(config)#vlan database	Configure VLAN database
Bridge2(config-vlan)# vlan 450 bridge 1 state enable	Create VLAN 450 on bridge 1
Bridge2(config-vlan)# vlan 900-1010 bridge 1 state enable	Create VLAN 900-1010 on bridge 1
Bridge2(config-vlan)#interface ce9/1	Configure interface ce9/1
Bridge2(config-if)#switchport	Configure ce9/1 as a layer 2 port
Bridge2(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge2(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge2(config-if)#switchport mode trunk	Configure port as trunk port
Bridge2(config-if)#switchport trunk allowed vlan add 450,900-1010	Allow vlan 450,900-1010 on ce9/1 interface
Bridge2(config-if)#interface ce6/1	Configure interface ce6/1
Bridge2(config-if)#switchport	Configure ce6/1 as a layer 2 port
Bridge2(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge2(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge2(config-if)#switchport mode trunk	Configure port as trunk port
Bridge2(config-if)#switchport trunk allowed vlan add 450,900-1010	Allow vlan 450,900-1010 on ce6/1 interface

Create cfm domain with type as character string with name mdna1 and set MIP creation criteria to default with level 7
Create MA type as string with name n27
Add VLAN 900
Set MIP-creation criteria to default
Create down MEP 27 for ce9/1 interface
Enable CC multicast
Exit ethernet CFM MA-MEP mode
Configure crosscheck to remote MEP with value 2027
Enable cc interval with 10s
Exit Ethernet ma mode
Create cfm domain with type as character string with name mdna5 and set MIP creation criteria to default with level 7
Create MA type as string with name n27
Add VLAN 900
Set MIP-creation criteria to default
Create down MEP 3037 for xe20 interface
Enable CC multicast
Exit ethernet CFM MA-MEP mode
Configure crosscheck to remote MEP with value 67
Enable cc interval with 10s

Bridge2(config-ether-cfm-ma)# exit-ether- ma-mode	Exit Ethernet ma mode
Bridge2(config-ether-cfm)#g8032 ring RING1	Create g8032 ring with name RING1 on bridge 1
Bridge2(g8032-ring-config)#east-interface ce9/1	Associate ce9/1 interface as east-interface
Bridge2(g8032-ring-config)#west-interface ce6/1	Associate ce6/1 interface as west-interface
Bridge2(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge2(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge2(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge2(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge2(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge2(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge2(g8032-config-switch)#ring RING1	Associate ring RING1 to erp1 instance
Bridge2(g8032-config-switch)#rpl role non- owner	Configure the node as non-owner node
Bridge2(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance
Bridge2(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge2(g8032-config-switch)#aps-channel vlan 900	Configure RAPS channel vlan as 900
Bridge2(g8032-config-switch)#data vlan 950	Configure traffic vlan 950
Bridge2(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge2(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge2(g8032-config-switch)#end	Exit g8032 erp instance mode

Bridge3#configure terminal	Enter configure mode
Bridge3(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge3(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string
Bridge3(config)#vlan database	Configure VLAN database

Bridge3(config-vlan)# vlan 450 bridge 1 state enable	Create VLAN 450 on bridge 1
Bridge3(config-vlan)# vlan 900-1010 bridge 1 state enable	Create VLAN 900-1010 on bridge 1
Bridge3(config-vlan)#interface ce4/1	Configure interface ce4/1
Bridge3(config-if)#switchport	Configure ce4/1 as a layer 2 port
Bridge3(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge3(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge3(config-if)#switchport mode trunk	Configure port as trunk port
Bridge3(config-if)#switchport trunk allowed vlan add 450,900-1010	Allow vlan 450,900-1010 on ce4/1 interface
Bridge3(config-if)#interface ce7/1	Configure interface ce7/1
Bridge3(config-if)#switchport	Configure ce7/1 as a layer 2 port
Bridge3(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge3(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge3(config-if)#switchport mode trunk	Configure port as trunk port
Bridge3(config-if)#switchport trunk allowed vlan add 450,900-1010	Allow vlan 450,900-1010 on ce7/1 interface
Bridge3(config-if)# ethernet cfm domain- type character-string domain-name mdna4 level 7 mip-creation default	Create cfm domain with type as character string with name mdna4 and set MIP creation criteria to default with level 7
Bridge3(config-ether-cfm)#service ma-type string ma-name n27	Create MA type as string with name n27
Bridge3(config-ether-cfm-ma)# vlan 900 bridge 1	Add VLAN 900
<pre>Bridge3(config-ether-cfm-ma)# mip-creation default</pre>	Set MIP-creation criteria to default
Bridge3(config-ether-cfm-ma)# ethernet cfm mep down mpid 5057 active true ce7/1	Create down MEP 5057 for ce7/1 interface
Bridge3(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge3(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge3(config-ether-cfm-ma)#mep crosscheck mpid 57	Configure crosscheck to remote MEP with value 57
Bridge3(config-ether-cfm-ma)#cc interval 10s	Enable cc interval with 10s
Bridge3(config-ether-cfm-ma)# exit-ether- ma-mode	Exit Ethernet ma mode

Bridge3(config-if)# ethernet cfm domain- type character-string domain-name mdna5 level 7 mip-creation default	Create cfm domain with type as character string with name mdna5 and set MIP creation criteria to default with level 7
Bridge3(config-ether-cfm)#service ma-type string ma-name n27	Create MA type as string with name n27
Bridge3(config-ether-cfm-ma)# vlan 900 bridge 1	Add VLAN 900
<pre>Bridge3(config-ether-cfm-ma)# mip-creation default</pre>	Set MIP-creation criteria to default
Bridge3(config-ether-cfm-ma)# ethernet cfm mep down mpid 67 active true ce4/1	Create down MEP 67 for ce4/1 interface
Bridge3(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast
Bridge3(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode
Bridge3(config-ether-cfm-ma)#mep crosscheck mpid 6067	Configure crosscheck to remote MEP with value 6067
Bridge3(config-ether-cfm-ma)#cc interval 10s	Enable cc interval with 10s
Bridge3(config-ether-cfm-ma)# exit-ether- ma-mode	Exit Ethernet ma mode
Bridge3(config-ether-cfm)#g8032 ring RING1	Create g8032 physical ring with name RING1
Bridge3(g8032-ring-config)#east-interface ce4/1	Associate ce4/1 interface as east-interface
Bridge3(g8032-ring-config)#west-interface ce7/1	Associate ce7/1 interface as west-interface
Bridge3(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1
Bridge3(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min
Bridge3(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0
Bridge3(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms
Bridge3(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode
Bridge3(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1
Bridge3(g8032-config-switch)#ring RING1	Associate ring RING1 to erp1 instance
Bridge3(g8032-config-switch)#rpl role non- owner	Configure the node as non-owner node

Bridge3(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance
Bridge3(g8032-config-switch)#aps-channel level 7	Configure level as 7
Bridge3(g8032-config-switch)#aps-channel vlan 900	Configure RAPS channel vlan as 900
Bridge1(g8032-config-switch)#data vlan 950	Configure traffic vlan 950
Bridge3(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge3(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge3(g8032-config-switch)#end	Exit g8032 erp instance mode

Bridge 4s

Bridge4#configure terminal	Enter configure mode
Bridge4(config)#ip router isis 1	Enable routing process - Intermediate System (IS-IS)
Bridge4(config-router)#net 49.3600.3600.0001.00	Configure net
Bridge4(config-router)#exit	End current mode and down to previous mode
Bridge4(config)#interface lo	Configure interface loopback
Bridge4(config-if)#ip address 1.1.1.1/32 secondary	Configure secondary ip address
Bridge4(config-if)#ip router isis 1	Enable routing process - Intermediate System (IS-IS)
Bridge4(config-if)#commit	Commit the candidate configuration to the running configuration
Bridge4(config-if)#exit	End current mode and down to previous mode
Bridge4(config)#router ldp	Enable LDP protocol
Bridge4(config-router)#router-id 1.1.1.1	Set router id
Bridge4(config-router)#targeted-peer ipv4 2.2.2.2	Configure targeted peer
Bridge4(config-router)#exit-targeted-peer- mode	Exit Targeted Peer configuration mode
Bridge4(config-router)#targeted-peer ipv4 3.3.3.3	Configure targeted peer
Bridge4(config-router)#exit-targeted-peer- mode	Exit Targeted Peer configuration mode
Bridge4(config-router)#transport-address ipv4 1.1.1.1	Configure a transport address for a label space
Bridge4(config-router)#commit	Commit the candidate configuration to the running configuration
Bridge4(config-router)#exit	End current mode and down to previous mode
Bridge4(config)#mpls vpls vpls450 450	Create an instance of MPLS based Virtual Private Lan Service (VPLS)

Bridge4(config-vpls)#signaling ldp	Establishing pseudowires with other PE routers using ldp protocol
Bridge4(config-vpls-sig)#vpls-peer 2.2.2.2	Add a peer to VPLS domain
Bridge4(config-vpls-sig)#vpls-peer 3.3.3.3	Add a peer to VPLS domain
Bridge4(config-vpls-sig)#exit-signaling	Exit from Signaling configuration mode and start signaling
Bridge4(config-vpls)# exit-vpls	Exit from vpls mode
Bridge4(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.
Bridge4(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string
Bridge4(config)#vlan database	Configure VLAN database
Bridge4(config-vlan)# vlan 900-1010 bridge 1 state enable	Create VLAN 900-1010 on bridge 1
Bridge4(config-vlan)#interface ce20	Configure interface ce20
Bridge4(config-if)#switchport	Configure ce20 as a layer 2 port
Bridge4(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge4(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge4(config-if)#switchport mode trunk	Configure port as trunk port
Bridge4(config-if)#switchport trunk allowed vlan add 900-1010	Allow vlan 900-1010 on ce20 interface
Bridge4(config-if)#interface interface ce20.450 switchport	Configure interface ce20.450 as L2 subinterface
Bridge4(config-if)#encapsulationdot1q450	Configure dotq encapsulation for vlan 450 packets
Bridge4(config-if)#access-if-vpls	Enter to VPLS MPLS Access interface mode
Bridge4(config-acc-if-vpls)#mpls-vpls vpls450	Attach VPLS instance
Bridge4(config-acc-if-vpls)#exit	End current mode and down to previous mode
Bridge4(config-if)#interface xel4	Configure interface xe14
Bridge4(config-if)#switchport	Configure xe14 as a layer 2 port
Bridge4(config-if)#bridge-group 1	Configure interface in bridge group 1
Bridge4(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface
Bridge4(config-if)#switchport mode trunk	Configure port as trunk port
Bridge4(config-if)#switchport trunk allowed vlan add 900-1010	Allow vlan 900-1010 on xe14 interface
Bridge4(config-if)#interface xe14.450	Configure sub-interface of xe14
Bridge4(config-if)#encapsulationdot1q450	Configure dotq encapsulation for vlan 450 packets
Bridge4(config-if)#ipaddress10.1.1.2/30	Configure ip address

Bridge4(config-if)#label-switching	Enable label-switching on interface	
Bridge4(config-if)#ip router isis 1	Enable routing process - Intermediate System (IS-IS)	
Bridge4(config-if)#enable-ldp ipv4	Enable LDP protocol	
Bridge4(config-if)#erps-instance none	Configure erps-instance in this subinterface	
Bridge4(config-if)#interface xe4	Configure interface xe24	
Bridge4(config-if)#ipaddress30.1.1.2/30	Configure ip address	
Bridge4(config-if)#label-switching	Enable label-switching on interface	
Bridge4(config-if)#ip router isis 1	Enable routing process - Intermediate System (IS-IS)	
Bridge4(config-if)#enable-ldp ipv4	Enable LDP protocol	
Bridgel(config-if)# ethernet cfm domain- type character-string domain-name mdna3 level 7 mip-creation default	Create cfm domain with type as character string with name mdna3 and set MIP creation criteria to default with level 7	
Bridge4(config-ether-cfm)#service ma-type string ma-name n27	Create MA type as string with name n27	
Bridge4(config-ether-cfm-ma)#vlan 900 bridge 1	Add VLAN 900	
Bridge4(config-ether-cfm-ma)# mip-creation default	Set MIP-creation criteria to default	
Bridge4(config-ether-cfm-ma)# ethernet cfm mep down mpid 4047 active true xel4	Create down MEP 4047 for xe14 interface	
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast	
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode	
Bridge4(config-ether-cfm-ma)#mep crosscheck mpid 47	Configure crosscheck to remote MEP with value 47	
Bridge4(config-ether-cfm-ma)#cc interval 10s	Enable cc interval with 10s	
Bridge4(config-ether-cfm-ma)# exit-ether- ma-mode	Exit Ethernet ma mode	
Bridge4(config-if)# ethernet cfm domain- type character-string domain-name mdna4 level 7 mip-creation default	Create cfm domain with type as character string with name mdna4 and set MIP creation criteria to default with level 7	
Bridge4(config-ether-cfm)#service ma-type string ma-name n27	Create MA type as string with name n27	
Bridge4(config-ether-cfm-ma)# vlan 900 bridge 1	Add VLAN 900	

Bridge4(config-ether-cfm-ma)# mip-creation default	Set MIP-creation criteria to default	
Bridge4(config-ether-cfm-ma)# ethernet cfm mep down mpid 57 active true ce20	Create down MEP 57 for ce20 interface	
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast	
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode	
Bridge4(config-ether-cfm-ma)#mep crosscheck mpid 5057	Configure crosscheck to remote MEP with value 5057	
Bridge4(config-ether-cfm-ma)#cc interval 10s	Enable cc interval with 10s	
Bridge4(config-ether-cfm-ma)# exit-ether- ma-mode	Exit Ethernet ma mode	
Bridge4(config-ether-cfm)#g8032 ring RING1	Create g8032 ring with name RING1	
Bridge4(g8032-ring-config)#east-interface ce20	Associate ce20 interface as east-interface	
Bridge4(g8032-ring-config)#west-interface xel4	Associate xe14 interface as west-interface	
Bridge4(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1	
Bridge4(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min	
Bridge4(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0	
Bridge4(g8032-profile-config)#timer guard- timer 10	- Configure guard-timer value as 10ms	
Bridge4(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode	
Bridge4(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1	
Bridge4(g8032-config-switch)#ring RING1	Associate ring RING1 to erp1 instance	
Bridge4(g8032-config-switch)#rpl role neighbor west-interface	Configure the node as neighbor towards west-interface	
Bridge4(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance	
Bridge4(g8032-config-switch)#aps-channel level 7	Configure level as 7	
Bridge4(g8032-config-switch)#aps-channel vlan 900	Configure RAPS channel vlan as 900	
Bridge4(g8032-config-switch)#data vlan 950	Configure traffic vlan 950	

Bridge4(g8032-config-switch)#ring-id 1	Configure ring-id as 1
Bridge4(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge4(g8032-config-switch)#end	Exit g8032 erp instance mode

Bridge5#configure terminal	Enter configure mode	
Bridge5(config)#ip router isis 1	Enable routing process - Intermediate System (IS-IS)	
Bridge5(config-router)# net 49.3600.3600.0002.00	Configure net	
Bridge5(config-router)#exit	End current mode and down to previous mode	
Bridge5(config)#interface lo	Configure interface loopback	
Bridge5(config-if)# ip address 2.2.2.2/32 secondary	Configure secondary ip address	
Bridge5(config-if)#ip router isis 1	Enable routing process - Intermediate System (IS-IS)	
Bridge5(config-if)#commit	Commit the candidate configuration to the running configuration	
Bridge5(config-if)#exit	End current mode and down to previous mode	
Bridge5(config)#router ldp	Enable LDP protocol	
Bridge5(config-router)#router-id 2.2.2.2	Set router id	
Bridge5(config-router)#targeted-peer ipv4 1.1.1.1	Configure targeted peer	
Bridge5(config-router)#exit-targeted-peer- mode	 Exit Targeted Peer configuration mode 	
Bridge5(config-router)#targeted-peer ipv4 3.3.3.3	Configure targeted peer	
Bridge5(config-router)#exit-targeted-peer- mode	Exit Targeted Peer configuration mode	
Bridge5(config-router)#transport-address ipv4 2.2.2.2	Configure a transport address for a label space	
Bridge5(config-router)#commit	Commit the candidate configuration to the running configuration	
Bridge5(config-router)#exit	End current mode and down to previous mode	
Bridge5(config)#mpls vpls vpls450 450	Create an instance of MPLS based Virtual Private Lan Service (VPLS)	
<pre>Bridge5(config-vpls)#signaling ldp</pre>	Establishing pseudowires with other PE routers using ldp protocol	
Bridge5(config-vpls-sig)#vpls-peer 1.1.1.1	Add a peer to VPLS domain	
Bridge5(config-vpls-sig)#vpls-peer 3.3.3.3	Add a peer to VPLS domain	
Bridge5(config-vpls-sig)#exit-signaling	Exit from Signaling configuration mode and start signaling	
Bridge5(config-vpls)# exit-vpls	Exit from vpls mode	

Bridge5(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.	
Bridge5(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string	
Bridge5(config)#vlan database	Configure VLAN database	
Bridge5(config-vlan)# vlan 900-1010 bridge 1 state enable	Create VLAN 900-1010 on bridge 1	
Bridge5(config-vlan)#interface xe15	Configure interface xe15	
Bridge5(config-if)#switchport	Configure xe15 as a layer 2 port	
Bridge5(config-if)#bridge-group 1	Configure interface in bridge group 1	
Bridge5(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface	
Bridge5(config-if)#switchport mode trunk	Configure port as trunk port	
Bridge5(config-if)#switchport trunk allowed vlan add 900-1010	Allow vlan 900-1010 on xe15 interface	
Bridge5(config-if)#interface interface xe15.450 switchport	Configure interface xe15.450 as L2 subinterface	
Bridge5(config-if)#encapsulationdot1q450	Configure dotq encapsulation for vlan 450 packets	
Bridge5(config-if)#access-if-vpls	Enter to VPLS MPLS Access interface mode	
Bridge5(config-acc-if-vpls)#mpls-vpls vpls450	Attach VPLS instance	
Bridge5(config-acc-if-vpls)#exit	End current mode and down to previous mode	
Bridge5(config-if)#interface xe0	Configure interface xe0	
Bridge5(config-if)#switchport	Configure xe0 as a layer 2 port	
Bridge5(config-if)#bridge-group 1	Configure interface in bridge group 1	
Bridge5(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface	
Bridge5(config-if)#switchport mode trunk	Configure port as trunk port	
Bridge5(config-if)#switchport trunk allowed vlan add 900-1010	Allow vlan 900-1010 on xe0 interface	
Bridge5(config-if)#interface xe0.450	Configure sub-interface of xe0	
Bridge5(config-if)#encapsulationdot1q450	Configure dotq encapsulation for vlan 450 packets	
Bridge5(config-if)#ipaddress10.1.1.1/30	Configure ip address	
Bridge5(config-if)#label-switching	Enable label-switching on interface	
Bridge5(config-if)#ip router isis 1	Enable routing process - Intermediate System (IS-IS)	
Bridge5(config-if)#enable-ldp ipv4	Enable LDP protocol	
Bridge5(config-if)#erps-instance none	Configure erps-instance in this subinterface	
Bridge5(config-if)#interface xe22	Configure interface xe24	
Bridge5(config-if)#ipaddress20.1.1.1/30	Configure ip address	

Bridge5(config-if)#label-switching	Enable label-switching on interface	
Bridge5(config-if)#ip router isis 1	Enable routing process - Intermediate System (IS-IS)	
Bridge5(config-if)#enable-ldp ipv4	Enable LDP protocol	
Bridge5(config-if)# ethernet cfm domain- type character-string domain-name mdna2 level 7 mip-creation default	Create cfm domain with type as character string with name mdna2 and set MIP creation criteria to default with level 7	
Bridge5(config-ether-cfm)#service ma-type string ma-name n27	Create MA type as string with name n27	
Bridge5(config-ether-cfm-ma)#vlan 900 bridge 1	Add VLAN 900	
Bridge5(config-ether-cfm-ma)# mip-creation default	Set MIP-creation criteria to default	
Bridge5(config-ether-cfm-ma)# ethernet cfm mep down mpid 37 active true xe15	Create down MEP 37 for xe15 interface	
Bridge5(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast	
Bridge5(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode	
Bridge5(config-ether-cfm-ma)#mep crosscheck mpid 3037	Configure crosscheck to remote MEP with value 3037	
Bridge5(config-ether-cfm-ma)#cc interval 10s	Enable cc interval with 10s	
Bridge5(config-ether-cfm-ma)# exit-ether- ma-mode	Exit Ethernet ma mode	
Bridge5(config-if)# ethernet cfm domain- type character-string domain-name mdna3 level 7 mip-creation default	Create cfm domain with type as character string with name mdna3 and set MIP creation criteria to default with level 7	
Bridge5(config-ether-cfm)#service ma-type string ma-name n27	Create MA type as string with name n27	
Bridge5(config-ether-cfm-ma)# vlan 900 bridge 1	Add VLAN 900	
Bridge5(config-ether-cfm-ma)# mip-creation default	Set MIP-creation criteria to default	
Bridge5(config-ether-cfm-ma)# ethernet cfm mep down mpid 47 active true xe0	Create down MEP 47 for xe0 interface	
Bridge5(config-ether-cfm-ma-mep)#cc multicast state enable	Enable CC multicast	
Bridge5(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit ethernet CFM MA-MEP mode	

Bridge5(config-ether-cfm-ma)#mep crosscheck mpid 4047	Configure crosscheck to remote MEP with value 4047	
Bridge5(config-ether-cfm-ma)#cc interval 10s	Enable cc interval with 10s	
Bridge5(config-ether-cfm-ma)# exit-ether- ma-mode	Exit Ethernet ma mode	
Bridge5(config-ether-cfm)#g8032 ring RING1	Create g8032 ring with name RING1	
Bridge5(g8032-ring-config)#east-interface xe0	Associate ce20 interface as east-interface	
Bridge5(g8032-ring-config)#west-interface xe15	Associate xe14 interface as west-interface	
Bridge5(g8032-ring-config)#g8032 profile profile1	Create g8032 profile with profile name profile1	
Bridge5(g8032-profile-config)#timer wait- to-restore 1	Configure wait to restore time as 1 min	
Bridge5(g8032-profile-config)#timer hold- off 0	Configure hold-off timer value as 0	
Bridge5(g8032-profile-config)#timer guard- timer 10	Configure guard-timer value as 10ms	
Bridge5(g8032-profile-config)#switching mode revertive	Configure Switching mode as revertive Switching mode	
Bridge5(g8032-profile-config)#g8032 erp- instance erp1	Create g8032 erp instance erp1	
Bridge5(g8032-config-switch)#ring RING1	Associate ring RING1 to erp1 instance	
Bridge5(g8032-config-switch)#rpl role owner east-interface	Configure the node as owner towards east-interface	
Bridge5(g8032-config-switch)#g8032-profile profile1	Associate Profile profile1 to erp1 instance	
Bridge5(g8032-config-switch)#aps-channel level 7	Configure level as 7	
Bridge5(g8032-config-switch)#aps-channel vlan 900	Configure RAPS channel vlan as 900	
Bridge5(g8032-config-switch)#data vlan 950	Configure traffic vlan 950	
Bridge5(g8032-config-switch)#ring-id 1	Configure ring-id as 1	
Bridge5(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration	
Bridge5(g8032-config-switch)#end	Exit g8032 erp instance mode	

Bridge6#configure terminal	Enter configure mode
Bridge6(config)#ip router isis 1	Enable routing process - Intermediate System (IS-IS)

Bridge6(config-router)# net 49.3600.3600.0003.00	Configure net		
Bridge6(config-router)#exit	End current mode and down to previous mode		
Bridge6(config)#interface lo	Configure interface loopback		
Bridge6(config-if)# ip address 3.3.3.3/32 secondary	Configure secondary ip address		
Bridge6(config-if)#ip router isis 1	Enable routing process - Intermediate System (IS-IS)		
Bridge6(config-if)#commit	Commit the candidate configuration to the running configuration		
Bridge6(config-if)#exit	End current mode and down to previous mode		
Bridge6(config)#router ldp	Enable LDP protocol		
Bridge6(config-router)#router-id 3.3.3.3	Set router id		
Bridge6(config-router)#targeted-peer ipv4 1.1.1.1	Configure targeted peer		
Bridge6(config-router)#exit-targeted-peer- mode	Exit Targeted Peer configuration mode		
Bridge6(config-router)#targeted-peer ipv4 2.2.2.2	Configure targeted peer		
Bridge6(config-router)#exit-targeted-peer- mode	Exit Targeted Peer configuration mode		
Bridge6(config-router)#transport-address ipv4 3.3.3.3	Configure a transport address for a label space		
Bridge6(config-router)#commit	Commit the candidate configuration to the running configuration		
Bridge6(config-router)#exit	End current mode and down to previous mode		
Bridge6(config)#mpls vpls vpls450 450	Create an instance of MPLS based Virtual Private Lan Service (VPLS)		
Bridge6(config-vpls)#signaling ldp	Establishing pseudowires with other PE routers using ldp protocol		
Bridge6(config-vpls-sig)#vpls-peer 1.1.1.1	Add a peer to VPLS domain		
Bridge6(config-vpls-sig)#vpls-peer 2.2.2.2	Add a peer to VPLS domain		
Bridge6(config-vpls-sig)#exit-signaling	Exit from Signaling configuration mode and start signaling		
Bridge6(config-vpls)# exit-vpls	Exit from vpls mode		
Bridge6(config)#bridge 1 protocol rstp vlan-bridge	Create bridge 1 as an RSTP VLAN-aware bridge.		
Bridge6(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string		
Bridge6(config)#vlan database	Configure VLAN database		
Bridge6(config-vlan)# vlan 450 bridge 1 state enable	Create VLAN 450 on bridge 1		
Bridge6(config-vlan) # vlan 900-1010 bridge 1 state enable	Create VLAN 900-1010 on bridge 1		

Bridge6(config-vlan)#interface xe4	Configure interface xe4	
Bridge6(config-if)#switchport	Configure xe4 as a layer 2 port	
Bridge6(config-if)#bridge-group 1	Configure interface in bridge group 1	
Bridge6(config-if)#bridge-group 1 spanning-tree disable	Disable spanning tree for bridge group 1 on that interface	
Bridge6(config-if)#switchport mode trunk	Configure port as trunk port	
Bridge6(config-if)#switchport trunk allowed vlan add 900-1010	Allow vlan 900-1010 on xe4 interface	
Bridge6(config-if)#interface interface xe4.450 switchport	Configure interface xe4.450 as L2 subinterface	
Bridge6(config-if)#encapsulationdot1q450	Configure dotq encapsulation for vlan 450 packets	
Bridge6(config-if)#access-if-vpls	Enter to VPLS MPLS Access interface mode	
Bridge6(config-acc-if-vpls)#mpls-vpls vpls450	Attach VPLS instance	
Bridge6(config-acc-if-vpls)#exit	End current mode and down to previous mode	
Bridge6(config-if)#interface xe2	Configure sub-interface of xe2	
Bridge6(config-if)#ipaddress20.1.1.2/30	Configure ip address	
Bridge6(config-if)#label-switching	Enable label-switching on interface	
Bridge6(config-if)#ip router isis 1	Enable routing process - Intermediate System (IS-IS)	
Bridge6(config-if)#enable-ldp ipv4	Enable LDP protocol	
Bridge6(config-if)#interface xe5	Configure interface xe24	
Bridge6(config-if)#ipaddress30.1.1.1/30	Configure ip address	
Bridge6(config-if)#label-switching	Enable label-switching on interface	
Bridge6(config-if)#ip router isis 1	Enable routing process - Intermediate System (IS-IS)	
Bridge6(config-if)#enable-ldp ipv4	Enable LDP protocol	
Bridge6(config-if)#commit	Commit the candidate configuration to the running configuration	
Bridge6(config-if)#end	Exit g8032 erp instance mode	

Validation

Bridge1:

show g8032 erp-instance erp1

Inst Name	: erp1
Description	:
State	: G8032_ST_IDLE
Phy Ring	: RING1
Ring Type	: MAJOR-RING
Role	: NON-OWNER

Node ID	:	14:44:8f:9c:20:dd	
		East Link	West Link
Interface	:	xe20	xe12
Protocol State	:	Unblocked	Unblocked
Link Status	:	UP	UP
Remote NodeId	:	f8:8e:a1:f3:25:42	-
Remote BPR	:	1	-
Endpoint Info			
Domain Name	:	mdna2	mdna1
MEP ID	:	3037	2027
MA Name	:	n27	n27
	===	=======================================	
Channel		I	
(LEVEL, VLAN,	RIN	G ID)	
(7, 900,	1)	 	

DataTraffic vlan: 950 Profile : profile1

Bridge2:

show g8032 erp-instance erp1

Inst Name Description State Phy Ring Ring Type Role Node ID	::	erp1 G8032_ST_IDLE RING1 MAJOR-RING NON-OWNER 34:ef:b6:2f:45:86	
		East Link	West Link
Interface Protocol State Link Status Remote NodeId Remote BPR Endpoint Info	:	ce9/1 Unblocked UP f8:8e:a1:f3:25:42 1	ce6/1 Unblocked UP -
Domain Name MEP ID MA Name	:	mdna1 27 n27	mdna5 6067 n27

Channel (LEVEL, VLAN,	 RING ID)	
(7, 900,	1)	
DataTraffic vla Profile :	n: 950 profile1	
Bridge3:		
show g8032	erp-instance erp1	
Inst Name Description State Phy Ring Ring Type Role Node ID	: erp1 : : G8032_ST_IDLE : RING1 : MAJOR-RING : NON-OWNER : 34:ef:b6:3c:55:c6	
	East Link	West Link
Interface Protocol State Link Status Remote NodeId Remote BPR Endpoint Info	: ce4/1 : Unblocked : UP : f8:8e:a1:f3:25:42 : 1	ce7/1 Unblocked UP -
Domain Name MEP ID MA Name	: mdna5 : 67 : n27	mdna4 5057 n27
Channel (LEVEL, VLAN,	RING ID)	
(7, 900,	1)	
DataTraffic vla Profile :	n: 950 profile1	
Bridge4: show g8032 erp-	instance erp1	

Inst Name : erp1

Description	:						
State	: G80)32_ST_I	DLE				
Phy Ring	: RIN	JG1					
Ring Type	: MAC	JOR-RING					
Role	: NEI	GHBOR (WEST)				
Node ID	: e8:	c5:7a:4	7:c8:37				
	Eá	ast Link		West Link			
Interface	: ce	======= e20		======================================			
Protocol State	: Ur	nblocked		Blocked			
Link Status	: UI	2		UP			
Remote NodeId	: f8	8:8e:al:	£3:25:42	f8:8e:a1:f3	:25:42		
Remote BPR	: 1			1			
Endpoint Info							
Domain Name	: mc	dna4		mdna3			
MEP ID	: 57	7		4047			
MA Name	: n2	27		n27			
Channel							
(LEVEL, VLAN,	RING 1	[D)					
	======= 1 \						
(7, 900,	⊥) ======	ا ======					
DataTraffic vla	in: 950)					
Profile :	protil	lel					
- · · · ·							
Bridge4:							
show mpls vpls	mesh						
(m) - Service m	napped	over mu	ltipath tra	nsport			
(e) - Service m	napped	over LD	P ECMP				
VPLS-ID Peer PW-INDEX SIG-Pr	Addr	I Statu	'unnel-Label	l In-Label	Network-Intf	Out-Label	Lkps/St
450 2.2.	2.2		3	26240	xe14.450	26241	2/Up
L LDP	2 2	Acti	ve	0.0041		0.0041	0 /11-0
450 5.5. 2 LDP	5.5	Acti	ve	20241	Xe4	20241	270p
Bridge4:							
show hel ifmar	13	1 1 5 0					
Interface • xel4	13 AEI 1 450 1	findex.	164331970	TVDE. TP [m]	olsl Oper Count	- 1 Ref Coun	+ 2
FIB: 0 Status :	UP/RI	JNNTNG	1010010,0	1 y p 0 • 11 [m]	piol ober coam	, i noi ooun	0 2
Ethertpe : 0x81	.00 (NC	OT CONFT	GURED)				
L3 Info Ifir	ndex :	4150	VID : 4150		: HW FIB	ID : 0L3 ear	ess
ID : 536875008	-						

lport: 0x800000f

```
Lif Id : 0x44802018 Encap Id : 0x2018
Configured ERPS Instance : NONE <0>
Current ERPS Instance : NONE <0>
Current ERPS Port State : Forward
Total number of Children port count : 1
IPv4 Address (Count: 1):
Pfx: 10.1.1.2/30 flags: 0 int_flags: 16
IPv6 Address (Count: 1):
Pfx: fe80::eac5:7aff:fe47:c831/64 flags: 0 int flags: 16
```

Bridge4:

	show hsl hw unit	0 ac-lif gr	ep 450			
16	0x4480200f	0x200f none	0x0	0	4149	450
0x1b	0x2011	Forward				
25	0x44802018	0x2018 port*v	vlan 0x241	.c00e4 450	4150	450
0x11	0x201a	Forward				

Bridge5:

show g8032 erp-instance erp1

Inst Name	:	erpl	
Description	:		
State	:	G8032_ST_IDLE	
Phy Ring	:	RING1	
Ring Type	:	MAJOR-RING	
Role	:	OWNER (EAST)	
Node ID	:	f8:8e:a1:f3:25:42	
		East Link	West Link
Interface	:	xe0	xe15
Protocol State	:	Blocked	Unblocked
Link Status	:	UP	UP
Remote NodeId	:	-	-
Remote BPR	:	-	-
Endpoint Info			
Domain Name	:	mdna3	mdna2
MEP ID	:	47	37
MA Name	:	n27	n27
Channel (LEVEL, VLAN,	RII	 NG ID) 	
(7, 900,	1)	 	

```
DataTraffic vlan: 950
Profile : profile1
```

Bridge5:

show mpls vpls mesh
(m) - Service mapped over multipath transport
(e) - Service mapped over LDP ECMP

VPLS-ID PW-INDEX	Peer Addr SIG-Protocol	Tunnel-Label Status	In-Label	Network-Intf	Out-Label	Lkps/St
450 1	1.1.1.1 LDP	3 Active	26241	xe0.450	26240	2/Up
450 2	3.3.3.3 LDP	3 Active	26240	xe22	26240	2/Up

Bridge6:

show mpls vpls mesh
(m) - Service mapped over multipath transport
(e) - Service mapped over LDP ECMP

VPLS-ID PW-INDEX	Peer Addr SIG-Protocol	Tunnel-Label Status	In-Label	Network-Intf	Out-Label	Lkps/St
450 1	1.1.1.1 LDP	3 Active	26241	xe5	26241	2/Up
450 2	2.2.2.2 LDP	3 Active-	26240	xe2	26240	2/Up

CHAPTER 12 ERPS with CFM Down-MEP over Bridge-Domain

Overview

Ethernet Ring Protection Switching (ERPS) over a bridge domain is a network feature that allows the implementation of ring protection in Ethernet networks using bridge domains. ERPS, a protocol specified by ITU-T G.8032, is designed to provide fast and seamless protection switching in ring topologies to ensure network availability. Previously, all ERPS instances were mapped to a single bridge domain. It is now possible to map different flooding domains with ERPS instances.

Feature Characteristics

- 1. **ERPS Configuration over L2 Sub-Interface:** OcNOS allows the configuration of ERPS over Layer 2 subinterfaces mapped under Bridge-Domains, enabling efficient utilization of network resources.
- 2. L2 Sub-Interface Configuration as Ring Ports: Layer 2 sub-interfaces can be easily configured as east and west ring ports of an ERPS ring, providing a flexible and intuitive setup.
- 3. **Support for Multiple ERPS Instances:** The software supports the creation of multiple ERPS instances, facilitating the deployment of different logical ERPS rings across various Bridge-Domains.
- 4. **Shared ERPS Instances for Logical Rings:** Optionally, multiple ERPS logical rings can utilize a single ERPS instance if the ring ports share the same parent interface, streamlining the configuration process.
- 5. **Single Bridge-Domain per ERPS Instance:** A single ERPS instance can only have ring ports from a single Bridge-Domain, ensuring consistent and efficient ring management.
- CFM Triggering for ERPS Instances: Configuration of Continuity Fault Management (CFM) over L2-subinterfaces will trigger signal fail events for ERPS instances created over the same L2-sub-interface upon link fault detection.
- 7. Single ERPS Instance Monitoring Multiple ERPS Rings: The software allows a single ERPS instance to monitor multiple ERPS rings, offering centralized management and improved network oversight.
 - Note: When a single instance is utilized to monitor multiple ERPS rings, only a fault detected by the primary ring will trigger a switchover (ERPS) in associate rings. Individual sub-interface (subifp) link shutdowns of associate ring member interfaces will not initiate a switchover in that instance.

Benefits

Network Resilience: ERPS enhances network resiliency by creating a ring topology, where traffic can be rerouted in case of a link or node failure, ensuring uninterrupted connectivity.

Faster Traffic Switchover: In case of a link or node failure within the ring, ERPS ensures rapid traffic switchover to the backup path, minimizing service disruptions.

Prerequisites

Before configuring ERPS over bridge-domains, ensure the following prerequisites are met:
Properly configure the bridge-domains and L2 sub-interfaces. For more details, refer *Bridging Support Over Layer2 Sub Interface* and *Layer 2 Subinterface Configuration* chapters in the *Layer 2 Guide*.

- Understand the network topology and ERPS requirements. For more details, refer G.8032 ERPS Version 2 chapter in the *Carrier Ethernet Configuration Guide*.
- Knowledge of CFM configuration if integrating CFM with ERPS. For more details, refer Carrier Ethernet Guide.

Major Ring Configuration

The major ring is the primary ring in an ERPS configuration. It carries the traffic under normal operating conditions. When no failure occurs, traffic flows through the major ring.

Topology

Figure 12-24 illustrates a sample Ring Protection topology in which protection switching is configured using four bridges. The Ring Protection Link (RPL) owner is the link between Bridge 3 and Bridge 4 (xe16), with Bridge 4 explicitly defined as the RPL owner and Bridge 3 as the RPL neighbor on one side of the link. The other bridges are explicitly configured as RPL non-owners to enable Ethernet Ring Protection Switching (ERPS) within the ring.



Figure 12-24: Major Ring Topology

Prerequisite

In configuration mode, enable the following hardware-profile commands related to CFM and then reboot the nodes:

hardware-profile filter cfm-domain-name-str enable hardware-profile statistics cfm-ccm enable

The following steps provide a detailed configuration of commands for setting up ERPS and CFM on Bridge1, Bridge2, Bridge3, and Bridge4 nodes. These commands enable the creation of rings, maintenance associations, Maintenance End Points (MEPs), and various parameters to ensure network reliability and protection against faults.

Pridgel#configure_terminal	Enter configure mode
Bridger#configure cerminal	
Bridgel(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string.
Bridgel(config)#interface xe6	Enter interface mode xe6.
Bridgel(config-if)#dotlad ethertype 0x88a8	Configure $xe6$ as a Layer 2 port with an Ethernet Type of $0x88a8$.
Bridgel(config-if)#interface xe6.1 switchport	Create a Layer 2 sub-interface $xe6.1$ within the physical interface $xe6$.
Bridge1(config-if)encapsulation dot1ad 200	Encapsulate the sub-interface with APS-channel VLAN ID 200.
Bridge1(config-if)encapsulation dot1ad 700	Encapsulate the sub-interface with data VLAN ID 700.
Bridgel(config-if)#exit	Exit interface mode xe6.
Bridgel(config)#interface xe8	Enter interface mode xe8.
Bridgel(config-if)#dotlad ethertype 0x88a8	Configure $xe8$ as a Layer 2 port with an Ethernet Type of $0x88a8$.
Bridge1(config)#interface xe8.1 switchport	Create a Layer 2 sub-interface $x \in 8.1$ within the physical interface $x \in 8$.
Bridgel(config-if)encapsulation dotlad 200	Encapsulate the sub-interface with APS-channel VLAN ID 200.
Bridge1(config-if)encapsulation dot1ad 700	Encapsulate the sub-interface with data VLAN ID 700.
Bridgel(config-if)#exit	Exit interface mode xe8.
Bridge1(config)#bridge-domain 1	Enter bridge domain configure mode and configure bridge domain instance 1.
Bridge1(config-bridge-domain)#interface xe6.1	Attach the sub-interface ${\tt xe6.1}$ to the bridge domain instance.
Bridge1(config-bridge-domain)#interface xe8.1	Attach the sub-interface ${\tt xe8.1}$ to the bridge domain instance.
Bridgel(config-bridge-domain)#exit	Exit bridge domain mode.
Bridgel(config)#ethernet cfm domain-type character-string domain-name P542 level 5	Create a CFM domain with character string type, name P542, and level 5.
Bridgel(config-ether-cfm)#service ma-type string ma-name ma542	Create a CFM Maintenance Association (MA) type as a string with the name ma542.
Bridge1(config-ether-cfm-ma)#vlan 200	Add VLAN 200 to the CFM MA.
Bridgel(config-ether-cfm-ma)#ethernet cfm mep down mpid 542 active true xe8.1	Create a down MEP 542 for ${\tt xe8.1}$ interface and activate it.
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable Continuity Check (CC) multicast for the MEP.
Bridge1(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.

Bridgel(config-ether-cfm-ma)#mep crosscheck mpid 452	Configure crosscheck for the remote MEP with value 452.
Bridge1(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridgel(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge1(config)#ethernet cfm domain-type character-string domain-name P522 level 5	Create a CFM domain with character string type, name P522, and level 5.
Bridge1(config-ether-cfm)#service ma-type string ma-name ma522	Create a CFM MA type as a string with the name ma522.
Bridge1(config-ether-cfm-ma)#vlan 200	Add VLAN 200 to the CFM MA.
Bridgel(config-ether-cfm-ma)#ethernet cfm mep down mpid 522 active true xe6.1	Create a down MEP 522 for ${\tt xe6.1}$ interface and activate it.
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enables CC multicast for the MEP.
Bridge1(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridgel(config-ether-cfm-ma)#mep crosscheck mpid 252	Configure crosscheck for the remote MEP with value 252.
Bridgel(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridgel(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge1(config)#g8032 ring RING1	Create a G.8032 ring named RING1.
Bridge1(g8032-ring-config)#east-interface xe8.1	Associate xe8.1 interface as the east interface in RING1.
Bridge1(g8032-ring-config)#west-interface xe6.1	Associate $xe6.1$ interface as the west interface in RING1.
Bridge1(g8032-ring-config)#g8032 profile profile1	Create a G.8032 profile named profile1.
Bridge1(g8032-profile-config)#timer wait- to-restore 1	Configure the wait-to-restore timer for 1 minute.
Bridge1(g8032-profile-config)#timer hold- off 0	Configure the hold-off timer with a value of 0.
Bridge1(g8032-profile-config)#timer guard- timer 10	Configure the guard timer with a value of 10 milliseconds.
Bridge1(g8032-profile-config)#switching mode revertive	Configure the switching mode as revertive.
Bridge1(g8032-profile-config)#exit	Exit profile configure mode and return to the ring configure mode.
Bridge1(g8032-ring-config)#exit	Exit ring configure mode and return to the configure mode.
Bridge1(config)#g8032 erp-instance erp1	Create a G.8032 Ethernet Ring Protection (ERP) instance named erp1.
Bridge1(g8032-config-switch)#ring-type major-ring	Configure the ring type as a major ring.

Bridge1(g8032-config-switch)#ring RING1	Associate RING1 with the ERP instance erp1.
Bridge1(g8032-config-switch)#rpl role non- owner	Configure the node as a non-owner node in the ring.
Bridge1(g8032-config-switch)#g8032-profile profile1	Associate profile1 with erp1 instance.
Bridge1(g8032-config-switch)#aps-channel level 7	Configure the R-APS channel level as 7.
Bridge1(g8032-config-switch)#aps-channel vlan 200	Configure the APS channel VLAN as 200.
Bridge1(g8032-config-switch)#ring-id 1	Configure the ring ID as 1.
Bridge1(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge1(g8032-config-switch)#end	Exit G.8032 configure mode.

Bridge2#configure terminal	Enter configure mode.
Bridge2(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string.
Bridge2(config)#interface xe3	Enter interface mode xe3.
Bridge2(config-if)#dot1ad ethertype 0x88a8	Configure $xe6$ as a Layer 2 port with an Ethernet Type of $0x88a8$.
Bridge2(config-if)#interface xe3.1 switchport	Create a Layer 2 sub-interface $xe3.1$ within the physical interface $xe3$.
Bridge2(config-if)encapsulation dot1ad 200	Encapsulate the sub-interface with APS-channel VLAN ID 200.
Bridge2(config-if)encapsulation dot1ad 700	Encapsulate the sub-interface with data VLAN ID 700.
Bridge2(config-if)#exit	Exit interface mode xe6.
Bridge2(config)#interface xe8	Enter interface mode xe8.
Bridge2(config-if)#dot1ad ethertype 0x88a8	Configure $xe8$ as a Layer 2 port with an Ethernet Type of $0x88a8$.
Bridge2(config)#interface xe8.1 switchport	Create a Layer 2 sub-interface $x \in 8.1$ within the physical interface $x \in 8$.
Bridge2(config-if)encapsulation dotlad 200	Encapsulate the sub-interface with APS-channel VLAN ID 200.
Bridge2(config-if)encapsulation dot1ad 700	Encapsulate the sub-interface with data VLAN ID 700.
Bridge2(config-if)#exit	Exit interface mode xe8.
Bridge2(config)#bridge-domain 1	Enter bridge domain configure mode and configure bridge domain instance 1.
Bridge2(config-bridge-domain)#interface xe3.1	Attach the sub-interface ${\tt xe3.1}$ to the bridge domain instance.
Bridge2(config-bridge-domain)#interface xe8.1	Attach the sub-interface ${\tt xe8.1}$ to the bridge domain instance.
Bridge2(config-bridge-domain)#exit	Exit bridge domain mode.

Bridge2(config)#ethernet cfm domain-type character-string domain-name P542 level 5	Create a CFM domain with character string type, name P542, and level 5.
Bridge2(config-ether-cfm)#service ma-type string ma-name ma542	Create a CFM Maintenance Association (MA) type as a string with the name ma542.
Bridge2(config-ether-cfm-ma)#vlan 200	Add VLAN 200 to the CFM MA.
Bridge2(config-ether-cfm-ma)#ethernet cfm mep down mpid 452 active true xe8.1	Create a down MEP 452 for xe8.1 interface and activate it.
Bridge2(config-ether-cfm-ma-mep)#cc multicast state enable	Enable Continuity Check (CC) multicast for the MEP.
Bridge2(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridge2(config-ether-cfm-ma)#mep crosscheck mpid 542	Configure crosscheck for the remote MEP with value 542.
Bridge2(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridge2(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge2(config)#ethernet cfm domain-type character-string domain-name P432 level 5	Create a CFM domain with character string type, name P432, and level 5.
Bridge2(config-ether-cfm)#service ma-type string ma-name ma432	Create a CFM MA type as a string with the name $ma432$.
Bridge2(config-ether-cfm-ma)#vlan 200	Add VLAN 200 to the CFM MA.
Bridge2(config-ether-cfm-ma)#ethernet cfm mep down mpid 432 active true xe3.1	Create a down MEP 432 for xe3.1 interface and activate it.
Bridge2(config-ether-cfm-ma-mep)#cc multicast state enable	Enables CC multicast for the MEP.
Bridge2(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridge2(config-ether-cfm-ma)#mep crosscheck mpid 532	Configure crosscheck for the remote MEP with value 532.
Bridge2(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridge2(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge2(config)#g8032 ring RING1	Create a G.8032 ring named RING1.
Bridge2(g8032-ring-config)#east-interface xe3.1	Associate $xe3.1$ interface as the east interface in RING1.
Bridge2(g8032-ring-config)#west-interface xe8.1	Associate xe8.1 interface as the west interface in RING1.

Bridge2(g8032-ring-config)#g8032 profile profile1	Create a G.8032 profile named profile1.
Bridge2(g8032-profile-config)#timer wait- to-restore 1	Configure the wait-to-restore timer for 1 minute.
Bridge2(g8032-profile-config)#timer hold- off 0	Configure the hold-off timer with a value of 0.
Bridge2(g8032-profile-config)#timer guard- timer 10	Configure the guard timer with a value of 10 milliseconds.
Bridge2(g8032-profile-config)#switching mode revertive	Configure the switching mode as revertive.
Bridge2(g8032-profile-config)#exit	Exit profile configure mode and return to the ring configure mode.
Bridge2(g8032-ring-config)#exit	Exit ring configure mode and return to the configure mode.
Bridge2(config)#g8032 erp-instance erp1	Create a G.8032 Ethernet Ring Protection (ERP) instance named erp1.
Bridge2(g8032-config-switch)#ring-type major-ring	Configure the ring type as a major ring.
Bridge2(g8032-config-switch)#ring RING1	Associate RING1 with the ERP instance erp1.
Bridge2(g8032-config-switch)#rpl role non- owner	Configure the node as a non-owner node in the ring.
Bridge2(g8032-config-switch)#g8032-profile profile1	Associate profile1 with erp1 instance.
Bridge2(g8032-config-switch)#aps-channel level 7	Configure the R-APS channel level as 7.
Bridge2(g8032-config-switch)#aps-channel vlan 200	Configure the APS channel VLAN as 200.
Bridge2(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge2(g8032-config-switch)#end	Exit G.8032 configure mode.

Bridge3#configure terminal	Enter configure mode.
Bridge3(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string.
Bridge3(config)#interface xe3	Enter interface mode xe3.
Bridge3(config-if)#dot1ad ethertype 0x88a8	Configure xe6 as a Layer 2 port with an Ethernet Type of 0x88a8.
Bridge3(config-if)#interface xe3.1 switchport	Create a Layer 2 sub-interface $xe3.1$ within the physical interface $xe3$.
Bridge3(config-if)encapsulation dot1ad 200	Encapsulate the sub-interface with APS-channel VLAN ID 200.
Bridge3(config-if)encapsulation dot1ad 700	Encapsulate the sub-interface with data VLAN ID 700.
Bridge3(config-if)#exit	Exit interface mode xe3.
Bridge3(config)#interface xel6	Enter interface mode xe8.
Bridge3(config-if)#dot1ad ethertype 0x88a8	Configure xe16 as a Layer 2 port with an Ethernet Type of 0x88a8.

Bridge3(config)#interface xel6.1 switchport	Create a Layer 2 sub-interface $xel6.1$ within the physical interface $xel6$.
Bridge3(config-if)encapsulation dot1ad 200	Encapsulate the sub-interface with APS-channel VLAN ID 200.
Bridge3(config-if)encapsulation dot1ad 700	Encapsulate the sub-interface with data VLAN ID 700.
Bridge3(config-if)#exit	Exit interface mode xe16.
Bridge3(config)#bridge-domain 1	Enter bridge domain configure mode and configure bridge domain instance 1.
Bridge3(config-bridge-domain)#interface xe3.1	Attach the sub-interface ${\tt xe3.1}$ to the bridge domain instance.
Bridge3(config-bridge-domain)#interface xe16.1	Attach the sub-interface $x e 16.1$ to the bridge domain instance.
Bridge3(config-bridge-domain)#exit	Exit bridge domain mode.
Bridge3(config)#ethernet cfm domain-type character-string domain-name P542 level 5	Create a CFM domain with character string type, name $P542$, and level 5.
Bridge3(config-ether-cfm)#service ma-type string ma-name ma542	Create a CFM Maintenance Association (MA) type as a string with the name ma542.
Bridge3(config-ether-cfm-ma)#vlan 200	Add VLAN 200 to the CFM MA.
Bridge3(config-ether-cfm-ma)#ethernet cfm mep down mpid 452 active true xe16.1	Create a down MEP 452 for xe16.1 interface and activate it.
Bridge3(config-ether-cfm-ma-mep)#cc multicast state enable	Enable Continuity Check (CC) multicast for the MEP.
Bridge3(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridge3(config-ether-cfm-ma)#mep crosscheck mpid 542	Configure crosscheck for the remote MEP with value 542.
Bridge3(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridge3(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge3(config)#ethernet cfm domain-type character-string domain-name P432 level 5	Create a CFM domain with character string type, name P432, and level 5.
Bridge3(config-ether-cfm)#service ma-type string ma-name ma432	Create a CFM MA type as a string with the name $ma432$.
Bridge3(config-ether-cfm-ma)#vlan 200	Add VLAN 200 to the CFM MA.
Bridge3(config-ether-cfm-ma)#ethernet cfm mep down mpid 342 active true xe3.1	Create a down MEP 342 for $xe3.1$ interface and activate it.
Bridge3(config-ether-cfm-ma-mep)#cc multicast state enable	Enables CC multicast for the MEP.

Bridge3(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridge3(config-ether-cfm-ma)#mep crosscheck mpid 432	Configure crosscheck for the remote MEP with value 432.
Bridge3(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridge3(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge3(config)#g8032 ring RING1	Create a G.8032 ring named RING1.
Bridge3(g8032-ring-config)#east-interface xe16.1	Associate xe16.1 interface as the east interface in RING1.
Bridge3(g8032-ring-config)#west-interface xe3.1	Associate xe3.1 interface as the west interface in RING1.
Bridge3(g8032-ring-config)#g8032 profile profile1	Create a G.8032 profile named profile1.
Bridge3(g8032-profile-config)#timer wait- to-restore 1	Configure the wait-to-restore timer for 1 minute.
Bridge3(g8032-profile-config)#timer hold- off 0	Configure the hold-off timer with a value of 0.
Bridge3(g8032-profile-config)#timer guard- timer 10	Configure the guard timer with a value of 10 milliseconds.
Bridge3(g8032-profile-config)#switching mode revertive	Configure the switching mode as revertive.
Bridge3(g8032-profile-config)#exit	Exit profile configure mode and return to the ring configure mode.
Bridge3(g8032-ring-config)#exit	Exit ring configure mode and return to the configure mode.
Bridge3(config)#g8032 erp-instance erp1	Create a G.8032 Ethernet Ring Protection (ERP) instance named erp1.
Bridge3(g8032-config-switch)#ring-type major-ring	Configure the ring type as a major ring.
Bridge3(g8032-config-switch)#ring RING1	Associate RING1 with the ERP instance erp1.
Bridge3(g8032-config-switch)#rpl role neighbor east-interface	Configure the node as the neighbor node for the ERPS ring and designate the east interface as the owner node in the ring.
Bridge3(g8032-config-switch)#g8032-profile profile1	Associate profile1 with erp1 instance.
Bridge3(g8032-config-switch)#aps-channel level 7	Configure the R-APS channel level as 7.
Bridge3(g8032-config-switch)#aps-channel vlan 200	Configure the APS channel VLAN as 200.
Bridge3(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge3(g8032-config-switch)#end	Exit G.8032 configure mode.

Bridge4#configure terminal	Enter configure mode.
Bridge4(config)#hardware-profile filter cfm-domain-name-str enable	Enable CFM domain name as string.
Bridge4(config)#interface xe6	Enter interface mode xe6.
Bridge4(config-if)#dot1ad ethertype 0x88a8	Configure xe6 as a Layer 2 port with an Ethernet Type of 0x88a8.
Bridge4(config-if)#interface xe6.1 switchport	Create a Layer 2 sub-interface $xe6.1$ within the physical interface $xe6$.
Bridge4(config-if)encapsulation dot1ad 200	Encapsulate the sub-interface with APS-channel VLAN ID 200.
Bridge4(config-if)encapsulation dot1ad 700	Encapsulate the sub-interface with data VLAN ID 700.
Bridge4(config-if)#exit	Exit interface mode xe6.
Bridge4(config)#interface xel6	Enter interface mode xe8.
Bridge4(config-if)#dot1ad ethertype 0x88a8	Configure xe16 as a Layer 2 port with an Ethernet Type of 0x88a8.
Bridge4(config)#interface xel6.1 switchport	Create a Layer 2 sub-interface $xel6.1$ within the physical interface $xel6$.
Bridge4(config-if)encapsulation dot1ad 200	Encapsulate the sub-interface with APS-channel VLAN ID 200.
Bridge4(config-if)encapsulation dot1ad 700	Encapsulate the sub-interface with data VLAN ID 700.
Bridge4(config-if)#exit	Exit interface mode xe16.
Bridge4(config)#bridge-domain 1	Enter bridge domain configure mode and configure bridge domain instance 1.
Bridge4(config-bridge-domain)#interface xe6.1	Attach the sub-interface ${\tt xe6.1}$ to the bridge domain instance.
Bridge4(config-bridge-domain)#interface xel6.1	Attach the sub-interface $xel6.1$ to the bridge domain instance.
Bridge4(config-bridge-domain)#exit	Exit bridge domain mode.
Bridge4(config)#ethernet cfm domain-type character-string domain-name P522 level 5	Create a CFM domain with character string type, name P522, and level 5.
Bridge4(config-ether-cfm)#service ma-type string ma-name ma522	Create a CFM Maintenance Association (MA) type as a string with the name ma522.
Bridge4(config-ether-cfm-ma)#vlan 200	Add VLAN 200 to the CFM MA.
Bridge4(config-ether-cfm-ma)#ethernet cfm mep down mpid 452 active true xel6.1	Create a down MEP 452 for xe16.1 interface and activate it.
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enable Continuity Check (CC) multicast for the MEP.
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.

Bridge4(config-ether-cfm-ma)#mep crosscheck mpid 542	Configure crosscheck for the remote MEP with value 542.
Bridge4(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridge4(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge4(config)#ethernet cfm domain-type character-string domain-name P522 level 5	Create a CFM domain with character string type, name P522, and level 5.
Bridge4(config-ether-cfm)#service ma-type string ma-name ma522	Create a CFM MA type as a string with the name $ma522$.
Bridge4(config-ether-cfm-ma)#vlan 200	Add VLAN 200 to the CFM MA.
Bridge4(config-ether-cfm-ma)#ethernet cfm mep down mpid 252 active true xe6.1	Create a down MEP 252 for xe6.1 interface and activate it.
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enables CC multicast for the MEP.
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridge4(config-ether-cfm-ma)#mep crosscheck mpid 522	Configure crosscheck for the remote MEP with value 522.
Bridge4(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridge4(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge4(config)#g8032 ring RING1	Create a G.8032 ring named RING1.
Bridge4(g8032-ring-config)#east-interface xe6.1	Associate $x \in 6.1$ interface as the east interface in RING1.
Bridge4(g8032-ring-config)#west-interface xe16.1	Associate xe16.1 interface as the west interface in RING1.
Bridge4(g8032-ring-config)#g8032 profile profile1	Create a G.8032 profile named profile1.
Bridge4(g8032-profile-config)#timer wait- to-restore 1	Configure the wait-to-restore timer for 1 minute.
Bridge4(g8032-profile-config)#timer hold- off 0	Configure the hold-off timer with a value of 0.
Bridge4(g8032-profile-config)#timer guard- timer 10	Configure the guard timer with a value of 10 milliseconds.
Bridge4(g8032-profile-config)#switching mode revertive	Configure the switching mode as revertive.
Bridge4(g8032-profile-config)#exit	Exit profile configure mode and return to the ring configure mode.
Bridge4(g8032-ring-config)#exit	Exit ring configure mode and return to the configure mode.
Bridge4(config)#g8032 erp-instance erp1	Create a G.8032 Ethernet Ring Protection (ERP) instance named erp1.
Bridge4(g8032-config-switch)#ring-type major-ring	Configure the ring type as a major ring.

Bridge4(g8032-config-switch)#ring RING1	Associate RING1 with the ERP instance erp1.
Bridge4(g8032-config-switch)#rpl role owner west-interface	Configure the node as the owner node for the ERPS ring and designate the west interface as the neighbor node in the ring.
Bridge4(g8032-config-switch)#g8032-profile profile1	Associate profile1 with erp1 instance.
Bridge4(g8032-config-switch)#aps-channel level 7	Configure the R-APS channel level as 7.
Bridge4(g8032-config-switch)#aps-channel vlan 200	Configure the APS channel VLAN as 200.
Bridge4(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge4(g8032-config-switch)#end	Exit G.8032 configure mode.

Validation

The following details provide validation for the G.8032 ERPS configuration on Bridge1, Bridge2, Bridge3, and Bridge4.

Bridge1

Bridge1#show g80)32 e	rp-instance	Fact	atata	West	atata	Ding
	10	State	Last	State	west	State	KING
erp1	1	IDLE	xe8.1	Unblock	ed xe6.1	Unblo	cked ring1
Bridgel#show g80)32 e	rp-instance	data-traffic				
Instance	ID	Data-vlan		East	West		Ring
erpl	1	bridge_doma	in 1	xe8.100	(F) xe6.1	(F)	ringl
Bridgel#show g8032 erp-instance erp1Inst Name: erp1 (1), node-id e8:c5:7a:a8:7c:b6, Profile (1)Description:Ring: MAJOR-RING (ring1), NON-OWNER, Attached (erp3,),tcn_propagation (0)							
State	: G8	032_ST_IDLE					
East West	: xe8.1, Unblocked, UP , BPR (-), remote (-) : xe6.1, Unblocked, UP , BPR (0), remote (b8:6a:97:25:a7:d4)						
East (cfm) West (cfm)	: mep_id (542), cc-interval (1s), Domain (P5P42), MA (ma542) : mep_id (522), cc-interval (1s), Domain (P5P22), MA (ma522)						
Channel	: Le	vel (5), vla	n (200), RING_	ID (1)			
Bridge2							

Bridge2#show g8032 erp-instance

Instance	ID	State	East	state	West	state	Ring
erpl	1	IDLE	xe3.1	Unblocked	xe8.1	Unblocked	ring1
Bridge2#show g80 Inst Name Description Ring	32 en : erp : : MAJ	rp-instance e ol (1), node- JOR-RING (rir	erpl -id e4:9d:73:bl ngl), NON-OWNER	L:c3:05, P: R,	rofile (1)		
State	: G80)32_ST_IDLE					
East West	: xe3 : xe8	3.1, Unblocke 3.1, Unblocke	ed, UP , BPR ed, UP , BPR	(-), remote (0), remote	e (-) e (b8:6a:97:25:	:a7:d4)	

East	(cfm)	:	mep_id	(432),	cc-interval	(1s),	Domain	(P4P32),	MA	(ma432)
West	(cfm)	:	mep_{id}	(452),	cc-interval	(1s),	Domain	(P5P42),	MA	(ma542)

Channel : Level (5), vlan (200), RING_ID (1)

Bridge2#show g8032 erp-instance data-traffic

Instance	ID	Data-vlan	East	West	Ring
erpl	1	bridge_domain 1	xe3.1 (F)	xe8.1 (F)	ringl

Bridge3

Bridge3#show	g8032	erp-instance	erp1
--------------	-------	--------------	------

Inst Name	: erpl (1), node-id 00:e0:4b:71:f1:26, Profile (1)
Description	:
Ring	: MAJOR-RING (ring1), NEIGHBOR (EAST),
State	: G8032_ST_IDLE
East	: xe16.1, Blocked , UP , BPR (0), remote (b8:6a:97:25:a7:d4)
West	: xe3.1, Unblocked, UP , BPR (0), remote (b8:6a:97:25:a7:d4)
East (cfm)	: mep_id (322), cc-interval (1s), Domain (P3P22), MA (ma322)
West (cfm)	: mep_id (342), cc-interval (1s), Domain (P4P32), MA (ma432)
Channel	: Level (5), vlan (200), RING ID (1)

Bridge3#show g8032 erp-instance

Instance	ID	State	East	state	West	state	Ring
erpl	1	IDLE	xe16.1 (N)	Blocked	xe3.1	Unblocked	 ring1

Bridge3#show g8032 erp-instance data-traffic

Instance	ID	Data-vlan	East	West	Ring
ern1	1	bridge domain 1	vel6 1 (B)	ve3 1 (F)	
erbr	+	bridge_domain i	VETO'T (D)	X63.1 (1)	TTUGT

Bridge4

Bridge4#show g80	32 e	rp-instance					
Instance	ID	State	East	state	West	state	e Ring
erp1	1	IDLE	xe6.1	Unblocked	xe16.1 (C)) Blocke	d ring1
Bridge4#show g80	32 e	rp-instance e	erp1				
Inst Name Description Ring	: erg : : MA. Att	pl (1), node- JOR-RING (rin tached (erp3,	-id b8:6a:97:2 ngl), OWNER (W .),tcn_propaga	5:a7:d4, F MEST), Mtion (0)	Profile (1	.)	
State	: G80	032_ST_IDLE					
East West	: xe : xe	6.1, Unblocke 16.1, Blocked	ed, UP , BPR d , UP , BPF	(-), remot (-), remo	te (-) te (-)		
East (cfm) West (cfm) Channel	ast (cfm) : mep_id (252), cc-interval (1s), Domain (P5P22), MA (ma522) est (cfm) : mep_id (223), cc-interval (1s), Domain (P3P22), MA (ma322)						
0.101.1101	• 20	.01 (0), 110	. (200),	(1)			
Bridge4#show g80 Instance	32 e: ID	rp-instance d Data-vlan	lata-traffic	East	Wes	st	Ring
erp1	1	bridge_domai	in 1	xe6.1 (F)	xe16	5.1 (B)	ringl

Associate Ring Configuration

The associate-ring is a newly introduced command for supporting ERPS within a bridge-domain. This command is used when there is a need to establish a single ERPS instance that can manage multiple rings. It is essential that all

rings associated with the associate-ring share the same parent interface as the primary ring linked to the ERPS instance. For more details, refer to the associate-ring command section.

Prerequisite

Before using the associate-ring command, it is necessary to configure the major ring for Bridge1, Bridge2, Bridge3, and Bridge4 as described in the Major Ring Configuration section.

Bridgel#configure terminal	Enter configure mode.				
Bridge1(config)#interface xe6.2 switchport	Create a Layer 2 sub-interface ${\tt xe6.2}$ for the physical interface ${\tt xe6}.$				
Bridge1(config-if)encapsulation dot1ad 2003	Encapsulate the sub-interface with APS-channel VLAN ID 2003.				
Bridgel(config-if)encapsulation dotlad 800	Encapsulate the sub-interface with data VLAN ID 800.				
Bridge1(config-if)#exit	Exit interface mode xe6.2.				
<pre>Bridge1(config)#interface xe8.2 switchport</pre>	Create a Layer 2 sub-interface $x \in 8$. 2 for the physical interface $x \in 8$.				
Bridge1(config-if)encapsulation dot1ad 2003	Encapsulate the sub-interface with APS-channel VLAN ID 2003.				
Bridge1(config-if)encapsulation dot1ad 800	Encapsulate the sub-interface with data VLAN ID 800.				
Bridgel(config-if)#exit	Exit interface mode xe8.2.				
Bridge1(config)#bridge-domain 2	Enter bridge domain configure mode and configure bridge domain instance 2.				
Bridge1(config-bridge-domain)#interface xe6.2	Attach the sub-interface $x \in 6.2$ to the bridge domain instance.				
Bridge1(config-bridge-domain)#interface xe8.2	Attach the sub-interface $x \! \in \! 8$. 2 to the bridge domain instance.				
Bridgel(config-bridge-domain)#exit	Exit bridge domain mode.				
Bridgel(config)#ethernet cfm domain-type character-string domain-name P543 level 5	Create a CFM domain with character string type, name P543, and level 5.				
Bridgel(config-ether-cfm)#service ma-type string ma-name ma543	Create a CFM Maintenance Association (MA) type as a string with the name ma543.				
Bridge1(config-ether-cfm-ma)#vlan 2003	Add VLAN 2003 to the CFM MA.				
Bridge1(config-ether-cfm-ma)#ethernet cfm mep down mpid 543 active true xe8.2	Create a down MEP 543 for ${\tt xe8.2}$ interface and activate it.				
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable Continuity Check (CC) multicast for the MEP.				
Bridge1(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.				
Bridgel(config-ether-cfm-ma)#mep crosscheck mpid 453	Configure crosscheck for the remote MEP with value 453.				

Bridge1(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridgel(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridgel(config)#ethernet cfm domain-type character-string domain-name P523 level 5	Create a CFM domain with character string type, name P523, and level 5.
Bridgel(config-ether-cfm)#service ma-type string ma-name ma523	Create a CFM MA type as a string with the name ma523.
Bridge1(config-ether-cfm-ma)#vlan 2003	Add VLAN 2003 to the CFM MA.
Bridge1(config-ether-cfm-ma)#ethernet cfm mep down mpid 523 active true xe6.2	Create a down MEP 523 for $\tt xe6.2$ interface and activate it.
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enables CC multicast for the MEP.
Bridgel(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridge1(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridgel(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge1(config)#g8032 ring RING2	Create a G.8032 ring named RING2.
Bridge1(g8032-ring-config)#east-interface xe8.2	Associate $xe8.2$ interface as the east interface in RING2.
Bridge1(g8032-ring-config)#west-interface xe6.2	Associate xe6.2 interface as the west interface in RING2.
Bridge1(g8032-ring-config)#exit	Exit ring configure mode and return to the configure mode.
Bridge1(config)#g8032 erp-instance erp1	Create a G.8032 Ethernet Ring Protection (ERP) instance named erp1.
Bridge1(g8032-config-switch)#associate- ring RING2	Map the associate ring named RING2 to the ERPS instance erp1.
Bridge1(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge1(g8032-config-switch)#end	Exit G.8032 configure mode.

Bridge2#configure terminal	Enter configure mode.
Bridge2(config)#interface xe3.2 switchport	Create a Layer 2 sub-interface ${\tt xe3.2}$ for the physical interface ${\tt xe3}.$
Bridge2(config-if)encapsulation dot1ad 2003	Encapsulate the sub-interface with APS-channel VLAN ID 2003.
Bridge2(config-if)encapsulation dotlad 800	Encapsulate the sub-interface with data VLAN ID 800.
Bridge2(config-if)#exit	Exit interface mode xe3.2.
Bridge2(config)#interface xe8.2 switchport	Create a Layer 2 sub-interface $x \in 8 \cdot 2$ for the physical interface $x \in 8$.

Bridge2(config-if)encapsulation dot1ad 2003	Encapsulate the sub-interface with APS-channel VLAN ID 2003.
Bridge2(config-if)encapsulation dot1ad 800	Encapsulate the sub-interface with data VLAN ID 800.
Bridge2(config-if)#exit	Exit interface mode xe8.2.
Bridge2(config)#bridge-domain 2	Enter bridge domain configure mode and configure bridge domain instance 2.
Bridge2(config-bridge-domain)#interface xe3.2	Attach the sub-interface ${\tt xe3.2}$ to the bridge domain instance.
Bridge2(config-bridge-domain)#interface xe8.2	Attach the sub-interface $x\!\in\!8$, 2 to the bridge domain instance.
Bridge2(config-bridge-domain)#exit	Exit bridge domain mode.
Bridge2(config)#ethernet cfm domain-type character-string domain-name P543 level 5	Create a CFM domain with character string type, name $P543$, and level 5.
Bridge2(config-ether-cfm)#service ma-type string ma-name ma543	Create a CFM Maintenance Association (MA) type as a string with the name ma543.
Bridge2(config-ether-cfm-ma)#vlan 2003	Add VLAN 2003 to the CFM MA.
Bridge2(config-ether-cfm-ma)#ethernet cfm mep down mpid 453 active true xe8.2	Create a down MEP 453 for xe8.2 interface and activate it.
Bridge2(config-ether-cfm-ma-mep)#cc multicast state enable	Enable Continuity Check (CC) multicast for the MEP.
Bridge2(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridge2(config-ether-cfm-ma)#mep crosscheck mpid 543	Configure crosscheck for the remote MEP with value 543.
Bridge2(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridge2(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge2(config)#ethernet cfm domain-type character-string domain-name P433 level 5	Create a CFM domain with character string type, name P433, and level 5.
Bridge2(config-ether-cfm)#service ma-type string ma-name ma433	Create a CFM MA type as a string with the name $ma433$.
Bridge2(config-ether-cfm-ma)#vlan 2003	Add VLAN 2003 to the CFM MA.
Bridge2(config-ether-cfm-ma)#ethernet cfm mep down mpid 433 active true xe3.2	Create a down MEP 433 for ${\tt xe3.2}$ interface and activate it.
Bridge2(config-ether-cfm-ma-mep)#cc multicast state enable	Enables CC multicast for the MEP.
Bridge2(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.

Bridge2(config-ether-cfm-ma)#mep crosscheck mpid 533	Configure crosscheck for the remote MEP with value 533.
Bridge2(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridge2(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge2(config)#g8032 ring RING2	Create a G.8032 ring named RING2.
Bridge2(g8032-ring-config)#east-interface xe3.2	Associate $xe3.2$ interface as the east interface in RING2.
Bridge2(g8032-ring-config)#west-interface xe8.2	Associate xe8.2 interface as the west interface in RING2.
Bridge2(g8032-ring-config)#exit	Exit ring configure mode and return to the configure mode.
Bridge2(config)#g8032 erp-instance erp1	Create a G.8032 Ethernet Ring Protection (ERP) instance named erp1.
Bridge2(g8032-config-switch)#associate- ring RING2	Map the associate ring named RING2 to the ERPS instance erp1.
Bridge2(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge2(g8032-config-switch)#end	Exit G.8032 configure mode.

Bridge3#configure terminal	Enter configure mode.
Bridge3(config)#interface xe3.2 switchport	Create a Layer 2 sub-interface $xe3.2$ for the physical interface $xe3$.
Bridge3(config-if)encapsulation dotlad 2003	Encapsulate the sub-interface with APS-channel VLAN ID 2003.
Bridge3(config-if)encapsulation dot1ad 800	Encapsulate the sub-interface with data VLAN ID 800.
Bridge3(config-if)#exit	Exit interface mode xe3.2.
Bridge3(config)#interface xel6.2 switchport	Create a Layer 2 sub-interface $xel6.2$ for the physical interface $xel6$.
Bridge3(config-if)encapsulation dotlad 2003	Encapsulate the sub-interface with APS-channel VLAN ID 2003.
Bridge3(config-if)encapsulation dot1ad 800	Encapsulate the sub-interface with data VLAN ID 800.
Bridge3(config-if)#exit	Exit interface mode xe16.2.
Bridge3(config)#bridge-domain 2	Enter bridge domain configure mode and configure bridge domain instance 2.
Bridge3(config-bridge-domain)#interface xe3.2	Attach the sub-interface ${\tt xe3.2}$ to the bridge domain instance.
Bridge3(config-bridge-domain)#interface xel6.2	Attach the sub-interface $xe16.2$ to the bridge domain instance.
Bridge3(config-bridge-domain)#exit	Exit bridge domain mode.
Bridge3(config)#ethernet cfm domain-type character-string domain-name P433 level 5	Create a CFM domain with character string type, name P433, and level 5.

Bridge3(config-ether-cfm)#service ma-type string ma-name ma433	Create a CFM Maintenance Association (MA) type as a string with the name ma433.
Bridge3(config-ether-cfm-ma)#vlan 2003	Add VLAN 2003 to the CFM MA.
Bridge3(config-ether-cfm-ma)#ethernet cfm mep down mpid 343 active true xel6.2	Create a down MEP 343 for xe16.2 interface and activate it.
Bridge3(config-ether-cfm-ma-mep)#cc multicast state enable	Enable Continuity Check (CC) multicast for the MEP.
Bridge3(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridge3(config-ether-cfm-ma)#mep crosscheck mpid 433	Configure crosscheck for the remote MEP with value 433.
Bridge3(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridge3(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge3(config)#ethernet cfm domain-type character-string domain-name P323 level 5	Create a CFM domain with character string type, name P323, and level 5.
Bridge3(config-ether-cfm)#service ma-type string ma-name ma323	Create a CFM MA type as a string with the name ma323.
Bridge3(config-ether-cfm-ma)#vlan 2003	Add VLAN 2003 to the CFM MA.
Bridge3(config-ether-cfm-ma)#ethernet cfm mep down mpid 323 active true xe3.2	Create a down MEP 323 for ${\tt xe3.2}$ interface and activate it.
Bridge3(config-ether-cfm-ma-mep)#cc multicast state enable	Enables CC multicast for the MEP.
Bridge3(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridge3(config-ether-cfm-ma)#mep crosscheck mpid 233	Configure crosscheck for the remote MEP with value 233.
Bridge3(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridge3(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge3(config)#g8032 ring RING2	Create a G.8032 ring named RING2.
Bridge3(g8032-ring-config)#east-interface xe16.2	Associate xe16.2 interface as the east interface in RING2.
Bridge3(g8032-ring-config)#west-interface xe3.2	Associate $xe3.2$ interface as the west interface in RING2.
Bridge3(g8032-ring-config)#exit	Exit ring configure mode and return to the configure mode.
Bridge3(config)#g8032 erp-instance erp1	Create a G.8032 Ethernet Ring Protection (ERP) instance named erp1.

Bridge3(g8032-config-switch)#associate- ring RING2	Map the associate ring named RING2 to the ERPS instance erp1.
Bridge3(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge3(g8032-config-switch)#end	Exit G.8032 configure mode.

Bridge4#configure terminal	Enter configure mode.	
Bridge4(config)#interface xe6.2 switchport	Create a Layer 2 sub-interface $x \in 6.2$ for the physical interface $x \in 6$.	
Bridge4(config-if)encapsulation dotlad 2003	Encapsulate the sub-interface with APS-channel VLAN ID 2003.	
Bridge4(config-if)encapsulation dot1ad 800	Encapsulate the sub-interface with data VLAN ID 800.	
Bridge4(config-if)#exit	Exit interface mode xe6.2.	
Bridge4(config)#interface xe16.2 switchport	Create a Layer 2 sub-interface $xe16.2$ for the physical interface $xe16$.	
Bridge4(config-if)encapsulation dotlad 2003	Encapsulate the sub-interface with APS-channel VLAN ID 2003.	
Bridge4(config-if)encapsulation dot1ad 800	Encapsulate the sub-interface with data VLAN ID 800.	
Bridge4(config-if)#exit	Exit interface mode xe16.2.	
Bridge4(config)#bridge-domain 2	Enter bridge domain configure mode and configure bridge domain instance 2.	
Bridge4(config-bridge-domain)#interface xe6.2	Attach the sub-interface $x \in 6$, 2 to the bridge domain instance.	
Bridge4(config-bridge-domain)#interface xel6.2	Attach the sub-interface $x e 16.2$ to the bridge domain instance.	
Bridge4(config-bridge-domain)#exit	Exit bridge domain mode.	
Bridge4(config)#ethernet cfm domain-type character-string domain-name P523 level 5	Create a CFM domain with character string type, name P523, and level 5.	
Bridge4(config-ether-cfm)#service ma-type string ma-name ma523	Create a CFM Maintenance Association (MA) type as a string with the name ma523.	
Bridge4(config-ether-cfm-ma)#vlan 2003	Add VLAN 2003 to the CFM MA.	
Bridge4(config-ether-cfm-ma)#ethernet cfm mep down mpid 253 active true xe6.2	Create a down MEP 253 for xe6.2 interface and activate it.	
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enable Continuity Check (CC) multicast for the MEP.	
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.	
Bridge4(config-ether-cfm-ma)#mep crosscheck mpid 523	Configure crosscheck for the remote MEP with value 523.	

Bridge4(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.		
Bridge4(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.		
Bridge4(config)#ethernet cfm domain-type character-string domain-name P323 level 5	Create a CFM domain with character string type, name P323, and level 5.		
Bridge4(config-ether-cfm)#service ma-type string ma-name ma323	Create a CFM MA type as a string with the name ma323.		
Bridge4(config-ether-cfm-ma)#vlan 2003	Add VLAN 2003 to the CFM MA.		
Bridge4(config-ether-cfm-ma)#ethernet cfm mep down mpid 233 active true xel6.2	Create a down MEP 233 for $\texttt{xe16.2}$ interface and activate it.		
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enables CC multicast for the MEP.		
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.		
Bridge4(config-ether-cfm-ma)#mep crosscheck mpid 323	Configure crosscheck for the remote MEP with value 323.		
Bridge4(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.		
Bridge4(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.		
Bridge4(config)#g8032 ring RING2	Create a G.8032 ring named RING2.		
Bridge4(g8032-ring-config)#east-interface xe6.2	Associate $xe6.2$ interface as the east interface in RING2.		
Bridge4(g8032-ring-config)#west-interface xe16.2	Associate xe16.2 interface as the west interface in RING2.		
Bridge4(g8032-ring-config)#exit	Exit ring configure mode and return to the configure mode.		
Bridge4(config)#g8032 erp-instance erp1	Create a G.8032 Ethernet Ring Protection (ERP) instance named erp1.		
Bridge4 (g8032-config-switch) #associate- ring RING2	Map the associate ring named RING2 to the ERPS instance erp1.		
Bridge4(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration		
Bridge4(g8032-config-switch)#end	Exit G.8032 configure mode.		

Validation

The following validation output displays data traffic details for ERP instances and provides details for the specified ERP instance using the show g8032 erp-instance data-traffic command on Bridge1, Bridge2, Bridge3, and Bridge4.

Bridgel#show g8032 erp-instance data-traffic

Instance	ID	Data-vlan	East	West	Ring
erpl	1	bridge_domain 1 bridge_domain 2	xe8.1 (F) xe8.2	xe25.1 (F) xe25.2	ring1 ring2

Bridge2#show g80)32 e	rp-instance data-traffic			
Instance	ID	Data-vlan	East	West	Ring
erpl	1	bridge_domain 1 bridge_domain 2	xe3.1 (F) xe3.2	xe82.1 (F) xe8.2	ring1 ring2
Bridge3#show g80)32 e	rp-instance data-traffic			
Instance	ID	Data-vlan	East	West	Ring
erpl	1	bridge_domain 1	xe16.1 (B)	xe3.1 (F)	ringl
		bridge_domain 2	xe16.2	xe3.2	ring2
Bridge4#show g80)32 e	rp-instance data-traffic			
Instance	ID	Data-vlan	East	West	Ring
erpl	1	bridge_domain 1	xe16.1 (F)	xe16.1 (B)	ringl
		bridge_domain 2	xe16.2	xe6.2	ring2

Sub-ring with Virtual Channel Configuration

An Ethernet ring connects to a Major Ring at the interconnection nodes. The Sub-Ring, by itself, does not constitute a closed ring. It connects to the interconnection nodes on only one port, which is configured as the east-interface.

Topology

Figure 12-25 displays a sample Ring Protection topology with five bridges, consisting of one major ring (Bridge1, Bridge2, Bridge3, and Bridge4) and one sub-ring (Bridge5, Bridge1, and Bridge2). In the major ring, the RPL is enabled between Bridge 3 (owner node) and Bridge 4 (neighbor node) on the xe16 interface, while other devices are non-owner nodes for that ring. In the sub-ring, the RPL is enabled between Bridge 5 (neighbor node) and Bridge 4 (owner node) on link xe7, with other devices as non-owner nodes. A virtual channel is enabled for this Sub-Ring on interconnected nodes on VLAN 100, and TCN propagation is also enabled.



Figure 12-25: Sub-ring with Virtual Channel

Prerequisite

Before configuring the sub-ring with virtual channel, it is necessary to configure the major ring for Bridge1, Bridge2, Bridge3, and Bridge4 as described in the Major Ring Configuration section.

Bridge5#configure terminal	Enter configure mode.
Bridge5(config)#interface xe2	Enter interface mode xe2.
Bridge5(config-if)#dot1ad ethertype 0x88a8	Configure xe2 as a Layer 2 port with an Ethernet Type of 0x88a8.
Bridge5(config-if)#interface xe2.1 switchport	Create a Layer 2 sub-interface $xe2.1$ within the physical interface $xe2$.
Bridge5(config-if)encapsulation dot1ad 200	Encapsulate the sub-interface with APS-channel VLAN ID 200.
Bridge5(config-if)encapsulation dotlad 600	Encapsulate the sub-interface with data VLAN ID 600.
Bridge5(config-if)#exit	Exit interface mode xe2.
Bridge5(config)#interface xe20	Enter interface mode xe20.
Bridge5(config-if)#dot1ad ethertype 0x88a8	Configure $xe20$ as a Layer 2 port with an Ethernet Type of $0x88a8$.
Bridge5(config)#interface xe20.1 switchport	Create a Layer 2 sub-interface $xe20.1$ within the physical interface $xe20$.
Bridge5(config-if)encapsulation dot1ad 200	Encapsulate the sub-interface with APS-channel VLAN ID 200.
Bridge5(config-if)encapsulation dot1ad 600	Encapsulate the sub-interface with data VLAN ID 600.
Bridge5(config-if)#exit	Exit interface mode xe20.
Bridge5(config)#bridge-domain 1	Enter bridge domain configure mode and configure bridge domain instance 1.
Bridge5(config-bridge-domain)#interface xe2.1	Attach the sub-interface ${\tt xe2.1}$ to the bridge domain instance.
Bridge5(config-bridge-domain)#interface xe20.1	Attach the sub-interface $xe20.1$ to the bridge domain instance.
Bridge5(config-bridge-domain)#exit	Exit bridge domain mode.
Bridge5(config)#ethernet cfm domain-type character-string domain-name P271 level 5	Create a CFM domain with character string type, name P271, and level 5.
Bridge5(config-ether-cfm)#service ma-type string ma-name ma8	Create a CFM Maintenance Association (MA) type as a string with the name ma8.
Bridge5(config-ether-cfm-ma)#vlan 200	Add VLAN 200 to the CFM MA.
Bridge5(config-ether-cfm-ma)#ethernet cfm mep down mpid 801 active true xe2.1	Create a down MEP 801 for $xe2.1$ interface and activate it.
Bridge5(config-ether-cfm-ma-mep)#cc multicast state enable	Enable Continuity Check (CC) multicast for the MEP.

Bridge5(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridge5(config-ether-cfm-ma)#mep crosscheck mpid 800	Configure crosscheck for the remote MEP with value 800.
Bridge5(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridge5(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge5(config)#ethernet cfm domain-type character-string domain-name P571 level 5	Create a CFM domain with character string type, name P571, and level 5.
Bridge5(config-ether-cfm)#service ma-type string ma-name ma7	Create a CFM MA type as a string with the name ${\tt ma7}$.
Bridge5(config-ether-cfm-ma)#vlan 200	Add VLAN 200 to the CFM MA.
Bridge5(config-ether-cfm-ma)#ethernet cfm mep down mpid 905 active true xe20.1	Create a down MEP 905 for xe20.1 interface and activate it.
	Enables CC multicast for the MEP.
Bridge5(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridge5(config-ether-cfm-ma)#mep crosscheck mpid 906	Configure crosscheck for the remote MEP with value 906.
Bridge5(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridge5(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge5(config)#g8032 ring subring2	Create a G.8032 ring named subring2.
Bridge5(g8032-ring-config)#east-interface xe2.1	Associate xe2.1 interface as the east interface in subring2.
Bridge5(g8032-ring-config)#west-interface xe20.1	Associate xe20.1 interface as the west interface in subring2.
Bridge5(g8032-ring-config)#g8032 profile profile1	Create a G.8032 profile named profile1.
Bridge5(g8032-profile-config)#timer wait- to-restore 2	Configure the wait-to-restore timer for 2 minute.
Bridge5(g8032-profile-config)#timer hold- off 200	Configure the hold-off timer with a value of 200.
Bridge5(g8032-profile-config)#timer guard- timer 20	Configure the guard timer with a value of 20 milliseconds.
Bridge5(g8032-profile-config)#switching mode revertive	Configure the switching mode as revertive.
Bridge5(g8032-profile-config)#exit	Exit profile configure mode and return to the ring configure mode.
Bridge5(g8032-ring-config)#exit	Exit ring configure mode and return to the configure mode.

Bridge5(config)#g8032 erp-instance erp2	Create a G.8032 Ethernet Ring Protection (ERP) instance named erp2.
Bridge5(g8032-config-switch)#ring-type sub-ring-vc	Configure the ring type as a sub-ring-vc.
Bridge5(g8032-config-switch)#ring subring2	Associate subring2 with the ERP instance erp2.
Bridge5(g8032-config-switch)#rpl role neighbor east-interface	Configure the node as the neighbor node for the specified ERPS ring and designate the east interface as the owner node in the ring.
Bridge5(g8032-config-switch)#g8032-profile profile1	Associate profile1 with erp2 instance.
Bridge5(g8032-config-switch)#aps-channel level 5	Configure the R-APS channel level as 5.
Bridge5(g8032-config-switch)#aps-channel vlan 200	Configure the APS channel VLAN as 200.
Bridge5(g8032-config-switch)#ring-id 3	Configure the ring ID as 3.
Bridge5(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge5(g8032-config-switch)#end	Exit G.8032 configure mode.

Bridgel#configure terminal	Enter configure mode.
Bridgel(config)#interface xe20	Enter interface mode xe20.
Bridgel(config-if)#dotlad ethertype 0x88a8	Configure $xe20$ as a Layer 2 port with an Ethernet Type of $0x88a8$.
Bridgel(config-if)#interface xe20.1 switchport	Create a Layer 2 sub-interface $xe20.1$ within the physical interface $xe20$.
Bridge1(config-if)encapsulation dot1ad 200	Encapsulate the sub-interface with APS-channel VLAN ID 200.
Bridgel(config-if)encapsulation dotlad 600	Encapsulate the sub-interface with data VLAN ID 600.
Bridgel(config-if)#exit	Exit interface mode xe20.
Bridgel(config)#bridge-domain 1	Enter bridge domain configure mode and configure bridge domain instance 1.
Bridge1(config-bridge-domain)#interface xe20.1	Attach the sub-interface $xe20.1$ to the bridge domain instance.
Bridgel(config-bridge-domain)#exit	Exit bridge domain mode.
Bridgel(config)#ethernet cfm domain-type character-string domain-name P571 level 5	Create a CFM domain with character string type, name P571, and level 5.
Bridgel(config-ether-cfm)#service ma-type string ma-name ma7	Create a CFM Maintenance Association (MA) type as a string with the name ma7.
Bridge1(config-ether-cfm-ma)#vlan 200	Add VLAN 200 to the CFM MA.

Bridgel(config-ether-cfm-ma)#ethernet cfm mep down mpid 906 active true xe20.1	Create a down MEP 906 for $xe20.1$ interface and activate it.
Bridge1(config-ether-cfm-ma-mep)#cc multicast state enable	Enable Continuity Check (CC) multicast for the MEP.
Bridgel(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridgel(config-ether-cfm-ma)#mep crosscheck mpid 905	Configure crosscheck for the remote MEP with value 905.
Bridgel(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridgel(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge1(config)#g8032 ring subring2	Create a G.8032 ring named subring2.
Bridge1(g8032-ring-config)#east-interface xe20.1	Associate xe20.1 interface as the east interface in subring2.
Bridge1(g8032-ring-config)#exit	Exit ring configure mode and return to the configure mode.
Bridge1(config)#g8032 erp-instance erp3	Create a G.8032 Ethernet Ring Protection (ERP) instance named erp3.
Bridge1(g8032-config-switch)#ring-type sub-ring-vc	Configure the ring type as a sub-ring-vc.
Bridge1(g8032-config-switch)#ring subring2	Associate subring2 with the ERP instance erp3.
Bridge1(g8032-config-switch)#rpl role non- owner	Configure the node as a non-owner node in the ring.
Bridge1(g8032-config-switch)#g8032-profile profile1	Associate profile1 with erp3 instance.
Bridge1(g8032-config-switch)#aps-channel level 5	Configure the R-APS channel level as 5.
Bridge1(g8032-config-switch)#aps-channel vlan 200	Configure the APS channel VLAN as 200.
Bridge1(g8032-config-switch)#ring-id 3	Configure the ring ID as 3.
Bridge1(g8032-config-switch)#virtual- channel 100 attached-to-instance erp1	Configure the virtual channel with VLAN 100 and attache it to ERP instance erp1.
Bridge1(g8032-config-switch)#enable-tcn- propagation	Enable Topology Change Notification (TCN) propagation.
Bridge1(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge1(g8032-config-switch)#end	Exit G.8032 configure mode.

Bridge4#configure terminal	Enter configure mode.
Bridge4(config)#interface xe2	Enter interface mode xe2.
Bridge4(config-if)#dot1ad ethertype 0x88a8	Configure xe2 as a Layer 2 port with an Ethernet Type of 0x88a8.
Bridge4(config-if)#interface xe2.1 switchport	Create a Layer 2 sub-interface $xe2.1$ within the physical interface $xe2$.

Bridge4(config-if)encapsulation dot1ad 200	Encapsulate the sub-interface with APS-channel VLAN ID 200.
Bridge4(config-if)encapsulation dotlad 600	Encapsulate the sub-interface with data VLAN ID 600.
Bridge4(config-if)#exit	Exit interface mode xe2.
Bridge4(config)#bridge-domain 1	Enter bridge domain configure mode and configure bridge domain instance 1.
Bridge4(config-bridge-domain)#interface xe2.1	Attach the sub-interface $xe2.1$ to the bridge domain instance.
Bridge4(config-bridge-domain)#exit	Exit bridge domain mode.
Bridge4(config)#ethernet cfm domain-type character-string domain-name P271 level 5	Create a CFM domain with character string type, name P271, and level 5.
Bridge4(config-ether-cfm)#service ma-type string ma-name ma8	Create a CFM Maintenance Association (MA) type as a string with the name ma8.
Bridge4(config-ether-cfm-ma)#vlan 200	Add VLAN 200 to the CFM MA.
Bridge4(config-ether-cfm-ma)#ethernet cfm mep down mpid 800 active true xe2.1	Create a down MEP 800 for ${\tt xe2.1}$ interface and activate it.
Bridge4(config-ether-cfm-ma-mep)#cc multicast state enable	Enable Continuity Check (CC) multicast for the MEP.
Bridge4(config-ether-cfm-ma-mep)#exit- ether-ma-mep-mode	Exit Ethernet CFM MA-MEP mode.
Bridge4(config-ether-cfm-ma)#mep crosscheck mpid 801	Configure crosscheck for the remote MEP with value 801.
Bridge4(config-ether-cfm-ma)#exit-ether- ma-mode	Exit Ethernet CFM MA mode.
Bridge4(config-ether-cfm)#exit	Exit Ethernet CFM mode and return to the configure mode.
Bridge4(config)#g8032 ring subring2	Create a G.8032 ring named subring2.
Bridge4(g8032-ring-config)#east-interface xe2.1	Associate xe2.1 interface as the east interface in subring2.
Bridge4(g8032-ring-config)#exit	Exit ring configure mode and return to the configure mode.
Bridge4(config)#g8032 erp-instance erp3	Create a G.8032 Ethernet Ring Protection (ERP) instance named erp3.
Bridge4(g8032-config-switch)#ring-type sub-ring-vc	Configure the ring type as a sub-ring-vc.
Bridge4(g8032-config-switch)#ring subring2	Associate subring2 with the ERP instance erp3.
Bridge4(g8032-config-switch)#rpl role owner east-interface	Configure the node as the owner node for the specified ERPS ring and designate the east interface as the neighbor node in the ring.
Bridge4(g8032-config-switch)#g8032-profile profile1	Associate profile1 with erp3 instance.
Bridge4(g8032-config-switch)#aps-channel level 5	Configure the R-APS channel level as 5.

Bridge4(g8032-config-switch)#aps-channel vlan 200	Configure the APS channel VLAN as 200.
Bridge4(g8032-config-switch)#ring-id 3	Configure the ring ID as 3.
Bridge4(g8032-config-switch)#virtual- channel 100 attached-to-instance erp1	Configure the virtual channel with VLAN 100 and attache it to ERP instance erp1.
Bridge4(g8032-config-switch)#enable-tcn- propagation	Enable Topology Change Notification (TCN) propagation.
Bridge4(g8032-config-switch)#commit	Commit the candidate configuration to the running configuration
Bridge4(g8032-config-switch)#end	Exit G.8032 configure mode.

Validation

The following validation output displays details for the specified ERP instance using the show g8032 erp-instance command on Bridge5, Bridge1, and Bridge4. It describes the sub-ring type for Bridge1 and Bridge4 as virtual. Additionally, it specifies that Bridge1 is a non-owner node, while Bridge4 is the owner node for the specified ERPS ring, designating the east interface as the neighbor node in the ring.

Bridge5#show	g8032	erp-inst	tance				
Instance	I	D State	East	state	West	state	Ring
erps2	1	IDLE	xe2.1	Blocked	xe20.1	Unblocked	subring2
Bridge1#show	g8032	erp-inst	tance				
Instance	I	D State	East	state	West	state	Ring
erpl	1	IDLE	xe8.1	Unblocked	xe6.1	Unblocked	1
erp3	3	IDLE	xe20.1	Unblocked	-	-	subring2
Bridge4#show	g8032	erp-inst	tance				
Instance	I	D State	East	state	West	state	Ring
erp1	1	IDLE	xe6.1	Unblocked	xe16.1	Blocked	Ring1
erp3	3	IDLE	xe2.1	Blocked	-	-	subring2
Bridge1#show	g8032	erp-inst	tance erp3				
Inst Name	:	erp3 (3),	node-id e8:c5:	7a:a8:7c:c8	8, Profile	(1)	
Description	:						
Ring	:	SUB-RING	(VIRTUAL) (subr	ing2), NON-	-OWNER, Vi	rtual (vid	100 : r
ing_id 1)							
		Attached	to (erp1),				

```
tcn_propagation (1)
```

State : G8032_ST_IDLE

East : xe20.1, Unblocked, UP , BPR (-), remote (-)

East (cfm) : mep id (906), cc-interval (1s), Domain (P5P71), MA (ma7)

Channel : Level (5), vlan (200), RING ID (2)

Bridge4#show	g8032 erp-instance erp3
Inst Name	: erp3 (3), node-id b8:6a:97:25:a7:bd, Profile (1)
Description	:
Ring	: SUB-RING (VIRTUAL) (subring2), OWNER (EAST), Virtual (vid 100
: ring_id 1)	
	Attached to (erp1),
	tcn_propagation (1)
State	: G8032_ST_IDLE
East	: xe2.1, Blocked , UP , BPR (-), remote (-)
East (cfm)	: mep_id (800), cc-interval (1s), Domain (P2P71), MA (ma8)
Channel	: Level (5), vlan (200), RING ID (2)

Sub-ring without Virtual Channel Configuration

The following section presents a sample Ring Protection topology, demonstrating the configuration of protection switching with five bridges.

Topology

Figure 12-26 illustrates a sample Ethernet Ring Protection Switching topology. This scenario consists of one major ring, which includes Bridge1, Bridge2, Bridge3, and Bridge4, and one sub-ring involving Bridge5, Bridge1, and Bridge2.

In the major ring, RPL is enabled between Bridge 3 (the owner node) and Bridge 4 (the neighbor node) through interface xe16. The remaining devices within this major ring are non-owner nodes. For the sub-ring, RPL is enabled between Bridge 5 (the neighbor node) and Bridge 4 (the owner node) using link xe7, while the other devices in this sub-ring function as non-owner nodes.



Figure 12-26: Sub-ring without Virtual Channel

Prerequisite

- 1. Before configuring the non-virtual channel, ensure that the major ring is configured for Bridge1, Bridge2, Bridge3, and Bridge4 following the instructions provided in the Major Ring Configuration section.
- 2. Repeat the same configuration steps for Bridge5, Bridge1, and Bridge4 as outlined in the Sub-ring without Virtual Channel Configuration section. Instead of using the virtual-channel command, configure the non-virtual channel command for Bridge1 and Bridge4 as shown below:

```
Configure the non-virtual channel and attach it to ERP instance.
Bridge4(g8032-config-switch)#non-virtual-
channel
                                                     Enable Topology Change Notification (TCN) propagation.
Bridge4(g8032-config-switch)#enable-tcn-
propagation
Bridge4 (g8032-config-switch) #tcn-to-
                                                     Attach TCN propagation to ERPS instance.
instance erp1
```

Validation

The following validation output displays details for the specified ERP instance using the show g8032 erp-instance command on Bridge5, Bridge1, and Bridge4. It describes the sub-ring type for Bridge1 and Bridge4 as non-virtual. Additionally, it specifies that Bridge1 is a non-owner node, while Bridge4 is the owner node for the specified ERPS ring, designating the east interface as the neighbor node in the ring.

Bridge5#show Instance	g8032 I	erp-i D Sta	n stance ce	East	state	West	state	Ring
erps2	1	IDL	: 2	xe2.1	Blocked	xe20.1	Unblocked	subring2
Bridgel#show	g8032	erp-i	nstance					
Instance	I	D Sta	te	East	state	West	state	Ring
erp1	 1 2	IDL	 2 7	xe8.1	Unblocked	xe6.1	Unblocked	1 2
erps	3	LDL.	2	xezu.1	UNDIOCKEd	-	-	Subring2
Bridge4#show	g8032	erp-i:	nstance					
Instance	I	D Sta	ce	East	state	West	state	Ring
erp1	1	IDL	Ξ	xe6.1	Unblocked	xe16.1	Blocked R	ingl
erp3	3	IDL	Ξ	xe2.1	Blocked	-	-	subring2
Bridge1#show	g8032	erp-i	nstance	erp3				
Inst Name	:	erp3 (3), node	e-id e8:c5	:7a:a8:7c:c8	8, Profile	(1)	
Description	:							
Ring (1) (erp1,)	:	SUB-RI	NG (NON	VIRTUAL)	(subring2),	NON-OWNER	, tcn_propa	gation
State	:	G8032_	ST_IDLE					
East	:	xe20.1	, Unblo	cked, UP	, BPR (-), I	remote (-)		

```
: mep id (906), cc-interval (1s), Domain (P5P71), MA (ma7)
East (cfm)
Channel
                : Level (5), vlan (200), RING ID (2)
Bridge4#show g8032 erp-instance erp3
Inst Name
                : erp3 (3), node-id b8:6a:97:25:a7:bd, Profile (1)
Description
                :
Ring
                : SUB-RING (NON VIRTUAL) (subring2), OWNER (EAST), tcn propagation
(1) (erp1,)
State
                : G8032 ST IDLE
                : xe2.1, Blocked , UP , BPR (-), remote (-)
East
                : mep id (800), cc-interval (1s), Domain (P2P71), MA (ma8)
East (cfm)
Channel
                : Level (5), vlan (200), RING ID (2)
```

Implementation Examples

We explore deploying Ethernet LAN (ELAN) services using a bridge domain and leveraging ERPS to enhance network resilience and accelerate traffic switchover.

ELAN services find common applications in data centers and enterprise networks, facilitating connectivity among multiple endpoints. A bridge domain serves as a logical segment where these services are extended and managed.

Ring Topology in Data Center Network Scenario

In a data center network, multiple access switches are connected to aggregation switches forming a ring topology using bridge domains. The data center operator wants to implement fast protection switching to ensure uninterrupted connectivity for critical services in case of link or node failures.

Use Case: The data center network can achieve network resiliency by configuring ERPS over the bridge domains. In the event of a link failure on one of the ring ports, ERPS will automatically redirect traffic through the backup path, maintaining service continuity and minimizing downtime.

Campus LAN with Redundant Links Scenario

A campus LAN network is designed with redundant links between distribution switches using bridge domains. The network administrators want to implement ring protection to ensure reliable communication between buildings and minimize service disruptions in case of link failures.

Use Case: The campus LAN network can achieve seamless switchover during link failures by deploying ERPS over the bridge domains connecting the distribution switches. ERPS will detect the failure and swiftly switch traffic to the backup link, ensuring continuous connectivity for users and devices.

Industrial Automation Network Scenario

An industrial automation network uses a redundant ring topology with bridge domains to connect various industrial devices and controllers. The network operator requires a solution to achieve rapid network recovery in case of link or node failures.

Use Case: The network operator can achieve seamless switchover during link or node failures by configuring ERPS over the bridge domains in the industrial automation network. ERPS will provide fast protection switching, reducing downtime and ensuring continuous operation of critical industrial processes.

New CLI Commands

The ERPS with CFM Down-MEP over Bridge-Domain introduces the following configuration commands.

associate-ring

Use this command to configure a single ERPS instance to monitor multiple rings. All the rings associated with the associate-ring command must share the same parent interface as the primary ring mapped to the ERPS instance.

Note: The primary ring or instance is responsible for monitoring and managing multiple associate rings. However, it's important to note that only failures detected by the primary instance will trigger a switchover in all associated rings. Individual failures, such as link shutdowns on ring ports of associate rings, will not independently trigger failover switches in the associate rings. Instead, the primary instance must detect the failure for it to propagate to the associated rings.

Command Syntax

associate-ring RINGNAME

Parameters

RINGNAME Spec

Specifies the name of the ring to associate with the ERPS instance.

Default

None

Command Mode

G.8032 configure switch mode

Applicability

This command was introduced in OcNOS version 6.4.1.

Examples

Here is a sample example of configuring a G.8032 ERP instance and associate ring in OcNOS device.

```
OcNOS#configure terminal
OcNOS(config)#g8032 erp-instance instance1
OcNOS(g8032-config-switch)#associate-ring ring1
OcNOS(g8032-config-switch)#end
```

hardware-profile aclif failover

Use this command to enable failover for the logical interface (LIF) resources, optimizing ERPS hardware failover ID.

Use the no parameter of this command to disable failover for the LIF resources.

Note: Recommend using per-interface-based Access Control List (ACL) failover on ERPS ring ports instead of a global profile.

Command Syntax

hardware-profile aclif failover hardware-profile aclif no-failover

Parameters

None

Default

None

Command Mode

Configure mode.

Applicability

This command was introduced in OcNOS version 6.4.1.

Examples

Below are examples of configuring hardware profiles for ACL interface (aclif) with and without failover in OcNOS device.

```
OcNOS#configure terminal
OcNOS(config)#hardware-profile aclif failover
```

OcNOS(config) #hardware-profile aclif no-failover

aclif failover

Use this command to enable failover for the logical interface (LIF) resources, enhancing the LIFs hardware profile for ERPS.

Use the no parameter of this command to disable failover for the LIF resources, providing control over individual LIFs.

Command Syntax

```
aclif failover
aclif no-failover
```

Parameters

None

Default

None

Command Mode

Interface mode.

Applicability

This command was introduced in OcNOS version 6.4.1.

Examples

Below are sample examples of configuring ACL interface (aclif) with and without failover on interface xe_2 in OcNOS device.

OcNOS#configure terminal OcNOS(config)#interface xe2 OcNOS(config)#aclif failover

```
OcNOS(config) #aclif no-failover
```

Revised CLI Commands

Below is the revised command for configuring ERPS with Bridge-Domain. For more details, refer G.8032 ERPS Version 2 Commands chapter in the *Carrier Ethernet Guide*.

clear g8032 erp-instance

- The command clear g8032 erp-instance is used to clear ERPS instance.
- The existing syntax now includes the newly added parameter for clearing all ERPS instance, namely all.

erp-instance

- The command erps-instance is used to set the ERPS-instance for the sub-interface.
- The syntax has been revised to remove the none parameter.

g8032 erp-instance force-switch

- The command g8032 erp-instance force-switch is used to configure administrative commands related to force switching within ERPS instances.
- The existing syntax now includes the newly added parameter to apply the command to all ERPS instances configured on the device, namely all.

g8032 erp-instance manual-switch

- The command g8032 erp-instance manual-switch is used to configure administrative commands related to force switching within ERPS instances.
- The existing syntax now includes the newly added parameter to apply the command to all ERPS instances configured on the device, namely all.

show g8032 erp-instance

- The command show g8032 erp-instance is used to display details about an ERP instance.
- The existing syntax now includes the newly added parameters to display data traffic details for ERP instances and details for a specific ERP instance, namely data-traffic and summary.

Troubleshooting

ERPS Conflict with VXLAN

In some scenarios, ERPS may encounter conflicts with VXLAN configurations, leading to issues with traffic forwarding. These conflicts primarily arise due to resource conflicts in the hardware for wide LIF data. This section provides insights into identifying and resolving such conflicts.

Issue Description

When VXLAN is used in conjunction with ERPS, traffic forwarding for xConnects configured in specific scenarios, such as Qumran2 series platform, may fail.

Conflict Details

ERPS optimizations, particularly those related to hardware failover IDs (hw-failover-id), can conflict with VXLAN bridge configurations and VXLAN xConnects, causing VXLAN-related functionalities to stop working as expected. The conflict arises due to resource contention in the hardware, particularly when dealing with wide LIFs data.

Proposed Solution

To address these conflicts and provide granular control over resource usage, a new CLI commands hardware-profile aclif failover and aclif failover has been introduced. This command allows users to enable or disable the hardware-aclif-failover feature for failover on LIFs.

Impact on ERPS

- For bridge and PB configurations, default aclif-failover features are available, and there is no impact on ERPS.
- For bridge-domain configurations, conflicts may arise with VXLAN on sub-interface LIFs. To resolve this, the CLI commands hardware-profile aclif failover and aclif failover must be configured on ring ports. It's important to note that enabling or configuring aclif-failover on ring ports for bridge-domain configurations does not result in any functional changes compared to the previous CLI settings.

Abbreviations

The following are some key abbreviations and their meanings relevant to this document:

Acronym	Description
ERPS	Ethernet Ring Protection Switching
CFM	Continuity Fault Management
ELAN	Ethernet LAN
LIF	Logical Interface
ACLIF	Access Control List Interface

Glossary

The following provides definitions for key terms used throughout this document.

Bridge Domain	A logical network segment where bridging services are extended and managed. It defines a broadcast domain in Ethernet bridging.
Bridge Ports	Physical or virtual ports/interfaces that connect devices within a bridge domain.
Network Resilience	The ability of a network to maintain service availability and performance in the face of failures or abnormal conditions.
Redundant Links	Backup or alternative network connections designed to ensure network reliability.
Distribution Switches	Network switches that aggregate traffic from access switches and connect them to core switches or routers.
Ring Topology	A network topology in which each network device is connected to exactly two other devices, forming a circular path.
Failover	The process of automatically switching to a backup or redundant system or path in case of a failure.
Downtime	The period during which a system, network, or service is unavailable or not functioning correctly.
VLAN	Virtual Local Area Network, a logical segmentation of a network to isolate traffic and improve network efficiency.
Backup Path	An alternative network path that can be used to reroute traffic in case of a failure in the primary path.
Granular Control	Fine-tuned control over specific aspects or resources within a system or network.
Resource Contention	Competition or conflict for limited resources, such as hardware resources in a network device.
Sub-Interface	A logical interface created within a physical interface to allow multiple virtual interfaces with different configurations.
Logical Interface	A virtual or logical network interface on a device.

CHAPTER 13 Ethernet in the First Mile Configuration

This chapter contains a complete sample Ethernet 802.3ah (EFM) configuration.

EFM stands for Ethernet in the First Mile and it is an Ethernet link-layer OAM, which works over direct/with ethernet repeaters point-to-point ethernet links. OAM PDUs (Protocol Data Units) uses slow protocol destination MAC address 0180.c200.0002. These frames are single-hop and can not be forwarded beyond a single hop. The transmission rate is limited to a maximum of 10 frames per second to avoid impact on normal operations. Following are the OAM features supported by EFM.

- Discovery
- Link Monitoring
- Remote Fault Detection
- Remote Loopback
- Note: Ethernet OAM is a layer 2 interface feature. So switchport configuration on interface is required. Configure the OAM Mode as Active or Passive. Both switch can be configured Active-Active or Active-Passive. But Passive-Passive on both switch won't work.
- Note: Remote-loopback & link monitor supported is configured by default when ethernet oam is enabled.
- Note: shut/no-shut should be performed to bring up the interface which becomes down after dying-gasp event.

Topology

Figure 13-27 displays a sample EFM topology.



Configuration

All configuration commands in the table below should be followed for each switch.

<pre>#configure terminal</pre>	Enter configure mode.
(config)#interface xe3	Enter interface mode.
(config-if) #switchport	Set switching characteristics on the port.
(config-if)#ethernet oam enable	Configure EFM on interface
(config-if) #ethernet oam mode passive	Configure EFM mode Passive. Default is Active
(config-if) #ethernet oam mode active	Configure EFM mode Active
<pre>(config-if)# ethernet oam remote-loopback start</pre>	Configure remote-loopback start
<pre>(config-if)# ethernet oam remote-loopback stop</pre>	Configure remote-loopback stop

(config-if) #commit	Commit the configuration
(config-if) # exit	Exit from interface mode

Validation

1. Verify OAM discovery

show ethernet oam discovery interface xe3

```
Local client:
```

```
_____
```

Administrative configurations:	
Mode:	active
Unidirection:	not supported
Link monitor:	supported(on)
Remote Loopback:	supported
MIB retrieval:	not supported
MTU Size :	1518
Operational status:	
Port status:	operational
Loopback status:	no loopback
PDU revision:	0

Remote client:

```
MAC address: 80a2.356c.21ff
Vendor(oui): 0 0 0
```

```
Administrative configurations:

Mode: passive

Unidirection: not supported

Link monitor: supported

Remote Loopback: supported

MIB retrieval: not supported

MTU Size : 1518
```

2. Verify the Discovery State Machine Details

```
show ethernet oam xe3
```

```
Discovery State Machine Details:

------

EFM Discovery Machine State:

Local Parser State:

Local Multiplexer State:

Remote Parser State:

Remote Multiplexer State:
```

```
Local Client:
```

Send Any

Forward

Forward

Forward

Forward
Symbol Period Error: 10000000 Symbol(s) Window: Threshold: 1 Symbol(s) Last Window Symbols Errors: 0 Symbol(s) Total Symbols Errors: 0 Symbol(s) Total Symbols Errors Events: 0 Events(s) Relative Timestamp of the Event: 0 x 100 milliseconds Frame Error: Window: 100 x 10 milliseconds Threshold: 1 Error Frame(s) Last Window Frame Errors: 0 Frame(s) Total Frame Errors: 0 Frames(s) Total Frame Errors Events: 0 Events(s) Relative Timestamp of the Event: 0 x 100 milliseconds Frame Period Error: Window: 10000000 Frames Threshold: 1 Error Frame(s) Last Window Frame Errors: 0 Frame(s) Total Frame Errors: 0 Frames(s) Total Frame Period Errors Events: 0 Events(s) Relative Timestamp of the Event: 0 x 100 milliseconds Frame Seconds Error: Window: 1000 x 10 milliseconds Threshold: 1 Error Second(s) Last Window Frame Second Errors: 0 Frame(s) Total Frame Second Errors: 0 Frames(s) Total Frame Second Errors Events: 0 Events(s) Relative Timestamp of the Event: 0 x 100 milliseconds Remote Client: _____ Symbol Period Error: Window: 0 Symbol(s) Threshold: 0 Symbol(s) Last Window Symbols Errors: 0 Symbol(s) Total Symbols Errors: 0 Symbol(s) 0 Events(s) Total Symbols Errors Events: Relative Timestamp of the Event: 0 x 100 milliseconds Frame Error: Window: 0 x 100 milliseconds Threshold: 0 Error Frame(s) Last Window Frame Errors: 0 Frame(s) Total Frame Errors: 0 Frames(s) Total Frame Errors Events: 0 Events(s) Relative Timestamp of the Event: 0 x 100 milliseconds

```
Frame Period Error:
        Window:
                                          0 Frames
        Threshold:
                                          0 Error Frame(s)
        Last Window Frame Errors:
                                          0 Frame(s)
        Total Frame Errors:
                                          0 Frames(s)
        Total Frame Period Errors Events: 0 Events(s)
        Relative Timestamp of the Event: 0 x 100 milliseconds
     Frame Seconds Error:
        Window:
                                          0 x 100 milliseconds
        Threshold:
                                          0 Error Second(s)
        Last Window Frame Second Errors: 0 Frame(s)
        Total Frame Second Errors:
                                          0 Frames(s)
        Total Frame Second Errors Events: 0 Events(s)
        Relative Timestamp of the Event: 0 x 100 milliseconds
3. Verify the oam statistics
show ethernet oam statistics interface xe3
Counters:
_____
    Information OAMPDU Tx
                                           : 331
    Information OAMPDU Rx
                                           : 323
    Event Notification OAMPDU Tx
                                           • 0
    Event Notification OAMPDU Rx
                                           : 0
    Loopback Control OAMPDU Tx
                                          : 0
    Loopback Control OAMPDU Rx
                                           : 0
    Unsupported OAMPDU Rx
                                           : 0
Local event logs:
_____
    0 Errored Symbol Period records
    0 Errored Frame records
    0 Errored Frame Period records
    0 Errored Frame Seconds records
Remote event logs:
_____
    0 Errored Symbol Period records
    0 Errored Frame records
    0 Errored Frame Period records
    0 Errored Frame Seconds records
```

4. Verify the oam status

show ethernet oam status interface xe3

General:

```
_____
  Mode:
                                      active
  PDU max rate:
                                      10 packets per second
   PDU min rate:
                                      1 packet per 1 second
   Link timeout:
                                      5 seconds
   High threshold action:
                                      no action
Link Monitoring:
_____
     Status:
                                      supported(on)
     Event log size:
                                      20 Entries
     Symbol Period Error:
        Window:
                                      100 million symbols
        Low threshold:
                                      1 error symbol(s)
        High threshold:
                                      none
     Frame Error:
        Window:
                                      100 x 10 milliseconds
        Low threshold:
                                      1 error frame(s)
        High threshold:
                                      none
     Frame Period Error:
        Window:
                                      1000 x 100,000 frames
        Low threshold:
                                      1 error frame(s)
        High threshold:
                                      none
     Frame Seconds Error:
                                      1000 x 10 milliseconds
        Window:
        Low threshold:
                                      1 error second(s)
        High threshold:
                                      none
```

CHAPTER 14 Ethernet Test Signal Lock Configuration

ETH-TST (Ethernet Test Signal) and ETH-LCK (Ethernet Lock Signal) protocols are defined in Y.1731. ETH-TST is used to perform one-way on-demand in-service or out-of-service diagnostics tests. This includes verifying bandwidth throughput, frame loss, bit errors, etc.

ETH-LCK is used to communicate the administrative locking of a MEP and consequential interruption of data traffic forwarding towards the MEP expecting this traffic. It allows a MEP receiving frames with ETH-LCK information to differentiate between a defect condition and an administrative locking action at lower level MEP.

Topology Convergence established Image: State of the state of

ETH-TST Configuration

Initiator/generator

#configure terminal	Enter configure mode.
<pre>(config) #hardware-profile filter cfm-domain- name-str enable</pre>	Configure Hardware profile filter.
<pre>(config)#hardware-profile statistics ingress-acl enable</pre>	Configure hardware profile statistics ingress-acl.
(config)#vlan database	Enter Vlan config mode.
(config-vlan)#vlan 2-100 bridge 1 state enable	Configure Vlans.
(config-vlan) #exit	Exit Vlan config mode.
(config)#interface xe15	Enter Interface config mode.
(config-if)#switchport	Configure Interface as switchport.
(config-if)#bridge-group 1	Configure bridge-group.
(config-if)#switchport mode trunk	Configure switchport mode as trunk.
(config-if)#switchport trunk allowed vlan all	Configure all vlans as part of switchport trunk.
(config-if)#no shutdown	Bring the interface into operation.
(config-if) #exit	Exit interface mode.

<pre>(config) #ethernet cfm domain-type character- string domain-name test1 level 7 mip- creation none</pre>	Enter ethernet cfm mode by specifying domain name and bridge.
(config-ether-cfm)#service ma-type string ma-name test1	Configure service ma.
(config-ether-cfm-ma)#vlan 10 bridge 1	Configure service Vlan.
(config-ether-cfm-ma)#mip-creation none	Configure mip-creation type.
(config-ether-cfm-ma)#ethernet cfm mep down mpid 200 active true xe15	Configure ethernet cfm mep.
(config-ether-cfm-ma-mep) #cc multicast state enable	Enable multicast state.
(config-ether-cfm-ma-mep) #exit-ether-ma- mep-mode	Exit Ethernet ma mep mode.
(config-ether-cfm-ma)#mep crosscheck mpid 100	Configure RMEP.
(config-ether-cfm-ma)#cc interval 5	Configure interval in ma mode.
(config-ether-cfm-ma) #exit-ether-ma-mode	Exit ma mode.
(config-ether-cfm) #exit	Exit Ethernet cfm mode.
(config)#ethernet cfm test-signal profile- name test	Configure Ethernet cfm test-signal profile.
(config-cfm-tst) #mode both	Configure test-signal mode as both(generator and receiver).
(config-cfm-tst)#frame-size 1500	Configure test-signal frame-size.
(config-cfm-tst) #commit	Commit the candidate configuration to the running configuration.
(config-cfm-tst) #exit	Exit Ethernet cfm test-signal mode.

Receiver

#configure terminal	Enter configure mode.	
<pre>(config) #hardware-profile filter cfm-domain- name-str enable</pre>	Configure Hardware profile filter.	
<pre>(config) #hardware-profile statistics ingress-acl enable</pre>	Configure hardware profile statistics ingress-acl.	
(config)#vlan database	Enter Vlan config mode.	
(config-vlan)#vlan 2-100 bridge 1 state enable	Configure Vlans.	
(config-vlan) #exit	Exit Vlan config mode.	
(config)#interface xe15	Enter Interface config mode.	
(config-if) #switchport	Configure Interface as switchport.	
(config-if)#bridge-group 1	Configure bridge-group.	
(config-if)#switchport mode trunk	Configure switchport mode as trunk.	
(config-if)#switchport trunk allowed vlan all	Configure all vlans as part of switchport trunk.	
(config-if)#no shutdown	Bring the interface into operation.	
(config-if) #exit	Exit interface mode.	

<pre>(config)#ethernet cfm domain-type character- string domain-name test1 level 7 mip- creation none</pre>	Enter ethernet cfm mode by specifying domain name and bridge.
(config-ether-cfm)#service ma-type string ma-name test1	Configure service ma.
(config-ether-cfm-ma)#vlan 10 bridge 1	Configure service Vlan.
(config-ether-cfm-ma)#mip-creation none	Configure mip-creation type.
(config-ether-cfm-ma)#ethernet cfm mep down mpid 100 active true xe15	Configure ethernet cfm mep.
(config-ether-cfm-ma-mep) #cc multicast state enable	Enable multicast state.
(config-ether-cfm-ma-mep) #exit-ether-ma- mep-mode	Exit Ethernet ma mep mode.
(config-ether-cfm-ma)#mep crosscheck mpid 200	Configure RMEP.
(config-ether-cfm-ma)#cc interval 3ms	Configure interval in ma mode.
(config-ether-cfm-ma) #exit-ether-ma-mode	Exit ma mode.
(config-ether-cfm) #exit	Exit Ethernet cfm mode.
<pre>(config)#ethernet cfm test-signal profile- name sample_tst</pre>	Configure Ethernet cfm test-signal profile.
(config-cfm-tst) #mode receiver	Configure test-signal mode as receiver.
(config-cfm-tst) #commit	Commit the candidate configuration to the running configuration.
(config-cfm-tst) #exit	Exit Ethernet cfm test-signal mode.

Validation

Before the ETH-TST signal is started, convergence needs to be established. Convergence is checked as mentioned below:

After the above convergence is established with the receiver node, ETH-TST signal is started from the exec mode as mentioned below.

Generator node

```
#test-signal start-time relative 0 stop-time relative 4 tst-profile-name test domain
test1 ma test1 mep 200 target mac-address 0018.236c.5cca bridge 1
```

Receiver node

#test-signal start-time relative 0 stop-time relative 4 tst-profile-name sample_tst
domain test1 ma test1 mep 100 target mac-address e8c5.7a78.712d bridge 1

ETH-TST Signal initiated is checked as mentioned below :

Generator node

#show @	ethernet	cfm test-signal	sessions		
MEP-Id	Status	StartTime		Tst-Profile	Peer MAC-Address
200	Active	2019/02/15 10	6:32:59	test	0018.236c.5cca

#show ethernet cfm test-signal domain test1 ma test1 mep 200 bridge 1 stats gtf TST Session status : In-Progress Elapsed Time(sec) : 77 MD : test1 MA : test1 MEP : 200 Peer MAC Address : 0018.236c.5cca : 100 RMEP ID Start Time : 2019 Feb 15 16:32:59 Transmitted Packet Count : 509767

Receiver Node

#show ethernet cfm test-sigr	nal domain test1 ma test1 mep 100 bridge 1 stats ctf
TST Session status	: In-Progress
Elapsed Time(sec)	: 83
MD	: test1
МА	: test1
MEP	: 100
Peer MAC Address	: e8c5.7a78.712d
RMEP ID	: 200
Start Time	: 2020 Dec 16 16:34:21
Received Packet Count	: 545827
Out-of-Order Packet Count	: 0
Error Packet Count	: 0
Last Packet Sequence Number	c : 664967

ETH-LCK Configuration

Eth-Lck configuration is performed at the MEP Level as shown below :

#configure terminal	Enter configure mode
<pre>(config)# ethernet cfm domain-type character-string domain-name test1 level 7 mip-creation none</pre>	Enter ethernet cfm mode by specifying domain name and bridge.
(config-ether-cfm)#service ma-type string ma-name test1	Configure service ma
(config-ether-cfm-ma)#vlan 10 bridge 1	Configure service Vlan.
(config-ether-cfm-ma)#mip-creation none	Configure mip-creation type.
(config-ether-cfm-ma)#ethernet cfm mep down mpid 200 active true xe15	Configure ethernet cfm mep
(config-ether-cfm-ma-mep) #exit	Eth Lck configuration is performed in MEP Mode

Validation

Default state of the Ethernet cfm Lck details is as mentioned below:

#show ethernet cfm lck details domain test1 ma test1 mep 200 bridge 1

```
Maintenance Domain
                               : test1
Maintenance Association
                                 : test1
MEP ID
                                : 200
LCK PDU state
                                : Unlocked
LCK Message Level
                               : 0
LCK PDU Interval
                                : 1 sec
LCK PDU Priority
                                 : 3
(config-ether-cfm-ma-mep)#state ?
  lock Enable adminstrative locking state
  unlock Disable adminstrative locking state
(config-ether-cfm-ma-mep)#state lock
#show ethernet cfm lck details domain test1 ma test1 mep 200 bridge 1
Maintenance Domain
                               : test1
Maintenance Association
                                 : test1
                               : 200
MEP ID
LCK PDU state
                             : Locked
LCK Message Level
                               : 0
LCK PDU Interval
                                : 1 sec
LCK PDU Priority
                                 : 3
(config-ether-cfm-ma-mep) #message level ?
  <0-7> Enter the level for LCK transmission
(config-ether-cfm-ma-mep) #message level 3
#show ethernet cfm lck details domain test1 ma test1 mep 200 bridge 1
Maintenance Domain
                               : test1
Maintenance Association
                                 : test1
MEP ID
                               : 200
LCK PDU state
                                : Locked
                              : 3
LCK Message Level
LCK PDU Interval
                                : 1 sec
                                 : 3
LCK PDU Priority
(config-ether-cfm-ma-mep)#interval ?
1min PDU transmit interval is one minute
     PDU transmit interval is one second(default)
19
(config-ether-cfm-ma-mep) #interval 1min
#show ethernet cfm lck details domain test1 ma test1 mep 200 bridge 1
                              : test1
Maintenance Domain
Maintenance Association
                                  : test1
MEP ID
                                : 200
```

: Locked LCK PDU state LCK Message Level : 3 LCK PDU Interval : 1 min LCK PDU Priority : 3 (config-ether-cfm-ma-mep)#frame priority ? <0-7> Enter the priority for LCK transmission PDU.Default is 3 (config-ether-cfm-ma-mep)#frame priority 7 #show ethernet cfm lck details domain test1 ma test1 mep 200 bridge 1 Maintenance Domain : test1 Maintenance Association : test1 MEP ID : 200 : Locked LCK PDU state LCK Message Level : 3 LCK PDU Interval : 1 min : 7 LCK PDU Priority

CHAPTER 15 Ethernet Bandwidth Notification Configuration

This chapter contains a configuration example of Ethernet Bandwidth Notification (ETH-BN).

ETH-BN protocol is defined in ITU-T Y.1731. ETH-BN is used by a server MEP to signal the server layer link bandwidth in the transmit direction to a MEP at the client layer, for example when the server layer runs over a microwave link which has the capability to adapt its bandwidth according to the prevailing atmospheric conditions.

On receiving frames with ETH-BN information, the client layer MEP can use bandwidth information to adjust service policies, e.g., to reduce the rate of traffic being directed towards the degraded link.

A client MEP continues to receive periodic frames with ETH-BN information including currently available bandwidth until the full bandwidth is restored at server MEP. In addition, periodic frames with ETH-BN information may optionally be receive when there is no degradation or when the bandwidth degrades to 0.

OcNOS supports only ETH-BN PDU reception and received PDU is processed as per below FSM:

Note: ETH-BN transmission is not supported by OcNOS.

Note: ETH-BN session shall be initiated on pre-configured active MEP. MD, MA and MEP details shall be metadata or prerequisite for this feature.

Topology

Figure 15-29 displays a sample FSM topology.



Figure 15-29: FSM Topology

Figure 15-30 displays a sample ETH-BN topology.



Prerequisite

Configure below hardware-profile commands related to CFM in configuration mode and reboot the nodes.

```
hardware-profile filter cfm-domain-name-str enable hardware-profile statistics cfm-ccm enable (optional)
```

ETH-BN Configuration

Eth-Bn configuration is performed at the MEP Level as shown below.

Client-mep#configure terminal	Enter configure mode	
Client-mep(config)#bridge 1 protocol rstp vlan- bridge	Create bridge 1 as an RSTP VLAN-aware bridge.	
Client-mep (config)#vlan database	Entering vlan database	
Client-mep (config-vlan)#vlan 10 bridge 1 state enable	Create VLAN 10 on bridge 1.	
Client-mep (config-vlan)#exit	Exit vlan database	
Client-mep (config)#int ce49	Configure interface ce49.	
Client-mep (config-if)#bridge-group 1	Configure interface in bridge group 1.	
Client-mep (config-if)#switchport mode trunk	Configure interface mode as trunk.	
Client-mep (config-if)#switchport trunk allowed vlan all	Allow all VLANs on interface ce49.	
Client-mep (config-if)#exit	Exit config mode.	
Client-mep (config)#ethernet cfm domain-type character-string domain-name 12345 level 7 mip-creation none	Create cfm domain with type as character string and set mip creation criteria to none.	
Client-mep (config-ether-cfm)#service ma- type string ma-name 54321	Create ma type as string and set mip creation criteria to none.	
Client-mep (config-ether-cfm-ma)#vlan 10 bridge 1	Configure service Vlan	
Client-mep (config-ether-cfm-ma)# mip- creation none	Configure mip-creation type.	

Client-mep (config-ether-cfm-ma)#ethernet cfm mep down mpid 34 active true ce49	Create down mep for local-vid on ce49.
Client-mep (config-ether-cfm-ma-mep)#cc multicast state enable	Enable cc multicast.
Client-mep (config-ether-cfm-ma-mep)#bn receive	Enabling the eth-bn status
Client-mep (config-ether-cfm-ma-mep)#wait- to-restore-timer 50	Configure the eth-bn wait-too-restore-timer 50secs
Client-mep (config-ether-cfm-ma-mep)#exit- ether-ma- mep-mode	Exit Ethernet ma mep mode.
Client-mep (config-ether-cfm-ma)#mep crosscheck mpid 35	Enable MEP crosscheck
Client-mep (config-ether-cfm-ma)#cc interval 3ms	Enable cc interval in ms
Client-mep (config-ether-cfm-ma)#exit- ether-ma-mode	Exit ma mode.
Client-mep (config-ether-cfm)#commit	Commit the candidate configuration to the running configuration.
Client-mep (config-ether-cfm)#exit	Exit Ethernet cfm mode.

Validation

```
client-mep#show running-config cfm
!
!
ethernet cfm domain-type character-string domain-name 12345 level 7 mip-creation none
service ma-type string ma-name 54321
mip-creation none
ethernet cfm mep down mpid 34 active true ce49
bn receive
wait-to-restore-timer 50
exit-ether-ma-mep-mode
mep crosscheck mpid 35
   cc interval 3ms
exit-ether-ma-mode
!
client-mep#show ethernet cfm bn status
BNM status for interface xe26
_____
                        : SIGNAL PENDING
State
Restore Time
                        : 50 seconds
Total BNM Receive Count : 2
Sender Address
                        : 3c2c.99d6.16a9
Elapsed time in this state: 00:01:38
```

```
Nominal Bandwidth
Current Bandwidth
                   : 16 Mbps
                    : 16 Mbps
Lowest Bandwidth
                    : 16 Mbps
Last BNM Received
                    : 2019 Mar 14 15:09:50
BNM Period
                    : 60 seconds
Wait-to-Restore Timer : 45 second(s) remaining
Client-mep#show ethernet cfm bn mep 2 domain mdnam ma testtm
Ethernet BN MEP informations
_____
MA-Name : testtm
MEL : 2
Admin Status: ENABLE
Interface : ce49
VLAN : 25
Source Address : 3c2c.99d6.16a9
Wait to Restore Timer : 50 seconds
      State
                      : SIGNAL NORMAL
      Elapsed time in this state: 00:00:01
      Last BNM Received : 2019 Mar 14 15:09:50
      Nominal Bandwidth
                           : 16 Mbps
      Current Bandwidth : 16 Mbps
      Port-ID : -1412628480
      BNM Period : 60 seconds
Client-mep#show ethernet cfm statistics bn
MEPID Domain MA-Name RX-Frames Dropped-Frames WR-time-left(sec)
_____
             testtm 2
     mdnam
                                   0
2
                                                   44
```

Carrier Ethernet Command Reference

CHAPTER 1 CFM and Y.1731 Commands

This chapter describes the commands used to manage the Connectivity Fault Management (CFM). CFM refers to the service OAM of Ethernet used to manage individual Layer 2 Ethernet services. The CFM protocol can discover and verify the path through 802.1 bridges and LANs. OcNOS adheres to the IEEE 802.1ag 2007 standard.

CFM includes the features required by ITU Y.1731 standard OAM Functions and Mechanisms for Ethernet Based Networks. This recommendation identifies the functions required to enable fault management (such as fault localization and defect detection) and performance monitoring in an Ethernet network.

- abort delay-measurement
- abort loss-measurement
- abort test-signal domain
- adaptive bandwidth disable
- ais interval
- ais status
- bins-per-fd-interval
- bins-per-ifdv-interval
- bin-type
- bn receive
- bw-mapped-interface
- cc interval
- cc multicast
- cfm snmp restart
- clear ethernet cfm delay-measurement history
- clear ethernet cfm dm history
- clear ethernet cfm lm history
- clear ethernet cfm lm history
- clear ethernet cfm maintenance-point remote
- clear ethernet cfm statistics
- clear ethernet cfm statistics bn
- clear ethernet cfm statistics lck
- clear ethernet cfm statistics test-signal
- clear ethernet cfm traceroute-cache
- csf receive
- debug ethernet cfm
- delay-measurement type on-demand
- delay-measurement type proactive
- ethernet cfm delay-measurement profile-name
- ethernet cfm delay-measurement reply
- ethernet cfm domain-type

- ethernet cfm loss-measurement profile-name
- ethernet cfm loss-measurement reply
- ethernet cfm mep
- ethernet cfm mip
- ethernet cfm statistics csf
- ethernet cfm test-signal profile-name
- ethernet cfm traceroute cache
- evpn
- exit-ether-ma-mep-mode
- exit-ether-ma-mode
- frame priority
- hardware-profile filter cfm-domain-name-str
- interval
- intervals-stored
- Ick state
- link-level
- loss-measurement type on-demand
- loss-measurement type proactive
- measurement-interval
- measurement-type slm
- mep crosscheck
- mep lowest-priority-defect
- message level
- message-period
- mip-creation
- intervals-stored
- peer-port-id
- ping ethernet mac
- rmep auto-discovery
- service ma-type
- show ethernet cfm ais reception-status
- show ethernet cfm bn
- show ethernet cfm bn mep
- show ethernet cfm csf
- show ethernet cfm csf mep
- show ethernet cfm delay-measurement mep
- show ethernet cfm delay-measurement profile
- show ethernet cfm dm sessions
- show ethernet cfm errors

- show ethernet cfm eth-bn status
- show ethernet cfm frame-Im session
- show ethernet cfm lck details domain
- show ethernet cfm lck statistics
- show ethernet cfm loss-measurement mep
- show ethernet cfm loss-measurement profile
- show ethernet cfm ma status
- show ethernet cfm maintenance-points count
- show ethernet cfm maintenance-points local mep
- show ethernet cfm maintenance-points local mip
- show ethernet cfm maintenance-points remote
- show ethernet cfm statistics
- show ethernet cfm statistics bn
- show ethernet cfm statistics csf
- show ethernet cfm test-signal domain
- show ethernet cfm test-signal profile
- show ethernet cfm test-signal sessions
- show ethernet cfm traceroute-cache
- show running-config cfm
- test-signal frame-size
- test-signal mode
- test-signal pattern-type
- test-signal start-time
- test-signal test-type
- traceroute ethernet
- vlan
- vpws
- wait-to-restore-timer <0-86400>

abort delay-measurement

Use this command to stop the ongoing or scheduled CFM frame delay measurement session.

Command Syntax

abort delay-measurement mep MEPID domain DOMAIN_NAME ma MA_NAME

Parameters

me	2	Local MEP identifier
	MEPID	MEP identifier <1-8191>
dor	main	Specify domain.
	DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
ma		Specify Maintenance association name
	MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#abort delay-measurement mep 123 domain 12345 ma 1234
```

abort loss-measurement

Use this command to stop the ongoing CFM frame loss measurement session.

Command Syntax

abort loss-measurement mep MEPID domain DOMAIN_NAME ma MA_NAME

Parameters

mer	þ	Local MEP identifier
	MEPID	MEP identifier <1-8191>
dor	nain	Specify domain.
	DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
ma		Specify Maintenance association name
	MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

#abort loss-measurement mep 201 domain 12345 ma 1234

abort test-signal domain

Use this command to abort pre-configured test session.

Command Syntax

abort test-signal domain DOMAIN_NAME ma MA_NAME mep MEPID

Parameters

domain		Specify domain.
]	DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
ma		Specify Maintenance association name
I	MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.
mep		Specify mep
I	MEPID	Enter the MEPID ranging from <1-8191>

Command Mode

Exec mode

Default

None

Applicability

This command was introduced in OcNOS version 4.0.

```
#abort test-signal domain 12345 ma 43982 mep 21
```

adaptive bandwidth disable

Use this command to disable adaptive bandwidth for ETH-BNM.

Command Syntax

adaptive bandwidth disable

Parameters

None

Default

Enabled.

Command Mode

Ethernet CFM MEP BN mode.

Applicability

This command was introduced in OcNOS version 6.5.1.

```
OcNOS(config)#ethernet cfm domain-type character-string domain-name md000
level 7 mip-creation default
OcNOS(config-ether-cfm)# service ma-type string ma-name ma289
OcNOS(config-ether-cfm-ma)# vlan 1291 bridge 1
OcNOS(config-ether-cfm-ma)# ethernet cfm mep down mpid 3290 active true xe2
OcNOS(config-ether-cfm-ma-mep)# cc multicast state enable
OcNOS(config-ether-cfm-ma-mep)#bn receive
OcNOS(config-ether-cfm-ma-mep-bn)#adaptive bandwidth disable
OcNOS(config-ether-cfm-ma-mep-bn)#
```

ais interval

Use this command to set the AIS (Alarm Indication Signal) transmission interval.

Command Syntax

ais interval (1min|1s)

Parameters

lmin	AIS transmission interval in packets per second
1s	AIS transmission interval in packets per minute

Default

one-second

Command Mode

Ethernet CFM MA MEP mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#configure terminal
(config)#ethernet cfm domain-type character-string domain-name 12345 level 7
(config-ether-cfm)#service ma-type string ma-name 43982
(config-ether-cfm-ma)#ethernet cfm mep down mpid 201 active true local-vid 10 xe2
(config-ether-cfm-ma-mep)#ais interval 1m
```

ais status

Use this command to enable or disable AIS (Alarm Indication Signal) transmission and set the CFM MD level to transmit in AIS PDUs.

Command Syntax

ais status (enable|disable) level <0-7>

Parameters

enable	Enable AIS
disable	Disable AIS
<0-7>	CFM MD level

Default

disable

Command Mode

Ethernet CFM MA MEP mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#configure terminal
(config)#ethernet cfm domain-type character-string domain-name 12345 level 7
(config-ether-cfm)# service ma-type string ma-name testtm
(config-ether-cfm-ma)#vlan 5 bridge 10
(config-ether-cfm-ma)#ethernet cfm mep down mpid 201 active true xe2
(config-ether-cfm-ma-mep)#ais status enable level 7
```

bins-per-fd-interval

Use this command to the set number of measurement bins per measurement interval for a two-way performance monitoring frame delay measurements on a specific MEP.

Use the no form to set number of measurement bins per measurement interval for a two-way performance monitoring frame delay measurements on a specific MEP to its default (3).

Command Syntax

```
bins-per-fd-interval <2-10>
no bins-per-fd-interval
```

Parameters

<2-10> Number of frame delay bins to be created

Default

3

Command Mode

Ethernet CFM delay measurement mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#configure terminal
(config)#ethernet cfm delay-measurement profile-name PROF1
(config-cfm-dm)# bins-per-fd-interval 4
```

bins-per-ifdv-interval

Use this command to set the number of measurement bins per measurement interval for an inter-frame delay for a twoway performance monitoring frame delay measurements on a specific MEP.

Use the no form to set the number of measurement bins per measurement interval for an inter-frame delay for a twoway performance monitoring frame delay measurements on a specific MEP to its default (2).

Command Syntax

```
bins-per-ifdv-interval <2-10>
no bins-per-ifdv-interval
```

Parameters

<2-10> Number of inter-frame delay bins to be created

Default

2

Command Mode

Ethernet CFM delay measurement mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#configure terminal
(config)#ethernet cfm delay-measurement profile-name PROF1
(config-cfm-dm)# bins-per-ifdv-interval 3
```

bin-type

Use this command to set the threshold value for a particular bin for a two-way performance monitoring frame delay measurements on a specific MEP.

Use the no form to set threshold value for a particular bin for a two-way performance monitoring frame delay measurements on a specific MEP to its default.

Command Syntax

```
bin-type frame-delay bin 2 threshold 200
no bin-type frame-delay bin 2 threshold
bin-type inter-frame-delay-variation bin 2 threshold 1000
no bin-type inter-frame-delay-variation bin 2 threshold
```

Parameters

frame-delay Frame delay bin type

inter-frame-delay-variation

Inter frame delay variation bin type

<2–10> Bin number for which the threshold will be changed.

<1- 4294967295>

Threshold value for that bin.

Default

Incremental of 5000 microseconds from bin 2, that is bin 2's threshold will be 5000, bin 3's will be 10000, bin 4 will be 15000, so on and so forth.

Command Mode

Ethernet CFM delay measurement mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#configure terminal
(config)#ethernet cfm delay-measurement profile-name PROF1
(config-cfm-dm)# bin-type frame-delay bin 2 threshold 200
(config-cfm-dm)# bin-type inter-frame-delay-variation bin 2 threshold 1000
```

bn receive

Use this command to create EBN configuration and to enable/disable Eth-BN for the Mep.

Command Syntax

bn receive no bn receive

Parameters

None

Default

ETH-BN is disabled by default

Command Mode

Ethernet CFM MEP mode

Applicability

This command was introduced in OcNOS version 5.0

```
OcNOS(config)#ethernet cfm domain-type character-string domain-name abcde
level 5
OcNOS(config-ether-cfm)#service ma-type string ma-name 7
OcNOS(config-ether-cfm-ma)#vlan 10 bridge 1
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 100 active true xe9
OcNOS(config-ether-cfm-ma-mep)#bn receive
OcNOS(config-ether-cfm-ma-mep-bn)#commit
```

bw-mapped-interface

Use this command to configure modem interface where the shapers has to be applied. When Eth-BNM and Eth-CSF PDUs are received on Out-Of-Band interface, shapper will be updated on corresponding modem interface if this CLI is configured. Use <no> version of CLI to unconfigure modem interface mapping.

Command Syntax

```
bw-mapped-interface IFNAME
no bw-mapped-interface
```

Parameters

IFNAME Specify the interface name where bandwidth shapers can be applied

Command Mode

Ethernet CFM MEP mode

Applicability

This command was introduced in OcNOS version 5.2

```
OcNOS(config)#ethernet cfm domain-type character-string domain-name abcde
level 5
OcNOS(config-ether-cfm)#service ma-type string ma-name 7
OcNOS(config-ether-cfm-ma)#vlan 10 bridge 1
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 100 active true xe9
OcNOS(config-ether-cfm-ma-mep)# bw-mapped-interface modem1
OcNOS(config-ether-cfm-ma-mep)# bw-mapped-interface modem1
```

cc interval

Use this command to set the continuity checking (CC) message interval.

Command Syntax

cc interval (3ms|10ms|100ms|1s|10s|1min|10min)

Parameters

3ms	3 milliseconds
10ms	10 milliseconds
100ms	100 milliseconds
1s	1 seconds
lmin	1 minute
10s	10 seconds
10min	10 minutes

Note: 1min and greater not supported in QAX.

Command Mode

Ethernet CFM MA mode

Applicability

This command was introduced in OcNOS version 3.0.

```
(config)#ethernet cfm domain-type character-string domain-name 12345 level 7
(config-ether-cfm)#service ma-type string ma-name 43982
OcNOS(config-ether-cfm-ma)#vlan 10 bridge 1
(config-ether-cfm-ma)#ethernet cfm mep down mpid 2331 active true xe2
OcnOS(config-ether-cfm-ma-mep)cc interval 3ms
OcnOS(config-ether-cfm-ma-mep)#cc multicast state enable
```

cc multicast

Use this command to start or stop multicast continuity checking messages (CCMs) on a MEP.

Command Syntax

cc multicast state (enable|disable)

Parameters

enable	Start sending CCMs
disable	Stop sending CCMs

Command Mode

Ethernet CFM MA MEP mode

Applicability

This command was introduced in OcNOS version 3.0.

Examples

(config)#ethernet cfm domain-type character-string domain-name 12345 level 7 (config-ether-cfm)#service ma-type string ma-name 43982 (config-ether-cfm-ma)#vlan 10 bridge 1 (config-ether-cfm-ma)#ethernet cfm mep down mpid 2331 active true xe2 OcnOS(configether-cfm-ma-mep)#cc multicast state enable

cfm snmp restart

Use this command to restart SNMP in CFM Protocol.

Command Syntax

cfm snmp restart

Parameters

None

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Examples

OcNOS#cfm snmp restart

clear ethernet cfm delay-measurement history

Use this command to clear the CFM frame delay measurement history statistics from CFM_MEP DB.

Command Syntax

clear ethernet cfm delay-measurement history mep <1-8191> domain DOMAIN_NAME ma
 MA NAME

Parameters

MEPID	Local MEP identifier <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

#clear ethernet cfm delay-measurement history mep 123 domain no name ma 53322

clear ethernet cfm dm history

Use this command to clear the CFM frame delay measurement history statistics from CFM_MEP DB.

Command Syntax

clear ethernet cfm dm history mep MEPID domain DOMAIN_NAME ma MA_NAME

Parameters

MEPID	Local MEP identifier <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

#clear ethernet cfm dm history mep 123 domain no_name ma 123

clear ethernet cfm lm history

Use this command to clear the CFM frame loss measurement history statistics.

Command Syntax

clear ethernet cfm lm history mep MEPID domain DOMAIN_NAME ma MA_NAME s

Parameters

MEPID	Local MEP identifier <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

#clear ethernet cfm lm history mep 201 domain 12345 ma 123

clear ethernet cfm loss-measurement history

Use this command to clear the CFM frame loss measurement history statistics.

Command Syntax

```
clear ethernet cfm loss-measurement history mep <1-8191> domain DOMAIN_NAME ma MA NAME
```

Parameters

MEPID	Local MEP identifier <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#clear ethernet cfm loss-measurement history mep 201 domain 12345 ma 4327
```

clear ethernet cfm maintenance-point remote

Use this command to remove a dynamically learned RMEP.

The RMEP is relearned if rmep auto-discovery is enabled and a CCM (Continuity Checking Message) is received.

Command Syntax

clear ethernet cfm maintenance-points remote domain <DOMAIN-NAME>

Parameters

DOMAIN_NAME Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

#clear ethernet cfm maintenance-points remote domain
clear ethernet cfm statistics

Use this command to clear the CFM statistics.

Command Syntax

clear ethernet cfm statistics clear ethernet cfm statistics mep <MEPID> domain <DOMAIN_NAME> ma <MA_NAME>

Parameters

MEPID	MEP identifier <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

OcNOS#clear ethernet cfm statistics

clear ethernet cfm statistics bn

Use this command to clear the CFM Eth-BNM statistics.

Command Syntax

clear ethernet cfm statistics bn mep <MEPID> domain <DOMAIN NAME> ma <MA NAME>

Parameters

MEPID	MEP identifier <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 5.2.

Example

OcNOS#clear ethernet cfm statistics bn mep 123 domain 12345 ma 123

clear ethernet cfm statistics lck

Use this command to clear the CFM Eth-LCK statistics.

Command Syntax

clear ethernet cfm statistics lck mep <MEPID> domain <DOMAIN NAME> ma <MA NAME>

Parameters

MEPID	MEP identifier <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 6.3.0.

Example

OcNOS#clear ethernet cfm statistics lck mep 1 domain md001 ma ma01

clear ethernet cfm statistics test-signal

Use this command to clear the CFM ETH-Test receiver or generator statistics.

Command Syntax

```
clear ethernet cfm statistics test-signal domain <DOMAIN_NAME> ma <MANAME> mep
<MEPID> stats (CTF|GTF)
```

Parameters

MEPID	MEP identifier <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.
CTF	ETH Test Frame Collector statistics
GTF	ETH Test Frame Generator statistics

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 6.3.0.

```
OcNOS#clear ethernet cfm statistics test-signal domain md001 ma ma01 mep 1
stats gtf
OcNOS#clear ethernet cfm statistics test-signal domain md001 ma ma01 mep 2
stats ctf
```

clear ethernet cfm traceroute-cache

Use this command to clear the CFM traceroute cache entry.

Command Syntax

clear ethernet cfm traceroute-cache

Parameters

None

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

#clear ethernet cfm traceroute-cache

csf receive

Use this command to create Eth-CSF configuration and to enable/disable Eth-CSF for the Mep.

Command Syntax

```
csf receive
no csf receive
```

Parameters

None

Default

Eth-CSF is disabled by default.

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 5.2.

```
OcNOS(config)#ethernet cfm domain-type character-string domain-name abcde level 5
OcNOS(config-ether-cfm)#service ma-type string ma-name testtm
OcNOS(config-ether-cfm-ma)#vlan 5 bridge 10
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 201 active true xe2
OcNOS(config-ether-cfm-ma-mep)#csf receive
OcNOS(config-ether-cfm-ma-mep-csf)#commit
```

debug ethernet cfm

Use this command to enable debug for ethernet cfm .

Use no from of this command to disable debug for ethernet cfm

Command Syntax

```
debug ethernet cfm (all|events|rx|tx|loopback|traceroute)
no debug ethernet cfm (all|events|rx|tx|loopback|traceroute)
```

Parameters

all	Enable all debugs
events	Enable event debugs
loopback	Enable loopback debugs
rx	Enable receive debugs
traceroute	Enable traceroute debugs
tx	Enable transmit debugs

Default

None

Command Mode

Configure mode

Applicability

This command was introduced in OcNOS version 5.0 and option all is introduced in OcNOS version 6.3.0.

```
OcNOS(config)#debug ethernet cfm events
OcNOS(config)#debug ethernet cfm loopback
OcNOS(config)#debug ethernet cfm rx
OcNOS(config)#debug ethernet cfm tx
OcNOS(config)#debug ethernet cfm traceroute
OcNOS(config)#no debug ethernet cfm events
OcNOS(config)#no debug ethernet cfm loopback
OcNOS(config)#no debug ethernet cfm rx
OcNOS(config)#no debug ethernet cfm tx
OcNOS(config)#no debug ethernet cfm traceroute
OcNOS(config)#no debug ethernet cfm all
```

delay-measurement type on-demand

Use this command to schedule an on-demand CFM delay measurement session.

Command Syntax

```
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|RMEPID)
start-time (immediate|relative HH:MM:SS|absolute HH:MM:SS <1-31> MONTH <1993-
2035>) repetition-period <6000-4294967295> mep MEPID domain DOMAIN_NAME
```

Parameters

WORD	Delay measurement profile name	
MAC	Destination MAC address in HHHH.HHHH.HHHH format	
RMEPID	Destination peer MEP identifier <1-8191>	
start-time	Measurement session start time	
immediate	Start immediately	
relative HH:MM:	SS	
	Relative time to start from the current system time	
absolute HH:MM:	SS <1-31> MONTH <1993-2035>	
	Scheduled date and time to start; for the month, specify the first three letters	
stop-time	Measurement session stop time	
none	Never stop	
relative HH:MM:SS		
	Relative time to stop from the current system time	
absolute HH:MM:	SS <1-31> MONTH <1993-2035>	
	Scheduled date and time to stop; for the month, specify the first three letters	
<6000-4294967295>		
	Repetition time in centiseconds	
MEPID	Local MEP identifier <1-8191>	
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1	
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.	

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#delay-measurement type on-demand profile-name PROF1 rmep 101 start-time relative
00:00:03 stop-time relative 00:03:00 repetition-period 7000 mep 123 domain no_name ma
123
```

delay-measurement type proactive

Use this command to configure and start a proactive CFM delay measurement session.

Command Syntax

```
delay-measurement type proactive profile-name WORD rmep (mac-address MAC|RMEPID)
  mep MEPID domain DOMAIN NAME ma MA NAME
```

Parameters

WORD	Delay measurement profile name
MAC	Destination MAC address in HHHH.HHHH.HHHH format
RMEPID	Remote MEP identifier <1-8191>
MEPID	Local MEP identifier <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#delay-measurement type proactive profile-name 123 rmep 101 mep 123 domain no_name ma 123
```

ethernet cfm delay-measurement profile-name

Use this command to create a CFM frame delay measurement profile and enter Ethernet CFM delay measurement mode.

Use the no form of this command to remove a CFM delay measurement profile.

Command Syntax

ethernet cfm delay-measurement profile-name WORD no ethernet cfm delay-measurement profile-name WORD

Parameters

WORD Profile name

Command Mode

Configure mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#configure terminal
(config)#ethernet cfm delay-measurement profile-name PROF1
(config-cfm-dm)#
```

ethernet cfm delay-measurement reply

Use this command to enable transmission of DMR (Delay Measurement Reply) PDUs for received DMMs (Delay Measurement Messages).

After this command is given, a delay measurement session cannot be configured to send DMMs. In that case, the device can only generate DMRs for received DMM PDUs.

Use the no form of this command to disable sending DMR PDUs. After no command is given we can thereby configure a delay measurement session to send DMMs if we need.

Command Syntax

```
ethernet cfm delay-measurement reply dmm
no ethernet cfm delay-measurement reply dmm
```

Parameters

None

Command Mode

Ethernet CFM MA MEP mode

Applicability

This command was introduced in OcNOS version 3.0.

```
OcNOS#configure terminal
OcNOS(config)# ethernet cfm domain-type no-name domain-name no_name level 4
OcNOS(config-ether-cfm)#service ma-type string ma-name 7
OcNOS(config-ether-cfm-ma)#vlan 10 bridge 10
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 100 active true xe9
OcNOS(config-ether-cfm-ma-mep)#ethernet cfm delay-measurement reply dmm
```

ethernet cfm domain-type

Use this command to create a CFM Maintenance Domain (MD) in a bridge and enter Ethernet CFM mode.

Use the no form of this command to remove a domain.

Note: You can create up to 15 MDs in a bridge.

Only one domain can be created without any domain name in a bridge.

A domain name of type character-string can only created only after the hardware-profile filter cfmdomain-name-str command is executed.

Command Syntax

ethernet cfm domain-type (no-name|character-string) domain-name DOMAIN_NAME level
<0-7> mip-creation (none|default|explicit) |

no ethernet cfm domain-name DOMAIN_NAME

Parameters

domain-type	Domain type (must match service ma-type setting)
no-name	No MD name. The ma-type must be integer or itu-t carrier code (ICC) format defined by Y.1731.
character	-string
	Character string name. The ma-type must be string.
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
<0-7>	MD level
mip-creation	Maintenance Intermediate Point (MIP) creation permission for this domain
none	No MIP can be created for this VLAN identifier
default	MIP can be created if no lower active level or MEP at next lower active level
explicit	Maintenance End Point (MEP) is needed at the next lower active level

Command Mode

Configure mode

Applicability

This command was introduced in OcNOS version 3.0.

```
OcNOS(config)#
OcNOS(config)#ethernet cfm domain-type character-string domain-name 12347
level 7 mip-creation none
OcNOS(config-ether-cfm)#
```

ethernet cfm loss-measurement profile-name

Use this command to create a CFM frame loss measurement profile and enter Ethernet CFM loss measurement mode. Use the no form of this command to remove a CFM loss measurement profile.

Command Syntax

```
ethernet cfm loss-measurement profile-name WORD no ethernet cfm loss-measurement profile-name WORD
```

Parameters

WORD Profile name

Command Mode

Configure mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#configure terminal
(config)#ethernet cfm loss-measurement profile-name PROF1
(config-cfm-lm)#
```

ethernet cfm loss-measurement reply

Use this command to enable transmission of SLR (Synthetic Loss Reply) PDUs for received SLMs (Synthetic Loss Messages) and to enable transmission of LMR (Loss Measurement Reply) PDUs for received LMMs (Loss Measurement Messages).

After this command is given, a loss measurement session cannot be configured to send SLMs. In that case, the device can only generate SLRs for received SLM PDUs. The same is true for LMM/LMR also.

Use the no form of this command to disable sending SLR/LMR PDUs.

Command Syntax

```
ethernet cfm loss-measurement reply (slm | lmm)
no ethernet cfm loss-measurement reply (slm | lmm)
```

Parameters

slm	Synthetic Loss Messages
lmm	Loss Measurement Messages

Command Mode

Ethernet CFM MA MEP mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#configure terminal
(config) # ethernet cfm domain-type no-name domain-name no_name level 4 mip-creation none
OcNOS(config-ether-cfm) #service ma-type string ma-name 7
OcNOS(config-ether-cfm-ma) #vlan 10 bridge 1
OcNOS(config-ether-cfm-ma) #mip-creation none
OcNOS(config-ether-cfm-ma) #ethernet cfm mep down mpid 100 active true xe9
OcNOS(config-ether-cfm-ma-mep) #ethernet cfm loss-measurement reply slm
```

ethernet cfm mep

Use this command to create a Maintenance End Point (MEP), make it active or inactive and enter Ethernet CFM MA MEP mode.

A MEP created with the active false option remains inactive and CFM functionality is suspended for such a MEP. Note:

- 1. For a VPWS instance, only an up MEP can be created; a down MEP cannot be created for VPWS.
- 2. Vlan parameters is supported only for sub-interface and MA without any service.

Use the no form of this command to delete a MEP.

Command Syntax

```
ethernet cfm mep (down|up) mpid <1-8191> active (false|true) (IFNAME ((vlan <1-
4094> (inner-vlan <1-4094>)|)|vpws VCNAME | evpn <1-16777215>)
```

no ethernet cfm mpid <1-8191> $\,$

Parameters

down	Down MEP
up	Up MEP
active	Administrative state of the MEP
true	Make the MEP active
false	Make the MEP inactive
IFNAME	Interface name
vlan	Outer vlan
inner-vlan	Inner vlan
VCNAME	Virtual circuit name
evpn <id></id>	EVPN instance ID

Command Mode

Ethernet CFM MA mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

Physical Interface:

```
OcNOS(config)#ethernet cfm domain-type character-string domain-name md001
level 7
OcNOS(config-ether-cfm)#service ma-type string ma-name ma001
OcNoS(config-ether-cfm-ma)#vlan 11 bridge 1
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 666 active true ge9
```

Sub-interface:

OcNOS(config)#ethernet cfm domain-type character-string domain-name md001 level 7 OcNOS(config-ether-cfm)#service ma-type string ma-name ma001

OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 111 active true ge9.1 vlan 100

ethernet cfm mip

Use this command to create a static MIP on an interface.

Use the no form of this command to remove a static MIP from an interface.

Command Syntax

ethernet cfm mip interface IFNAME no ethernet cfm mip interface IFNAME

Parameters

IFNAME Interface name of MIP

Command Mode

Ethernet CFM MA mode

Applicability

This command was introduced in OcNOS version 3.0.

```
OcNOS#con term
Enter configuration commands, one per line. End with CNTL/Z.
OcNOS(config)#ethernet cfm domain-type character-string domain-name 12345
level 7 mip-creation default
OcNOS(config-ether-cfm)# service ma-type string ma-name mal
OcNOS(config-ether-cfm-ma)# vlan 25 bridge 1
OcNOS(config-ether-cfm-ma)# mip-creation default
OcNOS(config-ether-cfm-ma)# ethernet cfm mip interface ge5
OcNOS(config-ether-cfm-ma)#no ethernet cfm mip interface ge5
```

ethernet cfm statistics csf

Use this command to clear the CFM Eth-CSF statistics.

Command Syntax

clear ethernet cfm statistics csf mep <MEPID> domain <DOMAIN NAME> ma <MA NAME>

Parameters

MEPID	MEP identifier <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 5.2.

Example

OcNOS#clear ethernet cfm statistics csf mep 123 domain 12345 ma 123

ethernet cfm test-signal profile-name

Use this command to create a test signal configuration profile associated with a specific MEP.

Use no form of this command to delete a test signal configuration profile.

Command Syntax

```
ethernet cfm test-signal profile-name WORD no ethernet cfm test-signal profile-name WORD
```

Parameters

profile-name	Specify a profile-name
WORD	Specify the test signal profile name with max length of 64 characters

Command Mode

Configure mode

Applicability

This command was introduced in OcNOS version 4.0.

Example

```
#configure terminal
(config)#ethernet cfm test-signal profile-name 123
(config-cfm-eth-tst)#
```

(config) #no ethernet cfm test-signal profile-name 123

evpn

Use this command to create a service Maintenance Association (MA), with EVPN.

Command Syntax

evpn <ID>

Parameters

<1-16777215> Enter the EVPN ID. Range(1-16777215)

Command Mode

Ethernet CFM MA mode

Applicability

This command was introduced in OcNOS-SP version 6.1.0

```
#configure terminal
OcNOS(config)#ethernet cfm domain-type character-string domain-name 12345 level 7
OcNOS(config-ether-cfm)#service ma-type string ma-name 43982
OcNOS(config-ether-cfm-ma)#evpn 100
OcNOS(config-ether-cfm-ma)#ethernet cfm mep up mpid 103 active true evpn 100
```

ethernet cfm traceroute cache

Use this command to set the cache size for traceroute output.

Use the no form of this command to set the cache size to its default (100).

Command Syntax

```
ethernet cfm traceroute cache size <1-4095>
no ethernet cfm traceroute cache size <1-4095>
```

Parameters

<1-4095> Number of entries in cache

Default

100 entries

Command Mode

Configure mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#configure terminal
(config)#ethernet cfm traceroute cache size 1
```

exit-ether-ma-mep-mode

Use this command to exit Ethernet CFM MA MEP mode and go back to Ethernet CFM MA mode.

Command Syntax

exit-ether-ma-mep-mode

Parameters

None

Command Mode

Ethernet CFM MA MEP mode

Applicability

This command was introduced in OcNOS version 3.0.

Examples

OcNOS#configure terminal OcNOS(config)#ethernet cfm domain-type character-string domain-name 12345 level 7 OcNOS(config-ether-cfm)# service ma-type string ma-name testtm OcNOS(config-ether-cfm-ma)#vlan 5 bridge 10 OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 201 active true xe2 OcNOS(config-ether-cfm-ma-mep)#exit-ether-ma-mep-mode

exit-ether-ma-mode

Use this command to exit Ethernet CFM MA mode and go back to Ethernet CFM mode.

Command Syntax

exit-ether-ma-mode

Parameters

None

Command Mode

Ethernet CFM MA mode

Applicability

This command was introduced in OcNOS version 3.0.

```
OcNOS#configure terminal
OcnOS(config)#ethernet cfm domain-type character-string domain-name 12345
level 7
OcNOS(config-ether-cfm)#service ma-type string ma-name testtm
OcnOS(config-ether-cfm-ma)#exit-ether-ma-mode
```

frame priority

Use this command to set/reset the PDU frame priority in the Eth-lock.

Command Syntax

```
frame priority <0-7>
no frame priority
```

Parameters

<0-7> Set the PDU priority range.

Command Mode

Ethernet CFM MA MEP LCK mode

Applicability

This command was introduced in OcNOS version 4.0.

```
OcNOS#configure terminal
OcNOS(config)#ethernet cfm domain-type character-string domain-name 12345
level 7
OcNOS(config-ether-cfm)# service ma-type string ma-name mal
OcNOS(config-ether-cfm-ma)# vlan 25 bridge 10
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 201 active true xe2
OcNOS(config-ether-cfm-ma-mep)#lck state
OcNOS(config-ether-cfm-ma-mep-lck)#frame priority 3
```

hardware-profile filter cfm-domain-name-str

Use this command to enable or disable setting the CFM domain name as a character string.

Note: The hardware-profile filter cfm-domain-name-str enable command is only applicable for Qumran platforms and not J2C platforms.

Command Syntax

hardware-profile filter cfm-domain-name-str (enable|disable)

Parameters

enable	Enable CFM domain name as a character string
disable	Disable CFM domain name as a character string

Default

Disabled

Command Mode

Configure mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#configure terminal
(config)#hardware-profile filter cfm-domain-name-str enable
```

interval

Use this command to set/reset the PDU interval for Eth-lock.

Command Syntax

```
interval (1s|1m)
no interval
```

Parameters

lm	Transmit interval one minute.
1s	Transmit interval one second

Command Mode

Ethernet CFM MA MEP LCK mode

Applicability

This command was introduced in OcNOS version 4.0.

Example

OcNOS#configure terminal

Enter configuration commands, one per line. End with CNTL/Z.

```
OcNOS(config)#ethernet cfm domain-type character-string domain-name mdnam
level 7
OcNOS(config-ether-cfm)# service ma-type string ma-name testtm
OcNOS(config-ether-cfm-ma)#vlan 5 bridge 10
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 2 active true xel4
OcNOS(config-ether-cfm-ma-mep)lck state
OcNOS(config-ether-cfm-ma-mep-lck)#interval 1m
OcNOS(config-ether-cfm-ma-mep-lck)#interval 1s
```

intervals-stored

Use this command to set the number of frame loss measurement intervals to store in the history table.

Use the no form to set the number of measurement intervals to its default (32).

Command Syntax

```
intervals-stored <2-1000>
no intervals-stored
```

Parameters

<2-1000> Time intervals

Default

32

Command Mode

Ethernet CFM loss measurement mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#configure terminal
(config)#ethernet cfm loss-measurement profile-name PROF1
(config-cfm-lm)#intervals-stored 50
```

Ick state

Use this command to enable or disable ETH-Lock PDU transmission.

Use no form to remove the command.

Command Syntax

```
lck state (unlock|lock)
no lck state
```

Parameters

unlock	Display ethernet lock PDU transmission
lock	Enable ethernet lock PDU transmission

Command Mode

Ethernet CFM MA MEP mode.

Default lock state is Unlock.

Applicability

This command was introduced in OcNOS version 4.0.

```
OcNOS#configure terminal
OcNOS(config)#ethernet cfm domain-type character-string domain-name 12345
level 7
OcNOS(config-ether-cfm)# service ma-type string ma-name testtm
OcNOS(config-ether-cfm-ma)#vlan 5 bridge 10
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 201 active true xe2
OcNOS(config-ether-cfm-ma-mep)#lck state lock
OcNOS(config-ether-cfm-ma-mep-lck)#
```

link-level

Use this command to create a maintenance association for link-level MEPs (level 0) which do not listen on a VLAN.

Command Syntax

link-level (bridge <1-32>)

Parameters

<1-32> Bridge id

Command Mode

Ethernet CFM MA mode

Applicability

This command was introduced in OcNOS-SP version 5.1.

```
OcNOS#configure terminal
OcNOS(config)#ethernet cfm domain-type character-string domain-name 12345 level 0
OcNOS(config-ether-cfm)#service ma-type string ma-name ma1
OcNOS(config-ether-cfm-ma)#link-level
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 2331 active true xe2
```

loss-measurement type on-demand

Use this command to schedule an on-demand CFM loss measurement session.

Command Syntax

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|mep-id MEPID) start-time (immediate|relative HH:MM:SS|absolute HH:MM:SS <1-31> MONTH <1993-2035>) stop-time (none|relative HH:MM:SS|absolute HH:MM:SS <1-31> MONTH <1993-2035>) repetition-period <6000-4294967295> mep MEPID domain DOMAIN_NAME ma MA_NAME

Parameters

WORD	Loss measurement profile name	
MAC	Destination MAC address in HHHH.HHHH.HHHH format	
MEPID	Remote MEP identifier <1-8191> to which to send the service OAM loss measurement frame	
start-time	Measurement session start time	
immediate	Start immediately	
relative HH:	MM:SS	
	Relative time to start from the current system time	
absolute HH:	MM:SS <1-31> MONTH <1993-2035>	
	Scheduled date and time to start; for the month, specify the first three letters	
stop-time	Measurement session stop time	
none	Never stop	
relative HH:	MM:SS	
	Relative time to stop from the current system time	
absolute HH:	MM:SS <1-31> MONTH <1993-2035>	
	Scheduled date and time to stop; for the month, specify the first three letters	
repetition-peri	.od	
	Repetition time between measurement intervals	
<0-429496729	15>	
	Repetition time in seconds	
MEPID	Remote MEP identifier <1-8191> to which to send the service OAM loss measurement frame	
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1	
MA_NAME	MA name	

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#loss-measurement type on-demand profile-name slm rmep mac-address 0018.2323.1234
start-time immediate stop-time none repetition-period 9000 mep 201 domain 12345 ma 123
```

loss-measurement type proactive

Use this command to configure and start a proactive CFM loss measurement session.

Command Syntax

```
loss-measurement type proactive profile-name WORD rmep (mac-address MAC) mep MEPID domain DOMAIN NAME ma MA NAME
```

Parameters

WORD	Loss measurement profile name
rmep	Remote MEP
MAC	Destination MAC address in HHHH.HHHH.HHHH format
MEPID	Remote MEP identifier <1-8191> to which to send the service OAM loss measurement frame
mep	MEP
MEPID	MEP identifier <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	MA name

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#loss-measurement type proactive profile-name slm rmep mac-address
0018.2323.1234 mep 201 domain 12345 ma 123
```

measurement-interval

Use this command to set the measurement interval for frame loss or delay measurement session.

Use the no form of this command to set the measurement interval to its default value (15 minutes).

Command Syntax

Loss measurement:

```
measurement-interval <1-525600>
no measurement-interval
```

Delay measurement:

```
measurement-interval <1-1440>
no measurement-interval
```

Parameters

For frame loss measurement:

<1-525600> Measurement interval in minutes

For frame delay measurement:

<1-1440> Measurement interval in minutes

Default

15 minutes

Command Mode

Ethernet CFM loss measurement mode and Ethernet CFM delay measurement mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

Loss measurement:

#configure terminal
(config)#ethernet cfm loss-measurement profile-name PROF1
(config-cfm-lm)#measurement-interval 500

Delay measurement:

```
#configure terminal
(config)#ethernet cfm delay-measurement profile-name PROF1
(config-cfm-dm)# measurement-interval 1
```

measurement-type slm

Use this command to generate Frame Loss Message (SLM/LMM) service OAM PDUs and track replies (SLR/LMR).

The measurement-type CCM is a dual-ended frame loss method in which generated CCM PDUs carry frame loss measurement information (TxFCf, RxFCb and TxFCb).

Use the no form of this command to set the measurement type to its default value (slm).

SLM and LMM cannot be enabled at the same time. All MEPs can use either LMM or SLM for frame loss measurement.

Command Syntax

```
measurement-type (slm | lmm | ccm)
no measurement-type
```

Parameters

slm	SLM service PDUs are generated and SLRs is tracked for frame loss measurement.
lmm	LMM service PDUs are generated and LMRs is tracked for frame loss measurement.
CCM	CCM PDUs are used for frame loss measurement which carries frame loss measurement information.

Command Mode

Ethernet CFM loss measurement mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#configure terminal
(config)#ethernet cfm loss-measurement profile-name PROF1
(config-cfm-lm)#measurement-type slm
```

mep crosscheck

Use this command to configure a remote MEP crosscheck.

Use the no form of this command to delete a crosscheck MEP.

Command Syntax

mep crosscheck mpid MEPID
no mep crosscheck mpid MEPID

Parameters

MEPID Remote host MEP identifier <1-8191>

Command Mode

Ethernet CFM MA or MEP mode.

Applicability

This command was introduced in OcNOS version 3.0.

Example

Physical interface:

```
OcNOS#configure terminal
OcNOS(config)#ethernet cfm domain-type character-string domain-name 12345
level 7
OcNOS(config-ether-cfm)# service ma-type string ma-name testtm
OcNOS(config-ether-cfm-ma)#vlan 5 bridge 10
OcNOS(config-ether-cfm-ma)#mep crosscheck mpid 51
```

Sub-interface:

OcNOS#configure terminal OcNOS(config)#ethernet cfm domain-type character-string domain-name md001 level 7 OcNOS(config-ether-cfm)# service ma-type string ma-name md001 OcNOS(config-ether-cfm-ma)# ethernet cfm mep down mpid 11 active true xel.1 vlan 10 OcNOS(config-ether-cfm-ma-mep)# cc multicast state enable OcNOS(config-ether-cfm-ma-mep)# mep crosscheck mpid 2

mep lowest-priority-defect

Use this command to set the lowest-priority defect that can generate a fault alarm.

Use the no form of this command to set the lowest-priority defect to its default (defMACstatus).

Command Syntax

```
mep lowest-priority-defect
  (defRDICCM|defMACstatus|defRemoteCCM|defErrorCCM|defXconCCM)
```

```
no mep lowest-priority-defect
```

Parameters

defRDICCM	1 (lowest): At least one of the Remote MEP state machines is receiving valid CCMs from its remote MEP that has the Remote Defect Indication (RDI) bit set.
defMACstatus	2: One or more of the remote MEPs is reporting a failure in its Port Status Type-Length- Value (TLV) or Interface Status TLV: MEP Down.
defRemoteCCM	3: At least one of the remote MEP state machines is not receiving valid CCMs from its remote MEP.
defErrorCCM	4: One or more invalid CCMs has been received, and 3.5 times the CCMs' transmission interval has not yet expired.
defXconCCM	5: (highest): One or more cross-connect continuity check messages (CCMs) has been received, and 3.5 times at least one of those CCMs' transmission interval has not yet expired.

Default Value

defMACstatus

Command Mode

Ethernet CFM MA MEP mode

Applicability

This command was introduced in OcNOS version 3.0.

```
OcNOS#configure terminal
OcNOS(config)#ethernet cfm domain-type character-string domain-name 12345 level 7
OcNOS(config-ether-cfm)#service ma-type string ma-name testtm
OcNOS(config-ether-cfm-ma)#vlan 5 bridge 10
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 201 active true xe2
OcnOS(config-ether-cfm-ma-mep)#mep lowest-priority-defect defRemoteCCM
```
message level

Use this command to set the PDU MD level for Eth-lock.

Command Syntax

```
message level <0-7>
no message level
```

Parameters

<0-7> Set the level of the MD PDU.

Command Mode

Ethernet CFM MA MEP LCK mode

Applicability

This command was introduced in OcNOS version 4.0.

```
OcNOS#configure terminal
OcNOS(config)#ethernet cfm domain-type character-string domain-name 12345
level 7
OcNOS(config-ether-cfm)# service ma-type string ma-name testtm
OcNOS(config-ether-cfm-ma)#vlan 5 bridge 10
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 201 active true xe2
OcNOS(config-ether-cfm-ma-mep)#lck state
OcNOS(config-ether-cfm-ma-mep-lck)#message level 2
```

message-period

Use this command to set the interval between loss or delay measurement OAM message transmission.

Use the no form of this command to set the interval between loss or delay measurement messages to its default value (1 second).

Command Syntax

```
message-period (3ms|10ms|100ms|1s|10s)
no message-period
```

Parameters

3ms	3 milliseconds
10ms	10 milliseconds
100ms	100 milliseconds
1s	1 second
10s	10 seconds

Default Value

1 second

Command Mode

Ethernet CFM loss measurement mode

Ethernet CFM delay measurement mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

Loss measurement:

```
#configure terminal
(config)#ethernet cfm loss-measurement profile-name PROF1
(config-cfm-lm)#message-period 3ms
```

Delay measurement:

```
#configure terminal
(config)#ethernet cfm delay-measurement profile-name PROF1
(config-cfm-dm)#message-period 10s
```

mip-creation

Use this command for Maintenance domain Intermediate Point (MIP) creation permission for this domain.

Command Syntax

```
(mip-creation (none|default|explicit|defer))|
```

Parameters

mip-creation	Maintenance domain Intermediate Point (MIP) creation permission for this domain
none	No MIP can be created for this VLAN identifier
default	MIP can be created if no lower active level or MEP at the next lower active level
explicit	MEP is needed at the next lower active level
defer	Use the MIP creation permissions of the MD to which this MA belongs

Command Mode

Ethernet CFM MA mode

Applicability

This command was introduced in OcNOS-SP version 5.1.

Example

OcNOS#configure terminal OcNOS(config)#ethernet cfm domain-type character-string domain-name 12345 level 7 mipcreation none OcNOS(config-ether-cfm)#service ma-type string ma-name 43982 OcNOS(config-ether-cfm-ma)#vlan 10 bridge 10 OcNOS(config-ether-cfm-ma)#mip-creation none OcnOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 2331 active true xe2

intervals-stored

Use this command to set the number of completed measurement intervals to store in the history statistic table for a twoway performance monitoring frame delay measurements on a specific MEP.

Use the no form to set the number of completed measurement intervals to store in the history statistic table for a twoway performance monitoring frame delay measurements on a specific MEP to its default (32).

Command Syntax

```
intervals-stored <2-1000>
no intervals-stored
```

Parameters

<2-1000> Number of records to store in history

Default

32

Command Mode

Ethernet CFM delay measurement mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#configure terminal
(config)#ethernet cfm delay-measurement profile-name PROF1
(config-cfm-dm)# intervals-stored 4
```

peer-port-id

Use this command to specify peer port-id for Eth-BNM. When this CLI is configured, received BNM PDU will be processed only if peer port-id value in PDU is same as configured peer-port-id. When this CLI is not configured, received BNM PDU is processed without peer port-id validation.

Use no form of CLI to unconfigure peer port id.

Command Syntax

```
peer-port-id <1-4294967295>
no peer-port-id
```

Parameters

<1-4294967295> Enter the peer port-id.Default is 0.

Command Mode

Ethernet CFM MEP BNM mode

Applicability

This command was introduced in OcNOS version 5.2.

```
OcNOS#configure terminal
OcNOS(config)#ethernet cfm domain-type character-string domain-name 12345 level 7 m
OcNOS(config-ether-cfm)#service ma-type string ma-name 43982
OcNOS(config-ether-cfm-ma)#vlan 10 bridge 10
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 2331 active true xe2
OcNOS(config-ether-cfm-ma-mep)# bn receive
OcNOS(config-ether-cfm-ma-mep-bn) peer-port-id 1234
```

ping ethernet mac

Use this command to send a loopback message for a MAC address to a remote MEP for fault verification. Use either the domain or the level parameter with the vlan or bridge parameter to target a specific device.

Command Syntax

ping ethernet mac MACADDRESS unicast source MEPID domain DOMAIN_NAME ma MA_NAME

Parameters

MACADDRESS	Destination MAC address in HHHH.HHHH.HHHH format
MEPID	Source host MEP ID <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	MA name

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Examples

#ping ethernet mac 0018.236e.5eb5 unicast source 201 domain 12345 ma 123

rmep auto-discovery

Use this command to enable or disable whether MEPs are discovered automatically based on received CCMs (Continuity Checking Messages).

On disabling RMEP auto-discovery, a previously learned RMEP is removed.

Command Syntax

```
rmep auto-discovery enable|disable
```

Parameters

enable	Enable automatic RMEP discovery
disable	Disable automatic RMEP discovery

Default

disable

Command Mode

Ethernet CFM MA or MEP mode

Applicability

This command was introduced in OcNOS version 3.0.

Examples

Physical interface:

```
OcNOS(config)#ethernet cfm domain-type character-string domain-name md002
level 7
OcNOS(config-ether-cfm)#service ma-type string ma-name ma002
Ocnos(config-ether-cfm-ma)#vlan 100 bridge 1
OcNOS(config-ether-cfm-ma-mep)#ethernet cfm mep down mpid 111 active true xe3
OcNOS(config-ether-cfm-ma-mep)#cc multicast state enable
OcNOS(config-ether-cfm-ma-mep)#rmep auto-discovery enable
```

Sub-interface:

```
OcNOS#configure terminal
OcNOS(config)#ethernet cfm domain-type character-string domain-name md001
level 7
OcNOS(config-ether-cfm)# service ma-type string ma-name ma001
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 11 active true xe1.1
vlan 10
OcnOS(config-ether-cfm-ma-mep)#rmep auto-discovery enable
```

service ma-type

Use this command to create a service Maintenance Association (MA), and enter Ethernet CFM MA mode. This command allows creation of a maintenance association for link-level MEPs (level 0) which do not listen on a VLAN.

A VID can be associated with an MA after MA is created.

Use the no form of this command to remove an MA.

Command Syntax

Ethernet CFM mode

service ma-type (string|integer|itu-t) ma-name MA_NAME

```
no service ma-name MA_NAME
```

Command Mode

Ethernet CFM mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

OcNOS#con term Enter configuration commands, one per line. End with CNTL/Z. OcNOS(config)#ethernet cfm domain-type character-string domain-name mdnam level 7 OcNOS(config-ether-cfm)#service ma-type string ma-name testtm

show ethernet cfm ais reception-status

Use this command to display information about the AIS (Alarm Indication Signal) frames received on a MEP.

Command Syntax

show ethernet cfm ais reception-status mep MEPID domain DOMAIN_NAME(ma-name MA_NAME

Parameters

MEPID	Source host MEP ID <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Maintenance association name (if type is character string maximum length of ma-name is 6. If type is integer maximum is 2-octets)
<1-32>	Bridge identifier

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

#show ethernet cfm ais reception-status mep 100 domain 12345

show ethernet cfm bn

Use this command to display information about Eth-BNM.

Command Syntax

show ethernet cfm bn

Parameters

None

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 5.2.

#show MEPID BW (Mbp 	ethernet Domain s) Curre	cfm bn MA-Name nt-BW(mbps 	Interface 5)	VLAN	S-Addr	Port-ID	Nominal-
 100 100	12345	123	xe2	100	00:00:11:11:11:1	L1 100	200
200 300	12345	124	xe1	200	00:00:11:11:11:1	L2 200	100
300 400	12445	123	xe3	300	00:00:11:11:11:1	100	300

show ethernet cfm bn mep

Use this command to display detail information about Eth-BNM configured on MEP.

Command Syntax

show ethernet cfm bn mep MEPID domain DOMAIN_NAME ma MA_NAME

Parameters

MEPID	Source host MEP ID <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Maintenance association name (if type is character string maximum length of ma-name is
	6. If type is integer maximum is 2-octets)

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 5.2.

```
#show ethernet cfm bn mep 100 domain 12345 ma 123
MA-Name : 223
MEL: 4
Admin Status : Enable
Interface : xe1
VLAN : 100
Source address : 00:00:11:11:11:11
Wait to Restore timer: 200 sec
State : SIGNAL_DEGRADED
Elapsed time in this state : 00:00:02
Last BNM Received : 2022 Mar 03 17:19:23
Nominal Bandwidth : 800 Mbps
Current Bandwidth : 600 Mbps
Port-Id : 2
BNM Period : 1 sec
```

show ethernet cfm csf

Use this command to display information about Eth-CSF.

Command Syntax

show ethernet cfm csf

Parameters

None

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 5.2.

Example

show ethernet cfm csf mep

Use this command to display detail information about Eth-CSF configured on MEP.

Command Syntax

show ethernet cfm csf mep MEPID domain DOMAIN_NAME ma MA_NAME

Parameters

MEPID	Source host MEP ID <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Maintenance association name (if type is character string maximum length of ma-name is

6. If type is integer maximum is 2-octets)

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 5.2.

```
#show ethernet cfm csf mep 100 domain 12345 ma 123
MA-Name : 123
MEL: 4
Admin Status : Enable
Interface : xe1
VLAN : 100
Source address : 00:00:11:11:11:11
Wait to Restore timer: 200 sec
State : SIGNAL_DEGRADED
Elapsed time in this state : 00:00:04
Last CSF Received : 2022 Mar 03 17:19:23
CSF Period : 1 sec
CFS Type : LOS
```

show ethernet cfm delay-measurement mep

Use this command to display delay measurement statistics for a MEP both for current and history or individually.

Command Syntax

```
show ethernet cfm delay-measurement mep MEPID domain DOMAIN_NAME (ma-name MA_NAME)
  ((current-stats|history-stats)|)
```

Parameters

MEPID	Local MEP identifier<1-8191>	
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-strin otherwise no_name if domain-type is no-name1	
MA_NAME	MA name	
current-stats	Current session DB statistics.	
history-stats	History DB statistics.	

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#show ethernet cfm delay-measurement mep 123 domain no name ma 200
MEP:
      123
MA : 200
VLANID: 10
PeerMAC Address:0000.0010.0000
CURRENT:
_____
Measurement ID : 2
Measurement Type:DMM
Elapsed time(sec):30
Start Time:2019 May 24 04:52:37
Min Frame Delay(usec):4
Max Frame Delay(usec):105
Avg Frame Delay(usec):81
Min Inter FD Variation(usec):34
Max Inter FD Variation(usec):34
Avg Inter FD Variation (usec):19
FRAME DELAY BINS
```

______ 0 - < 49993 1 5000- <99990 2 3 10000- <Inf0 INTER-FRAME DELAY BINS Bin NumberBin Threshold(usec)Bin Counter _____ 1 0 - < 49992 2 5000- <Inf0 HISTORY STATISTICS _____ MD : no name MA : 200 MEP: 123 VLAN ID: 10 Measurement ID : 1 Measurement Type: DMM Elapsed time(sec): 60 End Time: 2019 May 24 04:52:37 Min Frame Delay(usec): 56 Max Frame Delay(usec): 87 Avg Frame Delay(usec): 67 Min Inter FD Variation(usec): 1 Max Inter FD Variation(usec): 31 Avg Inter FD Variation(usec): 12 FRAME DELAY BINS Bin NumberBin Threshold(usec)Bin Counter 1 0 - < 49995 2 5000- <99990 3 10000- <Inf0 INTER-FRAME DELAY BINS Bin NumberBin Threshold(usec)Bin Counter _____ 1 0 - < 49994 2 5000- <Inf0

Table 1-1 explains the output fields.

Field	Description
MEP	Local Maintenance End Point identifier
МА	Maintenance Association name

Table 1-1: show ethernet cfm dm sessions

Field	Description
Vlan Id	Primary vlan identifier of MA
DM-Profile	delay measurement profile name
Peer MAC Address	Peer's MAC address
Measurement ID	Id of the current or history session for that particular measurement interval
Measurement Type	One way or two way DM
Elapsed time	Time still left to complete the measurement interval
Start time	Time when DM session started
Min frame delay	Minimum delay recorded
Max frame delay	Max delay recorded
Avg frame delay	Average delay calculated
Min Inter FD Variation	Minimum inter frame delay variation calculated
Max Inter FD Variation	Maximum inter frame delay variation calculated
Avg Inter FD Variation	Average inter frame delay variation calculated
FRAME DELAY BINS	Frame delay bin configuration
INTER-FRAME DELAY BINS	Inter frame delay bin configuration
Bin Number	Bin number for which the threshold and counter is configured
Bin Threshold	A bin's configured threshold value
Bin counter	The number of delays recorded in this range
RMEP Id	Peer's MEP Id
End time	The time when the Measurement Interval was completed.
MD	Maintenance domain name

Table 1-1: show ethernet cfm dm sessions

show ethernet cfm delay-measurement profile

Use this command to display information about a specified delay measurement profile or all configured delay measurement profiles.

Command Syntax

show ethernet cfm delay-measurement profile (WORD|)

Parameters

WORD

Profile name.

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

```
#sh ethernet cfm delay-measurement profile dmm
Profile Name: dmm
Measurement-type
                    – DMM
Measurement-interval - 1
Message-period - 10s
Number of intervals stored - 4
Bins per FD Interval
                          _
                             4
                         - 3
Bins per IFDV Interval
      Frame Delay Bins
Bin Number Bin Threshold
 1
                 0
 2
                 1
 3
                 4
   Inter-Frame Delay Bins
Bin Number Bin Threshold
 1
                 0
 2
                 5000
```

Table 1-2 explains the output fields.

Field	Description
Profile Name	Loss measurement profile name
Measurement-type	DM session is one way or two way

Table 1-2: show ethernet cfm delay-measurement profile

Field	Description
Measurement-interval	See measurement-interval
message-period	See message-period
Number of intervals stored	See intervals-stored
Bins per FD Interval	See bins-per-fd-interval
Bins per IFDV Interval	See bins-per-ifdv-interval
Frame Delay Bins	Number of Frame Delay bins configured
Inter-Frame Delay Bins	Number of Inter-Frame Delay bins configured
Bin number	See bin-type
Bin threshold	See bin-type

Table 1-2: show ethernet cfm delay-measurement profile

show ethernet cfm dm sessions

Use this command to display information about the delay measurement session.

Command Syntax

show ethernet cfm dm sessions

Parameters

None

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

#show e	ethernet	cfm dm sessions				
MEP-Id	Status	StartTime	DM-Profile	Mac-address	Repetition	Period(sec)
123	Active	2019/06/01 13:14:46	123	0018.236e.5eb5	60	

Table 1-3 explains the output fields.

Table 1-3: show ethernet cfm dm sessions

Field	Description
MEP-Id	Local Maintenance End Point identifier
Status	Inactive: if delay measurement session is not started Active: if delay measurement session is started
StartTime	Time when delay measurement session is started
DM-Profile	delay measurement profile name
Mac-address	MAC address
Repetition Period	Repetition time between measurement intervals in seconds

show ethernet cfm errors

Use this command to verify the defects present in a MEP.

Command Syntax

show ethernet cfm errors (domain DOMAIN_NAME)

Parameters

DOMAIN_NAME Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

#show ethernet	cfm errors	domain	12345	
Domain Name	Level	Vlan	MEPID	Defects
12345	7	10	100	

Table 1-4 explains the output fields

Table 1-4: show ethernet cfm errors

Field	Description
Domain Name	Maintenance Domain name
Level	MD Level
Vlan	Vlan identifier
MEPID	Maintenance End Point identifier
Defects	Defects in current MEP

show ethernet cfm eth-bn status

Display ETH-BN status for the MEP.

Command Syntax

show ethernet cfm eth-bn status

Parameters

None

Default

NA

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 5.0

Examples

OcNOS#show ethernet cfm eth-bn status

BNM status for interface xe9

state	:	SIGNAL NORMAL
Hold Time	:	60 —
Restore Time	:	90
Total BNM Receive Count	:	0
Sender Address	:	0000.0000.0000
Elapsed time in this stat	e:	00:17:54
Nominal Bandwidth	:	0
Current Bandwidth	:	0
Lowest Bandwidth	:	1250000000
Last BNM Received	:	NIL
BNM Period	:	1
Hold Timer	:	Not Running
Wait-to-Restore Timer :		Not Running
OcNOS#		5

show ethernet cfm frame-Im session

Use this command to display information about the frame loss measurement session.

Command Syntax

show ethernet cfm frame-lm session

Parameters

None

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

```
#show ethernet cfm frame-lm session
MEPID Status StartTime Lm-profile Mac-address Repetition Period(sec)
201 Active 2018/10/01 00:18:46 slm 0018.236e.5eb5 60
```

Table 1-5 explains the output fields.

Table 1-5: show ethernet cfm frame-Im session

Field	Description
MEPID	Maintenance End Point identifier
Status	Inactive: if loss measurement is not in progress Active: otherwise
StartTime	When loss measurement started
Lm-profile	Loss measurement profile name
Mac-address	MAC address
Repetition Period	Repetition time between measurement intervals in seconds

show ethernet cfm lck details domain

Use this command to display a CFM lock user configuration.

Command Syntax

show ethernet cfm lck details domain DOMAIN_NAME ma MA_NAME mep MEPID

Parameters

domain	Specify domain.
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
ma	Specify Maintenance association name
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.
mep	Specify mep
MEPID	Enter the MEPID ranging from <1-8191>

Command Mode

Exec mode

Default

None

Applicability

This command was introduced in OcNOS version 4.0.

Example

#show ethernet cfm lck details domain 12345 ma 200 mep 151

Maintenance Domain	:	12345
Maintenance Association	:	200
MEP ID	:	151
LCK PDU state	:	Locked
LCK Message Level	:	7
LCK PDU Interval	:	1 min
LCK PDU Priority	:	3

show ethernet cfm lck statistics

Use this command to display a CFM lock statistics for a MEP.

Command Syntax

show ethernet cfm lck statistics mep MEPID domain DOMAIN_NAME

Parameters

domain	Specify domain.
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
mep	Specify mep
MEPID	Enter the MEPID ranging from <1-8191>

Command Mode

Exec mode

Default

None

Applicability

This command was introduced in OcNOS version 4.0.

Example

show ethernet cfm loss-measurement mep

Use this command to display frame loss measurement statistics for a MEP.

Command Syntax

show ethernet cfm loss-measurement mep MEPID domain DOMAIN_NAME (ma-name MA_NAME)

Parameters

MEPID	Host MEP identifier <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	MA name

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#show ethernet cfm loss-measurement mep 201 domain 12345 ma 43982
MEP: 201 MA: 43982 CURRENT:
Measurement ID : 3
Measurement Type: slm
Elapsed time(sec): 51
Start Time: 2018 Nov 19 22:37:31
Near End loss: 0
Far End loss: 0
Near End accumulated loss : 0 Far End accumulated loss: 0
HISTORY:
 Measurement ID : 1
 Measurement Type
                             : slm
 Elapsed time(sec)
                           : 60
 End Time
                            : 2018 Nov 19 22:36:31
  Near End loss
                           : 0
  Far End loss
                             : 0
  Near End accumulated loss : 0
  Far End accumulated loss : 0
 Measurement ID : 2
  Measurement Type
                           : slm
 Elapsed time(sec)
                           : 60
  End Time
                           : 2018 Nov 19 22:37:31
  Near End loss
                            : 0
  Far End loss
                             : 0
```

Near End accumulated loss : 0 Far End accumulated loss : 0

Table 1-6 explains the output fields.

Table 1-6: show ethernet cfm loss-measurement mep

Field	Description
MEP	Maintenance End Point identifier
MA	Maintenance Association name
CURRENT:	Current loss measurement statistics
HISTORY:	Historic loss measurement statistics
Measurement ID	Sequence number
Measurement Type	See measurement-type slm
Elapsed time	Elapsed time in seconds
Start Time	Start time
End Time	End time
Near End loss	Near end loss
Far End loss	Far end loss
Near End accumulated loss	Near end accumulated loss
Far End accumulated loss	Far end accumulated loss

show ethernet cfm loss-measurement profile

Use this command to display information about a given loss measurement profile or all loss measurement profiles.

Command Syntax

show ethernet cfm loss-measurement profile WORD

Parameters

WORD

Profile name.

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

```
#show ethernet cfm loss-measurement profile slm
Profile Name:slm
measurement-type - slm
measurement-interval - 1
intervals-stored - 3
message-period - 1
```

Table 1-7 explains the output fields.

Table 1-7: show ethernet cfm loss-measurement profile

Field	Description
Profile Name	Loss measurement profile name
measurement-type	See measurement-type slm
measurement-interval	See measurement-interval
intervals-stored	See intervals-stored
message-period	See message-period

show ethernet cfm ma status

Use this command to display the connectivity status of Maintenance Associations (MAs) in a domain.

Command Syntax

```
show ethernet cfm ma status domain DOMAIN_NAME (mep <1-8191>| mep all|) (ma-name
MA NAME)
```

Parameters

DOMAIN_NAME	IAIN_NAME Enter the name of the domain. Name must be of 5 characters if type is character- otherwise no_name if domain-type is no-name1		
<2-4094>	VLAN identifier		
mep	Host MEP		
<1-8191>	Host MEP identifier		
all	All host MEPs		
MA_NAME	Maintenance association name. If ma-type is character string then maximum length of ma name is 6 else if it's integer then maximum is 2-octets		

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

#sł MA	now NAM	ethernet Æ	cfm ma VLAN	status	domain	12345 STATU	ma JS	43982
	1398	32	10			Activ	ve	
#sł	low	ethernet	cfm ma	status	domain	12345		
MA	NAM	4Ε 		STAT	rus			
4	1398	31		Act	ive			

Table 1-8 explains the output fields.

Table 1-8: show ethernet cfm ma status

Field	Description
MA NAME	Maintenance Association name

Field	Description
VLAN	VLAN identifier
STATUS	Active: All connected MEPs in MA are receiving the CCM with no defect or alarm present Partially Active: One or more connected MEPs in MA is not receiving CCM or it is receiving CCM with defect or alarm present Not Active: None of the connected MEPS in MA are receiving CCM or it is receiving CCM with defect or alarm present

Table 1-8: show ethernet cfm ma status (Continued)

show ethernet cfm maintenance-points count

Use this command to display information about the Total CFM sessions Count on a given interface.

Command Syntax

show ethernet cfm maintenance-points count IFNAME

Parameters

IFNAME Interface name

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 6.3.0.

Example

OcNOS#show ethernet cfm maintenance-points count xe6

```
Total No of MIPs
                                : 0
Total No of MEPs
                                : 6
Total No of UP MEPs
                                : 0
Total No of Down MEPs
                               : 6
Total No of Active MEP's
                               : 6
Total No of UP CCM sessions
                             : 5
Total No of Active Test sessions : 0
Total No of Active LM sessions : 0
Total No of Active DM sessions : 0
New: Total No of Active MEPs
                                         : 6
Old : Total No of Active CCM sessions : 6
```

show ethernet cfm maintenance-points local mep

Use this command to display information about the Maintenance End Points (MEPs) on a local interface.

Command Syntax

```
show ethernet cfm maintenance-points local (mep) (interface IFNAME|)(domain
DOMAIN NAME) (ma-name MA NAME)
```

Parameters

IFNAME	Interface name. This token can be used only for Down MEPs on L2 bridge.
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	Maintenance association name.

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

#show ethernet cfm maintenance-points local mep domain 12345 ma 123
MPID Dir Lvl VLAN CC-Stat HW-Status CC-Intvl MAC-AddressDef Port MD Name
100 Dn 7 10 EnableInstalled 100 ms3c2c.99f0.b0c1 Fxe212345

#show ethernet cfm maintenance-points local mep domain 12345 ma 123
MPID Dir Lvl CC-Stat HW-Status CC-Intvl MAC-AddressDef Port MD Name

200 Up 7Enable Installed 3 ms0018.23c8.f822 Fxe15 12345

Table 1-9: show ethernet cfm maintenance-points local mep Field Description MPID MEP identifier Dir Up MEP or Down MEP Lvl MD level Vlan VLAN identifier CC-Stat Whether continuity checking (CC) is enabled or disabled HW-Status Installed or pending to install in hardware CC-Intvl CCM Interval

Table 1-9 explains the output fields.

Field	Description
MAC-Address	MAC address
Def	Defect present
Port	CFM interface
MD Name	MD name

Table 1-9: show ethernet cfm maintenance-points local mep

show ethernet cfm maintenance-points local mip

Use this command to display information about the Maintenance Intermediate Points (MIPs) on a local interface.

Command Syntax

```
show ethernet cfm maintenance-points local (mip) (interface IFNAME| (level <0-7>)
  (ma-name MA NAME|))
```

Parameters

IFNAME	Interface name.
<0-7>	Maintenance level.
MA_NAME	Maintenance association name. If ma-type is character string then maximum length of ma- name is 6 else if it's integer then maximum is 2-octets

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

#show	ethern	et cfm	mainte	enance-points	local	mip	level	7	ma	123
Level	VID	Туре	Port	MAC-Address						
								-		
7	10	MIP	xe3	0018.23ea.da3	36					
7	10	MIP	xe5	0018.23ea.da3	38					

Table 1-10 explains the output fields.

Table 1-10: show ethernet cfm maintenance-points local mip

Field	Description
Level	MD level
VID	VLAN identifier
Туре	МІР
Port	Interface name
MAC-Address	MAC address

show ethernet cfm maintenance-points remote

Use this command to display information about a remote MEP.

Command Syntax

```
show ethernet cfm maintenance-points remote (mpid MEP_ID|) (domain DOMAIN_NAME)(ma-
name MA NAME)
```

Parameters

MEP_ID	Remote MEP identifier <1-8191>
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
MA_NAME	MA name

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

```
#show ethernet cfm maintenance-points remote domain 12345
MEPIDRMEPIDLEVELVLANRx CCMRDIPEER-MACTYPE
```

1002007 10 YesFalsea82b.b579.fd2aConfigured

Table 1-11 explains the output fields.

Table 1-11: show ethernet cfm maintenance-points remote

Field	Description
MEPID	MEP identifier
RMEPID	Remote MEP identifier
LEVEL	MD level
VLAN	VLAN identifier
Rx CCM	Yes if CCM receives, no if CCM doesn't receive.
RDI	Whether Remote Defect Indication (RDI) is on or off
PEER-MAC	Remote MEP mac address
TYPE	Configured or auto learned

show ethernet cfm statistics

Use this command to display CFM statistics: CCM sent and received, LBM sent and LBR received, LTM sent and LTR received.

Command Syntax

show ethernet cfm statistics mep MEPID domain DOMAIN_NAME ma-name MA_NAME

Parameters

MEPID	Host MEP identifier <1-8191>
MA_NAME	Maintenance association name. If ma-type is character string then maximum length of ma- name is 6 else if it's integer then maximum is 2-octets
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

Example

#show ethernet cfm statistics				
Continuity Check Messages				
CCM Sent	:	168164		
CCM Received	:	165460		
Loop Back Messages				
LBM Sent	:	5		
LBR Received(Valid)	:	5		
LBR Received(Bad msdu)	:	0		
LBR Received(Out-of-Seq)	:	0		
Link Trace Messages				
LTM Sent	:	1		
LTR Sent	:	0		
LTR Received(Valid)	:	3		
LTR Received(unexpected)	:	0		

Table 1-12 explains the output fields.

Table 1-12: show ethernet cfm sta	tatistics
-----------------------------------	-----------

Field	Description		
Continuity Check Messages			
CCM Sent	Number of continuity check messsages (CCMs) sent		

Field	Description	
CCM Received	Number of CCMs received	
Loop Back Messages		
LBM Sent	Number of loopback messages (LBMs) sent	
LBR Received(Valid)	Number of valid LBRs received	
LBR Received(Bad msdu)	Number of LBRs received with bad MAC service data unit	
LBR Received(Out-of- Seq)	Number of out-of-sequence LBRs received	
Link Trace Messages		
LTM Sent	Number of link trace messages (LTMs) sent	
LTR Received(Valid)	Number of link trace replies (LTRs) received	
LTR Received(unexpected)	Number of unexpected LTRs received	

Table 1-12: show ethernet cfm statistics
show ethernet cfm statistics bn

Use this command to display CFM Eth-BNM statistics.

Command Syntax

show ethernet cfm statistics bn

Parameters

None

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 5.2.

Example

 #show ethernet cfm statistics bn

 MEPID
 Domain
 MA-Name
 RX-Frames
 Dropped-Frames
 WR-time-left

 100
 12334
 123
 10001
 11 sec

 200
 12341
 234
 12000
 off

 300
 12421
 123
 13000
 12 sec

show ethernet cfm statistics csf

Use this command to display CFM Eth-CSF statistics.

Command Syntax

show ethernet cfm statistics csf

Parameters

None

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 5.2.

Example

 #show ethernet cfm statistics csf

 MEPID
 Domain
 MA-Name
 RX-Frames
 Dropped-Frames
 WR-time-left

 100
 12334
 123
 10001
 11 sec

 200
 12341
 234
 12000
 off

 300
 12421
 123
 13000
 12 sec

show ethernet cfm test-signal domain

Use this command to display ETH-Test receiver or generator statistics.

Command Syntax

```
show ethernet cfm test-signal domain DOMAIN_NAME ma MA_NAME mep MEPID stats
  (ctf|gtf)
```

Parameters

DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
ma	Specify Maintenance association name
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.
mep	Specify mep
MEPID	Enter the MEPID ranging from <1-8191>
stats	Display the statistics
ctf	Display ETH Test Frame Collector statistics
gtf	Display ETH Test Frame Generator statistics

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 4.0.

```
#show ethernet cfm test-signal domain 12345 ma 43982 mep 21 stats gtf
TST Session status : In-Progress
                           : 36
Elapsed Time(sec)
                          : 12345
MD
                          : 43982
MA
MEP
                          : 21
                         : 6cb9.c557.42d0
Peer MAC Address
                           : 12
RMEP ID
Start Time
                          : 2019 Mar 01 10:23:11
Transmitted Packet Count : 2854713
```

show ethernet cfm test-signal profile

Use this command to display ETH-Test signal profile configuration.

Command Syntax

```
show ethernet cfm test-signal profile (WORD|)
```

Parameters

WORD

Specify the test signal profile name with max length of 64 characters

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 4.0.

```
#show ethernet cfm test-signal profile 123
Profile Name : 123
Is Receiver : False
Is Generator : True
Test-Signal Type : In-Service
Frame Size(bytes) : 124
Test Pattern Type : Null-Signal-Without-CRC-32
```

show ethernet cfm test-signal sessions

Use this command to display CFM test-signal session.

Command Syntax

show ethernet cfm test-signal sessions

Parameters

None

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 4.0.

```
OcNOS#show ethernet cfm test-signal sessions
MEP-Id Status StartTime Tst-Profile Peer MAC-Address
```

show ethernet cfm traceroute-cache

Use this command to display the ethernet cfm traceroute cache

Command Syntax

show ethernet cfm traceroute-cache

Parameters

None

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 4.0.

OcNOS#show	ethernet cfm t	raceroute-cache	bridge 1
MEPID	Dest mac	Hops	Relay-action
2	e8c5.7a91.f8c	4 1	RlyHit
2	e8c5.7a91.f8c	4 1	RlyHit

show running-config cfm

Use this command to display CFM running configuration alone.

Command Syntax

show running-config cfm

Parameters

None

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

```
#show running-config cfm
ethernet cfm domain-type character-string domain-name 12347 level 2 mip-
creation none
 service ma-type string ma-name 123
  vlan 10 bridge 10
  mip-creation default
   ethernet cfm mep down mpid 14 active true xe4
    lck state lock
      message level 2
       interval 1s
       frame priority 3
       exit-ether-ma-mep-lck-mode
    ethernet cfm loss-measurement reply lmm
    exit-ether-ma-mep-mode
   mep crosscheck mpid 41
   exit-ether-ma-mode
    !
```

test-signal frame-size

Use this command to configure an ETH test signal frame size which is applicable only for generator test signal mode. Use no form of this command to delete the configured ETH test signal frame size.

Command Syntax

```
test-signal frame-size <68-9600>
no test-signal frame-size
```

Parameters

<68-9600> Specify the frame size within the range

Command Mode

Configure CFM ETH test mode

Default

None

Applicability

This command was introduced in OcNOS version 4.0.

```
#configure terminal
(config)#ethernet cfm test-signal profile-name 123
(config-cfm-eth-tst)#test-signal frame-size 124
```

```
(config-cfm-eth-tst) #no test-signal frame-size
```

test-signal mode

Use this command to enable an ETH test signal mode as generator or receiver or both.

Command Syntax

test-signal mode (generator|receiver|both)

Parameters

generator	The node will act as a ETH-TST frame generator
receiver	The node will act as a ETH-TST frame receiver
both	The node will act as both ETH-TST frame generator and receiver

Command Mode

Configure CFM ETH test mode

Default

The default test signal mode is receiver.

Applicability

This command was introduced in OcNOS version 4.0.

```
#configure terminal
(config)#ethernet cfm test-signal profile-name 123
(config-cfm-eth-tst)#test-signal mode generator
```

test-signal pattern-type

Use this command to configure the TLV type to be encoded in ETH-Test PDU.

Use no form of this command to reset the TLV pattern type to default.

Command Syntax

```
test-signal pattern-type (null-sig|null-sig-crc32|prbs|prbs-crc32)
no test-signal pattern-type
```

Parameters

null-sig	Specify test pattern as a Null signal without CRC-32
null-sig-crc32	Specify test pattern as a Null signal with CRC-32
prbs	Specify test pattern as a PRBS 2^31-1 without CRC-32
prbs-crc32	Specify test pattern as a PRBS 2^31-1 with CRC-32

Command Mode

Configure CFM ETH test mode

Default

Default TLV pattern type is Null signal.

Applicability

This command was introduced in OcNOS version 4.0.

```
#configure terminal
(config)#ethernet cfm test-signal profile-name 123
(config-cfm-eth-tst)#test-signal pattern-type null-signal
(config-cfm-eth-tst)#no test-signal pattern-type
```

test-signal start-time

Use this command to start the ETH-Test session.

Command Syntax

```
test-signal start-time (relative START-TIME | absolute START-TIME ) stop-time
(relative STOP-TIME | absolute STOP-TIME) tst-profile-name WORD domain
DOMAIN_NAME ma MA_NAME mep MEPID target (mac-address MAC|RMEPID)
```

Parameters

start-time	Specify Test session start time	
relative	Specify Test session start time as relative	
absolute	Specify Test session start time as absolute	
START-TIME	Test session start time in minutes	
stop-time	Specify Test session stop time	
STOP-TIME	Test session stop time in minutes	
tst-profile-name		

Test session profile name
Specify test session profile name
Specify domain.
Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1
Specify Maintenance association name
Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.
Specify mep
Enter the MEPID ranging from <1-8191>
Specify target
Unicast destination MAC address
MAC address in HHHH.HHHH.HHHH format
Enter the RMEP ID ranging from 1-8191

Command Mode

Exec mode

Default

None

Applicability

This command was introduced in OcNOS version 4.0.

Example

#test-signal start-time relative 0 stop-time relative 30 tst-profile-name 123
domain 12345 ma 43982 mep 21 target mac-address 6cb9.c557.42d0

test-signal test-type

Use this command to configure an ETH test signal test type is service interrupting or not.

Use no form of this command to delete the configured ETH test signal test type.

Command Syntax

```
test-signal test-type (in-service|out-of-service)
no test-signal test-type
```

Parameters

```
in-service This indicates the ETH-Test is in-service and normal client service traffic is not interrupted
out-of-service This indicates the ETH-Test is out-of-service and normal client service traffic is not
disrupted
```

Command Mode

Configure CFM ETH test mode

Default

None

Applicability

This command was introduced in OcNOS version 4.0.

```
#configure terminal
(config)#ethernet cfm test-signal profile-name 123
(config-cfm-eth-tst)#test-signal test-type in-service
(config-cfm-eth-tst)#no test-signal test-type
```

traceroute ethernet

Use this command to start traceroute messages on a remote MEP.

Command Syntax

traceroute ethernet MAC mepid MEPID domain DOMAIN (ma MA_NAME)

Parameters-

MAC	MAC address of the remote MEP or MIP in HHHH.HHHH.HHHH format.	
MEPID	Host MEP identifier <1-8191>.	
DOMAIN_NAME	Enter the name of the domain. Name must be of 5 characters if type is character-string otherwise no_name if domain-type is no-name1	
MA_NAME	Enter maintenance association name. If ma-type is character string then maximum length of ma-name is 6 else if it's integer then maximum is 2-octets.	

Command Mode

Exec mode and Privileged Exec mode

Applicability

This command was introduced in OcNOS version 3.0.

<pre>#traceroute et</pre>	hernet	0018.236e.5eb8	mepid	201 domain 12345	ma 123
MP Mac	Hops	Relay-action		Ingress/Egress	Ingress/Egress
action					
0018.23ea.da36	1	RlyFDB		Ingress	IngOK
0018.23ea.da38	2	RlyFDB		Egress	EgrOK
0018.236e.5eb8	3	RlyHit		Ingress	IngOK
#traceroute et	hernet	0018.236e.5eb8	mepid	201 domain 12345	vpws ETH-2001
MP Mac	Hops	Relay-action		Ingress/Egress	Ingress/Egress
action					
0018.23ea.da36	1	RlyFDB		Ingress	IngOK
0018.23ea.da38	2	RlyFDB		Egress	EgrOK
0018.236e.5eb8	3	RlyHit		Ingress	IngOK

vlan

Use this command to create a service Maintenance Association (MA), with a VLAN.

Command Syntax

vlan VLAN_ID (bridge <1-32> | inner-vlan VLAN_ID|)

Parameters

<1-32>	Bridge id
VLAN_ID	Inner VLAN identifier <1-4094>

Command Mode

Ethernet CFM MA mode

Applicability

This command was introduced in OcNOS-SP version 5.1

```
#configure terminal
OcNOS(config)#ethernet cfm domain-type character-string domain-name 12345 level 7
OcNOS(config-ether-cfm)#service ma-type string ma-name 43982
OcNOS(config-ether-cfm-ma)#vlan 10 bridge 10
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 2331 active true xe2
```

vpws

Use this command to create a service Maintenance Association (MA), with VPWS.

Command Syntax

vpws VCNAME

Parameters

VCNAME Virtual circuit name with maximum length being 30

Command Mode

Ethernet CFM MA mode

Applicability

This command was introduced in OcNOS-SP version 6.1.0

```
#configure terminal
OcNOS(config)#ethernet cfm domain-type character-string domain-name 12345 level 7
OcNOS(config-ether-cfm)#service ma-type string ma-name 43982
OcNOS(config-ether-cfm-ma)#vpws ETH-2001
OcNOS(config-ether-cfm-ma)#ethernet cfm mep up mpid 103 active true vpws ETH-2001
```

wait-to-restore-timer <0-86400>

Use this command to configure/unconfigure Wait-to-restore timer for Eth-BNM and Eth-CSF. For Eth-BNM, nominal bandwidth will be set after the wait-to-restore timer expiry. When this command is enabled for Eth-CSF 'DCI' state is restored after wait-to-restore timer expiry.

Command Syntax

wait-to-restore-timer <TIME>
no wait-to-restore-timer <TIME>

Parameters

TIME Wait-to-restore-timer <0-86400>

Default

Default is 10 seconds.

Command Mode

Ethernet CFM MEP BN and CFM MEP CSF mode

Applicability

This command was introduced in OcNOS version 5.0

```
OcNOS(config)#ethernet cfm domain-type character-string domain-name abcde
level 5
OcNOS(config-ether-cfm)#service ma-type string ma-name 7
OcNOS(config-ether-cfm-ma)#vlan 10 bridge 10
OcNOS(config-ether-cfm-ma)#ethernet cfm mep down mpid 100 active true xe9
OcNOS(config-ether-cfm-ma-mep)#bn receive
OcNOS(config-ether-cfm-ma-mep-bn)#wait-to-restore-timer 90
OcNOS(config-ether-cfm-ma-mep-bn)#
```

CHAPTER 2 G8031 ELPS Commands

This chapter describes the G8031 Ethernet Linear Protection Switching (ELPS) commands.

- aps-channel level
- backup
- clear
- control-vlan
- data vlan
- debug g8031
- eps-protection-group
- exercise
- force-switch
- g8031-eps
- g8031 eps-instance
- g8031 eps-protection group
- g8031 profile
- local-freeze
- local-lockout
- lockout
- manual-switch-protection
- manual-switch-working
- mode
- protection-port
- show g8031 eps-instance
- show g8031 eps-instance <EPS_ID>
- show hsl g8031 debug
- switching mode
- timer hold-off-time
- timer wait-to-restore
- working-port

aps-channel level

Use this command to associate CFM with g8031 protection group to carry APS message.

Use the no form of this command to disassociate CFM from g8031 protection group.

Note: It is mandatory for Working-port MEP and Protection-Port MEP to be in different Maintenance Domain but in same Maintenance Level. Moreover, Maintenance Association Vlan-id should be same as g8031 primary-vlan id. If both the conditions are met then, g8031 protection group can be associated to using the 'level' command.

Command Syntax

aps-channel level <0-7>

Parameters

<0-7> Maintainance Endpoint Level.

Command Mode

G8031 Switching Mode.

Applicability

This command was introduced before OcNOS version 5.0.

```
(config)#g8031 eps-instance eps1
(g8031-config-eps-instance)#aps-channel level 7
```

backup

Use this command to configure backup interface (protection port) under cross-connect for bridge-domain case.

Command Syntax

Backup IFPBKPNAME

Parameters

IFPBKPNAME AC Interface Backup Name.

Default

0 seconds.

Command Mode

Config Backup Crossconnect Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

```
#configure terminal
(config)#cross-connect 1
(config-xc)#interface xe10.1
(config-bkp-xc)#backup xe11.1
```

clear

Use this command to perform clear operation on g8031 protection group based on instance name.

Command Syntax

clear g8031 eps-instance <INSTANCENAME>

Parameters

<INSTANCENAME> g8031 instance name.

Command Mode

Exec mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

Examples

clear g8031 eps-instance eps1

control-vlan

Use this command to configure a contro-vlan for g8031 protection group.

Use the no form of this command to delete control-vlan for a g8031 protection group.

Command Syntax

```
control-vlan <2-4094>
control vlan <2-4094> inner-vlan <2-4094>
```

Parameters

<2-4094> vlan id.

Command Mode

G8031 Instance Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

```
#configure terminal
(config)#g8031 eps-instance eps2
(g8031-config-eps-instance)#control vlan 3
(g8031-config-eps-instance)#control vlan 3 inner-vlan 500
```

data vlan

Use this command to configure protected data vlans for g8031 protection group.

Use the no form of this command to delete a data vlan for g8031 protection group.

Note:

- Once mode is configured, data vlans can not be modified.
- Data vlans have to be configured individually using vlan command i.e Range of vlans not accepted with vlan command.
- This command has no impact on data-plane i.e Unprotected vlans are not blocked by g8031 working and protection-ports. It is left upto the administrator to configure only protected vlans with bridge-port configuration of working and protection g8031 ports.

Command Syntax

```
data vlan <2-4094>
no data vlan <2-4094>
```

Parameters

<2-4094> vlan-id.

Command Mode

G8031 Switching Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

```
#configure terminal
(config)#g8031 eps-instance eps1
(g8031-config-eps-instance)#data vlan 4-20
```

debug g8031

Use this command to debug configuration.

Command Syntax

```
debug g8031 (all|events|fsm|hal|rx|tx)
no debug g8031 (all|events|fsm|hal|rx|tx)
```

Parameters

all	All debugging options.
events	Protocol related events.
fsm	Instance Finite State Machine updates.
hal	HAL events.
rx	Received PDUs.
tx	Transmitted PDUs.

Command Mode

Exec mode.

Applicability

This command was introduced in OcNOS version 6.0.0.

- # debug g8031 tx
- # debug g8031 all

eps-protection-group

Use this command to map configured working/protection port under g8031 instance.

Use the no form of this command to unmap eps-protection group from g8031 instance.

Command Syntax

```
eps-protection-group <WORD>
no eps-protection-group
```

Parameters

Word eps protection group name in string.

Command Mode

G8031 Config EPS Instance Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

```
#configure terminal
(config)#g8031 eps-instance eps1
(g8031-config-eps-instance)#eps-protection-group eps1
```

exercise

Use this command to perform exercise operation on g8031 protection group based on instance name.

Use the ${\tt clear}$ command to clear exercise operation from g8031 protection group.

Command Syntax

g8031 eps-instance <INSTANCENAME> exercise

Parameters

<1-32> g8031 instance name.

Command Mode

Exec mode.

Applicability

This command was introduced before OcNOS version 5.0.

Examples

exercise bridge 1 g8031 eps-id 10

force-switch

Use this command to perform force-switch on g8031 protection group based on instance name.

Use the ${\tt clear}$ command to clear force-switch operation from g8031 protection group.

Command Syntax

g8031 eps instance <INSTANCENAME> force-switch

Parameters

<INSTANCENAME> g8031instance name.

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 6.5.2.

- # g8031 eps-instance eps1 force-switch
- # clear g8031 eps-instance eps1

g8031-eps

Use this command to map eps protection group under cross-connect were g8031 can be extended over bridge-domain.

Use the no form to unmap eps protection group from cross-connect.

Command Syntax

```
g8031-eps <EVCID>
no g8031-eps <EVCID>
```

Parameters

<EVCID> EVC ID.

Command Mode

Config Backup Crossconnect Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

```
#configure terminal
(config)#cross-connect 1
(config-xc)#interface xe10.1
(config-bkp-xc)#backup xe11.1
(config-bkp-xc)#g8031-eps eps1
```

g8031 eps-instance

Use this command to set instance-id for a particular g8031 protection group.

Use the no form of this command to remove instance-id for a g8031 protection group.

Command Syntax

g8031 eps-instance <INSTANCENAME>

Parameters

<INSTANCENAME> g8031 instance name.

Command Mode

Config Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

Examples

(config) #g8031 eps-instance eps1

g8031 eps-protection group

Use this command to configure working/protection port for g8031 eps protection.

Use the no form of this command to remove eps protection group.

Command Syntax

g8031 eps-protection group <WORD> no g8031 eps-protection group <WORD>

Parameters

<WORD> EPS protection group name in string.

Command Mode

Config Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

```
#configure terminal
(config)#g8031 eps-protection group eps1
```

g8031 profile

Use this command to configure g8031 mode, switching mode and timer-status for g8031 protection group.

Use the no form of this command to remove profile.

Command Syntax

g8031 profile <WORD> no g8031 profile <WORD>

Parameters

WORD eps profile name in string.

Command Mode

Config Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

```
#configure terminal
(config)#g8031 eps-instance eps1
```

local-freeze

Use this command to locally freeze the g8031 protection group.

Use the ${\tt clear}$ command to clear local-freeze from g8031 protection group.

Command Syntax

g8031 eps-instance <INSTANCENAME> local-freeze
clear g8031 eps-instance <INSTANCENAME> local-freeze

Parameters

<INSTANCENAME> g8031 instance name.

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 6.5.2.

Examples

#g8031 eps-instance eps1 local-freeze
#clear g8031 eps-instance eps1 local-freeze

local-lockout

Use this command to configure local lockout for g8031 protection group.

Use the ${\tt clear}$ command to clear local-lockout operation from g8031 protection group.

Command Syntax

g8031 eps-instance <INSTANCENAME> local-lockout clear g8031 eps-instance <INSTANCENAME> local-lockout

Parameters

<INSTANCENAME> g8031 instance name.

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 6.5.2.

- # g8031 eps-instance eps1 local-lockout
- # clear g8031 eps-instance eps1 local-lockout

lockout

Use this command to lockout for g8031 protection group.

Use the ${\tt clear}$ command to remove lockout from g8031 protection group.

Command Syntax

g8031 eps-instance <INSTANCENAME> lockout

Parameters

<INSTANCENAME> g8031 instance name.

Command Mode

Exec mode

Applicability

This command was introduced in OcNOS version 6.5.2.

- # g8031 eps-instance eps1 lockout
- # clear g8031 eps-instance eps1

manual-switch-protection

Use this command to perform manual-switch for protection port.

Use the clear command to remove manual switch.

Command Syntax

g8031 eps-instance <INSTANCENAME> manual-switch-protection

Parameters

<INSTANCENAME> g8031 instance name.

Command Mode

Exec Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

- # g8031 eps-instance eps1 manual-switch-protection
- # clear g8031 eps-instance eps1

manual-switch-working

Use this command to perform manual-switch for working port.

Use the clear command to remove manual switch.

Command Syntax

g8031 eps-instance <INSTANCENAME> manual-switch-working

Parameters

<INSTANCENAME> g8031 instance name.

Command Mode

Exec Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

- # g8031 eps-instance eps1 manual-switch-working
- # clear g8031 eps-instance eps1
mode

Use this command to configure mode for g8031 protection group.

Use the no form of this command to mode for g8031 protection group.

Note: Once mode is configured, it can not be changed. Administrator has to explicitly delete and re-configure a new mode.

Command Syntax

```
mode (one-and-one-bidirectional | one-plus-one-bidirectional | one-plus-one-
  unidirectional)
```

Parameters

```
one-and-one-bidirectional
one-plus-one-bidirectional
```

1:1 Bidirectional mode.

1+1 Bidirectional mode. 1+1 Unidirectional mode.

one-plus-one-unidirectional

Command Mode

G8031 Profile Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

```
#configure terminal
(config) #g8031 profile eps1
(g8031-config-profile) #mode one-and-one-bidirectional
```

protection-port

Use this command to configure a protection-port for a g8031 protection group.

Use the no form of this command to delete protection-port for a g8031 protection group.

Note:

- When both working and protection ports are in Signal-Failure state, Working Port is treated as Active port, and Protection group is in Signal-Failure-Protection State.
- Working and Protection Paths between two ELPS end nodes should not coincide i.e When having intermediate nodes it is required that the working path and protection path are configured via different intermediate nodes.
- Working port should be Layer-2 Physical or LAG interface. Command is also applicable for sub-interface.
- Protection port should be Layer-2 Physical or LAG interface. Command also applicable for sub-interface.

Command Syntax

protection-port IFNAME no protection-port

Parameters

IFNAME Interface name.

Command Mode

G8031 Config Protection Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

```
#configure terminal
(config)#g8031 eps-protection group eps1
(g8031-config-protection)#protection-port ge10.1
```

show g8031 eps-instance

Use this command to display the status of all configured g8031 protection groups.

Command Syntax

show g8031 eps-instance

Parameters

None

Command Mode

Exec mode

Applicability

This command was introduced from OcNOS version 6.5.2.

Examples

#show g8031 eps-instance

EPS-Name	Id	Mode	Working-Pa	th Sta	te Pro	tection-Pa	ath Sta	te Control-VLAN	CFM
eps1	1	1:1,BI xe	e6.1	Up	ge9.1	(A)	Up	11	Yes
eps2	1	1:1,BI ge9	.2	Up	xe6.2	(A)	Up	500	Yes

Table 2-13 explains the output fields:

Table 2-13: show g8031 eps-instance bridge output fields

Field	Description	
EPS Name	Eps instance name	
ID	Protection group id	
Mode	Architecture type - 1+1 or 1:1 and Directional (Uni/Bi)	
Working path	Working port	
Protection path	Protection port	
(A)	Active Path	
CFM	Working/protection MEP is configured and UP (Yes) Working/protection MEP is DOWN (No)	

show g8031 eps-instance <EPS_ID>

Use this command to display the status of a particular g8031 protection group.

Command Syntax

```
show g8031 eps-instance <EPS ID>
```

Parameters

<EPS-ID> EPS instance name.

Command Mode

Exec mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

Examples

Table 2-14 explains the output fields:

Table 2-14: show g8031 eps-instance output fields

Field	Description
Inst Name	Protection group instance, profile and protection group name
Mode & Group	Bridge (1:1 / 1+1), Direction (Uni/Bi), switching mode (revertive/non-revertive)
Current State	No request/Signal Fail/Wait-to-Restore, Active path (Working/Protection) dFOP state (defect mode).
Timer Status	WTR/Hold-Off timers

Field	Description
Working_cfm	Working CFM MEP with mep_id, cc-interval, domain and ma
Protection- cfm	Working CFM MEP with mep_id, cc-interval, domain and ma
APS- Channel	Control vlan and APS Level
Vlan	Data vlan
APS Statistics	APS PDU TX and RX
L-APS Tx count	Number of transmitted g8031 L-APS control pkts

show hsl g8031 debug

Use this command to display debugging related information of a particular g8031 protection group.

Command Syntax

show hsl g8031 debug <1-32>

Parameters

<1-32> Protection group id.

Command Mode

Exec mode

Applicability

This command was introduced before OcNOS version 5.0.

Examples

Service type: XC (Subinterface)

# show	hsl g8031 debu	g 1			
EPS_ID	Mode Service	Working_port	Protection_port	Active_port	Failover
	+	+	+		++
1	1:1,Bi XC	po1.2	sal.2	Working	4000005

Table 2-15 explains the output fields:

Table 2-15: show hsl g8031 output fields

Field	Description	
EPS ID	Protection group id	
Mode	Configured g8031 mode on protection group	
Service	XC(Subinterface) / L2 Bridge	
Working port	Working port	
Protection port	Protection port	
Active Ingress	Working/Protection port	
Failover	Egress failover	

switching mode

Use this command to configure revertive/non-revertive switchover-type for g8031 protection group.

Use the no form of this command to set default switchover-type for g8031 protection group.

Command Syntax

switching mode (revertive | non-revertive)
no switching mode

Parameters

None

Default

Non-revertive.

Command Mode

G8031 Profile Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

Examples

#configure terminal
(config)#g8031 profile eps1
(g8031-config-profile)#switching mode revertive

timer hold-off-time

Use this command to configure hold-off timer for g8031 protection group.

Use the no form of this command to set default hold-off timer value for a g8031 protection group.

Command Syntax

timer hold-off-time <0-10>
no timer hold-off-time

Parameters

<0-10> Timer value in seconds.

Default

0 seconds.

Command Mode

G8031 Profile Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

```
#configure terminal
(config)#g8031 profile eps1
(g8031-config-profile)#timer hold-off 2
```

timer wait-to-restore

Use this command to configure wait-to-restore timer for a g8031 protection group.

Use the no form of this command to set default wait-to-restore value for a g8031 protection group.

Note: This command is only applicable for revertive mode.

Command Syntax

```
timer wait-to-restore <300-720>
no timer wait-to-restore
```

Parameters

<300–720> Timer value in seconds.

Default

300 seconds.

Command Mode

G8031 Profile Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

```
#configure terminal
(config)#g8031 profile eps1
(g8031-config-profile)#timer wait-to-restore 360
```

working-port

Use this command to configure a working-port for a g8031 protection group.

Use the no form of this command delete working-port for a g8031 protection group.

Command Syntax

working-port IFNAME no working-port

Parameters

IFNAME Interface name.

Command Mode

G8031 Config Protection Mode.

Applicability

This command was introduced in OcNOS version 6.5.2.

```
#configure terminal
(config)#g8031 eps-protection group eps1
(g8031-config-protection)#working-port xe10
```

CHAPTER 3 G.8032 ERPS Version 2 Commands

This chapter contains the G.8032 (2012) Ethernet Ring Protection Switching (ERPS) version 2 commands.

- aclif failover
- aps-channel level
- aps-channel vlan
- associate-ring
- clear g8032 erp-instance
- data vlan
- debug g8032
- east-interface
- enable-tcn-propagation
- erps-instance
- g8032 erp-instance
- g8032 erp-instance force-switch
- g8032 erp-instance manual-switch
- g8032 ring
- g8032-profile
- g8032 profile
- hardware-profile aclif failover
- non-virtual-channel
- ring
- ring-id
- ring-type
- rpl role
- show g8032 erp-instance
- show g8032 profile
- show g8032 ring
- switching mode
- tcn-to-instance
- timer
- virtual-channel
- west-interface

aps-channel level

Use this command to set the maintenance entity group (MEG) level (MEL) to carry in R-APS messages.

Command Syntax

aps-channel level <0-7>

Parameters

<0-7> Level.

Command Mode

G.8032 configure switch mode

Examples

Here are sample examples of configuring G.8032 ERP instance with Automatic Protection Switching (APS) channel settings in OcNOS device.

OcNOS#configure terminal OcNOS(config)#g8032 erp-instance instance1 OcNOS(g8032-config-switch)#aps-channel level 2 OcNOS(g8032-config-switch)#end

aps-channel vlan

Use this command to configure APS channel VLAN-ID for the ERP instance.

Use no parameter of this command to remove APS channel VLAN-ID configuration for the ERP instance.

Command Syntax

```
aps-channel vlan <2-4094> (inner-vlan <2-4094>|)
no aps-channel vlan
```

Parameters

<2-4094>	VLANID
inner-vlan	Inner vlan
<2-4094>	VLANID

Command Mode

G.8032 configure switch mode.

Applicability

This command was introduced before OcNOS version 5.0.

```
OcNOS#configure terminal
OcNOS(config)#g8032 erp-instance instance1
OcNOS(g8032-config-switch)#aps-channel vlan 10 inner-vlan 5
OcNOS(g8032-config-switch)#end
```

clear g8032 erp-instance

Use this command to clear ERPS instance.

This command is used at an Ethernet ring node for the following operations:

- · Clearing an active local administrative command (forced switch or manual switch).
- Triggering reversion before the wait to restore (WTR) or wait to block (WTB) timer expires in the case of revertive operation.
- Triggering reversion in the case of non-revertive operation.

Command Syntax

```
clear g8032 erp-instance (INSTANCENAME | all)
```

Parameters

INSTANCENAME	Instance name (maximum 32 characters).
all	Clear all instances.

Command Mode

Exec mode.

Applicability

This command was introduced before OcNOS version 5.0 and was revised in OcNOS version 6.4.1 by adding a new parameter called all.

Examples

The following command clear a specific ERPS instance in the network.

OcNOS#clear g8032 erp-instance INST1

The following command clear all ERPS instance in the network.

OcNOS#clear g8032 erp-instance all

data vlan

Use this command to configure VLANs as data channels.

Use the no form of this command to remove VLAN configuration.

Command Syntax

data vlan VLAN_RANGE no data vlan VLAN RANGE

Parameters

VLAN_RANGE Enter VLAN ID 2-4094 or list of VLAN ID's separated by commas. Eg 2 or 2,4,5 or 50,51,52 etc.

Command Mode

G.8032 configure switch mode.

Applicability

This command was introduced before OcNOS version 5.0.

Examples

Here's an example of configuring G.8032 ERP instance with data VLANs 201, 202, and 203 in OcNOS device.

OcNOS#configure terminal OcNOS(config)#g8032 erp-instance instance1 OcNOS(g8032-config-switch)#data vlan 201,202,203 OcNOS(g8032-config-switch)#end

debug g8032

Use this command to debug configuration.

Command Syntax

```
debug g8032 (all|tx|rx|fsm|timers|events|external|hal)
no debug g8032 (all|tx|rx|fsm|timers|events|external|hal)
```

Parameters

all	All debugging options
events	Protocol event
external	External CFM and NSM events
fsm	Instance Finite State Machine updates
hal	HAL events
rx	Received PDUs
timers	Protocol timer events
tx	Transmitted PDUs

Command Mode

Configure mode and Exec mode

Applicability

This command was introduced in OcNOS version 6.0.0.

Examples

Here's an example of enabling G.8032 debugging for both transmit (tx) and all events in OcNOS device.

```
OcNOS#configure terminal
OcNOS(config)#debug g8032 tx
OcNOS(config)#debug g8032 all
OcNOS(config)#exit
```

east-interface

Use this command to set the east port associated to the protection ring.

Command Syntax

east-interface IFNAME
no east-interface

Parameters

IFNAME Interface name, such as xe1.

Command Mode

G8032 ring config mode.

Applicability

This command was introduced before OcNOS version 5.0.

Examples

The below example demonstrates the configuration of an ERPS ring named RING1 with the assignment of the east interface as cel.

```
OcNOS#configure terminal
OcNOS(config)#g8032 ring RING1
OcNOS(g8032-ring-config)#east-interface cel
OcNOS(g8032-ring-switch)#end
```

enable-tcn-propagation

Use this command to enable or disable TCN (topology change notification) propagation for an interconnected ring.

Command Syntax

```
enable-tcn-propagation
no enable-tcn-propagation
```

Parameters

None

Command Mode

G.8032 configure switch mode

Applicability

This command was introduced in OcNOS version 6.0.0.

Examples

In this example, the configuration for G.8032 ERP instance instance1 includes the enabling of topology change notification (TCN) propagation.

```
OcNOS#configure terminal
OcNOS(config)#g8032 erp-instance instance1
OcNOS(g8032-config-switch)#enable-tcn-propagation
OcNOS(g8032-config-switch)#end
```

erps-instance

Use this command to set the ERPS-instance for the sub-interface.

Use no parameter of this command to remove the ERPS-instance configuration from the sub-interface.

Command Syntax

```
erps-instance INSTANCENAME no erps-instance
```

Parameters

INSTANCENAME Name of the ERPS instance.

Command Mode

Interface mode.

Applicability

This command was introduced in OcNOS version 6.2.0 and was revised in OcNOS version 6.4.1 by removing a parameter called all.

Examples

The following configurations allow the association of an ERPS instance with a sub-interface. By configuring ERPS instances on sub-interfaces, it enables protection switching for specific network segments.

```
OcNOS#configure terminal
OcNOS(config)#interface xe2.1
OcNOS(config-if)#erps-instance erp1
OcNOS(config-if)#commit
OcNOS(config-if)#end
```

g8032 erp-instance

Use this command to create an ERP instance and change to G.8032 configure switch mode.

Use the no form of this command to delete an ERP instance.

Command Syntax

g8032 erp-instance INSTANCENAME no g8032 erp-instance INSTANCENAME

Parameters

INSTANCENAME Instance name (maximum 32 characters).

Command Mode

Configure mode

Examples

The below example demonstrates the configuration of G.8032 ERP instance with the instance name instance1.

OcNOS#configure terminal OcNOS(config)#g8032 erp-instance instance1 OcNOS(g8032-config-switch)#end

g8032 erp-instance force-switch

Use this command to configure administrative commands related to force switching within ERPS instances.

Command Syntax

```
g8032 erp-instance (INSTANCE-NAME | all) force-switch (east-interface | west-
interface)
```

Parameters

INSTANCENAME	Instance name (maximum 32 characters)
all	Apply to all instances.
east-interface	Apply command to east interface.
west-interface	Apply command to west interface.

Command Mode

Exec mode.

Applicability

This command was introduced before OcNOS version 5.0 and was revised in OcNOS version 6.4.1 by adding a new parameter called all.

Examples

The following commands allows to take manual control of ERPS instances and force traffic to switch to a specific interface (east or west) as needed for network protection.

```
OcNOS#g8032 erp-instance example force-switch east-interface
OcNOS#g8032 erp-instance all force-switch west-interface
```

g8032 erp-instance manual-switch

Use this command to configure manual protection switching for specific ERPS instances or for all instances on the device.

Command Syntax

```
g8032 erp-instance (INSTANCE-NAME | all) manual-switch (east-interface | west-
interface)
```

Parameters

INSTANCENAME	Instance name (maximum 32 characters)
all	Apply to all instances.
east-interface	Apply command to east interface.
west-interface	Apply command to west interface.

Command Mode

Exec mode.

Applicability

This command was introduced before OcNOS version 5.0 and was revised in OcNOS version 6.4.1 by adding a new parameter called all.

Examples

The following commands are used to configure specific ERPS instances to perform manual switching on either the west or east interface as needed.

OcNOS#g8032 erp-instance example manual-switch west-interface OcNOS#g8032 erp-instance all manual-switch east-interface

g8032 ring

Use this command to create a ring and associate east and west interfaces with it. All ERP instances on this ring have the same east and west interfaces,

Use the no form of this command to delete a ring.

Command Syntax

g8032 ring RINGNAME no g8032 ring RINGNAME

Parameters

ring Ring. RINGNAME Ring name (maximum 37 characters).

Command Mode

Configure mode

Examples

OcNOS#configure terminal OcNOS(config)#g8032 ring ERPS123 OcNOS(config)#no g8032 ring ERPS123 OcNOS(config)#exit

g8032-profile

Use this command to associate the ERP instance to a profile. After configuring this command, it will take to the ERP profile configuration mode.

Command Syntax

g8032-profile PROFILENAME

Parameters

PROFILENAME **Profile name**.

Command Mode

G.8032 configure switch mode

Examples

OcNOS#configure terminal OcNOS(config)#g8032 erp-instance instance1 OcNOS(g8032-config-switch)#g8032-profile prof_1 OcNOS(g8032-profile-config)#end

g8032 profile

Use this command to associate the ERPS profile to an instance.

Use the no form of this command to delete the ERPS profile from an instance.

Command Syntax

g8032 profile PROFILENAME

Parameters

PROFILENAME Profile name.

Command Mode

G.8032 configure switch mode

Examples

OcNOS#configure terminal OcNOS(config)#g8032 erp-instance instance1 OcNOS(g8032-config-switch)#g8032-profile prof_1

non-virtual-channel

Use this command to make a sub-ring function without a virtual channel.

Use the no form of this command to delete a non-virtual channel.

Command Syntax

```
non-virtual-channel
no non-virtual-channel
```

Parameters

None.

Command Mode

G.8032 configure switch mode.

Applicability

This command was introduced before OcNOS version 5.0.

```
OcNOS#configure terminal
OcNOS(config)#g8032 erp-instance instance1
OcNOS(g8032-config-switch)#non-virtual-channel
```

ring

Use this command to associate the ERP instance to a ring.

Command Syntax

ring RINGNAME

Parameters

RINGNAME Ring name.

Command Mode

G.8032 configure switch mode

Examples

OcNOS#configure terminal OcNOS(config)#g8032 erp-instance instance1 OcNOS(g8032-config-switch)#ring ring1

ring-id

Use this command to set the ring identifier.

Command Syntax

ring-id <1-239>

Parameters

<1-239> Ring identifier.

Command Mode

G.8032 configure switch mode.

Applicability

This command was introduced before OcNOS version 5.0.

```
OcNOS#configure terminal
OcNOS(config)#g8032 erp-instance instance1
OcNOS(g8032-config-switch)#ring-id 1
```

ring-type

Use this command to specify the type of the ethernet ring for this ERP instance.

Command Syntax

```
ring-type (major-ring | sub-ring | sub-ring-vc)
no ring-type
```

Parameters

major-ring	G.8032 major ring. In this type of rings nodes are connected in full circular topology
sub-ring	G.8032 sub-ring without virtual channel
sub-ring-vc	G.8032 sub-ring with virtual channel

Command Mode

G.8032 configure switch mode.

Applicability

This command was introduced before OcNOS version 5.0.

```
OcNOS#configure terminal
OcNOS(config)#g8032 erp-instance instance1
OcNOS(g8032-config-switch)#ring-type major-ring
OcNOS(g8032-config-switch)#ring-type sub-ring-vc
```

rpl role

Use this command to set the RPL (Ring Protection Link) role of the ring node.

Command Syntax

```
rpl role ((owner | neighbor | next-neighbor)(east-interface | west-interface) |
    non-owner )
```

Parameters

owner	Ring node is the RPL owner.
neighbor	Ring node is neighbor to the RPL owner.
next-neighbor	Ring node is neighbor to the neighbor of the RPL owner.
east-interface	
	Role assigned to east interface.
west-interface	
	Role assigned to west interface.
non-owner	Ring node does not own the RPL.

Command Mode

G.8032 configure switch mode.

Applicability

This command was introduced before OcNOS version 5.0.

```
OcNOS#configure terminal
OcNOS(config)#g8032 erp-instance instance1
OcNOS(g8032-config-switch)#rpl role owner east-interface
```

show g8032 erp-instance

Use this command to display details about an ERP instance.

Command Syntax

show g8032 erp-instance ((INSTANCENAME | data-traffic | summary)|)

Parameters

INSTANCENAME	Instance name.
data-traffic	Display data traffic details.
summary	Display summary details.

Command Mode

Exec mode.

Applicability

This command was introduced before OcNOS version 5.0 and revised in OcNOS version 6.4.1 by adding the new parameters data-traffic and summary.

Example

The below command display details about ERP instances:

OcNOS#show	g8032	erp-instance					
Instance	ID	State	East	state	West	state	Ring
phy_erp1	1	PENDING	xe24	Blocked	xe26	Unblocked	PR1
sub_erp1	2	PROTECTION	xe25	Blocked	-	-	SR1
erp3	3	PROTECTION	xe23	Blocked	-	-	SR2
br_erp1	4	PENDING	xe24.1	Blocked	xe26.1	Unblocked	BR1

Table 3-16 explains the output fields.

Table 3-16: show g8032 erp-instance

Field	Description
Instance	Lists the names of the ERP instances. Each instance has a unique name.
ID	Displays the ID of the ERP instance, which is a numerical identifier.
State	Indicates the current state of the ERP instance. PENDING state means the instance is waiting for activation, while PROTECTION state means it's actively providing protection.
East	Shows the interface on the east side (usually the primary side) of the ring.
State	Displays the east state of the interface, which can be Blocked or Unblocked. In the context of ERP, Blocked means the interface is in standby or backup mode, and Unblocked means it's active.
West	Shows the interface on the west side (usually the secondary side) of the ring.

Table 3-16: show g8032 erp-instance

Field	Description
State	Displays the west state of the interface,
Ring	Specifies the name or identifier of the ring associated with the ERP instance.

The below command display data traffic details for ERP instances:

OcNOS#show	g8032	erp-instance data-tr	raffic			
Instance	ID	Data-vlan	East	West	Ring	
phy_erp1	1	11-19	xe24 (B)	xe26 (F)	PR1	
sub_erp1	2	50-60	xe25 (B)	-	SR1	
br_erp1	4	bridge_domain 1	xe24.1 (B)	xe26.1 (F)	BR1	
		bridge_domain 2	xe24.2	xe26.2	BR2	

Table 3-17 explains the output fields.

Field	Description
Instance	Lists the names of the ERP instances. Each instance has a unique name.
ID	Displays the ID of the ERP instance, which is a numerical identifier.
Data-vlan	Specifies the range of VLANs associated with data traffic for each ERP instance.
East	Shows the interface on the east side (usually the primary side) of the ring that handles data traffic.
West	Shows the interface on the west side (usually the secondary side) of the ring that handles data traffic.
Ring	Specifies the name or identifier of the ring associated with the ERP instance.

Table 3-17: show g8032 erp-instance data-traffic

The below command display details for a specific ERP instance, in this case, erp0:

```
OcNOS#show g8032 erp-instance erp0
```

Inst Name	: erp3 (3) ,node-id d0:77:ce:df:40:1b ,Profile (1)
Description	:
Ring	: SUB-RING (subring), OWNER (EAST), virtual (vlan 10, ring 2) attached (-), attached to (erp1,erp2,erp3), tcn-propagation (0)
State	: G8032_ST_PROTECTION
Timer Status	: Init (0 min 4 sec), WTR (2 min 2 sec)
East	: xe25, Blocked, Down, BPR (0), remote (d0:77:ce:df:40:1e)
West	: xe24, Blocked, Down, BPR (0), remote (d0:77:ce:df:40:1f)
East (cfm)	: mep-id (1), cc-interval (10ms), domain (10), MA (finance)
West (cfm)	: mep-id (1), cc-interval (10ms), domain (10), MA (finance)
Channel	: Level (5), vlan (20), RING_ID (2)

Data Vlan : 50-60

Table 3-18 explains the output fields.

Field	Description
Inst Name	Provides information about the ERP instance, including its name, a numerical identifier, and a unique node ID. The profile number indicates the associated ERP profile.
Description	Provides a description of the ERP instance.
Ring	Specifies details about the ring associated with the ERP instance.
State	Indicates the current state of the ERP instance.
Timer Status	Displays timer-related information.
East	Shows the interface on the east side (usually the primary side) of the ring.
West	Shows the interface on the west side (usually the secondary side) of the ring.
East(cfm)	Provides CFM-related details for the east side.
West(cfm)	Provides CFM-related details for the west side.
Channel	Provides information about the ERP channel, including: ERP level VLAN associated with the channel Ring ID
Data Vlan	Specifies the range of VLANs associated with data traffic for the ERP instance.

Table 3-18: show g8032 erp-instance INSTANCENAME

show g8032 profile

Use this command to display details about a profile.

Command Syntax

show g8032 profile PROFILENAME

Parameters

PROFILENAME Profile name.

Command Mode

Exec mode.

Applicability

This command was introduced before OcNOS version 5.0.

Examples

OcNOS#show g8032 profile profile1 Profile : profile1 ======== Wait-To-Restore : 5 mins Hold Off Timer : 0 secs Guard Timer : 500 ms Wait-To-Block : 5500 ms Protection Type : Revertive

show g8032 ring

Use this command to display details about a ring.

Command Syntax

show g8032 ring RINGNAME

Parameters

RINGNAME Ring name.

Command Mode

Exec mode.

Applicability

This command was introduced before OcNOS version 5.0.

Examples

switching mode

Use this command to set the revertive behavior of the ring node.

Command Syntax

```
switching mode (non-revertive | revertive)
```

Parameters

revertive	Represents revertive mode operation of a G.8032 ethernet ring.
non-revertive	Represents non-revertive mode operation of a G.8032 ethernet ring.

Command Mode

G.8032 profile configure mode.

Applicability

This command was introduced before OcNOS version 5.0.

```
OcNOS#configure terminal
OcNOS(config)#g8032 erp-instance instance1
OcNOS(g8032-config-switch)#switching mode revertive
```
tcn-to-instance

Use this command to associate TCN instance (topology change notification) propagation for an interconnected ring when configured in non-virtual mode.

Command Syntax

tcn-to-instance INSTANCENANME

Parameters

INSTANCENAME Instance name.

Command Mode

G.8032 configure switch mode.

Applicability

This command was introduced before OcNOS version 5.0.

```
OcNOS#configure terminal
OcNOS(config)#g8032 erp-instance instance1
OcNOS(g8032-config-switch)#tcn-to-instance erp1
```

timer

Use this command to set timers.

Command Syntax

```
timer (wait-to-restore <1-12> | hold-off <0-10000> | guard-time <10-2000>)
```

Parameters

wait-to-restore

	Wait-to-restore timer used to verify that a signal failure is not intermittent.
<1-12>	Timer value in minutes.
hold-off	Hold-off timer used to filter intermittent link faults.
<0-10000>	Timer value in a multiple of 100 milliseconds.
guard-time	Guard timer that blocks latent outdated messages from causing unnecessary state changes.
<1-20000>	Timer value in a multiple of 10 milliseconds.

Command Mode

G.8032 profile configure mode

Examples

OcNOS#configure terminal

OcNOS(config)#interface xe3

```
OcNOS(config-if)#channel-group 2 mode active
OcNOS(config-if)#ethernet cfm domain-type character-string domain-name nod12 level 7
mip-creation none
OcNOS(config-ether-cfm)#g8032 ring lagring
OcNOS(g8032-ring-config)#east-interface pol
OcNOS(g8032-ring-config)#g8032 profile profile1
OcNOS(g8032-profile-config)#timer wait-to-restore 7
OcNOS(g8032-profile-config)#timer hold-off 50
OcNOS(g8032-profile-config)#timer guard-time 300
OcNOS(g8032-profile-config)#timer guard-time 30
OcNOS(g8032-profile-config)#timer guard-time 30
```

virtual-channel

Use this command on a sub-ring to attach it to a major instance.

Use the no form of this command to delete a virtual channel.

Command Syntax

```
virtual-channel (<2-4094>|) attached-to-instance INSTANCENAME
no virtual-channel
```

Parameters

<2-4094>	VLAN identifier.	
INSTANCENAME	Major instance name	

Command Mode

G.8032 configure switch mode.

Applicability

This command was introduced before OcNOS version 5.0.

```
OcNOS#configure terminal
OcNOS(config)#g8032 erp-instance instance1
OcNOS(g8032-config-switch)#virtual-channel 3 attached-to-instance inst1
```

west-interface

Use this command to set the west port associated to the protection ring.

Command Syntax

west-interface IFNAME
no west-interface

Parameters

IFNAME Interface name

Command Mode

G8032 ring config mode.

Applicability

This command was introduced before OcNOS version 5.0.

```
OcNOS#configure terminal
OcNOS(config)#interface xe2
OcNOS(config-if)#g8032 ring RING1
OcNOS(g8032-ring-config)#west-interface ce1
OcNOS(g8032-ring-config)#end
```

CHAPTER 4 EFM OAM Commands

Ethernet to the First Mile (EFM) provides a minimal extension to the MAC layer Operations, Administration and Maintenance (OAM) module. EFM supplies a mechanism for monitoring link operations, such as remote fault detection and remote loopback control.

This chapter includes the following commands:

- clear ethernet oam statistics interface
- debug ethernet oam
- ethernet oam enable
- ethernet oam link-monitor event-log-size
- ethernet oam link-monitor on
- ethernet oam link-monitor supported
- ethernet oam max-rate
- ethernet oam min-rate
- ethernet oam mode
- ethernet oam remote-failure
- ethernet oam remote-loopback (start|stop)
- ethernet oam remote-loopback {supported|timeout}
- ethernet oam timeout
- show ethernet oam
- show ethernet oam discovery
- show ethernet oam eventlog
- show ethernet oam statistics
- show ethernet oam status
- show ethernet oam discovery brief

clear ethernet oam statistics interface

Use this command to reset the OAM statistics to zero.

Command Syntax

clear ethernet oam statistics interface <IFNAME>

Parameter

None

Config Mode

Exec mode

Applicability

Ethernet OAM (EFM) supported platforms

Example

#clear ethernet oam statistics interface xe2

debug ethernet oam

Use this command to set the debugging functions for OAM.

Use the ${\tt no}$ form of this command to disable OAM debugging.

Command Syntax

```
debug ethernet oam (event|rx|tx|all)
no debug ethernet oam (event|rx|tx|all)
```

Parameters

event	Enable event debugging.
rx	Enable RX debugging.
tx	Enable TX debugging.
all	Enable Event, RX and TX debugging

Command Mode

Exec mode and Config mode

Example

#debug ethernet oam event

ethernet oam enable

Use this command to enable or disable Ethernet OAM functionality on a port.

Use the no form of this command to disable Ethernet OAM functionality on a port.

Command Syntax

ethernet oam enable no ethernet oam enable

Parameters

None

Default

Ethernet OAM is disabled.

Command Mode

Interface mode

Applicability

This command was introduced in OcNOS version 5.0.

```
#configure terminal
(config)#interface xe1
(config-if)#ethernet oam enable
```

ethernet oam link-monitor event-log-size

Use this command to set the maximum number of entries in the event log.

Command Syntax

ethernet oam link-monitor event-log-size <1-100>

Parameters

event-log-size Set a log size

<1-100> Set a log size

Command Mode

Interface mode

Default

The default size is 20 entries

```
#configure terminal
(config)#interface eth1
(config-if)#ethernet oam link-monitor event-log-size 100
```

ethernet oam link-monitor on

Use this command to turn on link monitoring on a interface.

Use the no form of this command to turn link monitoring off.

Command Syntax

```
ethernet oam link-monitor on no ethernet oam link-monitor on
```

Parameters

None

Default

When link monitor is supported, link monitoring is automatically turned on.

Command Mode

Interface mode

Applicability

This command was introduced in OcNOS version 5.0.

```
#configure terminal
(config)#interface xe1
(config-if)#ethernet oam link-monitor on
```

ethernet oam link-monitor supported

Use this command to configure link monitoring on an interface.

Use the no form of this command to remove support for link monitoring on an interface.

Command Syntax

ethernet oam link-monitor supported no ethernet oam link-monitor supported

Parameters

None

Command Mode

Interface mode

Default

The default state of the link monitor is supported.

Applicability

This command was introduced in OcNOS version 5.0.

```
#configure terminal
(config)#interface xe1
(config-if)#ethernet oam link-monitor supported
```

ethernet oam max-rate

Use this command to set the maximum number of PDUs per second.

This command ensures that the sublayer adheres to the maximum number of OAMPDUs per second. The minimum is 1 OAMPDU per second and the maximum is 10 OAMPDUs per second.

Use the no form of this command to reset the maximum rate to its default.

Command Syntax

```
ethernet oam max-rate <1-10> no ethernet oam max-rate
```

Parameter

<1-10> Maximum number of PDUs per second.

Default

The default maximum rate is 10 PDUs per second.

Command Mode

Interface mode

Applicability

This command was introduced in OcNOS version 5.0.

```
#configure terminal
(config)#interface xe1
(config-if)#ethernet oam max-rate 10
```

ethernet oam min-rate

Use this command to set the minimum number of PDUs per second.

This command ensures that the sublayer adheres to the maximum number of OAMPDUs per second. The minimum is 1 OAMPDU per second and the maximum is 10 OAMPDUs per second.

Use the no form of this command to reset the minimum to its default.

Command Syntax

```
ethernet oam min-rate <1-10> no ethernet oam min-rate
```

Parameter

<1-10> Minimum number of PDUs per second.

Default

The default minimum rate is 1 PDU per second.

Command Mode

Interface mode

Applicability

This command was introduced in OcNOS version 5.0.

```
#configure terminal
(config)#interface xe1
(config-if)#ethernet oam min-rate 1
```

ethernet oam mode

Use this command to set data terminal equipment (DTE) to either active or passive mode.

Command Syntax

ethernet oam mode (active|passive)

Parameters

active	Set DTE to active mode.	
passive	Set DTE to passive mode.	

Default

The default mode for the DTE is active.

Command Mode

Interface mode

Applicability

This command was introduced in OcNOS version 5.0.

```
#configure terminal
(config)#interface xe1
(config-if)#ethernet oam mode active
```

```
#configure terminal
(config)#interface xe1
(config-if)#ethernet oam mode passive
```

ethernet oam remote-failure

Use this command to define an action when a remote failure is detected.

Use no form of this command to remove an action.

Command Syntax

```
ethernet oam remote-failure {critical-event|dying-gasp|link-fault} action error-
disable-interface
no ethernet oam remote-failure {critical-event|dying-gasp|link-fault} action error-
disable-interface
```

Parameters

critical-event Critical link event.

dying-gasp	Dying-gasp event.
link-fault	Link-fault event.
action	Action on a remote failure.
error-disabi	le-interface

Disable the interface when a remote failure event is detected.

Default

A remote failure does not trigger any interface events by default.

Command Mode

Interface mode

Applicability

This command was introduced in OcNOS version 5.0.

```
#configure terminal
(config)#interface xe1
(config-if)#ethernet oam remote-failure critical-event action error-disable-
interface
```

ethernet oam remote-loopback (start|stop)

Use this command to start or stop remote loopback.

Command Syntax

ethernet oam remote-loopback start ethernet oam remote-loopback stop

Parameters

start	Specify to start remote loopback.
stop	Specify to stop remote loopback.

Command Mode

Interface mode

Applicability

This command was introduced in OcNOS version 5.0.

```
#configure terminal
(config)#interface xe1
(config-if)#ethernet oam remote-loopback start
#configure terminal
```

```
(config)#interface xel
(config-if)#ethernet oam remote-loopback stop
```

ethernet oam remote-loopback {supported|timeout}

Use this command to configure remote loopback on an interface.

Use the no form of this command to remove remote-loopback support from the interface.

Command Syntax

```
ethernet oam remote-loopback {supported|timeout <1-10>}
no ethernet oam remote-loopback {supported|timeout}
```

Parameters

supported	Configure remote loopback support.
timeout	Remote loopback timeout.
<1-10>	Number of seconds the DTE waits for the remote DTE to respond to the ethernet oam
	remote-roopback start command.

Default

The default state for remote loopback is supported. If a timeout is not set, the local DTE remains in remote loopback state until the remote DTE responds or the user stops remote loopback administratively.

Command Mode

Interface mode

Applicability

This command was introduced in OcNOS version 5.0.

```
#configure terminal
(config) #interface xe1
(config-if) #ethernet oam remote-loopback supported
#configure terminal
(config) #interface xe1
(config-if) #ethernet oam remote-loopback timeout 2
#configure terminal
(config) #interface xe1
(config-if) #no ethernet oam remote-loopback supported
```

```
#configure terminal
(config)#interface xe1
(config-if)#no ethernet oam remote-loopback timeout
```

ethernet oam timeout

Use this command to set the OAM timeout.

Use the no form of this command to reset the timeout to its default.

Command Syntax

```
ethernet oam timeout <2-30>
no ethernet oam timeout
```

Parameter

<2-30> Number of seconds for the link timeout

Command Mode

Interface mode

Default

The default timeout is 5 seconds

Applicability

This command was introduced in OcNOS version 5.0.

Examples

#configure terminal
(config)#interface xe1
(config-if)#ethernet oam timeout 5

(config) #interface xe1
(config-if) #no ethernet oam timeout

show ethernet oam

Use this command to show the discovery state machine state and link event statistics on the interface.

Command Syntax

show ethernet oam IFNAME

Parameter

IFNAME Specify the interface name.

Command Mode

Exec mode and Privileged Exec mode

Examples

The following sample output from this command displays the operational discovery state machine and link event statistics of the interface.

```
#show ethernet oam eth0
eth0
Discovery State Machine Details:
_____
EFM Discovery Machine State:
                                        Send Any
Local Parser State:
                                        Forward
Local Multiplexer State:
                                        Forward
Remote Parser State:
                                        Forward
Remote Multiplexer State:
                                        Forward
Local Client:
_____
    Symbol Period Error:
                                        05f5e100 Symbol(s)
       Window:
                                        00 Symbol(s)
       Threshold:
       Last Window Symbols Errors:
                                      00 Symbol(s)
       Total Symbols Errors:
                                       00 Symbol(s)
       Total Symbols Errors Events: 0 Events(s)
       Relative Timestamp of the Event: 0 x 100 milliseconds
    Frame Error:
                                        100 x 100 milliseconds
       Window:
       Threshold:
                                        1 Error Frame(s)
       Last Window Frame Errors:
                                    0 Frame(s)
       Total Frame Errors:
                                        00 Frames(s)
       Total Frame Errors Events:Of Frames(s)0 Events(s)
       Relative Timestamp of the Event: 0 x 100 milliseconds
    Frame Period Error:
       Window:
                                        989680 Frames
       Threshold:
                                        1 Error Frame(s)
       Last Window Frame Errors:
Total Frame Errors:
                                       0 Frame(s)
                                     00 Frames(s)
       Total Frame Period Errors Events: 0 Events(s)
       Relative Timestamp of the Event: 0 x 100 milliseconds
```

Frame Seconds Error: Window: 1000 x 100 milliseconds 1 Error Second(s) Threshold: Last Window Frame Second Errors: 0 Frame(s) Total Frame Second Errors: 00 Frames(s) Total Frame Second Errors Events: 0 Events(s) Relative Timestamp of the Event: 0 x 100 milliseconds Remote Client: -----Symbol Period Error: Window: 00 Symbol(s) Threshold: 00 Symbol(s) Last Window Symbols Errors: 00 Symbol(s) Total Symbols Errors:00 Symbol(s)Total Symbols Errors Events:0 Events(s) Relative Timestamp of the Event: 0 x 100 milliseconds Frame Error: 0 x 100 milliseconds Window: Threshold: 0 Error Frame(s) Last Window Frame Errors: 0 Frame(s) Total Frame Errors: 00 Frames(s) Total Frame Errors Events:0 Events(s) Relative Timestamp of the Event: 0 x 100 milliseconds Frame Period Error: Window: 0 Frames 0 Error Frame(s) Threshold: Last Window Frame Errors: 0 Frame(s) Total Frame Errors: 00 Frames(s) Total Frame Period Errors Events: 0 Events(s) Relative Timestamp of the Event: 0 x 100 milliseconds

show ethernet oam discovery

Use this command to display the Ethernet OAM administrative and operation configuration for local and remote DTE.

Command Syntax

show ethernet oam discovery interface IFNAME

Parameter

interface	Specify the interface.
IFNAME	Specify the interface name.

Command Mode

Exec mode and Privileged Exec mode

Example

The following output displays ethernet OAM administrative and operation configurations for local and remote DTE.

```
#show ethernet oam discovery interface eth0
eth0
Local client:
_____
 Administrative configurations:
    Mode:
                                        passive
    Unidirection:
                                        supported
    Link monitor:
                                        supported(on)
    Remote Loopback:
                                        supported
    MIB retrieval:
                                        not supported
    MTU Size
                                        1518
              :
  Operational status:
     Port status:
                                        operational
    Loopback status:
                                        no loopback
    PDU revision:
                                        1
Remote client:
_____
 MAC address: 0002.b3d5.93b7
 Vendor(oui): 3 0 50
  Administrative configurations:
    Mode:
                                        active
    Unidirection:
                                        supported
    Link monitor:
                                        supported
    Remote Loopback:
                                        supported
    MIB retrieval:
                                        not supported
    MTU Size
                                        1518
                :
```

show ethernet oam eventlog

Use this command to display all event logs for an interface within given range.

Command Syntax

show ethernet oam eventlog IFNAME range-start <1-100> range-end <1-100>

Parameters

IFNAME	The name of the interface.
range-start	Starting range of log index.
<1-100>	Starting range of log index. This should not exceed the maximum log size.
range-end	Ending range of log index.
<1-100>	Ending range of log index. This should not exceed the maximum log size.

Command Mode

Exec mode and Privileged Exec mode

Example

The following displays an example of this command:

#show ethernet oam eventlog eth1 range-start 10

show ethernet oam statistics

Use this command to see the Ethernet OAM statistics.

Command Syntax

show ethernet oam statistics interface IFNAME

Parameter

interface	Specify the interface.
IFNAME	Specify the interface name.

Command Mode

Privileged Exec mode

Example

The following sample output from this command displays Ethernet OAM statistics for the interface named eth0.

```
#show ethernet oam statistics interface eth0
eth0
Counters:
_____
   Information OAMPDU Tx
                                         : 39
   Information OAMPDU Rx
                                         : 39
   Event Notification OAMPDU Tx
                                         : 0
   Event Notification OAMPDU Rx
                                         : 0
   Loopback Control OAMPDU Tx
                                         : 0
   Loopback Control OAMPDU Rx
                                        : 0
                                        : 0
   Unsupported OAMPDU Rx
Local event logs:
 _____
   0 Errored Symbol Period records
   0 Errored Frame records
   0 Errored Frame Period records
   0 Errored Frame Seconds records
Remote event logs:
_____
   0 Errored Symbol Period records
   0 Errored Frame records
   0 Errored Frame Period records
    0 Errored Frame Seconds records
```

show ethernet oam status

Use this command to display the ethernet OAM and link monitoring status of the interface.

Command Syntax

show ethernet oam status interface IFNAME

Parameter

interface	Specify the interface.
IFNAME	Specify the interface name.

Command Mode

Privileged Exec mode

Example

The following sample output displays the operational discovery state machine and link event statistics of the interface.

```
#show ethernet oam status interface eth0
eth0
General:
  Mode:
                                       passive
   PDU max rate:
                                       10 packets per second
   PDU min rate:
                                       1 packet per 1 second
  Link timeout:
                                       5 seconds
  High threshold action:
                                      no action
Link Monitoring:
     Status:
                                       supported(on)
     Symbol Period Error:
                                       100 million symbols
        Window:
        Low threshold:
                                       0 error symbol(s)
        High threshold:
                                       none
     Frame Error:
                                       100 x 100 milliseconds
        Window:
        Low threshold:
                                       1 error frame(s)
        High threshold:
                                      none
     Frame Period Error:
                                       1000 x 100,000 frames
        Window:
        Low threshold:
                                       1 error frame(s)
        High threshold:
                                       none
     Frame Seconds Error:
        Window:
                                       1000 x 100 milliseconds
        Low threshold:
                                       1 error second(s)
        High threshold:
                                       none
```

show ethernet oam discovery brief

Use this command to list the brief overview of ethernet oam (EFM) across all the interfaces.

Command Syntax

show ethernet oam discovery brief

Parameter

None

Config Mode

Exec mode

Applicability

Ethernet OAM (EFM) supported platforms

Example

#show ethernet oam discovery brief

Flags : L - Link Monitoring support M - MIB Retrieval support
R - Remote Loopback support U - Unidirectional detection support

data is unavailable

Local	Interface	Remote MAC	Remote Capability	Local Capability
xe0		0000.0000.0000	Passive LR	Active LR
xe1		*	*	Active LR

Index

В

begin modifier 17 BGP community value command syntax 15 braces command syntax 14

С

cc interval 346, 347 cc multicast 354 CFM commands cc interval 346. 347 cc multicast 354 mep crosscheck mpid 395 show ethernet cfm ma status 424 command abbreviations 13 command completion 13 command line errors 13 help 12 keyboard operations 16 command modes 20 configure 20 exec 20 interface 20 privileged exec 20 router 20 command negation 14 command syntax ? 15 . 15 () 14 {} 14 | 14 A.B.C.D/M 15 AA:NN 15 BGP community value 15 braces 14 conventions 14 curly brackets 14 HH:MM:SS 15 **IFNAME 15** interface name 15 IPv4 address 15 IPv6 address 15 LINE 15 lowercase 14 MAC address 15 monospaced font 14 numeric range 15 parantheses 14 parentheses 14 period 15

question mark 15 square brackets 15 time 15 uppercase 14 variable placeholders 15 vertical bars 14 WORD 15 X:X::X:X 15 X:X::X:X/M 15 XX:XX:XX:XX:XX:XX 15 configure EFM OAM Ethernet to the First Mile 323 configure mode 20 curly brackets command syntax 14

Ε

Ethernet OAM CLI ethernet oam disable 512 ethernet oam enable 512 ethernet oam link-monitor on 514 ethernet oam link-monitor remote-failure 519 ethernet oam link-monitor supported 515 ethernet oam max-rate 516 ethernet oam remote-loopback 520 show ethernet oam discovery interface 525 show ethernet oam interface statistics 527 show ethernet oam status interface 528 ethernet oam disable 512 ethernet oam enable 512 ethernet oam link-monitor on 514 ethernet oam link-monitor remote-failure 519 ethernet oam link-monitor supported 515 ethernet oam max-rate 516 ethernet oam remote-loopback 520 Ethernet Ring Protection Switching (ERPS) configuration 211 EVPN-ELINE CFM Sub-Interface on Single Homing-5b80344b-e540-4a1a-ae98-fd895db9fd9c 35, 147, 184, 195 exec command mode 20

I

IFNAME 15 interface mode 20 IPv4 address command syntax 15 IPv6 address command syntax 15

L

LINE 15 link Monitoring validation 323, 335

Μ

MAC address command syntax 15

Ρ

parantheses command syntax 14 parentheses command syntax 14 period command syntax 15 privileged exec mode 20

Q

question mark command syntax 15

R

remote failure detection 324, 336 router mode 20

S

show commands 17 exclude modifier 18 include modifier 18 redirect modifier 19 show ethernet oam discovery interface 525 show ethernet oam interface statistics 527 show ethernet oam status interface 528 square brackets command syntax 15

Т

time command syntax 15

V

validation 324, 336 vertical bars command syntax 14

W

WORD 15