



OcNOS®
Open Compute
Network Operating System
for Service Providers
Version 6.4.2

NetConf Command Reference

December 2023

© 2023 IP Infusion Inc. All Rights Reserved.

This documentation is subject to change without notice. The software described in this document and this documentation are furnished under a license agreement or nondisclosure agreement. The software and documentation may be used or copied only in accordance with the terms of the applicable agreement. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or any means electronic or mechanical, including photocopying and recording for any purpose other than the purchaser's internal use without the written permission of IP Infusion Inc.

IP Infusion Inc.
3965 Freedom Circle, Suite 200
Santa Clara, CA 95054
+1 408-400-1900
<http://www.ipinfusion.com/>

For support, questions, or comments via E-mail, contact:
support@ipinfusion.com

Trademarks:

IP Infusion and OcNOS are trademarks or registered trademarks of IP Infusion. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Use of certain software included in this equipment is subject to the IP Infusion, Inc. End User License Agreement at <http://www.ipinfusion.com/license>. By using the equipment, you accept the terms of the End User License Agreement.

Contents

Preface	lxxxiii
Audience	lxxxiii
Conventions	lxxxiii
Related Documentation	lxxxiii
Feature Availability	lxxxiii
Support	lxxxiii
Comments	lxxxiii
CHAPTER 1 NetConf Reference	85
IPI-MANAGEMENT-SERVER	85
Configure feature enabled	85
Configure management port	85
Configure port	86
Configure enable	86
Configure retry max attempts	87
Configure retry interval	87
Configure translation mode	88
Configure feature netconf ssh	88
Configure vrf name	89
Configure feature netconf tls	89
Configure ssh port	90
Configure tls port	90
IPI-STREAMING-TELEMETRY	91
Configure feature enabled	91
Configure gnmi severity	92
Configure gnmi debug	92
IPI-MANAGEMENT-SERVER-NOTIFICATION	93
Configure severity	93
IPI-VRF	93
Configure instance name	93
Configure instance type	94
Configure description	95
Configure tunnel select policy	95
Configure router id	96
Configure evpn layer3 network id	96
Configure snmp context name	97
clear router-id	98
clear router-id vrf (VRFNAME)	98
IPI-INTERFACE	98
Configure name	98
Configure enable switchport	99
Configure vrf name	99

Configure vr name	100
Configure mtu	100
Configure dot1ad ether type	101
Configure bridge domain forward	101
Configure description	101
Configure shutdown	102
Configure if loopback	102
clear interface (IFNAME) counters	103
IPI-GLOBAL-TE	103
Configure id	103
IPI-IF-ETHERNET	104
Configure duplex mode	104
Configure secondary mac address	104
Configure port speed	105
Configure enable rcv	105
Configure enable rcv	106
Configure enable snd	107
IPI-IF-IP	108
Configure primary ip addr	108
Configure enable dhcp ip address	108
Configure ip addr label	109
Configure ipv4 unnumbered if name	109
Configure remote address	110
Configure primary anycast	110
Configure ip address	111
Configure ip label	112
Configure secondary anycast	112
Configure ipv6 unnumbered if name	113
Configure enable dhcp ipv6 address	113
Configure enable dhcp temporary ipv6 address	114
Configure dhcp address prefix length	114
Configure enable auto config	115
Configure ipv6 address	115
Configure anycast	116
Configure disable ip forwarding	117
Configure disable ipv6 forwarding	117
Configure router id	117
Configure enable auto router id selection	118
Configure default vrf enable icmp broadcast	118
Configure disable ip vrf forwarding	118
Configure disable ipv6 vrf forwarding	119
Configure enable icmp broadcast	119
IPI-IF-EXTENDED	120
Configure group index	120
Configure protected port	120
Configure name	121
Configure link flap error disable	121

Configure mac move limit error disable	122
Configure disable snmp trap link status	122
Configure mau default type	123
Configure debounce time	124
Configure enable re routing	124
Configure enable speed	125
Configure enable queue drops	125
Configure warning threshold	126
Configure subif service queue	126
Configure aclif type	127
Configure encap default	128
Configure encap untagged	128
Configure vlan action	129
Configure push tpid	130
Configure rewrite translate action	131
Configure dot1q dot1ad tpid	132
Configure outer vlan id	133
Configure enable pop	134
Configure vlan action	135
Configure encapsulation type	135
Configure outer vlan id	136
Configure split horizon group	137
Configure linkup debounce time	138
Configure rate	138
Configure l2cp type	139
Configure forward err correction	140
Configure load interval	140
Configure bcast value	141
Configure bcast rate limit format	142
Configure mcast value	142
Configure mcast rate limit format	143
Configure dlf bcast value	144
Configure dlf bcast rate limit format	145
Configure error disable stp bpdu guard	145
Configure reason	146
Configure link flap timer interval	146
Configure timeout interval	147
Configure mac move limit	147
Configure mode	148
Configure src	149
Configure multicast interface	149
Configure dst	150
Configure checksum enable	150
Configure tos byte	151
Configure ttl	151
Configure path mtu enable	152
Configure dst mac address	152

Configure gre key	153
clear interface (IFNAME) cpu counters	153
clear interface (IFNAME) fec	154
clear interface IFNAME error-disable	154
clear I2protocol interface (IFNAME) counters (peer tunnel discard tunnel-discard)	154
no sniff	155
IPI-IF-FLOWSPEC	155
Configure disable	155
IPI-SYNCE	156
Configure enable	156
Configure network option	156
Configure clock selection mode	157
Configure dpll3 select 10mhz in	157
Configure holdover timer	157
Configure name	158
Configure synchronous mode	158
Configure input source priority	159
Configure is output source	159
Configure wait to restore timer	160
Configure vlan id	161
Configure hold off timer	161
Configure quality level	162
Configure clock source id	162
Configure auto neg mode	163
Configure external synce interface	163
Configure options	164
clear synce stats (interface IFNAME)	164
debug synce (event recvd trans all)	164
no debug synce (event recvd trans all)	165
IPI-SYSTEM	165
Configure hostname	165
Configure timezone name	165
IPI-NETWORK-SERVICES-MANAGER	166
Configure options	166
Configure module name	166
debug nsm ((addressmonitor bfd events hal events hal ipc linkmonitor packet packet detail packet recv packet recv detail packet send packet send detail vxlan ipsec mpls all)) . 167	
no debug nsm ((addressmonitor bfd events hal events hal ipc linkmonitor packet packet detail packet recv packet recv detail packet send packet send detail vxlan ipsec mpls all)) . 167	
debug hsl (general ifmgr bridge msg fib fdb devdrv pktdrv platform pbr bfd lcp qos helper rbridge nvo ofl mlag mpls srv6 ptp extphy) {all default info debug warn error fatal admin counter pkt} 168	
no debug hsl (general ifmgr bridge msg fib fdb devdrv pktdrv platform pbr bfd lcp qos helper rbridge nvo ofl mlag mpls srv6 ptp extphy) {all default info debug warn error fatal admin counter pkt} 168	

debug pktmgr (l2 protocol cfm l2 protocol eapol l2 protocol efm l2 protocol igmp-snoop l2 protocol lacp l2 protocol lldp l2 protocol mldp-snoop l2 protocol mstp l2 protocol ptp l2 protocol all)	169
no debug pktmgr	169
debug pktmgr enable	169
debug pktmgr disable	170
debug pktmgr stats	170
debug pktmgr (stats pkt-errors)	170
clear nsm ipc stats	170
snmp restart nsm	171
IPI-BRIDGE	171
Configure protocol	171
Configure instance name	171
Configure disable dynamic learning	172
Configure l2 protocol destination mac	173
Configure dot1ad encapsulation	173
Configure spanning tree protocol status	174
Configure disable mac learning	175
Configure interface name	175
clear mac address-table (multicast) cvlan VID svlan VID bridge <1-32>	176
clear mac address-table (multicast) (interface IFNAME) (address MACADDR) (vlan VID) bridge <1-32>	177
clear mac address-table dynamic cvlan VID svlan VID bridge <1-32>	177
clear mac address-table dynamic (interface IFNAME) (address MACADDR) (vlan VID) bridge <1-32>	178
clear mac address-table dynamic interface IFNAME instance INST bridge <1-32>	178
IPI-VLAN	179
Configure disable mac learning	179
Configure vlan id	180
Configure type	181
Configure instance name	182
Configure instance type	183
Configure secondary vlan	183
Configure mac address	184
Configure ipv4 address	185
Configure ether type	185
Configure group id	186
Configure port name	186
Configure disable vlan classifier feature	187
Configure disable port security	187
Configure table name	188
Configure svlan id	188
Configure cvlan id	189
Configure cos to queue	190
Configure untagged ep	191
IPI-PORT-VLAN	193
Configure isolated vlan id	193

Configure cvlan registration table	193
Configure interface mode	194
Configure name	194
Configure acceptable frame type	195
Configure disable native vlan	196
Configure remove default vlan	196
Configure vlan id	197
Configure native vlan id	198
Configure translated svlan id	198
Configure original svlan id	199
Configure translated cvlan id	200
Configure cvlan id	201
Configure svlan id	202
Configure logging	203
Configure mode	203
Configure maximum limit	204
Configure mac address	204
Configure associate vlan id	205
Configure mapping vlan id	206
Configure association trunk vlan id	206
Configure instance name	207
Configure instance type	208
IPI-XSTP	209
Configure ageing time	209
Configure instance name	210
Configure enable cisco interoperability	210
Configure forwarding delay	211
Configure hello time	212
Configure max age	212
Configure max hops	213
Configure bridge priority	214
Configure transmit hold count	215
Configure enable bpdu filter	215
Configure enable bpdu guard	216
Configure enable error disable timeout	217
Configure force version	217
Configure path cost method	218
Configure bridge type	219
Configure disable spanning tree	219
Configure bridge forwarding	220
Configure enable shutdown	221
Configure region name	222
Configure revision number	223
Configure vlan id	224
Configure disable spanning tree	224
Configure name	225
Configure instance id	226

Configure instance type	227
Configure instance id	227
Configure path cost	228
Configure port priority	229
Configure port configuration	230
Configure enable automatic edge detection	231
Configure bpdu guard	231
Configure bpdu filter	232
Configure enable root guard	232
Configure link type	233
Configure enable restricted domain role	233
Configure enable restricted role	234
Configure enable restricted tcn	234
Configure enable instance restricted tcn	235
Configure enable instance restricted role	235
Configure forward delay	236
Configure svlan id	237
Configure options	237
debug (mstp protocol mstp protocol detail mstp timer mstp timer detail mstp packet tx mstp packet rx mstp cli mstp bpdu mstp mceec mstp all)	238
no debug (mstp protocol mstp protocol detail mstp timer mstp timer detail mstp packet tx mstp packet rx mstp cli mstp bpdu mstp mceec mstp all)	238
clear spanning-tree detected protocols bridge <1-32>	238
clear spanning-tree detected protocols interface INTERFACE	239
clear spanning-tree statistics (spbm <1-63>) bridge <1-32>	239
clear spanning-tree statistics interface IFNAME vlan <2-4094> bridge <1-32>	239
clear spanning-tree statistics interface IFNAME bridge <1-32>	240
clear spanning-tree statistics bridge <1-32>	240
clear spanning-tree statistics vlan <2-4094> bridge <1-32>	241
clear spanning-tree statistics interface IFNAME (spbm <1-63>) bridge <1-32>	241
snmp restart mstp	241
IPI-IF-AGGREGATE	242
Configure aggregate id	242
Configure lacp mode	242
Configure weight	243
Configure min links	244
Configure min bandwidth	244
IPI-LACP	245
Configure system priority	245
Configure options	245
Configure port priority	246
Configure timeout	246
Configure bridge type	247
Configure force up	247
snmp restart lacp	248
clear lacp (<1-65535>) counters	248
debug lacp (event cli timer packet rx tx sync ha all)	248

no debug lldp (event cli timer packet rx tx sync ha all)	249
IPI-LLDPV2	249
Configure enable	249
Configure notification interval	249
Configure port description	250
Configure system description	250
Configure system name	251
Configure system capabilities	251
Configure management address	252
Configure port vlan id	252
Configure port protocol vlan id	253
Configure vlan name	253
Configure protocol identifier	254
Configure vid digest	254
Configure management vlan id	254
Configure link aggregation	255
Configure mac phy	255
Configure max mtu size	256
Configure locally assigned chassis id	256
Configure options	257
Configure disable lldp agent	257
Configure agent circuit id	258
Configure med device type	258
Configure local name	259
Configure agent type	259
Configure enable tx rx	260
Configure reinit delay	260
Configure message tx interval	261
Configure message tx hold multiplier	262
Configure message fast tx	263
Configure tx credit max	263
Configure tx fast init	264
Configure neighbor timer	265
Configure port timer	266
Configure port address	267
Configure chassis id	267
Configure port id	268
Configure name	269
Configure network policy	270
Configure location	270
Configure inventory	271
Configure media capabilities	272
debug lldp (event rx tx message ha all)	273
no debug lldp (event rx tx message ha all)	273
clear lldp counters ((IFNAME))	273
snmp restart lldp	274
IPI-RIB	274

Configure fib retain	274
Configure max ecmp paths	274
Configure max static routes	275
Configure max fib routes	275
Configure ipv4 enable bfd all interfaces	276
Configure ipv6 enable bfd all interfaces	276
Configure rib options	276
Configure ipv4 routing options	277
Configure ipv6 routing options	277
Configure interface name	278
Configure bfd state	278
Configure description	279
Configure destination prefix	280
Configure distance	281
Configure gateway address	281
Configure track id	282
Configure source prefix	283
Configure ipv4 enable bfd	284
Configure ipv6 enable bfd	284
snmp restart rib	285
clear ip route kernel	285
clear ip kernel route	285
clear ipv6 route kernel	285
clear ip route *	285
clear ip route A.B.C.D/M	286
clear ipv4 route *	286
clear ipv4 route A.B.C.D/M	286
clear ipv6 route *	286
clear ipv6 route X:X::X:X/M	287
debug rib (all events packet packet send packet rcv packet detail packet send detail packet rcv detail nsm bfd monitor hal events hal ipc)	287
no debug rib (all events packet packet send packet rcv packet detail packet send detail packet rcv detail nsm bfd monitor hal events hal ipc)	287
debug ip routing (all add-route delete-route mod-route)	288
no debug ip routing (all add-route delete-route mod-route)	288
debug ipv6 routing (all add-route delete-route mod-route)	288
no debug ipv6 routing (all add-route delete-route mod-route)	288
IPI-RIB-VRF	289
Configure ipv4 enable bfd all interfaces	289
Configure ipv6 enable bfd all interfaces	289
Configure enable global table lookup	290
Configure interface name	291
Configure track id	292
Configure bfd state	293
Configure instance type	293
Configure description	294
Configure instance name	296

Configure destination prefix	297
Configure distance	298
Configure source prefix	299
Configure destination prefix	300
Configure enable ipv6 global table lookup	301
Configure gateway address	301
Configure gateway address	302
Configure protocol type	303
clear ip route vrf NAME *	304
clear ip route vrf NAME A.B.C.D/M	305
clear ipv4 route vrf NAME *	305
clear ipv4 route vrf NAME A.B.C.D/M	305
clear ipv6 route vrf NAME *	306
clear ipv6 route vrf NAME X:X::X:X/M	306
IPI-OSPF	306
Configure area interface config mode	306
Configure enable multi instance capability	307
Configure grace period	307
Configure max grace period	308
Configure disable all neighbors	308
Configure disable neighbor	309
Configure tie break method	309
Configure default retry interval	309
Configure enable better protection	310
Configure ospf id	310
Configure router id	311
Configure flood reduction	311
Configure rfc1583 compatibility	312
Configure database summary	312
Configure bfd enable all interfaces	313
Configure log adjacency changes	313
Configure shutdown	314
Configure area border type	314
Configure reference bandwidth	315
Configure max database descriptors	315
Configure p2p rfc incompatible	316
Configure context name	316
Configure passive interface all	317
Configure passive mode	317
Configure address	318
Configure originate	319
Configure route map	319
Configure mpls	320
Configure block range size	321
Configure disable receive	322
Configure advertise local	322
Configure entropy capability	323

Configure disable cspf	323
Configure disable traffic engineering	324
Configure disable graceful restart	324
Configure disable opaque lsa	325
Configure enable vrf lite	326
Configure link local signaling	326
Configure maximum areas number	327
Configure disable advertise	327
Configure authentication type	328
Configure default cost	329
Configure shortcut	329
Configure name	330
Configure cost	331
Configure network type	331
Configure passive	332
Configure priority	333
Configure area id	334
Configure enabled	335
Configure filter out	336
Configure traffic engineering metric	336
Configure ldp igp sync enable	337
Configure holddown timer	338
Configure dead interval	339
Configure hello interval	340
Configure retransmission interval	341
Configure no summary	342
Configure is stub	343
Configure nssa enable	344
Configure stability interval	344
Configure ip address	346
Configure instance id	347
Configure remote router id	347
Configure fall over	348
Configure key	349
Configure message digest id	350
Configure transmit delay	351
Configure destination id	352
Configure source id	353
Configure limit type	354
Configure exit interval	355
Configure keep all paths	356
Configure remote lfa areas	356
Configure idx	357
Configure default distance	358
Configure intra area distance	358
Configure access control list	359
Configure not advertise	360

Configure tag	360
Configure access control list isis	361
Configure access control list bgp	362
Configure access control list rip	362
Configure access control list static	363
Configure access control list connected	364
Configure access control list kernel	364
Configure ospf process id	365
Configure primary domain id address	366
Configure primary domain id hex	366
Configure secondary domain id address	367
Configure secondary domain id hex	368
Configure throttle timer	369
Configure poll interval	369
Configure termination hold interval	370
Configure min arrival interval	371
Configure max delay	372
Configure min delay	372
Configure default metric	373
Configure protocol	374
Configure metric	374
Configure metric type	375
Configure isis process id	376
Configure include stub	377
Configure enable max router lsa	378
Configure on startup include stub	378
Configure max on startup	379
Configure teName	380
Configure link local exchange	380
Configure neighbor	381
Configure rate limit	382
Configure bfd	384
Configure retransmission	386
Configure cspf events	387
Configure segment routing	387
Configure route	388
Configure rib	388
Configure nsm	388
Configure nfsm	389
Configure lsa	389
Configure ifsm	390
Configure events	390
Configure cspf hexdump	390
Configure distribute	391
Configure topology independent lfa	391
Configure lfa	391
Configure policy	392

Configure redistribute	392
Configure graceful restart	393
Configure packet hello	393
Configure packet dd	393
Configure packet ls request	394
Configure packet ls update	394
Configure packet ls ack	395
clear ip ospf <0-65535> process	395
clear ip ospf process	395
restart ip ospf graceful (grace-period <2-1800>)	395
snmp restart ospf	396
debug ospf all	396
no debug ospf all	396
debug ospf bfd	396
no debug ospf bfd	397
debug ospf database-timer rate-limit	397
no debug ospf database-timer rate-limit	397
debug ospf sr	397
no debug ospf sr	397
debug ospf route ({spf ia ase install spf-terse})	398
no debug ospf route ({spf ia ase install spf-terse})	398
debug ospf rib ({interface redistribute})	398
no debug ospf rib ({interface redistribute})	398
debug ospf packet ({send recv detail})	399
no debug ospf packet ({send recv detail})	399
debug ospf packet hello ({send recv detail})	399
no debug ospf packet hello ({send recv detail})	400
debug ospf packet dd ({send recv detail})	400
no debug ospf packet dd ({send recv detail})	400
debug ospf packet ls-request ({send recv detail})	400
no debug ospf packet ls-request ({send recv detail})	401
debug ospf packet ls-update ({send recv detail})	401
no debug ospf packet ls-update ({send recv detail})	401
debug ospf packet ls-ack ({send recv detail})	402
no debug ospf packet ls-ack ({send recv detail})	402
debug ospf nsm ({interface redistribute})	402
no debug ospf nsm ({interface redistribute})	402
debug ospf nsm ({status events timers})	403
no debug ospf nsm ({status events timers})	403
debug ospf lsa ({generate flooding install refresh maxage})	403
no debug ospf lsa ({generate flooding install refresh maxage})	404
debug ospf ifsm ({status events timers})	404
no debug ospf ifsm ({status events timers})	404
debug ospf events ({abr nssa asbr vlink lsa os router})	404
no debug ospf events ({abr nssa asbr vlink lsa os router})	405
debug cspf all	405
no debug cspf all	405

debug cspf events	406
no debug cspf events	406
debug cspf hexdump	406
no debug cspf hexdump	406
debug ip ospf all	406
no debug ip ospf all	407
debug ip ospf retransmission	407
no debug ip ospf retransmission	407
debug ip ospf dist-ls	407
no debug ip ospf dist-ls	407
debug ip ospf tilfa	408
no debug ip ospf tilfa	408
debug ip ospf lfa	408
no debug ip ospf lfa	408
debug ip ospf policy	408
no debug ip ospf policy	409
debug ip ospf redistribute ({{detail terse}})	409
no debug ip ospf redistribute ({{detail terse}})	409
debug ip ospf graceful-restart ({{detail terse}})	409
no debug ip ospf graceful-restart ({{detail terse}})	410
IPI-OSPF-INTERFACE	410
Configure cost	410
Configure priority	411
Configure mtu ignore	411
Configure network type	412
Configure disable all ospf	412
Configure traffic engineering metric	412
Configure mtu	413
Configure enable flood reduction	414
Configure enable demand circuit	414
Configure enable bfd	414
Configure disable fast reroute	415
Configure message digest id	415
Configure name	416
Configure authentication type	417
Configure key	418
Configure message digest encryption type	419
Configure filter out	419
Configure dead interval	420
Configure hello interval	421
Configure retransmission interval	422
Configure ldp igp sync enable	423
Configure transmit delay	423
Configure resync timeout	424
Configure holddown timer	424
Configure interface address	425
Configure message digest key	426

IPI-OSPFV3	427
Configure display route on single line	427
Configure grace period	427
Configure controlled restarts only	428
Configure max grace period	428
Configure disable all neighbors	429
Configure disable neighbor	429
Configure vrf name	430
Configure ospfv3 id	430
Configure router id	431
Configure bfd enable all interfaces	431
Configure database summary	432
Configure area border type	432
Configure default metric	433
Configure shutdown	433
Configure log adjacency changes	434
Configure reference bandwidth	434
Configure max database descriptors	435
Configure default distance	435
Configure intra area distance	436
Configure traffic engineering	437
Configure disable graceful restart	437
Configure exponential max delay	438
Configure ospf6SRv6enable	438
Configure ospf6SRv6LocatorName	439
Configure all interfaces	440
Configure name	440
Configure address	441
Configure translate tag	441
Configure not advertise	442
Configure all tag	443
Configure originate	444
Configure route map	444
Configure access control list	445
Configure protocol	446
Configure ospf process id	447
Configure metric	447
Configure metric type	448
Configure default cost	450
Configure no summary	450
Configure enable	451
Configure area id	452
Configure remote router id	452
Configure bfd fall over	453
Configure instance id	454
Configure authentication cryptomap	455
Configure dead interval	456

Configure tag	457
Configure always advertise default route	458
Configure protocol af	459
Configure route tag	460
Configure ospfv2 process id	461
Configure enabled	461
Configure throttle timer	462
Configure retransmission	463
Configure bfd	464
Configure dist ls	466
Configure events	466
Configure ifsm	466
Configure lsa	467
Configure nfsm	467
Configure nsm	468
Configure rib	468
Configure route	468
Configure packet hello	469
Configure packet dd	469
Configure packet ls request	469
Configure packet ls update	470
Configure packet ls ack	470
debug ipv6 ospf	471
no debug ipv6 ospf	471
debug ipv6 ospf all	471
no debug ipv6 ospf all	471
debug ipv6 ospf bfd	471
no debug ipv6 ospf bfd	472
debug ipv6 ospf retransmission	472
no debug ipv6 ospf retransmission	472
debug ipv6 ospf dist-ls	472
no debug ipv6 ospf dist-ls	472
debug ipv6 ospf events ({abr asbr vlink os router nssa})	473
no debug ipv6 ospf events ({abr asbr vlink os router nssa})	473
debug ipv6 ospf ifsm ({status events timers})	473
no debug ipv6 ospf ifsm ({status events timers})	473
debug ipv6 ospf lsa ({generate flooding install refresh maxage})	474
no debug ipv6 ospf lsa ({generate flooding install refresh maxage})	474
debug ipv6 ospf nfsm ({status events timers})	474
no debug ipv6 ospf nfsm ({status events timers})	475
debug ipv6 ospf nsm ({interface redistribute})	475
no debug ipv6 ospf nsm ({interface redistribute})	475
debug ipv6 ospf packet ({send recv detail})	475
no debug ipv6 ospf packet ({send recv detail})	476
debug ipv6 ospf packet hello ({send recv detail})	476
no debug ipv6 ospf packet hello ({send recv detail})	476
debug ipv6 ospf packet dd ({send recv detail})	477

no debug ipv6 ospf packet dd ({send recv detail})	477
debug ipv6 ospf packet ls-request ({send recv detail})	477
no debug ipv6 ospf packet ls-request ({send recv detail})	477
debug ipv6 ospf packet ls-update ({send recv detail})	478
no debug ipv6 ospf packet ls-update ({send recv detail})	478
debug ipv6 ospf packet ls-ack ({send recv detail})	478
no debug ipv6 ospf packet ls-ack ({send recv detail})	479
debug ipv6 ospf rib ({interface redistribute})	479
no debug ipv6 ospf rib ({interface redistribute})	479
debug ipv6 ospf route ({spf ia ase install})	479
no debug ipv6 ospf route ({spf ia ase install})	480
clear ipv6 ospf (WORD) process	480
restart ipv6 ospf graceful (grace-period <2-1800>)	480
snmp restart ospf6	481
IPI-OSPFV3-INTERFACE	481
Configure shutdown	481
Configure enable link lsa suppression	481
Configure enable bfd	482
Configure interface name	483
Configure instance id	483
Configure network type	484
Configure cost	485
Configure priority	485
Configure traffic engineering metric	486
Configure mtu	487
Configure mtu ignore	488
Configure authentication cryptomap	488
Configure area id	489
Configure ospfv3 id	490
Configure dead interval	491
Configure hello interval	491
Configure transmission delay	492
Configure retransmission interval	493
Configure address	494
Configure poll interval	494
IPI-BGP	496
Configure address family name	496
Configure vrf name	496
Configure action name	497
Configure action standard number	497
Configure action name standard	498
Configure list type	499
Configure name	500
Configure action expanded	501
Configure expanded type	501
Configure extended action number	502
Configure extended action	503

Configure action	504
Configure value	505
Configure access list name	505
Configure enable aggregate nexthop	506
Configure enable path select	506
Configure disable adj out	507
Configure enable extended asn capability	507
Configure enable nexthop tracking	508
Configure nexthop tracking delay	508
Configure enable rfc 1771 strict origin	509
Configure config type	509
Configure enable per prefix label mode	509
Configure options	510
Configure update options	510
restart bgp graceful	511
clear bgp statistics	511
snmp restart bgp	511
debug bgp (all nht nsm fsm events filters keepalives updates dampening bfd mpls vpls link- state rib srv6 normal)	511
no debug bgp (all nht nsm fsm events filters keepalives updates dampening bfd mpls vpls link- state rib srv6 normal)	512
debug bgp updates (in out)	512
no debug all bgp	512
IPI-BGP-INSTANCE	513
Configure no external fail over	513
Configure no best path tie break	513
Configure inbound route filter enable	514
Configure no client route reflection	514
Configure med type	515
Configure bgp as	515
Configure router id	516
Configure cluster id	516
Configure local preference	517
Configure graceful shutdown capable	517
Configure graceful shutdown	518
Configure graceful shutdown local preference	518
Configure log neighbor changes	519
Configure scan interval	519
Configure best path dont compare originator	520
Configure enable deterministic med	520
Configure enforce first as for ebgp	521
Configure local as count	522
Configure multi path relax	522
Configure enable mpls nexthop tracking	523
Configure ignore aigp for bestpath	523
Configure identifier	524

Configure peer as number	524
Configure enable graceful restart	525
Configure restart time	525
Configure stale path max retention time	526
Configure route selection max defer time	527
Configure graceful reset	527
Configure keep alive	528
Configure always compare med	529
Configure ignore as path length	529
Configure best path compare confed	530
Configure external compare router id	530
Configure source ip prefix	531
Configure access list name	532
Configure all routes	532
Configure route map name	533
IPI-BGP-ADDRESS-FAMILY	534
Configure safi	534
Configure additional path fast reroute	534
Configure additional paths mode	535
Configure bgp as	536
Configure afi	536
Configure additional path select all	537
Configure additional paths best select count	538
Configure no client route reflection	538
Configure enable auto summary	539
Configure enable additional path pic	540
Configure enable network igp sync	540
Configure map name	541
Configure table map filter	542
Configure enable igp sync	543
Configure backdoor	544
Configure local network prefix	545
Configure aggregate address	546
Configure aggregate type	546
Configure local	547
Configure ebgp	548
Configure ebgp max path	549
Configure ibgp max path	550
Configure eibgp max path	551
Configure enable dampening	551
Configure reach half life	552
Configure max suppress time	553
Configure reuse penalty	554
Configure suppress penalty	556
Configure unreachable half life	557
Configure dampening rmap name	558
Configure protocol type	559

Configure redist route map name	560
Configure afi	561
Configure redistribute ospf route map	561
Configure bgpSRv6enable	562
Configure bgpSRv6LocatorName	563
clear ip bgp (A.B.C.D X:X::X:X WORD) (description LINE)	564
IPI-BGP-PEER-GROUP	564
Configure optional as	564
Configure peer group tag	565
Configure bgp as	566
Configure peer group range	567
Configure group limit	567
Configure enable peer bfd	568
Configure enable peer bfd multihop	569
Configure auth key encrypt	569
Configure password	570
Configure additional paths mode	571
Configure afi	572
Configure safi	572
Configure additional path select all	573
Configure additional paths best select count	574
Configure bgp port	575
Configure activate	576
Configure default peer route map name	577
Configure peer route map orig name	578
Configure weight	578
Configure route server client	579
Configure next hop self	580
Configure flowspec validation disable	581
Configure peer route reflector	582
Configure peer remove private as	583
Configure no send community	584
Configure no send community type	585
Configure neighbor attribute unchanged	585
Configure orf prefix capability	586
Configure peer allow ebgp vpn	587
Configure allow as number	588
Configure capability graceful restart	589
Configure prefix count	590
Configure stop update	591
Configure maximum prefix warning	592
Configure threshold percentage	593
Configure warning only	594
Configure unsuppress route map name	595
Configure access list identifier	596
Configure filter direction	597
Configure safi	598

Configure as access list identifier	599
Configure as list direction.	600
Configure route map name	601
Configure route map direction	602
Configure peer as	603
Configure graceful shut	604
Configure graceful shutdown timer	604
Configure peer restart time	605
Configure peer description.	606
Configure peer connect interval	606
Configure peer as origin interval	607
Configure min route advertisement interval	608
Configure enable dynamic capability	609
Configure collide established	609
Configure source identifier.	610
Configure enforce multi hop.	611
Configure neighbor override capability	611
Configure neighbor strict capability match	612
Configure disallow infinite hold time.	612
Configure disable capability negotiation	613
Configure neighbor passive	614
Configure peer shutdown description	614
Configure peer port	615
Configure bgp version	616
Configure enable ext opt param len.	616
Configure tcp adjust mss	617
Configure keep alive	618
Configure enabled	619
Configure maximum hop count	619
Configure peer local as	620
Configure no prepend local as	621
clear bgp peer-group WORD l2vpn evpn soft (out in).	622
IPI-BGP-PEER	622
Configure enable peer bfd	622
Configure bgp as	623
Configure enable peer bfd multihop.	624
Configure peer address	624
Configure interface name.	625
Configure mapped peer group tag	625
Configure tcp adjust mss	626
Configure auth key encrypt	627
Configure password	628
Configure additional paths mode	628
Configure afi.	629
Configure safi.	630
Configure additional path select all	631
Configure additional paths best select count	632

Configure bgp port	633
Configure activate	633
Configure de activate	634
Configure default peer route map name.	635
Configure peer route map orig name	636
Configure weight	637
Configure route server client	638
Configure next hop self	639
Configure flowspec validation disable	639
Configure peer route reflector	640
Configure peer remove private as	641
Configure no send community	642
Configure no send community type	643
Configure neighbor attribute unchanged	644
Configure orf prefix capability.	645
Configure peer allow ebgp vpn.	646
Configure allow as number.	646
Configure capability graceful restart.	647
Configure extended nexthop encode	648
Configure mapped peer group tag af	649
Configure prefix count	650
Configure stop update	651
Configure maximum prefix warning	652
Configure threshold percentage	653
Configure warning only.	654
Configure unsuppress route map name.	655
Configure access list identifier	656
Configure filter direction	657
Configure prefix list name.	658
Configure prefix filter direction	659
Configure as access list identifier.	660
Configure as list direction	661
Configure route map name.	662
Configure route map direction	663
Configure peer port	664
Configure min route advertisement interval	665
Configure peer as origin interval	666
Configure collide established	666
Configure peer description	667
Configure disallow infinite hold time	668
Configure disable capability negotiation.	668
Configure enforce multi hop	669
Configure graceful shut	669
Configure graceful shutdown timer.	670
Configure neighbor override capability.	671
Configure neighbor passive	671
Configure peer restart time.	672

Configure peer shutdown	673
Configure neighbor strict capability match	674
Configure source identifier	674
Configure bgp version	675
Configure enable ext opt param len	676
Configure peer connect interval	676
Configure peer as	677
Configure enable dynamic capability	678
Configure peer shutdown description	678
Configure hold time	679
Configure keep alive	680
Configure enabled	681
Configure maximum hop count	681
Configure peer local as	682
Configure no prepend local as	683
Configure replace local as	684
Configure admin status	685
Configure aigp send med	686
Configure send cost community id	687
Configure enable transitive	688
Configure point of insertion	689
clear ip bgp * (description LINE)	690
clear bgp * I2vpn evpn soft (out in)	690
clear bgp <1-4294967295> I2vpn evpn soft (out in)	691
clear bgp (A.B.C.D X::X::X:X WORD) I2vpn evpn soft (out in)	691
IPI-BGP-ADDRESS-FAMILY-VRF	691
Configure enable auto summary	691
Configure enable network igp sync	692
Configure map name	693
Configure table map filter	694
Configure local	695
Configure enable igp sync	696
Configure ebgp max path	696
Configure bgp as	697
Configure ibgp max path	698
Configure optional as	699
Configure auth key encrypt	700
Configure afi	701
Configure multipath relax	702
Configure graceful shutdown	703
Configure graceful shutdown capable	703
Configure graceful shutdown local preference	704
Configure additional path select all	705
Configure additional paths mode	706
Configure enable pic	706
Configure additional paths best select count	707
Configure protocol type	708

Configure redistrib route map name	709
Configure ospf instance number	710
Configure redistribute ospf route map	711
Configure peer as	711
Configure source identifier	712
Configure bgp version	713
Configure peer connection interval	714
Configure hold time	715
Configure enforce multihop	716
Configure peer shutdown	717
Configure peer group tag	718
Configure peer group range	719
Configure safi	720
Configure vrf name	721
Configure group limit	722
Configure keep alive	723
Configure peer shutdown description	724
Configure enabled	725
Configure maximum hop count	726
Configure neighbor passive	727
Configure disable capability negotiation	728
Configure enable dynamic capability	729
Configure min route advertisement interval	730
Configure peer as origin interval	731
Configure neighbor as override	732
Configure peer description	733
Configure peer restart time	733
Configure site origin identifier	734
Configure graceful shut	735
Configure graceful shut timer	736
Configure bgp port	737
Configure enable ext opt param len	738
Configure tcp adjust mss	739
Configure enable peer bfd	740
Configure enable peer bfd multihop	741
Configure activate	742
Configure default peer route map name	742
Configure peer route map orig name	743
Configure weight	744
Configure flowspec validation disable	745
Configure peer route reflector	746
Configure peer remove private as	747
Configure no send community	748
Configure no send community type	749
Configure neighbor attribute unchanged	750
Configure orf prefix capability	751
Configure peer allow ebgp vpn	752

Configure allow as number	752
Configure capability graceful restart	754
Configure prefix count	754
Configure stop update	755
Configure maximum prefix warning	757
Configure threshold percentage	758
Configure warning only	759
Configure unsuppress route map name	760
Configure access list identifier	761
Configure as access list identifier	762
Configure prefix list name	763
Configure route map name	764
Configure peer address	765
Configure password	766
Configure peer interface name	767
Configure de activate	768
Configure mapped peer group tag af	769
Configure filter direction	770
Configure as list direction	771
Configure prefix filter direction	772
Configure route map direction	773
Configure identifier	774
Configure peer as number	775
Configure enable dampening	776
Configure reach half life	776
Configure max suppress time	777
Configure unreachable half life	779
Configure dampening rmap name	780
Configure bgpSRv6enable	781
Configure sid alloc type	782
Configure peer local as	782
Configure no prepend local as	783
Configure backdoor	785
Configure local network prefix	786
Configure replace local as	787
clear ip bgp all vrf (VRFNAME all default) (description LINE)	788
clear ip bgp vrf WORD (A.B.C.D X::X:X WORD WORD) (description LINE)	788
IPI-BGP-VRF	789
Configure rd string	789
Configure import map	789
Configure export map	790
Configure direction	791
Configure service type	791
IPI-BGP-EPE	792
Configure enable epe	792
Configure enable peer node	793
Configure set name	793

Configure address	794
Configure peer address	795
Configure hop address	796
Configure hop address	797
Configure adjacent address	798
IPI-BGP-FLOWSPEC	799
Configure enable flowspec controller	799
Configure local install	799
Configure afi type	800
Configure service policy type	800
Configure vrf name	801
Configure attached policy map name	802
IPI-ENHANCED-PBR	803
Configure class type	803
Configure reference description	803
Configure protocol	804
Configure port	805
Configure destination port	805
Configure source port	806
Configure packet length	806
Configure fragment type	807
Configure destination prefix	808
Configure source prefix	808
Configure icmp type	809
Configure icmp code	810
Configure bit mask	810
Configure match dscp value	811
Configure type	812
Configure policy map name	812
Configure class map name	813
Configure drop traffic	813
Configure dscp set value	814
Configure rate unit	815
Configure route target	816
IPI-BFD	817
Configure notification enabled	817
Configure echo mode enabled	817
Configure slow tx interval	818
Configure detection multiplier	818
Configure remote address	819
Configure key string	820
Configure options	820
Configure enable oam srv6	821
Configure enable mpls ping request	821
Configure mpls ping reply	822
snmp restart bfd	822
debug bfd (events packets ipc-error ipc-event session nsm all)	822

no debug bfd (events packets ipc-error ipc-event session nsm all)	822
debug oam srv6	823
no debug oam srv6	823
IPI-BFD-INTERFACE	823
Configure bfd disabled	823
Configure bfd session type	824
Configure detection multiplier	824
Configure ipv4 source	825
Configure name	825
Configure required minimum tx interval	826
Configure key string	826
Configure session type	827
Configure administrative down	828
Configure non persistent	829
IPI-SEAMLESS-BFD	829
Configure sr policy name	829
Configure admin down	830
Configure detection multiplier	830
Configure discriminator	831
Configure required min rx interval	832
IPI-IGP-TE	832
Configure delay	832
Configure delay variation	833
Configure loss percentage	833
Configure loss dynamic	834
Configure name	835
Configure dscp	835
Configure delay dynamic twamp	836
Configure a bit max	837
Configure max value	838
Configure loss a bit max	839
Configure a bit max range maximum	839
clear twamp measurement interface IFNAME	840
clear twamp measurement interface all	841
IPI-VRRP	841
Configure disable virtual router mac address	841
Configure vrrp v2 compatible	841
Configure ipv4 exclude pseudo header	842
Configure options	842
Configure interface name	843
Configure disable preempt mode	843
Configure disable accept mode	844
Configure virtual router id	844
Configure authentication data	845
Configure primary ip address	846
Configure mlag active standby	846
Configure priority	847

Configure preempt delay	848
Configure advertisement interval	848
Configure enable	849
Configure ip address owner	850
Configure interface tracking name	851
Configure tracking id	851
Configure virtual ip address	852
Configure priority decrement	853
Configure decrement	854
snmp restart vrrp	855
clear vrrp global statistics	855
clear vrrp ipv4 statistics	855
clear vrrp ipv6 statistics	855
clear vrrp ipv4 statistics <1-255> IFNAME	856
clear vrrp ipv6 statistics <1-255> IFNAME	856
debug vrrp	856
no debug vrrp	857
debug vrrp (all packet events packet send packet rcv)	857
no debug vrrp (all packet events packet send packet rcv)	857
IPI-PREFIX-LIST	857
Configure prefix list name	857
Configure prefix list type	858
Configure description	858
Configure prefix addr	859
Configure sequence id	860
Configure maximum prefix length match	860
Configure minimum prefix length match	861
Configure action	862
Configure exact prefix length match	863
Configure ipv6 prefix addr	864
Configure disable ipv4 sequence display	865
Configure disable ipv6 sequence display	865
clear (ip ipv6) prefix-list	866
clear ip prefix-list WORD (A.B.C.D/M)	866
clear ipv6 prefix-list WORD (X:X::X:X/M)	866
IPI-ISIS	867
Configure vrf name	867
Configure instance	867
Configure enable cspf capability	868
Configure disable gr capability	868
Configure disable adjacency check	869
Configure authentication send only	869
Configure distribute bgp ls	870
Configure distance	870
Configure dynamic host name	871
Configure ignore lsp errors	871
Configure lfa hold timer	872

Configure protocol topology	872
Configure level capability	873
Configure incremental spf levels	873
Configure priority tag	874
Configure enable bfd all interfaces	874
Configure maximum area addresses	875
Configure context name	875
Configure area password	876
Configure sequence number packet	876
Configure net	877
Configure domain password	878
Configure domain snp	878
Configure level number	879
Configure style	880
Configure lsp refresh interval	880
Configure lsp lifetime interval	881
Configure ipv4 router id	882
Configure ipv6 router id	882
Configure enable	883
Configure level 1 acl	883
Configure level 2 acl	884
Configure originate	885
Configure route map name	885
Configure afi name	886
Configure administrative distance	887
Configure ipv6 metric value	887
Configure prefix	888
Configure level	889
Configure isisSRv6enable	890
Configure isisSRv6LocatorName	890
Configure access list name	891
Configure set bit on boot	892
Configure enabled	892
Configure metric value	893
Configure metric	894
Configure id	895
Configure metric type	896
Configure passive interface all	897
Configure name	897
Configure hold timer	898
Configure max fib	898
Configure level type	899
Configure enable level 1	900
Configure enable level 2	900
Configure options	901
Configure enable hello	901
Configure cspf	902

clear clns is-neighbors System-ID	902
clear clns neighbors	902
clear ip isis (WORD) route (redistribution all)	902
clear ipv6 isis (WORD) route (redistribution all)	903
clear isis (WORD) process	903
clear isis counter	903
clear isis adjacency * (vrf VRFNAME)	904
clear isis WORD adjacency * (vrf VRFNAME)	904
clear isis WORD adjacency (IFNAME) (vrf VRFNAME)	904
clear isis adjacency (IFNAME) (vrf VRFNAME)	905
clear isis WORD adjacency system-id XXXX.XXXX.XXXX (vrf VRFNAME)	905
clear isis adjacency system-id XXXX.XXXX.XXXX (vrf VRFNAME)	905
snmp restart isis	906
debug isis (ifsm nfsm pdu lsp spf events nsm checksum authentication local-updates protocol-errors bfd mpls rib sr lfa dist-ls tilfa ofib all)	906
no debug isis (ifsm nfsm pdu lsp spf events nsm checksum authentication local-updates protocol-errors bfd mpls rib sr lfa dist-ls tilfa ofib all)	906
debug isis spf-trace	907
no debug isis spf-trace	907
debug isis hello	907
no debug isis hello	907
debug isis hello interface IFNAME	907
no debug isis hello interface IFNAME	908
debug isis hello System-ID	908
no debug isis hello System-ID	908
no debug all isis	909
debug isis cspf (events hexdump)	909
no debug isis cspf (events hexdump)	909
IPI-ISIS-LSP	909
Configure spf max delay	909
Configure lsp max wait interval	910
Configure lsp mtu size	911
Configure wait timer	912
Configure restart timer	912
Configure instance	913
Configure type	914
Configure mode	914
Configure key chain	915
IPI-ISIS-EXTENDED	916
Configure remote lfa protocol	916
Configure name	916
Configure enable all prefixes	917
Configure protocol	918
Configure preference index	919
Configure grace period	920
Configure enable helper only	920
Configure suppress adjacency	920

restart isis graceful (grace-period <1-65535>)	921
IPI-ISIS-SR	921
Configure receive disable	921
Configure enabled	922
Configure advertise local	922
Configure entropy capability	923
Configure global block base	923
IPI-ISIS-INTERFACE	924
Configure minimal	924
Configure name	925
Configure send only	925
Configure disable padding	926
Configure network type	926
Configure circuit type	927
Configure ipv4 instance tag	927
Configure ipv6 instance tag	928
Configure lsp interval	929
Configure retransmit interval	929
Configure mesh group id	930
Configure enable	930
Configure disable	931
Configure disable level 1	932
Configure disable level 2	932
Configure hello interval	933
Configure hello multiplier	934
Configure csnp interval	934
Configure priority	935
Configure metric	936
Configure password	937
Configure tag	937
Configure wide metric	938
Configure te metric	939
Configure restart hello interval	939
Configure mode	940
Configure key chain	941
Configure hold timer	942
Configure level	942
clear isis interface counter (IFNAME)	943
IPI-KEYCHAIN	943
Configure name	943
Configure key id	944
Configure key string	944
Configure encrypted	945
Configure start date time for accept	946
Configure start date time for send	947
IPI-PIM	948
Configure bfd	948

IPI-PIM-IPV4	948
Configure router id	948
Configure join prune interval	949
Configure ecmp bundle	949
Configure enable bfd all interfaces	950
Configure register reachability check	950
Configure rate limit	951
Configure suppress interval	951
Configure keep alive interval	952
Configure source address	953
Configure accept register	953
Configure ignore rp set priority	954
Configure cisco bsr interop enable	955
Configure access control list	955
Configure cisco register checksum enable	956
Configure vrf name	957
Configure enable	957
Configure range policy	958
Configure member rp address	959
Configure rp address	959
Configure override dynamically learned rp	960
Configure interface name	961
Configure hash mask length	962
Configure priority	962
Configure advertisement interval	963
Configure originator id	964
Configure group address	965
Configure address	966
Configure mesh group	966
Configure default peer	967
Configure prefix list	968
Configure password	969
Configure options	970
Configure passive enable	970
Configure pim mode	971
Configure bsr border	972
Configure dr priority	972
Configure hello interval	973
Configure hello holdtime	973
Configure exclude generated id	974
Configure unicast bootstrap router	974
Configure neighbor access control list filter	975
Configure state refresh origination interval	975
Configure name	976
Configure propagation delay	976
Configure enable bfd	977
Configure virtual router id	978

snmp restart pim	978
clear ip pim (vrf NAME) (sparse-mode) bsr rp-set *	979
clear ip mroute (vrf NAME) * pim (dense-mode sparse-mode).	979
clear ip mroute (vrf NAME) A.B.C.D pim sparse-mode.	979
clear ip mroute (vrf NAME) A.B.C.D A.B.C.D pim (dense-mode sparse-mode)	980
clear ip msdp (vrf NAME) peer (A.B.C.D)	980
clear ip msdp (vrf NAME) sa-cache (A.B.C.D).	981
debug ip pim (vrf NAME) (all events packet packet in packet out state mfc timer timer hello timer bsr timer joinprune timer hello ht timer hello nt timer hello tht timer joinprune jt timer joinprune et timer joinprune ppt timer joinprune kat timer joinprune ot timer assert timer register timer bsr bst timer bsr crp mib nsm nexthop mtrace msdp).	981
no debug ip pim (vrf NAME) (all events packet packet in packet out state mfc timer timer hello timer bsr timer joinprune timer hello ht timer hello nt timer hello tht timer joinprune jt timer joinprune et timer joinprune ppt timer joinprune kat timer joinprune ot timer assert timer register timer bsr bst timer bsr crp mib nsm nexthop mtrace msdp).	982
debug ip pim (vrf NAME).	982
no debug ip pim (vrf NAME)	983
IPI-PIM-IPV6	983
Configure router id	983
Configure join prune interval	984
Configure ecmp bundle	984
Configure enable bfd all interfaces	985
Configure register reachability check.	985
Configure rate limit.	986
Configure suppress interval	986
Configure keep alive interval	987
Configure source address	988
Configure accept register.	988
Configure ignore rp set priority.	989
Configure cisco bsr interop enable	990
Configure access control list	990
Configure cisco register checksum enable	991
Configure vrf name	992
Configure enable	992
Configure range policy.	993
Configure member rp address	994
Configure embed rp	994
Configure rp address	995
Configure override dynamically learned rp	996
Configure interface name.	996
Configure hash mask length	997
Configure priority	998
Configure advertisement interval	999
Configure options.	1000
Configure passive enable	1001
Configure pim mode.	1001
Configure bsr border	1002
Configure dr priority	1002

Configure hello interval	1003
Configure hello holdtime	1003
Configure exclude generated id	1004
Configure unicast bootstrap router	1004
Configure neighbor access control list filter	1005
Configure state refresh origination interval	1005
Configure name	1006
Configure propagation delay	1007
Configure enable bfd	1007
clear ipv6 pim (vrf NAME) (sparse-mode) bsr rp-set *	1008
clear ipv6 mroute (vrf NAME) * pim (dense-mode sparse-mode)	1008
clear ipv6 mroute (vrf NAME) X:X::X:X pim sparse-mode	1008
clear ipv6 mroute (vrf NAME) X:X::X:X X:X::X:X pim (dense-mode sparse-mode)	1009
debug pim bfd	1009
no debug pim bfd	1010
debug ipv6 pim (vrf NAME) (all events packet packet in packet out state mfc timer timer hello timer bsr timer joinprune timer hello ht timer hello nt timer hello tht timer joinprune jt timer joinprune et timer joinprune ppt timer joinprune kat timer joinprune ot timer assert timer register timer bsr bst timer bsr crp mib nsm nexthop mtrace)	1010
no debug ipv6 pim (vrf NAME) (all events packet packet in packet out state mfc timer timer hello timer bsr timer joinprune timer hello ht timer hello nt timer hello tht timer joinprune jt timer joinprune et timer joinprune ppt timer joinprune kat timer joinprune ot timer assert timer register timer bsr bst timer bsr crp mib nsm nexthop mtrace)	1010
debug ipv6 pim (vrf NAME)	1011
no debug ipv6 pim (vrf NAME)	1011
IPI-VXLAN	1012
Configure mac address	1012
Configure enable vxlan	1012
Configure vtep ipv4	1013
Configure mac ageing timer	1013
Configure arp nd refresh timer	1013
Configure traffic direction	1014
Configure tenant type	1014
Configure xconnect identifier	1015
Configure vrf name	1015
Configure map network	1016
Configure mac hold timer	1016
Configure tenant description	1017
Configure irb name	1017
Configure irb advertise host route	1018
Configure vxlan identifier	1018
Configure untagged interface name	1019
Configure default access interface	1020
Configure admin shutdown	1020
Configure description	1021
Configure dynamic learning disable	1021
Configure access mac hold time	1022
Configure arp nd flood suppress	1022

Configure garp gna enable	1023
Configure arp cache disable	1023
Configure nd cache disable	1024
Configure ipv4 address	1025
Configure ipv6 address	1025
Configure profile map type	1026
Configure vlan identifier	1027
Configure tag protocol identifier	1027
Configure interface name	1028
Configure profile name	1028
Configure inner vlan identifier	1029
clear mac address-table dynamic vxlan	1030
clear mac address-table dynamic vxlan vnid <1-16777215> (address MACADDR)	1030
clear nvo vxlan tunnels	1030
clear nvo vxlan tunnels dst-ip A.B.C.D	1030
clear nvo vxlan mac-stale-entries (vnid <1-16777215>)	1031
clear nvo vxlan counters access-port port IFNAME	1031
clear nvo vxlan counters access-port port-vlan IFNAME VLAN_RANGE	1031
clear nvo vxlan counters access-port port-vlan IFNAME outer-vlan <2-4094> inner-vlan <2-4094>	1032
clear nvo vxlan counters access-port all	1032
clear nvo vxlan counters network-port dst A.B.C.D	1032
clear nvo vxlan counters network-port all	1033
IPI-ETHERNET-VPN	1033
Configure esi hold time	1033
Configure enable vxlan multihoming	1033
Configure enable evpn mpls multihoming	1034
Configure enable evpn srv6 multihoming	1034
Configure enable irb	1035
Configure enable mpls irb	1035
Configure mac address	1035
Configure gateway mac	1036
Configure redundancy mode	1036
Configure name	1037
Configure service carving	1037
Configure preference weight	1038
Configure no preempt	1039
Configure ac driven	1039
Configure access if	1040
Configure evpn identifier	1040
Configure dynamic learning disable	1041
Configure arp nd flood suppress	1042
Configure arp cache disable	1042
Configure nd cache disable	1043
Configure mac hold time	1044
Configure garp gna enable	1044
Configure ipv4 address	1045

Configure ipv6 address	1046
Configure service type	1047
IPI-TFO	1047
Configure admin status	1047
Configure name	1047
Configure group id	1048
Configure failover trigger count	1049
clear tfo counter	1049
clear tfo counter fog <1-64>	1049
IPI-LOGGING	1050
Configure severity level	1050
Configure enable logging	1050
Configure max file size	1051
Configure file name	1051
Configure enable syslog	1052
Configure timestamp granularity	1052
Configure disable all modules debug	1053
no debug all	1053
clear debug logfile	1053
clear logging logfile	1054
remove file (techsupport) (all FILENAME)	1054
IPI-LOGGING-REMOTE	1054
Configure enable	1054
Configure enable rsyslog	1055
Configure vrf	1055
Configure port	1055
Configure severity	1056
Configure remote server facility	1057
IPI-LOGGING-CLI	1057
Configure enable logging	1057
Configure max session limit	1058
IPI-LOGGING-FAULT-MANAGEMENT	1058
Configure enable fault management	1058
fault-management flush-db	1059
fault-management shelve ALARM-TYPE	1059
fault-management close ACTIVE-ALARM-ID	1059
IPI-DHCP	1060
Configure disable dhcp feature	1060
IPI-RADIUS	1060
Configure vrf name	1060
Configure timeout	1061
Configure sequence number	1061
Configure secret key string	1062
Configure accounting port	1063
Configure host address	1064
Configure authentication port	1065
Configure key type	1066

Configure enable	1067
clear radius-server counters (vrf management)	1067
clear radius-server host (A.B.C.D X:X::X:X HOSTNAME) counters (vrf (management all))	1068
debug radius	1068
no debug radius	1068
IPI-USER-MANAGEMENT	1068
Configure enable	1068
Configure disable default user	1069
Configure username	1069
Configure role	1070
Configure password	1070
Configure password hashed	1071
Configure rbac role	1071
debug user-mgmt.	1072
no debug user-mgmt	1072
IPI-SSH	1072
Configure enable	1072
Configure vrf name	1073
Configure port	1073
Configure max login attempts	1074
Configure session limit.	1074
Configure triple des cbc	1075
Configure public key	1076
debug ssh server	1076
no debug ssh server	1077
clear ssh hosts	1077
ssh keygen host dsa (vrf management) (force)	1077
ssh keygen host rsa (length <1024-4096>) (vrf management) (force)	1077
ssh keygen host ecdsa (length (256 384 521)) (vrf management) (force)	1078
ssh keygen host ed25519 (vrf management) (force)	1078
clear ssh host-key ((dsa rsa ecdsa ed25519)) (vrf management)	1079
username USERNAME keypair rsa (length <1024-4096>) (force)	1079
username USERNAME keypair dsa (force)	1080
clear ssh keypair user USERNAME.	1080
IPI-TELNET	1080
Configure enable	1080
Configure vrf name	1081
Configure port	1081
Configure session limit.	1082
debug telnet server	1082
no debug telnet server	1083
IPI-NTP	1083
Configure feature enable	1083
Configure vrf name	1083
Configure enable ntp	1084
Configure enable logging	1084

Configure enable local master	1085
Configure local stratum	1085
Configure enable ntp auth	1086
Configure ntp trusted keys	1086
Configure ntp request key	1087
Configure key id	1088
Configure key value	1088
Configure prefer	1089
Configure server address	1090
Configure peer address	1091
Configure minimum pkt spacing	1092
Configure netmask	1093
Configure access options	1093
Configure client ip address	1094
Configure enable	1095
clear ntp statistics (all-peers io local memory)	1095
ntp sync-retry (vrf management)	1095
debug ntp	1096
no debug ntp	1096
IPI-AAA	1096
Configure authentication method rule	1096
Configure vrf name	1096
Configure accounting method rule	1097
Configure authorization method rule	1097
Configure error enable	1098
Configure enable fallback	1098
Configure group type	1099
Configure host address	1100
Configure group name	1100
Configure user non existent	1101
Configure authentication max failure attempts	1102
Configure local user unlock timeout	1102
Configure enable	1103
debug aaa	1103
no debug aaa	1103
clear aaa local user lockout username USERNAME	1103
IPI-DHCP-RELAY	1104
Configure disable dhcpv4 relay	1104
Configure disable dhcpv6 relay	1104
Configure ipv4 relay interface	1105
Configure ipv4 uplink interface	1105
Configure ipv4 group name	1106
Configure ipv6 relay interface	1106
Configure ipv6 uplink interface	1107
Configure ipv6 group name	1107
Configure interface type	1108
Configure interface type v6	1108

Configure link selection source ip	1109
Configure enable option82.	1110
Configure ip address	1110
Configure dhcpv4 server global vrf	1111
Configure vrf name	1111
Configure ipv6 address	1112
Configure dhcpv6 server global vrf	1113
Configure enable dhcpv6 pd route injection.	1113
Configure remote id	1114
Configure enable option82 always on	1114
Configure subscriber id	1115
Configure group6 name	1116
Configure group name	1116
Configure interface direction	1117
Configure interface direction v6	1118
Configure server	1118
clear ip dhcp relay statistics	1119
clear ip dhcp relay option statistics	1119
clear ipv6 dhcp pd-route (vrf NAME).	1119
IPI-DNS-RELAY	1120
Configure enable dns feature.	1120
Configure enable dnsv4 relay	1120
Configure enable dnsv6 relay	1120
Configure dns server v4 addr.	1121
Configure dns server v6 addr.	1121
Configure name	1122
Configure dns relay uplink	1122
Configure dns relay v6 uplink.	1122
Configure vrf name	1123
IPI-DNS-CLIENT	1124
Configure default domain name.	1124
Configure lookup enabled	1124
Configure vrf name	1125
Configure address	1125
Configure domain name.	1126
Configure ipv6 address	1126
Configure ipv4 address	1127
Configure hostname.	1128
Configure enable	1128
debug dns client.	1129
no debug dns client	1129
IPI-DHCP-CLIENT	1129
Configure request ipv4 dns	1129
Configure request log server	1130
Configure request host name.	1130
Configure request ntp server	1131
Configure request ipv6 dns	1131

Configure request ipv6 domain list	1132
Configure request ipv6 ntp server	1132
Configure request ipv6 rapid commit	1133
Configure request ipv6 vendor opts	1133
Configure ipv6 information request	1134
Configure ipv6 dad wait time	1134
Configure ipv6 client duid type	1135
Configure request ipv6 prefix	1135
Configure suffix ipv6 addr.	1136
IPI-DHCP-SERVER	1137
Configure enable ipv4 server	1137
Configure enable ipv6 server	1137
Configure pool6 name	1138
Configure pool name	1138
Configure max lease time.	1139
Configure default lease time.	1140
Configure rapid commit	1140
Configure preference	1141
Configure vrf name.	1141
Configure host name	1142
Configure routers	1142
Configure ntp server.	1143
Configure boot file	1144
Configure tftp server.	1144
Configure log server.	1145
Configure dns server	1146
Configure netmask	1146
Configure high address in range	1147
Configure domain name	1148
Configure vendor options	1149
Configure ipv6 netmask	1149
Configure low address in range	1150
Configure temporary address.	1151
Configure ipv6 prefix netmask	1152
IPI-SFLOW	1153
Configure enabled	1153
Configure source address	1153
Configure max datagram size	1153
Configure options	1154
debug sflow (agent sampling polling all).	1155
no debug sflow (agent sampling polling all)	1155
IPI-SFLOW-INTERFACE.	1155
Configure enabled	1155
Configure polling interval	1156
Configure sample size	1157
Configure name	1157
clear sflow statistics (interface IFNAME).	1158

IPI-WATCHDOG	1158
Configure watchdog disabled	1158
Configure keepalive interval	1159
Configure module watchdog status disabled	1159
clear cores (WORD)	1160
sys-update un-install	1160
sys-container (raon) (install update) file FILENAME	1160
sys-container (raon) un-install	1161
sys-container (raon) (start stop restart)	1161
sys-container (raon) get URL (source-interface IFNAME)	1161
sys-container (raon) remove file FILENAME	1162
sys-container (raon) verify image FILEPATH signature FILEPATH	1162
sys-container cancel download	1163
IPI-MRIB-IPV4	1163
Configure options	1163
Configure multicast routing enable	1164
Configure maximum routes	1164
Configure warning threshold	1165
Configure ttl threshold	1166
debug ip mrib (vrf WORD) (all event vif mrt stats fib-msg register-msg nsm-msg mrib- msg mtrace mtrace-detail)	1166
no debug ip mrib (vrf WORD) (all event vif mrt stats fib-msg register-msg nsm-msg mrib- msg mtrace mtrace-detail)	1167
clear ip mroute (vrf NAME) *	1167
clear ip mroute (vrf NAME) A.B.C.D	1167
clear ip mroute (vrf NAME) A.B.C.D A.B.C.D	1168
clear ip mroute (vrf NAME) statistics *	1168
clear ip mroute (vrf NAME) statistics A.B.C.D	1169
clear ip mroute (vrf NAME) statistics A.B.C.D A.B.C.D	1169
snmp restart mrib	1169
IPI-MRIB-IPV6	1170
Configure options	1170
Configure multicast routing enable	1170
Configure maximum routes	1171
Configure warning threshold	1171
debug ipv6 mrib (vrf WORD) (all event vif mrt stats fib-msg register-msg nsm-msg mrib- msg mtrace mtrace-detail)	1172
no debug ipv6 mrib (vrf WORD) (all event vif mrt stats fib-msg register-msg nsm-msg mrib- msg mtrace mtrace-detail)	1173
clear ipv6 mroute (vrf NAME) *	1173
clear ipv6 mroute (vrf NAME) X:X::X:X	1173
clear ipv6 mroute (vrf NAME) X:X::X:X X:X::X:X	1174
clear ipv6 mroute (vrf NAME) statistics *	1174
clear ipv6 mroute (vrf NAME) statistics X:X::X:X	1175
clear ipv6 mroute (vrf NAME) statistics X:X::X:X X:X::X:X	1175
IPI-IGMP	1175
Configure disable ssm map	1175

Configure disable tos check	1176
Configure limit exception acl	1176
Configure member limit	1177
Configure source	1178
Configure options	1179
debug ip igmp (vrf NAME) (all decode encode events fsm tib)	1179
no debug ip igmp (vrf NAME) (all decode encode events fsm tib)	1179
clear ip igmp (vrf NAME)	1180
clear ip igmp (vrf NAME) group *	1180
clear ip igmp (vrf NAME) group A.B.C.D IFNAME	1181
clear ip igmp (vrf NAME) interface IFNAME	1181
clear ip igmp (vrf NAME) group A.B.C.D	1181
IPI-IGMP-INTERFACE	1182
Configure enabled	1182
Configure last member query count	1182
Configure last member query interval	1183
Configure querier timeout	1183
Configure query interval	1184
Configure query max response time	1185
Configure startup query interval	1185
Configure startup query count	1186
Configure robustness variable	1186
Configure version	1187
Configure require router alert option	1187
Configure allow offlink host	1188
Configure enable proxy service	1188
Configure mroute proxy interface	1189
Configure unsolicited report interval	1189
Configure limit exception acl	1190
Configure member limit	1191
Configure access group name	1191
Configure immediate leave groups list	1192
Configure group address	1192
Configure source	1193
Configure name	1194
IPI-IGMP-SNOOPING	1194
Configure disable igmp snooping	1194
Configure disable report suppression	1195
Configure unknown multicast action	1195
Configure options	1196
Configure igmp snooping	1196
Configure report suppression	1197
Configure enable fast leave	1197
Configure mrouter interface name	1198
Configure enable querier	1198
Configure name	1199
Configure source address	1199

Configure group address	1200
clear igmp snooping group A.B.C.D IFNAME	1201
clear igmp snooping interface IFNAME	1201
clear igmp snooping group *	1201
clear igmp snooping	1201
clear igmp snooping group A.B.C.D	1202
debug igmp snooping (decode encode events fsm tib all)	1202
no debug igmp snooping (decode encode events fsm tib all)	1202
IPI-MLD-SNOOPING	1203
Configure disable mld snooping	1203
Configure disable report suppression	1203
Configure options	1203
Configure report suppression	1204
Configure mld snooping	1204
Configure enable fast leave	1205
Configure name	1205
Configure mrouter interface name	1206
Configure enable querier	1206
debug mld snooping (decode encode events fsm tib all)	1207
no debug mld snooping (decode encode events fsm tib all)	1207
clear mld snooping group X:X::X:X IFNAME	1207
clear mld snooping interface IFNAME	1208
clear mld snooping group X:X::X:X	1208
clear mld snooping group *	1208
clear mld snooping	1209
IPI-ROUTEMAP	1209
Configure action	1209
Configure continue to next sequence	1209
Configure next sequence number	1210
Configure interface name	1211
Configure metric	1211
Configure vlan id	1212
Configure mac access list name	1212
Configure tag	1213
Configure route type	1213
Configure as path name	1214
Configure route origin	1215
Configure packet max length	1215
Configure community identifier	1216
Configure extended community identifier	1217
Configure match type	1218
Configure ip access list name	1218
Configure ip prefix list name	1219
Configure peer access list name	1220
Configure next hop prefix list name	1220
Configure next hop access list name	1221
Configure ipv6 address access list name	1222

Configure ipv6 prefix list name	1222
Configure routemap name	1223
Configure sequence id	1224
Configure next hop match string	1224
Configure large community number match	1225
Configure metric value	1226
Configure forward interface type	1226
Configure route tag	1227
Configure weight	1227
Configure local preference	1228
Configure route origin type	1229
Configure metric type	1229
Configure aigp metric	1230
Configure level type	1230
Configure enable as path tag	1231
Configure atomic aggregate	1232
Configure delete community value	1232
Configure bgp originator id	1233
Configure as path prepend	1233
Configure ext community site of origin	1234
Configure ext community color	1235
Configure ip nexthop address	1235
Configure use peer address	1236
Configure default nexthop address	1236
Configure vpv4 nexthop address	1237
Configure ipv6 nexthop address	1238
Configure default ipv6 nexthop address	1238
Configure local ipv6 nexthop address	1239
Configure aggregator ip address	1239
Configure ext community rt	1240
Configure cost value	1241
Configure max suppress time limit	1242
Configure unreachable half life time	1243
Configure enable dampening	1244
Configure community with as number	1245
Configure large community number set	1245
IPI-RIP	1246
Configure options	1246
Configure split horizon	1246
Configure name	1247
Configure disable receive packet	1247
Configure disable send packet	1248
Configure receive version	1248
Configure send version	1249
Configure auth mode	1249
Configure auth string	1250
Configure auth keychain	1250

Configure rip enabled	1251
Configure bfd enable	1251
Configure receive buffer size	1251
Configure passive interfaces	1252
Configure static routes	1252
Configure neighbors	1253
Configure neighbor fall over bfd	1253
Configure enable cisco metric behavior	1253
Configure default metric	1254
Configure version	1254
Configure distance	1255
Configure network interfaces	1255
Configure network routes	1255
Configure access list name	1256
Configure route table update interval	1256
Configure warning threshold percentage	1257
Configure route type	1258
Configure route map	1258
Configure metric	1259
Configure originate	1259
Configure direction	1260
clear ip rip route (kernel connected static ospf isis bgp rip all)	1260
clear ip rip route A.B.C.D/M	1261
clear ip rip statistics (IFNAME)	1261
snmp restart rip	1261
debug rip (all events packet send packet recv packet packet detail nsm rib bfd)	1261
no debug rip (all events packet send packet recv packet packet detail nsm rib bfd)	1262
IPI-RIP-VRF	1262
Configure vrf name	1262
Configure enable cisco metric behavior	1263
Configure default metric	1263
Configure version	1264
Configure distance	1264
Configure network interfaces	1265
Configure network routes	1265
Configure access list name	1266
Configure route type	1267
Configure route map	1267
Configure metric	1268
Configure originate	1269
Configure direction	1269
Configure name	1270
clear ip rip route vrf NAME A.B.C.D/M	1271
clear ip rip route vrf NAME *	1271
IPI-PBR	1272
Configure enabled	1272
Configure route map name	1272

Configure route map v6 name	1273
clear route-map WORD pbr-statistics	1273
IPI-SNMP	1273
Configure enable link down trap	1273
Configure enable link up trap	1274
Configure include interface name	1274
Configure enable traps	1275
debug (snmp send snmp receive snmp process snmp xdump snmp error-string snmp detail snmp snmp all)	1275
no debug (snmp send snmp receive snmp process snmp xdump snmp error-string snmp detail snmp snmp all)	1276
IPI-SNMP-SERVER	1276
Configure vrf name	1276
Configure system contact	1277
Configure system location	1277
Configure tcp session enabled	1278
Configure disable default instance	1278
IPI-SNMP-SERVER-EXTENDED	1279
Configure enable	1279
Configure filter type	1279
Configure engine id	1280
Configure smux port enable	1280
Configure host name	1281
Configure notification type	1282
Configure snmp version	1283
Configure snmpv3 auth type	1284
Configure community	1285
Configure snmpv3 user	1286
Configure udp port	1287
Configure user name	1288
Configure authentication type	1289
Configure user type	1289
Configure encryption type	1290
Configure authentication password	1291
Configure privilege type	1292
Configure privilege password	1293
Configure vrf name	1295
Configure context name	1296
Configure acl name	1296
Configure community name	1297
Configure snmp group	1298
Configure access privileges	1298
Configure access	1299
Configure community context	1300
Configure group name	1301
Configure group version	1301
Configure context	1302

Configure snmpv3 group auth type	1303
debug snmp-server	1304
no debug snmp-server	1304
IPI-LDP	1304
Configure multicast hello disable	1304
Configure ldp instance	1305
Configure router identifier	1305
Configure pseudowire status tlv	1306
Configure rfa ilm optimization	1306
Configure entropy label capability enable	1306
Configure advertise label for default route	1307
Configure import bgp routes	1307
Configure ldp optimization	1308
Configure explicit null	1308
Configure global merge	1309
Configure propagate release	1309
Configure fast reroute	1309
Configure auto targeted session	1310
Configure control mode	1310
Configure retention mode	1311
Configure advertisement mode	1311
Configure hello interval	1312
Configure hello holdtime	1312
Configure keepalive interval	1313
Configure keepalive timeout	1313
Configure request retry timeout	1314
Configure request retry	1314
Configure label request policy ipv4	1315
Configure loop detection enable	1315
Configure path vector limit	1316
Configure hop count limit	1316
Configure session protection enable	1317
Configure duration	1317
Configure session protection prefix list name	1318
Configure ldp	1318
Configure enable	1319
Configure neighbor liveness time	1319
Configure max recovery time	1320
Configure inter area acl name	1320
Configure transport address ipv4	1321
Configure peer address	1321
Configure group name	1322
Configure prefix list	1322
Configure auth	1323
Configure prefix access control list name	1324
Configure peer access control list name	1324
Configure tcp mss range	1325

clear ldp statistics	1325
clear ldp statistics advertise-labels	1325
clear ldp statistics advertise-labels for PREFIX	1325
clear ldp statistics advertise-labels for PREFIX to PEER	1326
clear ldp session *	1326
clear ldp session A.B.C.D.	1326
clear ldp adjacency *	1327
clear ldp adjacency A.B.C.D.	1327
snmp restart ldp	1327
debug ldp (events fsm hexdump dsm usm tsm qos nsm advertise-labels cspf vc usm vc dsm graceful-restart rib inter-area packet notification packet hello packet initialization packet keepalive packet address packet label packet all)	1327
no debug ldp (events fsm hexdump dsm usm tsm qos nsm advertise-labels cspf vc usm vc dsm graceful-restart rib inter-area packet notification packet hello packet initialization packet keepalive packet address packet label packet all)	1328
restart ldp graceful	1328
IPI-LDP-INTERFACE	1328
Configure enable ldp ipv4.	1328
Configure name	1329
Configure multicast hello disable	1329
Configure maximum pdu length	1330
Configure ldp igp sync delay interval	1330
Configure hello interval.	1331
Configure hello holdtime.	1331
Configure keepalive interval.	1332
Configure keepalive timeout.	1333
Configure interface advertisement mode	1333
Configure interface retention mode	1334
IPI-LDP-PEER.	1335
Configure targeted global hello interval	1335
Configure targeted global hello holdtime	1335
Configure target address	1336
Configure hello interval.	1336
Configure hello holdtime.	1337
IPI-QOS	1337
Configure enable qos	1337
Configure red drop disabled.	1338
Configure statistics enabled	1338
Configure name	1338
Configure cos value	1339
Configure queue id	1340
Configure color	1341
Configure precedence value	1341
Configure remark dscp value	1342
Configure dscp value	1343
Configure dscp encap value.	1344
Configure exp value	1345

Configure profile id	1346
Configure remark precedence value	1346
Configure cos	1347
Configure dscp	1348
Configure type	1348
Configure match criteria	1349
Configure reference description	1349
Configure access control list name	1350
Configure ethertype	1351
Configure traffic type	1351
Configure inner cos	1352
Configure vlan	1352
Configure inner vlan	1353
Configure rtp	1354
Configure mpls exp	1354
Configure ipv6 dscp	1355
Configure precedence	1355
Configure ipv6 precedence	1356
Configure port type	1357
Configure protocol	1358
Configure ethertype all	1358
Configure traffic type all	1359
Configure cos all	1360
Configure inner cos all	1360
Configure vlan all	1361
Configure inner vlan all	1361
Configure rtp all	1362
Configure mpls exp all	1363
Configure dscp all	1363
Configure ipv6 dscp all	1364
Configure precedence all	1365
Configure ipv6 precedence all	1365
Configure port all	1366
Configure protocol all	1367
Configure vlan queue	1367
Configure queue	1368
Configure service template name	1369
Configure interface	1369
Configure policy map name	1370
Configure class map name	1370
Configure child service policy name	1371
Configure byte compensation	1372
Configure delay tolerance	1373
Configure priority level	1373
Configure weighted fair queueing queue weight	1374
Configure weight	1375
Configure min threshold	1376

Configure min threshold unit	1377
Configure max threshold	1378
Configure max threshold unit	1380
Configure max threshold type	1381
Configure rate value	1382
Configure rate unit	1383
Configure priority	1384
Configure precedence remark	1385
Configure dscp value remark	1385
Configure cir	1386
Configure cir unit	1387
Configure eir	1388
Configure eir unit	1389
Configure bc	1390
Configure bc unit	1392
Configure be	1393
Configure be unit	1394
clear qos statistics (interface IFNAME) ((type qos type qos input type qos output type queuing type all))	1396
IPI-QOS-IF	1396
Configure untagged priority	1396
Configure trust dscp	1397
Configure cos	1397
Configure dscp	1398
Configure name	1398
Configure cos to queue	1399
Configure dscp to dscp	1399
Configure precedence to precedence	1400
Configure dscp to queue	1401
Configure precedence to queue	1401
Configure exp encapsulation	1402
Configure dscp encapsulation	1402
Configure queue color to cos	1403
Configure type qos policy map name	1403
Configure type queuing policy map name	1404
IPI-RSVP	1405
Configure options	1405
Configure enable rsvp trap	1405
Configure disable refresh resv parsing	1406
Configure disable refresh path parsing	1406
Configure disable loop detection	1406
Configure enable php	1407
Configure enable entropy label capability	1407
Configure enable bundle send	1408
Configure enable local protection	1408
Configure enable explicit null	1408
Configure detour allow primary upstream path	1409

Configure rsvp	1409
Configure revert timer	1410
Configure ingress	1410
Configure enable message ack	1411
Configure disable refresh reduction	1411
Configure ack send timer	1412
Configure ack wait timeout	1412
Configure refresh time	1413
Configure keep multiplier	1413
Configure default frr protection	1414
Configure preemption type	1414
Configure bypass lsp addr query interval	1415
Configure detour id	1415
Configure disable cspf	1416
Configure cspf lsp reoptimization time	1416
Configure enable hello receipt	1417
Configure enable graceful restart	1417
Configure hello interval	1418
Configure hello timeout	1418
Configure restart time	1419
Configure recovery time	1419
Configure enable gmpls notification	1420
Configure enable pre program suggested label	1420
Configure srlg disjoint	1421
Configure enable override diff serv	1421
Configure address	1422
clear rsvp statistics	1422
snmp restart rsvp	1422
debug rsvp (events packet packet in packet out hexdump nsm cspf fsm egress fsm transit downstream fsm transit upstream fsm ingress rib neighbor fsm fsm transit all)	1423
no debug rsvp (events packet packet in packet out hexdump nsm cspf fsm egress fsm transit downstream fsm transit upstream fsm ingress rib neighbor fsm fsm transit all)	1423
restart rsvp graceful	1423
IPI-RSVP-TRUNK	1424
Configure path name	1424
Configure description	1424
Configure hop address	1425
Configure strict hop address	1425
Configure unnumbered ip addr	1426
Configure multipath name	1427
Configure destination	1427
Configure bypass name	1428
Configure ingress	1428
Configure egress	1429
Configure ext tunnel id	1429
Configure update type	1430
Configure backup bandwidth type	1430

Configure disable route record	1431
Configure enable reuse route record	1432
Configure traffic type	1432
Configure retry count	1433
Configure retry interval	1434
Configure cspf retry count	1434
Configure cspf retry interval	1435
Configure exclude addr	1436
Configure bandwidth	1436
Configure enable label record	1437
Configure hold priority	1438
Configure setup priority	1438
Configure hop limit	1439
Configure filter type	1440
Configure dscp exp map exp val	1440
Configure trunk name	1441
Configure enable igp shortcut	1442
Configure enable reoptimize	1442
Configure multipath group	1443
Configure absolute metric	1443
Configure relative metric	1444
Configure revert timer	1444
Configure trunk color	1445
Configure bsid value	1446
Configure switching capability	1446
Configure direction	1447
Configure generalized pid	1447
Configure path option dynamic	1448
Configure pce entity identifier	1449
Configure pce state report	1449
Configure pce lsp delegate	1450
Configure address	1450
Configure dst addr	1451
Configure priority value	1452
Configure priority path	1453
Configure secondary priority srlg disjoint	1453
Configure end label range	1454
Configure enable node protection	1455
Configure protection	1455
Configure frr hold priority	1456
Configure frr setup priority	1457
Configure frr hop limit	1457
Configure fast reroute bandwidth	1458
Configure admin group name	1459
Configure srlg disjoint secondary	1460
Configure trunk session type	1460
Configure disable affinity	1461

Configure disable cspf	1462
Configure enable local protection	1462
Configure name	1463
Configure link protection	1464
Configure forward label value	1465
Configure reverse label value	1465
Configure dscp exp map class name	1466
Configure elsp signal	1467
Configure elsp signal class1	1468
Configure elsp signal class2	1469
Configure elsp signal class3	1470
Configure elsp signal class4	1471
Configure elsp signal class5	1472
Configure elsp signal class6	1474
Configure elsp signal class7	1475
clear rsvp session *	1476
clear rsvp trunk (TRUNKNAME *)	1477
clear rsvp trunk (TRUNKNAME *) (primary)	1477
clear rsvp trunk (TRUNKNAME *) (secondary)	1477
clear rsvp trunk ingress (TRUNKNAME *)	1477
clear rsvp trunk non-ingress (TRUNKNAME *)	1478
rsvp-trunk TRUNKNAME force-reoptimize	1478
rsvp-trunk TRUNKNAME force-switchover-secondary (off on)	1478
rsvp-trunk-restart	1479
clear rsvp session TUNNEL-ID LSP-ID INGRESS EGRESS	1479
IPI-RSVP-INTERFACE	1480
Configure enable rsvp	1480
Configure enable iana hello config	1480
Configure disable refresh reduction	1481
Configure enable message ack	1481
Configure ack wait timeout	1482
Configure refresh time	1482
Configure keep multiplier	1483
Configure enable hello receipt	1484
Configure hello interval	1484
Configure hello timeout	1485
IPI-MPLS	1486
Configure name	1486
Configure match all	1486
Configure match single tag outer vlan range	1487
Configure match untagged	1487
Configure match inner vlan id	1488
Configure vlan action type	1488
Configure outer vlan identifier	1489
Configure group name	1490
Configure local packet handling	1491
Configure lsp stitching	1491

Configure propagate ttl	1491
Configure ingress ttl value	1492
Configure lsp model uniform	1492
Configure enable	1493
Configure admin group name	1493
Configure bandwidth	1494
Configure reservable bandwidth	1494
Configure shared risk link group	1495
Configure uni available bandwidth	1495
Configure uni residual bandwidth	1496
Configure uni utilized bandwidth	1497
Configure max label	1497
Configure label space name	1498
Configure ftn ecmp protocol	1499
Configure ilm ecmp protocol	1499
Configure max bandwidth	1500
IPI-MPLS-RIB	1500
Configure route prefix	1500
Configure out interface name	1501
Configure tunnel id	1502
Configure fec prefix	1502
Configure enable pop label	1503
Configure incoming label	1504
Configure in interface name	1505
Configure swapped label	1506
Configure nexthop ip address	1507
IPI-MPLS-BFD	1508
Configure fec address	1508
Configure lsp ping interval	1509
Configure admin down	1509
Configure detection multiplier	1510
Configure lsp type	1511
Configure minimum tx	1511
Configure tunnel name	1512
Configure minimum rx	1512
IPI-L2VPN-VPWS	1513
Configure pseudowire identifier	1513
Configure instance name	1514
Configure instance type	1515
Configure peer address	1516
Configure enable default tagged mode	1518
Configure service tpid	1519
Configure enable manual pseudowire	1520
Configure tunnel name	1521
Configure enable control word	1522
Configure tunnel identifier	1523
Configure tunnel policy	1524

Configure group name	1525
Configure group identifier	1526
Configure enable interface parameter tlv	1527
Configure enable static flow label	1528
Configure flow label direction	1529
Configure control channel type	1530
Configure control verification type	1531
Configure enable tagged mode	1532
Configure enable flow label	1533
Configure enable raw mode	1534
Configure attachment group identifier	1534
Configure source attachment individual identifier	1535
Configure target attachment individual identifier	1536
Configure service template	1537
Configure enable	1538
Configure enable revertive mode	1539
Configure vpws name	1539
Configure pseudowire name	1540
Configure name	1541
Configure service template name	1542
Configure queue to cos profile name	1543
Configure access interface name	1543
clear mpls l2-circuit NAME statistics	1544
clear mpls l2-circuit NAME statistics (access-port network-port)	1545
vc-switchover NAME NAME	1545
IPI-SEGMENT-ROUTING	1545
Configure enable	1545
Configure adj sid absolute	1546
Configure adj sid index	1546
Configure n flag clear	1547
Configure name	1548
Configure enable preference	1548
Configure preference	1549
Configure start address	1549
Configure start sid	1550
Configure end	1551
Configure start	1552
Configure fast reroute enable	1552
Configure list name	1553
Configure sid value	1553
Configure prefix	1554
Configure end point	1555
Configure admin state	1555
Configure explicit null	1556
Configure cspf retry limit	1556
Configure cspf retry interval	1557
Configure entropy erld	1557

Configure pce lsp delegate	1558
Configure pce state report	1559
Configure pce entity id	1559
Configure bsid value	1560
Configure discriminator	1560
Configure protocol origin	1561
Configure pcep	1562
Configure isis	1562
Configure ospf	1563
Configure ospf empty	1564
Configure originator	1565
Configure admin group name	1566
Configure metric type	1567
Configure bound	1568
Configure address	1569
Configure locator name	1570
Configure options	1570
debug sr-policy (policy cp pce all)	1571
no debug sr-policy (policy cp pce all)	1571
IPI-L2VPN-VPLS	1571
Configure service template name	1571
Configure admin status	1572
Configure attachment circuit description	1572
Configure mac learning	1573
Configure split horizon	1574
Configure static mac address	1574
Configure profile name	1575
Configure out label	1576
Configure vpls identifier	1576
Configure enable	1577
Configure vpls name	1578
Configure disable mac learning	1578
Configure name	1579
Configure vpls identifier	1579
Configure service transport identifier	1580
Configure maximum transmission unit	1581
Configure vpls description	1581
Configure control word	1582
Configure mac learning disable	1583
Configure mac learning limit	1583
Configure attachment circuit group name	1584
Configure pseudowire type	1584
Configure enable interface parameter tlv	1585
Configure enable static flow label	1586
Configure flow label direction	1587
Configure signaling protocol ldp	1587
Configure disable mac withdrawal	1588

Configure vpls encapsulation type	1588
Configure peer address	1589
Configure instance name	1590
Configure instance type	1591
Configure tunnel policy	1591
Configure tunnel name	1592
Configure tunnel identifier	1593
Configure target attachment individual identifier	1594
Configure attachment group identifier	1595
Configure source attachment individual identifier	1596
Configure signaling protocol bgp	1597
Configure vpls edge identifier	1597
Configure profile type	1598
clear mpls vpls NAME statistics (access-port network-port)	1599
clear mpls vpls NAME statistics network-port peer A.B.C.D	1599
clear mpls vpls NAME statistics network-port spoke-vc VC_NAME	1599
clear mpls vpls NAME statistics access-port WORD (vlan (<1-4094>) ethernet)	1600
clear mpls vpls NAME statistics	1600
clear mpls vpls NAME mac-addresses	1601
clear mpls vpls mac-addresses	1601
IPI-MCEC	1601
Configure options	1601
Configure system number	1601
Configure address	1602
Configure priority	1602
Configure hello timeout	1603
Configure interface	1603
Configure vrf	1604
Configure interface mode	1604
Configure revertive timer	1605
Configure enable non revertive	1605
debug mcec (hello info timer event cli mac-sync stp all)	1606
no debug mcec (hello info timer event cli mac-sync stp all)	1606
clear mcec statistics	1606
reload-trigger-mcec-notification	1607
IPI-MLAG	1607
Configure mlag id	1607
reload-trigger-save-mlag-info	1607
IPI-PLATFORM	1608
Configure enable cmm	1608
Configure enable ddm	1608
Configure warning repeat	1608
Configure locator led enable	1609
Configure ddm monitor time interval	1609
Configure service unsupported transceiver	1610
Configure enable ddm monitor	1610
Configure system 15min load avg alarm	1610

Configure alarm threshold	1611
Configure gps position disable	1612
Configure gps survey in position accuracy	1612
Configure gps fixed altitude	1613
Configure monitor port	1613
Configure poe enable	1614
Configure raon aodu port	1614
Configure transceiver code	1615
Configure wavelength	1615
Configure tx disable	1616
Configure edfa operating mode	1616
Configure edfa target output power	1617
Configure edfa target gain	1617
Configure interval	1618
Configure read threshold	1618
Configure write threshold	1619
clear ddm transceiver alarm all	1619
clear ddm transceiver alarm	1619
debug ddm	1620
no debug ddm	1620
debug cmm	1620
no debug cmm	1620
IPI-PLATFORM-PROFILE	1620
Configure flow control	1620
Configure micro bfd	1621
Configure aclif	1621
Configure seamless bfd	1622
Configure ufis9510 28dc port mode	1622
Configure ufis9600 64x port mode	1622
Configure as7315 27x port mode	1623
Configure as5916 as5912 54x port mode	1623
Configure as7316 26xb port mode	1624
Configure s9500 30xs port mode	1624
Configure ufis9600 32x port mode	1624
Configure ufis9600 56dx port mode	1625
Configure ufis9610 36d port mode	1625
Configure custom service queue profile	1626
Configure bgp flowspec mode	1626
Configure ingress ipv6 extended	1627
Configure ingress ipv6 extended vlan	1627
Configure ingress ipv6	1627
Configure ingress ipv4	1628
Configure ingress ipv4 extended	1628
Configure ingress ipv4 subif	1629
Configure ingress ipv4 qos	1629
Configure ingress arp	1630
Configure ingress ipv6 qos	1630

Configure ipv4 bgp flowspec	1631
Configure ipv6 bgp flowspec	1631
Configure qos	1631
Configure qos extended	1632
Configure qos policer	1632
Configure qos ipv6	1633
Configure egress ipv4	1633
Configure egress layer2	1634
Configure ingress layer2	1634
Configure ingress layer2 extended	1635
Configure ingress layer2 subif	1635
Configure cfm domain name string	1635
Configure twamp ipv4	1636
Configure twamp ipv6	1636
Configure twamp ipv6 mpls	1637
Configure vxlan arp nd	1637
Configure vxlan multi homing	1638
Configure evpn mpls multi homing	1638
Configure evpn mpls control word	1639
Configure dhcp snoop	1639
Configure dhcp snoop ipv6	1639
Configure ipsg	1640
Configure ipsg ipv6	1640
Configure attachment circuit logical if	1641
Configure tunnel logical if	1641
Configure ingress acl	1642
Configure egress acl	1642
Configure ingress qos	1643
Configure evpn mpls stats	1643
Configure mpls pseudowire	1643
Configure cfm frame loss measurements	1644
Configure cfm continuity check messages	1644
Configure virtual output queue full color	1645
Configure virtual output queue forward drop	1645
Configure profile type	1646
Configure ipv6 percentage	1646
Configure enable	1647
Configure mpls label based	1647
Configure vlan based	1648
Configure protocol id based	1648
Configure next header based	1649
Configure queue name	1650
Configure monitor status	1650
Configure rate	1651
cpu-q-default rate <0-100000>	1652
no cpu-q-default rate	1652
IPI-PLATFORM-PROFILE-EXTENDED	1653

Configure soc	1653
IPI-PLATFORM-CMIS	1653
Configure fp port.	1653
Configure application	1654
Configure service disable	1654
Configure type	1654
Configure location	1655
Configure lane number	1656
Configure id	1656
Configure high alarm	1657
Configure low alarm	1658
Configure high warning	1658
Configure low warning	1659
Configure channel	1660
Configure grid.	1661
Configure fine tune freq	1661
Configure output power	1662
tbit-olt-microplug set interface IFNAME management-vlan-tpid (0x8100 0x88a8)	1663
tbit-olt-microplug set interface IFNAME management-vlan-id <1-4094>.	1663
tbit-olt-microplug set interface IFNAME ethernet-mac-address XX:XX:XX:XX:XX:XX	1664
tbit-olt-microplug set interface IFNAME next-active-firmware-bank-id <0-3>	1664
tbit-olt-microplug reboot interface IFNAME	1664
IPI-PLATFORM-TRANSCEIVER-SMART-SFP	1665
Configure xcvr loopback remote.	1665
xcvr IFNAME tx-disable <1-256> remote	1665
xcvr IFNAME reset remote	1666
IPI-AUTHENTICATION	1666
Configure mac authentication.	1666
Configure dot1x authentication.	1666
Configure dot1x control	1667
Configure protocol version	1667
Configure quiet period	1668
Configure max reauth value	1669
Configure interval period	1669
Configure reauthentication period	1670
Configure enable reauthentication	1670
Configure enable mac auth bypass	1671
Configure supplicant timeout	1672
Configure server timeout	1672
Configure mac control	1673
Configure mac mode	1673
Configure dynamic vlan creation	1674
Configure mac address aging	1674
Configure options	1675
dot1x initialize interface IFNAME	1675
snmp restart auth	1676
debug dot1x (event timer packet nsn all).	1676

no debug dot1x (event timer packet nsm all)	1676
IPI-AUTHENTICATION-RADIUS	1676
Configure port	1676
Configure timeout	1677
Configure retransmit max retries	1677
Configure key string	1678
Configure encryption key	1678
Configure host address	1679
Configure host port	1679
Configure host timeout	1680
Configure host retransmit max retries	1680
IPI-ACL	1681
Configure type	1681
Configure name	1681
Configure description	1682
Configure ipv6 disable default icmpv6 rule	1682
Configure starting sequence number	1683
Configure forwarding action default	1684
Configure inner vlan id	1684
Configure sequence id	1686
Configure forwarding action	1687
Configure protocol tcp	1688
Configure source address	1690
Configure destination address	1691
Configure lower destination port in range	1693
Configure upper destination port in range	1695
Configure precedence	1696
Configure source port operator	1698
Configure tcp source port	1700
Configure destination port operator	1702
Configure tcp flags	1704
Configure dscp	1705
Configure vlan id	1707
Configure lower source port in range	1709
Configure upper source port in range	1711
Configure tcp destination port	1713
Configure protocol udp	1715
Configure udp destination port	1716
Configure udp source port	1717
Configure protocol icmp	1719
Configure protocol name	1720
IPI-ACL-IPV6	1721
Configure vlan id	1721
Configure name	1723
Configure type	1724
Configure sequence id	1726
Configure forwarding action	1728

Configure protocol tcp	1729
Configure source address	1731
Configure lower source port in range	1733
Configure upper source port in range.	1734
Configure protocol udp	1736
Configure destination address	1737
Configure lower destination port in range.	1739
Configure source port operator	1740
Configure udp source port	1742
Configure dscp	1744
Configure destination port operator	1745
Configure upper destination port in range	1747
Configure protocol icmp	1749
Configure protocol sctp	1750
Configure sctp destination port.	1751
Configure sctp source port	1753
Configure protocol name	1754
IPI-ACL-ARP	1756
Configure source mac any	1756
Configure name	1757
Configure type	1758
Configure source mac host	1760
Configure sequence id	1761
Configure forwarding action	1763
Configure source mac address	1764
Configure arp packet type	1766
Configure source ip address	1767
Configure vlan id	1769
Configure inner vlan id	1770
Configure source mac mask.	1772
IPI-ACL-MAC.	1773
Configure source mac any	1773
Configure name	1774
Configure type	1776
Configure source mac host	1777
Configure sequence id	1779
Configure forwarding action	1780
Configure source mac address	1782
Configure source mac mask.	1783
Configure destination mac address	1785
Configure inner vlan id	1786
Configure destination mac host	1788
Configure destination mac mask	1789
Configure destination mac any.	1790
Configure ethertype	1792
Configure cos value	1793
Configure vlan id	1795

IPI-ACL-PORTS	1796
Configure acl name	1796
Configure name	1797
Configure acl type	1798
Configure time range	1799
clear access-list counters	1800
clear access-list NAME counters	1800
clear ip access-list counters	1800
clear ip access-list NAME counters	1800
clear ipv6 access-list counters	1801
clear ipv6 access-list NAME counters	1801
clear mac access-list counters	1801
clear mac access-list NAME counters	1801
clear arp access-list counters	1802
clear arp access-list NAME counters	1802
IPI-DHCP-SNOOPING	1802
Configure options	1802
Configure snooping enable	1803
Configure verify mac address	1803
Configure option 82 enable	1804
Configure write delay	1804
Configure strict validation	1805
Configure vlan range	1805
Configure enable	1806
Configure validate	1806
Configure bridge id	1807
Configure if name	1807
Configure mac address	1808
ip dhcp snooping database bridge WORD	1809
renew ip dhcp snooping binding database bridge WORD	1810
ip dhcp snooping source database bridge WORD	1810
renew ip dhcp snooping source binding database bridge WORD	1810
clear ip dhcp snooping source binding bridge WORD	1810
clear ip dhcp snooping binding bridge WORD	1811
debug ip dhcp snooping (event rx tx packet all)	1811
no debug ip dhcp snooping (event rx tx packet all)	1811
IPI-DHCP-SNOOPING-INTERFACE	1812
Configure snooping trust	1812
Configure verify snooping vlan	1812
Configure verify access group mode	1813
clear hsl ipc-stat VALUE VALUE	1813
clear hsl ipc-stat	1814
clear hsl mlag mac-sync-count	1814
clear hardware-discard-counters	1814
clear hsl fdb debug-counters	1814
IPI-UNICAST-RPF	1815
Configure enable route lookup	1815

Configure enable default route check	1815
Configure source reachability mode	1815
IPI-OSPF-INTERFACE-TRACKING	1816
Configure event name	1816
Configure event neighbor ip address	1817
Configure name	1817
IPI-PORT-MIRROR	1818
Configure id	1818
Configure enabled	1818
Configure description	1819
Configure source vlan	1819
Configure interface name	1820
Configure reflector interface name	1820
Configure direction	1821
IPI-RIPNG	1822
Configure options	1822
Configure split horizon	1822
Configure name	1823
Configure enabled	1823
Configure metric offset	1824
Configure ripng enabled	1824
Configure enable cisco metric behavior	1825
Configure passive interfaces	1825
Configure distance	1825
Configure static routes	1826
Configure aggregate prefixes	1826
Configure default metric	1827
Configure originate default route	1827
Configure receive buffer size	1827
Configure route type	1828
Configure route map	1828
Configure metric	1829
Configure route table update interval	1829
Configure address	1830
Configure type	1831
Configure access list name	1831
Configure direction	1832
Configure list name	1833
debug ipv6 rip (all events packet send packet recv packet packet detail nsm rib)	1834
no debug ipv6 rip (all events packet send packet recv packet packet detail nsm rib)	1834
clear ipv6 rip route (kernel connected static isis ospf6 bgp rip all)	1834
clear ipv6 rip route X::X:X/M	1835
IPI-RIPNG-VRF	1835
Configure vrf name	1835
Configure enable cisco metric behavior	1835
Configure passive interfaces	1836
Configure distance	1836

Configure static routes	1837
Configure aggregate prefixes	1838
Configure default metric	1838
Configure originate default route	1839
Configure receive buffer size	1839
Configure route type	1840
Configure route map	1840
Configure metric	1841
Configure route table update interval	1842
Configure address	1843
Configure type	1843
Configure access list name	1844
Configure direction	1845
Configure list name	1846
IPI-ARP	1847
Configure ip address	1847
Configure respond to arp request	1848
Configure icmp redirect	1848
Configure enable	1849
Configure enable proxy arp	1849
Configure enable local proxy arp	1849
Configure enable ip redirects	1850
Configure arp ageing timeout	1850
Configure arp reachable time	1851
debug ip arp event	1851
no debug ip arp event	1852
clear arp (A.B.C.D) (vrf (all VRFNAME default))	1852
clear arp IFNAME (vrf (all VRFNAME default))	1852
IPI-NEIGHBOR-DISCOVERY	1853
Configure interface name	1853
Configure ipv6 address	1853
Configure enable	1854
Configure nd ageing timeout	1854
Configure nd reachable time	1855
debug ipv6 nd event	1855
no debug ipv6 nd event	1855
clear ipv6 neighbors (X:X::X:X/M) (vrf (all VRFNAME default))	1856
clear ipv6 neighbors IFNAME (vrf (all VRFNAME default))	1856
IPI-USER-SESSION-MANAGEMENT	1856
Configure console id	1856
Configure privilege level	1857
Configure command history max limit	1857
Configure seconds	1858
Configure minutes	1859
Configure vty id	1859
clear line WORD	1860
mem-info imi monitor-start	1860

mem-info imi monitor-stop	1860
IPI-IPV6-ROUTER-ADV	1861
Configure suppress ra	1861
Configure suppress ra mtu	1861
Configure managed flag	1862
Configure other config flag	1862
Configure current hop limit	1863
Configure link mtu	1863
Configure dad attempts	1864
Configure off link	1864
Configure no auto configuration	1865
Configure valid lifetime	1865
Configure preferred lifetime	1866
Configure ipv6 address	1867
Configure name	1867
Configure reachable time	1868
Configure retransmission time	1869
Configure router lifetime	1869
Configure max ra interval	1870
IPI-NETWORK-ADDRESS-TRANSLATION	1871
Configure generic timeout	1871
Configure icmp timeout	1871
Configure tcp timeout	1872
Configure udp timeout	1872
Configure tcp fin timeout	1873
Configure global address	1873
Configure local address	1874
Configure address	1875
IPI-NETWORK-ADDRESS-TRANSLATION-INTERFACE	1876
Configure incoming	1876
Configure outgoing	1876
IPI-ERPSV2	1877
Configure ring name	1877
Configure east interface	1877
Configure west interface	1878
Configure description	1878
Configure profile name	1879
Configure wait to restore timer	1879
Configure hold off timer	1880
Configure guard time	1881
Configure protection mode	1881
Configure name	1882
Configure mapped profile name	1882
Configure ring type	1883
Configure enable tcn propagation	1883
Configure tcn to instances	1884
Configure non virtual channel	1884

Configure ring id	1885
Configure associate ring name	1885
Configure owner port id	1886
Configure neighbor port id	1887
Configure next neighbor port id	1887
Configure non owner	1888
Configure level	1888
Configure vlan id	1889
Configure data vlan	1890
Configure attached instance	1890
Configure options	1891
Configure instance name	1891
g8032 erp-instance (INSTANCENAME all) (force-switch manual-switch) (east- interface west-interface)	1892
clear g8032 erp-instance (INSTANCENAME all)	1892
clear g8032 aps-statistics INSTANCENAME	1893
debug g8032 (all tx rx fsm timers events external hal)	1893
no debug g8032 (all tx rx fsm timers events external hal)	1893
IPI-G8031	1894
Configure eps id	1894
Configure working port	1894
Configure protection port	1895
Configure elps instance id	1895
Configure data vlans	1896
Configure primary vlan	1896
IPI-G8031-ELPS	1897
Configure wait to restore	1897
Configure hold off	1898
Configure local freeze	1898
Configure protection type	1899
Configure enable revertive mode	1899
Configure level identifier	1900
Configure options	1900
lockout bridge WORD g8031 eps-id <1-32>	1901
force-switch bridge WORD g8031 eps-id <1-32>	1901
manual-switch bridge WORD g8031 eps-id <1-32>	1902
exercise bridge WORD g8031 eps-id <1-32>	1902
clear bridge WORD g8031 eps-id <1-32>	1902
debug g8031 (all rx tx fsm events hal)	1903
no debug g8031 (all rx tx fsm events hal)	1903
IPI-CFM	1903
Configure cache enable	1903
Configure cache size	1904
Configure options	1905
Configure type	1905
Configure ma name	1906
Configure enable rmep auto discovery	1906

Configure bridge id	1907
Configure md name	1908
Configure mip creation	1908
Configure inner vlan id	1909
Configure link level ma	1910
Configure mip interface name	1911
Configure evpn id	1911
Configure vpws vc name	1912
Configure ccm interval	1913
Configure static rmep identifiers	1913
Configure mep id	1914
Configure direction	1915
Configure administrative state	1916
Configure bw mapped interface	1917
Configure enable cc multicast	1918
Configure lowest fault priority defect	1919
clear ethernet cfm maintenance-points remote domain DOMAIN_NAME	1920
clear ethernet cfm statistics	1920
clear ethernet cfm statistics mep <1-8191> domain DOMAIN_NAME ma MA_NAME	1920
cfm snmp restart	1921
debug ethernet cfm (events rx tx loopback traceroute all)	1921
no debug ethernet cfm (events rx tx loopback traceroute all)	1921
clear ethernet cfm traceroute-cache	1921
IPI-CFM-Y1731	1922
Configure enable receive	1922
Configure wait to restore timer	1923
Configure peer port id	1924
Configure md name	1925
Configure lock state	1926
Configure client md level	1926
Configure interval	1927
Configure priority	1928
Configure enable status	1929
Configure ma name	1930
Configure enable lm responder	1931
Configure enable dm responder	1932
Configure profile name	1933
Configure mode	1934
Configure test type	1934
Configure frame size	1935
Configure pattern type	1935
Configure message period	1936
Configure measurement type	1936
Configure measurement interval	1937
Configure intervals stored	1937
Configure bins per fd interval	1938
Configure bins per ifdv interval	1938

Configure bin number 1939

abort test-signal domain DOMAIN_NAME ma MA_NAME mep <1-8191> 1940

test-signal start-time (relative) <0-4294967295> stop-time (relative) <0-4294967295> tst-profile-name WORD domain DOMAIN_NAME ma MA_NAME mep <1-8191> target (mac-address MAC|<1-8191>) 1940

test-signal start-time (absolute) START-TIME stop-time (relative) <0-4294967295> tst-profile-name WORD domain DOMAIN_NAME ma MA_NAME mep <1-8191> target (mac-address MAC|<1-8191>) 1941

test-signal start-time (relative) <0-4294967295> stop-time (absolute) STOP-TIME tst-profile-name WORD domain DOMAIN_NAME ma MA_NAME mep <1-8191> target (mac-address MAC|<1-8191>) 1942

test-signal start-time (absolute) START-TIME stop-time (absolute) STOP-TIME tst-profile-name WORD domain DOMAIN_NAME ma MA_NAME mep <1-8191> target (mac-address MAC|<1-8191>) 1944

loss-measurement type proactive profile-name WORD rmep (mac-address MAC|<1-8191>) mep <1-8191> domain DOMAIN_NAME ma MA_NAME 1945

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (immediate) stop-time (none) repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME 1945

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (immediate) stop-time (relative) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME 1946

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (immediate) stop-time (absolute) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME 1948

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (relative) START-TIME stop-time (none) repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME 1949

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (relative) START-TIME stop-time (relative) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME 1950

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (relative) START-TIME stop-time (absolute) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME 1951

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (absolute) START-TIME stop-time (none) repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME 1952

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (absolute) START-TIME stop-time (relative) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME 1954

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (absolute) START-TIME stop-time (absolute) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME 1955

abort loss-measurement mep <1-8191> domain DOMAIN_NAME ma MA_NAME ... 1956

clear ethernet cfm loss-measurement history mep <1-8191> domain DOMAIN_NAME ma MA_NAME 1957

delay-measurement type proactive profile-name WORD rmep (mac-address MAC|<1-8191>) mep <1-8191> domain DOMAIN_NAME ma MA_NAME 1957

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (immediate) stop-time (none) repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME 1958

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC <1-8191>) start-time (immediate) stop-time (relative) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME	1959
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC <1-8191>) start-time (immediate) stop-time (absolute) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME	1960
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC <1-8191>) start-time (relative) START-TIME stop-time (none) repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME	1961
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC <1-8191>) start-time (relative) START-TIME stop-time (relative) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME	1962
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC <1-8191>) start-time (relative) START-TIME stop-time (absolute) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME	1964
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC <1-8191>) start-time (absolute) START-TIME stop-time (none) repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME	1965
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC <1-8191>) start-time (absolute) START-TIME stop-time (relative) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME	1966
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC <1-8191>) start-time (absolute) START-TIME stop-time (absolute) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME	1967
abort delay-measurement mep <1-8191> domain DOMAIN_NAME ma MA_NAME. . .	1968
clear ethernet cfm delay-measurement history mep <1-8191> domain DOMAIN_NAME ma MA_NAME	1969
clear ethernet cfm statistics csf mep <1-8191> domain DOMAIN_NAME ma MA_NAME. . .	1970
clear ethernet cfm statistics bn mep <1-8191> domain DOMAIN_NAME ma MA_NAME. . .	1970
clear ethernet cfm statistics lck mep <1-8191> domain DOMAIN_NAME ma MA_NAME. . .	1971
clear ethernet cfm statistics test-signal domain DOMAIN_NAME ma MA_NAME mep <1-8191> stats (gtf ctf).	1971
IPI-UDLD	1972
Configure enable	1972
Configure message time	1972
Configure options	1973
Configure mode	1973
Configure administrative state	1974
debug udld (event packet timer nsm hal all).	1974
no debug udld (event packet timer nsm hal all)	1974
IPI-PTP	1975
Configure instance type	1975
Configure color frame	1975
Configure drop frame	1976
Configure denominator	1976
Configure I2 pkt forward	1977
Configure domain	1978

Configure servo config	1978
Configure external clock holdover duration	1979
Configure system clock sync	1979
Configure ptp clock sync	1980
Configure ptsf wtr duration.	1981
Configure g8265p1 wtr duration.	1981
Configure g8265p1 option	1982
Configure reserved vlan base	1982
Configure two step.	1983
Configure clock type tgm	1984
Configure one way	1984
Configure number ports	1985
Configure pps pulse offset	1985
Configure pps in smx tod type	1986
Configure priority 1.	1987
Configure priority 2.	1987
Configure slave only	1988
Configure local priority	1988
Configure max steps removed	1989
Configure start boundary hops.	1990
Configure servo history interval	1990
Configure clock class	1991
Configure clock accuracy.	1992
Configure offset scaled log variance	1992
Configure offset nano seconds	1993
Configure port number.	1994
Configure description	1994
Configure transport type	1995
Configure transport v6 type	1996
Configure transport v6 mulitcast type	1996
Configure non forwardable mac addr.	1997
Configure log min delay req interval	1998
Configure log announce interval	1998
Configure announce receipt timeout	1999
Configure log sync interval.	2000
Configure time to live	2001
Configure ip dscp	2001
Configure unicast grant duration	2002
Configure master only	2003
Configure grandmaster priority 2	2003
Configure append	2004
Configure process	2005
Configure source ipv6 link local address	2005
Configure source ipv6 interface address	2006
Configure source ipv4 interface address	2007
Configure source ipv6 address	2007
Configure source ipv4 address	2008

Configure delay asymmetry nsec	2009
Configure network interface	2010
Configure vlan physical interface name	2010
Configure vlan physical dot1q vlan id	2011
Configure dot1q vlan id	2012
Configure inner dot1q vlan id	2013
Configure master clock source ipv4 address	2014
Configure master ipv4 address priority	2015
Configure master clock source ipv6 address	2016
Configure master ipv6 address priority	2017
Configure io type	2017
Configure utc date	2018
Configure baseline seconds	2019
Configure enable	2019
Configure hw timestamp	2020
clear ptp clock <0-1> stats	2020
debug ptp	2021
no debug ptp	2021
IPI-EVPN-MPLS	2021
Configure enable evpn mpls	2021
Configure vtep ipv4	2021
Configure mac ageing timer	2022
Configure arp nd refresh time	2022
Configure tenant identifier	2023
Configure control word	2023
Configure vpws identifier	2024
Configure vrf name	2024
Configure mac holdtime	2025
Configure tenant description	2025
Configure tunnel policy name	2026
Configure irb name	2026
Configure irb advertise host route	2027
clear mac address-table dynamic evpn-mpls	2027
clear mac address-table dynamic evpn-mpls evid <1-16777215> (address MACADDR)	2027
clear evpn mpls counters (vpn-id <1-16777215>) network (egress) (dst A.B.C.D)	2028
clear evpn mpls counters (vpn-id <1-16777215>) network (ingress)	2028
IPI-TWAMP	2029
Configure enable	2029
Configure administrative state	2029
Configure vrf name	2030
Configure name	2031
Configure options	2031
Configure port	2032
Configure max connection duration	2032
Configure max connections	2033
Configure max connections per client	2033

Configure maximum sessions	2033
Configure maximum sessions per connection	2034
Configure inactivity timeout	2034
twamp start test-session WORD packet-count <1-65535> (interval <500-10000>) (delay-threshold <0-1000000>)	2035
twamp stop test-session WORD	2035
debug (twamp)	2036
no debug (twamp)	2036
IPI-ROLE-BASED-ACCESS-CONTROL	2036
Configure policy name	2036
Configure command mode	2037
Configure rule name	2038
Configure rule type	2038
Configure role name	2039
Configure default policy	2040
Configure enable	2040
IPI-PORT-BREAKOUT	2041
Configure interface	2041
Configure mode	2041
Configure name	2042
IPI-PCEP	2042
Configure entity id	2042
Configure keep alive interval	2043
Configure dead interval	2043
Configure request timeout	2044
Configure tolerance keepalive	2044
Configure tolerance dead interval	2045
Configure cool off timeout	2045
Configure source address	2046
Configure recovery policy	2046
Configure segment routing v6	2047
Configure pce instantiate	2047
Configure segment routing	2048
Configure redelegation timeout	2049
Configure lsp state timeout	2049
Configure flap interval	2050
Configure interval	2050
Configure lsp limit	2051
Configure options	2051
Configure srv6 spirent comp	2052
debug pcep (events error packet timer update report instantiation delegation request all)	2052
no debug pcep (events error packet timer update report instantiation delegation request all)	2053
clear pcep request (<5001-65535> all)	2053
IPI-PCEP-PEER	2053
Configure address	2053

Configure delegation preference	2054
Configure authentication key	2054
clear pcep peer *	2055
clear pcep peer (A.B.C.D X:X::X:X)	2055
clear pcep statistics	2056
IPI-SOURCE-INTERFACE	2056
Configure protocol type	2056
Configure interface name	2057
IPI-TACACS	2057
Configure feature enable	2057
Configure vrf name	2058
Configure key type	2059
Configure timeout	2059
Configure host address	2060
Configure secret key string	2060
Configure port	2061
Configure sequence number	2062
Configure enable	2063
clear tacacs-server counters (vrf management)	2063
clear tacacs-server (A.B.C.D X:X::X:X HOSTNAME) counters (vrf (management all))	2064
debug tacacs+	2064
no debug tacacs+	2064
IPI-TIME-RANGE	2064
Configure name	2064
Configure absolute start time	2065
Configure relative start time	2065
Configure absolute end time	2066
Configure relative end time	2066
Configure frequency	2067
crypto pki generate rsa common-name ipv4 IPv4ADDR	2067
IPI-IP-SLA	2068
Configure identifier	2068
Configure host	2068
Configure frequency	2069
Configure timeout	2070
Configure threshold	2070
Configure vrf name	2071
clear ip sla statistics (<1-65535>)	2071
IPI-SERVICE-MAP	2072
Configure name	2072
Configure color code	2072
Configure selection mode	2073
Configure tunnel type	2073
IPI-CROSS-CONNECT	2074
Configure xc name	2074
Configure description	2075
Configure admin disable	2075

Configure endpoint if	2076
IPI-BRIDGE-DOMAIN	2076
Configure domain id	2076
Configure description	2077
Configure route interface	2078
Configure bridge id	2078
Configure instance id	2079
Configure name	2080
clear mac address-table dynamic bridge-domain all	2081
clear mac address-table dynamic bridge-domain id <1-2147483647> (interface IFNAME) (address MACADDR)	2081
IPI-OBJECT-TRACKING	2081
Configure tracker id	2081
Configure delay down	2082
Configure delay up	2082
Configure select option	2083
Configure track id	2084
IPI-DELAY-PROFILE	2084
Configure profile type	2084
Configure mode	2085
Configure sender port	2085
Configure burst interval	2086
Configure burst count	2086
Configure interval	2087
Configure disable	2087
Configure threshold	2088
Configure minimum change	2088
Configure enable	2089
Configure delay profile enable	2089
IPI-ELK	2090
Configure password	2090
Configure certificate path	2090
service enable metricbeat (vrf management)	2091
service enable filebeat (vrf management)	2091
service disable metricbeat (vrf management)	2091
service disable filebeat (vrf management)	2092
IPI-IPSEC	2092
Configure transform set name	2092
Configure transform set mode	2093
Configure ah authentication	2093
Configure esp encryption	2094
Configure esp authentication	2094
Configure name	2095
Configure sequence id	2096
Configure peer	2096
Configure security parameter index	2097
IPI-EVPN-SRV6	2098

Configure enabled	2098
Configure vtep ipv6 address.	2099
Configure tenant identifier	2099
Configure vpws identifier	2100
Configure vrf name	2100
Configure tenant description	2101
Configure tunnel policy name.	2101
Configure srv6 locator name	2102
IPI-SEGMENT-ROUTING-ODN	2102
Configure color	2102
Configure cspf retry limit.	2103
Configure cspf retry interval	2103
Configure pce lsp delegate.	2104
Configure pce state report	2104
Configure pce entity id	2105
Configure binding sid label	2106
Configure discriminator	2106
Configure preference	2107
Configure pcep	2108
Configure isis instance id	2109
Configure ospf process id.	2109
Configure ospf empty	2110
Configure enable	2111
Configure protocol origin	2112
Configure admin group name.	2113
Configure metric type	2114
Configure bound	2115
Configure address	2116
IPI-HOST	2117
Configure disable service advanced vty.	2117
Configure service passwd encryption.	2118
Configure passwd encrypted	2118
Configure banner motd.	2118
Configure service term length	2119
IPI-TWAMP-CLIENT	2119
Configure enable	2119
Configure maximum sessions	2120
Configure maximum connections	2120
Configure maximum sessions per connection	2120
Configure connection name	2121
Configure server address	2121
twamp client start connection NAME (vrf WORD) packet-count <0-1000000>	2122
twamp client stop connection NAME (vrf WORD)	2123
twamp client reset connection NAME (session NAME) (vrf WORD)	2123
CHAPTER 2 Pyang Tree	2125
module: ipi-aaa	2125

module: ipi-acl	2126
module: ipi-alarms	2135
module: ipi-arp	2135
module: ipi-authentication-radius	2137
module: ipi-authentication	2138
module: ipi-bfd	2141
module: ipi-bgp-vrf	2149
module: ipi-bgp	2151
module: ipi-bridge-domain	2201
module: ipi-bridge	2202
module: ipi-cfm	2204
module: ipi-cross-connect	2221
module: ipi-crypto	2222
module: ipi-delay-profile	2222
module: ipi-dhcp	2223
module: ipi-dns-client	2233
module: ipi-dns-relay	2234
module: ipi-elk	2235
module: ipi-enhanced-pbr	2236
module: ipi-erpsv2	2238
module: ipi-ethernet-vpn	2242
module: ipi-evpn-mpls	2244
module: ipi-evpn-srv6	2247
module: ipi-g8031	2248
module: ipi-global-te	2250
module: ipi-host	2250
module: ipi-hwtable	2251
module: ipi-if-aggregate	2251
module: ipi-if-ethernet	2252
module: ipi-if-extended	2253
module: ipi-if-flowspec	2261
module: ipi-if-ip	2262
module: ipi-igmp-snooping	2264
module: ipi-igmp	2265
module: ipi-igp-te	2270
module: ipi-interface	2273
module: ipi-ip-sla	2275
module: ipi-ipsec	2277
module: ipi-ipv6-router-adv	2278
module: ipi-isis	2280
module: ipi-keychain	2312
module: ipi-l2vpn-vpls	2313
module: ipi-l2vpn-vpws	2319
module: ipi-lacp	2326
module: ipi-ldp	2329
module: ipi-lldpv2	2338
module: ipi-logging	2344

module: ipi-management-server	2346
module: ipi-mcec	2348
module: ipi-mlag	2351
module: ipi-mld-snooping	2351
module: ipi-mpls-bfd	2353
module: ipi-mpls-rib	2355
module: ipi-mpls	2361
module: ipi-mrib	2364
module: ipi-neighbor-discovery	2369
module: ipi-network-address-translation	2371
module: ipi-network-instance	2373
module: ipi-network-services-manager	2373
module: ipi-ntp	2375
module: ipi-object-tracking	2377
module: ipi-ospf-interface-tracking	2378
module: ipi-ospf	2379
module: ipi-ospfv3	2411
module: ipi-pbr	2433
module: ipi-pcep	2433
module: ipi-pim	2439
module: ipi-ping	2456
module: ipi-platform-port	2457
module: ipi-platform-transceiver-smart-sfp	2458
module: ipi-platform	2458
module: ipi-port-breakout	2515
module: ipi-port-mirror	2515
module: ipi-port-vlan	2518
module: ipi-prefix-list	2521
module: ipi-ntp	2522
module: ipi-qos-if	2531
module: ipi-qos	2535
module: ipi-radius	2546
module: ipi-ras	2548
module: ipi-rib-vrf	2548
module: ipi-rib	2554
module: ipi-rip	2559
module: ipi-ripng	2567
module: ipi-role-based-access-control	2573
module: ipi-routemap	2574
module: ipi-rsvp	2579
module: ipi-seamless-bfd	2596
module: ipi-segment-routing	2597
module: ipi-service-map	2606
module: ipi-sflow-interface	2607
module: ipi-sflow	2608
module: ipi-snmp-server-extended	2609
module: ipi-snmp-server	2613

module: ipi-snmpp 2613

module: ipi-source-interface 2614

module: ipi-ssh 2615

module: ipi-streaming-telemetry 2617

module: ipi-synce 2617

module: ipi-sys-mgmt. 2620

module: ipi-sys-notifications 2620

module: ipi-sys-update 2621

module: ipi-system 2623

module: ipi-tacacs 2623

module: ipi-telnet 2624

module: ipi-tfo 2625

module: ipi-time-range 2626

module: ipi-twamp 2627

module: ipi-udld 2632

module: ipi-unicast-rpf 2633

module: ipi-user-management 2633

module: ipi-user-session-management 2634

module: ipi-vlan. 2636

module: ipi-vrf 2638

module: ipi-vrrp 2639

module: ipi-vxlan. 2646

module: ipi-watchdog 2655

module: ipi-xstp 2656

Preface

This document describes the OcNOS commands for NetConf.

Audience

This guide is intended for network administrators and other engineering professionals who configure and manage NetConf for OcNOS.

Conventions

[Table P-1](#) shows the conventions used in this guide.

Table P-1: Conventions

Convention	Description
<i>Italics</i>	Emphasized terms; titles of books
Note:	Special instructions, suggestions, or warnings
<code>monospaced type</code>	Code elements such as XML tags, commands, parameters, files, and directories

Related Documentation

For information about installing OcNOS, see the *Installation Guide* for your platform.

Feature Availability

The features described in this document are available depending upon the OcNOS SKU that you purchased. See the *Feature Matrix* for a description of the OcNOS SKUs.

Support

For support-related questions, contact support@ipinfusion.com.

Comments

If you have comments, or need to report a problem with the content, contact techpubs@ipinfusion.com.

IPI-MANAGEMENT-SERVER

Configure feature enabled

Enable callhome feature on the NETCONF server

This command is supported when following feature are enabled NETCONF feature

Attribute Name: feature-enabled

Attribute Type: empty

Netconf edit-config payload

```
<netconf-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-management-server">
  <callhome>
  <config>
    </feature-enabled>
  </config>
</callhome>
</netconf-server>
```

Command Syntax

```
feature netconf callhome enable
```

Configure management port

Interface to be used to connect the callhome server

This command is supported when following feature are enabled NETCONF feature

Attribute Name: management-port

Attribute Type: string

Default Value: eth0

Attribute Range: 1-49

Netconf edit-config payload

```
<netconf-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-management-server">
  <callhome>
  <config>
    <management-port>IFNAME</management-port> <!-- operation="delete"-->
  </config>
</callhome>
</netconf-server>
```

Command Syntax

```
management-port IFNAME
```

Configure port

Callhome server listening port number

This command is supported when following feature are enabled NETCONF feature

Attribute Name: port

Attribute Type: inet:port-number

Default Value: 4334

Attribute Range: 1-65535

Attribute Name: address

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<netconf-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-management-server">
  <callhome>
    <netconf-clients>
      <netconf-client>
        <name>WORD</name>
        <config>
          <name>WORD</name>
          <address>A.B.C.D|X:X::X:X|HOSTNAME</address>
        </config>
        <port>1</port>
      </netconf-client>
    </netconf-clients>
  </callhome>
</netconf-server>
```

Command Syntax

```
callhome server WORD (A.B.C.D|X:X::X:X|HOSTNAME) (port <1-65535>|)
```

Configure enable

specifies whether server will reconnect after client closes the session

This command is supported when following feature are enabled NETCONF feature

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<netconf-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-management-server">
  <callhome>
    <reconnect>
```

```
<config>
  </enable>
</config>
</reconnect>
</callhome>
</netconf-server>
```

Command Syntax

```
reconnect enable
```

Configure retry max attempts

Specifies the number of retry attempts the server should attempt to the callhome server before giving up. Set 0 to retry infinitely.

This command is supported when following feature are enabled NETCONF feature

Attribute Name: retry-max-attempts

Attribute Type: uint8

Default Value: 3

Attribute Range: 0-255

Netconf edit-config payload

```
<netconf-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-management-server">
  <callhome>
  <reconnect>
  <config>
    <retry-max-attempts>0</retry-max-attempts> <!-- operation="delete"-->
  </config>
  </reconnect>
  </callhome>
</netconf-server>
```

Command Syntax

```
retry-max-attempts <0-255>
```

Configure retry interval

Specifies the number of seconds to wait after a connect attempt to the callhome server has failed

This command is supported when following feature are enabled NETCONF feature

Attribute Name: retry-interval

Attribute Type: uint32

Default Value: 300

Attribute Range: 1-86400

Netconf edit-config payload

```
<netconf-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-management-server">
  <callhome>
```

```
<reconnect>
<config>
  <retry-interval>1</retry-interval> <!-- operation="delete"-->
</config>
</reconnect>
</callhome>
</netconf-server>
```

Command Syntax

```
retry-interval <1-86400>
```

Configure translation mode

Enable/disable NETCONF translation

This command is supported when following feature are enabled NETCONF translation feature,NETCONF feature

Attribute Name: translation-mode

Attribute Type: enum (openconfig)

Netconf edit-config payload

```
<netconf-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-management-server">
<netconf-translation>
<config>
  <translation-mode>openconfig</translation-mode> <!-- operation="delete"-->
</config>
</netconf-translation>
</netconf-server>
```

Command Syntax

```
netconf translation (openconfig)
```

Configure feature netconf ssh

Use this attribute to enable or disable NETCONF SSH feature.

Attribute Name: feature-netconf-ssh

Attribute Type: boolean

Netconf edit-config payload

```
<netconf-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-management-server">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
</netconf-ssh-config>
<config>
  <feature-netconf-ssh>true</feature-netconf-ssh> <!-- operation="delete"-->
</config>
```



```

</config>
</netconf-ssh-config>
</vrf>
</vrfs>
</netconf-server>

```

Command Syntax

```
feature netconf-ssh (vrf management|)
```

Configure vrf name

Use this attribute to enable or disable NETCONF SSH feature.

Attribute Name: feature-netconf-ssh

Attribute Type: boolean

Netconf edit-config payload

```

<netconf-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-management-server">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <netconf-ssh-config>
    <config>
      <feature-netconf-ssh>true</feature-netconf-ssh> <!-- operation="delete"-->
    </config>
  </netconf-ssh-config>
</netconf-server>

```

Command Syntax

```
no feature netconf-ssh (vrf management|)
```

Configure feature netconf tls

Use this attribute to enable or disable NETCONF TLS feature.

Attribute Name: feature-netconf-tls

Attribute Type: boolean

Netconf edit-config payload

```

<netconf-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-management-server">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
</netconf-server>

```

```
    </config>
</netconf-tls-config>
<config>
    <feature-netconf-tls>true</feature-netconf-tls> <!-- operation="delete"-->
</config>
</netconf-tls-config>
</vrf>
</vrfs>
</netconf-server>
```

Command Syntax

```
feature netconf-tls (vrf management|)
```

Configure ssh port

Use this attribute to set the ssh-port number on which the NETCONF server listens for connections. The default port on which the netconf-ssh server listens is 830.

This command is supported when following feature are enabled Virtual routing and forwarding,NETCONF feature

Attribute Name: ssh-port

Attribute Type: uint32

Attribute Range: 1024-65535

Netconf edit-config payload

```
<netconf-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-management-server">
<vrfs>
<vrf>
    <vrf-name>management</vrf-name>
    <config>
        <vrf-name>management</vrf-name>
    </config>
</netconf-ssh-config>
<config>
    <ssh-port>1024</ssh-port> <!-- operation="delete"-->
</config>
</netconf-ssh-config>
</vrf>
</vrfs>
</netconf-server>
```

Command Syntax

```
netconf server ssh-port <1024-65535> (vrf management|)
```

Configure tls port

Use this attribute to set the tls-port number on which the NETCONF server listens for connections. The default port on which the netconf-tls server listens is 6513.

This command is supported when following feature are enabled Virtual routing and forwarding,NETCONF feature

Attribute Name: tls-port

Attribute Type: uint32

Attribute Range: 1024-65535

Netconf edit-config payload

```
<netconf-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-management-server">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <netconf-tls-config>
    <config>
      <tls-port>1024</tls-port> <!-- operation="delete"-->
    </config>
  </netconf-tls-config>
</netconf-server>
```

Command Syntax

```
netconf server tls-port <1024-65535> (vrf management|)
```

IPI-STREAMING-TELEMETRY

Configure feature enabled

Enable or Disable device's telemetry system

Attribute Name: feature-enabled

Attribute Type: empty

Netconf edit-config payload

```
<telemetry-system xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-streaming-
telemetry">
  <streaming-telemetry>
    <config>
      </feature-enabled><!-- operation="delete"-->
    </config>
  </streaming-telemetry>
</telemetry-system>
```

Command Syntax

```
feature streaming-telemetry
```

Configure gnmi severity

device's debug telemetry severity level

Attribute Name: gnmi-severity

Attribute Type: enum (debug|info|warning|error|fatal|panic|d-panic)

Default Value: error

Attribute Name: gnmi-debug

Attribute Type: empty

Netconf edit-config payload

```
<telemetry-system xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-streaming-telemetry">
  <streaming-telemetry>
    <debug>
      <config>
        </gnmi-debug><!-- operation="delete"-->
        <gnmi-severity>error</gnmi-severity> <!-- operation="delete"-->
      </config>
    </debug>
  </streaming-telemetry>
</telemetry-system>
```

Command Syntax

```
debug telemetry gnmi enable severity (debug|info|warning|error|fatal|panic|d-panic)
```

Configure gnmi debug

Enable or Disable device's debug telemetry

Attribute Name: gnmi-debug

Attribute Type: empty

Netconf edit-config payload

```
<telemetry-system xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-streaming-telemetry">
  <streaming-telemetry>
    <debug>
      <config>
        </gnmi-debug><!-- operation="delete"-->
      </config>
    </debug>
  </streaming-telemetry>
</telemetry-system>
```

Command Syntax

```
debug telemetry gnmi enable
```

IPI-MANAGEMENT-SERVER-NOTIFICATION

Configure severity

If notification enabled, all the notifications having severity higher than or equal to this severity allowed. If notification disabled, all the notifications having severity lower than or equal to this severity not allowed

Attribute Name: severity

Attribute Type: enum (all|info|warning|minor|major|critical)

Default Value: all

Attribute Name: enable

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<management-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-management-server">
  <module-notifications>
    <module-notification>
      <module-name>auth</module-name>
      <config>
        <module-name>auth</module-name>
        <enable>enable</enable>
      </config>
      <severity>all</severity>
    </module-notification>
  </module-notifications>
</management-server>
```

Command Syntax

```
module
  (auth|bgp|cmm|hostp|hsl|isis|ldp|lag|l2mrib|mstp|mrib|nsm|onm|oam|ospf|ospf6|ptp
  |rip|pim|rib|vrrp|sflow|rsvp|pserv|cml|ndd|ripng|vlog|all|synce|pcep|udld)
notification (disable|enable) (severity (all|info|warning|minor|major|critical) |)
```

IPI-VRF

Configure instance name

Network Instance Name. For VRF and MAC VRF, instance name can be up to 32 chars long. For VPWS and VPLS instances, instance name can be up to 128 chars long. For L2NI (bridge) instance, instance name has to be a number between (1-32). For Cross-Connect, instance name can be up to 30 chars long. For Bridge-domain, instance, instance name has to be a number between (1-2147483647).

Attribute Name: instance-name

Attribute Type: string

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance> <!-- operation="delete"-->
    <instance-type>vrf</instance-type>
    <config>
      <instance-type>vrf</instance-type>
      <instance-name>WORD</instance-name>
    </config>
    <instance-name>WORD</instance-name>
  <vrf>
    <config>
      <vrf-name>WORD</vrf-name>
    </config>
  </vrf>
</network-instance>
</network-instances>
```

Command Syntax

```
ip vrf WORD
```

Configure instance type

Network Instance Name. For VRF and MAC VRF, instance name can be up to 32 chars long. For VPWS and VPLS instances, instance name can be up to 128 chars long. For L2NI (bridge) instance, instance name has to be a number between (1-32). For Cross-Connect, instance name can be up to 30 chars long. For Bridge-domain, instance, instance name has to be a number between (1-2147483647).

Attribute Name: instance-name

Attribute Type: string

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance> <!-- operation="delete"-->
    <instance-type>mac-vrf</instance-type>
    <config>
      <instance-type>mac-vrf</instance-type>
      <instance-name>WORD</instance-name>
    </config>
    <instance-name>WORD</instance-name>
  <vrf>
    <config>
      <vrf-name>WORD</vrf-name>
    </config>
  </vrf>
</network-instance>
</network-instances>
```

```
</vrf>
</network-instance>
</network-instances>
```

Command Syntax

```
mac vrf WORD
```

Configure description

VRF-specific description

Attribute Name: description

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
      <config>
        <description>LINE</description> <!-- operation="delete"-->
      </config>
    </vrf>
  </network-instance>
</network-instances>
```

Command Syntax

```
description LINE
```

Configure tunnel select policy

tunnel policy to be configured

Attribute Name: tunnel-select-policy

Attribute Type: string

Attribute Range: 1-127

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
```

```
    <instance-type>vrf</instance-type>
  </config>
  <instance-type>vrf</instance-type>
  <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
  <config>
    <tunnel-select-policy>NAME</tunnel-select-policy> <!--
operation="delete"-->
  </config>
</vrf>
</network-instance>
</network-instances>
```

Command Syntax

```
tunnel-select-policy NAME
```

Configure router id

VRF Router ID

Attribute Name: router-id

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
    <config>
      <router-id>A.B.C.D</router-id> <!-- operation="delete"-->
    </config>
  </vrf>
</network-instance>
</network-instances>
```

Command Syntax

```
router-id A.B.C.D
```

Configure evpn layer3 network id

L3 EVPN Identifier

Attribute Name: evpn-layer3-network-id

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
      <config>
        <evpn-layer3-network-id>1</evpn-layer3-network-id> <!--
operation="delete"-->
      </config>
    </vrf>
  </network-instance>
</network-instances>

```

Command Syntax

```
13vni <1-16777215>
```

Configure snmp context name

Use this attribute to set the SNMP context for VRF.

This command is supported when following feature are enabled SNMP feature

Attribute Name: snmp-context-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
      <snmp>
        <config>
          <snmp-context-name>WORD</snmp-context-name> <!-- operation="delete"-->
        </config>
      </snmp>
    </vrf>
  </network-instance>
</network-instances>

```

Command Syntax

```
snmp context-name WORD
```

clear router-id

Netconf RPC payload

```
<clear-default-router-id xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf"/>
```

Command Syntax

```
clear router-id
```

clear router-id vrf (VRFNAME|)

Attribute Name: vrfName

Attribute Type: string

Netconf RPC payload

```
<clear-vrf-router-id xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">  
<vrfName>VRFNAME</vrfName>  
</clear-vrf-router-id>
```

Command Syntax

```
clear router-id vrf (VRFNAME|)
```

IPI-INTERFACE

Configure name

The textual name of the interface. The value of this object should be the name of the interface as assigned by the local device and should be suitable for use in commands entered at the device's 'console'. This might be a text name, such as 'le0' or a simple port number, such as '1', depending on the interface naming syntax of the device. If several entries in the ifTable together represent a single interface as named by the device, then each will have the same value of name. Note that for an agent which responds to SNMP queries concerning an interface on some other (proxied) device, then the value of name for such an interface is the proxied device's local name for it. If there is no local name, or this object is otherwise not applicable, then this object contains a zero-length string.

Attribute Name: name

Attribute Type: string

Attribute Range: 1-33

Attribute Name: enable-switchport

Attribute Type: uint8

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">  
<interface> <!-- operation="delete"-->
```

```

    <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
    </enable-switchport>
  </config>
</interface>
</interfaces>

```

Command Syntax

```
interface IFNAME (switchport|)
```

Configure enable switchport

This attribute is used to set the mode of the Hybrid Switch Router feature to switched only. All interfaces are configured routed by default

Attribute Name: enable-switchport

Attribute Type: empty

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    </enable-switchport><!-- operation="delete"-->
  </interface>
</interfaces>

```

Command Syntax

```
switchport
```

Configure vrf name

This attribute is used to associates an interface with a VRF

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <vrf-name>WORD</vrf-name> <!-- operation="delete"-->
  </interface>
</interfaces>

```

Command Syntax

```
ip vrf forwarding WORD
```

Configure vr name

This attribute is used to associates an interface with a VR

Attribute Name: vr-name

Attribute Type: string

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <vr-name>WORD</vr-name> <!-- operation="delete"-->
</interface>
</interfaces>
```

Command Syntax

```
virtual-router forwarding WORD
```

Configure mtu

This attribute is used to set mtu value to interface. The size of the largest packet which can be sent/received on the interface, specified in octets. For interfaces that are used for transmitting network datagrams, this is the size of the largest network datagram that can be sent on the interface.

Attribute Name: mtu

Attribute Type: uint32

Attribute Range: 64-65535

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <mtu>64</mtu> <!-- operation="delete"-->
</interface>
</interfaces>
```

Command Syntax

```
mtu <64-65535>
```

Configure dot1ad ether type

This attribute is used to configure the ethertype value for the interface in the format 0xhhhh. Currently supported values are 0x8100 (default) or 0x88a8 or 0x9100 or 0x9200.

Attribute Name: dot1ad-ether-type

Attribute Type: string

Attribute Range: 6-6

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <dot1ad-ether-type>ETHERTYPE</dot1ad-ether-type> <!-- operation="delete"-->
  </interface>
</interfaces>
```

Command Syntax

```
dot1ad ethertype ETHERTYPE
```

Configure bridge domain forward

Attribute to change domain forward value

Attribute Name: bridge-domain-forward

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    </bridge-domain-forward><!-- operation="delete"-->
  </interface>
</interfaces>
```

Command Syntax

```
bridge-domain forward
```

Configure description

Use this attribute to set description for the interface

Attribute Name: description

Attribute Type: string

Attribute Range: 1-128

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <description>1</description> <!-- operation="delete"-->
</interface>
</interfaces>
```

Command Syntax

description LINE

Configure shutdown

Use this attribute to enable the selected interface. This leaf contains the configured, desired state of the interface. The testing(3) state indicates that no operational packets can be passed. When a managed system initializes, all interfaces start with ifAdminStatus in the down(2) state. As a result of either explicit management action or per configuration information retained by the managed system, ifAdminStatus is then changed to either the up(1) or testing(3) states (or remains in the down(2) state).

Attribute Name: shutdown

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  </shutdown><!-- operation="delete"-->
</interface>
</interfaces>
```

Command Syntax

shutdown

Configure if loopback

This attribute is used to enable port loopback

Attribute Name: if-loopback

Attribute Type: enum (tx|rx)

Attribute Name: if-loopback-level

Attribute Type: enum (mac|phy)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
<interface-loopback>
<config>
  <if-loopback-level>mac</if-loopback-level>
  <if-loopback>tx</if-loopback>
</config>
</interface-loopback>
</interface>
</interfaces>
```

Command Syntax

```
loopback (tx|rx) (mac|phy)
```

clear interface (IFNAME|) counters

Attribute Name: name

Attribute Type: string

Netconf RPC payload

```
<clear-interface-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
interface">
  <name>IFNAME</name>
</clear-interface-counters>
```

Command Syntax

```
clear interface (IFNAME|) counters
```

IPI-GLOBAL-TE

Configure id

identifier value for the administrative group

Attribute Name: id

Attribute Type: uint8

Attribute Range: 0-31

Netconf edit-config payload

```
<admin-groups xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-global-te">
<admin-group> <!-- operation="delete"-->
  <id>0</id>
```

```
<config>
  <id>0</id>
  <name>NAME</name>
</config>
<name>NAME</name>
</admin-group>
</admin-groups>
```

Command Syntax

```
admin-group NAME <0-31>
```

IPI-IF-ETHERNET

Configure duplex mode

Use this attribute to set the duplex mode for the interface. Auto-negotiation if enabled, is turned off when duplex mode is set for the interface. When auto-negotiation is enabled, the interface should negotiate the duplex mode directly (typically full-duplex).

Attribute Name: duplex-mode

Attribute Type: enum (half|full)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ethernet">
      <config>
        <duplex-mode>half</duplex-mode> <!-- operation="delete"-->
      </config>
    </ethernet>
  </interface>
</interfaces>
```

Command Syntax

```
duplex (half|full)
```

Configure secondary mac address

Use this attribute to set the secondary mac address for an interface to terminate L3 packets.

Attribute Name: secondary-mac-address

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ethernet">
    <config>
      </secondary-mac-address><!-- operation="delete"-->
    </config>
  </ethernet>
</interface>
</interfaces>
```

Command Syntax

```
mac-address secondary peer-mlag
```

Configure port speed

This attribute is used to set the link speed for the interface. To enable auto-negotiation for the interface, set this attribute to value auto. When auto-negotiation is enabled, it is expected that the interface will select the highest speed available based on negotiation. When auto-negotiation is not enabled, sets the link speed to a fixed value -- supported values are defined by IF_INTERFACE_SPEED_T enum.

Attribute Name: port-speed

Attribute Type: enum (10m|100m|1g|2.5g|10g|20g|25g|40g|50g|100g|auto)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ethernet">
    <config>
      <port-speed>10m</port-speed> <!-- operation="delete"-->
    </config>
  </ethernet>
</interface>
</interfaces>
```

Command Syntax

```
speed (10m|100m|1g|2.5g|10g|20g|25g|40g|50g|100g|auto)
```

Configure enable rcv

The textual name of the interface. The value of this object should be the name of the interface as assigned by the local device and should be suitable for use in commands entered at the device's 'console'. This might be a text name, such

as 'le0' or a simple port number, such as '1', depending on the interface naming syntax of the device. If several entries in the ifTable together represent a single interface as named by the device, then each will have the same value of name. Note that for an agent which responds to SNMP queries concerning an interface on some other (proxied) device, then the value of name for such an interface is the proxied device's local name for it. If there is no local name, or this object is otherwise not applicable, then this object contains a zero-length string.

Attribute Name: name

Attribute Type: string

Attribute Name: enable-rcv

Attribute Type: enum (off|on)

Attribute Name: enable-snd

Attribute Type: enum (off|on)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
<ethernet>
<flow-control>
<config>
  <enable-rcv>off</enable-rcv>
  <enable-snd>off</enable-snd>
</config>
</flow-control>
</ethernet>
</interface>
</interfaces>
```

Command Syntax

```
flowcontrol both
```

Configure enable rcv

This attribute is used to show flow control on receive

This command is supported when following feature are enabled L2 feature

Attribute Name: enable-rcv

Attribute Type: enum (off|on)

Default Value: off

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
```

```

    <name>IFNAME</name>
  </config>
<ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ethernet">
  <flow-control>
  <config>
    <enable-rcv>off</enable-rcv> <!-- operation="delete"-->
  </config>
</flow-control>
</ethernet>
</interface>
</interfaces>

```

Command Syntax

```
flowcontrol receive (off|on)
```

Configure enable snd

This attribute is used to show flow control on send

This command is supported when following feature are enabled L2 feature

Attribute Name: enable-snd

Attribute Type: enum (off|on)

Default Value: off

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ethernet">
      <flow-control>
      <config>
        <enable-snd>off</enable-snd> <!-- operation="delete"-->
      </config>
    </flow-control>
  </ethernet>
</interface>
</interfaces>

```

Command Syntax

```
flowcontrol send (off|on)
```

IPI-IF-IP

Configure primary ip addr

Use this attribute to specify that an IP address and prefix length will be used by this interface. If the secondary parameter is not specified, this attribute overwrites the primary IP address. If the secondary parameter is specified, this attribute adds a new IP address to the interface. The secondary address cannot be configured in the absence of a primary IP address. The primary address cannot be removed when a secondary address is present.

Attribute Name: primary-ip-addr

Attribute Type: string

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ipv4 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
      <config>
        <primary-ip-addr>A.B.C.D/M|A.B.C.D A.B.C.D</primary-ip-addr> <!--
operation="delete"-->
      </config>
    </ipv4>
  </interface>
</interfaces>
```

Command Syntax

```
ip address (A.B.C.D/M|A.B.C.D A.B.C.D)
```

Configure enable dhcp ip address

Use this attribute to specify that a DHCP client will be used to obtain an IP address for an interface.

Attribute Name: enable-dhcp-ip-address

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ipv4 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
      <config>
        </enable-dhcp-ip-address><!-- operation="delete"-->
      </config>
    </ipv4>
  </interface>
</interfaces>
```

```

    </config>
  </ipv4>
</interface>
</interfaces>

```

Command Syntax

```
ip address dhcp
```

Configure ip addr label

Label of this address.

Attribute Name: ip-addr-label

Attribute Type: string

Default Value: NULL

Attribute Name: primary-ip-addr

Attribute Type: string

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ipv4 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
      <config>
        <primary-ip-addr>A.B.C.D/M|A.B.C.D A.B.C.D</primary-ip-addr> <!--
operation="delete"-->
        <ip-addr-label>LINE</ip-addr-label> <!-- operation="delete"-->
      </config>
    </ipv4>
  </interface>
</interfaces>

```

Command Syntax

```
ip address (A.B.C.D/M|A.B.C.D A.B.C.D) label LINE
```

Configure ipv4 unnumbered if name

This attribute is used to Enable IP processing without an explicit address

Attribute Name: ipv4-unnumbered-if-name

Attribute Type: string

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>

```

```
<config>
  <name>IFNAME</name>
</config>
<ipv4 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
  <config>
    <ipv4-unnumbered-if-name>IFNAME</ipv4-unnumbered-if-name> <!--
operation="delete"-->
  </config>
</ipv4>
</interface>
</interfaces>
```

Command Syntax

```
ip unnumbered IFNAME
```

Configure remote address

This attribute is used to set the remote address of the PPP link

Attribute Name: remote-address

Attribute Type: string

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ipv4 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
      <config>
        <remote-address>A.B.C.D/M</remote-address> <!-- operation="delete"-->
      </config>
    </ipv4>
  </interface>
</interfaces>
```

Command Syntax

```
ip remote-address A.B.C.D/M
```

Configure primary anycast

Use this attribute to set the anycast flag for the IPv4 primary address of an interface.

Attribute Name: primary-anycast

Attribute Type: empty

Attribute Name: primary-ip-addr

Attribute Type: string

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ipv4 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
      <config>
        <primary-ip-addr>A.B.C.D/M|A.B.C.D A.B.C.D</primary-ip-addr> <!--
operation="delete"-->
        </primary-anycast><!-- operation="delete"-->
      </config>
    </ipv4>
  </interface>
</interfaces>

```

Command Syntax

```
ip address (A.B.C.D/M|A.B.C.D A.B.C.D) anycast
```

Configure ip address

Use this attribute to specify a secondary IP address that will be used by this interface. The secondary address cannot be configured in the absence of a primary IP address. The primary address cannot be removed when a secondary address is present.

Attribute Name: ip-address

Attribute Type: string

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ipv4 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
      <secondary-addresses> <!-- operation="delete"-->
        <ip-address>A.B.C.D/M|A.B.C.D A.B.C.D</ip-address>
        <config>
          <ip-address>A.B.C.D/M|A.B.C.D A.B.C.D</ip-address>
        </config>
      </secondary-addresses>
    </ipv4>
  </interface>
</interfaces>

```

Command Syntax

```
ip address (A.B.C.D/M|A.B.C.D A.B.C.D) secondary
```

Configure ip label

Use this attribute to specify a descriptive label for this IPv4 address.

Attribute Name: ip-label

Attribute Type: string

Default Value: NULL

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ipv4 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
      <secondary-addresses>
        <ip-address>A.B.C.D/M|A.B.C.D A.B.C.D</ip-address>
        <config>
          <ip-address>A.B.C.D/M</ip-address>
          </config>
          <ip-label>LINE</ip-label> <!-- operation="delete"-->
        </secondary-addresses>
      </ipv4>
    </interface>
  </interfaces>
```

Command Syntax

```
ip address (A.B.C.D/M|A.B.C.D A.B.C.D) secondary label LINE
```

Configure secondary anycast

Use this attribute to set the anycast flag for the IPv4 secondary address of an interface.

Attribute Name: secondary-anycast

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ipv4 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
      <secondary-addresses>
        <ip-address>A.B.C.D/M|A.B.C.D A.B.C.D</ip-address>
        <config>
          <ip-address>A.B.C.D/M</ip-address>
          </config>
        </secondary-addresses>
      </ipv4>
    </interface>
  </interfaces>
```



```

        </secondary-anycast><!-- operation="delete"-->
    </secondary-addresses>
</ipv4>
</interface>
</interfaces>

```

Command Syntax

```
ip address (A.B.C.D/M|A.B.C.D A.B.C.D) secondary anycast
```

Configure ipv6 unnumbered if name

Use this attribute to enable IP processing without an explicit address

This command is supported when following feature are enabled IPV6 feature

Attribute Name: ipv6-unnumbered-if-name

Attribute Type: string

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
    <name>IFNAME</name>
    <config>
        <name>IFNAME</name>
    </config>
    <ipv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
    <config>
        <ipv6-unnumbered-if-name>IFNAME</ipv6-unnumbered-if-name> <!--
operation="delete"-->
    </config>
    </ipv6>
</interface>
</interfaces>

```

Command Syntax

```
ipv6 unnumbered IFNAME
```

Configure enable dhcp ipv6 address

Use this attribute to specify that a DHCP client will be used to obtain an IP address for an interface.

This command is supported when following feature are enabled IPV6 feature

Attribute Name: enable-dhcp-ipv6-address

Attribute Type: empty

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
    <name>IFNAME</name>
    <config>

```

```
    <name>IFNAME</name>
  </config>
  <ipv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
    <config>
      </enable-dhcp-ipv6-address><!-- operation="delete"-->
    </config>
  </ipv6>
</interface>
</interfaces>
```

Command Syntax

```
ipv6 address dhcp
```

Configure enable dhcp temporary ipv6 address

Use this attribute to specify that a DHCP client will be used to obtain an temporary IP address for an interface.

This command is supported when following feature are enabled IPV6 feature

Attribute Name: enable-dhcp-temporary-ipv6-address

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ipv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
      <config>
        </enable-dhcp-temporary-ipv6-address><!-- operation="delete"-->
      </config>
    </ipv6>
  </interface>
</interfaces>
```

Command Syntax

```
ipv6 address dhcp temporary
```

Configure dhcp address prefix length

Use this attribute to configure the prefix length for the dynamically learnt ipv6 address

This command is supported when following feature are enabled IPV6 feature

Attribute Name: dhcp-address-prefix-length

Attribute Type: uint8

Attribute Range: 1-128

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <ipv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
    <config>
      <dhcp-address-prefix-length>1</dhcp-address-prefix-length> <!--
operation="delete"-->
    </config>
  </ipv6>
</interface>
</interfaces>
```

Command Syntax

```
ipv6 dhcp address-prefix-length <1-128>
```

Configure enable auto config

Use this attribute to enable autoconfiguration of IPv6 address in host interface. IPv6 address are formed using the Prefix learned from RA and suffix formed using EUI-64 method.

This command is supported when following feature are enabled IPV6 feature

Attribute Name: enable-auto-config

Attribute Type: boolean

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <ipv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
    <config>
      <enable-auto-config>true</enable-auto-config> <!-- operation="delete"-->
    </config>
  </ipv6>
</interface>
</interfaces>
```

Command Syntax

```
ipv6 address autoconfig
```

Configure ipv6 address

Use this attribute to set the IPv6 address of an interface

This command is supported when following feature are enabled IPV6 feature

Attribute Name: ipv6-address

Attribute Type: string

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <ipv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
    <addresses> <!-- operation="delete"-->
      <ipv6-address>X:X::X:X/M</ipv6-address>
      <config>
        <ipv6-address>X:X::X:X/M</ipv6-address>
      </config>
    </addresses>
  </ipv6>
</interface>
</interfaces>
```

Command Syntax

```
ipv6 address X:X::X:X/M
```

Configure anycast

Use this attribute to set the anycast flag for the IPv6 address of an interface. Anycast flag cannot be deleted for an IPv6 address once set. Please delete IPv6 address and reconfigure to remove anycast property.

This command is supported when following feature are enabled IPV6 feature

Attribute Name: anycast

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <ipv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
    <addresses>
      <ipv6-address>X:X::X:X/M</ipv6-address>
      <config>
        <ipv6-address>X:X::X:X/M</ipv6-address>
      </config>
      </anycast><!-- operation="delete"-->
    </addresses>
```

```
</ipv6>  
</interface>  
</interfaces>
```

Command Syntax

```
ipv6 address X:X::X:X/M anycast
```

Configure disable ip forwarding

Enable IP forwarding for the router

Attribute Name: disable-ip-forwarding

Attribute Type: uint8

Netconf edit-config payload

```
<ip-global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">  
<config>  
  </disable-ip-forwarding><!-- operation="delete"-->  
</config>  
</ip-global>
```

Command Syntax

```
no ip forwarding
```

Configure disable ipv6 forwarding

Enable IPv6 forwarding for the router

Attribute Name: disable-ipv6-forwarding

Attribute Type: uint8

Netconf edit-config payload

```
<ip-global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">  
<config>  
  </disable-ipv6-forwarding><!-- operation="delete"-->  
</config>  
</ip-global>
```

Command Syntax

```
no ipv6 forwarding
```

Configure router id

Router id of the router - an unsigned 32-bit integer expressed in dotted quad notation

Attribute Name: router-id

Attribute Type: string

Netconf edit-config payload

```
<ip-global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
```

```
<config>
  <router-id>A.B.C.D</router-id> <!-- operation="delete"-->
</config>
</ip-global>
```

Command Syntax

```
router-id A.B.C.D
```

Configure enable auto router id selection

Turn on Automatic Selection of Router ID

Attribute Name: enable-auto-router-id-selection

Attribute Type: empty

Netconf edit-config payload

```
<ip-global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
<config>
  </enable-auto-router-id-selection><!-- operation="delete"-->
</config>
</ip-global>
```

Command Syntax

```
automatic-router-id-selection enable
```

Configure default vrf enable icmp broadcast

This attribute is used to control ICMP echo broadcast reply. It ignores ICMP echo broadcast when set to true

Attribute Name: default-vrf-enable-icmp-broadcast

Attribute Type: empty

Netconf edit-config payload

```
<ip-global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
<config>
  </default-vrf-enable-icmp-broadcast><!-- operation="delete"-->
</config>
</ip-global>
```

Command Syntax

```
ip icmp-broadcast
```

Configure disable ip vrf forwarding

Turn on IP forwarding for the VRF instance

Attribute Name: disable-ip-vrf-forwarding

Attribute Type: uint8

Netconf edit-config payload

```
<ip-global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
<vrf>
  <vrf-name>NAME</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  </disable-ip-vrf-forwarding><!-- operation="delete"-->
</vrf>
</ip-global>
```

Command Syntax

```
no ip forwarding vrf NAME
```

Configure disable ipv6 vrf forwarding

Turn on IPv6 forwarding for the VRF instance

Attribute Name: disable-ipv6-vrf-forwarding

Attribute Type: uint8

Netconf edit-config payload

```
<ip-global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
<vrf>
  <vrf-name>NAME</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  </disable-ipv6-vrf-forwarding><!-- operation="delete"-->
</vrf>
</ip-global>
```

Command Syntax

```
no ipv6 forwarding vrf NAME
```

Configure enable icmp broadcast

This attribute is used to control ICMP echo broadcast reply for VRF instance. It ignores ICMP echo broadcast when set to true

This command is supported when following feature are enabled Virtual routing and forwarding

Attribute Name: enable-icmp-broadcast

Attribute Type: empty

Netconf edit-config payload

```
<ip-global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ip">
<vrf>
  <vrf-name>NAME</vrf-name>
  <config>
```

```
    <vrf-name>NAME</vrf-name>
  </config>
  </enable-icmp-broadcast><!-- operation="delete"-->
</vrf>
</ip-global>
```

Command Syntax

```
ip icmp-broadcast vrf NAME
```

IPI-IF-EXTENDED

Configure group index

This attribute specifies the port group number

This command is supported when following feature are enabled dune feature,hal feature and following feature are disabled swfwd feature

Attribute Name: group-index

Attribute Type: uint8

Attribute Range: 1-64

Attribute Name: group-speed

Attribute Type: enum (1g|10g|25g|40g|50g|100g)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <port-group-speed-map <!-- operation="delete"-->
    <group-index>1</group-index>
  </port-group-speed-map>
  <config>
    <group-index>1</group-index>
    <group-speed>1g</group-speed>
  </config>
</interfaces>
```

Command Syntax

```
port-group <1-64> speed (1g|10g|25g|40g|50g|100g)
```

Configure protected port

Attribute to change port protectedtype value

Attribute Name: protected-port

Attribute Type: enum (community|isolated|promiscuous)

Default Value: promiscuous

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <config>
      <protected-port>promiscuous</protected-port>
    </config>
  </extended>
</interface>
</interfaces>
```

Command Syntax

```
switchport protected (isolated|promiscuous)
```

Configure name

Attribute to change port protectedtype value

Attribute Name: protected-port

Attribute Type: enum (community|isolated|promiscuous)

Default Value: promiscuous

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <config>
      <protected-port>promiscuous</protected-port>
    </config>
  </extended>
</interface>
</interfaces>
```

Command Syntax

```
switchport protected (community|isolated|promiscuous)
```

Configure link flap error disable

This object specifies whether the interface is enabled for link-flap error-disable or not. If this is '0', then interface is not enabled. Otherwise it is enabled.

Attribute Name: link-flap-error-disable

Attribute Type: uint8

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <config>
        </link-flap-error-disable><!-- operation="delete"-->
      </config>
    </extended>
  </interface>
</interfaces>
```

Command Syntax

```
no link-flap errdisable
```

Configure mac move limit error disable

This object specifies whether the interface is enabled for mac-move-limit error-disable or not. If this is '0', then interface is not enabled. Otherwise it is enabled.

Attribute Name: mac-move-limit-error-disable

Attribute Type: uint8

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <config>
        </mac-move-limit-error-disable><!-- operation="delete"-->
      </config>
    </extended>
  </interface>
</interfaces>
```

Command Syntax

```
no mac-move-limit errdisable
```

Configure disable snmp trap link status

This Object is used to set the snmp trap link status in an interface

Attribute Name: disable-snmp-trap-link-status

Attribute Type: uint8

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <config>
        </disable-snmp-trap-link-status><!-- operation="delete"-->
      </config>
    </extended>
  </interface>
</interfaces>
```

Command Syntax

```
no snmp trap link-status
```

Configure mau default type

This attribute is used to set the mau type in an interface

Attribute Name: mau-default-type

Attribute Type: enum

(dot3MauType10BaseTHD|dot3MauType10BaseTFD|dot3MauType100BaseTXHD|dot3MauType100BaseTXFD|dot3MauType1000BaseXHD|dot3MauType1000BaseXFD|dot3MauType10GigBaseCX4|dot3MauType10GbaseKX4|dot3MauType10GbaseKR|dot3MauType40GbaseCR4)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <config>
        <mau-default-type>dot3MauType10BaseTHD</mau-default-type> <!--
operation="delete"-->
      </config>
    </extended>
  </interface>
</interfaces>
```

Command Syntax

```
mau-default-type
(dot3MauType10BaseTHD|dot3MauType10BaseTFD|dot3MauType100BaseTXHD|dot3MauType100
```

```
BaseTXFD|dot3MauType1000BaseXHD|dot3MauType1000BaseXFD|dot3MauType10GigBaseCX4|d
ot3MauType10GbaseKX4|dot3MauType10GbaseKR|dot3MauType40GbaseCR4)
```

Configure debounce time

Use this attribute to set the interface debounce timer value

Attribute Name: debounce-time

Attribute Type: uint16

Attribute Range: 250-5000

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
  <config>
    <debounce-time>250</debounce-time> <!-- operation="delete"-->
  </config>
</extended>
</interface>
</interfaces>
```

Command Syntax

```
debounce-time <250-5000>
```

Configure enable re routing

Enable re-routing when the bandwidth crosses down the minimum bandwidth

Attribute Name: enable-re-routing

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
  <bandwidth-management>
  <config>
    </enable-re-routing><!-- operation="delete"-->
  </config>
</bandwidth-management>
</extended>
```

```
</interface>
</interfaces>
```

Command Syntax

```
re-routing
```

Configure enable speed

This object is used to enable port-monitoring for the specified parameters, average speed of the interface

Attribute Name: enable-speed

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <port-monitor>
      <config>
        </enable-speed><!-- operation="delete"-->
      </config>
    </port-monitor>
  </extended>
</interface>
</interfaces>
```

Command Syntax

```
monitor speed
```

Configure enable queue drops

This object is used to enable queue-drops of the interface

Attribute Name: enable-queue-drops

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <port-monitor>
      <config>
```

```
        </enable-queue-drops><!-- operation="delete"-->
    </config>
</port-monitor>
</extended>
</interface>
</interfaces>
```

Command Syntax

```
monitor queue-drops
```

Configure warning threshold

This object is used to specify warning threshold for port speed monitor. Warning threshold must be greater than recovery threshold. Default value of warning-threshold is 90.

Attribute Name: warning-threshold

Attribute Type: uint8

Attribute Range: 1-100

Attribute Name: recovery-threshold

Attribute Type: uint8

Attribute Range: 1-100

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <port-monitor>
        <port-monitor-threshold>
          <config>
            <recovery-threshold>1</recovery-threshold>
            <warning-threshold>1</warning-threshold>
          </config>
        </port-monitor-threshold>
      </port-monitor>
    </extended>
  </interface>
</interfaces>
```

Command Syntax

```
monitor speed threshold warning <1-100> recovery <1-100>
```

Configure subif service queue

This attribute specifies the sub interface queue type

This command is supported when following feature are enabled subinterface feature

Attribute Name: subif-service-queue

Attribute Type: enum (physical|flow-id)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <service-queue>
        <config>
          <subif-service-queue>physical</subif-service-queue> <!--
operation="delete"-->
        </config>
      </service-queue>
    </extended>
  </interface>
</interfaces>
```

Command Syntax

```
service-queue (physical|flow-id)
```

Configure aclif type

Use this attribute to set the Hardware timestamp

Attribute Name: aclif-type

Attribute Type: enum (failover|no-failover)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <aclif>
        <config>
          <aclif-type>failover</aclif-type> <!-- operation="delete"-->
        </config>
      </aclif>
    </extended>
  </interface>
</interfaces>
```

Command Syntax

```
aclif (failover|no-failover)
```

Configure encap default

Use this attribute to configure encapsulation as default

This command is supported when following feature are enabled subinterface feature

Attribute Name: encap-default

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <subinterface-encapsulation>
        <config>
          </encap-default><!-- operation="delete"-->
        </config>
      </subinterface-encapsulation>
    </extended>
  </interface>
</interfaces>
```

Command Syntax

```
encapsulation default
```

Configure encap untagged

Use this attribute to configure encapsulation as untagged

This command is supported when following feature are enabled subinterface feature

Attribute Name: encap-untagged

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <subinterface-encapsulation>
        <config>
```



```

        </encap-untagged><!-- operation="delete"-->
    </config>
</subinterface-encapsulation>
</extended>
</interface>
</interfaces>

```

Command Syntax

```
encapsulation untagged
```

Configure vlan action

The textual name of the interface. The value of this object should be the name of the interface as assigned by the local device and should be suitable for use in commands entered at the device's 'console'. This might be a text name, such as 'le0' or a simple port number, such as '1', depending on the interface naming syntax of the device. If several entries in the ifTable together represent a single interface as named by the device, then each will have the same value of name. Note that for an agent which responds to SNMP queries concerning an interface on some other (proxied) device, then the value of name for such an interface is the proxied device's local name for it. If there is no local name, or this object is otherwise not applicable, then this object contains a zero-length string.

Attribute Name: name

Attribute Type: string

Attribute Name: vlan-action

Attribute Type: enum (pop|push|translate)

Attribute Name: push-tpid

Attribute Type: union

Attribute Name: push-outer-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface> <!-- operation="delete"-->
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
  <extended>
    <subinterface-encapsulation>
      <rewrite>
        <config>
          <vlan-action>pop</vlan-action>
          <push-tpid>dot1q</push-tpid>
          <push-outer-vlan-id>1</push-outer-vlan-id>
        </config>
      </rewrite>
    </subinterface-encapsulation>
  </extended>

```

```
</interface>  
</interfaces>
```

Command Syntax

```
rewrite (push) (dot1q|dot1ad|TPID) <1-4094>
```

Configure push tpid

The textual name of the interface. The value of this object should be the name of the interface as assigned by the local device and should be suitable for use in commands entered at the device's 'console'. This might be a text name, such as 'le0' or a simple port number, such as '1', depending on the interface naming syntax of the device. If several entries in the ifTable together represent a single interface as named by the device, then each will have the same value of name. Note that for an agent which responds to SNMP queries concerning an interface on some other (proxied) device, then the value of name for such an interface is the proxied device's local name for it. If there is no local name, or this object is otherwise not applicable, then this object contains a zero-length string.

Attribute Name: name

Attribute Type: string

Attribute Name: vlan-action

Attribute Type: enum (pop|push|translate)

Attribute Name: push-tpid

Attribute Type: enum (dot1q|dot1ad)

Attribute Name: push-outer-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: push-inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">  
<interface> <!-- operation="delete"-->  
  <name>IFNAME</name>  
  <config>  
    <name>IFNAME</name>  
  </config>  
<extended>  
<subinterface-encapsulation>  
<rewrite>  
<config>  
  <vlan-action>pop</vlan-action>  
  <push-tpid>dot1q</push-tpid>  
  <push-outer-vlan-id>1</push-outer-vlan-id>  
  <push-inner-vlan-id>inner-dot1q</push-inner-vlan-id>  
  </config>  
</rewrite>  
</subinterface-encapsulation>
```

```

</extended>
</interface>
</interfaces>

```

Command Syntax

```
rewrite (push) (dot1q|dot1ad) <1-4094> inner-dot1q <1-4094>
```

Configure rewrite translate action

The textual name of the interface. The value of this object should be the name of the interface as assigned by the local device and should be suitable for use in commands entered at the device's 'console'. This might be a text name, such as 'le0' or a simple port number, such as '1', depending on the interface naming syntax of the device. If several entries in the ifTable together represent a single interface as named by the device, then each will have the same value of name. Note that for an agent which responds to SNMP queries concerning an interface on some other (proxied) device, then the value of name for such an interface is the proxied device's local name for it. If there is no local name, or this object is otherwise not applicable, then this object contains a zero-length string.

Attribute Name: name

Attribute Type: string

Attribute Name: vlan-action

Attribute Type: enum (pop|push|translate)

Attribute Name: rewrite-translate-action

Attribute Type: enum (1-to-1|1-to-2|2-to-2|2-to-1)

Attribute Name: dot1q-dot1ad-tpid

Attribute Type: union

Attribute Name: outer-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface> <!-- operation="delete"-->
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
  <extended>
  <subinterface-encapsulation>
  <rewrite>
  <config>
    <vlan-action>pop</vlan-action>
    <rewrite-translate-action>1-to-1</rewrite-translate-action>
    <dot1q-dot1ad-tpid>dot1q</dot1q-dot1ad-tpid>
    <outer-vlan-id>1</outer-vlan-id>
  </config>
  </rewrite>
  </subinterface-encapsulation>

```

```
</extended>  
</interface>  
</interfaces>
```

Command Syntax

```
rewrite (translate) (1-to-1) (dot1q|dot1ad|TPID) <1-4094>
```

Configure dot1q dot1ad tpid

The textual name of the interface. The value of this object should be the name of the interface as assigned by the local device and should be suitable for use in commands entered at the device's 'console'. This might be a text name, such as 'le0' or a simple port number, such as '1', depending on the interface naming syntax of the device. If several entries in the ifTable together represent a single interface as named by the device, then each will have the same value of name. Note that for an agent which responds to SNMP queries concerning an interface on some other (proxied) device, then the value of name for such an interface is the proxied device's local name for it. If there is no local name, or this object is otherwise not applicable, then this object contains a zero-length string.

Attribute Name: name

Attribute Type: string

Attribute Name: vlan-action

Attribute Type: enum (pop|push|translate)

Attribute Name: rewrite-translate-action

Attribute Type: enum (1-to-1|1-to-2|2-to-2|2-to-1)

Attribute Name: dot1q-dot1ad-tpid

Attribute Type: enum (dot1q|dot1ad)

Attribute Name: outer-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: i-dot1q-dot1ad-tpid

Attribute Type: union

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">  
<interface> <!-- operation="delete"-->  
  <name>IFNAME</name>  
  <config>  
    <name>IFNAME</name>  
  </config>  
</interface>  
</interfaces>  
<subinterface-encapsulation>  
<rewrite>  
</rewrite>  
</subinterface-encapsulation>
```

```

    <vlan-action>pop</vlan-action>
      <rewrite-translate-action>1-to-1</rewrite-translate-action>
        <dot1q-dot1ad-tpid>dot1q</dot1q-dot1ad-tpid>
          <outer-vlan-id>1</outer-vlan-id>
            <i-dot1q-dot1ad-tpid>dot1q</i-dot1q-dot1ad-tpid>
              <inner-vlan-id>1</inner-vlan-id>
            </config>
          </rewrite>
        </subinterface-encapsulation>
      </extended>
    </interface>
  </interfaces>

```

Command Syntax

```
rewrite (translate) (1-to-2) (dot1q|dot1ad) <1-4094> (dot1q|TPID) <1-4094>
```

Configure outer vlan id

The textual name of the interface. The value of this object should be the name of the interface as assigned by the local device and should be suitable for use in commands entered at the device's 'console'. This might be a text name, such as 'le0' or a simple port number, such as '1', depending on the interface naming syntax of the device. If several entries in the ifTable together represent a single interface as named by the device, then each will have the same value of name. Note that for an agent which responds to SNMP queries concerning an interface on some other (proxied) device, then the value of name for such an interface is the proxied device's local name for it. If there is no local name, or this object is otherwise not applicable, then this object contains a zero-length string.

Attribute Name: name

Attribute Type: string

Attribute Name: vlan-action

Attribute Type: enum (pop|push|translate)

Attribute Name: rewrite-translate-action

Attribute Type: enum (1-to-1|1-to-2|2-to-2|2-to-1)

Attribute Name: dot1q-dot1ad-tpid

Attribute Type: enum (dot1q|dot1ad)

Attribute Name: outer-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: i-dot1q-dot1ad-tpid

Attribute Type: enum (dot1q)

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
```

```
<interface> <!-- operation="delete"-->
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
<extended>
<subinterface-encapsulation>
<rewrite>
<config>
  <vlan-action>pop</vlan-action>
  <rewrite-translate-action>1-to-1</rewrite-translate-action>
  <dot1q-dot1ad-tpid>dot1q</dot1q-dot1ad-tpid>
  <outer-vlan-id>1</outer-vlan-id>
  <i-dot1q-dot1ad-tpid>dot1q</i-dot1q-dot1ad-tpid>
  <inner-vlan-id>1</inner-vlan-id>
</config>
</rewrite>
</subinterface-encapsulation>
</extended>
</interface>
</interfaces>
```

Command Syntax

```
rewrite (translate) (2-to-2) (dot1q|dot1ad) <1-4094> (dot1q) <1-4094>
```

Configure enable pop

This attribute is used to configure pop outer and inner tag. To change the rewrite config, delete and recreate the entire rewrite config.

Attribute Name: enable-pop

Attribute Type: enum (1tag|2tag)

Attribute Name: vlan-action

Attribute Type: enum (pop|push|translate)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <subinterface-encapsulation>
        <rewrite>
          <config>
            <vlan-action>pop</vlan-action>
            <enable-pop>1</enable-pop>
          </config>
        </rewrite>
      </subinterface-encapsulation>
    </extended>
  </interface>
</interfaces>
```

```
</rewrite>
</subinterface-encapsulation>
</extended>
</interface>
</interfaces>
```

Command Syntax

```
rewrite (pop)
```

Configure vlan action

This attribute is used to configure pop outer and inner tag. To change the rewrite config, delete and recreate the entire rewrite config.

Attribute Name: enable-pop

Attribute Type: enum (1tag|2tag)

Attribute Name: vlan-action

Attribute Type: enum (pop|push|translate)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <subinterface-encapsulation>
        <rewrite>
          <config>
            <vlan-action>1</vlan-action>
            <enable-pop>2</enable-pop>
          </config>
        </rewrite>
      </subinterface-encapsulation>
    </extended>
  </interface>
</interfaces>
```

Command Syntax

```
rewrite pop-2tag
```

Configure encapsulation type

This attribute is used to configure the encapsulation type(dot1q/dot1ad).

This command is supported when following feature are enabled subinterface feature

Attribute Name: encapsulation-type

Attribute Type: enum (dot1q|dot1ad)

Attribute Name: outer-vlan-id

Attribute Type: string

Attribute Range: 1-4094

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <subinterface-encapsulation>
      <single-tag-vlan-matches>
        <single-tag-vlan-match> <!-- operation="delete"-->
          <encapsulation-type>dot1q</encapsulation-type>
          <config>
            <encapsulation-type>dot1q</encapsulation-type>
            <outer-vlan-id>VLAN_RANGE2</outer-vlan-id>
          </config>
        </single-tag-vlan-match>
      </single-tag-vlan-matches>
    </subinterface-encapsulation>
  </extended>
</interface>
</interfaces>
```

Command Syntax

```
encapsulation (dot1q|dot1ad) VLAN_RANGE2
```

Configure outer vlan id

This attribute is used to configure the outer VLAN tag as a single value alone

This command is supported when following feature are enabled subinterface feature

Attribute Name: outer-vlan-id

Attribute Type: string

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: string

Attribute Range: 1-4094

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
```



```

    <name>IFNAME</name>
  </config>
  <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <subinterface-encapsulation>
      <double-tag-vlan-matches>
        <double-tag-vlan-match> <!-- operation="delete"-->
          <outer-vlan-id>VLAN_RANGE2</outer-vlan-id>
          <config>
            <outer-vlan-id>1</outer-vlan-id>
            <encap-type>dot1q</encap-type>
            <inner-vlan-id>VLAN_RANGE2</inner-vlan-id>
          </config>
          <encap-type>dot1q</encap-type>
        </double-tag-vlan-match>
      </double-tag-vlan-matches>
    </subinterface-encapsulation>
  </extended>
</interface>
</interfaces>

```

Command Syntax

```
encapsulation (dot1q|dot1ad) VLAN_RANGE2 inner-dot1q VLAN_RANGE2
```

Configure split horizon group

This attribute is used to configure the split-horizon

This command is supported when following feature are enabled subinterface feature and following feature are disabled DNX feature

Attribute Name: split-horizon-group

Attribute Type: enum (network|access1|access2)

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <subinterface-split-horizon>
        <config>
          <split-horizon-group>network</split-horizon-group> <!--
operation="delete"-->
        </config>
      </subinterface-split-horizon>
    </extended>
  </interface>
</interfaces>

```

Command Syntax

```
split-horizon group (network|access1|access2)
```

Configure linkup debounce time

Link debounce timer value for down-up transition

Attribute Name: linkup-debounce-time

Attribute Type: uint16

Attribute Range: 0-5000

Attribute Name: linkdown-debounce-time

Attribute Type: uint16

Attribute Range: 0-5000

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <link-debounce-time>
        <config>
          <linkdown-debounce-time>0</linkdown-debounce-time>
          <linkup-debounce-time>0</linkup-debounce-time>
        </config>
      </link-debounce-time>
    </extended>
  </interface>
</interfaces>
```

Command Syntax

```
link-debounce-time <0-5000> <0-5000>
```

Configure rate

Interface minimum bandwidth

This command is supported when following feature are enabled TE Enabled

Attribute Name: rate

Attribute Type: uint32

Attribute Range: 1-1000000000

Attribute Name: rate-unit

Attribute Type: enum (kbps|mbps|gbps)

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
  <minimum-bandwidth>
  <config>
    <rate-unit>kbps</rate-unit>
    <rate>1</rate>
  </config>
</minimum-bandwidth>
</extended>
</interface>
</interfaces>

```

Command Syntax

```
minimum-bandwidth <1-1000000000> (kbps|mbps|gbps)
```

Configure l2cp type

This attribute is used to configure the layer2 control-protocol type

Attribute Name: l2cp-type

Attribute Type: enum (stp|lacp|dot1x|lldp|efm|elmi|synce)

Attribute Name: protocol-process

Attribute Type: enum (peer|tunnel|discard)

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <extended xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
  <l2-control-protocol> <!-- operation="delete"-->
    <l2cp-type>stp</l2cp-type>
    <config>
      <l2cp-type>stp</l2cp-type>
      <protocol-process>peer</protocol-process>
    </config>
  </l2-control-protocol>
</extended>
</interface>
</interfaces>

```

Command Syntax

```
l2protocol (stp|lacp|dot1x|lldp|efm|elmi|synce) (peer|tunnel|discard)
```

Configure forward err correction

This Object is used to set forward-error-correction to interface

Attribute Name: forward-err-correction

Attribute Type: enum (off|on|auto|on cl74|on cl91)

Default Value: auto

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ethernet">
      <extended-ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
        <config>
          <forward-err-correction>auto</forward-err-correction> <!--
operation="delete"-->
        </config>
      </extended-ethernet>
    </ethernet>
  </interface>
</interfaces>
```

Command Syntax

```
fec (off|on|auto|on cl74|on cl91)
```

Configure load interval

This attribute is used to configure load interval period in multiples of 30 seconds

Attribute Name: load-interval

Attribute Type: uint16

Default Value: 300

Attribute Range: 30-300

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
```

```

    <ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ethernet">
      <extended-ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
        <config>
          <load-interval>30</load-interval> <!-- operation="delete"-->
        </config>
      </extended-ethernet>
    </ethernet>
  </interface>
</interfaces>

```

Command Syntax

```
load-interval <30-300>
```

Configure bcast value

This attribute is used to set the storm control configuration, Set Broadcast Rate Limiting of layer2 Interface

This command is supported when following feature are enabled rate limit feature

Attribute Name: bcast-value

Attribute Type: union

Attribute Name: bcast-rate-limit-format

Attribute Type: enum (level|kbps|mbps|gbps)

Attribute Name: bcast-burst-value

Attribute Type: uint32

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ethernet">
      <storm-control xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
        <broadcast>
          <config>
            <bcast-rate-limit-format>0</bcast-rate-limit-format>
            <bcast-burst-value>1</bcast-burst-value>
            <bcast-value>LEVEL</bcast-value>
          </config>
        </broadcast>
      </storm-control>
    </ethernet>
  </interface>
</interfaces>

```

Command Syntax

```
storm-control broadcast level LEVEL (burst-size <1-33292>|)
```

Configure bcast rate limit format

This attribute is used to set the storm control configuration, Set the format for units in kbps|mbps|gbps or level for threshold percentage

This command is supported when following feature are enabled rate limit feature

Attribute Name: bcast-rate-limit-format

Attribute Type: enum (level|kbps|mbps|gbps)

Attribute Name: bcast-value

Attribute Type: union

Attribute Name: bcast-burst-value

Attribute Type: uint32

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ethernet">
      <storm-control xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
        <broadcast>
          <config>
            <bcast-value>0</bcast-value>
            <bcast-burst-value>1</bcast-burst-value>
            <bcast-rate-limit-format>level</bcast-rate-limit-format>
          </config>
        </broadcast>
      </storm-control>
    </ethernet>
  </interface>
</interfaces>
```

Command Syntax

```
storm-control broadcast <0-4294967294> (kbps|mbps|gbps) (burst-size <1-33292>|)
```

Configure mcast value

This attribute is used to set the storm control configuration, Set Multicast Rate Limiting of layer2 Interface

This command is supported when following feature are enabled rate limit feature

Attribute Name: mcast-value

Attribute Type: union

Attribute Name: mcast-rate-limit-format

Attribute Type: enum (level|kbps|mbps|gbps)

Attribute Name: mcast-burst-value

Attribute Type: uint32

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ethernet">
      <storm-control xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
        <multicast>
          <config>
            <mcast-rate-limit-format>0</mcast-rate-limit-format>
            <mcast-burst-value>1</mcast-burst-value>
            <mcast-value>LEVEL</mcast-value>
          </config>
        </multicast>
      </storm-control>
    </ethernet>
  </interface>
</interfaces>
```

Command Syntax

```
storm-control multicast level LEVEL (burst-size <1-33292>|)
```

Configure mcast rate limit format

This attribute is used to set the storm control configuration, Set the format for units in kbps|mbps|gbps or level for threshold percentage

This command is supported when following feature are enabled rate limit feature

Attribute Name: mcast-rate-limit-format

Attribute Type: enum (level|kbps|mbps|gbps)

Attribute Name: mcast-value

Attribute Type: union

Attribute Name: mcast-burst-value

Attribute Type: uint32

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
```

```
    <name>IFNAME</name>
  </config>
  <ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ethernet">
    <storm-control xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <multicast>
        <config>
          <mcast-value>0</mcast-value>
          <mcast-burst-value>1</mcast-burst-value>
          <mcast-rate-limit-format>level</mcast-rate-limit-format>
        </config>
      </multicast>
    </storm-control>
  </ethernet>
</interface>
</interfaces>
```

Command Syntax

```
storm-control multicast <0-4294967294> (kbps|mbps|gbps) (burst-size <1-33292>|)
```

Configure dlf bcast value

This attribute is used to set the storm control configuration, Set DLF Broadcast Rate Limiting of layer2 Interface

This command is supported when following feature are enabled rate limit feature

Attribute Name: dlf-bcast-value

Attribute Type: union

Attribute Name: dlf-bcast-rate-limit-format

Attribute Type: enum (level|kbps|mbps|gbps)

Attribute Name: dlf-bcast-burst-value

Attribute Type: uint32

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
  <ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ethernet">
    <storm-control xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <dlf-broadcast>
        <config>
          <dlf-bcast-rate-limit-format>0</dlf-bcast-rate-limit-format>
          <dlf-bcast-burst-value>1</dlf-bcast-burst-value>
          <dlf-bcast-value>LEVEL</dlf-bcast-value>
        </config>
      </dlf-broadcast>
    </storm-control>
```



```

</ethernet>
</interface>
</interfaces>

```

Command Syntax

```
storm-control dlf level LEVEL (burst-size <1-33292>|)
```

Configure dlf bcast rate limit format

This attribute is used to set the storm control configuration, Set the format for units in kbps|mbps|gbps or level for threshold percentage

This command is supported when following feature are enabled rate limit feature

Attribute Name: dlf-bcast-rate-limit-format

Attribute Type: enum (level|kbps|mbps|gbps)

Attribute Name: dlf-bcast-value

Attribute Type: union

Attribute Name: dlf-bcast-burst-value

Attribute Type: uint32

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <ethernet xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-ethernet">
      <storm-control xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
        <dlf-broadcast>
          <config>
            <dlf-bcast-value>0</dlf-bcast-value>
            <dlf-bcast-burst-value>1</dlf-bcast-burst-value>
            <dlf-bcast-rate-limit-format>level</dlf-bcast-rate-limit-format>
          </config>
        </dlf-broadcast>
      </storm-control>
    </ethernet>
  </interface>
</interfaces>

```

Command Syntax

```
storm-control dlf <0-4294967294> (kbps|mbps|gbps) (burst-size <1-33292>|)
```

Configure error disable stp bpdu guard

This object is used to configure error disable STP BPDU Guard

Attribute Name: error-disable-stp-bpdu-guard

Attribute Type: boolean

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <error-disable>
      <config>
        <error-disable-stp-bpdu-guard>true</error-disable-stp-bpdu-guard> <!--
operation="delete"-->
      </config>
    </error-disable>
  </global>
</interfaces>
```

Command Syntax

```
no errdisable cause stp-bpdu-guard
```

Configure reason

This object is to enable various error-disable reasons like lag-mismatch, stp-bpdu-guard, link-flap and loopback-detection. As the datatype is BITS, 0th bit corresponds to lag-mismatch, 1st bit corresponds to stp-bpdu-guard, 2nd bit corresponds to link-flap

Attribute Name: reason

Attribute Type: bits (lag-mismatch|link-flap|mac-move-limit)

Attribute Name: error-disable-stp-bpdu-guard

Attribute Type: boolean

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <error-disable>
      <config>
        <error-disable-stp-bpdu-guard>true</error-disable-stp-bpdu-guard> <!--
operation="delete"-->
        <reason>lag-mismatch</reason> <!-- operation="delete"-->
      </config>
    </error-disable>
  </global>
</interfaces>
```

Command Syntax

```
errdisable cause stp-bpdu-guard {lag-mismatch|link-flap|mac-move-limit}
```

Configure link flap timer interval

This object is configure timer interval for link-flap timer

Attribute Name: link-flap-timer-interval

Attribute Type: uint32

Attribute Range: 1-1800

Attribute Name: link-flap-max-count

Attribute Type: uint32

Attribute Range: 1-100

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <error-disable>
      <config>
        <link-flap-max-count>1</link-flap-max-count> <!-- operation="delete"-->
        <link-flap-timer-interval>1</link-flap-timer-interval> <!--
operation="delete"-->
      </config>
    </error-disable>
  </global>
</interfaces>
```

Command Syntax

```
errdisable link-flap-setting max-flaps <1-100> time <1-1800>
```

Configure timeout interval

This object is to configure timeout for error-disable automatic recovery timer

Attribute Name: timeout-interval

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-1000000

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <error-disable>
      <config>
        <timeout-interval>0</timeout-interval> <!-- operation="delete"-->
      </config>
    </error-disable>
  </global>
</interfaces>
```

Command Syntax

```
errdisable timeout interval <0-1000000>
```

Configure mac move limit

This object configures threshold for mac movement

Attribute Name: mac-move-limit

Attribute Type: uint32

Default Value: 100

Attribute Range: 1-1000

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <error-disable>
      <config>
        <mac-move-limit>1</mac-move-limit> <!-- operation="delete"-->
      </config>
    </error-disable>
  </global>
</interfaces>
```

Command Syntax

```
errdisable mac-move-limit <1-1000>
```

Configure mode

This attribute is used to unset the tunnel mode

This command is supported when following feature are enabled tunnel feature

Attribute Name: mode

Attribute Type: enum (vxlan)

Default Value: vxlan

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <tunnel xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <config>
        <mode>vxlan</mode> <!-- operation="delete"-->
      </config>
    </tunnel>
  </interface>
</interfaces>
```

Command Syntax

```
tunnel mode (vxlan)
```

Configure src

This attribute is used to set tunnel source

This command is supported when following feature are enabled tunnel feature

Attribute Name: src

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <tunnel xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <config>
        <src>A.B.C.D</src> <!-- operation="delete"-->
      </config>
    </tunnel>
  </interface>
</interfaces>
```

Command Syntax

```
tunnel source A.B.C.D
```

Configure multicast interface

This attribute is used to configure egress multicast interface for tunnel

This command is supported when following feature are enabled tunnel feature

Attribute Name: multicast-interface

Attribute Type: string

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <tunnel xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <config>
        <multicast-interface>IFNAME</multicast-interface> <!--
operation="delete"-->
      </config>
    </tunnel>
  </interface>
</interfaces>
```

Command Syntax

```
tunnel egress-multicast-interface IFNAME
```

Configure dst

This attribute is used to set destination of tunnel packets

This command is supported when following feature are enabled tunnel feature

Attribute Name: dst

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <tunnel xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <config>
        <dst>A.B.C.D</dst> <!-- operation="delete"-->
      </config>
    </tunnel>
  </interface>
</interfaces>
```

Command Syntax

```
tunnel destination A.B.C.D
```

Configure checksum enable

This attribute is used to enable end to end checksumming of packets

This command is supported when following feature are enabled tunnel feature

Attribute Name: checksum-enable

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <tunnel xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
      <config>
        </checksum-enable><!-- operation="delete"-->
      </config>
    </tunnel>
  </interface>
</interfaces>
```

```
</interface>
</interfaces>
```

Command Syntax

```
tunnel checksum
```

Configure tos byte

This attribute is used to set type of service byte

This command is supported when following feature are enabled tunnel feature

Attribute Name: tos-byte

Attribute Type: uint16

Attribute Range: 0-255

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <tunnel xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <config>
      <tos-byte>0</tos-byte> <!-- operation="delete"-->
    </config>
  </tunnel>
</interface>
</interfaces>
```

Command Syntax

```
tunnel tos <0-255>
```

Configure ttl

This attribute is used to set time to live

This command is supported when following feature are enabled tunnel feature

Attribute Name: ttl

Attribute Type: uint16

Attribute Range: 1-255

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
```

```
</config>
<tunnel xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
<config>
    <t1>1</t1> <!-- operation="delete"-->
</config>
</tunnel>
</interface>
</interfaces>
```

Command Syntax

```
tunnel ttl <1-255>
```

Configure path mtu enable

This attribute is used to enable Path MTU Discovery on tunnel

This command is supported when following feature are enabled tunnel feature

Attribute Name: path-mtu-enable

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
    <name>IFNAME</name>
    <config>
        <name>IFNAME</name>
    </config>
    <tunnel xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <config>
        </path-mtu-enable><!-- operation="delete"-->
    </config>
</tunnel>
</interface>
</interfaces>
```

Command Syntax

```
tunnel path-mtu-discovery
```

Configure dst mac address

This attribute is used to set next Hop Destination MAC Address of Tunnel Packets

This command is supported when following feature are enabled tunnel feature

Attribute Name: dst-mac-address

Attribute Type: string

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
```



```

    <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <tunnel xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
  <config>
    <dst-mac-address>MAC</dst-mac-address> <!-- operation="delete"-->
  </config>
</tunnel>
</interface>
</interfaces>

```

Command Syntax

```
tunnel dmac MAC
```

Configure gre key

This attribute is used to set the gre-key for tunnel

This command is supported when following feature are enabled tunnel feature

Attribute Name: gre-key

Attribute Type: union

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <tunnel xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
    <config>
      <gre-key>IF_TUNNEL_KEY_T</gre-key>
    </config>
  </tunnel>
</interface>
</interfaces>

```

Command Syntax

```
tunnel key (A.B.C.D|<0-4294967295>)
```

clear interface (IFNAME|) cpu counters

Attribute Name: if-name

Attribute Type: string

Netconf RPC payload

```

<clear-interface-cpu-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">

```

```
<if-name>IFNAME</if-name>
</clear-interface-cpu-counters>
```

Command Syntax

```
clear interface (IFNAME|) cpu counters
```

clear interface (IFNAME|) fec

Attribute Name: if-name

Attribute Type: string

Netconf RPC payload

```
<clear-interface-forward-error-correction-counters xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-if-extended">
  <if-name>IFNAME</if-name>
</clear-interface-forward-error-correction-counters>
```

Command Syntax

```
clear interface (IFNAME|) fec
```

clear interface IFNAME error-disable

Attribute Name: if-name

Attribute Type: string

Netconf RPC payload

```
<clear-interface-error-disable xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
if-extended">
  <if-name>IFNAME</if-name>
</clear-interface-error-disable>
```

Command Syntax

```
clear interface IFNAME error-disable
```

clear l2protocol interface (IFNAME|) counters (peer|tunnel|discard|tunnel- discard|)

Attribute Name: if-name

Attribute Type: string

Attribute Name: protocol

Attribute Type: enum (peer|tunnel|discard|tunnel-discard|all)

Default Value: all

Netconf RPC payload

```
<clear-l2protocol-interface-counter xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-if-extended">
  <if-name>IFNAME</if-name>
```

```
<protocol>all</protocol>
</clear-l2protocol-interface-counter>
```

Command Syntax

```
clear l2protocol interface (IFNAME|) counters (peer|tunnel|discard|tunnel-discard|)
```

no sniff

Attribute Name: interface-name

Attribute Type: string

Netconf RPC payload

```
<interface-sniff-disable xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-extended">
  <interface-name>WORD</interface-name>
</interface-sniff-disable>
```

Command Syntax

```
no sniff
```

IPI-IF-FLOWSPEC

Configure disable

disable FLOWSPEC for an interface

Attribute Name: disable

Attribute Type: empty

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <interface-flowspec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-flowspec">
      <ipv4>
        <flowspec>
          </disable><!-- operation="delete"-->
        </flowspec>
      </ipv4>
    </interface-flowspec>
  </interface>
</interfaces>
```

Command Syntax

```
ipv4 flowspec disable
```

IPI-SYNCE

Configure enable

Use this command to configure Synchronous Ethernet. This command changes the mode from configure mode to configure Synchronous Ethernet mode and initializes the global Synchronous Ethernet parameters.

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
  <globals>
  <config>
    </enable>
  </config>
</globals>
</synce>
```

Command Syntax

```
synce
```

Configure network option

Use this command to set the synchronization option for the internal clock that is locked in frequency to an incoming signal.

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: network-option

Attribute Type: enum (1|2)

Default Value: 1

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
  <globals>
  <config>
    <network-option>1</network-option> <!-- operation="delete"-->
  </config>
</globals>
</synce>
```

Command Syntax

```
synchronization option (1|2)
```

Configure clock selection mode

Use this command to determine whether to use the Quality Level (QL) as a criteria when selecting a clock

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: clock-selection-mode

Attribute Type: enum (ql-enabled|ql-disabled)

Default Value: ql-enabled

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
  <globals>
  <config>
    <clock-selection-mode>ql-enabled</clock-selection-mode> <!-- operation="delete"-->
->
  </config>
</globals>
</synce>
```

Command Syntax

```
clock-selection mode (ql-enabled|ql-disabled)
```

Configure dpll3 select 10mhz in

Use this command to select/deselect dpll3 input

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: dpll3-select-10mhz-in

Attribute Type: empty

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
  <globals>
  <config>
    </dpll3-select-10mhz-in><!-- operation="delete"-->
  </config>
</globals>
</synce>
```

Command Syntax

```
dpll3-select 10mhz-in
```

Configure holdover timer

set this command to enable synce holdover (default 120 min)

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: holdover-timer

Attribute Type: uint16

Default Value: 120

Attribute Range: 0-1440

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
  <globals>
  <config>
    <holdover-timer>0</holdover-timer> <!-- operation="delete"-->
  </config>
</globals>
</synce>
```

Command Syntax

```
holdover <0-1440>
```

Configure name

Use this command to enable Synchronous Ethernet for an interface. This command changes the mode from interface mode to interface Synchronous Ethernet mode. This command does not automatically start synchronization distribution. You must explicitly give the mode command, specifying the synchronous option

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
  <interfaces>
  <interface>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
    </enable>
  </interface>
</interfaces>
</synce>
```

Command Syntax

```
synce
```

Configure synchronous mode

Use this command to configure the interface as synchronous or non-synchronous

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: synchronous-mode

Attribute Type: enum (synchronous|non-synchronous)

Default Value: non-synchronous

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <synchronous-mode>non-synchronous</synchronous-mode> <!-- operation="delete"-->
</interface>
</interfaces>
</synce>
```

Command Syntax

```
mode (synchronous|non-synchronous)
```

Configure input source priority

Use this command to set an input timing source. Synchronization packets are received from this source and sent to the clock selection algorithm

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: input-source-priority

Attribute Type: uint8

Default Value: 255

Attribute Range: 0-255

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <input-source-priority>0</input-source-priority> <!-- operation="delete"-->
</interface>
</interfaces>
</synce>
```

Command Syntax

```
input-source <0-255>
```

Configure is output source

Use this command to configures an Ethernet interface as a timing output interface

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: is-output-source

Attribute Type: boolean

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <is-output-source>true</is-output-source> <!-- operation="delete"-->
</interface>
</interfaces>
</synce>
```

Command Syntax

```
output-source
```

Configure wait to restore timer

Use this command to set the wait-to-restore timer in minutes. The wait-to-restore time ensures that a synchronization source that previously failed is considered by the selection process again only if it is fault free for a certain time.

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: wait-to-restore-timer

Attribute Type: uint8

Default Value: 5

Attribute Range: 0-12

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <wait-to-restore-timer>0</wait-to-restore-timer> <!-- operation="delete"-->
</interface>
</interfaces>
</synce>
```

Command Syntax

```
wait-to-restore <0-12>
```

Configure vlan id

use this command to configure and unconfigure the dot1q 1-4095

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <vlan-id>1</vlan-id> <!-- operation="delete"-->
</interface>
</interfaces>
</synce>
```

Command Syntax

```
dot1q <1-4095>
```

Configure hold off timer

Use this command to set the hold-off time in milliseconds. The hold-off time ensures that short activation of signal fail is not passed to the selection process.

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: hold-off-timer

Attribute Type: uint16

Default Value: 300

Attribute Range: 300-1800

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <hold-off-timer>300</hold-off-timer> <!-- operation="delete"-->
</interface>
</interfaces>
</synce>
```

Command Syntax

```
hold-off <300-1800>
```

Configure quality level

Use this command to set the quality level (QL) for the timing source

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: quality-level

Attribute Type: string

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <quality-level>QL_VAL</quality-level> <!-- operation="delete"-->
    </interface>
  </interfaces>
</synce>
```

Command Syntax

```
quality-level QL_VAL
```

Configure clock source id

Configure clock-source-identifier

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: clock-source-id

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <clock-source-id>1</clock-source-id> <!-- operation="delete"-->
    </interface>
  </interfaces>
</synce>
```

Command Syntax

```
clock-source-id <1-255>
```

Configure auto neg mode

Use this command to configure mode

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: auto-neg-mode

Attribute Type: enum (master|slave)

Netconf edit-config payload

```
<sync xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sync">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <auto-neg-mode>master</auto-neg-mode> <!-- operation="delete"-->
    </interface>
  </interfaces>
</sync>
```

Command Syntax

```
base-t (master|slave)
```

Configure external sync interface

sync external interface name

Attribute Name: external-sync-interface

Attribute Type: enum (gps|10mhz-in|ptp|bits-t1|bits-e1|2mhz-in|bits-t1-1|bits-t1-2|bits-t1-3|bits-e1-1|bits-e1-2|bits-e1-3)

Netconf edit-config payload

```
<sync xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sync">
  <external-interfaces>
    <external-interface> <!-- operation="delete"-->
      <external-sync-interface>gps</external-sync-interface>
      <config>
        <external-sync-interface>gps</external-sync-interface>
      </config>
    </external-interface>
  </external-interfaces>
</sync>
```

Command Syntax

```
sync-interface (gps|10mhz-in|ptp|2mhz-in)
```

Configure options

Use this Attribute to set or unset the SyncE debug related configurations

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: options

Attribute Type: bits (event|recvd|trans|all)

Netconf edit-config payload

```
<synce xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
  <debug>
    <config>
      <options>event</options> <!-- operation="delete"-->
    </config>
  </debug>
</synce>
```

Command Syntax

```
debug synce (event|recvd|trans|all)
```

clear synce stats (interface IFNAME|)

Attribute Name: interface-name

Attribute Type: string

Netconf RPC payload

```
<clear-synce-stats xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
  <interface-name>IFNAME</interface-name>
</clear-synce-stats>
```

Command Syntax

```
clear synce stats (interface IFNAME|)
```

debug synce (event|recvd|trans|all)

Attribute Name: debug-options

Attribute Type: bits (event|recvd|trans|all)

Netconf RPC payload

```
<synce-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
  <debug-options>event</debug-options>
</synce-terminal-debug-on>
```

Command Syntax

```
debug synce (event|recvd|trans|all)
```

no debug synce (event|recvd|trans|all)

Attribute Name: debug-options

Attribute Type: bits (event|recvd|trans|all)

Netconf RPC payload

```
<synce-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-synce">
  <debug-options>event</debug-options>
</synce-terminal-debug-off>
```

Command Syntax

```
no debug synce (event|recvd|trans|all)
```

IPI-SYSTEM

Configure hostname

Use this command to set the network name for the device. OcNOS uses this name in system prompts and default configuration filenames. Setting a host name using this command also sets the host name in the kernel. After giving the hostname command, you must write to memory using the write command. If you do not write to memory, the change made by this command (the new host name) is not set after the device reboots.

Attribute Name: hostname

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<system-info xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-system">
  <config>
    <hostname>WORD</hostname> <!-- operation="delete"-->
  </config>
</system-info>
```

Command Syntax

```
hostname WORD
```

Configure timezone name

The attribute display timezone name used for the system

Attribute Name: timezone-name

Attribute Type: string

Netconf edit-config payload

```
<system-info xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-system">
  <clock>
```

```
<config>
  <timezone-name>WORD</timezone-name> <!-- operation="delete"-->
</config>
</clock>
</system-info>
```

Command Syntax

```
clock timezone WORD
```

IPI-NETWORK-SERVICES-MANAGER

Configure options

Use this attribute to debug nsm

Attribute Name: options

Attribute Type: bits (addressmonitor|bfd|events|hal events|hal ipc|linkmonitor|packet|packet detail|packet rcv|packet rcv detail|packet send|packet send detail|vxlan|ipsec|mpls|all)

Netconf edit-config payload

```
<network-services-manager xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
services-manager">
  <debug>
    <nsm>
      <config>
        <options>addressmonitor</options> <!-- operation="delete"-->
      </config>
    </nsm>
  </debug>
</network-services-manager>
```

Command Syntax

```
debug nsm ((addressmonitor|bfd|events|hal events|hal ipc|linkmonitor|packet|packet
  detail|packet rcv|packet rcv detail|packet send|packet send
  detail|vxlan|ipsec|mpls|all) |)
```

Configure module name

Use this attribute to set debug HSL module

This command is supported when following feature are enabled HSL feature

Attribute Name: module-name

Attribute Type: enum

(general|ifmgr|bridge|msg|fib|fdb|devdrv|pktdrv|platform|pbr|bfd|lacp|qos|helper|rbridge|nvo|ofl|mlag|mpls|srv6|ptp|extp
hy)

Attribute Name: level

Attribute Type: bits (all|default|info|debug|warn|error|fatal|admin|counter|pkt)

Netconf edit-config payload

```

<network-services-manager xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
services-manager">
  <debug>
  <hsl>
  <hsl-module> <!-- operation="delete"-->
    <module-name>general</module-name>
    <config>
      <module-name>general</module-name>
      <level>all</level>
    </config>
  </hsl-module>
</hsl>
</debug>
</network-services-manager>

```

Command Syntax

```

debug hsl
  (general|ifmgr|bridge|msg|fib|fdb|devdrv|pktdrv|platform|pbr|bfd|lacp|qos|helper
  |rbridge|nvo|ofl|mlag|mpls|srv6|ptp|extphy)
  {all|default|info|debug|warn|error|fatal|admin|counter|pkt}

```

debug nsm ((addressmonitor|bfd|events|hal events|hal ipc|linkmonitor|packet|packet detail|packet rcv|packet rcv detail|packet send|packet send detail|vxlan|ipsec|mpls|all))

Attribute Name: terminal-debug-options

Attribute Type: bits (addressmonitor|bfd|events|hal events|hal ipc|linkmonitor|packet|packet detail|packet rcv|packet rcv detail|packet send|packet send detail|vxlan|ipsec|mpls|all)

Netconf RPC payload

```

<nsm-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
services-manager">
  <terminal-debug-options>addressmonitor</terminal-debug-options>
</nsm-terminal-debug-on>

```

Command Syntax

```

debug nsm ((addressmonitor|bfd|events|hal events|hal ipc|linkmonitor|packet|packet
  detail|packet rcv|packet rcv detail|packet send|packet send
  detail|vxlan|ipsec|mpls|all))

```

no debug nsm ((addressmonitor|bfd|events|hal events|hal ipc|linkmonitor|packet|packet detail|packet rcv|packet rcv detail|packet send|packet send detail|vxlan|ipsec|mpls|all))

Attribute Name: terminal-debug-options

Attribute Type: bits (addressmonitor|bfd|events|hal events|hal ipc|linkmonitor|packet|packet detail|packet rcv|packet rcv detail|packet send|packet send detail|vxlan|ipsec|mpls|all)

Netconf RPC payload

```
<nsm-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
services-manager">
  <terminal-debug-options>addressmonitor</terminal-debug-options>
</nsm-terminal-debug-off>
```

Command Syntax

```
no debug nsm ((addressmonitor|bfd|events|hal events|hal
ipc|linkmonitor|packet|packet detail|packet rcv|packet rcv detail|packet
send|packet send detail|vxlan|ipsec|mpls|all) |)
```

debug hsl

**(general|ifmgr|bridge|msg|fib|fdb|devdrv|pktdrv|platform|pbr|bfd|lacp|qos|help
er|rbridge|nvo|ofl|mlag|mpls|srv6|ptp|extphy)**
{all|default|info|debug|warn|error|fatal|admin|counter|pkt}

Attribute Name: module-name

Attribute Type: enum

(general|ifmgr|bridge|msg|fib|fdb|devdrv|pktdrv|platform|pbr|bfd|lacp|qos|helper|rbridge|nvo|ofl|mlag|mpls|srv6|ptp|extphy)

Attribute Name: level

Attribute Type: bits (all|default|info|debug|warn|error|fatal|admin|counter|pkt)

Netconf RPC payload

```
<hsl-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
services-manager">
  <module-name>general</module-name>
  <level>all</level>
</hsl-terminal-debug-on>
```

Command Syntax

```
debug hsl
  (general|ifmgr|bridge|msg|fib|fdb|devdrv|pktdrv|platform|pbr|bfd|lacp|qos|helper
|rbridge|nvo|ofl|mlag|mpls|srv6|ptp|extphy)
{all|default|info|debug|warn|error|fatal|admin|counter|pkt}
```

no debug hsl

**(general|ifmgr|bridge|msg|fib|fdb|devdrv|pktdrv|platform|pbr|bfd|lacp|qos|help
er|rbridge|nvo|ofl|mlag|mpls|srv6|ptp|extphy)**
{all|default|info|debug|warn|error|fatal|admin|counter|pkt}

Attribute Name: module-name

Attribute Type: enum

(general|ifmgr|bridge|msg|fib|fdb|devdrv|pktdrv|platform|pbr|bfd|lacp|qos|helper|rbridge|nvo|ofl|mlag|mpls|srv6|ptp|extphy)

Attribute Name: level

Attribute Type: bits (all|default|info|debug|warn|error|fatal|admin|counter|pkt)

Netconf RPC payload

```
<hsl-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
services-manager">
  <module-name>general</module-name>
  <level>all</level>
</hsl-terminal-debug-off>
```

Command Syntax

```
no debug hsl
  (general|ifmgr|bridge|msg|fib|fdb|devdrv|pktdrv|platform|pbr|bfd|lACP|qos|helper
  |rbridge|nvo|ofl|mLag|mpls|srv6|ptp|extphy)
  {all|default|info|debug|warn|error|fatal|admin|counter|pkt}
```

debug pktmgr (l2 protocol cfm|l2 protocol eapol|l2 protocol efm|l2 protocol igmp-snoop|l2 protocol lacp|l2 protocol lldp|l2 protocol mldp-snoop|l2 protocol mstp|l2 protocol ptp|l2 protocol all)

Attribute Name: terminal-debug-options

Attribute Type: bits (l2 protocol cfm|l2 protocol eapol|l2 protocol efm|l2 protocol igmp-snoop|l2 protocol lacp|l2 protocol lldp|l2 protocol mldp-snoop|l2 protocol mstp|l2 protocol ptp|l2 protocol all)

Netconf RPC payload

```
<pktmgr-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
network-services-manager">
  <terminal-debug-options>l2 protocol cfm</terminal-debug-options>
</pktmgr-terminal-debug-on>
```

Command Syntax

```
debug pktmgr (l2 protocol cfm|l2 protocol eapol|l2 protocol efm|l2 protocol igmp-
snoop|l2 protocol lacp|l2 protocol lldp|l2 protocol mldp-snoop|l2 protocol
mstp|l2 protocol ptp|l2 protocol all)
```

no debug pktmgr

Netconf RPC payload

```
<pktmgr-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
network-services-manager"/>
```

Command Syntax

```
no debug pktmgr
```

debug pktmgr enable

Netconf RPC payload

```
<pktmgr-debug-statistics-enable xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
network-services-manager"/>
```

Command Syntax

```
debug pktmgr enable
```

debug pktmgr disable

Netconf RPC payload

```
<pktmgr-debug-statistics-disable xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-network-services-manager"/>
```

Command Syntax

```
debug pktmgr disable
```

debug pktmgr stats

Netconf RPC payload

```
<pktmgr-debug-statistics-get xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
network-services-manager"/>
```

Command Syntax

```
debug pktmgr stats
```

debug pktmgr (stats|pkt-errors)

Attribute Name: debug-error-statistics

Attribute Type: enum (stats|pkt-errors)

Netconf RPC payload

```
<pktmgr-debug-error-statistics-get xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-network-services-manager">
  <debug-error-statistics>stats</debug-error-statistics>
</pktmgr-debug-error-statistics-get>
```

Command Syntax

```
debug pktmgr (stats|pkt-errors)
```

clear nsm ipc stats

Netconf RPC payload

```
<clear-nsm-ipc-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
network-services-manager"/>
```

Command Syntax

```
clear nsm ipc stats
```

snmp restart nsm

Netconf RPC payload

```
<nsm-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-services-manager"/>
```

Command Syntax

```
snmp restart nsm
```

IPI-BRIDGE

Configure protocol

Bridge protocol type

Attribute Name: protocol

Attribute Type: enum (ieee|ieee vlan-bridge|rstp|rstp vlan-bridge|mstp|provider-rstp|provider-mstp|rstp ring|mstp ring|provider-rstp edge|provider-mstp edge|rstp vlan-bridge ring)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-instance">
  <network-instance>
    <instance-name>l</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <config>
        <protocol>ieee</protocol>
      </config>
    </bridge>
  </network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> protocol (ieee|ieee vlan-bridge|rstp|rstp vlan-bridge|mstp|rstp ring|mstp ring|rstp vlan-bridge ring)
```

Configure instance name

Bridge protocol type

Attribute Name: protocol

Attribute Type: enum (ieee|ieee vlan-bridge|rstp|rstp vlan-bridge|mstp|provider-rstp|provider-mstp|rstp ring|mstp ring|provider-rstp edge|provider-mstp edge|rstp vlan-bridge ring)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <config>
        <protocol>ieee</protocol>
      </config>
    </bridge>
  </network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> protocol (ieee|ieee vlan-bridge|rstp|rstp vlan-bridge|mstp|provider-
rstp|provider-mstp|rstp ring|mstp ring|provider-rstp edge|provider-mstp edge|rstp
vlan-bridge ring)
```

Configure disable dynamic learning

Network Instance Name. For VRF and MAC VRF, instance name can be up to 32 chars long. For VPWS and VPLS instances, instance name can be up to 128 chars long. For L2NI (bridge) instance, instance name has to be a number between (1-32). For Cross-Connect, instance name can be up to 30 chars long. For Bridge-domain, instance, instance name has to be a number between (1-2147483647).

Attribute Name: instance-name

Attribute Type: string

Attribute Name: disable-dynamic-learning

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-type>vrf</instance-type>
    <config>
      <instance-type>vrf</instance-type>
      <instance-name>WORD</instance-name>
    </config>
    <instance-name>WORD</instance-name>
  <bridge>
    <config>
      </disable-dynamic-learning>
    </config>
  </bridge>
```

```
</network-instance>
</network-instances>
```

Command Syntax

```
no bridge <1-32> acquire
```

Configure l2 protocol destination mac

This attribute changes L2 protocol destination MAC

Attribute Name: l2-protocol-destination-mac

Attribute Type: string

Default Value: 0100.C2CD.CDD0

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <config>
        <l2-protocol-destination-mac>XXXX.XXXX.XXXX</l2-protocol-destination-mac>
      <!-- operation="delete"-->
      </config>
    </bridge>
  </network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> l2protocol encapsulation dest-mac XXXX.XXXX.XXXX
```

Configure dot1ad encapsulation

Configure to use encapsulated dot1ad value for switching and routing by bridge ports

Attribute Name: dot1ad-encapsulation

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
```

```
    <instance-type>l2ni</instance-type>
  </config>
  <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
  <config>
    </dotlad-encapsulation><!-- operation="delete"-->
  </config>
</bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> encapsulation dotlad
```

Configure spanning tree protocol status

Attribute specifies to enable/disable Spanning Tree Protocol on a interface

Attribute Name: spanning-tree-protocol-status

Attribute Type: enum (enable|disable)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <bridge-ports>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <spanning-tree-protocol-status>enable</spanning-tree-protocol-status>
    </interface>
    </bridge-ports>
    </bridge>
  </network-instance>
</network-instances>
```

Command Syntax

```
bridge-group <1-32> (spanning-tree (enable|disable) |)
```

Configure disable mac learning

Use this attribute to disable MAC learning on a interface

Attribute Name: disable-mac-learning

Attribute Type: uint8

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>l</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <fdb>
      <interfaces>
      <interface>
        <interface-name>IFNAME</interface-name>
        <config>
          <interface-name>WORD</interface-name>
        </config>
        </disable-mac-learning><!-- operation="delete"-->
      </interface>
    </interfaces>
    </fdb>
  </bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
no mac-address-table learning bridge <1-32> interface IFNAME
```

Configure interface name

The textual name of the interface

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-33

Attribute Name: action

Attribute Type: enum (discard|forward)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
```

```
<network-instance>
  <instance-name>1</instance-name>
  <config>
    <instance-name>WORD</instance-name>
    <instance-type>l2ni</instance-type>
  </config>
  <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <fdb>
      <static-mac-table>
        <entry>
          <mac-address>XXXX.XXXX.XXXX</mac-address>
          <config>
            <mac-address>XXXX.XXXX.XXXX</mac-address>
            <action>discard</action>
          </config>
          <interface-name>IFNAME</interface-name>
        </entry>
      </static-mac-table>
    </fdb>
  </bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> address XXXX.XXXX.XXXX (discard|forward) IFNAME
```

clear mac address-table (multicast) cvlan VID svlan VID bridge <1-32>

Attribute Name: mac-type

Attribute Type: enum (multicast)

Attribute Name: cvlan-id

Attribute Type: uint16

Attribute Name: svlan-id

Attribute Type: uint16

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<bridge-clear-provider-edge-mac-address-table xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-bridge">
  <mac-type>multicast</mac-type>
  <cvlan-id>VID</cvlan-id>
  <svlan-id>VID</svlan-id>
  <bridge-id>1</bridge-id>
</bridge-clear-provider-edge-mac-address-table>
```


Command Syntax

```
clear mac address-table (multicast) cvlan VID svlan VID bridge <1-32>
```

clear mac address-table (multicast) (interface IFNAME|) (address MACADDR|) (vlan VID|) bridge <1-32>

Attribute Name: mac-type

Attribute Type: enum (multicast)

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-33

Attribute Name: mac-address

Attribute Type: string

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<bridge-clear-mac-address-table xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
  <mac-type>multicast</mac-type>
  <interface-name>IFNAME</interface-name>
  <mac-address>MACADDR</mac-address>
  <vlan-id>VID</vlan-id>
  <bridge-id>1</bridge-id>
</bridge-clear-mac-address-table>
```

Command Syntax

```
clear mac address-table (multicast) (interface IFNAME|) (address MACADDR|) (vlan VID|) bridge <1-32>
```

clear mac address-table dynamic cvlan VID svlan VID bridge <1-32>

Attribute Name: cvlan-id

Attribute Type: uint16

Attribute Name: svlan-id

Attribute Type: uint16

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<bridge-clear-provider-edge-dynamic-mac-address-table xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
```

```
<cvlan-id>VID</cvlan-id>  
<svlan-id>VID</svlan-id>  
<bridge-id>1</bridge-id>  
</bridge-clear-provider-edge-dynamic-mac-address-table>
```

Command Syntax

```
clear mac address-table dynamic cvlan VID svlan VID bridge <1-32>
```

clear mac address-table dynamic (interface IFNAME|) (address MACADDR|) (vlan VID|) bridge <1-32>

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-33

Attribute Name: mac-address

Attribute Type: string

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<bridge-clear-dynamic-mac-address-table xmlns="http://www.ipinfusion.com/yang/  
ocnos/ipi-bridge">  
  <interface-name>IFNAME</interface-name>  
  <mac-address>MACADDR</mac-address>  
  <vlan-id>VID</vlan-id>  
  <bridge-id>1</bridge-id>  
</bridge-clear-dynamic-mac-address-table>
```

Command Syntax

```
clear mac address-table dynamic (interface IFNAME|) (address MACADDR|) (vlan VID|)  
  bridge <1-32>
```

clear mac address-table dynamic interface IFNAME instance INST bridge <1-32>

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-33

Attribute Name: instance-id

Attribute Type: uint32

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```

    <bridge-clear-mstp-port-dynamic-mac-address-table xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <interface-name>IFNAME</interface-name>
    <instance-id>INST</instance-id>
    <bridge-id>1</bridge-id>
    </bridge-clear-mstp-port-dynamic-mac-address-table>

```

Command Syntax

```
clear mac address-table dynamic interface IFNAME instance INST bridge <1-32>
```

IPI-VLAN

Configure disable mac learning

Use attribute to disable mac address learning

Attribute Name: disable-mac-learning

Attribute Type: uint8

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <vlans xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vlan">
        <vlan>
          <vlan-id>VLAN_RANGE</vlan-id>
          <config>
            <vlan-id>VLAN_RANGE</vlan-id>
            </config>
            </disable-mac-learning><!-- operation="delete"-->
          </vlan>
        </vlans>
      </bridge>
    </network-instance>
  </network-instances>

```

Command Syntax

```
no mac-address-table learning bridge <1-32> vlan VLAN_RANGE
```

Configure vlan id

Vlan identifier

Attribute Name: vlan-id

Attribute Type: string

Attribute Range: 2-4094

Attribute Name: type

Attribute Type: enum (customer)

Attribute Name: name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: state

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <vlans xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vlan">
      <vlan <!-- operation="delete"-->
        <vlan-id>VLAN_RANGE</vlan-id>
        <config>
          <vlan-id>VLAN_RANGE</vlan-id>
        </config>
        <customer-vlan>
          <config>
            <type>customer</type>
            <name>WORD</name>
            <state>disable</state>
          </config>
        </customer-vlan>
      </vlan>
    </vlans>
  </bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
vlan VLAN_RANGE (type (customer)|) bridge <1-32> (name WORD|) (state
(disable|enable)|)
```

Configure type

Vlan identifier

Attribute Name: vlan-id

Attribute Type: string

Attribute Range: 2-4094

Attribute Name: type

Attribute Type: enum (point-point|multipoint-multipoint|rooted-multipoint)

Attribute Name: state

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <vlans xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vlan">
        <vlan <!-- operation="delete"-->
          <vlan-id>VLAN_RANGE</vlan-id>
          <config>
            <vlan-id>VLAN_RANGE</vlan-id>
          </config>
          <service-vlan>
            <config>
              <type>point-point</type>
              <state>disable</state>
            </config>
          </service-vlan>
        </vlan>
      </vlans>
    </bridge>
  </network-instance>
</network-instances>
```

Command Syntax

```
vlan VLAN_RANGE type service (point-point|multipoint-multipoint|rooted-multipoint)
bridge <1-32> (state (disable|enable)|)
```

Configure instance name

Vlan identifier

Attribute Name: vlan-id

Attribute Type: string

Attribute Range: 2-4094

Attribute Name: type

Attribute Type: enum (point-point|multipoint-multipoint|rooted-multipoint)

Attribute Name: name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: state

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <vlans xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vlan">
      <vlan <!-- operation="delete"-->
        <vlan-id>VLAN_RANGE</vlan-id>
        <config>
          <vlan-id>VLAN_RANGE</vlan-id>
        </config>
        <service-vlan>
          <config>
            <type>point-point</type>
            <name>WORD</name>
            <state>disable</state>
          </config>
        </service-vlan>
      </vlan>
    </vlans>
  </bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
vlan VLAN_RANGE type service (point-point|multipoint-multipoint|rooted-multipoint)
  bridge <1-32> name WORD (state (disable|enable)|)
```

Configure instance type

private vlan type

Attribute Name: type

Attribute Type: enum (community|isolated|primary)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>l</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <vlans xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vlan">
        <vlan>
          <vlan-id>VLAN_RANGE</vlan-id>
          <config>
            <vlan-id>VLAN_RANGE</vlan-id>
          </config>
          <private-vlan>
            <config>
              <type>community</type>
            </config>
          </private-vlan>
        </vlan>
      </vlans>
    </bridge>
  </network-instance>
</network-instances>
```

Command Syntax

```
private-vlan <2-4094> (community|isolated|primary) bridge <1-32>
```

Configure secondary vlan

Use this attribute to configure associated secondary vlan for private vlan

Attribute Name: secondary-vlan

Attribute Type: string

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <vlans xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vlan">
      <vlan>
        <vlan-id>VLAN_RANGE</vlan-id>
        <config>
          <vlan-id>VLAN_RANGE</vlan-id>
        </config>
        <private-vlan>
          <association>
            <config>
              <secondary-vlan>VLAN_ID</secondary-vlan> <!-- operation="delete"-->
            </config>
          </association>
        </private-vlan>
      </vlan>
    </vlans>
  </bridge>
</network-instance>
</network-instances>

```

Command Syntax

```
private-vlan <2-4094> association add VLAN_ID bridge <1-32>
```

Configure mac address

Use this attribute to configure classifier for given MAC address

This command is supported when following feature are enabled VLAN Classifier feature

Attribute Name: mac-address

Attribute Type: string

Netconf edit-config payload

```

<vlan-classifier xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vlan">
  <classifier-rules>
    <classifier-rule>
      <rule-id>1</rule-id>
      <config>
        <rule-id>1</rule-id>
      </config>
    </rule-criteria>

```



```

<config>
  <mac-address>WORD</mac-address> <!-- operation="delete"-->
</config>
</rule-criteria>
</classifier-rule>
</classifier-rules>
</vlan-classifier>

```

Command Syntax

```
vlan classifier rule <1-256> mac WORD
```

Configure ipv4 address

Use this attribute to configure classifier for given IPv4 address

This command is supported when following feature are enabled VLAN Classifier feature

Attribute Name: ipv4-address

Attribute Type: string

Netconf edit-config payload

```

<vlan-classifier xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vlan">
  <classifier-rules>
    <classifier-rule>
      <rule-id>1</rule-id>
      <config>
        <rule-id>1</rule-id>
      </config>
    </rule-criteria>
  </config>
  <ipv4-address>A.B.C.D/M</ipv4-address> <!-- operation="delete"-->
</config>
</rule-criteria>
</classifier-rule>
</classifier-rules>
</vlan-classifier>

```

Command Syntax

```
vlan classifier rule <1-256> ipv4 A.B.C.D/M
```

Configure ether type

Use this attribute to configure classifier for protocols based on Ethertype value

This command is supported when following feature are enabled VLAN Classifier feature

Attribute Name: ether-type

Attribute Type: union

Netconf edit-config payload

```
<vlan-classifier xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vlan">
```

```

<classifier-rules>
<classifier-rule>
  <rule-id>1</rule-id>
  <config>
    <rule-id>1</rule-id>
  </config>
<rule-criteria>
<config>
  <ether-type>VLAN_CLASSIFIER_ETHERTYPE_T</ether-type>
</config>
</rule-criteria>
</classifier-rule>
</classifier-rules>
</vlan-classifier>

```

Command Syntax

```

vlan classifier rule <1-256> proto
  (ETHERTYPE|ip|x25|arp|g8bpqx25|ieeepup|ieeeeaddrtrans|dec|decndadumpload|decndare
  moteconsole|decndarouting|declat|decdiagnostics|rarp|atalkddp|atalkaarp|ipx|ipv6
  |atmmulti|pppdiscovery|pppsession|atmtransport)

```

Configure group id

Classifier group ID

Attribute Name: group-id

Attribute Type: uint8

Attribute Range: 1-16

Netconf edit-config payload

```

<vlan-classifier xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vlan">
<classifier-groups>
<classifier-group> <!-- operation="delete"-->
  <rule-id>1</rule-id>
  <config>
    <rule-id>1</rule-id>
    <group-id>1</group-id>
  </config>
  <group-id>1</group-id>
</classifier-group>
</classifier-groups>
</vlan-classifier>

```

Command Syntax

```

vlan classifier group <1-16> add rule <1-256>

```

Configure port name

VLAN classifier group ID

Attribute Name: group-id

Attribute Type: uint8

Attribute Range: 1-16

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 2-4094

Netconf edit-config payload

```
<vlan-classifier xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vlan">
  <ports>
    <port> <!-- operation="delete"-->
      <group-id>1</group-id>
      <config>
        <group-id>1</group-id>
        <port-name>WORD</port-name>
        <vlan-id>2</vlan-id>
      </config>
      <port-name>WORD</port-name>
    </port>
  </ports>
</vlan-classifier>
```

Command Syntax

```
vlan classifier activate <1-16> vlan <2-4094>
```

Configure disable vlan classifier feature

Use this command to enable or disable VLAN classifier feature.

Attribute Name: disable-vlan-classifier-feature

Attribute Type: uint8

Netconf edit-config payload

```
<layer2-global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vlan">
  <config>
    </disable-vlan-classifier-feature><!-- operation="delete"-->
  </config>
</layer2-global>
```

Command Syntax

```
no feature vlan classifier
```

Configure disable port security

Use this attribute to disable or enable port-security globally.

Attribute Name: disable-port-security

Attribute Type: uint8

Netconf edit-config payload

```
<layer2-global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vlan">
  <config>
    </disable-port-security>
  </config>
</layer2-global>
```

Command Syntax

```
port-security disable
```

Configure table name

Use this to configure the name of the CVLAN registration table.

Attribute Name: table-name

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <cvlan-registration-tables xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
vlan">
      <cvlan-registration-table> <!-- operation="delete"-->
        <table-name>WORD</table-name>
        <config>
          <table-name>WORD</table-name>
        </config>
      </cvlan-registration-table>
    </cvlan-registration-tables>
  </bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
cvlan registration table WORD bridge <1-32>
```

Configure svlan id

Service VLAN ID in registration table

This command is supported when following feature are enabled VLAN feature, Provider Bridging feature

Attribute Name: svlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Attribute Name: translated-cvlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <cvlan-registration-tables xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
vlan">
        <cvlan-registration-table>
          <table-name>WORD</table-name>
          <config>
            <table-name>WORD</table-name>
          </config>
          <cvlan-mappings>
            <cvlan-mapping>
              <cvlan-id>VLAN_RANGE2</cvlan-id>
              <config>
                <cvlan-id>VLAN_RANGE2</cvlan-id>
                <svlan-id>1</svlan-id>
                <translated-cvlan-id>1</translated-cvlan-id>
              </config>
              <svlan-id>1</svlan-id>
            </cvlan-mapping>
          </cvlan-mappings>
        </cvlan-registration-table>
      </cvlan-registration-tables>
    </bridge>
  </network-instance>
</network-instances>
```

Command Syntax

```
cvlan VLAN_RANGE2 cvlan <1-4095> svlan <1-4095>
```

Configure cvlan id

Service VLAN ID in registration table

This command is supported when following feature are enabled VLAN feature, Provider Bridging feature

Attribute Name: svlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <cvlan-registration-tables xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
vlan">
      <cvlan-registration-table>
        <table-name>WORD</table-name>
        <config>
          <table-name>WORD</table-name>
        </config>
        <cvlan-mappings>
          <cvlan-mapping>
            <cvlan-id>VLAN_RANGE2</cvlan-id>
            <config>
              <cvlan-id>VLAN_RANGE2</cvlan-id>
              <svlan-id>1</svlan-id>
            </config>
            <svlan-id>1</svlan-id>
          </cvlan-mapping>
        </cvlan-mappings>
      </cvlan-registration-table>
    </cvlan-registration-tables>
  </bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
cvlan VLAN_RANGE2 svlan <1-4095>
```

Configure cos to queue

Name of CoS to queue profile to map to CVLAN ID

This command is supported when following feature are enabled VLAN feature, Provider Bridging feature

Attribute Name: cos-to-queue

Attribute Type: string

Attribute Name: translated-cvlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Attribute Name: remark-cos

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <cvlan-registration-tables xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
vlan">
      <cvlan-registration-table>
        <table-name>WORD</table-name>
        <config>
          <table-name>WORD</table-name>
        </config>
        <cvlan-mappings>
          <cvlan-mapping>
            <cvlan-id>VLAN_RANGE2</cvlan-id>
            <config>
              <cvlan-id>VLAN_RANGE2</cvlan-id>
              <svlan-id>1</svlan-id>
              <translated-cvlan-id>1</translated-cvlan-id>
              </remark-cos>
            </config>
            <svlan-id>1</svlan-id>
            <cos-to-queue>NAME</cos-to-queue>
          </cvlan-mapping>
        </cvlan-mappings>
      </cvlan-registration-table>
    </cvlan-registration-tables>
  </bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
cvlan VLAN_RANGE2 cvlan <1-4095> svlan <1-4095> ({ remark-cos | cos-to-queue NAME
})
```

Configure untagged ep

Customer/provider edge port is untagged for specified CVLAN

This command is supported when following feature are enabled VLAN feature, Provider Bridging feature

Attribute Name: untagged-ep

Attribute Type: bits (default|untagged-ep|untagged-cep)

Attribute Name: remark-cos

Attribute Type: empty

Attribute Name: cos-to-queue

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <cvlan-registration-tables xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
vlan">
      <cvlan-registration-table>
        <table-name>WORD</table-name>
        <config>
          <table-name>WORD</table-name>
        </config>
        <cvlan-mappings>
          <cvlan-mapping>
            <cvlan-id>VLAN_RANGE2</cvlan-id>
            <config>
              <cvlan-id>VLAN_RANGE2</cvlan-id>
              <svlan-id>1</svlan-id>
              </remark-cos>
              <cos-to-queue>NAME</cos-to-queue>
            </config>
            <svlan-id>1</svlan-id>
            <untagged-ep>untagged-ep</untagged-ep>
          </cvlan-mapping>
        </cvlan-mappings>
      </cvlan-registration-table>
    </cvlan-registration-tables>
  </bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
cvlan VLAN_RANGE2 svlan <1-4095> ({ remark-cos | cos-to-queue NAME | untagged-
pep | untagged-cep })
```

IPI-PORT-VLAN

Configure isolated vlan id

Isolated VLAN identifier

Attribute Name: isolated-vlan-id

Attribute Type: string

Attribute Range: 2-4094,2-4094

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
      <global>
        <config>
          <isolated-vlan-id>2</isolated-vlan-id> <!-- operation="delete"-->
        </config>
      </global>
    </port-vlan>
  </interface>
</interfaces>
```

Command Syntax

```
switchport (provider-network) isolated-vlan WORD
```

Configure cvlan registration table

cvlan registration table

Attribute Name: cvlan-registration-table

Attribute Type: string

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
      <global>
        <config>
```

```
        <cvlan-registration-table>WORD</cvlan-registration-table> <!--  
operation="delete"-->  
    </config>  
</global>  
</port-vlan>  
</interface>  
</interfaces>
```

Command Syntax

```
switchport (customer-edge) vlan registration WORD
```

Configure interface mode

Set the interface to access or trunk or hybrid mode for VLANs

Attribute Name: interface-mode

Attribute Type: enum (access|hybrid|trunk|customer-network|provider-network|customer-edge access|customer-edge hybrid|customer-edge trunk)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">  
<interface>  
    <name>IFNAME</name>  
    <config>  
        <name>IFNAME</name>  
    </config>  
<port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">  
<switched-vlans>  
<switched-vlan> <!-- operation="delete"-->  
    <interface-mode>access</interface-mode>  
    <config>  
        <interface-mode>access</interface-mode>  
    </config>  
</switched-vlan>  
</switched-vlans>  
</port-vlan>  
</interface>  
</interfaces>
```

Command Syntax

```
switchport mode (access|hybrid|trunk|provider-network|customer-edge  
access|customer-edge hybrid|customer-edge trunk)
```

Configure name

Set the interface to access or trunk or hybrid mode for VLANs

Attribute Name: interface-mode

Attribute Type: enum (access|hybrid|trunk|customer-network|provider-network|customer-edge access|customer-edge hybrid|customer-edge trunk)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
  <switched-vlans>
  <switched-vlan> <!-- operation="delete"-->
    <interface-mode>access</interface-mode>
    <config>
      <interface-mode>access</interface-mode>
    </config>
  </switched-vlan>
</switched-vlans>
</port-vlan>
</interface>
</interfaces>
```

Command Syntax

```
switchport mode (customer-network)
```

Configure acceptable frame type

Use this attribute to set the interface acceptable frame types. This processing occurs after VLAN classification

Attribute Name: acceptable-frame-type

Attribute Type: enum (vlan-tagged|all)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
  <switched-vlans>
  <switched-vlan>
    <interface-mode>access</interface-mode>
    <config>
      <interface-mode>access</interface-mode>
    </config>
    <acceptable-frame-type>all</acceptable-frame-type> <!--
operation="delete"-->
  </switched-vlan>
</switched-vlans>
</port-vlan>
</interface>
```

```
</interfaces>
```

Command Syntax

```
switchport mode (hybrid) acceptable-frame-type (vlan-tagged|all)
```

Configure disable native vlan

Use this attribute to disable native VLAN for the port. Untagged frames will be dropped.

Attribute Name: disable-native-vlan

Attribute Type: uint8

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
  <switched-vlans>
  <switched-vlan>
    <interface-mode>access</interface-mode>
    <config>
      <interface-mode>access</interface-mode>
    </config>
    </disable-native-vlan><!-- operation="delete"-->
  </switched-vlan>
</switched-vlans>
</port-vlan>
</interface>
</interfaces>
```

Command Syntax

```
switchport mode (trunk) disable-native-vlan
```

Configure remove default vlan

Use this attribute to remove default VLAN for the port. Untagged frames will be dropped.

Attribute Name: remove-default-vlan

Attribute Type: uint8

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
```

```

<port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
  <switched-vlans>
    <switched-vlan>
      <interface-mode>access</interface-mode>
      <config>
        <interface-mode>access</interface-mode>
      </config>
      </remove-default-vlan><!-- operation="delete"-->
    </switched-vlan>
  </switched-vlans>
</port-vlan>
</interface>
</interfaces>

```

Command Syntax

```
switchport mode (trunk) remove-default-vlan
```

Configure vlan id

Default VLAN identifier

Attribute Name: vlan-id

Attribute Type: uint16

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
      <switched-vlans>
        <switched-vlan>
          <interface-mode>access</interface-mode>
          <config>
            <interface-mode>access</interface-mode>
          </config>
          <vlans>
            <config>
              <vlan-id>2</vlan-id> <!-- operation="delete"-->
            </config>
          </vlans>
        </switched-vlan>
      </switched-vlans>
    </port-vlan>
  </interface>
</interfaces>

```

Command Syntax

```
switchport (access|hybrid) vlan <2-4094>
```

Configure native vlan id

Native VLAN ID

Attribute Name: native-vlan-id

Attribute Type: uint16

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
      <switched-vlans>
        <switched-vlan>
          <interface-mode>access</interface-mode>
          <config>
            <interface-mode>access</interface-mode>
          </config>
          <vlans>
            <config>
              <native-vlan-id>2</native-vlan-id> <!-- operation="delete"-->
            </config>
          </vlans>
        </switched-vlan>
      </switched-vlans>
    </port-vlan>
  </interface>
</interfaces>
```

Command Syntax

```
switchport (trunk) native vlan <2-4094>
```

Configure translated svlan id

Specifies translated service VLAN identifier

Attribute Name: translated-svlan-id

Attribute Type: uint16

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
```

```

    <name>IFNAME</name>
  </config>
  <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
    <switched-vlans>
      <switched-vlan>
        <interface-mode>access</interface-mode>
        <config>
          <interface-mode>access</interface-mode>
        </config>
        <svlan-translations>
          <svlan-translation>
            <original-svlan-id>VLAN_ID</original-svlan-id>
            <config>
              <original-svlan-id>VLAN_ID</original-svlan-id>
              </config>
              <translated-svlan-id>VLAN_ID</translated-svlan-id> <!--
operation="delete"-->
            </svlan-translation>
          </svlan-translations>
        </switched-vlan>
      </switched-vlans>
    </port-vlan>
  </interface>
</interfaces>

```

Command Syntax

```
switchport (provider-network) vlan translation svlan VLAN_ID svlan VLAN_ID
```

Configure original svlan id

Specifies translated service VLAN identifier

Attribute Name: translated-svlan-id

Attribute Type: uint16

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
      <switched-vlans>
        <switched-vlan>
          <interface-mode>access</interface-mode>
          <config>
            <interface-mode>access</interface-mode>
          </config>
          <svlan-translations>

```

```

    <svlan-translation>
      <original-svlan-id>VLAN_ID</original-svlan-id>
      <config>
        <original-svlan-id>VLAN_ID</original-svlan-id>
      </config>
      <translated-svlan-id>VLAN_ID</translated-svlan-id> <!--
operation="delete"-->
    </svlan-translation>
  </svlan-translations>
</switched-vlan>
</switched-vlans>
</port-vlan>
</interface>
</interfaces>

```

Command Syntax

```
switchport (customer-network) vlan translation svlan VLAN_ID svlan VLAN_ID
```

Configure translated cvlan id

Specifies translated service VLAN identifier

Attribute Name: translated-svlan-id

Attribute Type: uint16

Attribute Name: translated-cvlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
      <switched-vlans>
        <switched-vlan>
          <interface-mode>access</interface-mode>
          <config>
            <interface-mode>access</interface-mode>
          </config>
          <svlan-translations>
            <svlan-translation>
              <original-svlan-id>VLAN_ID</original-svlan-id>
              <config>
                <original-svlan-id>VLAN_ID</original-svlan-id>
                <translated-cvlan-id>1</translated-cvlan-id> <!-- operation="delete"--
            >

```



```

        </config>
        <translated-svlan-id>VLAN_ID</translated-svlan-id> <!--
operation="delete"-->
        </svlan-translation>
    </svlan-translations>
</switched-vlan>
</switched-vlans>
</port-vlan>
</interface>
</interfaces>

```

Command Syntax

```

switchport (provider-network) vlan translation svlan VLAN_ID cvlan <1-4095> svlan
VLAN_ID

```

Configure cvlan id

Specifies translated service VLAN identifier

Attribute Name: translated-svlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
    <name>IFNAME</name>
    <config>
        <name>IFNAME</name>
    </config>
    <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
    <switched-vlans>
    <switched-vlan>
        <interface-mode>access</interface-mode>
        <config>
            <interface-mode>access</interface-mode>
        </config>
        <cvlan-svlan-translations>
        <cvlan-svlan-translation>
            <svlan-id>1</svlan-id>
            <config>
                <svlan-id>1</svlan-id>
                <cvlan-id>1</cvlan-id>
            </config>
            <cvlan-id>1</cvlan-id>
            <translated-svlan-id>1</translated-svlan-id>
        </cvlan-svlan-translation>
        </cvlan-svlan-translations>
    </switched-vlan>
    </switched-vlans>

```

```
</port-vlan>  
</interface>  
</interfaces>
```

Command Syntax

```
switchport (provider-network) vlan translation cvlan <1-4095> svlan <1-4095> svlan  
<1-4095>
```

Configure svlan id

Specifies translated service VLAN identifier

Attribute Name: translated-svlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">  
<interface>  
  <name>IFNAME</name>  
  <config>  
    <name>IFNAME</name>  
  </config>  
<port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">  
<switched-vlans>  
<switched-vlan>  
  <interface-mode>access</interface-mode>  
  <config>  
    <interface-mode>access</interface-mode>  
  </config>  
  <cvlan-svlan-translations>  
  <cvlan-svlan-translation>  
    <svlan-id>1</svlan-id>  
    <config>  
      <svlan-id>1</svlan-id>  
      <cvlan-id>1</cvlan-id>  
    </config>  
    <cvlan-id>1</cvlan-id>  
    <translated-svlan-id>1</translated-svlan-id>  
  </cvlan-svlan-translation>  
</cvlan-svlan-translations>  
</switched-vlan>  
</switched-vlans>  
</port-vlan>  
</interface>  
</interfaces>
```

Command Syntax

```
switchport (customer-network) vlan translation cvlan <1-4095> svlan <1-4095> svlan  
<1-4095>
```

Configure logging

port security logging

Attribute Name: logging

Attribute Type: uint8

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
      <port-security>
        <config>
          </logging><!-- operation="delete"-->
        </config>
      </port-security>
    </port-vlan>
  </interface>
</interfaces>
```

Command Syntax

```
switchport port-security logging enable
```

Configure mode

port security mode type

Attribute Name: mode

Attribute Type: enum (static|default)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
      <port-security>
        <config>
          <mode>2</mode>
        </config>
      </port-security>
    </port-vlan>
  </interface>
</interfaces>
```

Command Syntax

```
switchport port-security
```

Configure maximum limit

Maximum limit for port security

Attribute Name: maximum-limit

Attribute Type: uint16

Default Value: 1

Attribute Range: 1-1000

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
  <port-security>
  <config>
    <maximum-limit>1</maximum-limit> <!-- operation="delete"-->
  </config>
</port-security>
</port-vlan>
</interface>
</interfaces>
```

Command Syntax

```
switchport port-security maximum <1-1000>
```

Configure mac address

Use this attribute to configure the static forwarding entry for port-security

This command is supported when following feature are enabled Provider bridging feature

Attribute Name: mac-address

Attribute Type: string

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
```

```

    <port-security>
    <secure-mac>
    <default-vlan-mappings>
    <default-vlan-mapping> <!-- operation="delete"-->
        <mac-address>XXXX.XXXX.XXXX</mac-address>
        <config>
            <mac-address>XXXX.XXXX.XXXX</mac-address>
        </config>
    </default-vlan-mapping>
</default-vlan-mappings>
</secure-mac>
</port-security>
</port-vlan>
</interface>
</interfaces>

```

Command Syntax

```
switchport port-security mac-address XXXX.XXXX.XXXX
```

Configure associate vlan id

Private VLAN Association

Attribute Name: associate-vlan-id

Attribute Type: uint16

Netconf edit-config payload

```

<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
    <name>IFNAME</name>
    <config>
        <name>IFNAME</name>
    </config>
    <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
    <private-vlan>
    <associations>
    <association>
        <vlan-id>2</vlan-id>
        <config>
            <vlan-id>2</vlan-id>
        </config>
        <associate-vlan-id>2</associate-vlan-id>
    </association>
    </associations>
    </private-vlan>
    </port-vlan>
</interface>
</interfaces>

```

Command Syntax

```
switchport private-vlan host-association <2-4094> add <2-4094>
```

Configure mapping vlan id

Primary vlan identifier

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Name: mapping-vlan-id

Attribute Type: string

Attribute Range: 2-4094

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
  <private-vlan>
  <associations>
  <association> <!-- operation="delete"-->
    <vlan-id>2</vlan-id>
    <config>
      <vlan-id>2</vlan-id>
      <mapping-vlan-id>VLAN_ID</mapping-vlan-id>
    </config>
  </association>
</associations>
</private-vlan>
</port-vlan>
</interface>
</interfaces>
```

Command Syntax

```
switchport private-vlan mapping <2-4094> add VLAN_ID
```

Configure association trunk vlan id

private-vlan Mapping

Attribute Name: association-trunk-vlan-id

Attribute Type: uint16

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
```

```

<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <port-vlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
  <private-vlan>
  <associations>
  <association>
    <vlan-id>2</vlan-id>
    <config>
      <vlan-id>2</vlan-id>
    </config>
    <association-trunk-vlan-id>2</association-trunk-vlan-id>
  </association>
</associations>
</private-vlan>
</port-vlan>
</interface>
</interfaces>

```

Command Syntax

```
switchport private-vlan association-trunk <2-4094> <2-4094>
```

Configure instance name

Specifies service VLAN identifier for static MAC entry

Attribute Name: svlan-id

Attribute Type: uint16

Attribute Range: 2-4094

Attribute Name: action

Attribute Type: enum (discard|forward)

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-33

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">

```

```

    <vlan-static-fdb xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">
    <entries>
    <entry>
        <vlan-id>2</vlan-id>
        <config>
            <vlan-id>2</vlan-id>
            <mac-address>XXXX.XXXX.XXXX</mac-address>
            <action>discard</action>
            <interface-name>IFNAME</interface-name>
        </config>
        <mac-address>XXXX.XXXX.XXXX</mac-address>
        <svlan-id>2</svlan-id>
    </entry>
    </entries>
</vlan-static-fdb>
</bridge>
</network-instance>
</network-instances>

```

Command Syntax

```

bridge <1-32> address XXXX.XXXX.XXXX (discard|forward) IFNAME vlan <2-4094> svlan
<2-4094>

```

Configure instance type

Specifies VLAN identifier for static MAC entry in case of provider-network VLAN will be considered as service VLAN

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 2-4094

Attribute Name: action

Attribute Type: enum (discard|forward)

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-33

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <vlan-static-fdb xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-vlan">

```



```

    <entries>
    <entry>
      <vlan-id>2</vlan-id>
      <config>
        <vlan-id>2</vlan-id>
        <mac-address>XXXX.XXXX.XXXX</mac-address>
        <action>discard</action>
        <interface-name>IFNAME</interface-name>
      </config>
      <mac-address>XXXX.XXXX.XXXX</mac-address>
    </entry>
  </entries>
</vlan-static-fdb>
</bridge>
</network-instance>
</network-instances>

```

Command Syntax

```
bridge <1-32> address XXXX.XXXX.XXXX (discard|forward) IFNAME vlan <2-4094>
```

IPI-XSTP

Configure ageing time

Use this attribute to specify the aging-out time for a learned MAC address. The learned MAC address persists until this specified time. Setting value to 0 would disable ageing of the bridge.

Attribute Name: ageing-time

Attribute Type: union

Default Value: 300

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>l</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
        <config>
          <ageing-time>300</ageing-time> <!-- operation="delete"-->
        </config>
      </stp>
    </bridge>
  </network-instance>
</network-instances>

```

```
</network-instance>  
</network-instances>
```

Command Syntax

```
bridge <1-32> ageing disable
```

Configure instance name

Use this attribute to specify the aging-out time for a learned MAC address. The learned MAC address persists until this specified time. Setting value to 0 would disable ageing of the bridge.

Attribute Name: ageing-time

Attribute Type: union

Default Value: 300

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-  
instance">  
  <network-instance>  
    <instance-name>1</instance-name>  
    <config>  
      <instance-name>WORD</instance-name>  
      <instance-type>l2ni</instance-type>  
    </config>  
    <instance-type>l2ni</instance-type>  
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">  
      <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">  
        <config>  
          <ageing-time>300</ageing-time> <!-- operation="delete"-->  
        </config>  
      </stp>  
    </bridge>  
  </network-instance>  
</network-instances>
```

Command Syntax

```
bridge <1-32> ageing-time (0|<10-572>)
```

Configure enable cisco interoperability

Use this attribute to enable/disable Cisco interoperability for MSTP (Multiple Spanning Tree Protocol). If Cisco interoperability is required, all devices in the switched LAN must be Cisco-interoperability enabled. When router interoperates with Cisco, the only criteria used to classify a region are the region name and revision level. VLAN-to-instance mapping is not used to classify regions when interoperating with Cisco.

Attribute Name: enable-cisco-interoperability

Attribute Type: empty

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
        <config>
          </enable-cisco-interoperability><!-- operation="delete"-->
        </config>
      </stp>
    </bridge>
  </network-instance>
</network-instances>

```

Command Syntax

```
bridge <1-32> cisco-interoperability enable
```

Configure forwarding delay

Use this attribute to set the time (in seconds) after which (if this bridge is the root bridge) each port changes states to learning and forwarding. This value is used by all instances

Attribute Name: forwarding-delay

Attribute Type: uint8

Default Value: 15

Attribute Range: 4-30

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
        <config>
          <forwarding-delay>4</forwarding-delay> <!-- operation="delete"-->
        </config>
      </stp>
    </bridge>
  </network-instance>
</network-instances>

```

```
</network-instance>  
</network-instances>
```

Command Syntax

```
bridge <1-32> forward-time <4-30>
```

Configure hello time

Use this attribute to set the hello-time, the time in seconds after which (if this bridge is the root bridge) all the bridges in a bridged LAN exchange Bridge Protocol Data Units (BPDUs). A very low value of this parameter leads to excessive traffic on the network, while a higher value delays the detection of topology change. This value is used by all instances. Configure the bridge instance name before using this attribute. The allowable range of values is 1-10 seconds. However, make sure that the value of hello time is always greater than the value of hold time (2 seconds by default)

Attribute Name: hello-time

Attribute Type: uint8

Default Value: 2

Attribute Range: 1-10

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-  
instance">  
  <network-instance>  
    <instance-name>1</instance-name>  
    <config>  
      <instance-name>WORD</instance-name>  
      <instance-type>l2ni</instance-type>  
    </config>  
    <instance-type>l2ni</instance-type>  
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">  
      <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">  
        <config>  
          <hello-time>1</hello-time> <!-- operation="delete"-->  
        </config>  
      </stp>  
    </bridge>  
  </network-instance>  
</network-instances>
```

Command Syntax

```
bridge <1-32> hello-time <1-10>
```

Configure max age

Use this attribute to set the maximum age for a bridge. This value is used by all instances. Maximum age is the maximum time in seconds for which (if a bridge is the root bridge) a message is considered valid. This prevents the frames from looping indefinitely. The value of maximum age should be greater than twice the value of hello time plus 1, but less than twice the value of forward delay minus 1. The allowable range for max-age is 6-40 seconds. Configure

this value sufficiently high, so that a frame generated by root can be propagated to the leaf nodes without exceeding the maximum age.

Attribute Name: max-age

Attribute Type: uint8

Default Value: 20

Attribute Range: 6-40

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>l</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
        <config>
          <max-age>6</max-age> <!-- operation="delete"-->
        </config>
      </stp>
    </bridge>
  </network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> max-age <6-40>
```

Configure max hops

Use this attribute to specify the maximum allowed hops for a BPDU in a MST region. This parameter is used by all the instances of the MST. Specifying the maximum hops for a BPDU prevents the messages from looping indefinitely in the network. When a bridge receives an MST BPDU that has exceeded the allowed maximum hops, it discards the BPDU.

Attribute Name: max-hops

Attribute Type: uint8

Default Value: 20

Attribute Range: 1-40

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>l</instance-name>
    <config>
      <instance-name>WORD</instance-name>
```

```
    <instance-type>l2ni</instance-type>
  </config>
  <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
      <config>
        <max-hops>1</max-hops> <!-- operation="delete"-->
      </config>
    </stp>
  </bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> max-hops <1-40>
```

Configure bridge priority

Use this attribute to set the bridge priority for the common instance. Using a lower priority indicates a greater likelihood of the bridge becoming root. The priority values can be set only in increments of 4096.

Attribute Name: bridge-priority

Attribute Type: uint32

Default Value: 32768

Attribute Range: 0-61440

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
        <config>
          <bridge-priority>0</bridge-priority> <!-- operation="delete"-->
        </config>
      </stp>
    </bridge>
  </network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> priority <0-61440>
```

Configure transmit hold count

Use this attribute to set the maximum number of transmissions of BPDUs by the transmit state machine

Attribute Name: transmit-hold-count

Attribute Type: uint8

Default Value: 6

Attribute Range: 1-10

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
        <config>
          <transmit-hold-count>1</transmit-hold-count> <!-- operation="delete"-->
        </config>
      </stp>
    </bridge>
  </network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> transmit-holdcount <1-10>
```

Configure enable bpdu filter

All ports that have their BPDU filter set to default take the same value of BPDU filter as that of the bridge. The Spanning Tree Protocol sends BPDUs from all ports. Enabling the BPDU Filter feature ensures that PortFast-enabled ports do not transmit or receive any BPDUs.

Attribute Name: enable-bpdu-filter

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
```

```
</config>
  <instance-type>l2ni</instance-type>
<bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
  <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
    <global>
      <config>
        </enable-bpdu-filter><!-- operation="delete"-->
      </config>
    </global>
  </stp>
</bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> spanning-tree portfast bpdu-filter
```

Configure enable bpdu guard

Use this attribute to set the portfast BPDU (Bridge Protocol Data Unit) guard or filter for the bridge

Attribute Name: enable-bpdu-guard

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>l</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
      <global>
        <config>
          </enable-bpdu-guard><!-- operation="delete"-->
        </config>
      </global>
    </stp>
  </bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> spanning-tree portfast bpdu-guard
```

Configure enable error disable timeout

Use this attribute to enable the error-disable-timeout facility, which sets a timeout for ports that are disabled due to the BPDU guard feature. The BPDU guard feature shuts down the port on receiving a BPDU on a BPDU-guard enabled port. This attribute associates a timer with the feature such that the port gets enabled back without manual intervention after a set interval.

Attribute Name: enable-error-disable-timeout

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>l</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
        <global>
          <config>
            </enable-error-disable-timeout><!-- operation="delete"-->
          </config>
        </global>
      </stp>
    </bridge>
  </network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> spanning-tree errdisable-timeout enable
```

Configure force version

Use this attribute to set the version for the bridge. A version identifier of less than a value of 2 enforces the spanning tree protocol. Although the attribute supports an input range of 0-4, for RSTP, the valid range is 0-2. When the force-version is set for a bridge, all ports of the bridge have the same spanning tree version set.

Attribute Name: force-version

Attribute Type: uint8

Default Value: 0

Attribute Range: 0-4

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
```

```
<instance-name>1</instance-name>
<config>
  <instance-name>WORD</instance-name>
  <instance-type>l2ni</instance-type>
</config>
  <instance-type>l2ni</instance-type>
<bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
  <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
    <global>
      <config>
        <force-version>0</force-version> <!-- operation="delete"-->
      </config>
    </global>
  </stp>
</bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> spanning-tree force-version <0-4>
```

Configure path cost method

Use this attribute to set a spanning-tree path cost method. If the short parameter is used, the switch uses a value for the default path cost a number in the range 1 through 65,535. If the long parameter is used, the switch uses a value for the default path cost a number in the range 1 through 200,000,000.

Attribute Name: path-cost-method

Attribute Type: enum (short|long|default)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
      <global>
        <config>
          <path-cost-method>default</path-cost-method> <!-- operation="delete"--
>
        </config>
      </global>
    </stp>
  </bridge>
</network-instance>
```

```
</network-instances>
```

Command Syntax

```
bridge <1-32> spanning-tree pathcost method (short|long)
```

Configure bridge type

Network Instance Name. For VRF and MAC VRF, instance name can be up to 32 chars long. For VPWS and VPLS instances, instance name can be up to 128 chars long. For L2NI (bridge) instance, instance name has to be a number between (1-32). For Cross-Connect, instance name can be up to 30 chars long. For Bridge-domain, instance, instance name has to be a number between (1-2147483647).

Attribute Name: instance-name

Attribute Type: string

Attribute Name: bridge-type

Attribute Type: enum (spanning-tree|rapid-spanning-tree|multiple-spanning-tree)

Attribute Name: disable-spanning-tree

Attribute Type: uint8

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance> <!-- operation="delete"-->
    <instance-type>l2ni</instance-type>
    <config>
      <instance-type>l2ni</instance-type>
      <instance-name>WORD</instance-name>
    </config>
    <instance-name>WORD</instance-name>
  <stp>
  <global>
  <bridge-admins>
  <bridge-admin>
    <bridge-type>spanning-tree</bridge-type>
    </disable-spanning-tree>
  </bridge-admin>
</bridge-admins>
</global>
</stp>
</network-instance>
</network-instances>
```

Command Syntax

```
no bridge <1-32> (rapid-spanning-tree|multiple-spanning-tree) enable
```

Configure disable spanning tree

Network Instance Name. For VRF and MAC VRF, instance name can be up to 32 chars long. For VPWS and VPLS instances, instance name can be up to 128 chars long. For L2NI (bridge) instance, instance name has to be a number

between (1-32). For Cross-Connect, instance name can be up to 30 chars long. For Bridge-domain, instance, instance name has to be a number between (1-2147483647).

Attribute Name: instance-name

Attribute Type: string

Attribute Name: bridge-type

Attribute Type: enum (spanning-tree|rapid-spanning-tree|multiple-spanning-tree)

Attribute Name: disable-spanning-tree

Attribute Type: uint8

Attribute Name: bridge-forwarding

Attribute Type: enum (bridge-blocked|bridge-forward)

Default Value: bridge-blocked

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance> <!-- operation="delete"-->
    <instance-type>l2ni</instance-type>
    <config>
      <instance-type>l2ni</instance-type>
      <instance-name>WORD</instance-name>
    </config>
    <instance-name>WORD</instance-name>
  <stp>
  <global>
  <bridge-admins>
  <bridge-admin>
    <bridge-type>spanning-tree</bridge-type>
    </disable-spanning-tree>
    <config>
      <bridge-forwarding>bridge-blocked</bridge-forwarding>
    </config>
  </bridge-admin>
</bridge-admins>
</global>
</stp>
</network-instance>
</network-instances>
```

Command Syntax

```
no bridge <1-32> (rapid-spanning-tree|multiple-spanning-tree) enable (bridge-
blocked|bridge-forward)
```

Configure bridge forwarding

Network Instance Name. For VRF and MAC VRF, instance name can be up to 32 chars long. For VPWS and VPLS instances, instance name can be up to 128 chars long. For L2NI (bridge) instance, instance name has to be a number

between (1-32). For Cross-Connect, instance name can be up to 30 chars long. For Bridge-domain, instance, instance name has to be a number between (1-2147483647).

Attribute Name: instance-name

Attribute Type: string

Attribute Name: bridge-type

Attribute Type: enum (spanning-tree|rapid-spanning-tree|multiple-spanning-tree)

Attribute Name: disable-spanning-tree

Attribute Type: uint8

Attribute Name: bridge-forwarding

Attribute Type: enum (bridge-blocked|bridge-forward)

Default Value: bridge-blocked

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance> <!-- operation="delete"-->
    <instance-type>l2ni</instance-type>
    <config>
      <instance-type>l2ni</instance-type>
      <instance-name>WORD</instance-name>
    </config>
    <instance-name>WORD</instance-name>
  <stp>
  <global>
  <bridge-admins>
  <bridge-admin>
    <bridge-type>spanning-tree</bridge-type>
    </disable-spanning-tree>
    <config>
      <bridge-forwarding>bridge-blocked</bridge-forwarding>
    </config>
  </bridge-admin>
</bridge-admins>
</global>
</stp>
</network-instance>
</network-instances>
```

Command Syntax

```
no bridge <1-32> spanning-tree enable (bridge-blocked|bridge-forward)
```

Configure enable shutdown

Network Instance Name. For VRF and MAC VRF, instance name can be up to 32 chars long. For VPWS and VPLS instances, instance name can be up to 128 chars long. For L2NI (bridge) instance, instance name has to be a number between (1-32). For Cross-Connect, instance name can be up to 30 chars long. For Bridge-domain, instance, instance name has to be a number between (1-2147483647).

Attribute Name: instance-name

Attribute Type: string

Attribute Name: enable-shutdown

Attribute Type: uint8

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance> <!-- operation="delete"-->
    <instance-type>l2ni</instance-type>
    <config>
      <instance-type>l2ni</instance-type>
      <instance-name>WORD</instance-name>
    </config>
    <instance-name>WORD</instance-name>
  <stp>
  <global>
  <bridge-shutdowns>
  <bridge-shutdown>
    </enable-shutdown>
  </bridge-shutdown>
  </bridge-shutdowns>
  </global>
  </stp>
</network-instance>
</network-instances>
```

Command Syntax

```
bridge shutdown <1-32>
```

Configure region name

Use this attribute to create an MST region and specify its name. MST bridges of a region form different spanning trees for different VLANs.

Attribute Name: region-name

Attribute Type: string

Default Value: Default

Attribute Range: 1-32

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
```

```

    <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
      <mstp>
        <config>
          <region-name>REGION_NAME</region-name> <!-- operation="delete"-->
        </config>
      </mstp>
    </stp>
  </bridge>
</network-instance>
</network-instances>

```

Command Syntax

```
bridge <1-32> region REGION_NAME
```

Configure revision number

Use this attribute to specify the number for configuration information.

Attribute Name: revision-number

Attribute Type: uint16

Attribute Range: 0-65535

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>l</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
        <mstp>
          <config>
            <revision-number>0</revision-number> <!-- operation="delete"-->
          </config>
        </mstp>
      </stp>
    </bridge>
  </network-instance>
</network-instances>

```

Command Syntax

```
bridge <1-32> revision <0-65535>
```

Configure vlan id

Use this attribute to simultaneously add multiple VLANs for the corresponding instance of a bridge. The VLANs must be created before being associated with an MST instance (MSTI). If the VLAN range is not specified, the MSTI will not be created.

Attribute Name: vlan-id

Attribute Type: uint16

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
    <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
      <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
        <mstp>
          <mst-instances>
            <te-mst-instance>
              <config>
                <vlan-id>VLANID</vlan-id> <!-- operation="delete"-->
              </config>
            </te-mst-instance>
          </mst-instances>
        </mstp>
      </stp>
    </bridge>
  </network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> te-msti vlan VLANID
```

Configure disable spanning tree

Use this attribute to disable spanning tree for TE MSTI instance

Attribute Name: disable-spanning-tree

Attribute Type: uint8

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
```



```

    <instance-name>WORD</instance-name>
    <instance-type>vrf</instance-type>
</config>
    <instance-type>l2ni</instance-type>
<bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
        <mstp>
            <mst-instances>
                <te-mst-instance>
                    <config>
                        </disable-spanning-tree><!-- operation="delete"-->
                    </config>
                </te-mst-instance>
            </mst-instances>
        </mstp>
    </stp>
</bridge>
</network-instance>
</network-instances>

```

Command Syntax

```
no bridge <1-32> te-msti
```

Configure name

The textual name of the interface

Attribute Name: name

Attribute Type: string

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>l</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>l2ni</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
      <mstp>
        <mst-instances>
          <te-mst-instance>
            <interfaces>
              <interface> <!-- operation="delete"-->
                <name>WORD</name>
                <config>
                  <name>WORD</name>

```

```
        </config>
    </interface>
</interfaces>
</te-mst-instance>
</mst-instances>
</mstp>
</stp>
</bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
bridge-group <1-32> instance te-msti
```

Configure instance id

Network Instance Name. For VRF and MAC VRF, instance name can be up to 32 chars long. For VPWS and VPLS instances, instance name can be up to 128 chars long. For L2NI (bridge) instance, instance name has to be a number between (1-32). For Cross-Connect, instance name can be up to 30 chars long. For Bridge-domain, instance, instance name has to be a number between (1-2147483647).

Attribute Name: instance-name

Attribute Type: string

Attribute Name: instance-id

Attribute Type: union

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance> <!-- operation="delete"-->
    <instance-type>l2ni</instance-type>
    <config>
      <instance-type>l2ni</instance-type>
      <instance-name>WORD</instance-name>
    </config>
    <instance-name>WORD</instance-name>
  <stp>
  <mstp>
  <mst-instances>
  <mst-instance>
    <instance-id>MSTP_INSTANCE_T</instance-id>
  </mst-instance>
</mst-instances>
</mstp>
</stp>
</network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> (instance <1-63>)
```

Configure instance type

Use this attribute to simultaneously add multiple VLANs for the corresponding instance of a bridge. The VLANs must be created before being associated with an MST instance (MSTI). If the VLAN range is not specified, the MSTI will not be created.

Attribute Name: vlan-id

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>l</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
      <mstp>
        <mst-instances>
          <mst-instance>
            <instance-id>MSTP_INSTANCE_T</instance-id>
            <config>
              <instance-id>MSTP_INSTANCE_T</instance-id>
            </config>
            <vlan-id>VLAN_RANGE</vlan-id> <!-- operation="delete"-->
          </mst-instance>
        </mst-instances>
      </mstp>
    </stp>
  </bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> instance vlan VLAN_RANGE
```

Configure instance id

Use this attribute to set the bridge instance priority.

Attribute Name: bridge-priority

Attribute Type: uint32

Default Value: 32768

Attribute Range: 0-61440

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
      <mstp>
        <mst-instances>
          <mst-instance>
            <instance-id>MSTP_INSTANCE_T</instance-id>
            <config>
              <instance-id>MSTP_INSTANCE_T</instance-id>
            </config>
            <bridge-priority>0</bridge-priority> <!-- operation="delete"-->
          </mst-instance>
        </mst-instances>
      </mstp>
    </stp>
  </bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
bridge <1-32> instance <1-63> priority <0-61440>
```

Configure path cost

Use this attribute to set a path cost for a multiple spanning tree instance. Before using this attribute, you must explicitly add an MST instance to a port using the bridge-group instance attribute.

Attribute Name: path-cost

Attribute Type: uint32

Default Value: 20000000

Attribute Range: 1-200000000

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>1</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
```

```

    <instance-type>l2ni</instance-type>
  <bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
    <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
      <mstp>
        <mst-instaces>
          <mst-instance>
            <instance-id>MSTP_INSTANCE_T</instance-id>
            <config>
              <instance-id>MSTP_INSTANCE_T</instance-id>
            </config>
            <interfaces>
              <interface>
                <name>WORD</name>
                <config>
                  <name>WORD</name>
                </config>
                <path-cost>1</path-cost> <!-- operation="delete"-->
              </interface>
            </interfaces>
          </mst-instance>
        </mst-instaces>
      </mstp>
    </stp>
  </bridge>
</network-instance>
</network-instaces>

```

Command Syntax

```
bridge-group <1-32> instance <1-63> path-cost <1-200000000>
```

Configure port priority

Use this attribute to set the bridge instance priority. The Multiple Spanning Tree Protocol uses port priority as a tiebreaker to determine which port should forward frames for a particular instance on a LAN, or which port should be the root port for an instance. A lower value implies a better priority. In the case of the same priority, the interface index will serve as the tiebreaker, with the lower-numbered interface being preferred over others.

Attribute Name: port-priority

Attribute Type: int16

Default Value: 128

Attribute Range: 0-240

Netconf edit-config payload

```

  <network-instaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
    <network-instance>
      <instance-name>1</instance-name>
      <config>
        <instance-name>WORD</instance-name>
        <instance-type>vrf</instance-type>

```

```
</config>
  <instance-type>l2ni</instance-type>
<bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge">
  <stp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
    <mstp>
      <mst-instances>
        <mst-instance>
          <instance-id>MSTP_INSTANCE_T</instance-id>
          <config>
            <instance-id>MSTP_INSTANCE_T</instance-id>
          </config>
          <interfaces>
            <interface>
              <name>WORD</name>
              <config>
                <name>WORD</name>
              </config>
              <port-priority>0</port-priority> <!-- operation="delete"-->
            </interface>
          </interfaces>
        </mst-instance>
      </mst-instances>
    </mstp>
  </stp>
</bridge>
</network-instance>
</network-instances>
```

Command Syntax

```
bridge-group <1-32> instance <1-63> priority <0-240>
```

Configure port configuration

Use this attribute to set a port as an edge-port and to enable rapid transitions.

Attribute Name: port-configuration

Attribute Type: enum (edgeport|portfast)

Default Value: portfast

Netconf edit-config payload

```
<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <port-configuration>portfast</port-configuration> <!-- operation="delete"-->
    </interface>
  </interfaces>
```

```
</xstp>
```

Command Syntax

```
spanning-tree (edgeport|portfast)
```

Configure enable automatic edge detection

Use this attribute to enable automatic edge detection.

Attribute Name: enable-automatic-edge-detection

Attribute Type: empty

Netconf edit-config payload

```
<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </enable-automatic-edge-detection><!-- operation="delete"-->
    </interface>
  </interfaces>
</xstp>
```

Command Syntax

```
spanning-tree autoedge
```

Configure bpdu guard

Use this attribute to set the portfast BPDU (Bridge Protocol Data Unit) guard or filter for the bridge. When the BPDU guard feature is set for a bridge, all portfast-enabled ports of the bridge that have the BPDU guard set to default shut down the port on receiving a BPDU. In this case, the BPDU is not processed. You can configure the errdisable-timeout feature to enable the port after the specified time interval.

Attribute Name: bpdu-guard

Attribute Type: enum (enable|disable|default)

Default Value: default

Netconf edit-config payload

```
<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <bpdu-guard>default</bpdu-guard> <!-- operation="delete"-->
    </interface>
  </interfaces>
```

```
</xstp>
```

Command Syntax

```
spanning-tree bpdu-guard (enable|disable|default)
```

Configure bpdu filter

Use this attribute to set the portfast BPDU (Bridge Protocol Data Unit) guard or filter for the bridge. All ports that have their BPDU filter set to default take the same value of BPDU filter as that of the bridge. The Spanning Tree Protocol sends BPDUs from all ports. Enabling the BPDU Filter feature ensures that PortFast-enabled ports do not transmit or receive any BPDUs

Attribute Name: bpdu-filter

Attribute Type: enum (enable|disable|default)

Default Value: default

Netconf edit-config payload

```
<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <bpdu-filter>default</bpdu-filter> <!-- operation="delete"-->
</interface>
</interfaces>
</xstp>
```

Command Syntax

```
spanning-tree bpdu-filter (enable|disable|default)
```

Configure enable root guard

Use this attribute to enable the root guard feature for the port. This feature disables reception of superior BPDUs. The root guard feature makes sure that the port on which it is enabled is a designated port. If the root guard enabled port receives a superior BPDU, it goes to a Listening state (for STP) or discarding state (for RSTP and MSTP).

Attribute Name: enable-root-guard

Attribute Type: empty

Netconf edit-config payload

```
<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </enable-root-guard><!-- operation="delete"-->
</interface>
</interfaces>
</xstp>
```



```

</interface>
</interfaces>
</xstp>

```

Command Syntax

```
spanning-tree guard root
```

Configure link type

Use this attribute to enable or disable point-to-point or shared link types. RSTP has a backward-compatible STP , spanning-tree link-type shared. An alternative is the spanning-tree force-version 0

Attribute Name: link-type

Attribute Type: enum (shared|point-to-point|auto)

Default Value: point-to-point

Netconf edit-config payload

```

<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <link-type>point-to-point</link-type> <!-- operation="delete"-->
</interface>
</interfaces>
</xstp>

```

Command Syntax

```
spanning-tree link-type (shared|point-to-point|auto)
```

Configure enable restricted domain role

Use this attribute to set the restricted-domain-role value of the port to TRUE.

Attribute Name: enable-restricted-domain-role

Attribute Type: empty

Netconf edit-config payload

```

<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </enable-restricted-domain-role><!-- operation="delete"-->
</interface>
</interfaces>

```

```
</xstp>
```

Command Syntax

```
spanning-tree restricted-domain-role
```

Configure enable restricted role

Use this attribute to set the restricted-role value of the port to TRUE

Attribute Name: enable-restricted-role

Attribute Type: empty

Netconf edit-config payload

```
<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </enable-restricted-role><!-- operation="delete"-->
</interface>
</interfaces>
</xstp>
```

Command Syntax

```
spanning-tree restricted-role
```

Configure enable restricted tcn

Use this attribute to set the restricted TCN value of the port to TRUE

Attribute Name: enable-restricted-tcn

Attribute Type: empty

Netconf edit-config payload

```
<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </enable-restricted-tcn><!-- operation="delete"-->
</interface>
</interfaces>
</xstp>
```

Command Syntax

```
spanning-tree restricted-tcn
```

Configure enable instance restricted tcn

Use this attribute to set the restricted TCN value for the instance to TRUE

Attribute Name: enable-instance-restricted-tcn

Attribute Type: uint8

Netconf edit-config payload

```
<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <mstp>
      <mst-instances>
        <mst-instance>
          <instance-id>MSTP_INSTANCE_T</instance-id>
          <config>
            <instance-id>MSTP_INSTANCE_T</instance-id>
            </enable-instance-restricted-tcn><!-- operation="delete"-->
          </config>
        </mst-instance>
      </mst-instances>
    </mstp>
  </interface>
</interfaces>
</xstp>
```

Command Syntax

```
spanning-tree instance <1-63> restricted-tcn
```

Configure enable instance restricted role

Use this attribute to set the restricted role value for the instance to TRUE

Attribute Name: enable-instance-restricted-role

Attribute Type: uint8

Netconf edit-config payload

```
<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <mstp>
      <mst-instances>
```

```

<mst-instance>
  <instance-id>MSTP_INSTANCE_T</instance-id>
  <config>
    <instance-id>MSTP_INSTANCE_T</instance-id>
  </config>
  </enable-instance-restricted-role><!-- operation="delete"-->
</mst-instance>
</mst-instances>
</mstp>
</interface>
</interfaces>
</xstp>

```

Command Syntax

```
spanning-tree instance <1-63> restricted-role
```

Configure forward delay

Use this attribute to set the time (in seconds) after which (if this bridge is the root bridge) each port changes states to learning and forwarding. This value is used by all instances

This command is supported when following feature are enabled provider bridge feature

Attribute Name: forward-delay

Attribute Type: uint8

Default Value: 15

Attribute Range: 4-30

Netconf edit-config payload

```

<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <customer-spanning-tree>
      <config>
        <forward-delay>4</forward-delay> <!-- operation="delete"-->
      </config>
    </customer-spanning-tree>
  </interface>
</interfaces>
</xstp>

```

Command Syntax

```
customer-spanning-tree forward-time <4-30>
```

Configure svlan id

Use this attribute to set the bridge path cost.

This command is supported when following feature are enabled provider bridge feature

Attribute Name: path-cost

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-200000000

Netconf edit-config payload

```
<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <customer-spanning-tree>
    <provider-edge>
    <vlans>
    <vlan>
      <svlan-id>0</svlan-id>
      <config>
        <svlan-id>2</svlan-id>
      </config>
      <path-cost>1</path-cost> <!-- operation="delete"-->
    </vlan>
    </vlans>
    </provider-edge>
    </customer-spanning-tree>
    </interface>
  </interfaces>
</xstp>
```

Command Syntax

```
customer-spanning-tree provider-edge svlan <2-4094> path-cost <1-200000000>
```

Configure options

Debug configuration flag

Attribute Name: options

Attribute Type: bits (mstp protocol|mstp protocol detail|mstp timer|mstp timer detail|mstp packet tx|mstp packet rx|mstp cli|mstp bpdu|mstp mcec|mstp all)

Netconf edit-config payload

```
<xstp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <mstp>
```

```
<debug>
<config>
  <options>mstp protocol</options> <!-- operation="delete"-->
</config>
</debug>
</mstp>
</xstp>
```

Command Syntax

```
debug (mstp protocol|mstp protocol detail|mstp timer|mstp timer detail|mstp packet
tx|mstp packet rx|mstp cli|mstp bpdu|mstp mcec|mstp all)
```

debug (mstp protocol|mstp protocol detail|mstp timer|mstp timer detail|mstp packet tx|mstp packet rx|mstp cli|mstp bpdu|mstp mcec|mstp all)

Attribute Name: terminal-debug-options

Attribute Type: bits (mstp protocol|mstp protocol detail|mstp timer|mstp timer detail|mstp packet tx|mstp packet rx|mstp cli|mstp bpdu|mstp mcec|mstp all)

Netconf RPC payload

```
<mstp-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
<terminal-debug-options>mstp protocol</terminal-debug-options>
</mstp-terminal-debug-on>
```

Command Syntax

```
debug (mstp protocol|mstp protocol detail|mstp timer|mstp timer detail|mstp packet
tx|mstp packet rx|mstp cli|mstp bpdu|mstp mcec|mstp all)
```

no debug (mstp protocol|mstp protocol detail|mstp timer|mstp timer detail|mstp packet tx|mstp packet rx|mstp cli|mstp bpdu|mstp mcec|mstp all)

Attribute Name: terminal-debug-options

Attribute Type: bits (mstp protocol|mstp protocol detail|mstp timer|mstp timer detail|mstp packet tx|mstp packet rx|mstp cli|mstp bpdu|mstp mcec|mstp all)

Netconf RPC payload

```
<mstp-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
<terminal-debug-options>mstp protocol</terminal-debug-options>
</mstp-terminal-debug-off>
```

Command Syntax

```
no debug (mstp protocol|mstp protocol detail|mstp timer|mstp timer detail|mstp
packet tx|mstp packet rx|mstp cli|mstp bpdu|mstp mcec|mstp all)
```

clear spanning-tree detected protocols bridge <1-32>

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<clear-spanning-tree-detected-protocols-per-bridge xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <bridge-id>1</bridge-id>
</clear-spanning-tree-detected-protocols-per-bridge>
```

Command Syntax

```
clear spanning-tree detected protocols bridge <1-32>
```

clear spanning-tree detected protocols interface INTERFACE

Attribute Name: interface-name

Attribute Type: string

Netconf RPC payload

```
<clear-spanning-tree-detected-protocols-per-interface xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <interface-name>INTERFACE</interface-name>
</clear-spanning-tree-detected-protocols-per-interface>
```

Command Syntax

```
clear spanning-tree detected protocols interface INTERFACE
```

clear spanning-tree statistics (spbm|<1-63>) bridge <1-32>

Attribute Name: mst-instance-id

Attribute Type: union

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<clear-spanning-tree-statistics-per-instance-and-bridge xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <mst-instance-id>MSTP_INSTANCE_SPBM_TYPE_T</mst-instance-id>
  <bridge-id>1</bridge-id>
</clear-spanning-tree-statistics-per-instance-and-bridge>
```

Command Syntax

```
clear spanning-tree statistics (spbm|<1-63>) bridge <1-32>
```

clear spanning-tree statistics interface IFNAME vlan <2-4094> bridge <1-32>

Attribute Name: interface-name

Attribute Type: string

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 2-4094

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<clear-spanning-tree-statistics-per-interface-vlan-and-bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <interface-name>IFNAME</interface-name>
  <vlan-id>2</vlan-id>
  <bridge-id>1</bridge-id>
</clear-spanning-tree-statistics-per-interface-vlan-and-bridge>
```

Command Syntax

```
clear spanning-tree statistics interface IFNAME vlan <2-4094> bridge <1-32>
```

clear spanning-tree statistics interface IFNAME bridge <1-32>

Attribute Name: interface-name

Attribute Type: string

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<clear-spanning-tree-statistics-per-interface-and-bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <interface-name>IFNAME</interface-name>
  <bridge-id>1</bridge-id>
</clear-spanning-tree-statistics-per-interface-and-bridge>
```

Command Syntax

```
clear spanning-tree statistics interface IFNAME bridge <1-32>
```

clear spanning-tree statistics bridge <1-32>

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<clear-spanning-tree-statistics-per-bridge xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <bridge-id>1</bridge-id>
</clear-spanning-tree-statistics-per-bridge>
```

Command Syntax

```
clear spanning-tree statistics bridge <1-32>
```

clear spanning-tree statistics vlan <2-4094> bridge <1-32>

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 2-4094

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<clear-spanning-tree-statistics-per-vlan-and-bridge xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <vlan-id>2</vlan-id>
  <bridge-id>1</bridge-id>
</clear-spanning-tree-statistics-per-vlan-and-bridge>
```

Command Syntax

```
clear spanning-tree statistics vlan <2-4094> bridge <1-32>
```

clear spanning-tree statistics interface IFNAME (spbm|<1-63>) bridge <1-32>

Attribute Name: interface-name

Attribute Type: string

Attribute Name: mst-instance-id

Attribute Type: union

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<clear-spanning-tree-statistics-per-interface-instance-and-bridge xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-xstp">
  <interface-name>IFNAME</interface-name>
  <mst-instance-id>MSTP_INSTANCE_SPBM_TYPE_T</mst-instance-id>
  <bridge-id>1</bridge-id>
</clear-spanning-tree-statistics-per-interface-instance-and-bridge>
```

Command Syntax

```
clear spanning-tree statistics interface IFNAME (spbm|<1-63>) bridge <1-32>
```

snmp restart mstp

Netconf RPC payload

```
<mstp-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-xstp"/>
```

Command Syntax

```
snmp restart mstp
```

IPI-IF-AGGREGATE

Configure aggregate id

Channel group identifier

Attribute Name: aggregate-id

Attribute Type: uint16

Attribute Range: 1-16383

Attribute Name: agg-type

Attribute Type: enum (lacp|static)

Attribute Name: lacp-mode

Attribute Type: enum (passive|active)

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <member-aggregation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-
aggregate">
      <config>
        <agg-type>2</agg-type>
        <lacp-mode>1</lacp-mode>
        <aggregate-id>1</aggregate-id>
      </config>
    </member-aggregation>
  </interface>
</interfaces>
```

Command Syntax

```
static-channel-group <1-16383>
```

Configure lacp mode

Use this command to add a port to a channel group specified by the channel group number (1-12). This command enables link aggregation on a port, so that it may be selected for aggregation by the local system.

Attribute Name: lacp-mode

Attribute Type: enum (passive|active)

Attribute Name: agg-type

Attribute Type: enum (lacp|static)

Attribute Name: aggregate-id

Attribute Type: uint16

Attribute Range: 1-16383

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <member-aggregation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-
aggregate">
      <config>
        <agg-type>1</agg-type>
        <aggregate-id>1</aggregate-id>
        <lacp-mode>passive</lacp-mode>
      </config>
    </member-aggregation>
  </interface>
</interfaces>
```

Command Syntax

```
channel-group <1-16383> mode (passive|active)
```

Configure weight

Set the port channel weight

This command is supported when following feature are enabled dune feature

Attribute Name: weight

Attribute Type: uint16

Attribute Range: 1-16

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <member-aggregation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-
aggregate">
      <port-channel-weight>
        <config>
          <weight>1</weight> <!-- operation="delete"-->
        </config>
      </port-channel-weight>
    </member-aggregation>
  </interface>
```

```
</interfaces>
```

Command Syntax

```
port-channel weight <1-16>
```

Configure min links

Minimum number of active links required in this aggregator

Attribute Name: min-links

Attribute Type: uint8

Attribute Range: 2-32

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <aggregator xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-aggregate">
      <config>
        <min-links>2</min-links> <!-- operation="delete"-->
      </config>
    </aggregator>
  </interface>
</interfaces>
```

Command Syntax

```
port-channel min-links <2-32>
```

Configure min bandwidth

Minimum number of bandwidth required in this aggregator

Attribute Name: min-bandwidth

Attribute Type: string

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <aggregator xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-if-aggregate">
      <config>
        <min-bandwidth>BANDWIDTH</min-bandwidth> <!-- operation="delete"-->
      </config>
    </aggregator>
  </interface>
</interfaces>
```

```
</aggregator>  
</interface>  
</interfaces>
```

Command Syntax

```
port-channel min-bandwidth BANDWIDTH
```

IPI-LACP

Configure system priority

Use this attribute to the system priority of this switch. This priority is used for determining the system that is responsible for resolving conflicts in the choice of aggregation groups. A lower numerical value has a higher priority.

Attribute Name: system-priority

Attribute Type: uint32

Default Value: 32768

Attribute Range: 0-65535

Netconf edit-config payload

```
<lacp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lacp">  
  <global>  
    <config>  
      <system-priority>0</system-priority> <!-- operation="delete"-->  
    </config>  
  </global>  
</lacp>
```

Command Syntax

```
lacp system-priority <0-65535>
```

Configure options

This attribute returns the terminal debug options which are enabled

Attribute Name: options

Attribute Type: bits (event|cli|timer|packet|rx|tx|sync|ha|all)

Netconf edit-config payload

```
<lacp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lacp">  
  <debug>  
    <config>  
      <options>event</options> <!-- operation="delete"-->  
    </config>  
  </debug>  
</lacp>
```

Command Syntax

```
debug lacp (event|cli|timer|packet|rx|tx|sync|ha|all)
```

Configure port priority

Use this attribute to set the priority of a channel. Channels are selected for aggregation based on their priority with the higher priority (numerically lower) channels selected first

Attribute Name: port-priority

Attribute Type: uint32

Default Value: 32768

Attribute Range: 1-65535

Netconf edit-config payload

```
<lacp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lacp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<member-aggregation>
<config>
  <port-priority>1</port-priority> <!-- operation="delete"-->
</config>
</member-aggregation>
</interface>
</interfaces>
</lacp>
```

Command Syntax

```
lacp port-priority <1-65535>
```

Configure timeout

Use this attribute to set either a short or long timeout value on a port. The timeout value is the number of seconds before invalidating a received LACP data unit (DU). If the LACP_timeout bit (encoded in Actor_State and Partner_State fields) is set to 1, the short timeout takes effect; if set to 0, the long timeout takes effect.

Attribute Name: timeout

Attribute Type: enum (long|short)

Default Value: long

Netconf edit-config payload

```
<lacp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lacp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
```

```

        <name>WORD</name>
    </config>
<member-aggregation>
<config>
    <timeout>long</timeout> <!-- operation="delete"-->
</config>
</member-aggregation>
</interface>
</interfaces>
</lacp>

```

Command Syntax

```
lacp timeout (long|short)
```

Configure bridge type

Use this attribute to set the address type to use for sending LACPDUs (Link Aggregation Control Protocol Data Units).

Attribute Name: bridge-type

Attribute Type: enum (customer-bridge-group-address|multicast-group-address|non-tmpr-group-address)

Default Value: multicast-group-address

Netconf edit-config payload

```

<lacp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lacp">
<interfaces>
<interface>
    <name>WORD</name>
    <config>
        <name>WORD</name>
    </config>
<member-aggregation>
<config>
    <bridge-type>multicast-group-address</bridge-type> <!-- operation="delete"-->
</config>
</member-aggregation>
</interface>
</interfaces>
</lacp>

```

Command Syntax

```
lacp destination-mac (customer-bridge-group-address|multicast-group-address|non-
tmpr-group-address)
```

Configure force up

Use this attribute to enable the port as force-up in a channel group. Setting this attribute makes the port logically operational even if link aggregation goes down.

Attribute Name: force-up

Attribute Type: empty

Netconf edit-config payload

```
<lacp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lacp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<member-aggregation>
<config>
  </force-up><!-- operation="delete"-->
</config>
</member-aggregation>
</interface>
</interfaces>
</lacp>
```

Command Syntax

```
lacp force-up
```

snmp restart lacp

Netconf RPC payload

```
<lacp-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lacp"/>
```

Command Syntax

```
snmp restart lacp
```

clear lacp (<1-65535>|) counters

Attribute Name: aggregate-id

Attribute Type: uint16

Attribute Range: 1-65535

Netconf RPC payload

```
<clear-lacp-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lacp">
<aggregate-id>1</aggregate-id>
</clear-lacp-counters>
```

Command Syntax

```
clear lacp (<1-65535>|) counters
```

debug lacp (event|cli|timer|packet|rx|tx|sync|ha|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (event|cli|timer|packet|rx|tx|sync|ha|all)

Netconf RPC payload

```
<lacp-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lacp">
  <terminal-debug-options>event</terminal-debug-options>
</lacp-terminal-debug-on>
```

Command Syntax

```
debug lacp (event|cli|timer|packet|rx|tx|sync|ha|all)
```

no debug lacp (event|cli|timer|packet|rx|tx|sync|ha|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (event|cli|timer|packet|rx|tx|sync|ha|all)

Netconf RPC payload

```
<lacp-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lacp">
  <terminal-debug-options>event</terminal-debug-options>
</lacp-terminal-debug-off>
```

Command Syntax

```
no debug lacp (event|cli|timer|packet|rx|tx|sync|ha|all)
```

IPI-LLDPV2

Configure enable

Enable or disable the LLDP protocol at node level

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
  <config>
    </enable><!-- operation="delete"-->
  </config>
</global>
</lldp>
```

Command Syntax

```
lldp run
```

Configure notification interval

This object controls the interval between transmission of LLDP notifications during normal transmission periods

Attribute Name: notification-interval

Attribute Type: uint16

Default Value: 30

Attribute Range: 5-3600

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
    <config>
      <notification-interval>5</notification-interval> <!-- operation="delete"-->
    </config>
  </global>
</lldp>
```

Command Syntax

```
lldp notification-interval <5-3600>
```

Configure port description

This attribute specifies to include basic management port description information in LLDP TLV

Attribute Name: port-description

Attribute Type: empty

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
    <global-tlv-control>
      <global-basic-management>
        <config>
          </port-description><!-- operation="delete"-->
        </config>
      </global-basic-management>
    </global-tlv-control>
  </global>
</lldp>
```

Command Syntax

```
lldp tlv-select basic-mgmt port-description
```

Configure system description

This attribute specifies to include basic management system description information in LLDP TLV

Attribute Name: system-description

Attribute Type: empty

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
```

```

<global-tlv-control>
<global-basic-management>
<config>
  </system-description><!-- operation="delete"-->
</config>
</global-basic-management>
</global-tlv-control>
</global>
</lldp>

```

Command Syntax

```
lldp tlv-select basic-mgmt system-description
```

Configure system name

This attribute specifies to include basic management system name information in LLDP TLV

Attribute Name: system-name

Attribute Type: empty

Netconf edit-config payload

```

<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<global>
<global-tlv-control>
<global-basic-management>
<config>
  </system-name><!-- operation="delete"-->
</config>
</global-basic-management>
</global-tlv-control>
</global>
</lldp>

```

Command Syntax

```
lldp tlv-select basic-mgmt system-name
```

Configure system capabilities

This attribute specifies to include basic management system capabilities information in LLDP TLV

Attribute Name: system-capabilities

Attribute Type: empty

Netconf edit-config payload

```

<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<global>
<global-tlv-control>
<global-basic-management>
<config>
  </system-capabilities><!-- operation="delete"-->

```

```
</config>
</global-basic-management>
</global-tlv-control>
</global>
</lldp>
```

Command Syntax

```
lldp tlv-select basic-mgmt system-capabilities
```

Configure management address

This attribute specifies to include basic management management-address information in LLDP TLV

Attribute Name: management-address

Attribute Type: empty

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
    <global-tlv-control>
      <global-basic-management>
        <config>
          </management-address><!-- operation="delete"-->
        </config>
      </global-basic-management>
    </global-tlv-control>
  </global>
</lldp>
```

Command Syntax

```
lldp tlv-select basic-mgmt management-address
```

Configure port vlan id

This attribute specifies to include ieee-8021-org-specific port vlan-id information in LLDP TLV

Attribute Name: port-vlan-id

Attribute Type: empty

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
    <global-tlv-control>
      <global-ieee-8021-org-specific>
        <config>
          </port-vlan-id><!-- operation="delete"-->
        </config>
      </global-ieee-8021-org-specific>
    </global-tlv-control>
  </global>
</lldp>
```

```
</lldp>
```

Command Syntax

```
lldp tlv-select ieee-8021-org-specific port-vlanid
```

Configure port protocol vlan id

This attribute specifies to include ieee-8021-org-specific port protocol vlan-id information in LLDP TLV

Attribute Name: port-protocol-vlan-id

Attribute Type: empty

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
    <global-tlv-control>
      <global-ieee-8021-org-specific>
        <config>
          </port-protocol-vlan-id><!-- operation="delete"-->
        </config>
      </global-ieee-8021-org-specific>
    </global-tlv-control>
  </global>
</lldp>
```

Command Syntax

```
lldp tlv-select ieee-8021-org-specific port-ptcl-vlanid
```

Configure vlan name

This attribute specifies to include ieee-8021-org-specific vlan name information in LLDP TLV

Attribute Name: vlan-name

Attribute Type: empty

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
    <global-tlv-control>
      <global-ieee-8021-org-specific>
        <config>
          </vlan-name><!-- operation="delete"-->
        </config>
      </global-ieee-8021-org-specific>
    </global-tlv-control>
  </global>
</lldp>
```

Command Syntax

```
lldp tlv-select ieee-8021-org-specific vlan-name
```

Configure protocol identifier

This attribute specifies to include ieee-8021-org-specific protocol identifier information in LLDP TLV

Attribute Name: protocol-identifier

Attribute Type: empty

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
    <global-tlv-control>
      <global-ieee-8021-org-specific>
        <config>
          </protocol-identifier><!-- operation="delete"-->
        </config>
      </global-ieee-8021-org-specific>
    </global-tlv-control>
  </global>
</lldp>
```

Command Syntax

```
lldp tlv-select ieee-8021-org-specific ptcl-identity
```

Configure vid digest

This attribute specifies to include ieee-8021-org-specific vid usage digest information in LLDP TLV

Attribute Name: vid-digest

Attribute Type: empty

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
    <global-tlv-control>
      <global-ieee-8021-org-specific>
        <config>
          </vid-digest><!-- operation="delete"-->
        </config>
      </global-ieee-8021-org-specific>
    </global-tlv-control>
  </global>
</lldp>
```

Command Syntax

```
lldp tlv-select ieee-8021-org-specific vid-digest
```

Configure management vlan id

This attribute specifies to include ieee-8021-org-specific management vlan-id information in LLDP TLV

Attribute Name: management-vlan-id

Attribute Type: empty

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
    <global-tlv-control>
      <global-ieee-8021-org-specific>
        <config>
          </management-vlan-id><!-- operation="delete"-->
        </config>
      </global-ieee-8021-org-specific>
    </global-tlv-control>
  </global>
</lldp>
```

Command Syntax

```
lldp tlv-select ieee-8021-org-specific mgmt-vid
```

Configure link aggregation

This attribute specifies to include ieee-8021-org-specific link aggregation information in LLDP TLV

Attribute Name: link-aggregation

Attribute Type: empty

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
    <global-tlv-control>
      <global-ieee-8021-org-specific>
        <config>
          </link-aggregation><!-- operation="delete"-->
        </config>
      </global-ieee-8021-org-specific>
    </global-tlv-control>
  </global>
</lldp>
```

Command Syntax

```
lldp tlv-select ieee-8021-org-specific link-agg
```

Configure mac phy

This attribute specifies to include ieee-8023-org-specific MAC or PHY information in LLDP TLV

Attribute Name: mac-phy

Attribute Type: empty

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
    <global-tlv-control>
      <global-ieee-8023-org-specific>
        <config>
          </mac-phy><!-- operation="delete"-->
        </config>
      </global-ieee-8023-org-specific>
    </global-tlv-control>
  </global>
</lldp>
```

Command Syntax

```
lldp tlv-select ieee-8023-org-specific mac-phy
```

Configure max mtu size

This attribute specifies to include ieee-8023-org-specific maximum mtu size information in LLDP TLV

Attribute Name: max-mtu-size

Attribute Type: empty

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <global>
    <global-tlv-control>
      <global-ieee-8023-org-specific>
        <config>
          </max-mtu-size><!-- operation="delete"-->
        </config>
      </global-ieee-8023-org-specific>
    </global-tlv-control>
  </global>
</lldp>
```

Command Syntax

```
lldp tlv-select ieee-8023-org-specific max-mtu-size
```

Configure locally assigned chassis id

This attribute used to identify the chassis component associated with the local system

Attribute Name: locally-assigned-chassis-id

Attribute Type: string

Default Value: NULL

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
```



```

<global>
<management-if>
<config>
  <locally-assigned-chassis-id>NAME</locally-assigned-chassis-id> <!--
operation="delete"-->
</config>
</management-if>
</global>
</lldp>

```

Command Syntax

```
set lldp chassis locally-assigned NAME
```

Configure options

This attribute returns the terminal debug options which are enabled

Attribute Name: options

Attribute Type: bits (event|rx|tx|message|ha|all)

Netconf edit-config payload

```

<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<debug>
<config>
  <options>event</options> <!-- operation="delete"-->
</config>
</debug>
</lldp>

```

Command Syntax

```
debug lldp (event|rx|tx|message|ha|all)
```

Configure disable lldp agent

Use this attribute to disable LLDP on interface when it is enabled globally

Attribute Name: disable-lldp-agent

Attribute Type: uint8

Netconf edit-config payload

```

<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<interfaces>
<interface>
  <name>WORD</name>
<config>
  <name>WORD</name>
</config>
  </disable-lldp-agent><!-- operation="delete"-->
</interface>
</interfaces>

```

```
</lldp>
```

Command Syntax

```
lldp disable default-agent
```

Configure agent circuit id

DHCP agent circuit ID association on interface

Attribute Name: agent-circuit-id

Attribute Type: string

Default Value: NULL

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <agent-circuit-id>VALUE</agent-circuit-id> <!-- operation="delete"-->
    </interface>
  </interfaces>
</lldp>
```

Command Syntax

```
set lldp agt-circuit-id VALUE
```

Configure med device type

LLDP-MED type of interface. Class-0 is not defined, Class-1 is for generic endpoints and is applicable to all endpoints that require the base LLDP discovery services. Class-2 is for media endpoints and it includes endpoints that have IP media capabilities. Class-3 is for communication endpoints i.e., devices acting as end user communication appliances. Class-4 is for Network Connectivity Device. Class 5-255 are Reserved

Attribute Name: med-device-type

Attribute Type: enum (ep-class1|ep-class2|ep-class3|net-connect)

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <med-device-type>ep-class1</med-device-type> <!-- operation="delete"-->
    </interface>
  </interfaces>
</lldp>
```

```
</lldp>
```

Command Syntax

```
set lldp med-devtype (ep-class1|ep-class2|ep-class3|net-connect)
```

Configure local name

Interface sub type with local name

Attribute Name: local-name

Attribute Type: string

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <local-name>NAME</local-name> <!-- operation="delete"-->
</interface>
</interfaces>
</lldp>
```

Command Syntax

```
set lldp locally-assigned NAME
```

Configure agent type

LLDP agent type on this interface

Attribute Name: agent-type

Attribute Type: enum (non-tpmr-bridge|customer-bridge|default)

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<agents>
<agent> <!-- operation="delete"-->
  <agent-type>default</agent-type>
  <config>
    <agent-type>default</agent-type>
  </config>
</agent>
```

```
</agents>
</interface>
</interfaces>
</lldp>
```

Command Syntax

```
lldp-agent (non-tpmr-bridge|customer-bridge|)
```

Configure enable tx rx

Enables interface with LLDP protocol and specifies to send and(or) receive packets on interface

Attribute Name: enable-tx-rx

Attribute Type: enum (rxonly|txonly|txrx)

Default Value: rxonly

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
  <agents>
    <agent>
      <agent-type>default</agent-type>
      <config>
        <agent-type>default</agent-type>
        <enable-tx-rx>rxonly</enable-tx-rx> <!-- operation="delete"-->
      </config>
    </agent>
  </agents>
</lldp>
```

Command Syntax

```
set lldp enable (rxonly|txonly|txrx)
```

Configure reinit delay

The minimum time interval an LLDP port waits before re-initializing an LLDP transmission

Attribute Name: reinit-delay

Attribute Type: uint32

Default Value: 2

Attribute Range: 1-10

Netconf edit-config payload

```

<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
</interface>
</interfaces>
<agents>
<agent>
  <agent-type>default</agent-type>
  <config>
    <agent-type>default</agent-type>
  </config>
  <transmit>
  <config>
    <reinit-delay>1</reinit-delay> <!-- operation="delete" -->
  </config>
</transmit>
</agent>
</agents>
</lldp>

```

Command Syntax

```
set lldp timer reinit-delay <1-10>
```

Configure message tx interval

The delay between successive LLDP frame transmissions during normal transmission periods

Attribute Name: message-tx-interval

Attribute Type: uint32

Default Value: 30

Attribute Range: 5-3600

Netconf edit-config payload

```

<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
</interface>
</interfaces>
<agents>
<agent>
  <agent-type>default</agent-type>
  <config>

```

```
        <agent-type>default</agent-type>
    </config>
    <transmit>
    <config>
        <message-tx-interval>5</message-tx-interval> <!-- operation="delete"-->
    </config>
</transmit>
</agent>
</agents>
</interface>
</interfaces>
</lldp>
```

Command Syntax

```
set lldp timer msg-tx-interval <5-3600>
```

Configure message tx hold multiplier

Multiplier of message-tx-interval to determine the Time To Live (TTL) that is carried in LLDP frames transmitted by the LLDP agent

Attribute Name: message-tx-hold-multiplier

Attribute Type: uint32

Default Value: 4

Attribute Range: 1-100

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
  <agents>
    <agent>
      <agent-type>default</agent-type>
      <config>
        <agent-type>default</agent-type>
      </config>
      <transmit>
      <config>
        <message-tx-hold-multiplier>1</message-tx-hold-multiplier> <!--
operation="delete"-->
      </config>
    </transmit>
  </agent>
</agents>
</interface>
</interfaces>
```

```
</lldp>
```

Command Syntax

```
set lldp msg-tx-hold <1-100>
```

Configure message fast tx

The interval at which LLDP frames are transmitted on behalf of LLDP agent during fast transmission periods

Attribute Name: message-fast-tx

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-3600

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
  <agents>
    <agent>
      <agent-type>default</agent-type>
      <config>
        <agent-type>default</agent-type>
      </config>
      <transmit>
        <config>
          <message-fast-tx>1</message-fast-tx> <!-- operation="delete"-->
        </config>
      </transmit>
    </agent>
  </agents>
</lldp>
```

Command Syntax

```
set lldp timer msg-fast-tx <1-3600>
```

Configure tx credit max

The maximum number of consecutive LLDPDUs that can be transmitted at any time

Attribute Name: tx-credit-max

Attribute Type: uint32

Default Value: 5

Attribute Range: 1-10

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<agents>
<agent>
  <agent-type>default</agent-type>
  <config>
    <agent-type>default</agent-type>
  </config>
  <transmit>
  <config>
    <tx-credit-max>1</tx-credit-max> <!-- operation="delete" -->
  </config>
</transmit>
</agent>
</agents>
</interface>
</interfaces>
</lldp>
```

Command Syntax

```
set lldp tx-max-credit <1-10>
```

Configure tx fast init

The number of LLDPDUs to send during the fast transmission periods

Attribute Name: tx-fast-init

Attribute Type: uint32

Default Value: 4

Attribute Range: 1-8

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<agents>
<agent>
```



```

    <agent-type>default</agent-type>
  </config>
  <agent-type>default</agent-type>
</config>
<transmit>
<config>
  <tx-fast-init>1</tx-fast-init> <!-- operation="delete"-->
</config>
</transmit>
</agent>
</agents>
</interface>
</interfaces>
</lldp>

```

Command Syntax

```
set lldp tx-fast-init <1-8>
```

Configure neighbor timer

This attribute configures timer to discard received message when remote table is full

Attribute Name: neighbor-timer

Attribute Type: uint32

Attribute Range: 1-65535

Attribute Name: neighbor-limit

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```

<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
  <agents>
    <agent>
      <agent-type>default</agent-type>
      <config>
        <agent-type>default</agent-type>
      </config>
      <receive>
        <config>
          <neighbor-limit>1</neighbor-limit> <!-- operation="delete"-->
          <neighbor-timer>1</neighbor-timer> <!-- operation="delete"-->
        </config>
      </receive>
    </agent>
  </agents>
</lldp>

```

```
</agent>  
</agents>  
</interface>  
</interfaces>  
</lldp>
```

Command Syntax

```
set lldp too-many-neighbors limit <1-65535> discard received-info timer <1-65535>
```

Configure port timer

This attribute configures timer to discard or delete existing info for received message port MAC when the remote table is full

Attribute Name: port-timer

Attribute Type: uint32

Attribute Range: 1-65535

Attribute Name: neighbor-limit

Attribute Type: uint32

Attribute Range: 1-65535

Attribute Name: port-mac

Attribute Type: string

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">  
  <interfaces>  
    <interface>  
      <name>WORD</name>  
      <config>  
        <name>WORD</name>  
      </config>  
    <agents>  
      <agent>  
        <agent-type>default</agent-type>  
        <config>  
          <agent-type>default</agent-type>  
        </config>  
        <receive>  
          <config>  
            <neighbor-limit>1</neighbor-limit> <!-- operation="delete"-->  
            <port-mac>MAC</port-mac> <!-- operation="delete"-->  
            <port-timer>1</port-timer> <!-- operation="delete"-->  
          </config>  
        </receive>  
      </agent>  
    </agents>  
  </interface>  
</interfaces>
```

```
</lldp>
```

Command Syntax

```
set lldp too-many-neighbors limit <1-65535> discard existing-info MAC timer <1-65535>
```

Configure port address

This attribute specifies sub type of the Management Address TLV. Can be configured as mac-addresss or ip-address

Attribute Name: port-address

Attribute Type: enum (mac-address|ip-address)

Default Value: mac-address

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
  <agents>
    <agent>
      <agent-type>default</agent-type>
      <config>
        <agent-type>default</agent-type>
      </config>
      <agent-tlv>
        <config>
          <port-address>mac-address</port-address> <!-- operation="delete"-->
        </config>
      </agent-tlv>
    </agent>
  </agents>
</lldp>
```

Command Syntax

```
set lldp management-address-tlv (mac-address|ip-address)
```

Configure chassis id

This attribute specifies chassis ID subtype for the LLDP agent on a port. Can be configured as if-alias or ip-address or mac-address or if-name or locally-assgined name

Attribute Name: chassis-id

Attribute Type: enum (if-alias|ip-address|mac-address|if-name|locally-assigned)

Default Value: mac-address

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
</interface>
</interfaces>
<agents>
<agent>
  <agent-type>default</agent-type>
  <config>
    <agent-type>default</agent-type>
  </config>
  <agent-tlv>
    <config>
      <chassis-id>mac-address</chassis-id> <!-- operation="delete" -->
    </config>
  </agent-tlv>
</agent>
</agents>
</lldp>
```

Command Syntax

```
set lldp chassis-id-tlv (if-alias|ip-address|mac-address|if-name|locally-assigned)
```

Configure port id

This attribute specifies sub type of the port id TLV. Can be configured as if-alias or mac-address or ip-address or if-name or agent-circuit-id or locally assigned name

Attribute Name: port-id

Attribute Type: enum (if-alias|mac-address|ip-address|if-name|agt-circuit-id|locally-assigned)

Default Value: mac-address

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
</interface>
</interfaces>
<agents>
<agent>
  <agent-type>default</agent-type>
```

```

<config>
  <agent-type>default</agent-type>
</config>
<agent-tlv>
<config>
  <port-id>mac-address</port-id> <!-- operation="delete"-->
</config>
</agent-tlv>
</agent>
</agents>
</interface>
</interfaces>
</lldp>

```

Command Syntax

```
set lldp port-id-tlv (if-alias|mac-address|ip-address|if-name|agt-circuit-
id|locally-assigned)
```

Configure name

This attribute specifies to include basic management port description information in LLDP TLV

Attribute Name: port-description

Attribute Type: enum (not-set|select|unselect)

Default Value: not-set

Netconf edit-config payload

```

<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<agents>
<agent>
  <agent-type>default</agent-type>
  <config>
    <agent-type>default</agent-type>
  </config>
  <tlv-control>
  <basic-management>
  <config>
    <port-description>not-set</port-description> <!-- operation="delete"-->
  </config>
</basic-management>
</tlv-control>
</agent>
</agents>
</interface>

```

```
</interfaces>  
</lldp>
```

Command Syntax

```
lldp tlv basic-mgmt port-description (select|unselect)
```

Configure network policy

Network policy information configured on the port for connected media endpoint. Following network policy will be supported VLAN ID, Priority Tagging, VLAN DSCP

Attribute Name: network-policy

Attribute Type: enum (not-set|select|unselect)

Default Value: not-set

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">  
<interfaces>  
<interface>  
  <name>WORD</name>  
  <config>  
    <name>WORD</name>  
  </config>  
<agents>  
<agent>  
  <agent-type>default</agent-type>  
  <config>  
    <agent-type>default</agent-type>  
  </config>  
  <tlv-control>  
  <tlv-media-capabilities>  
  <config>  
    <network-policy>not-set</network-policy> <!-- operation="delete"-->  
  </config>  
</tlv-media-capabilities>  
</tlv-control>  
</agent>  
</agents>  
</interface>  
</interfaces>  
</lldp>
```

Command Syntax

```
lldp tlv med network-policy (select|unselect)
```

Configure location

Media Tlv type Location information configured for the port

Attribute Name: location

Attribute Type: enum (not-set|select|unselect)

Default Value: not-set

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
</interface>
</interfaces>
<agents>
<agent>
  <agent-type>default</agent-type>
  <config>
    <agent-type>default</agent-type>
  </config>
  <tlv-control>
  <tlv-media-capabilities>
  <config>
    <location>not-set</location> <!-- operation="delete"-->
  </config>
</tlv-media-capabilities>
</tlv-control>
</agent>
</agents>
</interface>
</interfaces>
</lldp>
```

Command Syntax

```
lldp tlv med location (select|unselect)
```

Configure inventory

Includes the TLV for information like hardware revision, software revision etc based on the current hardware platform and the software version

Attribute Name: inventory

Attribute Type: enum (not-set|select|unselect)

Default Value: not-set

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
```

```
    </config>
  <agents>
  <agent>
    <agent-type>default</agent-type>
    <config>
      <agent-type>default</agent-type>
    </config>
    <tlv-control>
    <tlv-media-capabilities>
    <config>
      <inventory>not-set</inventory> <!-- operation="delete"-->
    </config>
  </tlv-media-capabilities>
</tlv-control>
</agent>
</agents>
</interface>
</interfaces>
</lldp>
```

Command Syntax

```
lldp tlv med inventory (select|unselect)
```

Configure media capabilities

Includes various media-capabilities of the box for the neighbor

Attribute Name: media-capabilities

Attribute Type: enum (not-set|select|unselect)

Default Value: not-set

Netconf edit-config payload

```
<lldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <interfaces>
  <interface>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
  <agents>
  <agent>
    <agent-type>default</agent-type>
    <config>
      <agent-type>default</agent-type>
    </config>
    <tlv-control>
    <tlv-media-capabilities>
    <config>
      <media-capabilities>not-set</media-capabilities> <!-- operation="delete"-->
    </config>
  </tlv-media-capabilities>
</tlv-control>
</agent>
</agents>
</interface>
</interfaces>
->
```



```

    </config>
  </tlv-media-capabilities>
</tlv-control>
</agent>
</agents>
</interface>
</interfaces>
</lldp>

```

Command Syntax

```
lldp tlv med media-capabilities (select|unselect)
```

debug lldp (event|rx|tx|message|ha|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (event|rx|tx|message|ha|all)

Netconf RPC payload

```

<lldp-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <terminal-debug-options>event</terminal-debug-options>
</lldp-terminal-debug-on>

```

Command Syntax

```
debug lldp (event|rx|tx|message|ha|all)
```

no debug lldp (event|rx|tx|message|ha|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (event|rx|tx|message|ha|all)

Netconf RPC payload

```

<lldp-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
lldpv2">
  <terminal-debug-options>event</terminal-debug-options>
</lldp-terminal-debug-off>

```

Command Syntax

```
no debug lldp (event|rx|tx|message|ha|all)
```

clear lldp counters ((IFNAME|))

Attribute Name: interface-name

Attribute Type: string

Netconf RPC payload

```

<clear-lldp-counter xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2">
  <interface-name>IFNAME</interface-name>
</clear-lldp-counter>

```

Command Syntax

```
clear lldp counters ((IFNAME|))
```

snmp restart lldp

Netconf RPC payload

```
<lldp-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-lldpv2"/>
```

Command Syntax

```
snmp restart lldp
```

IPI-RIB

Configure fib retain

Use this attribute to configure retain time for stale routes (forever or specific time in seconds) in FIB after RIB restarts

Attribute Name: fib-retain

Attribute Type: union

Default Value: 60

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
  <global>
    <config>
      <fib-retain>60</fib-retain> <!-- operation="delete"-->
    </config>
  </global>
</routing>
```

Command Syntax

```
fib retain (time <1-65535>|forever|)
```

Configure max ecmp paths

Use this attribute to set the maximum number of paths to install in the FIB (Forwarding Information Base) for the ECMP (Equal-Cost MultiPath) feature.

Attribute Name: max-ecmp-paths

Attribute Type: uint8

Default Value: 8

Attribute Range: 1-64

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
  <global>
```

```
<config>
  <max-ecmp-paths>1</max-ecmp-paths> <!-- operation="delete"-->
</config>
</global>
</routing>
```

Command Syntax

```
maximum-paths <1-64>
```

Configure max static routes

Use this attribute to set the maximum number of static routes.

Attribute Name: max-static-routes

Attribute Type: uint32

Default Value: 4294967294

Attribute Range: 1-4294967294

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
<global>
<config>
  <max-static-routes>1</max-static-routes> <!-- operation="delete"-->
</config>
</global>
</routing>
```

Command Syntax

```
max-static-routes <1-4294967294>
```

Configure max fib routes

Use this attribute to set the maximum number of FIB (Forwarding Information Base) routes excluding kernel, connected, and static routes.

Attribute Name: max-fib-routes

Attribute Type: uint32

Attribute Range: 1-16384

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
<global>
<config>
  <max-fib-routes>1</max-fib-routes> <!-- operation="delete"-->
</config>
</global>
</routing>
```

Command Syntax

```
max-fib-routes <1-16384>
```

Configure ipv4 enable bfd all interfaces

Use this attribute to enable static BFD on all interfaces.

Attribute Name: ipv4-enable-bfd-all-interfaces

Attribute Type: empty

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
  <global>
    <config>
      </ipv4-enable-bfd-all-interfaces><!-- operation="delete"-->
    </config>
  </global>
</routing>
```

Command Syntax

```
ip bfd static all-interfaces
```

Configure ipv6 enable bfd all interfaces

Use this attribute to enable ipv6 static BFD on all interfaces.

Attribute Name: ipv6-enable-bfd-all-interfaces

Attribute Type: empty

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
  <global>
    <config>
      </ipv6-enable-bfd-all-interfaces><!-- operation="delete"-->
    </config>
  </global>
</routing>
```

Command Syntax

```
ipv6 bfd static all-interfaces
```

Configure rib options

Use this attribute to debug the ribd process.

Attribute Name: rib-options

Attribute Type: bits (all|events|packet|packet send|packet rcv|packet detail|packet send detail|packet rcv detail|nsm|bfd|monitor|hal events)

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
<debug>
<config>
  <rib-options>all</rib-options> <!-- operation="delete"-->
</config>
</debug>
</routing>
```

Command Syntax

```
debug rib (all|events|packet|packet send|packet recv|packet detail|packet send
detail|packet recv detail|nsm|bfd|monitor|hal events)
```

Configure ipv4 routing options

Use this attribute to debug ip route.

Attribute Name: ipv4-routing-options

Attribute Type: bits (all|add-route|delete-route|mod-route)

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
<debug>
<config>
  <ipv4-routing-options>all</ipv4-routing-options> <!-- operation="delete"-->
</config>
</debug>
</routing>
```

Command Syntax

```
debug ip routing (all|add-route|delete-route|mod-route)
```

Configure ipv6 routing options

Use this attribute to debug ipv6 route.

Attribute Name: ipv6-routing-options

Attribute Type: bits (all|add-route|delete-route|mod-route)

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
<debug>
<config>
  <ipv6-routing-options>all</ipv6-routing-options> <!-- operation="delete"-->
</config>
</debug>
</routing>
```

Command Syntax

```
debug ipv6 routing (all|add-route|delete-route|mod-route)
```

Configure interface name

Use this attribute to create an IPv4 static route where nexthop is interface name.

Attribute Name: interface-name

Attribute Type: string

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
  <static-routes>
    <ipv4>
      <route-vrfs>
        <route-vrf> <!-- operation="delete"-->
          <interface-name>IFNAME</interface-name>
          <config>
            <interface-name>IFNAME</interface-name>
            <gateway-address>A.B.C.D</gateway-address>
            <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
          </config>
          <gateway-address>A.B.C.D</gateway-address>
          <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
        </route-vrf>
      </route-vrfs>
    </ipv4>
  </static-routes>
</routing>
```

Command Syntax

```
ip route (A.B.C.D/M|A.B.C.D A.B.C.D) A.B.C.D IFNAME
```

Configure bfd state

Use this attribute to set fall-over detection.

Attribute Name: bfd-state

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
  <static-routes>
    <ipv4>
      <routes>
        <route>
          <gateway-address>A.B.C.D</gateway-address>
          <config>
            <gateway-address>A.B.C.D</gateway-address>
            <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
          </config>
          <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
          <bfd-state>disable</bfd-state> <!-- operation="delete"-->
        </route>
      </routes>
    </ipv4>
  </static-routes>
</routing>
```

```

</route>
</routes>
</ipv4>
</static-routes>
</routing>

```

Command Syntax

```
ip static A.B.C.D/M A.B.C.D fall-over-bfd (disable|enable)
```

Configure description

Use this attribute to set description of the static route.

Attribute Name: description

Attribute Type: string

Attribute Name: distance

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-255

Attribute Name: tag

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Attribute Name: track-id

Attribute Type: uint16

Attribute Range: 1-500

Netconf edit-config payload

```

<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
  <static-routes>
    <ipv4>
      <routes>
        <route>
          <gateway-address>A.B.C.D</gateway-address>
          <config>
            <gateway-address>A.B.C.D</gateway-address>
            <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
            <distance>1</distance> <!-- operation="delete"-->
            <tag>0</tag> <!-- operation="delete"-->
            <track-id>1</track-id> <!-- operation="delete"-->
          </config>
          <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
          <description>LINE</description> <!-- operation="delete"-->
        </route>
      </routes>
    </ipv4>

```

```
</static-routes>  
</routing>
```

Command Syntax

```
ip route (A.B.C.D/M|A.B.C.D A.B.C.D) A.B.C.D (<1-255>|) (tag <0-4294967295>|)  
(track <1-500>|) (description LINE|)
```

Configure destination prefix

Use this attribute to set description of the static route.

Attribute Name: description

Attribute Type: string

Attribute Name: distance

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-255

Attribute Name: tag

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Attribute Name: track-id

Attribute Type: uint16

Attribute Range: 1-500

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">  
<static-routes>  
<ipv4>  
<interface-routes>  
<interface-route>  
  <interface-name>IFNAME</interface-name>  
  <config>  
    <interface-name>IFNAME</interface-name>  
    <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>  
    <distance>1</distance> <!-- operation="delete"-->  
    <tag>0</tag> <!-- operation="delete"-->  
    <track-id>1</track-id> <!-- operation="delete"-->  
  </config>  
  <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>  
  <description>LINE</description> <!-- operation="delete"-->  
</interface-route>  
</interface-routes>  
</ipv4>  
</static-routes>  
</routing>
```


Command Syntax

```
ip route (A.B.C.D/M|A.B.C.D A.B.C.D) IFNAME (<1-255>|) (tag <0-4294967295>|) (track
<1-500>|) (description LINE|)
```

Configure distance

Use this attribute to configure administrative distance for mroute.

Attribute Name: distance

Attribute Type: uint32

Attribute Range: 0-255

Attribute Name: gateway-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
<static-routes>
<ipv4>
<multicast-routes>
<multicast-route>
  <protocol-type>default</protocol-type>
  <config>
    <protocol-type>default</protocol-type>
    <source-prefix>A.B.C.D/M</source-prefix>
    <gateway-address>A.B.C.D</gateway-address>
  </config>
  <source-prefix>A.B.C.D/M</source-prefix>
  <distance>0</distance>
</multicast-route>
</multicast-routes>
</ipv4>
</static-routes>
</routing>
```

Command Syntax

```
ip mroute A.B.C.D/M ((static|rip|ospf|bgp|isis)|) A.B.C.D (<0-255>|)
```

Configure gateway address

Use this attribute to create an IPv6 static route for a subnet.

This command is supported when following feature are enabled ipv6 feature

Attribute Name: gateway-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
<static-routes>
```

```
<ipv6>
<routes>
<route> <!-- operation="delete"-->
  <gateway-address>X:X::X:X</gateway-address>
  <config>
    <gateway-address>X:X::X:X</gateway-address>
    <destination-prefix>X:X::X:X/M</destination-prefix>
  </config>
  <destination-prefix>X:X::X:X/M</destination-prefix>
</route>
</routes>
</ipv6>
</static-routes>
</routing>
```

Command Syntax

```
ipv6 route X:X::X:X/M X:X::X:X
```

Configure track id

Use this attribute to set description of the static route.

This command is supported when following feature are enabled ipv6 feature

Attribute Name: description

Attribute Type: string

Attribute Name: distance

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-255

Attribute Name: track-id

Attribute Type: uint16

Attribute Range: 1-500

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
<static-routes>
<ipv6>
<routes>
<route>
  <gateway-address>X:X::X:X</gateway-address>
  <config>
    <gateway-address>X:X::X:X</gateway-address>
    <destination-prefix>X:X::X:X/M</destination-prefix>
    <distance>1</distance> <!-- operation="delete"-->
    <track-id>1</track-id> <!-- operation="delete"-->
  </config>
  <destination-prefix>X:X::X:X/M</destination-prefix>
```

```

    <description>LINE</description> <!-- operation="delete"-->
</route>
</routes>
</ipv6>
</static-routes>
</routing>

```

Command Syntax

```
ipv6 route X:X::X:X/M X:X::X:X (<1-255>|) (track <1-500>|) (description LINE|)
```

Configure source prefix

Use this attribute to configure administrative distance for mroute.

This command is supported when following feature are enabled ipv6 feature

Attribute Name: distance

Attribute Type: uint32

Attribute Range: 0-255

Attribute Name: gateway-mroute

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```

<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
<static-routes>
<ipv6>
<multicast-routes>
<multicast-route>
  <protocol-type>default</protocol-type>
  <config>
    <protocol-type>default</protocol-type>
    <source-prefix>X:X::X:X/M</source-prefix>
  </config>
  <source-prefix>X:X::X:X/M</source-prefix>
</multicast-route>
</multicast-routes>
</ipv6>
</static-routes>
</routing>

```

Command Syntax

```
ipv6 mroute X:X::X:X/M ((static|rip|ospf|bgp|isis)|) X:X::X:X (<0-255>|)
```

Configure ipv4 enable bfd

Use this attribute to enable or disable Bidirectional Forwarding Detection static routes.

This command is supported when following feature are enabled bfd feature

Attribute Name: ipv4-enable-bfd

Attribute Type: enum (enable|disable)

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <bfd>
      <config>
        <ipv4-enable-bfd>enable</ipv4-enable-bfd> <!-- operation="delete"-->
      </config>
    </bfd>
  </interface>
</interfaces>
</routing>
```

Command Syntax

```
ip static bfd (enable|disable)
```

Configure ipv6 enable bfd

Use this attribute to enable or disable Bidirectional Forwarding Detection static routes.

This command is supported when following feature are enabled bfd feature

Attribute Name: ipv6-enable-bfd

Attribute Type: enum (enable|disable)

Netconf edit-config payload

```
<routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <bfd>
      <config>
        <ipv6-enable-bfd>enable</ipv6-enable-bfd> <!-- operation="delete"-->
      </config>
    </bfd>
  </interface>
</interfaces>
</routing>
```

```
</interface>  
</interfaces>  
</routing>
```

Command Syntax

```
ipv6 static bfd (enable|disable)
```

snmp restart rib

Netconf RPC payload

```
<rib-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib"/>
```

Command Syntax

```
snmp restart rib
```

clear ip route kernel

Netconf RPC payload

```
<clear-ip-stale-kernel-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib"/>
```

Command Syntax

```
clear ip route kernel
```

clear ip kernel route

Netconf RPC payload

```
<clear-ip-kernel-route xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib"/>
```

Command Syntax

```
clear ip kernel route
```

clear ipv6 route kernel

Netconf RPC payload

```
<clear-ipv6-stale-kernel-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib"/>
```

Command Syntax

```
clear ipv6 route kernel
```

clear ip route *

Netconf RPC payload

```
<clear-ip-route-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib"/>
```

Command Syntax

```
clear ip route *
```

clear ip route A.B.C.D/M

Attribute Name: prefix-address

Attribute Type: string

Netconf RPC payload

```
<clear-ip-route xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">  
<prefix-address>A.B.C.D/M</prefix-address>  
</clear-ip-route>
```

Command Syntax

```
clear ip route A.B.C.D/M
```

clear ipv4 route *

Netconf RPC payload

```
<clear-ipv4-route-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib"/>
```

Command Syntax

```
clear ipv4 route *
```

clear ipv4 route A.B.C.D/M

Attribute Name: prefix-address

Attribute Type: string

Netconf RPC payload

```
<clear-ipv4-route xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">  
<prefix-address>A.B.C.D/M</prefix-address>  
</clear-ipv4-route>
```

Command Syntax

```
clear ipv4 route A.B.C.D/M
```

clear ipv6 route *

Netconf RPC payload

```
<clear-ipv6-route-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib"/>
```

Command Syntax

```
clear ipv6 route *
```

clear ipv6 route X:X::X:X/M

Attribute Name: prefix-ipv6-address

Attribute Type: string

Netconf RPC payload

```
<clear-ipv6-route xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
  <prefix-ipv6-address>X:X::X:X/M</prefix-ipv6-address>
</clear-ipv6-route>
```

Command Syntax

```
clear ipv6 route X:X::X:X/M
```

debug rib (all|events|packet|packet send|packet rcv|packet detail|packet send detail|packet rcv detail|nsm|bfd|monitor|hal events|hal ipc)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|events|packet|packet send|packet rcv|packet detail|packet send detail|packet rcv detail|nsm|bfd|monitor|hal events|hal ipc)

Netconf RPC payload

```
<rib-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
  <terminal-debug-options>all</terminal-debug-options>
</rib-terminal-debug-on>
```

Command Syntax

```
debug rib (all|events|packet|packet send|packet rcv|packet detail|packet send
  detail|packet rcv detail|nsm|bfd|monitor|hal events|hal ipc)
```

no debug rib (all|events|packet|packet send|packet rcv|packet detail|packet send detail|packet rcv detail|nsm|bfd|monitor|hal events|hal ipc)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|events|packet|packet send|packet rcv|packet detail|packet send detail|packet rcv detail|nsm|bfd|monitor|hal events|hal ipc)

Netconf RPC payload

```
<rib-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
  <terminal-debug-options>all</terminal-debug-options>
</rib-terminal-debug-off>
```

Command Syntax

```
no debug rib (all|events|packet|packet send|packet rcv|packet detail|packet send
  detail|packet rcv detail|nsm|bfd|monitor|hal events|hal ipc)
```

debug ip routing (all|add-route|delete-route|mod-route)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|add-route|delete-route|mod-route)

Netconf RPC payload

```
<rib-terminal-debug-ipv4-routing-on xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-rib">
  <terminal-debug-options>all</terminal-debug-options>
</rib-terminal-debug-ipv4-routing-on>
```

Command Syntax

```
debug ip routing (all|add-route|delete-route|mod-route)
```

no debug ip routing (all|add-route|delete-route|mod-route)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|add-route|delete-route|mod-route)

Netconf RPC payload

```
<rib-terminal-debug-ipv4-routing-off xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-rib">
  <terminal-debug-options>all</terminal-debug-options>
</rib-terminal-debug-ipv4-routing-off>
```

Command Syntax

```
no debug ip routing (all|add-route|delete-route|mod-route)
```

debug ipv6 routing (all|add-route|delete-route|mod-route)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|add-route|delete-route|mod-route)

Netconf RPC payload

```
<rib-terminal-debug-ipv6-routing-on xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-rib">
  <terminal-debug-options>all</terminal-debug-options>
</rib-terminal-debug-ipv6-routing-on>
```

Command Syntax

```
debug ipv6 routing (all|add-route|delete-route|mod-route)
```

no debug ipv6 routing (all|add-route|delete-route|mod-route)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|add-route|delete-route|mod-route)

Netconf RPC payload

```

<rib-terminal-debug-ipv6-routing-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib">
  <terminal-debug-options>all</terminal-debug-options>
</rib-terminal-debug-ipv6-routing-off>

```

Command Syntax

```
no debug ipv6 routing (all|add-route|delete-route|mod-route)
```

IPI-RIB-VRF

Configure ipv4 enable bfd all interfaces

Use this attribute to enable static BFD on all interfaces.

Attribute Name: ipv4-enable-bfd-all-interfaces

Attribute Type: empty

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
      <global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
        <config>
          </ipv4-enable-bfd-all-interfaces><!-- operation="delete"-->
        </config>
      </global>
    </vrf>
  </network-instance>
</network-instances>

```

Command Syntax

```
ip bfd vrf NAME static all-interfaces
```

Configure ipv6 enable bfd all interfaces

Use this attribute to enable ipv6 static BFD on all interfaces.

Attribute Name: ipv6-enable-bfd-all-interfaces

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
  <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
    <global xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
      <config>
        </ipv6-enable-bfd-all-interfaces><!-- operation="delete"-->
      </config>
    </global>
  </vrf>
</network-instance>
</network-instances>
```

Command Syntax

```
ipv6 bfd vrf NAME static all-interfaces
```

Configure enable global table lookup

Use this attribute to create an IPv4 vrf static route with gateway in default vrf table.

Attribute Name: enable-global-table-lookup

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
  <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
    <static-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
      <ipv4>
        <gateway-interface-routes-global>
          <gateway-interface-route-global> <!-- operation="delete"-->
            </enable-global-table-lookup>
          </config>
          </enable-global-table-lookup>
          <interface-name>IFNAME</interface-name>
          <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
        </static-routes>
      </ipv4>
    </static-routes>
  </vrf>
</network-instance>
</network-instances>
```

```

    </config>
    <interface-name>IFNAME</interface-name>
    <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
  </gateway-interface-route-global>
</gateway-interface-routes-global>
</ipv4>
</static-routes>
</vrf>
</network-instance>
</network-instances>

```

Command Syntax

```
ip route vrf NAME (A.B.C.D/M|A.B.C.D A.B.C.D) IFNAME global
```

Configure interface name

Use this attribute to create an IPv4 static route where nextthop is a global interface.

Attribute Name: interface-name

Attribute Type: string

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
  <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
    <static-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
      <ipv4>
        <gateway-interface-routes-global>
          <gateway-interface-route-global>
            </enable-global-table-lookup>
          <config>
            </enable-global-table-lookup><!-- operation="delete"-->
            <interface-name>IFNAME</interface-name>
            <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
          </config>
            <interface-name>IFNAME</interface-name>
            <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
          </gateway-interface-route-global>
        </gateway-interface-routes-global>
      </ipv4>
    </static-routes>
  </vrf>
</network-instance>

```

```
</network-instances>
```

Command Syntax

```
ip route vrf NAME (A.B.C.D/M|A.B.C.D A.B.C.D) IFNAME global IFNAME
```

Configure track id

Use this attribute to track a object.

Attribute Name: track-id

Attribute Type: uint16

Attribute Range: 1-500

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
      <static-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
        <ipv4>
          <gateway-interface-routes-global>
            <gateway-interface-route-global>
              </enable-global-table-lookup>
            <config>
              </enable-global-table-lookup><!-- operation="delete"-->
              <interface-name>IFNAME</interface-name>
              <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
            </config>
            <interface-name>IFNAME</interface-name>
            <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
            <track-id>1</track-id> <!-- operation="delete"-->
          </gateway-interface-route-global>
        </gateway-interface-routes-global>
      </ipv4>
    </static-routes>
  </vrf>
</network-instance>
</network-instances>
```

Command Syntax

```
ip route vrf NAME (A.B.C.D/M|A.B.C.D A.B.C.D) IFNAME global track <1-500>
```

Configure bfd state

Use this attribute to set fall-over detection.

Attribute Name: bfd-state

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
      <static-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
        <ipv4>
          <routes>
            <route>
              <gateway-address>A.B.C.D</gateway-address>
              <config>
                <gateway-address>A.B.C.D</gateway-address>
                <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
              </config>
                <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
                <bfd-state>disable</bfd-state> <!-- operation="delete"-->
            </route>
          </routes>
        </ipv4>
      </static-routes>
    </vrf>
  </network-instance>
</network-instances>
```

Command Syntax

```
ip static vrf NAME A.B.C.D/M A.B.C.D fall-over-bfd (disable|enable)
```

Configure instance type

Use this attribute to create an IPv4 static route where nexthop is interface name.

Attribute Name: interface-name

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
```

```
<network-instance>
  <instance-name>NAME</instance-name>
  <config>
    <instance-name>WORD</instance-name>
    <instance-type>vrf</instance-type>
  </config>
  <instance-type>vrf</instance-type>
  <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
    <static-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
      <ipv4>
        <routes>
          <route>
            <gateway-address>A.B.C.D</gateway-address>
            <config>
              <gateway-address>A.B.C.D</gateway-address>
              <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
            </config>
            <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
            <gateway-interface-routes>
              <gateway-interface-route> <!-- operation="delete"-->
                <interface-name>IFNAME</interface-name>
                <config>
                  <interface-name>IFNAME</interface-name>
                </config>
              </gateway-interface-route>
            </gateway-interface-routes>
          </route>
        </routes>
      </ipv4>
    </static-routes>
  </vrf>
</network-instance>
</network-instances>
```

Command Syntax

```
ip route vrf NAME A.B.C.D/M A.B.C.D IFNAME
```

Configure description

Use this attribute to set description of the static route.

Attribute Name: description

Attribute Type: string

Attribute Name: distance

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-255

Attribute Name: tag

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Attribute Name: track-id

Attribute Type: uint16

Attribute Range: 1-500

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
      <static-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
        <ipv4>
          <routes>
            <route>
              <gateway-address>A.B.C.D</gateway-address>
              <config>
                <gateway-address>A.B.C.D</gateway-address>
                <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
              </config>
              <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
              <gateway-interface-routes>
                <gateway-interface-route>
                  <interface-name>IFNAME</interface-name>
                  <config>
                    <interface-name>IFNAME</interface-name>
                    <distance>1</distance> <!-- operation="delete"-->
                    <tag>0</tag><!-- operation="delete"-->
                    <track-id>1</track-id> <!-- operation="delete"-->
                  </config>
                  <description>LINE</description> <!-- operation="delete"-->
                </gateway-interface-route>
              </gateway-interface-routes>
            </route>
          </routes>
        </ipv4>
      </static-routes>
    </vrf>
  </network-instance>
</network-instances>
```

Command Syntax

```
ip route vrf NAME (A.B.C.D/M|A.B.C.D A.B.C.D) A.B.C.D IFNAME (<1-255>|) (tag <0-4294967295>|) (track <1-500>|) (description LINE|)
```

Configure instance name

Use this attribute to create an IPv4 vrf static route with gateway in default vrf table.

Attribute Name: enable-global-table-lookup

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
  <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
    <static-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
      <ipv4>
        <routes>
          <route>
            <gateway-address>A.B.C.D</gateway-address>
            <config>
              <gateway-address>A.B.C.D</gateway-address>
              <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
            </config>
            <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
            <interface-routes-global>
              <interface-route-global> <!-- operation="delete"-->
                </enable-global-table-lookup>
                <config>
                  </enable-global-table-lookup>
                  <interface-name>IFNAME</interface-name>
                </config>
                <interface-name>IFNAME</interface-name>
              </interface-route-global>
            </interface-routes-global>
          </route>
        </routes>
      </ipv4>
    </static-routes>
  </vrf>
</network-instance>
</network-instances>
```


Command Syntax

```
ip route vrf NAME (A.B.C.D/M|A.B.C.D A.B.C.D) A.B.C.D IFNAME global
```

Configure destination prefix

Use this attribute to track a object.

Attribute Name: track-id

Attribute Type: uint16

Attribute Range: 1-500

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
      <static-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
        <ipv4>
          <routes>
            <route>
              <gateway-address>A.B.C.D</gateway-address>
              <config>
                <gateway-address>A.B.C.D</gateway-address>
                <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
              </config>
              <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
            <interface-routes-global>
              <interface-route-global>
                </enable-global-table-lookup>
                <config>
                  </enable-global-table-lookup><!-- operation="delete"-->
                  <interface-name>IFNAME</interface-name>
                </config>
                <interface-name>IFNAME</interface-name>
                <track-id>1</track-id> <!-- operation="delete"-->
              </interface-route-global>
            </interface-routes-global>
          </route>
        </routes>
      </ipv4>
    </static-routes>
  </vrf>
</network-instance>
</network-instances>
```

Command Syntax

```
ip route vrf NAME (A.B.C.D/M|A.B.C.D A.B.C.D) A.B.C.D IFNAME global track <1-500>
```

Configure distance

Use this attribute to set description of the static route.

Attribute Name: description

Attribute Type: string

Attribute Name: distance

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-255

Attribute Name: tag

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Attribute Name: track-id

Attribute Type: uint16

Attribute Range: 1-500

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
  <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
    <static-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
      <ipv4>
        <interface-routes>
          <interface-route>
            <interface-name>IFNAME</interface-name>
            <config>
              <interface-name>IFNAME</interface-name>
              <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
              <distance>1</distance> <!-- operation="delete"-->
              <tag>0</tag> <!-- operation="delete"-->
              <track-id>1</track-id> <!-- operation="delete"-->
            </config>
            <destination-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</destination-prefix>
            <description>LINE</description> <!-- operation="delete"-->
          </interface-route>
        </interface-routes>
      </ipv4>
    </static-routes>
  </vrf>
</network-instance>
</network-instances>
```

```

    </interface-route>
  </interface-routes>
</ipv4>
</static-routes>
</vrf>
</network-instance>
</network-instances>

```

Command Syntax

```

ip route vrf NAME (A.B.C.D/M|A.B.C.D A.B.C.D) IFNAME (<1-255>|) (tag <0-4294967295>|) (track <1-500>|) (description LINE|)

```

Configure source prefix

Use this attribute to configure administrative distance for mroute.

Attribute Name: distance

Attribute Type: uint32

Attribute Range: 0-255

Attribute Name: gateway-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
      <static-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
        <ipv4>
          <multicast-routes>
            <multicast-route>
              <protocol-type>default</protocol-type>
              <config>
                <protocol-type>default</protocol-type>
                <source-prefix>A.B.C.D/M</source-prefix>
                <gateway-address>A.B.C.D</gateway-address>
              </config>
              <source-prefix>A.B.C.D/M</source-prefix>
              <distance>0</distance>
            </multicast-route>
          </multicast-routes>
        </ipv4>
      </static-routes>
    </vrf>
  </network-instance>
</network-instances>

```

```
</vrf>  
</network-instance>  
</network-instances>
```

Command Syntax

```
ip mroute vrf NAME A.B.C.D/M ((static|rip|ospf|bgp|isis)|) A.B.C.D (<0-255>|)
```

Configure destination prefix

Network Instance Type

Attribute Name: instance-type

Attribute Type: enum (vrf|mac-vrf|l2ni|vpls|vpws|evpn|cross-connect|bridge-domain)

Attribute Name: destination-prefix

Attribute Type: string

Attribute Name: interface-name

Attribute Type: string

Attribute Name: enable-ipv6-global-table-lookup

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-  
instance">  
  <network-instance> <!-- operation="delete"-->  
    <instance-type>vrf</instance-type>  
    <config>  
      <instance-type>vrf</instance-type>  
      <instance-name>WORD</instance-name>  
    </config>  
    <instance-name>WORD</instance-name>  
  <static-routes>  
  <ipv6>  
  <interface-routes-global>  
  <interface-route-global>  
    <destination-prefix>X:X::X:X/M</destination-prefix>  
    <interface-name>IFNAME</interface-name>  
    </enable-ipv6-global-table-lookup>  
  </interface-route-global>  
  </interface-routes-global>  
</ipv6>  
</static-routes>  
</network-instance>  
</network-instances>
```

Command Syntax

```
ipv6 route vrf NAME X:X::X:X/M IFNAME global
```

Configure enable ipv6 global table lookup

Use this attribute to track a object.

Attribute Name: track-id

Attribute Type: uint16

Attribute Range: 1-500

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
  <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
    <static-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
      <ipv6>
        <interface-routes-global>
          <interface-route-global>
            </enable-ipv6-global-table-lookup>
            <config>
              </enable-ipv6-global-table-lookup><!-- operation="delete"-->
              <interface-name>IFNAME</interface-name>
              <destination-prefix>X:X::X:X/M</destination-prefix>
            </config>
            <interface-name>IFNAME</interface-name>
            <destination-prefix>X:X::X:X/M</destination-prefix>
            <track-id>1</track-id> <!-- operation="delete"-->
          </interface-route-global>
        </interface-routes-global>
      </ipv6>
    </static-routes>
  </vrf>
</network-instance>
</network-instances>
```

Command Syntax

```
ipv6 route vrf NAME X:X::X:X/M IFNAME global track <1-500>
```

Configure gateway address

Network Instance Type

Attribute Name: instance-type

Attribute Type: enum (vrf|mac-vrf|l2ni|vpls|vpws|evpn|cross-connect|bridge-domain)

Attribute Name: destination-prefix

Attribute Type: string

Attribute Name: gateway-address

Attribute Type: inet:ipv6-address

Attribute Name: interface-name

Attribute Type: string

Attribute Name: enable-ipv6-global-table-lookup

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance> <!-- operation="delete"-->
    <instance-type>vrf</instance-type>
    <config>
      <instance-type>vrf</instance-type>
      <instance-name>WORD</instance-name>
    </config>
    <instance-name>WORD</instance-name>
  <static-routes>
  <ipv6>
    <gateway-interface-routes-global>
    <gateway-interface-route-global>
      <destination-prefix>X:X::X:X/M</destination-prefix>
      <gateway-address>X:X::X:X</gateway-address>
      <interface-name>IFNAME</interface-name>
      </enable-ipv6-global-table-lookup>
      </gateway-interface-route-global>
    </gateway-interface-routes-global>
  </ipv6>
</static-routes>
</network-instance>
</network-instances>
```

Command Syntax

```
ipv6 route vrf NAME X:X::X:X/M X:X::X:X IFNAME global
```

Configure gateway address

Use this attribute to track a object.

Attribute Name: track-id

Attribute Type: uint16

Attribute Range: 1-500

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
```

```

<instance-name>NAME</instance-name>
<config>
  <instance-name>WORD</instance-name>
  <instance-type>vrf</instance-type>
</config>
  <instance-type>vrf</instance-type>
<vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
  <static-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
  <ipv6>
  <gateway-interface-routes-global>
  <gateway-interface-route-global>
    </enable-ipv6-global-table-lookup>
    <config>
      </enable-ipv6-global-table-lookup><!-- operation="delete"-->
      <interface-name>IFNAME</interface-name>
      <gateway-address>X:X::X:X</gateway-address>
      <destination-prefix>X:X::X:X/M</destination-prefix>
    </config>
      <interface-name>IFNAME</interface-name>
      <gateway-address>X:X::X:X</gateway-address>
      <destination-prefix>X:X::X:X/M</destination-prefix>
      <track-id>1</track-id> <!-- operation="delete"-->
    </gateway-interface-route-global>
  </gateway-interface-routes-global>
</ipv6>
</static-routes>
</vrf>
</network-instance>
</network-instances>

```

Command Syntax

```
ipv6 route vrf NAME X:X::X:X/M X:X::X:X IFNAME global track <1-500>
```

Configure protocol type

Use this attribute to configure administrative distance for mroute.

This command is supported when following feature are enabled ipv6 feature

Attribute Name: distance

Attribute Type: uint32

Attribute Range: 0-255

Attribute Name: gateway-mroute

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>

```

```
<config>
  <instance-name>WORD</instance-name>
  <instance-type>vrf</instance-type>
</config>
  <instance-type>vrf</instance-type>
<vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
  <static-routes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
    <ipv6>
      <multicast-routes>
        <multicast-route>
          <protocol-type>default</protocol-type>
          <config>
            <protocol-type>default</protocol-type>
            <source-prefix>X:X::X:X/M</source-prefix>
          </config>
          <source-prefix>X:X::X:X/M</source-prefix>
          <nexthop>
            <config>
              <gateway-mroute>X:X::X:X</gateway-mroute>
              <distance>0</distance>
            </config>
          </nexthop>
        </multicast-route>
      </multicast-routes>
    </ipv6>
  </static-routes>
</vrf>
</network-instance>
</network-instances>
```

Command Syntax

```
ipv6 mroute vrf NAME X:X::X:X/M ((static|rip|ospf|bgp|isis)|) X:X::X:X (<0-255>|)
```

clear ip route vrf NAME *

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<clear-ip-vrf-route-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-
vrf">
  <vrf-name>NAME</vrf-name>
</clear-ip-vrf-route-all>
```

Command Syntax

```
clear ip route vrf NAME *
```

clear ip route vrf NAME A.B.C.D/M

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: prefix-address

Attribute Type: string

Netconf RPC payload

```
<clear-ip-vrf-route xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
  <vrf-name>NAME</vrf-name>
  <prefix-address>A.B.C.D/M</prefix-address>
</clear-ip-vrf-route>
```

Command Syntax

```
clear ip route vrf NAME A.B.C.D/M
```

clear ipv4 route vrf NAME *

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<clear-ipv4-vrf-route-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-
vrf">
  <vrf-name>NAME</vrf-name>
</clear-ipv4-vrf-route-all>
```

Command Syntax

```
clear ipv4 route vrf NAME *
```

clear ipv4 route vrf NAME A.B.C.D/M

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: prefix-address

Attribute Type: string

Netconf RPC payload

```
<clear-ipv4-vrf-route xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
  <vrf-name>NAME</vrf-name>
  <prefix-address>A.B.C.D/M</prefix-address>
</clear-ipv4-vrf-route>
```

Command Syntax

```
clear ipv4 route vrf NAME A.B.C.D/M
```

clear ipv6 route vrf NAME *

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<clear-ipv6-vrf-route-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
  <vrf-name>NAME</vrf-name>
</clear-ipv6-vrf-route-all>
```

Command Syntax

```
clear ipv6 route vrf NAME *
```

clear ipv6 route vrf NAME X:X::X:X/M

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: prefix-ipv6-address

Attribute Type: string

Netconf RPC payload

```
<clear-ipv6-vrf-route xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rib-vrf">
  <vrf-name>NAME</vrf-name>
  <prefix-ipv6-address>X:X::X:X/M</prefix-ipv6-address>
</clear-ipv6-vrf-route>
```

Command Syntax

```
clear ipv6 route vrf NAME X:X::X:X/M
```

IPI-OSPF

Configure area interface config mode

Use this attribute to set the OSPF area interface mode operation. Enabling this makes OSPF compatible with OpenConfig datamodel.

Attribute Name: area-interface-config-mode

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <global>
  <config>
    </area-interface-config-mode><!-- operation="delete"-->
  </config>
```

```
</global>  
</ospfv2>
```

Command Syntax

```
ospf area-interface-config-mode
```

Configure enable multi instance capability

Use this attribute to enable OSPF multiple instances capability.

Attribute Name: enable-multi-instance-capability

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<global>  
<config>  
  </enable-multi-instance-capability><!-- operation="delete"-->  
</config>  
</global>  
</ospfv2>
```

Command Syntax

```
enable ext-ospf-multi-inst
```

Configure grace period

Use this attribute to set the grace period for restarting the router OSPF.

This command is supported when following feature are enabled Restart capability

Attribute Name: grace-period

Attribute Type: uint16

Default Value: 120

Attribute Range: 2-1800

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<global>  
<graceful-restart>  
<config>  
  <grace-period>2</grace-period> <!-- operation="delete"-->  
</config>  
</graceful-restart>  
</global>  
</ospfv2>
```

Command Syntax

```
ospf restart grace-period <2-1800>
```

Configure max grace period

Use this attribute to set the maximum grace period. Act as helper only if received grace-period is less than this value.

This command is supported when following feature are enabled Restart capability

Attribute Name: max-grace-period

Attribute Type: uint16

Attribute Range: 2-1800

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <global>
    <graceful-restart>
      <helper>
        <config>
          <max-grace-period>2</max-grace-period> <!-- operation="delete"-->
        </config>
      </helper>
    </graceful-restart>
  </global>
</ospfv2>
```

Command Syntax

```
ospf restart helper max-grace-period <2-1800>
```

Configure disable all neighbors

Use this attribute to prevent the router OSPF from acting as helper for any neighbor.

This command is supported when following feature are enabled Restart capability

Attribute Name: disable-all-neighbors

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <global>
    <graceful-restart>
      <helper>
        <config>
          </disable-all-neighbors><!-- operation="delete"-->
        </config>
      </helper>
    </graceful-restart>
  </global>
</ospfv2>
```

Command Syntax

```
ospf restart helper never
```

Configure disable neighbor

Use this attribute to set the neighbor router-id for which never act as helper.

This command is supported when following feature are enabled Restart capability

Attribute Name: disable-neighbor

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <global>
    <graceful-restart>
    <helper>
    <config>
      <disable-neighbor>A.B.C.D</disable-neighbor> <!-- operation="delete"-->
    </config>
  </helper>
</graceful-restart>
</global>
</ospfv2>
```

Command Syntax

```
ospf restart helper never router-id A.B.C.D
```

Configure tie break method

Use this attribute to set the CSPF (Constrained Shortest Path First) tie-break method.

This command is supported when following feature are enabled OSPF Constrained Shortest Path First (CSPF)

Attribute Name: tie-break-method

Attribute Type: enum (random|most-fill|least-fill)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <global>
    <cspf>
    <config>
      <tie-break-method>random</tie-break-method> <!-- operation="delete"-->
    </config>
  </cspf>
</global>
</ospfv2>
```

Command Syntax

```
ospf cspf tie-break (random|most-fill|least-fill)
```

Configure default retry interval

Use this attribute to set the CSPF (Constrained Shortest Path First) default computation retry-interval.

This command is supported when following feature are enabled OSPF Constrained Shortest Path First (CSPF)

Attribute Name: default-retry-interval

Attribute Type: uint16

Attribute Range: 1-3600

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <global>
    <cspf>
      <config>
        <default-retry-interval>1</default-retry-interval> <!-- operation="delete"-->
      </config>
    </cspf>
  </global>
</ospfv2>
```

Command Syntax

```
ospf cspf default-retry-interval <1-3600>
```

Configure enable better protection

Use this attribute to enable the CSPF (Constrained Shortest Path First) protection type.

This command is supported when following feature are enabled OSPF Constrained Shortest Path First (CSPF)

Attribute Name: enable-better-protection

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <global>
    <cspf>
      <config>
        </enable-better-protection><!-- operation="delete"-->
      </config>
    </cspf>
  </global>
</ospfv2>
```

Command Syntax

```
ospf cspf enable-better-protection
```

Configure ospf id

Use this attribute to set the OSPF process ID.

Attribute Name: ospf-id

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process> <!-- operation="delete"-->
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
        <vrf-name>WORD</vrf-name>
      </config>
    </process>
  </processes>
</ospfv2>
```

Command Syntax

```
router ospf (<0-65535>|) (WORD|)
```

Configure router id

Use this attribute to set a router ID for the OSPF process. Configure each router OSPF with an unique router ID.

Attribute Name: router-id

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
      <router-id>A.B.C.D</router-id> <!-- operation="delete"-->
    </process>
  </processes>
</ospfv2>
```

Command Syntax

```
router-id A.B.C.D
```

Configure flood reduction

Use this attribute to enable flood reduction on all OSPF interfaces.

Attribute Name: flood-reduction

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
      </flood-reduction><!-- operation="delete"-->
    </process>
  </processes>
</ospfv2>
```

Command Syntax

```
ospf flood-reduction
```

Configure rfc1583 compatibility

Use this attribute to restore the method used to calculate summary route costs per RFC 1583.

Attribute Name: rfc1583-compatibility

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
      </rfc1583-compatibility><!-- operation="delete"-->
    </process>
  </processes>
</ospfv2>
```

Command Syntax

```
compatible rfc1583
```

Configure database summary

Use this attribute to enable the database summary list optimization.

Attribute Name: database-summary

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
```



```

    <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
</database-summary><!-- operation="delete"-->
</process>
</processes>
</ospfv2>

```

Command Syntax

```
enable db-summary-opt
```

Configure bfd enable all interfaces

Use this attribute to enable Bidirectional Forwarding Detection (BFD) on all interfaces.

Attribute Name: bfd-enable-all-interfaces

Attribute Type: empty

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
      </bfd-enable-all-interfaces><!-- operation="delete"-->
    </process>
  </processes>
</ospfv2>

```

Command Syntax

```
bfd all-interfaces
```

Configure log adjacency changes

Use this attribute for the router to send a SYSLOG message when an OSPF neighbor goes up or down.

Attribute Name: log-adjacency-changes

Attribute Type: enum (brief|detail)

Default Value: brief

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>

```

```
        <ospf-id>0</ospf-id>
    </config>
    <log-adjacency-changes>brief</log-adjacency-changes> <!-- operation="delete"-->
</process>
</processes>
</ospfv2>
```

Command Syntax

```
log-adjacency-changes (brief|detail|)
```

Configure shutdown

Use this attribute to shutdown OSPF process.

Attribute Name: shutdown

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
    <ospf-id>0</ospf-id>
    <config>
        <ospf-id>0</ospf-id>
    </config>
    </shutdown><!-- operation="delete"-->
</process>
</processes>
</ospfv2>
```

Command Syntax

```
shutdown
```

Configure area border type

Use this attribute to set an OSPF Area Border Router (ABR) type.

Attribute Name: area-border-type

Attribute Type: enum (standard|cisco|ibm|shortcut)

Default Value: cisco

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
    <ospf-id>0</ospf-id>
    <config>
        <ospf-id>0</ospf-id>
    </config>
</process>
</processes>
</ospfv2>
```

```

    <area-border-type>cisco</area-border-type> <!-- operation="delete"-->
</process>
</processes>
</ospfv2>

```

Command Syntax

```
ospf abr-type (standard|cisco|ibm|shortcut|)
```

Configure reference bandwidth

Use this attribute to control how OSPF calculates the default metric for the interface.

Attribute Name: reference-bandwidth

Attribute Type: uint32

Default Value: 100

Attribute Range: 1-4294967

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
    <ospf-id>0</ospf-id>
    <config>
        <ospf-id>0</ospf-id>
    </config>
    <reference-bandwidth>1</reference-bandwidth> <!-- operation="delete"-->
</process>
</processes>
</ospfv2>

```

Command Syntax

```
auto-cost reference-bandwidth <1-4294967>
```

Configure max database descriptors

Use this attribute to limit the number of Database Descriptors (DD) that can be processed concurrently.

Attribute Name: max-database-descriptors

Attribute Type: uint16

Default Value: 64

Attribute Range: 1-65535

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
    <ospf-id>0</ospf-id>
    <config>

```

```
        <ospf-id>0</ospf-id>
    </config>
    <max-database-descriptors>1</max-database-descriptors> <!-- operation="delete"-->
>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
max-concurrent-dd <1-65535>
```

Configure p2p rfc incompatible

Use this attribute to enable unicast packet on point-point interface.

Attribute Name: p2p-rfc-incompatible

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
    <ospf-id>0</ospf-id>
    <config>
        <ospf-id>0</ospf-id>
    </config>
    </p2p-rfc-incompatible><!-- operation="delete"-->
</process>
</processes>
</ospfv2>
```

Command Syntax

```
ospf point-point rfc-incompatible
```

Configure context name

Use this attribute to set the SNMP context name for OSPF instance.

Attribute Name: context-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
    <ospf-id>0</ospf-id>
    <config>
        <ospf-id>0</ospf-id>
    </config>
</process>
</processes>
</ospfv2>
```

```

    <context-name>WORD</context-name> <!-- operation="delete"-->
  </process>
</processes>
</ospfv2>

```

Command Syntax

```
snmp context-name WORD
```

Configure passive interface all

Use this attribute to set all interfaces as passive.

Attribute Name: passive-interface-all

Attribute Type: empty

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    <passive-interfaces>
      <config>
        </passive-interface-all><!-- operation="delete"-->
      </config>
    </passive-interfaces>
  </process>
</processes>
</ospfv2>

```

Command Syntax

```
passive-interface
```

Configure passive mode

Use this attribute to define the passive mode.

Attribute Name: passive-mode

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>

```

```
<passive-interfaces>
<passive-interface>
  <name>IFNAME</name>
  <config>
    <name>WORD</name>
  </config>
  <passive-mode>enable</passive-mode> <!-- operation="delete"-->
</passive-interface>
</passive-interfaces>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
passive-interface IFNAME (disable|enable)
```

Configure address

Use this attribute to set interface address as passive.

Attribute Name: address

Attribute Type: inet:ipv4-address

Attribute Name: passive-mode

Attribute Type: enum (enable)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
<passive-interfaces>
<passive-interface>
  <name>IFNAME</name>
  <config>
    <name>WORD</name>
  </config>
  <passive-addresses>
<passive-address> <!-- operation="delete"-->
  <address>A.B.C.D</address>
  <config>
    <address>A.B.C.D</address>
    <passive-mode>enable</passive-mode>
  </config>
</passive-address>
</passive-addresses>
</passive-interface>
```

```

</passive-interfaces>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
passive-interface IFNAME A.B.C.D (enable)
```

Configure originate

Use this attribute to create a default external route into an OSPF routing domain. The system acts like an Autonomous System Boundary Router (ASBR) when you use the default-information originate command to redistribute routes into an OSPF routing domain. An ASBR does not by default generate a default route into the OSPF routing domain

Attribute Name: originate

Attribute Type: uint8

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
<default-information>
<config>
  </originate><!-- operation="delete"-->
</config>
</default-information>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
default-information originate
```

Configure route map

Use this attribute to set route-map instance.

Attribute Name: route-map

Attribute Type: string

Attribute Name: originate

Attribute Type: empty

Attribute Name: always-advertise-default-route

Attribute Type: empty

Attribute Name: metric

Attribute Type: uint32

Default Value: 10

Attribute Range: 0-16777214

Attribute Name: metric-type

Attribute Type: enum (1|2)

Default Value: 2

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <default-information>
    <config>
      </originate><!-- operation="delete"-->
      </always-advertise-default-route><!-- operation="delete"-->
      <metric>0</metric> <!-- operation="delete"-->
      <metric-type>2</metric-type> <!-- operation="delete"-->
      <route-map>WORD</route-map> <!-- operation="delete"-->
    </config>
  </default-information>
</ospfv2>
```

Command Syntax

```
default-information originate { always| metric <0-16777214>| metric-type (1|2)|
  route-map WORD }
```

Configure mpls

Use this attribute to enable MPLS-based segment routing for OSPF.

This command is supported when following feature are enabled Multi-Protocol Label Switching (MPLS) Segment Routing (SR)

Attribute Name: mpls

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
</ospfv2>
```



```

    </config>
  <segment-routing>
  <config>
    </mpls><!-- operation="delete"-->
  </config>
</segment-routing>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
segment-routing mpls
```

Configure block range size

Use this attribute to set the segment routing block ending range value.

This command is supported when following feature are enabled Multi-Protocol Label Switching (MPLS) Segment Routing (SR)

Attribute Name: block-range-size

Attribute Type: uint32

Attribute Range: 16-1048575

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
  <process>
    <ospf-id>0</ospf-id>
    <config>
      <ospf-id>0</ospf-id>
    </config>
  <segment-routing>
  <global-blocks>
  <global-block> <!-- operation="delete"-->
    <block-range-size>16</block-range-size>
    <config>
      <block-range-size>16</block-range-size>
      <block-base-value>16</block-base-value>
    </config>
    <block-base-value>16</block-base-value>
  </global-block>
</global-blocks>
</segment-routing>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
ospf segment-routing global block <16-1048575> <16-1048575>
```

Configure disable receive

Use this attribute to enable or disable receiving prefix SID mappings from a mapping server.

Attribute Name: disable-receive

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    <segment-routing>
      <prefix-sid-map>
        <config>
          </disable-receive><!-- operation="delete"-->
        </config>
      </prefix-sid-map>
    </segment-routing>
  </process>
</processes>
</ospfv2>
```

Command Syntax

```
segment-routing prefix-sid-map receive disable
```

Configure advertise local

Use this attribute to advertise local mapping server entries to other routers in the segment routing domain.

This command is supported when following feature are enabled Multi-Protocol Label Switching (MPLS) Segment Routing (SR)

Attribute Name: advertise-local

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    <segment-routing>
      <prefix-sid-map>
        <config>
          </advertise-local><!-- operation="delete"-->
        </config>
      </prefix-sid-map>
    </segment-routing>
  </process>
</processes>
</ospfv2>
```

```

</config>
</prefix-sid-map>
</segment-routing>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
segment-routing prefix-sid-map advertise-local
```

Configure entropy capability

Use this attribute to enable segment routing entropy capability.

This command is supported when following feature are enabled Multi-Protocol Label Switching (MPLS) Segment Routing (SR)

Attribute Name: entropy-capability

Attribute Type: empty

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </segment-routing>
    <sr-capability-entropy>
      <config>
        </entropy-capability><!-- operation="delete"-->
      </config>
    </sr-capability-entropy>
  </segment-routing>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
segment-routing capability entropy
```

Configure disable cspf

Use this attribute to enable the CSPF (Constrained Shortest Path First) feature. The default value for CSPF is enabled.

Attribute Name: disable-cspf

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
```

```
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
<capability>
<config>
  </disable-cspf><!-- operation="delete"-->
</config>
</capability>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
no capability cspf
```

Configure disable traffic engineering

Use this attribute to enable OSPF Traffic Engineering feature.

Attribute Name: disable-traffic-engineering

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
<capability>
<config>
  </disable-traffic-engineering><!-- operation="delete"-->
</config>
</capability>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
no capability traffic-engineering
```

Configure disable graceful restart

Graceful OSPF Restart.

Attribute Name: disable-graceful-restart

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    <capability>
      <config>
        </disable-graceful-restart><!-- operation="delete"-->
      </config>
    </capability>
  </process>
</processes>
</ospfv2>
```

Command Syntax

```
no capability restart graceful
```

Configure disable opaque lsa

Use this attribute to enable opaque-LSAs which are Type 9, 10 and 11 LSAs.

Attribute Name: disable-opaque-lsa

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    <capability>
      <config>
        </disable-opaque-lsa><!-- operation="delete"-->
      </config>
    </capability>
  </process>
</processes>
</ospfv2>
```

Command Syntax

```
no capability opaque
```

Configure enable vrf lite

Use this attribute to enable VRF-lite feature.

Attribute Name: enable-vrf-lite

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <capability>
    <config>
      </enable-vrf-lite><!-- operation="delete"-->
    </config>
  </capability>
</ospfv2>
```

Command Syntax

```
capability vrf-lite
```

Configure link local signaling

Use this attribute to enable link-local signaling feature.

Attribute Name: link-local-signaling

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <capability>
    <config>
      </link-local-signaling><!-- operation="delete"-->
    </config>
  </capability>
</ospfv2>
```

Command Syntax

```
capability lls
```

Configure maximum areas number

Use this attribute to set the maximum number of OSPF areas (excluding Backbone Area).

Attribute Name: maximum-areas-number

Attribute Type: uint32

Attribute Range: 1-4294967294

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <config>
      <maximum-areas-number>1</maximum-areas-number> <!-- operation="delete"-->
    </config>
  </areas>
</ospfv2>
```

Command Syntax

```
maximum-area <1-4294967294>
```

Configure disable advertise

Use this attribute to disable the advertisement of these routes.

Attribute Name: disable-advertise

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPF_AREA_T</area-id>
    </area>
  </areas>
</ospfv2>
```

```
<config>
  <area-id>OSPF_AREA_T</area-id>
</config>
<area-ranges>
<area-range>
  <address>A.B.C.D/M|A.B.C.D A.B.C.D</address>
  <config>
    <address>A.B.C.D/M|A.B.C.D A.B.C.D</address>
  </config>
  </disable-advertise><!-- operation="delete"-->
</area-range>
</area-ranges>
</area>
</areas>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
area (A.B.C.D|<0-4294967295>) range (A.B.C.D/M|A.B.C.D A.B.C.D) not-advertise
```

Configure authentication type

Use this attribute to set the area authentication type.

Attribute Name: authentication-type

Attribute Type: enum (authentication|authentication message-digest)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
<areas>
<area>
  <area-id>OSPF_AREA_T</area-id>
  <config>
    <area-id>OSPF_AREA_T</area-id>
  </config>
  <authentication-type>authentication</authentication-type> <!--
operation="delete"-->
</area>
</areas>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
area (authentication|authentication message-digest)
```

Configure default cost

Use this attribute to set the summary-default cost of a NSSA or stub area.

Attribute Name: default-cost

Attribute Type: uint32

Attribute Range: 0-16777215

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPF_AREA_T</area-id>
      <config>
        <area-id>OSPF_AREA_T</area-id>
        </config>
        <default-cost>0</default-cost> <!-- operation="delete"-->
      </area>
    </areas>
  </processes>
</ospfv2>
```

Command Syntax

```
area default-cost <0-16777215>
```

Configure shortcut

Use this attribute to set the area shortcutting mode.

Attribute Name: shortcut

Attribute Type: enum (default|enable|disable)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
</ospfv2>
```

```
    </config>
</areas>
<area>
  <area-id>OSPF_AREA_T</area-id>
  <config>
    <area-id>OSPF_AREA_T</area-id>
  </config>
  <shortcut>default</shortcut> <!-- operation="delete"-->
</area>
</areas>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
area shortcut (default|enable|disable)
```

Configure name

Use this attribute to set the interface to enable OSPF area.

Attribute Name: name

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
</process>
</processes>
<areas>
<area>
  <area-id>OSPF_AREA_T</area-id>
  <config>
    <area-id>OSPF_AREA_T</area-id>
  </config>
  <interfaces>
<interface> <!-- operation="delete"-->
  <name>IFNAME</name>
  <config>
    <name>WORD</name>
  </config>
</interface>
</interfaces>
</area>
</areas>
</process>
</processes>
```

```
</ospfv2>
```

Command Syntax

```
area interface IFNAME
```

Configure cost

Use this attribute to explicitly specify the cost of the link-state metric in a router-LSA.

Attribute Name: cost

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPF_AREA_T</area-id>
      <config>
        <area-id>OSPF_AREA_T</area-id>
      </config>
      <interfaces>
        <interface>
          <name>IFNAME</name>
          <config>
            <name>WORD</name>
          </config>
          <cost>1</cost> <!-- operation="delete"-->
        </interface>
      </interfaces>
    </area>
  </areas>
</ospfv2>
```

Command Syntax

```
area interface IFNAME cost <1-65535>
```

Configure network type

Use this attribute to set the area interface network type.

Attribute Name: network-type

Attribute Type: enum (point-to-point|broadcast|non-broadcast|point-to-multipoint|point-to-multipoint non-broadcast)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPF_AREA_T</area-id>
      <config>
        <area-id>OSPF_AREA_T</area-id>
      </config>
      <interfaces>
        <interface>
          <name>IFNAME</name>
          <config>
            <name>WORD</name>
          </config>
          <network-type>point-to-point</network-type> <!-- operation="delete"-->
        </interface>
      </interfaces>
    </area>
  </areas>
</ospfv2>
```

Command Syntax

```
area interface IFNAME network-type (point-to-point|broadcast|non-broadcast|point-
to-multipoint|point-to-multipoint non-broadcast)
```

Configure passive

Use this attribute to set area interface as passive.

Attribute Name: passive

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
</ospfv2>
```

```

    </config>
<areas>
<area>
  <area-id>OSPF_AREA_T</area-id>
  <config>
    <area-id>OSPF_AREA_T</area-id>
  </config>
  <interfaces>
  <interface>
    <name>IFNAME</name>
    <config>
      <name>WORD</name>
    </config>
    </passive><!-- operation="delete"-->
  </interface>
</interfaces>
</area>
</areas>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
area interface IFNAME passive
```

Configure priority

Use this attribute to set the router priority to determine the designated router (DR) for the network.

Attribute Name: priority

Attribute Type: uint8

Default Value: 1

Attribute Range: 0-255

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
  <process>
    <ospf-id>0</ospf-id>
    <config>
      <ospf-id>0</ospf-id>
    </config>
  </process>
</processes>
<areas>
<area>
  <area-id>OSPF_AREA_T</area-id>
  <config>
    <area-id>OSPF_AREA_T</area-id>
  </config>
</area>
</areas>

```

```
<interface>
  <name>IFNAME</name>
  <config>
    <name>WORD</name>
  </config>
  <priority>0</priority> <!-- operation="delete"-->
</interface>
</interfaces>
</area>
</areas>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
area interface IFNAME priority <0-255>
```

Configure area id

Use this attribute to configure authentication on this interface.

Attribute Name: authentication-type

Attribute Type: enum (null|simple|message-digest)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPF_AREA_T</area-id>
      <config>
        <area-id>OSPF_AREA_T</area-id>
      </config>
      <interfaces>
        <interface>
          <name>IFNAME</name>
          <config>
            <name>WORD</name>
          </config>
          <authentication-type>simple</authentication-type> <!--
operation="delete"-->
        </interface>
      </interfaces>
    </area>
  </areas>
```

```

</process>
</processes>
</ospfv2>

```

Command Syntax

```
area interface IFNAME authentication (null|message-digest|)
```

Configure enabled

Use this attribute to enable Bidirectional Forwarding Detection (BFD).

This command is supported when following feature are enabled Bidirectional Forwarding Detection (BFD)

Attribute Name: enabled

Attribute Type: enum (enable|disable)

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPF_AREA_T</area-id>
      <config>
        <area-id>OSPF_AREA_T</area-id>
      </config>
      <interfaces>
        <interface>
          <name>IFNAME</name>
          <config>
            <name>WORD</name>
          </config>
          <enable-bfd>
            <config>
              <enabled>enable</enabled> <!-- operation="delete"-->
            </config>
          </enable-bfd>
        </interface>
      </interfaces>
    </area>
  </areas>
</ospfv2>

```

Command Syntax

```
area interface IFNAME bfd (disable|)
```

Configure filter out

Use this attribute to turn on the LSA database-filter for a particular interface. OSPF floods new LSAs over all interfaces in an area, except the interface on which the LSA arrives. This redundancy ensures robust flooding. However, too much redundancy can waste bandwidth and might lead to excessive link and CPU usage in certain topologies, resulting in destabilizing the network. To avoid this, use this attribute to block flooding of LSAs over specified interfaces.

Attribute Name: filter-out

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPF_AREA_T</area-id>
      <config>
        <area-id>OSPF_AREA_T</area-id>
      </config>
      <interfaces>
        <interface>
          <name>IFNAME</name>
          <config>
            <name>WORD</name>
          </config>
          <lsa-filter>
            <config>
              </filter-out><!-- operation="delete"-->
            </config>
          </lsa-filter>
        </interface>
      </interfaces>
    </area>
  </areas>
</ospfv2>
```

Command Syntax

```
area interface IFNAME database-filter all out
```

Configure traffic engineering metric

Use this attribute to set the minimum delay in milliseconds between accepting the same LSA from neighbors.

Attribute Name: traffic-engineering-metric

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPF_AREA_T</area-id>
      <config>
        <area-id>OSPF_AREA_T</area-id>
        <interfaces>
          <interface>
            <name>IFNAME</name>
            <config>
              <name>WORD</name>
            </config>
            <mpls>
              <config>
                <traffic-engineering-metric>1</traffic-engineering-metric> <!--
operation="delete"-->
              </config>
            </mpls>
          </interface>
        </interfaces>
      </config>
    </area>
  </areas>
</ospfv2>
```

Command Syntax

```
area interface IFNAME te-metric <1-65535>
```

Configure ldp igp sync enable

Use this attribute to enable the MPLS LDP IGP SYNC on OSPF.

Attribute Name: ldp-igp-sync-enable

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
```

```
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
</areas>
<area>
  <area-id>OSPF_AREA_T</area-id>
  <config>
    <area-id>OSPF_AREA_T</area-id>
  </config>
  <interfaces>
  <interface>
    <name>IFNAME</name>
    <config>
      <name>WORD</name>
    </config>
    <mpls>
    <igp-ldp-sync>
    <config>
      </ldp-igp-sync-enable><!-- operation="delete"-->
    </config>
    </igp-ldp-sync>
  </mpls>
</interface>
</interfaces>
</area>
</areas>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
area interface IFNAME mpls ldp-igp sync ospf
```

Configure holddown timer

Use this attribute to configure the hold-down timer for which OSPF will wait for LDP to converge and advertises Max cost. When the configured time expires, OSPF starts advertising the actual cost in the Router-LSA.

Attribute Name: holddown-timer

Attribute Type: uint32

Default Value: 70000

Attribute Range: 1-2147483

Attribute Name: ldp-igp-sync-enable

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
```

```

<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
<areas>
<area>
  <area-id>OSPF_AREA_T</area-id>
  <config>
    <area-id>OSPF_AREA_T</area-id>
  </config>
  <interfaces>
  <interface>
    <name>IFNAME</name>
    <config>
      <name>WORD</name>
    </config>
    <mpls>
    <igp-ldp-sync>
    <config>
      </ldp-igp-sync-enable><!-- operation="delete"-->
      <holddown-timer>1</holddown-timer> <!-- operation="delete"-->
    </config>
    </igp-ldp-sync>
  </mpls>
</interface>
</interfaces>
</area>
</areas>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
area interface IFNAME mpls ldp-igp sync ospf holddown-timer <1-2147483>
```

Configure dead interval

Use this attribute to set the interval during which the router waits to receive an OSPF hello packet from the neighbor before declaring the neighbor down.

Attribute Name: dead-interval

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>

```

```
<ospf-id>0</ospf-id>
<config>
  <ospf-id>0</ospf-id>
</config>
<areas>
<area>
  <area-id>OSPF_AREA_T</area-id>
  <config>
    <area-id>OSPF_AREA_T</area-id>
  </config>
  <interfaces>
  <interface>
    <name>IFNAME</name>
    <config>
      <name>WORD</name>
    </config>
    <timers>
    <config>
      <dead-interval>1</dead-interval> <!-- operation="delete"-->
    </config>
    </timers>
  </interface>
</interfaces>
</area>
</areas>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
area interface IFNAME dead-interval <1-65535>
```

Configure hello interval

Use this attribute to specify the interval between hello packets.

Attribute Name: hello-interval

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
  <process>
    <ospf-id>0</ospf-id>
    <config>
      <ospf-id>0</ospf-id>
    </config>
```

```

<areas>
<area>
  <area-id>OSPF_AREA_T</area-id>
  <config>
    <area-id>OSPF_AREA_T</area-id>
  </config>
  <interfaces>
  <interface>
    <name>IFNAME</name>
    <config>
      <name>WORD</name>
    </config>
    <timers>
    <config>
      <hello-interval>1</hello-interval> <!-- operation="delete"-->
    </config>
    </timers>
  </interface>
</interfaces>
</area>
</areas>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
area interface IFNAME hello-interval <1-65535>
```

Configure retransmission interval

Use this attribute to specify the time between link-state advertisement (LSA) retransmissions for adjacencies belonging to the interface.

Attribute Name: retransmission-interval

Attribute Type: uint16

Default Value: 5

Attribute Range: 1-3600

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
  <process>
    <ospf-id>0</ospf-id>
    <config>
      <ospf-id>0</ospf-id>
    </config>
  </process>
  </processes>
  <areas>
  <area>
    <area-id>OSPF_AREA_T</area-id>

```

```
<config>
  <area-id>OSPF_AREA_T</area-id>
</config>
<interfaces>
<interface>
  <name>IFNAME</name>
  <config>
    <name>WORD</name>
  </config>
  <timers>
  <config>
    <retransmission-interval>1</retransmission-interval> <!--
operation="delete"-->
  </config>
  </timers>
</interface>
</interfaces>
</area>
</areas>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
area interface IFNAME retransmit-interval <1-3600>
```

Configure no summary

Use this attribute to set the OSPF area stub with no-summary, this will prevent an ABR from sending summary link state advertisements into the stub area.

Attribute Name: no-summary

Attribute Type: empty

Attribute Name: is-stub

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
</process>
</processes>
<areas>
<area>
  <area-id>OSPF_AREA_T</area-id>
  <config>
    <area-id>OSPF_AREA_T</area-id>
  </config>
</area>
</areas>
```

```

    <stub>
    <config>
        </is-stub><!-- operation="delete"-->
        </no-summary><!-- operation="delete"-->
    </config>
</stub>
</area>
</areas>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
area stub no-summary
```

Configure is stub

Use this attribute to set the OSPF area as stub.

Attribute Name: is-stub

Attribute Type: empty

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
    <ospf-id>0</ospf-id>
    <config>
        <ospf-id>0</ospf-id>
    </config>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
area stub
```

Configure nssa enable

Use this attribute to enable the OSPF area as NSSA.

This command is supported when following feature are enabled Not-So-Stubby Area (NSSA)

Attribute Name: nssa-enable

Attribute Type: enum (nssa)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPF_AREA_T</area-id>
      <config>
        <area-id>OSPF_AREA_T</area-id>
      </config>
      <nssas>
        <nssa> <!-- operation="delete"-->
          <nssa-enable>nssa</nssa-enable>
          <config>
            <nssa-enable>nssa</nssa-enable>
          </config>
        </nssa>
      </nssas>
    </area>
  </areas>
</ospfv2>
```

Command Syntax

```
area (nssa)
```

Configure stability interval

Use this attribute to set route-map instance.

This command is supported when following feature are enabled Not-So-Stubby Area (NSSA)

Attribute Name: route-map

Attribute Type: string

Attribute Name: no-summary

Attribute Type: empty

Attribute Name: stability-interval

Attribute Type: uint32

Default Value: 40

Attribute Range: 0-2147483647

Attribute Name: translator-role

Attribute Type: enum (never|always|candidate)

Attribute Name: no-redistribution

Attribute Type: empty

Attribute Name: default-information-originate

Attribute Type: empty

Attribute Name: metric

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-16777214

Attribute Name: metric-type

Attribute Type: enum (1|2)

Default Value: 2

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPF_AREA_T</area-id>
      <config>
        <area-id>OSPF_AREA_T</area-id>
      </config>
      <nssas>
        <nssa>
          <nssa-enable>nssa</nssa-enable>
          <config>
            <nssa-enable>nssa</nssa-enable>
          </no-summary>
          <stability-interval>0</stability-interval>
          <translator-role>never</translator-role>
          </no-redistribution>
          </default-information-originate>
          <metric>0</metric>
          <metric-type>2</metric-type>
        </nssa>
      </nssas>
    </area>
  </areas>
</ospfv2>
```

```
    </config>
    <route-map>WORD</route-map>
  </nssa>
</nssas>
</area>
</areas>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
area (nssa) { no-summary| stability-interval <0-2147483647>| translator-role
  (never|always|candidate)| no-redistribution| default-information-originate|
  metric <0-16777214>| metric-type (1|2)| route-map WORD }
```

Configure ip address

Use this attribute to set the OSPF area ID.

Attribute Name: area-id

Attribute Type: inet:ipv4-address

Attribute Name: ip-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <area> <!-- operation="delete"-->
      <area-id>OSPF_AREA_T</area-id>
      <config>
        <area-id>OSPF_AREA_T</area-id>
      </config>
      <hosts>
        <host>
          <ip-address>A.B.C.D</ip-address>
        </host>
      </hosts>
    </area>
  </areas>
</ospfv2>
```

Command Syntax

```
host A.B.C.D area
```

Configure instance id

Use this attribute to set the instance ID. Use this command with OSPF multiple-instance support enabled.

Attribute Name: instance-id

Attribute Type: uint8

Attribute Range: 0-255

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPF_AREA_T</area-id>
      <config>
        <area-id>OSPF_AREA_T</area-id>
      </config>
      <networks>
        <network>
          <prefix>A.B.C.D/M|A.B.C.D A.B.C.D</prefix>
          <config>
            <prefix>A.B.C.D/M|A.B.C.D A.B.C.D</prefix>
          </config>
          <instance-id>0</instance-id>
        </network>
      </networks>
    </area>
  </areas>
</ospfv2>
```

Command Syntax

```
network (A.B.C.D/M|A.B.C.D A.B.C.D) area (instance-id <0-255>|)
```

Configure remote router id

Use this attribute to set the interface IP address of the neighbor.

Attribute Name: remote-router-id

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
area virtual-link A.B.C.D
```

Configure fall over

Fall-over detection with Bidirectional Forwarding Detection (BFD).

Attribute Name: fall-over

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
</process>
</processes>
</ospfv2>
```

```

    <area-id>OSPF_AREA_T</area-id>
  </config>
</virtual-links>
<virtual-link>
  <remote-router-id>A.B.C.D</remote-router-id>
  <config>
    <remote-router-id>A.B.C.D</remote-router-id>
  </config>
  <bfd>
  <config>
    </fall-over><!-- operation="delete"-->
  </config>
</bfd>
</virtual-link>
</virtual-links>
</area>
</areas>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
area virtual-link A.B.C.D fall-over bfd
```

Configure key

Use this attribute to set the authentication password (key).

Attribute Name: key

Attribute Type: string

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
  <process>
    <ospf-id>0</ospf-id>
    <config>
      <ospf-id>0</ospf-id>
    </config>
  </process>
  </processes>
  <areas>
  <area>
    <area-id>OSPF_AREA_T</area-id>
    <config>
      <area-id>OSPF_AREA_T</area-id>
    </config>
    <virtual-links>
    <virtual-link>
      <remote-router-id>A.B.C.D</remote-router-id>
      <config>
        <remote-router-id>A.B.C.D</remote-router-id>
      </config>
    </virtual-link>
  </virtual-links>
  </area>
  </areas>
</ospfv2>

```

```
    </config>
    <authentication>
    <config>
        <key>WORD</key> <!-- operation="delete"-->
    </config>
    </authentication>
</virtual-link>
</virtual-links>
</area>
</areas>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
area virtual-link A.B.C.D authentication-key WORD
```

Configure message digest id

Use this attribute to set the authentication message digest key ID.

Attribute Name: message-digest-id

Attribute Type: uint8

Attribute Range: 1-255

Attribute Name: message-digest-encryption-type

Attribute Type: enum (md5)

Attribute Name: message-digest-key

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
    <ospf-id>0</ospf-id>
    <config>
        <ospf-id>0</ospf-id>
    </config>
</areas>
<area>
    <area-id>OSPF_AREA_T</area-id>
    <config>
        <area-id>OSPF_AREA_T</area-id>
    </config>
</virtual-links>
<virtual-link>
    <remote-router-id>A.B.C.D</remote-router-id>
    <config>
        <remote-router-id>A.B.C.D</remote-router-id>
```

```

</config>
<authentication>
<message-digests>
<message-digest> <!-- operation="delete"-->
  <message-digest-id>1</message-digest-id>
  <config>
    <message-digest-id>1</message-digest-id>
    <message-digest-encryption-type>md5</message-digest-encryption-type>
    <message-digest-key>WORD</message-digest-key>
  </config>
</message-digest>
</message-digests>
</authentication>
</virtual-link>
</virtual-links>
</area>
</areas>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
area virtual-link A.B.C.D message-digest-key <1-255> (md5) WORD
```

Configure transmit delay

Dead router detection time. Interval during which no packets are received and after which the router acknowledges a neighboring router as off-line.

Attribute Name: dead-interval

Attribute Type: uint16

Attribute Range: 1-65535

Attribute Name: hello-interval

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-65535

Attribute Name: transmit-delay

Attribute Type: uint16

Default Value: 1

Attribute Range: 1-3600

Attribute Name: retransmission-interval

Attribute Type: uint16

Default Value: 5

Attribute Range: 1-3600

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPF_AREA_T</area-id>
      <config>
        <area-id>OSPF_AREA_T</area-id>
      </config>
      <virtual-links>
        <virtual-link>
          <remote-router-id>A.B.C.D</remote-router-id>
          <config>
            <remote-router-id>A.B.C.D</remote-router-id>
          </config>
          <timers>
            <config>
              <hello-interval>1</hello-interval> <!-- operation="delete"-->
              <transmit-delay>1</transmit-delay> <!-- operation="delete"-->
              <retransmission-interval>1</retransmission-interval> <!--
operation="delete"-->
              <dead-interval>1</dead-interval> <!-- operation="delete"-->
            </config>
          </timers>
        </virtual-link>
      </virtual-links>
    </area>
  </areas>
</ospfv2>
```

Command Syntax

```
area virtual-link A.B.C.D { dead-interval <1-65535>| hello-interval <1-65535>|
  transmit-delay <1-3600>| retransmit-interval <1-3600> }
```

Configure destination id

Use this attribute to set the destination IP address of sham link.

This command is supported when following feature are enabled OSPF Virtual Routing and Forwarding (VRF), Multi-Protocol Label Switching (MPLS)

Attribute Name: destination-id

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
<areas>
<area>
  <area-id>OSPF_AREA_T</area-id>
  <config>
    <area-id>OSPF_AREA_T</area-id>
  </config>
  <sham-links>
  <sham-link> <!-- operation="delete"-->
    <destination-id>A.B.C.D</destination-id>
    <config>
      <destination-id>A.B.C.D</destination-id>
      <source-id>A.B.C.D</source-id>
    </config>
    <source-id>A.B.C.D</source-id>
  </sham-link>
</sham-links>
</area>
</areas>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
area sham-link A.B.C.D A.B.C.D
```

Configure source id

Use this attribute to set the sham link cost.

This command is supported when following feature are enabled OSPF Virtual Routing and Forwarding (VRF), Multi-Protocol Label Switching (MPLS)

Attribute Name: cost

Attribute Type: uint16

Default Value: 1

Attribute Range: 1-65535

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>

```

```
<config>
  <ospf-id>0</ospf-id>
</config>
<areas>
<area>
  <area-id>OSPF_AREA_T</area-id>
  <config>
    <area-id>OSPF_AREA_T</area-id>
  </config>
  <sham-links>
  <sham-link>
    <destination-id>A.B.C.D</destination-id>
    <config>
      <destination-id>A.B.C.D</destination-id>
      <source-id>A.B.C.D</source-id>
    </config>
    <source-id>A.B.C.D</source-id>
    <cost>1</cost> <!-- operation="delete"-->
  </sham-link>
</sham-links>
</area>
</areas>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
area sham-link A.B.C.D A.B.C.D cost <1-65535>
```

Configure limit type

Use this attribute to set the limit type. Soft limit: Warning message appears if the number of LSAs exceeds the specified value; Hard limit: Shutdown occurs if the number of LSAs exceeds the specified value. Default value is 2.

Attribute Name: limit-type

Attribute Type: enum (soft|hard)

Attribute Name: max-limit

Attribute Type: uint32

Attribute Range: 0-4294967294

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
  <process>
    <ospf-id>0</ospf-id>
    <config>
      <ospf-id>0</ospf-id>
    </config>
  </process>
</processes>
</ospfv2>
```

```

<overflow>
<normal-lsa>
<config>
    <max-limit>0</max-limit>
    <limit-type>hard</limit-type>
</config>
</normal-lsa>
</overflow>
</lsdb>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
overflow database <0-4294967294> ((soft|hard|))
```

Configure exit interval

Use this attribute to set the number of seconds the router waits before trying to exit the database overflow state. If this parameter is 0, the router exits the overflow state only after an explicit administrator command. Default value is 0.

This command is supported when following feature are enabled OSPF DataBase (DB) overflow

Attribute Name: exit-interval

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: max-limit

Attribute Type: uint32

Attribute Range: 0-2147483647

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
    <ospf-id>0</ospf-id>
    <config>
        <ospf-id>0</ospf-id>
    </config>
</process>
</processes>
</ospfv2>

```

```
</processes>  
</ospfv2>
```

Command Syntax

```
overflow database external <0-2147483647> <0-65535>
```

Configure keep all paths

Use this attribute to enable fast rerouting on all OSPF interfaces.

This command is supported when following feature are enabled OSPF Loop Free Alternate (LFA)

Attribute Name: keep-all-paths

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<processes>  
<process>  
  <ospf-id>0</ospf-id>  
  <config>  
    <ospf-id>0</ospf-id>  
  </config>  
<lfa>  
<fast-reroute>  
<config>  
  </keep-all-paths><!-- operation="delete"-->  
</config>  
</fast-reroute>  
</lfa>  
</process>  
</processes>  
</ospfv2>
```

Command Syntax

```
fast-reroute keep-all-paths
```

Configure remote lfa areas

Use this attribute to set remote-lfa for OSPF area.

This command is supported when following feature are enabled OSPF Loop Free Alternate (LFA)

Attribute Name: remote-lfa-areas

Attribute Type: union

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<processes>  
<process>  
  <ospf-id>0</ospf-id>
```

```

    <config>
      <ospf-id>0</ospf-id>
    </config>
  <lfa>
    <fast-reroute>
      <config>
        <remote-lfa-areas>OSPF_AREA_T</remote-lfa-areas>
      </config>
    </fast-reroute>
  </lfa>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
fast-reroute per-prefix remote-lfa area (A.B.C.D|<0-4294967295>) tunnel mpls-ldp
```

Configure idx

Use this attribute to set the tie breaking index. A lower value has higher preference.

This command is supported when following feature are enabled OSPF Loop Free Alternate (LFA)

Attribute Name: idx

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    <lfa>
      <fast-reroute>
        <tie-breaks>
          <tie-break>
            <type>primary-path</type>
            <config>
              <type>primary-path</type>
            </config>
            <idx>1</idx> <!-- operation="delete"-->
          </tie-break>
        </tie-breaks>
      </fast-reroute>
    </lfa>
  </process>
</processes>

```

```
</ospfv2>
```

Command Syntax

```
fast-reroute tie-break (primary-path|node-protecting|interface-disjoint|broadcast-  
interface-disjoint|downstream-path|secondary-path) index <1-255>
```

Configure default distance

Use this attribute to specifies a default administrative distance used when no other specification exists for a routing information source.

Attribute Name: default-distance

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<processes>  
<process>  
  <ospf-id>0</ospf-id>  
  <config>  
    <ospf-id>0</ospf-id>  
  </config>  
<administrative-distance>  
<config>  
  <default-distance>1</default-distance> <!-- operation="delete"-->  
</config>  
</administrative-distance>  
</process>  
</processes>  
</ospfv2>
```

Command Syntax

```
distance <1-255>
```

Configure intra area distance

Use this attribute to set the distance for all routes within an area.

Attribute Name: intra-area-distance

Attribute Type: uint8

Attribute Range: 1-255

Attribute Name: inter-area-distance

Attribute Type: uint8

Attribute Range: 1-255

Attribute Name: external-routes-distance

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
      <administrative-distance>
        <ospf>
          <config>
            <inter-area-distance>1</inter-area-distance> <!-- operation="delete"-->
            <external-routes-distance>1</external-routes-distance> <!--
operation="delete"-->
            <intra-area-distance>1</intra-area-distance> <!-- operation="delete"-->
          </config>
        </ospf>
      </administrative-distance>
    </process>
  </processes>
</ospfv2>
```

Command Syntax

```
distance ospf { intra-area <1-255>| inter-area <1-255>| external <1-255> }
```

Configure access control list

Use this attribute to specifies administrative distance network ACL.

Attribute Name: access-control-list

Attribute Type: string

Attribute Name: distance

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
      <administrative-distance>
        <networks>
          <network>
            <prefix>A.B.C.D/M</prefix>
```

```
<config>
  <prefix>A.B.C.D/M</prefix>
  <distance>1</distance>
</config>
  <access-control-list>WORD</access-control-list>
</network>
</networks>
</administrative-distance>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
distance <1-255> A.B.C.D/M (WORD|)
```

Configure not advertise

Use this attribute to suppress routes that match the address range.

Attribute Name: not-advertise

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    <summary-addresses>
      <summary-address>
        <address>A.B.C.D/M|A.B.C.D A.B.C.D</address>
        <config>
          <address>A.B.C.D/M</address>
        </config>
        </not-advertise><!-- operation="delete"-->
      </summary-address>
    </summary-addresses>
  </process>
</processes>
</ospfv2>
```

Command Syntax

```
summary-address (A.B.C.D/M|A.B.C.D A.B.C.D) not-advertise
```

Configure tag

Use this attribute to set the tag value to use as a match value for controlling redistribution via route maps.

Attribute Name: tag

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    <summary-addresses>
    <summary-address>
      <address>A.B.C.D/M|A.B.C.D A.B.C.D</address>
      <config>
        <address>A.B.C.D/M</address>
      </config>
      <tag>0</tag> <!-- operation="delete"-->
    </summary-address>
  </summary-addresses>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
summary-address (A.B.C.D/M|A.B.C.D A.B.C.D) tag <0-4294967295>
```

Configure access control list isis

Use this attribute to set the access control list name for ISIS protocol.

This command is supported when following feature are enabled Access-Control List (ACL)

Attribute Name: access-control-list-isis

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    <distribute-list>
    <filter-out>
    <config>
```

```
        <access-control-list-isis>WORD</access-control-list-isis> <!--
operation="delete"-->
    </config>
</filter-out>
</distribute-list>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
distribute-list WORD out isis
```

Configure access control list bgp

Use this attribute to set the access control list name for BGP protocol.

This command is supported when following feature are enabled Access-Control List (ACL)

Attribute Name: access-control-list-bgp

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <distribute-list>
    <filter-out>
      <config>
        <access-control-list-bgp>WORD</access-control-list-bgp> <!--
operation="delete"-->
      </config>
    </filter-out>
  </distribute-list>
</ospfv2>
```

Command Syntax

```
distribute-list WORD out bgp
```

Configure access control list rip

Use this attribute to set the access control list name for RIP protocol.

This command is supported when following feature are enabled Access-Control List (ACL)

Attribute Name: access-control-list-rip

Attribute Type: string

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
<distribute-list>
<filter-out>
<config>
  <access-control-list-rip>WORD</access-control-list-rip> <!--
operation="delete"-->
</config>
</filter-out>
</distribute-list>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
distribute-list WORD out rip
```

Configure access control list static

Use this attribute to set the access control list name for static routes.

This command is supported when following feature are enabled Access-Control List (ACL)

Attribute Name: access-control-list-static

Attribute Type: string

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
<distribute-list>
<filter-out>
<config>
  <access-control-list-static>WORD</access-control-list-static> <!--
operation="delete"-->
</config>
</filter-out>
</distribute-list>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
distribute-list WORD out static
```

Configure access control list connected

Use this attribute to set the access control list name for connected networks.

This command is supported when following feature are enabled Access-Control List (ACL)

Attribute Name: access-control-list-connected

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
      <distribute-list>
        <filter-out>
          <config>
            <access-control-list-connected>WORD</access-control-list-connected> <!--
operation="delete"-->
          </config>
        </filter-out>
      </distribute-list>
    </process>
  </processes>
</ospfv2>
```

Command Syntax

```
distribute-list WORD out connected
```

Configure access control list kernel

Use this attribute to set the access control list name for KERNEL routes.

This command is supported when following feature are enabled Access-Control List (ACL)

Attribute Name: access-control-list-kernel

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
</ospfv2>
```

```

    </config>
  <distributed-list>
  <filter-out>
  <config>
    <access-control-list-kernel>WORD</access-control-list-kernel> <!--
operation="delete"-->
  </config>
</filter-out>
</distributed-list>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
distributed-list WORD out kernel
```

Configure ospf process id

Use this attribute to set the OSPF ID in distribution list filter out.

This command is supported when following feature are enabled Access-Control List (ACL)

Attribute Name: ospf-process-id

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: access-control-list-out-ospf

Attribute Type: string

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
  <process>
    <ospf-id>0</ospf-id>
    <config>
      <ospf-id>0</ospf-id>
    </config>
  <distributed-list>
  <filter-out>
  <ospfv2-processes>
  <ospfv2-process>
    <ospf-process-id>0</ospf-process-id>
    <config>
      <ospf-process-id>0</ospf-process-id>
      <access-control-list-out-ospf>WORD</access-control-list-out-ospf> <!--
operation="delete"-->
    </config>
  </ospfv2-process>
</ospfv2-processes>
</filter-out>
</distributed-list>

```

```
</process>  
</processes>  
</ospfv2>
```

Command Syntax

```
distribute-list WORD out ospf (<0-65535>|)
```

Configure primary domain id address

Use this attribute to set the domain ID in IPv4 address format.

This command is supported when following feature are enabled OSPF Virtual Routing and Forwarding (VRF)

Attribute Name: primary-domain-id-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<processes>  
<process>  
  <ospf-id>0</ospf-id>  
  <config>  
    <ospf-id>0</ospf-id>  
  </config>  
<domain-id>  
<primary-domain>  
<config>  
  <primary-domain-id-address>A.B.C.D</primary-domain-id-address> <!--  
operation="delete"-->  
</config>  
</primary-domain>  
</domain-id>  
</process>  
</processes>  
</ospfv2>
```

Command Syntax

```
domain-id A.B.C.D
```

Configure primary domain id hex

Use this attribute to set domain ID in hexadecimal.

This command is supported when following feature are enabled OSPF Virtual Routing and Forwarding (VRF)

Attribute Name: primary-domain-id-hex

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<processes>
```

```

<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
</domain-id>
<primary-domain>
<hexes>
<hex> <!-- operation="delete"-->
  <primary-domain-id-hex>HEX_DATA</primary-domain-id-hex>
  <config>
    <primary-domain-id-hex>OSPF_DOMAIN_ID_HEX_STRING_T</primary-domain-id-hex>
    <primary-hex-type>type-as</primary-hex-type>
  </config>
  <primary-hex-type>type-as</primary-hex-type>
</hex>
</hexes>
</primary-domain>
</domain-id>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
domain-id type (type-as|type-as4|type-back-comp|type-ip) value HEX_DATA
```

Configure secondary domain id address

Use this attribute to set the secondary domain ID in IPv4 address format.

This command is supported when following feature are enabled OSPF Virtual Routing and Forwarding (VRF)

Attribute Name: secondary-domain-id-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
  <process>
    <ospf-id>0</ospf-id>
    <config>
      <ospf-id>0</ospf-id>
    </config>
  </domain-id>
  <secondary-domain>
  <addresses>
  <address> <!-- operation="delete"-->
    <secondary-domain-id-address>A.B.C.D</secondary-domain-id-address>
  <config>
    <secondary-domain-id-address>A.B.C.D</secondary-domain-id-address>
  </config>

```

```
</address>  
</addresses>  
</secondary-domain>  
</domain-id>  
</process>  
</processes>  
</ospfv2>
```

Command Syntax

```
domain-id A.B.C.D secondary
```

Configure secondary domain id hex

Use this attribute to set secondary domain ID in hexadecimal.

This command is supported when following feature are enabled OSPF Virtual Routing and Forwarding (VRF)

Attribute Name: secondary-domain-id-hex

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<processes>  
<process>  
  <ospf-id>0</ospf-id>  
  <config>  
    <ospf-id>0</ospf-id>  
  </config>  
<domain-id>  
<secondary-domain>  
<hexes>  
<hex> <!-- operation="delete"-->  
  <secondary-domain-id-hex>HEX_DATA</secondary-domain-id-hex>  
<config>  
  <secondary-domain-id-hex>OSPF_DOMAIN_ID_HEX_STRING_T</secondary-domain-id-  
hex>  
  <secondary-hex-type>type-as</secondary-hex-type>  
</config>  
  <secondary-hex-type>type-as</secondary-hex-type>  
</hex>  
</hexes>  
</secondary-domain>  
</domain-id>  
</process>  
</processes>  
</ospfv2>
```

Command Syntax

```
domain-id type (type-as|type-as4|type-back-comp|type-ip) value HEX_DATA secondary
```

Configure throttle timer

Use this attribute to set interval between processing LS DB.

This command is supported when following feature are enabled Border Gateway Protocol (BGP) Link State

Attribute Name: throttle-timer

Attribute Type: uint8

Default Value: 5

Attribute Range: 5-20

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
        </config>
      <distribute>
        <bgp-link-state>
          <config>
            </enabled><!-- operation="delete"-->
            <throttle-timer>5</throttle-timer> <!-- operation="delete"-->
          </config>
        </bgp-link-state>
      </distribute>
    </process>
  </processes>
</ospfv2>
```

Command Syntax

```
distribute bgp-ls throttle <5-20>
```

Configure poll interval

Use this attribute to set the router cost for point-to-multipoint neighbor.

Attribute Name: cost

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-65535

Attribute Name: priority

Attribute Type: uint8

Default Value: 0

Attribute Range: 0-255

Attribute Name: poll-interval

Attribute Type: uint32

Default Value: 120

Attribute Range: 1-2147483647

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
    <ospf-id>0</ospf-id>
  </config>
<neighbors>
<neighbor>
  <address>A.B.C.D</address>
  <config>
    <address>A.B.C.D</address>
    <priority>0</priority> <!-- operation="delete"-->
    <poll-interval>1</poll-interval> <!-- operation="delete"-->
  </config>
  <cost>1</cost> <!-- operation="delete"-->
</neighbor>
</neighbors>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
neighbor A.B.C.D { cost <1-65535>| priority <0-255>| poll-interval <1-2147483647> }
```

Configure termination hold interval

Use this attribute to set the LFA termination hold on interval. It represents the delay of primary route installation (to avoid micro loop) after a failover.

Attribute Name: termination-hold-interval

Attribute Type: uint32

Default Value: 6000

Attribute Range: 100-100000

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
  <ospf-id>0</ospf-id>
  <config>
```

```

        <ospf-id>0</ospf-id>
    </config>
<timers>
<lfa>
<config>
    <termination-hold-interval>100</termination-hold-interval> <!--
operation="delete"-->
</config>
</lfa>
</timers>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
fast-reroute terminate-hold-on interval <100-100000>
```

Configure min arrival interval

Use this attribute to set the minimum interval to accept the same link-state advertisement (LSA) from OSPF neighbors.

Attribute Name: min-arrival-interval

Attribute Type: uint32

Default Value: 1000

Attribute Range: 0-600000

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<processes>
<process>
    <ospf-id>0</ospf-id>
    <config>
        <ospf-id>0</ospf-id>
    </config>
<timers>
<lsa>
<config>
    <min-arrival-interval>0</min-arrival-interval> <!-- operation="delete"-->
</config>
</lsa>
</timers>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
timers lsa arrival <0-600000>
```

Configure max delay

Use this attribute to set the maximum wait time in milliseconds between generation of the same LSA.

Attribute Name: max-delay

Attribute Type: uint32

Attribute Range: 1-600000

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <timers>
    <lsa>
      <delays>
        <delay> <!-- operation="delete"-->
          <max-delay>1</max-delay>
          <config>
            <max-delay>1</max-delay>
            <min-delay>1</min-delay>
            <start-delay>0</start-delay>
          </config>
          <min-delay>1</min-delay>
          <start-delay>0</start-delay>
        </delay>
      </delays>
    </lsa>
  </timers>
</ospfv2>
```

Command Syntax

```
timers throttle lsa all <0-600000> <1-600000> <1-600000>
```

Configure min delay

Use this attribute to set the maximum delay between receiving a change to SPF calculation.

Attribute Name: max-delay

Attribute Type: uint32

Attribute Range: 0-2147483647

Attribute Name: min-delay

Attribute Type: uint32

Attribute Range: 0-2147483647

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    <timers>
      <spf>
        <delay>
          <config>
            <min-delay>0</min-delay>
            <max-delay>0</max-delay>
          </config>
        </delay>
      </spf>
    </timers>
  </process>
</processes>
</ospfv2>
```

Command Syntax

```
timers spf exp <0-2147483647> <0-2147483647>
```

Configure default metric

Use this attribute to set a default metric for OSPF. A default metric facilitates redistributing routes with incompatible metrics. If the metrics do not convert, the default metric provides an alternative. Use this attribute to use the same metric value for all redistributed routes. Use this attribute in conjunction with the redistribute command.

Attribute Name: default-metric

Attribute Type: uint32

Default Value: 2

Attribute Range: 1-16777214

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    <redistribute>
      <config>
        <default-metric>1</default-metric> <!-- operation="delete"-->
      </config>
    </redistribute>
  </process>
</processes>
</ospfv2>
```

```
</config>  
</redistribute>  
</process>  
</processes>  
</ospfv2>
```

Command Syntax

```
default-metric <1-16777214>
```

Configure protocol

This attribute redistributes routes from a routing protocol, static route, or kernel route into an OSPF routing table.

Attribute Name: protocol

Attribute Type: enum (kernel|connected|static|rip|ospf|bgp|isis)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<processes>  
<process>  
  <ospf-id>0</ospf-id>  
  <config>  
    <ospf-id>0</ospf-id>  
  </config>  
</redistribute>  
<routing-protocols>  
<routing-protocol> <!-- operation="delete"-->  
  <protocol>kernel</protocol>  
  <config>  
    <protocol>kernel</protocol>  
  </config>  
</routing-protocol>  
</routing-protocols>  
</redistribute>  
</process>  
</processes>  
</ospfv2>
```

Command Syntax

```
redistribute (kernel|connected|static|rip|ospf|bgp|isis)
```

Configure metric

Use this attribute to set metric value.

Attribute Name: metric

Attribute Type: uint32

Attribute Range: 0-16777214

Attribute Name: metric-type

Attribute Type: enum (1|2)

Attribute Name: route-map

Attribute Type: string

Attribute Name: tag

Attribute Type: uint32

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
  <process>
    <ospf-id>0</ospf-id>
    <config>
      <ospf-id>0</ospf-id>
    </config>
  <redistribute>
  <routing-protocols>
  <routing-protocol>
    <protocol>kernel</protocol>
    <config>
      <protocol>kernel</protocol>
      <metric-type>1</metric-type> <!-- operation="delete"-->
      <route-map>WORD</route-map> <!-- operation="delete"-->
      <tag>0</tag> <!-- operation="delete"-->
    </config>
    <metric>0</metric> <!-- operation="delete"-->
  </routing-protocol>
  </routing-protocols>
  </redistribute>
  </process>
  </processes>
</ospfv2>
```

Command Syntax

```
redistribute (kernel|connected|static|rip|ospf|bgp|isis) { metric <0-16777214>|
  metric-type (1|2)| route-map WORD| tag <0-4294967295> }
```

Configure metric type

Use this attribute to set metric value.

Attribute Name: metric

Attribute Type: uint32

Attribute Range: 0-16777214

Attribute Name: metric-type

Attribute Type: enum (1|2)

Attribute Name: route-map

Attribute Type: string

Attribute Name: tag

Attribute Type: uint32

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
  <redistribute>
    <ospf-processes>
      <ospf-process>
        <ospf-process-id>0</ospf-process-id>
        <config>
          <ospf-process-id>0</ospf-process-id>
          <metric-type>1</metric-type> <!-- operation="delete"-->
          <route-map>WORD</route-map> <!-- operation="delete"-->
          <tag>0</tag> <!-- operation="delete"-->
        </config>
        <metric>0</metric> <!-- operation="delete"-->
      </ospf-process>
    </ospf-processes>
  </redistribute>
</ospfv2>
```

Command Syntax

```
redistribute ospf <0-65535> { metric <0-16777214>| metric-type (1|2)| route-map
  WORD| tag <0-4294967295> }
```

Configure isis process id

This attribute redistributes routes from an instance of IS-IS into an OSPF routing table.

Attribute Name: isis-process-id

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    </process>
  </processes>
</ospfv2>
```



```

    </config>
  <redistribute>
    <isis-processes>
      <isis-process> <!-- operation="delete"-->
        <isis-process-id>WORD</isis-process-id>
      <config>
        <isis-process-id>WORD</isis-process-id>
      </config>
    </isis-process>
  </isis-processes>
</redistribute>
</process>
</processes>
</ospfv2>

```

Command Syntax

```
redistribute isis WORD
```

Configure include stub

Use this attribute to set the metric of a stub link in the router LSA to the default max metric.

This command is supported when following feature are enabled Generate lsa with max-metric

Attribute Name: include-stub

Attribute Type: empty

Attribute Name: enable-max-router-lsa

Attribute Type: empty

Attribute Name: max-external-lsa

Attribute Type: uint32

Attribute Range: 1-16777215

Attribute Name: max-summary-lsa

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    <max-metric>
      <config>
        </enable-max-router-lsa>
        <max-external-lsa>1</max-external-lsa>
        <max-summary-lsa>1</max-summary-lsa>
      </config>
    </process>
  </processes>
</ospfv2>

```

```
        </include-stub>
</config>
</max-metric>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
max-metric router-lsa { external-lsa (<1-16777215>|)| summary-lsa (<1-16777215>|)|
  include-stub }
```

Configure enable max router lsa

Use this attribute to set the metric in the router LSA to the default max metric.

This command is supported when following feature are enabled Generate lsa with max-metric

Attribute Name: enable-max-router-lsa

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
      </config>
    <max-metric>
      <config>
        </enable-max-router-lsa>
      </config>
    </max-metric>
  </process>
</processes>
</ospfv2>
```

Command Syntax

```
max-metric router-lsa
```

Configure on startup include stub

Use this attribute to set the metric of a stub link in the router LSA to the default max metric.

This command is supported when following feature are enabled Generate lsa with max-metric

Attribute Name: on-startup-include-stub

Attribute Type: empty

Attribute Name: max-on-startup

Attribute Type: uint32

Attribute Range: 5-86400

Attribute Name: max-on-startup-external-lsa

Attribute Type: uint32

Attribute Range: 1-16777215

Attribute Name: max-on-startup-summary-lsa

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
        <ospf-id>0</ospf-id>
        </config>
      <max-metric-on-startup>
        <config>
          <max-on-startup>5</max-on-startup>
          <max-on-startup-external-lsa>1</max-on-startup-external-lsa>
          <max-on-startup-summary-lsa>1</max-on-startup-summary-lsa>
          </on-startup-include-stub>
        </config>
      </max-metric-on-startup>
    </process>
  </processes>
</ospfv2>
```

Command Syntax

```
max-metric router-lsa on-startup <5-86400> { external-lsa (<1-16777215>|)| summary-
  lsa (<1-16777215>|)| include-stub }
```

Configure max on startup

Use this attribute to set the metric for router LSA on-startup for the transit link to the default max metric.

This command is supported when following feature are enabled Generate lsa with max-metric

Attribute Name: max-on-startup

Attribute Type: uint32

Attribute Range: 5-86400

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <processes>
    <process>
      <ospf-id>0</ospf-id>
      <config>
```

```
        <ospf-id>0</ospf-id>
    </config>
<max-metric-on-startup>
<config>
    <max-on-startup>5</max-on-startup>
</config>
</max-metric-on-startup>
</process>
</processes>
</ospfv2>
```

Command Syntax

```
max-metric router-lsa on-startup <5-86400>
```

Configure teName

Use this attribute to set the OSPF TE metric.

This command is supported when following feature are enabled OSPF Traffic Engineering (TE), Generalized Multi-Protocol Label Switching (GMPLS)

Attribute Name: metric

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <traffic-engineering-links>
    <traffic-engineering-link>
      <teName>WORD</teName>
      <config>
        <teName>WORD</teName>
      </config>
      <metric>1</metric> <!-- operation="delete"-->
    </traffic-engineering-link>
  </traffic-engineering-links>
</ospfv2>
```

Command Syntax

```
te-metric <1-65535>
```

Configure link local exchange

Use this attribute to enable OSPF TE link local exchange.

This command is supported when following feature are enabled OSPF Traffic Engineering (TE), Generalized Multi-Protocol Label Switching (GMPLS)

Attribute Name: link-local-exchange

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<traffic-engineering-links>
<traffic-engineering-link>
  <teName>WORD</teName>
  <config>
    <teName>WORD</teName>
  </config>
</link-local-exchange><!-- operation="delete"-->
</traffic-engineering-link>
</traffic-engineering-links>
</ospfv2>
```

Command Syntax

```
enable-te-link-local
```

Configure neighbor

Use this attribute to set the OSPF area ID in which to enable multi-area adjacency.

This command is supported when following feature are enabled HAVE_OSPF_MULTI_AREA

Attribute Name: area-id

Attribute Type: union

Attribute Name: neighbor

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<multi-area-interfaces>
<multi-area-interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<ospfv2-processes>
<ospfv2-process>
  <ospf-process-id>0</ospf-process-id>
  <config>
    <ospf-process-id>0</ospf-process-id>
  </config>
<multi-areas-neighbors>
<multi-area-neighbor> <!-- operation="delete"-->
  <area-id>OSPF_AREA_T</area-id>
  <config>
    <area-id>OSPF_AREA_T</area-id>
    <neighbor>A.B.C.D</neighbor>
  </config>
</multi-area-neighbor>
</multi-areas-neighbors>
```

```
</ospfv2-process>  
</ospfv2-processes>  
</multi-area-interface>  
</multi-area-interfaces>  
</ospfv2>
```

Command Syntax

```
ip ospf <0-65535> multi-area (A.B.C.D|<0-4294967295>) neighbor A.B.C.D
```

Configure rate limit

Use this attribute to enable OSPF Database Timers Rate Limiting Values for LSA Throttling debug.

Attribute Name: rate-limit

Attribute Type: uint8

Attribute Name: bfd

Attribute Type: empty

Attribute Name: segment-routing

Attribute Type: empty

Attribute Name: route

Attribute Type: bits (spf|ia|ase|install|spf-terse)

Attribute Name: rib

Attribute Type: bits (interface|redistribute)

Attribute Name: nsm

Attribute Type: bits (interface|redistribute)

Attribute Name: n fsm

Attribute Type: bits (status|events|timers)

Attribute Name: lsa

Attribute Type: bits (generate|flooding|install|refresh|maxage)

Attribute Name: ifsm

Attribute Type: bits (status|events|timers)

Attribute Name: events

Attribute Type: bits (abr|nssa|asbr|vlink|lsa|os|router)

Attribute Name: cspf-events

Attribute Type: empty

Attribute Name: cspf-hexdump

Attribute Type: empty

Attribute Name: retransmission

Attribute Type: empty

Attribute Name: distribute

Attribute Type: empty
 Attribute Name: topology-independent-lfa
 Attribute Type: empty
 Attribute Name: lfa
 Attribute Type: empty
 Attribute Name: policy
 Attribute Type: empty
 Attribute Name: redistribute
 Attribute Type: bits (detail|terse)
 Attribute Name: graceful-restart
 Attribute Type: bits (detail|terse)
 Attribute Name: packet-hello
 Attribute Type: bits (send|rcv|detail)
 Attribute Name: packet-dd
 Attribute Type: bits (send|rcv|detail)
 Attribute Name: packet-ls-request
 Attribute Type: bits (send|rcv|detail)
 Attribute Name: packet-ls-update
 Attribute Type: bits (send|rcv|detail)
 Attribute Name: packet-ls-ack
 Attribute Type: bits (send|rcv|detail)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    </bfd><!-- operation="delete"-->
    </segment-routing><!-- operation="delete"-->
    <route>spf</route> <!-- operation="delete"-->
    <rib>interface</rib> <!-- operation="delete"-->
    <nsm>interface</nsm> <!-- operation="delete"-->
    <nfsm>status</nfsm> <!-- operation="delete"-->
    <lsa>generate</lsa> <!-- operation="delete"-->
    <ifsm>status</ifsm> <!-- operation="delete"-->
    <events>abr</events> <!-- operation="delete"-->
    </cspf-events><!-- operation="delete"-->
    </cspf-hexdump><!-- operation="delete"-->
    </retransmission><!-- operation="delete"-->
    </distribute><!-- operation="delete"-->
    </topology-independent-lfa><!-- operation="delete"-->
    </lfa><!-- operation="delete"-->
    </policy><!-- operation="delete"-->
    <redistribute>detail</redistribute> <!-- operation="delete"-->
```

```
<graceful-restart>detail</graceful-restart> <!-- operation="delete"-->
<packet-hello>send</packet-hello> <!-- operation="delete"-->
<packet-dd>send</packet-dd> <!-- operation="delete"-->
<packet-ls-request>send</packet-ls-request> <!-- operation="delete"-->
<packet-ls-update>send</packet-ls-update> <!-- operation="delete"-->
<packet-ls-ack>send</packet-ls-ack> <!-- operation="delete"-->
</rate-limit><!-- operation="delete"-->
</config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ospf
```

Configure bfd

Use this attribute to enable OSPF Database Timers Rate Limiting Values for LSA Throttling debug.

Attribute Name: rate-limit

Attribute Type: uint8

Attribute Name: bfd

Attribute Type: empty

Attribute Name: segment-routing

Attribute Type: empty

Attribute Name: route

Attribute Type: bits (spf|ia|ase|install|spf-terse)

Attribute Name: rib

Attribute Type: bits (interface|redistribute)

Attribute Name: nsm

Attribute Type: bits (interface|redistribute)

Attribute Name: n fsm

Attribute Type: bits (status|events|timers)

Attribute Name: lsa

Attribute Type: bits (generate|flooding|install|refresh|maxage)

Attribute Name: ifsm

Attribute Type: bits (status|events|timers)

Attribute Name: events

Attribute Type: bits (abr|nssa|asbr|vlink|lsa|os|router)

Attribute Name: cspf-events

Attribute Type: empty

Attribute Name: cspf-hexdump

Attribute Type: empty

Attribute Name: retransmission
Attribute Type: empty
Attribute Name: distribute
Attribute Type: empty
Attribute Name: topology-independent-lfa
Attribute Type: empty
Attribute Name: lfa
Attribute Type: empty
Attribute Name: policy
Attribute Type: empty
Attribute Name: redistribute
Attribute Type: bits (detail|terse)
Attribute Name: graceful-restart
Attribute Type: bits (detail|terse)
Attribute Name: packet-hello
Attribute Type: bits (send|rcv|detail)
Attribute Name: packet-dd
Attribute Type: bits (send|rcv|detail)
Attribute Name: packet-ls-request
Attribute Type: bits (send|rcv|detail)
Attribute Name: packet-ls-update
Attribute Type: bits (send|rcv|detail)
Attribute Name: packet-ls-ack
Attribute Type: bits (send|rcv|detail)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<debug>
<config>
  </bfd><!-- operation="delete"-->
</segment-routing><!-- operation="delete"-->
<route>spf</route> <!-- operation="delete"-->
<rib>interface</rib> <!-- operation="delete"-->
<nsm>interface</nsm> <!-- operation="delete"-->
<nfsm>status</nfsm> <!-- operation="delete"-->
<lsa>generate</lsa> <!-- operation="delete"-->
<ifsm>status</ifsm> <!-- operation="delete"-->
<events>abr</events> <!-- operation="delete"-->
</cspf-events><!-- operation="delete"-->
</cspf-hexdump><!-- operation="delete"-->
</retransmission><!-- operation="delete"-->
```

```
</distribute><!-- operation="delete"-->
</topology-independent-lfa><!-- operation="delete"-->
</lfa><!-- operation="delete"-->
</policy><!-- operation="delete"-->
<redistribute>detail</redistribute> <!-- operation="delete"-->
<graceful-restart>detail</graceful-restart> <!-- operation="delete"-->
<packet-hello>send</packet-hello> <!-- operation="delete"-->
<packet-dd>send</packet-dd> <!-- operation="delete"-->
<packet-ls-request>send</packet-ls-request> <!-- operation="delete"-->
<packet-ls-update>send</packet-ls-update> <!-- operation="delete"-->
<packet-ls-ack>send</packet-ls-ack> <!-- operation="delete"-->
</rate-limit><!-- operation="delete"-->
</config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ospf all
```

Configure retransmission

Use this attribute to enable OSPF Debug retransmission information debug.

Attribute Name: retransmission

Attribute Type: uint8

Attribute Name: distribute

Attribute Type: empty

Attribute Name: topology-independent-lfa

Attribute Type: empty

Attribute Name: lfa

Attribute Type: empty

Attribute Name: policy

Attribute Type: empty

Attribute Name: redistribute

Attribute Type: bits (detail|terse)

Attribute Name: graceful-restart

Attribute Type: bits (detail|terse)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<debug>
<config>
  </distribute><!-- operation="delete"-->
  </topology-independent-lfa><!-- operation="delete"-->
  </lfa><!-- operation="delete"-->
```

```
</policy><!-- operation="delete"-->
<redistribute>detail</redistribute> <!-- operation="delete"-->
<graceful-restart>detail</graceful-restart> <!-- operation="delete"-->
</retransmission><!-- operation="delete"-->
</config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ip ospf all
```

Configure cspf events

Use this attribute to enable CSPF Information debug.

Attribute Name: cspf-events

Attribute Type: uint8

Attribute Name: cspf-hexdump

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<debug>
<config>
  </cspf-hexdump><!-- operation="delete"-->
  </cspf-events><!-- operation="delete"-->
</config>
</debug>
</ospfv2>
```

Command Syntax

```
debug cspf all
```

Configure segment routing

Use this attribute to enable Segment Routing debug.

Attribute Name: segment-routing

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<debug>
<config>
  </segment-routing><!-- operation="delete"-->
</config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ospf sr
```

Configure route

Use this attribute to enable OSPF route information debug.

Attribute Name: route

Attribute Type: bits (spf|ia|ase|install|spf-terse)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
    <config>
      <route>spf</route> <!-- operation="delete"-->
    </config>
  </debug>
</ospfv2>
```

Command Syntax

```
debug ospf route ({spf|ia|ase|install|spf-terse}||)
```

Configure rib

Use this attribute to enable OSPF RIB information debug.

Attribute Name: rib

Attribute Type: bits (interface|redistribute)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
    <config>
      <rib>interface</rib> <!-- operation="delete"-->
    </config>
  </debug>
</ospfv2>
```

Command Syntax

```
debug ospf rib ({interface|redistribute}||)
```

Configure nsm

Use this attribute to enable OSPF NSM information debug.

Attribute Name: nsm

Attribute Type: bits (interface|redistribute)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    <nsm>interface</nsm> <!-- operation="delete"-->
  </config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ospf nsm ({interface|redistribute|})
```

Configure nfsm

Use this attribute to enable OSPF Neighbor State Machine debug.

Attribute Name: nfsm

Attribute Type: bits (status|events|timers)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    <nfsm>status</nfsm> <!-- operation="delete"-->
  </config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ospf nfsm ({status|events|timers|})
```

Configure lsa

Use this attribute to enable OSPF Link State Advertisement debug.

Attribute Name: lsa

Attribute Type: bits (generate|flooding|install|refresh|maxage)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    <lsa>generate</lsa> <!-- operation="delete"-->
  </config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ospf lsa ({generate|flooding|install|refresh|maxage|})
```

Configure ifsm

Use this attribute to enable OSPF Interface State Machine debug.

Attribute Name: ifsm

Attribute Type: bits (status|events|timers)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    <ifsm>status</ifsm> <!-- operation="delete"-->
  </config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ospf ifsm ({status|events|timers|})
```

Configure events

Use this attribute to enable OSPF events information debug.

Attribute Name: events

Attribute Type: bits (abr|nssa|asbr|vlink|lsa|os|router)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    <events>abr</events> <!-- operation="delete"-->
  </config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ospf events ({abr|nssa|asbr|vlink|lsa|os|router|})
```

Configure cspf hexdump

Use this attribute to enable CSPF message hexdump debug.

Attribute Name: cspf-hexdump

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    </cspf-hexdump><!-- operation="delete"-->
  </config>
</debug>
</ospfv2>
```

```
</config>  
</debug>  
</ospfv2>
```

Command Syntax

```
debug cspf hexdump
```

Configure distribute

Use this attribute to enable OSPF distribute linkstate details debug.

Attribute Name: distribute

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<debug>  
<config>  
  </distribute><!-- operation="delete"-->  
</config>  
</debug>  
</ospfv2>
```

Command Syntax

```
debug ip ospf dist-ls
```

Configure topology independent lfa

Use this attribute to enable Topology Independent LFA debug.

Attribute Name: topology-independent-lfa

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<debug>  
<config>  
  </topology-independent-lfa><!-- operation="delete"-->  
</config>  
</debug>  
</ospfv2>
```

Command Syntax

```
debug ip ospf tilfa
```

Configure lfa

Use this attribute to enable OSPF LFA route install details debug.

Attribute Name: lfa

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    </lfa><!-- operation="delete"-->
  </config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ip ospf lfa
```

Configure policy

Use this attribute to enable OSPF policy information debug.

Attribute Name: policy

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    </policy><!-- operation="delete"-->
  </config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ip ospf policy
```

Configure redistribute

Use this attribute to enable OSPF redistribute information debug.

Attribute Name: redistribute

Attribute Type: bits (detail|terse)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    <redistribute>detail</redistribute> <!-- operation="delete"-->
  </config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ip ospf redistribute ({detail|terse})
```

Configure graceful restart

Use this attribute to enable OSPF graceful-restart debug.

Attribute Name: graceful-restart

Attribute Type: bits (detail|terse)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
    <config>
      <graceful-restart>detail</graceful-restart> <!-- operation="delete"-->
    </config>
  </debug>
</ospfv2>
```

Command Syntax

```
debug ip ospf graceful-restart ({detail|terse})
```

Configure packet hello

OSPF Hello

Attribute Name: packet-hello

Attribute Type: bits (send|recv|detail)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
    <config>
      <packet-hello>send</packet-hello> <!-- operation="delete"-->
    </config>
  </debug>
</ospfv2>
```

Command Syntax

```
debug ospf packet hello ({send|recv|detail})
```

Configure packet dd

OSPF Database Description

Attribute Name: packet-dd

Attribute Type: bits (send|recv|detail)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    <packet-dd>send</packet-dd> <!-- operation="delete"-->
  </config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ospf packet dd ({send|rcv|detail|})
```

Configure packet ls request

OSPF Link State Request

Attribute Name: packet-ls-request

Attribute Type: bits (send|rcv|detail)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    <packet-ls-request>send</packet-ls-request> <!-- operation="delete"-->
  </config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ospf packet ls-request ({send|rcv|detail|})
```

Configure packet ls update

OSPF Link State Update

Attribute Name: packet-ls-update

Attribute Type: bits (send|rcv|detail)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    <packet-ls-update>send</packet-ls-update> <!-- operation="delete"-->
  </config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ospf packet ls-update ({send|rcv|detail|})
```

Configure packet ls ack

OSPF Link State Acknowledgment

Attribute Name: packet-ls-ack

Attribute Type: bits (send|recv|detail)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <debug>
  <config>
    <packet-ls-ack>send</packet-ls-ack> <!-- operation="delete"-->
  </config>
</debug>
</ospfv2>
```

Command Syntax

```
debug ospf packet ls-ack ({send|recv|detail|})
```

clear ip ospf <0-65535> process

Attribute Name: process-id

Attribute Type: uint16

Attribute Range: 0-65535

Netconf RPC payload

```
<ospfv2-clear-process xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <process-id>0</process-id>
</ospfv2-clear-process>
```

Command Syntax

```
clear ip ospf <0-65535> process
```

clear ip ospf process

Netconf RPC payload

```
<ospfv2-clear-process-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
clear ip ospf process
```

restart ip ospf graceful (grace-period <2-1800>|)

Attribute Name: grace-period

Attribute Type: uint16

Attribute Range: 2-1800

Netconf RPC payload

```
<ospfv2-restart-graceful xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<grace-period>2</grace-period>  
</ospfv2-restart-graceful>
```

Command Syntax

```
restart ip ospf graceful (grace-period <2-1800>|)
```

snmp restart ospf

Netconf RPC payload

```
<ospfv2-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
snmp restart ospf
```

debug ospf all

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-ospf-all-on xmlns="http://  
www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
debug ospf all
```

no debug ospf all

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-ospf-all-off xmlns="http://  
www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
no debug ospf all
```

debug ospf bfd

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-bfd-on xmlns="http://www.ipinfusion.com/  
yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
debug ospf bfd
```

no debug ospf bfd

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-bfd-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
no debug ospf bfd
```

debug ospf database-timer rate-limit

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-rate-limit-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
debug ospf database-timer rate-limit
```

no debug ospf database-timer rate-limit

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-rate-limit-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
no debug ospf database-timer rate-limit
```

debug ospf sr

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-sr-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
debug ospf sr
```

no debug ospf sr

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-sr-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
no debug ospf sr
```

debug ospf route ({spf|ia|ase|install|spf-terse})

Attribute Name: route

Attribute Type: bits (spf|ia|ase|install|spf-terse)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-route-on xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-ospf">
  <route>spf</route>
</ipi-ospf-debug_ospfv2-terminal-debug-route-on>
```

Command Syntax

```
debug ospf route ({spf|ia|ase|install|spf-terse})
```

no debug ospf route ({spf|ia|ase|install|spf-terse})

Attribute Name: route

Attribute Type: bits (spf|ia|ase|install|spf-terse)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-route-off xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <route>spf</route>
</ipi-ospf-debug_ospfv2-terminal-debug-route-off>
```

Command Syntax

```
no debug ospf route ({spf|ia|ase|install|spf-terse})
```

debug ospf rib ({interface|redistribute})

Attribute Name: rib

Attribute Type: bits (interface|redistribute)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-rib-on xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-ospf">
  <rib>interface</rib>
</ipi-ospf-debug_ospfv2-terminal-debug-rib-on>
```

Command Syntax

```
debug ospf rib ({interface|redistribute})
```

no debug ospf rib ({interface|redistribute})

Attribute Name: rib

Attribute Type: bits (interface|redistribute)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-rib-off xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-ospf">
  <rib>interface</rib>
</ipi-ospf-debug_ospfv2-terminal-debug-rib-off>
```

Command Syntax

```
no debug ospf rib ({interface|redistribute|})
```

debug ospf packet ({send|recv|detail|})

Attribute Name: all

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-packet-all-on xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <all>send</all>
</ipi-ospf-debug_ospfv2-terminal-debug-packet-all-on>
```

Command Syntax

```
debug ospf packet ({send|recv|detail|})
```

no debug ospf packet ({send|recv|detail|})

Attribute Name: all

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-packet-all-off xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <all>send</all>
</ipi-ospf-debug_ospfv2-terminal-debug-packet-all-off>
```

Command Syntax

```
no debug ospf packet ({send|recv|detail|})
```

debug ospf packet hello ({send|recv|detail|})

Attribute Name: hello

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-packet-hello-on xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <hello>send</hello>
</ipi-ospf-debug_ospfv2-terminal-debug-packet-hello-on>
```

Command Syntax

```
debug ospf packet hello ({send|recv|detail}|)
```

no debug ospf packet hello ({send|recv|detail}|)

Attribute Name: hello

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-packet-hello-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <hello>send</hello>
</ipi-ospf-debug_ospfv2-terminal-debug-packet-hello-off>
```

Command Syntax

```
no debug ospf packet hello ({send|recv|detail}|)
```

debug ospf packet dd ({send|recv|detail}|)

Attribute Name: dd

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-packet-dd-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <dd>send</dd>
</ipi-ospf-debug_ospfv2-terminal-debug-packet-dd-on>
```

Command Syntax

```
debug ospf packet dd ({send|recv|detail}|)
```

no debug ospf packet dd ({send|recv|detail}|)

Attribute Name: dd

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-packet-dd-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <dd>send</dd>
</ipi-ospf-debug_ospfv2-terminal-debug-packet-dd-off>
```

Command Syntax

```
no debug ospf packet dd ({send|recv|detail}|)
```

debug ospf packet ls-request ({send|recv|detail}|)

Attribute Name: ls-request

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-packet-ls-request-on xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <ls-request>send</ls-request>
</ipi-ospf-debug_ospfv2-terminal-debug-packet-ls-request-on>
```

Command Syntax

```
debug ospf packet ls-request ({send|recv|detail}|)
```

no debug ospf packet ls-request ({send|recv|detail}|)

Attribute Name: ls-request

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-packet-ls-request-off xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <ls-request>send</ls-request>
</ipi-ospf-debug_ospfv2-terminal-debug-packet-ls-request-off>
```

Command Syntax

```
no debug ospf packet ls-request ({send|recv|detail}|)
```

debug ospf packet ls-update ({send|recv|detail}|)

Attribute Name: ls-update

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-packet-ls-update-on xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <ls-update>send</ls-update>
</ipi-ospf-debug_ospfv2-terminal-debug-packet-ls-update-on>
```

Command Syntax

```
debug ospf packet ls-update ({send|recv|detail}|)
```

no debug ospf packet ls-update ({send|recv|detail}|)

Attribute Name: ls-update

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-packet-ls-update-off xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <ls-update>send</ls-update>
</ipi-ospf-debug_ospfv2-terminal-debug-packet-ls-update-off>
```

Command Syntax

```
no debug ospf packet ls-update ({send|recv|detail}|)
```

debug ospf packet ls-ack ({send|recv|detail}|)

Attribute Name: ls-ack

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-packet-ls-ack-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <ls-ack>send</ls-ack>
</ipi-ospf-debug_ospfv2-terminal-debug-packet-ls-ack-on>
```

Command Syntax

```
debug ospf packet ls-ack ({send|recv|detail}|)
```

no debug ospf packet ls-ack ({send|recv|detail}|)

Attribute Name: ls-ack

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-packet-ls-ack-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <ls-ack>send</ls-ack>
</ipi-ospf-debug_ospfv2-terminal-debug-packet-ls-ack-off>
```

Command Syntax

```
no debug ospf packet ls-ack ({send|recv|detail}|)
```

debug ospf nsm ({interface|redistribute}|)

Attribute Name: nsm

Attribute Type: bits (interface|redistribute)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-nsm-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <nsm>interface</nsm>
</ipi-ospf-debug_ospfv2-terminal-debug-nsm-on>
```

Command Syntax

```
debug ospf nsm ({interface|redistribute}|)
```

no debug ospf nsm ({interface|redistribute}|)

Attribute Name: nsm

Attribute Type: bits (interface|redistribute)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-nsm-off xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-ospf">
  <nsm>interface</nsm>
</ipi-ospf-debug_ospfv2-terminal-debug-nsm-off>
```

Command Syntax

```
no debug ospf nsm ({interface|redistribute}|)
```

debug ospf nfsm ({status|events|timers}|)

Attribute Name: nfsm

Attribute Type: bits (status|events|timers)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-nfsm-on xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-ospf">
  <nfsm>status</nfsm>
</ipi-ospf-debug_ospfv2-terminal-debug-nfsm-on>
```

Command Syntax

```
debug ospf nfsm ({status|events|timers}|)
```

no debug ospf nfsm ({status|events|timers}|)

Attribute Name: nfsm

Attribute Type: bits (status|events|timers)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-nfsm-off xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-ospf">
  <nfsm>status</nfsm>
</ipi-ospf-debug_ospfv2-terminal-debug-nfsm-off>
```

Command Syntax

```
no debug ospf nfsm ({status|events|timers}|)
```

debug ospf lsa ({generate|flooding|install|refresh|maxage}|)

Attribute Name: lsa

Attribute Type: bits (generate|flooding|install|refresh|maxage)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-lsa-on xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-ospf">
  <lsa>generate</lsa>
</ipi-ospf-debug_ospfv2-terminal-debug-lsa-on>
```

Command Syntax

```
debug ospf lsa ({generate|flooding|install|refresh|maxage|})
```

no debug ospf lsa ({generate|flooding|install|refresh|maxage|})

Attribute Name: lsa

Attribute Type: bits (generate|flooding|install|refresh|maxage)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-lsa-off xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-ospf">
  <lsa>generate</lsa>
</ipi-ospf-debug_ospfv2-terminal-debug-lsa-off>
```

Command Syntax

```
no debug ospf lsa ({generate|flooding|install|refresh|maxage|})
```

debug ospf ifsm ({status|events|timers|})

Attribute Name: ifsm

Attribute Type: bits (status|events|timers)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-ifsm-on xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-ospf">
  <ifsm>status</ifsm>
</ipi-ospf-debug_ospfv2-terminal-debug-ifsm-on>
```

Command Syntax

```
debug ospf ifsm ({status|events|timers|})
```

no debug ospf ifsm ({status|events|timers|})

Attribute Name: ifsm

Attribute Type: bits (status|events|timers)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-ifsm-off xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-ospf">
  <ifsm>status</ifsm>
</ipi-ospf-debug_ospfv2-terminal-debug-ifsm-off>
```

Command Syntax

```
no debug ospf ifsm ({status|events|timers|})
```

debug ospf events ({abr|nssa|asbr|vlink|lsa|os|router|})

Attribute Name: events

Attribute Type: bits (abr|nssa|asbr|vlink|lsa|os|router)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-events-on xmlns="http://  
www.ipinfusion.com/yang/ocnos/ipi-ospf">  
  <events>abr</events>  
</ipi-ospf-debug_ospfv2-terminal-debug-events-on>
```

Command Syntax

```
debug ospf events ({abr|nssa|asbr|vlink|lsa|os|router}|)
```

no debug ospf events ({abr|nssa|asbr|vlink|lsa|os|router}|)

Attribute Name: events

Attribute Type: bits (abr|nssa|asbr|vlink|lsa|os|router)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-events-off xmlns="http://  
www.ipinfusion.com/yang/ocnos/ipi-ospf">  
  <events>abr</events>  
</ipi-ospf-debug_ospfv2-terminal-debug-events-off>
```

Command Syntax

```
no debug ospf events ({abr|nssa|asbr|vlink|lsa|os|router}|)
```

debug cspf all

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-cspf-all-on xmlns="http://  
www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
debug cspf all
```

no debug cspf all

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-cspf-all-off xmlns="http://  
www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
no debug cspf all
```

debug cspf events

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-cspf-events-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
debug cspf events
```

no debug cspf events

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-cspf-events-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
no debug cspf events
```

debug cspf hexdump

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-cspf-hexdump-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
debug cspf hexdump
```

no debug cspf hexdump

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-cspf-hexdump-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
no debug cspf hexdump
```

debug ip ospf all

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-all-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
debug ip ospf all
```

no debug ip ospf all

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-all-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
no debug ip ospf all
```

debug ip ospf retransmission

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-retransmission-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
debug ip ospf retransmission
```

no debug ip ospf retransmission

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-retransmission-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
no debug ip ospf retransmission
```

debug ip ospf dist-ls

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-dist-ls-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
debug ip ospf dist-ls
```

no debug ip ospf dist-ls

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-dist-ls-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
no debug ip ospf dist-ls
```

debug ip ospf tilfa

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-topology-independent-lfa-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
debug ip ospf tilfa
```

no debug ip ospf tilfa

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-topology-independent-lfa-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
no debug ip ospf tilfa
```

debug ip ospf lfa

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-lfa-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
debug ip ospf lfa
```

no debug ip ospf lfa

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-lfa-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
no debug ip ospf lfa
```

debug ip ospf policy

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-policy-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
debug ip ospf policy
```

no debug ip ospf policy

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-policy-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf"/>
```

Command Syntax

```
no debug ip ospf policy
```

debug ip ospf redistribute ({detail|terse})

Attribute Name: redistribute

Attribute Type: bits (detail|terse)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-redistribute-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
  <redistribute>detail</redistribute>  
</ipi-ospf-debug_ospfv2-terminal-debug-redistribute-on>
```

Command Syntax

```
debug ip ospf redistribute ({detail|terse})
```

no debug ip ospf redistribute ({detail|terse})

Attribute Name: redistribute

Attribute Type: bits (detail|terse)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-redistribute-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
  <redistribute>detail</redistribute>  
</ipi-ospf-debug_ospfv2-terminal-debug-redistribute-off>
```

Command Syntax

```
no debug ip ospf redistribute ({detail|terse})
```

debug ip ospf graceful-restart ({detail|terse})

Attribute Name: graceful-restart

Attribute Type: bits (detail|terse)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-graceful-restart-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
  <graceful-restart>detail</graceful-restart>  
</ipi-ospf-debug_ospfv2-terminal-debug-graceful-restart-on>
```

Command Syntax

```
debug ip ospf graceful-restart ({detail|terse|})
```

no debug ip ospf graceful-restart ({detail|terse|})

Attribute Name: graceful-restart

Attribute Type: bits (detail|terse)

Netconf RPC payload

```
<ipi-ospf-debug_ospfv2-terminal-debug-graceful-restart-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <graceful-restart>detail</graceful-restart>
</ipi-ospf-debug_ospfv2-terminal-debug-graceful-restart-off>
```

Command Syntax

```
no debug ip ospf graceful-restart ({detail|terse|})
```

IPI-OSPF-INTERFACE

Configure cost

Use this attribute to explicitly specify the cost of the link-state metric in a router-LSA.

Attribute Name: cost

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <cost>1</cost> <!-- operation="delete"-->
    </interface>
  </interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf cost <1-65535>
```

Configure priority

Use this attribute to set the router priority to determine the designated router (DR) for the network.

Attribute Name: priority

Attribute Type: uint8

Default Value: 1

Attribute Range: 0-255

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <priority>0</priority> <!-- operation="delete"-->
    </interface>
  </interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf priority <0-255>
```

Configure mtu ignore

Use this attribute to configure OSPF so that it does not check the MTU size during DD (Database Description) exchange.

Attribute Name: mtu-ignore

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </mtu-ignore><!-- operation="delete"-->
    </interface>
  </interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf mtu-ignore
```

Configure network type

Use this attribute to set the interface network type.

Attribute Name: network-type

Attribute Type: enum (point-to-point|broadcast|non-broadcast|point-to-multipoint|point-to-multipoint non-broadcast)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <network-type>point-to-point</network-type> <!-- operation="delete"-->
    </interface>
  </interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf network (point-to-point|broadcast|non-broadcast|point-to-multipoint|point-
to-multipoint non-broadcast)
```

Configure disable all ospf

Use this attribute to completely disable OSPF packet processing on an interface.

Attribute Name: disable-all-ospf

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </disable-all-ospf><!-- operation="delete"-->
    </interface>
  </interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf disable all
```

Configure traffic engineering metric

Use this attribute to set the minimum delay in milliseconds between accepting the same LSA from neighbors.

Attribute Name: traffic-engineering-metric

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <traffic-engineering-metric>1</traffic-engineering-metric> <!--
operation="delete"-->
    </interface>
  </interfaces>
</ospfv2>
```

Command Syntax

```
te-metric <1-65535>
```

Configure mtu

Use this attribute to set MTU size for OSPF to construct packets based on this value.

Attribute Name: mtu

Attribute Type: uint16

Default Value: 576

Attribute Range: 576-65535

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <mtu>576</mtu> <!-- operation="delete"-->
    </interface>
  </interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf mtu <576-65535>
```

Configure enable flood reduction

Use this attribute to enable flood reduction on an interface.

Attribute Name: enable-flood-reduction

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </enable-flood-reduction><!-- operation="delete"-->
    </interface>
  </interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf flood-reduction
```

Configure enable demand circuit

Use this attribute to enable Hello Suppression and LSA Suppression sent on OSPF interface.

Attribute Name: enable-demand-circuit

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </enable-demand-circuit><!-- operation="delete"-->
    </interface>
  </interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf demand-circuit
```

Configure enable bfd

Use this attribute to enable Bidirectional Forwarding Detection (BFD).

Attribute Name: enable-bfd

Attribute Type: enum (enable|disable)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <enable-bfd>enable</enable-bfd> <!-- operation="delete"-->
    </interface>
  </interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf bfd (disable|)
```

Configure disable fast reroute

Use this attribute to prohibit the interface from being used as the next hop in a repair path.

Attribute Name: disable-fast-reroute

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </disable-fast-reroute><!-- operation="delete"-->
    </interface>
  </interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf fast-reroute per-prefix candidate disable
```

Configure message digest id

Use this attribute to set the authentication message digest key ID.

Attribute Name: message-digest-id

Attribute Type: uint8

Attribute Range: 1-255

Attribute Name: message-digest-encryption-type

Attribute Type: enum (md5)

Attribute Name: message-digest-key

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <addresses>
  <address>
    <interface-address>A.B.C.D</interface-address>
    <config>
      <interface-address>A.B.C.D</interface-address>
    </config>
    <authentication>
    <message-digests>
    <message-digest>
      <message-digest-id>1</message-digest-id>
      <config>
        <message-digest-id>1</message-digest-id>
        <message-digest-encryption-type>md5</message-digest-encryption-type>
        <message-digest-key>WORD</message-digest-key>
      </config>
    </message-digest>
    </message-digests>
  </address>
  </addresses>
</interface>
</interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf A.B.C.D message-digest-key <1-255> (md5) WORD
```

Configure name

Use this attribute to set the authentication message digest key ID.

Attribute Name: message-digest-id

Attribute Type: uint8

Attribute Range: 1-255

Attribute Name: message-digest-encryption-type

Attribute Type: enum (md5)

Attribute Name: message-digest-key

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <authentication>
  <message-digests>
  <message-digest>
    <message-digest-id>1</message-digest-id>
    <config>
      <message-digest-id>1</message-digest-id>
      <message-digest-encryption-type>md5</message-digest-encryption-type>
      <message-digest-key>WORD</message-digest-key>
    </config>
  </message-digest>
</message-digests>
</authentication>
</interface>
</interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf message-digest-key <1-255> (md5) WORD
```

Configure authentication type

Use this attribute to configure authentication on this interface.

Attribute Name: authentication-type

Attribute Type: enum (null|simple|message-digest)

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <addresses>
  <address>
    <interface-address>A.B.C.D</interface-address>
```

```
    <config>
      <interface-address>A.B.C.D</interface-address>
    </config>
  <authentication>
    <config>
      <authentication-type>simple</authentication-type> <!--
operation="delete"-->
    </config>
  </authentication>
</address>
</addresses>
</interface>
</interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf A.B.C.D authentication (null|message-digest|)
```

Configure key

Use this attribute to set the authentication password (key).

Attribute Name: key

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <addresses>
        <address>
          <interface-address>A.B.C.D</interface-address>
          <config>
            <interface-address>A.B.C.D</interface-address>
          </config>
          <authentication>
            <config>
              <key>WORD</key> <!-- operation="delete"-->
            </config>
          </authentication>
        </address>
      </addresses>
    </interface>
  </interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf A.B.C.D authentication-key WORD
```

Configure message digest encryption type

Use this attribute to set the authentication message digest key ID.

Attribute Name: message-digest-id

Attribute Type: uint8

Attribute Range: 1-255

Attribute Name: message-digest-encryption-type

Attribute Type: enum (md5)

Attribute Name: message-digest-key

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <authentication>
        <message-digests>
          <message-digest> <!-- operation="delete"-->
            <message-digest-id>1</message-digest-id>
            <config>
              <message-digest-id>1</message-digest-id>
              <message-digest-encryption-type>md5</message-digest-encryption-type>
              <message-digest-key>WORD</message-digest-key>
            </config>
          </message-digest>
        </message-digests>
      </authentication>
    </interface>
  </interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf message-digest-key <1-255> (md5) WORD
```

Configure filter out

Use this attribute to turn on the LSA database-filter for a particular interface. OSPF floods new LSAs over all interfaces in an area, except the interface on which the LSA arrives. This redundancy ensures robust flooding. However, too much redundancy can waste bandwidth and might lead to excessive link and CPU usage in certain topologies, resulting in destabilizing the network. To avoid this, use this attribute to block flooding of LSAs over specified interfaces.

Attribute Name: filter-out

Attribute Type: empty

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <addresses>
  <address>
    <interface-address>A.B.C.D</interface-address>
    <config>
      <interface-address>A.B.C.D</interface-address>
    </config>
    <database-filter>
    <lsa>
    <config>
      </filter-out><!-- operation="delete"-->
    </config>
    </lsa>
  </database-filter>
  </address>
</addresses>
</interface>
</interfaces>
</ospfv2>
```

Command Syntax

```
ip ospf A.B.C.D database-filter all out
```

Configure dead interval

Use this attribute to set the interval during which the router waits to receive an OSPF hello packet from the neighbor before declaring the neighbor down.

Attribute Name: dead-interval

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
```

```

</config>
<addresses>
<address>
  <interface-address>A.B.C.D</interface-address>
  <config>
    <interface-address>A.B.C.D</interface-address>
  </config>
  <timers>
  <config>
    <dead-interval>1</dead-interval> <!-- operation="delete"-->
  </config>
</timers>
</address>
</addresses>
</interface>
</interfaces>
</ospfv2>

```

Command Syntax

```
ip ospf A.B.C.D dead-interval <1-65535>
```

Configure hello interval

Use this attribute to specify the interval between hello packets.

Attribute Name: hello-interval

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-65535

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <addresses>
  <address>
    <interface-address>A.B.C.D</interface-address>
    <config>
      <interface-address>A.B.C.D</interface-address>
    </config>
    <timers>
    <config>
      <hello-interval>1</hello-interval> <!-- operation="delete"-->
    </config>
  </timers>

```

```
</address>  
</addresses>  
</interface>  
</interfaces>  
</ospfv2>
```

Command Syntax

```
ip ospf A.B.C.D hello-interval <1-65535>
```

Configure retransmission interval

Use this attribute to specify the time between link-state advertisement (LSA) retransmissions for adjacencies belonging to the interface.

Attribute Name: retransmission-interval

Attribute Type: uint16

Default Value: 5

Attribute Range: 1-3600

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<interfaces>  
<interface>  
  <name>WORD</name>  
  <config>  
    <name>WORD</name>  
  </config>  
  <addresses>  
  <address>  
    <interface-address>A.B.C.D</interface-address>  
    <config>  
      <interface-address>A.B.C.D</interface-address>  
    </config>  
    <timers>  
    <config>  
      <retransmission-interval>1</retransmission-interval> <!--  
operation="delete"-->  
    </config>  
  </timers>  
</address>  
</addresses>  
</interface>  
</interfaces>  
</ospfv2>
```

Command Syntax

```
ip ospf A.B.C.D retransmit-interval <1-3600>
```

Configure ldp igp sync enable

Use this attribute to enable the MPLS LDP IGP SYNC on OSPF.

Attribute Name: ldp-igp-sync-enable

Attribute Type: uint8

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
        </config>
        <timers>
          <config>
            </ldp-igp-sync-enable><!-- operation="delete"-->
          </config>
        </timers>
      </interface>
    </interfaces>
  </ospfv2>
```

Command Syntax

```
mpls ldp-igp sync ospf
```

Configure transmit delay

Use this attribute to set the estimated time it takes to transmit a link-state-update packet on the interface.

Attribute Name: transmit-delay

Attribute Type: uint16

Default Value: 1

Attribute Range: 1-3600

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
        </config>
        <timers>
          <config>
            <transmit-delay>1</transmit-delay> <!-- operation="delete"-->
          </config>
        </timers>
      </interface>
    </interfaces>
  </ospfv2>
```

```
</interface>  
</interfaces>  
</ospfv2>
```

Command Syntax

```
ip ospf transmit-delay <1-3600>
```

Configure resync timeout

Use this attribute to configure the interval after which adjacency is reset if oob-resync is not started.

Attribute Name: resync-timeout

Attribute Type: uint16

Default Value: 40

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">  
<interfaces>  
<interface>  
  <name>WORD</name>  
  <config>  
    <name>WORD</name>  
  </config>  
  <timers>  
    <config>  
      <resync-timeout>1</resync-timeout> <!-- operation="delete"-->  
    </config>  
  </timers>  
</interface>  
</interfaces>  
</ospfv2>
```

Command Syntax

```
ip ospf resync-timeout <1-65535>
```

Configure holddown timer

Use this attribute to configure the hold-down timer for which OSPF will wait for LDP to converge and advertises Max cost. When the configured time expires, OSPF starts advertising the actual cost in the Router-LSA.

Attribute Name: holddown-timer

Attribute Type: uint32

Default Value: 70000

Attribute Range: 1-2147483

Attribute Name: ldp-igp-sync-enable

Attribute Type: empty

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <timers>
  <config>
    </ldp-igp-sync-enable><!-- operation="delete"-->
    <holddown-timer>1</holddown-timer> <!-- operation="delete"-->
  </config>
</timers>
</interface>
</interfaces>
</ospfv2>

```

Command Syntax

```
mpls ldp-igp sync ospf holddown-timer <1-2147483>
```

Configure interface address

Use this attribute to explicitly specify the cost of the link-state metric in a router-LSA.

Attribute Name: cost

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-65535

Netconf edit-config payload

```

<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <addresses>
  <address>
    <interface-address>A.B.C.D</interface-address>
    <config>
      <interface-address>A.B.C.D</interface-address>
    </config>
    <cost>1</cost> <!-- operation="delete"-->
  </address>
</addresses>
</interface>
</interfaces>

```

```
</ospfv2>
```

Command Syntax

```
ip ospf A.B.C.D cost <1-65535>
```

Configure message digest key

Use this attribute to set the authentication message digest key ID.

Attribute Name: message-digest-id

Attribute Type: uint8

Attribute Range: 1-255

Attribute Name: message-digest-encryption-type

Attribute Type: enum (md5)

Attribute Name: message-digest-key

Attribute Type: string

Netconf edit-config payload

```
<ospfv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <addresses>
        <address>
          <interface-address>A.B.C.D</interface-address>
          <config>
            <interface-address>A.B.C.D</interface-address>
            </config>
            <authentication>
              <message-digests>
                <message-digest>
                  <message-digest-id>1</message-digest-id>
                  <config>
                    <message-digest-id>1</message-digest-id>
                    <message-digest-encryption-type>md5</message-digest-encryption-type>
                    <message-digest-key>WORD</message-digest-key>
                  </config>
                </message-digest>
              </message-digests>
            </authentication>
          </address>
        </addresses>
      </interface>
    </interfaces>
  </ospfv2>
```

Command Syntax

```
ip ospf A.B.C.D message-digest-key <1-255> (md5) WORD
```

IPI-OSPFV3

Configure display route on single line

Use this attribute to display the output of the show ipv6 ospf route command with each route entry in a singleline.

Attribute Name: display-route-on-single-line

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <global>
    <config>
      </display-route-on-single-line><!-- operation="delete"-->
    </config>
  </global>
</ospfv3>
```

Command Syntax

```
ipv6 ospf display route single-line
```

Configure grace period

Use this attribute to enable the graceful restart feature and set the grace period for restarting the router

This command is supported when following feature are enabled Restart capability

Attribute Name: grace-period

Attribute Type: uint16

Default Value: 120

Attribute Range: 2-1800

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <global>
    <graceful-restart>
      <config>
        <grace-period>2</grace-period> <!-- operation="delete"-->
      </config>
    </graceful-restart>
  </global>
</ospfv3>
```

Command Syntax

```
ipv6 ospf restart grace-period <2-1800>
```

Configure controlled restarts only

Use this attribute to enable the graceful restart controlled restarts only for the router

This command is supported when following feature are enabled Restart capability

Attribute Name: controlled-restarts-only

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <global>
    <graceful-restart>
      <config>
        </controlled-restarts-only><!-- operation="delete"-->
      </config>
    </graceful-restart>
  </global>
</ospfv3>
```

Command Syntax

```
ipv6 ospf restart planned-only
```

Configure max grace period

Use this attribute to set the maximum grace period to act as helper. i.e Help only if received grace-period is less than set value.

This command is supported when following feature are enabled Restart capability

Attribute Name: max-grace-period

Attribute Type: uint16

Attribute Range: 2-1800

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <global>
    <graceful-restart>
      <helper>
        <config>
          <max-grace-period>2</max-grace-period> <!-- operation="delete"-->
        </config>
      </helper>
    </graceful-restart>
  </global>
</ospfv3>
```

Command Syntax

```
ipv6 ospf restart helper max-grace-period <2-1800>
```

Configure disable all neighbors

Use this attribute to set disable acting as helper for all neighbors.

This command is supported when following feature are enabled Restart capability

Attribute Name: disable-all-neighbors

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <global>
    <graceful-restart>
      <helper>
        <config>
          </disable-all-neighbors><!-- operation="delete"-->
        </config>
      </helper>
    </graceful-restart>
  </global>
</ospfv3>
```

Command Syntax

```
ipv6 ospf restart helper never
```

Configure disable neighbor

Use this attribute to set disable acting as helper for specified neighbor.

This command is supported when following feature are enabled Restart capability

Attribute Name: disable-neighbor

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <global>
    <graceful-restart>
      <helper>
        <config>
          <disable-neighbor>A.B.C.D</disable-neighbor> <!-- operation="delete"-->
        </config>
      </helper>
    </graceful-restart>
  </global>
</ospfv3>
```

Command Syntax

```
ipv6 ospf restart helper never router-id A.B.C.D
```

Configure vrf name

VRF Name to associate with this instance

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
      <vrf-name>WORD</vrf-name>
    </process>
  </processes>
</ospfv3>
```

Command Syntax

```
router ipv6 vrf ospf WORD
```

Configure ospfv3 id

Use this attribute to set the OSPFv3 process ID

Attribute Name: ospfv3-id

Attribute Type: string

Attribute Range: 0-254

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process> <!-- operation="delete"-->
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
        <vrf-name>WORD</vrf-name>
      </config>
    </process>
  </processes>
</ospfv3>
```

Command Syntax

```
router ipv6 ospf (WORD|) (WORD|)
```

Configure router id

Use this attribute to set a router ID for the OSPFv3 process. Configure each router OSPFv3 with an unique router ID

Attribute Name: router-id

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
      <router-id>A.B.C.D</router-id> <!-- operation="delete"-->
    </process>
  </processes>
</ospfv3>
```

Command Syntax

```
router-id A.B.C.D
```

Configure bfd enable all interfaces

Use this attribute to enable Bidirectional Forwarding Detection (BFD) on all interfaces.

Attribute Name: bfd-enable-all-interfaces

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
      </bfd-enable-all-interfaces><!-- operation="delete"-->
    </process>
  </processes>
</ospfv3>
```

Command Syntax

```
bfd all-interfaces
```

Configure database summary

Use this attribute to enable the database summary list optimization for OSPFv3.

Attribute Name: database-summary

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
      </database-summary><!-- operation="delete"-->
    </process>
  </processes>
</ospfv3>
```

Command Syntax

```
enable db-summary-opt
```

Configure area border type

Use this attribute to set an OSPFv3 Area Border Router (ABR) type.

Attribute Name: area-border-type

Attribute Type: enum (standard|cisco|ibm)

Default Value: cisco

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
      <area-border-type>cisco</area-border-type> <!-- operation="delete"-->
    </process>
  </processes>
</ospfv3>
```

Command Syntax

```
abr-type (standard|cisco|ibm)
```

Configure default metric

Use this attribute to set a default metric for OSPFv3.

Attribute Name: default-metric

Attribute Type: uint32

Default Value: 20

Attribute Range: 1-16777214

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
      <default-metric>1</default-metric> <!-- operation="delete"-->
    </process>
  </processes>
</ospfv3>
```

Command Syntax

```
default-metric <1-16777214>
```

Configure shutdown

Use this attribute to specify an OSPFv3 shutdown

Attribute Name: shutdown

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
      </shutdown><!-- operation="delete"-->
    </process>
  </processes>
</ospfv3>
```

Command Syntax

```
shutdown
```

Configure log adjacency changes

Use this attribute for the the router to send a SYSLOG message when an OSPFv3 neighbor goes up or down.

Attribute Name: log-adjacency-changes

Attribute Type: enum (brief|detail)

Default Value: brief

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
      <log-adjacency-changes>brief</log-adjacency-changes> <!-- operation="delete"-->
    </process>
  </processes>
</ospfv3>
```

Command Syntax

```
log-adjacency-changes (brief|detail|)
```

Configure reference bandwidth

Use this attribute to control how OSPFv3 calculates the default metric for the interface.

Attribute Name: reference-bandwidth

Attribute Type: uint32

Default Value: 100

Attribute Range: 1-4294967

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
      <reference-bandwidth>1</reference-bandwidth> <!-- operation="delete"-->
    </process>
  </processes>
</ospfv3>
```

Command Syntax

```
auto-cost reference-bandwidth <1-4294967>
```

Configure max database descriptors

Use this attribute to limit the number of Database Descriptors (DD) that can be processed concurrently.

Attribute Name: max-database-descriptors

Attribute Type: uint16

Default Value: 5

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
        </config>
        <max-database-descriptors>1</max-database-descriptors> <!-- operation="delete"-->
      >
    </process>
  </processes>
</ospfv3>
```

Command Syntax

```
max-concurrent-dd <1-65535>
```

Configure default distance

Default administrative distance value

Attribute Name: default-distance

Attribute Type: uint8

Default Value: 110

Attribute Range: 1-254

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
        </config>
        <administrative-distance>
          <config>
            <default-distance>1</default-distance> <!-- operation="delete"-->
          </config>
        </administrative-distance>
      </process>
```

```
</processes>  
</ospfv3>
```

Command Syntax

```
distance <1-254>
```

Configure intra area distance

Administrative distance for intra-area routes

Attribute Name: intra-area-distance

Attribute Type: uint8

Default Value: 110

Attribute Range: 1-254

Attribute Name: inter-area-distance

Attribute Type: uint8

Default Value: 110

Attribute Range: 1-254

Attribute Name: external-routes-distance

Attribute Type: uint8

Default Value: 110

Attribute Range: 1-254

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">  
  <processes>  
    <process>  
      <ospfv3-id>WORD</ospfv3-id>  
      <config>  
        <ospfv3-id>0</ospfv3-id>  
        </config>  
      <administrative-distance>  
        <ospf>  
          <config>  
            <inter-area-distance>1</inter-area-distance> <!-- operation="delete"-->  
            <external-routes-distance>1</external-routes-distance> <!--  
operation="delete"-->  
            <intra-area-distance>1</intra-area-distance> <!-- operation="delete"-->  
          </config>  
        </ospf>  
      </administrative-distance>  
    </process>  
  </processes>  
</ospfv3>
```

Command Syntax

```
distance ospfv3 { intra-area <1-254>| inter-area <1-254>| external <1-254> }
```

Configure traffic engineering

OSPFv3 Traffic Engineering extension

Attribute Name: traffic-engineering

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    <capability>
      <config>
        </traffic-engineering><!-- operation="delete"-->
      </config>
    </capability>
  </process>
</processes>
</ospfv3>
```

Command Syntax

```
capability te
```

Configure disable graceful restart

Graceful OSPFv3 Restart

Attribute Name: disable-graceful-restart

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    <capability>
      <config>
        </disable-graceful-restart><!-- operation="delete"-->
      </config>
    </capability>
  </processes>
</ospfv3>
```

```
</process>  
</processes>  
</ospfv3>
```

Command Syntax

```
no capability restart
```

Configure exponential max delay

Use this attribute to set the maximum SPF hold delay time in milliseconds

Attribute Name: exponential-max-delay

Attribute Type: uint32

Attribute Range: 0-2147483647

Attribute Name: exponential-min-delay

Attribute Type: uint32

Attribute Range: 0-2147483647

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">  
  <processes>  
    <process>  
      <ospfv3-id>WORD</ospfv3-id>  
      <config>  
        <ospfv3-id>0</ospfv3-id>  
      </config>  
      <timers>  
        <spf>  
          <config>  
            <exponential-min-delay>0</exponential-min-delay>  
            <exponential-max-delay>0</exponential-max-delay>  
          </config>  
        </spf>  
      </timers>  
    </process>  
  </processes>  
</ospfv3>
```

Command Syntax

```
timers spf exp <0-2147483647> <0-2147483647>
```

Configure ospf6SRv6enable

Enable segment routing v6

Attribute Name: ospf6SRv6enable

Attribute Type: uint8

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<processes>
<process>
  <ospfv3-id>WORD</ospfv3-id>
  <config>
    <ospfv3-id>0</ospfv3-id>
  </config>
</ospfv3-srv6>
<config>
  </ospfv3-srv6enable><!-- operation="delete"-->
</config>
</ospfv3-srv6>
</process>
</processes>
</ospfv3>

```

Command Syntax

```
segment-routing srv6
```

Configure ospf6SRv6LocatorName

Locator name

Attribute Name: ospf6SRv6LocatorName

Attribute Type: string

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<processes>
<process>
  <ospfv3-id>WORD</ospfv3-id>
  <config>
    <ospfv3-id>0</ospfv3-id>
  </config>
</ospfv3-srv6>
<locator-lists>
<locator-list> <!-- operation="delete"-->
  <ospf6SRv6LocatorName>WORD</ospf6SRv6LocatorName>
  <config>
    <ospf6SRv6LocatorName>WORD</ospf6SRv6LocatorName>
  </config>
</locator-list>
</locator-lists>
</ospfv3-srv6>
</process>
</processes>
</ospfv3>

```

Command Syntax

```
srv6-locator WORD
```

Configure all interfaces

Use this attribute to set all interfaces as passive

Attribute Name: all-interfaces

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    <passive-interfaces>
      <config>
        </all-interfaces><!-- operation="delete"-->
      </config>
    </passive-interfaces>
  </process>
</processes>
</ospfv3>
```

Command Syntax

```
passive-interface
```

Configure name

Use this attribute to set interface as passive or not.

Attribute Name: name

Attribute Type: string

Attribute Range: 1-33

Attribute Name: passive-mode

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    </process>
  </processes>
</ospfv3>
```



```

<passive-interfaces>
<passive-interface> <!-- operation="delete"-->
  <name>IFNAME</name>
  <config>
    <name>WORD</name>
    <passive-mode>enable</passive-mode>
  </config>
</passive-interface>
</passive-interfaces>
</process>
</processes>
</ospfv3>

```

Command Syntax

```
passive-interface IFNAME (disable|enable)
```

Configure address

Use this attribute to summarize or suppress external routes with the specified address range.

Attribute Name: address

Attribute Type: string

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<processes>
<process>
  <ospfv3-id>WORD</ospfv3-id>
  <config>
    <ospfv3-id>0</ospfv3-id>
  </config>
<summary-addresses>
<summary-address> <!-- operation="delete"-->
  <address>X:X::X:X/M</address>
  <config>
    <address>X:X::X:X/M</address>
  </config>
</summary-address>
</summary-addresses>
</process>
</processes>
</ospfv3>

```

Command Syntax

```
summary-address X:X::X:X/M
```

Configure translate tag

Use this attribute to set or unset translate tag to external routes with the specified address range.

Attribute Name: translate-tag

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Attribute Name: all-tag

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
      <summary-addresses>
        <summary-address>
          <address>X:X::X:X/M</address>
          <config>
            <address>X:X::X:X/M</address>
            <all-tag>0</all-tag> <!-- operation="delete"-->
          </config>
            <translate-tag>0</translate-tag> <!-- operation="delete"-->
        </summary-address>
      </summary-addresses>
    </process>
  </processes>
</ospfv3>
```

Command Syntax

```
summary-address X:X::X:X/M all-tag <0-4294967295> translate-tag <0-4294967295>
```

Configure not advertise

Use this attribute to set or unset not advertise to summarize or suppress external routes with the specified address range.

Attribute Name: not-advertise

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
```

```

    <config>
      <ospfv3-id>0</ospfv3-id>
    </config>
  <summary-addresses>
  <summary-address>
    <address>X:X::X:X/M</address>
    <config>
      <address>X:X::X:X/M</address>
    </config>
    </not-advertise><!-- operation="delete"-->
  </summary-address>
</summary-addresses>
</process>
</processes>
</ospfv3>

```

Command Syntax

```
summary-address X:X::X:X/M not-advertise
```

Configure all tag

Use this attribute to set or unset all tag to summarize or suppress external routes with the specified address range.

Attribute Name: all-tag

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
  <process>
    <ospfv3-id>WORD</ospfv3-id>
    <config>
      <ospfv3-id>0</ospfv3-id>
    </config>
  <summary-addresses>
  <summary-address>
    <address>X:X::X:X/M</address>
    <config>
      <address>X:X::X:X/M</address>
    </config>
    <all-tag>0</all-tag> <!-- operation="delete"-->
  </summary-address>
</summary-addresses>
</process>
</processes>
</ospfv3>

```

Command Syntax

```
summary-address X:X::X:X/M all-tag <0-4294967295>
```

Configure originate

Use this attribute to create a default external route into an OSPF routing domain. The system acts like an Autonomous System Boundary Router (ASBR) when you use the default-information originate command to redistribute routes into an OSPF routing domain. An ASBR does not by default generate a default route into the OSPF routing domain

Attribute Name: originate

Attribute Type: uint8

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
      <default-information>
        <config>
          </originate><!-- operation="delete"-->
        </config>
      </default-information>
    </process>
  </processes>
</ospfv3>
```

Command Syntax

```
default-information originate
```

Configure route map

Use this attribute to set route-map instance.

Attribute Name: route-map

Attribute Type: string

Attribute Range: 1-63

Attribute Name: originate

Attribute Type: empty

Attribute Name: always-advertise-default-route

Attribute Type: empty

Attribute Name: metric

Attribute Type: uint32

Default Value: 20

Attribute Range: 0-16777214

Attribute Name: metric-type

Attribute Type: enum (1|2)

Default Value: 2

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
  <process>
    <ospfv3-id>WORD</ospfv3-id>
    <config>
      <ospfv3-id>0</ospfv3-id>
    </config>
  <default-information>
  <config>
    </originate><!-- operation="delete"-->
    </always-advertise-default-route><!-- operation="delete"-->
    <metric>0</metric> <!-- operation="delete"-->
    <metric-type>2</metric-type> <!-- operation="delete"-->
    <route-map>WORD</route-map> <!-- operation="delete"-->
  </config>
</default-information>
</process>
</processes>
</ospfv3>
```

Command Syntax

```
default-information originate { always| metric <0-16777214>| metric-type (1|2)|
  route-map WORD }
```

Configure access control list

Use this attribute to set the access control list name in distribution list.

This command is supported when following feature are enabled HAVE_ACL

Attribute Name: access-control-list

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
  <process>
    <ospfv3-id>WORD</ospfv3-id>
    <config>
      <ospfv3-id>0</ospfv3-id>
    </config>
  <distribute-list>
```

```
<filter-in>
<config>
  <access-control-list>WORD</access-control-list> <!-- operation="delete"-->
</config>
</filter-in>
</distribute-list>
</process>
</processes>
</ospfv3>
```

Command Syntax

```
distribute-list WORD in
```

Configure protocol

Use this attribute to import routes from other routing protocols, or from another OSPF instance, into OSPFv3 ASexternal-LSAs.

This command is supported when following feature are enabled HAVE_ACL

Attribute Name: protocol

Attribute Type: enum (kernel|connected|static|rip|bgp|isis)

Attribute Name: access-control-list

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<processes>
<process>
  <ospfv3-id>WORD</ospfv3-id>
  <config>
    <ospfv3-id>0</ospfv3-id>
  </config>
<distribute-list>
<filter-out>
<routing-protocols>
<routing-protocol>
  <protocol>kernel</protocol>
  <config>
    <protocol>kernel</protocol>
    <access-control-list>WORD</access-control-list> <!-- operation="delete"-->
  </config>
</routing-protocol>
</routing-protocols>
</filter-out>
</distribute-list>
</process>
</processes>
</ospfv3>
```

Command Syntax

```
distribute-list WORD out (kernel|connected|static|rip|bgp|isis)
```

Configure ospf process id

Use this attribute to filter networks in routing updates.

This command is supported when following feature are enabled HAVE_ACL

Attribute Name: ospf-process-id

Attribute Type: string

Attribute Name: access-control-list

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    </process>
  </processes>
  <filter-out>
    <ospf-processes>
      <ospf-process>
        <ospf-process-id>1-65535</ospf-process-id>
        <config>
          <ospf-process-id>WORD</ospf-process-id>
          <access-control-list>WORD</access-control-list> <!-- operation="delete"-->
        </config>
      </ospf-process>
    </ospf-processes>
  </filter-out>
</ospfv3>
```

Command Syntax

```
distribute-list WORD out ospf (WORD|)
```

Configure metric

Use this attribute to inform the value of the metric for OSPFv3 default route.

Attribute Name: metric

Attribute Type: uint32

Default Value: 1

Attribute Range: 0-16777214

Attribute Name: metric-type

Attribute Type: enum (1|2)

Default Value: 2

Attribute Name: route-map

Attribute Type: string

Attribute Name: route-tag

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    </process>
  </processes>
  <redistribute>
    <routing-protocols>
      <routing-protocol>
        <protocol>kernel</protocol>
        <config>
          <protocol>kernel</protocol>
          <metric-type>2</metric-type> <!-- operation="delete"-->
          <route-map>WORD</route-map> <!-- operation="delete"-->
          <route-tag>0</route-tag> <!-- operation="delete"-->
        </config>
      </routing-protocol>
    </routing-protocols>
  </redistribute>
</ospfv3>
```

Command Syntax

```
redistribute (kernel|connected|static|rip|bgp|isis) { metric <0-16777214>| metric-
  type (1|2)| route-map WORD| tag <0-4294967295> }
```

Configure metric type

Use this attribute to inform the value of the metric for OSPFv3 default route.

Attribute Name: metric

Attribute Type: uint32

Default Value: 1

Attribute Range: 0-16777214

Attribute Name: metric-type

Attribute Type: enum (1|2)

Default Value: 2

Attribute Name: route-map

Attribute Type: string

Attribute Name: route-tag

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    </process>
  </processes>
  <ospf-processes>
    <ospf-process>
      <ospf-process-id>WORD</ospf-process-id>
      <config>
        <ospf-process-id>WORD</ospf-process-id>
        <metric-type>2</metric-type> <!-- operation="delete"-->
        <route-map>WORD</route-map> <!-- operation="delete"-->
        <route-tag>0</route-tag> <!-- operation="delete"-->
      </config>
      <metric>0</metric> <!-- operation="delete"-->
    </ospf-process>
  </ospf-processes>
</ospfv3>
```

Command Syntax

```
redistribute ospf (WORD|) { metric <0-16777214>| metric-type (1|2)| route-map WORD|
  tag <0-4294967295> }
```

Configure default cost

Use this attribute to set the cost for default summary route sent into a stub area. If an area is configured as a stub, the OSPFv3 router originates one type-3 inter-area-prefix-LSA into the stub area. This attribute changes the metric for this LSA.

Attribute Name: default-cost

Attribute Type: uint32

Default Value: 1

Attribute Range: 0-16777215

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPFV3_AREA_T</area-id>
      <config>
        <area-id>OSPFV3_AREA_T</area-id>
        <default-cost>0</default-cost> <!-- operation="delete"-->
      </config>
    </area>
  </areas>
</ospfv3>
```

Command Syntax

```
area (A.B.C.D|<0-4294967295>) default-cost <0-16777215>
```

Configure no summary

Use this attribute to do not inject inter-area routes into stub.

Attribute Name: no-summary

Attribute Type: empty

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
```

```

    <config>
      <ospfv3-id>0</ospfv3-id>
    </config>
  </areas>
  <area>
    <area-id>OSPFV3_AREA_T</area-id>
    <config>
      <area-id>OSPFV3_AREA_T</area-id>
    </config>
    <stub>
      <config>
        </enable><!-- operation="delete"-->
        </no-summary><!-- operation="delete"-->
      </config>
    </stub>
  </area>
</areas>
</process>
</processes>
</ospfv3>

```

Command Syntax

```
area stub no-summary
```

Configure enable

Use this attribute to define an area as a stub area on all routers.

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPFV3_AREA_T</area-id>
      <config>
        <area-id>OSPFV3_AREA_T</area-id>
      </config>
      <stub>
        <config>
          </enable>
        </config>
      </stub>
    </area>
  </areas>
</ospfv3>

```

```
</area>
</areas>
</process>
</processes>
</ospfv3>
```

Command Syntax

```
area stub
```

Configure area id

Use this attribute to set an area as a Not-So-Stubby-Area (NSSA).

Attribute Name: enable

Attribute Type: uint8

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPFV3_AREA_T</area-id>
      <config>
        <area-id>OSPFV3_AREA_T</area-id>
      </config>
      <nssa>
        <config>
          </enable><!-- operation="delete"-->
        </config>
      </nssa>
    </area>
  </areas>
</process>
</processes>
</ospfv3>
```

Command Syntax

```
area nssa
```

Configure remote router id

Use this attribute to set the interface IP address of the neighbor.

Attribute Name: remote-router-id

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<processes>
<process>
  <ospfv3-id>WORD</ospfv3-id>
  <config>
    <ospfv3-id>0</ospfv3-id>
  </config>
</process>
</processes>
<areas>
<area>
  <area-id>OSPFV3_AREA_T</area-id>
  <config>
    <area-id>OSPFV3_AREA_T</area-id>
  </config>
  <virtual-links>
  <virtual-link <!-- operation="delete"-->
    <remote-router-id>A.B.C.D</remote-router-id>
    <config>
      <remote-router-id>A.B.C.D</remote-router-id>
    </config>
  </virtual-link>
</virtual-links>
</area>
</areas>
</ospfv3>

```

Command Syntax

```
area virtual-link A.B.C.D
```

Configure bfd fall over

Use this attribute to enable BFD on a virtual-link.

Attribute Name: bfd-fall-over

Attribute Type: empty

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<processes>
<process>
  <ospfv3-id>WORD</ospfv3-id>
  <config>
    <ospfv3-id>0</ospfv3-id>
  </config>
</process>
</processes>
<areas>
<area>
  <area-id>OSPFV3_AREA_T</area-id>
  <config>

```

```
        <area-id>OSPFV3_AREA_T</area-id>
    </config>
    <virtual-links>
    <virtual-link>
        <remote-router-id>A.B.C.D</remote-router-id>
        <config>
            <remote-router-id>A.B.C.D</remote-router-id>
        </config>
        </bfd-fall-over><!-- operation="delete"-->
    </virtual-link>
</virtual-links>
</area>
</areas>
</process>
</processes>
</ospfv3>
```

Command Syntax

```
area virtual-link A.B.C.D fall-over bfd
```

Configure instance id

The OSPFv3 instance.

Attribute Name: instance-id

Attribute Type: uint8

Default Value: 0

Attribute Range: 0-31,64-95

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
  <process>
    <ospfv3-id>WORD</ospfv3-id>
    <config>
      <ospfv3-id>0</ospfv3-id>
    </config>
  </process>
  <areas>
  <area>
    <area-id>OSPFV3_AREA_T</area-id>
    <config>
      <area-id>OSPFV3_AREA_T</area-id>
    </config>
    <virtual-links>
    <virtual-link>
      <remote-router-id>A.B.C.D</remote-router-id>
      <config>
        <remote-router-id>A.B.C.D</remote-router-id>
      </config>
    </virtual-link>
  </virtual-links>
  </area>
</areas>
</processes>
</ospfv3>
```

```

        <instance-id>0</instance-id> <!-- operation="delete"-->
    </virtual-link>
</virtual-links>
</area>
</areas>
</process>
</processes>
</ospfv3>

```

Command Syntax

```
area virtual-link A.B.C.D instance-id (<0-31>|<64-95>)
```

Configure authentication cryptomap

Use this attribute to set the Crypto-map used to setup IPsec SA.

Attribute Name: authentication-cryptomap

Attribute Type: string

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<processes>
<process>
    <ospfv3-id>WORD</ospfv3-id>
    <config>
        <ospfv3-id>0</ospfv3-id>
    </config>
<areas>
<area>
    <area-id>OSPFV3_AREA_T</area-id>
    <config>
        <area-id>OSPFV3_AREA_T</area-id>
    </config>
    <virtual-links>
<virtual-link>
    <remote-router-id>A.B.C.D</remote-router-id>
    <config>
        <remote-router-id>A.B.C.D</remote-router-id>
    </config>
        <authentication-cryptomap>WORD</authentication-cryptomap> <!--
operation="delete"-->
    </virtual-link>
</virtual-links>
</area>
</areas>
</process>
</processes>
</ospfv3>

```

Command Syntax

```
area virtual-link A.B.C.D authentication cryptomap WORD
```

Configure dead interval

Use this command to set the amount of time that the router waits to receive an OSPF hello packet from the neighbor before declaring the neighbor down.

Attribute Name: dead-interval

Attribute Type: uint16

Default Value: 40

Attribute Range: 1-65535

Attribute Name: hello-interval

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-65535

Attribute Name: transmission-delay

Attribute Type: uint16

Default Value: 1

Attribute Range: 1-1800

Attribute Name: retransmission-interval

Attribute Type: uint16

Default Value: 5

Attribute Range: 1-1800

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    </process>
  </processes>
  <areas>
    <area>
      <area-id>OSPFV3_AREA_T</area-id>
      <config>
        <area-id>OSPFV3_AREA_T</area-id>
      </config>
      <virtual-links>
        <virtual-link>
          <remote-router-id>A.B.C.D</remote-router-id>
          <config>
            <remote-router-id>A.B.C.D</remote-router-id>
          </config>
        </virtual-link>
      </virtual-links>
    </area>
  </areas>
</ospfv3>
```



```

    </config>
    <timers>
    <config>
        <hello-interval>1</hello-interval> <!-- operation="delete"-->
        <transmission-delay>1</transmission-delay> <!-- operation="delete"-->
        <retransmission-interval>1</retransmission-interval> <!--
operation="delete"-->
        <dead-interval>1</dead-interval> <!-- operation="delete"-->
    </config>
    </timers>
</virtual-link>
</virtual-links>
</area>
</areas>
</process>
</processes>
</ospfv3>

```

Command Syntax

```

area virtual-link A.B.C.D { dead-interval <1-65535>| hello-interval <1-65535>|
    transmit-delay <1-1800>| retransmit-interval <1-1800> }

```

Configure tag

Use this attribute to configure the Tag value to use as a match value for controlling redistribution via route maps.

Attribute Name: tag

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<processes>
<process>
    <ospfv3-id>WORD</ospfv3-id>
    <config>
        <ospfv3-id>0</ospfv3-id>
    </config>
<address-family>
<ipv4>
<summary-addresses>
<summary-address>
    <address>A.B.C.D/M</address>
    <config>
        <address>A.B.C.D/M</address>
    </config>
    <tag>0</tag> <!-- operation="delete"-->
</summary-address>
</summary-addresses>

```

```
</ipv4>  
</address-family>  
</process>  
</processes>  
</ospfv3>
```

Command Syntax

```
summary-address A.B.C.D/M tag <0-4294967295>
```

Configure always advertise default route

Use this attribute to set route-map instance.

Attribute Name: route-map

Attribute Type: string

Attribute Range: 1-63

Attribute Name: originate

Attribute Type: empty

Attribute Name: always-advertise-default-route

Attribute Type: empty

Attribute Name: metric

Attribute Type: uint32

Default Value: 20

Attribute Range: 0-16777214

Attribute Name: metric-type

Attribute Type: enum (1|2)

Default Value: 2

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">  
<processes>  
<process>  
  <ospfv3-id>WORD</ospfv3-id>  
  <config>  
    <ospfv3-id>0</ospfv3-id>  
  </config>  
</process>  
</processes>  
<address-family>  
<ipv4>  
<default-information>  
<config>  
  </originate><!-- operation="delete"-->  
  </always-advertise-default-route><!-- operation="delete"-->  
  <metric>0</metric> <!-- operation="delete"-->  
  <metric-type>2</metric-type> <!-- operation="delete"-->  
  <route-map>WORD</route-map> <!-- operation="delete"-->  
</config>  
</default-information>  
</ipv4>  
</address-family>  
</ospfv3>
```

```

</config>
</default-information>
</ipv4>
</address-family>
</process>
</processes>
</ospfv3>

```

Command Syntax

```

default-information originate { always| metric <0-16777214>| metric-type (1|2)|
route-map WORD }

```

Configure protocol af

Use this attribute to import routes from other routing protocols, or from another OSPF instance, into OSPFv3 ASexternal-LSAs.

Attribute Name: protocol-af

Attribute Type: enum (kernel|connected|static|rip|bgp|isis)

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<processes>
<process>
  <ospfv3-id>WORD</ospfv3-id>
  <config>
    <ospfv3-id>0</ospfv3-id>
  </config>
<address-family>
<ipv4>
<redistribute>
<routing-protocols>
<routing-protocol> <!-- operation="delete"-->
  <protocol-af>kernel</protocol-af>
  <config>
    <protocol-af>kernel</protocol-af>
  </config>
</routing-protocol>
</routing-protocols>
</redistribute>
</ipv4>
</address-family>
</process>
</processes>
</ospfv3>

```

Command Syntax

```

redistribute (kernel|connected|static|rip|bgp|isis)

```

Configure route tag

Use this attribute to inform the value of the metric for OSPFv3 default route.

Attribute Name: metric

Attribute Type: uint32

Default Value: 1

Attribute Range: 0-16777214

Attribute Name: metric-type

Attribute Type: enum (1|2)

Default Value: 2

Attribute Name: route-map

Attribute Type: string

Attribute Name: route-tag

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    <address-family>
      <ipv4>
        <redistribute>
          <routing-protocols>
            <routing-protocol>
              <protocol-af>kernel</protocol-af>
              <config>
                <protocol-af>kernel</protocol-af>
                <metric-type>2</metric-type> <!-- operation="delete"-->
                <route-map>WORD</route-map> <!-- operation="delete"-->
                <route-tag>0</route-tag> <!-- operation="delete"-->
              </config>
              <metric>0</metric> <!-- operation="delete"-->
            </routing-protocol>
          </routing-protocols>
        </redistribute>
      </ipv4>
    </address-family>
  </process>
</processes>
```

```
</ospfv3>
```

Command Syntax

```
redistribute (kernel|connected|static|rip|bgp|isis) { metric <0-16777214>| metric-
  type (1|2)| route-map WORD| tag <0-4294967295> }
```

Configure ospfv2 process id

Use this attribute to specify OSPF routes.

Attribute Name: ospfv2-process-id

Attribute Type: uint16

Attribute Range: 0-65535

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    <address-family>
      <ipv4>
        <redistribute>
          <ospf-processes>
            <ospf-process> <!-- operation="delete"-->
              <ospfv2-process-id>0</ospfv2-process-id>
              <config>
                <ospfv2-process-id>0</ospfv2-process-id>
              </config>
            </ospf-process>
          </ospf-processes>
        </redistribute>
      </ipv4>
    </address-family>
  </process>
</processes>
</ospfv3>
```

Command Syntax

```
redistribute ospf (<0-65535>|)
```

Configure enabled

Use this attribute to distribute linkstate and TE Database to BGP.

This command is supported when following feature are enabled OSPFv3 BGP-LS for SRv6

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    <bgp-link-state>
    <distribute>
    <config>
      </enabled><!-- operation="delete"-->
    </config>
  </distribute>
</bgp-link-state>
</process>
</processes>
</ospfv3>
```

Command Syntax

```
distribute bgp-ls
```

Configure throttle timer

Use this attribute to set interval between processing LS DB.

This command is supported when following feature are enabled OSPFv3 BGP-LS for SRv6

Attribute Name: throttle-timer

Attribute Type: uint8

Default Value: 5

Attribute Range: 5-20

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <processes>
    <process>
      <ospfv3-id>WORD</ospfv3-id>
      <config>
        <ospfv3-id>0</ospfv3-id>
      </config>
    <bgp-link-state>
    <distribute>
    <config>
      </enabled><!-- operation="delete"-->
    </config>
  </distribute>
</bgp-link-state>
</process>
</processes>
</ospfv3>
```

```

        <throttle-timer>5</throttle-timer> <!-- operation="delete"-->
</config>
</distribute>
</bgp-link-state>
</process>
</processes>
</ospfv3>

```

Command Syntax

```
distribute bgp-ls throttle <5-20>
```

Configure retransmission

OSPFv3 retransmission information

Attribute Name: retransmission

Attribute Type: uint8

Attribute Name: bfd

Attribute Type: empty

Attribute Name: events

Attribute Type: bits (abr|asbr|vlink|os|router|nssa)

Attribute Name: ifsm

Attribute Type: bits (status|events|timers)

Attribute Name: lsa

Attribute Type: bits (generate|flooding|install|refresh|maxage)

Attribute Name: nfm

Attribute Type: bits (status|events|timers)

Attribute Name: nsm

Attribute Type: bits (interface|redistribute)

Attribute Name: route

Attribute Type: bits (spf|ia|ase|install)

Attribute Name: rib

Attribute Type: bits (interface|redistribute)

Attribute Name: dist-ls

Attribute Type: empty

Attribute Name: packet-hello

Attribute Type: bits (send|rcv|detail)

Attribute Name: packet-dd

Attribute Type: bits (send|rcv|detail)

Attribute Name: packet-ls-request

Attribute Type: bits (send|rcv|detail)

Attribute Name: packet-ls-update

Attribute Type: bits (send|recv|detail)

Attribute Name: packet-ls-ack

Attribute Type: bits (send|recv|detail)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<debug>
<config>
  </bfd><!-- operation="delete"-->
  <events>abr</events> <!-- operation="delete"-->
  <ifsm>status</ifsm> <!-- operation="delete"-->
  <lsa>generate</lsa> <!-- operation="delete"-->
  <n fsm>status</n fsm> <!-- operation="delete"-->
  <nsm>interface</nsm> <!-- operation="delete"-->
  <route>spf</route> <!-- operation="delete"-->
  <rib>interface</rib> <!-- operation="delete"-->
  </dist-ls><!-- operation="delete"-->
  <packet-hello>send</packet-hello> <!-- operation="delete"-->
  <packet-dd>send</packet-dd> <!-- operation="delete"-->
  <packet-ls-request>send</packet-ls-request> <!-- operation="delete"-->
  <packet-ls-update>send</packet-ls-update> <!-- operation="delete"-->
  <packet-ls-ack>send</packet-ls-ack> <!-- operation="delete"-->
  </retransmission><!-- operation="delete"-->
</config>
</debug>
</ospfv3>
```

Command Syntax

```
debug ipv6 ospf
```

Configure bfd

OSPFv3 retransmission information

Attribute Name: retransmission

Attribute Type: uint8

Attribute Name: bfd

Attribute Type: empty

Attribute Name: events

Attribute Type: bits (abr|asbr|vlink|os|router|nssa)

Attribute Name: ifsm

Attribute Type: bits (status|events|timers)

Attribute Name: lsa

Attribute Type: bits (generate|flooding|install|refresh|maxage)

Attribute Name: n fsm

Attribute Type: bits (status|events|timers)

Attribute Name: n sm

Attribute Type: bits (interface|redistribute)

Attribute Name: route

Attribute Type: bits (spf|ia|ase|install)

Attribute Name: rib

Attribute Type: bits (interface|redistribute)

Attribute Name: dist-ls

Attribute Type: empty

Attribute Name: packet-hello

Attribute Type: bits (send|rcv|detail)

Attribute Name: packet-dd

Attribute Type: bits (send|rcv|detail)

Attribute Name: packet-ls-request

Attribute Type: bits (send|rcv|detail)

Attribute Name: packet-ls-update

Attribute Type: bits (send|rcv|detail)

Attribute Name: packet-ls-ack

Attribute Type: bits (send|rcv|detail)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <debug>
  <config>
    </bfd><!-- operation="delete"-->
    <events>abr</events> <!-- operation="delete"-->
    <ifsm>status</ifsm> <!-- operation="delete"-->
    <lsa>generate</lsa> <!-- operation="delete"-->
    <n fsm>status</n fsm> <!-- operation="delete"-->
    <n sm>interface</n sm> <!-- operation="delete"-->
    <route>spf</route> <!-- operation="delete"-->
    <rib>interface</rib> <!-- operation="delete"-->
    </dist-ls><!-- operation="delete"-->
    <packet-hello>send</packet-hello> <!-- operation="delete"-->
    <packet-dd>send</packet-dd> <!-- operation="delete"-->
    <packet-ls-request>send</packet-ls-request> <!-- operation="delete"-->
    <packet-ls-update>send</packet-ls-update> <!-- operation="delete"-->
    <packet-ls-ack>send</packet-ls-ack> <!-- operation="delete"-->
    </retransmission><!-- operation="delete"-->
  </config>
</debug>
</ospfv3>
```

Command Syntax

```
debug ipv6 ospf all
```

Configure dist ls

Use this attribute to enable OSPF distribute linkstate details debug.

Attribute Name: dist-ls

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<debug>
<config>
  </dist-ls><!-- operation="delete"-->
</config>
</debug>
</ospfv3>
```

Command Syntax

```
debug ipv6 ospf dist-ls
```

Configure events

OSPFv3 events information

Attribute Name: events

Attribute Type: bits (abr|asbr|vlink|os|router|nssa)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<debug>
<config>
  <events>abr</events> <!-- operation="delete"-->
</config>
</debug>
</ospfv3>
```

Command Syntax

```
debug ipv6 ospf events ({abr|asbr|vlink|os|router|nssa}||)
```

Configure ifsm

Use this attribute to enable OSPFv3 Interface State Machine debug

Attribute Name: ifsm

Attribute Type: bits (status|events|timers)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <debug>
  <config>
    <ifsm>status</ifsm> <!-- operation="delete"-->
  </config>
</debug>
</ospfv3>
```

Command Syntax

```
debug ipv6 ospf ifsm ({status|events|timers}|)
```

Configure lsa

Use this attribute to enable OSPFv3 Link State Advertisement debug

Attribute Name: lsa

Attribute Type: bits (generate|flooding|install|refresh|maxage)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <debug>
  <config>
    <lsa>generate</lsa> <!-- operation="delete"-->
  </config>
</debug>
</ospfv3>
```

Command Syntax

```
debug ipv6 ospf lsa ({generate|flooding|install|refresh|maxage}|)
```

Configure nfsm

Use this attribute to enable OSPFv3 Neighbor State Machine debug

Attribute Name: nfsm

Attribute Type: bits (status|events|timers)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <debug>
  <config>
    <nfsm>status</nfsm> <!-- operation="delete"-->
  </config>
</debug>
</ospfv3>
```

Command Syntax

```
debug ipv6 ospf nfsm ({status|events|timers}|)
```

Configure nsm

Use this attribute to enable OSPFv3 NSM information debug

Attribute Name: nsm

Attribute Type: bits (interface|redistribute)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<debug>
<config>
  <nsm>interface</nsm> <!-- operation="delete"-->
</config>
</debug>
</ospfv3>
```

Command Syntax

```
debug ipv6 ospf nsm ({interface|redistribute}|)
```

Configure rib

Use this attribute to enable OSPFv3 RIB information debug

Attribute Name: rib

Attribute Type: bits (interface|redistribute)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<debug>
<config>
  <rib>interface</rib> <!-- operation="delete"-->
</config>
</debug>
</ospfv3>
```

Command Syntax

```
debug ipv6 ospf rib ({interface|redistribute}|)
```

Configure route

Use this attribute to enable OSPFv3 route information debug

Attribute Name: route

Attribute Type: bits (spf|ia|ase|install)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<debug>
<config>
  <route>spf</route> <!-- operation="delete"-->
</config>
</debug>
</ospfv3>
```

```

</config>
</debug>
</ospfv3>

```

Command Syntax

```
debug ipv6 ospf route ({spf|ia|ase|install|})
```

Configure packet hello

OSPFv3 Hello

Attribute Name: packet-hello

Attribute Type: bits (send|recv|detail)

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<debug>
<config>
  <packet-hello>send</packet-hello> <!-- operation="delete"-->
</config>
</debug>
</ospfv3>

```

Command Syntax

```
debug ipv6 ospf packet hello ({send|recv|detail|})
```

Configure packet dd

OSPFv3 Database Description

Attribute Name: packet-dd

Attribute Type: bits (send|recv|detail)

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<debug>
<config>
  <packet-dd>send</packet-dd> <!-- operation="delete"-->
</config>
</debug>
</ospfv3>

```

Command Syntax

```
debug ipv6 ospf packet dd ({send|recv|detail|})
```

Configure packet ls request

OSPFv3 Link State Request

Attribute Name: packet-ls-request

Attribute Type: bits (send|recv|detail)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<debug>
<config>
  <packet-ls-request>send</packet-ls-request> <!-- operation="delete"-->
</config>
</debug>
</ospfv3>
```

Command Syntax

```
debug ipv6 ospf packet ls-request ({send|recv|detail}|)
```

Configure packet ls update

OSPFv3 Link State Update

Attribute Name: packet-ls-update

Attribute Type: bits (send|recv|detail)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<debug>
<config>
  <packet-ls-update>send</packet-ls-update> <!-- operation="delete"-->
</config>
</debug>
</ospfv3>
```

Command Syntax

```
debug ipv6 ospf packet ls-update ({send|recv|detail}|)
```

Configure packet ls ack

OSPFv3 Link State Acknowledgment

Attribute Name: packet-ls-ack

Attribute Type: bits (send|recv|detail)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<debug>
<config>
  <packet-ls-ack>send</packet-ls-ack> <!-- operation="delete"-->
</config>
</debug>
</ospfv3>
```

Command Syntax

```
debug ipv6 ospf packet ls-ack ({send|recv|detail}|)
```

debug ipv6 ospf

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-ospf-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3"/>
```

Command Syntax

```
debug ipv6 ospf
```

no debug ipv6 ospf

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-ospf-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3"/>
```

Command Syntax

```
no debug ipv6 ospf
```

debug ipv6 ospf all

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-ospf-all-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3"/>
```

Command Syntax

```
debug ipv6 ospf all
```

no debug ipv6 ospf all

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-ospf-all-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3"/>
```

Command Syntax

```
no debug ipv6 ospf all
```

debug ipv6 ospf bfd

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-bfd-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3"/>
```

Command Syntax

```
debug ipv6 ospf bfd
```

no debug ipv6 ospf bfd

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-bfd-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3"/>
```

Command Syntax

```
no debug ipv6 ospf bfd
```

debug ipv6 ospf retransmission

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-retransmission-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3"/>
```

Command Syntax

```
debug ipv6 ospf retransmission
```

no debug ipv6 ospf retransmission

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-retransmission-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3"/>
```

Command Syntax

```
no debug ipv6 ospf retransmission
```

debug ipv6 ospf dist-ls

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-dist-ls-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3"/>
```

Command Syntax

```
debug ipv6 ospf dist-ls
```

no debug ipv6 ospf dist-ls

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-dist-ls-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3"/>
```

Command Syntax

```
no debug ipv6 ospf dist-ls
```

debug ipv6 ospf events ({abr|asbr|vlink|os|router|nssa|})

Attribute Name: events

Attribute Type: bits (abr|asbr|vlink|os|router|nssa)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-events-on xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <events>abr</events>
</ipi-ospfv3-debug_ospfv3-terminal-debug-events-on>
```

Command Syntax

```
debug ipv6 ospf events ({abr|asbr|vlink|os|router|nssa|})
```

no debug ipv6 ospf events ({abr|asbr|vlink|os|router|nssa|})

Attribute Name: events

Attribute Type: bits (abr|asbr|vlink|os|router|nssa)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-events-off xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <events>abr</events>
</ipi-ospfv3-debug_ospfv3-terminal-debug-events-off>
```

Command Syntax

```
no debug ipv6 ospf events ({abr|asbr|vlink|os|router|nssa|})
```

debug ipv6 ospf ifsm ({status|events|timers|})

Attribute Name: ifsm

Attribute Type: bits (status|events|timers)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-ifsm-on xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <ifsm>status</ifsm>
</ipi-ospfv3-debug_ospfv3-terminal-debug-ifsm-on>
```

Command Syntax

```
debug ipv6 ospf ifsm ({status|events|timers|})
```

no debug ipv6 ospf ifsm ({status|events|timers|})

Attribute Name: ifsm

Attribute Type: bits (status|events|timers)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-ifsm-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <ifsm>status</ifsm>
</ipi-ospfv3-debug_ospfv3-terminal-debug-ifsm-off>
```

Command Syntax

```
no debug ipv6 ospf ifsm ({status|events|timers}|)
```

debug ipv6 ospf lsa ({generate|flooding|install|refresh|maxage}|)

Attribute Name: lsa

Attribute Type: bits (generate|flooding|install|refresh|maxage)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-lsa-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <lsa>generate</lsa>
</ipi-ospfv3-debug_ospfv3-terminal-debug-lsa-on>
```

Command Syntax

```
debug ipv6 ospf lsa ({generate|flooding|install|refresh|maxage}|)
```

no debug ipv6 ospf lsa ({generate|flooding|install|refresh|maxage}|)

Attribute Name: lsa

Attribute Type: bits (generate|flooding|install|refresh|maxage)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-lsa-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <lsa>generate</lsa>
</ipi-ospfv3-debug_ospfv3-terminal-debug-lsa-off>
```

Command Syntax

```
no debug ipv6 ospf lsa ({generate|flooding|install|refresh|maxage}|)
```

debug ipv6 ospf nfsm ({status|events|timers}|)

Attribute Name: nfsm

Attribute Type: bits (status|events|timers)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-nfsm-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <nfsm>status</nfsm>
</ipi-ospfv3-debug_ospfv3-terminal-debug-nfsm-on>
```

Command Syntax

```
debug ipv6 ospf nfsm ({status|events|timers}|)
```

no debug ipv6 ospf nfsm ({status|events|timers}|)

Attribute Name: nfsm

Attribute Type: bits (status|events|timers)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-nfsm-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <nfsm>status</nfsm>
</ipi-ospfv3-debug_ospfv3-terminal-debug-nfsm-off>
```

Command Syntax

```
no debug ipv6 ospf nfsm ({status|events|timers}|)
```

debug ipv6 ospf nsm ({interface|redistribute}|)

Attribute Name: nsm

Attribute Type: bits (interface|redistribute)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-nsm-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <nsm>interface</nsm>
</ipi-ospfv3-debug_ospfv3-terminal-debug-nsm-on>
```

Command Syntax

```
debug ipv6 ospf nsm ({interface|redistribute}|)
```

no debug ipv6 ospf nsm ({interface|redistribute}|)

Attribute Name: nsm

Attribute Type: bits (interface|redistribute)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-nsm-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <nsm>interface</nsm>
</ipi-ospfv3-debug_ospfv3-terminal-debug-nsm-off>
```

Command Syntax

```
no debug ipv6 ospf nsm ({interface|redistribute}|)
```

debug ipv6 ospf packet ({send|recv|detail}|)

Attribute Name: all

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-packet-all-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <all>send</all>
</ipi-ospfv3-debug_ospfv3-terminal-debug-packet-all-on>
```

Command Syntax

```
debug ipv6 ospf packet ({send|recv|detail}|)
```

no debug ipv6 ospf packet ({send|recv|detail}|)

Attribute Name: all

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-packet-all-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <all>send</all>
</ipi-ospfv3-debug_ospfv3-terminal-debug-packet-all-off>
```

Command Syntax

```
no debug ipv6 ospf packet ({send|recv|detail}|)
```

debug ipv6 ospf packet hello ({send|recv|detail}|)

Attribute Name: hello

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-packet-hello-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <hello>send</hello>
</ipi-ospfv3-debug_ospfv3-terminal-debug-packet-hello-on>
```

Command Syntax

```
debug ipv6 ospf packet hello ({send|recv|detail}|)
```

no debug ipv6 ospf packet hello ({send|recv|detail}|)

Attribute Name: hello

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-packet-hello-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <hello>send</hello>
</ipi-ospfv3-debug_ospfv3-terminal-debug-packet-hello-off>
```

Command Syntax

```
no debug ipv6 ospf packet hello ({send|recv|detail}|)
```

debug ipv6 ospf packet dd ({send|recv|detail}|)

Attribute Name: dd

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-packet-dd-on xmlns="http://  
www.ipinfusion.com/yang/ocnos/ipi-ospfv3">  
  <dd>send</dd>  
</ipi-ospfv3-debug_ospfv3-terminal-debug-packet-dd-on>
```

Command Syntax

```
debug ipv6 ospf packet dd ({send|recv|detail}|)
```

no debug ipv6 ospf packet dd ({send|recv|detail}|)

Attribute Name: dd

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-packet-dd-off xmlns="http://  
www.ipinfusion.com/yang/ocnos/ipi-ospfv3">  
  <dd>send</dd>  
</ipi-ospfv3-debug_ospfv3-terminal-debug-packet-dd-off>
```

Command Syntax

```
no debug ipv6 ospf packet dd ({send|recv|detail}|)
```

debug ipv6 ospf packet ls-request ({send|recv|detail}|)

Attribute Name: ls-request

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-packet-ls-request-on xmlns="http://  
www.ipinfusion.com/yang/ocnos/ipi-ospfv3">  
  <ls-request>send</ls-request>  
</ipi-ospfv3-debug_ospfv3-terminal-debug-packet-ls-request-on>
```

Command Syntax

```
debug ipv6 ospf packet ls-request ({send|recv|detail}|)
```

no debug ipv6 ospf packet ls-request ({send|recv|detail}|)

Attribute Name: ls-request

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-packet-ls-request-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <ls-request>send</ls-request>
</ipi-ospfv3-debug_ospfv3-terminal-debug-packet-ls-request-off>
```

Command Syntax

```
no debug ipv6 ospf packet ls-request ({send|recv|detail}|)
```

debug ipv6 ospf packet ls-update ({send|recv|detail}|)

Attribute Name: ls-update

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-packet-ls-update-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <ls-update>send</ls-update>
</ipi-ospfv3-debug_ospfv3-terminal-debug-packet-ls-update-on>
```

Command Syntax

```
debug ipv6 ospf packet ls-update ({send|recv|detail}|)
```

no debug ipv6 ospf packet ls-update ({send|recv|detail}|)

Attribute Name: ls-update

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-packet-ls-update-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <ls-update>send</ls-update>
</ipi-ospfv3-debug_ospfv3-terminal-debug-packet-ls-update-off>
```

Command Syntax

```
no debug ipv6 ospf packet ls-update ({send|recv|detail}|)
```

debug ipv6 ospf packet ls-ack ({send|recv|detail}|)

Attribute Name: ls-ack

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-packet-ls-ack-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <ls-ack>send</ls-ack>
</ipi-ospfv3-debug_ospfv3-terminal-debug-packet-ls-ack-on>
```

Command Syntax

```
debug ipv6 ospf packet ls-ack ({send|recv|detail}|)
```

no debug ipv6 ospf packet ls-ack ({send|recv|detail}|)

Attribute Name: ls-ack

Attribute Type: bits (send|recv|detail)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-packet-ls-ack-off xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <ls-ack>send</ls-ack>
</ipi-ospfv3-debug_ospfv3-terminal-debug-packet-ls-ack-off>
```

Command Syntax

```
no debug ipv6 ospf packet ls-ack ({send|recv|detail}|)
```

debug ipv6 ospf rib ({interface|redistribute}|)

Attribute Name: rib

Attribute Type: bits (interface|redistribute)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-rib-on xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-ospfv3">
  <rib>interface</rib>
</ipi-ospfv3-debug_ospfv3-terminal-debug-rib-on>
```

Command Syntax

```
debug ipv6 ospf rib ({interface|redistribute}|)
```

no debug ipv6 ospf rib ({interface|redistribute}|)

Attribute Name: rib

Attribute Type: bits (interface|redistribute)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-rib-off xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <rib>interface</rib>
</ipi-ospfv3-debug_ospfv3-terminal-debug-rib-off>
```

Command Syntax

```
no debug ipv6 ospf rib ({interface|redistribute}|)
```

debug ipv6 ospf route ({spf|ia|ase|install}|)

Attribute Name: route

Attribute Type: bits (spf|ia|ase|install)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-route-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <route>spf</route>
</ipi-ospfv3-debug_ospfv3-terminal-debug-route-on>
```

Command Syntax

```
debug ipv6 ospf route ({spf|ia|ase|install|})
```

no debug ipv6 ospf route ({spf|ia|ase|install|})

Attribute Name: route

Attribute Type: bits (spf|ia|ase|install)

Netconf RPC payload

```
<ipi-ospfv3-debug_ospfv3-terminal-debug-route-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <route>spf</route>
</ipi-ospfv3-debug_ospfv3-terminal-debug-route-off>
```

Command Syntax

```
no debug ipv6 ospf route ({spf|ia|ase|install|})
```

clear ipv6 ospf (WORD|) process

Attribute Name: process-id

Attribute Type: string

Netconf RPC payload

```
<ipi-ospfv3-global_ospfv3-clear-process xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <process-id>WORD</process-id>
</ipi-ospfv3-global_ospfv3-clear-process>
```

Command Syntax

```
clear ipv6 ospf (WORD|) process
```

restart ipv6 ospf graceful (grace-period <2-1800>|)

Attribute Name: grace-period

Attribute Type: uint16

Attribute Range: 2-1800

Netconf RPC payload

```
<ipi-ospfv3-global_ospfv3-graceful-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
```



```
<grace-period>2</grace-period>
</ipi-ospfv3-global_ospfv3-graceful-restart>
```

Command Syntax

```
restart ipv6 ospf graceful (grace-period <2-1800>|)
```

snmp restart ospf6

Netconf RPC payload

```
<ipi-ospfv3-global_ospfv3-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3"/>
```

Command Syntax

```
snmp restart ospf6
```

IPI-OSPFV3-INTERFACE

Configure shutdown

Use this attribute to shutdown OSPFV3 on the interface

Attribute Name: shutdown

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <interfaces>
    <interface>
      <interface-name>WORD</interface-name>
      <config>
        <interface-name>WORD</interface-name>
      </config>
      </shutdown><!-- operation="delete"-->
    </interface>
  </interfaces>
</ospfv3>
```

Command Syntax

```
ospfv3 shutdown
```

Configure enable link lsa suppression

Use this attribute to enable or disable link LSA (type 8) suppression. A type 8 LSA gives information about link-local addresses and a list of IPv6 addresses on the link. If enabled and the interface type is not broadcast or NBMA, the router does not send type 8 link LSAs. This implies that other routers on the link determine the router's next-hop address using a mechanism other than the type 8 link LSA. This feature is implicitly disabled if the interface type is broadcast or NBMA.

Attribute Name: enable-link-lsa-suppression

Attribute Type: uint8

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<interfaces>
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  <instances>
  <instance>
    <instance-id>0</instance-id>
    <config>
      <instance-id>0</instance-id>
    </config>
    </enable-link-lsa-suppression><!-- operation="delete"-->
  </instance>
</instances>
</interface>
</interfaces>
</ospfv3>
```

Command Syntax

```
ipv6 ospf link-lsa-suppression enable (instance-id (<0-31>|<64-95>)|)
```

Configure enable bfd

Use this attribute to enable Bidirectional Forwarding Detection (BFD)

Attribute Name: enable-bfd

Attribute Type: boolean

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<interfaces>
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  <instances>
  <instance>
    <instance-id>0</instance-id>
    <config>
      <instance-id>0</instance-id>
    </config>
    <enable-bfd>true</enable-bfd> <!-- operation="delete"-->
  </instance>
```

```

</instances>
</interface>
</interfaces>
</ospfv3>

```

Command Syntax

```
ipv6 ospf bfd (instance-id (<0-31>|<64-95>))
```

Configure interface name

Use this attribute to enable Bidirectional Forwarding Detection (BFD)

Attribute Name: enable-bfd

Attribute Type: boolean

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<interfaces>
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
<instances>
<instance>
  <instance-id>0</instance-id>
  <config>
    <instance-id>0</instance-id>
  </config>
  <enable-bfd>true</enable-bfd> <!-- operation="delete"-->
</instance>
</instances>
</interface>
</interfaces>
</ospfv3>

```

Command Syntax

```
ipv6 ospf bfd disable (instance-id (<0-31>|<64-95>))
```

Configure instance id

Use this attribute to enable or disable link LSA (type 8) suppression. A type 8 LSA gives information about link-local addresses and a list of IPv6 addresses on the link. If enabled and the interface type is not broadcast or NBMA, the router does not send type 8 link LSAs. This implies that other routers on the link determine the router's next-hop address using a mechanism other than the type 8 link LSA. This feature is implicitly disabled if the interface type is broadcast or NBMA.

Attribute Name: enable-link-lsa-suppression

Attribute Type: uint8

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<interfaces>
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
<instances>
<instance>
  <instance-id>0</instance-id>
  <config>
    <instance-id>0</instance-id>
  </config>
  </enable-link-lsa-suppression><!-- operation="delete"-->
</instance>
</instances>
</interface>
</interfaces>
</ospfv3>
```

Command Syntax

```
ipv6 ospf link-lsa-suppression enable (instance-id (<0-31>|<64-95>)|)
```

Configure network type

Use this attribute to set an OSPFv3 network type.

Attribute Name: network-type

Attribute Type: enum (point-to-point|broadcast|non-broadcast|point-to-multipoint|point-to-multipoint non-broadcast)

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<interfaces>
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
<instances>
<instance>
  <instance-id>0</instance-id>
  <config>
    <instance-id>0</instance-id>
    <network-type>point-to-point</network-type> <!-- operation="delete"-->
  </instance>
</instances>
</interface>
</interfaces>
```

```
</ospfv3>
```

Command Syntax

```
ipv6 ospf network (point-to-point|broadcast|non-broadcast|point-to-
multipoint|point-to-multipoint non-broadcast) (instance-id (<0-31>|<64-95>))
```

Configure cost

Use this attribute to specify the link-cost described in LSAs. The cost (or metric) of an interface in OSPF indicates the overhead required to send packets across a certain interface. The value is taken to describe Link State information, and used for route calculation.

Attribute Name: cost

Attribute Type: uint16

Default Value: 1

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<interfaces>
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  <instances>
  <instance>
    <instance-id>0</instance-id>
    <config>
      <instance-id>0</instance-id>
    </config>
    <cost>1</cost> <!-- operation="delete"-->
  </instance>
</instances>
</interface>
</interfaces>
</ospfv3>
```

Command Syntax

```
ipv6 ospf cost <1-65535> (instance-id (<0-31>|<64-95>))
```

Configure priority

Use this attribute to set the router priority for determining the designated router (DR) for the network. A router with the higher router priority becomes the DR. If the priority is the same for two routers, the router with the higher router ID takes precedence. Only routers with a nonzero priority value are eligible to become the designated or backup designated router. Configure router priority for broadcast or NBMA networks only and not for point-to-point networks.

Attribute Name: priority

Attribute Type: uint8

Default Value: 1

Attribute Range: 0-255

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<interfaces>
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  <instances>
  <instance>
    <instance-id>0</instance-id>
    <config>
      <instance-id>0</instance-id>
    </config>
    <priority>0</priority> <!-- operation="delete"-->
  </instance>
</instances>
</interface>
</interfaces>
</ospfv3>
```

Command Syntax

```
ipv6 ospf priority <0-255> (instance-id (<0-31>|<64-95>)|)
```

Configure traffic engineering metric

Use this attribute to set the traffic engineering metric for an interface. The traffic engineering metric is used in OSPF-TE Link State Advertisements. If the traffic engineering metric is not set, the ipv6 ospf cost value for an interface is used in OSPF-TE Link State Advertisements.

Attribute Name: traffic-engineering-metric

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<interfaces>
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  <instances>
  <instance>
    <instance-id>0</instance-id>
    <config>
```

```

        <instance-id>0</instance-id>
    </config>
    <traffic-engineering-metric>1</traffic-engineering-metric> <!--
operation="delete"-->
</instance>
</instances>
</interface>
</interfaces>
</ospfv3>

```

Command Syntax

```
ipv6 te-metric <1-65535> (instance-id (<0-31>|<64-95>)) |)
```

Configure mtu

Use this attribute to set MTU size for OSPFv3 to construct packets based on this value. Whenever OSPFv3 constructs packets, it uses interface MTU size as Maximum IP packet size. this attribute forces OSPFv3 to use the specified value overriding the actual interface MTU size.

Attribute Name: mtu

Attribute Type: uint16

Default Value: 1500

Attribute Range: 1280-65535

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<interfaces>
<interface>
    <interface-name>WORD</interface-name>
    <config>
        <interface-name>WORD</interface-name>
    </config>
    <instances>
    <instance>
        <instance-id>0</instance-id>
        <config>
            <instance-id>0</instance-id>
            <mtu>1280</mtu> <!-- operation="delete"-->
        </config>
    </instance>
    </instances>
</interface>
</interfaces>
</ospfv3>

```

Command Syntax

```
ipv6 ospf mtu <1280-65535> (instance-id (<0-31>|<64-95>)) |)
```

Configure mtu ignore

Use this attribute to ignore the MTU size during DD (Database Description) exchange. By default, during the DD exchange process, OSPFv3 checks the MTU size described in DD packets received from its neighbor, and if the MTU size does not match the interface MTU, the neighbor adjacency is not established. Using this command makes OSPFv3 ignore this check and allows establishing of adjacency regardless of MTU size in the DD packet.

Attribute Name: mtu-ignore

Attribute Type: empty

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <interfaces>
    <interface>
      <interface-name>WORD</interface-name>
      <config>
        <interface-name>WORD</interface-name>
      </config>
      <instances>
        <instance>
          <instance-id>0</instance-id>
          <config>
            <instance-id>0</instance-id>
            </config>
            </mtu-ignore><!-- operation="delete"-->
          </instance>
        </instances>
      </interface>
    </interfaces>
  </ospfv3>
```

Command Syntax

```
ipv6 ospf mtu-ignore (instance-id (<0-31>|<64-95>))|)
```

Configure authentication cryptomap

Use this attribute to set the Crypto-map used to setup IPsec SA.

Attribute Name: authentication-cryptomap

Attribute Type: string

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <interfaces>
    <interface>
      <interface-name>WORD</interface-name>
      <config>
        <interface-name>WORD</interface-name>
      </config>
    </instances>
```



```

    <instance>
      <instance-id>0</instance-id>
      <config>
        <instance-id>0</instance-id>
      </config>
      <authentication-cryptomap>WORD</authentication-cryptomap> <!--
operation="delete"-->
    </instance>
  </instances>
</interface>
</interfaces>
</ospfv3>

```

Command Syntax

```
ipv6 ospf (instance-id (<0-31>|<64-95>)) authentication cryptomap WORD
```

Configure area id

Use this attribute to enable OSPFv3 routing on an interface. Specify the process ID to configure multiple instances of OSPFv3. When running a single instance of OSPFv3, you do not need to specify a instance ID. When OSPFv3 receives a packet, it checks if the instance ID in the packet matches the instance ID of the receiving interface.

Attribute Name: area-id

Attribute Type: union

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <interfaces>
    <interface>
      <interface-name>WORD</interface-name>
      <config>
        <interface-name>WORD</interface-name>
      </config>
      <instances>
        <instance>
          <instance-id>0</instance-id>
          <config>
            <instance-id>0</instance-id>
          </config>
          <routers>
            <router> <!-- operation="delete"-->
              <area-id>OSPFV3_AREA_T</area-id>
              <config>
                <area-id>OSPFV3_AREA_T</area-id>
                <ospfv3-id>WORD</ospfv3-id>
              </config>
                <ospfv3-id>WORD</ospfv3-id>
            </router>
          </routers>
        </instance>

```

```
</instances>  
</interface>  
</interfaces>  
</ospfv3>
```

Command Syntax

```
ipv6 router ospf area (A.B.C.D|<0-4294967295>) (instance-id (<0-31>|<64-95>)|)
```

Configure ospfv3 id

Use this attribute to enable OSPFv3 routing on an interface. Specify the process ID to configure multiple instances of OSPFv3. When running a single instance of OSPFv3, you do not need to specify an instance ID. When OSPFv3 receives a packet, it checks if the instance ID in the packet matches the instance ID of the receiving interface.

Attribute Name: area-id

Attribute Type: uint32

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">  
<interfaces>  
<interface>  
  <interface-name>WORD</interface-name>  
  <config>  
    <interface-name>WORD</interface-name>  
  </config>  
<instances>  
<instance>  
  <instance-id>0</instance-id>  
  <config>  
    <instance-id>0</instance-id>  
  </config>  
<routers>  
<router> <!-- operation="delete"-->  
  <area-id>OSPFV3_AREA_T</area-id>  
  <config>  
    <area-id>OSPFV3_AREA_T</area-id>  
    <ospfv3-id>WORD</ospfv3-id>  
  </config>  
  <ospfv3-id>WORD</ospfv3-id>  
</router>  
</routers>  
</instance>  
</instances>  
</interface>  
</interfaces>  
</ospfv3>
```

Command Syntax

```
ipv6 router ospf area (instance-id (<0-31>|<64-95>)|)
```

Configure dead interval

Use this attribute to set the amount of time that the router waits to receive an OSPF hello packet from the neighbor before declaring the neighbor down

Attribute Name: dead-interval

Attribute Type: uint16

Default Value: 40

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <interfaces>
    <interface>
      <interface-name>WORD</interface-name>
      <config>
        <interface-name>WORD</interface-name>
      </config>
      <instances>
        <instance>
          <instance-id>0</instance-id>
          <config>
            <instance-id>0</instance-id>
            </config>
            <timers>
              <config>
                <dead-interval>1</dead-interval> <!-- operation="delete"-->
              </config>
            </timers>
          </instance>
        </instances>
      </interface>
    </interfaces>
  </ospfv3>
```

Command Syntax

```
ipv6 ospf dead-interval <1-65535> (instance-id (<0-31>|<64-95>)|)
```

Configure hello interval

Use this attribute to set the interval between hello packets.

Attribute Name: hello-interval

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <interfaces>
```

```
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  <instances>
  <instance>
    <instance-id>0</instance-id>
    <config>
      <instance-id>0</instance-id>
    </config>
    <timers>
    <config>
      <hello-interval>1</hello-interval> <!-- operation="delete"-->
    </config>
    </timers>
  </instance>
</instances>
</interface>
</interfaces>
</ospfv3>
```

Command Syntax

```
ipv6 ospf hello-interval <1-65535> (instance-id (<0-31>|<64-95>)|)
```

Configure transmission delay

Use this attribute to set the estimated time it takes to transmit a Link State Update packet over the interface.

Attribute Name: transmission-delay

Attribute Type: uint16

Default Value: 1

Attribute Range: 1-1800

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <interfaces>
  <interface>
    <interface-name>WORD</interface-name>
    <config>
      <interface-name>WORD</interface-name>
    </config>
    <instances>
    <instance>
      <instance-id>0</instance-id>
      <config>
        <instance-id>0</instance-id>
      </config>
      <timers>
```

```

    <config>
      <transmission-delay>1</transmission-delay> <!-- operation="delete"-->
    </config>
  </timers>
</instance>
</instances>
</interface>
</interfaces>
</ospfv3>

```

Command Syntax

```
ipv6 ospf transmit-delay <1-1800> (instance-id (<0-31>|<64-95>)|)
```

Configure retransmission interval

Use this attribute to set the interval between retransmission of Link State Update packets.

Attribute Name: retransmission-interval

Attribute Type: uint16

Default Value: 5

Attribute Range: 1-1800

Netconf edit-config payload

```

<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <interfaces>
    <interface>
      <interface-name>WORD</interface-name>
      <config>
        <interface-name>WORD</interface-name>
      </config>
      <instances>
        <instance>
          <instance-id>0</instance-id>
          <config>
            <instance-id>0</instance-id>
          </config>
          <timers>
            <config>
              <retransmission-interval>1</retransmission-interval> <!--
operation="delete"-->
            </config>
          </timers>
        </instance>
      </instances>
    </interface>
  </interfaces>
</ospfv3>

```

Command Syntax

```
ipv6 ospf retransmit-interval <1-1800> (instance-id (<0-31>|<64-95>)|)
```

Configure address

Static neighbor IPv6 link-local address

Attribute Name: address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
  <interfaces>
    <interface>
      <interface-name>WORD</interface-name>
      <config>
        <interface-name>WORD</interface-name>
      </config>
      <instances>
        <instance>
          <instance-id>0</instance-id>
          <config>
            <instance-id>0</instance-id>
            </config>
            <neighbors-static>
              <neighbor-static> <!-- operation="delete"-->
                <address>X:X::X:X</address>
                <config>
                  <address>X:X::X:X</address>
                </config>
              </neighbor-static>
            </neighbors-static>
          </instance>
        </instances>
      </interface>
    </interfaces>
  </ospfv3>
```

Command Syntax

```
ipv6 ospf neighbor X:X::X:X (instance-id (<0-31>|<64-95>)|)
```

Configure poll interval

Use this attribute to set the dead neighbor polling interval in seconds. It is recommended to set this value much higher than the hello interval. The default is 120 seconds.

Attribute Name: poll-interval

Attribute Type: uint32

Default Value: 120

Attribute Range: 0-4294967295

Attribute Name: cost

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-65535

Attribute Name: priority

Attribute Type: uint8

Default Value: 0

Attribute Range: 0-255

Netconf edit-config payload

```
<ospfv3 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ospfv3">
<interfaces>
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  <instances>
  <instance>
    <instance-id>0</instance-id>
    <config>
      <instance-id>0</instance-id>
    </config>
    <neighbors-static>
    <neighbor-static>
      <address>X:X::X:X</address>
      <config>
        <address>X:X::X:X</address>
        <cost>1</cost> <!-- operation="delete"-->
        <priority>0</priority> <!-- operation="delete"-->
      </config>
      <poll-interval>0</poll-interval> <!-- operation="delete"-->
    </neighbor-static>
  </neighbors-static>
</instance>
</instances>
</interface>
</interfaces>
</ospfv3>
```

Command Syntax

```
ipv6 ospf neighbor X:X::X:X { cost <1-65535>| priority <0-255>| poll-interval <0-4294967295> } (instance-id (<0-31>|<64-95>)|)
```

IPI-BGP

Configure address family name

Use this attribute to specify address family name

Attribute Name: address-family-name

Attribute Type: enum (all-afs|vpn4|vpn6)

Attribute Name: label-alloc-type

Attribute Type: enum (per-prefix|per-vrf)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <global>
    <mpls-l3vpn-label-modes>
      <mpls-l3vpn-label-mode> <!-- operation="delete"-->
        <vrf-name>0</vrf-name>
        <config>
          <vrf-name>0</vrf-name>
          <address-family-name>all-afs</address-family-name>
          <label-alloc-type>per-prefix</label-alloc-type>
        </config>
        <address-family-name>all-afs</address-family-name>
      </mpls-l3vpn-label-mode>
    </mpls-l3vpn-label-modes>
  </global>
</bgp>
```

Command Syntax

```
mpls label mode (all-afs|vpn4|vpn6) all-vrfs (per-prefix|per-vrf)
```

Configure vrf name

Use this attribute to specify address family name

Attribute Name: address-family-name

Attribute Type: enum (all-afs|vpn4|vpn6)

Attribute Name: label-alloc-type

Attribute Type: enum (per-prefix|per-vrf)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <global>
    <mpls-l3vpn-label-modes>
      <mpls-l3vpn-label-mode> <!-- operation="delete"-->
        <vrf-name>BGP_VRF_TYPE_T</vrf-name>
      </mpls-l3vpn-label-mode>
    </mpls-l3vpn-label-modes>
  </global>
</bgp>
```



```

<config>
  <vrf-name>0</vrf-name>
  <address-family-name>all-afs</address-family-name>
  <label-alloc-type>per-prefix</label-alloc-type>
</config>
<address-family-name>all-afs</address-family-name>
</mpls-l3vpn-label-mode>
</mpls-l3vpn-label-modes>
</global>
</bgp>

```

Command Syntax

```
mpls label mode (all-afs|vpn4|vpn6) vrf WORD (per-prefix|per-vrf)
```

Configure action name

Use this attribute to specify a standard community list (1 to 99) that specifies BGP community attributes.

Attribute Name: action-name

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<global>
<community-lists>
<numbered-lists>
<numbered-list>
  <standard-number>1</standard-number>
  <config>
    <standard-number>1</standard-number>
  </config>
<action-for-any>
<config>
  <action-name>deny</action-name>
</config>
</action-for-any>
</numbered-list>
</numbered-lists>
</community-lists>
</global>
</bgp>

```

Command Syntax

```
ip community-list <1-99> (deny|permit)
```

Configure action standard number

Use this attribute to specify a standard community list (1 to 99) that specifies BGP community attributes.

Attribute Name: action-standard-number

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<global>
<community-lists>
<numbered-lists>
<numbered-list>
  <standard-number>1</standard-number>
  <config>
    <standard-number>1</standard-number>
  </config>
<action-list-values>
<action-list-value> <!-- operation="delete"-->
  <standard-number-value>AA:NN</standard-number-value>
  <config>
    <standard-number-value>WORD</standard-number-value>
    <action-standard-number>deny</action-standard-number>
  </config>
  <action-standard-number>deny</action-standard-number>
</action-list-value>
</action-list-values>
</numbered-list>
</numbered-lists>
</community-lists>
</global>
</bgp>
```

Command Syntax

```
ip community-list <1-99> (deny|permit) ((AA:NN|internet|local-AS|no-advertise|no-export))
```

Configure action name standard

Use the community-lists to specify BGP community attributes. The community attribute is used for implementing policy routing. It is an optional, transitive attribute and facilitates transfer of local policies through different autonomous systems. It includes community values that are 32 bits long. There are two kinds of community-lists: expanded and standard. The standard community-list defines the community attributes in a specified format without regular expressions. The expanded community-list defines the community attributes with regular expressions. Use this attribute to add a standard community-list entry. The standard community-list is compiled into binary format and is directly compared with the BGP communities attribute in the BGP updates. The comparison is faster than the expanded community-list. Any community value that does not match the standard community value is automatically treated as expanded.

Attribute Name: action-name-standard

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<global>
<community-lists>
```

```

<standards>
<standard>
  <name>WORD</name>
  <config>
    <name>WORD</name>
    <list-type>standard</list-type>
  </config>
  <list-type>standard</list-type>
</action-values>
<action-value> <!-- operation="delete"-->
  <community-value-standard>AA:NN</community-value-standard>
  <config>
    <community-value-standard>WORD</community-value-standard>
    <action-name-standard>deny</action-name-standard>
  </config>
  <action-name-standard>deny</action-name-standard>
</action-value>
</action-values>
</standard>
</standards>
</community-lists>
</global>
</bgp>

```

Command Syntax

```
ip community-list WORD (deny|permit) ((AA:NN|internet|local-AS|no-advertise|no-export))
```

Configure list type

Use this attribute to specify a standard community list (1 to 99) that specifies BGP community attributes.

Attribute Name: action-name

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<global>
<community-lists>
<standards>
<standard>
  <name>WORD</name>
  <config>
    <name>WORD</name>
    <list-type>standard</list-type>
  </config>
  <list-type>standard</list-type>
</action-for-any>
<config>
  <action-name>deny</action-name>

```

```
</config>  
</action-for-any>  
</standard>  
</standards>  
</community-lists>  
</global>  
</bgp>
```

Command Syntax

```
ip community-list (standard) WORD (deny|permit)
```

Configure name

Use the community-lists to specify BGP community attributes. The community attribute is used for implementing policy routing. It is an optional, transitive attribute and facilitates transfer of local policies through different autonomous systems. It includes community values that are 32 bits long. There are two kinds of community-lists: expanded and standard. The standard community-list defines the community attributes in a specified format without regular expressions. The expanded community-list defines the community attributes with regular expressions. Use this attribute to add a standard community-list entry. The standard community-list is compiled into binary format and is directly compared with the BGP communities attribute in the BGP updates. The comparison is faster than the expanded community-list. Any community value that does not match the standard community value is automatically treated as expanded.

Attribute Name: action-name-standard

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">  
<global>  
<community-lists>  
<standards>  
<standard>  
  <name>WORD</name>  
  <config>  
    <name>WORD</name>  
    <list-type>standard</list-type>  
  </config>  
  <list-type>standard</list-type>  
<action-values>  
<action-value> <!-- operation="delete"-->  
  <community-value-standard>AA:NN</community-value-standard>  
  <config>  
    <community-value-standard>WORD</community-value-standard>  
    <action-name-standard>deny</action-name-standard>  
  </config>  
  <action-name-standard>deny</action-name-standard>  
</action-value>  
</action-values>  
</standard>  
</standards>  
</community-lists>
```

```
</global>
</bgp>
```

Command Syntax

```
ip community-list (standard) WORD (deny|permit) ((AA:NN|internet|local-AS|no-
advertise|no-export))
```

Configure action expanded

Community list extended type

Attribute Name: action-expanded

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<global>
<community-lists>
<expanded-lists>
<expanded-list>
  <expanded-type>BGP_EXPANDED_LIST_TYPE_T</expanded-type>
  <config>
    <expanded-type>BGP_EXPANDED_LIST_TYPE_T</expanded-type>
    <list-type>expanded</list-type>
  </config>
  <list-type>expanded</list-type>
</expanded-list>
</expanded-lists>
</community-lists>
</global>
</bgp>
```

Command Syntax

```
ip community-list <100-500> (deny|permit) LINE
```

Configure expanded type

Community list extended type

Attribute Name: action-expanded

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <global>
    <community-lists>
      <expanded-lists>
        <expanded-list>
          <expanded-type>BGP_EXPANDED_LIST_TYPE_T</expanded-type>
          <config>
            <expanded-type>BGP_EXPANDED_LIST_TYPE_T</expanded-type>
            <list-type>expanded</list-type>
          </config>
          <list-type>expanded</list-type>
        </expanded-list>
      </expanded-lists>
      <action-values>
        <action-value> <!-- operation="delete"-->
          <regular-expression-list>LINE</regular-expression-list>
          <config>
            <regular-expression-list>LINE</regular-expression-list>
            <action-expanded>deny</action-expanded>
          </config>
          <action-expanded>deny</action-expanded>
        </action-value>
      </action-values>
    </community-lists>
  </global>
</bgp>
```

Command Syntax

```
ip community-list (expanded) WORD (deny|permit) LINE
```

Configure extended action number

Extended Community list type

Attribute Name: extended-action-number

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <global>
    <community-lists>
      <extended-community>
        <numbered-lists>
          <numbered-list>
            <standard-number>1</standard-number>
          </numbered-list>
        </numbered-lists>
      </extended-community>
    </community-lists>
  </global>
</bgp>
```

```

    </config>
<action-values>
<action-value> <!-- operation="delete"-->
    <extended-value>LINE</extended-value>
    <config>
        <extended-value>LINE</extended-value>
        <extended-action-number>deny</extended-action-number>
    </config>
    <extended-action-number>deny</extended-action-number>
</action-value>
</action-values>
</numbered-list>
</numbered-lists>
</extended-community>
</community-lists>
</global>
</bgp>

```

Command Syntax

```
ip extcommunity-list <1-99> (deny|permit) LINE
```

Configure extended action

extcommunity Community list type

Attribute Name: extended-action

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<global>
<community-lists>
<extended-community>
<standards>
<standard>
    <name>WORD</name>
    <config>
        <name>WORD</name>
    </config>
<action-values>
<action-value> <!-- operation="delete"-->
    <value>AA:NN</value>
    <config>
        <value>WORD</value>
        <route-target-soo>rt</route-target-soo>
        <extended-action>deny</extended-action>
    </config>
        <route-target-soo>rt</route-target-soo>
        <extended-action>deny</extended-action>
</action-value>

```

```
</action-values>
</standard>
</standards>
</extended-community>
</community-lists>
</global>
</bgp>
```

Command Syntax

```
ip extcommunity-list standard WORD (deny|permit) (rt|soo) AA:NN
```

Configure action

extcommunity Extended Community type

Attribute Name: action

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<global>
<community-lists>
<extended-community>
<expanded-lists>
<expanded-list>
  <expanded-type>BGP_EXPANDED_LIST_TYPE_T</expanded-type>
  <config>
    <expanded-type>BGP_EXPANDED_LIST_TYPE_T</expanded-type>
    <list-type>expanded</list-type>
  </config>
  <list-type>expanded</list-type>
</expanded-list>
</expanded-lists>
</extended-community>
</community-lists>
</global>
</bgp>
```

Command Syntax

```
ip extcommunity-list <100-500> (deny|permit) LINE
```

Configure value

extcommunity Extended Community type

Attribute Name: action

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <global>
    <community-lists>
      <extended-community>
        <expanded-lists>
          <expanded-list>
            <expanded-type>BGP_EXPANDED_LIST_TYPE_T</expanded-type>
            <config>
              <expanded-type>BGP_EXPANDED_LIST_TYPE_T</expanded-type>
              <list-type>expanded</list-type>
            </config>
            <list-type>expanded</list-type>
          </expanded-list>
        </expanded-lists>
      </extended-community>
    </community-lists>
  </global>
</bgp>
```

Command Syntax

```
ip extcommunity-list (expanded) WORD (deny|permit) LINE
```

Configure access list name

Use this attribute to define a BGP Autonomous System (AS) path access list. A named community list is a filter based on regular expressions. If the regular expression matches the specified string representing the AS path of the route, then the permit or deny condition applies. Use this attribute to define the BGP access list globally.

Attribute Name: access-list-name

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<global>
<as-path-access-lists>
<as-path-access-list> <!-- operation="delete"-->
  <access-list-regular-expression>LINE</access-list-regular-expression>
  <config>
    <access-list-regular-expression>LINE</access-list-regular-expression>
    <access-list-action>deny</access-list-action>
    <access-list-name>WORD</access-list-name>
  </config>
  <access-list-action>deny</access-list-action>
  <access-list-name>WORD</access-list-name>
</as-path-access-list>
</as-path-access-lists>
</global>
</bgp>
```

Command Syntax

```
ip as-path access-list WORD (deny|permit) LINE
```

Configure enable aggregate nexthop

Use this attribute to set the BGP option to perform aggregation only when next-hop matches the specified IP address.

Attribute Name: enable-aggregate-nexthop

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<global>
<config>
  </enable-aggregate-nexthop><!-- operation="delete"-->
</config>
</global>
</bgp>
```

Command Syntax

```
bgp aggregate-nexthop-check
```

Configure enable path select

Use this attribute to set RFC 1771 compatible path selection

Attribute Name: enable-path-select

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<global>
```

```
<config>
  </enable-path-select><!-- operation="delete"-->
</config>
</global>
</bgp>
```

Command Syntax

```
bgp rfc1771-path-select
```

Configure disable adj out

Use this attribute to Disable BGP ADJ_OUT.

Attribute Name: disable-adj-out

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<global>
<config>
  </disable-adj-out><!-- operation="delete"-->
</config>
</global>
</bgp>
```

Command Syntax

```
bgp disable-adj-out
```

Configure enable extended asn capability

Use this attribute to configure a BGP router to send 4-octet ASN capabilities. If attempting to change the AS capability from 2 to 4 or 4 to 2, a prompt occurs to remove the VRF configuration (if it exists), and reconfiguration is required, because the route distinguisher (RD) configuration would have been created with the current (2 octet or 4 octet) capability, and must be reconfigured before attempting to change the capability. While loading from a saved configuration with AS4 capability and BGP VRF configuration, the capability will not be changed because of the above described reason.

Attribute Name: enable-extended-asn-capability

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<global>
<config>
  </enable-extended-asn-capability><!-- operation="delete"-->
</config>
</global>
</bgp>
```

Command Syntax

```
bgp extended-asn-cap
```

Configure enable nexthop tracking

Use this attribute to enable nexthop address tracking. Nexthop address tracking is an event-driven notification system that monitors the status of routes installed in the Routing Information Base (RIB) and reports nexthop changes that affect internal BGP (iBGP) or external BGP (eBGP) prefixes directly to the BGP process. This improves the overall BGP convergence time, by allowing BGP to respond rapidly to nexthop changes for routes installed in the RIB. If nexthop tracking is enabled after certain routes are learned, the registration of all nexthops for selected BGP routes is done after the nexthop tracking feature is enabled. If nexthop tracking is disabled, and if there are still some selected BGP routes, BGP de-registers the nexthops of all selected BGP routes from NSM.

Attribute Name: enable-nexthop-tracking

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <global>
    <config>
      </enable-nexthop-tracking><!-- operation="delete"-->
    </config>
  </global>
</bgp>
```

Command Syntax

```
bgp nexthop-trigger enable
```

Configure nexthop tracking delay

Use this attribute to set the delay time for nexthop address tracking. This attribute configures the delay interval between routing table walks for nexthop delay tracking, after which BGP does a routing table scan on receiving a nexthop change trigger from NSM. The time period determines how long BGP waits before it walks the full BGP table to determine which prefixes are affected by the nexthop changes, after it receives the trigger from NSM about one or more nexthop changes.

Attribute Name: nexthop-tracking-delay

Attribute Type: uint8

Default Value: 5

Attribute Range: 1-100

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <global>
    <config>
      <nexthop-tracking-delay>1</nexthop-tracking-delay> <!-- operation="delete"-->
    </config>
  </global>
</bgp>
```

Command Syntax

```
bgp nexthop-trigger delay <1-100>
```

Configure enable rfc 1771 strict origin

Use this attribute to set the origin path attribute to IGP when the origin is a protocol such as RIP, OSPF, or ISIS as specified in RFC 1771. Otherwise, the origin is always set to incomplete which is the industry standard.

Attribute Name: enable-rfc-1771-strict-origin

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <global>
    <config>
      </enable-rfc-1771-strict-origin><!-- operation="delete"-->
    </config>
  </global>
</bgp>
```

Command Syntax

```
bgp rfc1771-strict
```

Configure config type

Use this attribute to set the BGP configuration to the standard type. After setting the configuration to the standard type, use the sendCommunity attribute to send out BGP community attributes. The zebos configuration type is the default and requires no specific configuration for sending out BGP standard community and extended community attributes.

Attribute Name: config-type

Attribute Type: enum (standard|zebos)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <global>
    <config>
      <config-type>standard</config-type> <!-- operation="delete"-->
    </config>
  </global>
</bgp>
```

Command Syntax

```
bgp config-type (standard|zebos)
```

Configure enable per prefix label mode

Use this attribute to configure mpls label mode

This command is supported when following feature are enabled MPLS feature enabled, bgp 6PE feature enabled

Attribute Name: enable-per-prefix-label-mode

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <global>
    <mpls-6pe>
      <config>
        </enable-per-prefix-label-mode><!-- operation="delete"-->
      </config>
    </mpls-6pe>
  </global>
</bgp>
```

Command Syntax

```
mpls label mode 6pe per-prefix
```

Configure options

Use this attribute to enable all BGP troubleshooting functions. Use this attribute without any parameters to turn on normal bgp debug information.

Attribute Name: options

Attribute Type: bits (all|nht|nsm|fsm|events|filters|keepalives|updates|dampening|bfd|mpls|vpls|link-state|rib|srv6|normal)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <global>
    <debug>
      <config>
        <options>all</options> <!-- operation="delete"-->
      </config>
    </debug>
  </global>
</bgp>
```

Command Syntax

```
debug bgp
  (all|nht|nsm|fsm|events|filters|keepalives|updates|dampening|bfd|mpls|vpls|link-
  state|rib|srv6|normal)
```

Configure update options

Use this attribute to enable all BGP troubleshooting functions. Use this attribute without any parameters to turn on normal bgp debug information.

Attribute Name: update-options

Attribute Type: bits (in|out)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<global>
<debug>
<config>
  <update-options>in</update-options> <!-- operation="delete"-->
</config>
</debug>
</global>
</bgp>
```

Command Syntax

```
debug bgp updates (in|out)
```

restart bgp graceful

Netconf RPC payload

```
<bgp-graceful-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp"/>
```

Command Syntax

```
restart bgp graceful
```

clear bgp statistics

Netconf RPC payload

```
<clear-bgp-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp"/>
```

Command Syntax

```
clear bgp statistics
```

snmp restart bgp

Netconf RPC payload

```
<bgp-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp"/>
```

Command Syntax

```
snmp restart bgp
```

debug bgp

(all|nht|nsm|fsm|events|filters|keepalives|updates|dampening|bfd|mpls|vpls|link-state|rib|srv6|normal)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|nht|nsm|fsm|events|filters|keepalives|updates|dampening|bfd|mpls|vpls|link-state|rib|srv6|normal)

Netconf RPC payload

```
<bgp-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">  
<terminal-debug-options>all</terminal-debug-options>  
</bgp-debug-on>
```

Command Syntax

```
debug bgp  
(all|nht|nsm|fsm|events|filters|keepalives|updates|dampening|bfd|mpls|vpls|link-  
state|rib|srv6|normal)
```

no debug bgp

(all|nht|nsm|fsm|events|filters|keepalives|updates|dampening|bfd|mpls|vpls|link-state|rib|srv6|normal)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|nht|nsm|fsm|events|filters|keepalives|updates|dampening|bfd|mpls|vpls|link-state|rib|srv6|normal)

Netconf RPC payload

```
<bgp-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">  
<terminal-debug-options>all</terminal-debug-options>  
</bgp-debug-off>
```

Command Syntax

```
no debug bgp  
(all|nht|nsm|fsm|events|filters|keepalives|updates|dampening|bfd|mpls|vpls|link-  
state|rib|srv6|normal)
```

debug bgp updates (in|out)

Attribute Name: terminal-debug-options

Attribute Type: bits (in|out)

Netconf RPC payload

```
<bgp-debug-updates-type-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">  
<terminal-debug-options>in</terminal-debug-options>  
</bgp-debug-updates-type-on>
```

Command Syntax

```
debug bgp updates (in|out)
```

no debug all bgp

Netconf RPC payload

```
<bgp-all-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp"/>
```

Command Syntax

```
no debug all bgp
```

IPI-BGP-INSTANCE

Configure no external fail over

Use this attribute to reset a BGP session immediately, if the interface used for BGP connection goes down.

Attribute Name: no-external-fail-over

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      </no-external-fail-over><!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
no bgp fast-external-failover
```

Configure no best path tie break

Use this attribute to always select a preferred older route even when the bestpathCompareRouterId attribute is configured

Attribute Name: no-best-path-tie-break

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      </no-best-path-tie-break><!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
no bgp bestpath tie-break-on-age
```

Configure inbound route filter enable

Use this attribute to enable the MPLS (Multiprotocol Label Switching) VPN/BGP inbound route filter. This attribute is used to control the installation of routing information into the BGP table. When a router runs MPLS VPN/BGP PE, it exchanges routing information with a routing distinguisher. By default, routing information that does not match the configured routing distinguisher value is not installed. When the local box has two VRFs where each routing distinguisher value is 10:100 and 20:200, routing information with routing distinguisher 10:200 is not installed into BGP table.

Attribute Name: inbound-route-filter-enable

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      </inbound-route-filter-enable><!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
no bgp inbound-route-filter
```

Configure no client route reflection

Use this attribute to configure routers as route reflectors. Route reflectors are used when all Interior Border Gateway Protocol (iBGP) speakers are not fully meshed. If the clients are fully meshed the route reflector is not required

Attribute Name: no-client-route-reflection

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      </no-client-route-reflection><!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```
</bgp>
```

Command Syntax

```
no bgp client-to-client reflection
```

Configure med type

Use this attribute to specify two MED (Multi Exit Discriminator) attributes, confed and missing-as-worst. The confed attribute enables MED comparison along paths learned from confederation peers. The MEDs are compared only if there is no external Autonomous System (an AS not within the confederation) in the path. If there is an external autonomous system in the path, the MED comparison is not made. The missing-as-worst to consider a missing MED attribute in a path as having a value of infinity, making the path without a MED value the least desirable path. If missing-as-worst is disabled, the missing MED is assigned the value of 0, making the path with the missing MED attribute the best path.

Attribute Name: med-type

Attribute Type: bits (confed|missing-as-worst|remove-recv-med|remove-send-med)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <med-type>3</med-type> <!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp bestpath med (confed) missing-as-worst
```

Configure bgp as

Use this attribute to specify two MED (Multi Exit Discriminator) attributes, confed and missing-as-worst. The confed attribute enables MED comparison along paths learned from confederation peers. The MEDs are compared only if there is no external Autonomous System (an AS not within the confederation) in the path. If there is an external autonomous system in the path, the MED comparison is not made. The missing-as-worst to consider a missing MED attribute in a path as having a value of infinity, making the path without a MED value the least desirable path. If missing-as-worst is disabled, the missing MED is assigned the value of 0, making the path with the missing MED attribute the best path.

Attribute Name: med-type

Attribute Type: bits (confed|missing-as-worst|remove-recv-med|remove-send-med)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
```

```
<bgp-as>1</bgp-as>
<config>
  <bgp-as>1</bgp-as>
</config>
  <med-type>3</med-type> <!-- operation="delete"-->
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
bgp bestpath med (missing-as-worst) confed
```

Configure router id

Use this attribute to manually configure a fixed router ID as a BGP router identifier. When this attribute is used to configure a fixed router ID, the current router identifier is overridden and the peers are reset.

Attribute Name: router-id

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <router-id>A.B.C.D</router-id> <!-- operation="delete"-->
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
bgp router-id A.B.C.D
```

Configure cluster id

Use this attribute to configure the cluster ID if the BGP cluster has more than one route reflector. A cluster includes route reflectors and its clients. Usually, each cluster is identified by the router ID of its single route reflector but to increase redundancy sometimes a cluster may have more than one route reflector. All router reflectors in such a cluster are then identified by a cluster ID. The clusterId attribute is used to configure the 4 byte cluster ID for clusters with more than one route reflectors in an IPv4 address format.

Attribute Name: cluster-id

Attribute Type: union

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
```

```

<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <cluster-id>BGP_CLUSTER_ID_T</cluster-id>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp cluster-id (A.B.C.D|<1-4294967295>)
```

Configure local preference

Use this attribute to change the default local preference value. Local preference indicates the preferred path when there are multiple paths to the same destination. The path having a higher preference is preferred. The preference is sent to all routers and access servers in the local autonomous system.

Attribute Name: local-preference

Attribute Type: uint32

Default Value: 100

Attribute Range: 0-4294967295

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <local-preference>0</local-preference> <!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>

```

Command Syntax

```
bgp default local-preference <0-4294967295>
```

Configure graceful shutdown capable

Use this attribute to enable the graceful shutdown capability at the router level and make available the graceful-shutdown related attributes at the router and BGP neighbor levels.

Attribute Name: graceful-shutdown-capable

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      </graceful-shutdown-capable><!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp g-shut-capable
```

Configure graceful shutdown

Use this attribute to gracefully shut down all BGP IPv4 sessions under this router. The BGP graceful shutdown feature reduces packet loss during maintenance activity.

Attribute Name: graceful-shutdown

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      </graceful-shutdown><!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp g-shut
```

Configure graceful shutdown local preference

Use this attribute to set the local preference of the router to use during graceful shutdown. The local preference value indicates the preferred path when there are multiple paths to the same destination in a single routing database. The path with a higher preference value is the preferred one. The preferred path is sent to all routers and access servers in the local autonomous system.

Attribute Name: graceful-shutdown-local-preference

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <graceful-shutdown-local-preference>0</graceful-shutdown-local-preference>
<!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp g-shut-local-preference <0-4294967295>
```

Configure log neighbor changes

Use this attribute to enable logging of status change messages without turning on debug bgp attributes. Product has many logging services for neighbor status, including debug bgp fsm and debug bgp events. However, these attributes cause system performance degradation. If you need to log neighbor status changes only, IP Infusion Inc. recommends turning off all debug attributes and using the setLogNbrChanges attribute instead.

Attribute Name: log-neighbor-changes

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      </log-neighbor-changes><!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp log-neighbor-changes
```

Configure scan interval

Use this attribute to configure scanning intervals of BGP routers. This interval is the period after which router checks the validity of the routes in its database. To disable BGP scanning, set the scan-time interval to 0 seconds.

Attribute Name: scan-interval

Attribute Type: uint32

Default Value: 60

Attribute Range: 0-60

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <scan-interval>0</scan-interval> <!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp scan-time <0-60>
```

Configure best path dont compare originator

Use this attribute to change the default bestpath selection by not comparing an originator-ID for an identical EBGp path

Attribute Name: best-path-dont-compare-originator

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
        </best-path-dont-compare-originator><!-- operation="delete"-->
      </config>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp bestpath dont-compare-originator-id
```

Configure enable deterministic med

Use this attribute to compare the Multi Exit Discriminator (MED) variable when choosing among routes advertised by different peers in the same autonomous system. MED is compared after BGP attributes weight, local preference, AS-path and origin have been compared and are equal. For a correct comparison result, enable this attribute on all routers in a local AS. After enabling this attribute, all paths for the same prefix are grouped together and arranged according to

their MED value. Based on this comparison, the best path is then chosen. This attribute compares MED variable when choosing routes advertised by different peers in the same AS, to compare MED, when choosing routes from neighbors in different ASs use the compareMed attribute. When the deterministicMed attribute is set, routes from the same AS are grouped together, and the best routes of each group are compared.

Attribute Name: enable-deterministic-med

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      </enable-deterministic-med><!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp deterministic-med
```

Configure enforce first as for ebgp

Use this attribute to enforce the first AS for eBGP routes. This attribute specifies that any updates received from an external neighbor that do not have the neighbors configured Autonomous System (AS) at the beginning of the AS_PATH in the received update must be denied. Enabling this feature adds to the security of the BGP network by not allowing traffic from unauthorized systems.

Attribute Name: enforce-first-as-for-ebgp

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      </enforce-first-as-for-ebgp><!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp enforce-first-as
```

Configure local as count

Use this attribute to set the number of times the local-AS (Autonomous System) is to be prepended.

Attribute Name: local-as-count

Attribute Type: uint8

Attribute Range: 2-64

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <local-as-count>2</local-as-count> <!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp as-local-count <2-64>
```

Configure multi path relax

Use this attribute to relax the same AS-Path requirement so any candidate eBGP AS-Path with the same AS-path length might be used for eBGP load-balancing. This feature does not load-balance between eBGP and iBGP paths. Normally eBGP load-balancing requires the candidate routes to be equal-cost paths with identical BGP attributes having the same weight, Local-Pref, AS-Path (both the AS numbers and the AS pathlength), origin, MED, and different next-hop.

Attribute Name: multi-path-relax

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      </multi-path-relax><!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp bestpath as-path multipath-relax
```

Configure enable mpls nexthop tracking

Use this attribute to enable mpls nexthop address tracking. MPLS Nexthop address tracking is an event-driven notification system that monitors the status of LSP installed in the NSM and reports changes that affect internal BGP (iBGP) or external BGP (eBGP) prefixes directly to the BGP process. This improves the overall BGP convergence time, by allowing BGP to respond rapidly to nexthop changes for FTN installed in the NSM. If MPLS nexthop tracking is enabled after certain routes are learned, the registration of all nexthops for selected BGP routes is done after the mpls nexthop tracking feature is enabled. If MPLS nexthop tracking is disabled, and if there are still some selected BGP routes, BGP de-registers the nexthops of all selected BGP routes from NSM.

Attribute Name: enable-mpls-nexthop-tracking

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      </enable-mpls-nexthop-tracking><!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
mpls-nexthop-tracking
```

Configure ignore aigp for bestpath

Use this config to ignore aigp attr in BGP best-path selection algorithm.

Attribute Name: ignore-aigp-for-bestpath

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      </ignore-aigp-for-bestpath><!-- operation="delete"-->
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp bestpath aigp ignore
```

Configure identifier

Use this attribute to specify a BGP confederation identifier

Attribute Name: identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <confederation>
        <config>
          <identifier>1</identifier> <!-- operation="delete"-->
        </config>
      </confederation>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp confederation identifier <1-4294967295>
```

Configure peer as number

Use this attribute to specify peer AS number in BGP confederation

Attribute Name: peer-as-number

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <confederation>
        <config>

```

```

        <peer-as-number>1</peer-as-number> <!-- operation="delete"-->
    </config>
</confederation>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp confederation peers .<1-4294967295>
```

Configure enable graceful restart

Use this attribute to enable BGP graceful-restart capabilities. The restart-time parameter is used for setting the maximum time that a graceful-restart neighbor waits to come back up after a restart. This value is applied to all neighbors unless you explicitly override it by configuring the corresponding value on the neighbor. The stalepath-time parameter is used to set the maximum time to preserve stale paths from a gracefully restarted neighbor. All stalepaths, unless reinstated by the neighbor after a re-establishment, will be deleted at the expiration of this timer.

Attribute Name: enable-graceful-restart

Attribute Type: empty

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <graceful-restart>
        <config>
          </enable-graceful-restart><!-- operation="delete"-->
        </config>
      </graceful-restart>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

Command Syntax

```
bgp graceful-restart
```

Configure restart time

Use this attribute to enable BGP graceful-restart capabilities. The restart-time parameter is used for setting the maximum time that a graceful-restart neighbor waits to come back up after a restart. This value is applied to all neighbors unless you explicitly override it by configuring the corresponding value on the neighbor.

Attribute Name: restart-time

Attribute Type: uint32

Default Value: 90

Attribute Range: 1-3600

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <graceful-restart>
        <config>
          <restart-time>1</restart-time> <!-- operation="delete"-->
        </config>
      </graceful-restart>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp graceful-restart restart-time <1-3600>
```

Configure stale path max retention time

Use this attribute to enable BGP graceful-restart capabilities. The stalepath-time parameter is used to set the maximum time to preserve stale paths from a gracefully restarted neighbor. All stalepaths, unless reinstated by the neighbor after a re-establishment, will be deleted at the expiration of this timer.

Attribute Name: stale-path-max-retention-time

Attribute Type: uint32

Default Value: 360

Attribute Range: 1-3600

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <graceful-restart>
        <config>
          <stale-path-max-retention-time>1</stale-path-max-retention-time> <!--
operation="delete"-->
        </config>
      </graceful-restart>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp graceful-restart stalepath-time <1-3600>
```

Configure route selection max defer time

Use this attribute to specify the update-delay value for a graceful-restart capable router. The update-delay value is the maximum time a graceful-restart capable router, which is restarting, will defer route-selection and advertisements to all its graceful-restart capable neighbors. This maximum time starts from the instance the first neighbor attains established state after restart. The restarting router prematurely terminates this timer when end-of-rib markers are received from all its graceful-restart capable neighbors.

Attribute Name: route-selection-max-defer-time

Attribute Type: uint32

Default Value: 120

Attribute Range: 1-3600

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <graceful-restart>
        <config>
          <route-selection-max-defer-time>1</route-selection-max-defer-time> <!--
operation="delete"-->
        </config>
      </graceful-restart>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp update-delay <1-3600>
```

Configure graceful reset

Use this attribute to enable BGP graceful-restart capabilities. The restart-time parameter is used for setting the maximum time that a graceful-restart neighbor waits to come back up after a restart. This value is applied to all neighbors unless you explicitly override it by configuring the corresponding value on the neighbor.

Attribute Name: graceful-reset

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
```

```
<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <graceful-restart>
  <config>
    </graceful-reset><!-- operation="delete"-->
  </config>
</graceful-restart>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
bgp graceful-restart graceful-reset
```

Configure keep alive

Use this attribute to globally set or reset the keepalive values for all the neighbors

Attribute Name: keep-alive

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: hold-time

Attribute Type: uint16

Attribute Range: 0-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <timers>
    <config>
      <hold-time>0</hold-time>
      <keep-alive>0</keep-alive>
    </config>
  </timers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
timers bgp <0-65535> <0-65535>
```

Configure always compare med

Use this attribute to compare the Multi Exit Discriminator (MED) for paths from neighbors in different autonomous systems. Multi Exit Discriminator (MED) is used in best path selection by BGP. MED is compared after BGP attributes weight, local preference, AS-path and origin have been compared and are equal. MED comparison is done only among paths from the same autonomous system (AS). Use compareMed attribute to allow comparison of MEDs from different ASs. The MED parameter is used to select the best path. A path with lower MED is preferred.

Attribute Name: always-compare-med

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <route-selection>
        <config>
          </always-compare-med><!-- operation="delete"-->
        </config>
      </route-selection>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp always-compare-med
```

Configure ignore as path length

Use this attribute to prevent the router from considering the autonomous system (AS) path length as a factor in the algorithm for choosing a best path route.

Attribute Name: ignore-as-path-length

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <route-selection>
        <config>
          </ignore-as-path-length><!-- operation="delete"-->
        </config>
      </route-selection>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```
</config>
</route-selection>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
bgp bestpath as-path ignore
```

Configure best path compare confed

Use this attribute to allow comparing of the confederation AS path length. This attribute specifies that the AS confederation path length must be used when available in the BGP best path decision process. It is effective only when bestpathAspath attribute has not been used.

Attribute Name: best-path-compare-confed

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <route-selection>
        <config>
          </best-path-compare-confed><!-- operation="delete"-->
        </config>
      </route-selection>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp bestpath compare-confed-aspath
```

Configure external compare router id

Use this attribute to compare router IDs for identical eBGP paths. When comparing similar routes from peers, the BGP router does not consider the router ID of the routes. By default, it selects the first received route. Use this attribute to include router ID in the selection process; similar routes are compared and the route with the lowest router ID is selected. The router ID is the highest IP address on the router, with preference given to loopback addresses. Router ID can be manually set by using the routerIpAddr attribute.

Attribute Name: external-compare-router-id

Attribute Type: empty

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <route-selection>
  <config>
    </external-compare-router-id><!-- operation="delete"-->
  </config>
</route-selection>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp bestpath compare-routerid
```

Configure source ip prefix

Use this attribute to set the administrative distance for ip source prefix.

Attribute Name: source-ip-prefix

Attribute Type: string

Attribute Name: distance

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <administrative-distances>
  <administrative-distance> <!-- operation="delete"-->
    <source-ip-prefix>A.B.C.D/M</source-ip-prefix>
    <config>
      <source-ip-prefix>A.B.C.D/M</source-ip-prefix>
      <distance>1</distance>
    </config>
  </administrative-distance>
</administrative-distances>
</bgp-instance>
</bgp-instances>

```

```
</bgp>
```

Command Syntax

```
distance <1-255> A.B.C.D/M
```

Configure access list name

Use this attribute to define an administrative distance along with ip source prefix and access list name.

Attribute Name: access-list-name

Attribute Type: string

Attribute Name: distance

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <administrative-distances>
        <administrative-distance>
          <source-ip-prefix>A.B.C.D/M</source-ip-prefix>
          <config>
            <source-ip-prefix>A.B.C.D/M</source-ip-prefix>
            <distance>1</distance>
          </config>
          <access-list-name>WORD</access-list-name>
        </administrative-distance>
      </administrative-distances>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
distance <1-255> A.B.C.D/M WORD
```

Configure all routes

Use this attribute to allocate label to all the advertised routes

This command is supported when following feature are enabled bgp lu feature

Attribute Name: all-routes

Attribute Type: empty

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <allocate-label>
  <config>
    </all-routes><!-- operation="delete"-->
  </config>
</allocate-label>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
allocate-label all
```

Configure route map name

Use this attribute to allocate label to those advertised routes that match route-map.

This command is supported when following feature are enabled bgp lu feature

Attribute Name: route-map-name

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <allocate-label>
  <config>
    <route-map-name>WORD</route-map-name> <!-- operation="delete"-->
  </config>
</allocate-label>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
allocate-label route-map WORD
```

IPI-BGP-ADDRESS-FAMILY

Configure safi

BGP sub address family identifier

Attribute Name: safi

Attribute Type: enum (unicast|multicast|labeled-unicast|l2vpn-vpls|evpn|link-state|vpn-unicast|rtfilter-unicast|flowspec|flowspec-mpls-vpn)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family> <!-- operation="delete"-->
          <safi>labeled-unicast</safi>
          <config>
            <safi>labeled-unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
address-family ipv4 labeled-unicast
```

Configure additional path fast reroute

Use this attribute to specify fast-reroute tie-break secondary-path

Attribute Name: additional-path-fast-reroute

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
```

```

    <bgp-as>1</bgp-as>
  </config>
</address-families>
<address-family>
  <safi>unicast</safi>
  <config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  </config>
  <afi>ipv4</afi>
  </additional-path-fast-reroute><!-- operation="delete"-->
</address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp fast-reroute tie-break secondary-path
```

Configure additional paths mode

Use this attribute to add additional paths in the BGP table

Attribute Name: additional-paths-mode

Attribute Type: bits (send-receive|receive|send)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <additional-paths-mode>send-receive</additional-paths-mode> <!--
operation="delete"-->
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

Command Syntax

```
bgp additional-paths (send-receive|receive|send)
```

Configure bgp as

Use this attribute to add additional paths in the BGP table

Attribute Name: additional-paths-mode

Attribute Type: bits (send-receive|receive|send)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <additional-paths-mode>send-receive</additional-paths-mode> <!--
operation="delete"-->
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp additional-paths (send-receive|receive|send)
```

Configure afi

Use this attribute to add additional paths in the BGP table

Attribute Name: additional-paths-mode

Attribute Type: bits (send-receive|receive|send)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
```



```

        <bgp-as>1</bgp-as>
    </config>
<address-families>
<address-family>
    <safi>unicast</safi>
    <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
    <additional-paths-mode>send-receive</additional-paths-mode> <!--
operation="delete"-->
    </address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp additional-paths (send-receive|receive|send)
```

Configure additional path select all

Use this attribute to select criteria to pick the paths

Attribute Name: additional-path-select-all

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
    <bgp-instance>
        <bgp-as>1</bgp-as>
        <config>
            <bgp-as>1</bgp-as>
        </config>
        <address-families>
        <address-family>
            <safi>unicast</safi>
            <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
            </config>
            <afi>ipv4</afi>
            <additional-path-select-all><!-- operation="delete"-->
        </address-family>
        </address-families>
    </bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp additional-paths select all
```

Configure additional paths best select count

Use this attribute to select best N paths

Attribute Name: additional-paths-best-select-count

Attribute Type: uint8

Attribute Range: 2-3

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <additional-paths-best-select-count>2</additional-paths-best-select-
count> <!-- operation="delete"-->
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp additional-paths select best <2-3>
```

Configure no client route reflection

Use this attribute to configure routers as route reflectors. Route reflectors are used when all Interior Border Gateway Protocol (iBGP) speakers are not fully meshed. If the clients are fully meshed the route reflector is not required.

Attribute Name: no-client-route-reflection

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
```

```

<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <address-families>
  <address-family>
    <safi>unicast</safi>
    <config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
    </no-client-route-reflection><!-- operation="delete"-->
  </address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
no bgp client-to-client reflection
```

Configure enable auto summary

Use this attribute to enable sending summarized routes by a BGP speaker to its peers. Auto-summary is used by a BGP router to advertise summarized routes to its peers. Auto-summary can be enabled if certain routes have already been advertised: in this case, configuring auto-summary advertises the summarized routes first, then corresponding non-summarized routes are withdrawn. If certain routes have already been advertised, and auto-summary is disabled, non-summarized routes are first advertised, then the corresponding summarized routes are withdrawn from all the connected peers.

Attribute Name: enable-auto-summary

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
      <address-family>
        <safi>unicast</safi>
        <config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>

```

```
        <afi>ipv4</afi>
        </enable-auto-summary><!-- operation="delete"-->
    </address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
auto-summary
```

Configure enable additional path pic

Use this attribute to enable the additional paths in the BGP table,install the indirect nexthop in RIB

Attribute Name: enable-additional-path-pic

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <afi>ipv4</afi>
      </enable-additional-path-pic><!-- operation="delete"-->
    </address-family>
  </address-families>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
bgp additional-paths install
```

Configure enable network igp sync

Use this attribute to enable IGP synchronization for BGP static network routes

Attribute Name: enable-network-igp-sync

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <afi>ipv4</afi>
      </enable-network-igp-sync><!-- operation="delete"-->
    </address-family>
  </address-families>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
network synchronization
```

Configure map name

Use this attribute to enable or disable suppression/modification of incoming BGP updates to IP RIB/FIB table installation. In a dedicated route reflector, all the routes it receives may not be required to be stored or only few selected routes need to be stored, because it may not lie in the data path. Table maps are particularly useful to attain this restriction. When map-name attribute is set, the route map referenced in the map-name attribute shall be used to set certain properties (such as the traffic index) of the routes for installation into the RIB. The route is always downloaded, regardless of whether it is permitted or denied by the route map.

Attribute Name: map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
```

```
<config>
  <safi>unicast</safi>
  <afi>ipv4</afi>
</config>
  <afi>ipv4</afi>
<table-map>
<config>
  <map-name>WORD</map-name> <!-- operation="delete"-->
</config>
</table-map>
</address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
table-map WORD
```

Configure table map filter

When tableMapFilter attribute is given in the table map attribute, the route map referenced is used to control whether a BGP route is to be downloaded to the IP RIB (hence the filter). A BGP route is not downloaded to the RIB if it is denied by the route map.

Attribute Name: table-map-filter

Attribute Type: boolean

Attribute Name: map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
        <table-map>
          <config>
```

```

        <map-name>WORD</map-name> <!-- operation="delete"-->
        <table-map-filter>true</table-map-filter> <!-- operation="delete"-->
>
    </config>
</table-map>
</address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
table-map WORD filter
```

Configure enable igp sync

Use this attribute to enable IGP synchronization of Internal BGP (iBGP) learned routes with the Internal Gateway Protocol (IGP) system. Synchronization is used when a BGP router should not advertise routes learned from iBGP neighbors, unless those routes are also present in an IGP (for example, OSPF). Synchronization may be enabled when all the routers in an autonomous system do not speak BGP, and the autonomous system is a transit for other autonomous systems.

Attribute Name: enable-igp-sync

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <afi>ipv4</afi>
      </enable-igp-sync><!-- operation="delete"-->
    </address-family>
  </address-families>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
synchronization
```

Configure backdoor

network address with backdoor for address family

Attribute Name: backdoor

Attribute Type: uint8

Attribute Name: network-rmap-name

Attribute Type: string

Default Value: NULL

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <network-lists>
            <network-list>
              <local-network-prefix>A.B.C.D</local-network-prefix>
              <config>
                <local-network-prefix>BGP_IP_NETWORK_T</local-network-prefix>
                <network-rmap-name>WORD</network-rmap-name>
              </config>
            </network-list>
          </network-lists>
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
network (A.B.C.D | A.B.C.D/M) (route-map WORD|) (backdoor|)
```

Configure local network prefix

network address with backdoor for address family

Attribute Name: backdoor

Attribute Type: uint8

Attribute Name: network-rmap-name

Attribute Type: string

Default Value: NULL

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <network-lists>
            <network-list>
              <local-network-prefix>A.B.C.D</local-network-prefix>
              <config>
                <local-network-prefix>BGP_IP_NETWORK_T</local-network-prefix>
                <network-rmap-name>WORD</network-rmap-name>
              </config>
            </network-list>
          </network-lists>
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
network (X:X::X:X/M) (route-map WORD|) (backdoor|)
```

Configure aggregate address

Aggregates are used to minimize the size of routing tables. Aggregation combines the characteristics of several different routes and advertises a single route. The aggregate-address attribute creates an aggregate entry in the BGP routing table if any more-specific BGP routes are available in the specified range.

Attribute Name: aggregate-address

Attribute Type: union

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <aggregate-address-lists>
            <aggregate-address-list> <!-- operation="delete"-->
              <aggregate-address>CML_IP_PREFIX_T</aggregate-address>
              <config>
                <aggregate-address>CML_IP_PREFIX_T</aggregate-address>
              </config>
            </aggregate-address-list>
          </aggregate-address-lists>
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
aggregate-address (A.B.C.D/M|A.B.C.D A.B.C.D|X:X::X:X/M)
```

Configure aggregate type

The aggregate-type attribute creates an aggregate entry advertising the path for this route, consisting of all elements contained in all paths being summarized. Use this parameter to reduce the size of path information by listing the AS number only once, even if it was included in multiple paths that were aggregated.

Attribute Name: aggregate-type

Attribute Type: enum (as-set|summary-only|as-set-and-summary-only)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <afi>ipv4</afi>
      <aggregate-address-lists>
      <aggregate-address-list>
        <aggregate-address>CML_IP_PREFIX_T</aggregate-address>
        <config>
          <aggregate-address>CML_IP_PREFIX_T</aggregate-address>
        </config>
        <aggregate-type>1</aggregate-type> <!-- operation="delete"-->
      </aggregate-address-list>
    </aggregate-address-lists>
    </address-family>
  </address-families>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
aggregate-address as-set
```

Configure local

Use this attribute to define an administrative distance for local routes. Local routes are routes that is redistributed from another process. A distance is a rating of trustworthiness of a router. The higher the distance the lower the trust rating. If the administrative distance is changed, it could create inconsistency in the routing table and obstruct routing.

Attribute Name: local

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>

```

```
        <bgp-as>1</bgp-as>
</config>
<address-families>
<address-family>
  <safi>unicast</safi>
  <config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  </config>
  <afi>ipv4</afi>
  <distances>
  <distance> <!-- operation="delete"-->
    <local>1</local>
    <config>
      <local>1</local>
      <ibgp>1</ibgp>
      <ebgp>1</ebgp>
    </config>
    <ibgp>1</ibgp>
    <ebgp>1</ebgp>
  </distance>
</distances>
</address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
distance bgp <1-255> <1-255> <1-255>
```

Configure ebgp

Use this attribute to define an administrative distance for local routes. Local routes are routes that is redistributed from another process. A distance is a rating of trustworthiness of a router. The higher the distance the lower the trust rating. If the administrative distance is changed, it could create inconsistency in the routing table and obstruct routing.

Attribute Name: local

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
  <address-families>
```

```

<address-family>
  <safi>unicast</safi>
  <config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  </config>
  <afi>ipv4</afi>
<distances>
<distance> <!-- operation="delete"-->
  <local>1</local>
  <config>
    <local>1</local>
    <ibgp>1</ibgp>
    <ebgp>1</ebgp>
  </config>
  <ibgp>1</ibgp>
  <ebgp>1</ebgp>
</distance>
</distances>
</address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
distance bgp <1-255> <1-255> <1-255>
```

Configure ebgp max path

Use this attribute to set the number of equal-cost multi-path (ECMP) routes for eBGP. You can install multiple BGP paths to the same destination to balance the load on the forwarding path

Attribute Name: ebgp-max-path

Attribute Type: int32

Attribute Range: 2-64

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>

```

```
        <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
    <maximum-paths>
    <config>
        <ebgp-max-path>2</ebgp-max-path> <!-- operation="delete"-->
    </config>
    </maximum-paths>
</address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
max-paths ebgp <2-64>
```

Configure ibgp max path

Use this attribute to set the number of equal-cost multi-path (ECMP) routes for iBGP. You can install multiple BGP paths to the same destination to balance the load on the forwarding path.

Attribute Name: `ibgp-max-path`

Attribute Type: `int32`

Attribute Range: `2-64`

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
        <afi>ipv4</afi>
      <maximum-paths>
      <config>
          <ibgp-max-path>2</ibgp-max-path> <!-- operation="delete"-->
      </config>
      </maximum-paths>
    </address-family>
  </address-families>
</bgp-instance>
```

```
</bgp-instances>
</bgp>
```

Command Syntax

```
max-paths ibgp <2-64>
```

Configure eibgp max path

Use this attribute to set the number of equal-cost multi-path (ECMP) routes for eiBGP. You can install multiple BGP paths to the same destination to balance the load on the forwarding path

Attribute Name: eibgp-max-path

Attribute Type: int32

Attribute Range: 2-64

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <maximum-paths>
            <config>
              <eibgp-max-path>2</eibgp-max-path> <!-- operation="delete"-->
            </config>
          </maximum-paths>
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
max-paths eibgp <2-64>
```

Configure enable dampening

This attribute enable BGP route dampening and set various parameters to default values.

Attribute Name: enable-dampening

Attribute Type: enum (enable-dampening)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <route-flap-dampenings>
            <route-flap-dampening> <!-- operation="delete"-->
              <enable-dampening>enable-dampening</enable-dampening>
            <config>
              <enable-dampening>enable-dampening</enable-dampening>
            </config>
          </route-flap-dampening>
        </route-flap-dampenings>
      </address-family>
    </address-families>
  </bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
bgp dampening
```

Configure reach half life

Use this attribute to configure reachability half-life time for the penalty in minutes for the bgp route dampening. The time for the penalty to decrease to one-half of its current value.

Attribute Name: reach-half-life

Attribute Type: uint32

Default Value: 15

Attribute Range: 1-45

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
```



```

    <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <address-families>
  <address-family>
    <safi>unicast</safi>
    <config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
    <route-flap-dampenings>
    <route-flap-dampening>
      <enable-dampening>enable-dampening</enable-dampening>
      <config>
        <enable-dampening>enable-dampening</enable-dampening>
      </config>
      <reach-half-life>1</reach-half-life> <!-- operation="delete"-->
    </route-flap-dampening>
  </route-flap-dampenings>
</address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp dampening <1-45>
```

Configure max suppress time

Use this attribute to configure the value to start suppressing a route for BGP route dampening. When the penalty for a route exceeds the suppress value, the route is suppressed

Attribute Name: max-suppress-time

Attribute Type: uint32

Attribute Range: 1-255

Attribute Name: reach-half-life

Attribute Type: uint32

Attribute Range: 1-45

Attribute Name: reuse-penalty

Attribute Type: uint32

Attribute Range: 1-20000

Attribute Name: suppress-penalty

Attribute Type: uint32

Attribute Range: 1-20000

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <route-flap-dampenings>
            <route-flap-dampening>
              <enable-dampening>enable-dampening</enable-dampening>
              <config>
                <enable-dampening>enable-dampening</enable-dampening>
                <reach-half-life>1</reach-half-life> <!-- operation="delete"-->
                <reuse-penalty>1</reuse-penalty> <!-- operation="delete"-->
                <suppress-penalty>1</suppress-penalty> <!-- operation="delete"-->
              </config>
                <max-suppress-time>1</max-suppress-time> <!-- operation="delete"-->
            </route-flap-dampening>
          </route-flap-dampenings>
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp dampening <1-45> <1-20000> <1-20000> <1-255>
```

Configure reuse penalty

Use this attribute to configure the value to start suppressing a route for BGP route dampening. When the penalty for a route exceeds the suppress value, the route is suppressed

Attribute Name: max-suppress-time

Attribute Type: uint32

Attribute Range: 1-255

Attribute Name: reach-half-life

Attribute Type: uint32

Attribute Range: 1-45

Attribute Name: reuse-penalty

Attribute Type: uint32

Attribute Range: 1-20000

Attribute Name: suppress-penalty

Attribute Type: uint32

Attribute Range: 1-20000

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <route-flap-dampenings>
            <route-flap-dampening>
              <enable-dampening>enable-dampening</enable-dampening>
              <config>
                <enable-dampening>enable-dampening</enable-dampening>
                <reach-half-life>1</reach-half-life> <!-- operation="delete"-->
                <reuse-penalty>1</reuse-penalty> <!-- operation="delete"-->
                <suppress-penalty>1</suppress-penalty> <!-- operation="delete"-->
              </config>
              <max-suppress-time>1</max-suppress-time> <!-- operation="delete"-->
            </route-flap-dampening>
          </route-flap-dampenings>
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp dampening <1-45> <1-20000> <1-20000> <1-255>
```

Configure suppress penalty

Use this attribute to configure the value to start suppressing a route for BGP route dampening. When the penalty for a route exceeds the suppress value, the route is suppressed

Attribute Name: max-suppress-time

Attribute Type: uint32

Attribute Range: 1-255

Attribute Name: reach-half-life

Attribute Type: uint32

Attribute Range: 1-45

Attribute Name: reuse-penalty

Attribute Type: uint32

Attribute Range: 1-20000

Attribute Name: suppress-penalty

Attribute Type: uint32

Attribute Range: 1-20000

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <route-flap-dampenings>
            <route-flap-dampening>
              <enable-dampening>enable-dampening</enable-dampening>
              <config>
                <enable-dampening>enable-dampening</enable-dampening>
                <reach-half-life>1</reach-half-life> <!-- operation="delete"-->
                <reuse-penalty>1</reuse-penalty> <!-- operation="delete"-->
                <suppress-penalty>1</suppress-penalty> <!-- operation="delete"-->
              </config>
              <max-suppress-time>1</max-suppress-time> <!-- operation="delete"-->
            </route-flap-dampening>
          </route-flap-dampenings>
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

    </address-family>
  </address-families>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp dampening <1-45> <1-20000> <1-20000> <1-255>
```

Configure unreachable half life

Use this attribute to configure un-reachability half-life time for the penalty in minutes for bgp route dampening. The dampening information is purged from the router once the penalty becomes less than half of the reuse limit.

Attribute Name: unreachable-half-life

Attribute Type: uint32

Attribute Range: 1-45

Attribute Name: reach-half-life

Attribute Type: uint32

Attribute Range: 1-45

Attribute Name: reuse-penalty

Attribute Type: uint32

Attribute Range: 1-20000

Attribute Name: suppress-penalty

Attribute Type: uint32

Attribute Range: 1-20000

Attribute Name: max-suppress-time

Attribute Type: uint32

Attribute Range: 1-255

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```

    <afi>ipv4</afi>
  <route-flap-dampenings>
  <route-flap-dampening>
    <enable-dampening>enable-dampening</enable-dampening>
    <config>
      <enable-dampening>enable-dampening</enable-dampening>
      <reach-half-life>1</reach-half-life> <!-- operation="delete"-->
      <reuse-penalty>1</reuse-penalty> <!-- operation="delete"-->
      <suppress-penalty>1</suppress-penalty> <!-- operation="delete"-->
      <max-suppress-time>1</max-suppress-time> <!-- operation="delete"-->
    </config>
    <unreach-half-life>1</unreach-half-life> <!-- operation="delete"-->
  </route-flap-dampening>
</route-flap-dampenings>
</address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp dampening <1-45> <1-20000> <1-20000> <1-255> <1-45>
```

Configure dampening rmap name

Use this attribute to configure route map to specify criteria for dampening.

Attribute Name: dampening-rmap-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
        </address-family>
      </address-families>
      <route-flap-dampenings>
        <route-flap-dampening>
          <enable-dampening>enable-dampening</enable-dampening>
        </route-flap-dampening>
      </route-flap-dampenings>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```

    <config>
      <enable-dampening>enable-dampening</enable-dampening>
    </config>
    <dampening-rmap-name>WORD</dampening-rmap-name> <!--
operation="delete"-->
  </route-flap-dampening>
</route-flap-dampenings>
</address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp dampening route-map WORD
```

Configure protocol type

Use this attribute to inject routes from one routing process into another. Redistribution is used by routing protocols to advertise routes that are learned by some other means, such as by another routing protocol or by static routes. Since all internal routes are dumped into BGP, careful filtering is applied to make sure that only routes to be advertised reach the internet, not everything. This attribute allows redistribution by injecting prefixes from one routing protocol into another routing protocol.

Attribute Name: protocol-type

Attribute Type: enum (kernel|connected|static|rip|ospf|isis|connected-host-routes)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <route-redistribute-lists>
            <route-redistribute-list> <!-- operation="delete"-->
              <protocol-type>kernel</protocol-type>
              <config>
                <protocol-type>kernel</protocol-type>
              </config>
            </route-redistribute-list>
          </route-redistribute-lists>
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```
    </address-family>
  </address-families>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
redistribute (kernel|connected|static|rip|ospf|isis|connected-host-routes)
```

Configure redist route map name

Use this attribute to configure route map to be used for redistributed routes.

Attribute Name: redist-route-map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <route-redistribute-lists>
            <route-redistribute-list>
              <protocol-type>kernel</protocol-type>
              <config>
                <protocol-type>kernel</protocol-type>
              </config>
              <redist-route-map-name>WORD</redist-route-map-name> <!--
operation="delete"-->
            </route-redistribute-list>
          </route-redistribute-lists>
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>
```


Command Syntax

```
redistribute (kernel|connected|static|rip|ospf|isis|connected-host-routes) route-
map WORD
```

Configure afi

Use this attribute to start a BGP process.

Attribute Name: bgp-as

Attribute Type: uint32

Attribute Name: afi

Attribute Type: enum (ipv4|ipv6|vpn4|vpn6|rtfilter|l2vpn|link-state)

Attribute Name: safi

Attribute Type: enum (unicast|multicast|labeled-unicast|l2vpn-vpls|evpn|link-state|vpn-unicast|rtfilter-unicast|flowspec|flowspec-mpls-vpn)

Attribute Name: ospf-instance-number

Attribute Type: union

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
<bgp-instance> <!-- operation="delete"-->
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <address-families>
  <address-family>
    <afi>ipv4</afi>
    <safi>unicast</safi>
    <bgp-redistributes-ospf>
    <bgp-redistribute-ospf>
      <ospf-instance-number>""</ospf-instance-number>
    </bgp-redistribute-ospf>
    </bgp-redistributes-ospf>
  </address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
redistribute (ospf) (WORD|<1-65535>)
```

Configure redistribute ospf route map

Use this attribute to specify route map to redistribute routes from OSPF into BGP.

Attribute Name: redistribute-ospf-route-map

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <afi>ipv4</afi>
          <bgp-redistributes-ospf>
            <bgp-redistribute-ospf>
              <ospf-instance-number>""</ospf-instance-number>
              <config>
                <ospf-instance-number>""</ospf-instance-number>
              </config>
              <redistribute-ospf-route-map>WORD</redistribute-ospf-route-map> <!--
- operation="delete"-->
            </bgp-redistribute-ospf>
          </bgp-redistributes-ospf>
        </address-family>
      </address-families>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
redistribute (ospf) route-map WORD
```

Configure bgpSRv6enable

This attribute enable Segment Routing V6

Attribute Name: bgpSRv6enable

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
```

```

<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <address-families>
  <address-family>
    <safi>unicast</safi>
    <config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
  <bgp-srv6>
  <config>
    </bgpSRv6enable>
  </config>
</bgp-srv6>
</address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
segment-routing srv6
```

Configure bgpSRv6LocatorName

Locator name

Attribute Name: bgpSRv6LocatorName

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-families>
      <address-family>
        <safi>unicast</safi>
        <config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>
        <afi>ipv4</afi>
      </address-family>
    </address-families>
  </bgp-instance>
</bgp-instances>

```

```
<bgp-srv6>
  <locator> <!-- operation="delete"-->
    <bgpSRv6LocatorName>WORD</bgpSRv6LocatorName>
    <config>
      <bgpSRv6LocatorName>WORD</bgpSRv6LocatorName>
    </config>
  </locator>
</bgp-srv6>
</address-family>
</address-families>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
srv6-locator WORD
```

clear ip bgp (A.B.C.D|X:X::X:X|WORD) (description LINE|)

Attribute Name: arg

Attribute Type: union

Attribute Name: peer-reset-description

Attribute Type: string

Attribute Range: 1-255

Netconf RPC payload

```
<ipi-bgp-address-family_clear-ip-bgp-peer xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <arg>A.B.C.D|X:X::X:X</arg>
  <peer-reset-description>l</peer-reset-description>
</ipi-bgp-address-family_clear-ip-bgp-peer>
```

Command Syntax

```
clear ip bgp (A.B.C.D|X:X::X:X|WORD) (description LINE|)
```

IPI-BGP-PEER-GROUP

Configure optional as

Use this attribute to specify optional AS number of BGP dynamic peer-group

Attribute Name: optional-as

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      <optional-as-lists>
      <optional-as-list> <!-- operation="delete"-->
        <optional-as>1</optional-as>
        <config>
          <optional-as>1</optional-as>
        </config>
      </optional-as-list>
    </optional-as-lists>
    </peer-group>
  </peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD optional-as <1-4294967295>
```

Configure peer group tag

Creates a peer-group group. Neighbors with the same update policies are grouped into peer-group groups. This facilitates the updates of various policies, such as distribute and filter lists. The peer-group group is then configured easily with any of the neighbor attributes. Any changes made to the peer-group group affect all members.

Attribute Name: peer-group-tag

Attribute Type: string

Attribute Name: peer-group-range

Attribute Type: union

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
  </bgp-instance>
</bgp-instances>
</bgp>

```

```
</config>
<peer-groups>
<peer-group> <!-- operation="delete"-->
  <peer-group-tag>WORD</peer-group-tag>
  <config>
    <peer-group-tag>WORD</peer-group-tag>
    <peer-group-range>0</peer-group-range>
  </config>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD peer-group
```

Configure bgp as

Creates a peer-group group. Neighbors with the same update policies are grouped into peer-group groups. This facilitates the updates of various policies, such as distribute and filter lists. The peer-group group is then configured easily with any of the neighbor attributes. Any changes made to the peer-group group affect all members.

Attribute Name: peer-group-tag

Attribute Type: string

Attribute Name: peer-group-range

Attribute Type: union

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group> <!-- operation="delete"-->
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
        <peer-group-range>A.B.C.D/M</peer-group-range>
      </config>
    </peer-group>
  </peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD peer-group range A.B.C.D/M
```

Configure peer group range

Creates a peer-group group. Neighbors with the same update policies are grouped into peer-group groups. This facilitates the updates of various policies, such as distribute and filter lists. The peer-group group is then configured easily with any of the neighbor attributes. Any changes made to the peer-group group affect all members.

Attribute Name: peer-group-tag

Attribute Type: string

Attribute Name: peer-group-range

Attribute Type: union

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
      <peer-group> <!-- operation="delete"-->
        <peer-group-tag>WORD</peer-group-tag>
        <config>
          <peer-group-tag>WORD</peer-group-tag>
          <peer-group-range>X:X::X:X/M</peer-group-range>
        </config>
      </peer-group>
    </peer-groups>
  </bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD peer-group range X:X::X:X/M
```

Configure group limit

This attribute specifies maximum number of peer-groups in a dynamic peer-group

Attribute Name: group-limit

Attribute Type: uint8

Attribute Range: 1-200

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
```

```
<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <peer-groups>
  <peer-group>
    <peer-group-tag>WORD</peer-group-tag>
    <config>
      <peer-group-tag>WORD</peer-group-tag>
    </config>
    <group-limit>1</group-limit> <!-- operation="delete"-->
  </peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD limit <1-200>
```

Configure enable peer bfd

Enable bidirectional forwarding detection (BFD) for the BGP peer-group

Attribute Name: enable-peer-bfd

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
      <peer-group>
        <peer-group-tag>WORD</peer-group-tag>
        <config>
          <peer-group-tag>WORD</peer-group-tag>
        </config>
        </enable-peer-bfd><!-- operation="delete"-->
      </peer-group>
    </peer-groups>
  </bgp-instance>
</bgp-instances>
</bgp>
```


Command Syntax

```
neighbor WORD fall-over bfd
```

Configure enable peer bfd multihop

Enable bidirectional forwarding detection (BFD) for the BGP peer-group with multihop

Attribute Name: enable-peer-bfd-multihop

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          </enable-peer-bfd-multihop><!-- operation="delete"-->
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD fall-over bfd multihop
```

Configure auth key encrypt

Use this attribute to configure the authentication key to specify if the password is to be encrypted or not.

Attribute Name: auth-key-encrypt

Attribute Type: enum (0|1)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
    </peer-groups>
  </bgp-instances>
</bgp>
```

```
<peer-group>
  <peer-group-tag>WORD</peer-group-tag>
  <config>
    <peer-group-tag>WORD</peer-group-tag>
  </config>
  <bgp-passwords>
  <bgp-password>
    <password>WORD</password>
    <config>
      <password>WORD</password>
    </config>
    <auth-key-encrypt>1</auth-key-encrypt>
  </bgp-password>
</bgp-passwords>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD authentication-key (0|1) WORD
```

Configure password

Use this attribute to configure the authentication key to specify if the password is to be encrypted or not.

Attribute Name: auth-key-encrypt

Attribute Type: enum (0|1)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
      <peer-group>
        <peer-group-tag>WORD</peer-group-tag>
        <config>
          <peer-group-tag>WORD</peer-group-tag>
        </config>
        <bgp-passwords>
        <bgp-password>
          <password>WORD</password>
          <config>
            <password>WORD</password>
          </config>
        </bgp-password>
      </peer-group>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

        <auth-key-encrypt>2</auth-key-encrypt>
    </bgp-password>
</bgp-passwords>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD authentication-key WORD
```

Configure additional paths mode

Adds additional paths in the BGP table

Attribute Name: additional-paths-mode

Attribute Type: bits (send-receive|receive|send|disable)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
              <additional-paths-mode>send-receive</additional-paths-mode> <!--
operation="delete"-->
            </address-family>
          </address-families>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD additional-paths (send-receive|receive|send|disable)
```

Configure afi

Adds additional paths in the BGP table

Attribute Name: additional-paths-mode

Attribute Type: bits (send-receive|receive|send|disable)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
                <afi>ipv4</afi>
                <additional-paths-mode>send-receive</additional-paths-mode> <!--
operation="delete"-->
            </address-family>
          </address-families>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD additional-paths (send-receive|receive|send|disable)
```

Configure safi

Adds additional paths in the BGP table

Attribute Name: additional-paths-mode

Attribute Type: bits (send-receive|receive|send|disable)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
              <additional-paths-mode>send-receive</additional-paths-mode> <!--
operation="delete"-->
            </address-family>
          </address-families>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD additional-paths (send-receive|receive|send|disable)
```

Configure additional path select all

Attribute to select advertise additional path

Attribute Name: additional-path-select-all

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
```

```
    <bgp-as>1</bgp-as>
  </config>
  <peer-groups>
  <peer-group>
    <peer-group-tag>WORD</peer-group-tag>
    <config>
      <peer-group-tag>WORD</peer-group-tag>
    </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
        <afi>ipv4</afi>
        </additional-path-select-all><!-- operation="delete"-->
      </address-family>
    </address-families>
  </peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD advertise additional-paths all
```

Configure additional paths best select count

Attribute to select best advertise additional path

Attribute Name: additional-paths-best-select-count

Attribute Type: uint8

Attribute Range: 2-3

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
      <peer-group>
        <peer-group-tag>WORD</peer-group-tag>
        <config>
          <peer-group-tag>WORD</peer-group-tag>
        </config>
      </peer-group>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <afi>ipv4</afi>
      <additional-paths-best-select-count>2</additional-paths-best-
select-count> <!-- operation="delete"-->
    </address-family>
  </address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD advertise additional-paths best <2-3>
```

Configure bgp port

The BGP port number of a neighbor

Attribute Name: bgp-port

Attribute Type: uint16

Default Value: 179

Attribute Range: 0-65535

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>

```

```
        </config>
        <afi>ipv4</afi>
        <bgp-port>0</bgp-port> <!-- operation="delete"-->
    </address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD port <0-65535>
```

Configure activate

Activate/Deactivate neighbor. This attribute enables or disables the exchange of AF information with a neighboring router.

Attribute Name: activate

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
      <peer-group>
        <peer-group-tag>WORD</peer-group-tag>
        <config>
          <peer-group-tag>WORD</peer-group-tag>
        </config>
        <address-families>
          <address-family>
            <safi>unicast</safi>
            <config>
              <safi>unicast</safi>
              <afi>ipv4</afi>
            </config>
            <afi>ipv4</afi>
            </activate><!-- operation="delete"-->
          </address-family>
        </address-families>
      </peer-group>
    </peer-groups>
  </bgp-instance>
```



```

</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD activate
```

Configure default peer route map name

This attribute allows a BGP local router to send the default route 0.0.0.0 to a neighbor for use as a default route for specified address-family.

Attribute Name: default-peer-route-map-name

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      <address-families>
      <address-family>
        <safi>unicast</safi>
        <config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>
        <afi>ipv4</afi>
        </default-peer-route-map-name><!-- operation="delete"-->
      </address-family>
    </address-families>
  </peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD default-originate
```

Configure peer route map orig name

This attribute configures route map to be used for a BGP local router to send the default route 0.0.0.0 to a neighbor for use as a default route for specified address-family. This attribute can be used with standard or extended access lists.

Attribute Name: peer-route-map-orig-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
              <peer-route-map-orig-name>WORD</peer-route-map-orig-name> <!--
operation="delete"-->
            </address-family>
          </address-families>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD default-originate route-map WORD
```

Configure weight

This attribute specifies a weight value, for specified address-family, to all routes learned from a neighbor for specified address-family. The route with the highest weight gets preference when the same prefix is learned from more than one peer. Unlike the local-preference attribute, the weight attribute is relevant only to the local router. When the weight is set for a peer group, all members of the peer group get the same weight. This attribute can also be used to assign a

different weight to an individual peer-group member. When an individually-configured weight of a peer-group member is removed, its weight is reset to its peer groups weight.

Attribute Name: weight

Attribute Type: uint16

Default Value: 0

Attribute Range: 0-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
              <weight>0</weight> <!-- operation="delete"-->
            </address-family>
          </address-families>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD weight <0-65535>
```

Configure route server client

This attribute configures a neighbor as the route server client for specified address-family.

Attribute Name: route-server-client

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
              </route-server-client><!-- operation="delete"-->
            </address-family>
          </address-families>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD route-server-client
```

Configure next hop self

This attribute configure the router as the next hop for a BGP-speaking neighbor or peer-group group. This attribute allows a BGP router to change the nexthop information that is sent to the iBGP peer-group. The nexthop information is set to the IP address of the interface used to communicate with the neighbor.

Attribute Name: next-hop-self

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

</config>
<peer-groups>
<peer-group>
  <peer-group-tag>WORD</peer-group-tag>
  <config>
    <peer-group-tag>WORD</peer-group-tag>
  </config>
<address-families>
<address-family>
  <safi>unicast</safi>
  <config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  </config>
  <afi>ipv4</afi>
  </next-hop-self><!-- operation="delete" -->
</address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD next-hop-self
```

Configure flowspec validation disable

This attribute specifies if FLOWSPEC validation should be disabled for a BGP neighbor for specified address-family.

Attribute Name: flowspec-validation-disable

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
    <address-families>
    <address-family>

```

```
        <safi>unicast</safi>
    <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
    </config>
        <afi>ipv4</afi>
        </flowspec-validation-disable><!-- operation="delete"-->
    </address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD flowspec-validation-disable
```

Configure peer route reflector

This attribute configures the router as a BGP route reflector and configure the specified neighbor as its client for specified address-family. Route reflectors are a solution for the explosion of iBGP peering within an autonomous system. By route reflection the number of iBGP peers within an AS is reduced. Use this attribute to configure the local router as the route reflector and specify neighbors as its client. An AS can have more than one route reflector. One route reflector treats the other route reflector as another iBGP speaker.

Attribute Name: peer-route-reflector

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
```

```

        <afi>ipv4</afi>
        </peer-route-reflector><!-- operation="delete"-->
    </address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD route-reflector-client
```

Configure peer remove private as

This attribute removes the private Autonomous System (AS) number from outbound updates. Private AS numbers are not advertised to the Internet. This attribute is used with external BGP peers only. The router removes the AS numbers only if the update includes private AS numbers. If the update includes both private and public AS numbers, the system treats it as an error.

Attribute Name: peer-remove-private-as

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
              </peer-remove-private-as><!-- operation="delete"-->
            </address-family>
          </address-families>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```
</bgp-instance>  
</bgp-instances>  
</bgp>
```

Command Syntax

```
neighbor WORD remove-private-AS
```

Configure no send community

This attribute specifies if a community attribute should be sent to a BGP neighbor for specified address-family. The community attribute groups destinations in a certain community and applies routing decisions according to those communities. By default, both standard and extended community attributes are sent to a neighbor

Attribute Name: no-send-community

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">  
<bgp-instances>  
  <bgp-instance>  
    <bgp-as>1</bgp-as>  
    <config>  
      <bgp-as>1</bgp-as>  
    </config>  
    <peer-groups>  
    <peer-group>  
      <peer-group-tag>WORD</peer-group-tag>  
      <config>  
        <peer-group-tag>WORD</peer-group-tag>  
      </config>  
      <address-families>  
      <address-family>  
        <safi>unicast</safi>  
        <config>  
          <safi>unicast</safi>  
          <afi>ipv4</afi>  
        </config>  
        <afi>ipv4</afi>  
        </no-send-community><!-- operation="delete" -->  
      </address-family>  
    </address-families>  
  </peer-group>  
</peer-groups>  
</bgp-instance>  
</bgp-instances>  
</bgp>
```

Command Syntax

```
no neighbor WORD send-community
```

Configure no send community type

This attribute specifies the type of community attribute to be sent to a BGP neighbor.

Attribute Name: no-send-community-type

Attribute Type: bits (both|standard|extended|large)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
              <no-send-community-type>both</no-send-community-type> <!--
operation="delete"-->
            </address-family>
          </address-families>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
no neighbor WORD send-community (both|standard|extended|large)
```

Configure neighbor attribute unchanged

This attribute advertises unchanged BGP AS path, next hop and med to the specified neighbor.

Attribute Name: neighbor-attribute-unchanged

Attribute Type: bits (as-path|next-hop|med)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
              <neighbor-attribute-unchanged>14</neighbor-attribute-unchanged> <!--
- operation="delete"-->
            </address-family>
          </address-families>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD attribute-unchanged
```

Configure orf prefix capability

This attribute enables Outbound Router Filtering (ORF), and advertise the ORF capability to its neighbors. The ORFs send and receive capabilities to lessen the number of updates exchanged between neighbors. By filtering updates, this option minimizes generating and processing of updates. The two routers exchange updates to maintain the ORF for each router.

Attribute Name: orf-prefix-capability

Attribute Type: bits (both|receive|send)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
```

```

<config>
  <bgp-as>1</bgp-as>
</config>
<peer-groups>
<peer-group>
  <peer-group-tag>WORD</peer-group-tag>
  <config>
    <peer-group-tag>WORD</peer-group-tag>
  </config>
  <address-families>
  <address-family>
    <safi>unicast</safi>
    <config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
    <orf-prefix-capability>both</orf-prefix-capability> <!--
operation="delete"-->
  </address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD capability orf prefix-list (both|receive|send)
```

Configure peer allow ebgp vpn

This attribute allows an eBGP neighbor to be a VPN peer. By default, BGP VPN functionality is allowed only for iBGP peers. Using the peer-allow-ebgp-vpn attribute allows the VPN connection to be established to an eBGP peer.

Attribute Name: peer-allow-ebgp-vpn

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
    <config>

```

```

        <peer-group-tag>WORD</peer-group-tag>
    </config>
    <address-families>
    <address-family>
        <safi>unicast</safi>
        <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
        </config>
        <afi>ipv4</afi>
        </peer-allow-ebgp-vpn><!-- operation="delete"-->
    </address-family>
    </address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD allow-ebgp-vpn
```

Configure allow as number

This attribute advertises prefixes (routes) even when the source of the prefixes is from the same Autonomous System (AS) number for specified address-family. Use this attribute in a scenario where two routers at different locations use the same Autonomous System number and are connected via an ISP. Once prefixes arrive from one branch at the ISP, they are tagged with the customers AS number. By default, when the ISP passes the prefixes to the other router, the prefixes are dropped if the other router uses the same AS number. Use this attribute to advertise the prefixes at the other side. Control the number of times an AS number is advertised by specifying a number. In a hub and spoke configuration in a VPN, a PE (Provider Edge) router advertises all prefixes containing duplicate AS numbers. Use this attribute to configure two VRFs on each PE router to receive and advertise prefixes. One of the VRFs receives prefixes with AS numbers from all PE routers and then advertises them to neighboring PE routers. The other VRF receives prefixes with AS numbers from the CE (Customer Edge) router and advertises them to all PE routers in the hub and spoke configuration.

Attribute Name: allow-as-number

Attribute Type: uint32

Default Value: 3

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
      <peer-group>

```

```

    <peer-group-tag>WORD</peer-group-tag>
  <config>
    <peer-group-tag>WORD</peer-group-tag>
  </config>
  <address-families>
  <address-family>
    <safi>unicast</safi>
    <config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
    <allow-as-number>1</allow-as-number> <!-- operation="delete"-->
  </address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD allowas-in <1-10>
```

Configure capability graceful restart

This attribute configures the router to advertise the Graceful Restart Capability to the neighbors. This configuration indicates that the BGP speaker has the ability to preserve its forwarding state for the address family when BGP restarts. Use this attribute to advertise to the neighbor routers the capability of graceful restart.

Attribute Name: capability-graceful-restart

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
      <peer-group>
        <peer-group-tag>WORD</peer-group-tag>
        <config>
          <peer-group-tag>WORD</peer-group-tag>
        </config>
      <address-families>
      <address-family>
        <safi>unicast</safi>

```

```
    <config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
  </capability-graceful-restart><!-- operation="delete"-->
</address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD capability graceful-restart
```

Configure prefix count

Use this attribute to specify maximum number of prefixes that can be received from a neighbor

Attribute Name: prefix-count

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
                <afi>ipv4</afi>
              <maximum-prefixes>
                <maximum-prefix> <!-- operation="delete"-->
                  <prefix-count>1</prefix-count>
                </maximum-prefix>
              </maximum-prefixes>
            </address-family>
          </address-families>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

        <config>
            <prefix-count>1</prefix-count>
        </config>
    </maximum-prefix>
</maximum-prefixes>
</address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD maximum-prefix <1-4294967295>
```

Configure stop update

Stop installing the routes when limit is exceeded.

Attribute Name: stop-update

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      <address-families>
      <address-family>
        <safi>unicast</safi>
        <config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>
        <afi>ipv4</afi>
      <maximum-prefixes>
      <maximum-prefix>
        <prefix-count>1</prefix-count>
      <config>
        <prefix-count>1</prefix-count>

```

```
        </config>
        </stop-update>
    </maximum-prefix>
</maximum-prefixes>
</address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD maximum-prefix <1-4294967295> stop-update
```

Configure maximum prefix warning

This attribute when enabled only give warning message when limit is exceeded. When it is not set and extra prefixes are received, the router ends the peering.

Attribute Name: maximum-prefix-warning

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <afi>ipv4</afi>
    <maximum-prefixes>
    <maximum-prefix>
      <prefix-count>1</prefix-count>
      <config>
        <prefix-count>1</prefix-count>
```



```

        </config>
        </maximum-prefix-warning>
    </maximum-prefix>
</maximum-prefixes>
</address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD maximum-prefix <1-4294967295> warning-only
```

Configure threshold percentage

Threshold-value in percen. This attribute controls the number of prefixes that can be received from a neighbor. This attribute allows the configuration of a specified number of prefixes that a BGP router is allowed to receive from a neighbor. When the maximum-prefix-warning attribute is not set and extra prefixes are received, the router ends the peering.

Attribute Name: threshold-percentage

Attribute Type: uint8

Default Value: 75

Attribute Range: 1-100

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      <address-families>
      <address-family>
        <safi>unicast</safi>
        <config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>
        <afi>ipv4</afi>
      </address-family>
    </address-families>
  </peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>

```

```
        <maximum-prefix>
          <prefix-count>1</prefix-count>
          <config>
            <prefix-count>1</prefix-count>
          </config>
          <threshold-percentage>1</threshold-percentage>
        </maximum-prefix>
      </maximum-prefixes>
    </address-family>
  </address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD maximum-prefix <1-4294967295> <1-100>
```

Configure warning only

Throw warning if exceeds threshold-value

Attribute Name: warning-only

Attribute Type: uint8

Attribute Name: threshold-percentage

Attribute Type: uint8

Default Value: 75

Attribute Range: 1-100

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
        </peer-group>
      </peer-groups>
      <address-families>
        <address-family>
          <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
```

```

        <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
    <maximum-prefixes>
    <maximum-prefix>
        <prefix-count>1</prefix-count>
    <config>
        <prefix-count>1</prefix-count>
        <threshold-percentage>1</threshold-percentage>
    </config>
    </warning-only>
    </maximum-prefix>
    </maximum-prefixes>
</address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD maximum-prefix <1-4294967295> <1-100> warning-only
```

Configure unsuppress route map name

unsuppress map name. This attribute is used to selectively leak more-specific routes to a particular neighbor.

Attribute Name: unsuppress-route-map-name

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
        <address-families>
          <address-family>
            <safi>unicast</safi>
          <config>
            <safi>unicast</safi>
          </config>
        </address-family>
      </peer-group>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```
        <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
    <unsuppress-route-map-name>WORD</unsuppress-route-map-name> <!--
operation="delete"-->
    </address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD unsuppress-map WORD
```

Configure access list identifier

Access List information

Attribute Name: access-list-identifier

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
            </address-family>
          </address-families>
          <distribute-list-filters>
            <distribute-list-filter>
              <filter-direction>in</filter-direction>
            </distribute-list-filter>
          </distribute-list-filters>
          <config>
            <filter-direction>in</filter-direction>
          </config>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

        </config>
        <access-list-identifier>WORD</access-list-identifier>
    </distribute-list-filter>
</distribute-list-filters>
</address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD distribute-list WORD (in|out)
```

Configure filter direction

Access List information

Attribute Name: access-list-identifier

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      <address-families>
      <address-family>
        <safi>unicast</safi>
        <config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>
        <afi>ipv4</afi>
      <distribute-list-filters>
      <distribute-list-filter>
        <filter-direction>in</filter-direction>
        <config>
          <filter-direction>in</filter-direction>
        </config>
      </distribute-list-filter>
    </peer-group>
    </peer-groups>
  </bgp-instance>
</bgp-instances>
</bgp>

```

```
        <access-list-identifier>WORD</access-list-identifier>
    </distribute-list-filter>
</distribute-list-filters>
</address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD distribute-list WORD (in|out)
```

Configure safi

Use this attribute to start a BGP process.

Attribute Name: bgp-as

Attribute Type: uint32

Attribute Name: afi

Attribute Type: enum (ipv4|ipv6|vpn4|vpn6|rtfilter|l2vpn|link-state)

Attribute Name: safi

Attribute Type: enum (unicast|multicast|labeled-unicast|l2vpn-vpls|evpn|link-state|vpn-unicast|rtfilter-unicast|flowspec|flowspec-mpls-vpn)

Attribute Name: peer-group-tag

Attribute Type: string

Attribute Range: 1-255

Attribute Name: prefix-list-name

Attribute Type: string

Attribute Name: prefix-filter-direction

Attribute Type: enum (in|out)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
<bgp-instance> <!-- operation="delete"-->
    <bgp-as>1</bgp-as>
    <config>
        <bgp-as>1</bgp-as>
    </config>
<peer-groups>
<peer-group>
<address-families>
<address-family>
    <afi>ipv4</afi>
```

```

    <safi>unicast</safi>
    <peer-group-tag>WORD</peer-group-tag>
    <prefix-list-filters>
    <prefix-list-filter>
    <config>
        <prefix-list-name>WORD</prefix-list-name>
        <prefix-filter-direction>in</prefix-filter-direction>
    </config>
    </prefix-list-filter>
    </prefix-list-filters>
</address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD prefix-list WORD (in|out)
```

Configure as access list identifier

Access-list number. This attribute sets a BGP filter. This attribute specifies an access list filter on updates based on the BGP autonomous system paths. Each filter is an access list based on regular expressions

Attribute Name: as-access-list-identifier

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
    </peer-group>
    </peer-groups>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
    </address-family>
    </address-families>
  </bgp-instance>
</bgp-instances>
</bgp>

```

```
        <afi>ipv4</afi>
    <as-list-filters>
    <as-list-filter>
        <as-list-direction>in</as-list-direction>
        <config>
            <as-list-direction>in</as-list-direction>
        </config>
        <as-access-list-identifier>WORD</as-access-list-identifier>
    </as-list-filter>
</as-list-filters>
</address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD filter-list WORD (in|out)
```

Configure as list direction

Access-list number. This attribute sets a BGP filter. This attribute specifies an access list filter on updates based on the BGP autonomous system paths. Each filter is an access list based on regular expressions

Attribute Name: as-access-list-identifier

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
    </peer-group>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
    </address-family>
  </bgp-instance>
</bgp-instances>
</bgp>
```



```

        <afi>ipv4</afi>
    <as-list-filters>
    <as-list-filter>
        <as-list-direction>in</as-list-direction>
        <config>
            <as-list-direction>in</as-list-direction>
        </config>
        <as-access-list-identifier>WORD</as-access-list-identifier>
    </as-list-filter>
</as-list-filters>
</address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD filter-list WORD (in|out)
```

Configure route map name

Use this attribute to apply a route map to incoming or outgoing routes. This attribute filters updates and modifies attributes. A route map is applied to inbound or outbound updates. Only the routes that pass the route map are sent or accepted in updates.

Attribute Name: route-map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>

```

```
        <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
    <route-map-filters>
    <route-map-filter>
        <route-map-direction>in</route-map-direction>
        <config>
            <route-map-direction>in</route-map-direction>
        </config>
        <route-map-name>WORD</route-map-name>
    </route-map-filter>
</route-map-filters>
</address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD route-map WORD (in|out)
```

Configure route map direction

Use this attribute to apply a route map to incoming or outgoing routes. This attribute filters updates and modifies attributes. A route map is applied to inbound or outbound updates. Only the routes that pass the route map are sent or accepted in updates.

Attribute Name: route-map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
```

```

    <config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
  <route-map-filters>
  <route-map-filter>
    <route-map-direction>in</route-map-direction>
    <config>
      <route-map-direction>in</route-map-direction>
    </config>
    <route-map-name>WORD</route-map-name>
  </route-map-filter>
</route-map-filters>
</address-family>
</address-families>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD route-map WORD (in|out)
```

Configure peer as

Autonomous system number of a neighbor. If the specified ASN matches the ASN number specified in the router bgp global configuration, the neighbor is identified as internal. If the ASN does no match, it is identified as external to the local AS.

Attribute Name: peer-as

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
        <peer-as>1</peer-as> <!-- operation="delete"-->

```

```
    </peer-group>
  </peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD remote-as <1-4294967295>
```

Configure graceful shut

Use this attribute to start a graceful shutdown for the BGP session of the specified BGP neighbor. The BGP session for this neighbor is shut down after the graceful shutdown timer expires. If there is no alternate path available for traffic to flow prior the actual shutdown of the BGP session, this path is made available for 60 seconds or for configured time after which the path is no longer available and traffic is dropped.

Attribute Name: graceful-shut

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          </graceful-shut><!-- operation="delete"-->
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD g-shut
```

Configure graceful shutdown timer

Configure the value of the graceful shutdown timer. After the timer expires, the BGP session initiated for graceful shutdown is shut down.

Attribute Name: graceful-shutdown-timer

Attribute Type: uint32

Attribute Range: 10-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <graceful-shutdown-timer>10</graceful-shutdown-timer> <!--
operation="delete"-->
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD g-shut-timer <10-65535>
```

Configure peer restart time

Sets a different restart-time other than the global restart-time. This attribute takes precedence over the restart-time value specified using the grstSet attribute. The restart-time value is the maximum time that a graceful-restart neighbor waits to come back up after a restart. The default value is 120 seconds.

Attribute Name: peer-restart-time

Attribute Type: uint32

Attribute Range: 1-3600

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```
        </config>
        <peer-restart-time>1</peer-restart-time> <!-- operation="delete"-->
    </peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD restart-time <1-3600>
```

Configure peer description

Associates a description with a neighbor. This helps in identifying a neighbor quickly. It is useful for an ISP that has multiple neighbor relationships.

Attribute Name: peer-description

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <peer-description>LINE</peer-description> <!-- operation="delete"-->
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD description LINE
```

Configure peer connect interval

This attribute sets the timers for a specific BGP neighbor. Keepalive messages are sent by a router to inform another router that the BGP connection between the two is still active. The keepalive interval is the period of time between each keepalive message sent by the router. The holdtime interval is the time the router waits to receive a keepalive message and if it does not receive a message for this period it declares the neighbor dead.

Attribute Name: peer-connect-interval

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <peer-connect-interval>1</peer-connect-interval> <!--
operation="delete"-->
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD timers connect <1-65535>
```

Configure peer as origin interval

Configures the minimum interval between the sending of AS-origination routing updates.

Attribute Name: peer-as-origin-interval

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
```

```
        <config>
          <peer-group-tag>WORD</peer-group-tag>
        </config>
        <peer-as-origin-interval>1</peer-as-origin-interval> <!--
operation="delete"-->
      </peer-group>
    </peer-groups>
  </bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD as-origination-interval <1-65535>
```

Configure min route advertisement interval

Sets a minimum route advertisement interval between the sending of BGP routing updates. To reduce the flapping of routes to internet, a minimum advertisement interval is set, so that the BGP routing updates are sent only per interval seconds.

Attribute Name: min-route-advertisement-interval

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <min-route-advertisement-interval>0</min-route-advertisement-interval>
        <!-- operation="delete"-->
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD advertisement-interval <0-65535>
```

Configure enable dynamic capability

Use this attribute to enable the dynamic capability for a specific peer-group. This attribute allows a BGP speaker to advertise or withdraw an address family capability to a peer-group in a non-disruptive manner.

Attribute Name: enable-dynamic-capability

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          </enable-dynamic-capability><!-- operation="delete"-->
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD capability dynamic
```

Configure collide established

Include a neighbor already in an established state for conflict resolution when a TCP connection collision is detected.

Attribute Name: collide-established

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
```

```
<config>
  <peer-group-tag>WORD</peer-group-tag>
</config>
  </collide-established><!-- operation="delete"-->
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD collide-established
```

Configure source identifier

Allows internal BGP sessions to use any operational interface for TCP connections. This attribute can be used in conjunction with any specified interface on the router. The loopback interface is the interface that is most commonly used with this attribute. The use of loopback interface eliminates a dependency and BGP does not have to rely on the availability of a particular interface for making TCP connections.

Attribute Name: source-identifier

Attribute Type: string

Default Value: NULL

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      <source-identifier>WORD</source-identifier> <!-- operation="delete"-->
    </peer-group>
  </peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD update-source WORD
```

Configure enforce multi hop

Turns on the enforcement of eBGP neighbors perform multihop.

Attribute Name: enforce-multi-hop

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          </enforce-multi-hop><!-- operation="delete"-->
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD enforce-multihop
```

Configure neighbor override capability

Override a capability negotiation result and use locally configured values.

Attribute Name: neighbor-override-capability

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
```

```
        <peer-group-tag>WORD</peer-group-tag>
    </config>
    </neighbor-override-capability><!-- operation="delete"-->
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD override-capability
```

Configure neighbor strict capability match

Close the BGP connection if capability value does not match the remote peer-group.

Attribute Name: neighbor-strict-capability-match

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          </neighbor-strict-capability-match><!-- operation="delete"-->
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD strict-capability-match
```

Configure disallow infinite hold time

Disallow configuration of infinite hold-time. A hold-time of 0 seconds from the peer-group (during exchange of open messages) or the user (during configuration) will be rejected.

Attribute Name: disallow-infinite-hold-time

Attribute Type: empty

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      </disallow-infinite-hold-time><!-- operation="delete"-->
    </peer-group>
  </peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD disallow-infinite-holdtime
```

Configure disable capability negotiation

Disable the capability negotiation. It allows compatibility with older BGP versions that have no capability parameters used in open messages between peer-groups.

Attribute Name: disable-capability-negotiation

Attribute Type: empty

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      </disable-capability-negotiation><!-- operation="delete"-->
    </peer-group>
  </peer-groups>
</bgp-instance>

```

```
</bgp-instances>  
</bgp>
```

Command Syntax

```
neighbor WORD dont-capability-negotiate
```

Configure neighbor passive

Sets a BGP neighbor as passive.

Attribute Name: neighbor-passive

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">  
<bgp-instances>  
  <bgp-instance>  
    <bgp-as>1</bgp-as>  
    <config>  
      <bgp-as>1</bgp-as>  
    </config>  
    <peer-groups>  
    <peer-group>  
      <peer-group-tag>WORD</peer-group-tag>  
      <config>  
        <peer-group-tag>WORD</peer-group-tag>  
      </config>  
      </neighbor-passive><!-- operation="delete"-->  
    </peer-group>  
  </peer-groups>  
</bgp-instance>  
</bgp-instances>  
</bgp>
```

Command Syntax

```
neighbor WORD passive
```

Configure peer shutdown description

Use this attribute to send shutdown communication message to inform peer the reason for the shutdown of the BGP session.

Attribute Name: peer-shutdown-description

Attribute Type: string

Attribute Range: 1-255

Attribute Name: peer-shutdown

Attribute Type: empty

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
        </peer-shutdown><!-- operation="delete"-->
      </config>
      <peer-shutdown-description>1</peer-shutdown-description> <!--
operation="delete"-->
    </peer-group>
  </peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD shutdown (description LINE|)
```

Configure peer port

Sets the BGP port number of a neighbor.

Attribute Name: peer-port

Attribute Type: uint16

Default Value: 179

Attribute Range: 0-65535

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
    </peer-group>
  </peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

```
        <peer-port>0</peer-port> <!-- operation="delete"-->
    </peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD port <0-65535>
```

Configure bgp version

Configure router to accept only a particular BGP version. By default, the system uses BGP version 4 and on request dynamically negotiates down to version 2. Disables the routers version-negotiation capability and forces the router to use only a specified version with the neighbor.

Attribute Name: bgp-version

Attribute Type: uint8

Default Value: 4

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <bgp-version>(4)</bgp-version> <!-- operation="delete"-->
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD version (4)
```

Configure enable ext opt param len

Use this attribute for a specific peer to encode extended optional parameter length.

Attribute Name: enable-ext-opt-param-len

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      </enable-ext-opt-param-len><!-- operation="delete"-->
    </peer-group>
  </peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD extended-optional-param
```

Configure tcp adjust mss

Use this attribute to set the BGP TCP MSS value of a neighbor.

Attribute Name: tcp-adjust-mss

Attribute Type: uint16

Attribute Range: 40-1440

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
        <tcp-adjust-mss>40</tcp-adjust-mss> <!-- operation="delete"-->
      </config>
    </peer-group>
  </peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

```
</bgp-instance>  
</bgp-instances>  
</bgp>
```

Command Syntax

```
neighbor WORD tcp-mss <40-1440>
```

Configure keep alive

Use this attribute to globally set or reset the keepalive values for all the neighbors

Attribute Name: keep-alive

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: hold-time

Attribute Type: uint16

Attribute Range: 0-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">  
<bgp-instances>  
  <bgp-instance>  
    <bgp-as>1</bgp-as>  
    <config>  
      <bgp-as>1</bgp-as>  
    </config>  
    <peer-groups>  
    <peer-group>  
      <peer-group-tag>WORD</peer-group-tag>  
      <config>  
        <peer-group-tag>WORD</peer-group-tag>  
      </config>  
      <timers>  
      <config>  
        <hold-time>0</hold-time>  
        <keep-alive>0</keep-alive>  
      </config>  
    </timers>  
  </peer-group>  
</peer-groups>  
</bgp-instance>  
</bgp-instances>  
</bgp>
```

Command Syntax

```
neighbor WORD timers <0-65535> <0-65535>
```

Configure enabled

Use this attribute to accept and attempt BGP connections to external peers on indirectly connected networks. Multihop is not established if the only route to the multihop peer is a default route. This avoids loop formation.

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <ebgp-multihop>
            <config>
              </enabled>
            </config>
          </ebgp-multihop>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD ebgp-multihop
```

Configure maximum hop count

Use this attribute to accept and attempt BGP connections to external peers on indirectly connected networks. Multihop is not established if the only route to the multihop peer is a default route. This avoids loop formation.

Attribute Name: enabled

Attribute Type: empty

Attribute Name: maximum-hop-count

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
```

```
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      <ebgp-multihop>
      <config>
        <maximum-hop-count>1</maximum-hop-count> <!-- operation="delete"-->
        </enabled><!-- operation="delete"-->
      </config>
    </ebgp-multihop>
  </peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD ebgp-multihop <1-255>
```

Configure peer local as

Specifies an AS (autonomous system) number to use with BGP neighbor.

Attribute Name: peer-local-as

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
      <peer-group>
        <peer-group-tag>WORD</peer-group-tag>
        <config>
          <peer-group-tag>WORD</peer-group-tag>
        </config>
      <local-as>
```

```

        <local-as-list> <!-- operation="delete"-->
            <peer-local-as>1</peer-local-as>
        </local-as-list>
    </local-as>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD local-as <1-4294967295>
```

Configure no prepend local as

Specifies an AS (autonomous system) number to use with BGP neighbor.

Attribute Name: peer-local-as

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: no-prepend-local-as

Attribute Type: empty

Attribute Name: replace-local-as

Attribute Type: empty

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <local-as>
            <local-as-list>
              <peer-local-as>1</peer-local-as>
            </local-as-list>
            <config>
              <peer-local-as>1</peer-local-as>
              </no-prepend-local-as>
            </config>
          </local-as>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```
        </replace-local-as>
    </config>
</local-as-list>
</local-as>
</peer-group>
</peer-groups>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD local-as <1-4294967295> (no-prepend|) (replace-as|)
```

clear bgp peer-group WORD l2vpn evpn soft (out|in|)

Attribute Name: peer-group-tag

Attribute Type: string

Attribute Range: 1-255

Attribute Name: soft-reconfig

Attribute Type: enum (out|in|soft-only)

Netconf RPC payload

```
<ipi-bgp-peer-group_clear-peer-group-l2vpn-evpn-soft-all xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <peer-group-tag>WORD</peer-group-tag>
  <soft-reconfig>soft-only</soft-reconfig>
</ipi-bgp-peer-group_clear-peer-group-l2vpn-evpn-soft-all>
```

Command Syntax

```
clear bgp peer-group WORD l2vpn evpn soft (out|in|)
```

IPI-BGP-PEER

Configure enable peer bfd

Enable bidirectional forwarding detection (BFD) for the BGP peer

Attribute Name: enable-peer-bfd

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

    <bgp-as>1</bgp-as>
  </config>
  <peers>
  <peer>
    <peer-address>A.B.C.D|X:X::X:X</peer-address>
    <config>
      <peer-address>BGP_IP_ADDR_T</peer-address>
    </config>
    </enable-peer-bfd><!-- operation="delete"-->
  </peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) fall-over bfd
```

Configure bgp as

Enable bidirectional forwarding detection (BFD) for the BGP peer

Attribute Name: enable-peer-bfd

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
      <peer>
        <peer-address>A.B.C.D|X:X::X:X</peer-address>
        <config>
          <peer-address>BGP_IP_ADDR_T</peer-address>
        </config>
        </enable-peer-bfd><!-- operation="delete"-->
      </peer>
    </peers>
  </bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD fall-over bfd
```

Configure enable peer bfd multihop

Enable bidirectional forwarding detection (BFD) for the BGP peer with multihop

Attribute Name: enable-peer-bfd-multihop

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          </enable-peer-bfd-multihop><!-- operation="delete"-->
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) fall-over bfd multihop
```

Configure peer address

Enable bidirectional forwarding detection (BFD) for the BGP peer with multihop

Attribute Name: enable-peer-bfd-multihop

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
```



```

        <peer-address>BGP_IP_ADDR_T</peer-address>
    </config>
    </enable-peer-bfd-multihop><!-- operation="delete"-->
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD fall-over bfd multihop
```

Configure interface name

Configure the interface name of a BGP neighbor.

Attribute Name: interface-name

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <interface-name>WORD</interface-name> <!-- operation="delete"-->
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) interface WORD
```

Configure mapped peer group tag

Adds a neighbor to an existing peer group. Neighbors with the same update policies are grouped into peer groups. This facilitates the updates of various policies, such as distribute and filter lists. The peer group is then configured easily with any of the neighbor attributes. Any changes made to the peer group affect all members.

Attribute Name: mapped-peer-group-tag

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <mapped-peer-group-tag>WORD</mapped-peer-group-tag> <!--
operation="delete"-->
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) peer-group WORD
```

Configure tcp adjust mss

Use this attribute to set the BGP TCP MSS value of a neighbor.

Attribute Name: tcp-adjust-mss

Attribute Type: uint16

Attribute Range: 40-1440

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
            <tcp-adjust-mss>40</tcp-adjust-mss> <!-- operation="delete"-->
          </config>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

    </peer>
  </peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD tcp-mss <40-1440>
```

Configure auth key encrypt

Use this attribute to configure the authentication key to specify if the password is to be encrypted or not.

Attribute Name: auth-key-encrypt

Attribute Type: enum (0|1)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <bgp-passwords>
            <bgp-password>
              <password>WORD</password>
              <config>
                <password>WORD</password>
              </config>
              <auth-key-encrypt>1</auth-key-encrypt>
            </bgp-password>
          </bgp-passwords>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) authentication-key (0|1) WORD
```

Configure password

Use this attribute to configure the authentication key to specify if the password is to be encrypted or not.

Attribute Name: auth-key-encrypt

Attribute Type: enum (0|1)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <bgp-passwords>
            <bgp-password>
              <password>WORD</password>
              <config>
                <password>WORD</password>
              </config>
              <auth-key-encrypt>2</auth-key-encrypt>
            </bgp-password>
          </bgp-passwords>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) authentication-key WORD
```

Configure additional paths mode

Adds additional paths in the BGP table

Attribute Name: additional-paths-mode

Attribute Type: bits (send-receive|receive|send|disable)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
```

```

    <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <peers>
  <peer>
    <peer-address>A.B.C.D|X:X::X:X</peer-address>
    <config>
      <peer-address>BGP_IP_ADDR_T</peer-address>
    </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <afi>ipv4</afi>
      <additional-paths-mode>send-receive</additional-paths-mode> <!--
operation="delete"-->
    </address-family>
  </address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) additional-paths (send-receive|receive|send|disable)
```

Configure afi

Adds additional paths in the BGP table

Attribute Name: additional-paths-mode

Attribute Type: bits (send-receive|receive|send|disable)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
      <peer>
        <peer-address>A.B.C.D|X:X::X:X</peer-address>
        <config>

```

```
        <peer-address>BGP_IP_ADDR_T</peer-address>
    </config>
    <address-families>
    <address-family>
        <safi>unicast</safi>
        <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
        </config>
        <afi>ipv4</afi>
        <additional-paths-mode>send-receive</additional-paths-mode> <!--
operation="delete"-->
    </address-family>
    </address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) additional-paths (send-receive|receive|send|disable)
```

Configure safi

Adds additional paths in the BGP table

Attribute Name: additional-paths-mode

Attribute Type: bits (send-receive|receive|send|disable)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
```

```

        </config>
        <afi>ipv4</afi>
        <additional-paths-mode>send-receive</additional-paths-mode> <!--
operation="delete"-->
        </address-family>
    </address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) additional-paths (send-receive|receive|send|disable)
```

Configure additional path select all

Attribute to select advertise additional path

Attribute Name: additional-path-select-all

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
      <address-families>
      <address-family>
        <safi>unicast</safi>
        <config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>
          <afi>ipv4</afi>
          </additional-path-select-all><!-- operation="delete"-->
        </address-family>
      </address-families>
    </peer>
  </peers>
</bgp-instance>

```

```
</bgp-instances>  
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) advertise additional-paths all
```

Configure additional paths best select count

Attribute to select best advertise additional path

Attribute Name: additional-paths-best-select-count

Attribute Type: uint8

Attribute Range: 2-3

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">  
<bgp-instances>  
  <bgp-instance>  
    <bgp-as>1</bgp-as>  
    <config>  
      <bgp-as>1</bgp-as>  
    </config>  
    <peers>  
    <peer>  
      <peer-address>A.B.C.D|X:X::X:X</peer-address>  
      <config>  
        <peer-address>BGP_IP_ADDR_T</peer-address>  
      </config>  
      <address-families>  
      <address-family>  
        <safi>unicast</safi>  
        <config>  
          <safi>unicast</safi>  
          <afi>ipv4</afi>  
        </config>  
        <afi>ipv4</afi>  
        <additional-paths-best-select-count>2</additional-paths-best-  
select-count> <!-- operation="delete"-->  
      </address-family>  
    </address-families>  
  </peer>  
</peers>  
</bgp-instance>  
</bgp-instances>  
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) advertise additional-paths best <2-3>
```

Configure bgp port

The BGP port number of a neighbor

Attribute Name: bgp-port

Attribute Type: uint16

Default Value: 179

Attribute Range: 0-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
              <bgp-port>0</bgp-port> <!-- operation="delete"-->
            </address-family>
          </address-families>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) port <0-65535>
```

Configure activate

Activate/Deactivate neighbor. This attribute enables or disables the exchange of AF information with a neighboring router.

Attribute Name: activate

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
                <afi>ipv4</afi>
                </activate><!-- operation="delete"-->
            </address-family>
          </address-families>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) activate
```

Configure de activate

Deactivate neighbor. This attribute disables the exchange of AF information with a neighboring router.

Attribute Name: de-activate

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

</config>
<peers>
<peer>
  <peer-address>A.B.C.D|X:X::X:X</peer-address>
  <config>
    <peer-address>BGP_IP_ADDR_T</peer-address>
  </config>
  <address-families>
  <address-family>
    <safi>unicast</safi>
    <config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
    </de-activate><!-- operation="delete"-->
  </address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) de-activate
```

Configure default peer route map name

This attribute allows a BGP local router to send the default route 0.0.0.0 to a neighbor for use as a default route for specified address-family.

Attribute Name: default-peer-route-map-name

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
    </address-families>
  </bgp-instance>
</bgp-instances>
</bgp>

```

```
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <afi>ipv4</afi>
    </default-peer-route-map-name><!-- operation="delete"-->
  </address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) default-originate
```

Configure peer route map orig name

This attribute configures route map to be used for a BGP local router to send the default route 0.0.0.0 to a neighbor for use as a default route for specified address-family. This attribute can be used with standard or extended access lists.

Attribute Name: peer-route-map-orig-name

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
            </address-family>
          </address-families>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

        <peer-route-map-orig-name>WORD</peer-route-map-orig-name> <!--
operation="delete"-->
        </address-family>
    </address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) default-originate route-map WORD
```

Configure weight

This attribute specifies a weight value, for specified address-family, to all routes learned from a neighbor for specified address-family. The route with the highest weight gets preference when the same prefix is learned from more than one peer. Unlike the local-preference attribute, the weight attribute is relevant only to the local router. When the weight is set for a peer group, all members of the peer group get the same weight. This attribute can also be used to assign a different weight to an individual peer-group member. When an individually-configured weight of a peer-group member is removed, its weight is reset to its peer groups weight.

Attribute Name: weight

Attribute Type: uint16

Default Value: 0

Attribute Range: 0-65535

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
      <address-families>
      <address-family>
        <safi>unicast</safi>
        <config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>
        <afi>ipv4</afi>
        <weight>0</weight> <!-- operation="delete"-->

```

```
        </address-family>
    </address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) weight <0-65535>
```

Configure route server client

This attribute configures a neighbor as the route server client for specified address-family.

Attribute Name: route-server-client

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
      <address-families>
      <address-family>
        <safi>unicast</safi>
        <config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>
        <afi>ipv4</afi>
        </route-server-client><!-- operation="delete"-->
      </address-family>
    </address-families>
    </peer>
  </peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) route-server-client
```

Configure next hop self

This attribute configure the router as the next hop for a BGP-speaking neighbor or peer group. This attribute allows a BGP router to change the nexthop information that is sent to the iBGP peer. The nexthop information is set to the IP address of the interface used to communicate with the neighbor.

Attribute Name: next-hop-self

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
                <afi>ipv4</afi>
                </next-hop-self><!-- operation="delete"-->
            </address-family>
          </address-families>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) next-hop-self
```

Configure flowspec validation disable

This attribute specifies if FLOWSPEC validation should be disabled for a specific peer

Attribute Name: flowspec-validation-disable

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
              </flowspec-validation-disable><!-- operation="delete"-->
            </address-family>
          </address-families>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) flowspec-validation-disable
```

Configure peer route reflector

This attribute configures the router as a BGP route reflector and configure the specified neighbor as its client for specified address-family. Route reflectors are a solution for the explosion of iBGP peering within an autonomous system. By route reflection the number of iBGP peers within an AS is reduced. Use this attribute to configure the local router as the route reflector and specify neighbors as its client. An AS can have more than one route reflector. One route reflector treats the other route reflector as another iBGP speaker.

Attribute Name: peer-route-reflector

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
```



```

<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
      <address-families>
      <address-family>
        <safi>unicast</safi>
        <config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>
        <afi>ipv4</afi>
        </peer-route-reflector><!-- operation="delete"-->
      </address-family>
    </address-families>
    </peer>
  </peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) route-reflector-client
```

Configure peer remove private as

This attribute removes the private Autonomous System (AS) number from outbound updates. Private AS numbers are not advertised to the Internet. This attribute is used with external BGP peers only. The router removes the AS numbers only if the update includes private AS numbers. If the update includes both private and public AS numbers, the system treats it as an error.

Attribute Name: peer-remove-private-as

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```
<peers>
  <peer>
    <peer-address>A.B.C.D|X:X::X:X</peer-address>
    <config>
      <peer-address>BGP_IP_ADDR_T</peer-address>
    </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <afi>ipv4</afi>
      </peer-remove-private-as><!-- operation="delete"-->
    </address-family>
  </address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) remove-private-AS
```

Configure no send community

This attribute specifies if a community attribute should be sent to a BGP neighbor for specified address-family. The community attribute groups destinations in a certain community and applies routing decisions according to those communities. By default, both standard and extended community attributes are sent to a neighbor

Attribute Name: no-send-community

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
      <peer>
        <peer-address>A.B.C.D|X:X::X:X</peer-address>
        <config>
          <peer-address>BGP_IP_ADDR_T</peer-address>
        </config>
      </address-families>
```

```

    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <afi>ipv4</afi>
      </no-send-community><!-- operation="delete"-->
    </address-family>
  </address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
no neighbor (A.B.C.D|X:X::X:X) send-community
```

Configure no send community type

This attribute specifies the type of community attribute to be sent to a BGP neighbor.

Attribute Name: no-send-community-type

Attribute Type: bits (both|standard|extended|large)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
              <no-send-community-type>both</no-send-community-type> <!--
operation="delete"-->

```

```

        </address-family>
    </address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
no neighbor (A.B.C.D|X:X::X:X) send-community (both|standard|extended|large)
```

Configure neighbor attribute unchanged

This attribute advertises unchanged BGP AS path, next hop and med to the specified neighbor.

Attribute Name: neighbor-attribute-unchanged

Attribute Type: bits (as-path|next-hop|med)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
                <afi>ipv4</afi>
                <neighbor-attribute-unchanged>14</neighbor-attribute-unchanged> <!--
- operation="delete"-->
            </address-family>
          </address-families>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) attribute-unchanged
```

Configure orf prefix capability

This attribute enables Outbound Router Filtering (ORF), and advertise the ORF capability to its neighbors. The ORFs send and receive capabilities to lessen the number of updates exchanged between neighbors. By filtering updates, this option minimizes generating and processing of updates. The two routers exchange updates to maintain the ORF for each router.

Attribute Name: orf-prefix-capability

Attribute Type: bits (both|receive|send)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
      <peer>
        <peer-address>A.B.C.D|X:X::X:X</peer-address>
        <config>
          <peer-address>BGP_IP_ADDR_T</peer-address>
        </config>
        <address-families>
          <address-family>
            <safi>unicast</safi>
            <config>
              <safi>unicast</safi>
              <afi>ipv4</afi>
            </config>
            <afi>ipv4</afi>
            <orf-prefix-capability>both</orf-prefix-capability> <!--
operation="delete"-->
          </address-family>
        </address-families>
      </peer>
    </peers>
  </bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) capability orf prefix-list (both|receive|send)
```

Configure peer allow ebgp vpn

This attribute allows an eBGP neighbor to be a VPN peer. By default, BGP VPN functionality is allowed only for iBGP peers. Using the peer-allow-ebgp-vpn attribute allows the VPN connection to be established to an eBGP peer.

Attribute Name: peer-allow-ebgp-vpn

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
              </peer-allow-ebgp-vpn><!-- operation="delete"-->
            </address-family>
          </address-families>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) allow-ebgp-vpn
```

Configure allow as number

This attribute advertises prefixes (routes) even when the source of the prefixes is from the same Autonomous System (AS) number for specified address-family. Use this attribute in a scenario where two routers at different locations use the same Autonomous System number and are connected via an ISP. Once prefixes arrive from one branch at the ISP, they are tagged with the customers AS number. By default, when the ISP passes the prefixes to the other router, the prefixes are dropped if the other router uses the same AS number. Use this attribute to advertise the prefixes at the other side. Control the number of times an AS number is advertised by specifying a number. In a hub and spoke

configuration in a VPN, a PE (Provider Edge) router advertises all prefixes containing duplicate AS numbers. Use this attribute to configure two VRFs on each PE router to receive and advertise prefixes. One of the VRFs receives prefixes with AS numbers from all PE routers and then advertises them to neighboring PE routers. The other VRF receives prefixes with AS numbers from the CE (Customer Edge) router and advertises them to all PE routers in the hub and spoke configuration.

Attribute Name: allow-as-number

Attribute Type: uint32

Default Value: 3

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
              <allow-as-number>1</allow-as-number> <!-- operation="delete"-->
            </address-family>
          </address-families>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) allowas-in <1-10>
```

Configure capability graceful restart

This attribute configures the router to advertise the Graceful Restart Capability to the neighbors. This configuration indicates that the BGP speaker has the ability to preserve its forwarding state for the address family when BGP restarts. Use this attribute to advertise to the neighbor routers the capability of graceful restart.

Attribute Name: capability-graceful-restart

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
                <afi>ipv4</afi>
                </capability-graceful-restart><!-- operation="delete"-->
            </address-family>
          </address-families>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) capability graceful-restart
```

Configure extended nexthop encode

A BGP speaker that wishes to advertise an IPv6 next hop for IPv4 NLRI for VPN-IPv4 NLRI to a BGP peer as per this specification MUST use the Capability Advertisement procedures defined with the Extended Next Hop Encoding capability to determine whether its peer supports this for the NLRI AFI/SAFI pair(s) of interest.

Attribute Name: extended-nexthop-encode

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
```



```

<config>
  <bgp-as>1</bgp-as>
</config>
<peers>
<peer>
  <peer-address>A.B.C.D|X:X::X:X</peer-address>
  <config>
    <peer-address>BGP_IP_ADDR_T</peer-address>
  </config>
  <address-families>
  <address-family>
    <safi>unicast</safi>
    <config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
    </extended-nexthop-encode><!-- operation="delete"-->
  </address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) capability extended-nexthop-encode
```

Configure mapped peer group tag af

BGP peer group name. Adds a neighbor to an existing peer group. Neighbors with the same update policies are grouped into peer groups. This facilitates the updates of various policies, such as distribute and filter lists. The peer group is then configured easily with any of the neighbor attributes. Any changes made to the peer group affect all members.

Attribute Name: mapped-peer-group-tag-af

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>

```

```
<config>
  <peer-address>BGP_IP_ADDR_T</peer-address>
</config>
<address-families>
<address-family>
  <safi>unicast</safi>
  <config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  </config>
  <afi>ipv4</afi>
  <mapped-peer-group-tag-af>WORD</mapped-peer-group-tag-af> <!--
operation="delete"-->
  </address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) peer-group WORD
```

Configure prefix count

Use this attribute to specify maximum number of prefixes that can be received from a neighbor

Attribute Name: prefix-count

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
      <address-families>
      <address-family>
        <safi>unicast</safi>
      <config>
```

```

        <safi>unicast</safi>
        <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
    <maximum-prefixes>
    <maximum-prefix> <!-- operation="delete"-->
        <prefix-count>1</prefix-count>
    </config>
        <prefix-count>1</prefix-count>
    </config>
    </maximum-prefix>
    </maximum-prefixes>
</address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) maximum-prefix <1-4294967295>
```

Configure stop update

Stop installing the routes when limit is exceeded.

Attribute Name: stop-update

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
        <address-families>
          <address-family>
            <safi>unicast</safi>
            <config>
              <safi>unicast</safi>
              <afi>ipv4</afi>
            </config>
          </address-family>
        </address-families>
      </peer>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```
    </config>
      <afi>ipv4</afi>
    <maximum-prefixes>
    <maximum-prefix>
      <prefix-count>1</prefix-count>
      <config>
        <prefix-count>1</prefix-count>
      </config>
    </stop-update>
  </maximum-prefix>
</maximum-prefixes>
</address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) maximum-prefix <1-4294967295> stop-update
```

Configure maximum prefix warning

This attribute when enabled only give warning message when limit is exceeded. When it is not set and extra prefixes are received, the router ends the peering.

Attribute Name: maximum-prefix-warning

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
            <config>
              <safi>unicast</safi>
            <afi>ipv4</afi>
```

```

    </config>
      <afi>ipv4</afi>
    <maximum-prefixes>
    <maximum-prefix>
      <prefix-count>1</prefix-count>
      <config>
        <prefix-count>1</prefix-count>
      </config>
    </maximum-prefix>
  </maximum-prefixes>
</address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) maximum-prefix <1-4294967295> warning-only
```

Configure threshold percentage

Threshold-value in percen. This attribute controls the number of prefixes that can be received from a neighbor. This attribute allows the configuration of a specified number of prefixes that a BGP router is allowed to receive from a neighbor. When the maximum-prefix-warning attribute is not set and extra prefixes are received, the router ends the peering.

Attribute Name: threshold-percentage

Attribute Type: uint8

Default Value: 75

Attribute Range: 1-100

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```
<safi>unicast</safi>
<config>
  <safi>unicast</safi>
  <afi>ipv4</afi>
</config>
  <afi>ipv4</afi>
<maximum-prefixes>
<maximum-prefix>
  <prefix-count>1</prefix-count>
  <config>
    <prefix-count>1</prefix-count>
  </config>
  <threshold-percentage>1</threshold-percentage>
</maximum-prefix>
</maximum-prefixes>
</address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) maximum-prefix <1-4294967295> <1-100>
```

Configure warning only

Throw warning if exceeds threshold-value

Attribute Name: warning-only

Attribute Type: uint8

Attribute Name: threshold-percentage

Attribute Type: uint8

Default Value: 75

Attribute Range: 1-100

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
    </peer>
  </bgp-instance>
</bgp-instances>
</bgp>
```

```

        <peer-address>BGP_IP_ADDR_T</peer-address>
    </config>
    <address-families>
    <address-family>
        <safi>unicast</safi>
        <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
        </config>
        <afi>ipv4</afi>
    <maximum-prefixes>
    <maximum-prefix>
        <prefix-count>1</prefix-count>
        <config>
            <prefix-count>1</prefix-count>
            <threshold-percentage>1</threshold-percentage>
        </config>
        </warning-only>
    </maximum-prefix>
    </maximum-prefixes>
    </address-family>
    </address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) maximum-prefix <1-4294967295> <1-100> warning-only
```

Configure unsuppress route map name

unsuppress map name. This attribute is used to selectively leak more-specific routes to a particular neighbor.

Attribute Name: unsuppress-route-map-name

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>

```

```
        <peer-address>BGP_IP_ADDR_T</peer-address>
    </config>
    <address-families>
    <address-family>
        <safi>unicast</safi>
        <config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
        </config>
        <afi>ipv4</afi>
        <unsuppress-route-map-name>WORD</unsuppress-route-map-name> <!--
operation="delete"-->
    </address-family>
    </address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) unsuppress-map WORD
```

Configure access list identifier

Access List information

Attribute Name: access-list-identifier

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
```



```

    </config>
    <afi>ipv4</afi>
  <distributed-list-filters>
  <distributed-list-filter>
    <filter-direction>in</filter-direction>
    <config>
      <filter-direction>in</filter-direction>
    </config>
    <access-list-identifier>WORD</access-list-identifier>
  </distributed-list-filter>
</distributed-list-filters>
</address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) distribute-list WORD (in|out)
```

Configure filter direction

Access List information

Attribute Name: access-list-identifier

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
            <config>
              <safi>unicast</safi>
              <afi>ipv4</afi>
            </config>

```

```
        <afi>ipv4</afi>
    <distribute-list-filters>
    <distribute-list-filter>
        <filter-direction>in</filter-direction>
        <config>
            <filter-direction>in</filter-direction>
        </config>
        <access-list-identifier>WORD</access-list-identifier>
    </distribute-list-filter>
</distribute-list-filters>
</address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) distribute-list WORD (in|out)
```

Configure prefix list name

This attribute specifies a prefix list for filtering BGP advertisements for specified address-family. Filtering by prefix list matches the prefixes of routes with those listed in the prefix list. If there is a match, the route is used. An empty prefix list permits all prefixes. If a given prefix does not match any entries of a prefix list, the route is denied access. When multiple entries of a prefix list match a prefix, the entry with the smallest sequence number is considered to be a real match. The router begins the search at the top of the prefix list, with the sequence number 1. Once a match or deny occurs, the router does not need to go through the rest of the prefix list. For efficiency the most common matches or denials are listed at the top.

Attribute Name: prefix-list-name

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
    </address-families>
    <address-family>
      <safi>unicast</safi>
```

```

    <config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
  <prefix-list-filters>
  <prefix-list-filter>
    <prefix-filter-direction>in</prefix-filter-direction>
    <config>
      <prefix-filter-direction>in</prefix-filter-direction>
    </config>
    <prefix-list-name>WORD</prefix-list-name>
  </prefix-list-filter>
</prefix-list-filters>
</address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) prefix-list WORD (in|out)
```

Configure prefix filter direction

This attribute specifies a prefix list for filtering BGP advertisements for specified address-family. Filtering by prefix list matches the prefixes of routes with those listed in the prefix list. If there is a match, the route is used. An empty prefix list permits all prefixes. If a given prefix does not match any entries of a prefix list, the route is denied access. When multiple entries of a prefix list match a prefix, the entry with the smallest sequence number is considered to be a real match. The router begins the search at the top of the prefix list, with the sequence number 1. Once a match or deny occurs, the router does not need to go through the rest of the prefix list. For efficiency the most common matches or denials are listed at the top.

Attribute Name: prefix-list-name

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>

```

```

    </config>
  <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <afi>ipv4</afi>
    <prefix-list-filters>
      <prefix-list-filter>
        <prefix-filter-direction>in</prefix-filter-direction>
        <config>
          <prefix-filter-direction>in</prefix-filter-direction>
        </config>
        <prefix-list-name>WORD</prefix-list-name>
      </prefix-list-filter>
    </prefix-list-filters>
  </address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD prefix-list WORD (in|out)
```

Configure as access list identifier

Access-list number. This attribute sets a BGP filter. This attribute specifies an access list filter on updates based on the BGP autonomous system paths. Each filter is an access list based on regular expressions

Attribute Name: as-access-list-identifier

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>

```

```

</config>
<address-families>
<address-family>
  <safi>unicast</safi>
  <config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  </config>
  <afi>ipv4</afi>
<as-list-filters>
<as-list-filter>
  <as-list-direction>in</as-list-direction>
  <config>
    <as-list-direction>in</as-list-direction>
  </config>
  <as-access-list-identifier>WORD</as-access-list-identifier>
</as-list-filter>
</as-list-filters>
</address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) filter-list WORD (in|out)
```

Configure as list direction

Access-list number. This attribute sets a BGP filter. This attribute specifies an access list filter on updates based on the BGP autonomous system paths. Each filter is an access list based on regular expressions

Attribute Name: as-access-list-identifier

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>

```

```
</config>
<address-families>
<address-family>
  <safi>unicast</safi>
  <config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  </config>
  <afi>ipv4</afi>
<as-list-filters>
<as-list-filter>
  <as-list-direction>in</as-list-direction>
  <config>
    <as-list-direction>in</as-list-direction>
  </config>
  <as-access-list-identifier>WORD</as-access-list-identifier>
</as-list-filter>
</as-list-filters>
</address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) filter-list WORD (in|out)
```

Configure route map name

Use this attribute to apply a route map to incoming or outgoing routes. This attribute filters updates and modifies attributes. A route map is applied to inbound or outbound updates. Only the routes that pass the route map are sent or accepted in updates.

Attribute Name: route-map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
```

```

    <config>
      <peer-address>BGP_IP_ADDR_T</peer-address>
    </config>
  <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <afi>ipv4</afi>
      <route-map-filters>
        <route-map-filter>
          <route-map-direction>in</route-map-direction>
          <config>
            <route-map-direction>in</route-map-direction>
          </config>
          <route-map-name>WORD</route-map-name>
        </route-map-filter>
      </route-map-filters>
    </address-family>
  </address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) route-map WORD (in|out)
```

Configure route map direction

Use this attribute to apply a route map to incoming or outgoing routes. This attribute filters updates and modifies attributes. A route map is applied to inbound or outbound updates. Only the routes that pass the route map are sent or accepted in updates.

Attribute Name: route-map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```
<peer>
  <peer-address>A.B.C.D|X:X::X:X</peer-address>
  <config>
    <peer-address>BGP_IP_ADDR_T</peer-address>
  </config>
  <address-families>
  <address-family>
    <safi>unicast</safi>
    <config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <afi>ipv4</afi>
    <route-map-filters>
    <route-map-filter>
      <route-map-direction>in</route-map-direction>
      <config>
        <route-map-direction>in</route-map-direction>
      </config>
      <route-map-name>WORD</route-map-name>
    </route-map-filter>
  </route-map-filters>
  </address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD route-map WORD (in|out)
```

Configure peer port

Sets the BGP port number of a neighbor.

Attribute Name: peer-port

Attribute Type: uint16

Default Value: 179

Attribute Range: 0-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
```



```

    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
      <peer-port>0</peer-port> <!-- operation="delete"-->
    </peer>
  </peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD port <0-65535>
```

Configure min route advertisement interval

Sets a minimum route advertisement interval between the sending of BGP routing updates. To reduce the flapping of routes to internet, a minimum advertisement interval is set, so that the BGP routing updates are sent only per interval seconds.

Attribute Name: min-route-advertisement-interval

Attribute Type: uint32

Attribute Range: 0-65535

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
      <peer>
        <peer-address>A.B.C.D|X:X::X:X</peer-address>
        <config>
          <peer-address>BGP_IP_ADDR_T</peer-address>
        </config>
        <min-route-advertisement-interval>0</min-route-advertisement-interval>
      <!-- operation="delete"-->
      </peer>
    </peers>
  </bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD advertisement-interval <0-65535>
```

Configure peer as origin interval

Configures the minimum interval between the sending of AS-origination routing updates.

Attribute Name: peer-as-origin-interval

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
            </config>
            <peer-as-origin-interval>1</peer-as-origin-interval> <!--
operation="delete"-->
          </peer>
        </peers>
      </bgp-instance>
    </bgp-instances>
  </bgp>
```

Command Syntax

```
neighbor WORD as-origination-interval <1-65535>
```

Configure collide established

Include a neighbor already in an established state for conflict resolution when a TCP connection collision is detected.

Attribute Name: collide-established

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
```

```

        <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
        <peer-address>A.B.C.D|X:X::X:X</peer-address>
        <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
        </config>
        </collide-established><!-- operation="delete"-->
    </peer>
    </peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD collide-established
```

Configure peer description

Associates a description with a neighbor. This helps in identifying a neighbor quickly. It is useful for an ISP that has multiple neighbor relationships.

Attribute Name: peer-description

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
    <bgp-instance>
        <bgp-as>1</bgp-as>
        <config>
            <bgp-as>1</bgp-as>
        </config>
        <peers>
        <peer>
            <peer-address>A.B.C.D|X:X::X:X</peer-address>
            <config>
                <peer-address>BGP_IP_ADDR_T</peer-address>
            </config>
            <peer-description>LINE</peer-description> <!-- operation="delete"-->
        </peer>
        </peers>
    </bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD description LINE
```

Configure disallow infinite hold time

Disallow configuration of infinite hold-time. A hold-time of 0 seconds from the peer (during exchange of open messages) or the user (during configuration) will be rejected.

Attribute Name: disallow-infinite-hold-time

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          </disallow-infinite-hold-time><!-- operation="delete"-->
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD disallow-infinite-holdtime
```

Configure disable capability negotiation

Disable the capability negotiation. It allows compatibility with older BGP versions that have no capability parameters used in open messages between peers.

Attribute Name: disable-capability-negotiation

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
```

```

    <peer-address>A.B.C.D|X:X::X:X</peer-address>
  </config>
  <peer-address>BGP_IP_ADDR_T</peer-address>
</config>
  </disable-capability-negotiation><!-- operation="delete"-->
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD dont-capability-negotiate
```

Configure enforce multi hop

Turns on the enforcement of eBGP neighbors perform multihop.

Attribute Name: enforce-multi-hop

Attribute Type: empty

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          </enforce-multi-hop><!-- operation="delete"-->
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD enforce-multihop
```

Configure graceful shut

Use this attribute to start a graceful shutdown for the BGP session of the specified BGP neighbor. The BGP session for this neighbor is shut down after the graceful shutdown timer expires. If there is no alternate path available for traffic to

flow prior the actual shutdown of the BGP session, this path is made available for 60 seconds or for configured time after which the path is no longer available and traffic is dropped.

Attribute Name: graceful-shut

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          </graceful-shut><!-- operation="delete"-->
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD g-shut
```

Configure graceful shutdown timer

Configure the value of the graceful shutdown timer. After the timer expires, the BGP session initiated for graceful shutdown is shut down.

Attribute Name: graceful-shutdown-timer

Attribute Type: uint32

Attribute Range: 10-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
```

```

    <config>
      <peer-address>BGP_IP_ADDR_T</peer-address>
    </config>
    <graceful-shutdown-timer>10</graceful-shutdown-timer> <!--
operation="delete"-->
  </peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD g-shut-timer <10-65535>
```

Configure neighbor override capability

Override a capability negotiation result and use locally configured values.

Attribute Name: neighbor-override-capability

Attribute Type: empty

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          </neighbor-override-capability><!-- operation="delete"-->
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD override-capability
```

Configure neighbor passive

Sets a BGP neighbor as passive.

Attribute Name: neighbor-passive

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          </neighbor-passive><!-- operation="delete"-->
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD passive
```

Configure peer restart time

Sets a different restart-time other than the global restart-time. This attribute takes precedence over the restart-time value specified using the grstSet attribute. The restart-time value is the maximum time that a graceful-restart neighbor waits to come back up after a restart. The default value is 120 seconds.

Attribute Name: peer-restart-time

Attribute Type: uint32

Attribute Range: 1-3600

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```



```

        <peer-restart-time>1</peer-restart-time> <!-- operation="delete"-->
    </peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD restart-time <1-3600>
```

Configure peer shutdown

Disables a neighbor administratively. It will terminate any active session for a specified neighbor and clear all related routing information. In case a peer group is specified for shutdown, a large number of peering sessions could be terminated.

Attribute Name: peer-shutdown

Attribute Type: empty

Attribute Name: peer-shutdown-description

Attribute Type: string

Attribute Range: 1-255

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
            <peer-shutdown-description>1</peer-shutdown-description> <!--
operation="delete"-->
          </config>
          </peer-shutdown><!-- operation="delete"-->
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD shutdown (description LINE|)
```

Configure neighbor strict capability match

Close the BGP connection if capability value does not match the remote peer.

Attribute Name: neighbor-strict-capability-match

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          </neighbor-strict-capability-match><!-- operation="delete"-->
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD strict-capability-match
```

Configure source identifier

Allows internal BGP sessions to use any operational interface for TCP connections. This attribute can be used in conjunction with any specified interface on the router. The loopback interface is the interface that is most commonly used with this attribute. The use of loopback interface eliminates a dependency and BGP does not have to rely on the availability of a particular interface for making TCP connections.

Attribute Name: source-identifier

Attribute Type: string

Default Value: NULL

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
      <source-identifier>WORD</source-identifier> <!-- operation="delete"-->
    </peer>
  </peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD update-source WORD
```

Configure bgp version

Configure router to accept only a particular BGP version. By default, the system uses BGP version 4 and on request dynamically negotiates down to version 2. Disables the routers version-negotiation capability and forces the router to use only a specified version with the neighbor.

Attribute Name: bgp-version

Attribute Type: uint8

Default Value: 4

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
      <peer>
        <peer-address>A.B.C.D|X:X::X:X</peer-address>
        <config>
          <peer-address>BGP_IP_ADDR_T</peer-address>
        </config>
        <bgp-version>(4)</bgp-version> <!-- operation="delete"-->
      </peer>
    </peers>
  </bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD version (4)
```

Configure enable ext opt param len

Use this attribute for a specific peer to encode extended optional parameter length.

Attribute Name: enable-ext-opt-param-len

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          </enable-ext-opt-param-len><!-- operation="delete"-->
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD extended-optional-param
```

Configure peer connect interval

This attribute sets the timers for a specific BGP neighbor. Keepalive messages are sent by a router to inform another router that the BGP connection between the two is still active. The keepalive interval is the period of time between each keepalive message sent by the router. The holdtime interval is the time the router waits to receive a keepalive message and if it does not receive a message for this period it declares the neighbor dead.

Attribute Name: peer-connect-interval

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
```

```

        <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
        <peer-address>A.B.C.D|X:X::X:X</peer-address>
        <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
        </config>
        <peer-connect-interval>1</peer-connect-interval> <!--
operation="delete"-->
    </peer>
    </peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD timers connect <1-65535>
```

Configure peer as

Autonomous system number of a neighbor. If the specified ASN matches the ASN number specified in the router bgp global configuration, the neighbor is identified as internal. If the ASN does no match, it is identified as external to the local AS.

Attribute Name: peer-as

Attribute Type: union

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
      <peer>
        <peer-address>A.B.C.D|X:X::X:X</peer-address>
        <config>
          <peer-address>BGP_IP_ADDR_T</peer-address>
        </config>
        <peer-as>-2</peer-as>
      </peer>
    </peers>
  </bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD remote-as internal
```

Configure enable dynamic capability

Use this attribute to enable the dynamic capability for a specific peer. This attribute allows a BGP speaker to advertise or withdraw an address family capability to a peer in a non-disruptive manner.

Attribute Name: enable-dynamic-capability

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
      </enable-dynamic-capability><!-- operation="delete"-->
    </peer>
  </peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) capability dynamic
```

Configure peer shutdown description

Use this attribute to send shutdown communication message to inform peer the reason for the shutdown of the BGP session.

Attribute Name: peer-shutdown-description

Attribute Type: string

Attribute Range: 1-255

Attribute Name: peer-shutdown

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
```

```

<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <peers>
  <peer>
    <peer-address>A.B.C.D|X:X::X:X</peer-address>
    <config>
      <peer-address>BGP_IP_ADDR_T</peer-address>
      </peer-shutdown><!-- operation="delete"-->
    </config>
    <peer-shutdown-description>1</peer-shutdown-description> <!--
operation="delete"-->
  </peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) shutdown (description LINE|)
```

Configure hold time

Use this attribute to globally set or reset the holdtime values for all the neighbors.

Attribute Name: hold-time

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: keep-alive

Attribute Type: uint16

Attribute Range: 0-65535

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
      <peer>
        <peer-address>A.B.C.D|X:X::X:X</peer-address>
        <config>
          <peer-address>BGP_IP_ADDR_T</peer-address>
        </config>
        <timers>

```

```
        <config>
            <keep-alive>0</keep-alive>
            <hold-time>0</hold-time>
        </config>
    </timers>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD timers <0-65535> <0-65535>
```

Configure keep alive

Use this attribute to globally set or reset the keepalive values for all the neighbors

Attribute Name: keep-alive

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: hold-time

Attribute Type: uint16

Attribute Range: 0-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <timers>
            <config>
              <hold-time>0</hold-time>
              <keep-alive>0</keep-alive>
            </config>
          </timers>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
```

```
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) timers <0-65535> <0-65535>
```

Configure enabled

Use this attribute to accept and attempt BGP connections to external peers on indirectly connected networks. Multihop is not established if the only route to the multihop peer is a default route. This avoids loop formation.

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <ebgp-multihop>
            <config>
              </enabled>
            </config>
          </ebgp-multihop>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) ebgp-multihop
```

Configure maximum hop count

Use this attribute to accept and attempt BGP connections to external peers on indirectly connected networks. Multihop is not established if the only route to the multihop peer is a default route. This avoids loop formation.

Attribute Name: enabled

Attribute Type: empty

Attribute Name: maximum-hop-count

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <ebgp-multihop>
            <config>
              <maximum-hop-count>1</maximum-hop-count> <!-- operation="delete"-->
              </enabled><!-- operation="delete"-->
            </config>
          </ebgp-multihop>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) ebgp-multihop <1-255>
```

Configure peer local as

Specifies an AS (autonomous system) number to use with BGP neighbor.

Attribute Name: peer-local-as

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
```

```

    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
    </local-as>
    <local-as-list> <!-- operation="delete"-->
      <peer-local-as>1</peer-local-as>
    </local-as-list>
  </local-as>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) local-as <1-4294967295>
```

Configure no prepend local as

Specifies an AS (autonomous system) number to use with BGP neighbor.

Attribute Name: peer-local-as

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: no-prepend-local-as

Attribute Type: empty

Attribute Name: replace-local-as

Attribute Type: empty

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
    </bgp-instance>
  </bgp-instances>
  <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
    </peer>
  </peers>
</bgp>

```

```
    <local-as>
    <local-as-list>
      <peer-local-as>1</peer-local-as>
      <config>
        <peer-local-as>1</peer-local-as>
        </no-prepend-local-as>
        </replace-local-as>
      </config>
    </local-as-list>
  </local-as>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) local-as <1-4294967295> (no-prepend|) (replace-as|)
```

Configure replace local as

Specifies an AS (autonomous system) number to use with BGP neighbor.

Attribute Name: peer-local-as

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: no-prepend-local-as

Attribute Type: empty

Attribute Name: replace-local-as

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <local-as>
            <local-as-list>
              <peer-local-as>1</peer-local-as>
```

```

        <config>
            <peer-local-as>1</peer-local-as>
            </no-prepend-local-as>
            </replace-local-as>
        </config>
    </local-as-list>
</local-as>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD local-as <1-4294967295> (no-prepend|) (replace-as|)
```

Configure admin status

Enable or disable AIGP

Attribute Name: admin-status

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
            </address-family>
          </address-families>
          <aigp>
            <config>
              <admin-status>disable</admin-status> <!-- operation="delete"-->
            </config>
          </aigp>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```
    </address-family>
  </address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) aigp (disable|enable)
```

Configure aigp send med

Enable AIGP send multi exit discriminator.

Attribute Name: aigp-send-med

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
            </address-family>
            <aigp>
              <config>
                <aigp-send-med><!-- operation="delete"-->
              </config>
            </aigp>
          </address-family>
        </address-families>
      </peer>
    </peers>
  </bgp-instance>
```

```

</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) aigp send med
```

Configure send cost community id

Send AIGP value in Cost community. And get the Community ID.

Attribute Name: send-cost-community-id

Attribute Type: uint8

Attribute Range: 0-255

Attribute Name: point-of-insertion

Attribute Type: enum (pre-bestpath|igp-cost)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <address-families>
            <address-family>
              <safi>unicast</safi>
              <config>
                <safi>unicast</safi>
                <afi>ipv4</afi>
              </config>
              <afi>ipv4</afi>
            </address-family>
            <aigp>
              <cost-community>
                <config>
                  <point-of-insertion>pre-bestpath</point-of-insertion>
                  <send-cost-community-id>0</send-cost-community-id>
                </config>
              </cost-community>
            </aigp>
          </address-family>
        </address-families>
      </peer>

```

```
</peers>  
</bgp-instance>  
</bgp-instances>  
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) aigp send cost-community <0-255> poi (pre-bestpath|igp-  
cost)
```

Configure enable transitive

Send AIGP value in Cost community and Enable Transitive Cost Community

Attribute Name: enable-transitive

Attribute Type: uint8

Attribute Name: send-cost-community-id

Attribute Type: uint8

Attribute Range: 0-255

Attribute Name: point-of-insertion

Attribute Type: enum (pre-bestpath|igp-cost)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">  
<bgp-instances>  
  <bgp-instance>  
    <bgp-as>1</bgp-as>  
    <config>  
      <bgp-as>1</bgp-as>  
    </config>  
    <peers>  
    <peer>  
      <peer-address>A.B.C.D|X:X::X:X</peer-address>  
      <config>  
        <peer-address>BGP_IP_ADDR_T</peer-address>  
      </config>  
      <address-families>  
      <address-family>  
        <safi>unicast</safi>  
      <config>  
        <safi>unicast</safi>  
        <afi>ipv4</afi>  
      </config>  
        <afi>ipv4</afi>  
      <aigp>  
      <cost-community>  
      <config>  
        <send-cost-community-id>0</send-cost-community-id> <!--  
operation="delete"-->
```



```

operation="delete"--> <point-of-insertion>pre-bestpath</point-of-insertion> <!--
                        </enable-transitive><!-- operation="delete"-->
                        </config>
                        </cost-community>
                    </aigp>
                </address-family>
            </address-families>
        </peer>
    </peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```

neighbor (A.B.C.D|X:X::X:X) aigp send cost-community <0-255> poi (pre-bestpath|igp-
cost) transitive

```

Configure point of insertion

Send AIGP value in Cost community. And get the Community ID.

Attribute Name: send-cost-community-id

Attribute Type: uint8

Attribute Range: 0-255

Attribute Name: point-of-insertion

Attribute Type: enum (pre-bestpath|igp-cost)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
    <peer>
      <peer-address>A.B.C.D|X:X::X:X</peer-address>
      <config>
        <peer-address>BGP_IP_ADDR_T</peer-address>
      </config>
    <address-families>
    <address-family>
      <safi>unicast</safi>
      <config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
    </address-family>
  </peer>
    </peers>
  </bgp-instance>
</bgp-instances>
</bgp>

```

```
        <afi>ipv4</afi>
    <aigp>
    <cost-community>
    <config>
        <point-of-insertion>pre-bestpath</point-of-insertion>
        <send-cost-community-id>0</send-cost-community-id>
    </config>
    </cost-community>
</aigp>
</address-family>
</address-families>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) aigp send cost-community <0-255> poi (pre-bestpath|igp-
cost)
```

clear ip bgp * (description LINE|)

Attribute Name: peer-reset-description

Attribute Type: string

Attribute Range: 1-255

Netconf RPC payload

```
<ipi-bgp-peer_clear-ip-bgp-all-peer xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-bgp">
  <peer-reset-description>1</peer-reset-description>
</ipi-bgp-peer_clear-ip-bgp-all-peer>
```

Command Syntax

```
clear ip bgp * (description LINE|)
```

clear bgp * l2vpn evpn soft (out|in|)

Attribute Name: soft-reconfig

Attribute Type: enum (out|in|soft-only)

Netconf RPC payload

```
<ipi-bgp-peer_clear-bgp-l2vpn-evpn-soft-all xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-bgp">
  <soft-reconfig>soft-only</soft-reconfig>
</ipi-bgp-peer_clear-bgp-l2vpn-evpn-soft-all>
```

Command Syntax

```
clear bgp * l2vpn evpn soft (out|in|)
```

clear bgp <1-4294967295> l2vpn evpn soft (out|in|)

Attribute Name: peer-as

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: soft-reconfig

Attribute Type: enum (out|in|soft-only)

Netconf RPC payload

```
<ipi-bgp-peer_clear-bgp-remote-as-l2vpn-evpn-soft-all xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <peer-as>1</peer-as>
  <soft-reconfig>soft-only</soft-reconfig>
</ipi-bgp-peer_clear-bgp-remote-as-l2vpn-evpn-soft-all>
```

Command Syntax

```
clear bgp <1-4294967295> l2vpn evpn soft (out|in|)
```

clear bgp (A.B.C.D|X:X::X:X|WORD) l2vpn evpn soft (out|in|)

Attribute Name: peer-address

Attribute Type: union

Attribute Name: soft-reconfig

Attribute Type: enum (out|in|soft-only)

Netconf RPC payload

```
<ipi-bgp-peer_clear-bgp-peer-address-l2vpn-evpn-soft xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <peer-address>BGP_IP_ADDR_T</peer-address>
  <soft-reconfig>soft-only</soft-reconfig>
</ipi-bgp-peer_clear-bgp-peer-address-l2vpn-evpn-soft>
```

Command Syntax

```
clear bgp (A.B.C.D|X:X::X:X|WORD) l2vpn evpn soft (out|in|)
```

IPI-BGP-ADDRESS-FAMILY-VRF

Configure enable auto summary

Use this attribute to enable sending summarized routes by a BGP speaker to its peers. Auto-summary is used by a BGP router to advertise summarized routes to its peers. Auto-summary can be enabled if certain routes have already been advertised: in this case, configuring auto-summary advertises the summarized routes first, then corresponding non-summarized routes are withdrawn. If certain routes have already been advertised, and auto-summary is disabled, non-summarized routes are first advertised, then the corresponding summarized routes are withdrawn from all the connected peers.

Attribute Name: enable-auto-summary

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </enable-auto-summary><!-- operation="delete"-->
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

auto-summary

Configure enable network igp sync

Use this attribute to enable IGP synchronization for BGP static network routes

Attribute Name: enable-network-igp-sync

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
```

```

        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
    </config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
    </enable-network-igp-sync><!-- operation="delete"-->
</address-family-vrfs>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
network synchronization
```

Configure map name

Use this attribute to enable or disable suppression/modification of incoming BGP updates to IP RIB/FIB table installation. In a dedicated route reflector, all the routes it receives may not be required to be stored or only few selected routes need to be stored, because it may not lie in the data path. Table maps are particularly useful to attain this restriction. When map-name attribute is set, the route map referenced in the map-name attribute shall be used to set certain properties (such as the traffic index) of the routes for installation into the RIB. The route is always downloaded, regardless of whether it is permitted or denied by the route map.

Attribute Name: map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <table-map>
            <config>
              <map-name>WORD</map-name> <!-- operation="delete"-->

```

```
        </config>
    </table-map>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
table-map WORD
```

Configure table map filter

When tableMapFilter attribute is given in the table map attribute, the route map referenced is used to control whether a BGP route is to be downloaded to the IP RIB (hence the filter). A BGP route is not downloaded to the RIB if it is denied by the route map.

Attribute Name: table-map-filter

Attribute Type: boolean

Attribute Name: map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <table-map>
            <config>
              <map-name>WORD</map-name> <!-- operation="delete"-->
              <table-map-filter>true</table-map-filter> <!-- operation="delete"-->
            </config>
          </table-map>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
table-map WORD filter
```

Configure local

Use this attribute to specify distance value for local routes

Attribute Name: local

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      <distances>
      <distance> <!-- operation="delete"-->
        <local>1</local>
        <config>
          <local>1</local>
          <ibgp>1</ibgp>
          <ebgp>1</ebgp>
        </config>
          <ibgp>1</ibgp>
          <ebgp>1</ebgp>
        </distance>
      </distances>
    </address-family-vrf>
  </address-family-vrfs>
</bgp-instance>
</bgp-instances>

```

```
</bgp>
```

Command Syntax

```
distance bgp <1-255> <1-255> <1-255>
```

Configure enable igp sync

Use this attribute to enable IGP synchronization of Internal BGP (iBGP) learned routes with the Internal Gateway Protocol (IGP) system. Synchronization is used when a BGP router should not advertise routes learned from iBGP neighbors, unless those routes are also present in an IGP (for example, OSPF). Synchronization may be enabled when all the routers in an autonomous system do not speak BGP, and the autonomous system is a transit for other autonomous systems.

Attribute Name: enable-igp-sync

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </enable-igp-sync><!-- operation="delete"-->
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
synchronization
```

Configure ebgp max path

Use this attribute to set the number of equal-cost multi-path (ECMP) routes for eBGP. You can install multiple BGP paths to the same destination to balance the load on the forwarding path

Attribute Name: ebgp-max-path

Attribute Type: int32

Attribute Range: 2-64

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <maximum-paths>
            <config>
              <ebgp-max-path>2</ebgp-max-path> <!-- operation="delete"-->
            </config>
          </maximum-paths>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
max-paths ebgp <2-64>
```

Configure bgp as

Use this attribute to set the number of equal-cost multi-path (ECMP) routes for eBGP. You can install multiple BGP paths to the same destination to balance the load on the forwarding path

Attribute Name: ebgp-max-path

Attribute Type: int32

Attribute Range: 2-64

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
```

```
<config>
  <bgp-as>1</bgp-as>
</config>
<address-family-vrfs>
<address-family-vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>WORD</vrf-name>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  </config>
  <safi>unicast</safi>
  <afi>ipv4</afi>
  <maximum-paths>
  <config>
    <ebgp-max-path>2</ebgp-max-path> <!-- operation="delete"-->
  </config>
</maximum-paths>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
max-paths ebgp <2-64>
```

Configure ibgp max path

Use this attribute to set the number of equal-cost multi-path (ECMP) routes for iBGP. You can install multiple BGP paths to the same destination to balance the load on the forwarding path.

Attribute Name: `ibgp-max-path`

Attribute Type: `int32`

Attribute Range: `2-64`

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
      <address-family-vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
          <safi>unicast</safi>
```

```

        <afi>ipv4</afi>
    </config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
    <maximum-paths>
    <config>
        <ibgp-max-path>2</ibgp-max-path> <!-- operation="delete"-->
    </config>
    </maximum-paths>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
max-paths ibgp <2-64>
```

Configure optional as

Use this attribute to specify optional AS for BGP dynamic peer-group

Attribute Name: optional-as

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
        </peer-group>
      </address-family-vrf>
    </address-family-vrfs>
  </bgp-instance>
</bgp-instances>

```

```
    <optional-as-lists>
    <optional-as-list> <!-- operation="delete"-->
      <optional-as>1</optional-as>
      <config>
        <optional-as>1</optional-as>
      </config>
    </optional-as-list>
  </optional-as-lists>
</peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD optional-as <1-4294967295>
```

Configure auth key encrypt

Use this attribute to configure the authentication key to specify if the password is to be encrypted or not.

Attribute Name: auth-key-encrypt

Attribute Type: enum (0|1)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
```

```

    <bgp-passwords>
    <bgp-password>
      <password>WORD</password>
    <config>
      <password>WORD</password>
    </config>
      <auth-key-encrypt>1</auth-key-encrypt>
    </bgp-password>
  </bgp-passwords>
</peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD authentication-key (0|1) WORD
```

Configure afi

Use this attribute to configure the authentication key to specify if the password is to be encrypted or not.

Attribute Name: auth-key-encrypt

Attribute Type: enum (0|1)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
    <config>
      <peer-group-tag>WORD</peer-group-tag>

```

```
    </config>
  <bgp-passwords>
    <bgp-password>
      <password>WORD</password>
      <config>
        <password>WORD</password>
      </config>
      <auth-key-encrypt>2</auth-key-encrypt>
    </bgp-password>
  </bgp-passwords>
</peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD authentication-key WORD
```

Configure multipath relax

This attribute to specifies a BGP as-path relax configuration.

Attribute Name: multipath-relax

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
          </multipath-relax><!-- operation="delete"-->
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
```

```
</bgp-instances>
</bgp>
```

Command Syntax

```
bgp bestpath as-path multipath-relax
```

Configure graceful shutdown

Gracefully shut down all sessions of the AFI/SAFI belonging to the vrf under this router. The BGP graceful shutdown feature reduces packet loss during maintenance activity.

Attribute Name: graceful-shutdown

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
      </graceful-shutdown><!-- operation="delete"-->
    </address-family-vrf>
  </address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
bgp g-shut
```

Configure graceful shutdown capable

This attribute to enable the graceful shutdown capability

Attribute Name: graceful-shutdown-capable

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
        </graceful-shutdown-capable><!-- operation="delete"-->
      </address-family-vrf>
    </address-family-vrfs>
  </bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
bgp g-shut-capable
```

Configure graceful shutdown local preference

This attribute sets the local preference of the router to use during graceful shutdown. The local preference value indicates the preferred path when there are multiple paths to the same destination in a single routing database. The path with a higher preference value is the preferred one. The preferred path is sent to all routers and access servers in the local autonomous system.

Attribute Name: graceful-shutdown-local-preference

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
```



```

    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
      <graceful-shutdown-local-preference>0</graceful-shutdown-local-
preference> <!-- operation="delete"-->
    </address-family-vrf>
  </address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp g-shut-local-preference <0-4294967295>
```

Configure additional path select all

Use this attribute to select criteria to pick the paths

Attribute Name: additional-path-select-all

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
            <additional-path-select-all><!-- operation="delete"-->
          </address-family-vrf>
        </address-family-vrfs>
      </bgp-instance>
    </bgp-instances>

```

```
</bgp>
```

Command Syntax

```
bgp additional-paths select all
```

Configure additional paths mode

Use this attribute to add additional paths in the BGP table

Attribute Name: additional-paths-mode

Attribute Type: bits (send-receive|receive|send)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <additional-paths-mode>send-receive</additional-paths-mode> <!--
operation="delete"-->
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp additional-paths (send-receive|receive|send)
```

Configure enable pic

Use this attribute to enable the additional paths in the BGP table,install the indirect nexthop in RIB

Attribute Name: enable-pic

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
```

```

<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
      </enable-pic><!-- operation="delete"-->
    </address-family-vrf>
  </address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp additional-paths install
```

Configure additional paths best select count

Use this attribute to select best N paths

Attribute Name: additional-paths-best-select-count

Attribute Type: uint8

Attribute Range: 2-3

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
      <address-family-vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>
      </address-family-vrf>
    </address-family-vrfs>
  </bgp-instance>
</bgp-instances>
</bgp>

```

```
        <safi>unicast</safi>
        <afi>ipv4</afi>
        <additional-paths-best-select-count>2</additional-paths-best-select-
count> <!-- operation="delete"-->
        </address-family-vrf>
    </address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
bgp additional-paths select best <2-3>
```

Configure protocol type

Use this attribute to inject routes from one routing process into another. Redistribution is used by routing protocols to advertise routes that are learned by some other means, such as by another routing protocol or by static routes. Since all internal routes are dumped into BGP, careful filtering is applied to make sure that only routes to be advertised reach the internet, not everything. This attribute allows redistribution by injecting prefixes from one routing protocol into another routing protocol.

Attribute Name: protocol-type

Attribute Type: enum (kernel|connected|static|rip|ospf|isis|connected-host-routes)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
      <route-redistribute-lists>
      <route-redistribute-list> <!-- operation="delete"-->
        <protocol-type>kernel</protocol-type>
        <config>
          <protocol-type>kernel</protocol-type>
        </config>
      </route-redistribute-list>
    </route-redistribute-lists>
  </address-family-vrf>
```

```

</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
redistribute (kernel|connected|static|rip|ospf|isis|connected-host-routes)
```

Configure redist route map name

Use this attribute to configure route map to be used for redistributed routes.

Attribute Name: redist-route-map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
      <route-redistribute-lists>
      <route-redistribute-list>
        <protocol-type>kernel</protocol-type>
        <config>
          <protocol-type>kernel</protocol-type>
        </config>
        <redist-route-map-name>WORD</redist-route-map-name> <!--
operation="delete"-->
      </route-redistribute-list>
    </route-redistribute-lists>
  </address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
redistribute (kernel|connected|static|rip|ospf|isis|connected-host-routes) route-
map WORD
```

Configure ospf instance number

Use this attribute to inject routes from one routing process into another. Redistribution is used by routing protocols to advertise routes that are learned by some other means, such as by another routing protocol or by static routes. Since all internal routes are dumped into BGP, careful filtering is applied to make sure that only routes to be advertised reach the internet, not everything. This attribute allows redistribution by injecting prefixes from one routing protocol into another routing protocol.

Attribute Name: ospf-instance-number

Attribute Type: union

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    <bgp-redistribute-ospfs>
    <bgp-redistribute-ospf> <!-- operation="delete"-->
      <ospf-instance-number>""</ospf-instance-number>
      <config>
        <ospf-instance-number>""</ospf-instance-number>
      </config>
    </bgp-redistribute-ospf>
    </bgp-redistribute-ospfs>
  </address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
redistribute (ospf) (WORD|<1-65535>)
```

Configure redistribute ospf route map

Use this attribute to specify route map to redistribute routes from OSPF into BGP.

Attribute Name: redistribute-ospf-route-map

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
          <bgp-redistribute-ospfs>
            <bgp-redistribute-ospf>
              <ospf-instance-number>""</ospf-instance-number>
              <config>
                <ospf-instance-number>""</ospf-instance-number>
              </config>
              <redistribute-ospf-route-map>WORD</redistribute-ospf-route-map> <!--
- operation="delete"-->
            </bgp-redistribute-ospf>
          </bgp-redistribute-ospfs>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
redistribute (ospf) route-map WORD
```

Configure peer as

This attribute specifies a neighbors autonomous system number. If the specified ASN matches the ASN number specified in the router bgp global configuration, the neighbor is identified as internal. If the ASN does not match, it is identified as external to the local AS.

Attribute Name: peer-as

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <vrf-peers>
            <vrf-peer>
              <peer-address>CML_IP_ADDR_T</peer-address>
              <config>
                <peer-address>CML_IP_ADDR_T</peer-address>
              </config>
                <peer-as>1</peer-as>
            </vrf-peer>
          </vrf-peers>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) remote-as <1-4294967295>
```

Configure source identifier

This attribute allows internal BGP sessions to use any operational interface for TCP connections. Use this attribute in conjunction with any specified interface on the router. The loopback interface is the interface that is most commonly used with this attribute. The use of loopback interface eliminates a dependency and BGP does not have to rely on the availability of a particular interface for making TCP connections.

Attribute Name: source-identifier

Attribute Type: string

Default Value: NULL

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      <vrf-peers>
      <vrf-peer>
        <peer-address>CML_IP_ADDR_T</peer-address>
        <config>
          <peer-address>CML_IP_ADDR_T</peer-address>
        </config>
        <source-identifier>WORD</source-identifier> <!--
operation="delete"-->
      </vrf-peer>
    </vrf-peers>
  </address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor update-source WORD
```

Configure bgp version

BGP Version. This attribute configures router to accept only a particular BGP version. By default, the system uses BGP version 4 and on request dynamically negotiates down to version 2. Using this attribute disables the routers version-negotiation capability and forces the router to use only a specified version with the neighbor.

Attribute Name: bgp-version

Attribute Type: uint8

Default Value: 4

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
      <address-family-vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        <vrf-peers>
        <vrf-peer>
          <peer-address>CML_IP_ADDR_T</peer-address>
          <config>
            <peer-address>CML_IP_ADDR_T</peer-address>
          </config>
          <bgp-version>(4)</bgp-version> <!-- operation="delete"-->
        </vrf-peer>
      </vrf-peers>
    </address-family-vrf>
  </address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor version (4)
```

Configure peer connection interval

Connect timer value. This attribute sets the timers for a specific BGP neighbor. Keepalive messages are sent by a router to inform another router that the BGP connection between the two is still active. The keepalive interval is the period of time between each keepalive message sent by the router. The holdtime interval is the time the router waits to receive a keepalive message and if it does not receive a message for this period it declares the neighbor dead.

Attribute Name: peer-connection-interval

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-65535

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    <vrf-peers>
    <vrf-peer>
      <peer-address>CML_IP_ADDR_T</peer-address>
      <config>
        <peer-address>CML_IP_ADDR_T</peer-address>
      </config>
      <peer-connection-interval>1</peer-connection-interval> <!--
operation="delete"-->
    </vrf-peer>
  </vrf-peers>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor timers connect <1-65535>
```

Configure hold time

Use this attribute to globally set or reset the holdtime values for all the neighbors.

Attribute Name: hold-time

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: keep-alive

Attribute Type: uint16

Attribute Range: 0-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </vrf-peers>
          <vrf-peer>
            <peer-address>CML_IP_ADDR_T</peer-address>
            <config>
              <peer-address>CML_IP_ADDR_T</peer-address>
            </config>
            <timers>
              <config>
                <keep-alive>0</keep-alive>
                <hold-time>0</hold-time>
              </config>
            </timers>
          </vrf-peer>
        </vrf-peers>
      </address-family-vrf>
    </address-family-vrfs>
  </bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor timers <0-65535> <0-65535>
```

Configure enforce multihop

This attribute turns on the enforcement of eBGP neighbors perform multihop.

Attribute Name: enforce-multihop

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
```

```

<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    <vrf-peers>
    <vrf-peer>
      <peer-address>CML_IP_ADDR_T</peer-address>
      <config>
        <peer-address>CML_IP_ADDR_T</peer-address>
      </config>
      </enforce-multihop><!-- operation="delete"-->
    </vrf-peer>
  </vrf-peers>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor enforce-multihop
```

Configure peer shutdown

This attribute disables a neighbor administratively. Use this attribute to terminate any active session for a specified neighbor and clear all related routing information. In case a peer group is specified for shutdown, a large number of peering sessions could be terminated.

Attribute Name: peer-shutdown

Attribute Type: uint8

Attribute Name: peer-shutdown-description

Attribute Type: string

Attribute Range: 1-255

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>

```

```
<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <address-family-vrfs>
  <address-family-vrf>
    <vrf-name>WORD</vrf-name>
    <config>
      <vrf-name>WORD</vrf-name>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  <vrf-peers>
  <vrf-peer>
    <peer-address>CML_IP_ADDR_T</peer-address>
    <config>
      <peer-address>CML_IP_ADDR_T</peer-address>
      <peer-shutdown-description>1</peer-shutdown-description> <!--
operation="delete"-->
    </config>
    </peer-shutdown><!-- operation="delete"-->
  </vrf-peer>
</vrf-peers>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor shutdown (description LINE|)
```

Configure peer group tag

Creates a peer group. Neighbors with the same update policies are grouped into peer groups. This facilitates the updates of various policies, such as distribute and filter lists. The peer group is then configured easily with any of the neighbor attributes. Any changes made to the peer group affect all members.

Attribute Name: peer-group-tag

Attribute Type: string

Attribute Name: peer-group-range

Attribute Type: union

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
```

```

<bgp-as>1</bgp-as>
<config>
  <bgp-as>1</bgp-as>
</config>
<address-family-vrfs>
<address-family-vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>WORD</vrf-name>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  </config>
  <safi>unicast</safi>
  <afi>ipv4</afi>
<peer-groups>
<peer-group> <!-- operation="delete"-->
  <peer-group-tag>WORD</peer-group-tag>
  <config>
    <peer-group-tag>WORD</peer-group-tag>
    <peer-group-range>0</peer-group-range>
  </config>
</peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD peer-group
```

Configure peer group range

this attribute creates a Dynamic peer group for address family. IPv4/IPv6 prefix range Must be specified to create dynamic peer group.

Attribute Name: peer-group-range

Attribute Type: union

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>

```

```
<vrf-name>WORD</vrf-name>
<config>
  <vrf-name>WORD</vrf-name>
  <safi>unicast</safi>
  <afi>ipv4</afi>
</config>
  <safi>unicast</safi>
  <afi>ipv4</afi>
<peer-groups>
<peer-group>
  <peer-group-tag>WORD</peer-group-tag>
  <config>
    <peer-group-tag>WORD</peer-group-tag>
  </config>
  <peer-group-range>A.B.C.D/M</peer-group-range>
</peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD peer-group range A.B.C.D/M
```

Configure safi

this attribute creates a Dynamic peer group for address family. IPv4/IPv6 prefix range Must be specified to create dynamic peer group.

Attribute Name: peer-group-range

Attribute Type: union

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
  <address-family-vrfs>
  <address-family-vrf>
    <vrf-name>WORD</vrf-name>
    <config>
      <vrf-name>WORD</vrf-name>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
```



```

    <safi>unicast</safi>
    <afi>ipv4</afi>
  <peer-groups>
  <peer-group>
    <peer-group-tag>WORD</peer-group-tag>
    <config>
      <peer-group-tag>WORD</peer-group-tag>
    </config>
    <peer-group-range> (X:X::X:X/M) </peer-group-range>
  </peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD peer-group range (X:X::X:X/M)
```

Configure vrf name

Creates a peer group. Neighbors with the same update policies are grouped into peer groups. This facilitates the updates of various policies, such as distribute and filter lists. The peer group is then configured easily with any of the neighbor attributes. Any changes made to the peer group affect all members.

Attribute Name: peer-group-tag

Attribute Type: string

Attribute Name: peer-group-range

Attribute Type: union

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```
<peer-groups>
  <peer-group> <!-- operation="delete"-->
    <peer-group-tag>WORD</peer-group-tag>
    <config>
      <peer-group-tag>WORD</peer-group-tag>
      <peer-group-range>0</peer-group-range>
    </config>
  </peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD peer-group
```

Configure group limit

Use this attribute to specify max number of peers in a dynamic peer-group for address family

Attribute Name: group-limit

Attribute Type: uint8

Attribute Range: 1-200

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </address-family-vrf>
      </address-family-vrfs>
      <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
        </peer-group>
      </peer-groups>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

        <group-limit>1</group-limit> <!-- operation="delete"-->
    </peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD limit <1-200>
```

Configure keep alive

Use this attribute to globally set or reset the holdtime values for all the neighbors.

Attribute Name: hold-time

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: keep-alive

Attribute Type: uint16

Attribute Range: 0-65535

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
              <config>
                <peer-group-tag>WORD</peer-group-tag>
              </config>
            <timers>
          </config>

```

```
        <keep-alive>0</keep-alive>
        <hold-time>0</hold-time>
    </config>
</timers>
</peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD timers <0-65535> <0-65535>
```

Configure peer shutdown description

This attribute disables a neighbor administratively. Use this attribute to terminate any active session for a specified neighbor and clear all related routing information. In case a peer group is specified for shutdown, a large number of peering sessions could be terminated.

Attribute Name: peer-shutdown

Attribute Type: uint8

Attribute Name: peer-shutdown-description

Attribute Type: string

Attribute Range: 1-255

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
        </peer-group>
      </config>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

        <peer-group-tag>WORD</peer-group-tag>
        <peer-shutdown-description>1</peer-shutdown-description> <!--
operation="delete"-->
        </config>
        </peer-shutdown><!-- operation="delete"-->
    </peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD shutdown (description LINE|)
```

Configure enabled

Use this attribute to accept and attempt BGP connections to external peers on indirectly connected networks. Multihop is not established if the only route to the multihop peer is a default route. This avoids loop formation.

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
    </peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      <ebgp-multihop>
    </config>
  </bgp-instance>
</bgp-instances>
</bgp>

```

```
        </enabled>
    </config>
</ebgp-multihop>
</peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD ebgp-multihop
```

Configure maximum hop count

Use this attribute to accept and attempt BGP connections to external peers on indirectly connected networks. Multihop is not established if the only route to the multihop peer is a default route. This avoids loop formation.

Attribute Name: enabled

Attribute Type: empty

Attribute Name: maximum-hop-count

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
        </peer-group>
      </address-family-vrf>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

        <ebgp-multihop>
        <config>
            <maximum-hop-count>1</maximum-hop-count> <!--
operation="delete"-->
            </enabled><!-- operation="delete"-->
        </config>
    </ebgp-multihop>
</peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD ebgp-multihop <1-255>
```

Configure neighbor passive

Use this attribute to set a BGP neighbor as passive.

Attribute Name: neighbor-passive

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
    <bgp-instance>
        <bgp-as>1</bgp-as>
        <config>
            <bgp-as>1</bgp-as>
        </config>
        <address-family-vrfs>
        <address-family-vrf>
            <vrf-name>WORD</vrf-name>
            <config>
                <vrf-name>WORD</vrf-name>
                <safi>unicast</safi>
                <afi>ipv4</afi>
            </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
        </peer-groups>
        <peer-group>
            <peer-group-tag>WORD</peer-group-tag>
            <config>
                <peer-group-tag>WORD</peer-group-tag>
            </config>
        </neighbor-passive><!-- operation="delete"-->
    </bgp-instance>
</bgp-instances>
</bgp>

```

```
        </peer-group>
    </peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD passive
```

Configure disable capability negotiation

Use this attribute to disable capability negotiation. The capability negotiation is performed by default. This attribute is used to allow compatibility with older BGP versions that have no capability parameters used in open messages between peers.

Attribute Name: disable-capability-negotiation

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      <peer-groups>
      <peer-group>
        <peer-group-tag>WORD</peer-group-tag>
        <config>
          <peer-group-tag>WORD</peer-group-tag>
        </config>
          </disable-capability-negotiation><!-- operation="delete"-->
        </peer-group>
      </peer-groups>
    </address-family-vrf>
  </address-family-vrfs>
</bgp-instance>
```



```
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD dont-capability-negotiate
```

Configure enable dynamic capability

Use this attribute to enable the dynamic capability for a specific peer. This attribute allows a BGP speaker to advertise or withdraw an address family capability to a peer in a non-disruptive manner.

Attribute Name: enable-dynamic-capability

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      </enable-dynamic-capability><!-- operation="delete"-->
    </peer-group>
  </peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD capability dynamic
```

Configure min route advertisement interval

Minimum route advertisement interval. Sets minimum interval between the sending of BGP routing updates. To reduce the flapping of routes to internet, a minimum advertisement interval is set, so that the BGP routing updates are sent only per interval seconds. BGP dampening can also be used to control the effects of flapping routes.

Attribute Name: min-route-advertisement-interval

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
              <config>
                <peer-group-tag>WORD</peer-group-tag>
              </config>
                <min-route-advertisement-interval>0</min-route-advertisement-
interval> <!-- operation="delete"-->
              </peer-group>
            </peer-groups>
          </address-family-vrf>
        </address-family-vrfs>
      </bgp-instance>
    </bgp-instances>
  </bgp>
```

Command Syntax

```
neighbor WORD advertisement-interval <0-65535>
```

Configure peer as origin interval

Time interval. This attribute adjust the interval of sending AS origination routing updates. This attribute is used to change the minimum interval between the sending of AS-origination routing updates.

Attribute Name: peer-as-origin-interval

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        <peer-groups>
          <peer-group>
            <peer-group-tag>WORD</peer-group-tag>
            <config>
              <peer-group-tag>WORD</peer-group-tag>
            </config>
            <peer-as-origin-interval>1</peer-as-origin-interval> <!--
operation="delete"-->
          </peer-group>
        </peer-groups>
      </address-family-vrf>
    </address-family-vrfs>
  </bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD as-origination-interval <1-65535>
```

Configure neighbor as override

Use this attribute to configure a PE router to override the Autonomous System Number (ASN) of a site with the ASN of a provider. BGP normally ignores the routes from the same AS. However, this attribute is used to override the customer's ASN in BGP, so that the customer CE accepts and installs routes from the same AS. Typically, this attribute is used when Customer Edge (CE) routers have the same ASN in some or all sites. As per BGP requirement, a BGP speaker rejects a route that has the same ASN as itself, in the AS_PATH attribute. Thus the CE routers having the same ASN do not accept routes from each other. Set neighborAsOverride attribute on the PE router removes the CE neighbors ASN from the AS_PATH attribute allowing CE routers with the same ASN to accept routes from each other.

Attribute Name: neighbor-as-override

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
              <config>
                <peer-group-tag>WORD</peer-group-tag>
              </config>
              </neighbor-as-override><!-- operation="delete"-->
            </peer-group>
          </peer-groups>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD as-override
```

Configure peer description

Use this attribute to associate a description with a neighbor. This attribute helps in identifying a neighbor quickly. It is useful for an ISP that has multiple neighbor relationships.

Attribute Name: peer-description

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
              <config>
                <peer-group-tag>WORD</peer-group-tag>
              </config>
              <peer-description>LINE</peer-description> <!-- operation="delete"-->
            </peer-group>
          </peer-groups>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD description LINE
```

Configure peer restart time

This attribute sets a different restart-time other than the global restart-time. This attribute takes precedence over the restart-time value specified using the graceful-restart-set attribute. The restart-time value is the maximum time that a graceful-restart neighbor waits to come back up after a restart. The default value is 120 seconds.

Attribute Name: peer-restart-time

Attribute Type: uint32

Attribute Range: 1-3600

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
              <config>
                <peer-group-tag>WORD</peer-group-tag>
              </config>
                <peer-restart-time>1</peer-restart-time> <!-- operation="delete"-->
              </peer-group>
            </peer-groups>
          </address-family-vrf>
        </address-family-vrfs>
      </bgp-instance>
    </bgp-instances>
  </bgp>
```

Command Syntax

```
neighbor WORD restart-time <1-3600>
```

Configure site origin identifier

Use this attribute to enable the site-of-origin (SOO) feature. If the customer AS is multi-homed to the ISP, this attribute ensures that the PE does not advertise the routes back to the same AS.

Attribute Name: site-origin-identifier

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      <peer-groups>
      <peer-group>
        <peer-group-tag>WORD</peer-group-tag>
        <config>
          <peer-group-tag>WORD</peer-group-tag>
        </config>
          <site-origin-identifier>AS:nn_or_IP:nn</site-origin-identifier> <!--
- operation="delete"-->
        </peer-group>
      </peer-groups>
    </address-family-vrf>
  </address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD soo AS:nn_or_IP:nn
```

Configure graceful shut

Use this attribute to start a graceful shutdown for the BGP session of the specified BGP neighbor. The BGP session for this neighbor is shut down after the graceful shutdown timer expires. If there is no alternate path available for traffic to flow prior the actual shutdown of the BGP session, this path is made available for 60 seconds or for configured time after which the path is no longer available and traffic is dropped.

Attribute Name: graceful-shut

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>

```

```
<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <address-family-vrfs>
  <address-family-vrf>
    <vrf-name>WORD</vrf-name>
    <config>
      <vrf-name>WORD</vrf-name>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  </peer-groups>
  <peer-group>
    <peer-group-tag>WORD</peer-group-tag>
    <config>
      <peer-group-tag>WORD</peer-group-tag>
    </config>
    </graceful-shut><!-- operation="delete"-->
  </peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD g-shut
```

Configure graceful shut timer

Use this attribute to configure the value of the graceful shutdown timer. After the timer expires, the BGP session initiated for graceful shutdown is shut down.

Attribute Name: graceful-shut-timer

Attribute Type: uint32

Attribute Range: 10-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
```



```

<address-family-vrfs>
<address-family-vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>WORD</vrf-name>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  </config>
  <safi>unicast</safi>
  <afi>ipv4</afi>
  <peer-groups>
  <peer-group>
    <peer-group-tag>WORD</peer-group-tag>
    <config>
      <peer-group-tag>WORD</peer-group-tag>
    </config>
    <graceful-shut-timer>10</graceful-shut-timer> <!--
operation="delete"-->
  </peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD g-shut-timer <10-65535>
```

Configure bgp port

The BGP port number of a neighbor

Attribute Name: bgp-port

Attribute Type: uint16

Default Value: 179

Attribute Range: 0-65535

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
  <address-family-vrfs>
  <address-family-vrf>
    <vrf-name>WORD</vrf-name>
    <config>

```

```
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
    </config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
    <peer-groups>
    <peer-group>
        <peer-group-tag>WORD</peer-group-tag>
        <config>
            <peer-group-tag>WORD</peer-group-tag>
        </config>
        <bgp-port>0</bgp-port> <!-- operation="delete"-->
    </peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD port <0-65535>
```

Configure enable ext opt param len

Use this attribute for a specific peer to encode extended optional parameter length.

Attribute Name: enable-ext-opt-param-len

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
    </peer-groups>
```

```

    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
    <config>
      <peer-group-tag>WORD</peer-group-tag>
    </config>
    </enable-ext-opt-param-len><!-- operation="delete"-->
  </peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD extended-optional-param
```

Configure tcp adjust mss

Use this attribute to set the BGP TCP MSS value of a neighbor.

Attribute Name: tcp-adjust-mss

Attribute Type: uint16

Attribute Range: 40-1440

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
            <config>
              <peer-group-tag>WORD</peer-group-tag>
            </config>
            <tcp-adjust-mss>40</tcp-adjust-mss> <!-- operation="delete"-->

```

```
        </peer-group>
    </peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD tcp-mss <40-1440>
```

Configure enable peer bfd

Enable bidirectional forwarding detection (BFD) for the BGP peer

Attribute Name: enable-peer-bfd

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      <peer-groups>
      <peer-group>
        <peer-group-tag>WORD</peer-group-tag>
        <config>
          <peer-group-tag>WORD</peer-group-tag>
        </config>
          </enable-peer-bfd><!-- operation="delete"-->
        </peer-group>
      </peer-groups>
    </address-family-vrf>
  </address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD fall-over bfd
```

Configure enable peer bfd multihop

Enable bidirectional forwarding detection (BFD) for the BGP peer with multihop

Attribute Name: enable-peer-bfd-multihop

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
              <config>
                <peer-group-tag>WORD</peer-group-tag>
              </config>
            </enable-peer-bfd-multihop><!-- operation="delete"-->
            </peer-group>
          </peer-groups>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD fall-over bfd multihop
```

Configure activate

Activate/Deactivate neighbor. This attribute enables or disables the exchange of AF information with a neighboring router.

Attribute Name: activate

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
              <config>
                <peer-group-tag>WORD</peer-group-tag>
              </config>
              </activate><!-- operation="delete"-->
            </peer-group>
          </peer-groups>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD activate
```

Configure default peer route map name

This attribute allows a BGP local router to send the default route 0.0.0.0 to a neighbor for use as a default route for specified address-family.

Attribute Name: default-peer-route-map-name

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      <peer-groups>
      <peer-group>
        <peer-group-tag>WORD</peer-group-tag>
        <config>
          <peer-group-tag>WORD</peer-group-tag>
        </config>
          </default-peer-route-map-name><!-- operation="delete"-->
        </peer-group>
      </peer-groups>
    </address-family-vrf>
  </address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD default-originate
```

Configure peer route map orig name

This attribute configures route map to be used for a BGP local router to send the default route 0.0.0.0 to a neighbor for use as a default route for specified address-family. This attribute can be used with standard or extended access lists.

Attribute Name: peer-route-map-orig-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
```

```
<bgp-instance>
  <bgp-as>1</bgp-as>
  <config>
    <bgp-as>1</bgp-as>
  </config>
  <address-family-vrfs>
  <address-family-vrf>
    <vrf-name>WORD</vrf-name>
    <config>
      <vrf-name>WORD</vrf-name>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    </config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  <peer-groups>
  <peer-group>
    <peer-group-tag>WORD</peer-group-tag>
    <config>
      <peer-group-tag>WORD</peer-group-tag>
    </config>
    <peer-route-map-orig-name>WORD</peer-route-map-orig-name> <!--
operation="delete"-->
  </peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD default-originate route-map WORD
```

Configure weight

This attribute specifies a weight value, for specified address-family, to all routes learned from a neighbor for specified address-family. The route with the highest weight gets preference when the same prefix is learned from more than one peer. Unlike the local-preference attribute, the weight attribute is relevant only to the local router. When the weight is set for a peer group, all members of the peer group get the same weight. This attribute can also be used to assign a different weight to an individual peer-group member. When an individually-configured weight of a peer-group member is removed, its weight is reset to its peer groups weight.

Attribute Name: weight

Attribute Type: uint16

Default Value: 0

Attribute Range: 0-65535

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
```



```

<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      <weight>0</weight> <!-- operation="delete"-->
    </peer-group>
  </peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD weight <0-65535>
```

Configure flowspec validation disable

This attribute specifies if FLOWSPEC validation should be disabled for a specific peer

Attribute Name: flowspec-validation-disable

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
    <address-family-vrfs>

```

```
<address-family-vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>WORD</vrf-name>
    <safi>unicast</safi>
    <afi>ipv4</afi>
  </config>
  <safi>unicast</safi>
  <afi>ipv4</afi>
</peer-groups>
<peer-group>
  <peer-group-tag>WORD</peer-group-tag>
  <config>
    <peer-group-tag>WORD</peer-group-tag>
  </config>
  </flowspec-validation-disable><!-- operation="delete"-->
</peer-group>
</peer-groups>
</address-family-vrfs>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD flowspec-validation-disable
```

Configure peer route reflector

This attribute configures the router as a BGP route reflector and configure the specified neighbor as its client for specified address-family. Route reflectors are a solution for the explosion of iBGP peering within an autonomous system. By route reflection the number of iBGP peers within an AS is reduced. Use this attribute to configure the local router as the route reflector and specify neighbors as its client. An AS can have more than one route reflector. One route reflector treats the other route reflector as another iBGP speaker.

Attribute Name: peer-route-reflector

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
    </bgp-instance>
  </bgp-instances>
  <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
    </address-family-vrf>
  </address-family-vrfs>
</bgp>
```

```

        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
    </config>
    <safi>unicast</safi>
    <afi>ipv4</afi>
    <peer-groups>
    <peer-group>
        <peer-group-tag>WORD</peer-group-tag>
    <config>
        <peer-group-tag>WORD</peer-group-tag>
    </config>
    </peer-route-reflector><!-- operation="delete"-->
    </peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD route-reflector-client
```

Configure peer remove private as

This attribute removes the private Autonomous System (AS) number from outbound updates. Private AS numbers are not advertised to the Internet. This attribute is used with external BGP peers only. The router removes the AS numbers only if the update includes private AS numbers. If the update includes both private and public AS numbers, the system treats it as an error.

Attribute Name: peer-remove-private-as

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>

```

```
    <safi>unicast</safi>
    <afi>ipv4</afi>
  <peer-groups>
  <peer-group>
    <peer-group-tag>WORD</peer-group-tag>
    <config>
      <peer-group-tag>WORD</peer-group-tag>
    </config>
    </peer-remove-private-as><!-- operation="delete"-->
  </peer-group>
</peer-groups>
</address-family-vrfs>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD remove-private-AS
```

Configure no send community

This attribute specifies if a community attribute should be sent to a BGP neighbor for specified address-family. The community attribute groups destinations in a certain community and applies routing decisions according to those communities. By default, both standard and extended community attributes are sent to a neighbor

Attribute Name: no-send-community

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
```

```

    <config>
      <peer-group-tag>WORD</peer-group-tag>
    </config>
    </no-send-community><!-- operation="delete"-->
  </peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
no neighbor WORD send-community
```

Configure no send community type

This attribute specifies the type of community attribute to be sent to a BGP neighbor.

Attribute Name: no-send-community-type

Attribute Type: bits (both|standard|extended|large)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
              <config>
                <peer-group-tag>WORD</peer-group-tag>
              </config>
              <no-send-community-type>both</no-send-community-type> <!--
operation="delete"-->
            </peer-group>
          </peer-groups>

```

```
    </address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
no neighbor WORD send-community (both|standard|extended|large)
```

Configure neighbor attribute unchanged

This attribute advertises unchanged BGP AS path, next hop and med to the specified neighbor.

Attribute Name: neighbor-attribute-unchanged

Attribute Type: bits (as-path|next-hop|med)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    <peer-groups>
    <peer-group>
      <peer-group-tag>WORD</peer-group-tag>
      <config>
        <peer-group-tag>WORD</peer-group-tag>
      </config>
      <neighbor-attribute-unchanged>14</neighbor-attribute-unchanged> <!--
- operation="delete"-->
    </peer-group>
  </peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD attribute-unchanged
```

Configure orf prefix capability

This attribute enables Outbound Router Filtering (ORF), and advertise the ORF capability to its neighbors. The ORFs send and receive capabilities to lessen the number of updates exchanged between neighbors. By filtering updates, this option minimizes generating and processing of updates. The two routers exchange updates to maintain the ORF for each router.

Attribute Name: orf-prefix-capability

Attribute Type: bits (both|receive|send)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
              <config>
                <peer-group-tag>WORD</peer-group-tag>
              </config>
              <orf-prefix-capability>both</orf-prefix-capability> <!--
operation="delete"-->
            </peer-group>
          </peer-groups>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD capability orf prefix-list (both|receive|send)
```

Configure peer allow ebgp vpn

This attribute allows an eBGP neighbor to be a VPN peer. By default, BGP VPN functionality is allowed only for iBGP peers. Using the peer-allow-ebgp-vpn attribute allows the VPN connection to be established to an eBGP peer.

Attribute Name: peer-allow-ebgp-vpn

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
              <config>
                <peer-group-tag>WORD</peer-group-tag>
              </config>
                </peer-allow-ebgp-vpn><!-- operation="delete"-->
              </peer-group>
            </peer-groups>
          </address-family-vrf>
        </address-family-vrfs>
      </bgp-instance>
    </bgp-instances>
  </bgp>
```

Command Syntax

```
neighbor WORD allow-ebgp-vpn
```

Configure allow as number

This attribute advertises prefixes (routes) even when the source of the prefixes is from the same Autonomous System (AS) number for specified address-family. Use this attribute in a scenario where two routers at different locations use the same Autonomous System number and are connected via an ISP. Once prefixes arrive from one branch at the ISP, they are tagged with the customers AS number. By default, when the ISP passes the prefixes to the other router, the

prefixes are dropped if the other router uses the same AS number. Use this attribute to advertise the prefixes at the other side. Control the number of times an AS number is advertised by specifying a number. In a hub and spoke configuration in a VPN, a PE (Provider Edge) router advertises all prefixes containing duplicate AS numbers. Use this attribute to configure two VRFs on each PE router to receive and advertise prefixes. One of the VRFs receives prefixes with AS numbers from all PE routers and then advertises them to neighboring PE routers. The other VRF receives prefixes with AS numbers from the CE (Customer Edge) router and advertises them to all PE routers in the hub and spoke configuration.

Attribute Name: allow-as-number

Attribute Type: uint32

Default Value: 3

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
              <config>
                <peer-group-tag>WORD</peer-group-tag>
              </config>
                <allow-as-number>1</allow-as-number> <!-- operation="delete"-->
              </peer-group>
            </peer-groups>
          </address-family-vrf>
        </address-family-vrfs>
      </bgp-instance>
    </bgp-instances>
  </bgp>
```

Command Syntax

```
neighbor WORD allowas-in <1-10>
```

Configure capability graceful restart

This attribute configures the router to advertise the Graceful Restart Capability to the neighbors. This configuration indicates that the BGP speaker has the ability to preserve its forwarding state for the address family when BGP restarts. Use this attribute to advertise to the neighbor routers the capability of graceful restart.

Attribute Name: capability-graceful-restart

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
              <config>
                <peer-group-tag>WORD</peer-group-tag>
              </config>
                </capability-graceful-restart><!-- operation="delete"-->
              </peer-group>
            </peer-groups>
          </address-family-vrf>
        </address-family-vrfs>
      </bgp-instance>
    </bgp-instances>
  </bgp>
```

Command Syntax

```
neighbor WORD capability graceful-restart
```

Configure prefix count

This attribute specifies number of prefixes that a BGP router is allowed to receive from a neighbor. When the maximum-prefix-warning attribute is not set and extra prefixes are received, the router ends the peering.

Attribute Name: prefix-count

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <maximum-prefixes>
            <maximum-prefix> <!-- operation="delete"-->
              <prefix-count>1</prefix-count>
            <config>
              <prefix-count>1</prefix-count>
            </config>
          </maximum-prefix>
        </maximum-prefixes>
      </peer-group>
    </peer-groups>
  </address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD maximum-prefix <1-4294967295>
```

Configure stop update

Stop installing the routes when limit is exceeded.

Attribute Name: stop-update

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
      <address-family-vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        <peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <maximum-prefixes>
          <maximum-prefix>
            <prefix-count>1</prefix-count>
            <config>
              <prefix-count>1</prefix-count>
            </config>
            </stop-update>
          </maximum-prefix>
          </maximum-prefixes>
        </peer-group>
      </peer-groups>
    </address-family-vrf>
  </address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD maximum-prefix <1-4294967295> stop-update
```

Configure maximum prefix warning

This attribute when enabled only give warning message when limit is exceeded. When it is not set and extra prefixes are received, the router ends the peering.

Attribute Name: maximum-prefix-warning

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        <peer-groups>
          <peer-group>
            <peer-group-tag>WORD</peer-group-tag>
            <config>
              <peer-group-tag>WORD</peer-group-tag>
            </config>
            <maximum-prefixes>
              <maximum-prefix>
                <prefix-count>1</prefix-count>
                <config>
                  <prefix-count>1</prefix-count>
                </config>
              </maximum-prefix-warning>
            </maximum-prefix>
          </maximum-prefixes>
        </peer-group>
      </peer-groups>
    </address-family-vrf>
  </address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD maximum-prefix <1-4294967295> warning-only
```

Configure threshold percentage

Threshold-value in percen. This attribute controls the number of prefixes that can be received from a neighbor. This attribute allows the configuration of a specified number of prefixes that a BGP router is allowed to receive from a neighbor. When the maximum-prefix-warning attribute is not set and extra prefixes are received, the router ends the peering.

Attribute Name: threshold-percentage

Attribute Type: uint8

Default Value: 75

Attribute Range: 1-100

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <maximum-prefixes>
            <maximum-prefix>
              <prefix-count>1</prefix-count>
              <config>
                <prefix-count>1</prefix-count>
              </config>
            </maximum-prefix>
          </maximum-prefixes>
        </peer-group>
      </address-family-vrf>
    </address-family-vrfs>
  </bgp-instance>
</bgp-instances>
</bgp>
```

```

    </peer-groups>
  </address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD maximum-prefix <1-4294967295> <1-100>
```

Configure warning only

Throw warning if exceeds threshold-value

Attribute Name: warning-only

Attribute Type: uint8

Attribute Name: threshold-percentage

Attribute Type: uint8

Default Value: 75

Attribute Range: 1-100

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
          <maximum-prefixes>
            <maximum-prefix>
              <prefix-count>1</prefix-count>
            </config>
          </maximum-prefixes>
        </peer-group>
      </address-family-vrf>
    </address-family-vrfs>
  </bgp-instance>
</bgp-instances>
</bgp>

```

```

        <prefix-count>1</prefix-count>
        <threshold-percentage>1</threshold-percentage>
    </config>
    </warning-only>
</maximum-prefix>
</maximum-prefixes>
</peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD maximum-prefix <1-4294967295> <1-100> warning-only
```

Configure unsuppress route map name

unsuppress map name. This attribute is used to selectively leak more-specific routes to a particular neighbor.

Attribute Name: unsuppress-route-map-name

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </peer-groups>
          <peer-group>
            <peer-group-tag>WORD</peer-group-tag>
            <config>
              <peer-group-tag>WORD</peer-group-tag>
            </config>
            <unsuppress-route-map-name>WORD</unsuppress-route-map-name> <!--
operation="delete"-->

```



```

        </peer-group>
    </peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD unsuppress-map WORD
```

Configure access list identifier

Access List information

Attribute Name: access-list-identifier

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <peer-groups>
            <peer-group>
              <peer-group-tag>WORD</peer-group-tag>
              <config>
                <peer-group-tag>WORD</peer-group-tag>
              </config>
              <distribute-list-filters>
                <distribute-list-filter>
                  <filter-direction>in</filter-direction>
                  <config>
                    <filter-direction>in</filter-direction>
                  </config>
                  <access-list-identifier>WORD</access-list-identifier>
                </distribute-list-filter>

```

```
        </distribute-list-filters>
    </peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD distribute-list WORD (in|out)
```

Configure as access list identifier

Access-list number. This attribute sets a BGP filter. This attribute specifies an access list filter on updates based on the BGP autonomous system paths. Each filter is an access list based on regular expressions

Attribute Name: as-access-list-identifier

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </peer-groups>
          <peer-group>
            <peer-group-tag>WORD</peer-group-tag>
            <config>
              <peer-group-tag>WORD</peer-group-tag>
            </config>
            <as-list-filters>
              <as-list-filter>
                <as-list-direction>in</as-list-direction>
                <config>
                  <as-list-direction>in</as-list-direction>
                </config>
              </as-list-filter>
            </as-list-filters>
          </peer-group>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

        <as-access-list-identifier>WORD</as-access-list-identifier>
    </as-list-filter>
</as-list-filters>
</peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD filter-list WORD (in|out)
```

Configure prefix list name

This attribute specifies a prefix list for filtering BGP advertisements for specified address-family. Filtering by prefix list matches the prefixes of routes with those listed in the prefix list. If there is a match, the route is used. An empty prefix list permits all prefixes. If a given prefix does not match any entries of a prefix list, the route is denied access. When multiple entries of a prefix list match a prefix, the entry with the smallest sequence number is considered to be a real match. The router begins the search at the top of the prefix list, with the sequence number 1. Once a match or deny occurs, the router does not need to go through the rest of the prefix list. For efficiency the most common matches or denials are listed at the top.

Attribute Name: prefix-list-name

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </peer-groups>
          <peer-group>
            <peer-group-tag>WORD</peer-group-tag>
            <config>
              <peer-group-tag>WORD</peer-group-tag>
            </config>

```

```
<prefix-list-filters>
  <prefix-list-filter>
    <prefix-filter-direction>in</prefix-filter-direction>
    <config>
      <prefix-filter-direction>in</prefix-filter-direction>
    </config>
    <prefix-list-name>WORD</prefix-list-name>
  </prefix-list-filter>
</prefix-list-filters>
</peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD prefix-list WORD (in|out)
```

Configure route map name

Use this attribute to apply a route map to incoming or outgoing routes. This attribute filters updates and modifies attributes. A route map is applied to inbound or outbound updates. Only the routes that pass the route map are sent or accepted in updates.

Attribute Name: route-map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

    <peer-group-tag>WORD</peer-group-tag>
  <config>
    <peer-group-tag>WORD</peer-group-tag>
  </config>
  <route-map-filters>
  <route-map-filter>
    <route-map-direction>in</route-map-direction>
    <config>
      <route-map-direction>in</route-map-direction>
    </config>
    <route-map-name>WORD</route-map-name>
  </route-map-filter>
</route-map-filters>
</peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor WORD route-map WORD (in|out)
```

Configure peer address

Use this attribute to configure the authentication key to specify if the password is to be encrypted or not.

Attribute Name: auth-key-encrypt

Attribute Type: enum (0|1)

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <vrf-peers>

```

```
<vrf-peer>
  <peer-address>CML_IP_ADDR_T</peer-address>
  <config>
    <peer-address>CML_IP_ADDR_T</peer-address>
  </config>
  <bgp-passwords>
  <bgp-password>
    <password>WORD</password>
    <config>
      <password>WORD</password>
    </config>
    <auth-key-encrypt>1</auth-key-encrypt>
  </bgp-password>
</bgp-passwords>
</vrf-peer>
</vrf-peers>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor authentication-key (0|1) WORD
```

Configure password

Use this attribute to configure the authentication key to specify if the password is to be encrypted or not.

Attribute Name: auth-key-encrypt

Attribute Type: enum (0|1)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
      <address-family-vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
```

```

    <vrf-peers>
    <vrf-peer>
      <peer-address>CML_IP_ADDR_T</peer-address>
      <config>
        <peer-address>CML_IP_ADDR_T</peer-address>
      </config>
      <bgp-passwords>
      <bgp-password>
        <password>WORD</password>
        <config>
          <password>WORD</password>
        </config>
        <auth-key-encrypt>2</auth-key-encrypt>
      </bgp-password>
    </bgp-passwords>
  </vrf-peer>
</vrf-peers>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor authentication-key WORD
```

Configure peer interface name

Interface name. Configures IP address or IPv6 address on interface

Attribute Name: peer-interface-name

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
    </address-family-vrf>
  </bgp-instance>
</bgp-instances>

```

```
        <afi>ipv4</afi>
    <vrf-peers>
    <vrf-peer>
        <peer-address>CML_IP_ADDR_T</peer-address>
        <config>
            <peer-address>CML_IP_ADDR_T</peer-address>
        </config>
        <peer-interface-name>WORD</peer-interface-name> <!--
operation="delete"-->
    </vrf-peer>
</vrf-peers>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) interface WORD
```

Configure de activate

Deactivate neighbor. This attribute disables the exchange of AF information with a neighboring router.

Attribute Name: de-activate

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
    <bgp-instance>
        <bgp-as>1</bgp-as>
        <config>
            <bgp-as>1</bgp-as>
        </config>
        <address-family-vrfs>
        <address-family-vrf>
            <vrf-name>WORD</vrf-name>
            <config>
                <vrf-name>WORD</vrf-name>
                <safi>unicast</safi>
                <afi>ipv4</afi>
            </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
        </vrf-peers>
        <vrf-peer>
            <peer-address>CML_IP_ADDR_T</peer-address>
            <config>
                <peer-address>CML_IP_ADDR_T</peer-address>
```



```

    </config>
    </de-activate><!-- operation="delete"-->
  </vrf-peer>
</vrf-peers>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor de-activate
```

Configure mapped peer group tag af

BGP peer group name. Adds a neighbor to an existing peer group. Neighbors with the same update policies are grouped into peer groups. This facilitates the updates of various policies, such as distribute and filter lists. The peer group is then configured easily with any of the neighbor attributes. Any changes made to the peer group affect all members.

Attribute Name: mapped-peer-group-tag-af

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <vrf-peers>
            <vrf-peer>
              <peer-address>CML_IP_ADDR_T</peer-address>
              <config>
                <peer-address>CML_IP_ADDR_T</peer-address>
              </config>
              <mapped-peer-group-tag-af>WORD</mapped-peer-group-tag-af> <!--
operation="delete"-->
            </vrf-peer>
          </vrf-peers>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```
    </address-family-vrf>  
</address-family-vrfs>  
</bgp-instance>  
</bgp-instances>  
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) peer-group WORD
```

Configure filter direction

Access List information

Attribute Name: access-list-identifier

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">  
<bgp-instances>  
  <bgp-instance>  
    <bgp-as>1</bgp-as>  
    <config>  
      <bgp-as>1</bgp-as>  
    </config>  
    <address-family-vrfs>  
    <address-family-vrf>  
      <vrf-name>WORD</vrf-name>  
      <config>  
        <vrf-name>WORD</vrf-name>  
        <safi>unicast</safi>  
        <afi>ipv4</afi>  
      </config>  
      <safi>unicast</safi>  
      <afi>ipv4</afi>  
    <vrf-peers>  
    <vrf-peer>  
      <peer-address>CML_IP_ADDR_T</peer-address>  
      <config>  
        <peer-address>CML_IP_ADDR_T</peer-address>  
      </config>  
      <distribute-list-filters>  
      <distribute-list-filter>  
        <filter-direction>in</filter-direction>  
        <config>  
          <filter-direction>in</filter-direction>  
        </config>  
        <access-list-identifier>WORD</access-list-identifier>  
      </distribute-list-filter>  
    </distribute-list-filters>  
    </vrf-peer>
```

```

    </vrf-peers>
  </address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor distribute-list WORD (in|out)
```

Configure as list direction

Access-list number. This attribute sets a BGP filter. This attribute specifies an access list filter on updates based on the BGP autonomous system paths. Each filter is an access list based on regular expressions

Attribute Name: as-access-list-identifier

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </address-family-vrf>
      </address-family-vrfs>
      <vrf-peers>
        <vrf-peer>
          <peer-address>CML_IP_ADDR_T</peer-address>
          <config>
            <peer-address>CML_IP_ADDR_T</peer-address>
          </config>
          <as-list-filters>
            <as-list-filter>
              <as-list-direction>in</as-list-direction>
              <config>
                <as-list-direction>in</as-list-direction>
              </config>
              <as-access-list-identifier>WORD</as-access-list-identifier>
            </as-list-filter>
          </as-list-filters>
        </vrf-peer>
      </vrf-peers>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

```
        </as-list-filters>
    </vrf-peer>
</vrf-peers>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor filter-list WORD (in|out)
```

Configure prefix filter direction

This attribute specifies a prefix list for filtering BGP advertisements for specified address-family. Filtering by prefix list matches the prefixes of routes with those listed in the prefix list. If there is a match, the route is used. An empty prefix list permits all prefixes. If a given prefix does not match any entries of a prefix list, the route is denied access. When multiple entries of a prefix list match a prefix, the entry with the smallest sequence number is considered to be a real match. The router begins the search at the top of the prefix list, with the sequence number 1. Once a match or deny occurs, the router does not need to go through the rest of the prefix list. For efficiency the most common matches or denials are listed at the top.

Attribute Name: prefix-list-name

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <vrf-peers>
            <vrf-peer>
              <peer-address>CML_IP_ADDR_T</peer-address>
              <config>
                <peer-address>CML_IP_ADDR_T</peer-address>
              </config>
            <prefix-list-filters>
            <prefix-list-filter>
```

```

        <prefix-filter-direction>in</prefix-filter-direction>
        <config>
            <prefix-filter-direction>in</prefix-filter-direction>
        </config>
        <prefix-list-name>WORD</prefix-list-name>
    </prefix-list-filter>
</prefix-list-filters>
</vrf-peer>
</vrf-peers>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor prefix-list WORD (in|out)
```

Configure route map direction

Use this attribute to apply a route map to incoming or outgoing routes. This attribute filters updates and modifies attributes. A route map is applied to inbound or outbound updates. Only the routes that pass the route map are sent or accepted in updates.

Attribute Name: route-map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <vrf-peers>
            <vrf-peer>
              <peer-address>CML_IP_ADDR_T</peer-address>
            <config>

```

```
        <peer-address>CML_IP_ADDR_T</peer-address>
    </config>
    <route-map-filters>
    <route-map-filter>
        <route-map-direction>in</route-map-direction>
        <config>
            <route-map-direction>in</route-map-direction>
        </config>
        <route-map-name>WORD</route-map-name>
    </route-map-filter>
    </route-map-filters>
</vrf-peer>
</vrf-peers>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor route-map WORD (in|out)
```

Configure identifier

This attribute to specifies a BGP confederation identifier.

Attribute Name: identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <confederation>
        </confederation>
      </config>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

```

        <identifier>1</identifier> <!-- operation="delete"-->
    </config>
</confederation>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp confederation identifier <1-4294967295>
```

Configure peer as number

Use this attribute to configure the Autonomous Systems (AS) that belong to a confederation. A confederation allows an AS to be divided into several ASs. The AS is given a confederation identifier. External BGP (eBGP) routers view only the whole confederation as one AS. Each AS is fully meshed within itself and is visible internally to the confederation.

Attribute Name: peer-as-number

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
      <safi>unicast</safi>
      <afi>ipv4</afi>
    <confederation>
    <config>
      <peer-as-number>1</peer-as-number> <!-- operation="delete"-->
    </config>
    </confederation>
  </address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp confederation peers .<1-4294967295>
```

Configure enable dampening

Use this attribute to enable route flap dampening

Attribute Name: enable-dampening

Attribute Type: enum (enable-dampening)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
          <route-flap-dampenings>
            <route-flap-dampening> <!-- operation="delete"-->
              <enable-dampening>enable-dampening</enable-dampening>
              <config>
                <enable-dampening>enable-dampening</enable-dampening>
              </config>
            </route-flap-dampening>
          </route-flap-dampenings>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp dampening
```

Configure reach half life

Use this attribute to configure reachability half-life time for the penalty in minutes for the bgp route dampening. The time for the penalty to decrease to one-half of its current value.

Attribute Name: reach-half-life

Attribute Type: uint32

Default Value: 15

Attribute Range: 1-45

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <route-flap-dampenings>
            <route-flap-dampening>
              <enable-dampening>enable-dampening</enable-dampening>
              <config>
                <enable-dampening>enable-dampening</enable-dampening>
              </config>
                <reach-half-life>1</reach-half-life> <!-- operation="delete"-->
              </route-flap-dampening>
            </route-flap-dampenings>
          </address-family-vrf>
        </address-family-vrfs>
      </bgp-instance>
    </bgp-instances>
  </bgp>
```

Command Syntax

```
bgp dampening <1-45>
```

Configure max suppress time

Use this attribute to configure the value to start suppressing a route for BGP route dampening. When the penalty for a route exceeds the suppress value, the route is suppressed

Attribute Name: max-suppress-time

Attribute Type: uint32

Attribute Range: 1-255

Attribute Name: reach-half-life

Attribute Type: uint32

Attribute Range: 1-45

Attribute Name: reuse-penalty

Attribute Type: uint32

Attribute Range: 1-20000

Attribute Name: suppress-penalty

Attribute Type: uint32

Attribute Range: 1-20000

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
          <route-flap-dampenings>
            <route-flap-dampening>
              <enable-dampening>enable-dampening</enable-dampening>
              <config>
                <enable-dampening>enable-dampening</enable-dampening>
                <reach-half-life>1</reach-half-life> <!-- operation="delete"-->
                <reuse-penalty>1</reuse-penalty> <!-- operation="delete"-->
                <suppress-penalty>1</suppress-penalty> <!-- operation="delete"-->
              </config>
              <max-suppress-time>1</max-suppress-time> <!-- operation="delete"-->
            </route-flap-dampening>
          </route-flap-dampenings>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
bgp dampening <1-45> <1-20000> <1-20000> <1-255>
```

Configure unreachable half life

Use this attribute to configure un-reachability half-life time for the penalty in minutes for bgp route dampening. The dampening information is purged from the router once the penalty becomes less than half of the reuse limit.

Attribute Name: unreachable-half-life

Attribute Type: uint32

Attribute Range: 1-45

Attribute Name: reach-half-life

Attribute Type: uint32

Attribute Range: 1-45

Attribute Name: reuse-penalty

Attribute Type: uint32

Attribute Range: 1-20000

Attribute Name: suppress-penalty

Attribute Type: uint32

Attribute Range: 1-20000

Attribute Name: max-suppress-time

Attribute Type: uint32

Attribute Range: 1-255

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <route-flap-dampenings>
            <route-flap-dampening>
              <enable-dampening>enable-dampening</enable-dampening>
```

```

    <config>
      <enable-dampening>enable-dampening</enable-dampening>
      <reach-half-life>1</reach-half-life> <!-- operation="delete"-->
      <reuse-penalty>1</reuse-penalty> <!-- operation="delete"-->
      <suppress-penalty>1</suppress-penalty> <!-- operation="delete"-->
      <max-suppress-time>1</max-suppress-time> <!-- operation="delete"-->
    </config>
    <unreach-half-life>1</unreach-half-life> <!-- operation="delete"-->
  </route-flap-dampening>
</route-flap-dampenings>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp dampening <1-45> <1-20000> <1-20000> <1-255> <1-45>
```

Configure dampening rmap name

Use this attribute to configure route map to specify criteria for dampening.

Attribute Name: dampening-rmap-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <route-flap-dampenings>
            <route-flap-dampening>
              <enable-dampening>enable-dampening</enable-dampening>
            <config>
              <enable-dampening>enable-dampening</enable-dampening>

```

```

        </config>
        <dampening-rmap-name>WORD</dampening-rmap-name> <!--
operation="delete"-->
        </route-flap-dampening>
    </route-flap-dampenings>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
bgp dampening route-map WORD
```

Configure bgpSRv6enable

This attribute enable Segment Routing V6

Attribute Name: bgpSRv6enable

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <address-family-vrfs>
    <address-family-vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      </config>
        <safi>unicast</safi>
        <afi>ipv4</afi>
      <bgp-srv6>
      <config>
        </bgpSRv6enable>
      </config>
    </bgp-srv6>
    </address-family-vrf>
  </address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
segment-routing srv6
```

Configure sid alloc type

sid-alloc

This command is supported when following feature are enabled Segment routing V6 feature

Attribute Name: sid-alloc-type

Attribute Type: enum (per-vrf)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <bgp-srv6>
            <sid-alloc-mode>
              <config>
                <sid-alloc-type>per-vrf</sid-alloc-type> <!-- operation="delete"-->
              </config>
            </sid-alloc-mode>
          </bgp-srv6>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
sid-alloc (per-vrf)
```

Configure peer local as

Specifies an AS (autonomous system) number to use with BGP neighbor.

Attribute Name: peer-local-as

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        <vrf-peers>
          <vrf-peer>
            <peer-address>CML_IP_ADDR_T</peer-address>
            <config>
              <peer-address>CML_IP_ADDR_T</peer-address>
            </config>
            <local-as>
              <local-as-list> <!-- operation="delete"-->
                <peer-local-as>1</peer-local-as>
              <config>
                <peer-local-as>1</peer-local-as>
              </config>
            </local-as-list>
          </local-as>
        </vrf-peer>
      </vrf-peers>
    </address-family-vrf>
  </address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor local-as <1-4294967295>
```

Configure no prepend local as

Specifies an AS (autonomous system) number to use with BGP neighbor.

Attribute Name: peer-local-as

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: no-prepend-local-as

Attribute Type: empty

Attribute Name: replace-local-as

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <vrf-peers>
            <vrf-peer>
              <peer-address>CML_IP_ADDR_T</peer-address>
              <config>
                <peer-address>CML_IP_ADDR_T</peer-address>
              </config>
              <local-as>
                <local-as-list>
                  <peer-local-as>1</peer-local-as>
                  <config>
                    <peer-local-as>1</peer-local-as>
                    </no-prepend-local-as>
                    </replace-local-as>
                  </config>
                </local-as-list>
              </local-as>
            </vrf-peer>
          </vrf-peers>
        </address-family-vrf>
      </address-family-vrfs>
    </bgp-instance>
  </bgp-instances>
```

```
</bgp>
```

Command Syntax

```
neighbor local-as <1-4294967295> (no-prepend|) (replace-as|)
```

Configure backdoor

network address with backdoor for address family

Attribute Name: backdoor

Attribute Type: uint8

Attribute Name: network-rmap-name

Attribute Type: string

Default Value: NULL

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          <network-lists>
            <network-list>
              <local-network-prefix>A.B.C.D</local-network-prefix>
              <config>
                <local-network-prefix>BGP_IP_NETWORK_T</local-network-prefix>
                <network-rmap-name>WORD</network-rmap-name>
              </config>
            </backdoor>
          </network-list>
        </network-lists>
      </address-family-vrf>
    </address-family-vrfs>
  </bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
network (A.B.C.D | A.B.C.D/M) (route-map WORD|) (backdoor|)
```

Configure local network prefix

network address with backdoor for address family

Attribute Name: backdoor

Attribute Type: uint8

Attribute Name: network-rmap-name

Attribute Type: string

Default Value: NULL

Attribute Range: 1-63

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </address-family-vrf>
      </address-family-vrfs>
      <network-lists>
        <network-list>
          <local-network-prefix>A.B.C.D</local-network-prefix>
          <config>
            <local-network-prefix>BGP_IP_NETWORK_T</local-network-prefix>
            <network-rmap-name>WORD</network-rmap-name>
          </config>
        </network-list>
      </network-lists>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
network (X:X::X:X/M) (route-map WORD|) (backdoor|)
```

Configure replace local as

Specifies an AS (autonomous system) number to use with BGP neighbor.

Attribute Name: peer-local-as

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: no-prepend-local-as

Attribute Type: empty

Attribute Name: replace-local-as

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <address-family-vrfs>
        <address-family-vrf>
          <vrf-name>WORD</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <safi>unicast</safi>
            <afi>ipv4</afi>
          </config>
          <safi>unicast</safi>
          <afi>ipv4</afi>
        </peer-groups>
        <peer-group>
          <peer-group-tag>WORD</peer-group-tag>
          <config>
            <peer-group-tag>WORD</peer-group-tag>
          </config>
        <local-as>
          <local-as-list>
            <peer-local-as>1</peer-local-as>
            <config>
              <peer-local-as>1</peer-local-as>
              </no-prepend-local-as>
              </replace-local-as>
            </config>
          </local-as-list>
        </local-as>
      </address-family-vrf>
    </address-family-vrfs>
  </bgp-instance>
</bgp-instances>
</bgp>
```

```
        </local-as>
    </peer-group>
</peer-groups>
</address-family-vrf>
</address-family-vrfs>
</bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor WORD local-as <1-4294967295> (no-prepend|) (replace-as|)
```

clear ip bgp all vrf (VRFNAME|all|default) (description LINE|)

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: peer-reset-description

Attribute Type: string

Attribute Range: 1-255

Netconf RPC payload

```
<ipi-bgp-address-family-vrf_clear-ip-bgp-all-vrf xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <vrf-name>VRFNAME</vrf-name>
  <peer-reset-description>l</peer-reset-description>
</ipi-bgp-address-family-vrf_clear-ip-bgp-all-vrf>
```

Command Syntax

```
clear ip bgp all vrf (VRFNAME|all|default) (description LINE|)
```

clear ip bgp vrf WORD (A.B.C.D|X:X::X:X|WORD|WORD) (description LINE|)

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: address

Attribute Type: union

Attribute Name: peer-reset-description

Attribute Type: string

Attribute Range: 1-255

Netconf RPC payload

```
<ipi-bgp-address-family-vrf_clear-ip-bgp-vrf-peer xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <vrf-name>WORD</vrf-name>
  <address>BGP_HOSTNAME_T</address>
  <peer-reset-description>l</peer-reset-description>
```

```
</ipi-bgp-address-family-vrf_clear-ip-bgp-vrf-peer>
```

Command Syntax

```
clear ip bgp vrf WORD (A.B.C.D|X:X::X:X|WORD|WORD) (description LINE|)
```

IPI-BGP-VRF

Configure rd string

Use this attribute to assign a route distinguisher (RD) for the VRF. The route distinguisher value must be a unique value on the router. This attribute creates routing and forwarding tables and specifies the default RD for a VPN. The RD is added to the customers IPv4 prefixes, changing them into globally unique VPN-IPv4 prefixes.

Attribute Name: rd-string

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
      <bgp-vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp-vrf">
        <config>
          <rd-string>ASN:nn_or_IP-address:nn</rd-string> <!--
operation="delete"-->
        </config>
      </bgp-vrf>
    </vrf>
  </network-instance>
</network-instances>
```

Command Syntax

```
rd ASN:nn_or_IP-address:nn
```

Configure import map

This attribute assigns a route map to the VRF. This map is applied for routing information imported from another PE or VRF. Use this attribute when an application requires finer control over the routes imported into a VRF than provided by the import and export extended communities. You can filter routes that are eligible for import into a VRF through the use of a route map. The route map can deny access to selected routes from a community that is on the import list.

Attribute Name: import-map

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
  <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
    <bgp-vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp-vrf">
      <config>
        <import-map>WORD</import-map> <!-- operation="delete"-->
      </config>
    </bgp-vrf>
  </vrf>
</network-instance>
</network-instances>
```

Command Syntax

```
import map WORD
```

Configure export map

export map name

Attribute Name: export-map

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
  <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
    <bgp-vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp-vrf">
      <config>
        <export-map>WORD</export-map> <!-- operation="delete"-->
      </config>
    </bgp-vrf>
  </vrf>
</network-instance>
```

```
</network-instances>
```

Command Syntax

```
export map WORD
```

Configure direction

Use this attribute to add a list of import and export route-target extended communities to the VRF. This attribute creates lists of import and export route-target extended communities for the VRF. It specifies a target VPN extended community. All routes with the specific route-target extended community are imported into all VRFs with the same extended community as an import route-target.

Attribute Name: direction

Attribute Type: bits (import|export|both)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
      <bgp-vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp-vrf">
        <route-targets>
          <route-target>
            <rt-rd-string>BGP_ROUTE_TARGET_TYPE_T</rt-rd-string>
            <config>
              <rt-rd-string>BGP_ROUTE_TARGET_TYPE_T</rt-rd-string>
            </config>
            <direction>import</direction>
          </route-target>
        </route-targets>
      </bgp-vrf>
    </vrf>
  </network-instance>
</network-instances>
```

Command Syntax

```
route-target (import|export|both) (ASN:nn_or_IP-address:nn|evpn-auto-rt)
```

Configure service type

Vlan-Based EVPN-Service Type

This command is supported when following feature are enabled MPLS feature enabled, bgp evpn feature enabled

Attribute Name: service-type

Attribute Type: enum (vlan-based|vlan-aware-bundle)

Default Value: vlan-aware-bundle

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vrf</instance-type>
    <vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrf">
      <evpn-service-type xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp-vrf">
        <config>
          <service-type>vlan-aware-bundle</service-type> <!--
operation="delete"-->
        </config>
      </evpn-service-type>
    </vrf>
  </network-instance>
</network-instances>
```

Command Syntax

```
evpn-vlan-service (vlan-based|vlan-aware-bundle)
```

IPI-BGP-EPE

Configure enable epe

Use this attribute to enable Egress Peer Engineering for bgp

Attribute Name: enable-epe

Attribute Type: uint8

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peer-engineering>
        <config>
          </enable-epe><!-- operation="delete"-->
        </config>
      </peer-engineering>
    </bgp-instance>
  </bgp-instances>
</bgp>
```



```

    </peer-engineering>
  </bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
egress-engineering
```

Configure enable peer node

Use this attribute to enable peer node SID for bgp neighbor

Attribute Name: enable-peer-node

Attribute Type: uint8

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance>
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <config>
            <peer-address>BGP_IP_ADDR_T</peer-address>
          </config>
          <egress-engineering>
            <config>
              </enable-peer-node><!-- operation="delete"-->
            </config>
          </egress-engineering>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) peer-node
```

Configure set name

Use this attribute for the set-name

Attribute Name: set-name

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
      <peer>
        <peer-address>A.B.C.D|X:X::X:X</peer-address>
        <config>
          <peer-address>BGP_IP_ADDR_T</peer-address>
        </config>
        <egress-engineering>
          <peer-set>
            <config>
              <set-name>NAME</set-name>
            </config>
          </peer-set>
        </egress-engineering>
      </peer>
    </peers>
  </bgp-instance>
</bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) peer-set NAME
```

Configure address

Use this attribute for the backup peer-address

Attribute Name: address

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
      <peer>
        <peer-address>A.B.C.D|X:X::X:X</peer-address>
        <config>
          <peer-address>BGP_IP_ADDR_T</peer-address>
        </config>
      </peer>
    </peers>
  </bgp-instance>
</bgp-instances>
</bgp>
```

```

        </config>
        <egress-engineering>
        <backup>
        <peer-node>
        <config>
            <address>A.B.C.D</address>
        </config>
        </peer-node>
    </backup>
</egress-engineering>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) peer-node backup backup-type peer-node backup-peer
A.B.C.D
```

Configure peer address

Use this attribute to start a BGP process.

Attribute Name: bgp-as

Attribute Type: uint32

Attribute Name: peer-address

Attribute Type: union

Attribute Name: adjacent-address

Attribute Type: string

Attribute Name: nexthop-address

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
<bgp-instance> <!-- operation="delete"-->
    <bgp-as>1</bgp-as>
    <config>
        <bgp-as>1</bgp-as>
    </config>
</peer>
<peer>
    <peer-address>A.B.C.D|X:X::X:X</peer-address>
    <egress-engineering>
    <backup>
    <adjacency>
    <config>

```

```

        <adjacent-address>A.B.C.D</adjacent-address>
        <nexthop-address>NEXTHOP</nexthop-address>
    </config>
</adjacency>
</backup>
</egress-engineering>
</peer>
</peers>
</bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```

neighbor (A.B.C.D|X:X::X:X) peer-node backup backup-type peer-adj backup-peer
A.B.C.D hop-address NHOP

```

Configure hop address

Use this attribute for the hop-address

Attribute Name: hop-address

Attribute Type: string

Netconf edit-config payload

```

<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<bgp-instances>
  <bgp-instance>
    <bgp-as>1</bgp-as>
    <config>
      <bgp-as>1</bgp-as>
    </config>
    <peers>
      <peer>
        <peer-address>A.B.C.D|X:X::X:X</peer-address>
        <config>
          <peer-address>BGP_IP_ADDR_T</peer-address>
        </config>
        <egress-engineering>
          <peer-adjacency> <!-- operation="delete"-->
            <hop-address>A.B.C.D</hop-address>
            <config>
              <hop-address>A.B.C.D</hop-address>
            </config>
          </peer-adjacency>
        </egress-engineering>
      </peer>
    </peers>
  </bgp-instance>
</bgp-instances>
</bgp>

```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) peer-adj hop-address A.B.C.D
```

Configure hop address

Use this attribute to start a BGP process.

Attribute Name: bgp-as

Attribute Type: uint32

Attribute Name: peer-address

Attribute Type: union

Attribute Name: hop-address

Attribute Type: string

Attribute Name: address

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <bgp-instances>
    <bgp-instance> <!-- operation="delete"-->
      <bgp-as>1</bgp-as>
      <config>
        <bgp-as>1</bgp-as>
      </config>
      <peers>
        <peer>
          <peer-address>A.B.C.D|X:X::X:X</peer-address>
          <egress-engineering>
            <peer-adjacency>
              <hop-address>A.B.C.D</hop-address>
              <backup>
                <peer-node>
                  <config>
                    <address>A.B.C.D</address>
                  </config>
                </peer-node>
              </backup>
            </peer-adjacency>
          </egress-engineering>
        </peer>
      </peers>
    </bgp-instance>
  </bgp-instances>
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) peer-adj hop-address A.B.C.D backup backup-type peer-  
node backup-peer A.B.C.D
```

Configure adjacent address

Use this attribute to start a BGP process.

Attribute Name: bgp-as

Attribute Type: uint32

Attribute Name: peer-address

Attribute Type: union

Attribute Name: hop-address

Attribute Type: string

Attribute Name: adjacent-address

Attribute Type: string

Attribute Name: nexthop-address

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">  
<bgp-instances>  
<bgp-instance> <!-- operation="delete"-->  
  <bgp-as>1</bgp-as>  
  <config>  
    <bgp-as>1</bgp-as>  
  </config>  
  <peers>  
  <peer>  
    <peer-address>A.B.C.D|X:X::X:X</peer-address>  
    <egress-engineering>  
    <peer-adjacency>  
      <hop-address>A.B.C.D</hop-address>  
      <backup>  
      <adjacency>  
        <config>  
          <adjacent-address>A.B.C.D</adjacent-address>  
          <nexthop-address>NEXTHOP</nexthop-address>  
        </config>  
      </adjacency>  
    </backup>  
  </peer-adjacency>  
  </egress-engineering>  
  </peer>  
</peers>  
</bgp-instance>  
</bgp-instances>
```

```
</bgp>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X) peer-adj hop-address A.B.C.D backup backup-type peer-adj backup-peer A.B.C.D hop-address NHOP
```

IPI-BGP-FLOWSPEC

Configure enable flowspec controller

Use this attribute to controllersly enable or disable FLOWSPEC controller

Attribute Name: enable-flowspec-controller

Attribute Type: empty

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <flowspec>
    <controllers>
      <controller> <!-- operation="delete"-->
        </enable-flowspec-controller>
      <config>
        </enable-flowspec-controller>
      </config>
    </controller>
  </controllers>
</flowspec>
</bgp>
```

Command Syntax

```
flowspec
```

Configure local install

Use this attribute to specify local-install for policy-map PBR

Attribute Name: local-install

Attribute Type: enum (interface-all)

Default Value: interface-all

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <flowspec>
    <controllers>
      <controller>
        </enable-flowspec-controller>
      <config>
        </enable-flowspec-controller><!-- operation="delete"-->

```

```
</config>
  <local-install>interface-all</local-install> <!-- operation="delete"-->
</controller>
</controllers>
</flowspec>
</bgp>
```

Command Syntax

```
local-install (interface-all)
```

Configure afi type

Use this attribute to controllersly enable or disable FLOWSPEC controller

Attribute Name: enable-flowspec-controller

Attribute Type: uint8

Attribute Name: afi-type

Attribute Type: enum (ipv4)

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <flowspec>
    <controllers>
      <controller> <!-- operation="delete"-->
        </enable-flowspec-controller>
      <config>
        </enable-flowspec-controller>
      </config>
    <address-families>
      <address-family>
        <afi-type>ipv4</afi-type>
      </address-family>
    </address-families>
  </controller>
</controllers>
</flowspec>
</bgp>
```

Command Syntax

```
address-family ipv4
```

Configure service policy type

Use this attribute to controllersly enable or disable FLOWSPEC controller

Attribute Name: enable-flowspec-controller

Attribute Type: uint8

Attribute Name: afi-type

Attribute Type: enum (ipv4)

Attribute Name: service-policy-type

Attribute Type: enum (pbr)

Attribute Name: attached-policy-map-name

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <flowspec>
    <controllers>
      <controller> <!-- operation="delete"-->
        </enable-flowspec-controller>
        <config>
          </enable-flowspec-controller>
        </config>
      <address-families>
        <address-family>
          <afi-type>ipv4</afi-type>
          <service-policy>
            <service-policy-type>pbr</service-policy-type>
            <attached-policy-map-name>WORD</attached-policy-map-name>
          </service-policy>
        </address-family>
      </address-families>
    </controller>
  </controllers>
</flowspec>
</bgp>
```

Command Syntax

```
service-policy type (pbr) NAME
```

Configure vrf name

Use this attribute to show the vrf name

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
  <flowspec>
    <controllers>
      <controller>
        </enable-flowspec-controller>
        <config>
          </enable-flowspec-controller>
        </config>
      </controller>
    </controllers>
  </flowspec>
</bgp>
```

```
<vrfs>
<vrf> <!-- operation="delete"-->
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>WORD</vrf-name>
  </config>
</vrf>
</vrfs>
</controller>
</controllers>
</flowspec>
</bgp>
```

Command Syntax

```
vrf WORD
```

Configure attached policy map name

Use this attribute to controllersly enable or disable FLOWSPEC controller

Attribute Name: enable-flowspec-controller

Attribute Type: uint8

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: afi-type

Attribute Type: enum (ipv4)

Attribute Name: service-policy-type

Attribute Type: enum (pbr)

Attribute Name: attached-policy-map-name

Attribute Type: string

Netconf edit-config payload

```
<bgp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bgp">
<flowspec>
<controllers>
<controller> <!-- operation="delete"-->
  </enable-flowspec-controller>
<config>
  </enable-flowspec-controller>
</config>
<vrfs>
<vrf>
  <vrf-name>WORD</vrf-name>
  <address-families>
  <address-family>
    <afi-type>ipv4</afi-type>
    <service-policy>
```

```

        <service-policy-type>pbr</service-policy-type>
          <attached-policy-map-name>WORD</attached-policy-map-name>
        </service-policy>
      </address-family>
    </address-families>
  </vrf>
</vrfs>
</controller>
</controllers>
</flowspec>
</bgp>

```

Command Syntax

```
service-policy type (pbr) NAME
```

IPI-ENHANCED-PBR

Configure class type

Use this attribute to set the class-map type.

Attribute Name: class-type

Attribute Type: enum (traffic)

Attribute Name: match-criteria

Attribute Type: enum (match-all)

Netconf edit-config payload

```

<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <class-maps>
    <class-map <!-- operation="delete"-->
      <class-type>traffic</class-type>
      <config>
        <class-type>traffic</class-type>
        <name>NAME</name>
        <match-criteria>match-all</match-criteria>
      </config>
      <name>WORD</name>
    </class-map>
  </class-maps>
</enhanced-pbr>

```

Command Syntax

```
class-map type (traffic) (match-all) NAME
```

Configure reference description

This attribute configures reference description message on class-map profile for QoS type.

Attribute Name: reference-description

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <class-maps>
  <class-map>
    <class-type>traffic</class-type>
    <config>
      <class-type>traffic</class-type>
      <name>NAME</name>
    </config>
    <name>WORD</name>
    <reference-description>LINE</reference-description> <!-- operation="delete"-->
  </class-map>
</class-maps>
</enhanced-pbr>
```

Command Syntax

```
WORD type (traffic) reference-description LINE
```

Configure protocol

Use this attribute to specify IP protocol

Attribute Name: protocol

Attribute Type: string

Attribute Range: 0-255

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <class-maps>
  <class-map>
    <class-type>traffic</class-type>
    <config>
      <class-type>traffic</class-type>
      <name>NAME</name>
    </config>
    <name>WORD</name>
  <match-filters>
  <config>
    <protocol>WORD</protocol> <!-- operation="delete"-->
  </config>
</match-filters>
</class-map>
</class-maps>
</enhanced-pbr>
```

Command Syntax

```
match protocol WORD
```

Configure port

Use this attribute to specify TCP/UDP port number

Attribute Name: port

Attribute Type: string

Attribute Range: 1-65535

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <class-maps>
    <class-map>
      <class-type>traffic</class-type>
      <config>
        <class-type>traffic</class-type>
        <name>NAME</name>
      </config>
      <name>WORD</name>
    </class-map>
  </class-maps>
  <match-filters>
    <config>
      <port>WORD</port> <!-- operation="delete"-->
    </config>
  </match-filters>
</enhanced-pbr>
```

Command Syntax

```
match port WORD
```

Configure destination port

Use this attribute to specify TCP/UDP destination port number

Attribute Name: destination-port

Attribute Type: string

Attribute Range: 1-65535

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <class-maps>
    <class-map>
      <class-type>traffic</class-type>
      <config>
        <class-type>traffic</class-type>
        <name>NAME</name>
      </config>
    </class-map>
  </class-maps>
</enhanced-pbr>
```

```
</config>
  <name>WORD</name>
<match-filters>
<config>
  <destination-port>WORD</destination-port> <!-- operation="delete"-->
</config>
</match-filters>
</class-map>
</class-maps>
</enhanced-pbr>
```

Command Syntax

```
match destination-port WORD
```

Configure source port

Use this attribute to specify TCP/UDP source port number

Attribute Name: source-port

Attribute Type: string

Attribute Range: 1-65535

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
<class-maps>
<class-map>
  <class-type>traffic</class-type>
  <config>
    <class-type>traffic</class-type>
    <name>NAME</name>
  </config>
  <name>WORD</name>
<match-filters>
<config>
  <source-port>WORD</source-port> <!-- operation="delete"-->
</config>
</match-filters>
</class-map>
</class-maps>
</enhanced-pbr>
```

Command Syntax

```
match source-port WORD
```

Configure packet length

Use this attribute to specify packet-length value

Attribute Name: packet-length

Attribute Type: string

Attribute Range: 21-12288

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <class-maps>
  <class-map>
    <class-type>traffic</class-type>
    <config>
      <class-type>traffic</class-type>
      <name>NAME</name>
    </config>
    <name>WORD</name>
  <match-filters>
  <config>
    <packet-length>WORD</packet-length> <!-- operation="delete"-->
  </config>
</match-filters>
</class-map>
</class-maps>
</enhanced-pbr>
```

Command Syntax

```
match packet-length WORD
```

Configure fragment type

Use this attribute to specify fragment type value

Attribute Name: fragment-type

Attribute Type: enum (df|isf|ff|lf|ff-isf)

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <class-maps>
  <class-map>
    <class-type>traffic</class-type>
    <config>
      <class-type>traffic</class-type>
      <name>NAME</name>
    </config>
    <name>WORD</name>
  <match-filters>
  <config>
    <fragment-type>df</fragment-type> <!-- operation="delete"-->
  </config>
</match-filters>
</class-map>
</class-maps>
</enhanced-pbr>
```

Command Syntax

```
match fragment-type (df|isf|ff|lf|lf-ff-isf)
```

Configure destination prefix

Use this attribute to specify IPv4 prefix

Attribute Name: destination-prefix

Attribute Type: string

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <class-maps>
    <class-map>
      <class-type>traffic</class-type>
      <config>
        <class-type>traffic</class-type>
        <name>NAME</name>
      </config>
      <name>WORD</name>
    </class-map>
  </class-maps>
  <ipv4>
    <config>
      <destination-prefix>A.B.C.D/M</destination-prefix> <!-- operation="delete"-->
    </config>
  </ipv4>
</match-filters>
</class-map>
</class-maps>
</enhanced-pbr>
```

Command Syntax

```
match destination-address ipv4 A.B.C.D/M
```

Configure source prefix

Use this attribute to specify IPv4 prefix

Attribute Name: source-prefix

Attribute Type: string

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <class-maps>
    <class-map>
      <class-type>traffic</class-type>
      <config>
        <class-type>traffic</class-type>
        <name>NAME</name>
      </config>
    </class-map>
  </class-maps>
</enhanced-pbr>
```



```

    <name>WORD</name>
  <match-filters>
  <ipv4>
  <config>
    <source-prefix>A.B.C.D/M</source-prefix> <!-- operation="delete"-->
  </config>
  </ipv4>
</match-filters>
</class-map>
</class-maps>
</enhanced-pbr>

```

Command Syntax

```
match source-address ipv4 A.B.C.D/M
```

Configure icmp type

Use this attribute to specify ICMP type

Attribute Name: icmp-type

Attribute Type: string

Attribute Range: 0-255

Netconf edit-config payload

```

<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <class-maps>
  <class-map>
    <class-type>traffic</class-type>
    <config>
      <class-type>traffic</class-type>
      <name>NAME</name>
    </config>
    <name>WORD</name>
  <match-filters>
  <ipv4>
  <icmp>
  <config>
    <icmp-type>WORD</icmp-type> <!-- operation="delete"-->
  </config>
  </icmp>
  </ipv4>
</match-filters>
</class-map>
</class-maps>
</enhanced-pbr>

```

Command Syntax

```
match ipv4 icmp-type WORD
```

Configure icmp code

Use this attribute to specify ICMP code

Attribute Name: icmp-code

Attribute Type: string

Attribute Range: 0-255

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <class-maps>
    <class-map>
      <class-type>traffic</class-type>
      <config>
        <class-type>traffic</class-type>
        <name>NAME</name>
      </config>
      <name>WORD</name>
    </class-map>
  </class-maps>
  <ipv4>
    <icmp>
      <config>
        <icmp-code>WORD</icmp-code> <!-- operation="delete" -->
      </config>
    </icmp>
  </ipv4>
</match-filters>
</class-map>
</class-maps>
</enhanced-pbr>
```

Command Syntax

```
match ipv4 icmp-code WORD
```

Configure bit mask

Use this attribute to specify bit-mask for TCP flag

Attribute Name: bit-mask

Attribute Type: string

Attribute Name: value

Attribute Type: string

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <class-maps>
    <class-map>
      <class-type>traffic</class-type>
      <config>
```

```

        <class-type>traffic</class-type>
        <name>NAME</name>
    </config>
    <name>WORD</name>
<match-filters>
<tcp-flag>
<config>
    <value>WORD</value> <!-- operation="delete"-->
    <bit-mask>WORD</bit-mask> <!-- operation="delete"-->
</config>
</tcp-flag>
</match-filters>
</class-map>
</class-maps>
</enhanced-pbr>

```

Command Syntax

```
match tcp-flag WORD bit-mask WORD
```

Configure match dscp value

Use this attribute to specify dscp value

Attribute Name: match-dscp-value

Attribute Type: string

Netconf edit-config payload

```

<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
<class-maps>
<class-map>
    <class-type>traffic</class-type>
    <config>
        <class-type>traffic</class-type>
        <name>NAME</name>
    </config>
    <name>WORD</name>
<match-filters>
<dscp>
<config>
    <match-dscp-value>WORD</match-dscp-value> <!-- operation="delete"-->
</config>
</dscp>
</match-filters>
</class-map>
</class-maps>
</enhanced-pbr>

```

Command Syntax

```
match dscp WORD
```

Configure type

Use this attribute to set the policy-map type.

Attribute Name: type

Attribute Type: enum (pbr)

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <policy-maps>
    <policy-map> <!-- operation="delete"-->
      <type>pbr</type>
      <config>
        <type>pbr</type>
        <policy-map-name>WORD</policy-map-name>
      </config>
      <policy-map-name>WORD</policy-map-name>
    </policy-map>
  </policy-maps>
</enhanced-pbr>
```

Command Syntax

```
policy-map type (pbr) NAME
```

Configure policy map name

This attribute configures reference description message on policy-map profile

Attribute Name: reference-description

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <policy-maps>
    <policy-map>
      <type>pbr</type>
      <config>
        <type>pbr</type>
        <policy-map-name>WORD</policy-map-name>
      </config>
      <policy-map-name>WORD</policy-map-name>
      <reference-description>LINE</reference-description> <!-- operation="delete"-->
    </policy-map>
  </policy-maps>
</enhanced-pbr>
```

Command Syntax

```
reference-description LINE
```

Configure class map name

Use this attribute to set the policy-map name

Attribute Name: policy-map-name

Attribute Type: string

Attribute Name: class-type

Attribute Type: enum (traffic)

Attribute Name: class-map-name

Attribute Type: string

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <policy-maps>
    <policy-map> <!-- operation="delete"-->
      <type>pbr</type>
      <config>
        <type>pbr</type>
        <policy-map-name>WORD</policy-map-name>
      </config>
      <policy-map-name>WORD</policy-map-name>
    </policy-map>
  </policy-maps>
  <classes>
    <class>
      <class-type>traffic</class-type>
      <class-map-name>WORD</class-map-name>
    </class>
  </classes>
</enhanced-pbr>
```

Command Syntax

```
class type (traffic) NAME
```

Configure drop traffic

Use this attribute to specify drop action

Attribute Name: drop-traffic

Attribute Type: empty

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <policy-maps>
    <policy-map>
      <type>pbr</type>
      <config>
        <type>pbr</type>
      </config>
    </policy-map>
  </policy-maps>
</enhanced-pbr>
```

```

    <policy-map-name>WORD</policy-map-name>
  </config>
  <policy-map-name>WORD</policy-map-name>
<classes>
<class>
  <class-type>traffic</class-type>
  <config>
    <class-type>traffic</class-type>
    <class-map-name>NAME</class-map-name>
  </config>
  <class-map-name>WORD</class-map-name>
  <policy-actions>
  <config>
    </drop-traffic><!-- operation="delete"-->
  </config>
</policy-actions>
</class>
</classes>
</policy-map>
</policy-maps>
</enhanced-pbr>

```

Command Syntax

drop

Configure dscp set value

Use this attribute to specify DSCP value

Attribute Name: dscp-set-value

Attribute Type: enum

(00|01|02|03|04|05|06|07|08|09|0a|0b|0c|0d|0e|0f|10|11|12|13|14|15|16|17|18|19|1a|1b|1c|1d|1e|1f|20|21|22|23|24|25|26|27|28|29|2a|2b|2c|2d|2e|2f|30|31|32|33|34|35|36|37|38|39|3a|3b|3c|3d|3e|3f)

Netconf edit-config payload

```

<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
  <policy-maps>
  <policy-map>
    <type>pbr</type>
    <config>
      <type>pbr</type>
      <policy-map-name>WORD</policy-map-name>
    </config>
    <policy-map-name>WORD</policy-map-name>
  </policy-map>
</policy-maps>
<classes>
<class>
  <class-type>traffic</class-type>
  <config>
    <class-type>traffic</class-type>
    <class-map-name>NAME</class-map-name>
  </config>
</class>
</classes>
</enhanced-pbr>

```

```

</config>
  <class-map-name>WORD</class-map-name>
</policy-actions>
</config>
  <dscp-set-value>00</dscp-set-value> <!-- operation="delete"-->
</config>
</policy-actions>
</class>
</classes>
</policy-map>
</policy-maps>
</enhanced-pbr>

```

Command Syntax

```

set dscp
(00|01|02|03|04|05|06|07|08|09|0a|0b|0c|0d|0e|0f|10|11|12|13|14|15|16|17|18|19|1
a|1b|1c|1d|1e|1f|20|21|22|23|24|25|26|27|28|29|2a|2b|2c|2d|2e|2f|30|31|32|33|34|
35|36|37|38|39|3a|3b|3c|3d|3e|3f)

```

Configure rate unit

Use this attribute to set a rate unit.

Attribute Name: rate-unit

Attribute Type: enum (bps|pps)

Default Value: bps

Attribute Name: rate

Attribute Type: uint64

Attribute Range: 1-1000000000

Netconf edit-config payload

```

<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
</policy-maps>
</policy-map>
  <type>pbr</type>
  <config>
    <type>pbr</type>
    <policy-map-name>WORD</policy-map-name>
  </config>
  <policy-map-name>WORD</policy-map-name>
</classes>
</class>
  <class-type>traffic</class-type>
  <config>
    <class-type>traffic</class-type>
    <class-map-name>NAME</class-map-name>
  </config>
  <class-map-name>WORD</class-map-name>
</policy-actions>

```

```
<police>
<config>
  <rate>1</rate> <!-- operation="delete"-->
  <rate-unit>bps</rate-unit> <!-- operation="delete"-->
</config>
</police>
</policy-actions>
</class>
</classes>
</policy-map>
</policy-maps>
</enhanced-pbr>
```

Command Syntax

```
police rate <1-1000000000> (bps|pps)
```

Configure route target

Use this attribute to specify route target for rt redirect action

Attribute Name: route-target

Attribute Type: string

Netconf edit-config payload

```
<enhanced-pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-enhanced-pbr">
<policy-maps>
<policy-map>
  <type>pbr</type>
  <config>
    <type>pbr</type>
    <policy-map-name>WORD</policy-map-name>
  </config>
  <policy-map-name>WORD</policy-map-name>
</classes>
<class>
  <class-type>traffic</class-type>
  <config>
    <class-type>traffic</class-type>
    <class-map-name>NAME</class-map-name>
  </config>
  <class-map-name>WORD</class-map-name>
  <policy-actions>
  <redirect>
  <ipv4>
  <extcommunity>
  <config>
    <route-target>ASN:nn_or_IP-address:nn</route-target> <!--
operation="delete"-->
  </config>
</extcommunity>
```



```

</ipv4>
</redirect>
</policy-actions>
</class>
</classes>
</policy-map>
</policy-maps>
</enhanced-pbr>

```

Command Syntax

```
redirect ipv4 extcommunity rt ASN:nn_or_IP-address:nn
```

IPI-BFD

Configure notification enabled

Use this attribute to enable or disable BFD SNMP notification.

Attribute Name: notification-enabled

Attribute Type: boolean

Default Value: false

Netconf edit-config payload

```

<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
<global>
<config>
  <notification-enabled>true</notification-enabled> <!-- operation="delete"-->
</config>
</global>
</bfd>

```

Command Syntax

```
bfd notification (disable|enable)
```

Configure echo mode enabled

This leaf exists when echo mode is running between the local and remote system. When it does not exist, solely asynchronous mode is active.

Attribute Name: echo-mode-enabled

Attribute Type: empty

Netconf edit-config payload

```

<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
<global>
<config>
  </echo-mode-enabled><!-- operation="delete"-->
</config>

```

```
</global>  
</bfd>
```

Command Syntax

```
bfd echo
```

Configure slow tx interval

Use this command to set a BFD slow timer interval.

Attribute Name: slow-tx-interval

Attribute Type: uint32

Default Value: 2000

Attribute Range: 1000-30000

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">  
<global>  
<config>  
  <slow-tx-interval>1000</slow-tx-interval> <!-- operation="delete"-->  
</config>  
</global>  
</bfd>
```

Command Syntax

```
bfd slow-timer <1000-30000>
```

Configure detection multiplier

The number of packets that must be missed to declare this session as down. The detection interval for the BFD session is calculated by multiplying the value of the negotiated transmission interval by this value.

This command is supported when following feature are enabled BFD-MONO feature enabled

Attribute Name: detection-multiplier

Attribute Type: uint8

Attribute Range: 3-50

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">  
<global>  
<intervals>  
<interval> <!-- operation="delete"-->  
  <detection-multiplier>3</detection-multiplier>  
<config>  
  <detection-multiplier>3</detection-multiplier>  
  <required-minimum-rx-interval>3</required-minimum-rx-interval>  
  <desired-minimum-tx-interval>3</desired-minimum-tx-interval>  
</config>
```

```

    <required-minimum-rx-interval>3</required-minimum-rx-interval>
    <desired-minimum-tx-interval>3</desired-minimum-tx-interval>
</interval>
</intervals>
</global>
</bfd>

```

Command Syntax

```
bfd interval <3-999> minrx <3-999> multiplier <3-50>
```

Configure remote address

The number of packets that must be missed to declare this session as down. The detection interval for the BFD session is calculated by multiplying the value of the negotiated transmission interval by this value.

This command is supported when following feature are enabled BFD-MONO feature enabled

Attribute Name: detection-multiplier

Attribute Type: uint8

Attribute Range: 3-50

Netconf edit-config payload

```

<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
<peers>
<peer>
    <remote-address>A.B.C.D</remote-address>
    <config>
        <remote-address>A.B.C.D</remote-address>
    </config>
</intervals>
<interval> <!-- operation="delete"-->
    <detection-multiplier>3</detection-multiplier>
    <config>
        <detection-multiplier>3</detection-multiplier>
        <required-minimum-rx-interval>3</required-minimum-rx-interval>
        <desired-minimum-tx-interval>3</desired-minimum-tx-interval>
    </config>
    <required-minimum-rx-interval>50</required-minimum-rx-interval>
    <desired-minimum-tx-interval>50</desired-minimum-tx-interval>
</interval>
</intervals>
</peer>
</peers>
</bfd>

```

Command Syntax

```
bfd multihop-peer (A.B.C.D|X:X::X:X) interval <50-999> minrx <50-999> multiplier
<3-50>
```

Configure key string

Use this attribute to specify the key authentication string

Attribute Name: key-string

Attribute Type: string

Attribute Name: key-type

Attribute Type: enum (simple|keyed-sha1|meticulous-keyed-sha1)

Attribute Name: key-id

Attribute Type: uint32

Attribute Range: 0-255

Attribute Name: key-encrypted

Attribute Type: enum (0|1)

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <peers>
    <peer>
      <remote-address>A.B.C.D</remote-address>
      <config>
        <remote-address>A.B.C.D</remote-address>
      </config>
    <authentication>
      <config>
        <key-type>simple</key-type> <!-- operation="delete"-->
        <key-id>0</key-id> <!-- operation="delete"-->
        <key-encrypted>0</key-encrypted> <!-- operation="delete"-->
        <key-string>WORD</key-string> <!-- operation="delete"-->
      </config>
    </authentication>
  </peer>
</peers>
</bfd>
```

Command Syntax

```
bfd multihop-peer (A.B.C.D|X:X::X:X) auth type (simple|keyed-sha1|meticulous-keyed-
sha1) key-id <0-255> (0|1) key WORD
```

Configure options

Use this attribute to debug the oamd process.

Attribute Name: options

Attribute Type: bits (events|packets|ipc-error|ipc-event|session|nsm|all)

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
```

```

<debug>
<config>
  <options>events</options> <!-- operation="delete"-->
</config>
</debug>
</bfd>

```

Command Syntax

```
debug bfd (events|packets|ipc-error|ipc-event|session|nsm|all)
```

Configure enable oam srv6

Use this attribute to debug OAM SRV6

Attribute Name: enable-oam-srv6

Attribute Type: empty

Netconf edit-config payload

```

<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
<debug>
<config>
  </enable-oam-srv6><!-- operation="delete"-->
</config>
</debug>
</bfd>

```

Command Syntax

```
debug oam srv6
```

Configure enable mpls ping request

Use this attribute to enable or disable MPLS ping request DSMAP TLV

This command is supported when following feature are enabled MPLS-OAM feature enabled

Attribute Name: enable-mpls-ping-request

Attribute Type: empty

Netconf edit-config payload

```

<oam-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
<config>
  </enable-mpls-ping-request><!-- operation="delete"-->
</config>
</oam-mpls>

```

Command Syntax

```
mpls-ping-request-dsmap-tlv
```

Configure mpls ping reply

Use this attribute to enable or disable MPLS ping reply TLV

This command is supported when following feature are enabled MPLS-OAM feature enabled

Attribute Name: mpls-ping-reply

Attribute Type: empty

Netconf edit-config payload

```
<oam-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <config>
    </mpls-ping-reply><!-- operation="delete"-->
  </config>
</oam-mpls>
```

Command Syntax

```
mpls-ping-reply-tlv
```

snmp restart bfd

Netconf RPC payload

```
<bfd-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd"/>
```

Command Syntax

```
snmp restart bfd
```

debug bfd (events|packets|ipc-error|ipc-event|session|nsm|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (events|packets|ipc-error|ipc-event|session|nsm|all)

Netconf RPC payload

```
<bfd-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <terminal-debug-options>events</terminal-debug-options>
</bfd-terminal-debug-on>
```

Command Syntax

```
debug bfd (events|packets|ipc-error|ipc-event|session|nsm|all)
```

no debug bfd (events|packets|ipc-error|ipc-event|session|nsm|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (events|packets|ipc-error|ipc-event|session|nsm|all)

Netconf RPC payload

```
<bfd-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <terminal-debug-options>events</terminal-debug-options>
</bfd-terminal-debug-off>
```

```
</bfd-terminal-debug-off>
```

Command Syntax

```
no debug bfd (events|packets|ipc-error|ipc-event|session|nsm|all)
```

debug oam srv6

Netconf RPC payload

```
<debug-oam-srv6-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd"/>
```

Command Syntax

```
debug oam srv6
```

no debug oam srv6

Netconf RPC payload

```
<debug-oam-srv6-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd"/>
```

Command Syntax

```
no debug oam srv6
```

IPI-BFD-INTERFACE

Configure bfd disabled

Use this attribute to enable or disable all the BFD sessions on this interface.

Attribute Name: bfd-disabled

Attribute Type: uint8

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </bfd-disabled><!-- operation="delete"-->
    </interface>
  </interfaces>
</bfd>
```

Command Syntax

```
bfd disable
```

Configure bfd session type

Use this attribute to offload Single HOP BFD sessions to software or hardware.

Attribute Name: bfd-session-type

Attribute Type: enum (hardware|software)

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <bfd-session-type>hardware</bfd-session-type> <!-- operation="delete"-->
    </interface>
  </interfaces>
</bfd>
```

Command Syntax

```
bfd session (hardware|software)
```

Configure detection multiplier

The number of packets that must be missed to declare this session as down. The detection interval for the BFD session is calculated by multiplying the value of the negotiated transmission interval by this value.

This command is supported when following feature are enabled BFD-MONO feature enabled

Attribute Name: detection-multiplier

Attribute Type: uint8

Attribute Range: 3-50

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <intervals>
        <interval> <!-- operation="delete"-->
          <detection-multiplier>3</detection-multiplier>
        </interval>
      </intervals>
      <config>
        <detection-multiplier>3</detection-multiplier>
        <required-minimum-rx-interval>3</required-minimum-rx-interval>
        <desired-minimum-tx-interval>3</desired-minimum-tx-interval>
      </config>
    </interface>
  </interfaces>
</bfd>
```



```

        <required-minimum-rx-interval>3</required-minimum-rx-interval>
        <desired-minimum-tx-interval>3</desired-minimum-tx-interval>
    </interval>
</intervals>
</interface>
</interfaces>
</bfd>

```

Command Syntax

```
bfd interval <3-999> minrx <3-999> multiplier <3-50>
```

Configure ipv4 source

Use this attribute to configure BFD echo packet IPv4 source address

Attribute Name: ipv4-source

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
<interfaces>
<interface>
    <name>WORD</name>
    <config>
        <name>WORD</name>
    </config>
    <echo>
    <config>
        <ipv4-source>A.B.C.D</ipv4-source> <!-- operation="delete"-->
    </config>
</echo>
</interface>
</interfaces>
</bfd>

```

Command Syntax

```
echo ipv4 source A.B.C.D
```

Configure name

Use this attribute to configure BFD echo packet IPv4 source address

Attribute Name: ipv4-source

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
<interfaces>
<interface>
    <name>WORD</name>

```

```
<config>
  <name>WORD</name>
</config>
<echo>
<config>
  <ipv4-source>A.B.C.D</ipv4-source> <!-- operation="delete"-->
</config>
</echo>
</interface>
</interfaces>
</bfd>
```

Command Syntax

```
bfd echo ipv4 source A.B.C.D
```

Configure required minimum tx interval

Use this attribute to configure BFD echo packet transmission interval, in milliseconds

Attribute Name: required-minimum-tx-interval

Attribute Type: uint32

Attribute Range: 50-4294967

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <echo>
  <config>
    <required-minimum-tx-interval>50</required-minimum-tx-interval> <!--
operation="delete"-->
  </config>
</echo>
</interface>
</interfaces>
</bfd>
```

Command Syntax

```
bfd echo interval <50-4294967>
```

Configure key string

Use this attribute to specify the key authentication string

Attribute Name: key-string

Attribute Type: string

Attribute Name: key-type

Attribute Type: enum (simple|keyed-sha1|meticulous-keyed-sha1)

Attribute Name: key-id

Attribute Type: uint32

Attribute Range: 0-255

Attribute Name: key-encrypted

Attribute Type: enum (0|1)

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <authentication>
        <config>
          <key-type>simple</key-type> <!-- operation="delete"-->
          <key-id>0</key-id> <!-- operation="delete"-->
          <key-encrypted>0</key-encrypted> <!-- operation="delete"-->
          <key-string>WORD</key-string> <!-- operation="delete"-->
        </config>
      </authentication>
    </interface>
  </interfaces>
</bfd>
```

Command Syntax

```
bfd auth type (simple|keyed-sha1|meticulous-keyed-sha1) key-id <0-255> (0|1) key
WORD
```

Configure session type

BFD session type

Attribute Name: session-type

Attribute Type: enum (singlehop|multihop)

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <sessions>
```

```
<session> <!-- operation="delete"-->
  <session-type>singlehop</session-type>
  <config>
    <session-type>singlehop</session-type>
    <remote-address>A.B.C.D</remote-address>
    <local-address>A.B.C.D</local-address>
  </config>
  <remote-address>A.B.C.D</remote-address>
  <local-address>A.B.C.D</local-address>
</session>
</sessions>
</interface>
</interfaces>
</bfd>
```

Command Syntax

```
bfd session (A.B.C.D|X:X::X:X) (A.B.C.D|X:X::X:X) (multihop|)
```

Configure administrative down

BFD administrative down session

Attribute Name: administrative-down

Attribute Type: empty

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <sessions>
        <session>
          <session-type>singlehop</session-type>
          <config>
            <session-type>singlehop</session-type>
            <remote-address>A.B.C.D</remote-address>
            <local-address>A.B.C.D</local-address>
          </config>
            <remote-address>A.B.C.D</remote-address>
            <local-address>A.B.C.D</local-address>
          </administrative-down><!-- operation="delete"-->
        </session>
      </sessions>
    </interface>
  </interfaces>
</bfd>
```

Command Syntax

```
bfd session (A.B.C.D|X:X::X:X) (A.B.C.D|X:X::X:X) (multihop|) admin-down
```

Configure non persistent

BFD non persistent session

Attribute Name: non-persistent

Attribute Type: empty

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <sessions>
  <session>
    <session-type>singlehop</session-type>
    <config>
      <session-type>singlehop</session-type>
      <remote-address>A.B.C.D</remote-address>
      <local-address>A.B.C.D</local-address>
    </config>
    <remote-address>A.B.C.D</remote-address>
    <local-address>A.B.C.D</local-address>
    </non-persistent><!-- operation="delete"-->
  </session>
</sessions>
</interface>
</interfaces>
</bfd>
```

Command Syntax

```
bfd session (A.B.C.D|X:X::X:X) (A.B.C.D|X:X::X:X) (multihop|) non-persistent
```

IPI-SEAMLESS-BFD

Configure sr policy name

This attribute is used to configure policy-name of the SR S-BFD session

Attribute Name: sr-policy-name

Attribute Type: string

Netconf edit-config payload

```
<seamless-bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-seamless-bfd">
<sr-policies>
<sr-policy> <!-- operation="delete"-->
  <sr-policy-name>NAME</sr-policy-name>
  <config>
    <sr-policy-name>WORD</sr-policy-name>
    <lsp-type>sr</lsp-type>
  </config>
  <lsp-type>sr</lsp-type>
</sr-policy>
</sr-policies>
</seamless-bfd>
```

Command Syntax

```
s-bfd (sr) policy NAME
```

Configure admin down

This attribute is used to shutdown selected S-BFD session

Attribute Name: admin-down

Attribute Type: empty

Netconf edit-config payload

```
<seamless-bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-seamless-bfd">
<sr-policies>
<sr-policy>
  <sr-policy-name>NAME</sr-policy-name>
  <config>
    <sr-policy-name>WORD</sr-policy-name>
    <lsp-type>sr</lsp-type>
  </config>
  <lsp-type>sr</lsp-type>
<session-attributes>
<config>
  </admin-down><!-- operation="delete"-->
</config>
</session-attributes>
</sr-policy>
</sr-policies>
</seamless-bfd>
```

Command Syntax

```
shutdown
```

Configure detection multiplier

This attribute is multiplied with minimum tx value to get detection time

Attribute Name: detection-multiplier

Attribute Type: uint8

Attribute Range: 3-50

Netconf edit-config payload

```
<seamless-bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-seamless-bfd">
  <sr-policies>
    <sr-policy>
      <sr-policy-name>NAME</sr-policy-name>
      <config>
        <sr-policy-name>WORD</sr-policy-name>
        <lsp-type>sr</lsp-type>
      </config>
      <lsp-type>sr</lsp-type>
    </sr-policy>
  </sr-policies>
  <session-attributes>
    <intervals>
      <interval> <!-- operation="delete"-->
        <detection-multiplier>3</detection-multiplier>
        <config>
          <detection-multiplier>1</detection-multiplier>
          <minimum-tx>3</minimum-tx>
        </config>
        <minimum-tx>3</minimum-tx>
      </interval>
    </intervals>
  </session-attributes>
</seamless-bfd>
```

Command Syntax

```
min-tx <3-999> multiplier <3-50>
```

Configure discriminator

This attribute is used to configure local discriminator value for reflector

Attribute Name: discriminator

Attribute Type: string

Netconf edit-config payload

```
<seamless-bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-seamless-bfd">
  <local-discriminators>
    <local-discriminator> <!-- operation="delete"-->
      <discriminator>A.B.C.D</discriminator>
    </local-discriminator>
  </local-discriminators>
</seamless-bfd>
```

```
</local-discriminators>  
</seamless-bfd>
```

Command Syntax

```
s-bfd discriminator A.B.C.D
```

Configure required min rx interval

This attribute is used to configure required minimum rx interval value for reflector

Attribute Name: required-min-rx-interval

Attribute Type: uint32

Attribute Range: 3-999

Netconf edit-config payload

```
<seamless-bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-seamless-bfd">  
<local-discriminators>  
<local-discriminator>  
  <discriminator>A.B.C.D</discriminator>  
  <config>  
    <discriminator>A.B.C.D</discriminator>  
  </config>  
  <required-min-rx-interval>3</required-min-rx-interval> <!-- operation="delete"-->  
</local-discriminator>  
</local-discriminators>  
</seamless-bfd>
```

Command Syntax

```
s-bfd discriminator A.B.C.D required-min-rx <3-999>
```

IPI-IGP-TE

Configure delay

Use this attribute to specify a unidirectional, link delay value for the interface

Attribute Name: delay

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```
<igp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igp-te">  
<interfaces>  
<interface>  
  <name>WORD</name>  
  <config>
```



```

        <name>WORD</name>
    </config>
</uni-link>
<config>
    <delay>1</delay> <!-- operation="delete" -->
</config>
</uni-link>
</interface>
</interfaces>
</igp-te>

```

Command Syntax

```
delay-measurement static uni-link-delay <1-16777215>
```

Configure delay variation

Use this attribute to specify a unidirectional, link delay variation value for the interface

Attribute Name: delay-variation

Attribute Type: uint32

Attribute Range: 0-16777215

Netconf edit-config payload

```

<igp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igp-te">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
  <uni-link>
    <config>
      <delay-variation>0</delay-variation> <!-- operation="delete" -->
    </config>
  </uni-link>
</igp-te>

```

Command Syntax

```
delay-measurement static uni-delay-variation <0-16777215>
```

Configure loss percentage

Use this attribute to specify a unidirectional, link loss value for the interface

Attribute Name: loss-percentage

Attribute Type: decimal64

Netconf edit-config payload

```
<igp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igp-te">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <uni-link>
    <config>
      <loss-percentage>VALUE</loss-percentage> <!-- operation="delete"-->
    </config>
    </uni-link>
  </interface>
</interfaces>
</igp-te>
```

Command Syntax

```
loss-measurement static uni-link-loss VALUE
```

Configure loss dynamic

Use this attribute to specify a loss percentage value dynamically for the interface

This command is supported when following feature are enabled TE feature

Attribute Name: loss-dynamic

Attribute Type: empty

Netconf edit-config payload

```
<igp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igp-te">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <uni-link>
    <twamp-loss-parameter>
    <config>
      </loss-dynamic><!-- operation="delete"-->
    </config>
    </twamp-loss-parameter>
  </interface>
</interfaces>
</igp-te>
```

Command Syntax

```
loss-measurement dynamic
```

Configure name

Use this attribute to specify a loss percentage value dynamically for the interface

This command is supported when following feature are enabled TE feature

Attribute Name: loss-dynamic

Attribute Type: empty

Netconf edit-config payload

```
<igp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igp-te">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <uni-link>
        <irb-twamp-loss-parameter>
          <config>
            </loss-dynamic><!-- operation="delete"-->
          </config>
        </irb-twamp-loss-parameter>
      </uni-link>
    </interface>
  </interfaces>
</igp-te>
```

Command Syntax

```
loss-measurement dynamic
```

Configure dscp

Use this attribute to classify traffic based on the Differentiated Services Code Point (DSCP) value. The DSCP value range is 0-63. Warning: In CLI show running, DSCP values with well-known names (ex.: af11, cs0) will be displayed as such. On Netconf, DSCP values will always be numeric. The string type allow up to 8 characters on well-known name.

This command is supported when following feature are enabled TE feature

Attribute Name: dscp

Attribute Type: string

Attribute Range: 1-8

Attribute Name: reflector-port

Attribute Type: uint16

Attribute Range: 1025-65535

Attribute Name: sender-ip

Attribute Type: union

Attribute Name: sender-port

Attribute Type: uint16

Attribute Range: 1025-65535

Netconf edit-config payload

```
<igp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igp-te">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <uni-link>
    <twamp-session-parameters>
    <twamp-session-parameter>
      <reflector-ip>CML_HOSTPNAME_T</reflector-ip>
      <config>
        <reflector-ip>CML_HOSTPNAME_T</reflector-ip>
        </delay-dynamic-twamp><!-- operation="delete"-->
        <reflector-port>1025</reflector-port> <!-- operation="delete"-->
        <sender-ip>CML_HOSTPNAME_T</sender-ip>
        <sender-port>1025</sender-port> <!-- operation="delete"-->
      </config>
      </delay-dynamic-twamp>
      <dscp>WORD</dscp> <!-- operation="delete"-->
    </twamp-session-parameter>
  </twamp-session-parameters>
</uni-link>
</interface>
</interfaces>
</igp-te>
```

Command Syntax

```
delay-measurement dynamic twamp reflector-ip (A.B.C.D|X:X::X:X|HOSTNAME)
  (reflector-port <1025-65535>|) (sender-ip (A.B.C.D|X:X::X:X|HOSTNAME)|) (sender-
  port <1025-65535>|) (dscp WORD|)
```

Configure delay dynamic twamp

Use this attribute to classify traffic based on the Differentiated Services Code Point (DSCP) value. The DSCP value range is 0-63. Warning: In CLI show running, DSCP values with well-known names (ex.: af11, cs0) will be displayed as such. On Netconf, DSCP values will always be numeric. The string type allow up to 8 characters on well-known name.

This command is supported when following feature are enabled TE feature

Attribute Name: dscp

Attribute Type: string

Attribute Range: 1-8

Attribute Name: reflector-port

Attribute Type: uint16

Attribute Range: 1025-65535

Attribute Name: sender-ip

Attribute Type: union

Attribute Name: sender-port

Attribute Type: uint16

Attribute Range: 1025-65535

Netconf edit-config payload

```
<igp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igp-te">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <uni-link>
    <twamp-session-parameters>
    <irb-twamp-session-parameter>
      <reflector-ip>CML_HOSTPNAME_T</reflector-ip>
      <config>
        <reflector-ip>CML_HOSTPNAME_T</reflector-ip>
        </delay-dynamic-twamp><!-- operation="delete"-->
        <reflector-port>1025</reflector-port> <!-- operation="delete"-->
        <sender-ip>CML_HOSTPNAME_T</sender-ip>
        <sender-port>1025</sender-port> <!-- operation="delete"-->
      </config>
      </delay-dynamic-twamp>
      <dscp>WORD</dscp> <!-- operation="delete"-->
    </irb-twamp-session-parameter>
  </twamp-session-parameters>
</uni-link>
</interface>
</interfaces>
</igp-te>
```

Command Syntax

```
delay-measurement dynamic twamp reflector-ip (A.B.C.D|X::X::X|HOSTNAME)
  (reflector-port <1025-65535>|) (sender-ip (A.B.C.D|X::X::X|HOSTNAME)|) (sender-
  port <1025-65535>|) (dscp WORD|)
```

Configure a bit max

use this attribute to configure a-bit-max

Attribute Name: a-bit-max

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```
<igp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igp-te">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<uni-link>
<delay-threshold>
<a-bit> <!-- operation="delete"-->
  <a-bit-max>1</a-bit-max>
  <config>
    <a-bit-max>1</a-bit-max>
    <a-bit-min>1</a-bit-min>
  </config>
  <a-bit-min>1</a-bit-min>
</a-bit>
</delay-threshold>
</uni-link>
</interface>
</interfaces>
</igp-te>
```

Command Syntax

```
delay-measurement a-bit-delay-threshold min <1-16777215> max <1-16777215>
```

Configure max value

use this attribute to configure max-value

Attribute Name: max-value

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```
<igp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igp-te">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<uni-link>
<min-max-delay>
<delay> <!-- operation="delete"-->
  <max-value>1</max-value>
<config>
  <max-value>1</max-value>
```

```

    <min-value>1</min-value>
  </config>
  <min-value>1</min-value>
</delay>
</min-max-delay>
</uni-link>
</interface>
</interfaces>
</igp-te>

```

Command Syntax

```
delay-measurement static min-max-uni-link-delay <1-16777215> <1-16777215>
```

Configure loss a bit max

use this attribute to configure loss-a-bit-max

Attribute Name: loss-a-bit-max

Attribute Type: decimal64

Netconf edit-config payload

```

<igp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igp-te">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <uni-link>
      <loss>
        <threshold> <!-- operation="delete"-->
          <loss-a-bit-max>VALUE</loss-a-bit-max>
          <config>
            <loss-a-bit-max>VALUE</loss-a-bit-max>
            <loss-a-bit-min>VALUE</loss-a-bit-min>
          </config>
          <loss-a-bit-min>VALUE</loss-a-bit-min>
        </threshold>
      </loss>
    </uni-link>
  </interface>
</interfaces>
</igp-te>

```

Command Syntax

```
loss-measurement a-bit-loss-threshold min VALUE max VALUE
```

Configure a bit max range maximum

use this attribute to configure a-bit-max-range-maximum

Attribute Name: a-bit-max-range-maximum

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```
<igp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igp-te">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <uni-link>
    <min-max-delay-threshold>
    <a-bit> <!-- operation="delete"-->
      <a-bit-max-range-maximum>1</a-bit-max-range-maximum>
      <config>
        <a-bit-max-range-maximum>1</a-bit-max-range-maximum>
        <a-bit-max-range-minimum>1</a-bit-max-range-minimum>
        <a-bit-min-range-maximum>1</a-bit-min-range-maximum>
        <a-bit-min-range-minimum>1</a-bit-min-range-minimum>
      </config>
      <a-bit-max-range-minimum>1</a-bit-max-range-minimum>
      <a-bit-min-range-maximum>1</a-bit-min-range-maximum>
      <a-bit-min-range-minimum>1</a-bit-min-range-minimum>
    </a-bit>
    </min-max-delay-threshold>
    </uni-link>
  </interface>
</interfaces>
</igp-te>
```

Command Syntax

```
delay-measurement a-bit-min-max-delay-threshold min <1-16777215> <1-16777215> max
<1-16777215> <1-16777215>
```

clear twamp measurement interface IFNAME

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-128

Netconf RPC payload

```
<twamp-clear-measurement-intf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igp-te">
  <interface-name>IFNAME</interface-name>
</twamp-clear-measurement-intf>
```

Command Syntax

```
clear twamp measurement interface IFNAME
```

clear twamp measurement interface all

Netconf RPC payload

```
<twamp-clear-measurement-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igp-te"/>
```

Command Syntax

```
clear twamp measurement interface all
```

IPI-VRRP

Configure disable virtual router mac address

Use this attribute to enable or disable Virtual MAC (VMAC). This affects all VRRP groups in a router. On a single network segment, multiple VRRP groups can be configured, each using a different VMAC. The use of VMAC addressing allows for faster switchover when a backup router assumes the master role. When this attribute is used to enable a VMAC, the virtual router forwards packets with a special-purpose multicast VMAC address (0:0:5e:0:01:VR_ID). Otherwise, it forwards with interface physical address. The VMAC address is assigned to a router interface at the time the VRRP group is enabled in the router.

Attribute Name: disable-virtual-router-mac-address

Attribute Type: empty

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
  <global>
    <config>
      </disable-virtual-router-mac-address><!-- operation="delete"-->
    </config>
  </global>
</vrrp>
```

Command Syntax

```
vrrp vmac disable
```

Configure vrrp v2 compatible

Use this attribute to enable or disable backward-compatibility feature. When enabled, both VRRPv3 and VRRPv2 interoperation are supported.

Attribute Name: vrrp-v2-compatible

Attribute Type: empty

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
<global>
<config>
  </vrrp-v2-compatible><!-- operation="delete"-->
</config>
</global>
</vrrp>
```

Command Syntax

```
vrrp compatible-v2 enable
```

Configure ipv4 exclude pseudo header

This command excludes the pseudo-header in IPv4 VRRPv3 checksum calculation on the VRRP group

Attribute Name: ipv4-exclude-pseudo-header

Attribute Type: empty

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
<global>
<config>
  </ipv4-exclude-pseudo-header><!-- operation="delete"-->
</config>
</global>
</vrrp>
```

Command Syntax

```
vrrp ipv4-exclude-pseudo-header enable
```

Configure options

use this attribute to specify debugging options for VRRP

Attribute Name: options

Attribute Type: bits (all|packet|events|packet send|packet rcv)

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
<debug>
<config>
  <options>14</options> <!-- operation="delete"-->
</config>
</debug>
</vrrp>
```

Command Syntax

```
debug vrrp
```

Configure interface name

Use this attribute to configure an VRRP routing process for an interface.

Attribute Name: interface-name

Attribute Type: string

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
  <ipv4-instances>
    <ipv4-instance>
      <virtual-router-id>1</virtual-router-id>
      <config>
        <virtual-router-id>1</virtual-router-id>
      </config>
    </ipv4-instance>
  </ipv4-instances>
  <interfaces>
    <interface> <!-- operation="delete"-->
      <interface-name>IFNAME</interface-name>
      <config>
        <interface-name>WORD</interface-name>
      </config>
    </interface>
  </interfaces>
</vrrp>
```

Command Syntax

```
router vrrp <1-255> IFNAME
```

Configure disable preempt mode

Use this attribute to configure preempt mode. If set to true, the highest priority backup is always the master when the default master is unavailable. If set to false, a higher priority backup does not preempt a lower priority backup which is acting as master

Attribute Name: disable-preempt-mode

Attribute Type: empty

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
  <ipv4-instances>
    <ipv4-instance>
      <virtual-router-id>1</virtual-router-id>
      <config>
        <virtual-router-id>1</virtual-router-id>
      </config>
    </ipv4-instance>
  </ipv4-instances>
  <interfaces>
    <interface>
      <interface-name>IFNAME</interface-name>
    </interface>
  </interfaces>
</vrrp>
```

```
<config>
  <interface-name>WORD</interface-name>
</config>
  </disable-preempt-mode><!-- operation="delete"-->
</interface>
</interfaces>
</ipv4-instance>
</ipv4-instances>
</vrrp>
```

Command Syntax

```
preempt-mode false
```

Configure disable accept mode

Use this attribute to enable accept mode for the session

Attribute Name: disable-accept-mode

Attribute Type: empty

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
  <ipv4-instances>
  <ipv4-instance>
    <virtual-router-id>1</virtual-router-id>
    <config>
      <virtual-router-id>1</virtual-router-id>
    </config>
  <interfaces>
  <interface>
    <interface-name>IFNAME</interface-name>
    <config>
      <interface-name>WORD</interface-name>
    </config>
    </disable-accept-mode><!-- operation="delete"-->
  </interface>
</interfaces>
</ipv4-instance>
</ipv4-instances>
</vrrp>
```

Command Syntax

```
accept-mode false
```

Configure virtual router id

Use this attribute to enable or disable the backward-compatibility feature

Attribute Name: vrrp-v2-compatible

Attribute Type: empty

Netconf edit-config payload

```

<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
<ipv4-instances>
<ipv4-instance>
  <virtual-router-id>1</virtual-router-id>
  <config>
    <virtual-router-id>1</virtual-router-id>
  </config>
</interfaces>
<interface>
  <interface-name>IFNAME</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  </vrrp-v2-compatible><!-- operation="delete"-->
</interface>
</interfaces>
</ipv4-instance>
</ipv4-instances>
</vrrp>

```

Command Syntax

```
v2-compatible
```

Configure authentication data

Use this attribute to include authentication simple text

Attribute Name: authentication-data

Attribute Type: string

Netconf edit-config payload

```

<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
<ipv4-instances>
<ipv4-instance>
  <virtual-router-id>1</virtual-router-id>
  <config>
    <virtual-router-id>1</virtual-router-id>
  </config>
</interfaces>
<interface>
  <interface-name>IFNAME</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  <authentication-data>TEXT-STRING</authentication-data> <!--
operation="delete"-->
</interface>
</interfaces>
</ipv4-instance>

```

```
</ipv4-instances>  
</vrrp>
```

Command Syntax

```
authentication text TEXT-STRING
```

Configure primary ip address

Use this attribute to set the operational-ip address for the virtual router

Attribute Name: primary-ip-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">  
<ipv4-instances>  
<ipv4-instance>  
  <virtual-router-id>1</virtual-router-id>  
  <config>  
    <virtual-router-id>1</virtual-router-id>  
  </config>  
<interfaces>  
<interface>  
  <interface-name>IFNAME</interface-name>  
  <config>  
    <interface-name>WORD</interface-name>  
    <primary-ip-address>A.B.C.D</primary-ip-address> <!-- operation="delete"-->  
  </config>  
</interface>  
</interfaces>  
</ipv4-instance>  
</ipv4-instances>  
</vrrp>
```

Command Syntax

```
operational-ip A.B.C.D
```

Configure mlag active standby

Use this attribute to set active-standby mlag mode

Attribute Name: mlag-active-standby

Attribute Type: empty

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">  
<ipv4-instances>  
<ipv4-instance>  
  <virtual-router-id>1</virtual-router-id>  
  <config>
```

```

        <virtual-router-id>1</virtual-router-id>
    </config>
</interfaces>
<interface>
    <interface-name>IFNAME</interface-name>
    <config>
        <interface-name>WORD</interface-name>
    </config>
    </mlag-active-standby><!-- operation="delete"-->
</interface>
</interfaces>
</ipv4-instance>
</ipv4-instances>
</vrrp>

```

Command Syntax

```
mlag active-standby
```

Configure priority

Use this attribute to configure the VRRP router priority within the virtual router. Priority determines the role that each VRRP router plays and what happens if the master virtual router fails. If a VRRP router owns the IP address of the virtual router and the IP address of the physical interface, this router functions as the master virtual router

Attribute Name: priority

Attribute Type: uint8

Attribute Range: 1-254

Netconf edit-config payload

```

<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
  <ipv4-instances>
    <ipv4-instance>
      <virtual-router-id>1</virtual-router-id>
      <config>
        <virtual-router-id>1</virtual-router-id>
      </config>
    </interfaces>
    <interface>
      <interface-name>IFNAME</interface-name>
      <config>
        <interface-name>WORD</interface-name>
      </config>
      <priority>1</priority> <!-- operation="delete"-->
    </interface>
  </interfaces>
</ipv4-instance>
</ipv4-instances>
</vrrp>

```

Command Syntax

```
priority <1-254>
```

Configure preempt delay

Use this attribute to set a switch-back delay timer for the master VRRP router. This feature prevents the original master VRRP router from transitioning back to the master state after coming back online until the configured delay timer has expired.

Attribute Name: preempt-delay

Attribute Type: uint32

Attribute Range: 1-500000

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
  <ipv4-instances>
    <ipv4-instance>
      <virtual-router-id>1</virtual-router-id>
      <config>
        <virtual-router-id>1</virtual-router-id>
      </config>
    </ipv4-instance>
  </ipv4-instances>
  <interfaces>
    <interface>
      <interface-name>IFNAME</interface-name>
      <config>
        <interface-name>WORD</interface-name>
        <preempt-delay>1</preempt-delay> <!-- operation="delete"-->
      </config>
    </interface>
  </interfaces>
</vrrp>
```

Command Syntax

```
switch-back-delay <1-500000>
```

Configure advertisement interval

Use this attribute to configure the advertisement interval of a virtual router. This is the length of time, in seconds, between each advertisement sent from the master to its backup(s). The master virtual router sends VRRP advertisements to other VRRP routers in the same group. The advertisements communicate the priority and state of the master virtual router. The VRRP advertisements are encapsulated in IP packets and sent to the multicast address assigned to the VRRP group (224.0.0.18). Advertisements are sent every second by default.

Attribute Name: advertisement-interval

Attribute Type: uint16

Default Value: 100

Attribute Range: 5-4095

Netconf edit-config payload

```

<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
<ipv4-instances>
<ipv4-instance>
  <virtual-router-id>1</virtual-router-id>
  <config>
    <virtual-router-id>1</virtual-router-id>
  </config>
</interfaces>
<interface>
  <interface-name>IFNAME</interface-name>
  <config>
    <interface-name>WORD</interface-name>
    </config>
    <advertisement-interval>5</advertisement-interval> <!-- operation="delete"-->
  </interface>
</interfaces>
</ipv4-instance>
</ipv4-instances>
</vrrp>

```

Command Syntax

```
advertisement-interval <5-4095>
```

Configure enable

Use this attribute to enable a VRRP session on the router (to make it participate in virtual routing). To make any changes to the VRRP configuration, first disable the router from participating in virtual routing using the disable command

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```

<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
<ipv4-instances>
<ipv4-instance>
  <virtual-router-id>1</virtual-router-id>
  <config>
    <virtual-router-id>1</virtual-router-id>
  </config>
</interfaces>
<interface>
  <interface-name>IFNAME</interface-name>
  <config>
    <interface-name>WORD</interface-name>
    </config>
    <protocol-enable>
  <config>
    </enable><!-- operation="delete"-->
  </interface>
</interfaces>
</ipv4-instance>
</ipv4-instances>
</vrrp>

```

```
</config>
</protocol-enable>
</interface>
</interfaces>
</ipv4-instance>
</ipv4-instances>
</vrrp>
```

Command Syntax

```
enable
```

Configure ip address owner

Use this attribute to set the virtual IP address for the VRRP virtual router as VRRP Owner. This is the IP address used by end hosts to address their default gateway.

Attribute Name: ip-address-owner

Attribute Type: boolean

Attribute Name: virtual-ip-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
  <ipv4-instances>
    <ipv4-instance>
      <virtual-router-id>1</virtual-router-id>
      <config>
        <virtual-router-id>1</virtual-router-id>
      </config>
    </ipv4-instance>
  </ipv4-instances>
  <interface>
    <interface-name>IFNAME</interface-name>
    <config>
      <interface-name>WORD</interface-name>
    </config>
    <virtual-ip>
      <config>
        <virtual-ip-address>A.B.C.D</virtual-ip-address>
        <ip-address-owner>true</ip-address-owner>
      </config>
    </virtual-ip>
  </interface>
</vrrp>
```

Command Syntax

```
virtual-ip A.B.C.D (owner|)
```

Configure interface tracking name

Use this command to enable the VRRP circuit failover feature.

Attribute Name: interface-tracking-name

Attribute Type: string

Attribute Name: priority-decrement

Attribute Type: uint8

Attribute Range: 1-253

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
  <ipv4-instances>
    <ipv4-instance>
      <virtual-router-id>1</virtual-router-id>
      <config>
        <virtual-router-id>1</virtual-router-id>
      </config>
    </ipv4-instance>
  </ipv4-instances>
  <interfaces>
    <interface>
      <interface-name>IFNAME</interface-name>
      <config>
        <interface-name>WORD</interface-name>
      </config>
      <interfaces-tracking>
        <interface-tracking> <!-- operation="delete"-->
          <interface-tracking-name>IFNAME</interface-tracking-name>
          <config>
            <interface-tracking-name>WORD</interface-tracking-name>
            <priority-decrement>1</priority-decrement>
          </config>
        </interface-tracking>
      </interfaces-tracking>
    </interface>
  </interfaces>
</vrrp>
```

Command Syntax

```
circuit-failover IFNAME <1-253>
```

Configure tracking id

Use this command to enable the VRRP object tracking feature.

This command is supported when following feature are enabled HAVE_OBJ_TRACKING

Attribute Name: tracking-id

Attribute Type: uint16

Attribute Name: decrement

Attribute Type: uint8

Attribute Range: 1-253

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
  <ipv4-instances>
    <ipv4-instance>
      <virtual-router-id>1</virtual-router-id>
      <config>
        <virtual-router-id>1</virtual-router-id>
      </config>
    </ipv4-instance>
  </ipv4-instances>
  <interfaces>
    <interface>
      <interface-name>IFNAME</interface-name>
      <config>
        <interface-name>WORD</interface-name>
      </config>
      <objects-tracking>
        <object-tracking <!-- operation="delete"-->
          <tracking-id>0</tracking-id>
          <config>
            <tracking-id>1</tracking-id>
            <decrement>1</decrement>
          </config>
        </object-tracking>
      </objects-tracking>
    </interface>
  </interfaces>
</vrrp>
```

Command Syntax

```
track <0-65535> decrement <1-253>
```

Configure virtual ip address

VRRP Virtual IPV6 address

This command is supported when following feature are enabled IPV6 feature

Attribute Name: virtual-ip-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
  <ipv6-instances>
    <ipv6-instance>
      <virtual-router-id>1</virtual-router-id>
```

```

    <config>
      <virtual-router-id>1</virtual-router-id>
    </config>
  </interfaces>
</interface>
  <interface-name>IFNAME</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  <virtual-ip-addresses>
  <virtual-ip-address> <!-- operation="delete"-->
    <virtual-ip-address>X:X::X:X</virtual-ip-address>
    <config>
      <virtual-ip-address>X:X::X:X</virtual-ip-address>
    </config>
  </virtual-ip-address>
</virtual-ip-addresses>
</interface>
</interfaces>
</ipv6-instance>
</ipv6-instances>
</vrrp>

```

Command Syntax

```
virtual-ipv6 X:X::X:X
```

Configure priority decrement

Use this command to enable the VRRP circuit failover feature.

Attribute Name: interface-tracking-name

Attribute Type: string

Attribute Name: priority-decrement

Attribute Type: uint8

Attribute Range: 1-253

Netconf edit-config payload

```

<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
  <ipv6-instances>
  <ipv6-instance>
    <virtual-router-id>1</virtual-router-id>
    <config>
      <virtual-router-id>1</virtual-router-id>
    </config>
  </interfaces>
  <interface>
    <interface-name>IFNAME</interface-name>
    <config>
      <interface-name>WORD</interface-name>

```

```
</config>
<interfaces-tracking>
<interface-tracking> <!-- operation="delete"-->
  <interface-tracking-name>IFNAME</interface-tracking-name>
  <config>
    <interface-tracking-name>WORD</interface-tracking-name>
    <priority-decrement>1</priority-decrement>
  </config>
</interface-tracking>
</interfaces-tracking>
</interface>
</interfaces>
</ipv6-instance>
</ipv6-instances>
</vrrp>
```

Command Syntax

```
circuit-failover IFNAME <1-253>
```

Configure decrement

Use this command to enable the VRRP object tracking feature.

This command is supported when following feature are enabled HAVE_OBJ_TRACKING

Attribute Name: tracking-id

Attribute Type: uint16

Attribute Name: decrement

Attribute Type: uint8

Attribute Range: 1-253

Netconf edit-config payload

```
<vrrp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">
<ipv6-instances>
<ipv6-instance>
  <virtual-router-id>1</virtual-router-id>
  <config>
    <virtual-router-id>1</virtual-router-id>
  </config>
</interfaces>
<interface>
  <interface-name>IFNAME</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  <objects-tracking>
  <object-tracking> <!-- operation="delete"-->
    <tracking-id>0</tracking-id>
    <config>
      <tracking-id>1</tracking-id>
```

```
        <decrement>1</decrement>
    </config>
</object-tracking>
</objects-tracking>
</interface>
</interfaces>
</ipv6-instance>
</ipv6-instances>
</vrrp>
```

Command Syntax

```
track <0-65535> decrement <1-253>
```

snmp restart vrrp

Netconf RPC payload

```
<vrrp-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp"/>
```

Command Syntax

```
snmp restart vrrp
```

clear vrrp global statistics

Netconf RPC payload

```
<vrrp-clear-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp"/>
```

Command Syntax

```
clear vrrp global statistics
```

clear vrrp ipv4 statistics

Netconf RPC payload

```
<vrrp-clear-ipv4-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp"/>
```

Command Syntax

```
clear vrrp ipv4 statistics
```

clear vrrp ipv6 statistics

Netconf RPC payload

```
<vrrp-clear-ipv6-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp"/>
```

Command Syntax

```
clear vrrp ipv6 statistics
```

clear vrrp ipv4 statistics <1-255> IFNAME

Attribute Name: vrrp-id

Attribute Type: uint8

Attribute Range: 1-255

Attribute Name: interface-name

Attribute Type: string

Netconf RPC payload

```
<vrrp-clear-session-ipv4-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-vrrp">
  <vrrp-id>1</vrrp-id>
  <interface-name>IFNAME</interface-name>
</vrrp-clear-session-ipv4-statistics>
```

Command Syntax

```
clear vrrp ipv4 statistics <1-255> IFNAME
```

clear vrrp ipv6 statistics <1-255> IFNAME

Attribute Name: vrrp-id

Attribute Type: uint8

Attribute Range: 1-255

Attribute Name: interface-name

Attribute Type: string

Netconf RPC payload

```
<vrrp-clear-session-ipv6-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-vrrp">
  <vrrp-id>1</vrrp-id>
  <interface-name>IFNAME</interface-name>
</vrrp-clear-session-ipv6-statistics>
```

Command Syntax

```
clear vrrp ipv6 statistics <1-255> IFNAME
```

debug vrrp

Netconf RPC payload

```
<vrrp-terminal-debug-all-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
vrrp"/>
```

Command Syntax

```
debug vrrp
```

no debug vrrp

Netconf RPC payload

```
<vrrp-terminal-debug-all-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp"/>
```

Command Syntax

```
no debug vrrp
```

debug vrrp (all|packet|events|packet send|packet recv)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|packet|events|packet send|packet recv)

Netconf RPC payload

```
<vrrp-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">  
<terminal-debug-options>all</terminal-debug-options>  
</vrrp-terminal-debug-on>
```

Command Syntax

```
debug vrrp (all|packet|events|packet send|packet recv)
```

no debug vrrp (all|packet|events|packet send|packet recv)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|packet|events|packet send|packet recv)

Netconf RPC payload

```
<vrrp-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vrrp">  
<terminal-debug-options>all</terminal-debug-options>  
</vrrp-terminal-debug-off>
```

Command Syntax

```
no debug vrrp (all|packet|events|packet send|packet recv)
```

IPI-PREFIX-LIST

Configure prefix list name

prefix-list name

Attribute Name: prefix-list-name

Attribute Type: string

Netconf edit-config payload

```
<prefixes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-list">
```

```
<prefix> <!-- operation="delete"-->
  <prefix-list-type>ip</prefix-list-type>
  <config>
    <prefix-list-type>ip</prefix-list-type>
    <prefix-list-name>WORD</prefix-list-name>
  </config>
  <prefix-list-name>WORD</prefix-list-name>
</prefix>
</prefixes>
```

Command Syntax

```
ip prefix-list WORD
```

Configure prefix list type

prefix-list name

Attribute Name: prefix-list-name

Attribute Type: string

Netconf edit-config payload

```
<prefixes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-list">
  <prefix> <!-- operation="delete"-->
    <prefix-list-type>ipv6</prefix-list-type>
    <config>
      <prefix-list-type>ipv6</prefix-list-type>
      <prefix-list-name>WORD</prefix-list-name>
    </config>
    <prefix-list-name>WORD</prefix-list-name>
  </prefix>
</prefixes>
```

Command Syntax

```
ipv6 prefix-list WORD
```

Configure description

Up to 80 characters describing this prefix-list

Attribute Name: description

Attribute Type: string

Attribute Range: 1-80

Netconf edit-config payload

```
<prefixes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-list">
  <prefix>
    <prefix-list-type>ip</prefix-list-type>
    <config>
      <prefix-list-type>ip</prefix-list-type>
    </config>
  </prefix>
</prefixes>
```

```

    <prefix-list-name>WORD</prefix-list-name>
  </config>
  <prefix-list-name>WORD</prefix-list-name>
  <description>LINE</description> <!-- operation="delete"-->
</prefix>
</prefixes>

```

Command Syntax

```
description LINE
```

Configure prefix addr

Either IP address mask and length of the prefix list mask or Take all packets of any length. This parameter is the same as using 0.0.0.0/0 le 32 for A.B.C.D/M.

Attribute Name: prefix-addr

Attribute Type: union

Netconf edit-config payload

```

<prefixes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-list">
  <prefix>
    <prefix-list-type>ip</prefix-list-type>
    <config>
      <prefix-list-type>ip</prefix-list-type>
      <prefix-list-name>WORD</prefix-list-name>
    </config>
    <prefix-list-name>WORD</prefix-list-name>
  </prefix-entries>
  <prefix-entry>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
    </config>
    <ipv4>
      <entry>
        <prefix-addr>any</prefix-addr>
        <config>
          <prefix-addr>any</prefix-addr>
          <action>deny</action>
        </config>
        <action>deny</action>
      </entry>
    </ipv4>
  </prefix-entry>
</prefix-entries>
</prefix>
</prefixes>

```

Command Syntax

```
(seq <1-4294967295>|) (deny|permit) any
```

Configure sequence id

Either IP address mask and length of the prefix list mask or Take all packets of any length. This parameter is the same as using 0.0.0.0/0 le 32 for A.B.C.D/M.

Attribute Name: prefix-addr

Attribute Type: enum (any)

Netconf edit-config payload

```
<prefixes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-list">
  <prefix>
    <prefix-list-type>ip</prefix-list-type>
    <config>
      <prefix-list-type>ip</prefix-list-type>
      <prefix-list-name>WORD</prefix-list-name>
    </config>
    <prefix-list-name>WORD</prefix-list-name>
  </prefix-entries>
  <prefix-entry>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
    </config>
    <ipv4>
      <entry>
        <prefix-addr>any</prefix-addr>
        <config>
          <prefix-addr>any</prefix-addr>
          <action>deny</action>
        </config>
        <action>deny</action>
      </entry>
    </ipv4>
  </prefix-entry>
</prefix-entries>
</prefix>
</prefixes>
```

Command Syntax

```
(seq <1-4294967295>|) (deny|permit)
```

Configure maximum prefix length match

Maximum prefix length match

Attribute Name: maximum-prefix-length-match

Attribute Type: uint8

Attribute Range: 0-32

Attribute Name: minimum-prefix-length-match

Attribute Type: uint8

Attribute Range: 0-32

Netconf edit-config payload

```
<prefixes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-list">
  <prefix>
    <prefix-list-type>ip</prefix-list-type>
    <config>
      <prefix-list-type>ip</prefix-list-type>
      <prefix-list-name>WORD</prefix-list-name>
    </config>
    <prefix-list-name>WORD</prefix-list-name>
  </prefix-entries>
  <prefix-entry>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
    </config>
    <ipv4>
      <entry>
        <prefix-addr>any</prefix-addr>
        <config>
          <prefix-addr>any</prefix-addr>
          <action>deny</action>
          <minimum-prefix-length-match>0</minimum-prefix-length-match> <!--
operation="delete"-->
          </config>
          <action>deny</action>
          <maximum-prefix-length-match>0</maximum-prefix-length-match> <!--
operation="delete"-->
        </entry>
      </ipv4>
    </prefix-entry>
  </prefix-entries>
</prefix>
</prefixes>
```

Command Syntax

```
(seq <1-4294967295>|) (deny|permit) ge <0-32> le <0-32>
```

Configure minimum prefix length match

Minimum prefix length match

Attribute Name: minimum-prefix-length-match

Attribute Type: uint8

Attribute Range: 0-32

Attribute Name: maximum-prefix-length-match

Attribute Type: uint8

Attribute Range: 0-32

Netconf edit-config payload

```
<prefixes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-list">
  <prefix>
    <prefix-list-type>ip</prefix-list-type>
    <config>
      <prefix-list-type>ip</prefix-list-type>
      <prefix-list-name>WORD</prefix-list-name>
    </config>
    <prefix-list-name>WORD</prefix-list-name>
  </prefix-entries>
  <prefix-entry>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
    </config>
    <ipv4>
      <entry>
        <prefix-addr>any</prefix-addr>
        <config>
          <prefix-addr>any</prefix-addr>
          <action>deny</action>
          <maximum-prefix-length-match>0</maximum-prefix-length-match> <!--
operation="delete"-->
          </config>
          <action>deny</action>
          <minimum-prefix-length-match>0</minimum-prefix-length-match> <!--
operation="delete"-->
        </entry>
      </ipv4>
    </prefix-entry>
  </prefix-entries>
</prefix>
</prefixes>
```

Command Syntax

```
(seq <1-4294967295>|) (deny|permit) le <0-32> ge <0-32>
```

Configure action

Minimum prefix length match

Attribute Name: minimum-prefix-length-match

Attribute Type: uint8

Attribute Range: 0-32

Netconf edit-config payload

```
<prefixes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-list">
  <prefix>
```

```

    <prefix-list-type>ip</prefix-list-type>
  <config>
    <prefix-list-type>ip</prefix-list-type>
    <prefix-list-name>WORD</prefix-list-name>
  </config>
  <prefix-list-name>WORD</prefix-list-name>
</prefix-entries>
<prefix-entry>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
  </config>
  <ipv4>
  <entry>
    <prefix-addr>any</prefix-addr>
    <config>
      <prefix-addr>any</prefix-addr>
      <action>deny</action>
    </config>
    <action>deny</action>
    <minimum-prefix-length-match>0</minimum-prefix-length-match> <!--
operation="delete"-->
  </entry>
</ipv4>
</prefix-entry>
</prefix-entries>
</prefix>
</prefixes>

```

Command Syntax

```
(seq <1-4294967295>|) (deny|permit) ge <0-32>
```

Configure exact prefix length match

Exact prefix length match

Attribute Name: exact-prefix-length-match

Attribute Type: uint8

Attribute Range: 0-32

Netconf edit-config payload

```

<prefixes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-list">
  <prefix>
    <prefix-list-type>ip</prefix-list-type>
    <config>
      <prefix-list-type>ip</prefix-list-type>
      <prefix-list-name>WORD</prefix-list-name>
    </config>
    <prefix-list-name>WORD</prefix-list-name>
  </prefix-entries>

```

```

<prefix-entry>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
  </config>
  <ipv4>
  <entry>
    <prefix-addr>any</prefix-addr>
    <config>
      <prefix-addr>any</prefix-addr>
      <action>deny</action>
    </config>
    <action>deny</action>
    <exact-prefix-length-match>0</exact-prefix-length-match> <!--
operation="delete"-->
  </entry>
</ipv4>
</prefix-entry>
</prefix-entries>
</prefix>
</prefixes>

```

Command Syntax

```
(seq <1-4294967295>|) (deny|permit) eq <0-32>
```

Configure ipv6 prefix addr

Either IPv6 address mask and length of the prefix list mask or This is the same as specifying ::/0 for X:X::X:X/M

This command is supported when following feature are enabled ipv6 feature

Attribute Name: ipv6-prefix-addr

Attribute Type: union

Netconf edit-config payload

```

<prefixes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-list">
  <prefix>
    <prefix-list-type>ip</prefix-list-type>
    <config>
      <prefix-list-type>ip</prefix-list-type>
      <prefix-list-name>WORD</prefix-list-name>
    </config>
    <prefix-list-name>WORD</prefix-list-name>
  </prefix-entries>
  <prefix-entry>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
    </config>
    <ipv6>
    <entry> <!-- operation="delete"-->

```



```

    <ipv6-prefix-addr>any</ipv6-prefix-addr>
  <config>
    <ipv6-prefix-addr>any</ipv6-prefix-addr>
    <action>deny</action>
  </config>
  <action>deny</action>
</entry>
</ipv6>
</prefix-entry>
</prefix-entries>
</prefix>
</prefixes>

```

Command Syntax

```
(seq <1-4294967295>|) (deny|permit) any
```

Configure disable ipv4 sequence display

Use this attribute to configure prefix list sequence number. Include and exclude sequence numbers in nonvolatile generation (NVGEN).

Attribute Name: disable-ipv4-sequence-display

Attribute Type: empty

Netconf edit-config payload

```

<prefixes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-list">
  <global>
    <config>
      </disable-ipv4-sequence-display><!-- operation="delete"-->
    </config>
  </global>
</prefixes>

```

Command Syntax

```
no ip prefix-list sequence-number
```

Configure disable ipv6 sequence display

Use this attribute to configure prefix list sequence number. Include and exclude sequence numbers in nonvolatile generation (NVGEN).

Attribute Name: disable-ipv6-sequence-display

Attribute Type: empty

Netconf edit-config payload

```

<prefixes xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-list">
  <global>
    <config>
      </disable-ipv6-sequence-display><!-- operation="delete"-->
    </config>
  </global>
</prefixes>

```

```
</global>
</prefixes>
```

Command Syntax

```
no ipv6 prefix-list sequence-number
```

clear (ip|ipv6) prefix-list

Attribute Name: type

Attribute Type: enum (ip|ipv6)

Netconf RPC payload

```
<clear-prefix-list-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-
list">
  <type>ip</type>
</clear-prefix-list-all>
```

Command Syntax

```
clear (ip|ipv6) prefix-list
```

clear ip prefix-list WORD (A.B.C.D/M|)

Attribute Name: prefix-list-name

Attribute Type: string

Attribute Name: prefix

Attribute Type: string

Netconf RPC payload

```
<clear-ipv4-prefix-list xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-
list">
  <prefix-list-name>WORD</prefix-list-name>
  <prefix>A.B.C.D/M</prefix>
</clear-ipv4-prefix-list>
```

Command Syntax

```
clear ip prefix-list WORD (A.B.C.D/M|)
```

clear ipv6 prefix-list WORD (X:X::X:X/M|)

Attribute Name: prefix-list-name

Attribute Type: string

Attribute Name: prefix

Attribute Type: string

Netconf RPC payload

```
<clear-ipv6-prefix-list xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-prefix-
list">
```

```
<prefix-list-name>WORD</prefix-list-name>  
<prefix>X:X::X:X/M</prefix>  
</clear-ipv6-prefix-list>
```

Command Syntax

```
clear ipv6 prefix-list WORD (X:X::X:X/M|)
```

IPI-ISIS

Configure vrf name

VRF Name to associate with this instance

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">  
<isis-instances>  
<isis-instance>  
  <instance>WORD</instance>  
  <config>  
    <instance>WORD</instance>  
  </config>  
  <vrf-name>WORD</vrf-name>  
</isis-instance>  
</isis-instances>  
</isis>
```

Command Syntax

```
router isis WORD WORD
```

Configure instance

Use this attribute to initiate an ISIS routing instance. Configure at least one NET to start routing.

Attribute Name: instance

Attribute Type: string

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">  
<isis-instances>  
<isis-instance> <!-- operation="delete"-->  
  <instance>WORD</instance>  
<config>
```

```
        <instance>WORD</instance>
        <vrf-name>WORD</vrf-name>
    </config>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
router isis WORD
```

Configure enable cspf capability

Use this attribute to enable the constrained shortest path first (CSPF) feature in the ISIS module. CSPF calculates optimum explicit route (ER), using Traffic Engineering Database and (TED) and pre-existing Label Switched Path (LSP). The resulting ER is used by a signaling protocol (RSVP-TE) to set up LSPs.

Attribute Name: enable-cspf-capability

Attribute Type: uint8

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    </enable-cspf-capability><!-- operation="delete"-->
  </isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
enable-cspf
```

Configure disable gr capability

Use this attribute to enable the GR

Attribute Name: disable-gr-capability

Attribute Type: uint8

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    </disable-gr-capability>
  </isis-instance>
</isis-instances>
</isis>
```

```

    </disable-gr-capability><!-- operation="delete"-->
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
no capability restart graceful
```

Configure disable adjacency check

Use this attribute to configure the policy of adjacency based on the protocol related TLVs in the ISIS Hello packet. ISIS checks adjacency with protocol related TLVs including Protocols Supported TLV or IP Interface Address TLV by default. The command with no parameter disables this check.

Attribute Name: disable-adjacency-check

Attribute Type: uint8

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
    <instance>WORD</instance>
    <config>
        <instance>WORD</instance>
    </config>
    </disable-adjacency-check><!-- operation="delete"-->
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
no adjacency-check
```

Configure authentication send only

Use this attribute to set the send-only option at the instance level. Use this command before configuring the authentication mode and authentication key-chain, so that the implementation of authentication goes smoothly. That is, the routers will have more time for the keys to be configured on each router if authentication is inserted only on the packets being sent, not checked on packets being received. After all routers that must communicate are configured with this command, enable the authentication mode and key chain on each router.

Attribute Name: authentication-send-only

Attribute Type: enum (level-1-only|level-2-only|level-1-2)

Default Value: level-1-2

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
    <instance>WORD</instance>

```

```
<config>
  <instance>WORD</instance>
</config>
<authentication-send-only>3</authentication-send-only> <!-- operation="delete"-->
>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
authentication send-only level-1
```

Configure distribute bgp ls

Use this attribute to distribute linkstate and TE Database to BGP

Attribute Name: distribute-bgp-ls

Attribute Type: union

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <distribute-bgp-ls>0</distribute-bgp-ls> <!-- operation="delete"-->
    </isis-instance>
  </isis-instances>
</isis>
```

Command Syntax

```
distribute bgp-ls
```

Configure distance

Use this attribute to set the administrative distance for all IPv4 routes.

Attribute Name: distance

Attribute Type: uint8

Default Value: 115

Attribute Range: 1-255

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
    </isis-instance>
  </isis-instances>
</isis>
```

```

    <config>
      <instance>WORD</instance>
    </config>
    <distance>1</distance> <!-- operation="delete"-->
  </isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
distance <1-255>
```

Configure dynamic host name

Use this attribute to configure the hostname to be advertised for an ISIS instance using the dynamic hostname exchange mechanism (RFC 2763) and system-ID-to-hostname translation. This command configures a hostname to be used for the Dynamic Hostname Exchange Mechanism and System-ID to hostname translation. Use the routing area tag as the hostname, not the router's global hostname

Attribute Name: dynamic-host-name

Attribute Type: enum (dynamic-hostname|area-tag)

Default Value: dynamic-hostname

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <dynamic-host-name>dynamic-hostname</dynamic-host-name> <!-- operation="delete"-
->
    </isis-instance>
  </isis-instances>
</isis>

```

Command Syntax

```
dynamic-hostname (area-tag|)
```

Configure ignore lsp errors

Use this attribute to ignore LSPs with checksum errors. By default, ISIS validates checksum for LSP whenever it receives LSPs and if the checksum has an error, the LSP will be dropped. Configuring this command to ignore the LSP checksum error and treat it as if checksum is passed.

Attribute Name: ignore-lsp-errors

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
```

```
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
</ignore-lsp-errors><!-- operation="delete"-->
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
ignore-lsp-errors
```

Configure lfa hold timer

LFA terminate-hold-on interval

Attribute Name: lfa-hold-timer

Attribute Type: int32

Default Value: 1000

Attribute Range: 100-100000

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
  <lfa-hold-timer>100</lfa-hold-timer> <!-- operation="delete"-->
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
fast-reroute terminate-hold-on interval <100-100000>
```

Configure protocol topology

Use this attribute to configure ISIS Protocol Topology Support.

Attribute Name: protocol-topology

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
```



```

<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
</protocol-topology><!-- operation="delete"-->
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
protocol-topology
```

Configure level capability

Use this attribute to set the IS to the specified level of routing. Changing is-type brings down, then brings up a particular level of routing. There is a limitation: Only one ISIS instance can run Level-2 routing (either Level-2 only IS, or Level-1-2 IS)

Attribute Name: level-capability

Attribute Type: enum (level-1|level-2-only|level-1-2)

Default Value: level-1-2

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <level-capability>level-1-2</level-capability> <!-- operation="delete"-->
    </isis-instance>
  </isis-instances>
</isis>

```

Command Syntax

```
is-type (level-1|level-2-only|level-1-2)
```

Configure incremental spf levels

Use this attribute to enable incremental SPF for a routing process

Attribute Name: incremental-spf-levels

Attribute Type: enum (level-1|level-2-only|level-1-2)

Default Value: level-1-2

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
```

```
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
  <incremental-spf-levels>level-1-2</incremental-spf-levels> <!--
operation="delete"-->
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
ispf (level-1|level-2-only|level-1-2|)
```

Configure priority tag

Use this attribute to set a high priority tag value

Attribute Name: priority-tag

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
  <priority-tag>1</priority-tag> <!-- operation="delete"-->
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
ip route high-priority tag <1-4294967295>
```

Configure enable bfd all interfaces

Use this attribute to enable the Bidirectional Forwarding Detection (BFD) feature on the interfaces enabled with this ISIS instance. This command sets BFD fall-over check for all the neighbors under specified process.

Attribute Name: enable-bfd-all-interfaces

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
```

```

<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
</enable-bfd-all-interfaces><!-- operation="delete"-->
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
bfd all-interfaces
```

Configure maximum area addresses

Use this attribute to set the maximum number of ISIS areas that can be configured on this router with the net command. By default, ISIS permits a maximum of three areas that can be defined on a router.

Attribute Name: maximum-area-addresses

Attribute Type: uint8

Default Value: 3

Attribute Range: 3-254

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <maximum-area-addresses>3</maximum-area-addresses> <!-- operation="delete"-->
    </isis-instance>
  </isis-instances>
</isis>

```

Command Syntax

```
max-area-address <3-254>
```

Configure context name

Use this attribute to set the SNMP context name for ISIS instance.

Attribute Name: context-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
```

```
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
  <context-name>WORD</context-name> <!-- operation="delete"-->
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
snmp context-name WORD
```

Configure area password

Use this attribute to set the authentication password for the Level-1 area and to set authentication on Level-1 SNP PDUs. This command enables authentication when receiving and sending LSP and SNP PDU in Level-1 areas. Area password must be the same for all the ISIS routers in the same area

Attribute Name: area-password

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
<area-authentication>
<config>
  <area-password>WORD</area-password>
</config>
</area-authentication>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
area-password WORD
```

Configure sequence number packet

Use this attribute to set the authentication password for the Level-1 area and to set authentication on Level-1 SNP PDUs. This command enables authentication when receiving and sending LSP and SNP PDU in Level-1 areas. Area password must be the same for all the ISIS routers in the same area

Attribute Name: sequence-number-packet

Attribute Type: enum (send-only|validate)

Attribute Name: area-password

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    <area-authentication>
      <config>
        <area-password>WORD</area-password> <!-- operation="delete"-->
        <sequence-number-packet>send-only</sequence-number-packet> <!--
operation="delete"-->
      </config>
    </area-authentication>
  </isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
area-password WORD authenticate snp (send-only|validate)
```

Configure net

Use this attribute to add a Network Entity Title (NET) for the instance. On a router running ISIS, a NET can be 8 to 20 bytes in length. The last byte is always the n-selector, and must be zero. The n-selector indicates no transport entity, and means that the packet is for the routing software of the system. The six bytes directly preceding the n-selector are the system ID. The system ID length is a fixed size and cannot be changed. The system ID must be unique throughout each area (Level 1) and throughout the backbone (Level 2). The bytes preceding the system ID are the area ID, which can be from 1 - 13 bytes in length. By default, a maximum of three NETs per router are allowed with a different area ID but the system ID should be the same for all NETs. You can increase the number of area IDs per system ID with the max-area-address command.

Attribute Name: net

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    <network-entity-title>
      <config>
```

```
        <net>NET</net> <!-- operation="delete"-->
</config>
</network-entity-title>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
net NET
```

Configure domain password

Use this attribute to set the authentication password for the Level-2 domain, and optionally, the authentication password on Level-2 SNP PDUs. Configuring this command to enable authentication when receiving and sending LSP and SNP PDU in Level-2 domain. Domain password must be the same in Level-2 domain.

Attribute Name: domain-password

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
<domain-authentication>
<config>
  <domain-password>WORD</domain-password>
</config>
</domain-authentication>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
domain-password WORD
```

Configure domain snp

Use this attribute to set the authentication password for the Level-2 domain, and optionally, the authentication password on Level-2 SNP PDUs. Configuring this command to enable authentication when receiving and sending LSP and SNP PDU in Level-2 domain. Domain password must be the same in Level-2 domain.

Attribute Name: domain-snp

Attribute Type: enum (send-only|validate)

Attribute Name: domain-password

Attribute Type: string

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
<domain-authentication>
<config>
  <domain-password>WORD</domain-password> <!-- operation="delete"-->
  <domain-snp>send-only</domain-snp> <!-- operation="delete"-->
</config>
</domain-authentication>
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
domain-password WORD authenticate snp (send-only|validate)
```

Configure level number

Use this attribute to configure the ISIS metric style for particular level

This command is supported when following feature are enabled wide metric feature

Attribute Name: level-number

Attribute Type: enum (level-1|level-2|level-1-2)

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
<metrics>
<metric> <!-- operation="delete"-->
  <level-number>level-1-2</level-number>
  <config>
    <level-number>level-1-2</level-number>
    <style>narrow</style>
  </config>
  <style>narrow</style>
</metric>
</metrics>
</isis-instance>
</isis-instances>

```

```
</isis>
```

Command Syntax

```
metric-style (narrow|wide|transition|narrow transition|wide transition) (level-1|level-2|)
```

Configure style

Use this attribute to configure the ISIS metric style

Attribute Name: style

Attribute Type: enum (narrow|wide|transition|narrow transition|wide transition)

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    </isis-instance>
  </isis-instances>
  <metrics>
    <metric>
      <level-number>level-1-2</level-number>
      <config>
        <level-number>level-1-2</level-number>
        <style>narrow</style>
      </config>
      <style>narrow</style>
    </metric>
  </metrics>
</isis>
```

Command Syntax

```
metric-style (narrow) level-1-2
```

Configure lsp refresh interval

Use this attribute to set the LSP refresh interval. IP Infusion Inc. recommends making the lsp-refresh-interval smaller than max-lsp-lifetime value.

Attribute Name: lsp-refresh-interval

Attribute Type: uint16

Default Value: 900

Attribute Range: 1-65535

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
lsp-refresh-interval <1-65535>
```

Configure lsp lifetime interval

Use this attribute to set the maximum LSP lifetime. You must set max-lsp-lifetime greater than lsp-refreshinterval.

Attribute Name: lsp-lifetime-interval

Attribute Type: uint16

Default Value: 1200

Attribute Range: 350-65535

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
max-lsp-lifetime <350-65535>
```

Configure ipv4 router id

Use this attribute to configure the traffic engineering stable IP address for a system.

Attribute Name: ipv4-router-id

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    </isis-instance>
  </isis-instances>
  <traffic-engineering>
    <config>
      <ipv4-router-id>A.B.C.D</ipv4-router-id> <!-- operation="delete"-->
    </config>
  </traffic-engineering>
</isis>
```

Command Syntax

```
mpls traffic-eng router-id A.B.C.D
```

Configure ipv6 router id

Use this attribute to configure the traffic engineering stable IPv6 address for a system.

Attribute Name: ipv6-router-id

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    </isis-instance>
  </isis-instances>
  <traffic-engineering>
    <config>
      <ipv6-router-id>X:X::X:X</ipv6-router-id> <!-- operation="delete"-->
    </config>
  </traffic-engineering>
</isis>
```

Command Syntax

```
mpls traffic-eng ipv6 router-id X:X::X:X
```

Configure enable

Use this attribute to redistribute reachability information from one level to the other level. If an distribute-list name is given with this command for an access list that does not exist, the routes are still redistributed.

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    <address-family-ipv6>
      <level-1-into-2-redistributes>
        <redistribute-level-1-into-2> <!-- operation="delete"-->
          </enable>
        <config>
          </enable>
        </config>
      </redistribute-level-1-into-2>
    </level-1-into-2-redistributes>
  </address-family-ipv6>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
redistribute isis level-1 into level-2
```

Configure level 1 acl

Use this attribute to redistribute reachability information from one level to the other level. If an distribute-list name is given with this command for an access list that does not exist, the routes are still redistributed.

Attribute Name: level-1-acl

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
```

```
    <instance>WORD</instance>
  </config>
<address-family-ipv6>
<level-1-into-2-redistributes>
<redistribute-level-1-into-2>
  </enable>
  <config>
    </enable><!-- operation="delete"-->
  </config>
    <level-1-acl>WORD</level-1-acl> <!-- operation="delete"-->
</redistribute-level-1-into-2>
</level-1-into-2-redistributes>
</address-family-ipv6>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
redistribute isis level-1 into level-2 distribute-list WORD
```

Configure level 2 acl

Use this attribute to redistribute reachability information from one level to the other level. If an distribute-list name is given with this command for an access list that does not exist, the routes are still redistributed.

Attribute Name: level-2-acl

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
<address-family-ipv6>
<level-2-into-1-redistributes>
<redistribute-level-2-into-1>
  </enable>
  <config>
    </enable><!-- operation="delete"-->
  </config>
    <level-2-acl>WORD</level-2-acl> <!-- operation="delete"-->
</redistribute-level-2-into-1>
</level-2-into-1-redistributes>
</address-family-ipv6>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
redistribute isis level-2 into level-1 distribute-list WORD
```

Configure originate

Use this attribute to set originate reachability information to Default destination into LSP. There is no default information in Level-2 domain by default, while Level-1 router calculates default to L1L2 route during SPF calculation. This command enables to originate default route into Level-2 domain.

Attribute Name: originate

Attribute Type: enum (originate|originate level-1|originate always)

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    </isis-instance>
  </isis-instances>
  <address-family-ipv6>
    <default-route-informations>
      <default-route-information> <!-- operation="delete"-->
        <originate>originate</originate>
      </default-route-information>
    </default-route-informations>
  </address-family-ipv6>
</isis>
```

Command Syntax

```
default-information (originate|originate level-1|originate always)
```

Configure route map name

Route-map Name

Attribute Name: route-map-name

Attribute Type: string

Default Value: ""

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
```

```
<instance>WORD</instance>
<config>
  <instance>WORD</instance>
</config>
<address-family-ipv6>
<default-route-informations>
<default-route-information>
  <originate>originate</originate>
  <config>
    <originate>originate</originate>
  </config>
  <route-map-name>WORD</route-map-name> <!-- operation="delete"-->
</default-route-information>
</default-route-informations>
</address-family-ipv6>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
default-information (originate|originate level-1|originate always) route-map WORD
```

Configure afi name

Use this attribute to configure IPv6 routing specific configuration

Attribute Name: afi-name

Attribute Type: enum (ipv6)

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
<address-family-ipv6>
<config>
  <afi-name>1</afi-name>
</config>
</address-family-ipv6>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
address-family ipv6
```

Configure administrative distance

Use this attribute to set the administrative distance for all IPv6 routes

Attribute Name: administrative-distance

Attribute Type: uint32

Default Value: 115

Attribute Range: 1-255

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    <address-family-ipv6>
      <config>
        <administrative-distance>1</administrative-distance> <!-- operation="delete"-
->
      </config>
    </address-family-ipv6>
  </isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
distance <1-255>
```

Configure ipv6 metric value

Use this attributes to redistribute routes from another protocol into the ISIS routing table. With metric, metric-type, level and route-map options.

Attribute Name: ipv6-metric-value

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-16777215

Attribute Name: ipv6-metric-type

Attribute Type: enum (internal|external)

Default Value: internal

Attribute Name: ipv6-level

Attribute Type: enum (level-1|level-2|level-1-2)

Default Value: level-2

Attribute Name: ipv6-route-map

Attribute Type: string

Default Value: ""

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    </isis-instance>
  </isis-instances>
  <address-family-ipv6>
    <redistributions>
      <redistribute>
        <ipv6-protocol-type>kernel</ipv6-protocol-type>
        <config>
          <ipv6-protocol-type>kernel</ipv6-protocol-type>
          <ipv6-metric-type>internal</ipv6-metric-type>
          <ipv6-level>level-2</ipv6-level>
          <ipv6-route-map>WORD</ipv6-route-map>
        </config>
        <ipv6-metric-value>0</ipv6-metric-value>
      </redistribute>
    </redistributions>
  </address-family-ipv6>
</isis>
```

Command Syntax

```
redistribute (kernel|connected|static|rip|ospf|bgp) ({ metric-type
  (internal|external)| level-1|level-2|level-1-2| route-map WORD| metric <0-
  16777215> }|)
```

Configure prefix

Use this attribute to configure the summary prefix to summarize IPv6 reachability information.

Attribute Name: prefix

Attribute Type: string

Attribute Name: level

Attribute Type: enum (level-1|level-2|level-1-2)

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 1-63

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
```



```

<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
</isis-instance>
</isis-instances>
<address-family-ipv6>
<summary-prefixes>
<summary-prefix> <!-- operation="delete"-->
  <prefix>X:X::X:X/M</prefix>
  <config>
    <prefix>X:X::X:X/M</prefix>
    <level>level-1</level>
    <metric>1</metric>
  </config>
</summary-prefix>
</summary-prefixes>
</address-family-ipv6>
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
summary-prefix X:X::X:X/M (level-1|level-2|level-1-2) (metric <1-63>|)
```

Configure level

Use this attribute to configure the ISIS Multi-topology

Attribute Name: level

Attribute Type: enum (level-1|level-2|level-1-2|level-1 transition|level-1-2 transition|level-2 transition)

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
</isis-instance>
</isis-instances>
<address-family-ipv6>
<multi-topologies>
<multi-topology>
  <level>level-1-2</level>
  <config>
    <level>level-1-2</level>
  </config>
</multi-topology>
</multi-topologies>
</address-family-ipv6>

```

```
</isis-instance>  
</isis-instances>  
</isis>
```

Command Syntax

```
multi-topology (level-1)
```

Configure isisSRv6enable

enable SRv6 for SR Policies

Attribute Name: isisSRv6enable

Attribute Type: uint8

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">  
<isis-instances>  
<isis-instance>  
  <instance>WORD</instance>  
  <config>  
    <instance>WORD</instance>  
  </config>  
<address-family-ipv6>  
<isis-srv6>  
<config>  
  </isisSRv6enable>  
</config>  
</isis-srv6>  
</address-family-ipv6>  
</isis-instance>  
</isis-instances>  
</isis>
```

Command Syntax

```
segment-routing srv6
```

Configure isisSRv6LocatorName

Locator name

Attribute Name: isisSRv6LocatorName

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">  
<isis-instances>  
<isis-instance>  
  <instance>WORD</instance>  
  <config>  
    <instance>WORD</instance>
```

```

    </config>
<address-family-ipv6>
<isis-srv6>
<locator-lists>
<locator-list> <!-- operation="delete"-->
    <isisSRv6LocatorName>WORD</isisSRv6LocatorName>
    <config>
        <isisSRv6LocatorName>WORD</isisSRv6LocatorName>
    </config>
</locator-list>
</locator-lists>
</isis-srv6>
</address-family-ipv6>
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
srv6-locator WORD
```

Configure access list name

Use this attribute to set the administrative distance for specific IPv4 routes.

Attribute Name: access-list-name

Attribute Type: string

Default Value: ""

Attribute Name: value

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
    <instance>WORD</instance>
    <config>
        <instance>WORD</instance>
    </config>
<distances>
<distance>
    <system-id>WORD</system-id>
    <config>
        <system-id>System-ID</system-id>
        <value>1</value> <!-- operation="delete"-->
    </config>
        <access-list-name>WORD</access-list-name> <!-- operation="delete"-->
</distance>
</distances>

```

```
</isis-instance>  
</isis-instances>  
</isis>
```

Command Syntax

```
distance <1-255> System-ID (WORD|)
```

Configure set bit on boot

Overload interval after reboot

Attribute Name: set-bit-on-boot

Attribute Type: union

Attribute Name: enabled

Attribute Type: empty

Attribute Name: suppress-type

Attribute Type: enum (default|external|interlevel|external interlevel|interlevel external)

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">  
  <isis-instances>  
    <isis-instance>  
      <instance>WORD</instance>  
      <config>  
        <instance>WORD</instance>  
      </config>  
    <lsp-over-load>  
      <config>  
        </enabled><!-- operation="delete"-->  
        <suppress-type>default</suppress-type> <!-- operation="delete"-->  
        <set-bit-on-boot>default</set-bit-on-boot> <!-- operation="delete"-->  
      </config>  
    </lsp-over-load>  
  </isis-instance>  
</isis-instances>  
</isis>
```

Command Syntax

```
set-overload-bit { suppress (external|interlevel|external interlevel|interlevel  
  external)| on-startup (wait-for-bgp|<5-86400>) }
```

Configure enabled

Use this attribute to set the overload-bit in self-LSPs. If the overload-bit is set in LSPs, the router is not used as a transit router during SPF calculation. This configuration causes a router to update its own LSP with the overload bit set and causes the other routers not to use this router as a transit or forwarding router. The router continues to receive LSPs when the overload bit is set. If the on-startup option is specified, the router sets the overload bit only at startup, then clears the bit after the specified interval has elapsed. If the on-startup option is specified using the wait-for-bgp option, the overload bit is setup at startup, then the bit is cleared after the BGP router signals it has finished converging or if the

router does not signal it has finished converging in 10 minutes. If there is no BGP process running, the overload bit clears immediately.

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    </isis-instance>
  </isis-instances>
  <lsp-over-load>
    <config>
      </enabled>
    </config>
  </lsp-over-load>
</isis>
```

Command Syntax

```
set-overload-bit
```

Configure metric value

IS-IS metric

Attribute Name: metric-value

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-16777215

Attribute Name: metric-type

Attribute Type: enum (internal|external)

Default Value: internal

Attribute Name: route-map

Attribute Type: string

Default Value: ""

Attribute Name: level

Attribute Type: enum (level-1|level-2|level-1-2)

Default Value: level-2

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
```

```
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
</address-family-ipv4>
</redistributions>
<redistribute>
  <protocol-type>kernel</protocol-type>
  <config>
    <protocol-type>kernel</protocol-type>
    <metric-type>internal</metric-type>
    <route-map>WORD</route-map>
    <level>level-2</level>
  </config>
  <metric-value>0</metric-value>
</redistribute>
</redistributions>
</address-family-ipv4>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
redistribute (kernel|connected|static|rip|ospf|bgp) ({ metric-type
  (internal|external)| route-map WORD| level-1|level-2|level-1-2| metric <0-
  16777215> }|)
```

Configure metric

Use this attribute to Summary Address to summarize IPv4 reachability information.

Attribute Name: prefix

Attribute Type: string

Attribute Name: level

Attribute Type: enum (level-1|level-2|level-1-2)

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 1-63

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
```

```

    </config>
<address-family-ipv4>
<summary-addresses>
<summary-address> <!-- operation="delete"-->
  <prefix>A.B.C.D/M</prefix>
  <config>
    <prefix>A.B.C.D/M</prefix>
    <level>level-1</level>
    <metric>1</metric>
  </config>
</summary-address>
</summary-addresses>
</address-family-ipv4>
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
summary-address A.B.C.D/M (level-1|level-2|level-1-2) (metric <1-63>|)
```

Configure id

Instance ID

Attribute Name: id

Attribute Type: string

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
<address-family-ipv4>
<redistribute-isis-instances>
<redistribute-isis-instance> <!-- operation="delete"-->
  <id>WORD</id>
  <config>
    <id>WORD</id>
  </config>
</redistribute-isis-instance>
</redistribute-isis-instances>
</address-family-ipv4>
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
redistribute isis WORD
```

Configure metric type

IS-IS metric

Attribute Name: metric-value

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-16777215

Attribute Name: metric-type

Attribute Type: enum (internal|external)

Default Value: internal

Attribute Name: route-map

Attribute Type: string

Default Value: ""

Attribute Name: level

Attribute Type: enum (level-1|level-2|level-1-2)

Default Value: level-2

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    </isis-instance>
  </isis-instances>
  <address-family-ipv4>
    <redistribute-isis-instances>
      <redistribute-isis-instance>
        <id>WORD</id>
        <config>
          <id>WORD</id>
          <metric-type>internal</metric-type>
          <route-map>WORD</route-map>
          <level>level-2</level>
        </config>
        <metric-value>0</metric-value>
      </redistribute-isis-instance>
    </redistribute-isis-instances>
  </address-family-ipv4>
</isis>
```


Command Syntax

```
redistribute isis WORD { metric-type (internal|external) | route-map WORD | level-
  1|level-2|level-1-2 | metric <0-16777215> }
```

Configure passive interface all

Use this attribute to set all interfaces as passive.

Attribute Name: passive-interface-all

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
passive-interface
```

Configure name

Use this attribute to set interface as passive.

Attribute Name: name

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
</isis-instance>
</isis-instances>
</isis>
```

```
    <name>WORD</name>
  </config>
</passive-interface>
</passive-interfaces>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
passive-interface IFNAME
```

Configure hold timer

Time that a router waits to acquire a set of LSPs to process together

Attribute Name: hold-timer

Attribute Type: uint8

Attribute Range: 1-60

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    </isis-instance>
    <microloop-avoidances>
      <microloop-avoidance>
        <level-type>level-1</level-type>
        <config>
          <level-type>level-1</level-type>
          <hold-timer>1</hold-timer> <!-- operation="delete"-->
        </config>
      </microloop-avoidance>
    </microloop-avoidances>
  </isis-instances>
</isis>
```

Command Syntax

```
microloop-avoidance hold-timer <1-60> (level-1|level-2)
```

Configure max fib

Maximum time required to update a FIB irrespective of the change

Attribute Name: max-fib

Attribute Type: uint8

Attribute Range: 1-60

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
</isis-instance>
</isis-instances>
<microloop-avoidances>
<microloop-avoidance>
  <level-type>level-1</level-type>
  <config>
    <level-type>level-1</level-type>
  </config>
  <max-fib>1</max-fib> <!-- operation="delete"-->
</microloop-avoidance>
</microloop-avoidances>
</isis>
```

Command Syntax

```
microloop-avoidance max-fib <1-60> (level-1|level-2)
```

Configure level type

Microloop avoidance

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
<isis-instance>
  <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
</isis-instance>
</isis-instances>
<microloop-avoidances>
<microloop-avoidance>
  <level-type>level-1</level-type>
  <config>
    <level-type>level-1</level-type>
  </config>
  </enable><!-- operation="delete"-->
</microloop-avoidance>
</microloop-avoidances>
```

```
</isis-instance>  
</isis-instances>  
</isis>
```

Command Syntax

```
microloop-avoidance (level-1|level-2)
```

Configure enable level 1

Use this attribute to configure MPLS Traffic Engineering feature for ISIS.

Attribute Name: enable-level-1

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">  
<isis-instances>  
<isis-instance>  
  <instance>WORD</instance>  
  <config>  
    <instance>WORD</instance>  
  </config>  
<mpls-traffic-engg>  
<config>  
  </enable-level-1><!-- operation="delete"-->  
</config>  
</mpls-traffic-engg>  
</isis-instance>  
</isis-instances>  
</isis>
```

Command Syntax

```
mpls traffic-eng level-1
```

Configure enable level 2

Use this attribute to configure MPLS Traffic Engineering feature for ISIS.

Attribute Name: enable-level-2

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">  
<isis-instances>  
<isis-instance>  
  <instance>WORD</instance>  
  <config>  
    <instance>WORD</instance>  
  </config>  
<mpls-traffic-engg>
```

```

<config>
  </enable-level-2><!-- operation="delete"-->
</config>
</mpls-traffic-eng>
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
mpls traffic-eng level-2
```

Configure options

Debug Configuration Flag

Attribute Name: options

Attribute Type: bits (ifsm|nfsm|pdu|lsp|spf|events|nsm|checksum|authentication|local-updates|protocol-errors|bfd|mpls|rib|sr|lfa|dist-ls|tilfa|ofib|all)

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <debug>
  <config>
    <options>ifsm</options> <!-- operation="delete"-->
  </config>
</debug>
</isis>

```

Command Syntax

```

debug isis (ifsm|nfsm|pdu|lsp|spf|events|nsm|checksum|authentication|local-
updates|protocol-errors|bfd|mpls|rib|sr|lfa|dist-ls|tilfa|ofib|all)

```

Configure enable hello

Use this attribute to turn on debugging for ISIS hello.

Attribute Name: enable-hello

Attribute Type: empty

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <debug>
  <config>
    </enable-hello><!-- operation="delete"-->
  </config>
</debug>
</isis>

```

Command Syntax

```
debug isis hello
```

Configure cspf

Use this attribute to enable CSPF debug logs.

Attribute Name: cspf

Attribute Type: bits (events|hexdump)

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <debug>
  <config>
    <cspf>events</cspf> <!-- operation="delete"-->
  </config>
</debug>
</isis>
```

Command Syntax

```
debug isis cspf (events|hexdump)
```

clear clns is-neighbors System-ID

Attribute Name: system-id

Attribute Type: string

Netconf RPC payload

```
<isis-clear-is-neighbors xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <system-id>System-ID</system-id>
</isis-clear-is-neighbors>
```

Command Syntax

```
clear clns is-neighbors System-ID
```

clear clns neighbors

Netconf RPC payload

```
<isis-clear-clns-neighbors xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis"/>
```

Command Syntax

```
clear clns neighbors
```

clear ip isis (WORD|) route (redistribution|all)

Attribute Name: instance

Attribute Type: string

Attribute Name: ipv4-route

Attribute Type: enum (redistribution|all)

Netconf RPC payload

```
<isis-clear-ip-route xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <instance>WORD</instance>
  <ipv4-route>redistribution</ipv4-route>
</isis-clear-ip-route>
```

Command Syntax

```
clear ip isis (WORD|) route (redistribution|all)
```

clear ipv6 isis (WORD|) route (redistribution|all)

Attribute Name: instance

Attribute Type: string

Attribute Name: ipv6-route

Attribute Type: enum (redistribution|all)

Netconf RPC payload

```
<isis-clear-ipv6-route xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <instance>WORD</instance>
  <ipv6-route>redistribution</ipv6-route>
</isis-clear-ipv6-route>
```

Command Syntax

```
clear ipv6 isis (WORD|) route (redistribution|all)
```

clear isis (WORD|) process

Attribute Name: instance

Attribute Type: string

Netconf RPC payload

```
<isis-process-clear xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <instance>WORD</instance>
</isis-process-clear>
```

Command Syntax

```
clear isis (WORD|) process
```

clear isis counter

Netconf RPC payload

```
<isis-clear-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis"/>
```

Command Syntax

```
clear isis counter
```

clear isis adjacency * (vrf VRFNAME|)

Attribute Name: adjacency-vrf-name

Attribute Type: string

Netconf RPC payload

```
<isis-clear-adjacency-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <adjacency-vrf-name>VRFNAME</adjacency-vrf-name>
</isis-clear-adjacency-all>
```

Command Syntax

```
clear isis adjacency * (vrf VRFNAME|)
```

clear isis WORD adjacency * (vrf VRFNAME|)

Attribute Name: tag-name

Attribute Type: string

Attribute Name: adjacency-vrf-name

Attribute Type: string

Netconf RPC payload

```
<isis-process-clear-adjacency-all xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-isis">
  <tag-name>WORD</tag-name>
  <adjacency-vrf-name>VRFNAME</adjacency-vrf-name>
</isis-process-clear-adjacency-all>
```

Command Syntax

```
clear isis WORD adjacency * (vrf VRFNAME|)
```

clear isis WORD adjacency (IFNAME|) (vrf VRFNAME|)

Attribute Name: tag-name

Attribute Type: string

Attribute Name: tag-if-name

Attribute Type: string

Attribute Name: adjacency-vrf-name

Attribute Type: string

Netconf RPC payload

```
<isis-process-clear-adjacency-interface xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-isis">
  <tag-name>WORD</tag-name>
  <tag-if-name>IFNAME</tag-if-name>
  <adjacency-vrf-name>VRFNAME</adjacency-vrf-name>
</isis-process-clear-adjacency-interface>
```

Command Syntax

```
clear isis WORD adjacency (IFNAME|) (vrf VRFNAME|)
```

clear isis adjacency (IFNAME|) (vrf VRFNAME|)

Attribute Name: adjacency-if-name

Attribute Type: string

Attribute Name: adjacency-vrf-name

Attribute Type: string

Netconf RPC payload

```
<isis-clear-adjacency-interface xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <adjacency-if-name>IFNAME</adjacency-if-name>
  <adjacency-vrf-name>VRFNAME</adjacency-vrf-name>
</isis-clear-adjacency-interface>
```

Command Syntax

```
clear isis adjacency (IFNAME|) (vrf VRFNAME|)
```

clear isis WORD adjacency system-id XXXX.XXXX.XXXX (vrf VRFNAME|)

Attribute Name: tag-name

Attribute Type: string

Attribute Name: tag-system-id

Attribute Type: string

Attribute Name: tag-vrf-name

Attribute Type: string

Netconf RPC payload

```
<isis-process-clear-adjacency-system-id xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <tag-name>WORD</tag-name>
  <tag-system-id>XXXX.XXXX.XXXX</tag-system-id>
  <tag-vrf-name>VRFNAME</tag-vrf-name>
</isis-process-clear-adjacency-system-id>
```

Command Syntax

```
clear isis WORD adjacency system-id XXXX.XXXX.XXXX (vrf VRFNAME|)
```

clear isis adjacency system-id XXXX.XXXX.XXXX (vrf VRFNAME|)

Attribute Name: adjacency-system-id

Attribute Type: string

Attribute Name: adjacency-vrf-name

Attribute Type: string

Netconf RPC payload

```
<isis-clear-adjacency-system-id xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <adjacency-system-id>XXXX.XXXX.XXXX</adjacency-system-id>
  <adjacency-vrf-name>VRFNAME</adjacency-vrf-name>
</isis-clear-adjacency-system-id>
```

Command Syntax

```
clear isis adjacency system-id XXXX.XXXX.XXXX (vrf VRFNAME|)
```

snmp restart isis

Netconf RPC payload

```
<isis-restart-snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis"/>
```

Command Syntax

```
snmp restart isis
```

debug isis (ifsm|nfsm|pdu|lsp|spf|events|nsm|checksum|authentication|local-updates|protocol-errors|bfd|mpls|rib|sr|lfa|dist-ls|tilfa|ofib|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (ifsm|nfsm|pdu|lsp|spf|events|nsm|checksum|authentication|local-updates|protocol-errors|bfd|mpls|rib|sr|lfa|dist-ls|tilfa|ofib|all)

Netconf RPC payload

```
<isis-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <terminal-debug-options>ifsm</terminal-debug-options>
</isis-terminal-debug-on>
```

Command Syntax

```
debug isis (ifsm|nfsm|pdu|lsp|spf|events|nsm|checksum|authentication|local-
updates|protocol-errors|bfd|mpls|rib|sr|lfa|dist-ls|tilfa|ofib|all)
```

no debug isis (ifsm|nfsm|pdu|lsp|spf|events|nsm|checksum|authentication|local-updates|protocol-errors|bfd|mpls|rib|sr|lfa|dist-ls|tilfa|ofib|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (ifsm|nfsm|pdu|lsp|spf|events|nsm|checksum|authentication|local-updates|protocol-errors|bfd|mpls|rib|sr|lfa|dist-ls|tilfa|ofib|all)

Netconf RPC payload

```
<isis-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <terminal-debug-options>ifsm</terminal-debug-options>
```

```
</isis-debug-off>
```

Command Syntax

```
no debug isis (ifsm|nfsm|pdu|lsp|spf|events|nsm|checksum|authentication|local-  
updates|protocol-errors|bfd|mpls|rib|sr|lfa|dist-ls|tilfa|ofib|all)
```

debug isis spf-trace

Netconf RPC payload

```
<isis-terminal-debug-spf-trace-on xmlns="http://www.ipinfusion.com/yang/ocnos/  
ipi-isis"/>
```

Command Syntax

```
debug isis spf-trace
```

no debug isis spf-trace

Netconf RPC payload

```
<isis-terminal-debug-spf-trace-off xmlns="http://www.ipinfusion.com/yang/ocnos/  
ipi-isis"/>
```

Command Syntax

```
no debug isis spf-trace
```

debug isis hello

Netconf RPC payload

```
<isis-debug-hello-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis"/>
```

Command Syntax

```
debug isis hello
```

no debug isis hello

Netconf RPC payload

```
<isis-debug-hello-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis"/>
```

Command Syntax

```
no debug isis hello
```

debug isis hello interface IFNAME

Attribute Name: interface

Attribute Type: string

Netconf RPC payload

```
<isis-debug-interface-hello-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interface>IFNAME</interface>
</isis-debug-interface-hello-on>
```

Command Syntax

```
debug isis hello interface IFNAME
```

no debug isis hello interface IFNAME

Attribute Name: interface

Attribute Type: string

Netconf RPC payload

```
<isis-debug-interface-hello-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interface>IFNAME</interface>
</isis-debug-interface-hello-off>
```

Command Syntax

```
no debug isis hello interface IFNAME
```

debug isis hello System-ID

Attribute Name: system-id

Attribute Type: string

Netconf RPC payload

```
<isis-debug-system-id-hello-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <system-id>System-ID</system-id>
</isis-debug-system-id-hello-on>
```

Command Syntax

```
debug isis hello System-ID
```

no debug isis hello System-ID

Attribute Name: system-id

Attribute Type: string

Netconf RPC payload

```
<isis-debug-system-id-hello-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <system-id>System-ID</system-id>
</isis-debug-system-id-hello-off>
```

Command Syntax

```
no debug isis hello System-ID
```

no debug all isis

Netconf RPC payload

```
<isis-all-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis"/>
```

Command Syntax

```
no debug all isis
```

debug isis cspf (events|hexdump)

Attribute Name: cspf-debug

Attribute Type: bits (events|hexdump)

Netconf RPC payload

```
<isis-debug-cspf-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">  
<cspf-debug>events</cspf-debug>  
</isis-debug-cspf-on>
```

Command Syntax

```
debug isis cspf (events|hexdump)
```

no debug isis cspf (events|hexdump)

Attribute Name: cspf-debug

Attribute Type: bits (events|hexdump)

Netconf RPC payload

```
<isis-debug-cspf-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">  
<cspf-debug>events</cspf-debug>  
</isis-debug-cspf-off>
```

Command Syntax

```
no debug isis cspf (events|hexdump)
```

IPI-ISIS-LSP

Configure spf max delay

Maximum delay between receiving a change to SPF calculation in milliseconds. The default value is 5000

Attribute Name: spf-max-delay

Attribute Type: uint32

Attribute Range: 0-2147483647

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <spf-levels>
        <spf-level>
          <level>level-1-2</level>
          <config>
            <level>level-1-2</level>
          </config>
          <spf-delays>
            <spf-delay> <!-- operation="delete"-->
              <spf-max-delay>0</spf-max-delay>
              <config>
                <spf-max-delay>0</spf-max-delay>
                <spf-min-delay>0</spf-min-delay>
              </config>
              <spf-min-delay>0</spf-min-delay>
            </spf-delay>
          </spf-delays>
        </spf-level>
      </spf-levels>
    </isis-instance>
  </isis-instances>
</isis>
```

Command Syntax

```
spf-interval-exp ((level-1|level-2) |) <0-2147483647> <0-2147483647>
```

Configure lsp max wait interval

Use this attribute to set minimum interval before regenerating the same LSP. The smaller the interval, the faster the convergence. However, this setting might cause more frequent flooding

Attribute Name: lsp-max-wait-interval

Attribute Type: uint32

Default Value: 5

Attribute Range: 1-120

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
```

```

    <instance>WORD</instance>
  <config>
    <instance>WORD</instance>
  </config>
</levels>
<level>
  <type>level-1-2</type>
  <config>
    <type>level-1-2</type>
  </config>
  <lsp-max-wait-interval>1</lsp-max-wait-interval> <!--
operation="delete"-->
</level>
</levels>
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
lsp-gen-interval ((level-1|level-2) |) <1-120>
```

Configure lsp mtu size

Use this attribute to set minimum interval before regenerating the same LSP

Attribute Name: lsp-mtu-size

Attribute Type: uint16

Default Value: 1492

Attribute Range: 512-4352

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <levels>
        <level>
          <type>level-1-2</type>
          <config>
            <type>level-1-2</type>
          </config>
          <lsp-mtu-size>512</lsp-mtu-size> <!-- operation="delete"-->
        </level>
      </levels>
    </isis-instance>
  </isis-instances>
</isis>

```

Command Syntax

```
lsp-mtu ((level-1|level-2)|) <512-4352>
```

Configure wait timer

Number of seconds to delay in waiting state before on state

Attribute Name: wait-timer

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <levels>
        <level>
          <type>level-1-2</type>
          <config>
            <type>level-1-2</type>
          </config>
          <wait-timer>1</wait-timer> <!-- operation="delete"-->
        </level>
      </levels>
    </isis-instance>
  </isis-instances>
</isis>
```

Command Syntax

```
isis wait-timer <1-65535> level-1-2
```

Configure restart timer

Use this attribute to restart the ISIS timer

Attribute Name: restart-timer

Attribute Type: uint16

Attribute Range: 5-65535

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
```



```

        <instance>WORD</instance>
    </config>
    <levels>
    <level>
        <type>level-1-2</type>
        <config>
            <type>level-1-2</type>
        </config>
        <restart-timer>5</restart-timer> <!-- operation="delete"-->
    </level>
    </levels>
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
restart-timer <5-65535> level-1-2
```

Configure instance

Number of seconds to delay in waiting state before on state

Attribute Name: wait-timer

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <levels>
      <level>
        <type>level-1-2</type>
        <config>
          <type>level-1-2</type>
        </config>
        <wait-timer>1</wait-timer> <!-- operation="delete"-->
      </level>
    </levels>
  </isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
isis wait-timer <1-65535> (level-1|level-2|)
```

Configure type

Use this attribute to restart the ISIS timer

Attribute Name: restart-timer

Attribute Type: uint16

Attribute Range: 5-65535

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <levels>
        <level>
          <type>level-1-2</type>
          <config>
            <type>level-1-2</type>
          </config>
          <restart-timer>5</restart-timer> <!-- operation="delete"-->
        </level>
      </levels>
    </isis-instance>
  </isis-instances>
</isis>
```

Command Syntax

```
restart-timer <5-65535> (level-1|level-2|)
```

Configure mode

Use this attribute to set the authentication mode at the instance level.

Attribute Name: mode

Attribute Type: enum (md5|text)

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <levels>
        <level>
          <type>level-1-2</type>
```

```

    <config>
      <type>level-1-2</type>
    </config>
  <authentication>
    <config>
      <mode>md5</mode>
    </config>
  </authentication>
</level>
</levels>
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
authentication mode (md5|text) (level-1|level-2|)
```

Configure key chain

Use this attribute to set the key chain to be used for authentication at the instance level. Authentication mode must be set to md5/text to configure the key chain.

Attribute Name: key-chain

Attribute Type: string

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <levels>
        <level>
          <type>level-1-2</type>
          <config>
            <type>level-1-2</type>
          </config>
          <authentication>
            <config>
              <key-chain>WORD</key-chain> <!-- operation="delete"-->
            </config>
          </authentication>
        </level>
      </levels>
    </isis-instance>
  </isis-instances>
</isis>

```

Command Syntax

```
authentication key-chain WORD (level-1|level-2|)
```

IPI-ISIS-EXTENDED

Configure remote lfa protocol

Protocol Address Family

Attribute Name: remote-lfa-protocol

Attribute Type: enum (ipv4)

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <fast-reroute-levels>
      <fast-reroute>
        <level-type>level-1</level-type>
        <config>
          <level-type>level-1</level-type>
        </config>
        <remote-lfa-protocol>ipv4</remote-lfa-protocol> <!--
operation="delete"-->
      </fast-reroute>
    </fast-reroute-levels>
  </isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
fast-reroute per-prefix remote-lfa (level-1|level-2) proto (ipv4) tunnel mpls-ldp
```

Configure name

Specific prefix allowed using this route map

Attribute Name: name

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
```

```

<instance>WORD</instance>
<config>
  <instance>WORD</instance>
</config>
<fast-reroute-levels>
<fast-reroute>
  <level-type>level-1</level-type>
  <config>
    <level-type>level-1</level-type>
  </config>
  <route-maps>
  <route-map>
    <protocol>ipv4</protocol>
    <config>
      <protocol>ipv4</protocol>
    </config>
    <name>WORD</name> <!-- operation="delete"-->
  </route-map>
</route-maps>
</fast-reroute>
</fast-reroute-levels>
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
fast-reroute per-prefix (level-1|level-2) proto (ipv4) route-map WORD
```

Configure enable all prefixes

Apply on all prefixes

Attribute Name: enable-all-prefixes

Attribute Type: enum (all)

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
  <isis-instance>
    <instance>WORD</instance>
    <config>
      <instance>WORD</instance>
    </config>
    <fast-reroute-levels>
    <fast-reroute>
      <level-type>level-1</level-type>
      <config>
        <level-type>level-1</level-type>
      </config>
    </fast-reroute>
  </isis-instance>
</isis-instances>
</isis>

```

```
        <route-map>
          <protocol>ipv4</protocol>
          <config>
            <protocol>ipv4</protocol>
          </config>
          <enable-all-prefixes>all</enable-all-prefixes> <!--
operation="delete"-->
        </route-map>
      </route-maps>
    </fast-reroute>
  </fast-reroute-levels>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
fast-reroute per-prefix (level-1|level-2) proto (ipv4) (all)
```

Configure protocol

Protocol Address Family

Attribute Name: protocol

Attribute Type: enum (ipv4)

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <fast-reroute-levels>
        <fast-reroute>
          <level-type>level-1</level-type>
          <config>
            <level-type>level-1</level-type>
          </config>
          <ti-lfas>
            <ti-lfa> <!-- operation="delete"-->
              <protocol>ipv4</protocol>
              <config>
                <protocol>ipv4</protocol>
              </config>
            </ti-lfa>
          </ti-lfas>
        </fast-reroute>
      </fast-reroute-levels>
    </isis-instance>
```

```
</isis-instances>
</isis>
```

Command Syntax

```
fast-reroute ti-lfa (level-1|level-2) proto (ipv4)
```

Configure preference index

this index indicates which tie-break option to be given preference

This command is supported when following feature are enabled ISIS feature

Attribute Name: preference-index

Attribute Type: uint32

Attribute Range: 1-255

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
  <isis-instance>
    <instance>WORD</instance>
    <config>
      <instance>WORD</instance>
    </config>
    <fast-reroute-levels>
    <fast-reroute>
      <level-type>level-1</level-type>
      <config>
        <level-type>level-1</level-type>
      </config>
      <protocols>
      <protocol>
        <preference-value>primary-path</preference-value>
        <config>
          <preference-value>primary-path</preference-value>
          <lfa-protocol>ipv4</lfa-protocol>
        </config>
          <lfa-protocol>ipv4</lfa-protocol>
          <preference-index>1</preference-index> <!-- operation="delete"-->
        </protocol>
      </protocols>
    </fast-reroute>
  </fast-reroute-levels>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
fast-reroute tie-break (level-1|level-2) proto (ipv4) (primary-path|node-protecting|interface-disjoint|broadcast-interface-disjoint|downstream-path|secondary-path) index <1-255>
```

Configure grace period

The period within which ISIS should come up

Attribute Name: grace-period

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <graceful-restart>
    <config>
      <grace-period>1</grace-period> <!-- operation="delete"-->
    </config>
  </graceful-restart>
</isis>
```

Command Syntax

```
isis restart grace-period <1-65535>
```

Configure enable helper only

Attribute to configure helper mode

Attribute Name: enable-helper-only

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <graceful-restart>
    <config>
      </enable-helper-only><!-- operation="delete"-->
    </config>
  </graceful-restart>
</isis>
```

Command Syntax

```
isis restart helper
```

Configure suppress adjacency

When set to true, adjacency is not advertised. The SA bit is used by a starting router to request that its neighbor suppress advertisement of the adjacency to the starting router in the neighbor's LSPs.

Attribute Name: suppress-adjacency

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <graceful-restart>
  <config>
    </suppress-adjacency><!-- operation="delete"-->
  </config>
</graceful-restart>
</isis>
```

Command Syntax

```
isis restart suppress-adjacency
```

restart isis graceful (grace-period <1-65535>|)

Attribute Name: grace-period

Attribute Type: uint16

Attribute Range: 1-65535

Netconf RPC payload

```
<ipi-isis-extended_isis-restart-graceful xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <grace-period>1</grace-period>
</ipi-isis-extended_isis-restart-graceful>
```

Command Syntax

```
restart isis graceful (grace-period <1-65535>|)
```

IPI-ISIS-SR

Configure receive disable

Use this attribute to receive label binding TLVs

Attribute Name: receive-disable

Attribute Type: uint8

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
    </isis-instance>
  </isis-instances>
  <segment-routing>
```

```
<config>
  </receive-disable><!-- operation="delete"-->
</config>
</segment-routing>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
segment-routing prefix-sid-map receive disable
```

Configure enabled

Use this attribute to enable MPLS-based segment routing for an ISIS process

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
  <isis-instance>
    <instance>WORD</instance>
    <config>
      <instance>WORD</instance>
    </config>
    <segment-routing>
    <config>
      </enabled>
    </config>
  </segment-routing>
</isis-instance>
</isis-instances>
</isis>
```

Command Syntax

```
segment-routing mpls
```

Configure advertise local

Use this attribute to advertise prefix-SID mapping

Attribute Name: advertise-local

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<isis-instances>
  <isis-instance>
    <instance>WORD</instance>
```

```

    <config>
      <instance>WORD</instance>
    </config>
  <segment-routing>
    <config>
      </advertise-local><!-- operation="delete"-->
    </config>
  </segment-routing>
</isis-instance>
</isis-instances>
</isis>

```

Command Syntax

```
segment-routing prefix-sid-map advertise-local
```

Configure entropy capability

Use this attribute to enable segment routing entropy capability.

Attribute Name: entropy-capability

Attribute Type: empty

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <segment-routing>
        <config>
          </entropy-capability><!-- operation="delete"-->
        </config>
      </segment-routing>
    </isis-instance>
  </isis-instances>
</isis>

```

Command Syntax

```
segment-routing capability entropy
```

Configure global block base

Segment Node Base Value. Default value is 16000

Attribute Name: global-block-base

Attribute Type: int32

Attribute Range: 16-1048575

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <isis-instances>
    <isis-instance>
      <instance>WORD</instance>
      <config>
        <instance>WORD</instance>
      </config>
      <segment-routing>
        <global-blocks>
          <global-block> <!-- operation="delete"-->
            <global-block-range>16</global-block-range>
            <config>
              <global-block-range>16</global-block-range>
              <global-block-base>16</global-block-base>
            </config>
            <global-block-base>16</global-block-base>
          </global-block>
        </global-blocks>
      </segment-routing>
    </isis-instance>
  </isis-instances>
</isis>
```

Command Syntax

```
isis segment-routing global block <16-1048575> <16-1048575>
```

IPI-ISIS-INTERFACE

Configure minimal

Use this attribute to set the minimal Hello interval in seconds.

Attribute Name: minimal

Attribute Type: enum (level-1-only|level-2-only|level-1-2)

Default Value: level-1-2

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <minimal>3</minimal> <!-- operation="delete"-->
    </interface>
  </interfaces>
```

```
</isis>
```

Command Syntax

```
isis hello-interval minimal level-1
```

Configure name

Use this attribute to set the minimal Hello interval in seconds.

Attribute Name: minimal

Attribute Type: enum (level-1-only|level-2-only|level-1-2)

Default Value: level-1-2

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <minimal>3</minimal> <!-- operation="delete"-->
</interface>
</interfaces>
</isis>
```

Command Syntax

```
isis hello-interval minimal level-2
```

Configure send only

Use this attribute to set the send-only option to the interface-related packets. Use this attribute before configuring the ISIS authentication mode and ISIS authentication key-chain, so that the implementation of authentication goes smoothly. That is, the routers will have more time for the keys to be configured on each router if authentication is inserted only on the packets being sent, not checked on packets being received. After all routers that must communicate are configured with this attribute, enable the authentication mode and key chain on each router.

Attribute Name: send-only

Attribute Type: enum (level-1-only|level-2-only|level-1-2)

Default Value: level-1-2

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
</interface>
</interfaces>
</isis>
```

```
        <send-only>3</send-only> <!-- operation="delete"-->
</interface>
</interfaces>
</isis>
```

Command Syntax

```
isis authentication send-only level-1
```

Configure disable padding

Use this attribute to configure/unconfigure the padding of the ISIS Hello packet. ISIS pads the Hello packet by default to notify neighbors of the supported MTU size.

Attribute Name: disable-padding

Attribute Type: uint8

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <interface-parameters>
  <config>
    </disable-padding><!-- operation="delete"-->
  </config>
</interface-parameters>
</interface>
</interfaces>
</isis>
```

Command Syntax

```
no isis hello padding
```

Configure network type

Use this attribute to change a broadcast interface network type to a point-to-point network type and vice-versa.

Attribute Name: network-type

Attribute Type: enum (broadcast|point-to-point)

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
```

```

</config>
<interface-parameters>
<config>
    <network-type>broadcast</network-type> <!-- operation="delete"-->
</config>
</interface-parameters>
</interface>
</interfaces>
</isis>

```

Command Syntax

```
isis network (broadcast|point-to-point)
```

Configure circuit type

Use this attribute to set the circuit type for the interface. If level-1 or level-2-only is specified in this attribute, ISIS sends only the specified level of PDUs. On the point-to-point interface, there is only one type of Hello packet, so in this case ISIS Hello will be sent regardless of circuit-type. If istype is configured as level-1 or level-2 only, routing for this instance is performed for only the specified level. In this manner, only the particular level of PDU is sent on the interface.

Attribute Name: circuit-type

Attribute Type: enum (level-1|level-2-only|level-1-2)

Default Value: level-1-2

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<interfaces>
<interface>
    <name>WORD</name>
    <config>
        <name>WORD</name>
    </config>
    <interface-parameters>
    <config>
        <circuit-type>level-1-2</circuit-type> <!-- operation="delete"-->
    </config>
</interface-parameters>
</interface>
</interfaces>
</isis>

```

Command Syntax

```
isis circuit-type (level-1|level-2-only|level-1-2)
```

Configure ipv4 instance tag

Use this attribute to enable ISIS IPv4 routing on the interface. This attribute is mandatory to ISIS configuration. Match the ISIS instance tag to one of existing instance.s tags, or a new instance with the tag name should be initiated, otherwise routing will not run on this interface. Configuring this attribute, the router sends ISIS Hello with IP address TLV on this interface, and IP reachability information TLV in the LSP will be updated.

Attribute Name: ipv4-instance-tag

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-parameters>
        <config>
          <ipv4-instance-tag>WORD</ipv4-instance-tag> <!-- operation="delete"-->
        </config>
      </interface-parameters>
    </interface>
  </interfaces>
</isis>
```

Command Syntax

```
ip router isis WORD
```

Configure ipv6 instance tag

Use this attribute to enable ISIS IPv6 routing on the interface. This attribute is mandatory to IPv6 ISIS configuration. Match the ISIS instance tag to one of existing instance.s tags, or a new instance with the tag name should be initiated, otherwise routing will not run on this interface. Configuring this attribute, the router sends ISIS Hello with IPv6 address TLV on this interface, and IPv6 reachability information TLV in the LSP will be updated.

Attribute Name: ipv6-instance-tag

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-parameters>
        <config>
          <ipv6-instance-tag>WORD</ipv6-instance-tag> <!-- operation="delete"-->
        </config>
      </interface-parameters>
    </interface>
  </interfaces>
</isis>
```


Command Syntax

```
ipv6 router isis WORD
```

Configure lsp interval

Use this attribute to set the Link State Packet (LSP) transmission interval. Configuring this attribute changes the minimum interval between two consecutive LSP transmission. When flooding or some other event triggers LSP to transmit, the LSP is put on the interface queue and scheduled to transmit according to this interval. Two consecutive LSP transmissions are scheduled to have at least this interval.

Attribute Name: lsp-interval

Attribute Type: uint32

Default Value: 33

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
        </config>
        <interface-parameters>
          <config>
            <lsp-interval>1</lsp-interval> <!-- operation="delete"-->
          </config>
        </interface-parameters>
      </interface>
    </interfaces>
  </isis>
```

Command Syntax

```
isis lsp-interval <1-4294967295>
```

Configure retransmit interval

Interval between retransmissions of the same LSP in seconds

Attribute Name: retransmit-interval

Attribute Type: uint16

Default Value: 5

Attribute Range: 1-65535

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
```

```
<name>WORD</name>
<config>
  <name>WORD</name>
</config>
<interface-parameters>
<config>
  <retransmit-interval>1</retransmit-interval> <!-- operation="delete"-->
</config>
</interface-parameters>
</interface>
</interfaces>
</isis>
```

Command Syntax

```
isis retransmit-interval <1-65535>
```

Configure mesh group id

Use this attribute to specify to block LSPs on the current interface. If an interface is configured as mesh group blocked, the standard LSP database synchronization process is applied if the interface receives CSNP or PSNP.

Attribute Name: mesh-group-id

Attribute Type: union

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <interface-parameters>
  <config>
    <mesh-group-id>blocked</mesh-group-id> <!-- operation="delete"-->
  </config>
</interface-parameters>
</interface>
</interfaces>
</isis>
```

Command Syntax

```
isis mesh-group (blocked|<1-4294967295>)
```

Configure enable

Use this attribute to enable the BFD check on interface.

This command is supported when following feature are enabled

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-parameters>
        <bfd>
          <config>
            </enable><!-- operation="delete"-->
          </config>
        </bfd>
      </interface-parameters>
    </interface>
  </interfaces>
</isis>
```

Command Syntax

```
isis bfd
```

Configure disable

Use this attribute to disable the BFD check on interface.

This command is supported when following feature are enabled

Attribute Name: disable

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-parameters>
        <bfd>
          <config>
            </disable><!-- operation="delete"-->
          </config>
        </bfd>
      </interface-parameters>
    </interface>
  </interfaces>
</isis>
```

Command Syntax

```
isis bfd disable
```

Configure disable level 1

Use this attribute to disable frr on an interface for level-1.

Attribute Name: disable-level-1

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-parameters>
        <fast-re-route>
          <config>
            </disable-level-1><!-- operation="delete"-->
          </config>
        </fast-re-route>
      </interface-parameters>
    </interface>
  </interfaces>
</isis>
```

Command Syntax

```
isis fast-reroute per-prefix candidate disable level-1
```

Configure disable level 2

Use this attribute to disable frr on an interface for level-2.

Attribute Name: disable-level-2

Attribute Type: empty

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-parameters>
        <fast-re-route>
          <config>
          </config>
        </fast-re-route>
      </interface-parameters>
    </interface>
  </interfaces>
</isis>
```

```

        </disable-level-2><!-- operation="delete"-->
    </config>
</fast-re-route>
</interface-parameters>
</interface>
</interfaces>
</isis>

```

Command Syntax

```
isis fast-reroute per-prefix candidate disable level-2
```

Configure hello interval

Use this attribute to set the Hello interval in seconds. The Hello-interval is set with the hello-multiplier. Configuring this attribute changes the time interval between two consecutive Hello transmissions. If a device receives its own LSP with a maximum sequence number, then it suspends ISIS for the hold interval. DIS sends Hello transmissions at three times the rate than non-DIS. If ISIS is elected as DIS on this interface, ISIS sends Hello every 3.3 seconds. If minimal keyword is specified, Holding timer in Hello PDU is set to 1 second and Hello interval is calculated by dividing by the hello-multiplier.

Attribute Name: hello-interval

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-65535

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-parameters>
        <level-infos>
          <level-info>
            <level>level-1-2</level>
            <config>
              <level>level-1-2</level>
            </config>
            <hello-interval>1</hello-interval> <!-- operation="delete"-->
          </level-info>
        </level-infos>
      </interface-parameters>
    </interface>
  </interfaces>
</isis>

```

Command Syntax

```
isis hello-interval <1-65535> (level-1|level-2|)
```

Configure hello multiplier

Use this attribute to set multiplier for Hello holding time. Changes Holding Timer in Hello PDU. Holding timer is calculated by .Hello-Interval. multiplied by this value. If minimal keyword is specified with the Hello-Interval, the holding timer is set to 1 second and the hello-interval is calculated by dividing 1 by this value.

Attribute Name: hello-multiplier

Attribute Type: uint8

Default Value: 3

Attribute Range: 2-100

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-parameters>
        <level-infos>
          <level-info>
            <level>level-1-2</level>
            <config>
              <level>level-1-2</level>
            </config>
            <hello-multiplier>2</hello-multiplier> <!-- operation="delete"-->
          </level-info>
        </level-infos>
      </interface-parameters>
    </interface>
  </interfaces>
</isis>
```

Command Syntax

```
isis hello-multiplier <2-100> (level-1|level-2|)
```

Configure csnp interval

Use this attribute to set CSNP (Complete sequence number PDU) interval in seconds. Configuring this attribute changes the interval between two consecutive CSNP transmission. By default, CSNP is sent every 10 seconds only by LAN DIS. This parameter is only valid on broadcast interface, since periodic CSNP is only sent on broadcast interface, while CSNP on Point-to-Point interface is sent only when adjacency is initiated.

Attribute Name: csnp-interval

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-65535

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <interface-parameters>
  <level-infos>
  <level-info>
    <level>level-1-2</level>
    <config>
      <level>level-1-2</level>
    </config>
    <csnp-interval>1</csnp-interval> <!-- operation="delete"-->
  </level-info>
</level-infos>
</interface-parameters>
</interface>
</interfaces>
</isis>

```

Command Syntax

```
isis csnp-interval <1-65535> (level-1|level-2|)
```

Configure priority

Use this attribute to set the priority for LAN DIS election. This attribute changes the priority value in LAN ISIS Hello PDUs. A lower priority value is less preferred in DIS election, and a higher priority value is more preferred

Attribute Name: priority

Attribute Type: uint8

Default Value: 64

Attribute Range: 0-127

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <interface-parameters>
  <level-infos>
  <level-info>
    <level>level-1-2</level>
    <config>

```

```
        <level>level-1-2</level>
    </config>
    <priority>0</priority> <!-- operation="delete"-->
</level-info>
</level-infos>
</interface-parameters>
</interface>
</interfaces>
</isis>
```

Command Syntax

```
isis priority <0-127> (level-1|level-2|)
```

Configure metric

Use this attribute to set default metric for the interface. The interface default metric is put into IP reachability information TLVs, IS reachability information TLVs and IPv6 reachability TLVs in LSPs. The value is used for SPF calculation, and is applied when the metric-style is configured as .narrow.

Attribute Name: metric

Attribute Type: uint8

Default Value: 10

Attribute Range: 1-63

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-parameters>
        <level-infos>
          <level-info>
            <level>level-1-2</level>
            <config>
              <level>level-1-2</level>
            </config>
            <metric>1</metric> <!-- operation="delete"-->
          </level-info>
        </level-infos>
      </interface-parameters>
    </interface>
  </interfaces>
</isis>
```

Command Syntax

```
isis metric <1-63> (level-1|level-2|)
```

Configure password

Use this attribute to set the authentication password of Hello PDU on the interface.

Attribute Name: password

Attribute Type: string

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-parameters>
        <level-infos>
          <level-info>
            <level>level-1-2</level>
            <config>
              <level>level-1-2</level>
            </config>
            <password>WORD</password> <!-- operation="delete"-->
          </level-info>
        </level-infos>
      </interface-parameters>
    </interface>
  </interfaces>
</isis>
```

Command Syntax

```
isis password WORD (level-1|level-2|)
```

Configure tag

Use this attribute to sets the tag for link-state packets (LSPs) sent out advertising routes for networks directly connected to an interface. If you do not specify a parameter, then the tag value is set for level-1-2 boundary

Attribute Name: tag

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
</isis>
```

```
<interface-parameters>
<level-infos>
<level-info>
  <level>level-1-2</level>
  <config>
    <level>level-1-2</level>
  </config>
  <tag>1</tag> <!-- operation="delete"-->
</level-info>
</level-infos>
</interface-parameters>
</interface>
</interfaces>
</isis>
```

Command Syntax

```
isis tag <1-4294967295> (level-1|level-2|)
```

Configure wide metric

Use this attribute to set wide metric for the interface. Interface wide-metric is put into Extended IP reachability TLVs, Extended IS reachability TLVs and IPv6 reachability TLVs in LSPs. The value is used for SPF calculation. This value is applied when metric-style is configured as 'wide'.

Attribute Name: wide-metric

Attribute Type: uint32

Default Value: 10

Attribute Range: 1-16777214

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <interface-parameters>
  <level-infos>
  <level-info>
    <level>level-1-2</level>
    <config>
      <level>level-1-2</level>
    </config>
    <wide-metric>1</wide-metric> <!-- operation="delete"-->
  </level-info>
</level-infos>
</interface-parameters>
</interface>
```

```
</interfaces>
</isis>
```

Command Syntax

```
isis wide-metric <1-16777214> (level-1|level-2|)
```

Configure te metric

Use this attribute to set te metric for the interface. Interface te-metric is put into Extended IS reachability TLVs and IPv6 reachability TLVs in LSPs. The value is used for CSPF calculation

Attribute Name: te-metric

Attribute Type: uint32

Attribute Range: 1-16777214

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <interface-parameters>
  <level-infos>
  <level-info>
    <level>level-1-2</level>
    <config>
      <level>level-1-2</level>
    </config>
    <te-metric>1</te-metric> <!-- operation="delete"-->
  </level-info>
</level-infos>
</interface-parameters>
</interface>
</interfaces>
</isis>
```

Command Syntax

```
isis te-metric <1-16777214> (level-1|level-2|)
```

Configure restart hello interval

Use this attribute to configure the T1 timer, interval of ISIS Hello packet with restart TLV.

Attribute Name: restart-hello-interval

Attribute Type: uint16

Default Value: 3

Attribute Range: 1-65535

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-parameters>
        <level-infos>
          <level-info>
            <level>level-1-2</level>
            <config>
              <level>level-1-2</level>
            </config>
            <restart-hello-interval>1</restart-hello-interval> <!--
operation="delete"-->
          </level-info>
        </level-infos>
      </interface-parameters>
    </interface>
  </interfaces>
</isis>
```

Command Syntax

```
isis restart-hello-interval <1-65535> (level-1|level-2|)
```

Configure mode

Use this attribute to set the MD5 authentication mode.

Attribute Name: mode

Attribute Type: enum (md5|text)

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-parameters>
        <level-infos>
          <level-info>
            <level>level-1-2</level>
            <config>
              <level>level-1-2</level>
            </config>
            <authentication>
```

```

    <config>
      <mode>md5</mode>
    </config>
  </authentication>
</level-info>
</level-infos>
</interface-parameters>
</interface>
</interfaces>
</isis>

```

Command Syntax

```
isis authentication mode (md5|text) (level-1|level-2|)
```

Configure key chain

Use this attribute to set the key chain to be used for authentication on the interface-related packets. Authentication mode must be set to md5/text to configure the key chain. Only one authentication key-chain is applied to an ISIS interface at a time. Authentication can be specified for an entire instance of ISIS, instead of at the interface level, by setting the authentication key-chain attribute at global level.

Attribute Name: key-chain

Attribute Type: string

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-parameters>
      <level-infos>
      <level-info>
        <level>level-1-2</level>
        <config>
          <level>level-1-2</level>
        </config>
        <authentication>
          <config>
            <key-chain>WORD</key-chain> <!-- operation="delete"-->
          </config>
        </authentication>
      </level-info>
    </level-infos>
  </interface-parameters>
</interface>
</interfaces>
</isis>

```

Command Syntax

```
isis authentication key-chain WORD (level-1|level-2|)
```

Configure hold timer

It is the max time period for which IGP should advertise the max metric for the interface in case of LDP session down on that interface.

Attribute Name: hold-timer

Attribute Type: uint32

Attribute Range: 1-2147483

Attribute Name: level

Attribute Type: enum (level-1|level-2|level-1-2)

Netconf edit-config payload

```
<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <igp-ldp-sync>
        <config>
          <level>level-1</level>
          <hold-timer>1</hold-timer>
        </config>
      </igp-ldp-sync>
    </interface>
  </interfaces>
</isis>
```

Command Syntax

```
mpls ldp-igp sync isis (level-1|level-2|level-1-2) (holddown-timer <1-2147483>|)
```

Configure level

It is the max time period for which IGP should advertise the max metric for the interface in case of LDP session down on that interface.

Attribute Name: hold-timer

Attribute Type: uint32

Attribute Range: 1-2147483

Attribute Name: level

Attribute Type: enum (level-1|level-2|level-1-2)

Netconf edit-config payload

```

<isis xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-isis">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <igp-ldp-sync>
  <config>
    <level>level-1</level>
    <hold-timer>1</hold-timer>
  </config>
</igp-ldp-sync>
</interface>
</interfaces>
</isis>

```

Command Syntax

```
mpls ldp-igp sync isis (level-1|level-2|level-1-2) (holddown-timer <1-2147483>|)
```

clear isis interface counter (IFNAME|)

Attribute Name: name

Attribute Type: string

Netconf RPC payload

```

<ipi-isis-interface_isis-clear-interface-counters xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-isis">
  <name>IFNAME</name>
</ipi-isis-interface_isis-clear-interface-counters>

```

Command Syntax

```
clear isis interface counter (IFNAME|)
```

IPI-KEYCHAIN

Configure name

key-chain name

Attribute Name: name

Attribute Type: string

Netconf edit-config payload

```

<key-chains xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-keychain">
<key-chain> <!-- operation="delete"-->

```

```
<name>WORD</name>
<config>
  <name>WORD</name>
</config>
</key-chain>
</key-chains>
```

Command Syntax

```
key chain WORD
```

Configure key id

Use this attribute to manage COMMA add or delete authentication keys in a key-chain

Attribute Name: key-id

Attribute Type: uint32

Attribute Range: 0-2147483647

Netconf edit-config payload

```
<key-chains xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-keychain">
  <key-chain>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
  </key-chain>
  <key-list> <!-- operation="delete"-->
    <key-id>0</key-id>
    <config>
      <key-id>0</key-id>
    </config>
  </key-list>
</key-chains>
```

Command Syntax

```
key-id <0-2147483647>
```

Configure key string

Use this attribute to define a password to be used by a key

Attribute Name: key-string

Attribute Type: string

Attribute Range: 1-80

Netconf edit-config payload

```
<key-chains xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-keychain">
```



```

<key-chain>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
</key-chain>
<key-list>
  <key-id>0</key-id>
  <config>
    <key-id>0</key-id>
  </config>
  <key-string>WORD</key-string> <!-- operation="delete"-->
</key-list>
</keys>
</key-chains>

```

Command Syntax

```
key-string WORD
```

Configure encrypted

Use this attribute to pass the key string in hexadecimal string format

Attribute Name: encrypted

Attribute Type: string

Attribute Range: 18-162

Netconf edit-config payload

```

<key-chains xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-keychain">
  <key-chain>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
  </key-chain>
  <key-list>
    <key-id>0</key-id>
    <config>
      <key-id>0</key-id>
    </config>
    <encrypted>WORD</encrypted> <!-- operation="delete"-->
  </key-list>
</key-chains>

```

Command Syntax

```
key-string encrypted WORD
```

Configure start date time for accept

Configure the start date-time of the key for accept-lifetime

Attribute Name: start-date-time-for-accept

Attribute Type: string

Attribute Name: end-date-time-for-accept

Attribute Type: string

Attribute Name: infinite-for-accept

Attribute Type: empty

Attribute Name: duration-for-accept

Attribute Type: uint32

Attribute Range: 1-2147483646

Netconf edit-config payload

```
<key-chains xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-keychain">
  <key-chain>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
  <keys>
    <key-list>
      <key-id>0</key-id>
      <config>
        <key-id>0</key-id>
      </config>
      <accept-lifetime>
        <config>
          <end-date-time-for-accept>KEYCHAIN_DATE_TIME_T</end-date-time-for-accept>
          </infinite-for-accept>
          <duration-for-accept>1</duration-for-accept>
          <start-date-time-for-accept>KEYCHAIN_DATE_TIME_T</start-date-time-for-accept>
        </config>
      </accept-lifetime>
    </key-list>
  </keys>
</key-chain>
</key-chains>
```

Command Syntax

```
accept-lifetime HH:MM:SS MONTH <01-31> <1993-2035> HH:MM:SS MONTH <01-31> <1993-2035>
infinite duration <1-2147483646>
```

Configure start date time for send

Configure the start date-time of the key for send-lifetime

Attribute Name: start-date-time-for-send

Attribute Type: string

Attribute Name: end-date-time-for-send

Attribute Type: string

Attribute Name: infinite-for-send

Attribute Type: empty

Attribute Name: duration-for-send

Attribute Type: uint32

Attribute Range: 1-2147483646

Netconf edit-config payload

```
<key-chains xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-keychain">
  <key-chain>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
  <keys>
    <key-list>
      <key-id>0</key-id>
      <config>
        <key-id>0</key-id>
        </config>
        <send-lifetime>
          <config>
            <end-date-time-for-send>KEYCHAIN_DATE_TIME_T</end-date-time-for-send>
            </infinite-for-send>
            <duration-for-send>1</duration-for-send>
            <start-date-time-for-send>KEYCHAIN_DATE_TIME_T</start-date-time-for-send>
          </config>
        </send-lifetime>
      </key-list>
    </keys>
  </key-chain>
</key-chains>
```

Command Syntax

```
send-lifetime HH:MM:SS MONTH <01-31> <1993-2035> HH:MM:SS MONTH <01-31> <1993-2035>
infinite duration <1-2147483646>
```

IPI-PIM

Configure bfd

Use this attribute to debug the PIM BFD feature.

This command is supported when following feature are enabled Bidirectional Forwarding Detection (BFD)

Attribute Name: bfd

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <debug>
    <config>
      </bfd><!-- operation="delete"-->
    </config>
  </debug>
</pim>
```

Command Syntax

```
debug pim bfd
```

IPI-PIM-IPV4

Configure router id

Use this attribute to configure PIM router-ID to uniquely identify the router. By default, PIM registers for the NSM router-id service. This attribute will override the router-id received from NSM.

Attribute Name: router-id

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <router-id>A.B.C.D</router-id> <!-- operation="delete"-->
      </instance>
    </instances>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) router-id A.B.C.D
```

Configure join prune interval

Use this attribute to set a PIM join/prune timer.

Attribute Name: join-prune-interval

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <join-prune-interval>1</join-prune-interval> <!-- operation="delete"-->
      </instance>
    </instances>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) jp-timer <1-65535>
```

Configure ecmp bundle

Use this attribute to create an ECMP bundle.

Attribute Name: ecmp-bundle

Attribute Type: string

Attribute Range: 1-50

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <ecmp-bundle>WORD</ecmp-bundle> <!-- operation="delete"-->
      </instance>
    </instances>
  </ipv4>
</pim>
```

```
</ipv4>  
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) ecmp-bundle WORD
```

Configure enable bfd all interfaces

Use this attribute to enable Bidirectional Forwarding Detection (BFD) on all interfaces.

Attribute Name: enable-bfd-all-interfaces

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">  
<ipv4>  
<instances>  
<instance>  
  <vrf-name>NAME</vrf-name>  
  <config>  
    <vrf-name>NAME</vrf-name>  
  </config>  
  </enable-bfd-all-interfaces><!-- operation="delete"-->  
</instance>  
</instances>  
</ipv4>  
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) bfd all-interfaces
```

Configure register reachability check

Use this attribute to enable the RP reachability check for PIM Registers at the designated router (DR).

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: register-reachability-check

Attribute Type: enum (disable|enable)

Default Value: enable

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">  
<ipv4>  
<instances>  
<instance>  
  <vrf-name>NAME</vrf-name>  
  <config>  
    <vrf-name>NAME</vrf-name>  
  </config>  
</instance>  
</instances>  
</ipv4>  
</pim>
```

```

    <register-packet>
    <config>
        <register-reachability-check>enable</register-reachability-check> <!--
operation="delete"-->
    </config>
</register-packet>
</instance>
</instances>
</ipv4>
</pim>

```

Command Syntax

```
ip pim (vrf NAME|) register-rp-reachability (disable|enable)
```

Configure rate limit

Use this attribute to configure the rate of register packets sent by this designated router (DR).

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: rate-limit

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
<ipv4>
<instances>
<instance>
    <vrf-name>NAME</vrf-name>
    <config>
        <vrf-name>NAME</vrf-name>
    </config>
    <register-packet>
    <config>
        <rate-limit>1</rate-limit> <!-- operation="delete"-->
    </config>
</register-packet>
</instance>
</instances>
</ipv4>
</pim>

```

Command Syntax

```
ip pim (vrf NAME|) register-rate-limit <1-65535>
```

Configure suppress interval

Use this attribute to configure the register suppression time.

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: suppress-interval

Attribute Type: uint16

Default Value: 60

Attribute Range: 11-65535

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
<ipv4>
<instances>
<instance>
  <vrf-name>NAME</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  <register-packet>
  <config>
    <suppress-interval>11</suppress-interval> <!-- operation="delete"-->
  </config>
</register-packet>
</instance>
</instances>
</ipv4>
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) register-suppression <11-65535>
```

Configure keep alive interval

Use this attribute to configure a Keep alive Timer (KAT) value for (S,G) states at RP to monitor PIM register packets.

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: keep-alive-interval

Attribute Type: uint16

Default Value: 185

Attribute Range: 1-65535

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
<ipv4>
<instances>
<instance>
  <vrf-name>NAME</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  <register-packet>
  <config>
```



```

        <keep-alive-interval>1</keep-alive-interval> <!-- operation="delete"-->
    </config>
</register-packet>
</instance>
</instances>
</ipv4>
</pim>

```

Command Syntax

```
ip pim (vrf NAME|) rp-register-kat <1-65535>
```

Configure source address

Use this attribute to configure the source address of register packets sent by this designated router (DR).

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: source-address

Attribute Type: union

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
          </config>
          <register-packet>
            <config>
              <source-address>PIM_IPV4_REG_SOURCE_T</source-address>
            </config>
          </register-packet>
        </instance>
      </instances>
    </ipv4>
  </pim>

```

Command Syntax

```
ip pim (vrf NAME|) register-source (A.B.C.D|IFNAME)
```

Configure accept register

Use this attribute to configure the ACL of register packets accepted by this designated router (DR).

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: accept-register

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <register-packet>
          <config>
            <accept-register>WORD</accept-register> <!-- operation="delete"-->
          </config>
        </register-packet>
      </instance>
    </instances>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) accept-register list WORD
```

Configure ignore rp set priority

Use this attribute to ignore the RP-SET priority value, and use only the hashing mechanism for RP selection. This is used to inter-operate with older Cisco IOS versions.

Attribute Name: ignore-rp-set-priority

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <interop>
          <config>
            </ignore-rp-set-priority><!-- operation="delete"-->
          </config>
        </interop>
      </instance>
    </instances>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) ignore-rp-set-priority
```

Configure cisco bsr interop enable

Use this attribute to turn on or turn the Candidate-RP debugging timerworking with Cisco BSR.

Attribute Name: cisco-bsr-interop-enable

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <interop>
          <config>
            </cisco-bsr-interop-enable><!-- operation="delete"-->
          </config>
        </interop>
      </instance>
    </instances>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) crp-cisco-prefix
```

Configure access control list

Use this attribute to configure the option to calculate the register checksum over the whole packet on multicast groups specified by the access control list.

Attribute Name: access-control-list

Attribute Type: string

Attribute Range: 1-64

Attribute Name: cisco-register-checksum-enable

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
```

```

    <vrf-name>NAME</vrf-name>
    <config>
      <vrf-name>NAME</vrf-name>
    </config>
    <interop>
    <register-packet>
    <config>
      </cisco-register-checksum-enable><!-- operation="delete"-->
      <access-control-list>WORD</access-control-list> <!-- operation="delete"--
>
    </config>
  </register-packet>
</interop>
</instance>
</instances>
</ipv4>
</pim>

```

Command Syntax

```
ip pim (vrf NAME|) cisco-register-checksum group-list WORD
```

Configure cisco register checksum enable

Use this attribute to configure the option to calculate the register checksum over the whole packet. This is used to inter-operate with older Cisco IOS versions.

Attribute Name: cisco-register-checksum-enable

Attribute Type: empty

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <interop>
        <register-packet>
        <config>
          </cisco-register-checksum-enable>
        </config>
      </register-packet>
    </instance>
  </instances>
</ipv4>
</pim>

```

Command Syntax

```
ip pim (vrf NAME|) cisco-register-checksum
```

Configure vrf name

Use this attribute to to enable the ability of the last-hop PIM router to switch to SPT for multicast group addresses indicated by the given standard access control list.

Attribute Name: access-control-list

Attribute Type: string

Attribute Range: 1-64

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <spt-switch>
          <config>
            </enable><!-- operation="delete"-->
            <access-control-list>WORD</access-control-list> <!-- operation="delete"-->
          </config>
        </spt-switch>
      </instance>
    </instances>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) spt-threshold group-list WORD
```

Configure enable

Use this attribute to enable the ability of the last-hop PIM router to switch to SPT.

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
```

```
<instance>
  <vrf-name>NAME</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  <spt-switch>
  <config>
    </enable>
  </config>
</spt-switch>
</instance>
</instances>
</ipv4>
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) spt-threshold
```

Configure range policy

Use this attribute to set Source Specific Multicast (SSM) and define the range of multicast IP addresses. Ranges can be either the default, which defines the SSM range as 232/8, or indicated by the given standard access control list.

This command is supported when following feature are enabled PIM Source Specific Multicast (SSM)

Attribute Name: range-policy

Attribute Type: union

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
  <instances>
  <instance>
    <vrf-name>NAME</vrf-name>
    <config>
      <vrf-name>NAME</vrf-name>
    </config>
    <ssm>
    <config>
      <range-policy>PIM_IPV4_SSM_RANGE_POLICY_TYPE_T</range-policy>
    </config>
  </ssm>
  </instance>
  </instances>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) ssm (range WORD|default)
```

Configure member rp address

Destination IP address where register messages are copied and sent. A Member RP is an individual RP member in the anycast RP set.

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: member-rp-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <anycast-rps>
          <anycast-rp> <!-- operation="delete"-->
            <member-rp-address>A.B.C.D</member-rp-address>
            <config>
              <member-rp-address>A.B.C.D</member-rp-address>
              <anycast-rp-address>A.B.C.D</anycast-rp-address>
            </config>
            <anycast-rp-address>A.B.C.D</anycast-rp-address>
          </anycast-rp>
        </anycast-rps>
      </instance>
    </instances>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) anycast-rp A.B.C.D A.B.C.D
```

Configure rp address

Use this attribute to statically configure Rendezvous Point (RP) address for multicast groups.

Attribute Name: rp-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
```

```
    <vrf-name>NAME</vrf-name>
  </config>
  <rendezvous-point>
  <static-rps>
  <static-rps-default>
  <static-rp-default> <!-- operation="delete"-->
    <rp-address>A.B.C.D</rp-address>
    <config>
      <rp-address>A.B.C.D</rp-address>
    </config>
  </static-rp-default>
</static-rps-default>
</static-rps>
</rendezvous-point>
</instance>
</instances>
</ipv4>
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) rp-address A.B.C.D
```

Configure override dynamically learned rp

Use this attribute to configure the flag to override dynamically learned RP mappings.

Attribute Name: override-dynamically-learned-rp

Attribute Type: empty

Attribute Name: access-control-list

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
  <instances>
  <instance>
    <vrf-name>NAME</vrf-name>
    <config>
      <vrf-name>NAME</vrf-name>
    </config>
    <rendezvous-point>
    <static-rps>
    <static-rps-default>
    <static-rp-default>
      <rp-address>A.B.C.D</rp-address>
    <config>
      <rp-address>A.B.C.D</rp-address>
```



```

    <access-control-list>WORD</access-control-list> <!-- operation="delete"-->
>
    </config>
    </override-dynamically-learned-rp><!-- operation="delete"-->
    </static-rp-default>
</static-rps-default>
</static-rps>
</rendezvous-point>
</instance>
</instances>
</ipv4>
</pim>

```

Command Syntax

```
ip pim (vrf NAME|) rp-address A.B.C.D WORD override
```

Configure interface name

Use this attribute to configure the interface for the candidate BSR router.

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-33

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <rendezvous-point>
          <bootstrap-router>
            <bsr-candidate>
              <config>
                <interface-name>IFNAME</interface-name> <!-- operation="delete"-->
              </config>
            </bsr-candidate>
          </bootstrap-router>
        </rendezvous-point>
      </instance>
    </instances>
  </ipv4>
</pim>

```

Command Syntax

```
ip pim (vrf NAME|) bsr-candidate IFNAME
```

Configure hash mask length

Use this attribute to configure the mask length used to calculate the group address for RP.

Attribute Name: hash-mask-length

Attribute Type: uint8

Attribute Range: 0-32

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-33

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <rendezvous-point>
          <bootstrap-router>
            <bsr-candidate>
              <config>
                <interface-name>IFNAME</interface-name> <!-- operation="delete"-->
                <hash-mask-length>0</hash-mask-length> <!-- operation="delete"-->
              </config>
            </bsr-candidate>
          </bootstrap-router>
        </rendezvous-point>
      </instance>
    </instances>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) bsr-candidate IFNAME <0-32>
```

Configure priority

Use this attribute to configure the priority value for candidate BSR router.

Attribute Name: priority

Attribute Type: uint8

Attribute Range: 0-255

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-33

Attribute Name: hash-mask-length

Attribute Type: uint8

Attribute Range: 0-32

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
          </config>
          <rendezvous-point>
            <bootstrap-router>
              <bsr-candidate>
                <config>
                  <interface-name>IFNAME</interface-name> <!-- operation="delete"-->
                  <hash-mask-length>0</hash-mask-length> <!-- operation="delete"-->
                  <priority>0</priority> <!-- operation="delete"-->
                </config>
              </bsr-candidate>
            </bootstrap-router>
          </rendezvous-point>
        </instance>
      </instances>
    </ipv4>
  </pim>
```

Command Syntax

```
ip pim (vrf NAME|) bsr-candidate IFNAME <0-32> <0-255>
```

Configure advertisement interval

Use this attribute to configure the priority value for RP candidate.

Attribute Name: priority

Attribute Type: uint8

Attribute Range: 0-255

Attribute Name: access-control-list

Attribute Type: string

Attribute Range: 1-64

Attribute Name: advertisement-interval

Attribute Type: uint16

Attribute Range: 1-16383

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <rendezvous-point>
          <rp-candidates>
            <rp-candidate>
              <interface-name>IFNAME</interface-name>
              <config>
                <interface-name>IFNAME</interface-name>
                <access-control-list>WORD</access-control-list> <!-- operation="delete"-->
              </config>
              <advertisement-interval>1</advertisement-interval> <!--
operation="delete"-->
            </rp-candidate>
          </rp-candidates>
        </rendezvous-point>
      </instance>
    </instances>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim (vrf NAME|) rp-candidate IFNAME (group-list WORD|) (interval <1-16383>|)
(priority <0-255>|)
```

Configure originator id

Use this attribute to allow a Multicast Source Discovery Protocol (MSDP) speaker that originates a Source-Active (SA) message to use the IP address of an interface as a rendezvous point (RP) address in the SA message.

This command is supported when following feature are enabled HAVE_PIM_MSDP

Attribute Name: originator-id

Attribute Type: string

Attribute Range: 1-33

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
```

```

    <vrf-name>NAME</vrf-name>
  </config>
  <msdp>
  <config>
    <originator-id>IFNAME</originator-id> <!-- operation="delete"-->
  </config>
</msdp>
</instance>
</instances>
</ipv4>
</pim>

```

Command Syntax

```
ip msdp (vrf NAME|) originator-id IFNAME
```

Configure group address

Use this attribute to configure an Multicast Source Discovery Protocol (MSDP) remote group.

This command is supported when following feature are enabled HAVE_PIM_MSDP

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Attribute Name: rp-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
  <instances>
  <instance>
    <vrf-name>NAME</vrf-name>
    <config>
      <vrf-name>NAME</vrf-name>
    </config>
    <msdp>
    <source-active-entries>
    <source-active-entry> <!-- operation="delete"-->
      <group-address>A.B.C.D</group-address>
      <config>
        <group-address>A.B.C.D</group-address>
        <source-address>A.B.C.D</source-address>
        <rp-address>A.B.C.D</rp-address>
      </config>
      <source-address>A.B.C.D</source-address>
    </source-active-entry>
  </source-active-entries>
  </msdp>
  </instance>
</instances>

```

```
</ipv4>  
</pim>
```

Command Syntax

```
ip msdp (vrf NAME|) sa s A.B.C.D g A.B.C.D r A.B.C.D
```

Configure address

Use this attribute to configure an Multicast Source Discovery Protocol (MSDP) peer relationship.

This command is supported when following feature are enabled HAVE_PIM_MSDP

Attribute Name: address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">  
<ipv4>  
<instances>  
<instance>  
  <vrf-name>NAME</vrf-name>  
  <config>  
    <vrf-name>NAME</vrf-name>  
  </config>  
  <msdp>  
  <peers>  
    <peer> <!-- operation="delete"-->  
      <address>A.B.C.D</address>  
      <config>  
        <address>A.B.C.D</address>  
      </config>  
    </peer>  
  </peers>  
</msdp>  
</instance>  
</instances>  
</ipv4>  
</pim>
```

Command Syntax

```
ip msdp (vrf NAME|) peer A.B.C.D
```

Configure mesh group

Use this attribute to configure an Multicast Source Discovery Protocol (MSDP) peer relationship.

This command is supported when following feature are enabled HAVE_PIM_MSDP

Attribute Name: address

Attribute Type: inet:ipv4-address

Attribute Name: mesh-group

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
<ipv4>
<instances>
<instance>
  <vrf-name>NAME</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  <msdp>
  <peers>
  <peer>
    <address>A.B.C.D</address>
    <config>
      <address>A.B.C.D</address>
      <mesh-group>WORD</mesh-group> <!-- operation="delete"-->
    </config>
  </peer>
</peers>
</msdp>
</instance>
</instances>
</ipv4>
</pim>
```

Command Syntax

```
ip msdp (vrf NAME|) mesh-group WORD A.B.C.D
```

Configure default peer

Use this attribute to configure an Multicast Source Discovery Protocol (MSDP) peer relationship.

This command is supported when following feature are enabled HAVE_PIM_MSDP

Attribute Name: address

Attribute Type: inet:ipv4-address

Attribute Name: default-peer

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
<ipv4>
<instances>
<instance>
  <vrf-name>NAME</vrf-name>
  <config>
```

```
    <vrf-name>NAME</vrf-name>
  </config>
  <msdp>
  <peers>
  <peer>
    <address>A.B.C.D</address>
    <config>
      <address>A.B.C.D</address>
      </default-peer><!-- operation="delete"-->
    </config>
  </peer>
</peers>
</msdp>
</instance>
</instances>
</ipv4>
</pim>
```

Command Syntax

```
ip msdp (vrf NAME|) default-peer A.B.C.D
```

Configure prefix list

Use this attribute to set a Multicast Source Discovery Protocol (MSDP) peer from which to accept Source-Active (SA) messages. You can have multiple active default peers: 1. When you enter multiple `ip msdp default-peer` commands with a `prefix-list` keyword, all the default peers are used at the same time for different RP prefixes. This form is typically used in a service provider cloud that connects stub site clouds. 2. When you enter multiple `ip msdp default-peer` commands without a `prefix-list` keyword, a single active peer accepts all SA messages. If that peer fails, the next configured default peer accepts all SA messages. This form is typically used at a stub site.

This command is supported when following feature are enabled `HAVE_PIM_MSDP`

Attribute Name: `prefix-list`

Attribute Type: union

Attribute Name: `default-peer`

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
  <instances>
  <instance>
    <vrf-name>NAME</vrf-name>
    <config>
      <vrf-name>NAME</vrf-name>
    </config>
  <msdp>
  <peers>
  <peer>
    <address>A.B.C.D</address>
```



```

    <config>
      <address>A.B.C.D</address>
      </default-peer><!-- operation="delete"-->
    </config>
    <prefix-list>PIM_IPV4_MSDP_PEER_ACL_T</prefix-list>
  </peer>
</peers>
</msdp>
</instance>
</instances>
</ipv4>
</pim>

```

Command Syntax

```
ip msdp (vrf NAME|) default-peer A.B.C.D prefix-list (WORD|<1-99>)
```

Configure password

Use this command to set an password key used for authenticating a Multicast Source Discovery Protocol (MSDP) peer. By default, no password is enabled.

This command is supported when following feature are enabled HAVE_PIM_MSDP

Attribute Name: password

Attribute Type: string

Attribute Range: 1-162

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <msdp>
          <peers>
            <peer>
              <address>A.B.C.D</address>
              <config>
                <address>A.B.C.D</address>
              </config>
              <authentication>
                <config>
                  <password>WORD</password> <!-- operation="delete"-->
                </config>
              </authentication>
            </peer>
          </peers>
        </msdp>
      </instance>
    </instances>
  </ipv4>
</pim>

```

```
</msdp>
</instance>
</instances>
</ipv4>
</pim>
```

Command Syntax

```
ip msdp (vrf NAME|) password WORD peer A.B.C.D
```

Configure options

Use this attribute to debug the PIM IPv4 feature.

Attribute Name: options

Attribute Type: bits (all|events|packet|packet in|packet out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr bst|timer bsr crp|mib|nsm|nexthop|mtrace|msdp)

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <debug>
          <config>
            <options>all</options> <!-- operation="delete"-->
          </config>
        </debug>
      </instance>
    </instances>
  </ipv4>
</pim>
```

Command Syntax

```
debug ip pim (vrf NAME|) (all|events|packet|packet in|packet
  out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer
  hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune
  ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr
  bst|timer bsr crp|mib|nsm|nexthop|mtrace|msdp)
```

Configure passive enable

PIM IPv4 passive mode.

Attribute Name: passive-enable

Attribute Type: empty

Attribute Name: pim-mode

Attribute Type: enum (dense-mode|sparse-mode)

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
          <pim-mode>dense-mode</pim-mode> <!-- operation="delete"-->
        </config>
        </passive-enable><!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim (dense-mode|sparse-mode) passive
```

Configure pim mode

PIM IPv4 mode to use when delivering multicast traffic via this interface.

Attribute Name: pim-mode

Attribute Type: enum (dense-mode|sparse-mode)

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
          </config>
          <pim-mode>dense-mode</pim-mode> <!-- operation="delete"-->
        </interface>
      </interfaces>
    </ipv4>
  </pim>
```

Command Syntax

```
ip pim (dense-mode|sparse-mode)
```

Configure bsr border

When set to true the device will not send bootstrap router messages over this interface. By default these are transmitted over all PIM IPv4 sparse mode (PIM-SM) enabled interfaces.

Attribute Name: bsr-border

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </bsr-border><!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim bsr-border
```

Configure dr priority

The designated router priority of this interface. Larger always preferred.

Attribute Name: dr-priority

Attribute Type: uint32

Attribute Range: 0-4294967294

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <dr-priority>0</dr-priority> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim dr-priority <0-4294967294>
```

Configure hello interval

Use this attribute to configure a hello interval value other than the default. When a hello-interval is configured and hello-holdtime is not configured, or when the hello-holdtime value configured is less than the new hello-interval value, the holdtime value is modified to $(3.5 * \text{hello_interval})$. Otherwise, the hello-holdtime value is the configured value.

Attribute Name: hello-interval

Attribute Type: uint16

Default Value: 30

Attribute Range: 1-18724

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <hello-interval>1</hello-interval> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim hello-interval <1-18724>
```

Configure hello holdtime

Use this attribute to configure a hello message holdtime other than the default.

Attribute Name: hello-holdtime

Attribute Type: uint16

Default Value: 105

Attribute Range: 1-65535

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
```

```
        <name>WORD</name>
    </config>
    <hello-holdtime>1</hello-holdtime> <!-- operation="delete"-->
</interface>
</interfaces>
</ipv4>
</pim>
```

Command Syntax

```
ip pim hello-holdtime <1-65535>
```

Configure exclude generated id

Exclude Gen-id option from PIM IPv4 Hello packets on this interface.

Attribute Name: exclude-generated-id

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
<ipv4>
<interfaces>
<interface>
    <name>WORD</name>
    <config>
        <name>WORD</name>
    </config>
    </exclude-generated-id><!-- operation="delete"-->
</interface>
</interfaces>
</ipv4>
</pim>
```

Command Syntax

```
ip pim exclude-genid
```

Configure unicast bootstrap router

Use this attribute to enable support for sending and receiving unicast Bootstrap Messages (BSM) on an interface.

Attribute Name: unicast-bootstrap-router

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
<ipv4>
<interfaces>
<interface>
    <name>WORD</name>
    <config>
```

```

    <name>WORD</name>
  </config>
</unicast-bootstrap-router><!-- operation="delete"-->
</interface>
</interfaces>
</ipv4>
</pim>

```

Command Syntax

```
ip pim unicast-bsm
```

Configure neighbor access control list filter

Use this attribute to enable filtering of neighbors on the interface. When configuring a neighbor filter, PIM IPv4 either not establishes adjacency with neighbor or terminates adjacency with existing neighbors, when denied by filtering access list.

Attribute Name: neighbor-access-control-list-filter

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <neighbor-access-control-list-filter>WORD</neighbor-access-control-list-
filter> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv4>
</pim>

```

Command Syntax

```
ip pim neighbor-filter WORD
```

Configure state refresh origination interval

Use this attribute to configure a PIM-DM State-Refresh origination interval other than the default value. The origination interval is the number of seconds between PIM-DM State Refresh control messages.

Attribute Name: state-refresh-origination-interval

Attribute Type: uint16

Default Value: 60

Attribute Range: 1-100

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <state-refresh-origination-interval>1</state-refresh-origination-interval>
<!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim state-refresh origination-interval <1-100>
```

Configure name

Use this attribute to configure an ECMP bundle.

Attribute Name: ecmp-bundle

Attribute Type: string

Attribute Range: 1-50

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
          <ecmp-bundle>WORD</ecmp-bundle> <!-- operation="delete"-->
        </config>
      </interface>
    </interfaces>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim bind ecmp-bundle WORD
```

Configure propagation delay

Propagation-delay value.

Attribute Name: propagation-delay

Attribute Type: uint16

Default Value: 1000

Attribute Range: 0-32767

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <propagation-delay>0</propagation-delay> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim propagation-delay <0-32767>
```

Configure enable bfd

Use this attribute to configure Bidirectional Forwarding Detection.

Attribute Name: enable-bfd

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <enable-bfd>enable</enable-bfd> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim bfd (disable|)
```

Configure virtual router id

Use this attribute to set the designated router's priority value.

This command is supported when following feature are enabled HAVE_PIM_SM_VRRP_AWARE

Attribute Name: dr-priority

Attribute Type: uint32

Attribute Range: 0-4294967294

Attribute Name: virtual-router-id

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv4>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <pim-redundancy>
          <vrrp>
            <config>
              <virtual-router-id>1</virtual-router-id>
              <dr-priority>0</dr-priority>
            </config>
          </vrrp>
        </pim-redundancy>
      </interface>
    </interfaces>
  </ipv4>
</pim>
```

Command Syntax

```
ip pim redundancy <1-255> vrrp dr-priority <0-4294967294>
```

snmp restart pim

Netconf RPC payload

```
<ipi-pim-ipv4_pim-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim"/>
```

Command Syntax

```
snmp restart pim
```

clear ip pim (vrf NAME|) (sparse-mode) bsr rp-set *

Attribute Name: vrf-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: pim-mode

Attribute Type: enum (sparse-mode)

Netconf RPC payload

```
<ipi-pim-ipv4_pim-ipv4-clear-bsr-rendezvous-point xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
  <pim-mode>sparse-mode</pim-mode>
</ipi-pim-ipv4_pim-ipv4-clear-bsr-rendezvous-point>
```

Command Syntax

```
clear ip pim (vrf NAME|) (sparse-mode) bsr rp-set *
```

clear ip mroute (vrf NAME|) * pim (dense-mode|sparse-mode)

Attribute Name: vrf-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: pim-mode

Attribute Type: enum (dense-mode|sparse-mode)

Netconf RPC payload

```
<ipi-pim-ipv4_pim-ipv4-clear-multicast-route xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
  <pim-mode>dense-mode</pim-mode>
</ipi-pim-ipv4_pim-ipv4-clear-multicast-route>
```

Command Syntax

```
clear ip mroute (vrf NAME|) * pim (dense-mode|sparse-mode)
```

clear ip mroute (vrf NAME|) A.B.C.D pim sparse-mode

Attribute Name: vrf-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<ipi-pim-ipv4_pim-ipv4-clear-multicast-route-source-group xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
  <group-address>A.B.C.D</group-address>
</ipi-pim-ipv4_pim-ipv4-clear-multicast-route-source-group>
```

Command Syntax

```
clear ip mroute (vrf NAME|) A.B.C.D pim sparse-mode
```

clear ip mroute (vrf NAME|) A.B.C.D A.B.C.D pim (dense-mode|sparse-mode)

Attribute Name: vrf-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Attribute Name: source-address

Attribute Type: inet:ipv4-address

Attribute Name: pim-mode

Attribute Type: enum (dense-mode|sparse-mode)

Netconf RPC payload

```
<ipi-pim-ipv4_pim-ipv4-clear-multicast-route-source-group-mode xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
  <group-address>A.B.C.D</group-address>
  <source-address>A.B.C.D</source-address>
  <pim-mode>dense-mode</pim-mode>
</ipi-pim-ipv4_pim-ipv4-clear-multicast-route-source-group-mode>
```

Command Syntax

```
clear ip mroute (vrf NAME|) A.B.C.D A.B.C.D pim (dense-mode|sparse-mode)
```

clear ip msdp (vrf NAME|) peer (A.B.C.D|)

Attribute Name: vrf-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: address

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<ipi-pim-ipv4_pim-ipv4-clear-msdp-peer xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
```

```
<vrf-name>NAME</vrf-name>
<address>A.B.C.D</address>
</ipi-pim-ipv4_pim-ipv4-clear-msdp-peer>
```

Command Syntax

```
clear ip msdp (vrf NAME|) peer (A.B.C.D|)
```

clear ip msdp (vrf NAME|) sa-cache (A.B.C.D|)

Attribute Name: vrf-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<ipi-pim-ipv4_pim-ipv4-clear-msdp-sa-cache xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
  <group-address>A.B.C.D</group-address>
</ipi-pim-ipv4_pim-ipv4-clear-msdp-sa-cache>
```

Command Syntax

```
clear ip msdp (vrf NAME|) sa-cache (A.B.C.D|)
```

debug ip pim (vrf NAME|) (all|events|packet|packet in|packet out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr bst|timer bsr crp|mib|nsm|nexthop|mtrace|msdp)

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: terminal-debug-options

Attribute Type: bits (all|events|packet|packet in|packet out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr bst|timer bsr crp|mib|nsm|nexthop|mtrace|msdp)

Netconf RPC payload

```
<ipi-pim-ipv4-debug_pim-ipv4-terminal-debug-on xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
  <terminal-debug-options>all</terminal-debug-options>
</ipi-pim-ipv4-debug_pim-ipv4-terminal-debug-on>
```

Command Syntax

```
debug ip pim (vrf NAME|) (all|events|packet|packet in|packet
out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer
hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune
ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr
bst|timer bsr crp|mib|nsm|nexthop|mtrace|msdp)
```

no debug ip pim (vrf NAME|) (all|events|packet|packet in|packet out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr bst|timer bsr crp|mib|nsm|nexthop|mtrace|msdp)

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: terminal-debug-options

Attribute Type: bits (all|events|packet|packet in|packet out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr bst|timer bsr crp|mib|nsm|nexthop|mtrace|msdp)

Netconf RPC payload

```
<ipi-pim-ipv4-debug_pim-ipv4-terminal-debug-off xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
  <terminal-debug-options>all</terminal-debug-options>
</ipi-pim-ipv4-debug_pim-ipv4-terminal-debug-off>
```

Command Syntax

```
no debug ip pim (vrf NAME|) (all|events|packet|packet in|packet
out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer
hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune
ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr
bst|timer bsr crp|mib|nsm|nexthop|mtrace|msdp)
```

debug ip pim (vrf NAME|)

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Netconf RPC payload

```
<ipi-pim-ipv4-debug_pim-ipv4-terminal-debug-all-on xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
</ipi-pim-ipv4-debug_pim-ipv4-terminal-debug-all-on>
```

Command Syntax

```
debug ip pim (vrf NAME|)
```

no debug ip pim (vrf NAME|)

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Netconf RPC payload

```
<ipi-pim-ipv4-debug_pim-ipv4-terminal-debug-all-off xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
</ipi-pim-ipv4-debug_pim-ipv4-terminal-debug-all-off>
```

Command Syntax

```
no debug ip pim (vrf NAME|)
```

IPI-PIM-IPV6

Configure router id

Use this attribute to configure PIM router-ID to uniquely identify the router. By default, PIM registers for the NSM router-id service. This attribute will override the router-id received from NSM.

Attribute Name: router-id

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <router-id>A.B.C.D</router-id> <!-- operation="delete"-->
      </instance>
    </instances>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) router-id A.B.C.D
```

Configure join prune interval

Use this attribute to set a PIM join/prune timer.

Attribute Name: join-prune-interval

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
          </config>
          <join-prune-interval>1</join-prune-interval> <!-- operation="delete"-->
        </instance>
      </instances>
    </ipv6>
  </pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) jp-timer <1-65535>
```

Configure ecmp bundle

Use this attribute to create an ECMP bundle.

Attribute Name: ecmp-bundle

Attribute Type: string

Attribute Range: 1-50

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
          </config>
          <ecmp-bundle>WORD</ecmp-bundle> <!-- operation="delete"-->
        </instance>
      </instances>
    </ipv6>
  </pim>
```


Command Syntax

```
ipv6 pim (vrf NAME|) ecmp-bundle WORD
```

Configure enable bfd all interfaces

Use this attribute to enable Bidirectional Forwarding Detection (BFD) on all interfaces.

Attribute Name: enable-bfd-all-interfaces

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        </enable-bfd-all-interfaces><!-- operation="delete"-->
      </instance>
    </instances>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) bfd all-interfaces
```

Configure register reachability check

Use this attribute to enable the RP reachability check for PIM Registers at the designated router (DR).

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: register-reachability-check

Attribute Type: enum (disable|enable)

Default Value: enable

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <register-packet>
          <config>
```

```
        <register-reachability-check>enable</register-reachability-check> <!--
operation="delete"-->
    </config>
</register-packet>
</instance>
</instances>
</ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) register-rp-reachability (disable|enable)
```

Configure rate limit

Use this attribute to configure the rate of register packets sent by this designated router (DR).

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: rate-limit

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
<ipv6>
<instances>
<instance>
    <vrf-name>NAME</vrf-name>
    <config>
        <vrf-name>NAME</vrf-name>
    </config>
    <register-packet>
    <config>
        <rate-limit>1</rate-limit> <!-- operation="delete"-->
    </config>
</register-packet>
</instance>
</instances>
</ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) register-rate-limit <1-65535>
```

Configure suppress interval

Use this attribute to configure the register suppression time.

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: suppress-interval

Attribute Type: uint16

Default Value: 60

Attribute Range: 11-65535

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <register-packet>
          <config>
            <suppress-interval>11</suppress-interval> <!-- operation="delete"-->
          </config>
        </register-packet>
      </instance>
    </instances>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) register-suppression <11-65535>
```

Configure keep alive interval

Use this attribute to configure a Keep alive Timer (KAT) value for (S,G) states at RP to monitor PIM register packets.

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: keep-alive-interval

Attribute Type: uint16

Default Value: 185

Attribute Range: 1-65535

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <register-packet>
          <config>
            <keep-alive-interval>1</keep-alive-interval> <!-- operation="delete"-->
          </config>
        </register-packet>
      </instance>
    </instances>
  </ipv6>
</pim>
```

```
    </config>
  </register-packet>
</instance>
</instances>
</ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) rp-register-kat <1-65535>
```

Configure source address

Use this attribute to configure the source address of register packets sent by this designated router (DR).

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: source-address

Attribute Type: union

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
          </config>
          <register-packet>
            <config>
              <source-address>PIM_IPV6_REG_SOURCE_T</source-address>
            </config>
          </register-packet>
        </instance>
      </instances>
    </ipv6>
  </pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) register-source (X:X::X:X|IFNAME)
```

Configure accept register

Use this attribute to configure the ACL of register packets accepted by this designated router (DR).

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: accept-register

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
<ipv6>
<instances>
<instance>
  <vrf-name>NAME</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  <register-packet>
  <config>
    <accept-register>WORD</accept-register> <!-- operation="delete"-->
  </config>
</register-packet>
</instance>
</instances>
</ipv6>
</pim>

```

Command Syntax

```
ipv6 pim (vrf NAME|) accept-register list WORD
```

Configure ignore rp set priority

Use this attribute to ignore the RP-SET priority value, and use only the hashing mechanism for RP selection. This is used to inter-operate with older Cisco IOS versions.

Attribute Name: ignore-rp-set-priority

Attribute Type: empty

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
<ipv6>
<instances>
<instance>
  <vrf-name>NAME</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  <interop>
  <config>
    </ignore-rp-set-priority><!-- operation="delete"-->
  </config>
</interop>
</instance>
</instances>
</ipv6>
</pim>

```

Command Syntax

```
ipv6 pim (vrf NAME|) ignore-rp-set-priority
```

Configure cisco bsr interop enable

Use this attribute to turn on or turn the Candidate-RP debugging timerworking with Cisco BSR.

Attribute Name: cisco-bsr-interop-enable

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
          </config>
          <interop>
            <config>
              </cisco-bsr-interop-enable><!-- operation="delete"-->
            </config>
          </interop>
        </instance>
      </instances>
    </ipv6>
  </pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) crp-cisco-prefix
```

Configure access control list

Use this attribute to configure the option to calculate the register checksum over the whole packet on multicast groups specified by the access control list.

Attribute Name: access-control-list

Attribute Type: string

Attribute Range: 1-64

Attribute Name: cisco-register-checksum-enable

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
```

```

    <vrf-name>NAME</vrf-name>
    <config>
      <vrf-name>NAME</vrf-name>
    </config>
    <interop>
    <register-packet>
    <config>
      </cisco-register-checksum-enable><!-- operation="delete"-->
      <access-control-list>WORD</access-control-list> <!-- operation="delete"--
>
      </config>
    </register-packet>
  </interop>
</instance>
</instances>
</ipv6>
</pim>

```

Command Syntax

```
ipv6 pim (vrf NAME|) cisco-register-checksum group-list WORD
```

Configure cisco register checksum enable

Use this attribute to configure the option to calculate the register checksum over the whole packet. This is used to inter-operate with older Cisco IOS versions.

Attribute Name: cisco-register-checksum-enable

Attribute Type: empty

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <interop>
        <register-packet>
        <config>
          </cisco-register-checksum-enable>
        </config>
      </register-packet>
    </interop>
  </instance>
</instances>
</ipv6>
</pim>

```

Command Syntax

```
ipv6 pim (vrf NAME|) cisco-register-checksum
```

Configure vrf name

Use this attribute to enable the ability of the last-hop PIM router to switch to SPT for multicast group addresses indicated by the given standard access control list.

Attribute Name: access-control-list

Attribute Type: string

Attribute Range: 1-64

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <spt-switch>
          <config>
            </enable><!-- operation="delete"-->
            <access-control-list>WORD</access-control-list> <!-- operation="delete"-->
          </config>
        </spt-switch>
      </instance>
    </instances>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) spt-threshold group-list WORD
```

Configure enable

Use this attribute to enable the ability of the last-hop PIM router to switch to SPT.

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
```



```

<instance>
  <vrf-name>NAME</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  <spt-switch>
    <config>
      </enable>
    </config>
  </spt-switch>
</instance>
</instances>
</ipv6>
</pim>

```

Command Syntax

```
ipv6 pim (vrf NAME|) spt-threshold
```

Configure range policy

Use this attribute to set Source Specific Multicast (SSM) and define the range of multicast IP addresses. Ranges can be either the default, which defines the SSM range as FF3x::/96, or indicated by the given standard access control list.

This command is supported when following feature are enabled PIM Source Specific Multicast (SSM)

Attribute Name: range-policy

Attribute Type: union

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <ssm>
          <config>
            <range-policy>PIM_IPV6_SSM_RANGE_POLICY_TYPE_T</range-policy>
          </config>
        </ssm>
      </instance>
    </instances>
  </ipv6>
</pim>

```

Command Syntax

```
ipv6 pim (vrf NAME|) ssm (range WORD|default)
```

Configure member rp address

Destination IPv6 address where register messages are copied and sent. A Member RP is an individual RP member in the anycast RP set.

This command is supported when following feature are enabled PIM Sparse Mode (SM)

Attribute Name: member-rp-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <anycast-rps>
          <anycast-rp> <!-- operation="delete"-->
            <member-rp-address>X:X::X:X</member-rp-address>
            <config>
              <member-rp-address>X:X::X:X</member-rp-address>
              <anycast-rp-address>X:X::X:X</anycast-rp-address>
            </config>
            <anycast-rp-address>X:X::X:X</anycast-rp-address>
          </anycast-rp>
        </anycast-rps>
      </instance>
    </instances>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) anycast-rp X:X::X:X X:X::X:X
```

Configure embed rp

Use this attribute to embed the PIM Rendezvous Point

Attribute Name: embed-rp

Attribute Type: enum (disable|enable)

Default Value: enable

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
```

```

    <vrf-name>NAME</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  <rendezvous-point>
  <config>
    <embed-rp>enable</embed-rp> <!-- operation="delete"-->
  </config>
</rendezvous-point>
</instance>
</instances>
</ipv6>
</pim>

```

Command Syntax

```
ipv6 pim (vrf NAME|) rp embedded (disable|enable)
```

Configure rp address

Use this attribute to statically configure Rendezvous Point (RP) address for multicast groups.

Attribute Name: rp-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <rendezvous-point>
          <static-rps>
            <static-rps-default>
              <static-rp-default> <!-- operation="delete"-->
                <rp-address>X:X::X:X</rp-address>
              <config>
                <rp-address>X:X::X:X</rp-address>
              </config>
            </static-rp-default>
          </static-rps-default>
        </static-rps>
      </rendezvous-point>
    </instance>
  </instances>
</ipv6>
</pim>

```

Command Syntax

```
ipv6 pim (vrf NAME|) rp-address X:X::X:X
```

Configure override dynamically learned rp

Use this attribute to configure the flag to override dynamically learned RP mappings.

Attribute Name: override-dynamically-learned-rp

Attribute Type: empty

Attribute Name: access-control-list

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <rendezvous-point>
          <static-rps>
            <static-rps-default>
              <static-rp-default>
                <rp-address>X:X::X:X</rp-address>
                <config>
                  <rp-address>X:X::X:X</rp-address>
                  <access-control-list>WORD</access-control-list> <!-- operation="delete"-->
                </config>
              </static-rp-default>
            </static-rps-default>
          </static-rps>
        </rendezvous-point>
      </instance>
    </instances>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) rp-address X:X::X:X WORD override
```

Configure interface name

Use this attribute to configure the interface for the candidate BSR router.

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-33

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
<ipv6>
<instances>
<instance>
  <vrf-name>NAME</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  <rendezvous-point>
  <bootstrap-router>
  <bsr-candidate>
  <config>
    <interface-name>IFNAME</interface-name> <!-- operation="delete"-->
  </config>
</bsr-candidate>
</bootstrap-router>
</rendezvous-point>
</instance>
</instances>
</ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) bsr-candidate IFNAME
```

Configure hash mask length

Use this attribute to configure the mask length used to calculate the group address for RP.

Attribute Name: hash-mask-length

Attribute Type: uint8

Attribute Range: 0-32

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-33

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
<ipv6>
<instances>
<instance>
  <vrf-name>NAME</vrf-name>
  <config>
```

```
    <vrf-name>NAME</vrf-name>
  </config>
  <rendezvous-point>
  <bootstrap-router>
  <bsr-candidate>
  <config>
    <interface-name>IFNAME</interface-name> <!-- operation="delete"-->
    <hash-mask-length>0</hash-mask-length> <!-- operation="delete"-->
  </config>
</bsr-candidate>
</bootstrap-router>
</rendezvous-point>
</instance>
</instances>
</ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) bsr-candidate IFNAME <0-32>
```

Configure priority

Use this attribute to configure the priority value for candidate BSR router.

Attribute Name: priority

Attribute Type: uint8

Attribute Range: 0-255

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-33

Attribute Name: hash-mask-length

Attribute Type: uint8

Attribute Range: 0-32

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <rendezvous-point>
        <bootstrap-router>
        <bsr-candidate>
        <config>
```

```

        <interface-name>IFNAME</interface-name> <!-- operation="delete"-->
        <hash-mask-length>0</hash-mask-length> <!-- operation="delete"-->
        <priority>0</priority> <!-- operation="delete"-->
    </config>
</bsr-candidate>
</bootstrap-router>
</rendezvous-point>
</instance>
</instances>
</ipv6>
</pim>

```

Command Syntax

```
ipv6 pim (vrf NAME|) bsr-candidate IFNAME <0-32> <0-255>
```

Configure advertisement interval

Use this attribute to configure the priority value for RP candidate.

Attribute Name: priority

Attribute Type: uint8

Attribute Range: 0-255

Attribute Name: access-control-list

Attribute Type: string

Attribute Range: 1-64

Attribute Name: advertisement-interval

Attribute Type: uint16

Attribute Range: 1-16383

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <rendezvous-point>
          <rp-candidates>
            <rp-candidate>
              <interface-name>IFNAME</interface-name>
              <config>
                <interface-name>IFNAME</interface-name>
                <access-control-list>WORD</access-control-list> <!-- operation="delete"-->
              >
                <advertisement-interval>1</advertisement-interval> <!--
operation="delete"-->

```

```
    </config>
      <priority>0</priority> <!-- operation="delete"-->
    </rp-candidate>
  </rp-candidates>
</rendezvous-point>
</instance>
</instances>
</ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (vrf NAME|) rp-candidate IFNAME (group-list WORD|) (interval <1-16383>|)
(priority <0-255>|)
```

Configure options

Use this attribute to debug the PIM IPv6 feature.

Attribute Name: options

Attribute Type: bits (all|events|packet|packet in|packet out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr bst|timer bsr crp|mib|nsm|nexthop|mtrace)

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <instances>
      <instance>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <debug>
          <config>
            <options>all</options> <!-- operation="delete"-->
          </config>
        </debug>
      </instance>
    </instances>
  </ipv6>
</pim>
```

Command Syntax

```
debug ipv6 pim (vrf NAME|) (all|events|packet|packet in|packet
out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer
hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune
ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr
bst|timer bsr crp|mib|nsm|nexthop|mtrace)
```

Configure passive enable

PIM IPv6 passive mode.

Attribute Name: passive-enable

Attribute Type: empty

Attribute Name: pim-mode

Attribute Type: enum (dense-mode|sparse-mode)

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
          <pim-mode>dense-mode</pim-mode> <!-- operation="delete"-->
        </config>
        </passive-enable><!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (dense-mode|sparse-mode) passive
```

Configure pim mode

PIM IPv6 mode to use when delivering multicast traffic via this interface.

Attribute Name: pim-mode

Attribute Type: enum (dense-mode|sparse-mode)

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
          <pim-mode>dense-mode</pim-mode> <!-- operation="delete"-->
        </config>
      </interface>
    </interfaces>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim (dense-mode|sparse-mode)
```

Configure bsr border

When set to true the device will not send bootstrap router messages over this interface. By default these are transmitted over all PIM IPv6 sparse mode (PIM-SM) enabled interfaces.

Attribute Name: bsr-border

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </bsr-border><!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim bsr-border
```

Configure dr priority

The designated router priority of this interface. Larger always preferred.

Attribute Name: dr-priority

Attribute Type: uint32

Attribute Range: 0-4294967294

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <dr-priority>0</dr-priority> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv6>
</pim>
```

```
</ipv6>  
</pim>
```

Command Syntax

```
ipv6 pim dr-priority <0-4294967294>
```

Configure hello interval

Use this attribute to configure a hello interval value other than the default. When a hello-interval is configured and hello-holdtime is not configured, or when the hello-holdtime value configured is less than the new hello-interval value, the holdtime value is modified to (3.5 * hello_interval). Otherwise, the hello-holdtime value is the configured value.

Attribute Name: hello-interval

Attribute Type: uint16

Default Value: 30

Attribute Range: 1-18724

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">  
<ipv6>  
<interfaces>  
<interface>  
  <name>WORD</name>  
  <config>  
    <name>WORD</name>  
    </config>  
    <hello-interval>1</hello-interval> <!-- operation="delete"-->  
</interface>  
</interfaces>  
</ipv6>  
</pim>
```

Command Syntax

```
ipv6 pim hello-interval <1-18724>
```

Configure hello holdtime

Use this attribute to configure a hello message holdtime other than the default.

Attribute Name: hello-holdtime

Attribute Type: uint16

Default Value: 105

Attribute Range: 1-65535

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">  
<ipv6>  
<interfaces>
```

```
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <hello-holdtime>1</hello-holdtime> <!-- operation="delete"-->
</interface>
</interfaces>
</ipv6>
</pim>
```

Command Syntax

```
ipv6 pim hello-holdtime <1-65535>
```

Configure exclude generated id

Exclude Gen-id option from PIM IPv6 Hello packets on this interface.

Attribute Name: exclude-generated-id

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </exclude-generated-id><!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim exclude-genid
```

Configure unicast bootstrap router

Use this attribute to enable support for sending and receiving unicast Bootstrap Messages (BSM) on an interface.

Attribute Name: unicast-bootstrap-router

Attribute Type: empty

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <interfaces>
```

```

<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </unicast-bootstrap-router><!-- operation="delete"-->
</interface>
</interfaces>
</ipv6>
</pim>

```

Command Syntax

```
ipv6 pim unicast-bsm
```

Configure neighbor access control list filter

Use this attribute to enable filtering of neighbors on the interface. When configuring a neighbor filter, PIM IPv6 either not establishes adjacency with neighbor or terminates adjacency with existing neighbors, when denied by filtering access list.

Attribute Name: neighbor-access-control-list-filter

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```

<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <neighbor-access-control-list-filter>WORD</neighbor-access-control-list-
filter> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv6>
</pim>

```

Command Syntax

```
ipv6 pim neighbor-filter WORD
```

Configure state refresh origination interval

Use this attribute to configure a PIM-DM State-Refresh origination interval other than the default value. The origination interval is the number of seconds between PIM-DM State Refresh control messages.

Attribute Name: state-refresh-origination-interval

Attribute Type: uint16

Default Value: 60

Attribute Range: 1-100

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <state-refresh-origination-interval>1</state-refresh-origination-interval>
<!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim state-refresh origination-interval <1-100>
```

Configure name

Use this attribute to configure an ECMP bundle.

Attribute Name: ecmp-bundle

Attribute Type: string

Attribute Range: 1-50

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <ecmp-bundle>WORD</ecmp-bundle> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim bind ecmp-bundle WORD
```

Configure propagation delay

Propagation-delay value.

Attribute Name: propagation-delay

Attribute Type: uint16

Default Value: 1000

Attribute Range: 0-32767

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <propagation-delay>0</propagation-delay> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim propagation-delay <0-32767>
```

Configure enable bfd

Use this attribute to configure Bidirectional Forwarding Detection.

Attribute Name: enable-bfd

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<pim xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <ipv6>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <enable-bfd>enable</enable-bfd> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </ipv6>
</pim>
```

Command Syntax

```
ipv6 pim bfd (disable|)
```

clear ipv6 pim (vrf NAME|) (sparse-mode) bsr rp-set *

Attribute Name: vrf-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: pim-mode

Attribute Type: enum (sparse-mode)

Netconf RPC payload

```
<ipi-pim-ipv6_pim-ipv6-clear-bsr-rendezvous-point xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
  <pim-mode>sparse-mode</pim-mode>
</ipi-pim-ipv6_pim-ipv6-clear-bsr-rendezvous-point>
```

Command Syntax

```
clear ipv6 pim (vrf NAME|) (sparse-mode) bsr rp-set *
```

clear ipv6 mroute (vrf NAME|) * pim (dense-mode|sparse-mode)

Attribute Name: vrf-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: pim-mode

Attribute Type: enum (dense-mode|sparse-mode)

Netconf RPC payload

```
<ipi-pim-ipv6_pim-ipv6-clear-multicast-route xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
  <pim-mode>dense-mode</pim-mode>
</ipi-pim-ipv6_pim-ipv6-clear-multicast-route>
```

Command Syntax

```
clear ipv6 mroute (vrf NAME|) * pim (dense-mode|sparse-mode)
```

clear ipv6 mroute (vrf NAME|) X:X::X:X pim sparse-mode

Attribute Name: vrf-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: group-address

Attribute Type: inet:ipv6-address

Netconf RPC payload

```
<ipi-pim-ipv6_pim-ipv6-clear-multicast-route-source-group xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
  <group-address>X:X::X:X</group-address>
</ipi-pim-ipv6_pim-ipv6-clear-multicast-route-source-group>
```

Command Syntax

```
clear ipv6 mroute (vrf NAME|) X:X::X:X pim sparse-mode
```

clear ipv6 mroute (vrf NAME|) X:X::X:X X:X::X:X pim (dense-mode|sparse-mode)

Attribute Name: vrf-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: group-address

Attribute Type: inet:ipv6-address

Attribute Name: source-address

Attribute Type: inet:ipv6-address

Attribute Name: pim-mode

Attribute Type: enum (dense-mode|sparse-mode)

Netconf RPC payload

```
<ipi-pim-ipv6_pim-ipv6-clear-multicast-route-source-group-mode xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
  <group-address>X:X::X:X</group-address>
  <source-address>X:X::X:X</source-address>
  <pim-mode>dense-mode</pim-mode>
</ipi-pim-ipv6_pim-ipv6-clear-multicast-route-source-group-mode>
```

Command Syntax

```
clear ipv6 mroute (vrf NAME|) X:X::X:X X:X::X:X pim (dense-mode|sparse-mode)
```

debug pim bfd

Netconf RPC payload

```
<ipi-pim-debug_pim-terminal-debug-bfd-on xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-pim"/>
```

Command Syntax

```
debug pim bfd
```

no debug pim bfd

Netconf RPC payload

```
<ipi-pim-debug_pim-terminal-debug-bfd-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim"/>
```

Command Syntax

```
no debug pim bfd
```

debug ipv6 pim (vrf NAME|) (all|events|packet|packet in|packet out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr bst|timer bsr crp|mib|nsm|nexthop|mtrace)

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: terminal-debug-options

Attribute Type: bits (all|events|packet|packet in|packet out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr bst|timer bsr crp|mib|nsm|nexthop|mtrace)

Netconf RPC payload

```
<ipi-pim-ipv6-debug_pim-ipv6-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
  <terminal-debug-options>all</terminal-debug-options>
</ipi-pim-ipv6-debug_pim-ipv6-terminal-debug-on>
```

Command Syntax

```
debug ipv6 pim (vrf NAME|) (all|events|packet|packet in|packet out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr bst|timer bsr crp|mib|nsm|nexthop|mtrace)
```

no debug ipv6 pim (vrf NAME|) (all|events|packet|packet in|packet out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr bst|timer bsr crp|mib|nsm|nexthop|mtrace)

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: terminal-debug-options

Attribute Type: bits (all|events|packet|packet in|packet out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr bst|timer bsr crp|mib|nsm|nexthop|mtrace)

Netconf RPC payload

```
<ipi-pim-ipv6-debug_pim-ipv6-terminal-debug-off xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
  <terminal-debug-options>all</terminal-debug-options>
</ipi-pim-ipv6-debug_pim-ipv6-terminal-debug-off>
```

Command Syntax

```
no debug ipv6 pim (vrf NAME|) (all|events|packet|packet in|packet
out|state|mfc|timer|timer hello|timer bsr|timer joinprune|timer hello ht|timer
hello nlt|timer hello tht|timer joinprune jt|timer joinprune et|timer joinprune
ppt|timer joinprune kat|timer joinprune ot|timer assert|timer register|timer bsr
bst|timer bsr crp|mib|nsm|nexthop|mtrace)
```

debug ipv6 pim (vrf NAME|)

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Netconf RPC payload

```
<ipi-pim-ipv6-debug_pim-ipv6-terminal-debug-all-on xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
</ipi-pim-ipv6-debug_pim-ipv6-terminal-debug-all-on>
```

Command Syntax

```
debug ipv6 pim (vrf NAME|)
```

no debug ipv6 pim (vrf NAME|)

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Netconf RPC payload

```
<ipi-pim-ipv6-debug_pim-ipv6-terminal-debug-all-off xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-pim">
  <vrf-name>NAME</vrf-name>
</ipi-pim-ipv6-debug_pim-ipv6-terminal-debug-all-off>
```

Command Syntax

```
no debug ipv6 pim (vrf NAME|)
```

IPI-VXLAN

Configure mac address

Use this attribute to set the mac address with arp-nd refresh-timer

Attribute Name: mac-address

Attribute Type: string

Attribute Name: arp-nd-refresh-timer

Attribute Type: uint32

Attribute Range: 3-190

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <global>
    <config>
      <arp-nd-refresh-timer>3</arp-nd-refresh-timer> <!-- operation="delete"-->
      <mac-address>XX-XX-XX-XX-XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</mac-address>
<!-- operation="delete"-->
    </config>
  </global>
</vxlan>
```

Command Syntax

```
nvo vxlan arp-nd refresh-timer <3-190> mac (XX-XX-XX-XX-XX-
  XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX)
```

Configure enable vxlan

Use this attribute to enable VxLAN module. Without this attribute vxlan functionality can not be achieved

Attribute Name: enable-vxlan

Attribute Type: empty

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <global>
    <config>
      </enable-vxlan>
    </config>
  </global>
</vxlan>
```

Command Syntax

```
nvo vxlan enable
```

Configure vtep ipv4

Use this attribute to set source vtep global ip address. This will be treated at vxlan tunnel source address

Attribute Name: vtep-ipv4

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <global>
    <config>
      <vtep-ipv4>A.B.C.D</vtep-ipv4> <!-- operation="delete"-->
    </config>
  </global>
</vxlan>
```

Command Syntax

```
nvo vxlan vtep-ip-global A.B.C.D
```

Configure mac ageing timer

Use this attribute to set the time till a learned mac address will persist after last update

Attribute Name: mac-ageing-timer

Attribute Type: uint32

Default Value: 300

Attribute Range: 10-572

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <global>
    <config>
      <mac-ageing-timer>10</mac-ageing-timer> <!-- operation="delete"-->
    </config>
  </global>
</vxlan>
```

Command Syntax

```
nvo vxlan mac-ageing-time <10-572>
```

Configure arp nd refresh timer

Use this attribute to configure aging out the arp-cache and nd-cache entries for given time multiplied by 3 in secs.

Attribute Name: arp-nd-refresh-timer

Attribute Type: uint32

Attribute Range: 3-190

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <global>
    <config>
      <arp-nd-refresh-timer>3</arp-nd-refresh-timer> <!-- operation="delete"-->
    </config>
  </global>
</vxlan>
```

Command Syntax

```
nvo vxlan arp-nd refresh-timer <3-190>
```

Configure traffic direction

Use this attribute to set global direction(ingress/egress) for VxLAN. Ingress means traffic coming to network side and egress means traffic going out from network side

This command is supported when following feature are enabled QOS feature

Attribute Name: traffic-direction

Attribute Type: enum (ingress|egress)

Attribute Name: profile-name

Attribute Type: string

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <qos-tunnel-mappings>
    <qos-tunnel-mapping> <!-- operation="delete"-->
      <traffic-direction>ingress</traffic-direction>
      <config>
        <traffic-direction>ingress</traffic-direction>
        <qos-map-mode>cos-dscp</qos-map-mode>
        <profile-name>NAME</profile-name>
      </config>
      <qos-map-mode>cos-dscp</qos-map-mode>
    </qos-tunnel-mapping>
  </qos-tunnel-mappings>
</vxlan>
```

Command Syntax

```
nvo vxlan tunnel qos-map-mode (cos-dscp) (ingress|egress) NAME
```

Configure tenant type

Use this attribute to create tenant with multicast tunnel

Attribute Name: tenant-type

Attribute Type: enum (default|multicast|ingress-replication|ingress-replication inner-vid-disabled)

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <vxlan-tenants>
  <vxlan-tenant>
    <vxlan-identifier>1</vxlan-identifier>
    <config>
      <vxlan-identifier>1</vxlan-identifier>
    </config>
    <tenant-type>default</tenant-type>
  </vxlan-tenant>
</vxlan-tenants>
</vxlan>
```

Command Syntax

```
nvo vxlan id <1-16777215> ((default|multicast|ingress-replication|ingress-
  replication inner-vid-disabled) |)
```

Configure xconnect identifier

Use this attribute to create Xconnect tenant

Attribute Name: xconnect-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Attribute Name: tenant-xconnect-type

Attribute Type: enum (default|inner-vid-disabled)

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <vxlan-tenants>
  <vxlan-tenant>
    <vxlan-identifier>1</vxlan-identifier>
    <config>
      <vxlan-identifier>1</vxlan-identifier>
      <tenant-xconnect-type>default</tenant-xconnect-type>
    </config>
    <xconnect-identifier>1</xconnect-identifier>
  </vxlan-tenant>
</vxlan-tenants>
</vxlan>
```

Command Syntax

```
nvo vxlan id <1-16777215> xconnect target-vxlan-id <1-16777215> ((default|inner-
  vid-disabled) |)
```

Configure vrf name

Use this attribute to map VRF to carry EVPN routes. This defines BGP as the mechanism for host reachability advertisement.

Attribute Name: vrf-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <vxlan-tenants>
    <vxlan-tenant>
      <vxlan-identifier>1</vxlan-identifier>
      <config>
        <vxlan-identifier>1</vxlan-identifier>
      </config>
      <vrf-name>NAME</vrf-name> <!-- operation="delete"-->
    </vxlan-tenant>
  </vxlan-tenants>
</vxlan>
```

Command Syntax

```
vxlan host-reachability-protocol evpn-bgp NAME
```

Configure map network

Use this attribute to map a tunnel to the tenant

Attribute Name: map-network

Attribute Type: string

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <vxlan-tenants>
    <vxlan-tenant>
      <vxlan-identifier>1</vxlan-identifier>
      <config>
        <vxlan-identifier>1</vxlan-identifier>
      </config>
      <map-network>NAME</map-network> <!-- operation="delete"-->
    </vxlan-tenant>
  </vxlan-tenants>
</vxlan>
```

Command Syntax

```
vxlan map-network tunnel NAME
```

Configure mac hold timer

Use this attribute to set the time a host mac entry will persist after unconfiguring. Hold time range -1 to 300 in seconds.
-1(never expire)

Attribute Name: mac-hold-timer

Attribute Type: int32

Default Value: 0

Attribute Range: -1-300

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <vxlan-tenants>
  <vxlan-tenant>
    <vxlan-identifier>1</vxlan-identifier>
    <config>
      <vxlan-identifier>1</vxlan-identifier>
    </config>
    <mac-hold-timer>-1</mac-hold-timer> <!-- operation="delete"-->
  </vxlan-tenant>
</vxlan-tenants>
</vxlan>
```

Command Syntax

```
mac-holdtime <-1-300>
```

Configure tenant description

Use this attribute to set VxLAN identifier name

Attribute Name: tenant-description

Attribute Type: string

Attribute Range: 1-10

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <vxlan-tenants>
  <vxlan-tenant>
    <vxlan-identifier>1</vxlan-identifier>
    <config>
      <vxlan-identifier>1</vxlan-identifier>
      <tenant-description>WORD</tenant-description> <!-- operation="delete"-->
    </config>
  </vxlan-tenant>
</vxlan-tenants>
</vxlan>
```

Command Syntax

```
vni-name WORD
```

Configure irb name

Use this attribute to to configure default gateway behavior on a VTEP for particular VNID.

Attribute Name: irb-name

Attribute Type: string

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <vxlan-tenants>
    <vxlan-tenant>
      <vxlan-identifier>1</vxlan-identifier>
      <config>
        <vxlan-identifier>1</vxlan-identifier>
      </config>
      <irb-name>NAME</irb-name> <!-- operation="delete"-->
    </vxlan-tenant>
  </vxlan-tenants>
</vxlan>
```

Command Syntax

```
evpn NAME
```

Configure irb advertise host route

Use this attribute to set advertise host to route

Attribute Name: irb-advertise-host-route

Attribute Type: empty

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <vxlan-tenants>
    <vxlan-tenant>
      <vxlan-identifier>1</vxlan-identifier>
      <config>
        <vxlan-identifier>1</vxlan-identifier>
      </config>
      <irb>
        <config>
          </irb-advertise-host-route><!-- operation="delete"-->
        </config>
      </irb>
    </vxlan-tenant>
  </vxlan-tenants>
</vxlan>
```

Command Syntax

```
evpn irb-advertise-host-route
```

Configure vxlan identifier

Use this attribute to know MAC address of the host.create a static route to reach a destination MAC in the VXLAN forwarding table. This command helps to supports different tenants so that they can have the same MAC/IP, but different VNIDs.This command is required for unicast tunnels to map the remote VTEP

Attribute Name: mac-address

Attribute Type: string

Attribute Name: remote-vtep-ipv4

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <vxlan-tenants>
  <vxlan-tenant>
    <vxlan-identifier>1</vxlan-identifier>
    <config>
      <vxlan-identifier>1</vxlan-identifier>
    </config>
  <static-tenants>
  <static-tenant> <!-- operation="delete"-->
    <mac-address>XX-XX-XX-XX-XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</mac-address>
    <config>
      <mac-address>CML_MAC_ADDR_T</mac-address>
      <remote-vtep-ipv4>A.B.C.D</remote-vtep-ipv4>
    </config>
  </static-tenant>
</static-tenants>
</vxlan-tenant>
</vxlan-tenants>
</vxlan>
```

Command Syntax

```
vxlan static-entry host-mac (XX-XX-XX-XX-XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX)
  remote-vtep-ip A.B.C.D
```

Configure untagged interface name

Use this attribute to map a physical interface to identify the tenant traffic and to enter NVO access interface mode

Attribute Name: untagged-interface-name

Attribute Type: string

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <untagged-access-interfaces>
  <untagged-access-interface> <!-- operation="delete"-->
    <untagged-interface-name>WORD</untagged-interface-name>
    <config>
      <untagged-interface-name>WORD</untagged-interface-name>
    </config>
  </untagged-access-interface>
</untagged-access-interfaces>
</vxlan>
```

Command Syntax

```
nvo vxlan access-if port IFNAME
```

Configure default access interface

Use this attribute to create default access interface

Attribute Name: default-access-interface

Attribute Type: empty

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <untagged-access-interfaces>
    <untagged-access-interface>
      <untagged-interface-name>WORD</untagged-interface-name>
      <config>
        <untagged-interface-name>WORD</untagged-interface-name>
      </config>
    </default-access-interface>
  </untagged-access-interface>
</untagged-access-interfaces>
</vxlan>
```

Command Syntax

```
nvo vxlan access-if port IFNAME default
```

Configure admin shutdown

Use this attribute to shutdown vxlan access interface

This command is supported when following feature are disabled DNX feature

Attribute Name: admin-shutdown

Attribute Type: empty

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <untagged-access-interfaces>
    <untagged-access-interface>
      <untagged-interface-name>WORD</untagged-interface-name>
      <config>
        <untagged-interface-name>WORD</untagged-interface-name>
      </config>
    </admin-shutdown><!-- operation="delete"-->
  </untagged-access-interface>
</untagged-access-interfaces>
</vxlan>
```

Command Syntax

```
shutdown
```

Configure description

Use this attribute to set description of access interface

This command is supported when following feature are disabled DNX feature

Attribute Name: description

Attribute Type: string

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <untagged-access-interfaces>
    <untagged-access-interface>
      <untagged-interface-name>WORD</untagged-interface-name>
      <config>
        <untagged-interface-name>WORD</untagged-interface-name>
      </config>
      <description>LINE</description> <!-- operation="delete"-->
    </untagged-access-interface>
  </untagged-access-interfaces>
</vxlan>
```

Command Syntax

```
description LINE
```

Configure dynamic learning disable

Use this attribute to disable dynamic learning of MACs at the access port. This command also disables dynamic learning of MAC/IP from ARP/ND messages received on this access port.

This command is supported when following feature are disabled DNX feature

Attribute Name: dynamic-learning-disable

Attribute Type: empty

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <untagged-access-interfaces>
    <untagged-access-interface>
      <untagged-interface-name>WORD</untagged-interface-name>
      <config>
        <untagged-interface-name>WORD</untagged-interface-name>
      </config>
      </dynamic-learning-disable><!-- operation="delete"-->
    </untagged-access-interface>
  </untagged-access-interfaces>
</vxlan>
```

Command Syntax

```
dynamic-learning disable
```

Configure access mac hold time

Use this attribute to set the time a host mac entry will persist after unconfiguring. The feature holds the MAC in hardware until BGP has withdrawn from the neighbors. This helps to reduce flooding to other access ports. This setting applies when the access port is shut down, the physical port on which the access port is down, or the access port is removed from the VNID using the no form of the map vnid command. When the MAC hold time is configured as -1, then the MAC is not removed from the hardware and is also not withdrawn from EVPN BGP

This command is supported when following feature are disabled DNX feature

Attribute Name: access-mac-hold-time

Attribute Type: int32

Attribute Range: -1-300

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <untagged-access-interfaces>
    <untagged-access-interface>
      <untagged-interface-name>WORD</untagged-interface-name>
      <config>
        <untagged-interface-name>WORD</untagged-interface-name>
      </config>
      <access-mac-hold-time>-1</access-mac-hold-time> <!-- operation="delete"-->
    </untagged-access-interface>
  </untagged-access-interfaces>
</vxlan>
```

Command Syntax

```
mac-holdtime <-1-300>
```

Configure arp nd flood suppress

Use this attribute to restrict the flood of ARP/ND packets towards remote VTEPs or other access ports. This command applies only when the ARP cache and ND cache are enabled. When the ARP cache is disabled, ARP flooding is not suppressed even if this command is given. When the ND cache is disabled, ND flooding is not disabled, even if this command is given

This command is supported when following feature are disabled DNX feature

Attribute Name: arp-nd-flood-suppress

Attribute Type: empty

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <untagged-access-interfaces>
    <untagged-access-interface>
      <untagged-interface-name>WORD</untagged-interface-name>
      <config>
        <untagged-interface-name>WORD</untagged-interface-name>
      </config>
      <arp-nd-flood-suppress><!-- operation="delete"-->
    </untagged-access-interface>
  </untagged-access-interfaces>
</vxlan>
```

```

</untagged-access-interface>
</untagged-access-interfaces>
</vxlan>

```

Command Syntax

```
arp-nd flood-suppress
```

Configure garp gna enable

Use this attribute to allow garp-gna packets advertisement

This command is supported when following feature are disabled DNX feature

Attribute Name: garp-gna-enable

Attribute Type: empty

Netconf edit-config payload

```

<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
<untagged-access-interfaces>
<untagged-access-interface>
  <untagged-interface-name>WORD</untagged-interface-name>
  <config>
    <untagged-interface-name>WORD</untagged-interface-name>
  </config>
</garp-gna-enable><!-- operation="delete"-->
</untagged-access-interface>
</untagged-access-interfaces>
</vxlan>

```

Command Syntax

```
garp-gna enable
```

Configure arp cache disable

Use this attribute to disable the ARP cache for MAC/IP. When the ARP cache is disabled on a VxLAN access port, ZebOS-XP does not reply to any ARP arriving on this port from the cache. ZebOS-XP withdraws all MAC/IPs configured/learned on this access port and removes the MAC/IP entry for this access port from the local ARP cache. ZebOS-XP also makes sure that on withdrawing the MAC/IP route, the MAC does not become unknown. If all routes for this MAC are being withdrawn because of this command, then ZebOS-XP advertises a MAC-only route. This is done so that the MAC does not become unknown and only the cache functionality becomes disabled. See also `nvo vxlan max-cache-disable`. Use the `no` form of this command to enable ARP cache for MAC/IP. Note: On enabling the cache, an IP will be in conflict, then the cache enable will fail. The conflict has to be manually removed and then the cache enabled.

This command is supported when following feature are disabled DNX feature

Attribute Name: arp-cache-disable

Attribute Type: empty

Netconf edit-config payload

```

<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
<untagged-access-interfaces>

```

```
<untagged-access-interface>
  <untagged-interface-name>WORD</untagged-interface-name>
  <config>
    <untagged-interface-name>WORD</untagged-interface-name>
  </config>
</cache>
<config>
  </arp-cache-disable><!-- operation="delete"-->
</config>
</cache>
</untagged-access-interface>
</untagged-access-interfaces>
</vxlan>
```

Command Syntax

```
arp-cache disable
```

Configure nd cache disable

Use this attribute to disable ND cache for MAC/IPv6. When the ARP cache is disabled on a VxLAN access port, ZebOS-XP does not reply to any ARP arriving on this port from the cache. ZebOS-XP withdraws all MAC/IPs configured/learned on this access port and removes the MAC/IP entry for this access port from the local ARP cache. ZebOS-XP also makes sure that on withdrawing the MAC/IP route, the MAC does not become unknown. If all routes for this MAC are being withdrawn because of this command, then ZebOS-XP advertises a MAC-only route. This is done so that the MAC does not become unknown and only the cache functionality becomes disabled. Use the no form of this command to enable ND cache for MAC/IPv6. Note: On enabling the cache, an IP will be in conflict, then the cache enable will fail. The conflict has to be manually removed and then the cache enabled.

This command is supported when following feature are disabled DNX feature

Attribute Name: nd-cache-disable

Attribute Type: empty

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <untagged-access-interfaces>
    <untagged-access-interface>
      <untagged-interface-name>WORD</untagged-interface-name>
      <config>
        <untagged-interface-name>WORD</untagged-interface-name>
      </config>
    </cache>
    <config>
      </nd-cache-disable><!-- operation="delete"-->
    </config>
  </cache>
</untagged-access-interface>
</untagged-access-interfaces>
</vxlan>
```


Command Syntax

```
nd-cache disable
```

Configure ipv4 address

Use this attribute to know MAC address of the host

Attribute Name: mac-address

Attribute Type: string

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <untagged-access-interfaces>
    <untagged-access-interface>
      <untagged-interface-name>WORD</untagged-interface-name>
      <config>
        <untagged-interface-name>WORD</untagged-interface-name>
      </config>
    </untagged-access-interface>
  </untagged-access-interfaces>
  <host-macs-ipv4>
    <host-mac-ipv4> <!-- operation="delete"-->
      <ipv4-address>A.B.C.D</ipv4-address>
      <config>
        <ipv4-address>A.B.C.D</ipv4-address>
        <mac-address>CML_MAC_ADDR_T</mac-address>
      </config>
    </host-mac-ipv4>
  </host-macs-ipv4>
</vxlan>
```

Command Syntax

```
mac (XX-XX-XX-XX-XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) ip IP-ADDRESS
```

Configure ipv6 address

Use this attribute to know MAC address of the host

Attribute Name: mac-address

Attribute Type: string

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <untagged-access-interfaces>
    <untagged-access-interface>
      <untagged-interface-name>WORD</untagged-interface-name>
      <config>
        <untagged-interface-name>WORD</untagged-interface-name>
      </config>
    </untagged-access-interface>
  </untagged-access-interfaces>
</vxlan>
```

```

<host-macs-ipv6>
<host-mac-ipv6> <!-- operation="delete"-->
  <ipv6-address>X:X::X:X</ipv6-address>
  <config>
    <ipv6-address>IP-ADDRESS</ipv6-address>
    <mac-address>XX-XX-XX-XX-XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</mac-address>
  </config>
  <mac-address>CML_MAC_ADDR_T</mac-address>
</host-mac-ipv6>
</host-macs-ipv6>
</untagged-access-interface>
</untagged-access-interfaces>
</vxlan>

```

Command Syntax

```
mac (XX-XX-XX-XX-XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) ipv6 IP-ADDRESS
```

Configure profile map type

Use this attribute to map the profile type for which qos profile is already created globally to access port

This command is supported when following feature are enabled QOS feature and following feature are disabled DNX feature

Attribute Name: profile-map-type

Attribute Type: enum (cos-to-queue|queue-color-to-cos)

Attribute Name: profile-name

Attribute Type: string

Netconf edit-config payload

```

<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
<untagged-access-interfaces>
<untagged-access-interface>
  <untagged-interface-name>WORD</untagged-interface-name>
  <config>
    <untagged-interface-name>WORD</untagged-interface-name>
  </config>
<access-interface-qos-type-mappings>
<access-interface-qos-type-mapping> <!-- operation="delete"-->
  <profile-map-type>cos-to-queue</profile-map-type>
  <config>
    <profile-map-type>cos-to-queue</profile-map-type>
    <profile-name>NAME</profile-name>
  </config>
</access-interface-qos-type-mapping>
</access-interface-qos-type-mappings>
</untagged-access-interface>
</untagged-access-interfaces>
</vxlan>

```

Command Syntax

```
map qos-profile (cos-to-queue|queue-color-to-cos) NAME
```

Configure vlan identifier

Use this attribute to map a VLAN on physical interface to identify the tenant traffic and to enter NVO access interface mode

This command is supported when following feature are disabled DNX feature

Attribute Name: vlan-identifier

Attribute Type: string

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <tagged-access-interfaces>
    <tagged-access-interface> <!-- operation="delete"-->
      <vlan-identifier>VLAN_RANGE</vlan-identifier>
      <config>
        <vlan-identifier>VLAN_RANGE</vlan-identifier>
        <interface-name>WORD</interface-name>
      </config>
    </tagged-access-interface>
  </tagged-access-interfaces>
</vxlan>
```

Command Syntax

```
nvo vxlan access-if port-vlan IFNAME VLAN_RANGE
```

Configure tag protocol identifier

Use this attribute to set the Tpid for the outer vlan. 0x88A8: IEEE 802.1ad Provider Bridging and 0x9100: IEEE 802.1Q VLAN-tagged frame with double tagging

This command is supported when following feature are disabled DNX feature

Attribute Name: tag-protocol-identifier

Attribute Type: string

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <tagged-access-interfaces>
    <tagged-access-interface>
      <vlan-identifier>VLAN_RANGE</vlan-identifier>
      <config>
        <vlan-identifier>VLAN_RANGE</vlan-identifier>
        <interface-name>WORD</interface-name>
      </config>
    </tagged-access-interface>
  </tagged-access-interfaces>
</vxlan>
```

```
-> <tag-protocol-identifier>TPID</tag-protocol-identifier> <!-- operation="delete"-  
</tagged-access-interface>  
</tagged-access-interfaces>  
</vxlan>
```

Command Syntax

```
encapsulation TPID
```

Configure interface name

Use this attribute to shutdown vxlan access interface

This command is supported when following feature are disabled DNX feature

Attribute Name: admin-shutdown

Attribute Type: empty

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">  
<tagged-access-interfaces>  
<tagged-access-interface>  
  <vlan-identifier>VLAN_RANGE</vlan-identifier>  
  <config>  
    <vlan-identifier>VLAN_RANGE</vlan-identifier>  
    <interface-name>WORD</interface-name>  
  </config>  
  <interface-name>WORD</interface-name>  
  </admin-shutdown><!-- operation="delete"-->  
</tagged-access-interface>  
</tagged-access-interfaces>  
</vxlan>
```

Command Syntax

```
shutdown
```

Configure profile name

Use this attribute to map the profile type for which qos profile is already created globally to access port

This command is supported when following feature are enabled QOS feature and following feature are disabled DNX feature

Attribute Name: profile-map-type

Attribute Type: enum (cos-to-queue|queue-color-to-cos)

Attribute Name: profile-name

Attribute Type: string

Netconf edit-config payload

```
<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">  
<tagged-access-interfaces>
```

```

<tagged-access-interface>
  <vlan-identifier>VLAN_RANGE</vlan-identifier>
  <config>
    <vlan-identifier>VLAN_RANGE</vlan-identifier>
    <interface-name>WORD</interface-name>
  </config>
  <interface-name>WORD</interface-name>
</access-interface-qos-type-mappings>
<access-interface-qos-type-mapping> <!-- operation="delete"-->
  <profile-map-type>cos-to-queue</profile-map-type>
  <config>
    <profile-map-type>cos-to-queue</profile-map-type>
    <profile-name>NAME</profile-name>
  </config>
</access-interface-qos-type-mapping>
</access-interface-qos-type-mappings>
</tagged-access-interface>
</tagged-access-interfaces>
</vxlan>

```

Command Syntax

```
map qos-profile (cos-to-queue|queue-color-to-cos) NAME
```

Configure inner vlan identifier

Use this attribute to map VLAN'S on an interface to identify the tenant traffic and to enter NVO access interface mode

This command is supported when following feature are disabled DNX feature

Attribute Name: inner-vlan-identifier

Attribute Type: uint32

Attribute Range: 2-4094

Netconf edit-config payload

```

<vxlan xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <double-tagged-access-interfaces>
  <double-tagged-access-interface> <!-- operation="delete"-->
    <inner-vlan-identifier>2</inner-vlan-identifier>
    <config>
      <inner-vlan-identifier>2</inner-vlan-identifier>
      <vlan-identifier>VLAN_RANGE</vlan-identifier>
      <interface-name>WORD</interface-name>
    </config>
    <vlan-identifier>VLAN_RANGE</vlan-identifier>
    <interface-name>WORD</interface-name>
  </double-tagged-access-interface>
</double-tagged-access-interfaces>
</vxlan>

```

Command Syntax

```
nvo vxlan access-if port-vlan IFNAME VLAN_RANGE inner-vlan <2-4094>
```

clear mac address-table dynamic vxlan

Netconf RPC payload

```
<clear-nvo-vxlan-dynamic-mac-address-table xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan"/>
```

Command Syntax

```
clear mac address-table dynamic vxlan
```

clear mac address-table dynamic vxlan vnid <1-16777215> (address MACADDR|)

Attribute Name: vxlan-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Attribute Name: mac-address

Attribute Type: string

Netconf RPC payload

```
<clear-nvo-vxlan-dynamic-mac-address-table-vnid xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">  
  <vxlan-identifier>1</vxlan-identifier>  
  <mac-address>MACADDR</mac-address>  
</clear-nvo-vxlan-dynamic-mac-address-table-vnid>
```

Command Syntax

```
clear mac address-table dynamic vxlan vnid <1-16777215> (address MACADDR|)
```

clear nvo vxlan tunnels

Netconf RPC payload

```
<clear-nvo-vxlan-tunnels xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan"/>
```

Command Syntax

```
clear nvo vxlan tunnels
```

clear nvo vxlan tunnels dst-ip A.B.C.D

Attribute Name: destination-vtep-ip

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<clear-nvo-id-vxlan-tunnels-destip xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-vxlan">
  <destination-vtep-ip>A.B.C.D</destination-vtep-ip>
</clear-nvo-id-vxlan-tunnels-destip>
```

Command Syntax

```
clear nvo vxlan tunnels dst-ip A.B.C.D
```

clear nvo vxlan mac-stale-entries (vnid <1-16777215>|)

Attribute Name: vxlan-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf RPC payload

```
<clear-nvo-vxlan-mac-stale-entries xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-vxlan">
  <vxlan-identifier>1</vxlan-identifier>
</clear-nvo-vxlan-mac-stale-entries>
```

Command Syntax

```
clear nvo vxlan mac-stale-entries (vnid <1-16777215>|)
```

clear nvo vxlan counters access-port port IFNAME

Attribute Name: interface-name

Attribute Type: string

Netconf RPC payload

```
<clear-vxlan-untagged-access-port-counters xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-vxlan">
  <interface-name>IFNAME</interface-name>
</clear-vxlan-untagged-access-port-counters>
```

Command Syntax

```
clear nvo vxlan counters access-port port IFNAME
```

clear nvo vxlan counters access-port port-vlan IFNAME VLAN_RANGE

Attribute Name: interface-name

Attribute Type: string

Attribute Name: vlan-identifier

Attribute Type: string

Netconf RPC payload

```
<clear-vxlan-single-tagged-access-port-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <interface-name>IFNAME</interface-name>
  <vlan-identifier>VLAN_RANGE</vlan-identifier>
</clear-vxlan-single-tagged-access-port-counters>
```

Command Syntax

```
clear nvo vxlan counters access-port port-vlan IFNAME VLAN_RANGE
```

clear nvo vxlan counters access-port port-vlan IFNAME outer-vlan <2-4094> inner-vlan <2-4094>

Attribute Name: interface-name

Attribute Type: string

Attribute Name: outer-vlan-identifier

Attribute Type: uint32

Attribute Range: 2-4094

Attribute Name: inner-vlan-identifier

Attribute Type: uint32

Attribute Range: 2-4094

Netconf RPC payload

```
<clear-vxlan-double-tagged-access-port-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan">
  <interface-name>IFNAME</interface-name>
  <outer-vlan-identifier>outer-vlan</outer-vlan-identifier>
  <inner-vlan-identifier>inner-vlan</inner-vlan-identifier>
</clear-vxlan-double-tagged-access-port-counters>
```

Command Syntax

```
clear nvo vxlan counters access-port port-vlan IFNAME outer-vlan <2-4094> inner-
vlan <2-4094>
```

clear nvo vxlan counters access-port all

Netconf RPC payload

```
<clear-vxlan-access-port-counters-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-vxlan"/>
```

Command Syntax

```
clear nvo vxlan counters access-port all
```

clear nvo vxlan counters network-port dst A.B.C.D

Attribute Name: destination-vtep-ip

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<clear-vxlan-network-port-counters xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-vxlan">
  <destination-vtep-ip>A.B.C.D</destination-vtep-ip>
</clear-vxlan-network-port-counters>
```

Command Syntax

```
clear nvo vxlan counters network-port dst A.B.C.D
```

clear nvo vxlan counters network-port all

Netconf RPC payload

```
<clear-vxlan-network-port-counters-all xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-vxlan"/>
```

Command Syntax

```
clear nvo vxlan counters network-port all
```

IPI-ETHERNET-VPN

Configure esi hold time

Use this attribute to set time before ESI can be made up on enabling evpn

Attribute Name: esi-hold-time

Attribute Type: uint32

Attribute Range: 10-300

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <multi-homing>
    <config>
      <esi-hold-time>10</esi-hold-time> <!-- operation="delete"-->
    </config>
  </multi-homing>
</evpn>
```

Command Syntax

```
evpn esi hold-time <10-300>
```

Configure enable vxlan multihoming

Use this attribute to enable multihoming module on vxlan. Without this attribute multihomig functionality can not be achieved

Attribute Name: enable-vxlan-multihoming

Attribute Type: uint8

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <global>
    <config>
      </enable-vxlan-multihoming><!-- operation="delete"-->
    </config>
  </global>
</evpn>
```

Command Syntax

```
evpn multihoming enable
```

Configure enable evpn mpls multihoming

Use this attribute to enable multihoming module on evpn mpls. Without this attribute multihomig functionality can not be achieved

Attribute Name: enable-evpn-mpls-multihoming

Attribute Type: empty

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <global>
    <config>
      </enable-evpn-mpls-multihoming><!-- operation="delete"-->
    </config>
  </global>
</evpn>
```

Command Syntax

```
evpn mpls multihoming enable
```

Configure enable evpn srv6 multihoming

Use this attribute to enable multihoming module on EVPN SRv6. Without this attribute multihomig functionality can not be achieved

Attribute Name: enable-evpn-srv6-multihoming

Attribute Type: empty

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <global>
    <config>
      </enable-evpn-srv6-multihoming><!-- operation="delete"-->
    </config>
  </global>
```

```
</evpn>
```

Command Syntax

```
evpn srv6 multihoming enable
```

Configure enable irb

Use this attribute to enable integrated routing and bridging module. Without this attribute IRB functionality can not be achieved

Attribute Name: enable-irb

Attribute Type: empty

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <global>
    <config>
      </enable-irb><!-- operation="delete"-->
    </config>
  </global>
</evpn>
```

Command Syntax

```
nvo vxlan irb
```

Configure enable mpls irb

Use this attribute to enable integrated routing and bridging module. Without this attribute IRB functionality can not be achieved

Attribute Name: enable-mpls-irb

Attribute Type: empty

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <global>
    <config>
      </enable-mpls-irb><!-- operation="delete"-->
    </config>
  </global>
</evpn>
```

Command Syntax

```
evpn mpls irb
```

Configure mac address

Use this attribute to configure common anycast mac-address for all IRB interfaces

Attribute Name: mac-address

Attribute Type: string

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <irb-forwarding>
    <config>
      <mac-address>XX-XX-XX-XX-XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</mac-address>
<!-- operation="delete"-->
    </config>
  </irb-forwarding>
</evpn>
```

Command Syntax

```
evpn irb-forwarding anycast-gateway-mac (XX-XX-XX-XX-XX-
  XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX)
```

Configure gateway mac

Use this attribute to configure anycast mac-address for an IRB interface

Attribute Name: gateway-mac

Attribute Type: empty

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <irb-forwarding>
    <irb-interfaces>
      <irb-interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </gateway-mac><!-- operation="delete"-->
      </irb-interface>
    </irb-interfaces>
  </irb-forwarding>
</evpn>
```

Command Syntax

```
evpn irb-if-forwarding anycast-gateway-mac
```

Configure redundancy mode

Use this attribute to configure load balancing type

Attribute Name: redundancy-mode

Attribute Type: enum (single-active|port-active)

Attribute Name: evpn-segment-id

Attribute Type: string

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
    <evpn-segment-id>XX:XX:XX:XX:XX:XX:XX:XX</evpn-segment-id>
  </config>
  <redundancy-mode>single-active</redundancy-mode>
</interface>
</interfaces>
</evpn>
```

Command Syntax

```
evpn multi-homed esi XX:XX:XX:XX:XX:XX:XX:XX (load-balancing (single-
active|port-active) |)
```

Configure name

Use this attribute to configure load balancing type

Attribute Name: redundancy-mode

Attribute Type: enum (single-active|port-active)

Attribute Name: system-mac

Attribute Type: string

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
    <system-mac>XX-XX-XX-XX-XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</system-mac>
  </config>
  <redundancy-mode>single-active</redundancy-mode>
</interface>
</interfaces>
</evpn>
```

Command Syntax

```
evpn multi-homed system-mac (XX-XX-XX-XX-XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX)
(load-balancing (single-active|port-active) |)
```

Configure service carving

Use this attribute to create or delete service-carving configuration

Attribute Name: service-carving

Attribute Type: enum (preference-based|auto|off)

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <mh-load-balance-esi>
    <config>
      <service-carving>preference-based</service-carving>
    </config>
    </mh-load-balance-esi>
  </interface>
</interfaces>
</evpn>
```

Command Syntax

```
service-carving (preference-based|auto|off)
```

Configure preference weight

Use this attribute to add preference to which should be elected as DF

Attribute Name: preference-weight

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <mh-load-balance-esi>
    <config>
      <preference-weight>1</preference-weight> <!-- operation="delete"-->
    </config>
    </mh-load-balance-esi>
  </interface>
</interfaces>
</evpn>
```

Command Syntax

```
service-carving weight <1-65535>
```

Configure no preempt

Use this attribute to set revertive DF capability

Attribute Name: no-preempt

Attribute Type: empty

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <mh-load-balance-esi>
      <config>
        </no-preempt><!-- operation="delete"-->
      </config>
    </mh-load-balance-esi>
  </interface>
</interfaces>
</evpn>
```

Command Syntax

```
service-carving dont-preempt
```

Configure ac driven

Use this attribute to set AC Influenced DF capability

Attribute Name: ac-driven

Attribute Type: empty

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <mh-load-balance-esi>
      <config>
        </ac-driven><!-- operation="delete"-->
      </config>
    </mh-load-balance-esi>
  </interface>
</interfaces>
</evpn>
```

```
</interface>
</interfaces>
</evpn>
```

Command Syntax

```
service-carving ac-driven
```

Configure access if

evpn-mpIs access port

This command is supported when following feature are enabled Sub Interface feature,NVO feature

Attribute Name: access-if

Attribute Type: enum (access-if|access-if-evpn)

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <access-interfaces>
    <access-interface> <!-- operation="delete"-->
      <access-if>access-if</access-if>
      <config>
        <access-if>access-if</access-if>
      </config>
    </access-interface>
    </access-interfaces>
  </interface>
</interfaces>
</evpn>
```

Command Syntax

```
(access-if-evpn)
```

Configure evpn identifier

Map already created tenant id

Attribute Name: evpn-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <interfaces>
```



```

<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<access-interfaces>
<access-interface>
  <access-if>access-if</access-if>
  <config>
    <access-if>access-if</access-if>
  </config>
  <evpn-identifier>1</evpn-identifier> <!-- operation="delete"-->
</access-interface>
</access-interfaces>
</interface>
</interfaces>
</evpn>

```

Command Syntax

```
map evpn mpls id <1-16777215>
```

Configure dynamic learning disable

Use this attribute to disable dynamic learning of MACs and MAC/IP at the access port

This command is supported when following feature are enabled Sub Interface feature,NVO feature

Attribute Name: dynamic-learning-disable

Attribute Type: empty

Netconf edit-config payload

```

<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <interfaces>
  <interface>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
  <access-interfaces>
  <access-interface>
    <access-if>access-if</access-if>
    <config>
      <access-if>access-if</access-if>
    </config>
    </dynamic-learning-disable><!-- operation="delete"-->
  </access-interface>
  </access-interfaces>
  </interface>
  </interfaces>
</evpn>

```

Command Syntax

```
dynamic-learning disable
```

Configure arp nd flood suppress

Use this attribute to restrict the flood of ARP/ND packets towards remote VTEPs or other access ports

This command is supported when following feature are enabled Sub Interface feature,NVO feature

Attribute Name: arp-nd-flood-suppress

Attribute Type: empty

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <access-interfaces>
      <access-interface>
        <access-if>access-if</access-if>
        <config>
          <access-if>access-if</access-if>
        </config>
        </arp-nd-flood-suppress><!-- operation="delete"-->
      </access-interface>
    </access-interfaces>
  </interface>
</interfaces>
</evpn>
```

Command Syntax

```
arp-nd flood-suppress
```

Configure arp cache disable

Use this attribute to disable the ARP cache for MAC/IP

This command is supported when following feature are enabled Sub Interface feature,NVO feature

Attribute Name: arp-cache-disable

Attribute Type: empty

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
```

```

    <name>WORD</name>
  </config>
</access-interfaces>
<access-interface>
  <access-if>access-if</access-if>
  <config>
    <access-if>access-if</access-if>
  </config>
  </arp-cache-disable><!-- operation="delete"-->
</access-interface>
</access-interfaces>
</interface>
</interfaces>
</evpn>

```

Command Syntax

```
arp-cache disable
```

Configure nd cache disable

Use this attribute to disable ND-cache on access interface

This command is supported when following feature are enabled Sub Interface feature,NVO feature

Attribute Name: nd-cache-disable

Attribute Type: empty

Netconf edit-config payload

```

<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
  <access-interfaces>
    <access-interface>
      <access-if>access-if</access-if>
      <config>
        <access-if>access-if</access-if>
      </config>
      </nd-cache-disable><!-- operation="delete"-->
    </access-interface>
  </access-interfaces>
</interface>
</interfaces>
</evpn>

```

Command Syntax

```
nd-cache disable
```

Configure mac hold time

Use this attribute to set the time a host MAC entry will persist after unconfig

This command is supported when following feature are enabled Sub Interface feature,NVO feature

Attribute Name: mac-hold-time

Attribute Type: int16

Default Value: 0

Attribute Range: -1-300

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <access-interfaces>
      <access-interface>
        <access-if>access-if</access-if>
        <config>
          <access-if>access-if</access-if>
        </config>
        <mac-hold-time>-1</mac-hold-time> <!-- operation="delete"-->
      </access-interface>
    </access-interfaces>
  </interface>
</interfaces>
</evpn>
```

Command Syntax

```
mac-holdtime <-1-300>
```

Configure garp gna enable

Use this attribute to allow garp-gna packets advertisement

This command is supported when following feature are enabled Sub Interface feature,NVO feature

Attribute Name: garp-gna-enable

Attribute Type: empty

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
```

```

    <name>WORD</name>
  </config>
</access-interfaces>
<access-interface>
  <access-if>access-if</access-if>
  <config>
    <access-if>access-if</access-if>
  </config>
  </garp-gna-enable><!-- operation="delete"-->
</access-interface>
</access-interfaces>
</interface>
</interfaces>
</evpn>

```

Command Syntax

```
garp-gna enable
```

Configure ipv4 address

Use this attribute to configure static MAC address of the host

Attribute Name: mac-address

Attribute Type: string

Netconf edit-config payload

```

<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
  <access-interfaces>
    <access-interface>
      <access-if>access-if</access-if>
      <config>
        <access-if>access-if</access-if>
      </config>
      <ipv4-host-mac-mappings>
        <ipv4-host-mac-mapping> <!-- operation="delete"-->
          <ipv4-address>A.B.C.D</ipv4-address>
          <config>
            <ipv4-address>A.B.C.D</ipv4-address>
            <mac-address>CML_MAC_ADDR_T</mac-address>
          </config>
          <mac-address>CML_MAC_ADDR_T</mac-address>
        </ipv4-host-mac-mapping>
      </ipv4-host-mac-mappings>
    </access-interface>
  </access-interfaces>
</evpn>

```

```
</access-interfaces>  
</interface>  
</interfaces>  
</evpn>
```

Command Syntax

```
mac (XX-XX-XX-XX-XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) ip IP-ADDRESS
```

Configure ipv6 address

Use this attribute to configure static MAC address of the host

Attribute Name: mac-address

Attribute Type: string

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">  
<interfaces>  
<interface>  
  <name>WORD</name>  
  <config>  
    <name>WORD</name>  
  </config>  
<access-interfaces>  
<access-interface>  
  <access-if>access-if</access-if>  
  <config>  
    <access-if>access-if</access-if>  
  </config>  
<ipv6-host-mac-mappings>  
<ipv6-host-mac-mapping> <!-- operation="delete"-->  
  <ipv6-address>IPv6-ADDRESS</ipv6-address>  
  <config>  
    <ipv6-address>IPv6-ADDRESS</ipv6-address>  
    <mac-address>XX-XX-XX-XX-XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</mac-  
address>  
  </config>  
    <mac-address>CML_MAC_ADDR_T</mac-address>  
  </ipv6-host-mac-mapping>  
</ipv6-host-mac-mappings>  
</access-interface>  
</access-interfaces>  
</interface>  
</interfaces>  
</evpn>
```

Command Syntax

```
mac (XX-XX-XX-XX-XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) ipv6 IPv6-ADDRESS
```

Configure service type

Use this attribute to configure Vlan-Based EVPN-Service Type

Attribute Name: service-type

Attribute Type: enum (vlan-based|vlan-aware-bundle)

Netconf edit-config payload

```
<evpn xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ethernet-vpn">
  <vrfs>
    <vrf>
      <vrf-name>WORD</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
      </config>
      <service-type>vlan-based</service-type> <!-- operation="delete"-->
    </vrf>
  </vrfs>
</evpn>
```

Command Syntax

```
evpn-vlan-service (vlan-based|vlan-aware-bundle)
```

IPI-TFO

Configure admin status

Use this attribute to enable or disable trigger failover (TFO).TFO can be enabled only if the bridge mode is STP or RSTP.

Attribute Name: admin-status

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<trigger-failover xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tfo">
  <config>
    <admin-status>disable</admin-status> <!-- operation="delete"-->
  </config>
</trigger-failover>
```

Command Syntax

```
tfo (disable|enable)
```

Configure name

Use this attribute to map links in a FOG.

Attribute Name: name

Attribute Type: string

Attribute Name: link-type

Attribute Type: enum (uplink|downlink)

Netconf edit-config payload

```
<trigger-failover xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tfo">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
        <link-type>uplink</link-type>
      </config>
    </interface>
  </interfaces>
</trigger-failover>
```

Command Syntax

```
link-type (uplink|downlink)
```

Configure group id

Use this attribute to map links in a FOG.

Attribute Name: name

Attribute Type: string

Attribute Name: group-id

Attribute Type: uint32

Attribute Range: 1-64

Attribute Name: group-type

Attribute Type: enum (mpg|cpg)

Netconf edit-config payload

```
<trigger-failover xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tfo">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  <tfo-groups>
    <tfo-group>
      <group-id>1</group-id>
      <config>
        <group-type>mpg</group-type>
      </config>
    </tfo-group>
  </tfo-groups>
</trigger-failover>
```



```
</tfo-groups>
</interface>
</interfaces>
</trigger-failover>
```

Command Syntax

```
fog <1-64> type (mpg|cpg)
```

Configure failover trigger count

Use this attribute to set the number of links to trigger failover for a Monitor Port Groups (MPG).

Attribute Name: failover-trigger-count

Attribute Type: uint32

Attribute Range: 0-63

Netconf edit-config payload

```
<trigger-failover xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tfo">
  <failover-groups>
    <failover-group>
      <group-id>1</group-id>
      <config>
        <group-id>1</group-id>
      </config>
      <failover-trigger-count>0</failover-trigger-count> <!-- operation="delete"-->
    </failover-group>
  </failover-groups>
</trigger-failover>
```

Command Syntax

```
fog <1-64> tfc <0-63>
```

clear tfo counter

Netconf RPC payload

```
<tfo-clear-counters-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tfo"/>
```

Command Syntax

```
clear tfo counter
```

clear tfo counter fog <1-64>

Attribute Name: group-id

Attribute Type: uint32

Attribute Range: 1-64

Netconf RPC payload

```
<tfo-clear-fog-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tfo">
  <group-id>1</group-id>
</tfo-clear-fog-counters>
```

Command Syntax

```
clear tfo counter fog <1-64>
```

IPI-LOGGING

Configure severity level

Use this attribute to set the severity level that a message for a specific module must reach before the messages is logged. Default value is 2-critical.

Attribute Name: severity-level

Attribute Type: enum (0|1|2|3|4|5|6|7)

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <logging-modules>
  <module-logging>
    <module-name>auth</module-name>
    <config>
      <module-name>auth</module-name>
    </config>
    <severity-level>2</severity-level>
  </module-logging>
</logging-modules>
</logging>
```

Command Syntax

```
logging level
(auth|bgp|cmm|hostp|hsl|isis|ldp|lag|l2mrib|mstp|mrrib|nsm|onm|oam|ospf|ospf6|ptp
|rip|pim|rib|vrrp|sflow|rsvp|pserv|cml|ndd|ripng|vlog|all|synce|pcep|udld)
((0|1|2|3|4|5|6|7)|)
```

Configure enable logging

Use this attribute to set severity level of logging monitor. Default value is 7-debug-details.

Attribute Name: severity-level

Attribute Type: enum (0|1|2|3|4|5|6|7)

Default Value: 7

Attribute Name: enable-logging

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <monitor-logging>
  <config>
    <enable-logging>enable</enable-logging> <!-- operation="delete"-->
    <severity-level>7</severity-level> <!-- operation="delete"-->
  </config>
</monitor-logging>
</logging>
```

Command Syntax

```
logging monitor ((disable)|) ((0|1|2|3|4|5|6|7)|)
```

Configure max file size

Set size of the log file in bytes. Default value is 419430400 bytes.

Attribute Name: max-file-size

Attribute Type: uint32

Attribute Range: 4096-419430400

Attribute Name: file-name

Attribute Type: string

Attribute Name: severity-level

Attribute Type: enum (0|1|2|3|4|5|6|7)

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <logfile>
  <config>
    <file-name>LOGFILENAME</file-name>
    <severity-level>6</severity-level>
    <max-file-size>4096</max-file-size>
  </config>
</logfile>
</logging>
```

Command Syntax

```
logging logfile LOGFILENAME (0|1|2|3|4|5|6|7) (size <4096-419430400>|)
```

Configure file name

Set size of the debug log file in bytes. The default value is 4194304 bytes.

Attribute Name: max-file-size

Attribute Type: uint32

Attribute Range: 4096-4194304

Attribute Name: file-name

Attribute Type: string

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <debug-logfile>
  <config>
    <file-name>LOGFILE</file-name>
    <max-file-size>4096</max-file-size>
  </config>
</debug-logfile>
</logging>
```

Command Syntax

```
debug logfile LOGFILE size <4096-4194304>
```

Configure enable syslog

Use this attribute to begin logging of information to the system log and set the level to debug.

This command is supported when following feature are enabled syslog feature

Attribute Name: enable-syslog

Attribute Type: empty

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <syslog>
  <config>
    </enable-syslog><!-- operation="delete"-->
  </config>
</syslog>
</logging>
```

Command Syntax

```
log syslog
```

Configure timestamp granularity

Use this attribute to set the logging timestamp granularity.

This command is supported when following feature are enabled syslog feature

Attribute Name: timestamp-granularity

Attribute Type: enum (none|microseconds|milliseconds|seconds)

Default Value: milliseconds

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <syslog>
  <config>
```

```
    <timestamp-granularity>milliseconds</timestamp-granularity> <!--
operation="delete"-->
  </config>
</syslog>
</logging>
```

Command Syntax

```
logging timestamp (none|microseconds|milliseconds|seconds|)
```

Configure disable all modules debug

Use this attribute to unset debug globally

Attribute Name: disable-all-modules-debug

Attribute Type: empty

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <global>
  <config>
    </disable-all-modules-debug><!-- operation="delete"-->
  </config>
</global>
</logging>
```

Command Syntax

```
no debug all
```

no debug all

Netconf RPC payload

```
<terminal-debug-all-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging"/>
```

Command Syntax

```
no debug all
```

clear debug logfile

Netconf RPC payload

```
<logging-clear-debug-logfile xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging"/>
```

Command Syntax

```
clear debug logfile
```

clear logging logfile

Netconf RPC payload

```
<logging-clear-logging-logfile xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging"/>
```

Command Syntax

```
clear logging logfile
```

remove file (techsupport) (all|FILENAME)

Attribute Name: file_type

Attribute Type: enum (techsupport)

Attribute Name: filename

Attribute Type: union

Netconf RPC payload

```
<remove-file xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <file_type>techsupport</file_type>
  <filename>FILE_TYPE_T</filename>
</remove-file>
```

Command Syntax

```
remove file (techsupport) (all|FILENAME)
```

IPI-LOGGING-REMOTE

Configure enable

This attribute enables/disables the logging host debug.

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <debug>
  <config>
    </enable><!-- operation="delete"-->
  </config>
</debug>
</logging>
```

Command Syntax

```
debug logging host
```

Configure enable rsyslog

Enable/disable the rsyslog feature

Attribute Name: enable-rsyslog

Attribute Type: boolean

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <remote-logging>
  <rsyslog>
    <vrf>management</vrf>
    <config>
      <vrf>management</vrf>
    </config>
    <enable-rsyslog>true</enable-rsyslog> <!-- operation="delete"-->
  </rsyslog>
</remote-logging>
</logging>
```

Command Syntax

```
feature rsyslog (vrf management|)
```

Configure vrf

Enable/disable the rsyslog feature

Attribute Name: enable-rsyslog

Attribute Type: boolean

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <remote-logging>
  <rsyslog>
    <vrf>management</vrf>
    <config>
      <vrf>management</vrf>
    </config>
    <enable-rsyslog>true</enable-rsyslog> <!-- operation="delete"-->
  </rsyslog>
</remote-logging>
</logging>
```

Command Syntax

```
no feature rsyslog (vrf management|)
```

Configure port

Use this attribute to configure the syslog server UDP port. Default value is 514

Attribute Name: port

Attribute Type: uint16

Attribute Range: 1024-65535

Attribute Name: severity

Attribute Type: enum (0|1|2|3|4|5|6|7)

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <remote-logging>
    <rsyslog>
      <vrf>management</vrf>
      <config>
        <vrf>management</vrf>
      </config>
      <remote-servers>
        <remote-server>
          <address>A.B.C.D</address>
          <config>
            <address>1</address>
            <severity>7</severity> <!-- operation="delete"-->
          </config>
          <port>1024</port> <!-- operation="delete"-->
        </remote-server>
      </remote-servers>
    </rsyslog>
  </remote-logging>
</logging>
```

Command Syntax

```
logging remote server (A.B.C.D|X:X::X:X|HOSTNAME) ((0|1|2|3|4|5|6|7)|) port <1024-65535> (vrf management|)
```

Configure severity

This attribute is used to specify the kind of messages by severity level. The default value is debug-detail. The possible values for levels are as follows: [Operator] 0-emerg; 1-alert; 2-critical; 3-error; 4-notify; 5-info [Debug] 3-error; 4-warning; 5-notif; 6-debug-info; 7-debug-detail

Attribute Name: severity

Attribute Type: enum (0|1|2|3|4|5|6|7)

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <remote-logging>
    <rsyslog>
      <vrf>management</vrf>
      <config>
        <vrf>management</vrf>
      </config>
    </rsyslog>
  </remote-logging>
</logging>
```



```

<remote-servers>
<remote-server>
  <address>A.B.C.D</address>
  <config>
    <address>1</address>
  </config>
  <severity>7</severity>
</remote-server>
</remote-servers>
</rsyslog>
</remote-logging>
</logging>

```

Command Syntax

```
logging remote server (A.B.C.D|X:X::X:X|HOSTNAME) ((0|1|2|3|4|5|6|7)|) (vrf
management|)
```

Configure remote server facility

This attribute is used to specify the facility level used by syslog messages. The default value is local7. The possible values are local0, local1, local2, local3, local4, local5, local6, local7 and user.

Attribute Name: remote-server-facility

Attribute Type: enum (local0|local1|local2|local3|local4|local5|local6|local7|user)

Default Value: local7

Netconf edit-config payload

```

<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
<global>
<config>
  <remote-server-facility>local7</remote-server-facility> <!--
operation="delete"-->
</config>
</global>
</logging>

```

Command Syntax

```
logging remote facility
(local0|local1|local2|local3|local4|local5|local6|local7|user)
```

IPI-LOGGING-CLI

Configure enable logging

Use this attribute to enable/disable CLI history logs. By default CLI history is enabled.

Attribute Name: enable-logging

Attribute Type: empty

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <cli-logging>
  <config>
    </enable-logging><!-- operation="delete"-->
  </config>
</cli-logging>
</logging>
```

Command Syntax

```
logging cli
```

Configure max session limit

Use this attribute to set maximum session limit for vty.

Attribute Name: max-session-limit

Attribute Type: uint8

Attribute Range: 1-40

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <cli-logging>
  <max-session-limit>
  <config>
    <max-session-limit>1</max-session-limit> <!-- operation="delete"-->
  </config>
</max-session-limit>
</cli-logging>
</logging>
```

Command Syntax

```
max-session <1-40>
```

IPI-LOGGING-FAULT-MANAGEMENT

Configure enable fault management

Enable Fault Management System

Attribute Name: enable-fault-management

Attribute Type: uint8

Netconf edit-config payload

```
<logging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-logging">
  <fault-management>
  <config>
```

```
        </enable-fault-management><!-- operation="delete"-->
</config>
</fault-management>
</logging>
```

Command Syntax

```
fault-management enable
```

fault-management flush-db

Netconf RPC payload

```
<ipi-logging-fault-management_logging-fms-flush-db xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-logging"/>
```

Command Syntax

```
fault-management flush-db
```

fault-management shelve ALARM-TYPE

Attribute Name: alarm-type

Attribute Type: string

Netconf RPC payload

```
<ipi-logging-fault-management_logging-fms-shelve xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-logging">
  <alarm-type>ALARM-TYPE</alarm-type>
</ipi-logging-fault-management_logging-fms-shelve>
```

Command Syntax

```
fault-management shelve ALARM-TYPE
```

fault-management close ACTIVE-ALARM-ID

Attribute Name: active-alarm-id

Attribute Type: string

Netconf RPC payload

```
<ipi-logging-fault-management_logging-fms-close xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-logging">
  <active-alarm-id>ACTIVE-ALARM-ID</active-alarm-id>
</ipi-logging-fault-management_logging-fms-close>
```

Command Syntax

```
fault-management close ACTIVE-ALARM-ID
```

IPI-DHCP

Configure disable dhcp feature

Disable the DHCP client and DHCP relay on the device.

Attribute Name: disable-dhcp-feature

Attribute Type: uint8

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <global>
    <config>
      </disable-dhcp-feature><!-- operation="delete"-->
    </config>
  </global>
</dhcp>
```

Command Syntax

```
no feature dhcp
```

IPI-RADIUS

Configure vrf name

VRF Name associated with this instance

This command is supported when following feature are enabled aaa feature

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: key-type

Attribute Type: enum (0|7)

Attribute Name: secret-key-string

Attribute Type: string

Netconf edit-config payload

```
<radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-radius">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
        <key-type>0</key-type> <!-- operation="delete"-->
        <secret-key-string>WORD</secret-key-string> <!-- operation="delete"-->
      </config>
    </vrf>
  </vrfs>
</radius>
```

```

    </config>
  </vrf>
</vrfs>
</radius>

```

Command Syntax

```
radius-server login key (0|7) WORD (vrf management|)
```

Configure timeout

VRF Name associated with this instance

This command is supported when following feature are enabled aaa feature

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: timeout

Attribute Type: uint8

Attribute Range: 1-60

Netconf edit-config payload

```

<radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-radius">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
        <timeout>1</timeout> <!-- operation="delete"-->
      </config>
    </vrf>
  </vrfs>
</radius>

```

Command Syntax

```
radius-server login timeout <1-60> (vrf management|)
```

Configure sequence number

Use this attribute to set the sequence-number/priority index for the RADIUS server

This command is supported when following feature are enabled aaa feature

Attribute Name: sequence-number

Attribute Type: uint8

Attribute Range: 1-8

Netconf edit-config payload

```

<radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-radius">
  <vrfs>
    <vrf>

```

```
<vrf-name>management</vrf-name>
<config>
  <vrf-name>management</vrf-name>
</config>
<remote-servers>
<server>
  <host-address>A.B.C.D</host-address>
  <config>
    <host-address>A.B.C.D</host-address>
  </config>
  <sequence-number>1</sequence-number>
</server>
</remote-servers>
</vrf>
</vrfs>
</radius>
```

Command Syntax

```
radius-server login host (A.B.C.D|X:X::X:X|HOSTNAME) (vrf management|) seq-num <1-8>
```

Configure secret key string

Shared key used between the authentication-server and the device

This command is supported when following feature are enabled aaa feature

Attribute Name: secret-key-string

Attribute Type: string

Attribute Name: sequence-number

Attribute Type: uint8

Attribute Range: 1-8

Attribute Name: key-type

Attribute Type: enum (0|7)

Netconf edit-config payload

```
<radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-radius">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
<remote-servers>
<server>
  <host-address>A.B.C.D</host-address>
  <config>
    <host-address>A.B.C.D</host-address>
    <sequence-number>1</sequence-number> <!-- operation="delete"-->
```

```

    <key-type>0</key-type> <!-- operation="delete"-->
  </config>
  <secret-key-string>WORD</secret-key-string> <!-- operation="delete"-->
</server>
</remote-servers>
</vrf>
</vrfs>
</radius>

```

Command Syntax

```

radius-server login host (A.B.C.D|X:X::X:X|HOSTNAME) (vrf management|) seq-num <1-
8> key (0|7) WORD

```

Configure accounting port

Use this attribute to configure a RADIUS server and specify a UDP port to use for RADIUS accounting messages

This command is supported when following feature are enabled aaa feature

Attribute Name: accounting-port

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: sequence-number

Attribute Type: uint8

Attribute Range: 1-8

Attribute Name: key-type

Attribute Type: enum (0|7)

Attribute Name: secret-key-string

Attribute Type: string

Netconf edit-config payload

```

<radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-radius">
  <vrfs>
  <vrf>
    <vrf-name>management</vrf-name>
    <config>
      <vrf-name>management</vrf-name>
    </config>
  </remote-servers>
  <server>
    <host-address>A.B.C.D</host-address>
    <config>
      <host-address>A.B.C.D</host-address>
      <sequence-number>1</sequence-number> <!-- operation="delete"-->
      <key-type>0</key-type> <!-- operation="delete"-->
      <secret-key-string>WORD</secret-key-string> <!-- operation="delete"-->
    </config>
    <accounting-port>0</accounting-port> <!-- operation="delete"-->
  </server>
  </vrf>
  </vrfs>
</radius>

```

```
</server>
</remote-servers>
</vrf>
</vrfs>
</radius>
```

Command Syntax

```
radius-server login host (A.B.C.D|X:X::X:X|HOSTNAME) (vrf management|) seq-num <1-8> key (0|7) WORD acct-port <0-65535>
```

Configure host address

To represent the timeout configured by the user

This command is supported when following feature are enabled aaa feature

Attribute Name: timeout

Attribute Type: uint8

Default Value: 5

Attribute Range: 1-60

Attribute Name: sequence-number

Attribute Type: uint8

Attribute Range: 1-8

Attribute Name: key-type

Attribute Type: enum (0|7)

Attribute Name: secret-key-string

Attribute Type: string

Attribute Name: accounting-port

Attribute Type: uint16

Attribute Range: 0-65535

Netconf edit-config payload

```
<radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-radius">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <remote-servers>
    <server>
      <host-address>A.B.C.D</host-address>
      <config>
        <host-address>A.B.C.D</host-address>
        <sequence-number>1</sequence-number> <!-- operation="delete"-->
        <key-type>0</key-type> <!-- operation="delete"-->
      </config>
    </server>
  </remote-servers>
</radius>
```



```

        <secret-key-string>WORD</secret-key-string> <!-- operation="delete"-->
        <accounting-port>0</accounting-port> <!-- operation="delete"-->
    </config>
        <timeout>1</timeout> <!-- operation="delete"-->
</server>
</remote-servers>
</vrf>
</vrfs>
</radius>

```

Command Syntax

```
radius-server login host (A.B.C.D|X:X::X:X|HOSTNAME) (vrf management|) seq-num <1-8> key (0|7) WORD acct-port <0-65535> timeout <1-60>
```

Configure authentication port

Use this attribute to configure a RADIUS server and specify a UDP port to use for RADIUS authentication messages

This command is supported when following feature are enabled aaa feature

Attribute Name: authentication-port

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: sequence-number

Attribute Type: uint8

Attribute Range: 1-8

Attribute Name: key-type

Attribute Type: enum (0|7)

Attribute Name: secret-key-string

Attribute Type: string

Netconf edit-config payload

```

<radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-radius">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <remote-servers>
    <server>
      <host-address>A.B.C.D</host-address>
      <config>
        <host-address>A.B.C.D</host-address>
        <sequence-number>1</sequence-number> <!-- operation="delete"-->
        <key-type>0</key-type> <!-- operation="delete"-->
        <secret-key-string>WORD</secret-key-string> <!-- operation="delete"-->
      </config>
    </server>
  </remote-servers>
</radius>

```

```

        <authentication-port>0</authentication-port> <!-- operation="delete"-->
</server>
</remote-servers>
</vrf>
</vrfs>
</radius>

```

Command Syntax

```

radius-server login host (A.B.C.D|X:X::X:X|HOSTNAME) (vrf management|) seq-num <1-
8> key (0|7) WORD auth-port <0-65535>

```

Configure key type

Use this attribute to configure a RADIUS server and specify a UDP port to use for RADIUS accounting messages

This command is supported when following feature are enabled aaa feature

Attribute Name: accounting-port

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: sequence-number

Attribute Type: uint8

Attribute Range: 1-8

Attribute Name: key-type

Attribute Type: enum (0|7)

Attribute Name: secret-key-string

Attribute Type: string

Attribute Name: authentication-port

Attribute Type: uint16

Attribute Range: 0-65535

Netconf edit-config payload

```

<radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-radius">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
</remote-servers>
<server>
  <host-address>A.B.C.D</host-address>
  <config>
    <host-address>A.B.C.D</host-address>
    <sequence-number>1</sequence-number> <!-- operation="delete"-->
    <key-type>0</key-type> <!-- operation="delete"-->
    <secret-key-string>WORD</secret-key-string> <!-- operation="delete"-->
  </config>
</server>
</remote-servers>
</vrfs>
</radius>

```

```

    <authentication-port>0</authentication-port> <!-- operation="delete"-->
  </config>
    <accounting-port>0</accounting-port> <!-- operation="delete"-->
</server>
</remote-servers>
</vrf>
</vrfs>
</radius>

```

Command Syntax

```
radius-server login host (A.B.C.D|X:X::X:X|HOSTNAME) (vrf management|) seq-num <1-8> key (0|7) WORD auth-port <0-65535> acct-port <0-65535>
```

Configure enable

This attribute is to enable/disable RADIUS debug logging

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```

<radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-radius">
  <debug>
  <config>
    </enable><!-- operation="delete"-->
  </config>
</debug>
</radius>

```

Command Syntax

```
debug radius
```

clear radius-server counters (vrf management|)

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```

<radius-clear-all-server-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-radius">
  <vrf-name>management</vrf-name>
</radius-clear-all-server-counters>

```

Command Syntax

```
clear radius-server counters (vrf management|)
```

clear radius-server host (A.B.C.D|X:X::X:X|HOSTNAME) counters (vrf (management|all)|)

Attribute Name: hostname

Attribute Type: union

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<radius-clear-server-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-radius">
  <hostname>A.B.C.D</hostname>
  <vrf-name>management</vrf-name>
</radius-clear-server-counters>
```

Command Syntax

```
clear radius-server host (A.B.C.D|X:X::X:X|HOSTNAME) counters (vrf
(management|all) |)
```

debug radius

Netconf RPC payload

```
<radius-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-radius"/>
```

Command Syntax

```
debug radius
```

no debug radius

Netconf RPC payload

```
<radius-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-radius"/>
```

Command Syntax

```
no debug radius
```

IPI-USER-MANAGEMENT

Configure enable

Use this attribute to enable user management debugging information.

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<user-management xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-management">
  <debug>
  <config>
    </enable><!-- operation="delete"-->
  </config>
  </debug>
</user-management>
```

Command Syntax

```
debug user-mgmt
```

Configure disable default user

Use this attribute to prevent default user from being enabled at start up

Attribute Name: disable-default-user

Attribute Type: empty

Netconf edit-config payload

```
<user-management xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-management">
  <global>
  <config>
    </disable-default-user><!-- operation="delete"-->
  </config>
  </global>
</user-management>
```

Command Syntax

```
username disable-default
```

Configure username

Login name of the user

Attribute Name: username

Attribute Type: string

Attribute Range: 2-32

Netconf edit-config payload

```
<user-management xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-management">
  <users>
  <user> <!-- operation="delete"-->
    <username>USERNAME</username>
  <config>
    <username>USERNAME</username>
  </config>
  </user>
</users>
```

```
</user-management>
```

Command Syntax

```
username USERNAME
```

Configure role

Use this attribute to set the user role. Operations that an user is allowed to perform are determined based on the role

Attribute Name: role

Attribute Type: enum (network-admin|network-engineer|network-operator|network-user)

Netconf edit-config payload

```
<user-management xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-management">
<users>
<user>
  <username>USERNAME</username>
  <config>
    <username>USERNAME</username>
  </config>
  <role>network-admin</role> <!-- operation="delete"-->
</user>
</users>
</user-management>
```

Command Syntax

```
username USERNAME role (network-admin|network-engineer|network-operator|network-
user)
```

Configure password

Use this attribute to add a user or to change a user password.

Attribute Name: password

Attribute Type: string

Attribute Range: 8-32

Attribute Name: role

Attribute Type: enum (network-admin|network-engineer|network-operator|network-user)

Netconf edit-config payload

```
<user-management xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-management">
<users>
<user>
  <username>USERNAME</username>
  <config>
    <username>USERNAME</username>
    <role>network-admin</role> <!-- operation="delete"-->
  </config>
  <password>PASSWORD</password> <!-- operation="delete"-->
</user>
</users>
</user-management>
```

```

</user>
</users>
</user-management>

```

Command Syntax

```

username USERNAME role (network-admin|network-engineer|network-operator|network-
user) password PASSWORD

```

Configure password hashed

Use this attribute to specify user password in encrypted form. This option is provided for reconfiguring a user password using an earlier encrypted password that was available in running configuration display or get-config payload. Users are advised not to use this option for entering passwords generated in any other method

Attribute Name: password-hashed

Attribute Type: string

Attribute Range: 26-106

Attribute Name: role

Attribute Type: enum (network-admin|network-engineer|network-operator|network-user)

Netconf edit-config payload

```

<user-management xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-management">
  <users>
    <user>
      <username>USERNAME</username>
      <config>
        <username>USERNAME</username>
        <role>network-admin</role> <!-- operation="delete"-->
      </config>
      <password-hashed>PASSWORD</password-hashed> <!-- operation="delete"-->
    </user>
  </users>
</user-management>

```

Command Syntax

```

username USERNAME role (network-admin|network-engineer|network-operator|network-
user) password encrypted PASSWORD

```

Configure rbac role

Use this attribute to set the user role. Operations that an user is allowed to perform are determined based on the role

Attribute Name: rbac-role

Attribute Type: string

Netconf edit-config payload

```

<user-management xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-management">
  <users>
    <user>

```

```
<username>USERNAME</username>
<config>
  <username>USERNAME</username>
</config>
<rbac-role>ROLE-NAME</rbac-role> <!-- operation="delete"-->
</user>
</users>
</user-management>
```

Command Syntax

```
username USERNAME role ROLE-NAME
```

debug user-mgmt

Netconf RPC payload

```
<user-management-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-user-management"/>
```

Command Syntax

```
debug user-mgmt
```

no debug user-mgmt

Netconf RPC payload

```
<user-management-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-user-management"/>
```

Command Syntax

```
no debug user-mgmt
```

IPI-SSH

Configure enable

Use this attribute to enable ssh debugging configurations

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<ssh-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">
<debug>
<config>
  </enable><!-- operation="delete"-->
</config>
</debug>
</ssh-server>
```

Command Syntax

```
debug ssh server
```

Configure vrf name

Use this attribute to enable the SSH server.

Attribute Name: enable

Attribute Type: boolean

Netconf edit-config payload

```
<ssh-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <enable>true</enable> <!-- operation="delete"-->
    </vrf>
  </vrfs>
</ssh-server>
```

Command Syntax

```
feature ssh (vrf management|)
```

Configure port

VRF Name associated with this instance

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: port

Attribute Type: uint32

Attribute Range: 1024-65535

Netconf edit-config payload

```
<ssh-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
        <port>1024</port> <!-- operation="delete"-->
      </config>
    </vrf>
  </vrfs>
</ssh-server>
```

Command Syntax

```
ssh server port <1024-65535> (vrf management|)
```

Configure max login attempts

VRF Name associated with this instance

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: max-login-attempts

Attribute Type: uint8

Default Value: 3

Attribute Range: 1-3

Netconf edit-config payload

```
<ssh-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
        <max-login-attempts>1</max-login-attempts> <!-- operation="delete"-->
      </config>
    </vrf>
  </vrfs>
</ssh-server>
```

Command Syntax

```
ssh login-attempts <1-3> (vrf management|)
```

Configure session limit

VRF Name associated with this instance

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: session-limit

Attribute Type: uint8

Attribute Range: 1-40

Netconf edit-config payload

```
<ssh-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
</ssh-server>
```

```

    <session-limit>1</session-limit> <!-- operation="delete"-->
  </config>
</vrf>
</vrfs>
</ssh-server>

```

Command Syntax

```
ssh server session-limit <1-40> (vrf management|)
```

Configure triple des cbc

Use this attribute to set the 3DES-CBC Cipher

This command is supported when following feature are enabled ssh server feature

Attribute Name: triple-des-cbc

Attribute Type: empty

Attribute Name: aes128-ctr

Attribute Type: empty

Attribute Name: aes192-ctr

Attribute Type: empty

Attribute Name: aes256-ctr

Attribute Type: empty

Attribute Name: aes128-cbc

Attribute Type: empty

Attribute Name: aes192-cbc

Attribute Type: empty

Attribute Name: aes256-cbc

Attribute Type: empty

Netconf edit-config payload

```

<ssh-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <encryption-algorithms>
    <config>
      </aes128-ctr><!-- operation="delete"-->
      </aes192-ctr><!-- operation="delete"-->
      </aes256-ctr><!-- operation="delete"-->
      </aes128-cbc><!-- operation="delete"-->
      </aes192-cbc><!-- operation="delete"-->
      </aes256-cbc><!-- operation="delete"-->
    </config>
  </encryption-algorithms>
</ssh-server>

```

```
        </triple-des-cbc><!-- operation="delete"-->
</config>
</encryption-algorithms>
</vrf>
</vrfs>
</ssh-server>
```

Command Syntax

```
ssh server algorithm encryption { aes128-ctr| aes192-ctr| aes256-ctr| aes128-cbc|
aes192-cbc| aes256-cbc| 3des-cbc } (vrf management|)
```

Configure public key

Use this attribute to set the ssh public-key

Attribute Name: public-key

Attribute Type: string

Netconf edit-config payload

```
<user-management xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-management">
<users>
  <user>
    <username>USERNAME</username>
    <config>
      <username>USERNAME</username>
    </config>
    <ssh-keys xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">
      <config>
        <public-key>LINE</public-key> <!-- operation="delete"-->
      </config>
    </ssh-keys>
  </user>
</users>
</user-management>
```

Command Syntax

```
username USERNAME sshkey LINE
```

debug ssh server

Netconf RPC payload

```
<ssh-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh"/>
```

Command Syntax

```
debug ssh server
```

no debug ssh server

Netconf RPC payload

```
<ssh-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh"/>
```

Command Syntax

```
no debug ssh server
```

clear ssh hosts

Netconf RPC payload

```
<ssh-clear-hosts xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh"/>
```

Command Syntax

```
clear ssh hosts
```

ssh keygen host dsa (vrf management|) (force|)

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Attribute Name: force

Attribute Type: boolean

Default Value: false

Netconf RPC payload

```
<ssh-generate-server-dsa-key xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">  
  <vrf-name>management</vrf-name>  
  <force>true</force/>  
</ssh-generate-server-dsa-key>
```

Command Syntax

```
ssh keygen host dsa (vrf management|) (force|)
```

ssh keygen host rsa (length <1024-4096>|) (vrf management|) (force|)

Attribute Name: length

Attribute Type: uint32

Default Value: 2048

Attribute Range: 1024-4096

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Attribute Name: force

Attribute Type: boolean

Default Value: false

Netconf RPC payload

```
<ssh-generate-server-rsa-key xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">  
  <length>1024</length>  
  <vrf-name>management</vrf-name>  
  <force>true</force/>  
</ssh-generate-server-rsa-key>
```

Command Syntax

```
ssh keygen host rsa (length <1024-4096>|) (vrf management|) (force|)
```

ssh keygen host ecdsa (length (256|384|521)|) (vrf management|) (force|)

Attribute Name: length

Attribute Type: enum (256|384|521)

Default Value: 521

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Attribute Name: force

Attribute Type: boolean

Default Value: false

Netconf RPC payload

```
<ssh-generate-server-ecdsa-key xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">  
  <length>521</length>  
  <vrf-name>management</vrf-name>  
  <force>true</force/>  
</ssh-generate-server-ecdsa-key>
```

Command Syntax

```
ssh keygen host ecdsa (length (256|384|521)|) (vrf management|) (force|)
```

ssh keygen host ed25519 (vrf management|) (force|)

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Attribute Name: force

Attribute Type: boolean

Default Value: false

Netconf RPC payload

```
<ssh-generate-server-ed25519-key xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-ssh">
  <vrf-name>management</vrf-name>
  <force>true</force/>
</ssh-generate-server-ed25519-key>
```

Command Syntax

```
ssh keygen host ed25519 (vrf management|) (force|)
```

clear ssh host-key ((dsa|rsa|ecdsa|ed25519)|) (vrf management|)

Attribute Name: type

Attribute Type: enum (all-keys|dsa|rsa|ecdsa|ed25519)

Default Value: all-keys

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Netconf RPC payload

```
<ssh-clear-server-keys xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">
  <type>all-keys</type>
  <vrf-name>management</vrf-name>
</ssh-clear-server-keys>
```

Command Syntax

```
clear ssh host-key ((dsa|rsa|ecdsa|ed25519)|) (vrf management|)
```

username USERNAME keypair rsa (length <1024-4096>|) (force|)

Attribute Name: user-name

Attribute Type: string

Attribute Name: length

Attribute Type: uint32

Default Value: 4096

Attribute Range: 1024-4096

Attribute Name: force

Attribute Type: boolean

Default Value: false

Netconf RPC payload

```
<ssh-generate-user-rsa-key xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">
  <user-name>USERNAME</user-name>
  <length>1024</length>
  <force>true</force/>
</ssh-generate-user-rsa-key>
```

Command Syntax

```
username USERNAME keypair rsa (length <1024-4096>|) (force|)
```

username USERNAME keypair dsa (force|)

Attribute Name: user-name

Attribute Type: string

Attribute Name: force

Attribute Type: boolean

Default Value: false

Netconf RPC payload

```
<ssh-generate-user-dsa-key xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">
  <user-name>USERNAME</user-name>
  <force>true</force/>
</ssh-generate-user-dsa-key>
```

Command Syntax

```
username USERNAME keypair dsa (force|)
```

clear ssh keypair user USERNAME

Attribute Name: user-name

Attribute Type: string

Netconf RPC payload

```
<ssh-clear-user-keys xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ssh">
  <user-name>USERNAME</user-name>
</ssh-clear-user-keys>
```

Command Syntax

```
clear ssh keypair user USERNAME
```

IPI-TELNET

Configure enable

Use this attribute to enable telnet debugging configurations

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<telnet-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-telnet">
  <debug>
  <config>
    </enable><!-- operation="delete"-->
  </config>
</debug>
</telnet-server>
```

Command Syntax

```
debug telnet server
```

Configure vrf name

Use this attribute to enable the Telnet server.

Attribute Name: enable

Attribute Type: boolean

Netconf edit-config payload

```
<telnet-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-telnet">
  <vrfs>
  <vrf>
    <vrf-name>management</vrf-name>
    <config>
      <vrf-name>management</vrf-name>
    </config>
    <enable>>true</enable> <!-- operation="delete"-->
  </vrf>
</vrfs>
</telnet-server>
```

Command Syntax

```
feature telnet (vrf management|)
```

Configure port

VRF Name associated with this instance

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: port

Attribute Type: uint32

Attribute Range: 1024-65535

Netconf edit-config payload

```
<telnet-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-telnet">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
    <port>1024</port> <!-- operation="delete"-->
  </config>
</vrf>
</vrfs>
</telnet-server>
```

Command Syntax

```
telnet server port <1024-65535> (vrf management|)
```

Configure session limit

VRF Name associated with this instance

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: session-limit

Attribute Type: uint8

Attribute Range: 1-40

Netconf edit-config payload

```
<telnet-server xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-telnet">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
    <session-limit>1</session-limit> <!-- operation="delete"-->
  </config>
</vrf>
</vrfs>
</telnet-server>
```

Command Syntax

```
telnet server session-limit <1-40> (vrf management|)
```

debug telnet server

Netconf RPC payload

```
<telnet-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-telnet"/>
```

Command Syntax

```
debug telnet server
```

no debug telnet server

Netconf RPC payload

```
<telnet-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-telnet"/>
```

Command Syntax

```
no debug telnet server
```

IPI-NTP

Configure feature enable

Use this attribute to enable or disable NTP feature.

Attribute Name: feature-enable

Attribute Type: boolean

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <feature-enable>true</feature-enable> <!-- operation="delete"-->
    </vrf>
  </vrfs>
</ntp>
```

Command Syntax

```
feature ntp (vrf management|)
```

Configure vrf name

Use this attribute to enable or disable NTP feature.

Attribute Name: feature-enable

Attribute Type: boolean

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
```

```
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
  <feature-enable>true</feature-enable> <!-- operation="delete"-->
</vrf>
</vrfs>
</ntp>
```

Command Syntax

```
no feature ntp (vrf management|)
```

Configure enable ntp

Use this attribute to enable or disable NTP server

Attribute Name: enable-ntp

Attribute Type: boolean

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <enable-ntp>true</enable-ntp> <!-- operation="delete"-->
    </vrf>
  </vrfs>
</ntp>
```

Command Syntax

```
ntp enable (vrf management|)
```

Configure enable logging

Use this attribute to specify the vrf for which ntp feature is enabled

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: enable-logging

Attribute Type: empty

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
    <vrf>
```

```
<vrf-name>management</vrf-name>
<config>
  <vrf-name>management</vrf-name>
  </enable-logging><!-- operation="delete"-->
</config>
</vrf>
</vrfns>
</ntp>
```

Command Syntax

```
ntp logging (vrf management|)
```

Configure enable local master

Use this attribute to configure the device as an NTP server.

Attribute Name: enable-local-master

Attribute Type: empty

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
<vrfns>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
<ref-clock-master>
<config>
  </enable-local-master>
</config>
</ref-clock-master>
</vrf>
</vrfns>
</ntp>
```

Command Syntax

```
ntp master (vrf management|)
```

Configure local stratum

Use this attribute to configure stratum level for a NTP server.

Attribute Name: local-stratum

Attribute Type: uint8

Attribute Range: 1-15

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
```

```
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
<ref-clock-master>
<config>
  <local-stratum>1</local-stratum> <!-- operation="delete"-->
</config>
</ref-clock-master>
</vrf>
</vrfs>
</ntp>
```

Command Syntax

```
ntp master stratum <1-15> (vrf management|)
```

Configure enable ntp auth

Use this attribute to enable NTP authentication.

Attribute Name: enable-ntp-auth

Attribute Type: empty

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
<authentication>
<config>
  </enable-ntp-auth><!-- operation="delete"-->
</config>
</authentication>
</vrf>
</vrfs>
</ntp>
```

Command Syntax

```
ntp authenticate (vrf management|)
```

Configure ntp trusted keys

Use this attribute to configure one or more trusted authentication keys. If a key is trusted, the device will synchronize with a system that specifies this key in its NTP packets

Attribute Name: ntp-trusted-keys

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <authentication>
    <config>
      <ntp-trusted-keys>1</ntp-trusted-keys> <!-- operation="delete"-->
    </config>
  </authentication>
</ntp>
```

Command Syntax

```
ntp trusted-key <1-65535> (vrf management|)
```

Configure ntp request key

Use this to attribute to configure request key which shall be used as password for ntpdc utility.

Attribute Name: ntp-request-key

Attribute Type: uint32

Attribute Range: 1-65534

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <authentication>
    <config>
      <ntp-request-key>1</ntp-request-key> <!-- operation="delete"-->
    </config>
  </authentication>
</ntp>
```

Command Syntax

```
ntp request-key <1-65534> (vrf management|)
```

Configure key id

Use this attribute to set an NTP authentication key.

Attribute Name: key-id

Attribute Type: uint32

Attribute Range: 1-65535

Attribute Name: key-value

Attribute Type: string

Attribute Name: key-type

Attribute Type: enum (0|7)

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <authentication>
    <ntp-keys>
      <ntp-key> <!-- operation="delete"-->
        <key-id>1</key-id>
        <config>
          <key-id>1</key-id>
          <key-value>WORD</key-value>
          <key-type>1</key-type>
        </config>
      </ntp-key>
    </ntp-keys>
  </authentication>
</ntp>
```

Command Syntax

```
ntp authentication-key <1-65535> md5 WORD 7 (vrf management|)
```

Configure key value

Use this attribute to set an NTP authentication key.

Attribute Name: key-id

Attribute Type: uint32

Attribute Range: 1-65535

Attribute Name: key-value

Attribute Type: string

Attribute Name: key-type

Attribute Type: enum (0|7)

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    <authentication>
      <ntp-keys>
        <ntp-key> <!-- operation="delete"-->
          <key-id>1</key-id>
          <config>
            <key-id>1</key-id>
            <key-value>WORD</key-value>
            <key-type>0</key-type>
          </config>
        </ntp-key>
      </ntp-keys>
    </authentication>
  </vrf>
</vrfs>
</ntp>
```

Command Syntax

```
ntp authentication-key <1-65535> md5 WORD (vrf management|)
```

Configure prefer

preferred NTP server/peer

Attribute Name: prefer

Attribute Type: empty

Attribute Name: auth-key

Attribute Type: uint32

Default Value: 65535

Attribute Range: 1-65535

Attribute Name: minpoll

Attribute Type: uint16

Default Value: 4

Attribute Range: 4-16

Attribute Name: maxpoll

Attribute Type: uint16

Default Value: 6

Attribute Range: 4-16

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <servers>
    <server>
      <server-address>A.B.C.D</server-address>
      <config>
        <server-address>A.B.C.D</server-address>
        <auth-key>1</auth-key> <!-- operation="delete"-->
        <minpoll>4</minpoll> <!-- operation="delete"-->
        <maxpoll>4</maxpoll> <!-- operation="delete"-->
      </config>
      </prefer><!-- operation="delete"-->
    </server>
  </servers>
</ntp>
```

Command Syntax

```
ntp server (A.B.C.D|X:X::X:X|HOSTNAME) { key <1-65535>| minpoll <4-16>| maxpoll <4-16>| prefer } (vrf management|)
```

Configure server address

Use this attribute to set the NTP server IP address or hostname

Attribute Name: server-address

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
```

```

    <vrf-name>management</vrf-name>
  </config>
</servers>
</vrf>
</vrf>
</ntps>
</ntps>
</ntps>
</ntps>

```

Command Syntax

```
ntp server (A.B.C.D|X:X::X:X|HOSTNAME) (vrf management|)
```

Configure peer address

preferred NTP server/peer

Attribute Name: prefer

Attribute Type: empty

Attribute Name: auth-key

Attribute Type: uint32

Default Value: 65535

Attribute Range: 1-65535

Attribute Name: minpoll

Attribute Type: uint16

Default Value: 4

Attribute Range: 4-16

Attribute Name: maxpoll

Attribute Type: uint16

Default Value: 6

Attribute Range: 4-16

Netconf edit-config payload

```

<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrf>
    <vrf-name>management</vrf-name>
    <config>
      <vrf-name>management</vrf-name>
    </config>
  </vrf>
</ntp>

```

```
<peer>
  <peer-address>A.B.C.D</peer-address>
  <config>
    <peer-address>A.B.C.D</peer-address>
    <auth-key>1</auth-key> <!-- operation="delete"-->
    <minpoll>4</minpoll> <!-- operation="delete"-->
    <maxpoll>4</maxpoll> <!-- operation="delete"-->
  </config>
</peer>
</peers>
</vrf>
</vrfs>
</ntp>
```

Command Syntax

```
ntp peer (A.B.C.D|X:X::X:X|HOSTNAME) { key <1-65535>| minpoll <4-16>| maxpoll <4-16>| prefer } (vrf management|)
```

Configure minimum pkt spacing

Use this attribute to specify the minimum packet spacing to be permitted

Attribute Name: minimum-pkt-spacing

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <rate-limiting>
    <config>
      <minimum-pkt-spacing>1</minimum-pkt-spacing> <!-- operation="delete"-->
    </config>
  </rate-limiting>
</ntp>
```

Command Syntax

```
ntp discard { minimum <1-65535> } (vrf management|)
```

Configure netmask

use this attribute to specify the allowed NTP client IP network mask

Attribute Name: netmask

Attribute Type: union

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    <access-control-entries>
    <access-control-entry>
      <client-ip-address>CML_IP_ADDR_T</client-ip-address>
      <config>
        <client-ip-address>CML_IP_ADDR_T</client-ip-address>
      </config>
      <netmask>NTP_CLIENT_IP_NET_MASK_T</netmask>
    </access-control-entry>
    </access-control-entries>
  </vrf>
</vrfs>
</ntp>
```

Command Syntax

```
ntp allow (A.B.C.D|X:X::X:X) mask (A.B.C.D|<1-128>) (vrf management|)
```

Configure access options

use this attribute to specify the allowed access options for NTP client

Attribute Name: access-options

Attribute Type: bits (kod|nopeer|noserve|noquery|nomodify|notrap|limited)

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    <access-control-entries>
    <access-control-entry>
      <client-ip-address>CML_IP_ADDR_T</client-ip-address>
      <config>
```

```
    <client-ip-address>CML_IP_ADDR_T</client-ip-address>
  </config>
  <access-options>kod</access-options> <!-- operation="delete"-->
</access-control-entry>
</access-control-entries>
</vrf>
</vrfs>
</ntp>
```

Command Syntax

```
ntp allow {kod|nopeer|noserve|noquery|nomodify|notrap|limited} (vrf management|)
```

Configure client ip address

use this attribute to specify the allowed access options for NTP client

Attribute Name: access-options

Attribute Type: bits (kod|nopeer|noserve|noquery|nomodify|notrap|limited)

Attribute Name: netmask

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <access-control-entries>
    <access-control-entry>
      <client-ip-address>CML_IP_ADDR_T</client-ip-address>
      <config>
        <client-ip-address>CML_IP_ADDR_T</client-ip-address>
        <netmask>NTP_CLIENT_IP_NET_MASK_T</netmask>
      </config>
      <access-options>kod</access-options> <!-- operation="delete"-->
    </access-control-entry>
  </access-control-entries>
</ntp>
```

Command Syntax

```
ntp allow mask {kod|nopeer|noserve|noquery|nomodify|notrap|limited} (vrf
management|)
```

Configure enable

Use this attribute to enable NTP debug logs

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <debug>
    <config>
      </enable><!-- operation="delete"-->
    </config>
  </debug>
</ntp>
```

Command Syntax

```
debug ntp
```

clear ntp statistics (all-peers|io|local|memory)

Attribute Name: statistics-type

Attribute Type: enum (all-peers|io|local|memory)

Netconf RPC payload

```
<ntp-clear-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <statistics-type>all-peers</statistics-type>
</ntp-clear-statistics>
```

Command Syntax

```
clear ntp statistics (all-peers|io|local|memory)
```

ntp sync-retry (vrf management|)

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<ntp-retry-server-synchronization xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-ntp">
  <vrf-name>management</vrf-name>
</ntp-retry-server-synchronization>
```

Command Syntax

```
ntp sync-retry (vrf management|)
```

debug ntp

Netconf RPC payload

```
<ntp-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp"/>
```

Command Syntax

```
debug ntp
```

no debug ntp

Netconf RPC payload

```
<ntp-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp"/>
```

Command Syntax

```
no debug ntp
```

IPI-AAA

Configure authentication method rule

Use this attribute to set AAA methods for authentication

Attribute Name: authentication-method-rule

Attribute Type: string

Netconf edit-config payload

```
<aaa xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <authentication-method-rule>LINE</authentication-method-rule> <!--
operation="delete"-->
    </vrf>
  </vrfs>
</aaa>
```

Command Syntax

```
aaa authentication login default (vrf management|) group LINE
```

Configure vrf name

Use this attribute to set AAA methods for authentication

Attribute Name: authentication-method-rule

Attribute Type: string

Netconf edit-config payload

```
<aaa xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <authentication-method-rule>LINE</authentication-method-rule> <!--
operation="delete"-->
    </vrf>
  </vrfs>
</aaa>
```

Command Syntax

```
aaa authentication login default (vrf management|) local
```

Configure accounting method rule

Use this attribute to set AAA methods for accounting

Attribute Name: accounting-method-rule

Attribute Type: string

Netconf edit-config payload

```
<aaa xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <accounting-method-rule>LINE</accounting-method-rule> <!-- operation="delete"-->
    </vrf>
  </vrfs>
</aaa>
```

Command Syntax

```
aaa accounting default (vrf management|) group LINE
```

Configure authorization method rule

Use this attribute to set AAA methods for authorization

Attribute Name: authorization-method-rule

Attribute Type: string

Netconf edit-config payload

```
<aaa xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <authorization-method-rule>LINE</authorization-method-rule> <!--
operation="delete"-->
    </vrf>
  </vrfs>
</aaa>
```

Command Syntax

```
aaa authorization default (vrf management|) group LINE
```

Configure error enable

This is to enable error message on login failures

Attribute Name: error-enable

Attribute Type: uint8

Netconf edit-config payload

```
<aaa xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      </error-enable><!-- operation="delete"-->
    </vrf>
  </vrfs>
</aaa>
```

Command Syntax

```
aaa authentication login error-enable (vrf management|)
```

Configure enable fallback

VRF Name associated with this instance

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: enable-fallback

Attribute Type: empty

Attribute Name: non-existent

Attribute Type: boolean

Netconf edit-config payload

```
<aaa xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
    </enable-fallback>
    <non-existent>>true</non-existent>
  </config>
</vrf>
</vrfs>
</aaa>
```

Command Syntax

```
aaa authentication login default fallback error local (non-existent-user|) (vrf
management|)
```

Configure group type

This is to create server group type

Attribute Name: group-type

Attribute Type: enum (tacacs+|radius)

Netconf edit-config payload

```
<aaa xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
<server-groups>
<server-group> <!-- operation="delete"-->
  <group-name>WORD</group-name>
  <config>
    <group-name>WORD</group-name>
    <group-type>tacacs+</group-type>
  </config>
  <group-type>tacacs+</group-type>
</server-group>
</server-groups>
</vrf>
</vrfs>
</aaa>
```

Command Syntax

```
aaa group server (tacacs+|radius) WORD (vrf management|)
```

Configure host address

Use this attribute to add a host address to a server group

Attribute Name: host-address

Attribute Type: union

Netconf edit-config payload

```
<aaa xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
</vrf>
</vrfs>
<server-groups>
<server-group>
  <group-name>WORD</group-name>
  <config>
    <group-name>WORD</group-name>
    <group-type>tacacs+</group-type>
  </config>
  <group-type>tacacs+</group-type>
  <server-addresses>
<server-address> <!-- operation="delete"-->
  <host-address>CML_HOSTNAME_T</host-address>
  <config>
    <host-address>CML_HOSTNAME_T</host-address>
  </config>
</server-address>
</server-addresses>
</server-group>
</server-groups>
</aaa>
```

Command Syntax

```
server (A.B.C.D|X:X::X:X|WORD)
```

Configure group name

Use this attribute to add a host address to a server group

Attribute Name: host-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<aaa xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
</server-groups>
<server-group>
  <group-name>WORD</group-name>
  <config>
    <group-name>WORD</group-name>
    <group-type>tacacs+</group-type>
  </config>
  <group-type>tacacs+</group-type>
  <server-addresses>
  <server-address>
    <host-address>CML_HOSTNAME_T</host-address>
    <config>
      <host-address>CML_HOSTNAME_T</host-address>
    </config>
  </server-address>
</server-addresses>
</server-group>
</server-groups>
</vrf>
</vrfs>
</aaa>

```

Command Syntax

```
server server
```

Configure user non existent

This is to enable fallback to local authentication if remote authentication is configured and all AAA servers are unreachable

Attribute Name: enable-fallback

Attribute Type: boolean

Attribute Name: user-non-existent

Attribute Type: boolean

Netconf edit-config payload

```

<aaa xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa">
<aaa-authentication-console>
<config>
  <user-non-existent>true</user-non-existent> <!-- operation="delete"-->
  <enable-fallback>true</enable-fallback> <!-- operation="delete"-->

```

```
</config>
</aaa-authentication-console>
</aaa>
```

Command Syntax

```
aaa authentication login console fallback error local (non-existent-user|)
```

Configure authentication max failure attempts

Use this attribute to set the number of unsuccessful authentication attempts before a user is locked out

Attribute Name: authentication-max-failure-attempts

Attribute Type: uint8

Attribute Range: 1-25

Netconf edit-config payload

```
<aaa xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa">
  <aaa-user>
    <config>
      <authentication-max-failure-attempts>1</authentication-max-failure-attempts> <!--
- operation="delete"-->
    </config>
  </aaa-user>
</aaa>
```

Command Syntax

```
aaa local authentication attempts max-fail <1-25>
```

Configure local user unlock timeout

Use this attribute to set unlock timeout after local user/s locked out

Attribute Name: local-user-unlock-timeout

Attribute Type: uint16

Attribute Range: 1-3600

Netconf edit-config payload

```
<aaa xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa">
  <aaa-user>
    <config>
      <local-user-unlock-timeout>1</local-user-unlock-timeout> <!--
operation="delete"-->
    </config>
  </aaa-user>
</aaa>
```

Command Syntax

```
aaa local authentication unlock-timeout <1-3600>
```

Configure enable

Use this attribute to display AAA debugging information.

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<aaa xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa">
  <debug>
  <config>
    </enable><!-- operation="delete"-->
  </config>
</debug>
</aaa>
```

Command Syntax

```
debug aaa
```

debug aaa

Netconf RPC payload

```
<aaa-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa"/>
```

Command Syntax

```
debug aaa
```

no debug aaa

Netconf RPC payload

```
<aaa-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-aaa"/>
```

Command Syntax

```
no debug aaa
```

clear aaa local user lockout username USERNAME

Attribute Name: username

Attribute Type: string

Attribute Range: 2-32

Netconf RPC payload

```
<aaa-clear-local-user-lockout xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
aaa">
  <username>USERNAME</username>
</aaa-clear-local-user-lockout>
```

Command Syntax

```
clear aaa local user lockout username USERNAME
```

IPI-DHCP-RELAY

Configure disable dhcpv4 relay

Use this attribute to disable the DHCP relay global config

Attribute Name: disable-dhcpv4-relay

Attribute Type: uint8

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <global>
      <config>
        </disable-dhcpv4-relay><!-- operation="delete"-->
      </config>
    </global>
  </relay>
</dhcp>
```

Command Syntax

```
no ip dhcp relay
```

Configure disable dhcpv6 relay

Use this attribute to disable the DHCP relay global config

Attribute Name: disable-dhcpv6-relay

Attribute Type: uint8

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <global>
      <config>
        </disable-dhcpv6-relay><!-- operation="delete"-->
      </config>
    </global>
  </relay>
</dhcp>
```

Command Syntax

```
no ipv6 dhcp relay
```

Configure ipv4 relay interface

Enable relay on Client facing interface

Attribute Name: ipv4-relay-interface

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
      </ipv4-relay-interface><!-- operation="delete"-->
    </interface>
  </interfaces>
</relay>
</dhcp>
```

Command Syntax

```
ip dhcp relay
```

Configure ipv4 uplink interface

Specify the interface as an uplink interface(Server facing)

Attribute Name: ipv4-uplink-interface

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
      </ipv4-uplink-interface><!-- operation="delete"-->
    </interface>
  </interfaces>
</relay>
</dhcp>
```

Command Syntax

```
ip dhcp relay uplink
```

Configure ipv4 group name

Correlate specified interface to a specified DHCP server group.

Attribute Name: ipv4-group-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <ipv4-group-name>GROUP-NAME</ipv4-group-name> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </relay>
</dhcp>
```

Command Syntax

```
ip dhcp relay server-select GROUP-NAME
```

Configure ipv6 relay interface

Enable IPv6 relay on Client facing interface

Attribute Name: ipv6-relay-interface

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </ipv6-relay-interface><!-- operation="delete"-->
      </interface>
    </interfaces>
  </relay>
</dhcp>
```

Command Syntax

```
ipv6 dhcp relay
```

Configure ipv6 uplink interface

Specify the interface as an uplink interface(Server facing)

Attribute Name: ipv6-uplink-interface

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </ipv6-uplink-interface><!-- operation="delete"-->
      </interface>
    </interfaces>
  </relay>
</dhcp>
```

Command Syntax

```
ipv6 dhcp relay uplink
```

Configure ipv6 group name

Correlate specified interface to a specified DHCPv6 server group.

Attribute Name: ipv6-group-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <ipv6-group-name>GROUP-NAME</ipv6-group-name> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </relay>
</dhcp>
```

Command Syntax

```
ipv6 dhcp relay server-select GROUP-NAME
```

Configure interface type

DHCP relay vpn interface type

Attribute Name: interface-type

Attribute Type: enum (l3vpn|evpn)

Attribute Name: interface-direction

Attribute Type: enum (uplink|downlink)

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <ipv4-vpn-links>
          <ipv4-vpn-link> <!-- operation="delete"-->
            <interface-type>l3vpn</interface-type>
            <config>
              <interface-type>l3vpn</interface-type>
              <interface-direction>uplink</interface-direction>
            </config>
          </ipv4-vpn-link>
        </ipv4-vpn-links>
      </vrf>
    </vrfs>
  </relay>
</dhcp>
```

Command Syntax

```
ip dhcp relay (uplink|downlink) (l3vpn|evpn)
```

Configure interface type v6

DHCPv6 relay vpn interface type

Attribute Name: interface-type-v6

Attribute Type: enum (l3vpn|evpn)

Attribute Name: interface-direction-v6

Attribute Type: enum (uplink|downlink)

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <vrfs>
```

```

<vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
</vrf>
<ipv6-vpn-links>
<ipv6-vpn-link> <!-- operation="delete"-->
  <interface-type-v6>l3vpn</interface-type-v6>
  <config>
    <interface-type-v6>l3vpn</interface-type-v6>
    <interface-direction-v6>uplink</interface-direction-v6>
  </config>
</ipv6-vpn-link>
</ipv6-vpn-links>
</vrf>
</vrfs>
</relay>
</dhcp>

```

Command Syntax

```
ipv6 dhcp relay (uplink|downlink) (l3vpn|evpn)
```

Configure link selection source ip

Enable link selection sub-option (5) in the option-82 in DHCP packet

Attribute Name: link-selection-source-ip

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
  <vrfs>
  <vrf>
    <vrf-name>WORD</vrf-name>
    <config>
      <vrf-name>NAME</vrf-name>
    </config>
    <link-selection-source-ip>A.B.C.D</link-selection-source-ip> <!--
operation="delete"-->
  </vrf>
  </vrfs>
  </relay>
</dhcp>

```

Command Syntax

```
ip dhcp relay information source-ip A.B.C.D
```

Configure enable option82

Enable the device to insert and remove option-82 information on DHCP packets forwarded by the DHCP relay agent.

Attribute Name: enable-option82

Attribute Type: uint8

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        </enable-option82><!-- operation="delete"-->
      </vrf>
    </vrfs>
  </relay>
</dhcp>
```

Command Syntax

```
ip dhcp relay information option
```

Configure ip address

IPv4 address of the DHCP server

Attribute Name: ip-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <ipv4-dhcp-servers>
          <ipv4-dhcp-server> <!-- operation="delete"-->
            <ip-address>A.B.C.D</ip-address>
            <config>
              <ip-address>A.B.C.D</ip-address>
            </config>
          </ipv4-dhcp-server>
        </ipv4-dhcp-servers>
      </vrf>
```

```

</vrfs>
</relay>
</dhcp>

```

Command Syntax

```
ip dhcp relay address A.B.C.D
```

Configure dhcpv4 server global vrf

This attributes defines the VRF in which the DHCPv4 relay server is present

Attribute Name: dhcpv4-server-global-vrf

Attribute Type: string

Netconf edit-config payload

```

<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <ipv4-dhcp-servers>
          <ipv4-dhcp-server>
            <ip-address>A.B.C.D</ip-address>
            <config>
              <ip-address>A.B.C.D</ip-address>
            </config>
            <dhcpv4-server-global-vrf>VRF-NAME</dhcpv4-server-global-vrf> <!--
operation="delete"-->
          </ipv4-dhcp-server>
        </ipv4-dhcp-servers>
      </vrf>
    </vrfs>
  </relay>
</dhcp>

```

Command Syntax

```
ip dhcp relay address A.B.C.D global (VRF-NAME|)
```

Configure vrf name

This attributes defines the VRF in which the DHCPv4 relay server is present

Attribute Name: dhcpv4-server-global-vrf

Attribute Type: string

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
```

```
<relay>
<vrfs>
<vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  <ipv4-dhcp-servers>
  <ipv4-dhcp-server>
    <ip-address>A.B.C.D</ip-address>
    <config>
      <ip-address>A.B.C.D</ip-address>
    </config>
    <dhcpv4-server-global-vrf>VRF-NAME</dhcpv4-server-global-vrf> <!--
operation="delete"-->
  </ipv4-dhcp-server>
</ipv4-dhcp-servers>
</vrf>
</vrfs>
</relay>
</dhcp>
```

Command Syntax

```
ip dhcp relay address A.B.C.D global (VRF-NAME|)
```

Configure ipv6 address

IPv6 address of the DHCP server

Attribute Name: ipv6-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
<relay>
<vrfs>
<vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  <ipv6-dhcp-servers>
  <ipv6-dhcp-server> <!-- operation="delete"-->
    <ipv6-address>X:X::X:X</ipv6-address>
    <config>
      <ipv6-address>X:X::X:X</ipv6-address>
    </config>
  </ipv6-dhcp-server>
</ipv6-dhcp-servers>
</vrf>
```



```

</vrfs>
</relay>
</dhcp>

```

Command Syntax

```
ipv6 dhcp relay address X:X::X:X
```

Configure dhcpv6 server global vrf

This attribute defines the VRF in which the DHCPv6 relay server is present

Attribute Name: dhcpv6-server-global-vrf

Attribute Type: string

Netconf edit-config payload

```

<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <ipv6-dhcp-servers>
          <ipv6-dhcp-server>
            <ipv6-address>X:X::X:X</ipv6-address>
            <config>
              <ipv6-address>X:X::X:X</ipv6-address>
            </config>
            <dhcpv6-server-global-vrf>VRF-NAME</dhcpv6-server-global-vrf> <!--
operation="delete"-->
          </ipv6-dhcp-server>
        </ipv6-dhcp-servers>
      </vrf>
    </vrfs>
  </relay>
</dhcp>

```

Command Syntax

```
ipv6 dhcp relay address X:X::X:X global (VRF-NAME|)
```

Configure enable dhcpv6 pd route injection

Enable the route installation from the prefixes learned through prefix delegation.

Attribute Name: enable-dhcpv6-pd-route-injection

Attribute Type: uint8

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
```

```
<relay>
<vrfs>
<vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  </enable-dhcpv6-pd-route-injection><!-- operation="delete"-->
</vrf>
</vrfs>
</relay>
</dhcp>
```

Command Syntax

```
ipv6 dhcp relay pd-route-injection
```

Configure remote id

Remote host identifier. Use option 82 to provide the DHCP server information about the DHCP client

Attribute Name: remote-id

Attribute Type: union

Attribute Name: enable-option82

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
<relay>
<vrfs>
<vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
    </enable-option82><!-- operation="delete"-->
  </config>
  <remote-id>WORD</remote-id> <!-- operation="delete"-->
</vrf>
</vrfs>
</relay>
</dhcp>
```

Command Syntax

```
ip dhcp relay information option remote-id WORD
```

Configure enable option82 always on

Keep option-82 information on DHCP packets forwarded by the DHCP relay agent.

Attribute Name: enable-option82-always-on

Attribute Type: uint8

Attribute Name: enable-option82

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
          </enable-option82><!-- operation="delete"-->
        </config>
        </enable-option82-always-on><!-- operation="delete"-->
      </vrf>
    </vrfs>
  </relay>
</dhcp>
```

Command Syntax

```
ip dhcp relay information option always-on
```

Configure subscriber id

Subscriber identifier. Use this option to allows the service provider to assign/activate subscriber-specific actions

Attribute Name: subscriber-id

Attribute Type: string

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
          </config>
          <subscriber-id>WORD</subscriber-id> <!-- operation="delete"-->
        </vrf>
      </vrfs>
    </relay>
  </dhcp>
```

Command Syntax

```
ipv6 dhcp relay information option subscriber-id WORD
```

Configure group6 name

IPv6 DHCP Relay group name

Attribute Name: group6-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
      <dhcpv6-groups>
        <dhcpv6-group> <!-- operation="delete"-->
          <group6-name>GROUP-NAME</group6-name>
          <config>
            <group6-name>WORD</group6-name>
          </config>
        </dhcpv6-group>
      </dhcpv6-groups>
    </vrf>
  </vrfs>
</relay>
</dhcp>
```

Command Syntax

```
ipv6 dhcp relay server-group GROUP-NAME
```

Configure group name

IPv4 DHCP Relay group name

Attribute Name: group-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
      </vrf>
    </vrfs>
  </relay>
</dhcp>
```

```

</config>
<dhcp-groups>
<dhcp-group> <!-- operation="delete"-->
  <group-name>GROUP-NAME</group-name>
  <config>
    <group-name>WORD</group-name>
  </config>
</dhcp-group>
</dhcp-groups>
</vrf>
</vrfs>
</relay>
</dhcp>

```

Command Syntax

```
ip dhcp relay server-group GROUP-NAME
```

Configure interface direction

DHCP relay vpn interface type

Attribute Name: interface-type

Attribute Type: enum (l3vpn|evpn)

Attribute Name: interface-direction

Attribute Type: enum (uplink|downlink)

Netconf edit-config payload

```

<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
<relay>
<vrfs>
<vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  <ipv4-vpn-links>
  <ipv4-vpn-link>
    <interface-type>l3vpn</interface-type>
    <config>
      <interface-type>l3vpn</interface-type>
      <interface-direction>uplink</interface-direction>
    </config>
  </ipv4-vpn-link>
</ipv4-vpn-links>
</vrf>
</vrfs>
</relay>
</dhcp>

```

Command Syntax

```
ip dhcp relay (uplink|downlink) (l3vpn|evpn)
```

Configure interface direction v6

DHCPv6 relay vpn interface type

This command is supported when following feature are enabled IPV6 feature

Attribute Name: interface-type-v6

Attribute Type: enum (l3vpn|evpn)

Attribute Name: interface-direction-v6

Attribute Type: enum (uplink|downlink)

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <relay>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>NAME</vrf-name>
        </config>
        <ipv6-vpn-links>
          <ipv6-vpn-link>
            <interface-type-v6>l3vpn</interface-type-v6>
            <config>
              <interface-type-v6>l3vpn</interface-type-v6>
              <interface-direction-v6>uplink</interface-direction-v6>
            </config>
          </ipv6-vpn-link>
        </ipv6-vpn-links>
      </vrf>
    </vrfs>
  </relay>
</dhcp>
```

Command Syntax

```
ipv6 dhcp relay (uplink|downlink) (l3vpn|evpn)
```

Configure server

IPv4 DHCP Relay Group server details

Attribute Name: server

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
```

```

<relay>
<vrfs>
<vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>NAME</vrf-name>
  </config>
  <dhcp-groups>
  <dhcp-group>
    <group-name>GROUP-NAME</group-name>
    <config>
      <group-name>WORD</group-name>
    </config>
    <server>A.B.C.D</server> <!-- operation="delete"-->
  </dhcp-group>
</dhcp-groups>
</vrf>
</vrfs>
</relay>
</dhcp>

```

Command Syntax

```
server A.B.C.D
```

clear ip dhcp relay statistics**Netconf RPC payload**

```
<ipi-dhcp-relay_clear-relay-stats xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-dhcp"/>
```

Command Syntax

```
clear ip dhcp relay statistics
```

clear ip dhcp relay option statistics**Netconf RPC payload**

```
<ipi-dhcp-relay_clear-relay-option-stats xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-dhcp"/>
```

Command Syntax

```
clear ip dhcp relay option statistics
```

clear ipv6 dhcp pd-route (vrf NAME|)

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<ipi-dhcp-relay_clear-dhcpv6-pd-route xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <vrf-name>NAME</vrf-name>
</ipi-dhcp-relay_clear-dhcpv6-pd-route>
```

Command Syntax

```
clear ipv6 dhcp pd-route (vrf NAME|)
```

IPI-DNS-RELAY

Configure enable dns feature

Use this attribute to enable the DNS relay agent feature.

Attribute Name: enable-dns-feature

Attribute Type: empty

Netconf edit-config payload

```
<dns-relay xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-relay">
  <config>
    </enable-dns-feature><!-- operation="delete"-->
  </config>
</dns-relay>
```

Command Syntax

```
feature dns relay
```

Configure enable dnsv4 relay

Use this attribute to enable the IPv4 DNS relay agent.

Attribute Name: enable-dnsv4-relay

Attribute Type: empty

Netconf edit-config payload

```
<dns-relay xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-relay">
  <config>
    </enable-dnsv4-relay><!-- operation="delete"-->
  </config>
</dns-relay>
```

Command Syntax

```
ip dns relay
```

Configure enable dnsv6 relay

Use this attribute to enable the IPv6 DNS relay agent.

Attribute Name: enable-dnsv6-relay

Attribute Type: empty

Netconf edit-config payload

```
<dns-relay xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-relay">
<config>
  </enable-dnsv6-relay><!-- operation="delete"-->
</config>
</dns-relay>
```

Command Syntax

```
ipv6 dns relay
```

Configure dns server v4 addr

Use this attribute to set the IPv4 address

Attribute Name: dns-server-v4-addr

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<dns-relay xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-relay">
<config>
  <dns-server-v4-addr>A.B.C.D</dns-server-v4-addr> <!-- operation="delete"-->
</config>
</dns-relay>
```

Command Syntax

```
ip dns relay address A.B.C.D
```

Configure dns server v6 addr

Use this attribute to set the IPv6 address

Attribute Name: dns-server-v6-addr

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<dns-relay xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-relay">
<config>
  <dns-server-v6-addr>X:X::X:X</dns-server-v6-addr> <!-- operation="delete"-->
</config>
</dns-relay>
```

Command Syntax

```
ipv6 dns relay address X:X::X:X
```

Configure name

Use this attribute to enable the IPv4 DNS relay agent.

Attribute Name: enable-dnsv4-relay

Attribute Type: empty

Netconf edit-config payload

```
<dns-relay xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-relay">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </enable-dnsv4-relay><!-- operation="delete"-->
    </interface>
  </interfaces>
</dns-relay>
```

Command Syntax

```
ip dns relay
```

Configure dns relay uplink

Use this attribute to set the uplink IPv4 DNS relay agent.

Attribute Name: dns-relay-uplink

Attribute Type: empty

Netconf edit-config payload

```
<dns-relay xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-relay">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </dns-relay-uplink><!-- operation="delete"-->
    </interface>
  </interfaces>
</dns-relay>
```

Command Syntax

```
ip dns relay uplink
```

Configure dns relay v6 uplink

Use this attribute to set the uplink IPv6 DNS relay agent.

Attribute Name: dns-relay-v6-uplink

Attribute Type: empty

Netconf edit-config payload

```
<dns-relay xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-relay">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </dns-relay-v6-uplink><!-- operation="delete"-->
</interface>
</interfaces>
</dns-relay>
```

Command Syntax

```
ipv6 dns relay uplink
```

Configure vrf name

Use this attribute to set the IPv4 address

This command is supported when following feature are enabled Virtual routing and forwarding

Attribute Name: dns-server-v4-addr

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<dns-relay xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-relay">
<vrfs>
<vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>WORD</vrf-name>
  </config>
  <dns-server-v4-addr>A.B.C.D</dns-server-v4-addr> <!-- operation="delete"-->
</vrf>
</vrfs>
</dns-relay>
```

Command Syntax

```
ip dns relay address A.B.C.D
```

IPI-DNS-CLIENT

Configure default domain name

Default domain name used to complete unqualified host names (names without a dotted-decimal domain name).

Attribute Name: default-domain-name

Attribute Type: inet:domain-name

Netconf edit-config payload

```
<dns xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-client">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <default-domain-name>DOMAIN-NAME</default-domain-name> <!-- operation="delete"-->
    </vrf>
  </vrfs>
</dns>
```

Command Syntax

```
ip domain-name (vrf management|) DOMAIN-NAME
```

Configure lookup enabled

Enable DNS translation.

Attribute Name: lookup-enabled

Attribute Type: boolean

Netconf edit-config payload

```
<dns xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-client">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <lookup-enabled>true</lookup-enabled> <!-- operation="delete"-->
    </vrf>
  </vrfs>
</dns>
```

Command Syntax

```
ip domain-lookup (vrf management|)
```

Configure vrf name

Enable DNS translation.

Attribute Name: lookup-enabled

Attribute Type: boolean

Netconf edit-config payload

```
<dns xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-client">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <lookup-enabled>>true</lookup-enabled> <!-- operation="delete"-->
    </vrf>
  </vrfs>
</dns>
```

Command Syntax

```
no ip domain-lookup (vrf management|)
```

Configure address

Name server address used for name resolution.

Attribute Name: address

Attribute Type: inet:ip-address

Netconf edit-config payload

```
<dns xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-client">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    <servers>
      <server> <!-- operation="delete"-->
        <address>CML_IP_ADDR_T</address>
        <config>
          <address>CML_IP_ADDR_T</address>
        </config>
      </server>
    </servers>
  </vrf>
</vrfs>
</dns>
```

Command Syntax

```
ip name-server (vrf management|) (A.B.C.D|X:X::X:X)
```

Configure domain name

Use this attribute to define a list of default domain names used to complete unqualified host names. Each domain in the list is to be tried in turn. The ip domain-list command is similar to the ip domain-name command, except that with the ip domain-list command you can define a list of domains, each to be tried in turn. If there is no domain list, the default domain name specified with the ip domain-name command is used. If there is a domain list, the default domain name is not used.

Attribute Name: domain-name

Attribute Type: inet:domain-name

Netconf edit-config payload

```
<dns xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-client">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
    <search-domains>
      <search-domain> <!-- operation="delete"-->
        <domain-name>DOMAIN-NAME</domain-name>
        <config>
          <domain-name>CML_DOMAIN_NAME_T</domain-name>
        </config>
      </search-domain>
    </search-domains>
  </vrfs>
</dns>
```

Command Syntax

```
ip domain-list (vrf management|) DOMAIN-NAME
```

Configure ipv6 address

Configure a static hostname-to-address IPv6 mapping in DNS.

Attribute Name: ipv6-address

Attribute Type: inet:ipv6-address

Attribute Name: ipv4-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<dns xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-client">
  <vrfs>
```

```

<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
</host-entries>
<host-entry>
  <hostname>HOSTNAME</hostname>
  <config>
    <hostname>1</hostname>
    <ipv4-address>A.B.C.D</ipv4-address> <!-- operation="delete"-->
  </config>
    <ipv6-address>X:X::X:X</ipv6-address> <!-- operation="delete"-->
</host-entry>
</host-entries>
</vrf>
</vrfs>
</dns>

```

Command Syntax

```
ip host (vrf management|) HOSTNAME A.B.C.D X:X::X:X
```

Configure ipv4 address

Configure a static hostname-to-address IPv4 mapping in DNS.

Attribute Name: ipv4-address

Attribute Type: inet:ipv4-address

Attribute Name: ipv6-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```

<dns xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-client">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </host-entries>
    <host-entry>
      <hostname>HOSTNAME</hostname>
      <config>
        <hostname>1</hostname>
        <ipv6-address>X:X::X:X</ipv6-address> <!-- operation="delete"-->
      </config>
        <ipv4-address>A.B.C.D</ipv4-address> <!-- operation="delete"-->
    </host-entry>
  </host-entries>

```

```
</vrf>
</vrfs>
</dns>
```

Command Syntax

```
ip host (vrf management|) HOSTNAME X:X::X:X A.B.C.D
```

Configure hostname

Configure a static hostname-to-address IPv4 mapping in DNS.

Attribute Name: ipv4-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<dns xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-client">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
<host-entries>
<host-entry>
  <hostname>HOSTNAME</hostname>
  <config>
    <hostname>1</hostname>
    <ipv4-address>A.B.C.D</ipv4-address> <!-- operation="delete"-->
  </config>
</host-entry>
</host-entries>
</vrf>
</vrfs>
</dns>
```

Command Syntax

```
ip host (vrf management|) HOSTNAME A.B.C.D
```

Configure enable

DNS client debug.

Attribute Name: enable

Attribute Type: uint8

Netconf edit-config payload

```
<dns xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dns-client">
<debug>
<config>
  </enable><!-- operation="delete"-->
</config>
</dns>
```



```

</config>
</debug>
</dns>

```

Command Syntax

```
debug dns client
```

debug dns client

Netconf RPC payload

```
<dns-client-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
dns-client"/>
```

Command Syntax

```
debug dns client
```

no debug dns client

Netconf RPC payload

```
<dns-client-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
dns-client"/>
```

Command Syntax

```
no debug dns client
```

IPI-DHCP-CLIENT

Configure request ipv4 dns

Use this attribute to to add an option to a DHCP request.

Attribute Name: request-ipv4-dns

Attribute Type: empty

Netconf edit-config payload

```

<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <client>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </request-ipv4-dns><!-- operation="delete"-->
      </interface>
    </interfaces>
  </client>

```

```
</dhcp>
```

Command Syntax

```
ip dhcp client request dns-nameserver
```

Configure request log server

Use this attribute to to add an option to a DHCP request.

Attribute Name: request-log-server

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <client>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </request-log-server><!-- operation="delete"-->
      </interface>
    </interfaces>
  </client>
</dhcp>
```

Command Syntax

```
ip dhcp client request log-server
```

Configure request host name

Use this attribute to to add an option to a DHCP request.

Attribute Name: request-host-name

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <client>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </request-host-name><!-- operation="delete"-->
      </interface>
    </interfaces>
  </client>
```

```
</dhcp>
```

Command Syntax

```
ip dhcp client request host-name
```

Configure request ntp server

Use this attribute to to add an option to a DHCP request.

Attribute Name: request-ntp-server

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <client>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </request-ntp-server><!-- operation="delete"-->
      </interface>
    </interfaces>
  </client>
</dhcp>
```

Command Syntax

```
ip dhcp client request ntp-server
```

Configure request ipv6 dns

Use this attribute to to add an option to a DHCP request.

Attribute Name: request-ipv6-dns

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <client>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </request-ipv6-dns><!-- operation="delete"-->
      </interface>
    </interfaces>
  </client>
```

```
</dhcp>
```

Command Syntax

```
ipv6 dhcp client request dns-nameserver
```

Configure request ipv6 domain list

Use this attribute to specifies a search list of Domain Names to be used by the client to locate not-fully-qualified domain names.

Attribute Name: request-ipv6-domain-list

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <client>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </request-ipv6-domain-list><!-- operation="delete"-->
      </interface>
    </interfaces>
  </client>
</dhcp>
```

Command Syntax

```
ipv6 dhcp client request domain-search
```

Configure request ipv6 ntp server

Use this attribute to specifies a list of local NTP servers available for the client to synchronize their clocks.

Attribute Name: request-ipv6-ntp-server

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <client>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </request-ipv6-ntp-server><!-- operation="delete"-->
      </interface>
    </interfaces>
  </client>
</dhcp>
```

```
</client>  
</dhcp>
```

Command Syntax

```
ipv6 dhcp client request ntp-server
```

Configure request ipv6 rapid commit

Use this attribute to indicate the clients to enter into rapid-commit with the server.

Attribute Name: request-ipv6-rapid-commit

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">  
  <client>  
    <interfaces>  
      <interface>  
        <name>WORD</name>  
        <config>  
          <name>WORD</name>  
          </request-ipv6-rapid-commit><!-- operation="delete"-->  
        </interface>  
      </interfaces>  
    </client>  
  </dhcp>
```

Command Syntax

```
ipv6 dhcp client request rapid-commit
```

Configure request ipv6 vendor opts

Use this attribute to specify a 32-bit Enterprise-ID number.

Attribute Name: request-ipv6-vendor-opts

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">  
  <client>  
    <interfaces>  
      <interface>  
        <name>WORD</name>  
        <config>  
          <name>WORD</name>  
          </request-ipv6-vendor-opts><!-- operation="delete"-->  
        </interface>  
      </interfaces>
```

```
</client>
</dhcp>
```

Command Syntax

```
ipv6 dhcp client request vendor-specific-information
```

Configure ipv6 information request

Use this attribute to get only stateless configuration parameters (i.e., without address).

Attribute Name: ipv6-information-request

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <client>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </ipv6-information-request><!-- operation="delete"-->
      </interface>
    </interfaces>
  </client>
</dhcp>
```

Command Syntax

```
ipv6 dhcp client information-request
```

Configure ipv6 dad wait time

Use this attribute to Specify maximum time (in seconds) that the client should wait for the duplicate address detection (DAD) to complete on an interface.

Attribute Name: ipv6-dad-wait-time

Attribute Type: uint16

Attribute Range: 1-600

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <client>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <ipv6-dad-wait-time>1</ipv6-dad-wait-time> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </client>
</dhcp>
```

```
</interface>
</interfaces>
</client>
</dhcp>
```

Command Syntax

```
ipv6 dhcp client dad-wait-time <1-600>
```

Configure ipv6 client duid type

Use this attribute to configure duid type(ll or llt).

Attribute Name: ipv6-client-duid-type

Attribute Type: enum (ll|llt)

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <client>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <ipv6-client-duid-type>ll</ipv6-client-duid-type> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </client>
</dhcp>
```

Command Syntax

```
ipv6 dhcp client duid (ll|llt)
```

Configure request ipv6 prefix

Use this attribute to add an option to a DHCP request.

Attribute Name: request-ipv6-prefix

Attribute Type: string

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <client>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
      </interface>
    </interfaces>
  </client>
</dhcp>
```

```
        <request-ipv6-prefix>PREFIX-NAME</request-ipv6-prefix> <!--  
operation="delete"-->  
    </interface>  
</interfaces>  
</client>  
</dhcp>
```

Command Syntax

```
ipv6 dhcp prefix-delegation PREFIX-NAME
```

Configure suffix ipv6 addr

This attribute points to IPv6 address

This command is supported when following feature are enabled IPV6 feature

Attribute Name: suffix-ipv6-addr

Attribute Type: string

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">  
  <client>  
    <interfaces>  
      <interface>  
        <name>WORD</name>  
        <config>  
          <name>WORD</name>  
        </config>  
        <prefix-ipv6-addresses>  
          <prefix-ipv6-address> <!-- operation="delete"-->  
            <suffix-ipv6-addr>X:X::X:X/M</suffix-ipv6-addr>  
            <config>  
              <suffix-ipv6-addr>X:X::X:X/M</suffix-ipv6-addr>  
              <prefix-name>PREFIX-NAME</prefix-name>  
            </config>  
            <prefix-name>PREFIX-NAME</prefix-name>  
          </prefix-ipv6-address>  
        </prefix-ipv6-addresses>  
      </interface>  
    </interfaces>  
  </client>  
</dhcp>
```

Command Syntax

```
ipv6 address PREFIX-NAME X:X::X:X/M
```

IPI-DHCP-SERVER

Configure enable ipv4 server

Interface on which IPv4 DHCP Server has to be run

Attribute Name: enable-ipv4-server

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </enable-ipv4-server><!-- operation="delete"-->
      </interface>
    </interfaces>
  </server>
</dhcp>
```

Command Syntax

```
ip dhcp server
```

Configure enable ipv6 server

Interface on which IPv6 DHCP Server has to be run

Attribute Name: enable-ipv6-server

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </enable-ipv6-server><!-- operation="delete"-->
      </interface>
    </interfaces>
  </server>
</dhcp>
```

Command Syntax

```
ipv6 dhcp server
```

Configure pool6 name

IPv6 DHCP Server address pool name

Attribute Name: pool6-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <dhcp6-pools>
          <dhcp6-pool> <!-- operation="delete"-->
            <pool6-name>NAME</pool6-name>
            <config>
              <pool6-name>WORD</pool6-name>
            </config>
          </dhcp6-pool>
        </dhcp6-pools>
      </vrf>
    </vrfs>
  </server>
</dhcp>
```

Command Syntax

```
ipv6 dhcp server pool NAME
```

Configure pool name

IPv4 DHCP Server address pool name

Attribute Name: pool-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
```

```

    <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>WORD</vrf-name>
  </config>
<dhcp-pools>
<dhcp-pool> <!-- operation="delete"-->
  <pool-name>NAME</pool-name>
  <config>
    <pool-name>WORD</pool-name>
  </config>
</dhcp-pool>
</dhcp-pools>
</vrf>
</vrfs>
</server>
</dhcp>

```

Command Syntax

```
ip dhcp server pool NAME
```

Configure max lease time

Maximum length in seconds that will be assigned to a lease. If not defined, the default maximum lease time is 86400.

Attribute Name: max-lease-time

Attribute Type: uint32

Default Value: 86400

Netconf edit-config payload

```

<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <max-lease-time>SECONDS</max-lease-time> <!-- operation="delete"-->
      </vrf>
    </vrfs>
  </server>
</dhcp>

```

Command Syntax

```
ip dhcp server max-lease-time SECONDS
```

Configure default lease time

Length in seconds that will be assigned to a lease if the client requesting the lease does not ask for a specific expiration time. The default is 43200

Attribute Name: default-lease-time

Attribute Type: uint32

Default Value: 43200

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <default-lease-time>SECONDS</default-lease-time> <!-- operation="delete"-->
      </vrf>
    </vrfs>
  </server>
</dhcp>
```

Command Syntax

```
ip dhcp server default-lease-time SECONDS
```

Configure rapid commit

Option enables the DHCP Client to obtain configuration parameters from the server through a rapid two message exchange (solicit and reply).

Attribute Name: rapid-commit

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        </rapid-commit><!-- operation="delete"-->
      </vrf>
    </vrfs>
  </server>
</dhcp>
```

Command Syntax

```
ipv6 dhcp server rapid-commit
```

Configure preference

Use this to configure preference option in dhcp server.

Attribute Name: preference

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        </preference><!-- operation="delete"-->
      </vrf>
    </vrfs>
  </server>
</dhcp>
```

Command Syntax

```
ipv6 dhcp server preference
```

Configure vrf name

Option enables the DHCP Client to obtain configuration parameters from the server through a rapid two message exchange (solicit and reply).

Attribute Name: rapid-commit

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        </rapid-commit><!-- operation="delete"-->
      </vrf>
    </vrfs>
  </server>
</dhcp>
```

Command Syntax

```
ipv6 dhcp server rapid-commit
```

Configure host name

IPv4 DHCP Server option to provide hostname details to a DHCP client

Attribute Name: host-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <dhcp-pools>
          <dhcp-pool>
            <pool-name>NAME</pool-name>
            <config>
              <pool-name>WORD</pool-name>
            </config>
            <host-name>NAME</host-name> <!-- operation="delete"-->
          </dhcp-pool>
        </dhcp-pools>
      </vrf>
    </vrfs>
  </server>
</dhcp>
```

Command Syntax

```
host-name NAME
```

Configure routers

IPv4 DHCP Server option to provide routers details to a DHCP client

Attribute Name: routers

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
```

```

    <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>WORD</vrf-name>
  </config>
  <dhcp-pools>
  <dhcp-pool>
    <pool-name>NAME</pool-name>
    <config>
      <pool-name>WORD</pool-name>
    </config>
    <router>A.B.C.D</router> <!-- operation="delete"-->
  </dhcp-pool>
</dhcp-pools>
</vrf>
</vrfs>
</server>
</dhcp>

```

Command Syntax

```
router A.B.C.D
```

Configure ntp server

IPv4 DHCP Server option to provide ntp-server details to a DHCP client

Attribute Name: ntp-server

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
  <vrfs>
  <vrf>
    <vrf-name>WORD</vrf-name>
    <config>
      <vrf-name>WORD</vrf-name>
    </config>
  <dhcp-pools>
  <dhcp-pool>
    <pool-name>NAME</pool-name>
    <config>
      <pool-name>WORD</pool-name>
    </config>
    <ntp-server>A.B.C.D</ntp-server> <!-- operation="delete"-->
  </dhcp-pool>
</dhcp-pools>
</vrf>
</vrfs>
</server>
</dhcp>

```

Command Syntax

```
ntp-server A.B.C.D
```

Configure boot file

IPv4 DHCP Server option to provide boot-file details to a DHCP client

Attribute Name: boot-file

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <dhcp-pools>
          <dhcp-pool>
            <pool-name>NAME</pool-name>
            <config>
              <pool-name>WORD</pool-name>
              </config>
              <boot-file>BOOTFILE</boot-file> <!-- operation="delete"-->
            </dhcp-pool>
          </dhcp-pools>
        </vrf>
      </vrfs>
    </server>
  </dhcp>
```

Command Syntax

```
boot-file BOOTFILE
```

Configure tftp server

IPv4 DHCP Server option to provide tftp-server details to a DHCP client

Attribute Name: tftp-server

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
```



```

    <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>WORD</vrf-name>
  </config>
  <dhcp-pools>
  <dhcp-pool>
    <pool-name>NAME</pool-name>
    <config>
      <pool-name>WORD</pool-name>
    </config>
    <tftp-server>A.B.C.D</tftp-server> <!-- operation="delete"-->
  </dhcp-pool>
</dhcp-pools>
</vrf>
</vrfs>
</server>
</dhcp>

```

Command Syntax

```
tftp-server A.B.C.D
```

Configure log server

IPv4 DHCP Server option to provide log-server details to a DHCP client

Attribute Name: log-server

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
  <vrfs>
  <vrf>
    <vrf-name>WORD</vrf-name>
    <config>
      <vrf-name>WORD</vrf-name>
    </config>
  <dhcp-pools>
  <dhcp-pool>
    <pool-name>NAME</pool-name>
    <config>
      <pool-name>WORD</pool-name>
    </config>
    <log-server>A.B.C.D</log-server> <!-- operation="delete"-->
  </dhcp-pool>
</dhcp-pools>
</vrf>
</vrfs>
</server>
</dhcp>

```

Command Syntax

```
log-server A.B.C.D
```

Configure dns server

IPv4 DHCP Server option to provide dns name-server details to a DHCP client

Attribute Name: dns-server

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
      <dhcp-pools>
        <dhcp-pool>
          <pool-name>NAME</pool-name>
          <config>
            <pool-name>WORD</pool-name>
            </config>
            <dns-server>A.B.C.D</dns-server> <!-- operation="delete"-->
          </dhcp-pool>
        </dhcp-pools>
      </vrf>
    </vrfs>
  </server>
</dhcp>
```

Command Syntax

```
dns-server A.B.C.D
```

Configure netmask

Mask part of the subnet that will be used to assign IPv4 addresses to hosts

Attribute Name: netmask

Attribute Type: inet:ipv4-address

Attribute Name: network

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
```

```

<vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>WORD</vrf-name>
  </config>
  <dhcp-pools>
  <dhcp-pool>
    <pool-name>NAME</pool-name>
    <config>
      <pool-name>WORD</pool-name>
      <network>A.B.C.D</network> <!-- operation="delete"-->
    </config>
      <netmask>A.B.C.D</netmask> <!-- operation="delete"-->
    </dhcp-pool>
  </dhcp-pools>
</vrf>
</vrfs>
</server>
</dhcp>

```

Command Syntax

```
network A.B.C.D netmask A.B.C.D
```

Configure high address in range

Specifies the high range of the IPv4 addresses that the DHCP server should assign to DHCP clients.

Attribute Name: high-address-in-range

Attribute Type: inet:ipv4-address

Attribute Name: low-address-in-range

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
  <vrfs>
  <vrf>
    <vrf-name>WORD</vrf-name>
    <config>
      <vrf-name>WORD</vrf-name>
    </config>
  <dhcp-pools>
  <dhcp-pool>
    <pool-name>NAME</pool-name>
    <config>
      <pool-name>WORD</pool-name>
      <low-address-in-range>A.B.C.D</low-address-in-range> <!--
operation="delete"-->
    </config>
  </dhcp-pool>
  </dhcp-pools>
  </vrf>
  </vrfs>
  </server>
</dhcp>

```

```
        <high-address-in-range>A.B.C.D</high-address-in-range> <!--
operation="delete"-->
    </dhcp-pool>
</dhcp-pools>
</vrf>
</vrfs>
</server>
</dhcp>
```

Command Syntax

```
address range low-address A.B.C.D (high-address A.B.C.D|)
```

Configure domain name

IPv6 DHCP Server option to provide domain-name details to a DHCP client

This command is supported when following feature are enabled IPV6 feature

Attribute Name: domain-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
<server>
<vrfs>
<vrf>
    <vrf-name>WORD</vrf-name>
    <config>
        <vrf-name>WORD</vrf-name>
    </config>
<dhcp6-pools>
<dhcp6-pool>
    <pool6-name>NAME</pool6-name>
    <config>
        <pool6-name>WORD</pool6-name>
    </config>
    <domain-name>NAME</domain-name> <!-- operation="delete"-->
</dhcp6-pool>
</dhcp6-pools>
</vrf>
</vrfs>
</server>
</dhcp>
```

Command Syntax

```
domain-name NAME
```

Configure vendor options

IPv6 DHCP Server option to provide vendor details to a DHCP client

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vendor-options

Attribute Type: string

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
      <dhcp6-pools>
        <dhcp6-pool>
          <pool6-name>NAME</pool6-name>
          <config>
            <pool6-name>WORD</pool6-name>
          </config>
          <vendor-options>VENDOR-OPTS</vendor-options> <!-- operation="delete"-->
        </dhcp6-pool>
      </dhcp6-pools>
    </vrf>
  </vrfs>
</server>
</dhcp>
```

Command Syntax

```
vendor-options VENDOR-OPTS
```

Configure ipv6 netmask

Mask part of the subnet that will be used to assign IPv6 addresses to hosts

This command is supported when following feature are enabled IPV6 feature

Attribute Name: ipv6-netmask

Attribute Type: uint8

Attribute Range: 1-128

Attribute Name: ipv6-network

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
```

```
<vrfs>
<vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>WORD</vrf-name>
  </config>
  <dhcp6-pools>
  <dhcp6-pool>
    <pool6-name>NAME</pool6-name>
    <config>
      <pool6-name>WORD</pool6-name>
      <ipv6-network>X:X::X:X</ipv6-network> <!-- operation="delete"-->
    </config>
    <ipv6-netmask>1</ipv6-netmask> <!-- operation="delete"-->
  </dhcp6-pool>
</dhcp6-pools>
</vrf>
</vrfs>
</server>
</dhcp>
```

Command Syntax

```
network X:X::X:X netmask <1-128>
```

Configure low address in range

Specifies the high range of the IPv6 addresses that the DHCP server should assign to DHCP clients.

This command is supported when following feature are enabled IPV6 feature

Attribute Name: high-address-in-range

Attribute Type: inet:ipv6-address

Attribute Name: low-address-in-range

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
<server>
<vrfs>
<vrf>
  <vrf-name>WORD</vrf-name>
  <config>
    <vrf-name>WORD</vrf-name>
  </config>
<dhcp6-pools>
<dhcp6-pool>
  <pool6-name>NAME</pool6-name>
  <config>
    <pool6-name>WORD</pool6-name>
```

```

        <low-address-in-range>X:X::X:X</low-address-in-range> <!--
operation="delete"-->
        </config>
        <high-address-in-range>X:X::X:X</high-address-in-range> <!--
operation="delete"-->
        </dhcp6-pool>
    </dhcp6-pools>
</vrf>
</vrfs>
</server>
</dhcp>

```

Command Syntax

```
address range low-address X:X::X:X (high-address X:X::X:X|)
```

Configure temporary address

Specifies the temporary IPv6 address that the DHCP server should assign to DHCP clients.

This command is supported when following feature are enabled IPV6 feature

Attribute Name: temporary-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```

<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <dhcp6-pools>
          <dhcp6-pool>
            <pool6-name>NAME</pool6-name>
            <config>
              <pool6-name>WORD</pool6-name>
            </config>
            <temporary-address>X:X::X:X</temporary-address> <!-- operation="delete"--
          >
        </dhcp6-pool>
      </dhcp6-pools>
    </vrf>
  </vrfs>
</server>
</dhcp>

```

Command Syntax

```
temporary address X:X::X:X
```

Configure ipv6 prefix netmask

Mask part of the ipv6 Prefix used for Prefix delegation

This command is supported when following feature are enabled IPV6 feature

Attribute Name: ipv6-prefix-netmask

Attribute Type: uint8

Attribute Range: 1-128

Attribute Name: ipv6-prefix-high-address

Attribute Type: inet:ipv6-address

Attribute Name: ipv6-prefix-low-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <server>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <dhcp6-pools>
          <dhcp6-pool>
            <pool6-name>NAME</pool6-name>
            <config>
              <pool6-name>WORD</pool6-name>
              <ipv6-prefix-high-address>X:X::X:X</ipv6-prefix-high-address> <!--
operation="delete"-->
              <ipv6-prefix-low-address>X:X::X:X</ipv6-prefix-low-address> <!--
operation="delete"-->
            </config>
            <ipv6-prefix-netmask>1</ipv6-prefix-netmask> <!-- operation="delete"-->
          </dhcp6-pool>
        </dhcp6-pools>
      </vrf>
    </vrfs>
  </server>
</dhcp>
```

Command Syntax

```
prefix high-range X:X::X:X low-range X:X::X:X netmask <1-128>
```

IPI-SFLOW

Configure enabled

Use this attribute to enable or disable Sampled Flow (sFlow) feature globally.

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<sampling xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow">
  <sflow>
    <config>
      </enabled>
    </config>
  </sflow>
</sampling>
```

Command Syntax

```
feature sflow
```

Configure source address

The IP address associated with this agent. In the case of a multi-homed agent, this should be the loopback address of the agent. The sFlowAgent address must provide SNMP connectivity to the agent. The address should be an invariant that does not change as interfaces are reconfigured, enabled, disabled, added or removed. A manager should be able to use the sFlowAgentAddress as a unique key that will identify this agent over extended periods of time so that a history can be maintained.

Attribute Name: source-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<sampling xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow">
  <sflow>
    <config>
      <source-address>A.B.C.D</source-address> <!-- operation="delete"-->
    </config>
  </sflow>
</sampling>
```

Command Syntax

```
sflow agent-ip A.B.C.D
```

Configure max datagram size

The maximum number of data bytes that can be sent in a single sample datagram. The manager should set this value to avoid fragmentation of the sFlow datagrams.

Attribute Name: max-datagram-size

Attribute Type: uint16

Attribute Range: 200-9000

Attribute Name: receiver-timeout

Attribute Type: uint32

Attribute Range: 0-2147483647

Netconf edit-config payload

```
<sampling xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow">
  <sflow>
    <collectors>
      <collector>
        <port>1024</port>
        <config>
          <port>1024</port>
          <address>A.B.C.D</address>
          <receiver-timeout>0</receiver-timeout> <!-- operation="delete"-->
        </config>
        <address>A.B.C.D</address>
        <max-datagram-size>200</max-datagram-size> <!-- operation="delete"-->
      </collector>
    </collectors>
  </sflow>
</sampling>
```

Command Syntax

```
sflow collector A.B.C.D port <1024-65535> receiver-time-out <0-2147483647> max-
datagram-size <200-9000>
```

Configure options

Set sFlow debug in config mode

Attribute Name: options

Attribute Type: bits (agent|sampling|polling|all)

Netconf edit-config payload

```
<sampling xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow">
  <sflow>
    <debug>
      <config>
        <options>agent</options> <!-- operation="delete"-->
      </config>
    </debug>
  </sflow>
</sampling>
```

Command Syntax

```
debug sflow (agent|sampling|polling|all)
```

debug sflow (agent|sampling|polling|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (agent|sampling|polling|all)

Netconf RPC payload

```
<sflow-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow">
  <terminal-debug-options>agent</terminal-debug-options>
</sflow-terminal-debug-on>
```

Command Syntax

```
debug sflow (agent|sampling|polling|all)
```

no debug sflow (agent|sampling|polling|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (agent|sampling|polling|all)

Netconf RPC payload

```
<sflow-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
sflow">
  <terminal-debug-options>agent</terminal-debug-options>
</sflow-terminal-debug-off>
```

Command Syntax

```
no debug sflow (agent|sampling|polling|all)
```

IPI-SFLOW-INTERFACE

Configure enabled

To enable or disable sampling on an interface after giving the sflow sampling-rate command on the same interface

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<sampling xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow">
  <sflow>
    <interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow-interface">
      <interface>
        <name>WORD</name>
        <config>
```

```
        <name>WORD</name>
    </config>
    </enabled><!-- operation="delete"-->
</interface>
</interfaces>
</sflow>
</sampling>
```

Command Syntax

```
sflow enable
```

Configure polling interval

The maximum number of seconds between successive samples of the counters associated with this data source. A sampling interval of 0 disables counter sampling. The agent is permitted to have minimum and maximum allowable values for the counter polling interval. A minimum interval lets the agent designer set an upper bound on the overhead associated with polling, and a maximum interval may be the result of implementation restrictions (such as counter size). In addition, not all values between the maximum and minimum may be realizable as the sampling interval (again because of implementation considerations). When the sampling rate is set, the agent is free to adjust the value so that it lies between the maximum and minimum values and has the closest achievable value. When read, the agent must return the actual sampling interval it will be using (after the adjustments previously described). The sampling algorithm must converge so that over time the number of packets sampled approaches 1/Nth of the total number of packets in the monitored flows.

Attribute Name: polling-interval

Attribute Type: uint8

Attribute Range: 5-60

Netconf edit-config payload

```
<sampling xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow">
<sflow>
  <interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow-interface">
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <polling-interval>5</polling-interval> <!-- operation="delete"-->
    </interface>
  </interfaces>
</sflow>
</sampling>
```

Command Syntax

```
sflow poll-interval <5-60>
```

Configure sample size

The maximum number of bytes that should be copied from a sampled packet. The agent may have an internal maximum and minimum permissible sizes. If an attempt is made to set this value outside the permissible range then the agent should adjust the value to the closest permissible value.

Attribute Name: sample-size

Attribute Type: uint16

Attribute Range: 16-256

Attribute Name: sampling-rate

Attribute Type: uint32

Attribute Range: 1024-16777215

Netconf edit-config payload

```
<sampling xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow">
  <sflow>
    <interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow-interface">
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <ingress>
          <config>
            <sampling-rate>1024</sampling-rate>
            <sample-size>16</sample-size>
          </config>
        </ingress>
      </interface>
    </interfaces>
  </sflow>
</sampling>
```

Command Syntax

```
sflow sampling-rate <1024-16777215> direction ingress max-header-size <16-256>
```

Configure name

The maximum number of bytes that should be copied from a sampled packet. The agent may have an internal maximum and minimum permissible sizes. If an attempt is made to set this value outside the permissible range then the agent should adjust the value to the closest permissible value.

Attribute Name: sample-size

Attribute Type: uint16

Attribute Range: 16-256

Attribute Name: sampling-rate

Attribute Type: uint32

Attribute Range: 1024-16777215

Netconf edit-config payload

```
<sampling xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow">
  <sflow>
    <interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow-interface">
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
          </config>
          <egress>
            <config>
              <sampling-rate>1024</sampling-rate>
              <sample-size>16</sample-size>
            </config>
          </egress>
        </interface>
      </interfaces>
    </sflow>
  </sampling>
```

Command Syntax

```
sflow sampling-rate <1024-16777215> direction egress max-header-size <16-256>
```

clear sflow statistics (interface IFNAME|)

Attribute Name: interface

Attribute Type: string

Netconf RPC payload

```
<sflow-clear-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sflow-
interface">
  <interface>IFNAME</interface>
</sflow-clear-statistics>
```

Command Syntax

```
clear sflow statistics (interface IFNAME|)
```

IPI-WATCHDOG

Configure watchdog disabled

Disable software watchdog functionality for all modules. This feature is enabled by default.

Attribute Name: watchdog-disabled

Attribute Type: uint8

Netconf edit-config payload

```
<watchdog xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-watchdog">
<config>
  </watchdog-disabled><!-- operation="delete"-->
</config>
</watchdog>
```

Command Syntax

```
no feature software-watchdog
```

Configure keepalive interval

Software watchdog keep-alive time interval in seconds. Default value is 60 seconds.

This command is supported when following feature are enabled Watchdog feature

Attribute Name: keepalive-interval

Attribute Type: uint16

Default Value: 60

Attribute Range: 30-1800

Netconf edit-config payload

```
<watchdog xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-watchdog">
<config>
  <keepalive-interval>30</keepalive-interval> <!-- operation="delete"-->
</config>
</watchdog>
```

Command Syntax

```
software-watchdog keep-alive-time <30-1800>
```

Configure module watchdog status disabled

Enable software watchdog functionality for a particular software module.

Attribute Name: module-watchdog-status-disabled

Attribute Type: uint8

Netconf edit-config payload

```
<watchdog xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-watchdog">
<software-modules>
<software-module>
  <name>nsm</name>
  <config>
    <name>nsm</name>
  </config>
  </module-watchdog-status-disabled><!-- operation="delete"-->
</software-module>
</software-modules>
```

```
</watchdog>
```

Command Syntax

```
no software-watchdog
(nsm|ripd|ripngd|ospfd|ospf6d|isisd|hostpd|ldpd|rsvdp|mribd|pimd|authd|mstpd|imi
|onmd|hsl|oamd|vlogd|ptpd|synced|vrrpd|ndd|ribd|bgpd|l2mribd|lagd|sflow|udld|cml
d|cmmd|pcep)
```

clear cores (WORD|)

Attribute Name: core-dump

Attribute Type: string

Netconf RPC payload

```
<clear-core-dump xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-watchdog">
<core-dump>WORD</core-dump>
</clear-core-dump>
```

Command Syntax

```
clear cores (WORD|)
```

sys-update un-install

Netconf RPC payload

```
<sys-update-uninstall xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sys-
update"/>
```

Command Syntax

```
sys-update un-install
```

sys-container (raon) (install|update) file FILENAME

Attribute Name: type

Attribute Type: enum (raon)

Attribute Name: upgrade-type

Attribute Type: enum (install|update)

Attribute Name: file

Attribute Type: string

Netconf RPC payload

```
<sys-container-install xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sys-
update">
<type>raon</type>
<upgrade-type>install</upgrade-type>
<file>FILENAME</file>
</sys-container-install>
```

Command Syntax

```
sys-container (raon) (install|update) file FILENAME
```

sys-container (raon) un-install

Attribute Name: type

Attribute Type: enum (raon)

Attribute Name: un-install

Attribute Type: boolean

Default Value: false

Netconf RPC payload

```
<sys-container-uninstall xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sys-
update">
  <type>raon</type>
  <un-install>true</un-install/>
</sys-container-uninstall>
```

Command Syntax

```
sys-container (raon) un-install
```

sys-container (raon) (start|stop|restart)

Attribute Name: type

Attribute Type: enum (raon)

Attribute Name: boot-type

Attribute Type: enum (start|stop|restart)

Netconf RPC payload

```
<sys-container-boot xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sys-update">
  <type>raon</type>
  <boot-type>start</boot-type>
</sys-container-boot>
```

Command Syntax

```
sys-container (raon) (start|stop|restart)
```

sys-container (raon) get URL (source-interface IFNAME|)

Attribute Name: type

Attribute Type: enum (raon)

Attribute Name: url

Attribute Type: string

Attribute Name: source-interface

Attribute Type: string

Netconf RPC payload

```
<sys-container-get xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sys-update">
  <type>raon</type>
  <url>URL</url>
  <source-interface>IFNAME</source-interface>
</sys-container-get>
```

Command Syntax

```
sys-container (raon) get URL (source-interface IFNAME|)
```

sys-container (raon) remove file FILENAME

Attribute Name: type

Attribute Type: enum (raon)

Attribute Name: file

Attribute Type: string

Netconf RPC payload

```
<sys-container-remove xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sys-
update">
  <type>raon</type>
  <file>FILENAME</file>
</sys-container-remove>
```

Command Syntax

```
sys-container (raon) remove file FILENAME
```

sys-container (raon) verify image FILEPATH signature FILEPATH

Attribute Name: type

Attribute Type: enum (raon)

Attribute Name: image

Attribute Type: string

Attribute Name: signature

Attribute Type: string

Netconf RPC payload

```
<sys-container-verify xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sys-
update">
  <type>raon</type>
  <image>FILEPATH</image>
  <signature>FILEPATH</signature>
</sys-container-verify>
```

Command Syntax

```
sys-container (raon) verify image FILEPATH signature FILEPATH
```

sys-container cancel download

Netconf RPC payload

```
<sys-container-cancel-download xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-sys-update"/>
```

Command Syntax

```
sys-container cancel download
```

IPI-MRIB-IPV4

Configure options

Use this attribute to specify debug options

Attribute Name: options

Attribute Type: bits (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-msg|mrrib-msg|mtrace|mtrace-detail)

Netconf edit-config payload

```
<mrrib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mrrib">
  <ipv4>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <debug>
          <config>
            <options>all</options> <!-- operation="delete"-->
          </config>
        </debug>
      </vrf>
    </vrfs>
  </ipv4>
</mrrib>
```

Command Syntax

```
debug ip mrrib (vrf WORD|) (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-
msg|mrrib-msg|mtrace|mtrace-detail)
```

Configure multicast routing enable

Use this attribute to turn on/off multicast routing on the router when turned off, the multicast protocol daemon remains present, but does not perform multicast functions. When multicast routing is enabled, the MRIB re-creates tunnels, and starts processing any VIF addition/deletion requests, MRT addition/deletion requests, and any multicast forwarding events.

Attribute Name: multicast-routing-enable

Attribute Type: uint8

Netconf edit-config payload

```
<mrib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mrib">
  <ipv4>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
      </multicast-routing-enable><!-- operation="delete"-->
    </vrf>
  </vrfs>
</ipv4>
</mrib>
```

Command Syntax

```
ip multicast-routing (vrf WORD|)
```

Configure maximum routes

Use this attribute to limit the number of multicast routes that can be added to a multicast routing table. It generates an error message when the limit is exceeded.

Attribute Name: maximum-routes

Attribute Type: uint32

Attribute Range: 1-2147483647

Netconf edit-config payload

```
<mrib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mrib">
  <ipv4>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
          </config>
          <route-limit>
            <config>
              <maximum-routes>1</maximum-routes> <!-- operation="delete"-->
            </config>
          </route-limit>
        </config>
      </vrf>
    </vrfs>
  </ipv4>
</mrib>
```

```

</route-limit>
</vrf>
</vrfs>
</ipv4>
</mrib>

```

Command Syntax

```
ip multicast (vrf WORD|) route-limit <1-2147483647>
```

Configure warning threshold

Use this attribute to limit the number of multicast routes that can be added to a multicast routing table. It generates an error message when the limit is exceeded. If the threshold parameter is set, a threshold warning message is generated when this threshold is exceeded and the message continues to occur until the number of mroutes reaches the limit set by the limit argument.

Attribute Name: warning-threshold

Attribute Type: uint32

Attribute Range: 1-2147483647

Attribute Name: maximum-routes

Attribute Type: uint32

Attribute Range: 1-2147483647

Netconf edit-config payload

```

<mrib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mrib">
  <ipv4>
    <vrfs>
      <vrf>
        <vrf-name>WORD</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
          </config>
          <route-limit>
            <config>
              <maximum-routes>1</maximum-routes> <!-- operation="delete"-->
              <warning-threshold>1</warning-threshold> <!-- operation="delete"-->
            </config>
          </route-limit>
        </vrf>
      </vrfs>
    </ipv4>
  </mrib>

```

Command Syntax

```
ip multicast (vrf WORD|) route-limit <1-2147483647> <1-2147483647>
```

Configure ttl threshold

Use this attribute to configure the time-to-live (TTL) threshold of packets being forwarded out of an interface. Only multicast packets with a TTL value greater than the threshold are forwarded out of the interface.

Attribute Name: ttl-threshold

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<mrib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mrib">
  <ipv4>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
          </config>
          <ttl-threshold>1</ttl-threshold> <!-- operation="delete"-->
        </interface>
      </interfaces>
    </ipv4>
  </mrib>
```

Command Syntax

```
ip multicast ttl-threshold <1-255>
```

debug ip mrib (vrf WORD|) (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-msg|mrib-msg|mtrace|mtrace-detail)

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: terminal-debug-options

Attribute Type: bits (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-msg|mrib-msg|mtrace|mtrace-detail)

Netconf RPC payload

```
<ipi-mrib-ipv4_mrib-ipv4-terminal-debug-on xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-mrib">
  <vrf-name>WORD</vrf-name>
  <terminal-debug-options>all</terminal-debug-options>
</ipi-mrib-ipv4_mrib-ipv4-terminal-debug-on>
```

Command Syntax

```
debug ip mrib (vrf WORD|) (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-
msg|mrib-msg|mtrace|mtrace-detail)
```

no debug ip mrib (vrf WORD|) (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-msg|mrib-msg|mtrace|mtrace-detail)

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: terminal-debug-options

Attribute Type: bits (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-msg|mrib-msg|mtrace|mtrace-detail)

Netconf RPC payload

```
<ipi-mrib-ipv4_mrib-ipv4-terminal-debug-off xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-mrib">
  <vrf-name>WORD</vrf-name>
  <terminal-debug-options>all</terminal-debug-options>
</ipi-mrib-ipv4_mrib-ipv4-terminal-debug-off>
```

Command Syntax

```
no debug ip mrib (vrf WORD|) (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-
msg|mrib-msg|mtrace|mtrace-detail)
```

clear ip mroute (vrf NAME|) *

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: all-routes

Attribute Type: empty

Netconf RPC payload

```
<ipi-mrib-ipv4_mrib-ipv4-clear-mroute-all xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-mrib">
  <vrf-name>NAME</vrf-name>
  <all-routes>CML_EMPTY_T</all-routes>
</ipi-mrib-ipv4_mrib-ipv4-clear-mroute-all>
```

Command Syntax

```
clear ip mroute (vrf NAME|) *
```

clear ip mroute (vrf NAME|) A.B.C.D

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<ipi-mrib-ipv4_mrib-ipv4-clear-mroute-group xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-mrib">
```

```
<vrf-name>NAME</vrf-name>
<group-address>A.B.C.D</group-address>
</ipi-mrib-ipv4_mrib-ipv4-clear-mroute-group>
```

Command Syntax

```
clear ip mroute (vrf NAME|) A.B.C.D
```

clear ip mroute (vrf NAME|) A.B.C.D A.B.C.D

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Attribute Name: source-address

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<ipi-mrib-ipv4_mrib-ipv4-clear-mroute-source-group xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-mrib">
  <vrf-name>NAME</vrf-name>
  <group-address>A.B.C.D</group-address>
  <source-address>A.B.C.D</source-address>
</ipi-mrib-ipv4_mrib-ipv4-clear-mroute-source-group>
```

Command Syntax

```
clear ip mroute (vrf NAME|) A.B.C.D A.B.C.D
```

clear ip mroute (vrf NAME|) statistics *

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: all-routes

Attribute Type: empty

Netconf RPC payload

```
<ipi-mrib-ipv4_mrib-ipv4-clear-mroute-statistics-all xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-mrib">
  <vrf-name>NAME</vrf-name>
  <all-routes>CML_EMPTY_T</all-routes>
</ipi-mrib-ipv4_mrib-ipv4-clear-mroute-statistics-all>
```

Command Syntax

```
clear ip mroute (vrf NAME|) statistics *
```

clear ip mroute (vrf NAME|) statistics A.B.C.D

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<ipi-mrib-ipv4_mrib-ipv4-clear-mroute-statistics-group xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mrib">
  <vrf-name>NAME</vrf-name>
  <group-address>A.B.C.D</group-address>
</ipi-mrib-ipv4_mrib-ipv4-clear-mroute-statistics-group>
```

Command Syntax

```
clear ip mroute (vrf NAME|) statistics A.B.C.D
```

clear ip mroute (vrf NAME|) statistics A.B.C.D A.B.C.D

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Attribute Name: source-address

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<ipi-mrib-ipv4_mrib-ipv4-clear-mroute-statistics-source-group xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mrib">
  <vrf-name>NAME</vrf-name>
  <group-address>A.B.C.D</group-address>
  <source-address>A.B.C.D</source-address>
</ipi-mrib-ipv4_mrib-ipv4-clear-mroute-statistics-source-group>
```

Command Syntax

```
clear ip mroute (vrf NAME|) statistics A.B.C.D A.B.C.D
```

snmp restart mrib

Netconf RPC payload

```
<ipi-mrib-ipv4_mrib-ipv4-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mrib"/>
```

Command Syntax

```
snmp restart mrib
```

IPI-MRIB-IPV6

Configure options

Use this attribute to specify debug options

Attribute Name: options

Attribute Type: bits (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-msg|mrrib-msg|mtrace|mtrace-detail)

Netconf edit-config payload

```
<mrrib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mrrib">
  <ipv6>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <debug>
          <config>
            <options>all</options> <!-- operation="delete"-->
          </config>
        </debug>
      </vrf>
    </vrfs>
  </ipv6>
</mrrib>
```

Command Syntax

```
debug ipv6 mrrib (vrf NAME|) (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-
msg|mrrib-msg|mtrace|mtrace-detail)
```

Configure multicast routing enable

Use this attribute to turn on/off multicast routing on the router when turned off, the multicast protocol daemon remains present, but does not perform multicast functions. When multicast routing is enabled, the MRIB re-creates tunnels, and starts processing any VIF addition/deletion requests, MRT addition/deletion requests, and any multicast forwarding events.

Attribute Name: multicast-routing-enable

Attribute Type: uint8

Netconf edit-config payload

```
<mrrib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mrrib">
  <ipv6>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
```

```

    <config>
      <vrf-name>WORD</vrf-name>
    </config>
  </multicast-routing-enable><!-- operation="delete"-->
</vrf>
</vrf>
</vrf>
</vrf>
</vrf>
</mrib>

```

Command Syntax

```
ipv6 multicast-routing (vrf NAME|)
```

Configure maximum routes

Use this attribute to limit the number of multicast routes that can be added to a multicast routing table. It generates an error message when the limit is exceeded.

Attribute Name: maximum-routes

Attribute Type: uint32

Attribute Range: 1-2147483647

Netconf edit-config payload

```

<mrib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mrib">
  <ipv6>
    <vrf>
      <vrf-name>NAME</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
      </config>
      <route-limit>
        <config>
          <maximum-routes>1</maximum-routes> <!-- operation="delete"-->
        </config>
      </route-limit>
    </vrf>
  </vrf>
</ipv6>
</mrib>

```

Command Syntax

```
ipv6 multicast (vrf NAME|) route-limit <1-2147483647>
```

Configure warning threshold

Use this attribute to limit the number of multicast routes that can be added to a multicast routing table. It generates an error message when the limit is exceeded. If the threshold parameter is set, a threshold warning message is generated when this threshold is exceeded and the message continues to occur until the number of mroutes reaches the limit set by the limit argument.

Attribute Name: warning-threshold

Attribute Type: uint32

Attribute Range: 1-2147483647

Attribute Name: maximum-routes

Attribute Type: uint32

Attribute Range: 1-2147483647

Netconf edit-config payload

```
<mrib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mrib">
  <ipv6>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <route-limit>
          <config>
            <maximum-routes>1</maximum-routes> <!-- operation="delete"-->
            <warning-threshold>1</warning-threshold> <!-- operation="delete"-->
          </config>
        </route-limit>
      </vrf>
    </vrfs>
  </ipv6>
</mrib>
```

Command Syntax

```
ipv6 multicast (vrf NAME|) route-limit <1-2147483647> <1-2147483647>
```

debug ipv6 mrib (vrf WORD|) (all|event|vif|mrt|stats|fib-msg|register-msg|nsm- msg|mrib-msg|mtrace|mtrace-detail)

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: terminal-debug-options

Attribute Type: bits (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-msg|mrib-msg|mtrace|mtrace-detail)

Netconf RPC payload

```
<ipi-mrib-ipv6_mrib-ipv6-terminal-debug-on xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-mrib">
  <vrf-name>WORD</vrf-name>
  <terminal-debug-options>all</terminal-debug-options>
</ipi-mrib-ipv6_mrib-ipv6-terminal-debug-on>
```

Command Syntax

```
debug ipv6 mrib (vrf WORD|) (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-
msg|mrib-msg|mtrace|mtrace-detail)
```

no debug ipv6 mrib (vrf WORD|) (all|event|vif|mrt|stats|fib-msg|register- msg|nsm-msg|mrib-msg|mtrace|mtrace-detail)

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: terminal-debug-options

Attribute Type: bits (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-msg|mrib-msg|mtrace|mtrace-detail)

Netconf RPC payload

```
<ipi-mrib-ipv6_mrib-ipv6-terminal-debug-off xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-mrib">
  <vrf-name>WORD</vrf-name>
  <terminal-debug-options>all</terminal-debug-options>
</ipi-mrib-ipv6_mrib-ipv6-terminal-debug-off>
```

Command Syntax

```
no debug ipv6 mrib (vrf WORD|) (all|event|vif|mrt|stats|fib-msg|register-msg|nsm-
msg|mrib-msg|mtrace|mtrace-detail)
```

clear ipv6 mroute (vrf NAME|) *

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: all-routes

Attribute Type: empty

Netconf RPC payload

```
<ipi-mrib-ipv6_mrib-ipv6-clear-mroute-all xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-mrib">
  <vrf-name>NAME</vrf-name>
  <all-routes>CML_EMPTY_T</all-routes>
</ipi-mrib-ipv6_mrib-ipv6-clear-mroute-all>
```

Command Syntax

```
clear ipv6 mroute (vrf NAME|) *
```

clear ipv6 mroute (vrf NAME|) X:X::X:X

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: group-address

Attribute Type: inet:ipv6-address

Netconf RPC payload

```
<ipi-mrib-ipv6_mrib-ipv6-clear-mroute-group xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-mrib">
  <vrf-name>NAME</vrf-name>
  <group-address>X:X::X:X</group-address>
</ipi-mrib-ipv6_mrib-ipv6-clear-mroute-group>
```

Command Syntax

```
clear ipv6 mroute (vrf NAME|) X:X::X:X
```

clear ipv6 mroute (vrf NAME|) X:X::X:X X:X::X:X

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: group-address

Attribute Type: inet:ipv6-address

Attribute Name: source-address

Attribute Type: inet:ipv6-address

Netconf RPC payload

```
<ipi-mrib-ipv6_mrib-ipv6-clear-mroute-source-group xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-mrib">
  <vrf-name>NAME</vrf-name>
  <group-address>X:X::X:X</group-address>
  <source-address>X:X::X:X</source-address>
</ipi-mrib-ipv6_mrib-ipv6-clear-mroute-source-group>
```

Command Syntax

```
clear ipv6 mroute (vrf NAME|) X:X::X:X X:X::X:X
```

clear ipv6 mroute (vrf NAME|) statistics *

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: all-routes

Attribute Type: empty

Netconf RPC payload

```
<ipi-mrib-ipv6_mrib-ipv6-clear-mroute-statistics-all xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-mrib">
  <vrf-name>NAME</vrf-name>
  <all-routes>CML_EMPTY_T</all-routes>
</ipi-mrib-ipv6_mrib-ipv6-clear-mroute-statistics-all>
```

Command Syntax

```
clear ipv6 mroute (vrf NAME|) statistics *
```

clear ipv6 mroute (vrf NAME|) statistics X:X::X:X

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: group-address

Attribute Type: inet:ipv6-address

Netconf RPC payload

```
<ipi-mrib-ipv6_mrib-ipv6-clear-mroute-statistics-group xmlns="http://
www.ipinfusion.com/yāng/ocnos/ipi-mrib">
  <vrf-name>NAME</vrf-name>
  <group-address>X:X::X:X</group-address>
</ipi-mrib-ipv6_mrib-ipv6-clear-mroute-statistics-group>
```

Command Syntax

```
clear ipv6 mroute (vrf NAME|) statistics X:X::X:X
```

clear ipv6 mroute (vrf NAME|) statistics X:X::X:X X:X::X:X

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: group-address

Attribute Type: inet:ipv6-address

Attribute Name: source-address

Attribute Type: inet:ipv6-address

Netconf RPC payload

```
<ipi-mrib-ipv6_mrib-ipv6-clear-mroute-statistics-source-group xmlns="http://
www.ipinfusion.com/yāng/ocnos/ipi-mrib">
  <vrf-name>NAME</vrf-name>
  <group-address>X:X::X:X</group-address>
  <source-address>X:X::X:X</source-address>
</ipi-mrib-ipv6_mrib-ipv6-clear-mroute-statistics-source-group>
```

Command Syntax

```
clear ipv6 mroute (vrf NAME|) statistics X:X::X:X X:X::X:X
```

IPI-IGMP

Configure disable ssm map

Use this attribute to enable the IGMP operation on an interface. This command enables IGMP operation in standalone mode, and can be used to learn local-membership information prior to enabling a multicast routing protocol on the interface. This command will have no effect on interfaces configured for IGMP proxy.

Attribute Name: disable-ssm-map

Attribute Type: empty

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <vrfs>
    <vrf>
      <vrf-name>NAME</vrf-name>
      <config>
        <vrf-name>NAME</vrf-name>
      </config>
    </disable-ssm-map><!-- operation="delete"-->
  </vrf>
</vrfs>
</igmp>
```

Command Syntax

```
no ip igmp (vrf NAME|) ssm-map enable
```

Configure disable tos check

Use this attribute to disable TOS check for Internetwork Control

Attribute Name: disable-tos-check

Attribute Type: empty

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <vrfs>
    <vrf>
      <vrf-name>NAME</vrf-name>
      <config>
        <vrf-name>NAME</vrf-name>
      </config>
    </disable-tos-check><!-- operation="delete"-->
  </vrf>
</vrfs>
</igmp>
```

Command Syntax

```
no ip igmp (vrf NAME|) tos-check
```

Configure limit exception acl

Use this attribute to set the maximum number of group membership states, at either the router level or at the interface level. Once the specified number of group memberships is reached, all further local-memberships are ignored.

Optionally, an exception access-list can be configured to specify the group-address(es) to be excluded from being subject to the limit. This command applies to interfaces configured for IGMP Layer-3 multicast protocols and IGMP Proxy. The limit applies, individually, to each of its constituent interfaces.

Attribute Name: limit-exception-acl

Attribute Type: string

Attribute Name: member-limit

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-2097152

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <vrfs>
    <vrf>
      <vrf-name>NAME</vrf-name>
      <config>
        <vrf-name>NAME</vrf-name>
      </config>
    <group-membership-control>
      <config>
        <member-limit>1</member-limit> <!-- operation="delete"-->
        <limit-exception-acl>WORD</limit-exception-acl> <!-- operation="delete"-->
      </config>
    </group-membership-control>
  </vrf>
</vrfs>
</igmp>
```

Command Syntax

```
ip igmp (vrf NAME|) limit <1-2097152> (except WORD|)
```

Configure member limit

Use this attribute to set the maximum number of group membership states, at either the router level or at the interface level. Once the specified number of group memberships is reached, all further local-memberships are ignored. Optionally, an exception access-list can be configured to specify the group-address(es) to be excluded from being subject to the limit. This command applies to interfaces configured for IGMP Layer-3 multicast protocols and IGMP Proxy. The limit applies, individually, to each of its constituent interfaces.

Attribute Name: member-limit

Attribute Type: uint32

Default Value: 1

Attribute Range: 1-2097152

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <vrfs>
    <vrf>
      <vrf-name>NAME</vrf-name>
      <config>
        <vrf-name>NAME</vrf-name>
      </config>
    </vrf>
  </vrfs>
</igmp>
```

```
    </config>
  <group-membership-control>
    <config>
      <member-limit>1</member-limit> <!-- operation="delete"-->
    </config>
  </group-membership-control>
</vrf>
</vrfs>
</igmp>
```

Command Syntax

```
ip igmp (vrf NAME|) limit <1-2097152>
```

Configure source

Use this attribute to specify the static mode of defining SSM mapping. SSM mapping statically assigns sources to IGMPv1 and IGMPv2 groups to translate such (star G) groups memberships to (S,G) memberships for use with PIMSSM. This attribute applies to interfaces configured for IGMP Layer-3 multicast protocols and IGMP Proxy.

Attribute Name: source

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <vrfs>
    <vrf>
      <vrf-name>NAME</vrf-name>
      <config>
        <vrf-name>NAME</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <ssm>
    <static-mappings>
      <static-mapping> <!-- operation="delete"-->
        <source>A.B.C.D</source>
        <config>
          <source>A.B.C.D</source>
          <group-ranges-acl>WORD</group-ranges-acl>
        </config>
        <group-ranges-acl>WORD</group-ranges-acl>
      </static-mapping>
    </static-mappings>
  </ssm>
</igmp>
```

Command Syntax

```
ip igmp (vrf NAME|) ssm-map static WORD A.B.C.D
```

Configure options

Use this attribute to enable igmp debugging configurations

Attribute Name: options

Attribute Type: bits (all|decode|encode|events|fsm|tib)

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <vrfs>
    <vrf>
      <vrf-name>NAME</vrf-name>
      <config>
        <vrf-name>NAME</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <debug>
    <config>
      <options>all</options> <!-- operation="delete"-->
    </config>
  </debug>
</igmp>
```

Command Syntax

```
debug ip igmp (vrf NAME|) (all|decode|encode|events|fsm|tib)
```

debug ip igmp (vrf NAME|) (all|decode|encode|events|fsm|tib)

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Attribute Name: terminal-debug-options

Attribute Type: bits (all|decode|encode|events|fsm|tib)

Netconf RPC payload

```
<igmp-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <vrf-name>NAME</vrf-name>
  <terminal-debug-options>all</terminal-debug-options>
</igmp-terminal-debug-on>
```

Command Syntax

```
debug ip igmp (vrf NAME|) (all|decode|encode|events|fsm|tib)
```

no debug ip igmp (vrf NAME|) (all|decode|encode|events|fsm|tib)

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Attribute Name: terminal-debug-options

Attribute Type: bits (all|decode|encode|events|fsm|tib)

Netconf RPC payload

```
<igmp-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <vrf-name>NAME</vrf-name>
  <terminal-debug-options>all</terminal-debug-options>
</igmp-terminal-debug-off>
```

Command Syntax

```
no debug ip igmp (vrf NAME|) (all|decode|encode|events|fsm|tib)
```

clear ip igmp (vrf NAME|)

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Netconf RPC payload

```
<igmp-clear-all-groups-for-vrf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <vrf-name>NAME</vrf-name>
</igmp-clear-all-groups-for-vrf>
```

Command Syntax

```
clear ip igmp (vrf NAME|)
```

clear ip igmp (vrf NAME|) group *

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Attribute Name: clear-all

Attribute Type: empty

Netconf RPC payload

```
<igmp-clear-all-groups xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <vrf-name>NAME</vrf-name>
  <clear-all>CML_EMPTY_T</clear-all>
</igmp-clear-all-groups>
```

Command Syntax

```
clear ip igmp (vrf NAME|) group *
```

clear ip igmp (vrf NAME|) group A.B.C.D IFNAME

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Attribute Name: if-name

Attribute Type: string

Netconf RPC payload

```
<igmp-clear-group-on-interface xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <vrf-name>NAME</vrf-name>
  <group-address>A.B.C.D</group-address>
  <if-name>IFNAME</if-name>
</igmp-clear-group-on-interface>
```

Command Syntax

```
clear ip igmp (vrf NAME|) group A.B.C.D IFNAME
```

clear ip igmp (vrf NAME|) interface IFNAME

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Attribute Name: if-name

Attribute Type: string

Netconf RPC payload

```
<igmp-clear-all-groups-on-interface xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <vrf-name>NAME</vrf-name>
  <if-name>IFNAME</if-name>
</igmp-clear-all-groups-on-interface>
```

Command Syntax

```
clear ip igmp (vrf NAME|) interface IFNAME
```

clear ip igmp (vrf NAME|) group A.B.C.D

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<igmp-clear-group xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <vrf-name>NAME</vrf-name>
  <group-address>A.B.C.D</group-address>
</igmp-clear-group>
```

Command Syntax

```
clear ip igmp (vrf NAME|) group A.B.C.D
```

IPI-IGMP-INTERFACE

Configure enabled

Use this attribute to enable the IGMP operation on an interface. This attribute enables IGMP operation in standalone mode, and can be used to learn local-membership information prior to enabling a multicast routing protocol on the interface. This attribute will have no effect on interfaces configured for IGMP proxy

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </enabled><!-- operation="delete"-->
    </interface>
  </interfaces>
</igmp>
```

Command Syntax

```
ip igmp
```

Configure last member query count

Use this attribute to set the last-member query-count value. This attribute applies to interfaces configured for IGMP Layer-3 multicast protocols and IGMP Proxy.

Attribute Name: last-member-query-count

Attribute Type: uint8

Default Value: 2

Attribute Range: 2-7

Netconf edit-config payload

```

<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <last-member-query-count>2</last-member-query-count> <!-- operation="delete"-
->
    </interface>
  </interfaces>
</igmp>

```

Command Syntax

```
ip igmp last-member-query-count <2-7>
```

Configure last member query interval

Use this attribute to configure the frequency at which the router sends IGMP group-specific host query messages. This attribute applies to interfaces configured for IGMP Layer-3 multicast protocols and IGMP Proxy.

Attribute Name: last-member-query-interval

Attribute Type: uint16

Default Value: 1000

Attribute Range: 1000-25500

Netconf edit-config payload

```

<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <last-member-query-interval>1000</last-member-query-interval> <!--
operation="delete"-->
    </interface>
  </interfaces>
</igmp>

```

Command Syntax

```
ip igmp last-member-query-interval <1000-25500>
```

Configure querier timeout

Use this attribute to set the timeout period before the router takes over as the querier for the interface after the previous querier has stopped querying. This attribute applies to interfaces configured for IGMP Layer-3 multicast protocols and IGMP Proxy.

Attribute Name: querier-timeout

Attribute Type: uint16

Default Value: 255

Attribute Range: 60-300

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <querier-timeout>60</querier-timeout> <!-- operation="delete"-->
</interface>
</interfaces>
</igmp>
```

Command Syntax

```
ip igmp querier-timeout <60-300>
```

Configure query interval

Use this attribute to set the frequency of sending IGMP host query messages. This attribute applies to interfaces configured for IGMP Layer-3 multicast protocols and IGMP Proxy.

Attribute Name: query-interval

Attribute Type: uint16

Default Value: 125

Attribute Range: 1-18000

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <query-interval>1</query-interval> <!-- operation="delete"-->
</interface>
</interfaces>
</igmp>
```

Command Syntax

```
ip igmp query-interval <1-18000>
```

Configure query max response time

Use this attribute to set the maximum response time advertised in IGMP queries. This attribute applies to interfaces configured for IGMP Layer-3 multicast protocols and IGMP Proxy.

Attribute Name: query-max-response-time

Attribute Type: uint8

Default Value: 10

Attribute Range: 1-240

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
        </config>
        <query-max-response-time>1</query-max-response-time> <!-- operation="delete"-
->
      </interface>
    </interfaces>
  </igmp>
```

Command Syntax

```
ip igmp query-max-response-time <1-240>
```

Configure startup query interval

Use this attribute to set a query interval value for IGMP

Attribute Name: startup-query-interval

Attribute Type: uint16

Default Value: 31

Attribute Range: 1-18000

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
        </config>
        <startup-query-interval>1</startup-query-interval> <!-- operation="delete"-->
      </interface>
    </interfaces>
  </igmp>
```

Command Syntax

```
ip igmp startup-query-interval <1-18000>
```

Configure startup query count

Use this attribute to set a startup query count for IGMP

Attribute Name: startup-query-count

Attribute Type: uint8

Default Value: 2

Attribute Range: 2-10

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <startup-query-count>2</startup-query-count> <!-- operation="delete"-->
    </interface>
  </interfaces>
</igmp>
```

Command Syntax

```
ip igmp startup-query-count <2-10>
```

Configure robustness variable

Use this attribute to set the robustness variable value on an interface. This attribute applies to interfaces configured for IGMP Layer-3 multicast protocols and IGMP Proxy.

Attribute Name: robustness-variable

Attribute Type: uint8

Default Value: 2

Attribute Range: 2-7

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <robustness-variable>2</robustness-variable> <!-- operation="delete"-->
    </interface>
  </interfaces>
</igmp>
```

```
</interfaces>
</igmp>
```

Command Syntax

```
ip igmp robustness-variable <2-7>
```

Configure version

Use this attribute to set the current IGMP protocol version on an interface. This attribute applies to interfaces configured for IGMP Layer-3 multicast protocols and IGMP Proxy.

Attribute Name: version

Attribute Type: uint8

Default Value: 3

Attribute Range: 1-3

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <version>1</version> <!-- operation="delete"-->
</interface>
</interfaces>
</igmp>
```

Command Syntax

```
ip igmp version <1-3>
```

Configure require router alert option

Use this attribute to configure strict Router Advertisement validation for IGMP.

Attribute Name: require-router-alert-option

Attribute Type: empty

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </require-router-alert-option><!-- operation="delete"-->
</interface>
```

```
</interfaces>
</igmp>
```

Command Syntax

```
ip igmp ra-option
```

Configure allow offlink host

Use this attribute to configure off-link for IGMP.

Attribute Name: allow-offlink-host

Attribute Type: empty

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </allow-offlink-host><!-- operation="delete"-->
</interface>
</interfaces>
</igmp>
```

Command Syntax

```
ip igmp offlink
```

Configure enable proxy service

Use this attribute to designate an interface to be the IGMP proxy-service (upstream host-side) interface, thus enabling IGMP host-side protocol operation on this interface. All associated downstream router-side interfaces will have their memberships consolidated on this interface, according to IGMP host-side functionality

Attribute Name: enable-proxy-service

Attribute Type: empty

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <proxy>
  <config>
    </enable-proxy-service><!-- operation="delete"-->
  </config>
</interface>
</interfaces>
</igmp>
```

```

</proxy>
</interface>
</interfaces>
</igmp>

```

Command Syntax

```
ip igmp proxy-service
```

Configure mroute proxy interface

Use this attribute to specify the IGMP Proxy service interface with which to be associated. IGMP router-side protocol operation is enabled only when the specified upstream proxy-service interface is functional.

Attribute Name: mroute-proxy-interface

Attribute Type: string

Default Value: NULL

Netconf edit-config payload

```

<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <proxy>
      <config>
        <mroute-proxy-interface>IFNAME</mroute-proxy-interface> <!--
operation="delete"-->
      </config>
    </proxy>
  </interface>
</interfaces>
</igmp>

```

Command Syntax

```
ip igmp mroute-proxy IFNAME
```

Configure unsolicited report interval

Use this attribute to set an unsolicited report interval for an interface designated as an IGMP proxy

Attribute Name: unsolicited-report-interval

Attribute Type: uint16

Default Value: 1000

Attribute Range: 1000-25500

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
```

```
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <proxy>
  <config>
    <unsolicited-report-interval>1000</unsolicited-report-interval> <!--
operation="delete"-->
  </config>
</proxy>
</interface>
</interfaces>
</igmp>
```

Command Syntax

```
ip igmp proxy unsolicited-report-interval <1000-25500>
```

Configure limit exception acl

Use this attribute to set the maximum number of group membership states, at either the router level or at the interface level. Once the specified number of group memberships is reached, all further local-memberships are ignored. Optionally, an exception access-list can be configured to specify the group-address to be excluded from being subject to the limit.

Attribute Name: limit-exception-acl

Attribute Type: string

Attribute Name: member-limit

Attribute Type: uint32

Attribute Range: 1-2097152

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <group-membership-control>
  <config>
    <member-limit>1</member-limit> <!-- operation="delete"-->
    <limit-exception-acl>WORD</limit-exception-acl> <!-- operation="delete"--
>
  </config>
</group-membership-control>
</interface>
</interfaces>
</igmp>
```

Command Syntax

```
ip igmp limit <1-2097152> (except WORD|)
```

Configure member limit

Use this attribute to set the maximum number of group membership states, at either the router level or at the interface level. Once the specified number of group memberships is reached, all further local-memberships are ignored. Optionally, an exception access-list can be configured to specify the group-address to be excluded from being subject to the limit.

Attribute Name: member-limit

Attribute Type: uint32

Attribute Range: 1-2097152

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <group-membership-control>
        <config>
          <member-limit>1</member-limit> <!-- operation="delete"-->
        </config>
      </group-membership-control>
    </interface>
  </interfaces>
</igmp>
```

Command Syntax

```
ip igmp limit <1-2097152>
```

Configure access group name

Use this attribute to control the multicast local-membership groups learned on an interface. This attribute applies to interfaces configured for IGMP Layer-3 multicast protocols, IGMP proxy.

Attribute Name: access-group-name

Attribute Type: string

Default Value: NULL

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
```

```
        <name>WORD</name>
    </config>
    <group-membership-control>
    <config>
        <access-group-name>WORD</access-group-name> <!-- operation="delete"-->
    </config>
</group-membership-control>
</interface>
</interfaces>
</igmp>
```

Command Syntax

```
ip igmp access-group WORD
```

Configure immediate leave groups list

In IGMP version 2, use this attribute to minimize the leave latency of IGMP memberships. This attribute is used when only one receiver host is connected to each interface. This command applies to interfaces configured for IGMP Layer-3 multicast protocols, IGMP Proxy.

Attribute Name: immediate-leave-groups-list

Attribute Type: string

Default Value: NULL

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <group-membership-control>
      <config>
        <immediate-leave-groups-list>WORD</immediate-leave-groups-list> <!--
operation="delete"-->
      </config>
    </group-membership-control>
  </interface>
</interfaces>
</igmp>
```

Command Syntax

```
ip igmp immediate-leave group-list WORD
```

Configure group address

Use this attribute to statically configure group membership entries on an interface. To statically add only a group membership, do not specify any parameters. This attribute applies to IGMP operation on a specific interface to statically add group and/or source records on a VLAN interface to statically add group and/or source records.

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <asm-static-groups>
  <asm-static-group <!-- operation="delete"-->
    <group-address>A.B.C.D</group-address>
    <config>
      <group-address>A.B.C.D</group-address>
    </config>
  </asm-static-group>
</asm-static-groups>
</interface>
</interfaces>
</igmp>
```

Command Syntax

```
ip igmp static-group A.B.C.D
```

Configure source

Use this attribute to statically configure the group to be joined.

Attribute Name: source

Attribute Type: union

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <ssm-static-groups>
  <ssm-static-group <!-- operation="delete"-->
    <source>ssm-map</source>
    <config>
      <source>ssm-map</source>
      <group-address>A.B.C.D</group-address>
    </config>
    <group-address>A.B.C.D</group-address>
  </ssm-static-group>
</interfaces>
```

```
</ssm-static-groups>  
</interface>  
</interfaces>  
</igmp>
```

Command Syntax

```
ip igmp static-group A.B.C.D source (ssm-map|A.B.C.D)
```

Configure name

Use this attribute to configure a join multicast group.

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<igmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp">  
<interfaces>  
<interface>  
  <name>WORD</name>  
  <config>  
    <name>WORD</name>  
  </config>  
  <asm-join-groups>  
  <asm-join-group> <!-- operation="delete"-->  
    <group-address>A.B.C.D</group-address>  
    <config>  
      <group-address>A.B.C.D</group-address>  
    </config>  
  </asm-join-group>  
</asm-join-groups>  
</interface>  
</interfaces>  
</igmp>
```

Command Syntax

```
ip igmp join-group A.B.C.D
```

IPI-IGMP-SNOOPING

Configure disable igmp snooping

Use this attribute to disable IGMP Snooping. When this attribute is given in the Configure mode, IGMP snooping is enabled at switch level on all the vlans in switch. When this attribute is given at the VLAN interface level, IGMP Snooping is enabled for that VLAN.

Attribute Name: disable-igmp-snooping

Attribute Type: uint8

Netconf edit-config payload

```
<igmp-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
  <global>
  <config>
    </disable-igmp-snooping><!-- operation="delete"-->
  </config>
</global>
</igmp-snooping>
```

Command Syntax

```
no igmp snooping
```

Configure disable report suppression

Use this attribute to disable report suppression for IGMP version 1, 2 and 3 reports. By default report suppression is enabled.

Attribute Name: disable-report-suppression

Attribute Type: uint8

Netconf edit-config payload

```
<igmp-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
  <global>
  <config>
    </disable-report-suppression><!-- operation="delete"-->
  </config>
</global>
</igmp-snooping>
```

Command Syntax

```
no igmp snooping report-suppression
```

Configure unknown multicast action

Use this attribute to set the action to be taken on receiving I2 unknown multicast packets.

Attribute Name: unknown-multicast-action

Attribute Type: enum (flood|discard)

Default Value: flood

Netconf edit-config payload

```
<igmp-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
  <global>
  <config>
    <unknown-multicast-action>flood</unknown-multicast-action> <!--
operation="delete"-->
  </config>
</global>
</igmp-snooping>
```

Command Syntax

```
12 unknown mcast (flood|discard)
```

Configure options

Enable IGMP snooping debug

Attribute Name: options

Attribute Type: bits (decode|encode|events|fsm|tib|all)

Netconf edit-config payload

```
<igmp-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
<debug>
<config>
  <options>decode</options> <!-- operation="delete"-->
</config>
</debug>
</igmp-snooping>
```

Command Syntax

```
debug igmp snooping (decode|encode|events|fsm|tib|all)
```

Configure igmp snooping

Use this attribute to enable or disable IGMP Snooping. When this command is given at the VLAN interface level, IGMP Snooping is enabled for that VLAN.

Attribute Name: igmp-snooping

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<igmp-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <igmp-snooping>disable</igmp-snooping> <!-- operation="delete"-->
</interface>
</interfaces>
</igmp-snooping>
```

Command Syntax

```
no ip igmp snooping
```

Configure report suppression

Use this attribute to enable or disable report suppression for IGMP version 1, 2 and 3 reports. By default report suppression is enabled.

Attribute Name: report-suppression

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<igmp-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <report-suppression>disable</report-suppression> <!-- operation="delete"-->
    </interface>
  </interfaces>
</igmp-snooping>
```

Command Syntax

```
no ip igmp snooping report-suppression
```

Configure enable fast leave

Use this attribute to enable IGMP Snooping fast-leave processing. Fast-leave processing is analogous to immediateleave processing the IGMP group-membership is removed, as soon as an IGMP leave group message is received without sending out a group-specific query

Attribute Name: enable-fast-leave

Attribute Type: uint8

Netconf edit-config payload

```
<igmp-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </enable-fast-leave><!-- operation="delete"-->
    </interface>
  </interfaces>
</igmp-snooping>
```

Command Syntax

```
ip igmp snooping fast-leave
```

Configure mrouter interface name

Use this attribute to statically configure the specified VLAN constituent interface as a multicast router interface for IGMP Snooping in that VLAN.

Attribute Name: mrouter-interface-name

Attribute Type: string

Netconf edit-config payload

```
<igmp-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <mrouter-interface-name>IFNAME</mrouter-interface-name> <!-- operation="delete"-
->
    </interface>
  </interfaces>
</igmp-snooping>
```

Command Syntax

```
ip igmp snooping mrouter interface IFNAME
```

Configure enable querier

Use this attribute to enable IGMP snooping querier functionality on a VLAN when IGMP is not enabled on the particular VLAN. When enabled, the IGMP Snooping querier sends out periodic IGMP queries for all interfaces on that VLAN. The IGMP Snooping querier uses the 0.0.0.0 source IP address, because it only masquerades as a proxy IGMP querier for faster network convergence. It does not start, or automatically cease, the IGMP Querier operation if it detects query message(s) from a multicast router. It restarts as the IGMP Snooping querier if no queries are seen within the other querier interval.

Attribute Name: enable-querier

Attribute Type: uint8

Netconf edit-config payload

```
<igmp-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </enable-querier><!-- operation="delete"-->
    </interface>
  </interfaces>
</igmp-snooping>
```

Command Syntax

```
ip igmp snooping querier
```

Configure name

Use this attribute to enable or disable IGMP Snooping. When this command is given at the VLAN interface level, IGMP Snooping is enabled for that VLAN.

Attribute Name: igmp-snooping

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<igmp-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <igmp-snooping>disable</igmp-snooping> <!-- operation="delete"-->
</interface>
</interfaces>
</igmp-snooping>
```

Command Syntax

```
igmp snooping (disable|enable)
```

Configure source address

Use this attribute to set the Source Address to be joined

Attribute Name: source-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<igmp-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<static-groups>
<ssm-groups>
<ssm-group>
  <interface-name>IFNAME</interface-name>
  <config>
    <interface-name>IFNAME</interface-name>
    <source-address>A.B.C.D</source-address>
    <group-address>A.B.C.D</group-address>
```

```
</config>
  <source-address>A.B.C.D</source-address>
  <group-address>A.B.C.D</group-address>
</ssm-group>
</ssm-groups>
</static-groups>
</interface>
</interfaces>
</igmp-snooping>
```

Command Syntax

```
igmp snooping static-group A.B.C.D source A.B.C.D interface IFNAME
```

Configure group address

Use this attribute to set the static group-address to be joined

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<igmp-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <static-groups>
    <ssm-groups>
    <ssm-group>
      <interface-name>IFNAME</interface-name>
      <config>
        <interface-name>IFNAME</interface-name>
        <source-address>A.B.C.D</source-address>
        <group-address>A.B.C.D</group-address>
      </config>
      <source-address>A.B.C.D</source-address>
      <group-address>A.B.C.D</group-address>
    </ssm-group>
  </ssm-groups>
</static-groups>
</interface>
</interfaces>
</igmp-snooping>
```

Command Syntax

```
igmp snooping static-group A.B.C.D interface IFNAME
```

clear igmp snooping group A.B.C.D IFNAME

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Attribute Name: interface-name

Attribute Type: string

Netconf RPC payload

```
<igmp-snooping-clear-group-interface xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
  <group-address>A.B.C.D</group-address>
  <interface-name>IFNAME</interface-name>
</igmp-snooping-clear-group-interface>
```

Command Syntax

```
clear igmp snooping group A.B.C.D IFNAME
```

clear igmp snooping interface IFNAME

Attribute Name: interface-name

Attribute Type: string

Netconf RPC payload

```
<igmp-snooping-clear-interface xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
  <interface-name>IFNAME</interface-name>
</igmp-snooping-clear-interface>
```

Command Syntax

```
clear igmp snooping interface IFNAME
```

clear igmp snooping group *

Netconf RPC payload

```
<igmp-snooping-clear-group-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping"/>
```

Command Syntax

```
clear igmp snooping group *
```

clear igmp snooping

Netconf RPC payload

```
<igmp-snooping-clear-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping"/>
```

Command Syntax

```
clear igmp snooping
```

clear igmp snooping group A.B.C.D

Attribute Name: group-address

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<igmp-snooping-clear-group xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
  <group-address>A.B.C.D</group-address>
</igmp-snooping-clear-group>
```

Command Syntax

```
clear igmp snooping group A.B.C.D
```

debug igmp snooping (decode|encode|events|fsm|tib|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (decode|encode|events|fsm|tib|all)

Netconf RPC payload

```
<igmp-snooping-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
  <terminal-debug-options>decode</terminal-debug-options>
</igmp-snooping-terminal-debug-on>
```

Command Syntax

```
debug igmp snooping (decode|encode|events|fsm|tib|all)
```

no debug igmp snooping (decode|encode|events|fsm|tib|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (decode|encode|events|fsm|tib|all)

Netconf RPC payload

```
<igmp-snooping-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-igmp-snooping">
  <terminal-debug-options>decode</terminal-debug-options>
</igmp-snooping-terminal-debug-off>
```

Command Syntax

```
no debug igmp snooping (decode|encode|events|fsm|tib|all)
```

IPI-MLD-SNOOPING

Configure disable mld snooping

Use this attribute to enable MLD Snooping. When this command is given in the Configure mode, MLD Snooping is enabled at the switch level. When this attribute is given at the VLAN interface level, 5MLD Snooping is enabled for that VLAN.

Attribute Name: disable-mld-snooping

Attribute Type: uint8

Netconf edit-config payload

```
<mld-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping">
  <global>
    <config>
      </disable-mld-snooping><!-- operation="delete"-->
    </config>
  </global>
</mld-snooping>
```

Command Syntax

```
no mld snooping
```

Configure disable report suppression

Use this attribute to enable report suppression for MLD version 1.

Attribute Name: disable-report-suppression

Attribute Type: uint8

Netconf edit-config payload

```
<mld-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping">
  <global>
    <config>
      </disable-report-suppression><!-- operation="delete"-->
    </config>
  </global>
</mld-snooping>
```

Command Syntax

```
no mld snooping report-suppression
```

Configure options

Use this attribute to enable mld snooping debugging configurations

Attribute Name: options

Attribute Type: bits (decode|encode|events|fsm|tib|all)

Netconf edit-config payload

```
<mld-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping">
  <debug>
  <config>
    <options>decode</options> <!-- operation="delete"-->
  </config>
</debug>
</mld-snooping>
```

Command Syntax

```
debug mld snooping (decode|encode|events|fsm|tib|all)
```

Configure report suppression

Use this attribute to enable or disable report suppression for MLD version 1, and 2 reports. By default report suppression is enabled.

Attribute Name: report-suppression

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<mld-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping">
  <interfaces>
  <interface>
    <name>WORD</name>
    <config>
      <name>WORD</name>
      <report-suppression>disable</report-suppression> <!-- operation="delete"-->
    </interface>
  </interfaces>
</mld-snooping>
```

Command Syntax

```
no mld snooping report-suppression
```

Configure mld snooping

Use this attribute to enable MLD Snooping. When this attribute is given at the VLAN interface level, MLD Snooping is enabled for that VLAN.

Attribute Name: mld-snooping

Attribute Type: enum (disable|enable)

Default Value: enable

Netconf edit-config payload

```
<mld-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping">
  <interfaces>
  <interface>
```

```
<name>WORD</name>
<config>
  <name>WORD</name>
</config>
<mld-snooping>enable</mld-snooping> <!-- operation="delete"-->
</interface>
</interfaces>
</mld-snooping>
```

Command Syntax

```
mld snooping (disable|enable)
```

Configure enable fast leave

Use this attribute to enable MLD Snooping fast-leave processing. Fast-leave processing is analogous to immediateleave processing the MLD group-membership is removed, as soon as an MLD leave group message is received without sending out a group-specific query.

Attribute Name: enable-fast-leave

Attribute Type: empty

Netconf edit-config payload

```
<mld-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </enable-fast-leave><!-- operation="delete"-->
</interface>
</interfaces>
</mld-snooping>
```

Command Syntax

```
mld snooping fast-leave
```

Configure name

Use this attribute to enable or disable report suppression for MLD version 1, and 2 reports. By default report suppression is enabled.

Attribute Name: report-suppression

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<mld-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping">
<interfaces>
<interface>
  <name>WORD</name>
```

```
<config>
  <name>WORD</name>
</config>
<report-suppression>disable</report-suppression> <!-- operation="delete"-->
</interface>
</interfaces>
</mld-snooping>
```

Command Syntax

```
mld snooping report-suppression (disable|enable)
```

Configure mrouter interface name

Use this attribute to statically configure the specified VLAN constituent interface as a multicast router interface for MLD Snooping in that VLAN

Attribute Name: mrouter-interface-name

Attribute Type: string

Netconf edit-config payload

```
<mld-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
    <mrouter-interface-name>IFNAME</mrouter-interface-name> <!-- operation="delete"-
->
  </interface>
</interfaces>
</mld-snooping>
```

Command Syntax

```
mld snooping mrouter interface IFNAME
```

Configure enable querier

Use this attribute to enable MLD querier operation on a subnet (VLAN) when no multicast routing protocol is configured in the subnet VLAN. When enabled, the MLD Snooping querier sends out periodic MLD queries for all interfaces on that VLAN. The MLD Snooping querier uses the 0.0.0.0 source IP address, because it masquerades as a proxy MLD querier for faster network convergence. It does not start or automatically cease the MLD querier operation if it detects a query message from a multicast router. It restarts as MLD snooping querier if no queries are seen within another querier interval

Attribute Name: enable-querier

Attribute Type: empty

Netconf edit-config payload

```
<mld-snooping xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping">
<interfaces>
```

```
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </enable-querier><!-- operation="delete"-->
</interface>
</interfaces>
</mld-snooping>
```

Command Syntax

```
mld snooping querier
```

debug mld snooping (decode|encode|events|fsm|tib|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (decode|encode|events|fsm|tib|all)

Netconf RPC payload

```
<mld-snooping-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
mld-snooping">
  <terminal-debug-options>decode</terminal-debug-options>
</mld-snooping-terminal-debug-on>
```

Command Syntax

```
debug mld snooping (decode|encode|events|fsm|tib|all)
```

no debug mld snooping (decode|encode|events|fsm|tib|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (decode|encode|events|fsm|tib|all)

Netconf RPC payload

```
<mld-snooping-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-mld-snooping">
  <terminal-debug-options>decode</terminal-debug-options>
</mld-snooping-terminal-debug-off>
```

Command Syntax

```
no debug mld snooping (decode|encode|events|fsm|tib|all)
```

clear mld snooping group X:X::X:X IFNAME

Attribute Name: group-address

Attribute Type: string

Attribute Name: interface-name

Attribute Type: string

Netconf RPC payload

```
<mld-snooping-clear-group-on-interface xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping">
  <group-address>X:X::X:X</group-address>
  <interface-name>IFNAME</interface-name>
</mld-snooping-clear-group-on-interface>
```

Command Syntax

```
clear mld snooping group X:X::X:X IFNAME
```

clear mld snooping interface IFNAME

Attribute Name: interface-name

Attribute Type: string

Netconf RPC payload

```
<mld-snooping-clear-all-groups-on-interface xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping">
  <interface-name>IFNAME</interface-name>
</mld-snooping-clear-all-groups-on-interface>
```

Command Syntax

```
clear mld snooping interface IFNAME
```

clear mld snooping group X:X::X:X

Attribute Name: group-address

Attribute Type: string

Netconf RPC payload

```
<mld-snooping-clear-group xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping">
  <group-address>X:X::X:X</group-address>
</mld-snooping-clear-group>
```

Command Syntax

```
clear mld snooping group X:X::X:X
```

clear mld snooping group *

Netconf RPC payload

```
<mld-snooping-clear-all-groups xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping"/>
```

Command Syntax

```
clear mld snooping group *
```

clear mld snooping

Netconf RPC payload

```
<mld-snooping-clear-all-groups-alias xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mld-snooping"/>
```

Command Syntax

```
clear mld snooping
```

IPI-ROTEMAP

Configure action

Use this attribute to enter the route-map mode and to permit or deny match/set operations. If deny is specified, and the match criteria are met, the route is not redistributed, and any other route maps with the same map tag are not examined. If permit is specified, and the match criteria are met, the route is redistributed as specified by the set actions. If the match criteria are not met, the next route map with the same tag is tested.

Attribute Name: action

Attribute Type: enum (permit|deny)

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
    <action>permit</action>
  </routemap>
</routemaps>
```

Command Syntax

```
route-map WORD ((permit|deny)|) (<1-65535>|)
```

Configure continue to next sequence

The continue clause provides the capability to execute additional entries in a route map after an entry is executed with a successful match and set clauses. Example: the continue command allows multiple entries to be evaluated within a single route-map.

Attribute Name: continue-to-next-sequence

Attribute Type: empty

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
```

```
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<continue-on-match>
<config>
  </continue-to-next-sequence><!-- operation="delete"-->
</config>
</continue-on-match>
</routemap>
</routemaps>
```

Command Syntax

continue

Configure next sequence number

Continue commands can be assigned optional sequence numbers that indicate the order in which clauses are to be evaluated.

Attribute Name: next-sequence-number

Attribute Type: uint32

Attribute Range: 2-65535

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<continue-on-match>
<config>
  <next-sequence-number>2</next-sequence-number> <!-- operation="delete"-->
</config>
</continue-on-match>
</routemap>
</routemaps>
```

Command Syntax

continue <2-65535>

Configure interface name

Use this attribute to define the interface match criterion. This command specifies the next-hop interface name of a route to be matched

Attribute Name: interface-name

Attribute Type: string

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<config>
  <interface-name>IFNAME</interface-name> <!-- operation="delete"-->
</config>
</match-condition>
</routemap>
</routemaps>
```

Command Syntax

```
match interface IFNAME
```

Configure metric

Use this attribute to match a metric of a route. The route specified by the policies might not be the same as specified by the routing protocols. Setting policies enable packets to take different routes depending on their length or content. Packet forwarding based on configured policies overrides packet forwarding specified in routing tables.

Attribute Name: metric

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<config>
  <metric>1</metric> <!-- operation="delete"-->
</config>
```

```
</config>
</match-condition>
</routemap>
</routemaps>
```

Command Syntax

```
match metric <1-4294967295>
```

Configure vlan id

use this attribute to set match entry traffic based on a VLAN

Attribute Name: vlan-id

Attribute Type: string

Attribute Range: 1-4094

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
</match-condition>
<config>
  <vlan-id>VLAN</vlan-id> <!-- operation="delete"-->
</config>
</match-condition>
</routemap>
</routemaps>
```

Command Syntax

```
match vlan VLAN
```

Configure mac access list name

use this attribute to set the match entry for mac-access list

Attribute Name: mac-access-list-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
```

```

    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<config>
    <mac-access-list-name>WORD</mac-access-list-name> <!-- operation="delete"-->
</config>
</match-condition>
</routemap>
</routemaps>

```

Command Syntax

```
match mac-list WORD
```

Configure tag

Use this command to set a tag value. The parameter is the route tag that is labeled by another routing protocol (BGP or other IGP when redistributing), because AS-external-LSA has a route-tag field in its LSAs. In addition, when using route-map, OcNOS can tag the LSAs with the appropriate tag value. Sometimes the tag matches with using route-map and sometimes, the value may be used by another application.

Attribute Name: tag

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```

<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
  <match-condition>
  <config>
    <tag>1</tag> <!-- operation="delete"-->
  </config>
  </match-condition>
</routemap>
</routemaps>

```

Command Syntax

```
match tag <1-4294967295>
```

Configure route type

Use this attribute to match an external route type. AS-external LSA is either Type-1 or Type-2. External type-1 matches only Type 1 external routes and external type-2 matches only Type 2 external routes.

Attribute Name: route-type

Attribute Type: enum (type-1|type-2)

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<config>
  <route-type>type-1</route-type> <!-- operation="delete"-->
</config>
</match-condition>
</routemap>
</routemaps>
```

Command Syntax

```
match route-type external (type-1|type-2)
```

Configure as path name

Use this command to match an autonomous system path access list. This command specifies the autonomous system path to be matched. If there is a match for the specified AS path, and permit is specified, the route is redistributed or controlled, as specified by the set action. If the match criteria are met, and deny is specified, the route is not redistributed or controlled. If the match criteria are not met then the route is neither accepted nor forwarded, irrespective of permit or deny specifications. The route specified by the policies might not be the same as specified by the routing protocols. Setting policies enable packets to take different routes, depending on their length or content. Packet forwarding based on configured policies overrides packet forwarding specified in routing tables.

Attribute Name: as-path-name

Attribute Type: string

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<config>
  <as-path-name>WORD</as-path-name> <!-- operation="delete"-->
</config>
</match-condition>
```

```
</routemap>
</routemaps>
```

Command Syntax

```
match as-path WORD
```

Configure route origin

Use this attribute to match origin code. The origin attribute defines the origin of the path information. The `egp` parameter is indicated as an `e` in the routing table, and it indicates that the origin of the information is learned via EGP (Exterior Gateway Protocol). The `igp` parameter is indicated as an `i` in the routing table, and it indicates the origin of the path information is interior to the originating AS. The `incomplete` parameter is indicated as a `?` in the routing table, and indicates that the origin of the path information is unknown or learned through other means. If a static route is redistributed into BGP, the origin of the route is incomplete. This command specifies the origin to be matched. If there is a match for the specified origin, and `permit` is specified when you created the route-map, the route is redistributed or controlled as specified by the `set` action. If the match criteria are met, and `deny` is specified, the route is not redistributed or controlled. If the match criteria are not met, the route is neither accepted nor forwarded, irrespective of `permit` or `deny` specifications. The route specified by the policies might not be the same as specified by the routing protocols. Setting policies enable packets to take different routes depending on their length or content. Packet forwarding based on configured policies overrides packet forwarding specified in routing tables

Attribute Name: `route-origin`

Attribute Type: enum (`egp|igp|incomplete`)

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
</match-condition>
<config>
  <route-origin>egp</route-origin> <!-- operation="delete"-->
</config>
</match-condition>
</routemap>
</routemaps>
```

Command Syntax

```
match origin (egp|igp|incomplete)
```

Configure packet max length

use this attribute to set match community maximum length

This command is supported when following feature are enabled PBR feature

Attribute Name: `packet-max-length`

Attribute Type: uint16

Attribute Range: 0-65535

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<route-filter>
<packet-length-constraints> <!-- operation="delete"-->
  <packet-max-length>0</packet-max-length>
  <config>
    <packet-max-length>0</packet-max-length>
    <packet-min-length>0</packet-min-length>
  </config>
  <packet-min-length>0</packet-min-length>
</packet-length-constraints>
</route-filter>
</match-condition>
</routemap>
</routemaps>
```

Command Syntax

```
match length <0-65535> <0-65535>
```

Configure community identifier

Use this attribute to specify the community to be matched. Communities are used to group and filter routes. They are designed to provide the ability to apply policies to large numbers of routes by using match and set commands. Community lists are used to identify and filter routes by their common attributes. This command allows the matching based on community lists. The values set by the match community command overrides the global values. The route that does not match at least one match clause is ignored.

Attribute Name: community-identifier

Attribute Type: union

Attribute Name: match-type

Attribute Type: enum (no-exact-match|exact-match)

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
```



```

    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<communities>
<community> <!-- operation="delete"-->
  <community-identifier>RMAP_COMMUNITY_STRING_T</community-identifier>
  <config>
    <community-identifier>RMAP_COMMUNITY_STRING_T</community-identifier>
    <match-type>no-exact-match</match-type>
  </config>
</community>
</communities>
</match-condition>
</routemap>
</routemaps>

```

Command Syntax

```
match community (WORD|<1-99>|<100-500>) ((exact-match)|)
```

Configure extended community identifier

Use this attribute to match BGP external community list. Communities are used to group and filter routes. They are designed to provide the ability to apply policies to large numbers of routes by using match and set commands. Community lists are used to identify and filter routes by their common attributes. This command allows the matching based on community lists. The values set by this command overrides the global values. The route that does not match at least one match clause is ignored

Attribute Name: extended-community-identifier

Attribute Type: union

Attribute Name: match-type

Attribute Type: enum (no-exact-match|exact-match)

Netconf edit-config payload

```

<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
  <match-condition>
  <extended-communities>
  <extended-community> <!-- operation="delete"-->
    <extended-community-identifier>RMAP_COMMUNITY_STRING_T</extended-community-
identifier>
    <config>
      <extended-community-identifier>RMAP_COMMUNITY_STRING_T</extended-community-
identifier>

```

```
        <match-type>no-exact-match</match-type>
    </config>
</extended-community>
</extended-communities>
</match-condition>
</routemap>
</routemaps>
```

Command Syntax

```
match extcommunity (WORD|<1-99>|<100-500>) ((exact-match)|)
```

Configure match type

Do exact matching of communities

Attribute Name: match-type

Attribute Type: enum (no-exact-match|exact-match)

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<extended-communities>
<extended-community>
  <extended-community-identifier>RMAP_COMMUNITY_STRING_T</extended-community-
identifier>
  <config>
    <extended-community-identifier>RMAP_COMMUNITY_STRING_T</extended-community-
identifier>
  </config>
  <match-type>0</match-type> <!-- operation="delete"-->
</extended-community>
</extended-communities>
</match-condition>
</routemap>
</routemaps>
```

Command Syntax

```
no match extcommunity exact-match
```

Configure ip access list name

Use this attribute to specify the match address of route. If there is a match for the specified IP address, and permit is specified, the route is redistributed or controlled, as specified by the set action. If the match criteria are met, and deny

is specified then the route is not redistributed or controlled. If the match criteria are not met, the route is neither accepted nor forwarded, irrespective of permit or deny specifications. The route specified by the policies might not be the same as specified by the routing protocols. Setting policies enable packets to take different routes, depending on their length or content. Packet forwarding based on configured policies overrides packet forwarding specified in routing tables.

Attribute Name: ip-access-list-name

Attribute Type: string

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<ipv4>
<config>
  <ip-access-list-name>WORD</ip-access-list-name> <!-- operation="delete"-->
</config>
</ipv4>
</match-condition>
</routemap>
</routemaps>
```

Command Syntax

```
match ip address WORD
```

Configure ip prefix list name

Use this attribute to match entries of a prefix-list. The route specified by the policies might not be the same as specified by the routing protocols. Setting policies enable packets to take different routes depending on their length or content. Packet forwarding based on configured policies overrides packet forwarding specified in routing tables.

Attribute Name: ip-prefix-list-name

Attribute Type: string

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<ipv4>
```

```
<config>
  <ip-prefix-list-name>WORD</ip-prefix-list-name> <!-- operation="delete"-->
</config>
</ipv4>
</match-condition>
</routemap>
</routemaps>
```

Command Syntax

```
match ip address prefix-list WORD
```

Configure peer access list name

Use this attribute to specify the match peer IPv4 address of a route.

Attribute Name: peer-access-list-name

Attribute Type: string

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<ipv4>
<config>
  <peer-access-list-name>WORD</peer-access-list-name> <!-- operation="delete"-->
>
</config>
</ipv4>
</match-condition>
</routemap>
</routemaps>
```

Command Syntax

```
match ip peer WORD
```

Configure next hop prefix list name

Use this attribute to specify the next-hop IP address match criterion using the prefix-list. This command matches the next-hop IP address of a route.

Attribute Name: next-hop-prefix-list-name

Attribute Type: string

Netconf edit-config payload

```

<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<ipv4>
<config>
  <next-hop-prefix-list-name>WORD</next-hop-prefix-list-name> <!--
operation="delete"-->
</config>
</ipv4>
</match-condition>
</routemap>
</routemaps>

```

Command Syntax

```
match ip next-hop prefix-list WORD
```

Configure next hop access list name

Use this attribute to specify a next-hop address to be matched in a route-map. The route specified by the policies might not be the same as specified by the routing protocols. Setting policies enable packets to take different routes depending on their length or content. Packet forwarding based on configured policies overrides packet forwarding specified in routing tables.

Attribute Name: next-hop-access-list-name

Attribute Type: string

Netconf edit-config payload

```

<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<ipv4>
<config>
  <next-hop-access-list-name>WORD</next-hop-access-list-name> <!--
operation="delete"-->
</config>
</ipv4>
</match-condition>
</routemap>

```

```
</routemaps>
```

Command Syntax

```
match ip next-hop WORD
```

Configure ipv6 address access list name

Use this attribute to specify the match address of route. The route specified by the policies might not be the same as specified by the routing protocols. Setting policies enable packets to take different routes depending on their length or content. Packet forwarding based on configured policies overrides packet forwarding specified in routing tables

This command is supported when following feature are enabled IPV6 feature

Attribute Name: ipv6-address-access-list-name

Attribute Type: string

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
  <match-condition>
    <ipv6>
      <config>
        <ipv6-address-access-list-name>WORD</ipv6-address-access-list-name> <!--
operation="delete"-->
      </config>
    </ipv6>
  </match-condition>
</routemap>
</routemaps>
```

Command Syntax

```
match ipv6 address WORD
```

Configure ipv6 prefix list name

Use this attribute to match entries of a prefix-list. The route specified by the policies might not be the same as specified by the routing protocols. Setting policies enable packets to take different routes, depending on their length or content. Packet forwarding based on configured policies overrides packet forwarding specified in routing tables.

This command is supported when following feature are enabled IPV6 feature

Attribute Name: ipv6-prefix-list-name

Attribute Type: string

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
```

```

<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<ipv6>
<config>
  <ipv6-prefix-list-name>WORD</ipv6-prefix-list-name> <!-- operation="delete"--
>
</config>
</ipv6>
</match-condition>
</routemap>
</routemaps>

```

Command Syntax

```
match ipv6 address prefix-list WORD
```

Configure routemap name

Use this attribute to specify the match peer IPv6 address of a route.

This command is supported when following feature are enabled IPV6 feature

Attribute Name: peer-access-list-name

Attribute Type: string

Netconf edit-config payload

```

<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<ipv6>
<config>
  <peer-access-list-name>WORD</peer-access-list-name> <!-- operation="delete"--
>
</config>
</ipv6>
</match-condition>
</routemap>
</routemaps>

```

Command Syntax

```
match ipv6 peer WORD
```

Configure sequence id

Use this attribute to match entries of a prefix-list. The route specified by the policies might not be the same as specified by the routing protocols. Setting policies enable packets to take different routes depending on their length or content. Packet forwarding based on configured policies overrides packet forwarding specified in routing tables.

This command is supported when following feature are enabled IPV6 feature

Attribute Name: next-hop-prefix-list-name

Attribute Type: string

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
  <match-condition>
    <ipv6>
      <config>
        <next-hop-prefix-list-name>WORD</next-hop-prefix-list-name> <!--
operation="delete"-->
      </config>
    </ipv6>
  </match-condition>
</routemap>
</routemaps>
```

Command Syntax

```
match ipv6 next-hop prefix-list WORD
```

Configure next hop match string

Use this attribute to specify the next-hop address to be matched. The route specified by the policies might not be the same as specified by the routing protocols. Setting policies enable packets to take different routes depending on their length or content. Packet forwarding based on configured policies overrides packet forwarding specified in routing tables.

This command is supported when following feature are enabled IPV6 feature

Attribute Name: next-hop-match-string

Attribute Type: union

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
```

```

<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<ipv6>
<config>
  <next-hop-match-string>RMAP_IPV6_NEXTHOP_T</next-hop-match-string>
</config>
</ipv6>
</match-condition>
</routemap>
</routemaps>

```

Command Syntax

```
match ipv6 next-hop (WORD|X:X::X:X)
```

Configure large community number match

Use this attributes to set the communities attribute. and group destinations in a certain community, as well as apply routing decisions according to those communities.

Attribute Name: large-community-number-match

Attribute Type: string

Netconf edit-config payload

```

<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<match-condition>
<large-match-community>
<config>
  <large-community-number-match>XXX:YYYY:ZZZ</large-community-number-match> <!--
- operation="delete"-->
  </config>
</large-match-community>
</match-condition>
</routemap>
</routemaps>

```

Command Syntax

```
match large-community [XXX:YYYY:ZZZ]
```

Configure metric value

Use this command to set a metric value for a route and influence external neighbors about the preferred path into an Autonomous System (AS). The preferred path is the one with a lower metric value. A router compares metrics for paths from neighbors in the same ASs. To compare metrics from neighbors coming from different ASs, use the `bgp always-compare-med` command. To use this command, you must first have a match clause. Match and set commands set the conditions for redistributing routes from one routing protocol to another. The match command specifies the match criteria under which redistribution is allowed for the current route-map. The set command specifies the set redistribution actions to be performed, if the match criteria are met. If the packets do not match any of the defined criteria, they are routed through the normal routing process.

Attribute Name: `metric-value`

Attribute Type: string

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<config>
  <metric-value>WORD</metric-value> <!-- operation="delete"-->
</config>
</set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set metric WORD
```

Configure forward interface type

Use this attributes to discard routes based on policy/rules configured for a route map. Route maps can be applied to BGP neighbors. When this command is given for a route map and that route map is applied to a BGP neighbor, the discard route entries are added by BGP for the prefix permitted by the route map.

Attribute Name: `forward-interface-type`

Attribute Type: enum (null|tunnel-te)

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
```

```

    <routemap-name>WORD</routemap-name>
  <set-action>
  <config>
    <forward-interface-type>null0</forward-interface-type> <!--
operation="delete"-->
  </config>
</set-action>
</routemap>
</routemaps>

```

Command Syntax

```
set interface (null0|tunnel-te)
```

Configure route tag

Use this attribute to set a tag value. The parameter is the route tag that is labeled by another routing protocol (BGP or other IGP when redistributing), because AS-external-LSA has a route-tag field in its LSAs. In addition, when using route-map, OcNOS can tag the LSAs with the appropriate tag value. Sometimes the tag matches with using route-map, and sometimes, the value may be used by another application.

Attribute Name: route-tag

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```

<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
  <set-action>
  <config>
    <route-tag>1</route-tag> <!-- operation="delete"-->
  </config>
</set-action>
</routemap>
</routemaps>

```

Command Syntax

```
set tag <1-4294967295>
```

Configure weight

Use this attribute to set weights for the routing table. The weight value is used to assist in best path selection. It is assigned locally to a router. When there are several routes with a common destination, the routes with a higher weight value are preferred. To use this command, you must first have a match clause. Match and set commands set the conditions for redistributing routes from one routing protocol to another. The match command specifies the match

criteria under which redistribution is allowed for the current route-map. The set command specifies the set redistribution actions to be performed, if the match criteria are met.

Attribute Name: weight

Attribute Type: uint32

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<config>
  <weight>0</weight> <!-- operation="delete"-->
</config>
</set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set weight <0-4294967295>
```

Configure local preference

Use this attribute to set the BGP local preference path attribute

Attribute Name: local-preference

Attribute Type: uint32

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<config>
  <local-preference>0</local-preference> <!-- operation="delete"-->
</config>
</set-action>
</routemap>
```

```
</routemaps>
```

Command Syntax

```
set local-preference <0-4294967295>
```

Configure route origin type

Use this command to set the BGP origin code. The origin attribute defines the origin of the path information. To use this command, you must first have a match clause. Match and set commands set the conditions for redistributing routes from one routing protocol to another. The match command specifies the match criteria under which redistribution is allowed for the current route-map. The set command specifies the set redistribution actions to be performed, if the match criteria are met. If the packets do not match any of the defined criteria, they are routed through the normal routing process.

Attribute Name: route-origin-type

Attribute Type: enum (egp|igp|incomplete)

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
  <set-action>
    <config>
      <route-origin-type>egp</route-origin-type> <!-- operation="delete"-->
    </config>
  </set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set origin (egp|igp|incomplete)
```

Configure metric type

Use this command to set the metric type for the destination routing protocol. Select a type to be either Type-1 or Type2 in the AS-external-LSA when the route-map matches the condition.

Attribute Name: metric-type

Attribute Type: enum (type-1|type-2|internal|external)

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
```

```
        <sequence-id>1</sequence-id>
        <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
<set-action>
<config>
    <metric-type>type-1</metric-type> <!-- operation="delete"-->
</config>
</set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set metric-type (type-1|type-2|internal|external)
```

Configure aigp metric

Use this command to set the AIGP metric for BGP protocol routes.

Attribute Name: aigp-metric

Attribute Type: union

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
    <sequence-id>1</sequence-id>
    <config>
        <sequence-id>1</sequence-id>
        <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
<set-action>
<config>
    <aigp-metric>igp-metric</aigp-metric> <!-- operation="delete"-->
</config>
</set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set aigp-metric (igp-metric|<1-4294967295>)
```

Configure level type

Use this attribute to set the IS-IS level to export a route.

Attribute Name: level-type

Attribute Type: enum (level-1|level-2|level-1-2)

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<config>
  <level-type>level-1</level-type> <!-- operation="delete"-->
</config>
</set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set level (level-1|level-2|level-1-2)
```

Configure enable as path tag

Use this command to modify an autonomous system path for a route. By specifying the length of the AS-Path, the router influences the best path selection by a neighbor

Attribute Name: enable-as-path-tag

Attribute Type: empty

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<config>
  </enable-as-path-tag><!-- operation="delete"-->
</config>
</set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set as-path tag
```

Configure atomic aggregate

Use this attribute to set an atomic aggregate attribute. To use this command, you must first have a match clause. Match and set commands set the conditions for redistributing routes from one routing protocol to another. The match command specifies the match criteria under which redistribution is allowed for the current route-map. The set command specifies the set redistribution actions to be performed, if the match criteria are met. If the packets do not match any of the defined criteria, they are routed through the normal routing process.

Attribute Name: atomic-aggregate

Attribute Type: empty

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
  <set-action>
    <config>
      </atomic-aggregate><!-- operation="delete"-->
    </config>
  </set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set atomic-aggregate
```

Configure delete community value

Use this attribute to delete the matched communities from the community attribute of an inbound or outbound update when applying route-map.

Attribute Name: delete-community-value

Attribute Type: union

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
  <set-action>
    <config>
```



```

        <delete-community-value>RMAP_COMMUNITY_STRING_T</delete-community-value>
</config>
</set-action>
</routemap>
</routemaps>

```

Command Syntax

```
set comm-list (WORD|<1-99>|<100-500>) delete
```

Configure bgp originator id

Use this command to set the originator ID attribute. To use this command, you must first have a match clause. Match and set commands set the conditions for redistributing routes from one routing protocol to another. The match command specifies the match criteria under which redistribution is allowed for the current route-map. The set command specifies the set redistribution actions to be performed, if the match criteria are met. If the packets do not match any of the defined criteria, they are routed through the normal routing process.

Attribute Name: bgp-originator-id

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
</set-action>
<config>
  <bgp-originator-id>A.B.C.D</bgp-originator-id> <!-- operation="delete"-->
</config>
</set-action>
</routemap>
</routemaps>

```

Command Syntax

```
set originator-id A.B.C.D
```

Configure as path prepend

Use this attributes to modify an autonomous system path for a route. By specifying the length of the AS-Path, the router influences the best path selection by a neighbor. Use this command to prepend an AS path string to routes increasing the AS path length. To use this command, you must first give the match and set commands configure the conditions for redistributing routes from one routing protocol to another: 1. The match command specifies the match criteria under which redistribution is allowed for the current route-map. 2. The set command specifies the set redistribution actions to be performed if the match criteria are met. If the packets do not match any of the defined criteria, they are routed through the normal routing process.

Attribute Name: as-path-prepend

Attribute Type: string

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<config>
  <as-path-prepend>1</as-path-prepend> <!-- operation="delete"-->
</config>
</set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set as-path prepend .<1-4294967295>
```

Configure ext community site of origin

Use this attribute to set an extended community attribute as Site-of-origin extended community.

Attribute Name: ext-community-site-of-origin

Attribute Type: string

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<config>
  <ext-community-site-of-origin>AA:NN</ext-community-site-of-origin> <!--
operation="delete"-->
</config>
</set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set extcommunity soo .AA:NN
```

Configure ext community color

Use this attribute to set an extended community attribute color value

Attribute Name: ext-community-color

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<config>
  <ext-community-color>1</ext-community-color> <!-- operation="delete"-->
</config>
</set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set extcommunity color <1-4294967295>
```

Configure ip nexthop address

Use this attribute to set the specified next-hop value.

Attribute Name: ip-nexthop-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<ipv4>
<config>
  <ip-nexthop-address>A.B.C.D</ip-nexthop-address> <!-- operation="delete"-->
</config>
</ipv4>
```

```
</set-action>  
</routemap>  
</routemaps>
```

Command Syntax

```
set ip next-hop A.B.C.D
```

Configure use peer address

Use this attribute to set the next hop value as BGP peer-address

Attribute Name: use-peer-address

Attribute Type: empty

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">  
<routemap>  
  <sequence-id>1</sequence-id>  
  <config>  
    <sequence-id>1</sequence-id>  
    <routemap-name>WORD</routemap-name>  
  </config>  
  <routemap-name>WORD</routemap-name>  
<set-action>  
<ipv4>  
<config>  
  </use-peer-address><!-- operation="delete"-->  
</config>  
</ipv4>  
</set-action>  
</routemap>  
</routemaps>
```

Command Syntax

```
set ip next-hop peer-address
```

Configure default nexthop address

Use this attribute to set the default next hop value

Attribute Name: default-nexthop-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">  
<routemap>  
  <sequence-id>1</sequence-id>  
  <config>  
    <sequence-id>1</sequence-id>  
    <routemap-name>WORD</routemap-name>
```

```

    </config>
    <routermap-name>WORD</routermap-name>
  <set-action>
  <ipv4>
  <config>
    <default-nexthop-address>A.B.C.D</default-nexthop-address> <!--
operation="delete"-->
  </config>
</ipv4>
</set-action>
</routermap>
</routermaps>

```

Command Syntax

```
set ip default next-hop A.B.C.D
```

Configure vpnv4 nexthop address

Use this command to set a VPNv4 next-hop address. To use this command, you must first have a match clause. Match and set commands set the conditions for redistributing routes from one routing protocol to another. The match command specifies the match criteria under which redistribution is allowed for the current route-map. The set command specifies the set redistribution actions to be performed, if the match criteria are met. If the packets do not match any of the defined criteria, they are routed through the normal routing process.

Attribute Name: vpnv4-nexthop-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<routermaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routermap">
  <routermap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routermap-name>WORD</routermap-name>
    </config>
    <routermap-name>WORD</routermap-name>
  <set-action>
  <ipv4>
  <config>
    <vpnv4-nexthop-address>A.B.C.D</vpnv4-nexthop-address> <!--
operation="delete"-->
  </config>
</ipv4>
</set-action>
</routermap>
</routermaps>

```

Command Syntax

```
set vpnv4 next-hop A.B.C.D
```

Configure ipv6 nexthop address

Use this attribute to set a next hop-address.

Attribute Name: ipv6-nexthop-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<ipv6>
<config>
  <ipv6-nexthop-address>X:X::X:X</ipv6-nexthop-address> <!--
operation="delete"-->
</config>
</ipv6>
</set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set ipv6 next-hop X:X::X:X
```

Configure default ipv6 nexthop address

Use this attribute to set the default ipv6 next hop-address

Attribute Name: default-ipv6-nexthop-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<ipv6>
<config>
```

```

        <default-ipv6-next-hop-address>X:X::X:X</default-ipv6-next-hop-address> <!--
operation="delete"-->
    </config>
</ipv6>
</set-action>
</routemap>
</routemaps>

```

Command Syntax

```
set ipv6 default next-hop X:X::X:X
```

Configure local ipv6 nexthop address

Use this attribute to set Local IPv6 address as next hop-address

Attribute Name: local-ipv6-next-hop-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```

<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
  <set-action>
    <ipv6>
      <config>
        <local-ipv6-next-hop-address>X:X::X:X</local-ipv6-next-hop-address> <!--
operation="delete"-->
      </config>
    </ipv6>
  </set-action>
</routemap>
</routemaps>

```

Command Syntax

```
set ipv6 next-hop local X:X::X:X
```

Configure aggregator ip address

IP address of aggregator.

Attribute Name: aggregator-ip-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
```

```
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<bgp-aggregator-attributes>
<bgp-aggregator-attribute> <!-- operation="delete"-->
  <aggregator-ip-address>A.B.C.D</aggregator-ip-address>
  <config>
    <aggregator-ip-address>A.B.C.D</aggregator-ip-address>
    <as-number>1</as-number>
  </config>
  <as-number>1</as-number>
</bgp-aggregator-attribute>
</bgp-aggregator-attributes>
</set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set aggregator as <1-4294967295> A.B.C.D
```

Configure ext community rt

use this attribute to set an Route target extended community

Attribute Name: ext-community-rt

Attribute Type: string

Attribute Name: additive-type

Attribute Type: enum (no-additive|additive)

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
  <set-action>
  <extended-community>
  <route-targets>
  <route-target> <!-- operation="delete"-->
    <ext-community-rt>AA:NN</ext-community-rt>
  </route-target>
  </route-targets>
  </extended-community>
  </set-action>
</routemaps>
```



```

        <ext-community-rt>AA:NN</ext-community-rt>
        <additive-type>no-additive</additive-type>
    </config>
</route-target>
</route-targets>
</extended-community>
</set-action>
</routemap>
</routemaps>

```

Command Syntax

```
set extcommunity rt .AA:NN ((additive)|)
```

Configure cost value

use this attribute to set Extended community cost value

Attribute Name: cost-value

Attribute Type: uint32

Attribute Range: 0-4294967295

Netconf edit-config payload

```

<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<extended-community>
<costs>
<cost> <!-- operation="delete"-->
  <cost-value>0</cost-value>
  <config>
    <cost-value>0</cost-value>
    <community-id>0</community-id>
    <comparison-type>no-comparision</comparison-type>
  </config>
  <community-id>0</community-id>
  <comparison-type>no-comparision</comparison-type>
</cost>
</costs>
</extended-community>
</set-action>
</routemap>
</routemaps>

```

Command Syntax

```
set extcommunity cost (igp|pre-bestpath|) <0-255> <0-4294967295>
```

Configure max suppress time limit

Maximum duration to suppress a stable route in minutes.

Attribute Name: max-suppress-time-limit

Attribute Type: uint8

Default Value: 60

Attribute Range: 1-255

Attribute Name: enable-dampening

Attribute Type: empty

Attribute Name: reachability-half-life-time

Attribute Type: uint8

Default Value: 15

Attribute Range: 1-45

Attribute Name: reuse-time-limit

Attribute Type: uint16

Default Value: 750

Attribute Range: 1-20000

Attribute Name: suppress-time-limit

Attribute Type: uint16

Default Value: 2000

Attribute Range: 1-20000

Netconf edit-config payload

```
<rotemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
  <set-action>
    <dampening>
      <config>
        </enable-dampening><!-- operation="delete"-->
        <reachability-half-life-time>1</reachability-half-life-time> <!--
operation="delete"-->
        <reuse-time-limit>1</reuse-time-limit> <!-- operation="delete"-->
        <suppress-time-limit>1</suppress-time-limit> <!-- operation="delete"-->
      </config>
    </dampening>
  </set-action>
</rotemaps>
```

```

->         <max-suppress-time-limit>1</max-suppress-time-limit> <!-- operation="delete"-
</config>
</dampening>
</set-action>
</routemap>
</routemaps>

```

Command Syntax

```
set dampening <1-45> <1-20000> <1-20000> <1-255>
```

Configure unreachability half life time

Un-reachability half-life time for the penalty in minutes.

Attribute Name: unreachability-half-life-time

Attribute Type: uint8

Default Value: 15

Attribute Range: 1-45

Attribute Name: enable-dampening

Attribute Type: empty

Attribute Name: reachability-half-life-time

Attribute Type: uint8

Default Value: 15

Attribute Range: 1-45

Attribute Name: reuse-time-limit

Attribute Type: uint16

Default Value: 750

Attribute Range: 1-20000

Attribute Name: suppress-time-limit

Attribute Type: uint16

Default Value: 2000

Attribute Range: 1-20000

Attribute Name: max-suppress-time-limit

Attribute Type: uint8

Default Value: 60

Attribute Range: 1-255

Netconf edit-config payload

```

<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
</config>

```

```

        <sequence-id>1</sequence-id>
        <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
<set-action>
<dampening>
<config>
    </enable-dampening><!-- operation="delete"-->
    <reachability-half-life-time>1</reachability-half-life-time> <!--
operation="delete"-->
    <reuse-time-limit>1</reuse-time-limit> <!-- operation="delete"-->
    <suppress-time-limit>1</suppress-time-limit> <!-- operation="delete"-->
    <max-suppress-time-limit>1</max-suppress-time-limit> <!-- operation="delete"-
->
    <unreachability-half-life-time>1</unreachability-half-life-time> <!--
operation="delete"-->
</config>
</dampening>
</set-action>
</routemap>
</routemaps>

```

Command Syntax

```
set dampening <1-45> <1-20000> <1-20000> <1-255> <1-45>
```

Configure enable dampening

Use this attribute to enable route dampening and set various parameters. Route dampening minimizes the instability caused by route flapping. A penalty is added for every flap in a flapping route. As soon as the total penalty reaches the suppress limit the advertisement of the route is suppressed. This penalty is decayed according to the configured half time value. Once the penalty is lower than the reuse limit, the route advertisement is unsuppressed. The dampening information is purged from the router once the penalty becomes less than half of the reuse limit. Reachability half-life time for the penalty in minutes. The time for the penalty to decrease to one-half of its current value.

Attribute Name: enable-dampening

Attribute Type: empty

Netconf edit-config payload

```

<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
  <routemap>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
      <routemap-name>WORD</routemap-name>
    </config>
    <routemap-name>WORD</routemap-name>
  <set-action>
  <dampening>
  <config>
    </enable-dampening>
  </config>

```

```

</dampening>
</set-action>
</routemap>
</routemaps>

```

Command Syntax

```
set dampening
```

Configure community with as number

Autonomous system (AS) number and network number entered in the 4-byte new community format. This value is configured with two 2-byte numbers separated by a colon. A number from 1 to 65535 can be entered as each 2-byte number. A single community can be entered or multiple communities can be entered, each separated by a space.

Attribute Name: community-with-as-number

Attribute Type: string

Attribute Name: additive-set

Attribute Type: empty

Netconf edit-config payload

```

<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
</set-action>
<communities>
<config>
  </additive-set><!-- operation="delete"-->
  <community-with-as-number>AA:NN</community-with-as-number> <!--
operation="delete"-->
</config>
</communities>
</set-action>
</routemap>
</routemaps>

```

Command Syntax

```
set community-additive .AA:NN
```

Configure large community number set

Use this attributes to set the communities attribute. and group destinations in a certain community, as well as apply routing decisions according to those communities.

Attribute Name: large-community-number-set

Attribute Type: string

Netconf edit-config payload

```
<routemaps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-routemap">
<routemap>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
    <routemap-name>WORD</routemap-name>
  </config>
  <routemap-name>WORD</routemap-name>
<set-action>
<large-community>
<config>
  <large-community-number-set>XXX:YYYY:ZZZ</large-community-number-set> <!--
operation="delete"-->
</config>
</large-community>
</set-action>
</routemap>
</routemaps>
```

Command Syntax

```
set large-community [XXX:YYYY:ZZZ]
```

IPI-RIP

Configure options

This attribute enables debugging for RIP

Attribute Name: options

Attribute Type: bits (all|events|packet send|packet rcv|packet|packet detail|nsm|rib|bfd)

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
<debug>
<config>
  <options>all</options> <!-- operation="delete"-->
</config>
</debug>
</rip>
```

Command Syntax

```
debug rip (all|events|packet send|packet rcv|packet|packet detail|nsm|rib|bfd)
```

Configure split horizon

Use this attribute to controls RIP split-horizon processing on the specified interface.

Attribute Name: split-horizon

Attribute Type: boolean

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <split-horizon>true</split-horizon> <!-- operation="delete"-->
    </interface>
  </interfaces>
</rip>
```

Command Syntax

```
ip rip split-horizon
```

Configure name

Use this attribute to controls RIP split-horizon processing on the specified interface.

Attribute Name: split-horizon

Attribute Type: boolean

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <split-horizon>true</split-horizon> <!-- operation="delete"-->
    </interface>
  </interfaces>
</rip>
```

Command Syntax

```
no ip rip split-horizon
```

Configure disable receive packet

Use this attribute to configure the interface to enable/disable the reception of RIP packets

Attribute Name: disable-receive-packet

Attribute Type: uint8

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </disable-receive-packet><!-- operation="delete"-->
    </interface>
  </interfaces>
</rip>
```

Command Syntax

```
no ip rip receive-packet
```

Configure disable send packet

Use this attribute to enable/disable sending RIP packets through current interface

Attribute Name: disable-send-packet

Attribute Type: uint8

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </disable-send-packet><!-- operation="delete"-->
    </interface>
  </interfaces>
</rip>
```

Command Syntax

```
no ip rip send-packet
```

Configure receive version

Use this attribute to receive specified version of RIP packets on an interface

Attribute Name: receive-version

Attribute Type: enum (1|2|1 2|1-compatible)

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <interfaces>
    <interface>
```



```

    <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <receive-version>1</receive-version> <!-- operation="delete"-->
</interface>
</interfaces>
</rip>

```

Command Syntax

```
ip rip receive version (1|2|1 2)
```

Configure send version

Use this attribute to set the version of RIP packets which can be sent from an interface

Attribute Name: send-version

Attribute Type: enum (1|2|1 2|1-compatible)

Netconf edit-config payload

```

<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <send-version>1</send-version> <!-- operation="delete"-->
    </interface>
  </interfaces>
</rip>

```

Command Syntax

```
ip rip send version (1|2|1 2|1-compatible)
```

Configure auth mode

Use this attribute to set the type of authentication mode used for RIP packets

Attribute Name: auth-mode

Attribute Type: enum (text|md5)

Netconf edit-config payload

```

<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
</rip>

```

```
<auth-mode>text</auth-mode> <!-- operation="delete"-->
</interface>
</interfaces>
</rip>
```

Command Syntax

```
ip rip authentication mode (text|md5)
```

Configure auth string

Use this attribute to set the authentication string or password used by a key

Attribute Name: auth-string

Attribute Type: string

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <auth-string>LINE</auth-string> <!-- operation="delete"-->
</interface>
</interfaces>
</rip>
```

Command Syntax

```
ip rip authentication string LINE
```

Configure auth keychain

Use this attribute to enable RIP authentication on an interface and specify the name of the key chain to be used

Attribute Name: auth-keychain

Attribute Type: string

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <auth-keychain>LINE</auth-keychain> <!-- operation="delete"-->
</interface>
</interfaces>
</rip>
```

Command Syntax

```
ip rip authentication key-chain LINE
```

Configure rip enabled

Use this attribute enable a RIP routing process

Attribute Name: rip-enabled

Attribute Type: uint8

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <config>
      </rip-enabled>
    </config>
  </instance>
</rip>
```

Command Syntax

```
router rip
```

Configure bfd enable

This feature indicates that the RIP implementation on the system supports BFD

Attribute Name: bfd-enable

Attribute Type: empty

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <config>
      </bfd-enable><!-- operation="delete"-->
    </config>
  </instance>
</rip>
```

Command Syntax

```
bfd all-interfaces
```

Configure receive buffer size

Use this attribute to set the RIP UDP receive-buffer size.

Attribute Name: receive-buffer-size

Attribute Type: uint32

Default Value: 32768

Attribute Range: 8192-2147483647

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <config>
      <receive-buffer-size>8192</receive-buffer-size> <!-- operation="delete"-->
    </config>
  </instance>
</rip>
```

Command Syntax

```
recv-buffer-size <8192-2147483647>
```

Configure passive interfaces

Disables sending of RIP packets on the specified interface

Attribute Name: passive-interfaces

Attribute Type: string

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <config>
      <passive-interfaces>IFNAME</passive-interfaces> <!-- operation="delete"-->
    </config>
  </instance>
</rip>
```

Command Syntax

```
passive-interface IFNAME
```

Configure static routes

Use this attribute to set static RIP routes

Attribute Name: static-routes

Attribute Type: string

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <config>
      <static-routes>A.B.C.D/M</static-routes> <!-- operation="delete"-->
    </config>
  </instance>
</rip>
```

Command Syntax

```
route A.B.C.D/M
```

Configure neighbors

Specifies the RIP neighbors

Attribute Name: neighbors

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <config>
      <neighbors>A.B.C.D</neighbors> <!-- operation="delete"-->
    </config>
  </instance>
</rip>
```

Command Syntax

```
neighbor A.B.C.D
```

Configure neighbor fall over bfd

Specified the BFD neighbors

Attribute Name: neighbor-fall-over-bfd

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <config>
      <neighbor-fall-over-bfd>A.B.C.D</neighbor-fall-over-bfd> <!--
operation="delete"-->
    </config>
  </instance>
</rip>
```

Command Syntax

```
neighbor A.B.C.D fall-over bfd
```

Configure enable cisco metric behavior

Use this attribute to set metric updation behavior as Cisco

Attribute Name: enable-cisco-metric-behavior

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <config>
```

```
        <enable-cisco-metric-behavior>disable</enable-cisco-metric-behavior> <!--
operation="delete"-->
    </config>
</instance>
</rip>
```

Command Syntax

```
cisco-metric-behavior (disable|enable)
```

Configure default metric

Set the default metric

Attribute Name: default-metric

Attribute Type: uint8

Default Value: 1

Attribute Range: 1-15

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <config>
      <default-metric>1</default-metric> <!-- operation="delete"-->
    </config>
  </instance>
</rip>
```

Command Syntax

```
default-metric <1-15>
```

Configure version

Use this attribute to set version of routing protocol

Attribute Name: version

Attribute Type: uint8

Default Value: 2

Attribute Range: 1-2

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <config>
      <version>1</version> <!-- operation="delete"-->
    </config>
  </instance>
</rip>
```

Command Syntax

```
version <1-2>
```

Configure distance

Use this attribute to set administrative distance of the RIP for the current RIP instance

Attribute Name: distance

Attribute Type: uint8

Default Value: 120

Attribute Range: 1-255

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <config>
      <distance>1</distance> <!-- operation="delete"-->
    </config>
  </instance>
</rip>
```

Command Syntax

```
distance <1-255>
```

Configure network interfaces

Use this attribute to enable routing on an interface

Attribute Name: network-interfaces

Attribute Type: string

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <config>
      <network-interfaces>IFNAME</network-interfaces> <!-- operation="delete"-->
    </config>
  </instance>
</rip>
```

Command Syntax

```
network IFNAME
```

Configure network routes

Use this attribute to enable routing on an IP network

Attribute Name: network-routes

Attribute Type: string

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <config>
      <network-routes>A.B.C.D/M</network-routes> <!-- operation="delete"-->
    </config>
  </instance>
</rip>
```

Command Syntax

```
network A.B.C.D/M
```

Configure access list name

Use this attribute to set the access list name

Attribute Name: access-list-name

Attribute Type: string

Attribute Name: distance

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <distances>
      <distance>
        <source-prefix>A.B.C.D/M</source-prefix>
        <config>
          <source-prefix>A.B.C.D/M</source-prefix>
          <distance>1</distance>
        </config>
        <access-list-name>WORD</access-list-name>
      </distance>
    </distances>
  </instance>
</rip>
```

Command Syntax

```
distance <1-255> A.B.C.D/M (WORD|)
```

Configure route table update interval

Interval at which RIP updates are sent

Attribute Name: route-table-update-interval

Attribute Type: uint32

Attribute Range: 5-2147483647

Attribute Name: route-info-timeout-interval

Attribute Type: uint32

Attribute Range: 5-2147483647

Attribute Name: garbage-collection-interval

Attribute Type: uint32

Attribute Range: 5-2147483647

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <timers>
      <config>
        <route-info-timeout-interval>5</route-info-timeout-interval>
        <garbage-collection-interval>5</garbage-collection-interval>
        <route-table-update-interval>5</route-table-update-interval>
      </config>
    </timers>
  </instance>
</rip>
```

Command Syntax

```
timers basic <5-2147483647> <5-2147483647> <5-2147483647>
```

Configure warning threshold percentage

Use this attribute to set the percentage of maximum routes to generate a warning

Attribute Name: warning-threshold-percentage

Attribute Type: uint32

Attribute Range: 1-100

Attribute Name: max-routes

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <maximum-prefix>
      <config>
        <max-routes>1</max-routes> <!-- operation="delete"-->
        <warning-threshold-percentage>1</warning-threshold-percentage> <!--
operation="delete"-->
      </config>
    </maximum-prefix>
  </instance>
</rip>
```

Command Syntax

```
maximum-prefix <1-65535> (<1-100>|)
```

Configure route type

Use this attribute to redistributes only specified route-type routes matching the specified route type into the RIP routing instance

Attribute Name: route-type

Attribute Type: enum (kernel|connected|static|ospf|isis|bgp)

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <redistribute-policies>
      <redistribute-policy> <!-- operation="delete"-->
        <route-type>kernel</route-type>
        <config>
          <route-type>kernel</route-type>
        </config>
      </redistribute-policy>
    </redistribute-policies>
  </instance>
</rip>
```

Command Syntax

```
redistribute (kernel|connected|static|ospf|isis|bgp)
```

Configure route map

Use this attribute to set th route-map

Attribute Name: route-map

Attribute Type: string

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 0-16

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <redistribute-policies>
      <redistribute-policy>
        <route-type>kernel</route-type>
        <config>
          <route-type>kernel</route-type>
          <metric>0</metric> <!-- operation="delete"-->
        </config>
      </redistribute-policy>
    </redistribute-policies>
  </instance>
</rip>
```

```

    <route-map>WORD</route-map> <!-- operation="delete"-->
</redistribute-policy>
</redistribute-policies>
</instance>
</rip>

```

Command Syntax

```
redistribute (kernel|connected|static|ospf|isis|bgp) metric <0-16> route-map WORD
```

Configure metric

Metric used for the redistributed route

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 0-16

Netconf edit-config payload

```

<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <redistribute-policies>
      <redistribute-policy>
        <route-type>kernel</route-type>
        <config>
          <route-type>kernel</route-type>
        </config>
        <metric>0</metric> <!-- operation="delete"-->
      </redistribute-policy>
    </redistribute-policies>
  </instance>
</rip>

```

Command Syntax

```
redistribute (kernel|connected|static|ospf|isis|bgp) metric <0-16>
```

Configure originate

Use this attribute to apply conditions of the route policy to the default route

Attribute Name: route-map

Attribute Type: string

Attribute Name: originate

Attribute Type: empty

Attribute Name: always-advertise

Attribute Type: empty

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
```

```
<instance>
<default-information>
<config>
  </originate><!-- operation="delete"-->
  </always-advertise><!-- operation="delete"-->
  <route-map>WORD</route-map> <!-- operation="delete"-->
</config>
</default-information>
</instance>
</rip>
```

Command Syntax

```
default-information originate (always|) (route-map WORD|)
```

Configure direction

Use this attribute to set the metric value of routing protocol

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 0-16

Attribute Name: access-list-name

Attribute Type: string

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
<instance>
<offset-lists>
<offset-list>
  <direction>in</direction>
  <config>
    <direction>in</direction>
    <access-list-name>WORD</access-list-name>
  </config>
  <metric>0</metric>
</offset-list>
</offset-lists>
</instance>
</rip>
```

Command Syntax

```
offset-list WORD (in|out) <0-16>
```

clear ip rip route (kernel|connected|static|ospf|isis|bgp|rip|all)

Attribute Name: route-type

Attribute Type: enum (kernel|connected|static|ospf|isis|bgp|rip|all)

Netconf RPC payload

```
<rip-clear-route xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <route-type>kernel</route-type>
</rip-clear-route>
```

Command Syntax

```
clear ip rip route (kernel|connected|static|ospf|isis|bgp|rip|all)
```

clear ip rip route A.B.C.D/M

Attribute Name: prefix-address

Attribute Type: string

Netconf RPC payload

```
<rip-clear-route-prefix xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <prefix-address>A.B.C.D/M</prefix-address>
</rip-clear-route-prefix>
```

Command Syntax

```
clear ip rip route A.B.C.D/M
```

clear ip rip statistics (IFNAME|)

Attribute Name: name

Attribute Type: string

Default Value: NULL

Netconf RPC payload

```
<rip-clear-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <name>IFNAME</name>
</rip-clear-statistics>
```

Command Syntax

```
clear ip rip statistics (IFNAME|)
```

snmp restart rip

Netconf RPC payload

```
<rip-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip"/>
```

Command Syntax

```
snmp restart rip
```

debug rip (all|events|packet send|packet recv|packet|packet detail|nsm|rib|bfd)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|events|packet send|packet rcv|packet|packet detail|nsm|rib|bfd)

Netconf RPC payload

```
<rip-terminal-debugging-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <terminal-debug-options>all</terminal-debug-options>
</rip-terminal-debugging-on>
```

Command Syntax

```
debug rip (all|events|packet send|packet rcv|packet|packet detail|nsm|rib|bfd)
```

no debug rip (all|events|packet send|packet rcv|packet|packet detail|nsm|rib|bfd)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|events|packet send|packet rcv|packet|packet detail|nsm|rib|bfd)

Netconf RPC payload

```
<rip-terminal-debugging-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <terminal-debug-options>all</terminal-debug-options>
</rip-terminal-debugging-off>
```

Command Syntax

```
no debug rip (all|events|packet send|packet rcv|packet|packet detail|nsm|rib|bfd)
```

IPI-RIP-VRF

Configure vrf name

VRF name

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <vrfs>
      <vrf <!-- operation="delete"-->
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
      </vrf>
    </vrfs>
  </instance>
</rip>
```

Command Syntax

```
address-family ipv4 vrf NAME
```

Configure enable cisco metric behavior

Use this attribute to set metric updation behavior as Cisco

Attribute Name: enable-cisco-metric-behavior

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <enable-cisco-metric-behavior>disable</enable-cisco-metric-behavior> <!--
operation="delete"-->
      </vrf>
    </vrfs>
  </instance>
</rip>
```

Command Syntax

```
cisco-metric-behavior (disable|enable)
```

Configure default metric

Set the default metric

Attribute Name: default-metric

Attribute Type: uint8

Default Value: 1

Attribute Range: 1-15

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <default-metric>1</default-metric> <!-- operation="delete"-->
      </vrf>
    </vrfs>
  </instance>
</rip>
```

```
</vrf>  
</instance>  
</rip>
```

Command Syntax

```
default-metric <1-15>
```

Configure version

Use this attribute to set version of routing protocol

Attribute Name: version

Attribute Type: uint8

Default Value: 2

Attribute Range: 1-2

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">  
<instance>  
  <vrf>  
    <vrf>  
      <vrf-name>NAME</vrf-name>  
      <config>  
        <vrf-name>WORD</vrf-name>  
      </config>  
      <version>1</version> <!-- operation="delete"-->  
    </vrf>  
  </vrf>  
</instance>  
</rip>
```

Command Syntax

```
version <1-2>
```

Configure distance

Use this attribute to set administrative distance of the RIP for the current RIP instance

Attribute Name: distance

Attribute Type: uint8

Default Value: 120

Attribute Range: 1-255

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">  
<instance>  
  <vrf>  
    <vrf>
```



```

    <vrf-name>NAME</vrf-name>
    <config>
      <vrf-name>WORD</vrf-name>
    </config>
    <distance>1</distance> <!-- operation="delete"-->
  </vrf>
</vrfs>
</instance>
</rip>

```

Command Syntax

```
distance <1-255>
```

Configure network interfaces

Use this attribute to enable routing on an interface

Attribute Name: network-interfaces

Attribute Type: string

Netconf edit-config payload

```

<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <network-interfaces>IFNAME</network-interfaces> <!-- operation="delete"-->
      >
    </vrf>
  </vrfs>
</instance>
</rip>

```

Command Syntax

```
network IFNAME
```

Configure network routes

Use this attribute to enable routing on an IP network

Attribute Name: network-routes

Attribute Type: string

Netconf edit-config payload

```

<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <vrfs>

```

```
<vrf>
  <vrf-name>NAME</vrf-name>
  <config>
    <vrf-name>WORD</vrf-name>
  </config>
  <network-routes>A.B.C.D/M</network-routes> <!-- operation="delete"-->
</vrf>
</vrfs>
</instance>
</rip>
```

Command Syntax

```
network A.B.C.D/M
```

Configure access list name

Use this attribute to set the access list name

Attribute Name: access-list-name

Attribute Type: string

Attribute Name: distance

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <distances>
          <distance>
            <source-prefix>A.B.C.D/M</source-prefix>
            <config>
              <source-prefix>A.B.C.D/M</source-prefix>
              <distance>1</distance>
            </config>
            <access-list-name>WORD</access-list-name>
          </distance>
        </distances>
      </vrf>
    </vrfs>
  </instance>
</rip>
```

Command Syntax

```
distance <1-255> A.B.C.D/M (WORD|)
```

Configure route type

Use this attribute to redistributes only specified route-type routes matching the specified route type into the RIP routing instance

Attribute Name: route-type

Attribute Type: enum (connected|static|ospf|bgp)

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <redistribute-policies>
          <redistribute-policy> <!-- operation="delete"-->
            <route-type>connected</route-type>
            <config>
              <route-type>connected</route-type>
            </config>
          </redistribute-policy>
        </redistribute-policies>
      </vrf>
    </vrfs>
  </instance>
</rip>
```

Command Syntax

```
redistribute (connected|static|ospf|bgp)
```

Configure route map

Use this attribute to set the name of the route-map

Attribute Name: route-map

Attribute Type: string

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 0-16

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
```

```
<instance>
  <vrfs>
    <vrf>
      <vrf-name>NAME</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
      </config>
      <redistribute-policies>
      <redistribute-policy>
        <route-type>connected</route-type>
        <config>
          <route-type>connected</route-type>
          <metric>0</metric> <!-- operation="delete"-->
        </config>
        <route-map>WORD</route-map> <!-- operation="delete"-->
      </redistribute-policy>
    </redistribute-policies>
  </vrf>
</vrfs>
</instance>
</rip>
```

Command Syntax

```
redistribute (connected|static|ospf|bgp) metric <0-16> route-map WORD
```

Configure metric

Use this attribute to set the metric used for the redistributed route

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 0-16

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <redistribute-policies>
        <redistribute-policy>
          <route-type>connected</route-type>
          <config>
            <route-type>connected</route-type>
            <metric>0</metric> <!-- operation="delete"-->
          </config>
        </redistribute-policy>
      </redistribute-policies>
    </vrf>
  </vrfs>
</instance>
```

```

    </redistribute-policies>
  </vrf>
</vrfs>
</instance>
</rip>

```

Command Syntax

```
redistribute (connected|static|ospf|bgp) metric <0-16>
```

Configure originate

Use this attribute to apply conditions of the route policy to the default route

Attribute Name: route-map

Attribute Type: string

Attribute Name: originate

Attribute Type: empty

Attribute Name: always-advertise

Attribute Type: empty

Netconf edit-config payload

```

<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <default-information>
          <config>
            </originate><!-- operation="delete"-->
            </always-advertise><!-- operation="delete"-->
            <route-map>WORD</route-map> <!-- operation="delete"-->
          </config>
        </default-information>
      </vrf>
    </vrfs>
  </instance>
</rip>

```

Command Syntax

```
default-information originate (always|) (route-map WORD|)
```

Configure direction

Use this attribute to set the metric value of routing protocol

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 0-16

Attribute Name: access-list-name

Attribute Type: string

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <offset-lists>
          <offset-list>
            <direction>in</direction>
            <config>
              <direction>in</direction>
              <access-list-name>WORD</access-list-name>
            </config>
            <metric>0</metric>
          </offset-list>
        </offset-lists>
      </vrf>
    </vrfs>
  </instance>
</rip>
```

Command Syntax

```
offset-list WORD (in|out) <0-16>
```

Configure name

Use this attribute to set the metric value of routing protocol

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 0-16

Attribute Name: access-list-name

Attribute Type: string

Netconf edit-config payload

```
<rip xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
```

```

<config>
  <vrf-name>WORD</vrf-name>
</config>
<interfaces>
<interface>
  <name>IFNAME</name>
  <config>
    <name>IFNAME</name>
  </config>
  <offset-lists>
  <offset-list>
    <direction>in</direction>
    <config>
      <direction>in</direction>
      <access-list-name>WORD</access-list-name>
    </config>
    <metric>0</metric>
  </offset-list>
</offset-lists>
</interface>
</interfaces>
</vrf>
</vrfs>
</instance>
</rip>

```

Command Syntax

```
offset-list WORD (in|out) <0-16> IFNAME
```

clear ip rip route vrf NAME A.B.C.D/M

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: prefix

Attribute Type: string

Netconf RPC payload

```

<ipi-rip-vrf_rip-vrf-clear-route xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-rip">
  <vrf-name>NAME</vrf-name>
  <prefix>A.B.C.D/M</prefix>
</ipi-rip-vrf_rip-vrf-clear-route>

```

Command Syntax

```
clear ip rip route vrf NAME A.B.C.D/M
```

clear ip rip route vrf NAME *

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<ipi-rip-vrf_rip-vrf-clear-route-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rip">
  <vrf-name>NAME</vrf-name>
</ipi-rip-vrf_rip-vrf-clear-route-all>
```

Command Syntax

```
clear ip rip route vrf NAME *
```

IPI-PBR

Configure enabled

Use this attribute to enable pbr support

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pbr">
  <config>
    </enabled><!-- operation="delete"-->
  </config>
</pbr>
```

Command Syntax

```
feature pbr
```

Configure route map name

Use this attribute to set ip policy for route-map.

Attribute Name: route-map-name

Attribute Type: string

Netconf edit-config payload

```
<pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pbr">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <route-map-name>WORD</route-map-name> <!-- operation="delete"-->
    </interface>
  </interfaces>
```

```
</pbr>
```

Command Syntax

```
ip policy route-map WORD
```

Configure route map v6 name

Use this attribute to set ipv6 policy for route-map.

Attribute Name: route-map-v6-name

Attribute Type: string

Netconf edit-config payload

```
<pbr xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pbr">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <route-map-v6-name>WORD</route-map-v6-name> <!-- operation="delete"-->
</interface>
</interfaces>
</pbr>
```

Command Syntax

```
ipv6 policy route-map WORD
```

clear route-map WORD pbr-statistics

Attribute Name: route-map-name

Attribute Type: string

Netconf RPC payload

```
<clear-route-map-pbr-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
pbr">
  <route-map-name>WORD</route-map-name>
</clear-route-map-pbr-statistics>
```

Command Syntax

```
clear route-map WORD pbr-statistics
```

IPI-SNMP

Configure enable link down trap

Use this attribute to enable or disable SNMP linkdown traps.

Attribute Name: enable-link-down-trap

Attribute Type: boolean

Attribute Name: enable-link-up-trap

Attribute Type: boolean

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <server-traps>
    <config>
      <enable-link-up-trap>true</enable-link-up-trap> <!-- operation="delete"-->
      <enable-link-down-trap>true</enable-link-down-trap> <!-- operation="delete"-->
    </config>
  </server-traps>
</snmp>
```

Command Syntax

```
snmp-server enable traps link
```

Configure enable link up trap

Use this attribute to enable or disable SNMP linkdown traps.

Attribute Name: enable-link-down-trap

Attribute Type: boolean

Attribute Name: enable-link-up-trap

Attribute Type: boolean

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <server-traps>
    <config>
      <enable-link-up-trap>true</enable-link-up-trap> <!-- operation="delete"-->
      <enable-link-down-trap>true</enable-link-down-trap> <!-- operation="delete"-->
    </config>
  </server-traps>
</snmp>
```

Command Syntax

```
no snmp-server enable traps link
```

Configure include interface name

Use this attribute to include ifname with SNMP linkdown traps.

Attribute Name: include-interface-name

Attribute Type: uint8

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <server-traps>
  <config>
    </include-interface-name><!-- operation="delete"-->
  </config>
</server-traps>
</snmp>
```

Command Syntax

```
snmp-server enable traps link include-interface-name
```

Configure enable traps

Use this attribute to enable or disable SNMP traps and inform requests.

This command is supported when following feature are enabled SNMP-AGENT feature

Attribute Name: enable-traps

Attribute Type: bits (snmp authentication|mpls|pw|pwdelete|rsvp|ospf|bgp|isis|vrrp|vxlan|ospf6|mpls3vpn|rib|pim)

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <server-traps>
  <config>
    <enable-traps>snmp authentication</enable-traps> <!-- operation="delete"-->
  </config>
</server-traps>
</snmp>
```

Command Syntax

```
snmp-server enable traps (snmp
  authentication|mpls|pw|pwdelete|rsvp|ospf|bgp|isis|vrrp|vxlan|ospf6|mpls3vpn|ri
  b|pim)
```

debug (snmp send|snmp receive|snmp process|snmp xdump|snmp error-string|snmp detail|snmp|snmp all)

Attribute Name: debug

Attribute Type: bits (snmp send|snmp receive|snmp process|snmp xdump|snmp error-string|snmp detail|snmp|snmp all)

Netconf RPC payload

```
<snmp-agentx-enable-terminal-debugging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <debug>snmp send</debug>
</snmp-agentx-enable-terminal-debugging>
```

Command Syntax

```
debug (snmp send|snmp receive|snmp process|snmp xdump|snmp error-string|snmp
detail|snmp|snmp all)
```

no debug (snmp send|snmp receive|snmp process|snmp xdump|snmp error-string|snmp detail|snmp|snmp all)

Attribute Name: debug

Attribute Type: bits (snmp send|snmp receive|snmp process|snmp xdump|snmp error-string|snmp detail|snmp|snmp all)

Netconf RPC payload

```
<snmp-agentx-disable-terminal-debugging xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snm">
  <debug>snmp send</debug>
</snmp-agentx-disable-terminal-debugging>
```

Command Syntax

```
no debug (snmp send|snmp receive|snmp process|snmp xdump|snmp error-string|snmp
detail|snmp|snmp all)
```

IPI-SNMP-SERVER

Configure vrf name

VRF name associated with this instance.

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snm">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snm-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
        </enabled>
      </config>
    </server>
  </servers>
</snmp>
```

Command Syntax

```
snmp-server enable snmp (vrf management|)
```

Configure system contact

Use this attribute to set the system contact information for the device (sysContact object)

Attribute Name: system-contact

Attribute Type: string

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
<servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
<server>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
  <global>
  <config>
    <system-contact>LINE</system-contact> <!-- operation="delete"-->
  </config>
</global>
</server>
</servers>
</snmp>
```

Command Syntax

```
snmp-server contact (vrf management|) LINE
```

Configure system location

Use this attribute to set the physical location information of the device (sysLocation object)

Attribute Name: system-location

Attribute Type: string

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
<servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
<server>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
  <global>
  <config>
    <system-location>LINE</system-location> <!-- operation="delete"-->
  </config>
</global>
```

```
</server>  
</servers>  
</snmp>
```

Command Syntax

```
snmp-server location (vrf management|) LINE
```

Configure tcp session enabled

Use this attribute to start the SNMP agent daemon over TCP

Attribute Name: tcp-session-enabled

Attribute Type: empty

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">  
<servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">  
<server>  
  <vrf-name>management</vrf-name>  
  <config>  
    <vrf-name>management</vrf-name>  
  </config>  
  <global>  
  <config>  
    </tcp-session-enabled><!-- operation="delete"-->  
  </config>  
</global>  
</server>  
</servers>  
</snmp>
```

Command Syntax

```
snmp-server tcp-session (vrf management|)
```

Configure disable default instance

Use this attribute to prevent default snmp instance from being enabled at start up

Attribute Name: disable-default-instance

Attribute Type: empty

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">  
<servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">  
<default-instance>  
<config>  
  </disable-default-instance><!-- operation="delete"-->  
</config>  
</default-instance>  
</servers>
```

```
</snmp>
```

Command Syntax

```
snmp-server disable-default
```

IPI-SNMP-SERVER-EXTENDED

Configure enable

Use this attribute to enable/disable SNMP server debugging

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <debug xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
      <config>
        </enable><!-- operation="delete"-->
      </config>
    </debug>
  </servers>
</snmp>
```

Command Syntax

```
debug snmp-server
```

Configure filter type

Use this attribute to update oid tree filter type for a view entry.

This command is supported when following feature are enabled SNMP-AGENT feature

Attribute Name: filter-type

Attribute Type: enum (included|excluded)

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <snmp-views xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
        <snmp-view>
          <view-name>VIEW-NAME</view-name>
        </snmp-view>
      </snmp-views>
    </server>
  </servers>
</snmp>
```

```
<config>
  <view-name>VIEW-NAME</view-name>
</config>
<oid-trees>
  <oid-tree>
    <oid>OID-TREE</oid>
    <config>
      <oid>OID-TREE</oid>
    </config>
    <filter-type>included</filter-type> <!-- operation="delete"-->
  </oid-tree>
</oid-trees>
</snmp-view>
</snmp-views>
</server>
</servers>
</snmp>
```

Command Syntax

```
snmp-server view VIEW-NAME OID-TREE (included|excluded) (vrf management|)
```

Configure engine id

Use this attribute to configure SNMPv3 engine ID.

This command is supported when following feature are enabled snmp version v3

Attribute Name: engine-id

Attribute Type: string

Attribute Range: 1-24

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <engine-id xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
  <config>
    <engine-id>ENGINE_ID_STR</engine-id> <!-- operation="delete"-->
  </config>
  </engine-id>
</snmp>
```

Command Syntax

```
snmp-server engineID ENGINE_ID_STR
```

Configure smux port enable

Use this attribute to enable smux-port.

Attribute Name: smux-port-enable

Attribute Type: empty

Netconf edit-config payload

```

<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <smux-port xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
        <config>
          </smux-port-enable><!-- operation="delete"-->
        </config>
      </smux-port>
    </server>
  </servers>
</snmp>

```

Command Syntax

```
snmp-server smux-port-enable (vrf management|)
```

Configure host name

Use this attribute to configure an SNMP trap host. An SNMP trap host is usually a network management station (NMS) or an SNMP manager.

Attribute Name: host-name

Attribute Type: string

Attribute Range: 1-63

Attribute Name: notification-type

Attribute Type: enum (traps|informs)

Attribute Name: snmp-version

Attribute Type: enum (1|2c|3)

Attribute Name: community

Attribute Type: string

Attribute Name: udp-port

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```

<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </server>
  </servers>
</snmp>

```

```
</config>
<hosts xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
  <host>
    <host-name>A.B.C.D</host-name>
    <config>
      <host-name>A.B.C.D</host-name>
      <notification-type>traps</notification-type>
      <snmp-version>1</snmp-version>
      <community>WORD</community>
      <udp-port>1</udp-port>
    </config>
  </host>
</hosts>
</server>
</servers>
</snmp>
```

Command Syntax

```
snmp-server host (A.B.C.D|X:X::X:X|HOSTNAME) (traps) version (1|2c) WORD (udp-port
<1-65535>|) (vrf management|)
```

Configure notification type

Use this attribute to configure an SNMP trap host. An SNMP trap host is usually a network management station (NMS) or an SNMP manager.

Attribute Name: host-name

Attribute Type: string

Attribute Range: 1-63

Attribute Name: notification-type

Attribute Type: enum (traps|informs)

Attribute Name: snmp-version

Attribute Type: enum (1|2c|3)

Attribute Name: snmpv3-auth-type

Attribute Type: enum (noauth|auth|priv)

Attribute Name: snmpv3-user

Attribute Type: string

Attribute Name: udp-port

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
```

```

<config>
  <vrf-name>management</vrf-name>
</config>
<hosts xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
<host>
  <host-name>A.B.C.D</host-name>
  <config>
    <host-name>A.B.C.D</host-name>
    <notification-type>traps</notification-type>
    <snmp-version>1</snmp-version>
    <snmpv3-auth-type>noauth</snmpv3-auth-type>
    <snmpv3-user>WORD</snmpv3-user>
    <udp-port>1</udp-port>
  </config>
</host>
</hosts>
</server>
</servers>
</snmp>

```

Command Syntax

```
snmp-server host (A.B.C.D|X:X::X:X|HOSTNAME) (traps) version (3) (noauth|auth|priv)
WORD (udp-port <1-65535>|) (vrf management|)
```

Configure snmp version

Use this attribute to configure an SNMP trap host. An SNMP trap host is usually a network management station (NMS) or an SNMP manager.

Attribute Name: host-name

Attribute Type: string

Attribute Range: 1-63

Attribute Name: notification-type

Attribute Type: enum (traps|informs)

Attribute Name: snmp-version

Attribute Type: enum (1|2c|3)

Attribute Name: community

Attribute Type: string

Attribute Name: udp-port

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```

<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
<servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
  <server>

```

```
<vrf-name>management</vrf-name>
<config>
  <vrf-name>management</vrf-name>
</config>
<hosts xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
<host>
  <host-name>A.B.C.D</host-name>
  <config>
    <host-name>A.B.C.D</host-name>
    <notification-type>traps</notification-type>
    <snmp-version>1</snmp-version>
    <community>WORD</community>
    <udp-port>1</udp-port>
  </config>
</host>
</hosts>
</server>
</servers>
</snmp>
```

Command Syntax

```
snmp-server host (A.B.C.D|X:X::X:X|HOSTNAME) (informs) version (2c) WORD (udp-port
<1-65535>|) (vrf management|)
```

Configure snmpv3 auth type

Use this attribute to configure an SNMP trap host. An SNMP trap host is usually a network management station (NMS) or an SNMP manager.

Attribute Name: host-name

Attribute Type: string

Attribute Range: 1-63

Attribute Name: notification-type

Attribute Type: enum (traps|informs)

Attribute Name: snmp-version

Attribute Type: enum (1|2c|3)

Attribute Name: snmpv3-auth-type

Attribute Type: enum (noauth|auth|priv)

Attribute Name: snmpv3-user

Attribute Type: string

Attribute Name: udp-port

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
```

```

<servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
  <server>
    <vrf-name>management</vrf-name>
    <config>
      <vrf-name>management</vrf-name>
    </config>
    <hosts xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
      <host>
        <host-name>A.B.C.D</host-name>
        <config>
          <host-name>A.B.C.D</host-name>
          <notification-type>traps</notification-type>
          <snmp-version>1</snmp-version>
          <snmpv3-auth-type>noauth</snmpv3-auth-type>
          <snmpv3-user>WORD</snmpv3-user>
          <udp-port>1</udp-port>
        </config>
      </host>
    </hosts>
  </server>
</servers>
</snmp>

```

Command Syntax

```

snmp-server host (A.B.C.D|X:X::X:X|HOSTNAME) (informs) version (3)
(noauth|auth|priv) WORD (udp-port <1-65535>|) (vrf management|)

```

Configure community

Use this attribute to configure an SNMP trap host. An SNMP trap host is usually a network management station (NMS) or an SNMP manager.

Attribute Name: host-name

Attribute Type: string

Attribute Range: 1-63

Attribute Name: snmp-version

Attribute Type: enum (1|2c|3)

Attribute Name: community

Attribute Type: string

Attribute Name: udp-port

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```

<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>

```

```
<vrf-name>management</vrf-name>
<config>
  <vrf-name>management</vrf-name>
</config>
<hosts xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
<host>
  <host-name>A.B.C.D</host-name>
  <config>
    <host-name>A.B.C.D</host-name>
    <snmp-version>1</snmp-version>
    <community>WORD</community>
    <udp-port>1</udp-port>
  </config>
</host>
</hosts>
</server>
</servers>
</snmp>
```

Command Syntax

```
snmp-server host (A.B.C.D|X:X::X:X|HOSTNAME) version (1|2c) WORD (udp-port <1-65535>|) (vrf management|)
```

Configure snmpv3 user

Use this attribute to configure an SNMP trap host. An SNMP trap host is usually a network management station (NMS) or an SNMP manager.

Attribute Name: host-name

Attribute Type: string

Attribute Range: 1-63

Attribute Name: snmp-version

Attribute Type: enum (1|2c|3)

Attribute Name: snmpv3-auth-type

Attribute Type: enum (noauth|auth|priv)

Attribute Name: snmpv3-user

Attribute Type: string

Attribute Name: udp-port

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
<servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
  <server>
    <vrf-name>management</vrf-name>
```

```

<config>
  <vrf-name>management</vrf-name>
</config>
<hosts xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
<host>
  <host-name>A.B.C.D</host-name>
  <config>
    <host-name>A.B.C.D</host-name>
    <snmp-version>1</snmp-version>
    <snmpv3-auth-type>noauth</snmpv3-auth-type>
    <snmpv3-user>WORD</snmpv3-user>
    <udp-port>1</udp-port>
  </config>
</host>
</hosts>
</server>
</servers>
</snmp>

```

Command Syntax

```
snmp-server host (A.B.C.D|X:X::X:X|HOSTNAME) version (3) (noauth|auth|priv) WORD
(udp-port <1-65535>|) (vrf management|)
```

Configure udp port

Use this attribute to specify the port to be used when SNMP sends packets to host. The default is 162.

This command is supported when following feature are enabled SNMP-AGENT feature

Attribute Name: udp-port

Attribute Type: uint32

Attribute Range: 1-65535

Attribute Name: host-user

Attribute Type: string

Netconf edit-config payload

```

<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
<servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
  <server>
    <vrf-name>management</vrf-name>
    <config>
      <vrf-name>management</vrf-name>
    </config>
    <hosts xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
    <host>
      <host-name>A.B.C.D</host-name>
      <config>
        <host-name>A.B.C.D</host-name>
        <host-user>WORD</host-user> <!-- operation="delete"-->
      </config>
    </host>
  </hosts>
</server>
</servers>
</snmp>

```

```
        <udp-port>1</udp-port> <!-- operation="delete"-->
    </host>
</hosts>
</server>
</servers>
</snmp>
```

Command Syntax

```
snmp-server host (A.B.C.D|X:X::X:X|HOSTNAME) WORD (udp-port <1-65535>|) (vrf
management|)
```

Configure user name

Use this attribute to create an SNMP server user.

Attribute Name: user-name

Attribute Type: string

Attribute Range: 5-32

Attribute Name: authentication-type

Attribute Type: enum (md5|sha)

Attribute Name: encryption-type

Attribute Type: enum (plain|encrypt)

Attribute Name: authentication-password

Attribute Type: string

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
<servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
  <server>
    <vrf-name>management</vrf-name>
    <config>
      <vrf-name>management</vrf-name>
    </config>
    <users xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
      <user> <!-- operation="delete"-->
        <user-name>WORD</user-name>
        <config>
          <user-name>WORD</user-name>
          <authentication-type>md5</authentication-type>
          <encryption-type>1</encryption-type>
          <authentication-password>AUTH-PASSWORD</authentication-password>
        </config>
      </user>
    </users>
  </server>
</servers>
</snmp>
```

Command Syntax

```
snmp-server user WORD auth (md5|sha) encrypt AUTH-PASSWORD (vrf management|)
```

Configure authentication type

Use this attribute to create an SNMP server user.

Attribute Name: user-name

Attribute Type: string

Attribute Range: 5-32

Attribute Name: authentication-type

Attribute Type: enum (md5|sha)

Attribute Name: encryption-type

Attribute Type: enum (plain|encrypt)

Attribute Name: authentication-password

Attribute Type: string

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <users xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
        <user> <!-- operation="delete"-->
          <user-name>WORD</user-name>
          <config>
            <user-name>WORD</user-name>
            <authentication-type>md5</authentication-type>
            <encryption-type>0</encryption-type>
            <authentication-password>AUTH-PASSWORD</authentication-password>
          </config>
        </user>
      </users>
    </server>
  </servers>
</snmp>
```

Command Syntax

```
snmp-server user WORD auth (md5|sha) AUTH-PASSWORD (vrf management|)
```

Configure user type

Use this attribute to create an SNMP server user.

Attribute Name: user-name

Attribute Type: string

Attribute Range: 5-32

Attribute Name: user-type

Attribute Type: union

Attribute Name: authentication-type

Attribute Type: enum (md5|sha)

Attribute Name: encryption-type

Attribute Type: enum (plain|encrypt)

Attribute Name: authentication-password

Attribute Type: string

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <users xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
        <user <!-- operation="delete"-->
          <user-name>WORD</user-name>
          <config>
            <user-name>WORD</user-name>
            <user-type>network-operator</user-type>
            <authentication-type>md5</authentication-type>
            <encryption-type>1</encryption-type>
            <authentication-password>AUTH-PASSWORD</authentication-password>
          </config>
        </user>
      </users>
    </server>
  </servers>
</snmp>
```

Command Syntax

```
snmp-server user WORD (network-operator|network-admin|WORD) auth (md5|sha) encrypt
AUTH-PASSWORD (vrf management|)
```

Configure encryption type

Use this attribute to create an SNMP server user.

Attribute Name: user-name

Attribute Type: string

Attribute Range: 5-32

Attribute Name: user-type

Attribute Type: union

Attribute Name: authentication-type

Attribute Type: enum (md5|sha)

Attribute Name: encryption-type

Attribute Type: enum (plain|encrypt)

Attribute Name: authentication-password

Attribute Type: string

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <users xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
        <user> <!-- operation="delete"-->
          <user-name>WORD</user-name>
          <config>
            <user-name>WORD</user-name>
            <user-type>network-operator</user-type>
            <authentication-type>md5</authentication-type>
            <encryption-type>0</encryption-type>
            <authentication-password>AUTH-PASSWORD</authentication-password>
          </config>
        </user>
      </users>
    </server>
  </servers>
</snmp>
```

Command Syntax

```
snmp-server user WORD (network-operator|network-admin|WORD) auth (md5|sha) AUTH-
PASSWORD (vrf management|)
```

Configure authentication password

Use this attribute to create an SNMP server user.

Attribute Name: user-name

Attribute Type: string

Attribute Range: 5-32

Attribute Name: authentication-type

Attribute Type: enum (md5|sha)

Attribute Name: encryption-type

Attribute Type: enum (plain|encrypt)

Attribute Name: authentication-password

Attribute Type: string

Attribute Name: privilege-type

Attribute Type: enum (des|aes)

Attribute Name: privilege-password

Attribute Type: string

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <users xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
        <user <!-- operation="delete"-->
          <user-name>WORD</user-name>
          <config>
            <user-name>WORD</user-name>
            <authentication-type>md5</authentication-type>
            <encryption-type>1</encryption-type>
            <authentication-password>AUTH-PASSWORD</authentication-password>
            <privilege-type>des</privilege-type>
            <privilege-password>PRIV-PASSWORD</privilege-password>
          </config>
        </user>
      </users>
    </server>
  </servers>
</snmp>
```

Command Syntax

```
snmp-server user WORD auth (md5|sha) encrypt AUTH-PASSWORD priv (des|aes) PRIV-
PASSWORD (vrf management|)
```

Configure privilege type

Use this attribute to create an SNMP server user.

Attribute Name: user-name

Attribute Type: string

Attribute Range: 5-32

Attribute Name: authentication-type

Attribute Type: enum (md5|sha)

Attribute Name: encryption-type

Attribute Type: enum (plain|encrypt)

Attribute Name: authentication-password

Attribute Type: string

Attribute Name: privilege-type

Attribute Type: enum (des|aes)

Attribute Name: privilege-password

Attribute Type: string

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <users xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
        <user <!-- operation="delete"-->
          <user-name>WORD</user-name>
          <config>
            <user-name>WORD</user-name>
            <authentication-type>md5</authentication-type>
            <encryption-type>0</encryption-type>
            <authentication-password>AUTH-PASSWORD</authentication-password>
            <privilege-type>des</privilege-type>
            <privilege-password>PRIV-PASSWORD</privilege-password>
          </config>
        </user>
      </users>
    </server>
  </servers>
</snmp>
```

Command Syntax

```
snmp-server user WORD auth (md5|sha) AUTH-PASSWORD priv (des|aes) PRIV-PASSWORD
(vrf management|)
```

Configure privilege password

Use this attribute to create an SNMP server user.

Attribute Name: user-name

Attribute Type: string

Attribute Range: 5-32

Attribute Name: user-type

Attribute Type: union

Attribute Name: authentication-type

Attribute Type: enum (md5|sha)

Attribute Name: encryption-type

Attribute Type: enum (plain|encrypt)

Attribute Name: authentication-password

Attribute Type: string

Attribute Name: privilege-type

Attribute Type: enum (des|aes)

Attribute Name: privilege-password

Attribute Type: string

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <users xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
        <user> <!-- operation="delete"-->
          <user-name>WORD</user-name>
          <config>
            <user-name>WORD</user-name>
            <user-type>network-operator</user-type>
            <authentication-type>md5</authentication-type>
            <encryption-type>1</encryption-type>
            <authentication-password>AUTH-PASSWORD</authentication-password>
            <privilege-type>des</privilege-type>
            <privilege-password>PRIV-PASSWORD</privilege-password>
          </config>
        </user>
      </users>
    </server>
  </servers>
</snmp>
```

Command Syntax

```
snmp-server user WORD (network-operator|network-admin|WORD) auth (md5|sha) encrypt
AUTH-PASSWORD priv (des|aes) PRIV-PASSWORD (vrf management|)
```

Configure vrf name

Use this attribute to create an SNMP server user.

Attribute Name: user-name

Attribute Type: string

Attribute Range: 5-32

Attribute Name: user-type

Attribute Type: union

Attribute Name: authentication-type

Attribute Type: enum (md5|sha)

Attribute Name: encryption-type

Attribute Type: enum (plain|encrypt)

Attribute Name: authentication-password

Attribute Type: string

Attribute Name: privilege-type

Attribute Type: enum (des|aes)

Attribute Name: privilege-password

Attribute Type: string

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snm">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snm-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <users xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snm-server-extended">
        <user> <!-- operation="delete"-->
          <user-name>WORD</user-name>
          <config>
            <user-name>WORD</user-name>
            <user-type>network-operator</user-type>
            <authentication-type>md5</authentication-type>
            <encryption-type>0</encryption-type>
            <authentication-password>AUTH-PASSWORD</authentication-password>
            <privilege-type>des</privilege-type>
            <privilege-password>PRIV-PASSWORD</privilege-password>
          </config>
        </user>
      </users>
    </server>
  </servers>
</snmp>
```

Command Syntax

```
snmp-server user WORD (network-operator|network-admin|WORD) auth (md5|sha) AUTH-  
PASSWORD priv (des|aes) PRIV-PASSWORD (vrf management|)
```

Configure context name

Use this attribute to create an SNMP server context

Attribute Name: context-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">  
<servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">  
  <server>  
    <vrf-name>management</vrf-name>  
    <config>  
      <vrf-name>management</vrf-name>  
    </config>  
    <contexts xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-  
extended">  
      <context>  
        <context-name>WORD</context-name>  
        <config>  
          <context-name>WORD</context-name>  
        </config>  
      </context>  
    </contexts>  
  </server>  
</servers>  
</snmp>
```

Command Syntax

```
snmp-server context WORD (vrf management|)
```

Configure acl name

Use this attribute to create an SNMP community string and user-acl.

This command is supported when following feature are enabled SNMP-AGENT feature

Attribute Name: acl-name

Attribute Type: string

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">  
<servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">  
  <server>  
    <vrf-name>management</vrf-name>
```



```

    <config>
      <vrf-name>management</vrf-name>
    </config>
  <communities xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
    <community>
      <community-name>WORD</community-name>
      <config>
        <community-name>WORD</community-name>
      </config>
      <acl-name>WORD</acl-name> <!-- operation="delete"-->
    </community>
  </communities>
</server>
</servers>
</snmp>

```

Command Syntax

```
snmp-server community WORD use-acl WORD (vrf management|)
```

Configure community name

Use this attribute to create an SNMP community string and access privileges.

This command is supported when following feature are enabled SNMP-AGENT feature

Attribute Name: community-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```

<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <communities xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
        <community>
          <community-name>WORD</community-name>
          <config>
            <community-name>WORD</community-name>
          </config>
        </community>
      </communities>
    </server>
  </servers>
</snmp>

```

Command Syntax

```
snmp-server community WORD (vrf management|)
```

Configure snmp group

Use this attribute to create an SNMP community string with group.

This command is supported when following feature are enabled SNMP-AGENT feature

Attribute Name: snmp-group

Attribute Type: enum (network-operator|network-admin)

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <communities xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
        <community>
          <community-name>WORD</community-name>
          <config>
            <community-name>WORD</community-name>
          </config>
          <snmp-group>network-operator</snmp-group> <!-- operation="delete"-->
        </community>
      </communities>
    </server>
  </servers>
</snmp>
```

Command Syntax

```
snmp-server community WORD group (network-operator|network-admin) (vrf management|)
```

Configure access privileges

Use this attribute to create an SNMP community string and access privileges.

This command is supported when following feature are enabled SNMP-AGENT feature

Attribute Name: access-privileges

Attribute Type: enum (ro)

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
```

```

    <config>
      <vrf-name>management</vrf-name>
    </config>
  <communities xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
    <community>
      <community-name>WORD</community-name>
      <config>
        <community-name>WORD</community-name>
      </config>
      <access-privileges>ro</access-privileges> <!-- operation="delete"-->
    </community>
  </communities>
</server>
</servers>
</snmp>

```

Command Syntax

```
snmp-server community WORD (ro) (vrf management|)
```

Configure access

Use this attribute to set access privileges to this community view.

This command is supported when following feature are enabled SNMP-AGENT feature

Attribute Name: access

Attribute Type: enum (ro)

Attribute Name: community-view-name

Attribute Type: string

Attribute Name: version

Attribute Type: enum (v1|v2c)

Netconf edit-config payload

```

<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <communities xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
        <community>
          <community-name>WORD</community-name>
          <config>
            <community-name>WORD</community-name>
            <community-view-name>VIEW-NAME</community-view-name> <!--
operation="delete"-->
            <version>v1</version> <!-- operation="delete"-->
          </config>
        </community>
      </communities>
    </server>
  </servers>
</snmp>

```

```
        </config>
        <access>ro</access> <!-- operation="delete"-->
    </community>
</communities>
</server>
</servers>
</snmp>
```

Command Syntax

```
snmp-server community WORD view VIEW-NAME version (v1|v2c) (ro) (vrf management|)
```

Configure community context

Use this attribute to create an SNMP community string and access privileges.

Attribute Name: community-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: community-context

Attribute Type: string

Attribute Range: 1-32

Attribute Name: community-user

Attribute Type: string

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmpp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmpp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <communities xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmpp-server-extended">
        <community>
          <community-name>WORD</community-name>
          <config>
            <community-name>WORD</community-name>
          </config>
          <community-context-mapping>
            <config>
              <community-context>WORD</community-context>
              <community-user>WORD</community-user>
            </config>
          </community-context-mapping>
        </community>
      </communities>
    </server>
```

```
</servers>
</snmp>
```

Command Syntax

```
snmp-server community-map WORD context WORD user WORD (vrf management|)
```

Configure group name

Use this attribute to create an SNMP group string.

Attribute Name: group-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: group-version

Attribute Type: enum (1|2c|3)

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <server-groups xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
        <server-group>
          <group-name>WORD</group-name>
          <config>
            <group-name>WORD</group-name>
            <group-version>1</group-version>
          </config>
        </server-group>
      </server-groups>
    </server>
  </servers>
</snmp>
```

Command Syntax

```
snmp-server group WORD version (1|2c) (vrf management|)
```

Configure group version

Use this attribute to create an SNMP group string.

Attribute Name: group-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: group-version

Attribute Type: enum (1|2c|3)

Attribute Name: snmpv3-group-auth-type

Attribute Type: enum (auth|priv|noauth)

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
      <server-groups xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
        <server-group>
          <group-name>WORD</group-name>
          <config>
            <group-name>WORD</group-name>
            <group-version>1</group-version>
            <snmpv3-group-auth-type>auth</snmpv3-group-auth-type>
          </config>
        </server-group>
      </server-groups>
    </server>
  </servers>
</snmp>
```

Command Syntax

```
snmp-server group WORD version (3) (auth|priv|noauth) (vrf management|)
```

Configure context

Use this attribute to create an SNMP group string.

Attribute Name: group-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: group-version

Attribute Type: enum (1|2c|3)

Attribute Name: context

Attribute Type: union

Attribute Range: 1-32

Netconf edit-config payload

```
<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
```

```

    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    <server-groups xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
      <server-group>
        <group-name>WORD</group-name>
        <config>
          <group-name>WORD</group-name>
          <group-version>1</group-version>
          <context>1</context>
        </config>
      </server-group>
    </server-groups>
  </server>
</servers>
</snmp>

```

Command Syntax

```
snmp-server group WORD version (1|2c) context (all|WORD) (vrf management|)
```

Configure snmpv3 group auth type

Use this attribute to create an SNMP group string.

Attribute Name: group-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: group-version

Attribute Type: enum (1|2c|3)

Attribute Name: snmpv3-group-auth-type

Attribute Type: enum (auth|priv|noauth)

Attribute Name: context

Attribute Type: enum (all)

Attribute Range: 1-32

Netconf edit-config payload

```

<snmp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp">
  <servers xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server">
    <server>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </server>
  </servers>
</snmp>

```

```
<server-groups xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-snmp-server-extended">
  <server-group>
    <group-name>WORD</group-name>
    <config>
      <group-name>WORD</group-name>
      <group-version>1</group-version>
      <snmpv3-group-auth-type>auth</snmpv3-group-auth-type>
      <context>1</context>
    </config>
  </server-group>
</server-groups>
</server>
</servers>
</snmp>
```

Command Syntax

```
snmp-server group WORD version (3) (auth|priv|noauth) context <1-32> (all) (vrf
management|)
```

debug snmp-server

Netconf RPC payload

```
<snmp-server-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
snmp-server-extended"/>
```

Command Syntax

```
debug snmp-server
```

no debug snmp-server

Netconf RPC payload

```
<snmp-server-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
snmp-server-extended"/>
```

Command Syntax

```
no debug snmp-server
```

IPI-LDP

Configure multicast hello disable

This attribute enable multicast hello exchange on all interfaces enabled for LDP. This is used for autodiscovery of LDP peers on directly connected networks. This option is enabled by default.

Attribute Name: multicast-hello-disable

Attribute Type: uint8

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
  <config>
    </multicast-hello-disable><!-- operation="delete"-->
  </config>
</global>
</ldp>
```

Command Syntax

```
no multicast-hellos
```

Configure ldp instance

This command is used to enter the LDP specific command-line mode in which global attributes for the LDP process can be set. Without this command, the LSR does not perform any LDP operations, such as sending hello packets.

Attribute Name: ldp-instance

Attribute Type: enum (ldp)

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
  <config>
    <ldp-instance>ldp</ldp-instance>
  </config>
</global>
</ldp>
```

Command Syntax

```
router (ldp)
```

Configure router identifier

This attribute sets the router-id to the supplied IP address; the router uses this address to generate the LDP-ID

Attribute Name: router-identifier

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
  <config>
    <router-identifier>A.B.C.D</router-identifier> <!-- operation="delete"-->
  </config>
</global>
</ldp>
```

Command Syntax

```
router-id A.B.C.D
```

Configure pseudowire status tlv

This attribute enables the use of the PW Status TLV to signal the pseudowire status

Attribute Name: pseudowire-status-tlv

Attribute Type: boolean

Default Value: false

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <config>
      <pseudowire-status-tlv>true</pseudowire-status-tlv> <!-- operation="delete"-->
    </config>
  </global>
</ldp>
```

Command Syntax

```
pw-status-tlv
```

Configure rlfa ilm optimization

This attribute enables the rlfa ilm optimization

Attribute Name: rlfa-ilm-optimization

Attribute Type: boolean

Default Value: false

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <config>
      <rlfa-ilm-optimization>true</rlfa-ilm-optimization> <!-- operation="delete"-->
    </config>
  </global>
</ldp>
```

Command Syntax

```
rlfa-ilm-optimization
```

Configure entropy label capability enable

This attribute enables ELC for the router. An ELC TLV will be inserted in the label mapping message if the router is capable of processing Entropy Label.

Attribute Name: entropy-label-capability-enable

Attribute Type: boolean

Default Value: false

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <config>
      <entropy-label-capability-enable>true</entropy-label-capability-enable> <!--
operation="delete"-->
    </config>
  </global>
</ldp>
```

Command Syntax

```
entropy-label-capability
```

Configure advertise label for default route

Advertise the label for default route.

Attribute Name: advertise-label-for-default-route

Attribute Type: empty

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <config>
      </advertise-label-for-default-route><!-- operation="delete"-->
    </config>
  </global>
</ldp>
```

Command Syntax

```
advertise-label-for-default-route
```

Configure import bgp routes

This attribute is used to import BGP routes into LDP. BGP routes are not imported into LDP by default. Use the no parameter to flush out all BGP routes currently being used by LDP, and to reject any further BGP specific routing updates from ZebOS-XP.

Attribute Name: import-bgp-routes

Attribute Type: boolean

Default Value: false

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <config>
      <import-bgp-routes>true</import-bgp-routes> <!-- operation="delete"-->
    </config>
  </global>
</ldp>
```

Command Syntax

```
import-bgp-routes
```

Configure ldp optimization

This command helps optimize the resetting of an LDP session by enabling the two scalability features for LDP. It Resets the session keepalive timer on receipt of a hello message and Resets the hold timer on receipt of any LDP control message.

Attribute Name: ldp-optimization

Attribute Type: boolean

Default Value: false

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <config>
      <ldp-optimization>true</ldp-optimization> <!-- operation="delete"-->
    </config>
  </global>
</ldp>
```

Command Syntax

```
ldp-optimization
```

Configure explicit null

This attribute is used to configure the router to send explicit-null labels for directly connected FECs instead of implicit-null labels. Implicit-nulls are the default labels.

Attribute Name: explicit-null

Attribute Type: boolean

Default Value: false

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <config>
      <explicit-null>true</explicit-null> <!-- operation="delete"-->
    </config>
  </global>
</ldp>
```

Command Syntax

```
explicit-null
```

Configure global merge

This attribute is used to override the default merge capability setting of all the interfaces for the current LSR. The merge capability aggregates multiple incoming flows with the same destination address into a single outgoing flow.

Attribute Name: global-merge

Attribute Type: enum (merge-capable|non-merge-capable)

Default Value: merge-capable

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <config>
      <global-merge>merge-capable</global-merge> <!-- operation="delete"-->
    </config>
  </global>
</ldp>
```

Command Syntax

```
global-merge-capability (merge-capable|non-merge-capable)
```

Configure propagate release

This attribute is used to propagate the release of labels to downstream routers

Attribute Name: propagate-release

Attribute Type: boolean

Default Value: false

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <config>
      <propagate-release>true</propagate-release> <!-- operation="delete"-->
    </config>
  </global>
</ldp>
```

Command Syntax

```
propagate-release
```

Configure fast reroute

This attribute is used to enable the use by LDP of the LFA next-hop

Attribute Name: fast-reroute

Attribute Type: empty

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
  <config>
    </fast-reroute><!-- operation="delete"-->
  </config>
</global>
</ldp>
```

Command Syntax

```
fast-reroute
```

Configure auto targeted session

This attribute is used to dynamically create TLDP session for LDP RLFA.

Attribute Name: auto-targeted-session

Attribute Type: empty

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
  <config>
    </auto-targeted-session><!-- operation="delete"-->
  </config>
</global>
</ldp>
```

Command Syntax

```
auto-targeted-session
```

Configure control mode

Use this attribute to override the default merge capability setting of all the interfaces for the current LSR. The merge capability aggregates multiple incoming flows with the same destination address into a single outgoing flow. This reduces the label-space shortage by sharing labels for different flows with the same destination, or the same FEC (Forwarding Equivalence Class). An LSR replies to a request packet from an LSR higher in the chain only after it receives a label from an LSR lower in the chain. Independent processing sets the mode to instant replies. In independent control mode, each LSR might advertise label mappings to its neighbors at any time. In independent downstream-on-demand mode, an LSR might answer requests for label mappings immediately, without waiting for a label mapping from the next hop. In independent downstream unsolicited mode, an LSR might advertise a label mapping for an Forwarding Equivalence Class (FEC) to its neighbors when ever it is prepared to label-switch that FEC. In independent mode, an upstream label can be advertised before a downstream label is received. In ordered control mode, an LSR may initiate the transmission of label mapping only for an FEC for which it has a label mapping for the FEC next hop, or for which the LSR is the egress. For each FEC for which the LSR is not the egress and no mapping exists, the LSR must wait until a label from a downstream LSR is received. An LSR may be an egress for some FECs and a non-egress for others. Changes in control mode only affect labels that were sent or received after the change was made.

Attribute Name: control-mode

Attribute Type: enum (independent|ordered)

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<global>
<label-management>
<config>
  <control-mode>independent</control-mode> <!-- operation="delete"-->
</config>
</label-management>
</global>
</ldp>
```

Command Syntax

```
control-mode (independent|ordered)
```

Configure retention mode

This attribute is used to set the retention mode to be used for all labels exchanged. When an LSR receives a label binding for a particular FEC (Forwarding Equivalence Class) from another LSR that is not its next hop for that FEC, it might keep track of such bindings or discard them. Use the liberal parameter to retain all labels binding to FEC received from label distribution peers, even if the LSR is not the current next-hop. Use the conservative parameter to maintain only the label bindings for valid next-hops in a LSP.

Attribute Name: retention-mode

Attribute Type: enum (liberal|conservative)

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<global>
<label-management>
<config>
  <retention-mode>liberal</retention-mode> <!-- operation="delete"-->
</config>
</label-management>
</global>
</ldp>
```

Command Syntax

```
label-retention-mode (liberal|conservative)
```

Configure advertisement mode

This attribute is used to set the label advertisement mode for all the interfaces for the current LSR. Specifying downstream-on-demand and downstream-unsolicited mode affects which LSR initiates mapping requests and mapping advertisements. This command is a global command used to set the label advertisement mode for all interfaces for the current LSR.

Attribute Name: advertisement-mode

Attribute Type: enum (downstream-unsolicited|downstream-on-demand)

Default Value: downstream-unsolicited

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <label-management>
      <config>
        <advertisement-mode>downstream-unsolicited</advertisement-mode> <!--
operation="delete"-->
      </config>
    </label-management>
  </global>
</ldp>
```

Command Syntax

```
advertisement-mode (downstream-unsolicited|downstream-on-demand)
```

Configure hello interval

Use this attribute set the hello interval to send the hello messages to peers

Attribute Name: hello-interval

Attribute Type: uint16

Default Value: 5

Attribute Range: 1-21845

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <timers>
      <config>
        <hello-interval>1</hello-interval> <!-- operation="delete"-->
      </config>
    </timers>
  </global>
</ldp>
```

Command Syntax

```
hello-interval <1-21845>
```

Configure hello holdtime

Use this attribute set the hello hold time as the time out value that the router waits before rejecting an adjacency

Attribute Name: hello-holdtime

Attribute Type: uint16

Default Value: 15

Attribute Range: 3-65535

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<global>
<timers>
<config>
  <hello-holdtime>3</hello-holdtime> <!-- operation="delete"-->
</config>
</timers>
</global>
</ldp>
```

Command Syntax

```
hold-time <3-65535>
```

Configure keepalive interval

Use this attribute to set the global value for the interval after which keep-alive packets are sent out

Attribute Name: keepalive-interval

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-21845

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<global>
<timers>
<config>
  <keepalive-interval>1</keepalive-interval> <!-- operation="delete"-->
</config>
</timers>
</global>
</ldp>
```

Command Syntax

```
keepalive-interval <1-21845>
```

Configure keepalive timeout

Use this attribute to set the time period for which an LSR must wait for successive keep-alive messages from LDP peers

Attribute Name: keepalive-timeout

Attribute Type: uint16

Default Value: 30

Attribute Range: 3-65535

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <timers>
      <config>
        <keepalive-timeout>3</keepalive-timeout> <!-- operation="delete"-->
      </config>
    </timers>
  </global>
</ldp>
```

Command Syntax

```
keepalive-timeout <3-65535>
```

Configure request retry timeout

Use this attribute to set the interval between retries. Before this time is over, a request is re-sent to a peer. This command changes the interval between request messages that are resent to a peer to account for routing changes.

Attribute Name: request-retry-timeout

Attribute Type: uint16

Default Value: 5

Attribute Range: 1-65535

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <label-request-policy>
      <config>
        <request-retry-timeout>1</request-retry-timeout> <!-- operation="delete"-->
      </config>
    </label-request-policy>
  </global>
</ldp>
```

Command Syntax

```
request-retry-timeout <1-65535>
```

Configure request retry

Use this attribute to enable the retry of requests once a request for a label has been rejected for a valid reason. This command enables the LSR to send a maximum of five label requests if a label request is rejected by an LDP peer.

Attribute Name: request-retry

Attribute Type: boolean

Default Value: false

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
```

```

<global>
<label-request-policy>
<config>
  <request-retry>true</request-retry> <!-- operation="delete"-->
</config>
</label-request-policy>
</global>
</ldp>

```

Command Syntax

```
request-retry
```

Configure label request policy ipv4

Use this attribute to send LDP Label Request Message for certain IPv4 FEC prefixes.

Attribute Name: label-request-policy-ipv4

Attribute Type: string

Netconf edit-config payload

```

<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<global>
<label-request-policy>
<config>
  <label-request-policy-ipv4>NAME</label-request-policy-ipv4> <!--
operation="delete"-->
</config>
</label-request-policy>
</global>
</ldp>

```

Command Syntax

```
request-labels-for prefix-list-ipv4 NAME
```

Configure loop detection enable

Use this attribute to enable loop detection on the current LSR. This command detects looping LSPs, and prevent Label Request messages from looping because of non-merge capable LSRs. This loop detection mechanism is useful for networks of non time-to-live (non TTL) decrementing devices that can not allocate resources among traffic flows.

Attribute Name: loop-detection-enable

Attribute Type: empty

Netconf edit-config payload

```

<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<global>
<loop-detection-policy>
<config>
  </loop-detection-enable>
</config>

```

```
</loop-detection-policy>  
</global>  
</ldp>
```

Command Syntax

```
loop-detection
```

Configure path vector limit

Use this attribute to set the loop detection vec (vector) count, which determines the maximum supported path vectors. This command sets the maximum supported path vectors for loop detection, which specifies the permitted path vector length. An LSR that detects a path vector has reached the maximum length behaves as if the containing message has traversed a loop. This command ensures that a loop is detected while establishing a label switched path before any data is passed over that LSP.

Attribute Name: path-vector-limit

Attribute Type: uint32

Default Value: 255

Attribute Range: 1-255

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">  
  <global>  
    <loop-detection-policy>  
      <config>  
        <path-vector-limit>1</path-vector-limit> <!-- operation="delete"-->  
      </config>  
    </loop-detection-policy>  
  </global>  
</ldp>
```

Command Syntax

```
loop-detection-path-vec-count <1-255>
```

Configure hop count limit

Use this attribute to set the loop detection hop count, which determines the maximum hop-count value. This command sets the maximum hop count value, which specifies the permitted maximum permitted hop-count. An LSR that detects a maximum hop count behaves as if the containing message has traversed a loop. The use of this command ensures that a loop is detected while establishing a label switched path before any data is passed via LSP

Attribute Name: hop-count-limit

Attribute Type: uint32

Default Value: 255

Attribute Range: 1-255

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">  
  <global>
```

```
<loop-detection-policy>
<config>
  <hop-count-limit>1</hop-count-limit> <!-- operation="delete"-->
</config>
</loop-detection-policy>
</global>
</ldp>
```

Command Syntax

```
loop-detection-hop-count <1-255>
```

Configure session protection enable

This attribute is used to activate adjacency session protection.

This command is supported when following feature are enabled LDP Session Protection feature

Attribute Name: session-protection-enable

Attribute Type: empty

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<global>
<session-protection>
<config>
  </session-protection-enable>
</config>
</session-protection>
</global>
</ldp>
```

Command Syntax

```
session-protection
```

Configure duration

Set adjacency session protection duration. Protection is infinite, it is not configured

This command is supported when following feature are enabled LDP Session Protection feature

Attribute Name: duration

Attribute Type: union

Attribute Name: session-protection-enable

Attribute Type: empty

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<global>
<session-protection>
<config>
```

```
    </session-protection-enable><!-- operation="delete"-->
    <duration>infinite</duration> <!-- operation="delete"-->
</config>
</session-protection>
</global>
</ldp>
```

Command Syntax

```
session-protection duration (infinite|<5-86400>)
```

Configure session protection prefix list name

This attribute is used to set adjacency prefixes for session protection.

This command is supported when following feature are enabled LDP Session Protection feature

Attribute Name: session-protection-prefix-list-name

Attribute Type: union

Attribute Name: session-protection-enable

Attribute Type: empty

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <global>
    <session-protection>
      <config>
        </session-protection-enable><!-- operation="delete"-->
        <session-protection-prefix-list-name>none</session-protection-prefix-list-name>
<!-- operation="delete"-->
      </config>
    </session-protection>
  </global>
</ldp>
```

Command Syntax

```
session-protection for (none|WORD)
```

Configure ldp

Use this attribute to enable the debugging of all LDP events.

Attribute Name: ldp

Attribute Type: bits (events|fsm|hexdump|dsm|usm|tsm|qos|nsm|advertise-labels|cspf|vc usm|vc dsm|graceful-restart|rib|inter-area|packet notification|packet hello|packet initialization|packet keepalive|packet address|packet label|packet|all)

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <debug>
  <config>
```

```

    <ldp>events</ldp> <!-- operation="delete"-->
</config>
</debug>
</ldp>

```

Command Syntax

```

debug ldp (events|fsm|hexdump|dsm|usm|tsm|qos|nsm|advertise-labels|cspf|vc usm|vc
dsm|graceful-restart|rib|inter-area|packet notification|packet hello|packet
initialization|packet keepalive|packet address|packet label|packet|all)

```

Configure enable

Use this attribute with the enable option to enable Graceful Restart capability on a router. This is a global command. LDP decides whether or not to encode FT Session TLV in its initialization message for each session depending on this capability, but the restart capability of each session also depends on support for graceful restart at the peer router

This command is supported when following feature are enabled restart feature

Attribute Name: enable

Attribute Type: enum (full|helper-only)

Netconf edit-config payload

```

<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<graceful-restart>
<config>
    <enable>full</enable>
</config>
</graceful-restart>
</ldp>

```

Command Syntax

```

graceful-restart (full|helper-only)

```

Configure neighbor liveness time

Use this attribute to set the Neighbor-Liveness timer. The amount of time the LSR keeps its stale label-FEC (Forwarding Equivalence Class) bindings is set to the lesser of the Fault Tolerant (FT) Reconnect timeout and Neighbor-Liveness timer. This command sets the Neighbor-Liveness timer

This command is supported when following feature are enabled restart feature

Attribute Name: neighbor-liveness-time

Attribute Type: uint16

Default Value: 120

Attribute Range: 5-300

Netconf edit-config payload

```

<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<graceful-restart>
<config>
    <neighbor-liveness-time>5</neighbor-liveness-time> <!-- operation="delete"-->

```

```
</config>
</graceful-restart>
</ldp>
```

Command Syntax

```
graceful-restart timers neighbor-liveness <5-300>
```

Configure max recovery time

Use this attribute to set the maximum recovery time. If the LSR determines that the neighbor was able to preserve its MPLS forwarding state, the LSR should keep the stale label-FEC (Forwarding Equivalence Class) bindings for as long as the lesser of: the recovery time advertised by the neighbor and a local maximum recovery time. This command sets the maximum recovery time

This command is supported when following feature are enabled restart feature

Attribute Name: max-recovery-time

Attribute Type: uint16

Default Value: 120

Attribute Range: 15-600

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <graceful-restart>
    <config>
      <max-recovery-time>15</max-recovery-time> <!-- operation="delete"-->
    </config>
  </graceful-restart>
</ldp>
```

Command Syntax

```
graceful-restart timers max-recovery <15-600>
```

Configure inter area acl name

Use this attribute to enable creation of inter-area LSPs.

Attribute Name: inter-area-acl-name

Attribute Type: string

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <inter-area>
    <inter-area-enable>WORD</inter-area-enable>
    <config>
      <inter-area-enable>WORD</inter-area-enable>
      <inter-area-acl-name>WORD</inter-area-acl-name>
    </config>
    <inter-area-acl-name>WORD</inter-area-acl-name>
  </inter-area>
```

```
</ldp>
```

Command Syntax

```
inter-area-lsp (PREFIX_ACL|) (config-only|)
```

Configure transport address ipv4

Use this attribute to configure the IPv4 transport address for a label space. The transport address is the address used for the TCP session over which LDP is running. Use this attribute to manually configure the transport address. Transport addresses may either be bound to a loopback interface, or to a physical interface that is bound to the label space in question. A transport address can also be manually configured using the CLI with the loopback address as the transport address.

Attribute Name: transport-address-ipv4

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <transport-addresses>
    <transport-address>
      <label-space-identifier>0</label-space-identifier>
      <config>
        <label-space-identifier>0</label-space-identifier>
      </config>
      <transport-address-ipv4>A.B.C.D</transport-address-ipv4> <!--
operation="delete"-->
    </transport-address>
  </transport-addresses>
</ldp>
```

Command Syntax

```
transport-address ipv4 A.B.C.D ((0|))
```

Configure peer address

Use this attribute to configure neighbors of LDP for authentication.

This command is supported when following feature are enabled TCP MD5SIG encrypt password enabled

Attribute Name: peer-address

Attribute Type: union

Attribute Name: password-type

Attribute Type: enum (plain-text|encrypt)

Attribute Name: password

Attribute Type: string

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <peer-authentication>
```

```
<peer-authentication-lists>
<peer-authentication-list> <!-- operation="delete"-->
  <peer-address>all</peer-address>
  <config>
    <peer-address>all</peer-address>
    <password-type>plain-text</password-type>
    <password>WORD</password>
  </config>
</peer-authentication-list>
</peer-authentication-lists>
</peer-authentication>
</ldp>
```

Command Syntax

```
neighbor (all|auto-targeted|A.B.C.D) auth md5 password (plain-text|encrypt) WORD
```

Configure group name

LDP Session group name.

Attribute Name: group-name

Attribute Type: string

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<peer-authentication>
<authentication-groups>
<authentication-group> <!-- operation="delete"-->
  <group-name>NAME</group-name>
  <config>
    <group-name>WORD</group-name>
  </config>
</authentication-group>
</authentication-groups>
</peer-authentication>
</ldp>
```

Command Syntax

```
session-group name NAME
```

Configure prefix list

Peer authentication group prefix list.

Attribute Name: prefix-list

Attribute Type: string

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<peer-authentication>
```

```

<authentication-groups>
<authentication-group>
  <group-name>NAME</group-name>
  <config>
    <group-name>WORD</group-name>
  </config>
  <prefix-list>NAME</prefix-list> <!-- operation="delete"-->
</authentication-group>
</authentication-groups>
</peer-authentication>
</ldp>

```

Command Syntax

```
neighbor prefix-list NAME
```

Configure auth

Use this attribute to configure session-group authentication.

Attribute Name: auth

Attribute Type: enum (auth)

Attribute Name: password-type

Attribute Type: enum (plain-text|encrypt)

Attribute Name: password

Attribute Type: string

Netconf edit-config payload

```

<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<peer-authentication>
<authentication-groups>
<authentication-group>
  <group-name>NAME</group-name>
  <config>
    <group-name>WORD</group-name>
  </config>
<authentication-group-passwords>
<authentication-group-password> <!-- operation="delete"-->
  <auth>auth</auth>
  <config>
    <auth>auth</auth>
    <password-type>plain-text</password-type>
    <password>WORD</password>
  </config>
</authentication-group-password>
</authentication-group-passwords>
</authentication-group>
</authentication-groups>
</peer-authentication>
</ldp>

```

Command Syntax

```
(auth) md5 password (plain-text|encrypt) WORD
```

Configure prefix access control list name

Use this attribute to prevent the distribution of any locally assigned labels

Attribute Name: prefix-access-control-list-name

Attribute Type: string

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<label-mapping-access-lists>
<label-mapping-access-list>
  <prefix-access-control-list-name>WORD</prefix-access-control-list-name>
  <config>
    <prefix-access-control-list-name>WORD</prefix-access-control-list-name>
    <peer-access-control-list-name>WORD</peer-access-control-list-name>
  </config>
  <peer-access-control-list-name>WORD</peer-access-control-list-name>
</label-mapping-access-list>
</label-mapping-access-lists>
</ldp>
```

Command Syntax

```
advertise-labels for any to none
```

Configure peer access control list name

Use this attribute to prevent the distribution of any locally assigned labels

Attribute Name: prefix-access-control-list-name

Attribute Type: string

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<label-mapping-access-lists>
<label-mapping-access-list>
  <prefix-access-control-list-name>WORD</prefix-access-control-list-name>
  <config>
    <prefix-access-control-list-name>WORD</prefix-access-control-list-name>
    <peer-access-control-list-name>WORD</peer-access-control-list-name>
  </config>
  <peer-access-control-list-name>WORD</peer-access-control-list-name>
</label-mapping-access-list>
</label-mapping-access-lists>
</ldp>
```

Command Syntax

```
advertise-labels for PREFIX to (any|PEER)
```

Configure tcp mss range

Use this attribute to configure TCP MSS for LDP neighbors

Attribute Name: tcp-mss-range

Attribute Type: uint32

Attribute Range: 560-1440

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <tcp-mss-lists>
    <tcp-mss-list>
      <peer-address>all</peer-address>
      <config>
        <peer-address>all</peer-address>
      </config>
      <tcp-mss-range>560</tcp-mss-range> <!-- operation="delete"-->
    </tcp-mss-list>
  </tcp-mss-lists>
</ldp>
```

Command Syntax

```
neighbor (all|auto-targeted|A.B.C.D) tcp-mss <560-1440>
```

clear ldp statistics

Netconf RPC payload

```
<clear-ldp-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp"/>
```

Command Syntax

```
clear ldp statistics
```

clear ldp statistics advertise-labels

Netconf RPC payload

```
<clear-ldp-statistics-advertise-labels xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp"/>
```

Command Syntax

```
clear ldp statistics advertise-labels
```

clear ldp statistics advertise-labels for PREFIX

Attribute Name: prefix

Attribute Type: string

Netconf RPC payload

```
<clear-ldp-statistics-advertise-labels-prefix xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-ldp">
  <prefix>PREFIX</prefix>
</clear-ldp-statistics-advertise-labels-prefix>
```

Command Syntax

```
clear ldp statistics advertise-labels for PREFIX
```

clear ldp statistics advertise-labels for PREFIX to PEER

Attribute Name: prefix

Attribute Type: string

Attribute Name: peer

Attribute Type: string

Netconf RPC payload

```
<clear-ldp-statistics-advertise-labels-prefix-peer xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <prefix>PREFIX</prefix>
  <peer>PEER</peer>
</clear-ldp-statistics-advertise-labels-prefix-peer>
```

Command Syntax

```
clear ldp statistics advertise-labels for PREFIX to PEER
```

clear ldp session *

Netconf RPC payload

```
<clear-ldp-session-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp"/>
```

Command Syntax

```
clear ldp session *
```

clear ldp session A.B.C.D

Attribute Name: addr

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<clear-ldp-session-ipv4 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <addr>A.B.C.D</addr>
</clear-ldp-session-ipv4>
```

Command Syntax

```
clear ldp session A.B.C.D
```

clear ldp adjacency *

Netconf RPC payload

```
<clear-ldp-adjacency-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp"/>
```

Command Syntax

```
clear ldp adjacency *
```

clear ldp adjacency A.B.C.D

Attribute Name: addr

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<clear-ldp-adjacency-ipv4 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">  
<addr>A.B.C.D</addr>  
</clear-ldp-adjacency-ipv4>
```

Command Syntax

```
clear ldp adjacency A.B.C.D
```

snmp restart ldp

Netconf RPC payload

```
<snmp-restart-ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp"/>
```

Command Syntax

```
snmp restart ldp
```

debug ldp (events|fsm|hexdump|dsm|usm|tsm|qos|nsm|advertise-labels|cspf|vc usm|vc dsm|graceful-restart|rib|inter-area|packet notification|packet hello|packet initialization|packet keepalive|packet address|packet label|packet|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (events|fsm|hexdump|dsm|usm|tsm|qos|nsm|advertise-labels|cspf|vc usm|vc dsm|graceful-restart|rib|inter-area|packet notification|packet hello|packet initialization|packet keepalive|packet address|packet label|packet|all)

Netconf RPC payload

```
<ldp-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">  
<terminal-debug-options>events</terminal-debug-options>
```

```
</ldp-terminal-debug-on>
```

Command Syntax

```
debug ldp (events|fsm|hexdump|dsm|usm|tsm|qos|nsm|advertise-labels|cspf|vc usm|vc  
dsm|graceful-restart|rib|inter-area|packet notification|packet hello|packet  
initialization|packet keepalive|packet address|packet label|packet|all)
```

no debug ldp (events|fsm|hexdump|dsm|usm|tsm|qos|nsm|advertise-labels|cspf|vc usm|vc dsm|graceful-restart|rib|inter-area|packet notification|packet hello|packet initialization|packet keepalive|packet address|packet label|packet|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (events|fsm|hexdump|dsm|usm|tsm|qos|nsm|advertise-labels|cspf|vc usm|vc dsm|graceful-restart|rib|inter-area|packet notification|packet hello|packet initialization|packet keepalive|packet address|packet label|packet|all)

Netconf RPC payload

```
<ldp-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">  
<terminal-debug-options>events</terminal-debug-options>  
</ldp-terminal-debug-off>
```

Command Syntax

```
no debug ldp (events|fsm|hexdump|dsm|usm|tsm|qos|nsm|advertise-labels|cspf|vc  
usm|vc dsm|graceful-restart|rib|inter-area|packet notification|packet  
hello|packet initialization|packet keepalive|packet address|packet  
label|packet|all)
```

restart ldp graceful

Netconf RPC payload

```
<restart-ldp-graceful xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp"/>
```

Command Syntax

```
restart ldp graceful
```

IPI-LDP-INTERFACE

Configure enable ldp ipv4

Use this attribute to enable LDP IPv4, on a specified interface. This command enables the transmission of Hello packets through the current interface, so that LDP adjacencies and LDP sessions can be created.

Attribute Name: enable-ldp-ipv4

Attribute Type: uint8

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </enable-ldp-ipv4><!-- operation="delete"-->
</interface>
</interfaces>
</ldp>
```

Command Syntax

```
enable-ldp ipv4
```

Configure name

Use this attribute to enable LDP IPv4, on a specified interface. This command enables the transmission of Hello packets through the current interface, so that LDP adjacencies and LDP sessions can be created.

Attribute Name: enable-ldp-ipv4

Attribute Type: uint8

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </enable-ldp-ipv4><!-- operation="delete"-->
</interface>
</interfaces>
</ldp>
```

Command Syntax

```
enable-ldp ipv4 no-igp-sync
```

Configure multicast hello disable

Use this attribute to enable multicast hello exchange on specified interfaces enabled for LDP.

Attribute Name: multicast-hello-disable

Attribute Type: uint8

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<interfaces>
```

```
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </multicast-hello-disable><!-- operation="delete"-->
</interface>
</interfaces>
</ldp>
```

Command Syntax

```
no ldp multicast-hellos
```

Configure maximum pdu length

Use this attribute to specify max pdu length

Attribute Name: maximum-pdu-length

Attribute Type: uint32

Default Value: 4096

Attribute Range: 256-65535

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <maximum-pdu-length>256</maximum-pdu-length> <!-- operation="delete"-->
    </interface>
  </interfaces>
</ldp>
```

Command Syntax

```
ldp max-pdu-length <256-65535>
```

Configure ldp igp sync delay interval

Use this attribute to configure a synchronization delay, that is, a delay for notifications of LDP convergence to the IGP protocol used, which can be either IS-IS or OSPF.

Attribute Name: ldp-igp-sync-delay-interval

Attribute Type: uint32

Attribute Range: 5-60

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
```

```

<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <ldp-igp-sync-delay-interval>5</ldp-igp-sync-delay-interval> <!--
operation="delete"-->
</interface>
</interfaces>
</ldp>

```

Command Syntax

```
mpls ldp-igp sync-delay <5-60>
```

Configure hello interval

Use this attribute set the hello interval to send the hello messages to peers

Attribute Name: hello-interval

Attribute Type: uint16

Default Value: 5

Attribute Range: 1-21845

Netconf edit-config payload

```

<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <hello-timers>
  <config>
    <hello-interval>1</hello-interval> <!-- operation="delete"-->
  </config>
</hello-timers>
</interface>
</interfaces>
</ldp>

```

Command Syntax

```
ldp hello-interval <1-21845>
```

Configure hello holdtime

Use this attribute set the hello hold time as the time out value that the router waits before rejecting an adjacency

Attribute Name: hello-holdtime

Attribute Type: uint16

Default Value: 15

Attribute Range: 3-65535

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <hello-timers>
        <config>
          <hello-holdtime>3</hello-holdtime> <!-- operation="delete"-->
        </config>
      </hello-timers>
    </interface>
  </interfaces>
</ldp>
```

Command Syntax

```
ldp hold-time <3-65535>
```

Configure keepalive interval

Use this attribute to set the global value for the interval after which keep-alive packets are sent out

Attribute Name: keepalive-interval

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-21845

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <session-timers>
        <config>
          <keepalive-interval>1</keepalive-interval> <!-- operation="delete"-->
        </config>
      </session-timers>
    </interface>
  </interfaces>
</ldp>
```

```
</ldp>
```

Command Syntax

```
ldp keepalive-interval <1-21845>
```

Configure keepalive timeout

Use this attribute to set the time period for which an LSR must wait for successive keep-alive messages from LDP peers

Attribute Name: keepalive-timeout

Attribute Type: uint16

Default Value: 30

Attribute Range: 3-65535

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
        </config>
        <session-timers>
          <config>
            <keepalive-timeout>3</keepalive-timeout> <!-- operation="delete"-->
          </config>
        </session-timers>
      </interface>
    </interfaces>
  </ldp>
```

Command Syntax

```
ldp keepalive-timeout <3-65535>
```

Configure interface advertisement mode

Use this attribute to set the label advertisement mode for an interface to either downstream-ondemand (label is sent only when requested) or downstream-unsolicited (label is sent unrequested).

Attribute Name: interface-advertisement-mode

Attribute Type: enum (downstream-unsolicited|downstream-on-demand)

Default Value: downstream-unsolicited

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <interfaces>
    <interface>
      <name>WORD</name>
```

```
<config>
  <name>WORD</name>
</config>
<label-management>
<config>
  <interface-advertisement-mode>downstream-unsolicited</interface-
advertisement-mode> <!-- operation="delete"-->
</config>
</label-management>
</interface>
</interfaces>
</ldp>
```

Command Syntax

```
ldp advertisement-mode (downstream-unsolicited|downstream-on-demand)
```

Configure interface retention mode

Use this attribute to set the retention mode to be used for all labels exchanged via the given interface. When an LSR receives a label binding for a particular FEC (Forwarding Equivalence Class) from another LSR that is not its next hop for that FEC, it might keep track of such bindings or discard them. Use the liberal parameter to retain all labels binding to FEC received from label distribution peers, even if the LSR is not the current next-hop. Use the conservative parameter to maintain only the label bindings for valid next-hops in a LSP. Liberal label retention mode allows for quicker adaptation to routing changes, whereas conservative label retention mode requires an LSR to maintain fewer labels.

Attribute Name: interface-retention-mode

Attribute Type: enum (liberal|conservative)

Default Value: liberal

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <label-management>
  <config>
    <interface-retention-mode>liberal</interface-retention-mode> <!--
operation="delete"-->
  </config>
</label-management>
</interface>
</interfaces>
</ldp>
```

Command Syntax

```
ldp label-retention-mode (liberal|conservative)
```

IPI-LDP-PEER

Configure targeted global hello interval

Use this attribute to set the interval for sending unicast hello packets to targeted peers

Attribute Name: targeted-global-hello-interval

Attribute Type: uint16

Default Value: 15

Attribute Range: 1-21845

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <targeted-peers>
    <global-timers>
      <config>
        <targeted-global-hello-interval>1</targeted-global-hello-interval> <!--
operation="delete"-->
      </config>
    </global-timers>
  </targeted-peers>
</ldp>
```

Command Syntax

```
targeted-peer-hello-interval <1-21845>
```

Configure targeted global hello holdtime

Use this attribute to set the time-out value that is the time that the router waits before rejecting an adjacency with targeted peers.

Attribute Name: targeted-global-hello-holdtime

Attribute Type: uint16

Default Value: 45

Attribute Range: 3-65535

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <targeted-peers>
    <global-timers>
      <config>
        <targeted-global-hello-holdtime>3</targeted-global-hello-holdtime> <!--
operation="delete"-->
      </config>
    </global-timers>
  </targeted-peers>
</ldp>
```

Command Syntax

```
targeted-peer-hold-time <3-65535>
```

Configure target address

Use this attribute to enter a targeted IPv4 or IPv6 LDP peer mode. A targeted session is an LDP session between non-directly connected LSRs. Set this command to send a targeted hello messages to specific IP addresses. This command is specific to a targeted IPv4 or IPv6 LDP peer.

Attribute Name: target-address

Attribute Type: union

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<targeted-peers>
<targeted-peer> <!-- operation="delete"-->
  <target-address>LDP_IP_ADDR_T</target-address>
  <config>
    <target-address>LDP_IP_ADDR_T</target-address>
  </config>
</targeted-peer>
</targeted-peers>
</ldp>
```

Command Syntax

```
targeted-peer (ipv4 A.B.C.D)
```

Configure hello interval

Use this attribute set the hello interval to send the hello messages to peers

Attribute Name: hello-interval

Attribute Type: uint16

Default Value: 5

Attribute Range: 1-21845

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
<targeted-peers>
<targeted-peer>
  <target-address>LDP_IP_ADDR_T</target-address>
  <config>
    <target-address>LDP_IP_ADDR_T</target-address>
  </config>
  <hello-interval>1</hello-interval> <!-- operation="delete"-->
</targeted-peer>
</targeted-peers>
</ldp>
```

Command Syntax

```
hello-interval <1-21845>
```

Configure hello holdtime

Use this attribute set the hello hold time as the time out value that the router waits before rejecting an adjacency

Attribute Name: hello-holdtime

Attribute Type: uint16

Default Value: 15

Attribute Range: 3-65535

Netconf edit-config payload

```
<ldp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ldp">
  <targeted-peers>
    <targeted-peer>
      <target-address>LDP_IP_ADDR_T</target-address>
      <config>
        <target-address>LDP_IP_ADDR_T</target-address>
      </config>
      <hello-holdtime>3</hello-holdtime> <!-- operation="delete"-->
    </targeted-peer>
  </targeted-peers>
</ldp>
```

Command Syntax

```
hold-time <3-65535>
```

IPI-QOS

Configure enable qos

Use this attribute to globally enable or disable QoS

Attribute Name: enable-qos

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <config>
      <enable-qos>disable</enable-qos> <!-- operation="delete"-->
    </config>
  </global>
</qos>
```

Command Syntax

```
qos (disable|enable)
```

Configure red drop disabled

Use this attribute to disable red packet drop in the system. Red packets are dropped in the system by default to achieve ingress rate limiting via policer and storm control. However, this command is used when there is no use-case for rate limiting traffic and red packets need to be allowed in the system

Attribute Name: red-drop-disabled

Attribute Type: empty

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <config>
      </red-drop-disabled><!-- operation="delete"-->
    </config>
  </global>
</qos>
```

Command Syntax

```
qos red-drop-disable
```

Configure statistics enabled

Use this attribute to enable QoS statistics

Attribute Name: statistics-enabled

Attribute Type: empty

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <config>
      </statistics-enabled><!-- operation="delete"-->
    </config>
  </global>
</qos>
```

Command Syntax

```
qos statistics
```

Configure name

Use this attribute to set a name to CoS to Traffic-Class profile

This command is supported when following feature are enabled QoS Mapping Profile feature

Attribute Name: name

Attribute Type: string

Attribute Range: 1-31

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <map-profile>
      <cos-to-queue-profiles>
        <cos-to-queue-profile> <!-- operation="delete"-->
          <name>NAME</name>
          <config>
            <name>WORD</name>
          </config>
        </cos-to-queue-profile>
      </cos-to-queue-profiles>
    </map-profile>
  </global>
</qos>
```

Command Syntax

```
qos profile cos-to-queue (NAME|default)
```

Configure cos value

Use this attribute to map a Class of Service (CoS) value to a particular Traffic-Class

This command is supported when following feature are enabled QoS custom options2, QoS Mapping Profile feature

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: queue-id

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <map-profile>
      <cos-to-queue-profiles>
        <cos-to-queue-profile>
          <name>NAME</name>
          <config>
            <name>WORD</name>
          </config>
        <cos-to-queues>
          <cos-to-queue> <!-- operation="delete"-->
            <cos-value>0</cos-value>
          <config>
```

```
        <cos-value>0</cos-value>
        <queue-id>0</queue-id>
    </config>
</cos-to-queue>
</cos-to-queues>
</cos-to-queue-profile>
</cos-to-queue-profiles>
</map-profile>
</global>
</qos>
```

Command Syntax

```
cos <0-7> queue <0-7>
```

Configure queue id

Use this attribute to select the Traffic-Class CoS is mapped to

This command is supported when following feature are enabled QoS custom options2,QoS Mapping Profile feature

Attribute Name: queue-id

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <map-profile>
      <cos-to-queue-profiles>
        <cos-to-queue-profile>
          <name>NAME</name>
          <config>
            <name>WORD</name>
          </config>
        </cos-to-queue>
      </cos-to-queues>
      <cos-to-queue>
        <cos-value>0</cos-value>
        <config>
          <cos-value>0</cos-value>
        </config>
        <queue-id>0</queue-id> <!-- operation="delete"-->
      </cos-to-queue>
    </cos-to-queues>
  </map-profile>
</global>
</qos>
```

Command Syntax

```
cos <0-7> queue <0-7>
```

Configure color

Use this attribute to select the color to map. Default value is 3.

This command is supported when following feature are enabled QoS Mapping Profile feature

Attribute Name: color

Attribute Type: enum (green|yellow|red|all)

Attribute Name: remark-dscp-value

Attribute Type: uint8

Attribute Range: 0-63

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <map-profile>
      <dscp-to-dscp-profiles>
        <dscp-to-dscp-profile>
          <name>NAME</name>
          <config>
            <name>WORD</name>
          </config>
        <dscp-to-dscps>
          <dscp-to-dscp> <!-- operation="delete"-->
            <color>all</color>
            <config>
              <color>all</color>
              <dscp-value>0</dscp-value>
              <remark-dscp-value>0</remark-dscp-value>
            </config>
            <dscp-value>0</dscp-value>
          </dscp-to-dscp>
        </dscp-to-dscps>
      </dscp-to-dscp-profile>
    </dscp-to-dscp-profiles>
  </map-profile>
</global>
</qos>
```

Command Syntax

```
dscp <0-63> (color (green|yellow|red|all) |) dscp <0-63>
```

Configure precedence value

Use this attribute to select IP Precedence value in

This command is supported when following feature are enabled QoS Mapping Profile feature

Attribute Name: precedence-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: remark-precedence-value

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <map-profile>
      <precedence-to-precedence-profiles>
        <precedence-to-precedence-profile>
          <name>NAME</name>
          <config>
            <name>WORD</name>
          </config>
        </precedence-to-precedences>
        <precedence-to-precedence> <!-- operation="delete"-->
          <precedence-value>0</precedence-value>
          <config>
            <precedence-value>0</precedence-value>
            <remark-precedence-value>0</remark-precedence-value>
          </config>
        </precedence-to-precedence>
      </precedence-to-precedences>
    </precedence-to-precedence-profile>
  </precedence-to-precedence-profiles>
</map-profile>
</global>
</qos>
```

Command Syntax

```
precedence <0-7> precedence <0-7>
```

Configure remark dscp value

Use this attribute to select Differentiated Services Control Protocol (DSCP) value out.

This command is supported when following feature are enabled QoS Mapping Profile feature

Attribute Name: remark-dscp-value

Attribute Type: uint8

Attribute Range: 0-63

Attribute Name: queue-id

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: color

Attribute Type: enum (green|yellow|red)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <map-profile>
      <dscp-to-queue-profiles>
        <dscp-to-queue-profile>
          <name>NAME</name>
          <config>
            <name>WORD</name>
          </config>
        <dscp-to-queues>
          <dscp-to-queue>
            <dscp-value>0</dscp-value>
            <config>
              <dscp-value>0</dscp-value>
              <queue-id>0</queue-id> <!-- operation="delete"-->
              <color>green</color> <!-- operation="delete"-->
            </config>
            <remark-dscp-value>0</remark-dscp-value> <!-- operation="delete"-->
          </dscp-to-queue>
        </dscp-to-queues>
      </dscp-to-queue-profile>
    </dscp-to-queue-profiles>
  </map-profile>
</global>
</qos>
```

Command Syntax

```
dscp <0-63> queue <0-7> color (green|yellow|red) dscp <0-63>
```

Configure dscp value

Use this attribute to select the color to map.

This command is supported when following feature are enabled QoS Mapping Profile feature

Attribute Name: color

Attribute Type: enum (green|yellow|red)

Attribute Name: queue-id

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
```

```
<map-profile>
<dscp-to-queue-profiles>
<dscp-to-queue-profile>
  <name>NAME</name>
  <config>
    <name>WORD</name>
  </config>
<dscp-to-queues>
<dscp-to-queue>
  <dscp-value>0</dscp-value>
  <config>
    <dscp-value>0</dscp-value>
    <queue-id>0</queue-id> <!-- operation="delete"-->
  </config>
  <color>green</color> <!-- operation="delete"-->
</dscp-to-queue>
</dscp-to-queues>
</dscp-to-queue-profile>
</dscp-to-queue-profiles>
</map-profile>
</global>
</qos>
```

Command Syntax

```
dscp <0-63> queue <0-7> color (green|yellow|red)
```

Configure dscp encaps value

Use this attribute to map a Differentiated Services Control Protocol (DSCP) value

This command is supported when following feature are enabled QoS custom options2,QoS Mapping Profile feature

Attribute Name: dscp-value

Attribute Type: uint8

Attribute Range: 0-63

Attribute Name: dscp-encap-value

Attribute Type: uint8

Attribute Range: 0-63

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<map-profile>
<dscp-encapsulation-profiles>
<dscp-encapsulation-profile>
  <name>NAME</name>
  <config>
    <name>WORD</name>
  </config>
```



```

<layer-3>
<dscp-to-dscp-encaps>
<dscp-to-dscp-encap> <!-- operation="delete"-->
  <dscp-value>0</dscp-value>
  <config>
    <dscp-value>0</dscp-value>
    <dscp-encap-value>0</dscp-encap-value>
  </config>
</dscp-to-dscp-encap>
</dscp-to-dscp-encaps>
</layer-3>
</dscp-encapsulation-profile>
</dscp-encapsulation-profiles>
</map-profile>
</global>
</qos>

```

Command Syntax

```
13 dscp <0-63> dscpEncap <0-63>
```

Configure exp value

Use this attribute to select the color to map. Default value is 3.

This command is supported when following feature are enabled Diffserv feature, QoS custom options2, QoS Mapping Profile feature and following feature are disabled QoS custom options3

Attribute Name: color

Attribute Type: enum (green|yellow|red|all)

Attribute Name: exp-value

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<map-profile>
<exp-encapsulation-profiles>
<exp-encapsulation-profile>
  <name>NAME</name>
  <config>
    <name>WORD</name>
  </config>
<layer-2>
<queue-color-to-exps>
<queue-color-to-exp> <!-- operation="delete"-->
  <color>all</color>
  <config>
    <color>all</color>
    <queue-id>0</queue-id>

```

```
    <exp-value>0</exp-value>
  </config>
  <queue-id>0</queue-id>
</queue-color-to-exp>
</queue-color-to-exps>
</layer-2>
</exp-encapsulation-profile>
</exp-encapsulation-profiles>
</map-profile>
</global>
</qos>
```

Command Syntax

```
12 queue <0-7> (color (green|yellow|red|all)|) exp <0-7>
```

Configure profile id

Use this attribute to set a name to MPLS experimental (EXP) to Traffic-Class profile name. Default value is 0.

This command is supported when following feature are enabled Diffserv feature, QoS Mapping Profile feature

Attribute Name: profile-id

Attribute Type: enum (default)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <map-profile>
      <exp-to-queue-profiles>
        <exp-to-queue-profile> <!-- operation="delete"-->
          <profile-id>default</profile-id>
          <config>
            <profile-id>default</profile-id>
          </config>
        </exp-to-queue-profile>
      </exp-to-queue-profiles>
    </map-profile>
  </global>
</qos>
```

Command Syntax

```
qos profile exp-to-queue default
```

Configure remark precedence value

Use this attribute to select IP Precedence value out.

This command is supported when following feature are enabled QoS Mapping Profile feature

Attribute Name: remark-precedence-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: queue-id

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <map-profile>
      <precedence-to-queue-profiles>
        <precedence-to-queue-profile>
          <name>NAME</name>
          <config>
            <name>WORD</name>
          </config>
        <precedence-to-queues>
          <precedence-to-queue>
            <precedence-value>0</precedence-value>
            <config>
              <precedence-value>0</precedence-value>
              <queue-id>0</queue-id> <!-- operation="delete"-->
            </config>
            <remark-precedence-value>0</remark-precedence-value> <!-- operation="delete"-
->
          </precedence-to-queue>
        </precedence-to-queues>
      </precedence-to-queue-profile>
    </precedence-to-queue-profiles>
  </map-profile>
</global>
</qos>
```

Command Syntax

```
precedence <0-7> queue <0-7> precedence <0-7>
```

Configure cos

Use this command to enable remarking of CoS set by the egress map

Attribute Name: cos

Attribute Type: empty

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <remark>
      <config>
        </cos><!-- operation="delete"-->
      </config>
```

```
</remark>
</global>
</qos>
```

Command Syntax

```
qos remark cos
```

Configure dscp

Use this command to enable remarking of DSCP set by the egress map

Attribute Name: dscp

Attribute Type: empty

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <remark>
      <config>
        </dscp><!-- operation="delete"-->
      </config>
    </remark>
  </global>
</qos>
```

Command Syntax

```
qos remark dscp
```

Configure type

Use this attribute to set the class-map name

Attribute Name: name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: type

Attribute Type: enum (qos|queuing|queuing-default)

Attribute Name: match-criteria

Attribute Type: enum (match-all|match-any)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map> <!-- operation="delete"-->
        <name>NAME</name>
      </class-map>
    </class-maps>
  </global>
</qos>
```

```

        <type>1</type>
        <match-criteria>1</match-criteria>
    </config>
</class-map>
</class-maps>
</global>
</qos>

```

Command Syntax

```
class-map NAME
```

Configure match criteria

Use this attribute to set the class-map name

Attribute Name: name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: type

Attribute Type: enum (qos|queuing|queuing-default)

Attribute Name: match-criteria

Attribute Type: enum (match-all|match-any)

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<class-maps>
<class-map> <!-- operation="delete"-->
  <name>NAME</name>
  <config>
    <name>NAME</name>
    <type>qos</type>
    <match-criteria>1</match-criteria>
  </config>
</class-map>
</class-maps>
</global>
</qos>

```

Command Syntax

```
class-map type (qos) NAME
```

Configure reference description

This attribute configures reference description message on class-map profile for QoS type.

Attribute Name: reference-description

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
        <reference-description>LINE</reference-description> <!-- operation="delete"-->
      </class-map>
    </class-maps>
  </global>
</qos>
```

Command Syntax

```
reference-description LINE
```

Configure access control list name

Use this attribute to classify traffic based on the Access Control List (ACL)

Attribute Name: access-control-list-name

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
        <match-any-conditions>
          <config>
            <access-control-list-name>NAME</access-control-list-name> <!--
operation="delete"-->
          </config>
        </match-any-conditions>
      </class-map>
    </class-maps>
  </global>
</qos>
```

Command Syntax

```
match access-group NAME
```

Configure ethertype

Use this attribute to classify traffic based on the EtherType value(s)

Attribute Name: ethertype

Attribute Type: string

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-any-conditions>
        <config>
          <ethertype>WORD</ethertype> <!-- operation="delete"-->
        </config>
      </match-any-conditions>
    </class-map>
  </class-maps>
</global>
</qos>
```

Command Syntax

```
match ethertype WORD
```

Configure traffic type

Use this attribute to classify traffic based on the traffic type value

Attribute Name: traffic-type

Attribute Type: enum (l2-mc|l2-bc|default|l2-unknown)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-any-conditions>
        <config>
          <traffic-type>l2-mc</traffic-type> <!-- operation="delete"-->
        </config>
      </match-any-conditions>
    </class-map>
  </class-maps>
</global>
</qos>
```

```
</class-map>
</class-maps>
</global>
</qos>
```

Command Syntax

```
match traffic-type (l2-mc|l2-bc|default|l2-unknown)
```

Configure inner cos

Use this attribute to classify traffic based on inner Class of Service (CoS) value

Attribute Name: inner-cos

Attribute Type: string

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-any-conditions>
      <config>
        <inner-cos>WORD</inner-cos> <!-- operation="delete"-->
      </config>
    </match-any-conditions>
  </class-map>
</class-maps>
</global>
</qos>
```

Command Syntax

```
match cos inner WORD
```

Configure vlan

Use this attribute to classify traffic based on VLAN ID. Enter VLAN ID 1-4094 or range of VLAN ID's.

Attribute Name: vlan

Attribute Type: string

Attribute Range: 1-4094

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
```



```

<class-maps>
<class-map>
  <name>NAME</name>
  <config>
    <name>NAME</name>
  </config>
<match-any-conditions>
<config>
  <vlan>WORD</vlan> <!-- operation="delete"-->
</config>
</match-any-conditions>
</class-map>
</class-maps>
</global>
</qos>

```

Command Syntax

```
match vlan WORD
```

Configure inner vlan

Use this attribute to classify traffic based on inner VLAN ID. Enter VLAN ID 1-4094 or range of VLAN ID's.

Attribute Name: inner-vlan

Attribute Type: string

Attribute Range: 1-4094

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<class-maps>
<class-map>
  <name>NAME</name>
  <config>
    <name>NAME</name>
  </config>
<match-any-conditions>
<config>
  <inner-vlan>WORD</inner-vlan> <!-- operation="delete"-->
</config>
</match-any-conditions>
</class-map>
</class-maps>
</global>
</qos>

```

Command Syntax

```
match vlan inner WORD
```

Configure rtp

Use this attribute to classify traffic based on the Real-time Transport Protocol (RTP). The rtp value 2000-65535 or range of rtp values.

Attribute Name: rtp

Attribute Type: string

Attribute Range: 2000-65535

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-any-conditions>
        <config>
          <rtp>WORD</rtp> <!-- operation="delete"-->
        </config>
      </match-any-conditions>
    </class-map>
  </class-maps>
</global>
</qos>
```

Command Syntax

```
match ip rtp WORD
```

Configure mpls exp

Use this attribute to classify traffic based on the MPLS experimental (EXP) value

Attribute Name: mpls-exp

Attribute Type: string

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-any-conditions>
```

```

<config>
  <mpls-exp>WORD</mpls-exp> <!-- operation="delete"-->
</config>
</match-any-conditions>
</class-map>
</class-maps>
</global>
</qos>

```

Command Syntax

```
match mpls experimental topmost WORD
```

Configure ipv6 dscp

Use this attribute to classify traffic based on the Differentiated Services Control Protocol (DSCP) value. Warning: In CLI show running, DSCP values with well-known names (ex.: af11, cs0) will be displayed as such. On Netconf, DSCP values will always be numeric.

Attribute Name: ipv6-dscp

Attribute Type: string

Attribute Range: 0-63

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
          </config>
        <match-any-conditions>
          <config>
            <ipv6-dscp>WORD</ipv6-dscp> <!-- operation="delete"-->
          </config>
        </match-any-conditions>
      </class-map>
    </class-maps>
  </global>
</qos>

```

Command Syntax

```
match ipv6 dscp WORD
```

Configure precedence

Use this attribute to classify traffic based on the precedence value. Warning: In CLI show running, precedence values with well-known names (ex.: priority, immediate) will be displayed as such. On Netconf, precedence values will always be numeric.

Attribute Name: precedence

Attribute Type: string

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-any-conditions>
        <config>
          <precedence>WORD</precedence> <!-- operation="delete"-->
        </config>
      </match-any-conditions>
    </class-map>
  </class-maps>
</global>
</qos>
```

Command Syntax

```
match precedence WORD
```

Configure ipv6 precedence

Use this attribute to classify IPv6 traffic based on the precedence value. Warning: In CLI show running, precedence values with well-known names (ex.: priority, immediate) will be displayed as such. On Netconf, precedence values will always be numeric.

Attribute Name: ipv6-precedence

Attribute Type: string

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-any-conditions>
        <config>
          <ipv6-precedence>WORD</ipv6-precedence> <!-- operation="delete"-->
        </config>
      </match-any-conditions>
    </class-map>
  </class-maps>
</global>
</qos>
```

```

</match-any-conditions>
</class-map>
</class-maps>
</global>
</qos>

```

Command Syntax

```
match ipv6 precedence WORD
```

Configure port type

Use this attribute to classify traffic based on layer 4 source port or destination port

Attribute Name: port-type

Attribute Type: enum (source-port|destination-port)

Attribute Name: port

Attribute Type: string

Attribute Range: 1-65535

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<class-maps>
<class-map>
  <name>NAME</name>
  <config>
    <name>NAME</name>
  </config>
<match-any-conditions>
<ipv4>
<layer4-match> <!-- operation="delete"-->
  <port-type>source-port</port-type>
  <config>
    <port-type>source-port</port-type>
    <protocol>any</protocol>
    <port>WORD</port>
  </config>
  <protocol>any</protocol>
</layer4-match>
</ipv4>
</match-any-conditions>
</class-map>
</class-maps>
</global>
</qos>

```

Command Syntax

```
match layer4 (any|tcp|udp) (source-port|destination-port) WORD
```

Configure protocol

Use this attribute to classify traffic based on layer 4 source port or destination port

Attribute Name: port-type

Attribute Type: enum (source-port|destination-port)

Attribute Name: port

Attribute Type: string

Attribute Range: 1-65535

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
          </config>
        <match-any-conditions>
          <ipv6>
            <layer4-match> <!-- operation="delete"-->
              <port-type>source-port</port-type>
              <config>
                <port-type>source-port</port-type>
                <protocol>any</protocol>
                <port>WORD</port>
              </config>
              <protocol>any</protocol>
            </layer4-match>
          </ipv6>
        </match-any-conditions>
      </class-map>
    </class-maps>
  </global>
</qos>
```

Command Syntax

```
match ipv6 layer4 (any|tcp|udp) (source-port|destination-port) WORD
```

Configure ethertype all

Use this attribute to classify traffic based on the EtherType value

Attribute Name: ethertype-all

Attribute Type: string

Attribute Range: 5-6

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
  <class-maps>
  <class-map>
    <name>NAME</name>
    <config>
      <name>NAME</name>
    </config>
  <match-all-conditions>
  <config>
    <ethertype-all>WORD</ethertype-all> <!-- operation="delete"-->
  </config>
</match-all-conditions>
</class-map>
</class-maps>
</global>
</qos>

```

Command Syntax

```
match ethertype WORD
```

Configure traffic type all

Use this attribute to classify traffic based on the traffic type

Attribute Name: traffic-type-all

Attribute Type: enum (l2-mc|l2-bc|default|l2-unknown)

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
  <class-maps>
  <class-map>
    <name>NAME</name>
    <config>
      <name>NAME</name>
    </config>
  <match-all-conditions>
  <config>
    <traffic-type-all>l2-mc</traffic-type-all> <!-- operation="delete"-->
  </config>
</match-all-conditions>
</class-map>
</class-maps>
</global>
</qos>

```

Command Syntax

```
match traffic-type (l2-mc|l2-bc|default|l2-unknown)
```

Configure cos all

Use this attribute to classify traffic based on the Class of Service (CoS) value

Attribute Name: cos-all

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-all-conditions>
      <config>
        <cos-all>0</cos-all> <!-- operation="delete"-->
      </config>
    </match-all-conditions>
  </class-map>
</class-maps>
</global>
</qos>
```

Command Syntax

```
match cos <0-7>
```

Configure inner cos all

Use this attribute to classify traffic based on the inner Class of Service (CoS) value

Attribute Name: inner-cos-all

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-all-conditions>
      <config>
```



```
        <inner-cos-all>0</inner-cos-all> <!-- operation="delete"-->
</config>
</match-all-conditions>
</class-map>
</class-maps>
</global>
</qos>
```

Command Syntax

```
match cos inner <0-7>
```

Configure vlan all

Use this attribute to classify traffic based on the VLAN ID

Attribute Name: vlan-all

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<class-maps>
<class-map>
  <name>NAME</name>
  <config>
    <name>NAME</name>
  </config>
</match-all-conditions>
<config>
  <vlan-all>1</vlan-all> <!-- operation="delete"-->
</config>
</match-all-conditions>
</class-map>
</class-maps>
</global>
</qos>
```

Command Syntax

```
match vlan <1-4094>
```

Configure inner vlan all

Use this attribute to classify traffic based on the inner VLAN ID

Attribute Name: inner-vlan-all

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-all-conditions>
      <config>
        <inner-vlan-all>1</inner-vlan-all> <!-- operation="delete"-->
      </config>
    </match-all-conditions>
  </class-map>
</class-maps>
</global>
</qos>
```

Command Syntax

```
match vlan inner <1-4094>
```

Configure rtp all

Use this attribute to classify traffic based on the Real-time Transport Protocol (RTP)

Attribute Name: rtp-all

Attribute Type: uint32

Attribute Range: 2000-65535

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-all-conditions>
      <config>
        <rtp-all>2000</rtp-all> <!-- operation="delete"-->
      </config>
    </match-all-conditions>
  </class-map>
</class-maps>
</global>
</qos>
```

Command Syntax

```
match ip rtp <2000-65535>
```

Configure mpls exp all

Use this attribute to classify traffic based on the MPLS experimental (EXP) value

Attribute Name: mpls-exp-all

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-all-conditions>
        <config>
          <mpls-exp-all>0</mpls-exp-all> <!-- operation="delete"-->
        </config>
      </match-all-conditions>
    </class-map>
  </class-maps>
</global>
</qos>
```

Command Syntax

```
match mpls experimental topmost <0-7>
```

Configure dscp all

Use this attribute to classify traffic based on the Differentiated Services Control Protocol (DSCP) value. The DSCP value range is 0-63. Warning: In CLI show running, DSCP values with well-known names (ex.: af11, cs0) will be displayed as such. On Netconf, DSCP values will always be numeric. The string type allow up to 8 characters on well-known name.

Attribute Name: dscp-all

Attribute Type: string

Attribute Range: 1-8

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
```

```
<name>NAME</name>
<config>
  <name>NAME</name>
</config>
<match-all-conditions>
<config>
  <dscp-all>WORD</dscp-all> <!-- operation="delete"-->
</config>
</match-all-conditions>
</class-map>
</class-maps>
</global>
</qos>
```

Command Syntax

```
match dscp WORD
```

Configure ipv6 dscp all

Use this attribute to classify traffic based on the Differentiated Services Control Protocol (DSCP) value upon IPv6 packet. The DSCP value range is 0-63. Warning: In CLI show running, DSCP values with well-known names (ex.: af11, cs0) will be displayed as such. On Netconf, DSCP values will always be numeric. The string type allow up to 8 characters on well-known name.

Attribute Name: ipv6-dscp-all

Attribute Type: string

Attribute Range: 1-8

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<class-maps>
<class-map>
  <name>NAME</name>
  <config>
    <name>NAME</name>
  </config>
<match-all-conditions>
<config>
  <ipv6-dscp-all>WORD</ipv6-dscp-all> <!-- operation="delete"-->
</config>
</match-all-conditions>
</class-map>
</class-maps>
</global>
</qos>
```

Command Syntax

```
match ipv6 dscp WORD
```

Configure precedence all

Use this attribute to classify traffic based on the precedence value. The precedence value range is 0-7. Warning: In CLI show running, precedence values with well-known names (ex.: priority, immediate) will be displayed as such. On Netconf, precedence values will always be numeric. The string type allow up to 13 characters on well-known name.

Attribute Name: precedence-all

Attribute Type: string

Attribute Range: 1-13

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-all-conditions>
        <config>
          <precedence-all>WORD</precedence-all> <!-- operation="delete"-->
        </config>
      </match-all-conditions>
    </class-map>
  </class-maps>
</global>
</qos>
```

Command Syntax

```
match precedence WORD
```

Configure ipv6 precedence all

Use this attribute to classify traffic based on the precedence value upon IPv6 packet. The precedence value range is 0-7. Warning: In CLI show running, precedence values with well-known names (ex.: priority, immediate) will be displayed as such. On Netconf, precedence values will always be numeric. The string type allow up to 13 characters on well-known name.

Attribute Name: ipv6-precedence-all

Attribute Type: string

Attribute Range: 1-13

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
```

```
        <name>NAME</name>
    </config>
<match-all-conditions>
<config>
    <ipv6-precedence-all>WORD</ipv6-precedence-all> <!-- operation="delete"-->
</config>
</match-all-conditions>
</class-map>
</class-maps>
</global>
</qos>
```

Command Syntax

```
match ipv6 precedence WORD
```

Configure port all

Use this attribute to classify traffic based on the port

Attribute Name: port-all

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<class-maps>
<class-map>
    <name>NAME</name>
    <config>
        <name>NAME</name>
    </config>
<match-all-conditions>
<layer4-matches-ipv4>
<layer4-match-ipv4> <!-- operation="delete"-->
    <port-all>1</port-all>
    <config>
        <port-all>1</port-all>
        <port-type-all>source-port</port-type-all>
        <protocol-all>any</protocol-all>
    </config>
    <port-type-all>source-port</port-type-all>
    <protocol-all>any</protocol-all>
</layer4-match-ipv4>
</layer4-matches-ipv4>
</match-all-conditions>
</class-map>
</class-maps>
</global>
</qos>
```

Command Syntax

```
match layer4 (any|tcp|udp) (source-port|destination-port) <1-65535>
```

Configure protocol all

Use this attribute to classify traffic based on the port

Attribute Name: port-all

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps>
      <class-map>
        <name>NAME</name>
        <config>
          <name>NAME</name>
        </config>
      <match-all-conditions>
        <layer4-matches-ipv6>
          <layer4-match-ipv6> <!-- operation="delete"-->
            <port-all>1</port-all>
            <config>
              <port-all>1</port-all>
              <port-type-all>source-port</port-type-all>
              <protocol-all>any</protocol-all>
            </config>
            <port-type-all>source-port</port-type-all>
            <protocol-all>any</protocol-all>
          </layer4-match-ipv6>
        </layer4-matches-ipv6>
      </match-all-conditions>
    </class-map>
  </class-maps>
</global>
</qos>
```

Command Syntax

```
match ipv6 layer4 (any|tcp|udp) (source-port|destination-port) <1-65535>
```

Configure vlan queue

Use this attribute to classify traffic based on the VLAN ID

Attribute Name: vlan-queue

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps-queuing>
      <class-map-queuing>
        <name>WORD</name>
        <config>
          <name>NAME</name>
        </config>
      </class-map-queuing>
    </class-maps-queuing>
  </global>
  <match-conditions>
    <config>
      <vlan-queue>1</vlan-queue> <!-- operation="delete"-->
    </config>
  </match-conditions>
</qos>
```

Command Syntax

```
match vlan <1-4094>
```

Configure queue

Use this attribute to classify traffic based on queue value

Attribute Name: queue

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps-queuing>
      <class-map-queuing>
        <name>WORD</name>
        <config>
          <name>NAME</name>
        </config>
      </class-map-queuing>
    </class-maps-queuing>
  </global>
  <match-conditions>
    <config>
      <queue>0</queue> <!-- operation="delete"-->
    </config>
  </match-conditions>
</qos>
```


Command Syntax

```
match queue <0-7>
```

Configure service template name

Use this attribute to classify traffic based on service template

Attribute Name: service-template-name

Attribute Type: string

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps-queuing>
      <class-map-queuing>
        <name>WORD</name>
        <config>
          <name>NAME</name>
        </config>
      <match-conditions>
        <config>
          <service-template-name>NAME</service-template-name> <!-- operation="delete"-->
        </config>
      </match-conditions>
    </class-map-queuing>
  </class-maps-queuing>
</global>
</qos>
```

Command Syntax

```
match service-template NAME
```

Configure interface

Use this attribute to classify traffic based on the subinterface or vlan interface name

Attribute Name: interface

Attribute Type: string

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <class-maps-queuing>
      <class-map-queuing>
        <name>WORD</name>
        <config>
          <name>NAME</name>
        </config>
      <match-conditions>
```

```
<config>
  <interface>IFNAME</interface> <!-- operation="delete"-->
</config>
</match-conditions>
</class-map-queuing>
</class-maps-queuing>
</global>
</qos>
```

Command Syntax

```
match interface IFNAME
```

Configure policy map name

Use this attribute to set the policy-map name

Attribute Name: policy-map-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: type

Attribute Type: enum (qos|queuing|queuing default)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <policy-maps>
      <policy-map> <!-- operation="delete"-->
        <policy-map-name>NAME</policy-map-name>
        <config>
          <policy-map-name>NAME</policy-map-name>
          <type>1</type>
        </config>
      </policy-map>
    </policy-maps>
  </global>
</qos>
```

Command Syntax

```
policy-map NAME
```

Configure class map name

Use this attribute to attach a class-map of type qos or queue to the policy-map

Attribute Name: class-map-name

Attribute Type: union

Attribute Name: type

Attribute Type: enum (qos|queuing|queuing default)

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<policy-maps>
<policy-map>
  <policy-map-name>NAME</policy-map-name>
  <config>
    <policy-map-name>NAME</policy-map-name>
  </config>
</policy-map>
</policy-maps>
</global>
</qos>

```

Command Syntax

```
class (type (qos)|) NAME
```

Configure child service policy name

Use this attribute to attach a child service-policy to the policy-map

Attribute Name: child-service-policy-name

Attribute Type: string

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<policy-maps>
<policy-map>
  <policy-map-name>NAME</policy-map-name>
  <config>
    <policy-map-name>NAME</policy-map-name>
  </config>
</policy-map>
</policy-maps>
</global>
</qos>

```

```
</class>  
</classes>  
</policy-map>  
</policy-maps>  
</global>  
</qos>
```

Command Syntax

```
service-policy NAME
```

Configure byte compensation

Use this attribute to set the compensation used to adjust this byte difference in order to achieve the expected egress queue rate.

Attribute Name: byte-compensation

Attribute Type: int8

Attribute Range: -64-64

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">  
<global>  
<policy-maps>  
<policy-map>  
  <policy-map-name>NAME</policy-map-name>  
  <config>  
    <policy-map-name>NAME</policy-map-name>  
  </config>  
</policy-map>  
</policy-maps>  
</global>  
</qos>
```

Command Syntax

```
compensation <-64-64>
```

Configure delay tolerance

Use this attribute to set the low delay tolerance profile.

Attribute Name: delay-tolerance

Attribute Type: empty

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <policy-maps>
      <policy-map>
        <policy-map-name>NAME</policy-map-name>
        <config>
          <policy-map-name>NAME</policy-map-name>
        </config>
      <classes>
        <class>
          <class-map-name>NAME</class-map-name>
          <config>
            <class-map-name>NAME</class-map-name>
          </config>
          <queue-mode>
            <config>
              </delay-tolerance><!-- operation="delete"-->
            </config>
          </queue-mode>
        </class>
      </classes>
    </policy-map>
  </policy-maps>
</global>
</qos>
```

Command Syntax

```
low-delay-tolerance-profile
```

Configure priority level

Use this attribute to set the class traffic level for Priority queue scheduling algorithm

Attribute Name: priority-level

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <policy-maps>
      <policy-map>
```

```

    <policy-map-name>NAME</policy-map-name>
  <config>
    <policy-map-name>NAME</policy-map-name>
  </config>
</classes>
<class>
  <class-map-name>NAME</class-map-name>
  <config>
    <class-map-name>NAME</class-map-name>
  </config>
  <queue-mode>
  <config>
    <priority-level>0</priority-level> <!-- operation="delete"-->
  </config>
</queue-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>

```

Command Syntax

```
priority level <0-7>
```

Configure weighted fair queueing queue weight

Use this attribute to set the weight for Weighted Fair Queueing queue scheduling algorithm

Attribute Name: weighted-fair-queueing-queue-weight

Attribute Type: uint8

Attribute Range: 1-63

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <policy-maps>
      <policy-map>
        <policy-map-name>NAME</policy-map-name>
        <config>
          <policy-map-name>NAME</policy-map-name>
        </config>
      </policy-map>
    </policy-maps>
  </global>
  <class>
    <class-map-name>NAME</class-map-name>
    <config>
      <class-map-name>NAME</class-map-name>
    </config>
  </class>
  <queue-mode>
  <config>

```

```

        <weighted-fair-queueing-queue-weight>1</weighted-fair-queueing-queue-
weight> <!-- operation="delete"-->
    </config>
</queue-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>

```

Command Syntax

```
wfq-queue weight <1-63>
```

Configure weight

Use this attribute to set weight for Weighted Random Early Detection

Attribute Name: weight

Attribute Type: uint8

Attribute Range: 0-31

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<policy-maps>
<policy-map>
    <policy-map-name>NAME</policy-map-name>
    <config>
        <policy-map-name>NAME</policy-map-name>
    </config>
</classes>
<class>
    <class-map-name>NAME</class-map-name>
    <config>
        <class-map-name>NAME</class-map-name>
    </config>
    <queue-mode>
    <red>
    <config>
        <weight>0</weight> <!-- operation="delete"-->
    </config>
</red>
</queue-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>

```

Command Syntax

```
random-detect weight <0-31>
```

Configure min threshold

Use this attribute to set Weighted Random Early Detection color. Default value is 3.

Attribute Name: color

Attribute Type: enum (green|yellow|red|all)

Attribute Name: min-threshold

Attribute Type: uint32

Attribute Range: 1-629145600

Attribute Name: min-threshold-unit

Attribute Type: enum (packets|bytes|kbytes|mbytes|ms|us)

Attribute Name: max-threshold

Attribute Type: uint32

Attribute Range: 1-629145600

Attribute Name: max-threshold-unit

Attribute Type: enum (packets|bytes|kbytes|mbytes|ms|us)

Attribute Name: drop-probability

Attribute Type: uint8

Attribute Range: 1-100

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <policy-maps>
      <policy-map>
        <policy-map-name>NAME</policy-map-name>
        <config>
          <policy-map-name>NAME</policy-map-name>
        </config>
      </policy-map>
    </policy-maps>
    <classes>
      <class>
        <class-map-name>NAME</class-map-name>
        <config>
          <class-map-name>NAME</class-map-name>
        </config>
        <queue-mode>
          <red>
            <wreds>
              <wred> <!-- operation="delete"-->
                <color>all</color>
              </wred>
            </wreds>
          </red>
        </queue-mode>
      </class>
    </classes>
  </global>
</qos>
```



```

    <min-threshold>1</min-threshold>
    <min-threshold-unit>packets</min-threshold-unit>
    <max-threshold>1</max-threshold>
    <max-threshold-unit>packets</max-threshold-unit>
    <drop-probability>1</drop-probability>
  </config>
</wred>
</wreds>
</red>
</queue-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>

```

Command Syntax

```

random-detect ((green|yellow|red|all) |) <1-629145600>
  (packets|bytes|kbytes|mbytes|ms|us) <1-629145600>
  (packets|bytes|kbytes|mbytes|ms|us) (drop-probability <1-100>|)

```

Configure min threshold unit

Use this attribute to set Weighted Random Early Detection color. Default value is 3.

Attribute Name: color

Attribute Type: enum (green|yellow|red|all)

Attribute Name: min-threshold

Attribute Type: uint32

Attribute Range: 1-629145600

Attribute Name: min-threshold-unit

Attribute Type: enum (packets|bytes|kbytes|mbytes|ms|us)

Attribute Name: max-threshold

Attribute Type: uint32

Attribute Range: 1-629145600

Attribute Name: max-threshold-unit

Attribute Type: enum (packets|bytes|kbytes|mbytes|ms|us)

Attribute Name: drop-probability

Attribute Type: uint8

Attribute Range: 1-100

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>

```

```
<policy-maps>
<policy-map>
  <policy-map-name>NAME</policy-map-name>
  <config>
    <policy-map-name>NAME</policy-map-name>
  </config>
</classes>
<class>
  <class-map-name>NAME</class-map-name>
  <config>
    <class-map-name>NAME</class-map-name>
  </config>
  <queue-mode>
  <red>
  <wreds>
  <wred> <!-- operation="delete"-->
    <color>all</color>
    <config>
      <color>all</color>
      <min-threshold>1</min-threshold>
      <min-threshold-unit>packets</min-threshold-unit>
      <max-threshold>1</max-threshold>
      <max-threshold-unit>packets</max-threshold-unit>
      <drop-probability>1</drop-probability>
    </config>
  </wred>
</wreds>
</red>
</queue-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>
```

Command Syntax

```
random-detect ((green|yellow|red|all)|) min-threshold <1-629145600>
  (packets|bytes|kbytes|mbytes|ms|us) max-threshold <1-629145600>
  (packets|bytes|kbytes|mbytes|ms|us) (drop-probability <1-100>|)
```

Configure max threshold

Use this attribute to set Weighted Random Early Detection color. Default value is 3.

Attribute Name: color

Attribute Type: enum (green|yellow|red|all)

Attribute Name: min-threshold

Attribute Type: uint32

Attribute Range: 1-629145600

Attribute Name: min-threshold-unit

Attribute Type: enum (packets|bytes|kbytes|mbytes|ms|us)

Attribute Name: max-threshold

Attribute Type: uint32

Attribute Range: 1-629145600

Attribute Name: max-threshold-unit

Attribute Type: enum (packets|bytes|kbytes|mbytes|ms|us)

Attribute Name: drop-probability

Attribute Type: uint8

Attribute Range: 1-100

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <policy-maps>
      <policy-map>
        <policy-map-name>NAME</policy-map-name>
        <config>
          <policy-map-name>NAME</policy-map-name>
        </config>
      </policy-map>
    </policy-maps>
    <classes>
      <class>
        <class-map-name>NAME</class-map-name>
        <config>
          <class-map-name>NAME</class-map-name>
          <queue-mode>
            <red>
              <wreds>
                <wred> <!-- operation="delete"-->
                  <color>all</color>
                  <config>
                    <color>all</color>
                    <min-threshold>1</min-threshold>
                    <min-threshold-unit>packets</min-threshold-unit>
                    <max-threshold>1</max-threshold>
                    <max-threshold-unit>packets</max-threshold-unit>
                    <drop-probability>1</drop-probability>
                  </config>
                </wred>
              </wreds>
            </red>
          </queue-mode>
        </config>
      </class>
    </classes>
  </global>
</qos>
```

```
</policy-map>  
</policy-maps>  
</global>  
</qos>
```

Command Syntax

```
random-detect ((green|yellow|red|all) |) <1-629145600>  
  (packets|bytes|kbytes|mbytes|ms|us) max-threshold <1-629145600>  
  (packets|bytes|kbytes|mbytes|ms|us) (drop-probability <1-100>|)
```

Configure max threshold unit

Use this attribute to set Weighted Random Early Detection color. Default value is 3.

Attribute Name: color

Attribute Type: enum (green|yellow|red|all)

Attribute Name: min-threshold

Attribute Type: uint32

Attribute Range: 1-629145600

Attribute Name: min-threshold-unit

Attribute Type: enum (packets|bytes|kbytes|mbytes|ms|us)

Attribute Name: max-threshold

Attribute Type: uint32

Attribute Range: 1-629145600

Attribute Name: max-threshold-unit

Attribute Type: enum (packets|bytes|kbytes|mbytes|ms|us)

Attribute Name: drop-probability

Attribute Type: uint8

Attribute Range: 1-100

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">  
  <global>  
    <policy-maps>  
      <policy-map>  
        <policy-map-name>NAME</policy-map-name>  
        <config>  
          <policy-map-name>NAME</policy-map-name>  
        </config>  
      </policy-map>  
    </policy-maps>  
    <classes>  
      <class>  
        <class-map-name>NAME</class-map-name>  
        <config>  
          <class-map-name>NAME</class-map-name>  
        </config>  
      </class>  
    </classes>  
  </global>  
</qos>
```

```

    <queue-mode>
    <red>
    <wreds>
    <wred> <!-- operation="delete"-->
        <color>all</color>
        <config>
            <color>all</color>
            <min-threshold>1</min-threshold>
            <min-threshold-unit>packets</min-threshold-unit>
            <max-threshold>1</max-threshold>
            <max-threshold-unit>packets</max-threshold-unit>
            <drop-probability>1</drop-probability>
        </config>
    </wred>
</wreds>
</red>
</queue-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>

```

Command Syntax

```

random-detect ((green|yellow|red|all)|) min-threshold <1-629145600>
    (packets|bytes|kbytes|mbytes|ms|us) <1-629145600>
    (packets|bytes|kbytes|mbytes|ms|us) (drop-probability <1-100>|)

```

Configure max threshold type

Use this attribute to set tail drop limits on egress queue

Attribute Name: max-threshold-type

Attribute Type: enum (packets|bytes|kbytes|mbytes|ms|us)

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<policy-maps>
<policy-map>
    <policy-map-name>NAME</policy-map-name>
    <config>
        <policy-map-name>NAME</policy-map-name>
    </config>
</classes>
<class>
    <class-map-name>NAME</class-map-name>
    <config>
        <class-map-name>NAME</class-map-name>

```

```
</config>
<queue-mode>
<tail-drops>
<tail-drop> <!-- operation="delete"-->
  <max-threshold-type>packets</max-threshold-type>
  <config>
    <max-threshold-type>packets</max-threshold-type>
    <max-threshold>1</max-threshold>
  </config>
  <max-threshold>1</max-threshold>
</tail-drop>
</tail-drops>
</queue-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>
```

Command Syntax

```
queue-limit <1-629145600> (packets|bytes|kbytes|mbytes|ms|us)
```

Configure rate value

Use this attribute to set a maximum shaping rate on the egress queue

Attribute Name: rate-value

Attribute Type: uint32

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<policy-maps>
<policy-map>
  <policy-map-name>NAME</policy-map-name>
  <config>
    <policy-map-name>NAME</policy-map-name>
  </config>
</classes>
<class>
  <class-map-name>NAME</class-map-name>
  <config>
    <class-map-name>NAME</class-map-name>
  </config>
  <queue-mode>
  <shapes>
  <shape> <!-- operation="delete"-->
    <rate-unit>kbps</rate-unit>
  <config>
```

```

        <rate-unit>kbps</rate-unit>
        <rate-value>0</rate-value>
    </config>
    <rate-value>0</rate-value>
</shape>
</shapes>
</queue-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>

```

Command Syntax

```
shape <1-483000000> (kbps|mbps|gbps)
```

Configure rate unit

Use this attribute to set a maximum shaping rate on the egress queue

Attribute Name: rate-value

Attribute Type: uint32

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<global>
<policy-maps>
<policy-map>
    <policy-map-name>NAME</policy-map-name>
    <config>
        <policy-map-name>NAME</policy-map-name>
    </config>
</classes>
<class>
    <class-map-name>NAME</class-map-name>
    <config>
        <class-map-name>NAME</class-map-name>
    </config>
<queue-mode>
<shapes>
<shape> <!-- operation="delete"-->
    <rate-unit>kbps</rate-unit>
    <config>
        <rate-unit>kbps</rate-unit>
        <rate-value>0</rate-value>
    </config>
    <rate-value>0</rate-value>
</shape>
</shapes>

```

```
</queue-mode>  
</class>  
</classes>  
</policy-map>  
</policy-maps>  
</global>  
</qos>
```

Command Syntax

```
shape (percent) <1-100>
```

Configure priority

Use this attribute to set the user priority for the class attached to this policy-map

Attribute Name: priority

Attribute Type: uint16

Attribute Range: 1-1000

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">  
<global>  
<policy-maps>  
<policy-map>  
  <policy-map-name>NAME</policy-map-name>  
  <config>  
    <policy-map-name>NAME</policy-map-name>  
  </config>  
</classes>  
<class>  
  <class-map-name>NAME</class-map-name>  
  <config>  
    <class-map-name>NAME</class-map-name>  
  </config>  
  <qos-mode>  
  <config>  
    <priority>1</priority> <!-- operation="delete"-->  
  </config>  
</qos-mode>  
</class>  
</policy-maps>  
</global>  
</qos>
```

Command Syntax

```
priority <1-1000>
```

Configure precedence remark

Use this attribute to match traffic classes set action as change precedence in the egress packet to the defined value. The precedence value range is 0-7. Warning: In CLI show running, precedence values with well-known names (ex.: priority, immediate) will be displayed as such. On Netconf, precedence values will always be numeric. The string type allow up to 13 characters on well-known name.

Attribute Name: precedence-remark

Attribute Type: string

Attribute Range: 1-13

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <policy-maps>
      <policy-map>
        <policy-map-name>NAME</policy-map-name>
        <config>
          <policy-map-name>NAME</policy-map-name>
        </config>
      </policy-map>
    </policy-maps>
    <classes>
      <class>
        <class-map-name>NAME</class-map-name>
        <config>
          <class-map-name>NAME</class-map-name>
        </config>
        <qos-mode>
          <config>
            <precedence-remark>WORD</precedence-remark> <!-- operation="delete"-->
          </config>
        </qos-mode>
      </class>
    </classes>
  </policy-map>
</policy-maps>
</global>
</qos>
```

Command Syntax

```
set precedence WORD
```

Configure dscp value remark

Use this attribute to match traffic classes set action as change DSCP in the egress packet to the defined value. The DSCP value range is 0-63. Warning: In CLI show running, DSCP values with well-known names (ex.: af11, cs0) will be displayed as such. On Netconf, DSCP values will always be numeric. The string type allow up to 8 characters on well-known name.

Attribute Name: dscp-value-remark

Attribute Type: string

Attribute Range: 1-8

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
  <policy-maps>
  <policy-map>
    <policy-map-name>NAME</policy-map-name>
    <config>
      <policy-map-name>NAME</policy-map-name>
    </config>
  </policy-map>
  <classes>
  <class>
    <class-map-name>NAME</class-map-name>
    <config>
      <class-map-name>NAME</class-map-name>
    </config>
    <qos-mode>
    <config>
      <dscp-value-remark>WORD</dscp-value-remark> <!-- operation="delete"-->
    </config>
  </qos-mode>
  </class>
  </classes>
  </policy-map>
  </policy-maps>
  </global>
</qos>
```

Command Syntax

```
set dscp WORD
```

Configure cir

Use this attribute to set a Committed Information Rate. Default value is 1.

Attribute Name: cir

Attribute Type: uint64

Attribute Range: 1-720000000

Attribute Name: type

Attribute Type: enum (none|colour-blind|colour-aware)

Attribute Name: cir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
  <policy-maps>
```

```

<policy-map>
  <policy-map-name>NAME</policy-map-name>
  <config>
    <policy-map-name>NAME</policy-map-name>
  </config>
</classes>
<class>
  <class-map-name>NAME</class-map-name>
  <config>
    <class-map-name>NAME</class-map-name>
  </config>
  <qos-mode>
  <police>
  <config>
    <type>none</type> <!-- operation="delete"-->
    <cir-unit>kbps</cir-unit> <!-- operation="delete"-->
    <cir>1</cir> <!-- operation="delete"-->
  </config>
</police>
</qos-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>

```

Command Syntax

```
police ((colour-blind|colour-aware)|) cir <1-720000000> (kbps|mbps|gbps)
```

Configure cir unit

Use this attribute to set a Committed Information Rate. Default value is 1.

Attribute Name: cir

Attribute Type: uint64

Attribute Name: type

Attribute Type: enum (none|colour-blind|colour-aware)

Attribute Name: cir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
  <policy-maps>
  <policy-map>
    <policy-map-name>NAME</policy-map-name>
    <config>
      <policy-map-name>NAME</policy-map-name>

```

```
    </config>
<classes>
<class>
  <class-map-name>NAME</class-map-name>
  <config>
    <class-map-name>NAME</class-map-name>
  </config>
  <qos-mode>
  <police>
  <config>
    <type>none</type> <!-- operation="delete"-->
    <cir-unit>kbps</cir-unit> <!-- operation="delete"-->
    <cir>1</cir> <!-- operation="delete"-->
  </config>
</police>
</qos-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>
```

Command Syntax

```
police ((colour-blind|colour-aware)|) cir percent <1-100>
```

Configure eir

Use this attribute to set a Committed Information Rate. Default value is 1.

Attribute Name: cir

Attribute Type: uint64

Attribute Range: 1-720000000

Attribute Name: type

Attribute Type: enum (none|colour-blind|colour-aware)

Attribute Name: cir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Attribute Name: eir

Attribute Type: uint64

Attribute Range: 1-720000000

Attribute Name: eir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
```

```

<policy-maps>
<policy-map>
  <policy-map-name>NAME</policy-map-name>
  <config>
    <policy-map-name>NAME</policy-map-name>
  </config>
<classes>
<class>
  <class-map-name>NAME</class-map-name>
  <config>
    <class-map-name>NAME</class-map-name>
  </config>
  <qos-mode>
  <police>
  <config>
    <type>none</type> <!-- operation="delete"-->
    <cir-unit>kbps</cir-unit> <!-- operation="delete"-->
    <eir>1</eir> <!-- operation="delete"-->
    <eir-unit>kbps</eir-unit> <!-- operation="delete"-->
    <cir>1</cir> <!-- operation="delete"-->
  </config>
</police>
</qos-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>

```

Command Syntax

```

police ((colour-blind|colour-aware)|) cir <1-720000000> (kbps|mbps|gbps) eir <1-
720000000> (kbps|mbps|gbps)

```

Configure eir unit

Use this attribute to set a Committed Information Rate. Default value is 1.

Attribute Name: cir

Attribute Type: uint64

Attribute Name: type

Attribute Type: enum (none|colour-blind|colour-aware)

Attribute Name: cir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Attribute Name: eir

Attribute Type: uint64

Attribute Range: 1-720000000

Attribute Name: eir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
  <policy-maps>
  <policy-map>
    <policy-map-name>NAME</policy-map-name>
    <config>
      <policy-map-name>NAME</policy-map-name>
    </config>
  <classes>
  <class>
    <class-map-name>NAME</class-map-name>
    <config>
      <class-map-name>NAME</class-map-name>
    </config>
    <qos-mode>
    <police>
    <config>
      <type>none</type> <!-- operation="delete"-->
      <cir-unit>kbps</cir-unit> <!-- operation="delete"-->
      <eir>1</eir> <!-- operation="delete"-->
      <eir-unit>kbps</eir-unit> <!-- operation="delete"-->
      <cir>1</cir> <!-- operation="delete"-->
    </config>
  </police>
</qos-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>
```

Command Syntax

```
police ((colour-blind|colour-aware)|) cir percent <1-100> eir <1-720000000>
(kbps|mbps|gbps)
```

Configure bc

Use this attribute to set a Committed Information Rate. Default value is 1.

Attribute Name: cir

Attribute Type: uint64

Attribute Range: 1-720000000

Attribute Name: type

Attribute Type: enum (none|colour-blind|colour-aware)

Attribute Name: cir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Attribute Name: eir

Attribute Type: uint64

Attribute Range: 1-720000000

Attribute Name: eir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Attribute Name: bc

Attribute Type: uint64

Attribute Range: 1-4161

Attribute Name: bc-unit

Attribute Type: enum (none|kbytes|mbytes|ms|us)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <policy-maps>
      <policy-map>
        <policy-map-name>NAME</policy-map-name>
        <config>
          <policy-map-name>NAME</policy-map-name>
        </config>
      <classes>
        <class>
          <class-map-name>NAME</class-map-name>
          <config>
            <class-map-name>NAME</class-map-name>
          </config>
          <qos-mode>
            <police>
              <config>
                <type>none</type> <!-- operation="delete"-->
                <cir-unit>kbps</cir-unit> <!-- operation="delete"-->
                <eir>1</eir> <!-- operation="delete"-->
                <eir-unit>kbps</eir-unit> <!-- operation="delete"-->
                <bc>1</bc> <!-- operation="delete"-->
                <bc-unit>none</bc-unit> <!-- operation="delete"-->
                <cir>1</cir> <!-- operation="delete"-->
              </config>
            </police>
          </qos-mode>
        </class>
      </classes>
    </policy-map>
  </policy-maps>
</global>
```

```
</qos>
```

Command Syntax

```
police ((colour-blind|colour-aware)|) cir <1-720000000> (kbps|mbps|gbps) eir <1-720000000> (kbps|mbps|gbps) bc <1-4161> (kbytes|mbytes|ms|us)
```

Configure bc unit

Use this attribute to set a Committed Information Rate. Default value is 1.

Attribute Name: cir

Attribute Type: uint64

Attribute Name: type

Attribute Type: enum (none|colour-blind|colour-aware)

Attribute Name: cir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Attribute Name: eir

Attribute Type: uint64

Attribute Range: 1-720000000

Attribute Name: eir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Attribute Name: bc

Attribute Type: uint64

Attribute Range: 1-4161

Attribute Name: bc-unit

Attribute Type: enum (none|kbytes|mbytes|ms|us)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <policy-maps>
      <policy-map>
        <policy-map-name>NAME</policy-map-name>
        <config>
          <policy-map-name>NAME</policy-map-name>
        </config>
      </policy-map>
    </policy-maps>
    <classes>
      <class>
        <class-map-name>NAME</class-map-name>
        <config>
          <class-map-name>NAME</class-map-name>
        </config>
      </class>
    </classes>
  </global>
  <police>
    <config>
```



```

        <type>none</type> <!-- operation="delete"-->
        <cir-unit>kbps</cir-unit> <!-- operation="delete"-->
        <eir>1</eir> <!-- operation="delete"-->
        <eir-unit>kbps</eir-unit> <!-- operation="delete"-->
        <bc>1</bc> <!-- operation="delete"-->
        <bc-unit>none</bc-unit> <!-- operation="delete"-->
        <cir>1</cir> <!-- operation="delete"-->
    </config>
</police>
</qos-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>

```

Command Syntax

```

police ((colour-blind|colour-aware)|) cir percent <1-100> eir <1-720000000>
    (kbps|mbps|gbps) bc <1-4161> (kbytes|mbytes|ms|us)

```

Configure be

Use this attribute to set a Committed Information Rate. Default value is 1.

Attribute Name: cir

Attribute Type: uint64

Attribute Range: 1-720000000

Attribute Name: type

Attribute Type: enum (none|colour-blind|colour-aware)

Attribute Name: cir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Attribute Name: eir

Attribute Type: uint64

Attribute Range: 1-720000000

Attribute Name: eir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Attribute Name: be

Attribute Type: uint32

Attribute Range: 1-4161

Attribute Name: be-unit

Attribute Type: enum (none|kbytes|mbytes|ms|us)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
  <policy-maps>
  <policy-map>
    <policy-map-name>NAME</policy-map-name>
    <config>
      <policy-map-name>NAME</policy-map-name>
    </config>
  <classes>
  <class>
    <class-map-name>NAME</class-map-name>
    <config>
      <class-map-name>NAME</class-map-name>
    </config>
    <qos-mode>
    <police>
    <config>
      <type>none</type> <!-- operation="delete"-->
      <cir-unit>kbps</cir-unit> <!-- operation="delete"-->
      <eir>1</eir> <!-- operation="delete"-->
      <eir-unit>kbps</eir-unit> <!-- operation="delete"-->
      <be>1</be> <!-- operation="delete"-->
      <be-unit>none</be-unit> <!-- operation="delete"-->
      <cir>1</cir> <!-- operation="delete"-->
    </config>
  </police>
</qos-mode>
</class>
</classes>
</policy-map>
</policy-maps>
</global>
</qos>
```

Command Syntax

```
police ((colour-blind|colour-aware)|) cir <1-720000000> (kbps|mbps|gbps) eir <1-720000000> (kbps|mbps|gbps) be <1-4161> (kbytes|mbytes|ms|us)
```

Configure be unit

Use this attribute to set a Committed Information Rate. Default value is 1.

Attribute Name: cir

Attribute Type: uint64

Attribute Name: type

Attribute Type: enum (none|colour-blind|colour-aware)

Attribute Name: cir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Attribute Name: eir

Attribute Type: uint64

Attribute Range: 1-720000000

Attribute Name: eir-unit

Attribute Type: enum (kbps|mbps|gbps|percent)

Attribute Name: be

Attribute Type: uint32

Attribute Range: 1-4161

Attribute Name: be-unit

Attribute Type: enum (none|kbytes|mbytes|ms|us)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <global>
    <policy-maps>
      <policy-map>
        <policy-map-name>NAME</policy-map-name>
        <config>
          <policy-map-name>NAME</policy-map-name>
        </config>
      <classes>
        <class>
          <class-map-name>NAME</class-map-name>
          <config>
            <class-map-name>NAME</class-map-name>
          </config>
          <qos-mode>
            <police>
              <config>
                <type>none</type> <!-- operation="delete"-->
                <cir-unit>kbps</cir-unit> <!-- operation="delete"-->
                <eir>1</eir> <!-- operation="delete"-->
                <eir-unit>kbps</eir-unit> <!-- operation="delete"-->
                <be>1</be> <!-- operation="delete"-->
                <be-unit>none</be-unit> <!-- operation="delete"-->
                <cir>1</cir> <!-- operation="delete"-->
              </config>
            </police>
          </qos-mode>
        </class>
      </classes>
    </policy-map>
  </policy-maps>
</global>
</qos>
```

Command Syntax

```
police ((colour-blind|colour-aware)|) cir percent <1-100> eir <1-720000000>
(kbps|mbps|gbps) be <1-4161> (kbytes|mbytes|ms|us)
```

clear qos statistics (interface IFNAME) ((type qos|type qos input|type qos output|type queuing|type all))

Attribute Name: interface-name

Attribute Type: string

Default Value: NULL

Attribute Name: type

Attribute Type: enum (type qos|type qos input|type qos output|type queuing|type all)

Default Value: type all

Netconf RPC payload

```
<qos-clear-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<interface-name>IFNAME</interface-name>
<type>type all</type>
</qos-clear-statistics>
```

Command Syntax

```
clear qos statistics (interface IFNAME|) ((type qos|type qos input|type qos
output|type queuing|type all)|)
```

IPI-QOS-IF

Configure untagged priority

Use this attribute to set internal priority for untagged traffic on L2 interface

Attribute Name: untagged-priority

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">
<interface>
<name>WORD</name>
<config>
<name>WORD</name>
</config>
<untagged-priority>0</untagged-priority> <!-- operation="delete"-->
</interface>
</interfaces>
```

```
</qos>
```

Command Syntax

```
qos untagged-priority <0-7>
```

Configure trust dscp

Use this command to classify the ingress traffic based on DSCP map on L2 interface

Attribute Name: trust-dscp

Attribute Type: empty

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </trust-dscp><!-- operation="delete"-->
</interface>
</interfaces>
</qos>
```

Command Syntax

```
trust dscp
```

Configure cos

Use this command to enable/disable remarking of CoS set by the egress map

Attribute Name: cos

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <remark>
  <config>
    <cos>disable</cos> <!-- operation="delete"-->
  </config>
</remark>
</interface>
</interfaces>
```

```
</qos>
```

Command Syntax

```
qos remark cos (disable|enable)
```

Configure dscp

Use this command to enable/disable remarking of DSCP set by the egress map

Attribute Name: dscp

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <remark>
  <config>
    <dscp>disable</dscp> <!-- operation="delete"-->
  </config>
</remark>
</interface>
</interfaces>
</qos>
```

Command Syntax

```
qos remark dscp (disable|enable)
```

Configure name

Interface name for which QoS is being configured

Attribute Name: name

Attribute Type: string

Attribute Name: rate

Attribute Type: uint64

Attribute Name: rate-unit

Attribute Type: enum (kbps|mbps|gbps)

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">
<interface> <!-- operation="delete"-->
  <name>WORD</name>
```

```

<config>
  <name>WORD</name>
</config>
<traffic-shape>
<config>
  <rate>1</rate>
  <rate-unit>kbps</rate-unit>
</config>
</traffic-shape>
</interface>
</interfaces>
</qos>

```

Command Syntax

```
shape rate <1-1000000000> (kbps|mbps|gbps)
```

Configure cos to queue

Use this attribute to attach a CoS to Traffic-Class profile to the interface

This command is supported when following feature are enabled QoS Mapping profile

Attribute Name: cos-to-queue

Attribute Type: string

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <map-profile>
  <config>
    <cos-to-queue>NAME</cos-to-queue> <!-- operation="delete"-->
  </config>
</map-profile>
</interface>
</interfaces>
</qos>

```

Command Syntax

```
qos map-profile cos-to-queue NAME
```

Configure dscp to dscp

Use this attribute to attach a DSCP to DSCP profile to the interface

This command is supported when following feature are enabled QoS Mapping profile

Attribute Name: dscp-to-dscp

Attribute Type: string

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <map-profile>
        <config>
          <dscp-to-dscp>NAME</dscp-to-dscp> <!-- operation="delete"-->
        </config>
      </map-profile>
    </interface>
  </interfaces>
</qos>
```

Command Syntax

```
qos map-profile dscp-to-dscp NAME
```

Configure precedence to precedence

Use this attribute to attach a Precedence to Precedence profile to the interface

This command is supported when following feature are enabled QoS Mapping profile

Attribute Name: precedence-to-precedence

Attribute Type: string

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <map-profile>
        <config>
          <precedence-to-precedence>NAME</precedence-to-precedence> <!--
operation="delete"-->
        </config>
      </map-profile>
    </interface>
  </interfaces>
</qos>
```

Command Syntax

```
qos map-profile precedence-to-precedence NAME
```

Configure dscp to queue

Use this attribute to attach a DSCP to Traffic-Class profile to the interface

This command is supported when following feature are enabled QoS Mapping profile

Attribute Name: dscp-to-queue

Attribute Type: string

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
        </config>
        <map-profile>
          <config>
            <dscp-to-queue>NAME</dscp-to-queue> <!-- operation="delete"-->
          </config>
        </map-profile>
      </interface>
    </interfaces>
  </qos>
```

Command Syntax

```
qos map-profile dscp-to-queue NAME
```

Configure precedence to queue

Use this attribute to attach a Precedence to Traffic-Class profile to the interface

This command is supported when following feature are enabled QoS Mapping profile

Attribute Name: precedence-to-queue

Attribute Type: string

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
  <interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
        </config>
        <map-profile>
          <config>
            <precedence-to-queue>NAME</precedence-to-queue> <!-- operation="delete"-->
          </config>
        </map-profile>
      </interface>
    </interfaces>
  </qos>
```

```
</map-profile>  
</interface>  
</interfaces>  
</qos>
```

Command Syntax

```
qos map-profile precedence-to-queue NAME
```

Configure exp encapsulation

Use this attribute to attach a MPLS experimental encapsulation profile to the interface

This command is supported when following feature are enabled QoS Mapping profile

Attribute Name: exp-encapsulation

Attribute Type: string

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">  
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">  
<interface>  
  <name>WORD</name>  
  <config>  
    <name>WORD</name>  
  </config>  
  <map-profile>  
  <config>  
    <exp-encapsulation>NAME</exp-encapsulation> <!-- operation="delete"-->  
  </config>  
</map-profile>  
</interface>  
</interfaces>  
</qos>
```

Command Syntax

```
qos map-profile exp-encap NAME
```

Configure dscp encapsulation

Use this attribute to attach a MPLS dscp encapsulation profile to the interface

This command is supported when following feature are enabled QoS Mapping profile

Attribute Name: dscp-encapsulation

Attribute Type: string

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">  
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">  
<interface>  
  <name>WORD</name>
```

```

<config>
  <name>WORD</name>
</config>
<map-profile>
<config>
  <dscp-encapsulation>NAME</dscp-encapsulation> <!-- operation="delete"-->
</config>
</map-profile>
</interface>
</interfaces>
</qos>

```

Command Syntax

```
qos map-profile dscp-encap NAME
```

Configure queue color to cos

Use this attribute to attach a Traffic-Class color to CoS profile to the interface

This command is supported when following feature are enabled QoS Mapping profile

Attribute Name: queue-color-to-cos

Attribute Type: string

Netconf edit-config payload

```

<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <map-profile>
  <config>
    <queue-color-to-cos>NAME</queue-color-to-cos> <!-- operation="delete"-->
  </config>
</map-profile>
</interface>
</interfaces>
</qos>

```

Command Syntax

```
qos map-profile queue-color-to-cos NAME
```

Configure type qos policy map name

Use this attribute to attach a service-policy of type qos to the interface

Attribute Name: type-qos-policy-map-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <service-policy>
  <ingress>
  <config>
    <type-qos-policy-map-name>NAME</type-qos-policy-map-name> <!--
operation="delete"-->
  </config>
</ingress>
</service-policy>
</interface>
</interfaces>
</qos>
```

Command Syntax

```
service-policy type qos input NAME
```

Configure type queuing policy map name

Use this attribute to attach a service-policy of type queue to the interface

Attribute Name: type-queuing-policy-map-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<qos xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos">
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-qos-if">
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <service-policy>
  <egress>
  <config>
    <type-queuing-policy-map-name>NAME</type-queuing-policy-map-name> <!--
operation="delete"-->
  </config>
</egress>
</service-policy>
</interface>
```

```
</interfaces>
</qos>
```

Command Syntax

```
service-policy type queuing output NAME
```

IPI-RSVP

Configure options

Use this attribute to enable all debugging options for an RSVP daemon. Enable RSVP debugs at configuration mode

Attribute Name: options

Attribute Type: bits (events|packet|packet in|packet out|hexdump|nsm|cspf|fsm egress|fsm transit downstream|fsm transit upstream|fsm ingress|rib|neighbor|fsm|fsm transit|all)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <debug>
    <config>
      <options>events</options> <!-- operation="delete"-->
    </config>
  </debug>
</rsvp-te>
```

Command Syntax

```
debug rsvp (events|packet|packet in|packet out|hexdump|nsm|cspf|fsm egress|fsm
  transit downstream|fsm transit upstream|fsm ingress|rib|neighbor|fsm|fsm
  transit|all|)
```

Configure enable rsvp trap

Use this attribute to enable/disable the rsvp trap

Attribute Name: enable-rsvp-trap

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <snmp-configuration>
    <config>
      </enable-rsvp-trap><!-- operation="delete"-->
    </config>
  </snmp-configuration>
</rsvp-te>
```

Command Syntax

```
rsvp-trap enable
```

Configure disable refresh resv parsing

Use this attribute to disable parsing of Refresh RESV messages received from upstream nodes. Use this attribute to minimize message processing by RSVP when you are sure that a particular router does not need to parse Refresh RESV messages to check for changes because LSPs passing through this router are not required to be updated simultaneously.

Attribute Name: disable-refresh-resv-parsing

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <config>
      </disable-refresh-resv-parsing><!-- operation="delete"-->
    </config>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
no refresh-resv-parsing
```

Configure disable refresh path parsing

Use this attribute to disable parsing of Refresh PATH messages received from upstream nodes. Use this attribute to minimize message processing by RSVP when you are sure that a particular router does not need to parse Refresh-PATH messages to check for changes, because LSPs passing through this router are not required to be updated simultaneously.

Attribute Name: disable-refresh-path-parsing

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <config>
      </disable-refresh-path-parsing><!-- operation="delete"-->
    </config>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
no refresh-path-parsing
```

Configure disable loop detection

Use this attribute to turn on loop detection for Path and Reservation messages exchanged between LSRs

Attribute Name: disable-loop-detection

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <config>
      </disable-loop-detection><!-- operation="delete"-->
    </config>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
no loop-detection
```

Configure enable php

Use this attribute to enable Penultimate-Hop-Popping for the router. An egress router sends either the implicit-null or the explicit-null label for LSPs. If the no-php command has been enabled, the egress router sends non-reserved labels (those labels in the label pool range allotted to RSVP) to the upstream router.

Attribute Name: enable-php

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <config>
      </enable-php><!-- operation="delete"-->
    </config>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
php
```

Configure enable entropy label capability

Use this attribute to enable Entropy Label Capability (ELC) for the router. An egress router may insert ELC TLV in Attributes Flags TLV of Resv message. If no entropy-label-capability command has been enabled, the egress router doesn't include ELC TLV in Resv message.

Attribute Name: enable-entropy-label-capability

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <config>
      </enable-entropy-label-capability><!-- operation="delete"-->
    </config>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
entropy-label-capability
```

Configure enable bundle send

Use this attribute to enable sending of BUNDLE messages for all the interfaces

Attribute Name: enable-bundle-send

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <config>
      </enable-bundle-send><!-- operation="delete"-->
    </config>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
bundle-send
```

Configure enable local protection

Use this attribute to enable/disable the local repair of explicit routes for which this router is a transit node

Attribute Name: enable-local-protection

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <config>
      </enable-local-protection><!-- operation="delete"-->
    </config>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
local-protection
```

Configure enable explicit null

Use this attribute to send explicit-null labels for directly-connected forwarding equivalency classes (FECs) instead of implicit-null labels. This command controls the label value advertised to an egress router of an LSP. By default, implicit null label (label 3) is advertised for directly connected FECs. If implicit-null label is advertised, the penultimate hop removes the label and sends the packet as a plain IP packet to the egress router. The explicit-null command advertises label 0 and retains the label so the egress router can pop it. For details about usage of explicit-null, please refer to RFC 3032. Use the no parameter with this command to stop sending explicit-null labels for directly-connected FECs and resume sending implicit-null labels.

Attribute Name: enable-explicit-null

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <config>
      </enable-explicit-null><!-- operation="delete"-->
    </config>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
explicit-null
```

Configure detour allow primary upstream path

Use this attribute to ensure detour formation allowed to consider upstream path of primary, a deviation to RFC 4090 section 6.2 recommendation. This attribute intended to be used on special case where detour protection required on ring topology with no additional alternate path available.

Attribute Name: detour-allow-primary-upstream-path

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <fast-reroute>
      <config>
        </detour-allow-primary-upstream-path><!-- operation="delete"-->
      </config>
    </fast-reroute>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
detour-allow-primary-upstream-path
```

Configure rsvp

Use this attribute to enter router mode from configure mode and to enable the RSVP daemon, if it is not already enabled and Enter in to router rsvp mode from configure mode

Attribute Name: rsvp

Attribute Type: enum (rsvp)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <config>
```

```
<rsvp>rsvp</rsvp>
</config>
</rsvp-instance>
</rsvp-te>
```

Command Syntax

```
router (rsvp)
```

Configure revert timer

Use this attribute to Hold-on timer before revert back to primary session

Attribute Name: revert-timer

Attribute Type: uint32

Default Value: 60

Attribute Range: 1-65535

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<rsvp-instance>
<config>
  <revert-timer>1</revert-timer> <!-- operation="delete"-->
</config>
</rsvp-instance>
</rsvp-te>
```

Command Syntax

```
revert-timer <1-65535>
```

Configure ingress

Use this attribute to specify a .from. IPv4 address for the RSVP daemon. This command can be invoked from either the router rsvp mode or from the rsvp-trunk mode. In the RSVP router mode, this command defines the source address as an IPv4 packet sent out by the RSVP daemon. In the RSVP trunk mode, this command indicates a sender.s address in the sender template object that is used in path messages.

Attribute Name: ingress

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<rsvp-instance>
<config>
  <ingress>A.B.C.D</ingress> <!-- operation="delete"-->
</config>
</rsvp-instance>
</rsvp-te>
```

Command Syntax

```
from A.B.C.D
```

Configure enable message ack

Use this attribute to enable message acknowledgement for all messages being sent to neighbors that are known to support refresh reduction.

Attribute Name: enable-message-ack

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <route-refresh>
      <config>
        </enable-message-ack><!-- operation="delete"-->
      </config>
    </route-refresh>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
message-ack
```

Configure disable refresh reduction

Use this attribute to enable refresh reduction capability advertisement for all interfaces

Attribute Name: disable-refresh-reduction

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <route-refresh>
      <config>
        </disable-refresh-reduction><!-- operation="delete"-->
      </config>
    </route-refresh>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
no refresh-reduction
```

Configure ack send timer

Use this attribute to configure the timer for sending acknowledgement for all RSVP-TE neighbors. By default, timer is disabled.

Attribute Name: ack-send-timer

Attribute Type: uint16

Attribute Range: 1-5

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <route-refresh>
      <config>
        <ack-send-timer>1</ack-send-timer> <!-- operation="delete"-->
      </config>
    </route-refresh>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
ack-send-timer <1-5>
```

Configure ack wait timeout

Use this attribute to configure the acknowledgement wait timeout for all RSVP-TE neighbors

Attribute Name: ack-wait-timeout

Attribute Type: uint32

Default Value: 10

Attribute Range: 1-65535

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <route-refresh>
      <config>
        <ack-wait-timeout>1</ack-wait-timeout> <!-- operation="delete"-->
      </config>
    </route-refresh>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
ack-wait-timeout <1-65535>
```

Configure refresh time

Use this attribute to configure RSVP refresh interval timer. The timer specifies the interval after which Path and/ or Reservation Request (Resv) messages will be sent out. The refresh time and keep multiplier are two interrelated timing parameters used to calculate the valid Reservation Lifetime for an LSP. Refresh time regulates the interval between Refresh messages which include Path and Reservation Request (Resv) messages. Refresh messages are sent periodically so that reservation does not timeout in the neighboring nodes. Each sender and receiver host sends Path and Resv messages, downstream and upstream respectively, along the paths.

Attribute Name: refresh-time

Attribute Type: uint16

Default Value: 30

Attribute Range: 1-65535

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <route-refresh>
      <config>
        <refresh-time>1</refresh-time> <!-- operation="delete"-->
      </config>
    </route-refresh>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
refresh-time <1-65535>
```

Configure keep multiplier

Use this attribute to configure the constant to be used to calculate a valid reservation lifetime for a Labeled Switched Path (LSP). The refresh time and keep multiplier are two interrelated timing parameters used to calculate the valid reservation lifetime for an LSP. The router sends refresh messages periodically so that the neighbors do not timeout

Attribute Name: keep-multiplier

Attribute Type: int32

Default Value: 3

Attribute Range: 1-255

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <route-refresh>
      <config>
        <keep-multiplier>1</keep-multiplier> <!-- operation="delete"-->
      </config>
    </route-refresh>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
keep-multiplier <1-255>
```

Configure default frr protection

Use this attribute to set default FRR protection mechanism to trigger when local protection requested by protection mechanism not mentioned via FRR object. When FRR object explicitly requests for the protection type, this attribute will not come into picture. Default will be one-to-one protection.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: default-frr-protection

Attribute Type: enum (one-to-one|facility)

Default Value: one-to-one

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <fast-reroute>
      <config>
        <default-frr-protection>one-to-one</default-frr-protection> <!--
operation="delete"-->
      </config>
    </fast-reroute>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
default-frr-protection (one-to-one|facility)
```

Configure preemption type

Use this attribute to set preemption type for an LSP for the router. Preemption of an LSP or set of LSPs happens based on bandwidth constraints like preempting an LSP cause less number of LSPs be preempted upon satisfying the bandwidth required, preempting an LSP or set of LSPs which results in an LSP having less unused(remaining) bandwidth.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: preemption-type

Attribute Type: enum (less-lsp-preempted|less-unused-bandwidth)

Default Value: less-lsp-preempted

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <fast-reroute>
      <config>
        <preemption-type>less-lsp-preempted</preemption-type> <!-- operation="delete"-->
      </config>
    </fast-reroute>
  </rsvp-instance>
</rsvp-te>
```

```
</rsvp-instance>
</rsvp-te>
```

Command Syntax

```
preemption-type (less-lsp-preempted|less-unused-bandwidth)
```

Configure bypass lsp addr query interval

Modify interval of bypass trunk querying LSP address

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: bypass-lsp-addr-query-interval

Attribute Type: uint8

Default Value: 60

Attribute Range: 10-60

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <fast-reroute>
      <config>
        <bypass-lsp-addr-query-interval>10</bypass-lsp-addr-query-interval> <!--
operation="delete"-->
      </config>
    </fast-reroute>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
bypass-lsp-addr-query-interval <10-60>
```

Configure detour id

Use this attribute to set a path-specific detour LSP identification method, using the detour object.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: detour-id

Attribute Type: enum (sender-template|path)

Default Value: path

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <fast-reroute>
      <config>
        <detour-id>path</detour-id> <!-- operation="delete"-->
      </config>
    </fast-reroute>
  </rsvp-instance>
</rsvp-te>
```

```
</rsvp-instance>  
</rsvp-te>
```

Command Syntax

```
detour-identification (sender-template|path)
```

Configure disable cspf

Use this attribute to disable the use of the Constrained Shortest Path First (CSPF) server for all RSVP sessions. Disable CSPF when no nodes support the required traffic engineering extensions. When this command is executed in Router mode, CSPF is enabled for all configured RSVP sessions, and all RSVP sessions configured from this point forward. If the default CSPF per RSVP session is enabled, it will be disabled. The CSPF status for RSVP sessions can be verified using the `show rsvp session` command with the `detail` option

Attribute Name: `disable-cspf`

Attribute Type: `uint8`

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">  
<rsvp-instance>  
<cspf>  
<config>  
  </disable-cspf><!-- operation="delete"-->  
</config>  
</cspf>  
</rsvp-instance>  
</rsvp-te>
```

Command Syntax

```
no cspf
```

Configure cspf lsp reoptimization time

Use this attribute to configure timer for the reoptimizing lsp.

This command is supported when following feature are enabled CSPF feature

Attribute Name: `cspf-lsp-reoptimization-time`

Attribute Type: `uint32`

Default Value: 5

Attribute Range: 1-240

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">  
<rsvp-instance>  
<cspf>  
<config>  
  <cspf-lsp-reoptimization-time>1</cspf-lsp-reoptimization-time> <!--  
operation="delete"-->  
</config>
```



```
</cspf>
</rsvp-instance>
</rsvp-te>
```

Command Syntax

```
lsp-reoptimization-timer <1-240>
```

Configure enable hello receipt

Use this attribute to enable the receipt of Hello messages from peers.

Attribute Name: enable-hello-receipt

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <global>
      <hellos>
        <config>
          </enable-hello-receipt><!-- operation="delete"-->
        </config>
      </hellos>
    </global>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
hello-receipt
```

Configure enable graceful restart

Use this attribute to enable RSVP-TE Graceful Restart capability on a router. This is a global parameter. RSVP-TE determines whether or not to send the graceful restart capability object in its hello message. However, this capability also depends on support for graceful restart on the neighbor router.

Attribute Name: enable-graceful-restart

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <global>
      <graceful-restart>
        <config>
          </enable-graceful-restart>
        </config>
      </graceful-restart>
    </global>
  </rsvp-instance>
```

```
</rsvp-te>
```

Command Syntax

```
graceful-restart
```

Configure hello interval

Use this attribute to set an interval between Hello packets. Used as a global command, this value is over-ridden by the hello-interval set on the interface (see rsvp hello-interval). For optimum performance, set this value no more than one-third of the hello-timeout value.

Attribute Name: hello-interval

Attribute Type: int32

Default Value: 2

Attribute Range: 1-65535

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <global>
      <hellos>
        <config>
          <hello-interval>1</hello-interval> <!-- operation="delete"-->
        </config>
      </hellos>
    </global>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
hello-interval <1-65535>
```

Configure hello timeout

Timeout for clearing up all sessions shared with a neighbor. If an LSR has not received a Hello message from a peer within the number of seconds set with this command, all sessions shared with this peer are reset. The hello-timeout determines how long an RSVP node waits for a hello message before declaring a neighbor to be down.

Attribute Name: hello-timeout

Attribute Type: int32

Default Value: 7

Attribute Range: 1-65535

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <global>
      <hellos>
        <config>
```

```
    <hello-timeout>1</hello-timeout> <!-- operation="delete"-->
</config>
</hellos>
</global>
</rsvp-instance>
</rsvp-te>
```

Command Syntax

```
hello-timeout <1-65535>
```

Configure restart time

Use this attribute to set a restart time for an RSVP-TE graceful restart configuration.

This command is supported when following feature are enabled grst feature

Attribute Name: restart-time

Attribute Type: uint32

Default Value: 180000

Attribute Range: 10000-600000

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <global>
      <graceful-restart>
        <config>
          <restart-time>10000</restart-time> <!-- operation="delete"-->
        </config>
      </graceful-restart>
    </global>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
graceful-restart restart-time <10000-600000>
```

Configure recovery time

Use this attribute to set a recovery time for an RSVP-TE graceful restart configuration.

This command is supported when following feature are enabled grst feature

Attribute Name: recovery-time

Attribute Type: uint32

Default Value: 360000

Attribute Range: 60000-3600000

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
```

```
<rsvp-instance>
<global>
<graceful-restart>
<config>
  <recovery-time>60000</recovery-time> <!-- operation="delete"-->
</config>
</graceful-restart>
</global>
</rsvp-instance>
</rsvp-te>
```

Command Syntax

```
graceful-restart recovery-time <60000-3600000>
```

Configure enable gmpls notification

Use this attribute to enable a router's ability to send notification messages for all GMPLS LSPs configured on the box. This command can be used to enable or disable sending notification messages. By default, notification is enabled for all GMPLS LSPs configured on the box.

Attribute Name: enable-gmpls-notification

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<rsvp-instance>
<gmpls>
<config>
  </enable-gmpls-notification><!-- operation="delete"-->
</config>
</gmpls>
</rsvp-instance>
</rsvp-te>
```

Command Syntax

```
notification
```

Configure enable pre program suggested label

Enable suggested label feature of gmpls

Attribute Name: enable-pre-program-suggested-label

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<rsvp-instance>
<gmpls>
<config>
  </enable-pre-program-suggested-label><!-- operation="delete"-->
</config>
</gmpls>
</rsvp-instance>
</rsvp-te>
```

```
</config>  
</gmpls>  
</rsvp-instance>  
</rsvp-te>
```

Command Syntax

```
preprogram-suggested-label
```

Configure srlg disjoint

Use the attribute to configure the srlg-disjoint path-protection in global mode

This command is supported when following feature are enabled Shared Risk Link Groups feature

Attribute Name: srlg-disjoint

Attribute Type: enum (forced|preferred)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">  
<rsvp-instance>  
<srlg>  
<config>  
  <srlg-disjoint>forced</srlg-disjoint> <!-- operation="delete"-->  
</config>  
</srlg>  
</rsvp-instance>  
</rsvp-te>
```

Command Syntax

```
srlg-disjoint (forced|preferred)
```

Configure enable override diff serv

Setup a non-diffserv lsp if diffserv obj is not present in Path message

Attribute Name: enable-override-diff-serv

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">  
<rsvp-instance>  
<diff-serv>  
<config>  
  </enable-override-diff-serv><!-- operation="delete"-->  
</config>  
</diff-serv>  
</rsvp-instance>  
</rsvp-te>
```

Command Syntax

```
override-diffserv
```

Configure address

Directly connected neighbor

Attribute Name: address

Attribute Type: inet:ip-address

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-instance>
    <neighbors>
      <neighbor> <!-- operation="delete"-->
        <address>CML_IP_ADDR_T</address>
        <config>
          <address>CML_IP_ADDR_T</address>
        </config>
      </neighbor>
    </neighbors>
  </rsvp-instance>
</rsvp-te>
```

Command Syntax

```
neighbor (A.B.C.D|X:X::X:X)
```

clear rsvp statistics

Netconf RPC payload

```
<clear-rsvp-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp"/>
```

Command Syntax

```
clear rsvp statistics
```

snmp restart rsvp

Netconf RPC payload

```
<rsvp-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp"/>
```

Command Syntax

```
snmp restart rsvp
```

debug rsvp (events|packet|packet in|packet out|hexdump|nsm|cspf|fsm egress|fsm transit downstream|fsm transit upstream|fsm ingress|rib|neighbor|fsm|fsm transit|all|)

Attribute Name: terminal-debug-options

Attribute Type: bits (events|packet|packet in|packet out|hexdump|nsm|cspf|fsm egress|fsm transit downstream|fsm transit upstream|fsm ingress|rib|neighbor|fsm|fsm transit|all)

Netconf RPC payload

```
<rsvp-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<terminal-debug-options>events</terminal-debug-options>
</rsvp-terminal-debug-on>
```

Command Syntax

```
debug rsvp (events|packet|packet in|packet out|hexdump|nsm|cspf|fsm egress|fsm
transit downstream|fsm transit upstream|fsm ingress|rib|neighbor|fsm|fsm
transit|all|)
```

no debug rsvp (events|packet|packet in|packet out|hexdump|nsm|cspf|fsm egress|fsm transit downstream|fsm transit upstream|fsm ingress|rib|neighbor|fsm|fsm transit|all|)

Attribute Name: terminal-debug-options

Attribute Type: bits (events|packet|packet in|packet out|hexdump|nsm|cspf|fsm egress|fsm transit downstream|fsm transit upstream|fsm ingress|rib|neighbor|fsm|fsm transit|all)

Netconf RPC payload

```
<rsvp-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<terminal-debug-options>events</terminal-debug-options>
</rsvp-terminal-debug-off>
```

Command Syntax

```
no debug rsvp (events|packet|packet in|packet out|hexdump|nsm|cspf|fsm egress|fsm
transit downstream|fsm transit upstream|fsm ingress|rib|neighbor|fsm|fsm
transit|all|)
```

restart rsvp graceful

Netconf RPC payload

```
<restart-rsvp-graceful xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp"/>
```

Command Syntax

```
restart rsvp graceful
```

IPI-RSVP-TRUNK

Configure path name

Use this attribute to configure the path

Attribute Name: path-name

Attribute Type: string

Attribute Range: 1-128

Attribute Name: path-type

Attribute Type: enum (mpls|gmpls)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-paths>
    <rsvp-path>
      <path-name>PATHNAME</path-name>
      <config>
        <path-name>PATHNAME</path-name>
        <path-type>mpls</path-type>
      </config>
    </rsvp-path>
  </rsvp-paths>
</rsvp-te>
```

Command Syntax

```
rsvp-path PATHNAME (mpls|gmpls|)
```

Configure description

Use this attribute to add description for rsvp path

This command is supported when following feature are disabled Generic MPLS Tunnel Infra Feature

Attribute Name: description

Attribute Type: string

Attribute Range: 1-255

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-paths>
    <rsvp-path>
      <path-name>PATHNAME</path-name>
      <config>
        <path-name>PATHNAME</path-name>
      </config>
      <description>LINE</description> <!-- operation="delete"-->
    </rsvp-path>
  </rsvp-paths>
</rsvp-te>
```



```

</rsvp-path>
</rsvp-paths>
</rsvp-te>

```

Command Syntax

```
description LINE
```

Configure hop address

Use this attribute to define an explicit IPv4 or IPv6 route sub-object as either loose or strict hop. A list of sub-objects specifies an explicit route to the egress router for an LSP

Attribute Name: hop-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-paths>
    <rsvp-path>
      <path-name>PATHNAME</path-name>
      <config>
        <path-name>PATHNAME</path-name>
      </config>
      <explicit-route-object>
        <mpls-hops>
          <mpls-hop <!-- operation="delete"-->
            <hop-type>loose</hop-type>
            <config>
              <hop-type>loose</hop-type>
              <hop-address>A.B.C.D</hop-address>
            </config>
            <hop-address>A.B.C.D</hop-address>
          </mpls-hop>
        </mpls-hops>
      </explicit-route-object>
    </rsvp-path>
  </rsvp-paths>
</rsvp-te>

```

Command Syntax

```
A.B.C.D (loose|strict)
```

Configure strict hop address

Use this attribute to define an ERO path for a numbered (IPv4) interface. Only strict hops can be configured, and the strict type is implicit.

Attribute Name: strict-hop-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-paths>
    <rsvp-path>
      <path-name>PATHNAME</path-name>
      <config>
        <path-name>PATHNAME</path-name>
      </config>
      <explicit-route-object>
        <gmpls-strict-hops>
          <gmpls-strict-hop>
            <strict-hop-address>A.B.C.D</strict-hop-address>
            <config>
              <strict-hop-address>A.B.C.D</strict-hop-address>
            </config>
          </gmpls-strict-hop>
        </gmpls-strict-hops>
      </explicit-route-object>
    </rsvp-path>
  </rsvp-paths>
</rsvp-te>
```

Command Syntax

```
strict-hop A.B.C.D
```

Configure unnumbered ip addr

Use this attribute to define an ERO path for an unnumbered interface. Both the router ID and the link ID must be entered.

Attribute Name: unnumbered-ip-addr

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <rsvp-paths>
    <rsvp-path>
      <path-name>PATHNAME</path-name>
      <config>
        <path-name>PATHNAME</path-name>
      </config>
      <explicit-route-object>
        <gmpls-unnumbered-entry>
          <gmpls-unnumbered-hop>
            <link-id>1</link-id>
            <config>
              <link-id>1</link-id>
              <unnumbered-ip-addr>A.B.C.D</unnumbered-ip-addr>
            </config>
          </gmpls-unnumbered-hop>
        </gmpls-unnumbered-entry>
      </explicit-route-object>
    </rsvp-path>
  </rsvp-paths>
</rsvp-te>
```

```

    </gmpls-unnumbered-hop>
  </gmpls-unnumbered-entry>
</explicit-route-object>
</rsvp-path>
</rsvp-paths>
</rsvp-te>

```

Command Syntax

```
unnumbered A.B.C.D link-id <1-4294967295>
```

Configure multipath name

Use this attribute to create the multipath group name

Attribute Name: multipath-name

Attribute Type: string

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <multipaths>
    <multipath>
      <multipath-name>GROUPNAME</multipath-name>
    </multipath>
  </multipaths>
</rsvp-te>

```

Command Syntax

```
rsvp-multipath GROUPNAME
```

Configure destination

Use this attribute to add destination prefix for multipath group

This command is supported when following feature are enabled RSVP multipath feature

Attribute Name: destination

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <multipaths>
    <multipath>
      <multipath-name>GROUPNAME</multipath-name>
      <config>
        <multipath-name>GROUPNAME</multipath-name>
      </config>
      <destination>A.B.C.D</destination> <!-- operation="delete"-->
    </multipath>
  </multipaths>
</rsvp-te>

```

```
</multipath>  
</multipaths>  
</rsvp-te>
```

Command Syntax

```
to A.B.C.D
```

Configure bypass name

rsvp trunk bypass name

Attribute Name: bypass-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">  
  <trunks>  
    <bypass-trunks>  
      <bypass-trunk>  
        <bypass-name>BYPASSNAME</bypass-name>  
        <config>  
          <bypass-name>BYPASSNAME</bypass-name>  
        </config>  
      </bypass-trunk>  
    </bypass-trunks>  
  </trunks>  
</rsvp-te>
```

Command Syntax

```
rsvp-bypass BYPASSNAME
```

Configure ingress

Use this attribute to specify a from IPv4 address for the RSVP daemon. In the RSVP trunk mode, this command indicates a sender's address in the sender template object that is used in path messages.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: ingress

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">  
  <trunks>  
    <bypass-trunks>  
      <bypass-trunk>  
        <bypass-name>BYPASSNAME</bypass-name>  
        <config>  
          <bypass-name>BYPASSNAME</bypass-name>  
        </config>  
      </bypass-trunk>  
    </bypass-trunks>  
  </trunks>  
</rsvp-te>
```

```

    </config>
      <ingress>A.B.C.D</ingress> <!-- operation="delete"-->
</bypass-trunk>
</bypass-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
from A.B.C.D
```

Configure egress

Use this attribute to specify an IPv4 egress for an LSP. When configuring an LSP, you must specify the address of the egress router by using this command in the trunk node. An egress definition is a mandatory attribute; no RSVP session is created when an egress is not defined.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: egress

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <bypass-trunks>
      <bypass-trunk>
        <bypass-name>BYPASSNAME</bypass-name>
      <config>
        <bypass-name>BYPASSNAME</bypass-name>
      </config>
      <egress>A.B.C.D</egress> <!-- operation="delete"-->
    </bypass-trunk>
  </bypass-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
to A.B.C.D
```

Configure ext tunnel id

Use this attribute to configure an extended-tunnel identifier as an IPv4/IPv6 address. These identifiers are used in RSVP messages. If no extended-tunnel ID is specified, the LSR-ID for the router is used as the extended-tunnel ID for all LSPs. The extended-tunnel ID is a simple way of identifying all LSPs belonging to the same trunk.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: ext-tunnel-id

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <bypass-trunks>
      <bypass-trunk>
        <bypass-name>BYPASSNAME</bypass-name>
        <config>
          <bypass-name>BYPASSNAME</bypass-name>
        </config>
        <ext-tunnel-id>A.B.C.D</ext-tunnel-id> <!-- operation="delete"-->
      </bypass-trunk>
    </bypass-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
ext-tunnel-id A.B.C.D
```

Configure update type

Use this attribute to change the method of updating attributes for sessions (primary/ secondary) for this trunk as either make-before-break (default) or break-before-make

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: update-type

Attribute Type: enum (break-before-make|make-before-break)

Default Value: make-before-break

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <bypass-trunks>
      <bypass-trunk>
        <bypass-name>BYPASSNAME</bypass-name>
        <config>
          <bypass-name>BYPASSNAME</bypass-name>
          <update-type>make-before-break</update-type> <!-- operation="delete"-->
        </config>
      </bypass-trunk>
    </bypass-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
update-type (break-before-make|make-before-break)
```

Configure backup bandwidth type

rsvp bypass trunk backup bandwidth type

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: backup-bandwidth-type

Attribute Type: enum (best-effort|dedicated)

Default Value: best-effort

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <bypass-trunks>
      <bypass-trunk>
        <bypass-name>BYPASSNAME</bypass-name>
        <config>
          <bypass-name>BYPASSNAME</bypass-name>
        </config>
        <backup-bandwidth-type>best-effort</backup-bandwidth-type> <!--
operation="delete"-->
      </bypass-trunk>
    </bypass-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
backup-bw-type (best-effort|dedicated)
```

Configure disable route record

Use this attribute to enable recording of the route taken by Path and Reservation Request (Resv) messages. These messages confirm the establishment of reservations and also identifies errors. Routes are recorded by means of the Route Record Object (RRO) in the RSVP message.

Attribute Name: disable-route-record

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <bypass-trunks>
      <bypass-trunk>
        <bypass-name>BYPASSNAME</bypass-name>
        <config>
          <bypass-name>BYPASSNAME</bypass-name>
        </config>
        <session>
          <config>
            </disable-route-record><!-- operation="delete"-->
          </config>
        </session>
      </bypass-trunk>
    </bypass-trunks>
```

```
</trunks>
</rsvp-te>
```

Command Syntax

```
no record
```

Configure enable reuse route record

Use this attribute to use the updated Route Record List as an Explicit Route (with all strict nodes) when a path message is sent out at the next refresh.

Attribute Name: enable-reuse-route-record

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<trunks>
<bypass-trunks>
<bypass-trunk>
  <bypass-name>BYPASSNAME</bypass-name>
  <config>
    <bypass-name>BYPASSNAME</bypass-name>
  </config>
</bypass-trunk>
</bypass-trunks>
</trunks>
</rsvp-te>
```

Command Syntax

```
reuse-route-record
```

Configure traffic type

Use this attribute to identify the traffic type for this RSVP Trunk/bypss/P2MP LSP's

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: traffic-type

Attribute Type: enum (controlled-load|guaranteed)

Default Value: controlled-load

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<trunks>
<bypass-trunks>
```



```

<bypass-trunk>
  <bypass-name>BYPASSNAME</bypass-name>
  <config>
    <bypass-name>BYPASSNAME</bypass-name>
  </config>
  <session>
    <config>
      <traffic-type>controlled-load</traffic-type> <!-- operation="delete"-->
    </config>
  </session>
</bypass-trunk>
</bypass-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
traffic (controlled-load|guaranteed)
```

Configure retry count

Use this attribute to specify a retry count for an RSVP Trunk.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: retry-count

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <bypass-trunks>
      <bypass-trunk>
        <bypass-name>BYPASSNAME</bypass-name>
        <config>
          <bypass-name>BYPASSNAME</bypass-name>
        </config>
        <session>
          <config>
            <retry-count>1</retry-count> <!-- operation="delete"-->
          </config>
        </session>
      </bypass-trunk>
    </bypass-trunks>
  </trunks>
</rsvp-te>

```

Command Syntax

```
retry-limit <1-65535>
```

Configure retry interval

Use this attribute to specify a retry interval for an RSVP Trunk. When an ingress node tries to configure an LSP and the setup fails due to the receipt of a Path Error message, the system waits for the time configured with this command, before retrying the LSP setup process

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: retry-interval

Attribute Type: uint16

Default Value: 30

Attribute Range: 1-600

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <bypass-trunks>
      <bypass-trunk>
        <bypass-name>BYPASSNAME</bypass-name>
        <config>
          <bypass-name>BYPASSNAME</bypass-name>
        </config>
      </bypass-trunk>
    </bypass-trunks>
  </trunks>
  <session>
    <config>
      <retry-interval>1</retry-interval> <!-- operation="delete"-->
    </config>
  </session>
</rsvp-te>
```

Command Syntax

```
retry-timer <1-600>
```

Configure cspf retry count

Use this attribute to specify the number of retries that CSPF should carry out for a request received from RSVP.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: cspf-retry-count

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <bypass-trunks>
      <bypass-trunk>
```

```

    <bypass-name>BYPASSNAME</bypass-name>
  <config>
    <bypass-name>BYPASSNAME</bypass-name>
  </config>
</session>
<config>
  <cspf-retry-count>1</cspf-retry-count> <!-- operation="delete"-->
</config>
</session>
</bypass-trunk>
</bypass-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
cspf-retry-limit <1-65535>
```

Configure cspf retry interval

Use this attribute to specify the time between each retry that CSPF might carry out for a request received from RSVP.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: cspf-retry-interval

Attribute Type: uint16

Default Value: 30

Attribute Range: 1-600

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
  <bypass-trunks>
  <bypass-trunk>
    <bypass-name>BYPASSNAME</bypass-name>
    <config>
      <bypass-name>BYPASSNAME</bypass-name>
    </config>
  </bypass-trunk>
  </bypass-trunks>
  </trunks>
  <config>
    <cspf-retry-interval>1</cspf-retry-interval> <!-- operation="delete"-->
  </config>
</rsvp-te>

```

Command Syntax

```
cspf-retry-timer <1-600>
```

Configure exclude addr

Use this attribute to exclude an address link or address node from the LSP creation of the Bypass Tunnel.

Attribute Name: exclude-addr

Attribute Type: inet:ipv4-address

Attribute Name: exclude-type

Attribute Type: enum (link|node)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <bypass-trunks>
      <bypass-trunk>
        <bypass-name>BYPASSNAME</bypass-name>
        <config>
          <bypass-name>BYPASSNAME</bypass-name>
        </config>
        <session>
          <exclude-path>
            <config>
              <exclude-type>node</exclude-type>
              <exclude-addr>A.B.C.D</exclude-addr>
            </config>
          </exclude-path>
        </session>
      </bypass-trunk>
    </bypass-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
exclude-address (link|node) A.B.C.D
```

Configure bandwidth

Use this attribute to reserve the primary/secondary bandwidth in bits per second for the current trunk.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: bandwidth

Attribute Type: string

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <bypass-trunks>
      <bypass-trunk>
        <bypass-name>BYPASSNAME</bypass-name>
        <config>
```

```

    <bypass-name>BYPASSNAME</bypass-name>
  </config>
</session>
<path-state-block>
<config>
    <bandwidth>BANDWIDTH</bandwidth> <!-- operation="delete"-->
  </config>
</path-state-block>
</session>
</bypass-trunk>
</bypass-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
bandwidth BANDWIDTH
```

Configure enable label record

Use this attribute to record all labels exchanged between RSVP-enabled routers during the reservation setup process

Attribute Name: enable-label-record

Attribute Type: uint8

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
  <bypass-trunks>
  <bypass-trunk>
    <bypass-name>BYPASSNAME</bypass-name>
    <config>
      <bypass-name>BYPASSNAME</bypass-name>
    </config>
  </bypass-trunk>
  </bypass-trunks>
  </trunks>
  <session-attributes>
  <config>
    </enable-label-record><!-- operation="delete"-->
  </config>
</session-attributes>
</path-state-block>
</session>
</bypass-trunk>
</bypass-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
label-record
```

Configure hold priority

Use this attribute to configure the hold priority value for the selected trunk.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: hold-priority

Attribute Type: uint8

Default Value: 0

Attribute Range: 0-7

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <bypass-trunks>
      <bypass-trunk>
        <bypass-name>BYPASSNAME</bypass-name>
        <config>
          <bypass-name>BYPASSNAME</bypass-name>
        </config>
      </bypass-trunk>
    </bypass-trunks>
  </trunks>
  <session>
    <path-state-block>
      <session-attributes>
        <config>
          <hold-priority>0</hold-priority> <!-- operation="delete"-->
        </config>
      </session-attributes>
    </path-state-block>
  </session>
</rsvp-te>
```

Command Syntax

```
hold-priority <0-7>
```

Configure setup priority

Use this attribute to configure the setup priority value for the selected trunk

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: setup-priority

Attribute Type: uint8

Default Value: 7

Attribute Range: 0-7

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
```

```

<trunks>
<bypass-trunks>
<bypass-trunk>
  <bypass-name>BYPASSNAME</bypass-name>
  <config>
    <bypass-name>BYPASSNAME</bypass-name>
  </config>
  <session>
  <path-state-block>
  <session-attributes>
  <config>
    <setup-priority>0</setup-priority> <!-- operation="delete"-->
  </config>
</session-attributes>
</path-state-block>
</session>
</bypass-trunk>
</bypass-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
setup-priority <0-7>
```

Configure hop limit

Use this attribute to specify a limit of hops for an RSVP trunk. Hop-limit data is sent to the CSPF server if CSPF is used.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: hop-limit

Attribute Type: uint16

Default Value: 255

Attribute Range: 1-255

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<trunks>
<bypass-trunks>
<bypass-trunk>
  <bypass-name>BYPASSNAME</bypass-name>
  <config>
    <bypass-name>BYPASSNAME</bypass-name>
  </config>
  <session>
  <path-state-block>
  <session-attributes>
  <config>
    <hop-limit>1</hop-limit> <!-- operation="delete"-->
  </config>

```

```
</session-attributes>  
</path-state-block>  
</session>  
</bypass-trunk>  
</bypass-trunks>  
</trunks>  
</rsvp-te>
```

Command Syntax

```
hop-limit <1-255>
```

Configure filter type

Use this attribute to set the filter to fixed or shared filter style for RSVP trunk.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: filter-type

Attribute Type: enum (fixed|shared-explicit)

Default Value: shared-explicit

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">  
<trunks>  
<bypass-trunks>  
<bypass-trunk>  
  <bypass-name>BYPASSNAME</bypass-name>  
  <config>  
    <bypass-name>BYPASSNAME</bypass-name>  
  </config>  
<session>  
<path-state-block>  
<session-attributes>  
<config>  
  <filter-type>shared-explicit</filter-type> <!-- operation="delete"-->  
</config>  
</session-attributes>  
</path-state-block>  
</session>  
</bypass-trunk>  
</bypass-trunks>  
</trunks>  
</rsvp-te>
```

Command Syntax

```
filter (fixed)
```

Configure dscp exp map exp val

```
rsvp trunk dsinfo exp val
```


Attribute Name: dscp-exp-map-exp-val

Attribute Type: int32

Attribute Range: 0-7

Attribute Name: dscp-exp-map-class-name

Attribute Type: string

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <bypass-trunks>
      <bypass-trunk>
        <bypass-name>BYPASSNAME</bypass-name>
        <config>
          <bypass-name>BYPASSNAME</bypass-name>
        </config>
      <session>
        <diff-serv-info>
          <dscp-exp-maps>
            <dscp-exp-map>
              <dscp-exp-map-exp-val>0</dscp-exp-map-exp-val>
              <config>
                <dscp-exp-map-exp-val>0</dscp-exp-map-exp-val>
                <dscp-exp-map-class-name>CLASS</dscp-exp-map-class-name>
              </config>
            </dscp-exp-map>
          </dscp-exp-maps>
        </diff-serv-info>
      </session>
    </bypass-trunk>
  </bypass-trunks>
</trunks>
</rsvp-te>
```

Command Syntax

```
class-to-exp-bit (CLASS|<0-7>) <0-7>
```

Configure trunk name

rsvp trunk name

Attribute Name: trunk-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: trunk-family

Attribute Type: enum (gmpls|ipv4)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
          <trunk-family>ipv4</trunk-family>
        </config>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
rsvp-trunk TRUNKNAME (gmpls|ipv4|)
```

Configure enable igp shortcut

Use this attribute to enable Interior Gateway Protocol (IGP) Shortcut. With IGP Shortcut, link-state IGP's calculate IP routes to forward traffic over tunnels configured by TE.

Attribute Name: enable-igp-shortcut

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        </enable-igp-shortcut><!-- operation="delete"-->
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
enable-igp-shortcut
```

Configure enable reoptimize

Use this attribute to enable the reoptimization for the RSVP Trunk

Attribute Name: enable-reoptimize

Attribute Type: uint8

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        </enable-reoptimize><!-- operation="delete"-->
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>

```

Command Syntax

```
reoptimize
```

Configure multipath group

Use this attribute to configure a multipath group name for the RSVP Trunk

Attribute Name: multipath-group

Attribute Type: string

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
          <multipath-group>GROUPNAME</multipath-group> <!-- operation="delete"-->
        </config>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>

```

Command Syntax

```
multipath-group GROUPNAME
```

Configure absolute metric

Use this attribute to set LSP absolute metric metric for IGP Shortcut use

Attribute Name: absolute-metric

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <absolute-metric>1</absolute-metric> <!-- operation="delete"-->
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
lsp-metric absolute-metric <1-65535>
```

Configure relative metric

Use this attribute to set LSP relative metric metric for IGP Shortcut use

Attribute Name: relative-metric

Attribute Type: int32

Attribute Range: -65535-0,1-65535

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <relative-metric>-65535</relative-metric> <!-- operation="delete"-->
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
lsp-metric relative (<-65535-0>|<1-65535>)
```

Configure revert timer

Use this attribute configure the Hold-on timer before revert back to RSVP session

Attribute Name: revert-timer

Attribute Type: uint32

Default Value: 60

Attribute Range: 1-65535

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <revert-timer>1</revert-timer> <!-- operation="delete"-->
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
revert-timer <1-65535>
```

Configure trunk color

Use this attribute to configure color for RSVP Trunk

Attribute Name: trunk-color

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
          <trunk-color>1</trunk-color> <!-- operation="delete"-->
        </config>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
trunk-color-code <1-4294967295>
```

Configure bsid value

Use this attribute to configure static binding segment identifier value

Attribute Name: bsid-value

Attribute Type: uint32

Attribute Range: 16-15999

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <bsid-value>16</bsid-value> <!-- operation="delete"-->
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
binding-sid mpls label <16-15999>
```

Configure switching capability

Use this attribute to configure a switching capability for the RSVP Trunk

This command is supported when following feature are enabled gmppls feature

Attribute Name: switching-capability

Attribute Type: enum (psc-1|psc-2|psc-3|psc-4)

Default Value: psc-1

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <gmppls>
          <config>
            <switching-capability>psc-1</switching-capability> <!--
operation="delete"-->
          </config>
        </gmppls>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

```

</gmpls>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
capability (psc-1|psc-2|psc-3|psc-4)
```

Configure direction

Use this attribute to configure a direction for the RSVP Trunk

This command is supported when following feature are enabled gmpls feature

Attribute Name: direction

Attribute Type: enum (unidirectional|bidirectional)

Default Value: unidirectional

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <gmpls>
          <config>
            <direction>unidirectional</direction> <!-- operation="delete"-->
          </config>
        </gmpls>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>

```

Command Syntax

```
direction (unidirectional|bidirectional)
```

Configure generalized pid

Use this attribute to configure a generalized PID for the RSVP Trunk

This command is supported when following feature are enabled gmpls feature

Attribute Name: generalized-pid

Attribute Type: enum (ethernet|ipv4)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <gmpls>
          <config>
            <generalized-pid>ethernet</generalized-pid> <!-- operation="delete"-->
          </config>
        </gmpls>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
gpid (ethernet|ipv4)
```

Configure path option dynamic

Use the attribute to enable Tunnel to get ERO from Path Computation Element

This command is supported when following feature are enabled gmpls feature

Attribute Name: path-option-dynamic

Attribute Type: enum (pce)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <path-computation-element>
          <config>
            <path-option-dynamic>pce</path-option-dynamic> <!-- operation="delete"-->
          </config>
        </path-computation-element>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
path-option dynamic (pce)
```

Configure pce entity identifier

Use this attribute to assign PCE Entity ID for the tunnel

This command is supported when following feature are enabled gmpls feature

Attribute Name: pce-entity-identifier

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <path-computation-element>
          <config>
            <pce-entity-identifier>1</pce-entity-identifier> <!-- operation="delete"-
->
          </config>
        </path-computation-element>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
pce entity <1-255>
```

Configure pce state report

Use this attribute to enable or disable lsp state report to PCE

This command is supported when following feature are enabled gmpls feature

Attribute Name: pce-state-report

Attribute Type: empty

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
```

```
<config>
  <trunk-name>TRUNKNAME</trunk-name>
</config>
<path-computation-element>
<config>
  </pce-state-report><!-- operation="delete"-->
</config>
</path-computation-element>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>
```

Command Syntax

```
pce state-report
```

Configure pce lsp delegate

Use this attribute to enable or disable lsp delegation to PCE

This command is supported when following feature are enabled gmpls feature

Attribute Name: pce-lsp-delegate

Attribute Type: empty

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<trunks>
<ingress-trunks>
<ingress-trunk>
  <trunk-name>TRUNKNAME</trunk-name>
  <config>
    <trunk-name>TRUNKNAME</trunk-name>
  </config>
  <path-computation-element>
  <config>
    </pce-lsp-delegate><!-- operation="delete"-->
  </config>
</path-computation-element>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>
```

Command Syntax

```
pce lsp-delegate
```

Configure address

rsvp trunk ipv4 map route address

Attribute Name: address

Attribute Type: string

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <mapped-ip-routes>
          <mapped-ip-route>
            <address>A.B.C.D/M</address>
            <config>
              <address>A.B.C.D/M|A.B.C.D A.B.C.D</address>
            </config>
          </mapped-ip-route>
        </mapped-ip-routes>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
map-route (A.B.C.D/M|A.B.C.D A.B.C.D)
```

Configure dst addr

rsvp trunk map route address

Attribute Name: dst-addr

Attribute Type: string

Attribute Name: name

Attribute Type: string

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <mapped-prefix-class-routes>
          <mapped-prefix-class-route>
            <dst-addr>A.B.C.D/M</dst-addr>
          </mapped-prefix-class-route>
        </mapped-prefix-class-routes>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

```
    <config>
      <dst-addr>A.B.C.D/M</dst-addr>
      <name>CLASS</name>
    </config>
  </mapped-prefix-class-route>
</mapped-prefix-class-routes>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>
```

Command Syntax

```
map-route (A.B.C.D/M|A.B.C.D A.B.C.D) CLASS
```

Configure priority value

Use this attribute to configure the secondary priorities of the RSVP Trunk.

Attribute Name: priority-value

Attribute Type: int32

Attribute Range: 1-5

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <secondary-priorities>
          <secondary-priority> <!-- operation="delete"-->
            <priority-value>1</priority-value>
            <config>
              <priority-value>1</priority-value>
            </config>
          </secondary-priority>
        </secondary-priorities>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
secondary-priority <1-5>
```

Configure priority path

Use this attribute to configure the secondary priority path for the RSVP Trunk.

Attribute Name: priority-path

Attribute Type: string

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <secondary-priorities>
          <secondary-priority>
            <priority-value>1</priority-value>
            <config>
              <priority-value>1</priority-value>
            </config>
            <priority-path>PATHNAME</priority-path> <!-- operation="delete"-->
          </secondary-priority>
        </secondary-priorities>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
secondary-priority <1-5> path PATHNAME
```

Configure secondary priority srlg disjoint

Use this attribute to configure the SRLG disjoint path for the RSVP Trunk.

Attribute Name: secondary-priority-srlg-disjoint

Attribute Type: enum (forced|preferred)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <secondary-priorities>
```

```
<secondary-priority>
  <priority-value>1</priority-value>
  <config>
    <priority-value>1</priority-value>
  </config>
  <secondary-priority-srlg-disjoint>forced</secondary-priority-srlg-
disjoint> <!-- operation="delete"-->
</secondary-priority>
</secondary-priorities>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>
```

Command Syntax

```
secondary-priority <1-5> srlg-disjoint (forced|preferred)
```

Configure end label range

Use this attribute to configure the gmpls label set end label

This command is supported when following feature are enabled gmpls feature

Attribute Name: end-label-range

Attribute Type: int32

Attribute Range: 16-1048575

Attribute Name: action-type

Attribute Type: boolean

Attribute Name: start-label-range

Attribute Type: int32

Attribute Range: 16-1048575

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <gmpls-label-set>
          <config>
            <action-type>>true</action-type>
            <start-label-range>16</start-label-range>
            <end-label-range>16</end-label-range>
          </config>
        </gmpls-label-set>
      </ingress-trunk>
```

```

</ingress-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
gmpls-label-set (packet|) range <16-1048575> <16-1048575>
```

Configure enable node protection

Use this attribute to configure fast-reroute node-protection

Attribute Name: enable-node-protection

Attribute Type: uint8

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<trunks>
<ingress-trunks>
<ingress-trunk>
  <trunk-name>TRUNKNAME</trunk-name>
  <config>
    <trunk-name>TRUNKNAME</trunk-name>
  </config>
  <sessions>
  <fast-reroute>
  <config>
    </enable-node-protection><!-- operation="delete"-->
  </config>
</fast-reroute>
</sessions>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
(primary) fast-reroute node-protection
```

Configure protection

Use this attribute to create an Fast Reroute backup and to set an LSP one-to-one protection mechanism. This command can also be used to create an FRR Facility (Bypass) backup and assign a Facility Backup (Bypass Tunnel) available to the protected LSP.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: protection

Attribute Type: enum (one-to-one|facility)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
```

```
<trunks>
<ingress-trunks>
<ingress-trunk>
  <trunk-name>TRUNKNAME</trunk-name>
  <config>
    <trunk-name>TRUNKNAME</trunk-name>
  </config>
  <sessions>
  <fast-reroute>
  <config>
    <protection>one-to-one</protection> <!-- operation="delete"-->
  </config>
</fast-reroute>
</sessions>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>
```

Command Syntax

(primary) fast-reroute protection (one-to-one|facility)

Configure frr hold priority

Use this attribute to configure the hold priority value for the selected trunk.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: frr-hold-priority

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-7

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<trunks>
<ingress-trunks>
<ingress-trunk>
  <trunk-name>TRUNKNAME</trunk-name>
  <config>
    <trunk-name>TRUNKNAME</trunk-name>
  </config>
  <sessions>
  <fast-reroute>
  <config>
    <frr-hold-priority>0</frr-hold-priority> <!-- operation="delete"-->
  </config>
</fast-reroute>
</sessions>
</ingress-trunk>
```



```

</ingress-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
(primary) fast-reroute hold-priority <0-7>
```

Configure frr setup priority

Use this attribute to configure the setup priority value for the selected trunk

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: frr-setup-priority

Attribute Type: uint32

Default Value: 7

Attribute Range: 0-7

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<trunks>
<ingress-trunks>
<ingress-trunk>
  <trunk-name>TRUNKNAME</trunk-name>
  <config>
    <trunk-name>TRUNKNAME</trunk-name>
  </config>
  <sessions>
  <fast-reroute>
  <config>
    <frr-setup-priority>0</frr-setup-priority> <!-- operation="delete"-->
  </config>
</fast-reroute>
</sessions>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
(primary) fast-reroute setup-priority <0-7>
```

Configure frr hop limit

Use this attribute to specify a limit of hops for an RSVP trunk. Hop-limit data is sent to the CSPF server if CSPF is used.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: frr-hop-limit

Attribute Type: uint32

Default Value: 255

Attribute Range: 1-255

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <sessions>
          <fast-reroute>
            <config>
              <frr-hop-limit>1</frr-hop-limit> <!-- operation="delete"-->
            </config>
          </fast-reroute>
        </sessions>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
(primary) fast-reroute hop-limit <1-255>
```

Configure fast reroute bandwidth

Use this attribute to reserve the primary/secondary bandwidth in bits per second for the current trunk.

This command is supported when following feature are enabled MPLS-FRR feature

Attribute Name: fast-reroute-bandwidth

Attribute Type: string

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <sessions>
          <fast-reroute>
            <config>
              <fast-reroute-bandwidth>BANDWIDTH</fast-reroute-bandwidth> <!--
operation="delete"-->
```

```

    </config>
  </fast-reroute>
</sessions>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
(primary) fast-reroute bandwidth BANDWIDTH
```

Configure admin group name

rsvp admin group name

Attribute Name: admin-group-name

Attribute Type: string

Attribute Name: admin-group-type

Attribute Type: enum (exclude-any|include-any)

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
  <fast-reroute>
    <frr-admin-groups>
      <frr-admin-group>
        <admin-group-name>ADMIN-GROUP-NAME</admin-group-name>
        <config>
          <admin-group-name>ADMIN-GROUP-NAME</admin-group-name>
          <admin-group-type>exclude-any</admin-group-type>
        </config>
      </frr-admin-group>
    </frr-admin-groups>
  </fast-reroute>
</rsvp-te>

```

Command Syntax

```
(primary) fast-reroute (exclude-any|include-any) ADMIN-GROUP-NAME
```

Configure srlg disjoint secondary

Use this attribute to enable secondary srlg disjoint

This command is supported when following feature are enabled Shared Risk Link Group

Attribute Name: srlg-disjoint-secondary

Attribute Type: enum (forced|preferred)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <sessions>
          <srlg>
            <config>
              <srlg-disjoint-secondary>forced</srlg-disjoint-secondary> <!--
operation="delete"-->
            </config>
          </srlg>
        </sessions>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
(secondary) srlg-disjoint (forced|preferred)
```

Configure trunk session type

rsvp trunk session type

Attribute Name: trunk-session-type

Attribute Type: enum (secondary|primary)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <sessions>
```

```

<session> <!-- operation="delete"-->
  <trunk-session-type>secondary</trunk-session-type>
  <config>
    <trunk-session-type>secondary</trunk-session-type>
  </config>
</session>
</sessions>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

(secondary)

Configure disable affinity

Use this attribute to enable sending of session attribute objects with resource affinity data.

Attribute Name: disable-affinity

Attribute Type: uint8

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
      </ingress-trunk>
    </ingress-trunks>
    <session>
      <trunk-session-type>secondary</trunk-session-type>
      <config>
        <trunk-session-type>secondary</trunk-session-type>
      </config>
      </disable-affinity><!-- operation="delete"-->
    </session>
  </trunks>
</rsvp-te>

```

Command Syntax

no (secondary|primary) affinity

Configure disable cspf

Use this attribute to enable the use of Constrained Shortest Path First (CSPF) server for an explicit route to the egress, or all RSVP sessions. When CSPF is turned off globally, it cannot be enabled for any LSP.

Attribute Name: disable-cspf

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
      <sessions>
        <session>
          <trunk-session-type>secondary</trunk-session-type>
          <config>
            <trunk-session-type>secondary</trunk-session-type>
          </config>
          </disable-cspf><!-- operation="delete"-->
        </session>
      </sessions>
    </ingress-trunk>
  </ingress-trunks>
</trunks>
</rsvp-te>
```

Command Syntax

```
no (secondary|primary) cspf
```

Configure enable local protection

Use this attribute to enable the local repair of explicit routes for which this router is a transit node.

Attribute Name: enable-local-protection

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

```

<sessions>
  <session>
    <trunk-session-type>secondary</trunk-session-type>
    <config>
      <trunk-session-type>secondary</trunk-session-type>
    </config>
    </enable-local-protection><!-- operation="delete"-->
  </session>
</sessions>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

(secondary|primary) local-protection

Configure name

rsvp admin group name

Attribute Name: name

Attribute Type: string

Attribute Name: type

Attribute Type: enum (exclude-any|include-any|include-all)

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
  <sessions>
    <session>
      <trunk-session-type>secondary</trunk-session-type>
      <config>
        <trunk-session-type>secondary</trunk-session-type>
      </config>
      <admin-groups>
        <admin-group>
          <name>ADMIN-GROUP-NAME</name>
          <config>
            <name>ADMIN-GROUP-NAME</name>
            <type>exclude-any</type>
          </config>
        </admin-group>
      </admin-groups>
    </session>
  </sessions>
</rsvp-te>

```

```
    </admin-groups>
</session>
</sessions>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>
```

Command Syntax

(secondary|primary) (exclude-any|include-any|include-all) ADMIN-GROUP-NAME

Configure link protection

Use this attribute to configure the gmpls link-protection for the RSVP Trunk

Attribute Name: link-protection

Attribute Type: enum (extra-traffic|unprotected|shared|dedicated-one-to-one|dedicated-one-plus-one|enhanced)

Default Value: unprotected

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<trunks>
<ingress-trunks>
<ingress-trunk>
  <trunk-name>TRUNKNAME</trunk-name>
  <config>
    <trunk-name>TRUNKNAME</trunk-name>
  </config>
<sessions>
<session>
  <trunk-session-type>secondary</trunk-session-type>
  <config>
    <trunk-session-type>secondary</trunk-session-type>
  </config>
  <gmpls-attributes>
  <config>
    <link-protection>unprotected</link-protection> <!--
operation="delete"-->
  </config>
  </gmpls-attributes>
</session>
</sessions>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>
```

Command Syntax

(secondary|primary) protection (extra-traffic|unprotected|shared|dedicated-one-to-one|dedicated-one-plus-one|enhanced)

Configure forward label value

Use this attribute to configure the explicit label supported for an LSP.

Attribute Name: forward-label-value

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: forward-direction

Attribute Type: enum (forward|packet forward)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <sessions>
          <session>
            <trunk-session-type>secondary</trunk-session-type>
            <config>
              <trunk-session-type>secondary</trunk-session-type>
            </config>
            <gmpls-attributes>
              <explicit-forward>
                <forward-label-value>16</forward-label-value>
                <config>
                  <forward-label-value>16</forward-label-value>
                  <forward-direction>forward</forward-direction>
                </config>
              </explicit-forward>
            </gmpls-attributes>
          </session>
        </sessions>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
(secondary|primary) explicit-label <16-1048575> (forward|packet forward)
```

Configure reverse label value

Use this attribute to configure the explicit label supported for an LSP.

Attribute Name: reverse-label-value

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: reverse-direction

Attribute Type: enum (reverse|packet reverse)

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <sessions>
          <session>
            <trunk-session-type>secondary</trunk-session-type>
            <config>
              <trunk-session-type>secondary</trunk-session-type>
            </config>
            <gmpls-attributes>
              <explicit-reverse>
                <reverse-label-value>16</reverse-label-value>
                <config>
                  <reverse-label-value>16</reverse-label-value>
                  <reverse-direction>reverse</reverse-direction>
                </config>
              </explicit-reverse>
            </gmpls-attributes>
          </session>
        </sessions>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

(secondary|primary) explicit-label <16-1048575> (reverse|packet reverse)

Configure dscp exp map class name

rsvp trunk dsinfo exp val

Attribute Name: dscp-exp-map-exp-val

Attribute Type: int32

Attribute Range: 0-7

Attribute Name: dscp-exp-map-class-name

Attribute Type: string

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <sessions>
          <session>
            <trunk-session-type>secondary</trunk-session-type>
            <config>
              <trunk-session-type>secondary</trunk-session-type>
            </config>
            <diff-serv-info>
              <dscp-exp-maps>
                <dscp-exp-map>
                  <dscp-exp-map-exp-val>0</dscp-exp-map-exp-val>
                  <config>
                    <dscp-exp-map-exp-val>0</dscp-exp-map-exp-val>
                    <dscp-exp-map-class-name>CLASS</dscp-exp-map-class-name>
                  </config>
                </dscp-exp-map>
              </dscp-exp-maps>
            </diff-serv-info>
          </session>
        </sessions>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>

```

Command Syntax

```
(secondary|primary) class-to-exp-bit CLASS <0-7>
```

Configure elsp signal

Use this attribute to configure a primary Diff-Serv (Differentiated Services) explicitly signaled E-LSP (EXP-InferredPSC LSP) interface.

This command is supported when following feature are enabled diffserv feature

Attribute Name: elsp-signal

Attribute Type: empty

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>

```

```
<trunk-name>TRUNKNAME</trunk-name>
<config>
  <trunk-name>TRUNKNAME</trunk-name>
</config>
<sessions>
<session>
  <trunk-session-type>secondary</trunk-session-type>
  <config>
    <trunk-session-type>secondary</trunk-session-type>
  </config>
  <diff-serv-info>
  <elsp-class>
  <config>
    </elsp-signal><!-- operation="delete"-->
  </config>
  </elsp-class>
</diff-serv-info>
</session>
</sessions>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>
```

Command Syntax

(secondary|primary) elsp-sigaled

Configure elsp signal class1

Use this attribute to configure a primary Diff-Serv (Differentiated Services) explicitly signaled E-LSP (EXP-InferredPSC LSP) interface class1

This command is supported when following feature are enabled diffserv feature

Attribute Name: elsp-signal-class1

Attribute Type: string

Attribute Name: elsp-signal

Attribute Type: empty

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<trunks>
<ingress-trunks>
<ingress-trunk>
  <trunk-name>TRUNKNAME</trunk-name>
  <config>
    <trunk-name>TRUNKNAME</trunk-name>
  </config>
<sessions>
<session>
```

```

    <trunk-session-type>secondary</trunk-session-type>
  <config>
    <trunk-session-type>secondary</trunk-session-type>
  </config>
  <diff-serv-info>
    <elsp-class>
      <config>
        </elsp-signal><!-- operation="delete"-->
        <elsp-signal-class1>CLASS1</elsp-signal-class1> <!--
operation="delete"-->
      </config>
    </elsp-class>
  </diff-serv-info>
</session>
</sessions>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
(secondary|primary) elsp-signaled CLASS1
```

Configure elsp signal class2

Use this attribute to configure a primary Diff-Serv (Differentiated Services) explicitly signaled E-LSP (EXP-InferredPSC LSP) interface class2

This command is supported when following feature are enabled diffserv feature

Attribute Name: elsp-signal-class2

Attribute Type: string

Attribute Name: elsp-signal

Attribute Type: empty

Attribute Name: elsp-signal-class1

Attribute Type: string

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
      <sessions>
        <session>
          <trunk-session-type>secondary</trunk-session-type>

```

```
<config>
  <trunk-session-type>secondary</trunk-session-type>
</config>
<diff-serv-info>
  <elsp-class>
    <config>
      </elsp-signal><!-- operation="delete"-->
      <elsp-signal-class1>CLASS1</elsp-signal-class1> <!--
operation="delete"-->
      <elsp-signal-class2>CLASS2</elsp-signal-class2> <!--
operation="delete"-->
    </config>
  </elsp-class>
</diff-serv-info>
</session>
</sessions>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>
```

Command Syntax

```
(secondary|primary) elsp-signalized CLASS1 CLASS2
```

Configure elsp signal class3

Use this attribute to configure a primary Diff-Serv (Differentiated Services) explicitly signaled E-LSP (EXP-InferredPSC LSP) interface class3

This command is supported when following feature are enabled diffserv feature

Attribute Name: elsp-signal-class3

Attribute Type: string

Attribute Name: elsp-signal

Attribute Type: empty

Attribute Name: elsp-signal-class1

Attribute Type: string

Attribute Name: elsp-signal-class2

Attribute Type: string

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

```

<sessions>
  <session>
    <trunk-session-type>secondary</trunk-session-type>
    <config>
      <trunk-session-type>secondary</trunk-session-type>
    </config>
    <diff-serv-info>
      <elsp-class>
        <config>
          </elsp-signal><!-- operation="delete"-->
          <elsp-signal-class1>CLASS1</elsp-signal-class1> <!--
operation="delete"-->
          <elsp-signal-class2>CLASS2</elsp-signal-class2> <!--
operation="delete"-->
          <elsp-signal-class3>CLASS3</elsp-signal-class3> <!--
operation="delete"-->
        </config>
      </elsp-class>
    </diff-serv-info>
  </session>
</sessions>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
(secondary|primary) elsp-signal CLASS1 CLASS2 CLASS3
```

Configure elsp signal class4

Use this attribute to configure a primary Diff-Serv (Differentiated Services) explicitly signaled E-LSP (EXP-InferredPSC LSP) interface class4

This command is supported when following feature are enabled diffserv feature

Attribute Name: elsp-signal-class4

Attribute Type: string

Attribute Name: elsp-signal

Attribute Type: empty

Attribute Name: elsp-signal-class1

Attribute Type: string

Attribute Name: elsp-signal-class2

Attribute Type: string

Attribute Name: elsp-signal-class3

Attribute Type: string

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <sessions>
          <session>
            <trunk-session-type>secondary</trunk-session-type>
            <config>
              <trunk-session-type>secondary</trunk-session-type>
            </config>
            <diff-serv-info>
              <elsp-class>
                <config>
                  </elsp-signal><!-- operation="delete"-->
                    <elsp-signal-class1>CLASS1</elsp-signal-class1> <!--
operation="delete"-->
                    <elsp-signal-class2>CLASS2</elsp-signal-class2> <!--
operation="delete"-->
                    <elsp-signal-class3>CLASS3</elsp-signal-class3> <!--
operation="delete"-->
                    <elsp-signal-class4>CLASS4</elsp-signal-class4> <!--
operation="delete"-->
                </config>
              </elsp-class>
            </diff-serv-info>
          </session>
        </sessions>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>

```

Command Syntax

```
(secondary|primary) elsp-sigaled CLASS1 CLASS2 CLASS3 CLASS4
```

Configure elsp signal class5

Use this attribute to configure a primary Diff-Serv (Differentiated Services) explicitly signaled E-LSP (EXP-InferredPSC LSP) interface class5

This command is supported when following feature are enabled diffserv feature

Attribute Name: elsp-signal-class5

Attribute Type: string

Attribute Name: elsp-signal

Attribute Type: empty

Attribute Name: elsp-signal-class1

Attribute Type: string

Attribute Name: elsp-signal-class2

Attribute Type: string

Attribute Name: elsp-signal-class3

Attribute Type: string

Attribute Name: elsp-signal-class4

Attribute Type: string

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <sessions>
          <session>
            <trunk-session-type>secondary</trunk-session-type>
            <config>
              <trunk-session-type>secondary</trunk-session-type>
            </config>
            <diff-serv-info>
              <elsp-class>
                <config>
                  </elsp-signal><!-- operation="delete"-->
                  <elsp-signal-class1>CLASS1</elsp-signal-class1> <!--
operation="delete"-->
                  <elsp-signal-class2>CLASS2</elsp-signal-class2> <!--
operation="delete"-->
                  <elsp-signal-class3>CLASS3</elsp-signal-class3> <!--
operation="delete"-->
                  <elsp-signal-class4>CLASS4</elsp-signal-class4> <!--
operation="delete"-->
                  <elsp-signal-class5>CLASS5</elsp-signal-class5> <!--
operation="delete"-->
                </config>
              </elsp-class>
            </diff-serv-info>
          </session>
        </sessions>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>
```

Command Syntax

```
(secondary|primary) elsp-sigaled CLASS1 CLASS2 CLASS3 CLASS4 CLASS5
```

Configure elsp signal class6

Use this attribute to configure a primary Diff-Serv (Differentiated Services) explicitly signaled E-LSP (EXP-InferredPSC LSP) interface class6

This command is supported when following feature are enabled diffserv feature

Attribute Name: elsp-signal-class6

Attribute Type: string

Attribute Name: elsp-signal

Attribute Type: empty

Attribute Name: elsp-signal-class1

Attribute Type: string

Attribute Name: elsp-signal-class2

Attribute Type: string

Attribute Name: elsp-signal-class3

Attribute Type: string

Attribute Name: elsp-signal-class4

Attribute Type: string

Attribute Name: elsp-signal-class5

Attribute Type: string

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <sessions>
          <session>
            <trunk-session-type>secondary</trunk-session-type>
            <config>
              <trunk-session-type>secondary</trunk-session-type>
            </config>
            <diff-serv-info>
              <elsp-class>
                <config>
                  </elsp-signal><!-- operation="delete"-->
                  <elsp-signal-class1>CLASS1</elsp-signal-class1> <!--
operation="delete"-->
```

```

        <elsp-signal-class2>CLASS2</elsp-signal-class2> <!--
operation="delete"-->
        <elsp-signal-class3>CLASS3</elsp-signal-class3> <!--
operation="delete"-->
        <elsp-signal-class4>CLASS4</elsp-signal-class4> <!--
operation="delete"-->
        <elsp-signal-class5>CLASS5</elsp-signal-class5> <!--
operation="delete"-->
        <elsp-signal-class6>CLASS6</elsp-signal-class6> <!--
operation="delete"-->
    </config>
</elsp-class>
</diff-serv-info>
</session>
</sessions>
</ingress-trunk>
</ingress-trunks>
</trunks>
</rsvp-te>

```

Command Syntax

```
(secondary|primary) elsp-signal CLASS1 CLASS2 CLASS3 CLASS4 CLASS5 CLASS6
```

Configure elsp signal class7

Use this attribute to configure a primary Diff-Serv (Differentiated Services) explicitly signaled E-LSP (EXP-InferredPSC LSP) interface class7

This command is supported when following feature are enabled diffserv feature

Attribute Name: elsp-signal-class7

Attribute Type: string

Attribute Name: elsp-signal

Attribute Type: empty

Attribute Name: elsp-signal-class1

Attribute Type: string

Attribute Name: elsp-signal-class2

Attribute Type: string

Attribute Name: elsp-signal-class3

Attribute Type: string

Attribute Name: elsp-signal-class4

Attribute Type: string

Attribute Name: elsp-signal-class5

Attribute Type: string

Attribute Name: elsp-signal-class6

Attribute Type: string

Netconf edit-config payload

```

<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunks>
    <ingress-trunks>
      <ingress-trunk>
        <trunk-name>TRUNKNAME</trunk-name>
        <config>
          <trunk-name>TRUNKNAME</trunk-name>
        </config>
        <sessions>
          <session>
            <trunk-session-type>secondary</trunk-session-type>
            <config>
              <trunk-session-type>secondary</trunk-session-type>
            </config>
            <diff-serv-info>
              <elsp-class>
                <config>
                  </elsp-signal><!-- operation="delete"-->
                  <elsp-signal-class1>CLASS1</elsp-signal-class1> <!--
operation="delete"-->
                  <elsp-signal-class2>CLASS2</elsp-signal-class2> <!--
operation="delete"-->
                  <elsp-signal-class3>CLASS3</elsp-signal-class3> <!--
operation="delete"-->
                  <elsp-signal-class4>CLASS4</elsp-signal-class4> <!--
operation="delete"-->
                  <elsp-signal-class5>CLASS5</elsp-signal-class5> <!--
operation="delete"-->
                  <elsp-signal-class6>CLASS6</elsp-signal-class6> <!--
operation="delete"-->
                  <elsp-signal-class7>CLASS7</elsp-signal-class7> <!--
operation="delete"-->
                </config>
              </elsp-class>
            </diff-serv-info>
          </session>
        </sessions>
      </ingress-trunk>
    </ingress-trunks>
  </trunks>
</rsvp-te>

```

Command Syntax

```
(secondary|primary) elsp-signaled CLASS1 CLASS2 CLASS3 CLASS4 CLASS5 CLASS6 CLASS7
```

clear rsvp session ***Netconf RPC payload**

```

<ipi-rsvp-trunk_clear-rsvp-session xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-rsvp"/>

```

Command Syntax

```
clear rsvp session *
```

clear rsvp trunk (TRUNKNAME|*)

Attribute Name: trunk-name

Attribute Type: string

Netconf RPC payload

```
<ipi-rsvp-trunk_clear-rsvp-trunk xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-rsvp">
  <trunk-name>TRUNKNAME</trunk-name>
</ipi-rsvp-trunk_clear-rsvp-trunk>
```

Command Syntax

```
clear rsvp trunk (TRUNKNAME|*)
```

clear rsvp trunk (TRUNKNAME|*) (primary)

Attribute Name: trunk-name

Attribute Type: string

Netconf RPC payload

```
<ipi-rsvp-trunk_clear-rsvp-primary-trunk xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-rsvp">
  <trunk-name>TRUNKNAME</trunk-name>
</ipi-rsvp-trunk_clear-rsvp-primary-trunk>
```

Command Syntax

```
clear rsvp trunk (TRUNKNAME|*) (primary)
```

clear rsvp trunk (TRUNKNAME|*) (secondary)

Attribute Name: trunk-name

Attribute Type: string

Netconf RPC payload

```
<ipi-rsvp-trunk_clear-rsvp-secondary-trunk xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-rsvp">
  <trunk-name>TRUNKNAME</trunk-name>
</ipi-rsvp-trunk_clear-rsvp-secondary-trunk>
```

Command Syntax

```
clear rsvp trunk (TRUNKNAME|*) (secondary)
```

clear rsvp trunk ingress (TRUNKNAME|*)

Attribute Name: trunk-name

Attribute Type: string

Netconf RPC payload

```
<ipi-rsvp-trunk_clear-rsvp-ingress-trunk xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunk-name>TRUNKNAME</trunk-name>
</ipi-rsvp-trunk_clear-rsvp-ingress-trunk>
```

Command Syntax

```
clear rsvp trunk ingress (TRUNKNAME|*)
```

clear rsvp trunk non-ingress (TRUNKNAME|*)

Attribute Name: trunk-name

Attribute Type: string

Netconf RPC payload

```
<ipi-rsvp-trunk_clear-rsvp-non-ingress-trunk xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunk-name>TRUNKNAME</trunk-name>
</ipi-rsvp-trunk_clear-rsvp-non-ingress-trunk>
```

Command Syntax

```
clear rsvp trunk non-ingress (TRUNKNAME|*)
```

rsvp-trunk TRUNKNAME force-reoptimize

Attribute Name: trunk-name

Attribute Type: string

Netconf RPC payload

```
<ipi-rsvp-trunk_rsvp-trunk-force-reoptimize-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunk-name>TRUNKNAME</trunk-name>
</ipi-rsvp-trunk_rsvp-trunk-force-reoptimize-on>
```

Command Syntax

```
rsvp-trunk TRUNKNAME force-reoptimize
```

rsvp-trunk TRUNKNAME force-switchover-secondary (off|on)

Attribute Name: trunk-name

Attribute Type: string

Attribute Name: action

Attribute Type: enum (off|on)

Netconf RPC payload

```
<ipi-rsvp-trunk_rsvp-trunk-force-switchover-secondary xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunk-name>TRUNKNAME</trunk-name>
  <action>off</action>
</ipi-rsvp-trunk_rsvp-trunk-force-switchover-secondary>
```

Command Syntax

```
rsvp-trunk TRUNKNAME force-switchover-secondary (off|on)
```

rsvp-trunk-restart

Attribute Name: trunk-name

Attribute Type: string

Netconf RPC payload

```
<ipi-rsvp-trunk_rsvp-trunk-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <trunk-name>WORD</trunk-name>
</ipi-rsvp-trunk_rsvp-trunk-restart>
```

Command Syntax

```
rsvp-trunk-restart
```

clear rsvp session TUNNEL-ID LSP-ID INGRESS EGRESS

Attribute Name: tunnel-id

Attribute Type: uint32

Attribute Name: lsp-id

Attribute Type: uint32

Attribute Name: ingress

Attribute Type: inet:ipv4-address

Attribute Name: egress

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<ipi-rsvp-trunk_rsvp-session-reset xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <tunnel-id>TUNNEL-ID</tunnel-id>
  <lsp-id>LSP-ID</lsp-id>
  <ingress>INGRESS</ingress>
  <egress>EGRESS</egress>
</ipi-rsvp-trunk_rsvp-session-reset>
```

Command Syntax

```
clear rsvp session TUNNEL-ID LSP-ID INGRESS EGRESS
```

IPI-RSVP-INTERFACE

Configure enable rsvp

Use this attribute to enable control adjacency to send and receive RSVP-TE control messages for MPLS and GMPLS

Attribute Name: enable-rsvp

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </enable-rsvp><!-- operation="delete"-->
    </interface>
  </interfaces>
</rsvp-te>
```

Command Syntax

```
enable-rsvp
```

Configure enable iana hello config

Enable the exchange of non IANA specific Hello messages

Attribute Name: enable-iana-hello-config

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </enable-iana-hello-config><!-- operation="delete"-->
    </interface>
  </interfaces>
</rsvp-te>
```

Command Syntax

```
rsvp non-IANA-hello
```

Configure disable refresh reduction

Use this attribute to enable refresh reduction capability advertisement for all interfaces

Attribute Name: disable-refresh-reduction

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <refresh-reduction>
        <config>
          </disable-refresh-reduction><!-- operation="delete"-->
        </config>
      </refresh-reduction>
    </interface>
  </interfaces>
</rsvp-te>
```

Command Syntax

```
no rsvp refresh-reduction
```

Configure enable message ack

Use this attribute to enable message acknowledgement for all messages being sent to neighbors that are known to support refresh reduction.

Attribute Name: enable-message-ack

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <refresh-reduction>
        <config>
          </enable-message-ack><!-- operation="delete"-->
        </config>
      </refresh-reduction>
    </interface>
  </interfaces>
```

```
</rsvp-te>
```

Command Syntax

```
rsvp message-ack
```

Configure ack wait timeout

Use this attribute to configure the acknowledgement wait timeout for all RSVP-TE neighbors

Attribute Name: ack-wait-timeout

Attribute Type: uint32

Default Value: 10

Attribute Range: 1-65535

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <refresh-reduction>
        <config>
          <ack-wait-timeout>1</ack-wait-timeout> <!-- operation="delete"-->
        </config>
      </refresh-reduction>
    </interface>
  </interfaces>
</rsvp-te>
```

Command Syntax

```
rsvp ack-wait-timeout <1-65535>
```

Configure refresh time

Use this attribute to configure RSVP refresh interval timer. The timer specifies the interval after which Path and/ or Reservation Request (Resv) messages will be sent out. The refresh time and keep multiplier are two interrelated timing parameters used to calculate the valid Reservation Lifetime for an LSP. Refresh time regulates the interval between Refresh messages which include Path and Reservation Request (Resv) messages. Refresh messages are sent periodically so that reservation does not timeout in the neighboring nodes. Each sender and receiver host sends Path and Resv messages, downstream and upstream respectively, along the paths.

Attribute Name: refresh-time

Attribute Type: uint16

Default Value: 30

Attribute Range: 1-65535

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <refresh-reduction>
  <config>
    <refresh-time>1</refresh-time> <!-- operation="delete"-->
  </config>
</refresh-reduction>
</interface>
</interfaces>
</rsvp-te>
```

Command Syntax

```
rsvp refresh-time <1-65535>
```

Configure keep multiplier

Use this attribute to configure the constant to be used to calculate a valid reservation lifetime for a Labeled Switched Path (LSP). The refresh time and keep multiplier are two interrelated timing parameters used to calculate the valid reservation lifetime for an LSP. The router sends refresh messages periodically so that the neighbors do not timeout

Attribute Name: keep-multiplier

Attribute Type: int32

Default Value: 3

Attribute Range: 1-255

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <refresh-reduction>
  <config>
    <keep-multiplier>1</keep-multiplier> <!-- operation="delete"-->
  </config>
</refresh-reduction>
</interface>
</interfaces>
</rsvp-te>
```

Command Syntax

```
rsvp keep-multiplier <1-255>
```

Configure enable hello receipt

Use this attribute to enable the receipt of Hello messages from peers.

Attribute Name: enable-hello-receipt

Attribute Type: uint8

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <hellos>
        <config>
          </enable-hello-receipt><!-- operation="delete"-->
        </config>
      </hellos>
    </interface>
  </interfaces>
</rsvp-te>
```

Command Syntax

```
rsvp hello-receipt
```

Configure hello interval

Use this attribute to set an interval between Hello packets.Used as a global command, this value is over-ridden by the hello-interval set on the interface (see rsvp hello-interval).For optimum performance, set this value no more than one-third of the hello-timeout value.

Attribute Name: hello-interval

Attribute Type: int32

Default Value: 2

Attribute Range: 1-65535

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
</rsvp-te>
```

```
<hellos>
<config>
  <hello-interval>1</hello-interval> <!-- operation="delete"-->
</config>
</hellos>
</interface>
</interfaces>
</rsvp-te>
```

Command Syntax

```
rsvp hello-interval <1-65535>
```

Configure hello timeout

Timeout for clearing up all sessions shared with a neighbor. If an LSR has not received a Hello message from a peer within the number of seconds set with this command, all sessions shared with this peer are reset. The hello-timeout determines how long an RSVP node waits for a hello message before declaring a neighbor to be down.

Attribute Name: hello-timeout

Attribute Type: int32

Default Value: 7

Attribute Range: 1-65535

Netconf edit-config payload

```
<rsvp-te xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-rsvp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <hellos>
  <config>
    <hello-timeout>1</hello-timeout> <!-- operation="delete"-->
  </config>
</hellos>
</interface>
</interfaces>
</rsvp-te>
```

Command Syntax

```
rsvp hello-timeout <1-65535>
```

IPI-MPLS

Configure name

Specify service template name

Attribute Name: name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <l2vpn>
    <customer-service-templates>
      <customer-service-template <!-- operation="delete"-->
        <name>NAME</name>
        <config>
          <name>WORD</name>
        </config>
      </customer-service-template>
    </customer-service-templates>
  </l2vpn>
</mpls>
```

Command Syntax

```
service-template NAME
```

Configure match all

Use this attribute to specify match criteria as match all

Attribute Name: match-all

Attribute Type: empty

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <l2vpn>
    <customer-service-templates>
      <customer-service-template>
        <name>NAME</name>
        <config>
          <name>WORD</name>
        </config>
        </match-all><!-- operation="delete"-->
      </customer-service-template>
    </customer-service-templates>
  </l2vpn>
</mpls>
```

Command Syntax

```
match all
```

Configure match single tag outer vlan range

Use this attribute to set match type with outer vlan value

Attribute Name: match-single-tag-outer-vlan-range

Attribute Type: string

Attribute Range: 1-4094

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <l2vpn>
    <customer-service-templates>
      <customer-service-template>
        <name>NAME</name>
        <config>
          <name>WORD</name>
        </config>
        <match-single-tag-outer-vlan-range>VLAN_RANGE2</match-single-tag-outer-vlan-
range> <!-- operation="delete"-->
      </customer-service-template>
    </customer-service-templates>
  </l2vpn>
</mpls>
```

Command Syntax

```
match outer-vlan VLAN_RANGE2
```

Configure match untagged

Use this attribute to specify match criteria as match untagged

Attribute Name: match-untagged

Attribute Type: empty

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <l2vpn>
    <customer-service-templates>
      <customer-service-template>
        <name>NAME</name>
        <config>
          <name>WORD</name>
        </config>
        </match-untagged><!-- operation="delete"-->
      </customer-service-template>
    </customer-service-templates>
  </l2vpn>
</mpls>
```

```
</l2vpn>  
</mpls>
```

Command Syntax

```
match untagged
```

Configure match inner vlan id

Specify inner vlan VID or range(VLAN ID 1-4094 or range: 2-5) for match double tag

Attribute Name: match-inner-vlan-id

Attribute Type: string

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">  
  <l2vpn>  
    <customer-service-templates>  
      <customer-service-template>  
        <name>NAME</name>  
        <config>  
          <name>WORD</name>  
        </config>  
      <double-tags>  
        <double-tag>  
          <match-outer-vlan-id>1</match-outer-vlan-id>  
          <config>  
            <match-outer-vlan-id>1</match-outer-vlan-id>  
            <match-inner-vlan-id>VLAN_RANGE2</match-inner-vlan-id> <!--  
operation="delete"-->  
          </double-tag>  
        </double-tags>  
      </customer-service-template>  
    </customer-service-templates>  
  </l2vpn>  
</mpls>
```

Command Syntax

```
match double-tag outer-vlan <1-4094> inner-vlan VLAN_RANGE2
```

Configure vlan action type

Specify rewrite ingress action type

Attribute Name: vlan-action-type

Attribute Type: enum (pop|push|translate)

Attribute Name: tag-protocol-identifier

Attribute Type: enum (dot1.q|dot1.ad|0x9100)

Netconf edit-config payload

```

<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
<l2vpn>
<customer-service-templates>
<customer-service-template>
  <name>NAME</name>
  <config>
    <name>WORD</name>
  </config>
</customer-service-template>
</customer-service-templates>
</l2vpn>
</mpls>

```

Command Syntax

```
rewrite ingress (pop) (outgoing-tpid (dot1.q|dot1.ad|0x9100) |)
```

Configure outer vlan identifier

Specify rewrite ingress action type

Attribute Name: vlan-action-type

Attribute Type: enum (pop|push|translate)

Attribute Name: outer-vlan-identifier

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: tag-protocol-identifier

Attribute Type: enum (dot1.q|dot1.ad|0x9100)

Netconf edit-config payload

```

<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
<l2vpn>
<customer-service-templates>
<customer-service-template>
  <name>NAME</name>
  <config>
    <name>WORD</name>
  </config>
</customer-service-template>
</customer-service-templates>
</l2vpn>
</mpls>

```

```
<action-type>
  <vlan-action-type>pop</vlan-action-type>
  <config>
    <vlan-action-type>pop</vlan-action-type>
    <outer-vlan-identifier>1</outer-vlan-identifier>
    <tag-protocol-identifier>dot1.q</tag-protocol-identifier>
  </config>
</action-type>
</action-types>
</customer-service-template>
</customer-service-templates>
</l2vpn>
</mpls>
```

Command Syntax

```
rewrite ingress (translate) <1-4094> (outgoing-tpid (dot1.q|dot1.ad|0x9100)|)
```

Configure group name

Use this attribute to create a new access circuit group for MPLS

This command is supported when following feature are enabled MPLS-VC feature

Attribute Name: group-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: group-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <l2vpn>
    <access-circuit-groups>
      <access-circuit-group> <!-- operation="delete"-->
        <group-name>NAME</group-name>
        <config>
          <group-name>WORD</group-name>
          <group-identifier>1</group-identifier>
        </config>
      </access-circuit-group>
    </access-circuit-groups>
  </l2vpn>
</mpls>
```

Command Syntax

```
mpls ac-group NAME <1-4294967295>
```

Configure local packet handling

Use this attribute to enable the labeling of locally generated TCP packets. All other locally generated packets are not looked at by the MPLS Forwarder

Attribute Name: local-packet-handling

Attribute Type: empty

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <global>
  <config>
    </local-packet-handling><!-- operation="delete"-->
  </config>
</global>
</mpls>
```

Command Syntax

```
mpls local-packet-handling
```

Configure lsp stitching

Use this attribute to enable lsp stitching for ILM and installed FTM

Attribute Name: lsp-stitching

Attribute Type: empty

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <global>
  <config>
    </lsp-stitching><!-- operation="delete"-->
  </config>
</global>
</mpls>
```

Command Syntax

```
mpls lsp-stitching
```

Configure propagate ttl

Use this attribute to enable TTL propagation. Enabling TTL propagation causes the TTL value in the IP header to be copied onto the TTL field in the shim header, at the LSP ingress

Attribute Name: propagate-ttl

Attribute Type: empty

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <global>
```

```
<config>
  </propagate-ttl><!-- operation="delete"-->
</config>
</global>
</mpls>
```

Command Syntax

```
mpls propagate-ttl
```

Configure ingress ttl value

Use this attribute to set a Time to Live (TTL) value for LSPs for which this LSR is the ingress.

Attribute Name: ingress-ttl-value

Attribute Type: uint8

Attribute Range: 0-255

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
<global>
<config>
  <ingress-ttl-value>0</ingress-ttl-value> <!-- operation="delete"-->
</config>
</global>
</mpls>
```

Command Syntax

```
mpls ingress-ttl <0-255>
```

Configure lsp model uniform

Use this attribute to configure the MPLS LSP model as Uniform.

Attribute Name: lsp-model-uniform

Attribute Type: empty

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
<global>
<config>
  </lsp-model-uniform><!-- operation="delete"-->
</config>
</global>
</mpls>
```

Command Syntax

```
mpls lsp-model uniform
```

Configure enable

Use this attribute to enable label-switching on a TE link

Attribute Name: enable

Attribute Type: empty

Attribute Name: label-space

Attribute Type: uint16

Attribute Range: 0-60000

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <label-switching>
      <config>
        <label-space>0</label-space>
        </enable>
      </config>
    </label-switching>
  </interface>
</interfaces>
</mpls>
```

Command Syntax

```
label-switching (<0-60000>|)
```

Configure admin group name

Use this attribute to create an administrative group to be used for links. Each link can be a member of one or more, or no administrative groups. This attribute adds link between an interface and a group. The name is the name of the group previously configured. There can be multiple groups per interface.

Attribute Name: admin-group-name

Attribute Type: string

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <mpls-interface-bandwidth>
```

```
<config>
  <admin-group-name>NAME</admin-group-name> <!-- operation="delete"-->
</config>
</mpls-interface-bandwidth>
</interface>
</interfaces>
</mpls>
```

Command Syntax

```
admin-group NAME
```

Configure bandwidth

Use this attribute to specify a discrete, maximum bandwidth value for the interface. The bandwidth attribute takes input ranges from 1 to 999 kbps, 1 to 999 mbps and 1 to 100 gbps.

Attribute Name: bandwidth

Attribute Type: string

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <mpls-interface-bandwidth>
        <config>
          <bandwidth>BANDWIDTH</bandwidth> <!-- operation="delete"-->
        </config>
      </mpls-interface-bandwidth>
    </interface>
  </interfaces>
</mpls>
```

Command Syntax

```
bandwidth BANDWIDTH
```

Configure reservable bandwidth

Use this attribute to specify the maximum reservable bandwidth per interface. This value can be equal or smaller value than max-bandwidth. Attribute takes input from 1 to 999 kbps, 1 to 999 mbps and 1 to 100 gbps

Attribute Name: reservable-bandwidth

Attribute Type: string

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <interfaces>
```

```

<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <mpls-interface-bandwidth>
  <config>
    <reservable-bandwidth>BANDWIDTH</reservable-bandwidth> <!--
operation="delete"-->
  </config>
</mpls-interface-bandwidth>
</interface>
</interfaces>
</mpls>

```

Command Syntax

```
reservable-bandwidth BANDWIDTH
```

Configure shared risk link group

Use this attribute to add the link to a srlg group

Attribute Name: shared-risk-link-group

Attribute Type: uint32

Attribute Range: 0-4294967295

Netconf edit-config payload

```

<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <mpls-interface-bandwidth>
      <config>
        <shared-risk-link-group>0</shared-risk-link-group> <!-- operation="delete"-->
      </config>
    </mpls-interface-bandwidth>
  </interface>
</interfaces>
</mpls>

```

Command Syntax

```
mpls traffic-eng srlg <0-4294967295>
```

Configure uni available bandwidth

Use this attribute to specify a unidirectional, available bandwidth value for the interface. The bandwidth attribute takes input in 0-999 kbps, 0-999 mbps and 0-100 gbps.

Attribute Name: uni-available-bandwidth

Attribute Type: string

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <mpls-interface-bandwidth>
        <config>
          <uni-available-bandwidth>BANDWIDTH</uni-available-bandwidth> <!--
operation="delete"-->
        </config>
      </mpls-interface-bandwidth>
    </interface>
  </interfaces>
</mpls>
```

Command Syntax

```
bandwidth-measurement static uni-available-bandwidth BANDWIDTH
```

Configure uni residual bandwidth

Use this attribute to specify a unidirectional, residual bandwidth value for the interface. The bandwidth attribute takes input in 0-999 kbps, 0-999 mbps and 0-100 gbps.

Attribute Name: uni-residual-bandwidth

Attribute Type: string

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <mpls-interface-bandwidth>
        <config>
          <uni-residual-bandwidth>BANDWIDTH</uni-residual-bandwidth> <!--
operation="delete"-->
        </config>
      </mpls-interface-bandwidth>
    </interface>
  </interfaces>
</mpls>
```

Command Syntax

```
bandwidth-measurement static uni-residual-bandwidth BANDWIDTH
```

Configure uni utilized bandwidth

Use this attribute to specify a unidirectional, utilised bandwidth value for the interface. The bandwidth attribute takes input in 0 to 999 kbps, 0 to 999 mbps and 1 to 100gbps.

Attribute Name: uni-utilized-bandwidth

Attribute Type: string

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <mpls-interface-bandwidth>
      <config>
        <uni-utilized-bandwidth>BANDWIDTH</uni-utilized-bandwidth> <!--
operation="delete"-->
      </config>
    </mpls-interface-bandwidth>
  </interface>
</interfaces>
</mpls>
```

Command Syntax

```
bandwidth-measurement static uni-utilized-bandwidth BANDWIDTH
```

Configure max label

Use this attribute to configure a maximum label value for a label space. After setting a maximum label value for a label space, make sure to bind the label space to an interface

Attribute Name: max-label

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: min-label

Attribute Type: uint32

Attribute Range: 16-1048575

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <label-spaces>
    <label-space>
```

```
<label-space-name>0</label-space-name>
<config>
  <label-space-name>0</label-space-name>
</config>
<global-label-range>
<config>
  <min-label>16</min-label>
  <max-label>16</max-label>
</config>
</global-label-range>
</label-space>
</label-spaces>
</mpls>
```

Command Syntax

```
mpls min-label-value <16-1048575> max-label-value <16-1048575> (label-space <0-60000>|)
```

Configure label space name

This attribute identifies the label space

Attribute Name: label-space-name

Attribute Type: uint16

Attribute Range: 0-60000

Attribute Name: module-name

Attribute Type: enum (rsvp|ldp|ldp-vc|bgp)

Attribute Name: min-label

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: max-label

Attribute Type: uint32

Attribute Range: 16-1048575

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
<label-spaces>
<label-space> <!-- operation="delete"-->
  <label-space-name>0</label-space-name>
  <config>
    <label-space-name>0</label-space-name>
  </config>
</label-space>
</label-spaces>
<module-label-ranges>
<module-label-range>
  <module-name>rsvp</module-name>
  <config>
    <min-label>16</min-label>
```

```

        <max-label>16</max-label>
    </config>
</module-label-range>
</module-label-ranges>
</label-space>
</label-spaces>
</mpls>

```

Command Syntax

```
mpls (rsvp|ldp|ldp-vc|bgp) min-label-value <16-1048575> max-label-value <16-1048575> (label-space <0-60000>|)
```

Configure ftn ecmp protocol

Use this attribute to configure ECMP on forwarder for supported protocol FTNs

Attribute Name: ftn-ecmp-protocol

Attribute Type: bits (ldp)

Netconf edit-config payload

```

<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <ecmp>
    <config>
      <ftn-ecmp-protocol>ldp</ftn-ecmp-protocol> <!-- operation="delete"-->
    </config>
  </ecmp>
</mpls>

```

Command Syntax

```
mpls ftn-ecmp (ldp)
```

Configure ilm ecmp protocol

Use this attribute to configure ECMP on forwarder for supported protocol ILMs

Attribute Name: ilm-ecmp-protocol

Attribute Type: bits (ldp)

Netconf edit-config payload

```

<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <ecmp>
    <config>
      <ilm-ecmp-protocol>ldp</ilm-ecmp-protocol> <!-- operation="delete"-->
    </config>
  </ecmp>
</mpls>

```

Command Syntax

```
mpls ilm-ecmp (ldp)
```

Configure max bandwidth

Use this attribute to specify the maximum bandwidth to be used for a bandwidth-class. The bandwidth value is in bits

This command is supported when following feature are enabled TE feature

Attribute Name: max-bandwidth

Attribute Type: string

Attribute Name: setup-priority

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: hold-priority

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <bandwidth-classes>
    <bandwidth-class>
      <name>NAME</name>
      <config>
        <name>WORD</name>
      </config>
    <properties>
      <config>
        <setup-priority>0</setup-priority>
        <hold-priority>0</hold-priority>
        <max-bandwidth>BANDWIDTH</max-bandwidth>
      </config>
    </properties>
  </bandwidth-class>
</bandwidth-classes>
</mpls>
```

Command Syntax

```
bandwidth BANDWIDTH setup-priority <0-7> hold-priority <0-7>
```

IPI-MPLS-RIB

Configure route prefix

Use this attribute to specify the route prefix for which FEC mapping needs to be added

Attribute Name: route-prefix

Attribute Type: string

Attribute Name: mapped-fec

Attribute Type: string

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
<rib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-rib">
<map-route>
<static-ipv4-map-routes>
<static-ipv4-map-route> <!-- operation="delete"-->
  <route-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</route-prefix>
  <config>
    <route-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</route-prefix>
    <mapped-fec>A.B.C.D/M|A.B.C.D A.B.C.D</mapped-fec>
  </config>
</static-ipv4-map-route>
</static-ipv4-map-routes>
</map-route>
</rib>
</mpls>
```

Command Syntax

```
mpls map-route (A.B.C.D/M|A.B.C.D A.B.C.D) (A.B.C.D/M|A.B.C.D A.B.C.D)
```

Configure out interface name

Outgoing interface name

Attribute Name: out-interface-name

Attribute Type: string

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
<rib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-rib">
<static-lsps>
<ipv4-static-ftn-entries>
<ipv4-static-ftn-entry>
  <out-interface-name>IFNAME</out-interface-name>
  <config>
    <out-interface-name>IFNAME</out-interface-name>
    <nexthop-ip-address>A.B.C.D</nexthop-ip-address>
    <pushed-label>16</pushed-label>
    <fec-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</fec-prefix>
  </config>
  <nexthop-ip-address>A.B.C.D</nexthop-ip-address>
  <pushed-label>16</pushed-label>
  <fec-prefix>A.B.C.D/M|A.B.C.D A.B.C.D</fec-prefix>
</ipv4-static-ftn-entry>
</ipv4-static-ftn-entries>
</static-lsps>
</rib>
</mpls>
```

Command Syntax

```
mpls ftn-entry (A.B.C.D/M|A.B.C.D A.B.C.D) <16-1048575> A.B.C.D IFNAME
```

Configure tunnel id

FTN tunnel-id value

Attribute Name: tunnel-id

Attribute Type: uint32

Attribute Range: 1-5000

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
<rib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-rib">
<static-lsps>
<static-ftn-tunnels>
<static-ftn-tunnel> <!-- operation="delete"-->
  <is-primary>primary</is-primary>
  <config>
    <is-primary>primary</is-primary>
    <out-interface-name>IFNAME</out-interface-name>
    <nexthop-ip-address>CML_IP_ADDR_T</nexthop-ip-address>
    <pushed-label>16</pushed-label>
    <fec-prefix>CML_IP_PREFIX_T</fec-prefix>
    <tunnel-id>1</tunnel-id>
  </config>
  <out-interface-name>IFNAME</out-interface-name>
  <nexthop-ip-address>CML_IP_ADDR_T</nexthop-ip-address>
  <pushed-label>16</pushed-label>
  <fec-prefix>CML_IP_PREFIX_T</fec-prefix>
  <tunnel-id>1</tunnel-id>
</static-ftn-tunnel>
</static-ftn-tunnels>
</static-lsps>
</rib>
</mpls>
```

Command Syntax

```
mpls ftn-entry tunnel-id <1-5000> (A.B.C.D/M|A.B.C.D A.B.C.D) <16-1048575> A.B.C.D
IFNAME ((secondary|primary)|)
```

Configure fec prefix

FTN tunnel-id value

Attribute Name: tunnel-id

Attribute Type: uint32

Attribute Range: 1-5000

Netconf edit-config payload

```

<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
<rib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-rib">
<static-lsps>
<static-ftn-tunnels>
<static-ftn-tunnel> <!-- operation="delete"-->
  <is-primary>primary</is-primary>
  <config>
    <is-primary>primary</is-primary>
    <out-interface-name>IFNAME</out-interface-name>
    <nexthop-ip-address>CML_IP_ADDR_T</nexthop-ip-address>
    <pushed-label>16</pushed-label>
    <fec-prefix>CML_IP_PREFIX_T</fec-prefix>
    <tunnel-id>1</tunnel-id>
  </config>
  <out-interface-name>IFNAME</out-interface-name>
  <nexthop-ip-address>CML_IP_ADDR_T</nexthop-ip-address>
  <pushed-label>16</pushed-label>
  <fec-prefix>CML_IP_PREFIX_T</fec-prefix>
  <tunnel-id>1</tunnel-id>
</static-ftn-tunnel>
</static-ftn-tunnels>
</static-lsps>
</rib>
</mpls>

```

Command Syntax

```

mpls ftn-entry tunnel-id <1-5000> X:X::X:X/M <16-1048575> X:X::X:X IFNAME
((secondary|primary) |)

```

Configure enable pop label

Use this attribute to create an ILM entry in the ILM table to which a POP incoming interface is bound. Upon receipt of a labeled packet on an MPLS-enabled router, a lookup is done based on the incoming label in the ILM table. If a match is found, the packet may either be label-switched downstream, or popped and passed over IP. In a pop operation, an outgoing label is not needed as is either accepted or forwarded over IP. The nexthop option is also not mandatory because the FEC IP address could be a local IP address

Attribute Name: enable-pop-label

Attribute Type: uint8

Netconf edit-config payload

```

<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
<rib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-rib">
<static-lsps>
<static-ilm-entries>
<static-ilm-entry>
  <incoming-label>16</incoming-label>
  <config>
    <incoming-label>16</incoming-label>

```

```
</config>
<pop>
<config>
  </enable-pop-label>
</config>
</pop>
</static-ilm-entry>
</static-ilm-entries>
</static-lsps>
</rib>
</mpls>
```

Command Syntax

```
mpls ilm-entry <16-1048575> pop
```

Configure incoming label

Incoming Label

Attribute Name: incoming-label

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: in-interface-name

Attribute Type: string

Attribute Name: swapped-label

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: out-interface-name

Attribute Type: string

Attribute Name: nexthop-ip-address

Attribute Type: inet:ip-address

Attribute Name: fec-prefix

Attribute Type: union

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
<rib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-rib">
<static-lsps>
<static-ilm-entries>
<static-ilm-entry> <!-- operation="delete"-->
  <incoming-label>16</incoming-label>
<config>
  <incoming-label>16</incoming-label>
</config>
<swaps>
```



```

    <swap>
      <in-interface-name>IFNAME</in-interface-name>
      <swapped-label>16</swapped-label>
      <out-interface-name>IFNAME</out-interface-name>
      <nexthop-ip-address>CML_IP_ADDR_T</nexthop-ip-address>
      <fec-prefix>CML_IP_PREFIX_T</fec-prefix>
    </swap>
  </swaps>
</static-ilm-entry>
</static-ilm-entries>
</static-lsps>
</rib>
</mpls>

```

Command Syntax

```

mpls ilm-entry <16-1048575> swap <16-1048575> IFNAME A.B.C.D (A.B.C.D/M|A.B.C.D
A.B.C.D)

```

Configure in interface name

Incoming Label

Attribute Name: incoming-label

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: in-interface-name

Attribute Type: string

Attribute Name: swapped-label

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: out-interface-name

Attribute Type: string

Attribute Name: nexthop-ip-address

Attribute Type: inet:ipv4-address

Attribute Name: fec-prefix

Attribute Type: string

Netconf edit-config payload

```

<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <rib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-rib">
    <static-lsps>
      <static-ilm-entries>
        <static-ilm-entry> <!-- operation="delete"-->
          <incoming-label>16</incoming-label>
        </static-ilm-entry>
      </static-ilm-entries>
    </static-lsps>
  </rib>
</mpls>

```

```
</config>
<swaps>
<swap>
  <in-interface-name>IFNAME</in-interface-name>
  <swapped-label>16</swapped-label>
  <out-interface-name>IFNAME</out-interface-name>
  <nexthop-ip-address>CML_IP_ADDR_T</nexthop-ip-address>
  <fec-prefix>CML_IP_PREFIX_T</fec-prefix>
</swap>
</swaps>
</static-ilm-entry>
</static-ilm-entries>
</static-lsps>
</rib>
</mpls>
```

Command Syntax

```
mpls ilm-entry <16-1048575> IFNAME swap <16-1048575> IFNAME A.B.C.D (A.B.C.D/
M|A.B.C.D A.B.C.D)
```

Configure swapped label

Incoming Label

Attribute Name: incoming-label

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: in-interface-name

Attribute Type: string

Attribute Name: swapped-label

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: out-interface-name

Attribute Type: string

Attribute Name: nexthop-ip-address

Attribute Type: inet:ipv4-address

Attribute Name: fec-prefix

Attribute Type: string

Netconf edit-config payload

```
<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
<rib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-rib">
<static-lsps>
<static-ilm-entries>
<static-ilm-entry> <!-- operation="delete"-->
  <incoming-label>16</incoming-label>
```

```

<config>
  <incoming-label>16</incoming-label>
</config>
<swaps>
<swap>
  <in-interface-name>IFNAME</in-interface-name>
    <swapped-label>16</swapped-label>
      <out-interface-name>IFNAME</out-interface-name>
        <nexthop-ip-address>CML_IP_ADDR_T</nexthop-ip-address>
          <fec-prefix>CML_IP_PREFIX_T</fec-prefix>
        </swap>
      </swaps>
    </static-ilm-entry>
  </static-ilm-entries>
</static-lsps>
</rib>
</mpls>

```

Command Syntax

```
mpls ilm-entry <16-1048575> swap <16-1048575> IFNAME X:X::X:X X:X::X:X/M
```

Configure nexthop ip address

Incoming Label

Attribute Name: incoming-label

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: in-interface-name

Attribute Type: string

Attribute Name: swapped-label

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: out-interface-name

Attribute Type: string

Attribute Name: nexthop-ip-address

Attribute Type: inet:ipv4-address

Attribute Name: fec-prefix

Attribute Type: string

Netconf edit-config payload

```

<mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls">
  <rib xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-rib">
    <static-lsps>
      <static-ilm-entries>

```

```

<static-ilm-entry> <!-- operation="delete"-->
  <incoming-label>16</incoming-label>
  <config>
    <incoming-label>16</incoming-label>
  </config>
  <swaps>
  <swap>
    <in-interface-name>IFNAME</in-interface-name>
    <swapped-label>16</swapped-label>
    <out-interface-name>IFNAME</out-interface-name>
    <nexthop-ip-address>CML_IP_ADDR_T</nexthop-ip-address>
    <fec-prefix>CML_IP_PREFIX_T</fec-prefix>
  </swap>
  </swaps>
</static-ilm-entry>
</static-ilm-entries>
</static-lsps>
</rib>
</mpls>

```

Command Syntax

```
mpls ilm-entry <16-1048575> IFNAME swap <16-1048575> IFNAME X:X::X:X X:X::X:X/M
```

IPI-MPLS-BFD

Configure fec address

This attribute is used to configure fec address of the MPLS BFD session

Attribute Name: fec-address

Attribute Type: string

Netconf edit-config payload

```

<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <mpls-lsp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-bfd">
    <session-groups>
      <session-group> <!-- operation="delete"-->
        <fec-address>A.B.C.D/M</fec-address>
        <config>
          <fec-address>A.B.C.D/M</fec-address>
          <lsp-type>ldp</lsp-type>
        </config>
        <lsp-type>ldp</lsp-type>
      </session-group>
    </session-groups>
  </mpls-lsp>
</bfd>

```

Command Syntax

```
mpls bfd (ldp|static) A.B.C.D/M
```

Configure lsp ping interval

Use this attribute to set LSP ping interval

Attribute Name: lsp-ping-interval

Attribute Type: uint16

Default Value: 5

Attribute Range: 0-1000

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <mpls-lsp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-bfd">
    <session-groups>
      <session-group>
        <fec-address>A.B.C.D/M</fec-address>
        <config>
          <fec-address>A.B.C.D/M</fec-address>
          <lsp-type>ldp</lsp-type>
        </config>
        <lsp-type>ldp</lsp-type>
        <session-attributes>
          <config>
            <lsp-ping-interval>0</lsp-ping-interval> <!-- operation="delete"-->
          </config>
        </session-attributes>
      </session-group>
    </session-groups>
  </mpls-lsp>
</bfd>
```

Command Syntax

```
lsp-ping-interval <0-1000>
```

Configure admin down

Use this attribute to shutdown selected MPLS BFD session

Attribute Name: admin-down

Attribute Type: empty

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <mpls-lsp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-bfd">
    <session-groups>
      <session-group>
        <fec-address>A.B.C.D/M</fec-address>
```

```
<config>
  <fec-address>A.B.C.D/M</fec-address>
  <lsp-type>ldp</lsp-type>
</config>
  <lsp-type>ldp</lsp-type>
<session-attributes>
<config>
  </admin-down><!-- operation="delete"-->
</config>
</session-attributes>
</session-group>
</session-groups>
</mpls-lsp>
</bfd>
```

Command Syntax

shutdown

Configure detection multiplier

Use this attribute to set MPLS BFD detection multiplier value

Attribute Name: detection-multiplier

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
<mpls-lsp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-bfd">
<session-groups>
<session-group>
  <fec-address>A.B.C.D/M</fec-address>
  <config>
    <fec-address>A.B.C.D/M</fec-address>
    <lsp-type>ldp</lsp-type>
  </config>
  <lsp-type>ldp</lsp-type>
<session-attributes>
<intervals>
<interval> <!-- operation="delete"-->
  <detection-multiplier>1</detection-multiplier>
  <config>
    <detection-multiplier>1</detection-multiplier>
    <minimum-rx>3</minimum-rx>
    <minimum-tx>3</minimum-tx>
  </config>
  <minimum-rx>3</minimum-rx>
  <minimum-tx>3</minimum-tx>
</interval>
</intervals>
```

```

</session-attributes>
</session-group>
</session-groups>
</mpls-lsp>
</bfd>

```

Command Syntax

```
min-tx <3-4294967> min-rx <3-4294967> multiplier <1-255>
```

Configure lsp type

This attribute is used to configure lsp type of the MPLS BFD session

Attribute Name: lsp-type

Attribute Type: enum (ldp|rsvp|static|generic)

Netconf edit-config payload

```

<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
<mpls-all-lsps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-bfd">
<mpls-all-lsp> <!-- operation="delete"-->
  <lsp-type>ldp</lsp-type>
  <config>
    <lsp-type>ldp</lsp-type>
  </config>
</mpls-all-lsp>
</mpls-all-lsps>
</bfd>

```

Command Syntax

```
mpls bfd (ldp|rsvp|static|generic) all
```

Configure minimum tx

Use this attribute to set MPLS BFD detection multiplier value

Attribute Name: detection-multiplier

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```

<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
<mpls-all-lsps xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-bfd">
<mpls-all-lsp>
  <lsp-type>ldp</lsp-type>
  <config>
    <lsp-type>ldp</lsp-type>
  </config>
  <session-attributes>
  <intervals>

```

```
<interval> <!-- operation="delete"-->
  <detection-multiplier>1</detection-multiplier>
  <config>
    <detection-multiplier>1</detection-multiplier>
    <minimum-rx>3</minimum-rx>
    <minimum-tx>3</minimum-tx>
  </config>
  <minimum-rx>3</minimum-rx>
  <minimum-tx>3</minimum-tx>
</interval>
</intervals>
</session-attributes>
</mpls-all-lsp>
</mpls-all-lsps>
</bfd>
```

Command Syntax

```
min-tx <3-4294967> min-rx <3-4294967> multiplier <1-255>
```

Configure tunnel name

This attribute is used to configure tunnel-name of the RSVP BFD session

Attribute Name: tunnel-name

Attribute Type: string

Netconf edit-config payload

```
<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
  <mpls-tunnels xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-bfd">
    <mpls-tunnel> <!-- operation="delete"-->
      <tunnel-name>NAME</tunnel-name>
      <config>
        <tunnel-name>WORD</tunnel-name>
        <lsp-type>rsvp</lsp-type>
      </config>
      <lsp-type>rsvp</lsp-type>
    </mpls-tunnel>
  </mpls-tunnels>
</bfd>
```

Command Syntax

```
mpls bfd (rsvp) tunnel-name NAME
```

Configure minimum rx

Use this attribute to set MPLS BFD detection multiplier value

Attribute Name: detection-multiplier

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```

<bfd xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bfd">
<mpls-tunnels xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mpls-bfd">
<mpls-tunnel>
  <tunnel-name>NAME</tunnel-name>
  <config>
    <tunnel-name>WORD</tunnel-name>
    <lsp-type>rsvp</lsp-type>
  </config>
  <lsp-type>rsvp</lsp-type>
<session-attributes>
<intervals>
<interval> <!-- operation="delete"-->
  <detection-multiplier>1</detection-multiplier>
  <config>
    <detection-multiplier>1</detection-multiplier>
    <minimum-rx>3</minimum-rx>
    <minimum-tx>3</minimum-tx>
  </config>
  <minimum-rx>3</minimum-rx>
  <minimum-tx>3</minimum-tx>
</interval>
</intervals>
</session-attributes>
</mpls-tunnel>
</mpls-tunnels>
</bfd>

```

Command Syntax

```
min-tx <3-4294967> min-rx <3-4294967> multiplier <1-255>
```

IPI-L2VPN-VPWS

Configure pseudowire identifier

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-default-tagged-mode

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
    <pseudowires>
    <pseudowire> <!-- operation="delete"-->
      <peer-address>VPWS_IP_ADDR_T</peer-address>
      <config>
        <peer-address>VPWS_IP_ADDR_T</peer-address>
        <pseudowire-identifier>1</pseudowire-identifier>
      </config>
      <pseudowire-identifier>1</pseudowire-identifier>
      <default-tagged>
      <config>
        </enable-default-tagged-mode>
      </config>
      </default-tagged>
    </pseudowire>
    </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
mpls l2-circuit NAME <1-4294967295> (A.B.C.D|X:X::X:X)
```

Configure instance name

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-default-tagged-mode

Attribute Type: empty

Attribute Name: service-tpid

Attribute Type: enum (dot1.q|dot1.ad|0x9100|0x9200)

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowires>
        <pseudowire>
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <config>
            <peer-address>VPWS_IP_ADDR_T</peer-address>
            <pseudowire-identifier>1</pseudowire-identifier>
          </config>
          <pseudowire-identifier>1</pseudowire-identifier>
          <default-tagged>
            <config>
              </enable-default-tagged-mode>
              <service-tpid>dot1.q</service-tpid>
            </config>
          </default-tagged>
        </pseudowire>
      </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>

```

Command Syntax

```
mpls l2-circuit NAME <1-4294967295> service-tpid (dot1.q|dot1.ad|0x9100|0x9200)
```

Configure instance type

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-default-tagged-mode

Attribute Type: empty

Attribute Name: service-tpid

Attribute Type: enum (dot1.q|dot1.ad|0x9100|0x9200)

Attribute Name: enable-control-word

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowires>
        <pseudowire>
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <config>
            <peer-address>VPWS_IP_ADDR_T</peer-address>
            <pseudowire-identifier>1</pseudowire-identifier>
          </config>
          <pseudowire-identifier>1</pseudowire-identifier>
          <default-tagged>
            <config>
              </enable-default-tagged-mode>
              <service-tpid>dot1.q</service-tpid>
              </enable-control-word>
            </config>
          </default-tagged>
        </pseudowire>
      </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
mpls l2-circuit NAME <1-4294967295> service-tpid (dot1.q|dot1.ad|0x9100|0x9200)
control-word
```

Configure peer address

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-default-tagged-mode

Attribute Type: empty

Attribute Name: service-tpid

Attribute Type: enum (dot1.q|dot1.ad|0x9100|0x9200)

Attribute Name: enable-control-word

Attribute Type: empty

Attribute Name: enable-manual-pseudowire

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
    <pseudowires>
    <pseudowire>
      <peer-address>VPWS_IP_ADDR_T</peer-address>
      <config>
        <peer-address>VPWS_IP_ADDR_T</peer-address>
        <pseudowire-identifier>1</pseudowire-identifier>
      </config>
      <pseudowire-identifier>1</pseudowire-identifier>
      <default-tagged>
      <config>
        </enable-default-tagged-mode>
        <service-tpid>dot1.q</service-tpid>
        </enable-control-word>
        </enable-manual-pseudowire>
      </config>
      </default-tagged>
    </pseudowire>
    </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
mpls l2-circuit NAME <1-4294967295> service-tpid (dot1.q|dot1.ad|0x9100|0x9200)
control-word manual
```

Configure enable default tagged mode

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-default-tagged-mode

Attribute Type: empty

Attribute Name: enable-control-word

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowires>
        <pseudowire>
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <config>
            <peer-address>VPWS_IP_ADDR_T</peer-address>
            <pseudowire-identifier>1</pseudowire-identifier>
          </config>
          <pseudowire-identifier>1</pseudowire-identifier>
          <default-tagged>
            <config>
              </enable-default-tagged-mode>
              </enable-control-word>
            </config>
          </default-tagged>
        </pseudowire>
      </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
mpls l2-circuit NAME <1-4294967295> control-word
```

Configure service tpid

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-default-tagged-mode

Attribute Type: empty

Attribute Name: service-tpid

Attribute Type: enum (dot1.q|dot1.ad|0x9100|0x9200)

Attribute Name: enable-manual-pseudowire

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowires>
        <pseudowire>
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <config>
            <peer-address>VPWS_IP_ADDR_T</peer-address>
            <pseudowire-identifier>1</pseudowire-identifier>
          </config>
          <pseudowire-identifier>1</pseudowire-identifier>
          <default-tagged>
            <config>
              </enable-default-tagged-mode>
              <service-tpid>dot1.q</service-tpid>
              </enable-manual-pseudowire>
            </config>
          </default-tagged>
        </pseudowire>
      </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
mpls l2-circuit NAME <1-4294967295> service-tpid (dot1.q|dot1.ad|0x9100|0x9200)
  manual
```

Configure enable manual pseudowire

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-default-tagged-mode

Attribute Type: empty

Attribute Name: enable-manual-pseudowire

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowires>
        <pseudowire>
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <config>
            <peer-address>VPWS_IP_ADDR_T</peer-address>
            <pseudowire-identifier>1</pseudowire-identifier>
          </config>
          <pseudowire-identifier>1</pseudowire-identifier>
          <default-tagged>
            <config>
              </enable-default-tagged-mode>
              </enable-manual-pseudowire>
            </config>
          </default-tagged>
        </pseudowire>
      </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>
```


Command Syntax

```
mpls l2-circuit NAME <1-4294967295> manual
```

Configure tunnel name

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-default-tagged-mode

Attribute Type: empty

Attribute Name: tunnel-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowires>
        <pseudowire>
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <config>
            <peer-address>VPWS_IP_ADDR_T</peer-address>
            <pseudowire-identifier>1</pseudowire-identifier>
          </config>
          <pseudowire-identifier>1</pseudowire-identifier>
          <default-tagged>
            <config>
              </enable-default-tagged-mode>
              <tunnel-name>NAME</tunnel-name>
            </config>
          </default-tagged>
        </pseudowire>
      </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
mpls l2-circuit NAME <1-4294967295> tunnel-name NAME
```

Configure enable control word

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-default-tagged-mode

Attribute Type: empty

Attribute Name: service-tpid

Attribute Type: enum (dot1.q|dot1.ad|0x9100|0x9200)

Attribute Name: enable-control-word

Attribute Type: empty

Attribute Name: tunnel-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowires>
        <pseudowire>
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <config>
            <peer-address>VPWS_IP_ADDR_T</peer-address>
            <pseudowire-identifier>1</pseudowire-identifier>
          </config>
          <pseudowire-identifier>1</pseudowire-identifier>
          <default-tagged>
            <config>
              </enable-default-tagged-mode>
              <service-tpid>dot1.q</service-tpid>
              </enable-control-word>
            </config>
          </default-tagged>
        </pseudowire>
      </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>
```

```

        <tunnel-name>NAME</tunnel-name>
    </config>
</default-tagged>
</pseudowire>
</pseudowires>
</vpws-instance>
</network-instance>
</network-instances>

```

Command Syntax

```

mpls l2-circuit NAME <1-4294967295> service-tpid (dot1.q|dot1.ad|0x9100|0x9200)
control-word tunnel-name NAME

```

Configure tunnel identifier

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-default-tagged-mode

Attribute Type: empty

Attribute Name: tunnel-identifier

Attribute Type: uint32

Attribute Range: 1-5000

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowires>
        <pseudowire>
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <config>
            <peer-address>VPWS_IP_ADDR_T</peer-address>
            <pseudowire-identifier>1</pseudowire-identifier>
          </config>
          <pseudowire-identifier>1</pseudowire-identifier>
        </pseudowire>
      </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>

```

```
<config>
  </enable-default-tagged-mode>
  <tunnel-identifier>1</tunnel-identifier>
</config>
</default-tagged>
</pseudowire>
</pseudowires>
</vpws-instance>
</network-instance>
</network-instances>
```

Command Syntax

```
mpls l2-circuit NAME <1-4294967295> tunnel-id <1-5000>
```

Configure tunnel policy

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-default-tagged-mode

Attribute Type: empty

Attribute Name: tunnel-policy

Attribute Type: string

Attribute Range: 1-127

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
  <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
    <pseudowires>
      <pseudowire>
        <peer-address>VPWS_IP_ADDR_T</peer-address>
        <config>
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <pseudowire-identifier>1</pseudowire-identifier>
        </config>
        <pseudowire-identifier>1</pseudowire-identifier>
```

```

    <default-tagged>
    <config>
      </enable-default-tagged-mode>
      <tunnel-policy>POLICYNAME</tunnel-policy>
    </config>
  </default-tagged>
</pseudowire>
</pseudowires>
</vpws-instance>
</network-instance>
</network-instances>

```

Command Syntax

```
mpls l2-circuit NAME <1-4294967295> tunnel-select-policy POLICYNAME
```

Configure group name

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-default-tagged-mode

Attribute Type: empty

Attribute Name: group-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
  <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
    <pseudowires>
      <pseudowire>
        <peer-address>VPWS_IP_ADDR_T</peer-address>
        <config>
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <pseudowire-identifier>1</pseudowire-identifier>
        </config>
      </pseudowire>
    </pseudowires>
  </vpws-instance>
</network-instance>
</network-instances>

```

```
        <pseudowire-identifier>1</pseudowire-identifier>
    <default-tagged>
    <config>
        </enable-default-tagged-mode>
        <group-name>NAME</group-name>
    </config>
    </default-tagged>
</pseudowire>
</pseudowires>
</vpws-instance>
</network-instance>
</network-instances>
```

Command Syntax

```
mpls l2-circuit NAME <1-4294967295> NAME
```

Configure group identifier

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-default-tagged-mode

Attribute Type: empty

Attribute Name: group-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: service-tpid

Attribute Type: enum (dot1.q|dot1.ad|0x9100|0x9200)

Attribute Name: group-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-control-word

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
```

```

    <instance-type>vpws</instance-type>
  </config>
  <instance-type>vpws</instance-type>
  <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
  <pseudowires>
  <pseudowire>
    <peer-address>VPWS_IP_ADDR_T</peer-address>
    <config>
      <peer-address>VPWS_IP_ADDR_T</peer-address>
      <pseudowire-identifier>1</pseudowire-identifier>
    </config>
    <pseudowire-identifier>1</pseudowire-identifier>
  <default-tagged>
  <config>
    </enable-default-tagged-mode>
    <group-name>NAME</group-name>
    <service-tpid>dot1.q</service-tpid>
    <group-identifier>1</group-identifier>
    </enable-control-word>
  </config>
  </default-tagged>
  </pseudowire>
  </pseudowires>
  </vpws-instance>
</network-instance>
</network-instances>

```

Command Syntax

```

mpls l2-circuit NAME <1-4294967295> NAME service-tpid
(dot1.q|dot1.ad|0x9100|0x9200) group-id <1-4294967295> control-word

```

Configure enable interface parameter tlv

Use this attribute to configure interface parameter tlv for VPLS Virtual Circuits.

Attribute Name: enable-interface-parameter-tlv

Attribute Type: empty

Attribute Name: enable-flow-label

Attribute Type: empty

Attribute Name: flow-label-direction

Attribute Type: enum (both|transmit|receive)

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>

```

```

    <instance-type>vpws</instance-type>
  </config>
  <instance-type>vpws</instance-type>
  <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
  <pseudowires>
  <pseudowire>
    <peer-address>VPWS_IP_ADDR_T</peer-address>
    <config>
      <peer-address>VPWS_IP_ADDR_T</peer-address>
      <pseudowire-identifier>1</pseudowire-identifier>
    </config>
    <pseudowire-identifier>1</pseudowire-identifier>
    <default-tagged>
    <config>
      </enable-flow-label><!-- operation="delete"-->
      <flow-label-direction>both</flow-label-direction> <!--
operation="delete"-->
      </enable-interface-parameter-tlv><!-- operation="delete"-->
    </config>
    </default-tagged>
  </pseudowire>
</pseudowires>
</vpws-instance>
</network-instance>
</network-instances>

```

Command Syntax

```
flow-label (both|transmit|receive) interface-param-tlv
```

Configure enable static flow label

Use this attribute to enable static flow label for VPWS Virtual Circuits.

Attribute Name: enable-static-flow-label

Attribute Type: empty

Attribute Name: enable-flow-label

Attribute Type: empty

Attribute Name: flow-label-direction

Attribute Type: enum (both|transmit|receive)

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
  </network-instance>
</network-instances>

```



```

    <instance-type>vpws</instance-type>
<vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
<pseudowires>
<pseudowire>
    <peer-address>VPWS_IP_ADDR_T</peer-address>
    <config>
        <peer-address>VPWS_IP_ADDR_T</peer-address>
        <pseudowire-identifier>1</pseudowire-identifier>
    </config>
    <pseudowire-identifier>1</pseudowire-identifier>
    <default-tagged>
    <config>
        </enable-flow-label><!-- operation="delete"-->
        <flow-label-direction>both</flow-label-direction> <!--
operation="delete"-->
        </enable-static-flow-label><!-- operation="delete"-->
    </config>
    </default-tagged>
</pseudowire>
</pseudowires>
</vpws-instance>
</network-instance>
</network-instances>

```

Command Syntax

```
flow-label (both|transmit|receive) static
```

Configure flow label direction

Use this attribute to configure flow label direction to transmit, receive or both for VPWS Virtual Circuits.

Attribute Name: flow-label-direction

Attribute Type: enum (both|transmit|receive)

Attribute Name: enable-flow-label

Attribute Type: empty

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
<network-instance>
    <instance-name>NAME</instance-name>
    <config>
        <instance-name>WORD</instance-name>
        <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
<vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
<pseudowires>
<pseudowire>
    <peer-address>VPWS_IP_ADDR_T</peer-address>

```

```

    <config>
      <peer-address>VPWS_IP_ADDR_T</peer-address>
      <pseudowire-identifier>1</pseudowire-identifier>
    </config>
    <pseudowire-identifier>1</pseudowire-identifier>
    <default-tagged>
    <config>
      </enable-flow-label><!-- operation="delete"-->
      <flow-label-direction>both</flow-label-direction> <!--
operation="delete"-->
    </config>
  </default-tagged>
</pseudowire>
</pseudowires>
</vpws-instance>
</network-instance>
</network-instances>

```

Command Syntax

flow-label (both|transmit|receive)

Configure control channel type

Use this attribute to configure the Control-Channel type for VCCV

Attribute Name: control-channel-type

Attribute Type: bits (type-1|type-2|type-3)

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowires>
        <pseudowire>
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <config>
            <peer-address>VPWS_IP_ADDR_T</peer-address>
            <pseudowire-identifier>1</pseudowire-identifier>
          </config>
          <pseudowire-identifier>1</pseudowire-identifier>
          <default-tagged>
          <config>
            <control-channel-type>type-1</control-channel-type> <!--
operation="delete"-->

```

```

    </config>
  </default-tagged>
</pseudowire>
</pseudowires>
</vpws-instance>
</network-instance>
</network-instances>

```

Command Syntax

```
vccv cc-type (type-1|type-2|type-3)
```

Configure control verification type

Use this attribute to configure the Control-Verification supported by BFD for VCCV

Attribute Name: control-verification-type

Attribute Type: bits (type-1|type-2|type-3|type-4)

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowires>
        <pseudowire>
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <config>
            <peer-address>VPWS_IP_ADDR_T</peer-address>
            <pseudowire-identifier>1</pseudowire-identifier>
          </config>
          <pseudowire-identifier>1</pseudowire-identifier>
          <default-tagged>
            <config>
              <control-verification-type>type-1</control-verification-type> <!--
operation="delete"-->
            </config>
          </default-tagged>
        </pseudowire>
      </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>

```

Command Syntax

```
vccv cv-type (type-1|type-2|type-3|type-4)
```

Configure enable tagged mode

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-tagged-mode

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowires>
        <pseudowire> <!-- operation="delete"-->
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <config>
            <peer-address>VPWS_IP_ADDR_T</peer-address>
            <pseudowire-identifier>1</pseudowire-identifier>
          </config>
          <pseudowire-identifier>1</pseudowire-identifier>
          <tagged>
            <config>
              </enable-tagged-mode>
            </config>
          </tagged>
        </pseudowire>
      </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
mpls l2-circuit NAME <1-4294967295> mode tagged
```

Configure enable flow label

Use this attribute to configure interface parameter tlv for VPLS Virtual Circuits.

Attribute Name: enable-interface-parameter-tlv

Attribute Type: empty

Attribute Name: enable-flow-label

Attribute Type: empty

Attribute Name: flow-label-direction

Attribute Type: enum (both|transmit|receive)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowires>
        <pseudowire>
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <config>
            <peer-address>VPWS_IP_ADDR_T</peer-address>
            <pseudowire-identifier>1</pseudowire-identifier>
          </config>
          <pseudowire-identifier>1</pseudowire-identifier>
          <tagged>
            <config>
              </enable-flow-label><!-- operation="delete"-->
              <flow-label-direction>both</flow-label-direction> <!--
operation="delete"-->
              </enable-interface-parameter-tlv><!-- operation="delete"-->
            </config>
          </tagged>
        </pseudowire>
      </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
flow-label (both|transmit|receive) interface-param-tlv
```

Configure enable raw mode

Use this attribute to assign pseudowire identifier to create an instance of an MPLS layer 2 virtual circuit. A Layer-2 MPLS Virtual Circuit instance may be bound to any interface on the router; however, only one interface may be bound to a Layer-2 circuit at a time.

Attribute Name: pseudowire-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Attribute Name: enable-raw-mode

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowires>
        <pseudowire> <!-- operation="delete"-->
          <peer-address>VPWS_IP_ADDR_T</peer-address>
          <config>
            <peer-address>VPWS_IP_ADDR_T</peer-address>
            <pseudowire-identifier>1</pseudowire-identifier>
          </config>
          <pseudowire-identifier>1</pseudowire-identifier>
          <raw>
            <config>
              </enable-raw-mode>
            </config>
          </raw>
        </pseudowire>
      </pseudowires>
    </vpws-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
mpls l2-circuit NAME <1-4294967295> mode raw
```

Configure attachment group identifier

Use this attribute to enable control word for MPLS Layer-2 Virtual Circuit.

This command is supported when following feature are enabled Generic FEC129 Feature

Attribute Name: enable-control-word

Attribute Type: empty

Attribute Name: service-tpid

Attribute Type: enum (dot1.q|dot1.ad|0x9100|0x9200)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowire-fec129>
        <target-attachment-individual-identifier>NAME</target-attachment-individual-
identifier>
        <config>
          <target-attachment-individual-identifier>NAME</target-attachment-
individual-identifier>
          <source-attachment-individual-identifier>NAME</source-attachment-
individual-identifier>
          <attachment-group-identifier>NAME</attachment-group-identifier>
          <peer-address>A.B.C.D</peer-address>
          <service-tpid>dot1.q</service-tpid>
        </config>
        <source-attachment-individual-identifier>NAME</source-attachment-
individual-identifier>
        <attachment-group-identifier>NAME</attachment-group-identifier>
        <peer-address>A.B.C.D</peer-address>
        </enable-control-word>
      </pseudowire-fec129>
    </vpws-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
mpls l2-circuit NAME A.B.C.D agi NAME sai NAME tai NAME service-tpid
(dot1.q|dot1.ad|0x9100|0x9200) control-word
```

Configure source attachment individual identifier

Use this attribute to specify the transport tunnel-name to be used for MPLS Layer-2 Virtual Circuit.

This command is supported when following feature are enabled Generic FEC129 Feature

Attribute Name: tunnel-name

Attribute Type: string

Attribute Range: 1-32

Attribute Name: service-tpid

Attribute Type: enum (dot1.q|dot1.ad|0x9100|0x9200)

Attribute Name: enable-control-word

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowire-fec129>
        <target-attachment-individual-identifier>NAME</target-attachment-individual-
identifier>
        <config>
          <target-attachment-individual-identifier>NAME</target-attachment-
individual-identifier>
          <source-attachment-individual-identifier>NAME</source-attachment-
individual-identifier>
          <attachment-group-identifier>NAME</attachment-group-identifier>
          <peer-address>A.B.C.D</peer-address>
          <service-tpid>dot1.q</service-tpid>
          </enable-control-word>
        </config>
        <source-attachment-individual-identifier>NAME</source-attachment-
individual-identifier>
        <attachment-group-identifier>NAME</attachment-group-identifier>
        <peer-address>A.B.C.D</peer-address>
        <tunnel-name>NAME</tunnel-name>
      </pseudowire-fec129>
    </vpws-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
mpls l2-circuit NAME A.B.C.D agi NAME sai NAME tai NAME service-tpid
(dot1.q|dot1.ad|0x9100|0x9200) control-word tunnel-name NAME
```

Configure target attachment individual identifier

Use this attribute to specify the static tunnel-identifier to be used for MPLS Layer-2 Virtual Circuit.

This command is supported when following feature are enabled Generic FEC129 Feature

Attribute Name: tunnel-identifier

Attribute Type: uint32

Attribute Range: 1-5000

Attribute Name: service-tpid

Attribute Type: enum (dot1.q|dot1.ad|0x9100|0x9200)

Attribute Name: enable-control-word

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>NAME</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpws</instance-type>
    </config>
    <instance-type>vpws</instance-type>
    <vpws-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
      <pseudowire-fecl29>
        <target-attachment-individual-identifier>NAME</target-attachment-individual-
identifier>
        <config>
          <target-attachment-individual-identifier>NAME</target-attachment-
individual-identifier>
          <source-attachment-individual-identifier>NAME</source-attachment-
individual-identifier>
          <attachment-group-identifier>NAME</attachment-group-identifier>
          <peer-address>A.B.C.D</peer-address>
          <service-tpid>dot1.q</service-tpid>
          </enable-control-word>
        </config>
        <source-attachment-individual-identifier>NAME</source-attachment-
individual-identifier>
        <attachment-group-identifier>NAME</attachment-group-identifier>
        <peer-address>A.B.C.D</peer-address>
        <tunnel-identifier>1</tunnel-identifier>
      </pseudowire-fecl29>
    </vpws-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
mpls l2-circuit NAME A.B.C.D agi NAME saii NAME taii NAME service-tpid
(dot1.q|dot1.ad|0x9100|0x9200) control-word tunnel-id <1-5000>
```

Configure service template

This attribute is used to configure service-template for vc-mode

Attribute Name: service-template

Attribute Type: string

Attribute Name: mode

Attribute Type: enum (standby|revertive)

Netconf edit-config payload

```
<vpws xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<pseudowire-modes>
<pseudowire-mode>
  <service-template>WORD</service-template>
  <config>
    <service-template>NAME</service-template>
    <mode>standby</mode>
  </config>
</pseudowire-mode>
</pseudowire-modes>
</interface>
</interfaces>
</vpws>
```

Command Syntax

```
vc-mode (standby|revertive) service-template NAME
```

Configure enable

This attribute is used to enable VPWS service on Subinterface

This command is supported when following feature are enabled Subinterface feature

Attribute Name: enable

Attribute Type: uint8

Netconf edit-config payload

```
<vpws xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<vpws-access>
<config>
  </enable>
</config>
</vpws-access>
```

```

</interface>
</interfaces>
</vpws>

```

Command Syntax

```
access-if-vpws
```

Configure enable revertive mode

This attribute is used to configure vc-mode revertive on the interface

This command is supported when following feature are enabled Subinterface feature

Attribute Name: enable-revertive-mode

Attribute Type: empty

Netconf edit-config payload

```

<vpws xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
  <vpws-access>
    <config>
      </enable-revertive-mode><!-- operation="delete"-->
    </config>
  </vpws-access>
</vpws>

```

Command Syntax

```
vc-mode revertive
```

Configure vpws name

This attribute uniquely identifies a VPWS service on Subinterface

This command is supported when following feature are enabled Subinterface feature

Attribute Name: vpws-name

Attribute Type: string

Attribute Range: 1-128

Attribute Name: pseudowire-link-mode

Attribute Type: enum (primary|secondary)

Netconf edit-config payload

```

<vpws xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">

```

```
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<vpws-access>
<bindings>
<binding> <!-- operation="delete"-->
  <vpws-name>NAME</vpws-name>
  <config>
    <vpws-name>WORD</vpws-name>
    <pseudowire-link-mode>primary</pseudowire-link-mode>
  </config>
</binding>
</bindings>
</vpws-access>
</interface>
</interfaces>
</vpws>
```

Command Syntax

```
mpls-l2-circuit NAME ((primary|secondary)|)
```

Configure pseudowire name

Use this attribute to specify pseudowire name

Attribute Name: pseudowire-name

Attribute Type: string

Attribute Name: service-template-name

Attribute Type: string

Attribute Name: pseudowire-link-mode

Attribute Type: enum (primary|secondary)

Netconf edit-config payload

```
<vpws xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<service-template-mappings>
<service-template-mapping>
  <pseudowire-name>NAME</pseudowire-name>
  <config>
    <pseudowire-name>WORD</pseudowire-name>
    <service-template-name>NAME</service-template-name>
```

```

        <pseudowire-link-mode>primary</pseudowire-link-mode>
    </config>
</service-template-mapping>
</service-template-mappings>
</interface>
</interfaces>
</vpws>

```

Command Syntax

```
mpls-l2-circuit NAME service-template NAME ((primary|secondary)|)
```

Configure name

Use this attribute to specify pseudowire name

Attribute Name: pseudowire-name

Attribute Type: string

Attribute Name: service-template-name

Attribute Type: string

Attribute Name: cos-to-queue-profile-name

Attribute Type: string

Attribute Name: queue-to-cos-profile-name

Attribute Type: string

Attribute Name: pseudowire-link-mode

Attribute Type: enum (primary|secondary)

Netconf edit-config payload

```

<vpws xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <service-template-mappings>
    <service-template-mapping>
      <pseudowire-name>NAME</pseudowire-name>
      <config>
        <pseudowire-name>WORD</pseudowire-name>
        <service-template-name>NAME</service-template-name>
        <cos-to-queue-profile-name>NAME</cos-to-queue-profile-name>
        <queue-to-cos-profile-name>NAME</queue-to-cos-profile-name>
        <pseudowire-link-mode>primary</pseudowire-link-mode>
      </config>
    </service-template-mapping>
  </service-template-mappings>
</interface>

```

```
</interfaces>  
</vpws>
```

Command Syntax

```
mpls-l2-circuit NAME service-template NAME cos-to-queue NAME queue-color-to-cos  
NAME ((primary|secondary)|)
```

Configure service template name

Use this attribute to specify pseudowire name

Attribute Name: pseudowire-name

Attribute Type: string

Attribute Name: service-template-name

Attribute Type: string

Attribute Name: cos-to-queue-profile-name

Attribute Type: string

Attribute Name: pseudowire-link-mode

Attribute Type: enum (primary|secondary)

Netconf edit-config payload

```
<vpws xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">  
<interfaces>  
<interface>  
  <name>WORD</name>  
  <config>  
    <name>WORD</name>  
  </config>  
<service-template-mappings>  
<service-template-mapping>  
  <pseudowire-name>NAME</pseudowire-name>  
  <config>  
    <pseudowire-name>WORD</pseudowire-name>  
    <service-template-name>NAME</service-template-name>  
    <cos-to-queue-profile-name>NAME</cos-to-queue-profile-name>  
    <pseudowire-link-mode>primary</pseudowire-link-mode>  
  </config>  
</service-template-mapping>  
</service-template-mappings>  
</interface>  
</interfaces>  
</vpws>
```

Command Syntax

```
mpls-l2-circuit NAME service-template NAME cos-to-queue NAME ((primary|secondary)|)
```

Configure queue to cos profile name

Use this attribute to specify pseudowire name

Attribute Name: pseudowire-name

Attribute Type: string

Attribute Name: service-template-name

Attribute Type: string

Attribute Name: queue-to-cos-profile-name

Attribute Type: string

Attribute Name: pseudowire-link-mode

Attribute Type: enum (primary|secondary)

Netconf edit-config payload

```
<vpws xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <service-template-mappings>
      <service-template-mapping>
        <pseudowire-name>NAME</pseudowire-name>
        <config>
          <pseudowire-name>WORD</pseudowire-name>
          <service-template-name>NAME</service-template-name>
          <queue-to-cos-profile-name>NAME</queue-to-cos-profile-name>
          <pseudowire-link-mode>primary</pseudowire-link-mode>
        </config>
      </service-template-mapping>
    </service-template-mappings>
  </interface>
</interfaces>
</vpws>
```

Command Syntax

```
mpls-l2-circuit NAME service-template NAME queue-color-to-cos NAME
((primary|secondary) |)
```

Configure access interface name

This attribute is used to configure customer network interface for static VC fib entry

Attribute Name: access-interface-name

Attribute Type: string

Attribute Name: incoming-label

Attribute Type: uint32

Attribute Range: 16-15999

Attribute Name: outgoing-label

Attribute Type: uint32

Attribute Range: 16-15999

Attribute Name: nexthop-address

Attribute Type: inet:ip-address

Attribute Name: provider-interface-name

Attribute Type: string

Netconf edit-config payload

```
<vpws xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
  <static-forwarding>
    <forwarding-information-bases>
      <forwarding-information-base>
        <pseudowire-identifier>1</pseudowire-identifier>
        <config>
          <pseudowire-identifier>1</pseudowire-identifier>
          <incoming-label>16</incoming-label>
          <outgoing-label>16</outgoing-label>
          <nexthop-address>CML_IP_ADDR_T</nexthop-address>
          <provider-interface-name>IFNAME</provider-interface-name>
        </config>
        <access-interface-name>NAME</access-interface-name>
      </forwarding-information-base>
    </forwarding-information-bases>
  </static-forwarding>
</vpws>
```

Command Syntax

```
mpls l2-circuit-fib-entry <1-4294967295> <16-15999> <16-15999> (A.B.C.D|X:X::X:X)
  IFNAME NAME
```

clear mpls l2-circuit NAME statistics

Attribute Name: pseudowire-name

Attribute Type: string

Netconf RPC payload

```
<clear-mpls-l2-circuit-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-l2vpn-vpws">
  <pseudowire-name>NAME</pseudowire-name>
</clear-mpls-l2-circuit-statistics>
```

Command Syntax

```
clear mpls l2-circuit NAME statistics
```

clear mpls l2-circuit NAME statistics (access-port|network-port)

Attribute Name: port-pseudowire-name

Attribute Type: string

Attribute Name: port-type

Attribute Type: enum (access-port|network-port)

Default Value: network-port

Netconf RPC payload

```
<clear-mpls-l2-circuit-port-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
  <port-pseudowire-name>NAME</port-pseudowire-name>
  <port-type>network-port</port-type>
</clear-mpls-l2-circuit-port-statistics>
```

Command Syntax

```
clear mpls l2-circuit NAME statistics (access-port|network-port)
```

vc-switchover NAME NAME

Attribute Name: primary-pseudowire

Attribute Type: string

Attribute Name: secondary-pseudowire

Attribute Type: string

Netconf RPC payload

```
<pseudowire-manual-switchover xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpws">
  <primary-pseudowire>NAME</primary-pseudowire>
  <secondary-pseudowire>NAME</secondary-pseudowire>
</pseudowire-manual-switchover>
```

Command Syntax

```
vc-switchover NAME NAME
```

IPI-SEGMENT-ROUTING

Configure enable

Enable segment routing

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <config>
    </enable>
  </config>
</segment-routing>
```

Command Syntax

```
segment-routing
```

Configure adj sid absolute

This attribute is used to configure Segment Route adjacency SID absolute value

This command is supported when following feature are enabled sr mpls feature

Attribute Name: adj-sid-absolute

Attribute Type: uint32

Attribute Range: 16-1048575

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
        </config>
      <adjacency-segment>
        <config>
          <adj-sid-absolute>16</adj-sid-absolute> <!-- operation="delete"-->
        </config>
      </adjacency-segment>
    </interface>
  </interfaces>
</segment-routing>
```

Command Syntax

```
adjacency-sid absolute <16-1048575>
```

Configure adj sid index

This attribute is used to configure Segment Route adjacency SID index-value

This command is supported when following feature are enabled sr mpls feature

Attribute Name: adj-sid-index

Attribute Type: uint32

Attribute Range: 0-1048575

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <adjacency-segment>
      <config>
        <adj-sid-index>0</adj-sid-index> <!-- operation="delete"-->
      </config>
    </adjacency-segment>
  </interface>
</interfaces>
</segment-routing>
```

Command Syntax

```
adjacency-sid index <0-1048575>
```

Configure n flag clear

This attribute is used to set n-flag-clear

This command is supported when following feature are enabled sr mpls feature

Attribute Name: n-flag-clear

Attribute Type: enum (n-flag-clear)

Attribute Name: sid-absolute

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: exp-null

Attribute Type: enum (explicit-null|no-php)

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <prefix-segment>
      <config>
        <sid-absolute>16</sid-absolute> <!-- operation="delete"-->
        <exp-null>explicit-null</exp-null> <!-- operation="delete"-->
        <n-flag-clear>n-flag-clear</n-flag-clear> <!-- operation="delete"-->
      </config>
    </prefix-segment>
  </interface>
</interfaces>
```

```
</interface>  
</interfaces>  
</segment-routing>
```

Command Syntax

```
prefix-sid absolute <16-1048575> ((explicit-null|no-php)|) ((n-flag-clear)|)
```

Configure name

This attribute is used to set n-flag-clear

This command is supported when following feature are enabled sr mpls feature

Attribute Name: n-flag-clear

Attribute Type: enum (n-flag-clear)

Attribute Name: sid-index

Attribute Type: uint32

Attribute Range: 0-1048575

Attribute Name: exp-null

Attribute Type: enum (explicit-null|no-php)

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">  
  <interfaces>  
    <interface>  
      <name>WORD</name>  
      <config>  
        <name>WORD</name>  
      </config>  
      <prefix-segment>  
        <config>  
          <sid-index>0</sid-index> <!-- operation="delete"-->  
          <exp-null>explicit-null</exp-null> <!-- operation="delete"-->  
          <n-flag-clear>n-flag-clear</n-flag-clear> <!-- operation="delete"-->  
        </config>  
      </prefix-segment>  
    </interface>  
  </interfaces>  
</segment-routing>
```

Command Syntax

```
prefix-sid index <0-1048575> ((explicit-null|no-php)|) ((n-flag-clear)|)
```

Configure enable preference

preference for segment routing label over LDP

This command is supported when following feature are enabled sr mpls feature

Attribute Name: enable-preference

Attribute Type: empty

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <sr-mpls>
    <sr-prefer-over-ldp>
      <config>
        </enable-preference><!-- operation="delete"-->
      </config>
    </sr-prefer-over-ldp>
  </sr-mpls>
</segment-routing>
```

Command Syntax

```
mpls sr-prefer
```

Configure preference

preference for segment routing mapping server

This command is supported when following feature are enabled sr mpls feature

Attribute Name: preference

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <sr-mpls>
    <bindings>
      <mapping-server>
        <srms-preferenece>
          <config>
            <preference>1</preference> <!-- operation="delete"-->
          </config>
        </srms-preferenece>
      </mapping-server>
    </bindings>
  </sr-mpls>
</segment-routing>
```

Command Syntax

```
srms preference <1-255>
```

Configure start address

connected prefix for prefix-sid

Attribute Name: start-address

Attribute Type: string

Attribute Name: attached

Attribute Type: boolean

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <sr-mpls>
    <bindings>
      <mapping-server>
        <prefix-sid-map-ipv4>
          <mapping-entries>
            <mapping-entry> <!-- operation="delete"-->
              <start-sid>0</start-sid>
              <config>
                <start-sid>0</start-sid>
                <start-address>A.B.C.D/M</start-address>
                <attached>true</attached>
              </config>
            <start-address>A.B.C.D/M</start-address>
          </mapping-entry>
        </mapping-entries>
      </prefix-sid-map-ipv4>
    </mapping-server>
  </bindings>
</sr-mpls>
</segment-routing>
```

Command Syntax

```
A.B.C.D/M <0-1048575> attached
```

Configure start sid

connected prefix for prefix-sid

Attribute Name: start-address

Attribute Type: string

Attribute Name: range

Attribute Type: uint32

Attribute Range: 1-65535

Attribute Name: attached

Attribute Type: boolean

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <sr-mpls>
    <bindings>
      <mapping-server>
        <prefix-sid-map-ipv4>
          <mapping-entries>
```

```

<mapping-entry> <!-- operation="delete"-->
  <start-sid>0</start-sid>
  <config>
    <start-sid>0</start-sid>
    <start-address>A.B.C.D/M</start-address>
    <range>1</range>
    <attached>>true</attached>
  </config>
  <start-address>A.B.C.D/M</start-address>
</mapping-entry>
</mapping-entries>
</prefix-sid-map-ipv4>
</mapping-server>
</bindings>
</sr-mpls>
</segment-routing>

```

Command Syntax

```
A.B.C.D/M <0-1048575> range <1-65535> (attached|)
```

Configure end

SRGB end range

This command is supported when following feature are enabled sr mpls feature

Attribute Name: end

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: start

Attribute Type: uint32

Attribute Range: 16-1048575

Netconf edit-config payload

```

<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <sr-mpls>
    <global-block>
      <config>
        <start>16</start>
        <end>16</end>
      </config>
    </global-block>
  </sr-mpls>
</segment-routing>

```

Command Syntax

```
global block <16-1048575> <16-1048575>
```

Configure start

End range for srlb-config

This command is supported when following feature are enabled sr mpls feature

Attribute Name: end

Attribute Type: uint32

Attribute Range: 16-1048575

Attribute Name: start

Attribute Type: uint32

Attribute Range: 16-1048575

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <sr-mpls>
    <local-block>
      <config>
        <start>16</start>
        <end>16</end>
      </config>
    </local-block>
  </sr-mpls>
</segment-routing>
```

Command Syntax

```
local block <16-1048575> <16-1048575>
```

Configure fast reroute enable

Enable fast reroute for traffic engineering polices

Attribute Name: fast-reroute-enable

Attribute Type: empty

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <config>
      </fast-reroute-enable><!-- operation="delete"-->
    </config>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
policy-fast-reroute-enable
```

Configure list name

Segment-list name

Attribute Name: list-name

Attribute Type: string

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <attributes>
      <segment-lists>
        <segment-list> <!-- operation="delete"-->
          <list-name>WORD</list-name>
          <config>
            <list-name>WORD</list-name>
          </config>
        </segment-list>
      </segment-lists>
    </attributes>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
segment-list WORD
```

Configure sid value

MPLS label value

Attribute Name: sid-value

Attribute Type: uint32

Attribute Range: 0-1048575

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <attributes>
      <segment-lists>
        <segment-list>
          <list-name>WORD</list-name>
          <config>
            <list-name>WORD</list-name>
          </config>
        </segment-list>
      </segment-lists>
    <segments>
      <segment>
        <type>segment-type-1</type>
        <config>
          <type>segment-type-1</type>
          <segment-index>1</segment-index>
        </config>
      </segment>
    </segments>
  </traffic-engineering>
</segment-routing>
```

```
</config>
  <segment-index>1</segment-index>
<segment-type-1>
<config>
  <sid-value>0</sid-value>
</config>
</segment-type-1>
</segment>
</segments>
</segment-list>
</segment-lists>
</attributes>
</traffic-engineering>
</segment-routing>
```

Command Syntax

```
index <1-65535> (segment-type-1) <0-1048575>
```

Configure prefix

SRV6 Prefix

Attribute Name: prefix

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
<traffic-engineering>
<attributes>
<segment-lists>
<segment-list>
  <list-name>WORD</list-name>
  <config>
    <list-name>WORD</list-name>
  </config>
</segment-list>
</segment-lists>
</attributes>
</traffic-engineering>
</segment-routing>
```

```

</segment-list>
</segment-lists>
</attributes>
</traffic-engineering>
</segment-routing>

```

Command Syntax

```
index <1-65535> (segment-type-2) X:X::X:X
```

Configure end point

Policy end point IP address

Attribute Name: end-point

Attribute Type: inet:ip-address

Netconf edit-config payload

```

<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
      <policy-keys>
        <policy-key> <!-- operation="delete"-->
          <end-point>CML_IP_ADDR_T</end-point>
          <config>
            <end-point>CML_IP_ADDR_T</end-point>
            <color>1</color>
          </config>
          <color>1</color>
        </policy-key>
      </policy-keys>
    </policy>
  </policies>
</traffic-engineering>
</segment-routing>

```

Command Syntax

```
color <1-4294967295> end-point (A.B.C.D|X:X::X:X)
```

Configure admin state

SR policy administrative state, true for enabled, false for disabled

Attribute Name: admin-state

Attribute Type: empty

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </admin-state><!-- operation="delete"-->
      </policy>
    </policies>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
admin-state down
```

Configure explicit null

To set explicit null behaviour for the policy

Attribute Name: explicit-null

Attribute Type: enum (ipv4)

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
          <explicit-null>ipv4</explicit-null> <!-- operation="delete"-->
        </config>
      </policy>
    </policies>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
explicit-null (ipv4)
```

Configure cspf retry limit

Limit on the number of times a dynamic candidate path will retry to calculate segment-list

Attribute Name: cspf-retry-limit

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <cspf-retry-limit>1</cspf-retry-limit> <!-- operation="delete"-->
      </policy>
    </policies>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
cspf-retry-limit <1-65535>
```

Configure cspf retry interval

Interval between two successive retries for calculating segment list of a dynamic candidate path using CSPF

Attribute Name: cspf-retry-interval

Attribute Type: uint32

Attribute Range: 1-600

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <cspf-retry-interval>1</cspf-retry-interval> <!-- operation="delete"-->
      </policy>
    </policies>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
cspf-retry-interval <1-600>
```

Configure entropy erld

Setting Policy Entropy ERLD Value to Enable Policy Entropy Capability

Attribute Name: entropy-erld

Attribute Type: uint8

Attribute Range: 3-255

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <entropy-erld>3</entropy-erld> <!-- operation="delete"-->
      </policy>
    </policies>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
entropy-erld <3-255>
```

Configure pce lsp delegate

To delegate all the configured candidate path of policy to PCE controller

Attribute Name: pce-lsp-delegate

Attribute Type: empty

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <pce-lsp-delegate><!-- operation="delete"-->
      </policy>
    </policies>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
pce lsp-delegate
```

Configure pce state report

To only report all the configured candidate path of policy to PCE controller

Attribute Name: pce-state-report

Attribute Type: empty

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        </pce-state-report><!-- operation="delete"-->
      </policy>
    </policies>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
pce state-report
```

Configure pce entity id

Entity Id of PCEP entity to which this policy should be queried/reported/delegated

Attribute Name: pce-entity-id

Attribute Type: uint32

Attribute Range: 1-255

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <pce-entity-id>1</pce-entity-id> <!-- operation="delete"-->
      </policy>
    </policies>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
pce entity <1-255>
```

Configure bsid value

configurable value for static binding sid

Attribute Name: bsid-value

Attribute Type: uint32

Attribute Range: 16-15999

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <bsid-value>16</bsid-value> <!-- operation="delete"-->
      </policy>
    </policies>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
binding-sid mpls label <16-15999>
```

Configure discriminator

Candidate path distinguisher, it's taken as a unique identifier for a Local candidate path

Attribute Name: discriminator

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
      <candidate-paths>
        <candidate-path> <!-- operation="delete"-->
          <originator>WORD</originator>
          <config>
            <originator>WORD</originator>
            <protocol-origin>local</protocol-origin>
          </config>
        </candidate-path>
      </candidate-paths>
    </policies>
  </traffic-engineering>
</segment-routing>
```



```

    <discriminator>1</discriminator>
  </config>
  <protocol-origin>local</protocol-origin>
  <discriminator>1</discriminator>
</candidate-path>
</candidate-paths>
</policy>
</policies>
</traffic-engineering>
</segment-routing>

```

Command Syntax

```
candidate-path <1-65535>
```

Configure protocol origin

Candidate path preference

Attribute Name: preference

Attribute Type: uint32

Default Value: 100

Attribute Range: 1-65535

Netconf edit-config payload

```

<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
      <candidate-paths>
        <candidate-path>
          <originator>WORD</originator>
          <config>
            <originator>WORD</originator>
            <protocol-origin>local</protocol-origin>
            <discriminator>1</discriminator>
          </config>
            <protocol-origin>pcep</protocol-origin>
            <discriminator>1</discriminator>
            <preference>1</preference> <!-- operation="delete"-->
        </candidate-path>
      </candidate-paths>
    </policy>
  </policies>
</traffic-engineering>
</segment-routing>

```

Command Syntax

```
preference <1-65535>
```

Configure pcep

Dynamic candidate path properties of PCEP

Attribute Name: pcep

Attribute Type: empty

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
      <candidate-paths>
        <candidate-path>
          <originator>WORD</originator>
          <config>
            <originator>WORD</originator>
            <protocol-origin>local</protocol-origin>
            <discriminator>1</discriminator>
          </config>
          <protocol-origin>pcep</protocol-origin>
          <discriminator>1</discriminator>
          <dynamic>
            <config>
              </pcep><!-- operation="delete"-->
            </config>
          </dynamic>
        </candidate-path>
      </candidate-paths>
    </policy>
  </policies>
</traffic-engineering>
</segment-routing>
```

Command Syntax

```
dynamic-path pcep
```

Configure isis

Dynamic candidate path properties of ISIS

Attribute Name: isis

Attribute Type: string

Default Value: ""

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
      <candidate-paths>
        <candidate-path>
          <originator>WORD</originator>
          <config>
            <originator>WORD</originator>
            <protocol-origin>local</protocol-origin>
            <discriminator>1</discriminator>
          </config>
          <protocol-origin>pcep</protocol-origin>
          <discriminator>1</discriminator>
        <dynamic>
          <config>
            <isis>WORD</isis> <!-- operation="delete"-->
          </config>
        </dynamic>
      </candidate-path>
    </candidate-paths>
  </policy>
</policies>
</traffic-engineering>
</segment-routing>
```

Command Syntax

```
dynamic-path isis (WORD|)
```

Configure ospf

Dynamic candidate path properties of OSPF with process-id

Attribute Name: ospf

Attribute Type: int32

Attribute Range: 0-65535

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
```

```
<config>
  <name>WORD</name>
</config>
<candidate-paths>
<candidate-path>
  <originator>WORD</originator>
  <config>
    <originator>WORD</originator>
    <protocol-origin>local</protocol-origin>
    <discriminator>1</discriminator>
  </config>
  <protocol-origin>pcep</protocol-origin>
  <discriminator>1</discriminator>
</dynamic>
<config>
  <ospf>0</ospf> <!-- operation="delete"-->
</config>
</dynamic>
</candidate-path>
</candidate-paths>
</policy>
</policies>
</traffic-engineering>
</segment-routing>
```

Command Syntax

```
dynamic-path ospf <0-65535>
```

Configure ospf empty

Dynamic candidate path properties of OSPF without process-id

Attribute Name: ospf-empty

Attribute Type: empty

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
      </policy>
    </policies>
  </traffic-engineering>
  <candidate-paths>
    <candidate-path>
      <originator>WORD</originator>
      <config>
        <originator>WORD</originator>
        <protocol-origin>local</protocol-origin>
      </config>
    </candidate-path>
  </candidate-paths>
</segment-routing>
```

```

    <discriminator>1</discriminator>
  </config>
  <protocol-origin>pcep</protocol-origin>
  <discriminator>1</discriminator>
<dynamic>
<config>
  </ospf-empty><!-- operation="delete"-->
</config>
</dynamic>
</candidate-path>
</candidate-paths>
</policy>
</policies>
</traffic-engineering>
</segment-routing>

```

Command Syntax

```
dynamic-path ospf
```

Configure originator

Enable constraints for the candidate path

Attribute Name: enable

Attribute Type: uint8

Netconf edit-config payload

```

<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
      </policy>
    </policies>
    <candidate-paths>
      <candidate-path>
        <originator>WORD</originator>
        <config>
          <originator>WORD</originator>
          <protocol-origin>local</protocol-origin>
          <discriminator>1</discriminator>
        </config>
        <protocol-origin>local</protocol-origin>
        <discriminator>1</discriminator>
      </candidate-path>
    </candidate-paths>
    <constraints>
      <config>
        </enable>
      </config>
    </constraints>
  </traffic-engineering>
</segment-routing>

```

```
</constraints>
</dynamic>
</candidate-path>
</candidate-paths>
</policy>
</policies>
</traffic-engineering>
</segment-routing>
```

Command Syntax

```
constraints
```

Configure admin group name

admin group name

Attribute Name: admin-group-name

Attribute Type: string

Attribute Name: affinity-type

Attribute Type: enum (exclude-any|include-any|include-all)

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <policies>
      <policy>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
      <candidate-paths>
        <candidate-path>
          <originator>WORD</originator>
          <config>
            <originator>WORD</originator>
            <protocol-origin>local</protocol-origin>
            <discriminator>1</discriminator>
          </config>
          <protocol-origin>local</protocol-origin>
          <discriminator>1</discriminator>
        </dynamic>
      <constraints>
        <admin-groups>
          <admin-group> <!-- operation="delete"-->
            <admin-group-name>ADMIN-GROUP-NAME</admin-group-name>
            <config>
              <admin-group-name>ADMIN-GROUP-NAME</admin-group-name>
              <affinity-type>exclude-any</affinity-type>
            </config>
```

```

    </admin-group>
</admin-groups>
</constraints>
</dynamic>
</candidate-path>
</candidate-paths>
</policy>
</policies>
</traffic-engineering>
</segment-routing>

```

Command Syntax

```
affinity (exclude-any|include-any|include-all) ADMIN-GROUP-NAME
```

Configure metric type

Metric type can be IGP or TE

Attribute Name: metric-type

Attribute Type: enum (igp|te)

Netconf edit-config payload

```

<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
<traffic-engineering>
<policies>
<policy>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<candidate-paths>
<candidate-path>
  <originator>WORD</originator>
  <config>
    <originator>WORD</originator>
    <protocol-origin>local</protocol-origin>
    <discriminator>1</discriminator>
  </config>
    <protocol-origin>pcep</protocol-origin>
    <discriminator>1</discriminator>
  <dynamic>
  <constraints>
  <bounds>
  <bound> <!-- operation="delete"-->
    <metric-type>igp</metric-type>
    <config>
      <metric-type>igp</metric-type>
    </config>
  </bound>
  </bounds>
</bounds>

```

```
</constraints>
</dynamic>
</candidate-path>
</candidate-paths>
</policy>
</policies>
</traffic-engineering>
</segment-routing>
```

Command Syntax

```
metric-type (igp|te)
```

Configure bound

Path is invalid if its metric exceeds this value, If no value is specified

Attribute Name: bound

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
<traffic-engineering>
<policies>
<policy>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
</candidate-paths>
<candidate-path>
  <originator>WORD</originator>
  <config>
    <originator>WORD</originator>
    <protocol-origin>local</protocol-origin>
    <discriminator>1</discriminator>
  </config>
  <protocol-origin>pcep</protocol-origin>
  <discriminator>1</discriminator>
</dynamic>
<constraints>
<bounds>
<bound>
  <metric-type>igp</metric-type>
  <config>
    <metric-type>igp</metric-type>
  </config>
  <bound>1</bound> <!-- operation="delete"-->
</bound>
</bounds>
```



```

</constraints>
</dynamic>
</candidate-path>
</candidate-paths>
</policy>
</policies>
</traffic-engineering>
</segment-routing>

```

Command Syntax

```
metric-type (igp|te) bound <1-4294967295>
```

Configure address

Hop address which needs to be included in the LSP

Attribute Name: address

Attribute Type: inet:ip-address

Attribute Name: type

Attribute Type: enum (loose|strict)

Netconf edit-config payload

```

<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
<traffic-engineering>
<policies>
<policy>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
</candidate-paths>
<candidate-path>
  <originator>WORD</originator>
  <config>
    <originator>WORD</originator>
    <protocol-origin>local</protocol-origin>
    <discriminator>1</discriminator>
  </config>
  <protocol-origin>local</protocol-origin>
  <discriminator>1</discriminator>
</dynamic>
<constraints>
<ip>
<include-hop> <!-- operation="delete"-->
  <address>A.B.C.D/X:X::X:X</address>
  <config>
    <address>A.B.C.D/X:X::X:X</address>
    <type>loose</type>
  </config>

```

```
    </include-hop>
</ip>
</constraints>
</dynamic>
</candidate-path>
</candidate-paths>
</policy>
</policies>
</traffic-engineering>
</segment-routing>
```

Command Syntax

```
A.B.C.D/X:X::X:X (loose|strict|)
```

Configure locator name

Locator name

Attribute Name: locator-name

Attribute Type: string

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <srv6>
    <locators>
      <locator> <!-- operation="delete"-->
        <locator-name>WORD</locator-name>
        <config>
          <locator-name>WORD</locator-name>
        </config>
      </locator>
    </locators>
  </srv6>
</segment-routing>
```

Command Syntax

```
locator WORD
```

Configure options

This attribute is used to enable/disable SR Policy debug logs

Attribute Name: options

Attribute Type: bits (policy|cp|pce|all)

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <debug>
    <config>
      <options>policy</options> <!-- operation="delete"-->
    </config>
  </debug>
</segment-routing>
```

```

</config>
</debug>
</segment-routing>

```

Command Syntax

```
debug sr-policy (policy|cp|pce|all|)
```

debug sr-policy (policy|cp|pce|all|)

Attribute Name: terminal-debug-options

Attribute Type: bits (policy|cp|pce|all)

Netconf RPC payload

```

<sr-policy-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
segment-routing">
  <terminal-debug-options>policy</terminal-debug-options>
</sr-policy-terminal-debug-on>

```

Command Syntax

```
debug sr-policy (policy|cp|pce|all|)
```

no debug sr-policy (policy|cp|pce|all|)

Attribute Name: terminal-debug-options

Attribute Type: bits (policy|cp|pce|all)

Netconf RPC payload

```

<sr-policy-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
segment-routing">
  <terminal-debug-options>policy</terminal-debug-options>
</sr-policy-terminal-debug-off>

```

Command Syntax

```
no debug sr-policy (policy|cp|pce|all|)
```

IPI-L2VPN-VPLS

Configure service template name

Specify Customer service template name to bind to this Attachment circuit

Attribute Name: service-template-name

Attribute Type: string

Netconf edit-config payload

```

<vpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
  <attachment-circuit>

```

```
<service-template-mappings>
<service-template-mapping> <!-- operation="delete"-->
  <service-template-name>NAME</service-template-name>
  <config>
    <service-template-name>WORD</service-template-name>
    <vpls-name>WORD</vpls-name>
    <interface-name>WORD</interface-name>
  </config>
</vpls-name>NAME</vpls-name>
<interface-name>WORD</interface-name>
</service-template-mapping>
</service-template-mappings>
</attachment-circuit>
</vpls>
```

Command Syntax

```
mpls-vpls NAME service-template NAME
```

Configure admin status

Specify admin status for VPLS AC

Attribute Name: admin-status

Attribute Type: enum (down)

Netconf edit-config payload

```
<vpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
<attachment-circuit>
<service-template-mappings>
<service-template-mapping>
  <service-template-name>NAME</service-template-name>
  <config>
    <service-template-name>WORD</service-template-name>
    <vpls-name>WORD</vpls-name>
    <interface-name>WORD</interface-name>
  </config>
  <vpls-name>NAME</vpls-name>
  <interface-name>WORD</interface-name>
  <admin-status>down</admin-status> <!-- operation="delete"-->
</service-template-mapping>
</service-template-mappings>
</attachment-circuit>
</vpls>
```

Command Syntax

```
ac-admin-status (down)
```

Configure attachment circuit description

Specify description of VPLS AC

Attribute Name: attachment-circuit-description

Attribute Type: string

Netconf edit-config payload

```
<vpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
  <attachment-circuit>
    <service-template-mappings>
    <service-template-mapping>
      <service-template-name>NAME</service-template-name>
      <config>
        <service-template-name>WORD</service-template-name>
        <vpls-name>WORD</vpls-name>
        <interface-name>WORD</interface-name>
      </config>
    </service-template-mapping>
    </service-template-mappings>
  </attachment-circuit>
  <attachment-circuit-description>LINE</attachment-circuit-description> <!--
operation="delete"-->
</vpls>
```

Command Syntax

```
ac-description LINE
```

Configure mac learning

Specify mac-learning for VPLS AC

Attribute Name: mac-learning

Attribute Type: enum (enable|disable)

Netconf edit-config payload

```
<vpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
  <attachment-circuit>
    <service-template-mappings>
    <service-template-mapping>
      <service-template-name>NAME</service-template-name>
      <config>
        <service-template-name>WORD</service-template-name>
        <vpls-name>WORD</vpls-name>
        <interface-name>WORD</interface-name>
      </config>
    </service-template-mapping>
    </service-template-mappings>
  </attachment-circuit>
  <mac-learning>enable</mac-learning> <!-- operation="delete"-->
</vpls>
```

```
</vpls>
```

Command Syntax

```
learning (enable|disable)
```

Configure split horizon

Specify split-horizon for VPLS

Attribute Name: split-horizon

Attribute Type: enum (network|access1|access2)

Netconf edit-config payload

```
<vpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
  <attachment-circuit>
    <service-template-mappings>
      <service-template-mapping>
        <service-template-name>NAME</service-template-name>
        <config>
          <service-template-name>WORD</service-template-name>
          <vpls-name>WORD</vpls-name>
          <interface-name>WORD</interface-name>
        </config>
        <vpls-name>NAME</vpls-name>
        <interface-name>WORD</interface-name>
        <split-horizon>network</split-horizon> <!-- operation="delete"-->
      </service-template-mapping>
    </service-template-mappings>
  </attachment-circuit>
</vpls>
```

Command Syntax

```
split-horizon group (network|access1|access2)
```

Configure static mac address

Specify static-mac to be added on AC

Attribute Name: static-mac-address

Attribute Type: string

Netconf edit-config payload

```
<vpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
  <attachment-circuit>
    <service-template-mappings>
      <service-template-mapping>
        <service-template-name>NAME</service-template-name>
        <config>
          <service-template-name>WORD</service-template-name>
          <vpls-name>WORD</vpls-name>
        </config>
      </service-template-mapping>
    </service-template-mappings>
  </attachment-circuit>
</vpls>
```

```

        <interface-name>WORD</interface-name>
    </config>
    <vpls-name>NAME</vpls-name>
    <interface-name>WORD</interface-name>
    <static-mac-address>XXXX.XXXX.XXXX</static-mac-address> <!-- operation="delete"-
->
</service-template-mapping>
</service-template-mappings>
</attachment-circuit>
</vpls>

```

Command Syntax

```
static-mac XXXX.XXXX.XXXX
```

Configure profile name

Specify profile name for map profile

This command is supported when following feature are enabled QOS feature

Attribute Name: profile-name

Attribute Type: string

Netconf edit-config payload

```

<vpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
<attachment-circuit>
<service-template-mappings>
<service-template-mapping>
    <service-template-name>NAME</service-template-name>
    <config>
        <service-template-name>WORD</service-template-name>
        <vpls-name>WORD</vpls-name>
        <interface-name>WORD</interface-name>
    </config>
    <vpls-name>NAME</vpls-name>
    <interface-name>WORD</interface-name>
</service-template-mapping>
</service-template-mappings>
<quality-of-service-profiles>
<quality-of-service-profile> <!-- operation="delete"-->
    <profile-name>NAME</profile-name>
    <config>
        <profile-name>WORD</profile-name>
        <profile-type>cos-to-queue</profile-type>
    </config>
    <profile-type>cos-to-queue</profile-type>
</quality-of-service-profile>
</quality-of-service-profiles>
</service-template-mapping>
</service-template-mappings>
</attachment-circuit>
</vpls>

```

Command Syntax

```
vc-qos map-profile (cos-to-queue|queue-color-to-cos) NAME
```

Configure out label

Specify out going label for VPLS static forwarding

Attribute Name: out-label

Attribute Type: uint32

Attribute Range: 16-15999

Attribute Name: in-label

Attribute Type: uint32

Attribute Range: 16-15999

Attribute Name: out-interface-name

Attribute Type: string

Netconf edit-config payload

```
<vpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
  <static-forwarding>
    <vpls-entries>
      <vpls-entry>
        <peer-address>A.B.C.D</peer-address>
        <config>
          <peer-address>A.B.C.D</peer-address>
          <vpls-identifier>1</vpls-identifier>
          <in-label>16</in-label>
          <out-interface-name>OUT-INTF</out-interface-name>
        </config>
        <vpls-identifier>1</vpls-identifier>
        <out-label>16</out-label>
      </vpls-entry>
    </vpls-entries>
  </static-forwarding>
</vpls>
```

Command Syntax

```
vpls fib-entry <1-4294967295> peer A.B.C.D <16-15999> OUT-INTF <16-15999>
```

Configure vpls identifier

Specify out going label for VPLS static forwarding

Attribute Name: out-label

Attribute Type: uint32

Attribute Range: 16-15999

Attribute Name: in-label

Attribute Type: uint32

Attribute Range: 16-15999

Attribute Name: out-interface-name

Attribute Type: string

Netconf edit-config payload

```
<vpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
  <static-forwarding>
    <hierarchical-vpls-entries>
      <hierarchical-vpls-entry>
        <spoke-pseudowire-name>VC-NAME</spoke-pseudowire-name>
        <config>
          <spoke-pseudowire-name>WORD</spoke-pseudowire-name>
          <vpls-identifier>1</vpls-identifier>
          <in-label>16</in-label>
          <out-interface-name>OUT-INTF</out-interface-name>
        </config>
        <vpls-identifier>1</vpls-identifier>
        <out-label>16</out-label>
      </hierarchical-vpls-entry>
    </hierarchical-vpls-entries>
  </static-forwarding>
</vpls>
```

Command Syntax

```
vpls fib-entry <1-4294967295> spoke-vc WORD <16-15999> OUT-INTF <16-15999>
```

Configure enable

This attribute is used to enable VPLS service on Subinterface

This command is supported when following feature are enabled Subinterface feature

Attribute Name: enable

Attribute Type: uint8

Netconf edit-config payload

```
<vpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <vpls-access>
      <config>
        </enable>
      </config>
    </vpls-access>
```

```
</interface>  
</interfaces>  
</vpls>
```

Command Syntax

```
access-if-vpls
```

Configure vpls name

This attribute uniquely identifies a VPLS service on Subinterface

This command is supported when following feature are enabled Subinterface feature

Attribute Name: vpls-name

Attribute Type: string

Attribute Range: 1-128

Netconf edit-config payload

```
<vpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">  
<interfaces>  
<interface>  
  <name>WORD</name>  
  <config>  
    <name>WORD</name>  
  </config>  
<vpls-access>  
<config>  
  <vpls-name>NAME</vpls-name> <!-- operation="delete" -->  
</config>  
</vpls-access>  
</interface>  
</interfaces>  
</vpls>
```

Command Syntax

```
mpls-vpls NAME
```

Configure disable mac learning

Use this attribute to disable dynamic learning of MAC's

This command is supported when following feature are enabled Subinterface feature

Attribute Name: disable-mac-learning

Attribute Type: empty

Netconf edit-config payload

```
<vpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">  
<interfaces>  
<interface>  
  <name>WORD</name>
```

```

    <config>
      <name>WORD</name>
    </config>
  </vpls-access>
</config>
</vpls-access>
</interface>
</interfaces>
</vpls>

```

Command Syntax

```
learning disable
```

Configure name

Specify static-mac to be added on L2VPN VPLS

This command is supported when following feature are enabled Subinterface feature

Attribute Name: static-mac-address

Attribute Type: string

Netconf edit-config payload

```

<vpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </vpls-access>
  </config>
  <static-mac-address>XXXX.XXXX.XXXX</static-mac-address> <!--
operation="delete"-->
</config>
</vpls-access>
</interface>
</interfaces>
</vpls>

```

Command Syntax

```
static-mac XXXX.XXXX.XXXX
```

Configure vpls identifier

Network Instance Name. For VRF and MAC VRF, instance name can be up to 32 chars long. For VPWS and VPLS instances, instance name can be up to 128 chars long. For L2NI (bridge) instance, instance name has to be a number between (1-32). For Cross-Connect, instance name can be up to 30 chars long. For Bridge-domain, instance, instance name has to be a number between (1-2147483647).

Attribute Name: instance-name

Attribute Type: string

Attribute Name: vpls-identifier

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance> <!-- operation="delete"-->
    <instance-type>vpls</instance-type>
    <config>
      <instance-type>vpls</instance-type>
      <instance-name>WORD</instance-name>
    </config>
    <instance-name>WORD</instance-name>
  </network-instance>
  <vpls-instance>
    <config>
      <vpls-identifier>1</vpls-identifier>
    </config>
  </vpls-instance>
</network-instances>
```

Command Syntax

```
mpls vpls NAME <1-4294967295>
```

Configure service transport identifier

Specify service transport identifier

Attribute Name: service-transport-identifier

Attribute Type: enum (dot1.q|dot1.ad|0x9100|0x9200)

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
      <config>
        <service-transport-identifier>dot1.q</service-transport-identifier> <!--
operation="delete"-->
      </config>
    </vpls-instance>
  </network-instance>
</network-instances>
```

```

</vpls-instance>
</network-instance>
</network-instances>

```

Command Syntax

```
service-tpid (dot1.q|dot1.ad|0x9100|0x9200)
```

Configure maximum transmission unit

Set the Maximum Transmission Unit (MTU) size for a given VPLS instance. This size is signaled to peer VPLS routers

Attribute Name: maximum-transmission-unit

Attribute Type: uint16

Default Value: 1500

Attribute Range: 576-65535

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
      <config>
        <maximum-transmission-unit>576</maximum-transmission-unit> <!--
operation="delete"-->
      </config>
    </vpls-instance>
  </network-instance>
</network-instances>

```

Command Syntax

```
vpls-mtu <576-65535>
```

Configure vpls description

Specify a description for this VPLS instance

Attribute Name: vpls-description

Attribute Type: string

Default Value: NULL

Attribute Range: 1-64

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
  <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
    <config>
      <vpls-description>LINE</vpls-description> <!-- operation="delete"-->
    </config>
  </vpls-instance>
</network-instance>
</network-instances>
```

Command Syntax

```
vpls-description LINE
```

Configure control word

Control Word for VPLS instance

Attribute Name: control-word

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
  <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
    <config>
      </control-word><!-- operation="delete"-->
    </config>
  </vpls-instance>
</network-instance>
</network-instances>
```

Command Syntax

```
control-word
```

Configure mac learning disable

Specify mac learning disable for VPLS instance

Attribute Name: mac-learning-disable

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
      <config>
        </mac-learning-disable><!-- operation="delete"-->
      </config>
    </vpls-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
learning disable
```

Configure mac learning limit

Specify mac learning limit

Attribute Name: mac-learning-limit

Attribute Type: uint32

Default Value: 32767

Attribute Range: 5-32767

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
      <config>
        <mac-learning-limit>5</mac-learning-limit> <!-- operation="delete"-->
      </config>
    </vpls-instance>
  </network-instance>
</network-instances>
```

```
</config>
</vpls-instance>
</network-instance>
</network-instances>
```

Command Syntax

```
learning limit <5-32767>
```

Configure attachment circuit group name

Specify ac-group name

Attribute Name: attachment-circuit-group-name

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
      <config>
        <attachment-circuit-group-name>GROUPNAME</attachment-circuit-group-name>
      </config>
    </vpls-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
vpls-ac-group GROUPNAME
```

Configure pseudowire type

Specify pseudowire type

Attribute Name: pseudowire-type

Attribute Type: enum (vlan|ethernet)

Default Value: ethernet

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
```



```

<config>
  <instance-name>WORD</instance-name>
  <instance-type>vpls</instance-type>
</config>
  <instance-type>vpls</instance-type>
<vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
<spoke-pseudowires>
<spoke-pseudowire>
  <pseudowire-name>WORD</pseudowire-name>
  <config>
    <pseudowire-name>NAME</pseudowire-name>
  </config>
  <pseudowire-type>ethernet</pseudowire-type> <!-- operation="delete"-->
</spoke-pseudowire>
</spoke-pseudowires>
</vpls-instance>
</network-instance>
</network-instances>

```

Command Syntax

```
vpls-vc NAME ((vlan|ethernet)|)
```

Configure enable interface parameter tlv

Use this attribute to configure interface parameter tlv for VPLS Virtual Circuits.

Attribute Name: enable-interface-parameter-tlv

Attribute Type: empty

Attribute Name: enable-flow-label

Attribute Type: empty

Attribute Name: flow-label-direction

Attribute Type: enum (both|transmit|receive)

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
  <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
    <fat-label>
      <config>
        </enable-flow-label><!-- operation="delete"-->
        <flow-label-direction>both</flow-label-direction> <!--
operation="delete"-->

```

```

        </enable-interface-parameter-tlv><!-- operation="delete"-->
    </config>
</fat-label>
</vpls-instance>
</network-instance>
</network-instances>

```

Command Syntax

```
flow-label (both|transmit|receive) interface-param-tlv
```

Configure enable static flow label

Use this attribute to configure static flow label for VPLS Virtual Circuits.

Attribute Name: enable-static-flow-label

Attribute Type: empty

Attribute Name: enable-flow-label

Attribute Type: empty

Attribute Name: flow-label-direction

Attribute Type: enum (both|transmit|receive)

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
      <fat-label>
        <config>
          </enable-flow-label><!-- operation="delete"-->
          <flow-label-direction>both</flow-label-direction> <!--
operation="delete"-->
          </enable-static-flow-label><!-- operation="delete"-->
        </config>
      </fat-label>
    </vpls-instance>
  </network-instance>
</network-instances>

```

Command Syntax

```
flow-label (both|transmit|receive) static
```

Configure flow label direction

Use this attribute to configure flow label direction to transmit, receive or both for VPLS Virtual Circuits

Attribute Name: flow-label-direction

Attribute Type: enum (both|transmit|receive)

Attribute Name: enable-flow-label

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
      <fat-label>
        <config>
          </enable-flow-label><!-- operation="delete"-->
          <flow-label-direction>both</flow-label-direction> <!--
operation="delete"-->
        </config>
      </fat-label>
    </vpls-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
flow-label (both|transmit|receive)
```

Configure signaling protocol ldp

Specify protocol used for signaling is ldp

Attribute Name: signaling-protocol-ldp

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
```

```
    <instance-type>vpls</instance-type>
  <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
    <vpls-peers>
      <config>
        </signaling-protocol-ldp>
      </config>
    </vpls-peers>
  </vpls-instance>
</network-instance>
</network-instances>
```

Command Syntax

```
signaling ldp
```

Configure disable mac withdrawal

Specify mac address withdrawal disable

Attribute Name: disable-mac-withdrawal

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
      <vpls-peers>
        <config>
          </disable-mac-withdrawal><!-- operation="delete"-->
        </config>
      </vpls-peers>
    </vpls-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
mac-withdrawal disable
```

Configure vpls encapsulation type

Specify encapsulation type

Attribute Name: vpls-encapsulation-type

Attribute Type: enum (vlan|ethernet)

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
      <vpls-peers>
        <config>
          <vpls-encapsulation-type>ethernet</vpls-encapsulation-type> <!--
operation="delete"-->
        </config>
      </vpls-peers>
    </vpls-instance>
  </network-instance>
</network-instances>

```

Command Syntax

```
vpls-type (vlan|ethernet)
```

Configure peer address

Specify VPLS peer address

Attribute Name: peer-address

Attribute Type: string

Attribute Name: peer-type

Attribute Type: enum (manual)

Default Value: manual

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
      <vpls-peers>
        <vpls-peer> <!-- operation="delete"-->
          <peer-address>A.B.C.D</peer-address>
        </vpls-peer>
      </vpls-peers>
    </vpls-instance>
  </network-instance>
</network-instances>

```

```
        <peer-address>A.B.C.D</peer-address>
        <peer-type>manual</peer-type>
    </config>
</vpls-peer>
</vpls-peers>
</vpls-instance>
</network-instance>
</network-instances>
```

Command Syntax

```
vpls-peer A.B.C.D (manual)
```

Configure instance name

Specify VPLS peer address

Attribute Name: peer-address

Attribute Type: string

Attribute Name: tunnel-name

Attribute Type: string

Attribute Name: peer-type

Attribute Type: enum (manual)

Default Value: manual

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
      <vpls-peers>
        <vpls-peer <!-- operation="delete"-->
          <peer-address>A.B.C.D</peer-address>
          <config>
            <peer-address>A.B.C.D</peer-address>
            <tunnel-name>TUNNELNAME</tunnel-name>
            <peer-type>manual</peer-type>
          </config>
        </vpls-peer>
      </vpls-peers>
    </vpls-instance>
  </network-instance>
</network-instances>
```

Command Syntax

```
vpls-peer A.B.C.D tunnel-name TUNNELNAME (manual)
```

Configure instance type

Specify VPLS peer address

Attribute Name: peer-address

Attribute Type: string

Attribute Name: tunnel-identifier

Attribute Type: uint32

Attribute Name: peer-type

Attribute Type: enum (manual)

Default Value: manual

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
    <vpls-peers>
    <vpls-peer> <!-- operation="delete"-->
      <peer-address>A.B.C.D</peer-address>
      <config>
        <peer-address>A.B.C.D</peer-address>
        <tunnel-identifier>1</tunnel-identifier>
        <peer-type>manual</peer-type>
      </config>
    </vpls-peer>
    </vpls-peers>
    </vpls-instance>
    </network-instance>
  </network-instances>
```

Command Syntax

```
vpls-peer A.B.C.D tunnel-id <1-5000> (manual)
```

Configure tunnel policy

Specify VPLS peer address

Attribute Name: peer-address

Attribute Type: string

Attribute Name: tunnel-policy

Attribute Type: string

Attribute Name: peer-type

Attribute Type: enum (manual)

Default Value: manual

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
    <vpls-peers>
    <vpls-peer> <!-- operation="delete"-->
      <peer-address>A.B.C.D</peer-address>
      <config>
        <peer-address>A.B.C.D</peer-address>
        <tunnel-policy>POLICYNAME</tunnel-policy>
        <peer-type>manual</peer-type>
      </config>
    </vpls-peer>
    </vpls-peers>
    </vpls-instance>
    </network-instance>
  </network-instances>
```

Command Syntax

```
vpls-peer A.B.C.D tunnel-select-policy POLICYNAME (manual)
```

Configure tunnel name

Specify tunnel name

Attribute Name: tunnel-name

Attribute Type: string

Attribute Range: 1-128

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
```



```

<config>
  <instance-name>WORD</instance-name>
  <instance-type>vpls</instance-type>
</config>
  <instance-type>vpls</instance-type>
<vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
<vpls-peers>
<vpls-peer>
  <peer-address>A.B.C.D</peer-address>
  <config>
    <peer-address>A.B.C.D</peer-address>
  </config>
  <tunnel-name>TUNNELNAME</tunnel-name>
</vpls-peer>
</vpls-peers>
</vpls-instance>
</network-instance>
</network-instances>

```

Command Syntax

```
vpls-peer A.B.C.D tunnel-name TUNNELNAME
```

Configure tunnel identifier

Specify static tunnel identifier value

Attribute Name: tunnel-identifier

Attribute Type: uint32

Attribute Range: 1-5000

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
    <vpls-peers>
    <vpls-peer>
      <peer-address>A.B.C.D</peer-address>
      <config>
        <peer-address>A.B.C.D</peer-address>
      </config>
      <tunnel-identifier>1</tunnel-identifier>
    </vpls-peer>
    </vpls-peers>

```

```
</vpls-instance>  
</network-instance>  
</network-instances>
```

Command Syntax

```
vpls-peer A.B.C.D tunnel-id <1-5000>
```

Configure target attachment individual identifier

Specify the Target Attachment Individual Identifier

Attribute Name: target-attachment-individual-identifier

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-  
instance">  
  <network-instance>  
    <instance-name>WORD</instance-name>  
    <config>  
      <instance-name>WORD</instance-name>  
      <instance-type>vpls</instance-type>  
    </config>  
    <instance-type>vpls</instance-type>  
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">  
      <vpls-peers>  
        <vpls-peer>  
          <peer-address>A.B.C.D</peer-address>  
          <config>  
            <peer-address>A.B.C.D</peer-address>  
          </config>  
          <fec129s>  
            <fec129 <!-- operation="delete"-->  
              <target-attachment-individual-identifier>NAME</target-attachment-  
individual-identifier>  
              <config>  
                <target-attachment-individual-identifier>WORD</target-attachment-  
individual-identifier>  
                <source-attachment-individual-identifier>WORD</source-attachment-  
individual-identifier>  
                <attachment-group-identifier>WORD</attachment-group-identifier>  
              </config>  
              <source-attachment-individual-identifier>NAME</source-attachment-  
individual-identifier>  
              <attachment-group-identifier>NAME</attachment-group-identifier>  
            </fec129>  
          </fec129s>  
        </vpls-peer>  
      </vpls-peers>  
    </vpls-instance>  
  </network-instance>
```

```
</network-instances>
```

Command Syntax

```
agi NAME saii NAME taii NAME
```

Configure attachment group identifier

Specify VPLS peer address

Attribute Name: peer-address

Attribute Type: string

Attribute Name: attachment-group-identifier

Attribute Type: string

Attribute Name: source-attachment-individual-identifier

Attribute Type: string

Attribute Name: target-attachment-individual-identifier

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
    <vpls-peers>
    <vpls-peer> <!-- operation="delete"-->
      <peer-address>A.B.C.D</peer-address>
      <config>
        <peer-address>A.B.C.D</peer-address>
      </config>
    <fec129s>
    <fec129>
      <attachment-group-identifier>NAME</attachment-group-identifier>
      <source-attachment-individual-identifier>NAME</source-attachment-
individual-identifier>
      <target-attachment-individual-identifier>NAME</target-attachment-
individual-identifier>
    </fec129>
    </fec129s>
    </vpls-peer>
  </vpls-peers>
</vpls-instance>
</network-instance>
```

```
</network-instances>
```

Command Syntax

```
vpls-peer A.B.C.D agi NAME saii NAME taii NAME
```

Configure source attachment individual identifier

Specify VPLS peer address

Attribute Name: peer-address

Attribute Type: string

Attribute Name: attachment-group-identifier

Attribute Type: string

Attribute Name: source-attachment-individual-identifier

Attribute Type: string

Attribute Name: target-attachment-individual-identifier

Attribute Type: string

Attribute Name: tunnel-name

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vrf</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
      <vpls-peers>
        <vpls-peer> <!-- operation="delete"-->
          <peer-address>A.B.C.D</peer-address>
          <config>
            <peer-address>A.B.C.D</peer-address>
          </config>
          <fec129s>
            <fec129>
              <attachment-group-identifier>NAME</attachment-group-identifier>
              <source-attachment-individual-identifier>NAME</source-attachment-
individual-identifier>
              <target-attachment-individual-identifier>NAME</target-attachment-
individual-identifier>
              <config>
                <tunnel-name>TUNNELNAME</tunnel-name>
              </config>
            </fec129>
          </fec129s>
        </vpls-peer>
      </vpls-peers>
    </vpls-instance>
  </network-instance>
</network-instances>
```

```

        </fec129s>
    </vpls-peer>
</vpls-peers>
</vpls-instance>
</network-instance>
</network-instances>

```

Command Syntax

```
vpls-peer A.B.C.D agi NAME sai NAME tai NAME tunnel-name TUNNELNAME
```

Configure signaling protocol bgp

Specify protocol used for signaling is bgp

This command is supported when following feature are enabled Mpls BGP feature

Attribute Name: signaling-protocol-bgp

Attribute Type: empty

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
      <bgp-signaling>
        <config>
          </signaling-protocol-bgp>
        </config>
      </bgp-signaling>
    </vpls-instance>
  </network-instance>
</network-instances>

```

Command Syntax

```
signaling bgp
```

Configure vpls edge identifier

Specify VPLS edge identifier value

This command is supported when following feature are enabled Mpls BGP feature

Attribute Name: vpls-edge-identifier

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
    <bgp-signaling>
    <config>
      <vpls-edge-identifier>1</vpls-edge-identifier> <!-- operation="delete"-->
    </config>
  </bgp-signaling>
</vpls-instance>
</network-instance>
</network-instances>
```

Command Syntax

```
ve-id <1-65535>
```

Configure profile type

Specify profile name

This command is supported when following feature are enabled QOS feature

Attribute Name: profile-name

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>vpls</instance-type>
    </config>
    <instance-type>vpls</instance-type>
    <vpls-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
    <quality-of-service-profiles>
    <quality-of-service-profile> <!-- operation="delete"-->
      <profile-name>NAME</profile-name>
      <config>
        <profile-name>WORD</profile-name>
        <profile-type>cos-to-queue</profile-type>
      </config>
      <profile-type>cos-to-queue</profile-type>
    </vpls-instance>
  </network-instance>
</network-instances>
```

```

    </quality-of-service-profile>
  </quality-of-service-profiles>
</vpls-instance>
</network-instance>
</network-instances>

```

Command Syntax

```
vpls-qos map-profile (cos-to-queue|queue-color-to-cos) NAME
```

clear mpls vpls NAME statistics (access-port|network-port)

Attribute Name: port-circuit-name

Attribute Type: string

Attribute Name: port-type

Attribute Type: enum (access-port|network-port)

Netconf RPC payload

```

<clear-mpls-vpls-name-statistics-port-type xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-l2vpn-vpls">
  <port-circuit-name>NAME</port-circuit-name>
  <port-type>access-port</port-type>
</clear-mpls-vpls-name-statistics-port-type>

```

Command Syntax

```
clear mpls vpls NAME statistics (access-port|network-port)
```

clear mpls vpls NAME statistics network-port peer A.B.C.D

Attribute Name: port-circuit-name

Attribute Type: string

Attribute Name: vc-circuit-type

Attribute Type: string

Netconf RPC payload

```

<clear-mpls-vpls-name-statistics-network-port-peer xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
  <port-circuit-name>NAME</port-circuit-name>
  <vc-circuit-type>A.B.C.D</vc-circuit-type>
</clear-mpls-vpls-name-statistics-network-port-peer>

```

Command Syntax

```
clear mpls vpls NAME statistics network-port peer A.B.C.D
```

clear mpls vpls NAME statistics network-port spoke-vc VC_NAME

Attribute Name: port-circuit-name

Attribute Type: string

Attribute Name: vc-circuit-type

Attribute Type: string

Netconf RPC payload

```
<clear-mpls-vpls-name-statistics-network-port-spoke xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
  <port-circuit-name>NAME</port-circuit-name>
  <vc-circuit-type>VC_NAME</vc-circuit-type>
</clear-mpls-vpls-name-statistics-network-port-spoke>
```

Command Syntax

```
clear mpls vpls NAME statistics network-port spoke-vc VC_NAME
```

clear mpls vpls NAME statistics access-port WORD (vlan (<1-4094>)|ethernet)

Attribute Name: port-circuit-name

Attribute Type: string

Attribute Name: vc-interface-name

Attribute Type: string

Attribute Name: vc-access-type

Attribute Type: union

Netconf RPC payload

```
<clear-mpls-vpls-name-statistics-access-port xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
  <port-circuit-name>NAME</port-circuit-name>
  <vc-interface-name>WORD</vc-interface-name>
  <vc-access-type>VPLS_MPLS_ACCESS_TYPE_T</vc-access-type>
</clear-mpls-vpls-name-statistics-access-port>
```

Command Syntax

```
clear mpls vpls NAME statistics access-port WORD (vlan (<1-4094>)|ethernet)
```

clear mpls vpls NAME statistics

Attribute Name: vpls-circuit-name

Attribute Type: string

Netconf RPC payload

```
<clear-mpls-vpls-name-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-l2vpn-vpls">
  <vpls-circuit-name>NAME</vpls-circuit-name>
</clear-mpls-vpls-name-statistics>
```

Command Syntax

```
clear mpls vpls NAME statistics
```

clear mpls vpls NAME mac-addresses

Attribute Name: name

Attribute Type: string

Netconf RPC payload

```
<clear-mpls-vpls-mac-addresses-for-instance xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-l2vpn-vpls">
  <name>NAME</name>
</clear-mpls-vpls-mac-addresses-for-instance>
```

Command Syntax

```
clear mpls vpls NAME mac-addresses
```

clear mpls vpls mac-addresses

Netconf RPC payload

```
<clear-mpls-vpls-mac-addresses-all xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-l2vpn-vpls"/>
```

Command Syntax

```
clear mpls vpls mac-addresses
```

IPI-MCEC

Configure options

Use this attribute to debug the mlag feature.

Attribute Name: options

Attribute Type: bits (hello|info|timer|event|cli|mac-sync|stp|all)

Netconf edit-config payload

```
<mcec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec">
  <debug>
  <config>
    <options>hello</options> <!-- operation="delete"-->
  </config>
</debug>
</mcec>
```

Command Syntax

```
debug mcec (hello|info|timer|event|cli|mac-sync|stp|all)
```

Configure system number

Use this attribute to configure domain system number, which uniquely identifies domain system in MCEC domain

Attribute Name: system-number

Attribute Type: uint8

Attribute Range: 1-2

Netconf edit-config payload

```
<mcec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec">
  <domain>
    <config>
      <system-number>1</system-number> <!-- operation="delete"-->
    </config>
  </domain>
</mcec>
```

Command Syntax

```
domain-system-number <1-2>
```

Configure address

Use this attribute configure domain address, which helps to identify the MCEC domain

Attribute Name: address

Attribute Type: string

Netconf edit-config payload

```
<mcec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec">
  <domain>
    <config>
      <address>MAC</address> <!-- operation="delete"-->
    </config>
  </domain>
</mcec>
```

Command Syntax

```
domain-address MAC
```

Configure priority

Use this attribute to specify the priority value associated with MCEC domain

Attribute Name: priority

Attribute Type: uint16

Default Value: 32768

Attribute Range: 1-65535

Netconf edit-config payload

```
<mcec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec">
  <domain>
    <config>
```

```

    <priority>1</priority> <!-- operation="delete"-->
</config>
</domain>
</mcec>

```

Command Syntax

```
domain-priority <1-65535>
```

Configure hello timeout

Use this attribute to specify the domain hello-timeout value

Attribute Name: hello-timeout

Attribute Type: enum (long|short)

Default Value: long

Netconf edit-config payload

```

<mcec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec">
<domain>
<config>
    <hello-timeout>long</hello-timeout> <!-- operation="delete"-->
</config>
</domain>
</mcec>

```

Command Syntax

```
domain-hello-timeout (long|short)
```

Configure interface

Use this attribute to map an interface as intra domain link that connects the domain system with its neighbour in a mcec domain

Attribute Name: interface

Attribute Type: string

Netconf edit-config payload

```

<mcec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec">
<intra-domain>
<peer-link>
<config>
    <interface>IFNAME</interface> <!-- operation="delete"-->
</config>
</peer-link>
</intra-domain>
</mcec>

```

Command Syntax

```
intra-domain-link IFNAME
```

Configure vrf

vrf of the peer DSN node

Attribute Name: vrf

Attribute Type: string

Attribute Name: peer-address

Attribute Type: inet:ipv4-address

Attribute Name: local-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<mcec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec">
  <intra-domain>
    <peer-address>
      <config>
        <peer-address>A.B.C.D</peer-address>
        <local-address>A.B.C.D</local-address>
        <vrf>VRF_NAME</vrf>
      </config>
    </peer-address>
  </intra-domain>
</mcec>
```

Command Syntax

```
intra-domain-peer A.B.C.D source-address A.B.C.D (vrf VRF_NAME|)
```

Configure interface mode

Use this attribute to set the MC-LAG mode. active-standby: The interface is ready to transition from active to standby state should a failure occur in the other node.

Attribute Name: interface-mode

Attribute Type: enum (active-standby|active-active)

Default Value: active-standby

Netconf edit-config payload

```
<mcec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec">
  <mrag-interfaces>
    <mrag-interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <interface-mode>active-standby</interface-mode> <!-- operation="delete"-->
    </mrag-interface>
  </mrag-interfaces>
</mcec>
```

Command Syntax

```
mode (active-standby|active-active)
```

Configure revertive timer

Use this attribute to set the timer for MC-LAG switchover revertive type. After Revertive timer expires Slave will handover the control to Master Node. If a failure happens that triggers a switchover, after failure recovery the initially-active node becomes active again. Default switchover type is revertive 10s.

Attribute Name: revertive-timer

Attribute Type: uint8

Default Value: 10

Attribute Range: 1-255

Netconf edit-config payload

```
<mcec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec">
  <mlag-interfaces>
    <mlag-interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <switchover-type>
      <config>
        <revertive-timer>1</revertive-timer> <!-- operation="delete"-->
      </config>
    </switchover-type>
  </mlag-interface>
</mlag-interfaces>
</mcec>
```

Command Syntax

```
switchover type revertive <1-255>
```

Configure enable non revertive

Use this attribute to set the MC-LAG switchover to non-revertive type. Do not switch back to the initially-active node after failure recovery. Default switchover type is revertive 10s.

Attribute Name: enable-non-revertive

Attribute Type: empty

Netconf edit-config payload

```
<mcec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec">
  <mlag-interfaces>
    <mlag-interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </mlag-interface>
  </mlag-interfaces>
</mcec>
```

```
</config>
<switchover-type>
<config>
  </enable-non-revertive><!-- operation="delete"-->
</config>
</switchover-type>
</mlag-interface>
</mlag-interfaces>
</mcec>
```

Command Syntax

```
switchover type non-revertive
```

debug mcec (hello|info|timer|event|cli|mac-sync|stp|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (hello|info|timer|event|cli|mac-sync|stp|all)

Netconf RPC payload

```
<mcec-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec">
  <terminal-debug-options>hello</terminal-debug-options>
</mcec-terminal-debug-on>
```

Command Syntax

```
debug mcec (hello|info|timer|event|cli|mac-sync|stp|all)
```

no debug mcec (hello|info|timer|event|cli|mac-sync|stp|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (hello|info|timer|event|cli|mac-sync|stp|all)

Netconf RPC payload

```
<mcec-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec">
  <terminal-debug-options>hello</terminal-debug-options>
</mcec-terminal-debug-off>
```

Command Syntax

```
no debug mcec (hello|info|timer|event|cli|mac-sync|stp|all)
```

clear mcec statistics

Netconf RPC payload

```
<clear-mcec-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec"/>
```

Command Syntax

```
clear mcec statistics
```

reload-trigger-mcec-notification

Netconf RPC payload

```
<trigger-reload xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mcec"/>
```

Command Syntax

```
reload-trigger-mcec-notification
```

IPI-MLAG

Configure mlag id

MLAG group number

Attribute Name: mlag-id

Attribute Type: uint16

Attribute Range: 1-255

Netconf edit-config payload

```
<interfaces xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-interface">
  <interface>
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
    </config>
    <mlag-aggregation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mlag">
      <config>
        <mlag-id>1</mlag-id>
      </config>
    </mlag-aggregation>
  </interface>
</interfaces>
```

Command Syntax

```
mlag <1-255>
```

reload-trigger-save-mlag-info

Netconf RPC payload

```
<trigger-save-mlag-info xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-mlag"/>
```

Command Syntax

```
reload-trigger-save-mlag-info
```

IPI-PLATFORM

Configure enable cmm

Use this attribute to turn on debugging for chassis monitoring

Attribute Name: enable-cmm

Attribute Type: empty

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <debug>
    <config>
      </enable-cmm><!-- operation="delete"-->
    </config>
  </debug>
</components>
```

Command Syntax

```
debug cmm
```

Configure enable ddm

Use this attribute to turn on debugging for digital diagnostic monitoring

Attribute Name: enable-ddm

Attribute Type: empty

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <debug>
    <config>
      </enable-ddm><!-- operation="delete"-->
    </config>
  </debug>
</components>
```

Command Syntax

```
debug ddm
```

Configure warning repeat

To enable cmm warning level logs to repeat.

Attribute Name: warning-repeat

Attribute Type: empty

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <global>
  <config>
    </warning-repeat><!-- operation="delete"-->
  </config>
</global>
</components>
```

Command Syntax

```
cmm warning repeat
```

Configure locator led enable

To set the locator-led on or off.

Attribute Name: locator-led-enable

Attribute Type: empty

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <global>
  <config>
    </locator-led-enable><!-- operation="delete"-->
  </config>
</global>
</components>
```

Command Syntax

```
locator-led on
```

Configure ddm monitor time interval

To set DDM Monitor interval time.

Attribute Name: ddm-monitor-time-interval

Attribute Type: uint16

Attribute Range: 60-3600

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <global>
  <config>
    <ddm-monitor-time-interval>60</ddm-monitor-time-interval> <!--
operation="delete"-->
  </config>
</global>
</components>
```

Command Syntax

```
ddm monitor interval <60-3600>
```

Configure service unsupported transceiver

To enable DDM Monitor for unsupported transceivers at user risk.

Attribute Name: service-unsupported-transceiver

Attribute Type: empty

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <global>
    <config>
      </service-unsupported-transceiver><!-- operation="delete"-->
    </config>
  </global>
</components>
```

Command Syntax

```
service unsupported-transceiver
```

Configure enable ddm monitor

To enable DDM monitor for all transceivers.

Attribute Name: enable-ddm-monitor

Attribute Type: empty

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <global>
    <config>
      </enable-ddm-monitor><!-- operation="delete"-->
    </config>
  </global>
</components>
```

Command Syntax

```
ddm monitor all
```

Configure system 15min load avg alarm

System 15min average load for alarm

Attribute Name: system-15min-load-avg-alarm

Attribute Type: uint8

Attribute Range: 51-100

Netconf edit-config payload

```

<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <global>
    <system-load-average-thresholds>
      <system-load-average-threshold> <!-- operation="delete"-->
        <system-15min-load-avg-alarm>51</system-15min-load-avg-alarm>
      <config>
        <system-15min-load-avg-alarm>51</system-15min-load-avg-alarm>
        <system-5min-load-avg-alarm>51</system-5min-load-avg-alarm>
        <system-1min-load-avg-alarm>51</system-1min-load-avg-alarm>
        <system-1min-load-avg-warning-threshold>41</system-1min-load-avg-warning-
threshold>
      </config>
      <system-5min-load-avg-alarm>51</system-5min-load-avg-alarm>
      <system-1min-load-avg-alarm>51</system-1min-load-avg-alarm>
      <system-1min-load-avg-warning-threshold>41</system-1min-load-avg-warning-
threshold>
    </system-load-average-threshold>
  </system-load-average-thresholds>
</global>
</components>

```

Command Syntax

```

system-load-average 1min warning <41-100> alarm <51-100> 5min alarm <51-100> 15min
alarm <51-100>

```

Configure alarm threshold

Cpu threshold for alarm

Attribute Name: alarm-threshold

Attribute Type: uint8

Attribute Range: 91-100

Netconf edit-config payload

```

<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <global>
    <cpu-core-usage-thresholds>
      <cpu-core-usage-threshold> <!-- operation="delete"-->
        <alarm-threshold>91</alarm-threshold>
      <config>
        <alarm-threshold>91</alarm-threshold>
        <warning-threshold>51</warning-threshold>
      </config>
      <warning-threshold>51</warning-threshold>
    </cpu-core-usage-threshold>
  </cpu-core-usage-thresholds>
</global>
</components>

```

Command Syntax

```
cpu-core-usage warning <51-100> alarm <91-100>
```

Configure gps position disable

gps position disable

This command is supported when following feature are enabled PTP hardware offload feature enabled

Attribute Name: gps-position-disable

Attribute Type: empty

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <global>
    <gps-position>
      <config>
        </gps-position-disable><!-- operation="delete"-->
      </config>
    </gps-position>
  </global>
</components>
```

Command Syntax

```
gps position disable
```

Configure gps survey in position accuracy

GPS position accuracy

This command is supported when following feature are enabled PTP hardware offload feature enabled

Attribute Name: gps-survey-in-position-accuracy

Attribute Type: uint32

Attribute Range: 1-10000

Attribute Name: gps-survey-in-observation-time

Attribute Type: uint32

Attribute Range: 1-1440

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <global>
    <gps-position>
      <config>
        <gps-survey-in-observation-time>1</gps-survey-in-observation-time> <!--
operation="delete"-->
        <gps-survey-in-position-accuracy>1</gps-survey-in-position-accuracy> <!--
operation="delete"-->
      </config>
    </gps-position>
  </global>
</components>
```

```
</global>
</components>
```

Command Syntax

```
gps position survey-in <1-1440> <1-10000>
```

Configure gps fixed altitude

GPS fixed altitude in meters

This command is supported when following feature are enabled PTP hardware offload feature enabled

Attribute Name: gps-fixed-altitude

Attribute Type: decimal64

Attribute Name: gps-fixed-latitude

Attribute Type: decimal64

Attribute Name: gps-fixed-longitude

Attribute Type: decimal64

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<global>
<gps-position>
<config>
  <gps-fixed-latitude>LATITUDE</gps-fixed-latitude> <!-- operation="delete"-->
  <gps-fixed-longitude>LONGITUDE</gps-fixed-longitude> <!-- operation="delete"-->
  <gps-fixed-altitude>ALTITUDE</gps-fixed-altitude> <!-- operation="delete"-->
</config>
</gps-position>
</global>
</components>
```

Command Syntax

```
gps position fixed LATITUDE LONGITUDE ALTITUDE
```

Configure monitor port

To enable DDM monitor for current transceiver.

This command is supported when following feature are disabled Tibit MicroPlug OLT feature

Attribute Name: monitor-port

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<interfaces>
<interface>
  <interface-name>WORD</interface-name>
<config>
```

```
<interface-name>WORD</interface-name>
</config>
<monitor-port>disable</monitor-port> <!-- operation="delete"-->
</interface>
</interfaces>
</components>
```

Command Syntax

```
ddm monitor (disable|enable)
```

Configure poe enable

To enable PoE for current interface.

This command is supported when following feature are disabled Tibit MicroPlug OLT feature

Attribute Name: poe-enable

Attribute Type: empty

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<interfaces>
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  </poe-enable><!-- operation="delete"-->
</interface>
</interfaces>
</components>
```

Command Syntax

```
poe-enable
```

Configure raon aodu port

To enable RAON AODU connectivity over physical port.

This command is supported when following feature are disabled Tibit MicroPlug OLT feature

Attribute Name: raon-aodu-port

Attribute Type: enum (enable)

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<interfaces>
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  </raon-aodu-port><!-- operation="delete"-->
</interface>
</interfaces>
</components>
```

```

    </config>
    <raon-aodu-port>enable</raon-aodu-port> <!-- operation="delete"-->
</interface>
</interfaces>
</components>

```

Command Syntax

```
raon (enable)
```

Configure transceiver code

To set transceiver code for current transceiver.

This command is supported when following feature are disabled Tibit MicroPlug OLT feature

Attribute Name: transceiver-code

Attribute Type: enum (1000base-sx|1000base-lx|1000base-ex|1000base-cx|10gbase-sr|10gbase-lr|10gbase-er|10gbase-cr|25gbase-sr|25gbase-lr|25gbase-er|25gbase-cr|40gbase-sr4|40gbase-lr4|40gbase-er4|40gbase-cr4|100gbase-sr4|100gbase-lr4|100gbase-er4|100gbase-cr4)

Netconf edit-config payload

```

<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <interfaces>
    <interface>
      <interface-name>WORD</interface-name>
      <config>
        <interface-name>WORD</interface-name>
      </config>
      <transceiver-code>1000base-sx</transceiver-code> <!-- operation="delete"-->
    </interface>
  </interfaces>
</components>

```

Command Syntax

```
transceiver (1000base-sx|1000base-lx|1000base-ex|1000base-cx|10gbase-sr|10gbase-
lr|10gbase-er|10gbase-cr|25gbase-sr|25gbase-lr|25gbase-er|25gbase-cr|40gbase-
sr4|40gbase-lr4|40gbase-er4|40gbase-cr4|100gbase-sr4|100gbase-lr4|100gbase-
er4|100gbase-cr4)
```

Configure wavelength

wavelength

This command is supported when following feature are disabled Tibit MicroPlug OLT feature

Attribute Name: wavelength

Attribute Type: union

Netconf edit-config payload

```

<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <interfaces>

```

```
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  <wavelength>CML_WAVELENGTH_T</wavelength>
</interface>
</interfaces>
</components>
```

Command Syntax

```
wavelength (channel-number <1-96>|update <1528773-1566723>)
```

Configure tx disable

To disable laser tx for current transceiver.

This command is supported when following feature are disabled Tibit MicroPlug OLT feature

Attribute Name: tx-disable

Attribute Type: empty

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <interfaces>
    <interface>
      <interface-name>WORD</interface-name>
      <config>
        <interface-name>WORD</interface-name>
      </config>
      </tx-disable><!-- operation="delete"-->
    </interface>
  </interfaces>
</components>
```

Command Syntax

```
tx-disable
```

Configure edfa operating mode

To set the EDFA operating mode

This command is supported when following feature are disabled Tibit MicroPlug OLT feature

Attribute Name: edfa-operating-mode

Attribute Type: enum (agc|apc)

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <interfaces>
    <interface>
```



```

<interface-name>WORD</interface-name>
<config>
  <interface-name>WORD</interface-name>
</config>
<edfa-operating-mode>agc</edfa-operating-mode> <!-- operation="delete"-->
</interface>
</interfaces>
</components>

```

Command Syntax

```
edfa operating-mode (agc|apc)
```

Configure edfa target output power

To configure the target output power value in dBm

This command is supported when following feature are disabled Tibit MicroPlug OLT feature

Attribute Name: edfa-target-output-power

Attribute Type: decimal64

Netconf edit-config payload

```

<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<interfaces>
<interface>
  <interface-name>WORD</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  <edfa-target-output-power>VALUE</edfa-target-output-power> <!--
operation="delete"-->
</interface>
</interfaces>
</components>

```

Command Syntax

```
edfa target-outpwr VALUE
```

Configure edfa target gain

To set the target-gain

This command is supported when following feature are disabled Tibit MicroPlug OLT feature

Attribute Name: edfa-target-gain

Attribute Type: decimal64

Netconf edit-config payload

```

<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<interfaces>
<interface>

```

```
<interface-name>WORD</interface-name>
<config>
  <interface-name>WORD</interface-name>
</config>
<edfa-target-gain>VALUE</edfa-target-gain> <!-- operation="delete"-->
</interface>
</interfaces>
</components>
```

Command Syntax

```
edfa target-gain VALUE
```

Configure interval

To set disk activity sampling window interval time.

Attribute Name: interval

Attribute Type: uint16

Attribute Range: 30-1200

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<disk-activity-monitoring>
<config>
  <interval>30</interval> <!-- operation="delete"-->
</config>
</disk-activity-monitoring>
</components>
```

Command Syntax

```
disk-activity-monitoring interval <30-1200>
```

Configure read threshold

To set disk read activity alarm threshold.

Attribute Name: read-threshold

Attribute Type: uint32

Attribute Range: 1-20000

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<disk-activity-monitoring>
<config>
  <read-threshold>1</read-threshold> <!-- operation="delete"-->
</config>
</disk-activity-monitoring>
</components>
```

Command Syntax

```
disk-activity-monitoring threshold read <1-20000>
```

Configure write threshold

To set disk write activity alarm threshold.

Attribute Name: write-threshold

Attribute Type: uint32

Attribute Range: 1-20000

Netconf edit-config payload

```
<components xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <disk-activity-monitoring>
    <config>
      <write-threshold>1</write-threshold> <!-- operation="delete"-->
    </config>
  </disk-activity-monitoring>
</components>
```

Command Syntax

```
disk-activity-monitoring threshold write <1-20000>
```

clear ddm transceiver alarm all

Netconf RPC payload

```
<ddm-clear-transceiver-alarm-all xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-platform"/>
```

Command Syntax

```
clear ddm transceiver alarm all
```

clear ddm transceiver alarm

Attribute Name: name

Attribute Type: string

Netconf RPC payload

```
<ddm-clear-transceiver-alarm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
platform">
  <name>WORD</name>
</ddm-clear-transceiver-alarm>
```

Command Syntax

```
clear ddm transceiver alarm
```

debug ddm

Netconf RPC payload

```
<cmm-terminal-debug-ddm-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-  
platform"/>
```

Command Syntax

```
debug ddm
```

no debug ddm

Netconf RPC payload

```
<cmm-terminal-debug-ddm-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-  
platform"/>
```

Command Syntax

```
no debug ddm
```

debug cmm

Netconf RPC payload

```
<cmm-terminal-debug-cmm-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-  
platform"/>
```

Command Syntax

```
debug cmm
```

no debug cmm

Netconf RPC payload

```
<cmm-terminal-debug-cmm-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-  
platform"/>
```

Command Syntax

```
no debug cmm
```

IPI-PLATFORM-PROFILE

Configure flow control

Use this attribute to enable or disable hardware profile flowcontrol.

Attribute Name: flow-control

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      </flow-control><!-- operation="delete"-->
    </config>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile flowcontrol enable
```

Configure micro bfd

Use this attribute to enable or disable hardware profile micro-bfd.

Attribute Name: micro-bfd

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      </micro-bfd><!-- operation="delete"-->
    </config>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile micro-bfd enable
```

Configure aclif

Use this attribute to set or unset the hardware profile aclif

Attribute Name: aclif

Attribute Type: enum (failover|no-failover)

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      <aclif>failover</aclif> <!-- operation="delete"-->
    </config>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile aclif (failover|no-failover)
```

Configure seamless bfd

Use this attribute to enable or disable hardware profile seamless-bfd.

Attribute Name: seamless-bfd

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      </seamless-bfd><!-- operation="delete"-->
    </config>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile seamless-bfd enable
```

Configure ufis9510 28dc port mode

use this attribute to configure or unconfigure hardware profile port modes

Attribute Name: ufis9510-28dc-port-mode

Attribute Type: enum (mode1|mode2|mode3)

Default Value: mode2

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      <ufis9510-28dc-port-mode>mode2</ufis9510-28dc-port-mode> <!--
operation="delete"-->
    </config>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile port-config (mode1|mode2|mode3)
```

Configure ufis9600 64x port mode

use this attribute to configure or unconfigure hardware profile port modes

Attribute Name: ufis9600-64x-port-mode

Attribute Type: enum (mode1|mode2|mode3|mode4)

Default Value: mode2

Netconf edit-config payload

```

<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      <ufis9600-64x-port-mode>mode2</ufis9600-64x-port-mode> <!-- operation="delete"-->
    </config>
  </hardware-profile>
</profiles>

```

Command Syntax

```
hardware-profile port-config (mode1|mode2|mode3|mode4)
```

Configure as7315 27x port mode

use this attribute to configure or unconfigure hardware profile port modes

Attribute Name: as7315_27x-port-mode

Attribute Type: enum (mode1|mode2|mode3)

Default Value: mode1

Netconf edit-config payload

```

<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      <as7315_27x-port-mode>mode1</as7315_27x-port-mode> <!-- operation="delete"-->
    </config>
  </hardware-profile>
</profiles>

```

Command Syntax

```
hardware-profile port-config (mode1|mode2|mode3)
```

Configure as5916 as5912 54x port mode

use this attribute to configure or unconfigure hardware profile port modes

Attribute Name: as5916_as5912_54x-port-mode

Attribute Type: enum (mode1|mode2)

Default Value: mode1

Netconf edit-config payload

```

<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      <as5916_as5912_54x-port-mode>mode1</as5916_as5912_54x-port-mode> <!--
operation="delete"-->
    </config>
  </hardware-profile>

```

```
</profiles>
```

Command Syntax

```
hardware-profile port-config (mode1|mode2)
```

Configure as7316 26xb port mode

use this attribute to configure or unconfigure hardware profile port modes

Attribute Name: as7316_26xb-port-mode

Attribute Type: enum (mode1|mode2|mode3|mode4)

Default Value: mode1

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      <as7316_26xb-port-mode>mode1</as7316_26xb-port-mode> <!-- operation="delete"-->
    </config>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile port-config (mode1|mode2|mode3|mode4)
```

Configure s9500 30xs port mode

use this attribute to configure or unconfigure hardware profile port modes

Attribute Name: s9500_30xs-port-mode

Attribute Type: enum (mode1|mode2|mode3|mode4)

Default Value: mode1

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      <s9500_30xs-port-mode>mode1</s9500_30xs-port-mode> <!-- operation="delete"-->
    </config>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile port-config (mode1|mode2|mode3|mode4)
```

Configure ufis9600 32x port mode

use this attribute to configure or unconfigure hardware profile port modes

Attribute Name: ufis9600-32x-port-mode

Attribute Type: enum (mode1|mode2|mode3|mode4)

Default Value: mode2

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      <ufis9600-32x-port-mode>mode2</ufis9600-32x-port-mode> <!-- operation="delete"-->
    </config>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile port-config (mode1|mode2|mode3|mode4)
```

Configure ufis9600 56dx port mode

use this attribute to configure or unconfigure hardware profile port modes

Attribute Name: ufis9600-56dx-port-mode

Attribute Type: enum (mode1|mode2|mode3|mode4)

Default Value: mode1

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      <ufis9600-56dx-port-mode>mode1</ufis9600-56dx-port-mode> <!--
operation="delete"-->
    </config>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile port-config (mode1|mode2|mode3|mode4)
```

Configure ufis9610 36d port mode

use this attribute to configure or unconfigure hardware profile port modes

Attribute Name: ufis9610-36d-port-mode

Attribute Type: enum (mode1|mode2|mode3|mode4|mode5|mode6)

Default Value: mode1

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
```

```
<config>
  <ufis9610-36d-port-mode>model</ufis9610-36d-port-mode> <!-- operation="delete"-->
</config>
</hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile port-config (mode1|mode2|mode3|mode4|mode5|mode6)
```

Configure custom service queue profile

Use this attribute to configure or unconfigure hardware profile service-queue profile support.

Attribute Name: custom-service-queue-profile

Attribute Type: enum (profile1|profile2)

Default Value: profile1

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      <custom-service-queue-profile>profile1</custom-service-queue-profile> <!--
operation="delete"-->
    </config>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile service-queue (profile1|profile2)
```

Configure bgp flowspec mode

use this attribute to set bgp-flowspec-mode

Attribute Name: bgp-flowspec-mode

Attribute Type: enum (install-all|install-partial|no-prioritizing)

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <config>
      <bgp-flowspec-mode>install-all</bgp-flowspec-mode> <!-- operation="delete"-->
    </config>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile bgp-flowspec-mode (install-all|install-partial|no-prioritizing)
```

Configure ingress ipv6 extended

Use this attribute to enable or disable Ingress IPv6 extended filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ingress-ipv6-extended

Attribute Type: uint8

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </ingress-ipv6-extended><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ingress-ipv6-ext enable
```

Configure ingress ipv6 extended vlan

Use this attribute to enable or disable Ingress IPv6 extended vlan filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ingress-ipv6-extended-vlan

Attribute Type: uint8

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </ingress-ipv6-extended-vlan><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ingress-ipv6-ext-vlan enable
```

Configure ingress ipv6

Use this attribute to enable or disable Ingress IPv6 filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ingress-ipv6

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </ingress-ipv6><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ingress-ipv6 enable
```

Configure ingress ipv4

Use this attribute to enable or disable Ingress IPv4 filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ingress-ipv4

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </ingress-ipv4><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ingress-ipv4 enable
```

Configure ingress ipv4 extended

Use this attribute to enable or disable Ingress IPv4 extended filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ingress-ipv4-extended

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
```

```
<config>
  </ingress-ipv4-extended><!-- operation="delete"-->
</config>
</filters>
</hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ingress-ipv4-ext enable
```

Configure ingress ipv4 subif

Use this attribute to enable or disable Ingress IPv4 extended filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ingress-ipv4-subif

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<hardware-profile>
<filters>
<config>
  </ingress-ipv4-subif><!-- operation="delete"-->
</config>
</filters>
</hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ingress-ipv4-subif enable
```

Configure ingress ipv4 qos

Use this attribute to enable or disable Ingress IPv4 QoS filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ingress-ipv4-qos

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<hardware-profile>
<filters>
<config>
  </ingress-ipv4-qos><!-- operation="delete"-->
</config>
</filters>
</hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ingress-ipv4-qos enable
```

Configure ingress arp

Use this attribute to enable or disable Ingress ARP filter groups.

Attribute Name: ingress-arp

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </ingress-arp><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ingress-arp enable
```

Configure ingress ipv6 qos

Use this attribute to enable or disable Ingress IPv6 QoS filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ingress-ipv6-qos

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </ingress-ipv6-qos><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ingress-ipv6-qos enable
```

Configure ipv4 bgp flowspec

Use this attribute to enable or disable Ingress IPv4 BGP FLOWSPEC filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ipv4-bgp-flowspec

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </ipv4-bgp-flowspec><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ipv4-bgp-flowspec enable
```

Configure ipv6 bgp flowspec

Use this attribute to enable or disable Ingress IPv6 BGP FLOWSPEC filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ipv6-bgp-flowspec

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </ipv6-bgp-flowspec><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ipv6-bgp-flowspec enable
```

Configure qos

Use this attribute to enable or disable QoS filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: qos

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </qos><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter qos enable
```

Configure qos extended

Use this attribute to enable or disable QoS extended filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: qos-extended

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </qos-extended><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter qos-ext enable
```

Configure qos policer

Use this attribute to enable or disable QoS policer filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: qos-policer

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </qos-policer><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```



```
</config>
</filters>
</hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter qos-policer enable
```

Configure qos ipv6

Use this attribute to enable or disable QoS filter group for IPv6 traffic. Disabling filter groups increases the configurable filter entries.

Attribute Name: qos-ipv6

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </qos-ipv6><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter qos-ipv6 enable
```

Configure egress ipv4

Use this attribute to enable or disable Egress IPv4 filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: egress-ipv4

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </egress-ipv4><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter egress-ipv4 enable
```

Configure egress layer2

Use this attribute to enable or disable Egress L2 filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: egress-layer2

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </egress-layer2><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter egress-l2 enable
```

Configure ingress layer2

Use this attribute to enable or disable Ingress L2 filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ingress-layer2

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </ingress-layer2><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ingress-l2 enable
```

Configure ingress layer2 extended

Use this attribute to enable or disable Ingress L2 extended filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ingress-layer2-extended

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </ingress-layer2-extended><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ingress-l2-ext enable
```

Configure ingress layer2 subif

Use this attribute to enable or disable Ingress L2 extended filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ingress-layer2-subif

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </ingress-layer2-subif><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ingress-l2-subif enable
```

Configure cfm domain name string

Use this attribute to enable or disable CFM domain name filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: cfm-domain-name-string

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </cfm-domain-name-string><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter cfm-domain-name-str enable
```

Configure twamp ipv4

Use this attribute to enable or disable TWAMP IPv4 Forwarding filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: twamp-ipv4

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </twamp-ipv4><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter twamp-ipv4 enable
```

Configure twamp ipv6

Use this attribute to enable or disable TWAMP IPv6 Forwarding filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: twamp-ipv6

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
```

```
<config>
  </twamp-ipv6><!-- operation="delete"-->
</config>
</filters>
</hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter twamp-ipv6 enable
```

Configure twamp ipv6 mpls

Use this attribute to enable or disable TWAMP IPv6 for MPLS Forwarding filter groups. This group should be enabled in addition to twamp-ipv6. Disabling filter groups increases the configurable filter entries.

Attribute Name: twamp-ipv6-mpls

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
  <filters>
  <config>
    </twamp-ipv6-mpls><!-- operation="delete"-->
  </config>
  </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter twamp-ipv6-mpls enable
```

Configure vxlan arp nd

Use this attribute to enable or disable VxLAN Forwarding filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: vxlan-arp-nd

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
  <filters>
  <config>
    </vxlan-arp-nd><!-- operation="delete"-->
  </config>
  </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter vxlan enable
```

Configure vxlan multi homing

Use this attribute to enable or disable VxLAN Multi Homing Forwarding filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: vxlan-multi-homing

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </vxlan-multi-homing><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter vxlan-mh enable
```

Configure evpn mpls multi homing

Use this attribute to enable or disable EVPN-MPLS Multi Homing Forwarding filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: evpn-mpls-multi-homing

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </evpn-mpls-multi-homing><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter evpn-mpls-mh enable
```

Configure evpn mpls control word

Use this attribute to enable or disable EVPN-MPLS control-word option

Attribute Name: evpn-mpls-control-word

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </evpn-mpls-control-word><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter evpn-mpls-cw enable
```

Configure dhcp snoop

Use this attribute to enable or disable Dhcp snooping filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: dhcp-snoop

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </dhcp-snoop><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter dhcp-snoop enable
```

Configure dhcp snoop ipv6

Use this attribute to enable or disable Dhcp snooping ipv6 filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: dhcp-snoop-ipv6

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </dhcp-snoop-ipv6><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter dhcp-snoop-ipv6 enable
```

Configure ipsg

Use this attribute to enable or disable IP Source Guard(IPSG) filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ipsg

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </ipsg><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ipsg enable
```

Configure ipsg ipv6

Use this attribute to enable or disable IP Source Guard(IPSG) ipv6 filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ipsg-ipv6

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <filters>
      <config>
        </ipsg-ipv6><!-- operation="delete"-->
      </config>
    </filters>
  </hardware-profile>
</profiles>
```



```
</config>
</filters>
</hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile filter ipsg-ipv6 enable
```

Configure attachment circuit logical if

Use this attribute to enable or disable attachment circuits logical filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: attachment-circuit-logical-if

Attribute Type: uint8

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <statistics>
      <config>
        </attachment-circuit-logical-if><!-- operation="delete"-->
      </config>
    </statistics>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile statistics mpls-ac enable
```

Configure tunnel logical if

Use this attribute to enable or disable tunnel logical filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: tunnel-logical-if

Attribute Type: uint8

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <statistics>
      <config>
        </tunnel-logical-if><!-- operation="delete"-->
      </config>
    </statistics>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile statistics mpls-lsp enable
```

Configure ingress acl

Use this attribute to enable or disable Ingress ACL QoS and PBR filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ingress-acl

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <statistics>
      <config>
        </ingress-acl><!-- operation="delete"-->
      </config>
    </statistics>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile statistics ingress-acl enable
```

Configure egress acl

Use this attribute to enable or disable Egress ACL filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: egress-acl

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <statistics>
      <config>
        </egress-acl><!-- operation="delete"-->
      </config>
    </statistics>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile statistics egress-acl enable
```

Configure ingress qos

Use this attribute to enable or disable explicitly for QoS filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: ingress-qos

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <statistics>
      <config>
        </ingress-qos><!-- operation="delete"-->
      </config>
    </statistics>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile statistics ingress-qos enable
```

Configure evpn mpls stats

Use this attribute to enable or disable hardware statistics for evpn-mpls.

Attribute Name: evpn-mpls-stats

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <statistics>
      <config>
        </evpn-mpls-stats><!-- operation="delete"-->
      </config>
    </statistics>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile statistics evpn-mpls enable
```

Configure mpls pseudowire

Use this attribute to enable or disable MPLS Pseudowire filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: mpls-pseudowire

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <statistics>
      <config>
        </mpls-pseudowire><!-- operation="delete"-->
      </config>
    </statistics>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile statistics mpls-pwe enable
```

Configure cfm frame loss measurements

Use this attribute to enable or disable CFM Loss Measurements filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: cfm-frame-loss-measurements

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <statistics>
      <config>
        </cfm-frame-loss-measurements><!-- operation="delete"-->
      </config>
    </statistics>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile statistics cfm-lm enable
```

Configure cfm continuity check messages

Use this attribute to enable or disable CFM Continuity Check Messages filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: cfm-continuity-check-messages

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <statistics>
      <config>
        </cfm-continuity-check-messages><!-- operation="delete"-->
      </config>
    </statistics>
  </hardware-profile>
</profiles>
```

```
</config>
</statistics>
</hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile statistics cfm-ccm enable
```

Configure virtual output queue full color

Use this attribute to enable or disable Virtual Output Queue Full Color filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: virtual-output-queue-full-color

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <statistics>
      <config>
        </virtual-output-queue-full-color><!-- operation="delete"-->
      </config>
    </statistics>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile statistics voq-full-color enable
```

Configure virtual output queue forward drop

Use this attribute to enable or disable Virtual Output Queue Forward Drop filter groups. Disabling filter groups increases the configurable filter entries.

Attribute Name: virtual-output-queue-forward-drop

Attribute Type: empty

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <hardware-profile>
    <statistics>
      <config>
        </virtual-output-queue-forward-drop><!-- operation="delete"-->
      </config>
    </statistics>
  </hardware-profile>
</profiles>
```

Command Syntax

```
hardware-profile statistics voq-fwd-drop enable
```

Configure profile type

forwarding profile for KAPS

This command is supported when following feature are enabled dune feature,bcm uft feature and following feature are disabled dnx feature

Attribute Name: profile-type

Attribute Type: enum (profile-one|profile-two)

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <forwarding-profiles>
    <kaps>
      <config>
        <profile-type>profile-one</profile-type> <!-- operation="delete"-->
      </config>
    </kaps>
  </forwarding-profiles>
</profiles>
```

Command Syntax

```
forwarding profile kaps (profile-one|profile-two)
```

Configure ipv6 percentage

Use this attribute to set Percentage of entries for ipv6 routes

This command is supported when following feature are enabled dune feature,bcm uft feature and following feature are disabled dnx feature

Attribute Name: ipv6-percentage

Attribute Type: uint8

Attribute Range: 10-90

Attribute Name: profile-type

Attribute Type: enum (custom-profile)

Attribute Name: ipv4-percentage

Attribute Type: uint8

Attribute Range: 10-90

Netconf edit-config payload

```
<profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <forwarding-profiles>
    <custom-tcam>
      <config>
        <profile-type>custom-profile</profile-type>
      </config>
    </custom-tcam>
  </forwarding-profiles>
</profiles>
```

```

    <ipv4-percentage>10</ipv4-percentage>
    <ipv6-percentage>10</ipv6-percentage>
</config>
</custom-tcam>
</forwarding-profiles>
</profiles>

```

Command Syntax

```
forwarding profile elk-tcam (custom-profile) <10-90> <10-90>
```

Configure enable

This Object is set loadBalance

This command is supported when following feature are enabled broadcom feature

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```

<hardware xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <load-balance>
    <config>
      </enable>
    </config>
  </load-balance>
</hardware>

```

Command Syntax

```
load-balance enable
```

Configure mpls label based

This Object is set for load balancing based on mpls labels

This command is supported when following feature are enabled broadcom feature

Attribute Name: mpls-label-based

Attribute Type: empty

Netconf edit-config payload

```

<hardware xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <load-balance>
    <config>
      </mpls-label-based><!-- operation="delete"-->
    </config>
  </load-balance>
</hardware>

```

Command Syntax

```
load-balance mpls labels
```

Configure vlan based

This Object is set for Vlan based load balancing

This command is supported when following feature are enabled L2 feature,broadcom feature

Attribute Name: vlan-based

Attribute Type: empty

Attribute Name: dest-mac-based

Attribute Type: empty

Attribute Name: src-mac-based

Attribute Type: empty

Attribute Name: ether-type-based

Attribute Type: empty

Netconf edit-config payload

```
<hardware xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <load-balance>
    <l2>
      <config>
        </dest-mac-based><!-- operation="delete"-->
        </src-mac-based><!-- operation="delete"-->
        </ether-type-based><!-- operation="delete"-->
        </vlan-based><!-- operation="delete"-->
      </config>
    </l2>
  </load-balance>
</hardware>
```

Command Syntax

```
load-balance l2 { dest-mac| src-mac| ether-type| vlan }
```

Configure protocol id based

This Object is set for Protocol Id based load balancing

This command is supported when following feature are enabled L3 feature,broadcom feature

Attribute Name: protocol-id-based

Attribute Type: empty

Attribute Name: src-ipv4-address-based

Attribute Type: empty

Attribute Name: dest-ipv4-address-based

Attribute Type: empty

Attribute Name: src-l4-port-based

Attribute Type: empty

Attribute Name: dest-l4-port-based

Attribute Type: empty

Netconf edit-config payload

```
<hardware xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <load-balance>
    <ipv4>
      <config>
        </src-ipv4-address-based><!-- operation="delete"-->
        </dest-ipv4-address-based><!-- operation="delete"-->
        </src-l4-port-based><!-- operation="delete"-->
        </dest-l4-port-based><!-- operation="delete"-->
        </protocol-id-based><!-- operation="delete"-->
      </config>
    </ipv4>
  </load-balance>
</hardware>
```

Command Syntax

```
load-balance ipv4 { src-ipv4| dest-ipv4| srcl4-port| destl4-port| protocol-id }
```

Configure next header based

This Object is set for Next Header Field for IPV6

This command is supported when following feature are enabled L3 feature,broadcom feature

Attribute Name: next-header-based

Attribute Type: empty

Attribute Name: src-ipv6-address-based

Attribute Type: empty

Attribute Name: dest-ipv6-address-based

Attribute Type: empty

Attribute Name: src-l4-port-based

Attribute Type: empty

Attribute Name: dest-l4-port-based

Attribute Type: empty

Netconf edit-config payload

```
<hardware xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <load-balance>
    <ipv6>
      <config>
        </src-ipv6-address-based><!-- operation="delete"-->
        </dest-ipv6-address-based><!-- operation="delete"-->
        </src-l4-port-based><!-- operation="delete"-->
        </dest-l4-port-based><!-- operation="delete"-->
      </config>
    </ipv6>
  </load-balance>
</hardware>
```

```
    </next-header-based><!-- operation="delete"-->
</config>
</ipv6>
</load-balance>
</hardware>
```

Command Syntax

```
load-balance ipv6 { src-ipv6| dest-ipv6| srcl4-port| destl4-port| next-hdr }
```

Configure queue name

This attribute specifies CPU queue name for rate limiting config

Attribute Name: queue-name

Attribute Type: enum (cpu.q0|cpu.q1|cpu.q2|cpu.q3|cpu.q4|cpu.q5|cpu.q6|cpu.q7|igmp|isis|reserved-mc|link-local|ospf|bgp|rsvp-ldp|vrrp-rip-dhcp|pim|icmp|arp|bpdu|oamp|sflow|dsp|evpn|nhop|mgmt-route-leak|icmp-redirect|cfm|bfd)

Attribute Name: rate

Attribute Type: int32

Attribute Range: 0-100000

Netconf edit-config payload

```
<hardware xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <cpu-queue>
    <rate-limits>
      <rate-limit>
        <queue-name>cpu.q0</queue-name>
        <config>
          <queue-name>cpu.q0</queue-name>
          <rate>0</rate>
        </config>
      </rate-limit>
    </rate-limits>
  </cpu-queue>
</hardware>
```

Command Syntax

```
cpu-queue
(cpu.q0|cpu.q1|cpu.q2|cpu.q3|cpu.q4|cpu.q5|cpu.q6|cpu.q7|igmp|isis|reserved-
mc|link-local|ospf|bgp|rsvp-ldp|vrrp-rip-
dhcp|pim|icmp|arp|bpdu|oamp|sflow|dsp|evpn|nhop|mgmt-route-leak|icmp-
redirect|cfm|bfd) rate <0-100000>
```

Configure monitor status

This attribute specifies CPU queue name for rate limiting config

Attribute Name: queue-name

Attribute Type: enum (cpu.q0|cpu.q1|cpu.q2|cpu.q3|cpu.q4|cpu.q5|cpu.q6|cpu.q7|igmp|isis|reserved-mc|link-local|ospf|bgp|rsvp-ldp|vrrp-rip-dhcp|pim|icmp|arp|bpdu|oamp|sflow|dsp|evpn|nhop|mgmt-route-leak|icmp-redirect|cfm|bfd)

Attribute Name: monitor-status

Attribute Type: enum (no-monitor|monitor)

Netconf edit-config payload

```
<hardware xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <cpu-queue>
    <rate-limits>
      <rate-limit>
        <queue-name>cpu.q0</queue-name>
        <config>
          <queue-name>cpu.q0</queue-name>
          <monitor-status>no-monitor</monitor-status>
        </config>
      </rate-limit>
    </rate-limits>
  </cpu-queue>
</hardware>
```

Command Syntax

```
cpu-queue
  (cpu.q0|cpu.q1|cpu.q2|cpu.q3|cpu.q4|cpu.q5|cpu.q6|cpu.q7|igmp|isis|reserved-
  mc|link-local|ospf|bgp|rsvp-ldp|vrrp-rip-
  dhcp|pim|icmp|arp|bpdu|oamp|sflow|dsp|evpn|nhop|mgmt-route-leak|icmp-
  redirect|cfm|bfd) (no-monitor|monitor)
```

Configure rate

This attribute specifies CPU queue name for rate limiting config

Attribute Name: queue-name

Attribute Type: enum (cpu.q0|cpu.q1|cpu.q2|cpu.q3|cpu.q4|cpu.q5|cpu.q6|cpu.q7|igmp|isis|reserved-mc|link-local|ospf|bgp|rsvp-ldp|vrrp-rip-dhcp|pim|icmp|arp|bpdu|oamp|sflow|dsp|evpn|nhop|mgmt-route-leak|icmp-redirect|cfm|bfd)

Attribute Name: rate

Attribute Type: int32

Attribute Range: 0-100000

Attribute Name: monitor-status

Attribute Type: enum (no-monitor|monitor)

Netconf edit-config payload

```
<hardware xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <cpu-queue>
    <rate-limits>
      <rate-limit>
        <queue-name>cpu.q0</queue-name>
```

```
<config>
  <queue-name>cpu.q0</queue-name>
  <rate>0</rate>
  <monitor-status>no-monitor</monitor-status>
</config>
</rate-limit>
</rate-limits>
</cpu-queue>
</hardware>
```

Command Syntax

```
cpu-queue
(cpu.q0|cpu.q1|cpu.q2|cpu.q3|cpu.q4|cpu.q5|cpu.q6|cpu.q7|igmp|isis|reserved-
mc|link-local|ospf|bgp|rsvp-ldp|vrrp-rip-
dhcp|pim|icmp|arp|bpdu|oamp|sflow|dsp|evpn|nhop|mgmt-route-leak|icmp-
redirect|cfm|bfd) rate <0-100000> (no-monitor|monitor)
```

cpu-q-default rate <0-100000>

Attribute Name: rate

Attribute Type: uint32

Attribute Range: 0-100000

Netconf RPC payload

```
<ipi-platform-profile_platform-profile-cpu-q-rate-set xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-platform">
  <rate>0</rate>
</ipi-platform-profile_platform-profile-cpu-q-rate-set>
```

Command Syntax

```
cpu-q-default rate <0-100000>
```

no cpu-q-default rate

Attribute Name: rate

Attribute Type: empty

Netconf RPC payload

```
<ipi-platform-profile_platform-profile-cpu-q-rate-unset xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-platform">
  <rate>CML_EMPTY_T</rate>
</ipi-platform-profile_platform-profile-cpu-q-rate-unset>
```

Command Syntax

```
no cpu-q-default rate
```

IPI-PLATFORM-PROFILE-EXTENDED

Configure soc

Attribute to indicate the SoC running on this platform. This attribute cannot be configured.

Attribute Name: soc

Attribute Type: enum

(qax|qux|qmx|dnx|tomahawk|tomahawk2|tomahawk3|tomahawkplus|trident2|trident2plus|trident3|helix4|saber2|maverick2|hurricane4|unknown)

Netconf edit-config payload

```
<hardware xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <platform>
    <config>
      <soc>qax</soc> <!-- operation="delete"-->
    </config>
  </platform>
</hardware>
```

Command Syntax

```
platform-extended-soc
(qax|qux|qmx|dnx|tomahawk|tomahawk2|tomahawk3|tomahawkplus|trident2|trident2plus
|trident3|helix4|saber2|maverick2|hurricane4|unknown)
```

IPI-PLATFORM-CMIS

Configure fp port

Front port panel number

Attribute Name: fp-port

Attribute Type: uint8

Netconf edit-config payload

```
<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <qsfp-dd> <!-- operation="delete"-->
    <fp-port>0</fp-port>
  <config>
    <fp-port>0</fp-port>
  </config>
</qsfp-dd>
</qsfp-dds>
```

Command Syntax

```
qsfp-dd <0-255>
```

Configure application

Application configuration

Attribute Name: application

Attribute Type: uint8

Attribute Range: 2-15

Netconf edit-config payload

```
<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <qsfp-dd>
    <fp-port>0</fp-port>
    <config>
      <fp-port>0</fp-port>
    </config>
    <application>2</application> <!-- operation="delete"-->
  </qsfp-dd>
</qsfp-dds>
```

Command Syntax

```
application <2-15>
```

Configure service disable

To disable the service for a particular port

Attribute Name: service-disable

Attribute Type: empty

Netconf edit-config payload

```
<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <qsfp-dd>
    <fp-port>0</fp-port>
    <config>
      <fp-port>0</fp-port>
    </config>
    </service-disable><!-- operation="delete"-->
  </qsfp-dd>
</qsfp-dds>
```

Command Syntax

```
service-disable
```

Configure type

PRBS pattern type for generator/checker

Attribute Name: type

Attribute Type: enum (31q|31|23q|23|15q|15|13q|13|9q|9|7q|7|ssprq)

Netconf edit-config payload

```

<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<qsfp-dd>
  <fp-port>0</fp-port>
  <config>
    <fp-port>0</fp-port>
  </config>
</host>
</prbs>
</generator>
<config>
  <type>31q</type> <!-- operation="delete"-->
</config>
</generator>
</prbs>
</host>
</qsfp-dd>
</qsfp-dds>

```

Command Syntax

```
prbs generator type (31q|31|23q|23|15q|15|13q|13|9q|9|7q|7|ssprq) host
```

Configure location

PRBS pattern generator/checker location

Attribute Name: location

Attribute Type: enum (pre-fec|post-fec)

Netconf edit-config payload

```

<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<qsfp-dd>
  <fp-port>0</fp-port>
  <config>
    <fp-port>0</fp-port>
  </config>
</host>
</prbs>
</generator>
<config>
  <location>pre-fec</location> <!-- operation="delete"-->
</config>
</generator>
</prbs>
</host>
</qsfp-dd>
</qsfp-dds>

```

Command Syntax

```
prbs generator (pre-fec|post-fec) host
```

Configure lane number

Host lane number

Attribute Name: lane-number

Attribute Type: uint8

Netconf edit-config payload

```
<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <qsfp-dd>
    <fp-port>0</fp-port>
    <config>
      <fp-port>0</fp-port>
    </config>
  </qsfp-dd>
  <host>
    <lanes>
      <lane> <!-- operation="delete"-->
        <lane-number>1</lane-number>
        <config>
          <lane-number>1</lane-number>
        </config>
      </lane>
    </lanes>
  </host>
</qsfp-dds>
```

Command Syntax

```
host-lane <1-32>
```

Configure id

Threshold ID

Attribute Name: id

Attribute Type: enum (tx-fdd|tx-fed)

Netconf edit-config payload

```
<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <qsfp-dd>
    <fp-port>0</fp-port>
    <config>
      <fp-port>0</fp-port>
    </config>
  </qsfp-dd>
  <host>
    <lanes>
      <lane>
        <lane-number>1</lane-number>
        <config>
          <lane-number>1</lane-number>
        </config>
      </lane>
    </lanes>
  </host>
</qsfp-dds>
```



```

</config>
<thresholds>
<threshold> <!-- operation="delete"-->
  <id>tx-fdd</id>
  <config>
    <id>tx-fdd</id>
  </config>
</threshold>
</thresholds>
</lane>
</lanes>
</host>
</qsfp-dd>
</qsfp-dds>

```

Command Syntax

```
threshold (tx-fdd|tx-fed)
```

Configure high alarm

High alarm threshold

Attribute Name: high-alarm

Attribute Type: decimal64

Netconf edit-config payload

```

<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<qsfp-dd>
  <fp-port>0</fp-port>
  <config>
    <fp-port>0</fp-port>
  </config>
</qsfp-dd>
<host>
<lanes>
<lane>
  <lane-number>1</lane-number>
  <config>
    <lane-number>1</lane-number>
  </config>
  <thresholds>
  <threshold>
    <id>tx-fdd</id>
    <config>
      <id>tx-fdd</id>
    </config>
    <high-alarm>VALUE</high-alarm> <!-- operation="delete"-->
  </threshold>
</thresholds>
</lane>
</lanes>

```

```
</host>  
</qsfp-dd>  
</qsfp-dds>
```

Command Syntax

```
ha VALUE
```

Configure low alarm

Low alarm threshold

Attribute Name: low-alarm

Attribute Type: decimal64

Netconf edit-config payload

```
<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">  
  <qsfp-dd>  
    <fp-port>0</fp-port>  
    <config>  
      <fp-port>0</fp-port>  
    </config>  
  </qsfp-dd>  
</qsfp-dds>  
<host>  
<lanes>  
<lane>  
  <lane-number>1</lane-number>  
  <config>  
    <lane-number>1</lane-number>  
  </config>  
  <thresholds>  
  <threshold>  
    <id>tx-fdd</id>  
    <config>  
      <id>tx-fdd</id>  
      <low-alarm>VALUE</low-alarm> <!-- operation="delete" -->  
    </config>  
  </threshold>  
</thresholds>  
</lane>  
</lanes>  
</host>  
</qsfp-dd>  
</qsfp-dds>
```

Command Syntax

```
la VALUE
```

Configure high warning

High warn threshold

Attribute Name: high-warning

Attribute Type: decimal64

Netconf edit-config payload

```
<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<qsfp-dd>
  <fp-port>0</fp-port>
  <config>
    <fp-port>0</fp-port>
  </config>
</host>
<lanes>
<lane>
  <lane-number>1</lane-number>
  <config>
    <lane-number>1</lane-number>
  </config>
  <thresholds>
  <threshold>
    <id>tx-fdd</id>
    <config>
      <id>tx-fdd</id>
      <high-warning>VALUE</high-warning> <!-- operation="delete"-->
    </config>
  </threshold>
</thresholds>
</lane>
</lanes>
</host>
</qsfp-dd>
</qsfp-dds>
```

Command Syntax

```
hw VALUE
```

Configure low warning

Low warn threshold

Attribute Name: low-warning

Attribute Type: decimal64

Netconf edit-config payload

```
<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<qsfp-dd>
  <fp-port>0</fp-port>
  <config>
    <fp-port>0</fp-port>
  </config>
</host>
```

```

<lanes>
<lane>
  <lane-number>1</lane-number>
  <config>
    <lane-number>1</lane-number>
  </config>
  <thresholds>
  <threshold>
    <id>tx-fdd</id>
    <config>
      <id>tx-fdd</id>
    </config>
    <low-warning>VALUE</low-warning> <!-- operation="delete"-->
  </threshold>
</thresholds>
</lane>
</lanes>
</host>
</qsfp-dd>
</qsfp-dds>

```

Command Syntax

```
lw VALUE
```

Configure channel

Channel number

Attribute Name: channel

Attribute Type: int16

Netconf edit-config payload

```

<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<qsfp-dd>
  <fp-port>0</fp-port>
  <config>
    <fp-port>0</fp-port>
  </config>
<media>
<lanes>
<lane>
  <lane-number>1</lane-number>
  <config>
    <lane-number>1</lane-number>
  </config>
  <laser>
  <config>
    <channel>0</channel>
  </config>
</laser>

```

```

</lane>
</lanes>
</media>
</qsfp-dd>
</qsfp-dds>

```

Command Syntax

```
laser channel <-32768-32767>
```

Configure grid

Grid spacing

Attribute Name: grid

Attribute Type: enum (3p125|6p25|12p5|25|33|50|75|100)

Netconf edit-config payload

```

<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <qsfp-dd>
    <fp-port>0</fp-port>
    <config>
      <fp-port>0</fp-port>
    </config>
  </qsfp-dd>
  <media>
    <lanes>
      <lane>
        <lane-number>1</lane-number>
        <config>
          <lane-number>1</lane-number>
        </config>
        <laser>
          <config>
            <grid>3p125</grid> <!-- operation="delete"-->
          </config>
        </laser>
      </lane>
    </lanes>
  </media>
</qsfp-dds>

```

Command Syntax

```
laser grid (3p125|6p25|12p5|25|33|50|75|100)
```

Configure fine tune freq

Fine tune frequency offset

Attribute Name: fine-tune-freq

Attribute Type: decimal64

Netconf edit-config payload

```
<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<qsfp-dd>
  <fp-port>0</fp-port>
  <config>
    <fp-port>0</fp-port>
  </config>
</media>
</lanes>
</lane>
  <lane-number>1</lane-number>
  <config>
    <lane-number>1</lane-number>
  </config>
  <laser>
  <config>
    <fine-tune-freq>VALUE</fine-tune-freq> <!-- operation="delete"-->
  </config>
</laser>
</lane>
</lanes>
</media>
</qsfp-dd>
</qsfp-dds>
```

Command Syntax

```
laser fine-tune-freq VALUE
```

Configure output power

Targeted output power

Attribute Name: output-power

Attribute Type: decimal64

Netconf edit-config payload

```
<qsfp-dds xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
<qsfp-dd>
  <fp-port>0</fp-port>
  <config>
    <fp-port>0</fp-port>
  </config>
</media>
</lanes>
</lane>
  <lane-number>1</lane-number>
  <config>
    <lane-number>1</lane-number>
  </config>
  <laser>
```

```

    <config>
      <output-power>VALUE</output-power> <!-- operation="delete"-->
    </config>
  </laser>
</lane>
</lanes>
</media>
</qsfp-dd>
</qsfp-dds>

```

Command Syntax

```
laser output-power VALUE
```

tibit-olt-microplug set interface IFNAME management-vlan-tpid (0x8100|0x88a8)

Attribute Name: interface-name

Attribute Type: string

Attribute Name: vlan-tpid

Attribute Type: string

Netconf RPC payload

```

<ipi-platform-transceiver-tibit tibit-olt-microplug-set-management-vlan-tpid
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <interface-name>IFNAME</interface-name>
  <vlan-tpid>0x8100</vlan-tpid>
</ipi-platform-transceiver-tibit_tibit-olt-microplug-set-management-vlan-tpid>

```

Command Syntax

```
tibit-olt-microplug set interface IFNAME management-vlan-tpid (0x8100|0x88a8)
```

tibit-olt-microplug set interface IFNAME management-vlan-id <1-4094>

Attribute Name: interface-name

Attribute Type: string

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf RPC payload

```

<ipi-platform-transceiver-tibit tibit-olt-microplug-set-management-vlan-id
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <interface-name>IFNAME</interface-name>
  <vlan-id>1</vlan-id>
</ipi-platform-transceiver-tibit_tibit-olt-microplug-set-management-vlan-id>

```

Command Syntax

```
tibit-olt-microplug set interface IFNAME management-vlan-id <1-4094>
```

tibit-olt-microplug set interface IFNAME ethernet-mac-address XX:XX:XX:XX:XX:XX

Attribute Name: interface-name

Attribute Type: string

Attribute Name: mac-address

Attribute Type: yang:mac-address

Netconf RPC payload

```
<ipi-platform-transceiver-tibit tibit-olt-microplug-set-ethernet-mac-address
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <interface-name>IFNAME</interface-name>
  <mac-address>XX:XX:XX:XX:XX:XX</mac-address>
</ipi-platform-transceiver-tibit_tibit-olt-microplug-set-ethernet-mac-address>
```

Command Syntax

```
tibit-olt-microplug set interface IFNAME ethernet-mac-address XX:XX:XX:XX:XX:XX
```

tibit-olt-microplug set interface IFNAME next-active-firmware-bank-id <0-3>

Attribute Name: interface-name

Attribute Type: string

Attribute Name: bank-id

Attribute Type: uint8

Attribute Range: 0-3

Netconf RPC payload

```
<ipi-platform-transceiver-tibit tibit-olt-microplug-set-next-active-firmware-
bank xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform">
  <interface-name>IFNAME</interface-name>
  <bank-id>0</bank-id>
</ipi-platform-transceiver-tibit_tibit-olt-microplug-set-next-active-firmware-
bank>
```

Command Syntax

```
tibit-olt-microplug set interface IFNAME next-active-firmware-bank-id <0-3>
```

tibit-olt-microplug reboot interface IFNAME

Attribute Name: interface-name

Attribute Type: string

Netconf RPC payload

```
<ipi-platform-transceiver-tibit_tibit-olt-microplug-reboot xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-platform">
  <interface-name>IFNAME</interface-name>
</ipi-platform-transceiver-tibit_tibit-olt-microplug-reboot>
```

Command Syntax

```
tibit-olt-microplug reboot interface IFNAME
```

IPI-PLATFORM-TRANSCEIVER-SMART-SFP

Configure xcvr loopback remote

Use this attribute to set TX/RX loopback for remote

Attribute Name: xcvr-loopback-remote

Attribute Type: enum (in|out)

Netconf edit-config payload

```
<smart-sfp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-platform-transceiver-
smart-sfp">
  <interfaces>
  <interface>
    <interface-name>IFNAME</interface-name>
    <config>
      <interface-name>WORD</interface-name>
    </config>
    <xcvr-loopback-remote>in</xcvr-loopback-remote> <!-- operation="delete"-->
  </interface>
</interfaces>
</smart-sfp>
```

Command Syntax

```
xcvr loopback (in|out) remote
```

xcvr IFNAME tx-disable <1-256> remote

Attribute Name: if-name

Attribute Type: string

Attribute Name: xcvr-tx-disable-duration

Attribute Type: uint16

Attribute Range: 1-256

Netconf RPC payload

```
<smart-sfp-xcvr-txdisable-duration xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-platform-transceiver-smart-sfp">
  <if-name>IFNAME</if-name>
```

```
<xcvr-tx-disable-duration>1</xcvr-tx-disable-duration>
</smart-sfp-xcvr-txdisable-duration>
```

Command Syntax

```
xcvr IFNAME tx-disable <1-256> remote
```

xcvr IFNAME reset remote

Attribute Name: if-name

Attribute Type: string

Netconf RPC payload

```
<smart-sfp-xcvr-reset-remote xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
platform-transceiver-smart-sfp">
  <if-name>IFNAME</if-name>
</smart-sfp-xcvr-reset-remote>
```

Command Syntax

```
xcvr IFNAME reset remote
```

IPI-AUTHENTICATION

Configure mac authentication

Use this attribute to enable MAC authentication globally. If MAC authentication is not enabled, other MAC authentication related commands throw an error when issued.

This command is supported when following feature are enabled HAVE_AUTHD feature

Attribute Name: mac-authentication

Attribute Type: empty

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <global>
  <config>
    </mac-authentication><!-- operation="delete"-->
  </config>
</global>
</authentication>
```

Command Syntax

```
auth-mac system-auth-ctrl
```

Configure dot1x authentication

Use this attribute to enable globally authentication.

This command is supported when following feature are enabled HAVE_AUTHD feature

Attribute Name: dot1x-authentication

Attribute Type: empty

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <global>
  <config>
    </dot1x-authentication><!-- operation="delete"-->
  </config>
</global>
</authentication>
```

Command Syntax

```
dot1x system-auth-ctrl
```

Configure dot1x control

Use this attribute to enable or disable the 802.1X authentication control on an interface.

This command is supported when following feature are enabled HAVE_AUTHD feature

Attribute Name: dot1x-control

Attribute Type: enum (force-unauthorized|force-authorized|auto)

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <dot1x-interfaces>
  <dot1x-interface>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
    <dot1x-control>force-authorized</dot1x-control>
  </dot1x-interface>
</dot1x-interfaces>
</authentication>
```

Command Syntax

```
dot1x port-control (force-unauthorized|force-authorized|auto)
```

Configure protocol version

Use this attribute to set the protocol version of dot1x to 1 or 2. The protocol version must be synchronized with the Xsupplicant being used in that interface.

This command is supported when following feature are enabled HAVE_AUTHD feature

Attribute Name: protocol-version

Attribute Type: enum (1|2)

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <dot1x-interfaces>
  <dot1x-interface>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
    <protocol-version>2</protocol-version> <!-- operation="delete"-->
  </dot1x-interface>
</dot1x-interfaces>
</authentication>
```

Command Syntax

```
dot1x protocol-version (1|2)
```

Configure quiet period

Use this attribute to set the quiet-period time interval. When a switch cannot authenticate a client, the switch remains idle for a quiet-period interval of time, then tries again. By administratively changing the quiet-period interval, by entering a lower number than the default, a faster response time can be provided

This command is supported when following feature are enabled HAVE_AUTHD feature

Attribute Name: quiet-period

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <dot1x-interfaces>
  <dot1x-interface>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
  <authenticator-pae>
  <config>
    <quiet-period>1</quiet-period> <!-- operation="delete"-->
  </config>
</authenticator-pae>
</dot1x-interface>
</dot1x-interfaces>
</authentication>
```

Command Syntax

```
dot1x quiet-period <1-65535>
```

Configure max reauth value

Use this attribute to set the maximum reauthentication value, which sets the maximum number of reauthentication attempts after which the port will be unauthorized.

This command is supported when following feature are enabled HAVE_AUTHD feature

Attribute Name: max-reauth-value

Attribute Type: uint8

Attribute Range: 1-10

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <dot1x-interfaces>
    <dot1x-interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <authenticator-pae>
      <config>
        <max-reauth-value>1</max-reauth-value> <!-- operation="delete"-->
      </config>
    </authenticator-pae>
  </dot1x-interface>
</dot1x-interfaces>
</authentication>
```

Command Syntax

```
dot1x reauthMax <1-10>
```

Configure interval period

Use this attribute to set the interval between successive attempts to request an ID.

This command is supported when following feature are enabled HAVE_AUTHD feature

Attribute Name: interval-period

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <dot1x-interfaces>
    <dot1x-interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <authenticator-pae>
      <config>
```

```
        <interval-period>1</interval-period> <!-- operation="delete"-->
</config>
</authenticator-pae>
</dot1x-interface>
</dot1x-interfaces>
</authentication>
```

Command Syntax

```
dot1x timeout tx-period <1-65535>
```

Configure reauthentication period

Use this attribute to set the interval between reauthorization attempts.

This command is supported when following feature are enabled HAVE_AUTHD feature

Attribute Name: reauthentication-period

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
<dot1x-interfaces>
<dot1x-interface>
    <name>WORD</name>
    <config>
        <name>WORD</name>
    </config>
<reauthentication-timer>
<config>
    <reauthentication-period>1</reauthentication-period> <!-- operation="delete"-
->
</config>
</reauthentication-timer>
</dot1x-interface>
</dot1x-interfaces>
</authentication>
```

Command Syntax

```
dot1x timeout re-authperiod <1-4294967295>
```

Configure enable reauthentication

Use this attribute to enable reauthentication on a port.

This command is supported when following feature are enabled HAVE_AUTHD feature

Attribute Name: enable-reauthentication

Attribute Type: empty

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
<dot1x-interfaces>
<dot1x-interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<reauthentication-timer>
<config>
  </enable-reauthentication><!-- operation="delete"-->
</config>
</reauthentication-timer>
</dot1x-interface>
</dot1x-interfaces>
</authentication>
```

Command Syntax

```
dot1x reauthentication
```

Configure enable mac auth bypass

Use this attribute to enable/disable mac-auth-bypass on a port.

This command is supported when following feature are enabled HAVE_AUTHD feature

Attribute Name: enable-mac-auth-bypass

Attribute Type: enum (enable|disable)

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
<dot1x-interfaces>
<dot1x-interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
<reauthentication-timer>
<config>
  <enable-mac-auth-bypass>enable</enable-mac-auth-bypass> <!--
operation="delete"-->
</config>
</reauthentication-timer>
</dot1x-interface>
</dot1x-interfaces>
</authentication>
```

Command Syntax

```
dot1x mac-auth-bypass (enable|disable)
```

Configure supplicant timeout

Use this attribute to set the interval for a supplicant to respond.

This command is supported when following feature are enabled HAVE_AUTHD feature

Attribute Name: supplicant-timeout

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <dot1x-interfaces>
    <dot1x-interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <authenticator-be>
      <config>
        <supplicant-timeout>1</supplicant-timeout> <!-- operation="delete"-->
      </config>
    </authenticator-be>
  </dot1x-interface>
</dot1x-interfaces>
</authentication>
```

Command Syntax

```
dot1x timeout supp-timeout <1-65535>
```

Configure server timeout

Use this attribute to set the authentication server response timeout.

This command is supported when following feature are enabled HAVE_AUTHD feature

Attribute Name: server-timeout

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <dot1x-interfaces>
    <dot1x-interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <authenticator-be>
      <config>
```



```
        <server-timeout>1</server-timeout> <!-- operation="delete"-->
</config>
</authenticator-be>
</dot1x-interface>
</dot1x-interfaces>
</authentication>
```

Command Syntax

```
dot1x timeout server-timeout <1-65535>
```

Configure mac control

Use this attribute to enable or disable the MAC authentication control on an interface.

This command is supported when following feature are enabled MAC_AUTH feature,HAVE_AUTHD feature

Attribute Name: mac-control

Attribute Type: empty

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <mac-interfaces>
    <mac-interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </mac-control>
  </mac-interface>
</mac-interfaces>
</authentication>
```

Command Syntax

```
auth-mac
```

Configure mac mode

Use this attribute to enable or disable the MAC authentication mode on an interface.

This command is supported when following feature are enabled MAC_AUTH feature,HAVE_AUTHD feature

Attribute Name: mac-mode

Attribute Type: enum (filter|shutdown)

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <mac-interfaces>
    <mac-interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </mac-mode>
  </mac-interface>
</mac-interfaces>
</authentication>
```

```
</config>
  <mac-mode>shutdown</mac-mode> <!-- operation="delete"-->
</mac-interface>
</mac-interfaces>
</authentication>
```

Command Syntax

```
auth-mac mode (filter|shutdown)
```

Configure dynamic vlan creation

Use this attribute to enable or disable dynamic VLAN creation after successful MAC authentication.

This command is supported when following feature are enabled MAC_AUTH feature,HAVE_AUTHD feature

Attribute Name: dynamic-vlan-creation

Attribute Type: empty

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <mac-interfaces>
    <mac-interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </dynamic-vlan-creation><!-- operation="delete"-->
    </mac-interface>
  </mac-interfaces>
</authentication>
```

Command Syntax

```
auth-mac dynamic-vlan-creation
```

Configure mac address aging

Use this attribute to either enable or disable MAC aging. When enabled, a MAC entry is added to the forwarding database, with aging time equal to the bridge aging time. Otherwise, the MAC entry will not be aged out. If MAC aging is disabled, the MAC entry will not be aged out

This command is supported when following feature are enabled MAC_AUTH feature,HAVE_AUTHD feature

Attribute Name: mac-address-aging

Attribute Type: empty

Netconf edit-config payload

```
<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <mac-interfaces>
    <mac-interface>
      <name>WORD</name>
      <config>
```

```

    <name>WORD</name>
  </config>
  </mac-address-aging><!-- operation="delete"-->
</mac-interface>
</mac-interfaces>
</authentication>

```

Command Syntax

```
auth-mac mac-aging
```

Configure options

Use this attribute to turn on or turn off 802.1x debugging at various levels.

This command is supported when following feature are enabled HAVE_AUTHD feature

Attribute Name: options

Attribute Type: bits (event|timer|packet|nsm|all)

Netconf edit-config payload

```

<authentication xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-authentication">
  <debug>
  <config>
    <options>event</options> <!-- operation="delete"-->
  </config>
</debug>
</authentication>

```

Command Syntax

```
debug dot1x (event|timer|packet|nsm|all)
```

dot1x initialize interface IFNAME

Attribute Name: name

Attribute Type: string

Attribute Range: 1-33

Netconf RPC payload

```

<dot1x-authentication-initialize-interface xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-authentication">
  <name>IFNAME</name>
</dot1x-authentication-initialize-interface>

```

Command Syntax

```
dot1x initialize interface IFNAME
```

snmp restart auth

Netconf RPC payload

```
<dot1x-authentication-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-authentication"/>
```

Command Syntax

```
snmp restart auth
```

debug dot1x (event|timer|packet|nsm|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (event|timer|packet|nsm|all)

Netconf RPC payload

```
<dot1x-authentication-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-authentication">
  <terminal-debug-options>event</terminal-debug-options>
</dot1x-authentication-terminal-debug-on>
```

Command Syntax

```
debug dot1x (event|timer|packet|nsm|all)
```

no debug dot1x (event|timer|packet|nsm|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (event|timer|packet|nsm|all)

Netconf RPC payload

```
<dot1x-authentication-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-authentication">
  <terminal-debug-options>event</terminal-debug-options>
</dot1x-authentication-terminal-debug-off>
```

Command Syntax

```
no debug dot1x (event|timer|packet|nsm|all)
```

IPI-AUTHENTICATION-RADIUS

Configure port

Specify the radius client port number. The default port number is 1812.

This command is supported when following feature are enabled OpenSSL crypto library available

Attribute Name: port

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: source-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<authentication-radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
authentication-radius">
  <global>
    <config>
      <source-address>A.B.C.D</source-address> <!-- operation="delete"-->
      <port>0</port> <!-- operation="delete"-->
    </config>
  </global>
</authentication-radius>
```

Command Syntax

```
ip radius source-interface A.B.C.D <0-65535>
```

Configure timeout

Use this attribute to set the global timeout which is how long the device waits for a response from a RADIUS server before declaring a timeout failure.

This command is supported when following feature are enabled OpenSSL crypto library available

Attribute Name: timeout

Attribute Type: uint8

Attribute Range: 1-60

Netconf edit-config payload

```
<authentication-radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
authentication-radius">
  <global>
    <config>
      <timeout>1</timeout> <!-- operation="delete"-->
    </config>
  </global>
</authentication-radius>
```

Command Syntax

```
radius-server dot1x timeout <1-60>
```

Configure retransmit max retries

Use this attribute to specify the number of times the router transmits each radius request to the server before giving up

This command is supported when following feature are enabled OpenSSL crypto library available

Attribute Name: retransmit-max-retries

Attribute Type: uint8

Attribute Range: 1-100

Netconf edit-config payload

```
<authentication-radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
authentication-radius">
  <global>
    <config>
      <retransmit-max-retries>1</retransmit-max-retries> <!-- operation="delete"-->
    </config>
  </global>
</authentication-radius>
```

Command Syntax

```
radius-server dot1x retransmit <1-100>
```

Configure key string

Use this attribute to set a global preshared key (shared secret) which is a text string shared between the device and RADIUS servers

This command is supported when following feature are enabled OpenSSL crypto library available

Attribute Name: key-string

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```
<authentication-radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
authentication-radius">
  <global>
    <config>
      <key-string>WORD</key-string> <!-- operation="delete"-->
    </config>
  </global>
</authentication-radius>
```

Command Syntax

```
radius-server dot1x key-string WORD
```

Configure encryption key

Use this attribute to set a global preshared key (shared secret) which is a text string shared between the device and RADIUS servers

This command is supported when following feature are enabled OpenSSL crypto library available

Attribute Name: encryption-key

Attribute Type: string

Attribute Range: 18-130

Netconf edit-config payload

```
<authentication-radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
authentication-radius">
  <global>
  <config>
    <encryption-key>WORD</encryption-key> <!-- operation="delete"-->
  </config>
</global>
</authentication-radius>
```

Command Syntax

```
radius-server dot1x key-string encrypted WORD
```

Configure host address

The host-address to configure the radius host.

This command is supported when following feature are enabled OpenSSL crypto library available

Attribute Name: host-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<authentication-radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
authentication-radius">
  <hosts>
  <host> <!-- operation="delete"-->
    <host-address>A.B.C.D</host-address>
  <config>
    <host-address>A.B.C.D</host-address>
  </config>
</host>
</hosts>
</authentication-radius>
```

Command Syntax

```
radius-server dot1x host A.B.C.D
```

Configure host port

Specify the radius client port number. The default port number is 1812.

This command is supported when following feature are enabled OpenSSL crypto library available

Attribute Name: host-port

Attribute Type: uint16

Attribute Range: 0-65535

Netconf edit-config payload

```
<authentication-radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
authentication-radius">
```

```
<hosts>
<host>
  <host-address>A.B.C.D</host-address>
  <config>
    <host-address>A.B.C.D</host-address>
  </config>
  <host-port>0</host-port> <!-- operation="delete"-->
</host>
</hosts>
</authentication-radius>
```

Command Syntax

```
auth-port <0-65535>
```

Configure host timeout

Use this attribute to set the timeout which is how long the device waits for a response from a RADIUS server before declaring a timeout failure.

This command is supported when following feature are enabled OpenSSL crypto library available

Attribute Name: host-timeout

Attribute Type: uint8

Attribute Range: 0-60

Netconf edit-config payload

```
<authentication-radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
authentication-radius">
  <hosts>
  <host>
    <host-address>A.B.C.D</host-address>
    <config>
      <host-address>A.B.C.D</host-address>
    </config>
    <host-timeout>0</host-timeout> <!-- operation="delete"-->
  </host>
</hosts>
</authentication-radius>
```

Command Syntax

```
timeout <0-60>
```

Configure host retransmit max retries

Use this attribute to specify the number of times the router transmits each radius request to the server before giving up.

This command is supported when following feature are enabled OpenSSL crypto library available

Attribute Name: host-retransmit-max-retries

Attribute Type: uint8

Attribute Range: 0-100

Netconf edit-config payload

```

<authentication-radius xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
authentication-radius">
  <hosts>
    <host>
      <host-address>A.B.C.D</host-address>
      <config>
        <host-address>A.B.C.D</host-address>
      </config>
      <host-retransmit-max-retries>0</host-retransmit-max-retries> <!--
operation="delete"-->
    </host>
  </hosts>
</authentication-radius>

```

Command Syntax

```
retransmit <0-100>
```

IPI-ACL

Configure type

Type indicates the fields allowed in the ACL entries belonging to the ACL set (e.g., ip, ipv6, etc.)

Attribute Name: type

Attribute Type: enum (mac|ip|ipv6|arp)

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set> <!-- operation="delete"-->
      <type>ip</type>
      <config>
        <type>ip</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
</acl>

```

Command Syntax

```
ip access-list NAME
```

Configure name

Type indicates the fields allowed in the ACL entries belonging to the ACL set (e.g., ip, ipv6, etc.)

Attribute Name: type

Attribute Type: enum (mac|ip|ipv6|arp)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set> <!-- operation="delete"-->
      <type>ipv6</type>
      <config>
        <type>ipv6</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
</acl>
```

Command Syntax

```
ipv6 access-list NAME
```

Configure description

Description, or comment, for the ACL set

Attribute Name: description

Attribute Type: string

Attribute Range: 1-100

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
      <description>LINE</description> <!-- operation="delete"-->
    </acl-set>
  </acl-sets>
</acl>
```

Command Syntax

```
remark LINE
```

Configure ipv6 disable default icmpv6 rule

Use this attribute to inform that the default icmpv6 rule is disable for the IPv6 ACL.

Attribute Name: ipv6-disable-default-icmpv6-rule

Attribute Type: uint8

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
<acl-sets>
<acl-set>
  <type>mac</type>
  <config>
    <type>mac</type>
    <name>WORD</name>
  </config>
  <name>NAME</name>
  </ipv6-disable-default-icmpv6-rule><!-- operation="delete"-->
</acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
no 268435453 permit icmpv6 any any
```

Configure starting sequence number

Use this attribute to set starting sequence number for resequencing

Attribute Name: starting-sequence-number

Attribute Type: uint32

Attribute Range: 1-268435453

Attribute Name: increment-steps

Attribute Type: uint32

Attribute Range: 1-268435453

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
<acl-sets>
<acl-set>
  <type>mac</type>
  <config>
    <type>mac</type>
    <name>WORD</name>
  </config>
  <name>NAME</name>
  <re-sequence>
<config>
  <increment-steps>1</increment-steps> <!-- operation="delete"-->
  <starting-sequence-number>1</starting-sequence-number> <!--
operation="delete"-->
</config>
</re-sequence>
</acl-set>
```

```
</acl-sets>  
</acl>
```

Command Syntax

```
resequence <1-268435453> <1-268435453>
```

Configure forwarding action default

Use this attribute to set default forwarding action

Attribute Name: forwarding-action-default

Attribute Type: enum (deny-all|permit-all)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">  
<acl-sets>  
<acl-set>  
  <type>mac</type>  
  <config>  
    <type>mac</type>  
    <name>WORD</name>  
  </config>  
  <name>NAME</name>  
<default-actions>  
<config>  
  <forwarding-action-default>deny-all</forwarding-action-default> <!--  
operation="delete"-->  
</config>  
</default-actions>  
</acl-set>  
</acl-sets>  
</acl>
```

Command Syntax

```
default (deny-all|permit-all)
```

Configure inner vlan id

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: union

Attribute Name: destination-address

Attribute Type: union

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <ipv4>
        <config>
          <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
          </protocol-tcp><!-- operation="delete"-->
          <source-address>any</source-address> <!-- operation="delete"-->
          <destination-address>any</destination-address> <!-- operation="delete"-->
          <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
          <vlan-id>1</vlan-id> <!-- operation="delete"-->
          <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
        </config>
      </ipv4>
    </acl-entry>
  </acl-entries>
</acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
<1-268435453>|) (deny|permit) tcp (any|host A.B.C.D|A.B.C.D/M|A.B.C.D A.B.C.D)
  (any|host A.B.C.D|A.B.C.D/M|A.B.C.D A.B.C.D)
  ({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|) (inner-vlan <1-4094>|)
```

Configure sequence id

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: dscp

Attribute Type: union

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
  <acl-entry>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
    </config>
    <ipv4>
      <config>
        <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
        </protocol-tcp><!-- operation="delete"-->
        <source-address>any</source-address> <!-- operation="delete"-->
      </config>
    </ipv4>
  </acl-entry>
</acl>
```

```

        <destination-address>any</destination-address> <!-- operation="delete"-->
        <dscp>default</dscp> <!-- operation="delete"-->
        <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
    </config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) (any) dscp
  (default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
  af43|cs5|ef|cs6|cs7|<0-63>) ({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-
  4094>|) (inner-vlan <1-4094>|)

```

Configure forwarding action

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: precedence

Attribute Type: union

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">

```

```
<acl-sets>
<acl-set>
  <type>mac</type>
  <config>
    <type>mac</type>
    <name>WORD</name>
  </config>
  <name>NAME</name>
</acl-sets>
<acl-entries>
<acl-entry>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
  </config>
  <ipv4>
  <config>
    <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
    </protocol-tcp><!-- operation="delete"-->
    <source-address>any</source-address> <!-- operation="delete"-->
    <destination-address>any</destination-address> <!-- operation="delete"-->
    <precedence>routine</precedence> <!-- operation="delete"-->
    <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
    <vlan-id>1</vlan-id> <!-- operation="delete"-->
    <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
  </config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) tcp (any) (any) precedence
(routine|priority|immediate|flash|flashoverride|critical|internet|network|<0-7>)
({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|) (inner-vlan <1-4094>|)
```

Configure protocol tcp

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-destination-port

Attribute Type: union

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-sets>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <ipv4>
          <config>
            <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
            </protocol-tcp><!-- operation="delete"-->
            <source-address>any</source-address> <!-- operation="delete"-->
            <destination-address>any</destination-address> <!-- operation="delete"-->
            <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
            <tcp-destination-port>echo</tcp-destination-port> <!--
operation="delete"-->
            <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
            <vlan-id>1</vlan-id> <!-- operation="delete"-->
            <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
          </config>
        </ipv4>
      </acl-entry>
    </acl-entries>
  </acl>
```

```
</acl-entries>  
</acl-set>  
</acl-sets>  
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) tcp (any) (any) (eq|neq|lt|gt)  
  (echo|discard|daytime|chargen|ftp-  
  data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop  
  2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-  
  rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls|<0-  
  65535>) ({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|) (inner-vlan <1-  
  4094>|)
```

Configure source address

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-destination-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|p
im-auto-rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
<acl-sets>
<acl-set>
  <type>mac</type>
  <config>
    <type>mac</type>
    <name>WORD</name>
  </config>
  <name>NAME</name>
</acl-sets>
<acl-entries>
<acl-entry>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
  </config>
  <ipv4>
  <config>
    <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
    </protocol-tcp><!-- operation="delete"-->
    <source-address>any</source-address> <!-- operation="delete"-->
    <destination-address>any</destination-address> <!-- operation="delete"-->
    <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
    <tcp-destination-port>echo</tcp-destination-port> <!--
operation="delete"-->
    <dscp>default</dscp> <!-- operation="delete"-->
    <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
    <vlan-id>1</vlan-id> <!-- operation="delete"-->
    <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
  </config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) (any) (eq|neq|lt|gt)
(echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls) dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7) ({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|)
(inner-vlan <1-4094>|)

```

Configure destination address

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-destination-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: precedence

Attribute Type: enum (routine|priority|immediate|flash|flashoverride|critical|internet|network)

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <ipv4>
```

```

<config>
  <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
  </protocol-tcp><!-- operation="delete"-->
  <source-address>any</source-address> <!-- operation="delete"-->
  <destination-address>any</destination-address> <!-- operation="delete"-->
  <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
  <tcp-destination-port>echo</tcp-destination-port> <!--
operation="delete"-->
  <precedence>routine</precedence> <!-- operation="delete"-->
  <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
  <vlan-id>1</vlan-id> <!-- operation="delete"-->
  <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
</config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) (any) (eq|neq|lt|gt)
(echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)
precedence
(routine|priority|immediate|flash|flashoverride|critical|internet|network)
({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure lower destination port in range

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: lower-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
        </config>
        <ipv4>
          <config>
            <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
            </protocol-tcp><!-- operation="delete"-->
            <source-address>any</source-address> <!-- operation="delete"-->
            <destination-address>any</destination-address> <!-- operation="delete"-->
            <lower-destination-port-in-range>0</lower-destination-port-in-range> <!--
operation="delete"-->
            <upper-destination-port-in-range>0</upper-destination-port-in-range> <!--
operation="delete"-->
            <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
            <vlan-id>1</vlan-id> <!-- operation="delete"-->
            <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
          </config>
        </ipv4>
      </acl-entry>
    </acl-entries>
  </acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) tcp (any) (any) range <0-65535> <0-65535>
({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|) (inner-vlan <1-4094>|)
```

Configure upper destination port in range

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: lower-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
```

```

        <name>WORD</name>
    </config>
    <name>NAME</name>
<acl-entries>
<acl-entry>
    <sequence-id>1</sequence-id>
    <config>
        <sequence-id>1</sequence-id>
    </config>
    <ipv4>
    <config>
        <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
        </protocol-tcp><!-- operation="delete"-->
        <source-address>any</source-address> <!-- operation="delete"-->
        <destination-address>any</destination-address> <!-- operation="delete"-->
        <lower-destination-port-in-range>0</lower-destination-port-in-range> <!--
operation="delete"-->
        <upper-destination-port-in-range>0</upper-destination-port-in-range> <!--
operation="delete"-->
        <dscp>default</dscp> <!-- operation="delete"-->
        <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
    </config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) (any) range <0-65535> <0-65535> dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7) ({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|)
(inner-vlan <1-4094>|)

```

Configure precedence

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: lower-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: precedence

Attribute Type: enum (routine|priority|immediate|flash|flashoverride|critical|internet|network)

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <ipv4>
        <config>
          <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
          </protocol-tcp><!-- operation="delete"-->
          <source-address>any</source-address> <!-- operation="delete"-->
          <destination-address>any</destination-address> <!-- operation="delete"-->
          <lower-destination-port-in-range>0</lower-destination-port-in-range> <!--
operation="delete"-->
          <upper-destination-port-in-range>0</upper-destination-port-in-range> <!--
operation="delete"-->
          <precedence>routine</precedence> <!-- operation="delete"-->
          <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
        </config>
      </ipv4>
    </acl-entry>
  </acl-entries>
</acl>
```

```
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
    </config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) tcp (any) (any) range <0-65535> <0-65535> precedence
(routine|priority|immediate|flash|flashoverride|critical|internet|network)
({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|) (inner-vlan <1-4094>|)
```

Configure source port operator

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-source-port

Attribute Type: union

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-destination-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-rp|exec|login|cmd|pd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
  <acl-set>
    <type>mac</type>
    <config>
      <type>mac</type>
      <name>WORD</name>
    </config>
    <name>NAME</name>
  <acl-entries>
  <acl-entry>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
    </config>
    <ipv4>
    <config>
      <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
      </protocol-tcp><!-- operation="delete"-->
      <source-address>any</source-address> <!-- operation="delete"-->
      <source-port-operator>eq</source-port-operator> <!-- operation="delete"-->
    >
      <tcp-source-port>echo</tcp-source-port> <!-- operation="delete"-->
      <destination-address>any</destination-address> <!-- operation="delete"-->
      <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
      <tcp-destination-port>echo</tcp-destination-port> <!--
operation="delete"-->
      <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
      <vlan-id>1</vlan-id> <!-- operation="delete"-->
      <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
    </config>
  </ipv4>
  </acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) tcp (any) (eq|neq|lt|gt)
(echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls|<0-
65535>) (any) (eq|neq|lt|gt) (echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
```

```
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-  
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)  
({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|) (inner-vlan <1-4094>|)
```

Configure tcp source port

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-source-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|p
im-auto-rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-destination-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|p
im-auto-rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
<acl-sets>
<acl-set>
  <type>mac</type>
  <config>
    <type>mac</type>
    <name>WORD</name>
  </config>
  <name>NAME</name>
</acl-sets>
<acl-entries>
<acl-entry>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
  </config>
  <ipv4>
  <config>
    <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
    </protocol-tcp><!-- operation="delete"-->
    <source-address>any</source-address> <!-- operation="delete"-->
    <source-port-operator>eq</source-port-operator> <!-- operation="delete"-->
  >
    <tcp-source-port>echo</tcp-source-port> <!-- operation="delete"-->
    <destination-address>any</destination-address> <!-- operation="delete"-->
    <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
    <tcp-destination-port>echo</tcp-destination-port> <!--
operation="delete"-->
    <dscp>default</dscp> <!-- operation="delete"-->
    <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
    <vlan-id>1</vlan-id> <!-- operation="delete"-->
    <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
  </config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) (eq|neq|lt|gt)
(echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)
(any) (eq|neq|lt|gt) (echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls) dscp

```

```
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7) ({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|) (inner-vlan <1-4094>|)
```

Configure destination port operator

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-source-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-rp|exec|login|cmd|pd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-destination-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-rp|exec|login|cmd|pd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: precedence

Attribute Type: enum (routine|priority|immediate|flash|flashoverride|critical|internet|network)

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
```

```

<acl-sets>
<acl-set>
  <type>mac</type>
  <config>
    <type>mac</type>
    <name>WORD</name>
  </config>
  <name>NAME</name>
</acl-sets>
<acl-entries>
<acl-entry>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
  </config>
  <ipv4>
  <config>
    <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
    </protocol-tcp><!-- operation="delete"-->
    <source-address>any</source-address> <!-- operation="delete"-->
    <source-port-operator>eq</source-port-operator> <!-- operation="delete"-->
  </config>
  <tcp-source-port>echo</tcp-source-port> <!-- operation="delete"-->
  <destination-address>any</destination-address> <!-- operation="delete"-->
  <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
  <tcp-destination-port>echo</tcp-destination-port> <!--
operation="delete"-->
  <precedence>routine</precedence> <!-- operation="delete"-->
  <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
  <vlan-id>1</vlan-id> <!-- operation="delete"-->
  <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
  </config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) (eq|neq|lt|gt)
(echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)
(any) (eq|neq|lt|gt) (echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)
precedence
(routine|priority|immediate|flash|flashoverride|critical|internet|network)
({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure tcp flags

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-source-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: lower-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
    </acl-set>
  </acl-sets>
</acl>
```



```

    </config>
    <name>NAME</name>
  <acl-entries>
  <acl-entry>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
    </config>
    <ipv4>
    <config>
      <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
      </protocol-tcp><!-- operation="delete"-->
      <source-address>any</source-address> <!-- operation="delete"-->
      <source-port-operator>eq</source-port-operator> <!-- operation="delete"-->
    >
      <tcp-source-port>echo</tcp-source-port> <!-- operation="delete"-->
      <destination-address>any</destination-address> <!-- operation="delete"-->
      <lower-destination-port-in-range>0</lower-destination-port-in-range> <!--
operation="delete"-->
      <upper-destination-port-in-range>0</upper-destination-port-in-range> <!--
operation="delete"-->
      <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
      <vlan-id>1</vlan-id> <!-- operation="delete"-->
      <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
    </config>
  </ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) (eq|neq|lt|gt)
(echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)
(any) range <0-65535> <0-65535> ({ack|established|fin|psh|rst|syn|urg}|) (vlan
<1-4094>|) (inner-vlan <1-4094>|)

```

Configure dscp

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-source-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: lower-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
    </acl-entry>
  </acl-entries>
</acl>
```

```

</config>
<ipv4>
<config>
  <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
  </protocol-tcp><!-- operation="delete"-->
  <source-address>any</source-address> <!-- operation="delete"-->
  <source-port-operator>eq</source-port-operator> <!-- operation="delete"-->
>
  <tcp-source-port>echo</tcp-source-port> <!-- operation="delete"-->
  <destination-address>any</destination-address> <!-- operation="delete"-->
  <lower-destination-port-in-range>0</lower-destination-port-in-range> <!--
operation="delete"-->
  <upper-destination-port-in-range>0</upper-destination-port-in-range> <!--
operation="delete"-->
  <dscp>default</dscp> <!-- operation="delete"-->
  <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
  <vlan-id>1</vlan-id> <!-- operation="delete"-->
  <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
</config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) (eq|neq|lt|gt)
(echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)
(any) range <0-65535> <0-65535> dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7) ({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|)
(inner-vlan <1-4094>|)

```

Configure vlan id

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-source-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: lower-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: precedence

Attribute Type: enum (routine|priority|immediate|flash|flashoverride|critical|internet|network)

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <ipv4>
        <config>
          <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
          </protocol-tcp><!-- operation="delete"-->
        </config>
      </ipv4>
    </acl-entry>
  </acl-entries>
</acl>
```

```

    <source-address>any</source-address> <!-- operation="delete"-->
    <source-port-operator>eq</source-port-operator> <!-- operation="delete"--
>
    <tcp-source-port>echo</tcp-source-port> <!-- operation="delete"-->
    <destination-address>any</destination-address> <!-- operation="delete"-->
    <lower-destination-port-in-range>0</lower-destination-port-in-range> <!--
operation="delete"-->
    <upper-destination-port-in-range>0</upper-destination-port-in-range> <!--
operation="delete"-->
    <precedence>routinely</precedence> <!-- operation="delete"-->
    <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
    <vlan-id>1</vlan-id> <!-- operation="delete"-->
    <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
  </config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) (eq|neq|lt|gt)
(echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)
(any) range <0-65535> <0-65535> precedence
(routinely|priority|immediate|flash|flashoverride|critical|internet|network)
({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure lower source port in range

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: lower-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-destination-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <ipv4>
        <config>
          <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
          </protocol-tcp><!-- operation="delete"-->
          <source-address>any</source-address> <!-- operation="delete"-->
          <lower-source-port-in-range>0</lower-source-port-in-range> <!--
operation="delete"-->
          <upper-source-port-in-range>0</upper-source-port-in-range> <!--
operation="delete"-->
          <destination-address>any</destination-address> <!-- operation="delete"-->
          <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
        </config>
      </ipv4>
    </acl-entry>
  </acl-entries>
</acl>
```

```

        <tcp-destination-port>echo</tcp-destination-port> <!--
operation="delete"-->
        <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
    </config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) range <0-65535> <0-65535> (any)
(eq|neq|lt|gt) (echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)
({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure upper source port in range

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: lower-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-destination-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: dscp

Attribute Type: enum (default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <ipv4>
        <config>
          <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
          </protocol-tcp><!-- operation="delete"-->
          <source-address>any</source-address> <!-- operation="delete"-->
          <lower-source-port-in-range>0</lower-source-port-in-range> <!--
operation="delete"-->
          <upper-source-port-in-range>0</upper-source-port-in-range> <!--
operation="delete"-->
          <destination-address>any</destination-address> <!-- operation="delete"-->
          <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
          <tcp-destination-port>echo</tcp-destination-port> <!--
operation="delete"-->
          <dscp>default</dscp> <!-- operation="delete"-->
          <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
          <vlan-id>1</vlan-id> <!-- operation="delete"-->
          <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
        </config>
      </ipv4>
    </acl-entry>
  </acl-entries>
</acl>
```



```

</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) range <0-65535> <0-65535> (any)
(eq|neq|lt|gt) (echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls) dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7) ({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|)
(inner-vlan <1-4094>|)

```

Configure tcp destination port

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: lower-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-destination-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|p
im-auto-rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: precedence

Attribute Type: enum (routine|priority|immediate|flash|flashoverride|critical|internet|network)

Attribute Name: tcp-flags

Attribute Type: bits (ack|established|fin|psh|rst|syn|urg)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <ipv4>
        <config>
          <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
          </protocol-tcp><!-- operation="delete"-->
          <source-address>any</source-address> <!-- operation="delete"-->
          <lower-source-port-in-range>0</lower-source-port-in-range> <!--
operation="delete"-->
          <upper-source-port-in-range>0</upper-source-port-in-range> <!--
operation="delete"-->
          <destination-address>any</destination-address> <!-- operation="delete"-->
          <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
          <tcp-destination-port>echo</tcp-destination-port> <!--
operation="delete"-->
          <precedence>routine</precedence> <!-- operation="delete"-->
          <tcp-flags>ack</tcp-flags> <!-- operation="delete"-->
          <vlan-id>1</vlan-id> <!-- operation="delete"-->
          <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
        </config>
      </ipv4>
    </acl-entry>
  </acl-entries>
</acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) tcp (any) range <0-65535> <0-65535> (any)
  (eq|neq|lt|gt) (echo|discard|daytime|chargen|ftp-
  data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
  2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
  rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)
  precedence
  (routine|priority|immediate|flash|flashoverride|critical|internet|network)
  ({ack|established|fin|psh|rst|syn|urg}|) (vlan <1-4094>|) (inner-vlan <1-4094>|)
```

Configure protocol udp

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-udp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
    </acl-entry>
  </acl-entries>
</ipv4>
```

```
<config>
  <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
  </protocol-udp><!-- operation="delete"-->
  <source-address>any</source-address> <!-- operation="delete"-->
  <destination-address>any</destination-address> <!-- operation="delete"-->
  <vlan-id>1</vlan-id> <!-- operation="delete"-->
  <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
</config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) udp (any) (any) (vlan <1-4094>|) (inner-vlan <1-4094>|)
```

Configure udp destination port

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-udp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: udp-destination-port

Attribute Type: union

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
```

```

<acl-sets>
<acl-set>
  <type>mac</type>
  <config>
    <type>mac</type>
    <name>WORD</name>
  </config>
  <name>NAME</name>
<acl-entries>
<acl-entry>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
  </config>
  <ipv4>
  <config>
    <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
    </protocol-udp><!-- operation="delete"-->
    <source-address>any</source-address> <!-- operation="delete"-->
    <destination-address>any</destination-address> <!-- operation="delete"-->
    <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
    <udp-destination-port>echo</udp-destination-port> <!--
operation="delete"-->
    <vlan-id>1</vlan-id> <!-- operation="delete"-->
    <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
  </config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) udp (any) (any) (eq|neq|lt|gt)
(echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbio
s-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-
rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp|<0-65535>) (vlan <1-4094>|)
(inner-vlan <1-4094>|)

```

Configure udp source port

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-udp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: udp-source-port

Attribute Type: union

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: udp-destination-port

Attribute Type: enum (echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbios-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <ipv4>
        <config>
          <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
          </protocol-udp><!-- operation="delete"-->
          <source-address>any</source-address> <!-- operation="delete"-->
          <source-port-operator>eq</source-port-operator> <!-- operation="delete"-->
        </config>
      </ipv4>
    </acl-entry>
  </acl-entries>
  <acl-entry>
    <sequence-id>2</sequence-id>
    <config>
      <sequence-id>2</sequence-id>
    </config>
    <udp-source-port>echo</udp-source-port> <!-- operation="delete"-->
    <destination-address>any</destination-address> <!-- operation="delete"-->
  </acl-entry>
</acl>
```

```

        <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
        <udp-destination-port>echo</udp-destination-port> <!--
operation="delete"-->
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
    </config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) udp (any) (eq|neq|lt|gt)
(echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbio
s-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-
rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp|<0-65535>) (any) (eq|neq|lt|gt)
(echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbio
s-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-
rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp) (vlan <1-4094>|) (inner-vlan
<1-4094>|)

```

Configure protocol icmp

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-icmp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
<acl-sets>

```

```
<acl-set>
  <type>mac</type>
  <config>
    <type>mac</type>
    <name>WORD</name>
  </config>
  <name>NAME</name>
<acl-entries>
<acl-entry>
  <sequence-id>1</sequence-id>
  <config>
    <sequence-id>1</sequence-id>
  </config>
  <ipv4>
  <config>
    <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
    </protocol-icmp><!-- operation="delete"-->
    <source-address>any</source-address> <!-- operation="delete"-->
    <destination-address>any</destination-address> <!-- operation="delete"-->
    <vlan-id>1</vlan-id> <!-- operation="delete"-->
    <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
  </config>
</ipv4>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) icmp (any) (any) (vlan <1-4094>|) (inner-vlan <1-4094>|)
```

Configure protocol name

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-name

Attribute Type: union

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <type>mac</type>
      <config>
        <type>mac</type>
        <name>WORD</name>
      </config>
      <name>NAME</name>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <ipv4>
        <config>
          <forwarding-action>deny</forwarding-action> <!-- operation="delete"-->
          <protocol-name>igmp</protocol-name> <!-- operation="delete"-->
          <source-address>any</source-address> <!-- operation="delete"-->
          <destination-address>any</destination-address> <!-- operation="delete"-->
          <vlan-id>1</vlan-id> <!-- operation="delete"-->
          <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
        </config>
      </ipv4>
    </acl-entry>
  </acl-entries>
</acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit)
  (igmp|ipip|ipv6ip|rsvp|gre|esp|ahp|eigrp|ospf|pim|ipcomp|vrrp|any|<0-255>) (any)
  (any) (vlan <1-4094>|) (inner-vlan <1-4094>|)
```

IPI-ACL-IPV6

Configure vlan id

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: union

Attribute Name: destination-address

Attribute Type: union

Attribute Name: dscp

Attribute Type: union

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <ipv6>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            </protocol-tcp><!-- operation="delete"-->
            <source-address>any</source-address> <!-- operation="delete"-->
            <destination-address>any</destination-address> <!--
operation="delete"-->
            <dscp>default</dscp> <!-- operation="delete"-->
            <vlan-id>1</vlan-id> <!-- operation="delete"-->
          </config>
        </ipv6>
      </acl-entry>
    </acl-entries>
  </acl-set>
```

```
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) tcp (any|X:X::X:X/M|X:X::X:X X:X::X:X)
  (any|X:X::X:X/M|X:X::X:X X:X::X:X) (dscp
  (default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
  af43|cs5|ef|cs6|cs7|<0-63>)|) (vlan <1-4094>|)
```

Configure name

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-destination-port

Attribute Type: union

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    </acl-entries>
```

```

    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <ipv6>
        <config>
          <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
          </protocol-tcp><!-- operation="delete"-->
          <source-address>any</source-address> <!-- operation="delete"-->
operation="delete"-->
          <destination-address>any</destination-address> <!--
operation="delete"-->
          <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
          <tcp-destination-port>echo</tcp-destination-port> <!--
operation="delete"-->
          <dscp>default</dscp> <!-- operation="delete"-->
          <vlan-id>1</vlan-id> <!-- operation="delete"-->
        </config>
      </ipv6>
    </acl-entry>
  </acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) (any) (eq|neq|lt|gt)
(echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls|<0-
65535>) (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)

```

Configure type

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: lower-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <ipv6>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              </protocol-tcp><!-- operation="delete"-->
              <source-address>any</source-address> <!-- operation="delete"-->
              <destination-address>any</destination-address> <!--
operation="delete"-->
              <lower-destination-port-in-range>0</lower-destination-port-in-
range> <!-- operation="delete"-->
              <upper-destination-port-in-range>0</upper-destination-port-in-
range> <!-- operation="delete"-->
              <dscp>default</dscp> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
            </config>
          </ipv6>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>
```

```
</acl-entries>  
</acl-set>  
</acl-sets>  
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) tcp (any) (any) range <0-65535> <0-65535> (dscp  
  (default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|  
  af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)
```

Configure sequence id

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-source-port

Attribute Type: union

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-destination-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|p
im-auto-rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">  
<acl-sets>
```

```

<acl-set>
  <name>NAME</name>
  <config>
    <name>WORD</name>
    <type>mac</type>
  </config>
  <type>mac</type>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <ipv6>
        <config>
          <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
          </protocol-tcp><!-- operation="delete"-->
          <source-address>any</source-address> <!-- operation="delete"-->
          <source-port-operator>eq</source-port-operator> <!--
operation="delete"-->
          <tcp-source-port>echo</tcp-source-port> <!--
operation="delete"-->
          <destination-address>any</destination-address> <!--
operation="delete"-->
          <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
          <tcp-destination-port>echo</tcp-destination-port> <!--
operation="delete"-->
          <dscp>default</dscp> <!-- operation="delete"-->
          <vlan-id>1</vlan-id> <!-- operation="delete"-->
        </config>
      </ipv6>
    </acl-entry>
  </acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) (eq|neq|lt|gt)
(echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls|<0-
65535>) (any) (eq|neq|lt|gt) (echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)
(dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)

```

Configure forwarding action

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-source-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: lower-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    </acl-set>
  </acl-sets>
</acl>
```



```

    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <ipv6>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            </protocol-tcp><!-- operation="delete"-->
            <source-address>any</source-address> <!-- operation="delete"-->
            <source-port-operator>eq</source-port-operator> <!--
operation="delete"-->
            <tcp-source-port>echo</tcp-source-port> <!--
operation="delete"-->
            <destination-address>any</destination-address> <!--
operation="delete"-->
            <lower-destination-port-in-range>0</lower-destination-port-in-
range> <!-- operation="delete"-->
            <upper-destination-port-in-range>0</upper-destination-port-in-
range> <!-- operation="delete"-->
            <dscp>default</dscp> <!-- operation="delete"-->
            <vlan-id>1</vlan-id> <!-- operation="delete"-->
          </config>
        </ipv6>
      </acl-entry>
    </acl-entries>
  </acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) (eq|neq|lt|gt)
(echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)
(any) range <0-65535> <0-65535> (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)

```

Configure protocol tcp

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-source-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <ipv6>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              </protocol-tcp><!-- operation="delete"-->
              <source-address>any</source-address> <!-- operation="delete"-->
              <source-port-operator>eq</source-port-operator> <!--
operation="delete"-->
              <tcp-source-port>echo</tcp-source-port> <!--
operation="delete"-->
              <destination-address>any</destination-address> <!--
operation="delete"-->
              <dscp>default</dscp> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
            </config>
          </ipv6>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>
```

```

        </config>
    </ipv6>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) (eq|neq|lt|gt)
(echo|discard|daytime|chargen|ftp-
data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)
(any) (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)

```

Configure source address

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: lower-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: tcp-destination-port

Attribute Type: enum (echo|discard|daytime|chargen|ftp-data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-rp|exec|login|cmd|lldp|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <ipv6>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              </protocol-tcp><!-- operation="delete"-->
              <source-address>any</source-address> <!-- operation="delete"-->
              <lower-source-port-in-range>0</lower-source-port-in-range> <!--
operation="delete"-->
              <upper-source-port-in-range>0</upper-source-port-in-range> <!--
operation="delete"-->
              <destination-address>any</destination-address> <!--
operation="delete"-->
              <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
              <tcp-destination-port>echo</tcp-destination-port> <!--
operation="delete"-->
              <dscp>default</dscp> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
            </config>
          </ipv6>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) tcp (any) range <0-65535> <0-65535> (any)
  (eq|neq|lt|gt) (echo|discard|daytime|chargen|ftp-
  data|ftp|ssh|telnet|smtp|time|whois|tacacs|domain|gopher|finger|www|hostname|pop
  2|pop3|sunrpc|ident|nntp|bgp|irc|pim-auto-
  rp|exec|login|cmd|lpd|talk|uucp|klogin|kshell|netconf-ssh|drip|netconf-tls)
  (dscp
  (default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
  af43|cs5|ef|cs6|cs7) |) (vlan <1-4094>|)
```

Configure lower source port in range

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: lower-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: lower-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <ipv6>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              </protocol-tcp><!-- operation="delete"-->
              <source-address>any</source-address> <!-- operation="delete"-->
              <lower-source-port-in-range>0</lower-source-port-in-range> <!--
operation="delete"-->
              <upper-source-port-in-range>0</upper-source-port-in-range> <!--
operation="delete"-->
              <destination-address>any</destination-address> <!--
operation="delete"-->
              <lower-destination-port-in-range>0</lower-destination-port-in-
range> <!-- operation="delete"-->
              <upper-destination-port-in-range>0</upper-destination-port-in-
range> <!-- operation="delete"-->
              <dscp>default</dscp> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
            </config>
          </ipv6>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) range <0-65535> <0-65535> (any) range <0-
65535> <0-65535> (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)

```

Configure upper source port in range

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-tcp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: lower-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <ipv6>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
          </protocol-tcp><!-- operation="delete"-->
```

```

        <source-address>any</source-address> <!-- operation="delete"-->
        <lower-source-port-in-range>0</lower-source-port-in-range> <!--
operation="delete"-->
        <upper-source-port-in-range>0</upper-source-port-in-range> <!--
operation="delete"-->
        <destination-address>any</destination-address> <!--
operation="delete"-->
        <dscp>default</dscp> <!-- operation="delete"-->
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
    </config>
</ipv6>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) tcp (any) range <0-65535> <0-65535> (any) (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7) |) (vlan <1-4094>|)

```

Configure protocol udp

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-udp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
<acl-sets>
    <acl-set>

```



```

    <name>NAME</name>
    <config>
        <name>WORD</name>
        <type>mac</type>
    </config>
        <type>mac</type>
    <acl-entries>
        <acl-entry>
            <sequence-id>1</sequence-id>
            <config>
                <sequence-id>1</sequence-id>
            </config>
            <ipv6>
                <config>
                    <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
                    </protocol-udp><!-- operation="delete"-->
                    <source-address>any</source-address> <!-- operation="delete"-->
                    <destination-address>any</destination-address> <!--
operation="delete"-->
                    <dscp>default</dscp> <!-- operation="delete"-->
                    <vlan-id>1</vlan-id> <!-- operation="delete"-->
                </config>
            </ipv6>
        </acl-entry>
    </acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) udp (any) (any) (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)

```

Configure destination address

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-udp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: udp-destination-port

Attribute Type: union

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
        <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <ipv6>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              </protocol-udp><!-- operation="delete"-->
              <source-address>any</source-address> <!-- operation="delete"-->
              <destination-address>any</destination-address> <!--
operation="delete"-->
              <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
              <udp-destination-port>echo</udp-destination-port> <!--
operation="delete"-->
              <dscp>default</dscp> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
            </config>
          </ipv6>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) udp (any) (any) (eq|neq|lt|gt)
(echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbio
s-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-
rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp|<0-65535>) (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)
```

Configure lower destination port in range

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-udp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: lower-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
<acl-sets>
  <acl-set>
    <name>NAME</name>
    <config>
      <name>WORD</name>
      <type>mac</type>
    </config>
```

```

        <type>mac</type>
    <acl-entries>
        <acl-entry>
            <sequence-id>1</sequence-id>
            <config>
                <sequence-id>1</sequence-id>
            </config>
            <ipv6>
                <config>
                    <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
                    </protocol-udp><!-- operation="delete"-->
                    <source-address>any</source-address> <!-- operation="delete"-->
                    <destination-address>any</destination-address> <!--
operation="delete"-->
                    <lower-destination-port-in-range>0</lower-destination-port-in-
range> <!-- operation="delete"-->
                    <upper-destination-port-in-range>0</upper-destination-port-in-
range> <!-- operation="delete"-->
                    <dscp>default</dscp> <!-- operation="delete"-->
                    <vlan-id>1</vlan-id> <!-- operation="delete"-->
                </config>
            </ipv6>
        </acl-entry>
    </acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) udp (any) (any) range <0-65535> <0-65535> (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)

```

Configure source port operator

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-udp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: udp-source-port

Attribute Type: union

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: udp-destination-port

Attribute Type: enum (echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbios-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <ipv6>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            </protocol-udp><!-- operation="delete"-->
            <source-address>any</source-address> <!-- operation="delete"-->
            <source-port-operator>eq</source-port-operator> <!--
operation="delete"-->
            <udp-source-port>echo</udp-source-port> <!--
operation="delete"-->
            <destination-address>any</destination-address> <!--
operation="delete"-->
            <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
            <udp-destination-port>echo</udp-destination-port> <!--
operation="delete"-->
            <dscp>default</dscp> <!-- operation="delete"-->
```

```
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
    </config>
</ipv6>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) udp (any) (eq|neq|lt|gt)
(echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbio
s-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-
rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp|<0-65535>) (any) (eq|neq|lt|gt)
(echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbio
s-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-
rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp) (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)
```

Configure udp source port

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-udp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: udp-source-port

Attribute Type: enum (echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbios-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: lower-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <ipv6>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              </protocol-udp><!-- operation="delete"-->
              <source-address>any</source-address> <!-- operation="delete"-->
              <source-port-operator>eq</source-port-operator> <!--
operation="delete"-->
              <udp-source-port>echo</udp-source-port> <!--
operation="delete"-->
              <destination-address>any</destination-address> <!--
operation="delete"-->
              <lower-destination-port-in-range>0</lower-destination-port-in-
range> <!-- operation="delete"-->
              <upper-destination-port-in-range>0</upper-destination-port-in-
range> <!-- operation="delete"-->
              <dscp>default</dscp> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
            </config>
          </ipv6>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) udp (any) (eq|neq|lt|gt)
(echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbio
s-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-
rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp) (any) range <0-65535> <0-65535>
(dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)
```

Configure dscp

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-udp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: udp-source-port

Attribute Type: enum (echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbios-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
<acl-sets>
  <acl-set>
    <name>NAME</name>
    <config>
      <name>WORD</name>
      <type>mac</type>
    </config>
    <type>mac</type>
```



```

    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <ipv6>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            </protocol-udp><!-- operation="delete"-->
            <source-address>any</source-address> <!-- operation="delete"-->
operation="delete"-->
            <source-port-operator>eq</source-port-operator> <!--
operation="delete"-->
            <udp-source-port>echo</udp-source-port> <!--
operation="delete"-->
            <destination-address>any</destination-address> <!--
operation="delete"-->
            <dscp>default</dscp> <!-- operation="delete"-->
            <vlan-id>1</vlan-id> <!-- operation="delete"-->
          </config>
        </ipv6>
      </acl-entry>
    </acl-entries>
  </acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) udp (any) (eq|neq|lt|gt)
(echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbio
s-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-
rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp) (any) (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)

```

Configure destination port operator

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-udp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: lower-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: udp-destination-port

Attribute Type: enum (echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbios-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
        <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <ipv6>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              </protocol-udp><!-- operation="delete"-->
              <source-address>any</source-address> <!-- operation="delete"-->
              <lower-source-port-in-range>0</lower-source-port-in-range> <!--
operation="delete"-->
              <upper-source-port-in-range>0</upper-source-port-in-range> <!--
operation="delete"-->
              <destination-address>any</destination-address> <!--
operation="delete"-->
```

```

operation="delete"--> <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"--> <udp-destination-port>echo</udp-destination-port> <!--
                        <dscp>default</dscp> <!-- operation="delete"-->
                        <vlan-id>1</vlan-id> <!-- operation="delete"-->
                    </config>
                </ipv6>
            </acl-entry>
        </acl-entries>
    </acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) udp (any) range <0-65535> <0-65535> (any)
(eq|neq|lt|gt)
(echo|discard|time|nameserver|tacacs|domain|bootps|bootpc|tftp|sunrpc|ntp|netbio
s-ns|netbios-dgm|netbios-ss|snmp|snmptrap|xdmcp|dnsix|mobile-ip|pim-auto-
rp|isakmp|biff|who|syslog|talk|rip|non500-isakmp) (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)

```

Configure upper destination port in range

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-udp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: lower-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-source-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: lower-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: upper-destination-port-in-range

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <ipv6>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              </protocol-udp><!-- operation="delete"-->
              <source-address>any</source-address> <!-- operation="delete"-->
              <lower-source-port-in-range>0</lower-source-port-in-range> <!--
operation="delete"-->
              <upper-source-port-in-range>0</upper-source-port-in-range> <!--
operation="delete"-->
              <destination-address>any</destination-address> <!--
operation="delete"-->
              <lower-destination-port-in-range>0</lower-destination-port-in-
range> <!-- operation="delete"-->
              <upper-destination-port-in-range>0</upper-destination-port-in-
range> <!-- operation="delete"-->
              <dscp>default</dscp> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
            </config>
          </ipv6>
        </acl-entry>
      </acl-entries>
    </acl-set>
```

```
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) udp (any) range <0-65535> <0-65535> (any) range <0-65535> <0-65535> (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7) |) (vlan <1-4094>|)
```

Configure protocol icmp

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-icmp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
<acl-sets>
  <acl-set>
    <name>NAME</name>
    <config>
      <name>WORD</name>
      <type>mac</type>
    </config>
    <type>mac</type>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
    </acl-entry>
  </acl-entries>
</acl-sets>
</acli>
```

```
        <config>
          <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
          </protocol-icmp><!-- operation="delete"-->
          <source-address>any</source-address> <!-- operation="delete"-->
          <destination-address>any</destination-address> <!--
operation="delete"-->
          <dscp>default</dscp> <!-- operation="delete"-->
          <vlan-id>1</vlan-id> <!-- operation="delete"-->
        </config>
      </ipv6>
    </acl-entry>
  </acl-entries>
</acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) icmpv6 (any) (any) (dscp
  (default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
  af43|cs5|ef|cs6|cs7) |) (vlan <1-4094>|)
```

Configure protocol sctp

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-sctp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
```

```

    <name>NAME</name>
    <config>
      <name>WORD</name>
      <type>mac</type>
    </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <ipv6>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            </protocol-sctp><!-- operation="delete"-->
            <source-address>any</source-address> <!-- operation="delete"-->
            <destination-address>any</destination-address> <!--
operation="delete"-->
            <dscp>default</dscp> <!-- operation="delete"-->
            <vlan-id>1</vlan-id> <!-- operation="delete"-->
          </config>
        </ipv6>
      </acl-entry>
    </acl-entries>
  </acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) sctp (any) (any) (dscp
  (default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
  af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)

```

Configure sctp destination port

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-sctp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: destination-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: sctp-destination-port

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <ipv6>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              </protocol-sctp><!-- operation="delete"-->
              <source-address>any</source-address> <!-- operation="delete"-->
              <destination-address>any</destination-address> <!--
operation="delete"-->
              <destination-port-operator>eq</destination-port-operator> <!--
operation="delete"-->
              <sctp-destination-port>0</sctp-destination-port> <!--
operation="delete"-->
              <dscp>default</dscp> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
            </config>
          </ipv6>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
```



```
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) sctp (any) (any) (eq|neq|lt|gt) <0-65535> (dscp
  (default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
  af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)
```

Configure sctp source port

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-sctp

Attribute Type: empty

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: source-port-operator

Attribute Type: enum (eq|neq|lt|gt)

Attribute Name: sctp-source-port

Attribute Type: uint16

Attribute Range: 0-65535

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
```

```

        <sequence-id>1</sequence-id>
    </config>
    <sequence-id>1</sequence-id>
</config>
<ipv6>
<config>
    <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
    </protocol-sctp><!-- operation="delete"-->
    <source-address>any</source-address> <!-- operation="delete"-->
operation="delete"-->
    <source-port-operator>eq</source-port-operator> <!--
->
    <sctp-source-port>0</sctp-source-port> <!-- operation="delete"-
operation="delete"-->
    <destination-address>any</destination-address> <!--
    <dscp>default</dscp> <!-- operation="delete"-->
    <vlan-id>1</vlan-id> <!-- operation="delete"-->
    </config>
    </ipv6>
    </acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) sctp (any) (eq|neq|lt|gt) <0-65535> (any) (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)

```

Configure protocol name

Use this attribute to set the vlan-id

This command is supported when following feature are enabled IPV6 feature

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: protocol-name

Attribute Type: union

Attribute Name: source-address

Attribute Type: enum (any)

Attribute Name: destination-address

Attribute Type: enum (any)

Attribute Name: dscp

Attribute Type: enum

(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|af43|cs5|ef|cs6|cs7)

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <ipv6>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              <protocol-name>ipipv6</protocol-name> <!-- operation="delete"--
>
              <source-address>any</source-address> <!-- operation="delete"-->
              <destination-address>any</destination-address> <!--
operation="delete"-->
              <dscp>default</dscp> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
            </config>
          </ipv6>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit)
(ipipv6|ipv6ipv6|rsvp|gre|esp|ahp|ospf|pim|ipcomp|vrrp|any|<0-255>) (any) (any)
(dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7)|) (vlan <1-4094>|)
```

IPI-ACL-ARP

Configure source mac any

Use this attribute to indicate any source address.

Attribute Name: source-mac-any

Attribute Type: empty

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: arp-packet-type

Attribute Type: enum (none|request|response)

Attribute Name: source-ip-address

Attribute Type: union

Attribute Name: destination-ip-address

Attribute Type: union

Attribute Name: destination-mac-any

Attribute Type: empty

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <arp>
```

```

        <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
            <source-ip-address>any</source-ip-address> <!--
operation="delete"-->
            <destination-ip-address>any</destination-ip-address> <!--
operation="delete"-->
            </destination-mac-any><!-- operation="delete"-->
            <vlan-id>1</vlan-id> <!-- operation="delete"-->
            <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
            </source-mac-any><!-- operation="delete"-->
        </config>
    </arp>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) response ip (any|host A.B.C.D|A.B.C.D/M|A.B.C.D
A.B.C.D) (any|host A.B.C.D|A.B.C.D/M|A.B.C.D A.B.C.D) mac any any (vlan <1-
4094>|) (inner-vlan <1-4094>|)

```

Configure name

Use this attribute to indicate any source address.

Attribute Name: source-mac-any

Attribute Type: empty

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: arp-packet-type

Attribute Type: enum (none|request|response)

Attribute Name: source-ip-address

Attribute Type: enum (any)

Attribute Name: destination-ip-address

Attribute Type: enum (any)

Attribute Name: destination-mac-host

Attribute Type: string

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <arp>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
            <source-ip-address>any</source-ip-address> <!--
operation="delete"-->
            <destination-ip-address>any</destination-ip-address> <!--
operation="delete"-->
            <destination-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-host> <!-- operation="delete"-->
            <vlan-id>1</vlan-id> <!-- operation="delete"-->
            <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
            </source-mac-any><!-- operation="delete"-->
          </config>
        </arp>
      </acl-entry>
    </acl-entries>
  </acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) response ip (any) (any) mac any host (XX-XX-XX-XX-
XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure type

Use this attribute to indicate any source address.

Attribute Name: source-mac-any

Attribute Type: empty
 Attribute Name: forwarding-action
 Attribute Type: enum (deny|permit)
 Attribute Name: arp-packet-type
 Attribute Type: enum (none|request|response)
 Attribute Name: source-ip-address
 Attribute Type: enum (any)
 Attribute Name: destination-ip-address
 Attribute Type: enum (any)
 Attribute Name: destination-mac-address
 Attribute Type: string
 Attribute Name: destination-mac-mask
 Attribute Type: string
 Attribute Name: vlan-id
 Attribute Type: uint16
 Attribute Range: 1-4094
 Attribute Name: inner-vlan-id
 Attribute Type: uint16
 Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <arp>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
            <source-ip-address>any</source-ip-address> <!--
operation="delete"-->
```

```

        <destination-ip-address>any</destination-ip-address> <!--
operation="delete"-->
        <destination-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-address> <!-- operation="delete"--
>
        <destination-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-mask> <!-- operation="delete"-->
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
        </source-mac-any><!-- operation="delete"-->
    </config>
</arp>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) response ip (any) (any) mac any (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure source mac host

Use this attribute to set Host source address.

Attribute Name: source-mac-host

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: arp-packet-type

Attribute Type: enum (none|request|response)

Attribute Name: source-ip-address

Attribute Type: enum (any)

Attribute Name: destination-ip-address

Attribute Type: enum (any)

Attribute Name: destination-mac-any

Attribute Type: empty

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <arp>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
              <source-ip-address>any</source-ip-address> <!--
operation="delete"-->
              <destination-ip-address>any</destination-ip-address> <!--
operation="delete"-->
              </destination-mac-any><!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
              <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
              <source-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-host> <!-- operation="delete"-->
                </config>
              </arp>
            </acl-entry>
          </acl-entries>
        </acl-set>
      </acl-sets>
    </acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) response ip (any) (any) mac host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) any (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure sequence id

Use this attribute to set Host source address.

Attribute Name: source-mac-host

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: arp-packet-type

Attribute Type: enum (none|request|response)

Attribute Name: source-ip-address

Attribute Type: enum (any)

Attribute Name: destination-ip-address

Attribute Type: enum (any)

Attribute Name: destination-mac-host

Attribute Type: string

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
        <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <arp>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
              <source-ip-address>any</source-ip-address> <!--
operation="delete"-->
              <destination-ip-address>any</destination-ip-address> <!--
operation="delete"-->
              <destination-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-host> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
              <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
            </config>
          </arp>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>
```

```

        <source-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-host> <!-- operation="delete"-->
    </config>
  </arp>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) response ip (any) (any) mac host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure forwarding action

Use this attribute to set Host source address.

Attribute Name: source-mac-host

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: arp-packet-type

Attribute Type: enum (none|request|response)

Attribute Name: source-ip-address

Attribute Type: enum (any)

Attribute Name: destination-ip-address

Attribute Type: enum (any)

Attribute Name: destination-mac-address

Attribute Type: string

Attribute Name: destination-mac-mask

Attribute Type: string

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>

```

```

<name>NAME</name>
<config>
  <name>WORD</name>
  <type>mac</type>
</config>
  <type>mac</type>
<acl-entries>
  <acl-entry>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
    </config>
    <arp>
      <config>
        <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
        <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
        <source-ip-address>any</source-ip-address> <!--
operation="delete"-->
        <destination-ip-address>any</destination-ip-address> <!--
operation="delete"-->
        <destination-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-address> <!-- operation="delete"--
>
        <destination-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-mask> <!-- operation="delete"-->
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
        <source-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-host> <!-- operation="delete"-->
      </config>
    </arp>
  </acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) response ip (any) (any) mac host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure source mac address

Use this attribute to set source mac-address.

Attribute Name: source-mac-address

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)
 Attribute Name: arp-packet-type
 Attribute Type: enum (none|request|response)
 Attribute Name: source-ip-address
 Attribute Type: enum (any)
 Attribute Name: destination-ip-address
 Attribute Type: enum (any)
 Attribute Name: source-mac-mask
 Attribute Type: string
 Attribute Name: destination-mac-any
 Attribute Type: empty
 Attribute Name: vlan-id
 Attribute Type: uint16
 Attribute Range: 1-4094
 Attribute Name: inner-vlan-id
 Attribute Type: uint16
 Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <arp>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
            <source-ip-address>any</source-ip-address> <!--
operation="delete"-->
            <destination-ip-address>any</destination-ip-address> <!--
operation="delete"-->
```

```

        <source-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-mask> <!-- operation="delete"-->
        </destination-mac-any><!-- operation="delete"-->
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
        <source-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-address> <!-- operation="delete"-->
    </config>
</arp>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) response ip (any) (any) mac (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) any (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure arp packet type

Use this attribute to set source mac-address.

Attribute Name: source-mac-address

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: arp-packet-type

Attribute Type: enum (none|request|response)

Attribute Name: source-ip-address

Attribute Type: enum (any)

Attribute Name: destination-ip-address

Attribute Type: enum (any)

Attribute Name: source-mac-mask

Attribute Type: string

Attribute Name: destination-mac-host

Attribute Type: string

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <arp>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
              <source-ip-address>any</source-ip-address> <!--
operation="delete"-->
              <destination-ip-address>any</destination-ip-address> <!--
operation="delete"-->
              <source-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-mask> <!-- operation="delete"-->
              <destination-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-host> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
              <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
              <source-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-address> <!-- operation="delete"-->
            </config>
          </arp>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) response ip (any) (any) mac (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure source ip address

Use this attribute to set source mac-address.

Attribute Name: source-mac-address

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: arp-packet-type

Attribute Type: enum (none|request|response)

Attribute Name: source-ip-address

Attribute Type: enum (any)

Attribute Name: destination-ip-address

Attribute Type: enum (any)

Attribute Name: source-mac-mask

Attribute Type: string

Attribute Name: destination-mac-address

Attribute Type: string

Attribute Name: destination-mac-mask

Attribute Type: string

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <arp>
      <config>
```



```

operation="delete"--> <forwarding-action>deny</forwarding-action> <!--
operation="delete"--> <arp-packet-type>none</arp-packet-type> <!--
operation="delete"--> <source-ip-address>any</source-ip-address> <!--
operation="delete"--> <destination-ip-address>any</destination-ip-address> <!--
operation="delete"--> <source-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-mask> <!-- operation="delete"-->
<destination-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-address> <!-- operation="delete"--
>
<destination-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-mask> <!-- operation="delete"-->
<vlan-id>1</vlan-id> <!-- operation="delete"-->
<inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
<source-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-address> <!-- operation="delete"-->
</config>
</arp>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) response ip (any) (any) mac (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure vlan id

Use this attribute to indicate any source address.

Attribute Name: source-mac-any

Attribute Type: empty

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: arp-packet-type

Attribute Type: enum (none|request|response)

Attribute Name: source-ip-address

Attribute Type: enum (any)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
            </config>
            <arp>
              <config>
                <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
                <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
                <source-ip-address>any</source-ip-address> <!--
operation="delete"-->
                <vlan-id>1</vlan-id> <!-- operation="delete"-->
                <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
                </source-mac-any><!-- operation="delete"-->
              </config>
            </arp>
          </acl-entry>
        </acl-entries>
      </acl-set>
    </acl-sets>
  </acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) ((request)|) ip (any) mac any (vlan <1-4094>|)
(inner-vlan <1-4094>|)
```

Configure inner vlan id

Use this attribute to set Host source address.

Attribute Name: source-mac-host

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: arp-packet-type

Attribute Type: enum (none|request|response)

Attribute Name: source-ip-address

Attribute Type: enum (any)

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <arp>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
              <source-ip-address>any</source-ip-address> <!--
operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
              <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
              <source-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-host> <!-- operation="delete"-->
            </config>
          </arp>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) ((request)|) ip (any) mac host (XX-XX-XX-XX-XX-XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (vlan <1-4094>|) (inner-vlan <1-4094>|)
```

Configure source mac mask

Use this attribute to set source mac-address.

Attribute Name: source-mac-address

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: arp-packet-type

Attribute Type: enum (none|request|response)

Attribute Name: source-ip-address

Attribute Type: enum (any)

Attribute Name: source-mac-mask

Attribute Type: string

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <arp>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
```

```

operation="delete"--> <arp-packet-type>none</arp-packet-type> <!--
operation="delete"--> <source-ip-address>any</source-ip-address> <!--
                        <source-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-mask> <!-- operation="delete"-->
                        <vlan-id>1</vlan-id> <!-- operation="delete"-->
                        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
                        <source-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-address> <!-- operation="delete"-->
                        </config>
                    </arp>
                </acl-entry>
            </acl-entries>
        </acl-set>
    </acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) ((request)|) ip (any) mac (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

IPI-ACL-MAC

Configure source mac any

Use this attribute to indicate any source address.

Attribute Name: source-mac-any

Attribute Type: empty

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: destination-mac-any

Attribute Type: empty

Attribute Name: arp-packet-type

Attribute Type: enum (none)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <mac>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            </destination-mac-any><!-- operation="delete"-->
            <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
            <cos-value>0</cos-value> <!-- operation="delete"-->
            <vlan-id>1</vlan-id> <!-- operation="delete"-->
            <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
            </source-mac-any><!-- operation="delete"-->
          </config>
        </mac>
      </acl-entry>
    </acl-entries>
  </acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) any any arp (cos <0-7>|) (vlan <1-4094>|) (inner-
vlan <1-4094>|)
```

Configure name

Use this attribute to indicate any source address.

Attribute Name: source-mac-any

Attribute Type: empty

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: destination-mac-host

Attribute Type: string

Attribute Name: arp-packet-type

Attribute Type: enum (none)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <mac>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              <destination-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-host> <!-- operation="delete"-->
              <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
              <cos-value>0</cos-value> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
              <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
              </source-mac-any><!-- operation="delete"-->
            </config>
          </mac>
        </acl-entry>
```

```
    </acl-entries>  
</acl-set>  
</acl-sets>  
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) any host (XX-XX-XX-XX-XX-  
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) arp (cos <0-7>|) (vlan <1-4094>|) (inner-  
vlan <1-4094>|)
```

Configure type

Use this attribute to indicate any source address.

Attribute Name: source-mac-any

Attribute Type: empty

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: destination-mac-address

Attribute Type: string

Attribute Name: destination-mac-mask

Attribute Type: string

Attribute Name: arp-packet-type

Attribute Type: enum (none)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">  
<acl-sets>  
  <acl-set>  
    <name>NAME</name>  
    <config>  
      <name>WORD</name>  
      <type>mac</type>  
    </config>  
    <type>mac</type>
```



```

    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <mac>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            <destination-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-address> <!-- operation="delete"--
>
            <destination-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-mask> <!-- operation="delete"-->
            <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
            <cos-value>0</cos-value> <!-- operation="delete"-->
            <vlan-id>1</vlan-id> <!-- operation="delete"-->
            <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
            </source-mac-any><!-- operation="delete"-->
          </config>
        </mac>
      </acl-entry>
    </acl-entries>
  </acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) any (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) arp (cos <0-7>|) (vlan <1-4094>|) (inner-
vlan <1-4094>|)

```

Configure source mac host

Use this attribute to set Host source address.

Attribute Name: source-mac-host

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: destination-mac-any

Attribute Type: empty

Attribute Name: arp-packet-type

Attribute Type: enum (none)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <mac>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              </destination-mac-any><!-- operation="delete"-->
              <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
              <cos-value>0</cos-value> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
              <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
              <source-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-host> <!-- operation="delete"-->
            </config>
          </mac>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>

```

Command Syntax

```
(<1-268435453>|) (deny|permit) host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) any arp (cos <0-7>|) (vlan <1-4094>|)
(inner-vlan <1-4094>|)
```

Configure sequence id

Use this attribute to set Host source address.

Attribute Name: source-mac-host

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: destination-mac-host

Attribute Type: string

Attribute Name: arp-packet-type

Attribute Type: enum (none)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <mac>
```

```

        <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            <destination-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-host> <!-- operation="delete"-->
            <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
            <cos-value>0</cos-value> <!-- operation="delete"-->
            <vlan-id>1</vlan-id> <!-- operation="delete"-->
            <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
            <source-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-host> <!-- operation="delete"-->
        </config>
    </mac>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) arp (cos <0-7>|) (vlan <1-4094>|) (inner-
vlan <1-4094>|)

```

Configure forwarding action

Use this attribute to set Host source address.

Attribute Name: source-mac-host

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: destination-mac-address

Attribute Type: string

Attribute Name: destination-mac-mask

Attribute Type: string

Attribute Name: arp-packet-type

Attribute Type: enum (none)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <mac>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              <destination-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-address> <!-- operation="delete"--
>
              <destination-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-mask> <!-- operation="delete"-->
              <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
              <cos-value>0</cos-value> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
              <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
              <source-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-host> <!-- operation="delete"-->
            </config>
          </mac>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) arp (cos <0-7>|) (vlan <1-4094>|) (inner-
vlan <1-4094>|)
```

Configure source mac address

Use this attribute to set source mac-address.

Attribute Name: source-mac-address

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: source-mac-mask

Attribute Type: string

Attribute Name: destination-mac-any

Attribute Type: empty

Attribute Name: arp-packet-type

Attribute Type: enum (none)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <mac>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
```

```

        <source-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-mask> <!-- operation="delete"-->
        </destination-mac-any><!-- operation="delete"-->
        <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
        <cos-value>0</cos-value> <!-- operation="delete"-->
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
        <source-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-address> <!-- operation="delete"-->
    </config>
    </mac>
    </acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) any arp (cos <0-7>|) (vlan <1-4094>|)
(inner-vlan <1-4094>|)

```

Configure source mac mask

Use this attribute to set source mac-address.

Attribute Name: source-mac-address

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: source-mac-mask

Attribute Type: string

Attribute Name: destination-mac-host

Attribute Type: string

Attribute Name: arp-packet-type

Attribute Type: enum (none)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <mac>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            <source-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-mask> <!-- operation="delete"-->
            <destination-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-host> <!-- operation="delete"-->
            <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
            <cos-value>0</cos-value> <!-- operation="delete"-->
            <vlan-id>1</vlan-id> <!-- operation="delete"-->
            <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
            <source-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-address> <!-- operation="delete"-->
          </config>
        </mac>
      </acl-entry>
    </acl-entries>
  </acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) arp (cos <0-7>|) (vlan <1-4094>|) (inner-
vlan <1-4094>|)

```

Configure destination mac address

Use this attribute to set source mac-address.

Attribute Name: source-mac-address

Attribute Type: string

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: source-mac-mask

Attribute Type: string

Attribute Name: destination-mac-address

Attribute Type: string

Attribute Name: destination-mac-mask

Attribute Type: string

Attribute Name: arp-packet-type

Attribute Type: enum (none)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    </acl-set>
  </acl-sets>
  <acl-entries>
    <acl-entry>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <mac>
```

```

    <config>
        <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
        <source-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-mask> <!-- operation="delete"-->
        <destination-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-address> <!-- operation="delete"--
>
        <destination-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-mask> <!-- operation="delete"-->
        <arp-packet-type>none</arp-packet-type> <!--
operation="delete"-->
        <cos-value>0</cos-value> <!-- operation="delete"-->
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
        <source-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-address> <!-- operation="delete"-->
    </config>
</mac>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) arp (cos <0-7>|) (vlan <1-4094>|) (inner-
vlan <1-4094>|)

```

Configure inner vlan id

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: source-mac-any

Attribute Type: empty

Attribute Name: destination-mac-any

Attribute Type: empty

Attribute Name: ethertype

Attribute Type: union

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <mac>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              </source-mac-any><!-- operation="delete"-->
              </destination-mac-any><!-- operation="delete"-->
              <ethertype>ipv4</ethertype> <!-- operation="delete"-->
              <cos-value>0</cos-value> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
              <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
            </config>
          </mac>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) any any ((ipv4|vines-echo|etype-6000|mop-dump|mop-
console|decnet-iv|lat|diagnostic|lavc-sca|etype-
8042|appletalk|arp|ipv6|mpls|ETHTYPE)|) (cos <0-7>|) (vlan <1-4094>|) (inner-
vlan <1-4094>|)
```

Configure destination mac host

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: source-mac-any

Attribute Type: empty

Attribute Name: destination-mac-host

Attribute Type: string

Attribute Name: ethertype

Attribute Type: enum (ipv4|vines-echo|etype-6000|mop-dump|mop-console|decnet-iv|lat|diagnostic|lavc-sca|etype-8042|appletalk|arp|ipv6|mpls)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <mac>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            </source-mac-any><!-- operation="delete"-->
```

```

        <destination-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-host> <!-- operation="delete"-->
        <ethertype>ipv4</ethertype> <!-- operation="delete"-->
        <cos-value>0</cos-value> <!-- operation="delete"-->
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
    </config>
</mac>
</acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) any host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) ((ipv4|vines-echo|etype-6000|mop-dump|mop-
console|decnet-iv|lat|diagnostic|lavc-sca|etype-8042|appletalk|arp|ipv6|mpls)|)
(cos <0-7>|) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure destination mac mask

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: source-mac-any

Attribute Type: empty

Attribute Name: destination-mac-address

Attribute Type: string

Attribute Name: destination-mac-mask

Attribute Type: string

Attribute Name: ethertype

Attribute Type: enum (ipv4|vines-echo|etype-6000|mop-dump|mop-console|decnet-iv|lat|diagnostic|lavc-sca|etype-8042|appletalk|arp|ipv6|mpls)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
          </config>
          <mac>
            <config>
              <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
              </source-mac-any><!-- operation="delete"-->
              <destination-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-address> <!-- operation="delete"--
>
              <destination-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-mask> <!-- operation="delete"-->
              <ethertype>ipv4</ethertype> <!-- operation="delete"-->
              <cos-value>0</cos-value> <!-- operation="delete"-->
              <vlan-id>1</vlan-id> <!-- operation="delete"-->
              <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
            </config>
          </mac>
        </acl-entry>
      </acl-entries>
    </acl-set>
  </acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) any (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) ((ipv4|vines-echo|etype-6000|mop-dump|mop-
console|decnet-iv|lat|diagnostic|lavc-sca|etype-8042|appletalk|aarp|ipv6|mpls)|)
(cos <0-7>|) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure destination mac any

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: source-mac-host

Attribute Type: string

Attribute Name: destination-mac-any

Attribute Type: empty

Attribute Name: ethertype

Attribute Type: enum (ipv4|vines-echo|etype-6000|mop-dump|mop-console|decnet-iv|lat|diagnostic|lavo-sca|etype-8042|appletalk|arp|ipv6|mpls)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
    <acl-entries>
      <acl-entry>
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
        <mac>
          <config>
            <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
            <source-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-host> <!-- operation="delete"-->
            </destination-mac-any><!-- operation="delete"-->
            <ethertype>ipv4</ethertype> <!-- operation="delete"-->
            <cos-value>0</cos-value> <!-- operation="delete"-->
            <vlan-id>1</vlan-id> <!-- operation="delete"-->
            <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
          </config>
        </mac>
      </acl-entry>
    </acl-entries>
  </acl-set>
</acl-sets>
</acl>
```

```
        </mac>
    </acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) any ((ipv4|vines-echo|etype-6000|mop-
dump|mop-console|decnet-iv|lat|diagnostic|lavc-sca|etype-
8042|appletalk|arp|ipv6|mpls)|) (cos <0-7>|) (vlan <1-4094>|) (inner-vlan <1-
4094>|)
```

Configure ethertype

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: source-mac-host

Attribute Type: string

Attribute Name: destination-mac-host

Attribute Type: string

Attribute Name: ethertype

Attribute Type: enum (ipv4|vines-echo|etype-6000|mop-dump|mop-console|decnet-iv|lat|diagnostic|lavc-sca|etype-8042|appletalk|arp|ipv6|mpls)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
```



```

</config>
  <type>mac</type>
<acl-entries>
  <acl-entry>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
    </config>
    <mac>
      <config>
        <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
        <source-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-host> <!-- operation="delete"-->
        <destination-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-host> <!-- operation="delete"-->
        <ethertype>ipv4</ethertype> <!-- operation="delete"-->
        <cos-value>0</cos-value> <!-- operation="delete"-->
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
      </config>
    </mac>
  </acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) ((ipv4|vines-echo|etype-6000|mop-dump|mop-
console|decnet-iv|lat|diagnostic|lavc-sca|etype-8042|appletalk|arp|ipv6|mpls)|)
(cos <0-7>|) (vlan <1-4094>|) (inner-vlan <1-4094>|)

```

Configure cos value

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: source-mac-host

Attribute Type: string

Attribute Name: destination-mac-address

Attribute Type: string

Attribute Name: destination-mac-mask

Attribute Type: string

Attribute Name: ethertype

Attribute Type: enum (ipv4|vines-echo|etype-6000|mop-dump|mop-console|decnet-iv|lat|diagnostic|lavc-sca|etype-8042|appletalk|aarp|ipv6|mpls)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <acl-sets>
    <acl-set>
      <name>NAME</name>
      <config>
        <name>WORD</name>
        <type>mac</type>
      </config>
      <type>mac</type>
      <acl-entries>
        <acl-entry>
          <sequence-id>1</sequence-id>
          <config>
            <sequence-id>1</sequence-id>
            </config>
            <mac>
              <config>
                <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
                <source-mac-host>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-host> <!-- operation="delete"-->
                <destination-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-address> <!-- operation="delete"--
>
                <destination-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</destination-mac-mask> <!-- operation="delete"-->
                <ethertype>ipv4</ethertype> <!-- operation="delete"-->
                <cos-value>0</cos-value> <!-- operation="delete"-->
                <vlan-id>1</vlan-id> <!-- operation="delete"-->
                <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
              </config>
            </mac>
          </acl-entry>
        </acl-entries>
      </acl-set>
```

```
</acl-sets>
</acl>
```

Command Syntax

```
(<1-268435453>|) (deny|permit) host (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) ((ipv4|vines-echo|etype-6000|mop-dump|mop-
console|decnet-iv|lat|diagnostic|lavc-sca|etype-8042|appletalk|arp|ipv6|mpls)|)
(cos <0-7>|) (vlan <1-4094>|) (inner-vlan <1-4094>|)
```

Configure vlan id

Use this attribute to set the inner-vlan-id

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Attribute Name: forwarding-action

Attribute Type: enum (deny|permit)

Attribute Name: source-mac-address

Attribute Type: string

Attribute Name: source-mac-mask

Attribute Type: string

Attribute Name: destination-mac-any

Attribute Type: empty

Attribute Name: ethertype

Attribute Type: enum (ipv4|vines-echo|etype-6000|mop-dump|mop-console|decnet-iv|lat|diagnostic|lavc-sca|etype-8042|appletalk|arp|ipv6|mpls)

Attribute Name: cos-value

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4094

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
<acl-sets>
  <acl-set>
    <name>NAME</name>
    <config>
      <name>WORD</name>
      <type>mac</type>
```

```

</config>
  <type>mac</type>
<acl-entries>
  <acl-entry>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
    </config>
    <mac>
      <config>
        <forwarding-action>deny</forwarding-action> <!--
operation="delete"-->
        <source-mac-address>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-address> <!-- operation="delete"-->
        <source-mac-mask>XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX</source-mac-mask> <!-- operation="delete"-->
        </destination-mac-any><!-- operation="delete"-->
        <ethertype>ipv4</ethertype> <!-- operation="delete"-->
        <cos-value>0</cos-value> <!-- operation="delete"-->
        <vlan-id>1</vlan-id> <!-- operation="delete"-->
        <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
      </config>
    </mac>
  </acl-entry>
</acl-entries>
</acl-set>
</acl-sets>
</acl>

```

Command Syntax

```

(<1-268435453>|) (deny|permit) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) (XX-XX-XX-XX-XX-
XX|XX:XX:XX:XX:XX:XX|XXXX.XXXX.XXXX) any ((ipv4|vines-echo|etype-6000|mop-
dump|mop-console|decnet-iv|lat|diagnostic|lavc-sca|etype-
8042|appletalk|arp|ipv6|mpls)|) (cos <0-7>|) (vlan <1-4094>|) (inner-vlan <1-
4094>|)

```

IPI-ACL-PORTS

Configure acl name

The name of the access-list set applied on the interface

Attribute Name: acl-name

Attribute Type: string

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <interfaces>

```

```

<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <ingress-acl-sets>
  <ingress-acl-set>
    <acl-type>ip</acl-type>
    <config>
      <acl-type>ip</acl-type>
    </config>
    <access-groups>
    <access-group> <!-- operation="delete"-->
      <acl-name>WORD</acl-name>
      <config>
        <acl-name>WORD</acl-name>
      </config>
    </access-group>
  </access-groups>
</ingress-acl-set>
</ingress-acl-sets>
</interface>
</interfaces>
</acl>

```

Command Syntax

```
ip access-group NAME in
```

Configure name

The name of the access-list set applied on the interface

Attribute Name: acl-name

Attribute Type: string

Attribute Name: time-range

Attribute Type: string

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <interfaces>
  <interface>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
    <ingress-acl-sets>
    <ingress-acl-set>
      <acl-type>mac</acl-type>
    <config>

```

```
        <acl-type>mac</acl-type>
    </config>
<access-groups>
<access-group>
    <acl-name>WORD</acl-name>
    <config>
        <acl-name>WORD</acl-name>
        <time-range>WORD</time-range>
    </config>
</access-group>
</access-groups>
</ingress-acl-set>
</ingress-acl-sets>
</interface>
</interfaces>
</acl>
```

Command Syntax

```
ip access-group NAME in time-range WORD
```

Configure acl type

Reference to the base interface name

Attribute Name: name

Attribute Type: string

Attribute Name: acl-type

Attribute Type: enum (mac|ip|ipv6|arp)

Attribute Name: acl-name

Attribute Type: string

Netconf edit-config payload

```
<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
<interfaces>
<interface> <!-- operation="delete"-->
    <name>WORD</name>
    <config>
        <name>WORD</name>
    </config>
<ingress-acl-sets>
<ingress-acl-set>
    <acl-type>ipv6</acl-type>
    <access-groups>
    <access-group>
        <acl-name>WORD</acl-name>
    </access-group>
</access-groups>
</ingress-acl-set>
</ingress-acl-sets>
```

```

</interface>
</interfaces>
</acl>

```

Command Syntax

```
ipv6 access-group NAME in
```

Configure time range

The time-range associated with this access-group

Attribute Name: time-range

Attribute Type: string

Netconf edit-config payload

```

<acl xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <ingress-acl-sets>
  <ingress-acl-set>
    <acl-type>mac</acl-type>
    <config>
      <acl-type>mac</acl-type>
    </config>
    <access-groups>
    <access-group>
      <acl-name>WORD</acl-name>
      <config>
        <acl-name>WORD</acl-name>
        </config>
        <time-range>WORD</time-range> <!-- operation="delete"-->
      </access-group>
    </access-groups>
  </ingress-acl-set>
</ingress-acl-sets>
</interface>
</interfaces>
</acl>

```

Command Syntax

```
ipv6 access-group NAME in time-range WORD
```

clear access-list counters

Netconf RPC payload

```
<ipi-acl-ports_clear-access-list-counters-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl"/>
```

Command Syntax

```
clear access-list counters
```

clear access-list NAME counters

Attribute Name: name

Attribute Type: string

Netconf RPC payload

```
<ipi-acl-ports_clear-access-list-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <name>NAME</name>
</ipi-acl-ports_clear-access-list-counters>
```

Command Syntax

```
clear access-list NAME counters
```

clear ip access-list counters

Netconf RPC payload

```
<ipi-acl-ports_clear-ip-access-list-counters-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl"/>
```

Command Syntax

```
clear ip access-list counters
```

clear ip access-list NAME counters

Attribute Name: name

Attribute Type: string

Netconf RPC payload

```
<ipi-acl-ports_clear-ip-access-list-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">
  <name>NAME</name>
</ipi-acl-ports_clear-ip-access-list-counters>
```

Command Syntax

```
clear ip access-list NAME counters
```

clear ipv6 access-list counters

Netconf RPC payload

```
<ipi-acl-ports_clear-ipv6-access-list-counters-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl"/>
```

Command Syntax

```
clear ipv6 access-list counters
```

clear ipv6 access-list NAME counters

Attribute Name: name

Attribute Type: string

Netconf RPC payload

```
<ipi-acl-ports_clear-ipv6-access-list-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">  
  <name>NAME</name>  
</ipi-acl-ports_clear-ipv6-access-list-counters>
```

Command Syntax

```
clear ipv6 access-list NAME counters
```

clear mac access-list counters

Netconf RPC payload

```
<ipi-acl-ports_clear-mac-access-list-counters-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl"/>
```

Command Syntax

```
clear mac access-list counters
```

clear mac access-list NAME counters

Attribute Name: name

Attribute Type: string

Netconf RPC payload

```
<ipi-acl-ports_clear-mac-access-list-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">  
  <name>NAME</name>  
</ipi-acl-ports_clear-mac-access-list-counters>
```

Command Syntax

```
clear mac access-list NAME counters
```

clear arp access-list counters

Netconf RPC payload

```
<ipi-acl-ports_clear-arp-access-list-counters-all xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl"/>
```

Command Syntax

```
clear arp access-list counters
```

clear arp access-list NAME counters

Attribute Name: name

Attribute Type: string

Netconf RPC payload

```
<ipi-acl-ports_clear-arp-access-list-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-acl">  
  <name>NAME</name>  
</ipi-acl-ports_clear-arp-access-list-counters>
```

Command Syntax

```
clear arp access-list NAME counters
```

IPI-DHCP-SNOOPING

Configure options

Use this attribute to debug the DHCP snooping feature.

Attribute Name: options

Attribute Type: bits (event|rx|tx|packet|all)

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">  
  <snooping>  
    <debug>  
      <config>  
        <options>event</options> <!-- operation="delete"-->  
      </config>  
    </debug>  
  </snooping>  
</dhcp>
```

Command Syntax

```
debug ip dhcp snooping (event|rx|tx|packet|all)
```

Configure snooping enable

Enable DHCP snooping feature

Attribute Name: snooping-enable

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <snooping-bridges>
      <snooping-bridge>
        <bridge-id>1</bridge-id>
        <config>
          <bridge-id>1</bridge-id>
        </config>
      </snooping-bridge>
    </snooping-bridges>
  </snooping>
</dhcp>
```

Command Syntax

```
ip dhcp snooping bridge <1-32>
```

Configure verify mac address

Use this command to enable MAC address verification.

Attribute Name: verify-mac-address

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <snooping-bridges>
      <snooping-bridge>
        <bridge-id>1</bridge-id>
        <config>
          <bridge-id>1</bridge-id>
          </verify-mac-address><!-- operation="delete"-->
        </config>
      </snooping-bridge>
    </snooping-bridges>
  </snooping>
</dhcp>
```

Command Syntax

```
ip dhcp snooping verify mac-address bridge <1-32>
```

Configure option 82 enable

Use this command to insert interface and VLAN name in the option 82 field in DHCP packets.

Attribute Name: option-82-enable

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <snooping-bridges>
      <snooping-bridge>
        <bridge-id>1</bridge-id>
        <config>
          <bridge-id>1</bridge-id>
        </config>
      </option-82-enable><!-- operation="delete"-->
    </snooping-bridge>
  </snooping-bridges>
</snooping>
</dhcp>
```

Command Syntax

```
ip dhcp snooping information option bridge <1-32>
```

Configure write delay

Configure DHCP snooping database write delay in multiples of 10 seconds

Attribute Name: write-delay

Attribute Type: uint32

Default Value: 300

Attribute Range: 20-86400

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <snooping-bridges>
      <snooping-bridge>
        <bridge-id>1</bridge-id>
        <config>
          <bridge-id>1</bridge-id>
          <write-delay>20</write-delay> <!-- operation="delete"-->
        </config>
      </snooping-bridge>
    </snooping-bridges>
  </snooping>
</dhcp>
```

Command Syntax

```
ip dhcp snooping database write-delay <20-86400> bridge <1-32>
```

Configure strict validation

Use this command to enable strict validation of DHCP packets.

Attribute Name: strict-validation

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <snooping-bridges>
      <snooping-bridge>
        <bridge-id>1</bridge-id>
        <config>
          <bridge-id>1</bridge-id>
        </config>
        </strict-validation><!-- operation="delete"-->
      </snooping-bridge>
    </snooping-bridges>
  </snooping>
</dhcp>
```

Command Syntax

```
ip dhcp packet strict-validation bridge <1-32>
```

Configure vlan range

Use this command to enable DHCP snooping for the given VLAN.

Attribute Name: vlan-range

Attribute Type: string

Attribute Range: 2-4094

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <snooping-bridges>
      <snooping-bridge>
        <bridge-id>1</bridge-id>
        <config>
          <bridge-id>1</bridge-id>
          <vlan-range>VLAN_RANGE</vlan-range> <!-- operation="delete"-->
        </config>
      </snooping-bridge>
    </snooping-bridges>
  </snooping>
```

```
</dhcp>
```

Command Syntax

```
ip dhcp snooping vlan VLAN_RANGE bridge <1-32>
```

Configure enable

Use this command to enable/disable arp-inspection on the bridge.

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <snooping-bridges>
      <snooping-bridge>
        <bridge-id>1</bridge-id>
        <config>
          <bridge-id>1</bridge-id>
        </config>
        <arp-inspection>
          <config>
            </enable>
          </config>
        </arp-inspection>
      </snooping-bridge>
    </snooping-bridges>
  </snooping>
</dhcp>
```

Command Syntax

```
ip dhcp snooping arp-inspection bridge <1-32>
```

Configure validate

Use this command to enable validation of the source-mac, destination-mac, or IP address field in the ARP packet payload.

Attribute Name: validate

Attribute Type: enum (src-mac|dst-mac|ip)

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <snooping-bridges>
      <snooping-bridge>
        <bridge-id>1</bridge-id>
        <config>
          <bridge-id>1</bridge-id>
        </config>
      </snooping-bridge>
    </snooping-bridges>
  </snooping>
</dhcp>
```

```

    </config>
    <arp-inspection>
    <config>
        <validate>src-mac</validate> <!-- operation="delete"-->
    </config>
</arp-inspection>
</snooping-bridge>
</snooping-bridges>
</snooping>
</dhcp>

```

Command Syntax

```
ip dhcp snooping arp-inspection validate (src-mac|dst-mac|ip) bridge <1-32>
```

Configure bridge id

Use this command to enable ARP inspection on the VLAN in a bridge.

Attribute Name: vlan-range

Attribute Type: string

Attribute Range: 2-4094

Netconf edit-config payload

```

<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <snooping-bridges>
      <snooping-bridge>
        <bridge-id>1</bridge-id>
        <config>
          <bridge-id>1</bridge-id>
        </config>
        <arp-inspection>
          <config>
            <vlan-range>VLAN_RANGE</vlan-range> <!-- operation="delete"-->
          </config>
        </arp-inspection>
      </snooping-bridge>
    </snooping-bridges>
  </snooping>
</dhcp>

```

Command Syntax

```
ip dhcp snooping arp-inspection vlan VLAN_RANGE bridge <1-32>
```

Configure if name

Use this attribute to set the interface name

Attribute Name: if-name

Attribute Type: string

Attribute Name: ipv4-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <snooping-bridges>
      <snooping-bridge>
        <bridge-id>1</bridge-id>
        <config>
          <bridge-id>1</bridge-id>
        </config>
      </snooping-bridge>
    </snooping-bridges>
  </snooping>
  <vlans>
    <vlan>
      <vlan-id>1</vlan-id>
      <config>
        <vlan-id>1</vlan-id>
      </config>
      <mac-addresses-ipv4>
        <mac-address-ipv4>
          <mac-address>XXXX.XXXX.XXXX</mac-address>
          <config>
            <mac-address>XXXX.XXXX.XXXX</mac-address>
            <ipv4-address>A.B.C.D</ipv4-address>
          </config>
          <if-name>IFNAME</if-name>
        </mac-address-ipv4>
      </mac-addresses-ipv4>
    </vlan>
  </vlans>
</dhcp>
```

Command Syntax

```
ip dhcp snooping binding bridge <1-32> XXXX.XXXX.XXXX <1-4094> ipv4 A.B.C.D IFNAME
```

Configure mac address

Use this attribute to set the interface name

This command is supported when following feature are enabled HAVE_IPV6 feature enabled

Attribute Name: if-name

Attribute Type: string

Attribute Name: ipv6-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```

<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <snooping-bridges>
      <snooping-bridge>
        <bridge-id>1</bridge-id>
        <config>
          <bridge-id>1</bridge-id>
        </config>
      </snooping-bridge>
    </snooping-bridges>
  </snooping>
  <vlans>
    <vlan>
      <vlan-id>1</vlan-id>
      <config>
        <vlan-id>1</vlan-id>
      </config>
      <mac-addresses-ipv6>
        <mac-address-ipv6>
          <mac-address>XXXX.XXXX.XXXX</mac-address>
          <config>
            <mac-address>XXXX.XXXX.XXXX</mac-address>
            <ipv6-address>X:X::X:X</ipv6-address>
          </config>
          <if-name>IFNAME</if-name>
        </mac-address-ipv6>
      </mac-addresses-ipv6>
    </vlan>
  </vlans>
</dhcp>

```

Command Syntax

```
ip dhcp snooping binding bridge <1-32> XXXX.XXXX.XXXX <1-4094> ipv6 X:X::X:X IFNAME
```

ip dhcp snooping database bridge WORD

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```

<ipi-dhcp-snooping_dhcp-snooping-write-database xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <bridge-id>WORD</bridge-id>
</ipi-dhcp-snooping_dhcp-snooping-write-database>

```

Command Syntax

```
ip dhcp snooping database bridge WORD
```

renew ip dhcp snooping binding database bridge WORD

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<ipi-dhcp-snooping_dhcp-snooping-renew-database xmlns="http://  
www.ipinfusion.com/yang/ocnos/ipi-dhcp">  
  <bridge-id>WORD</bridge-id>  
</ipi-dhcp-snooping_dhcp-snooping-renew-database>
```

Command Syntax

```
renew ip dhcp snooping binding database bridge WORD
```

ip dhcp snooping source database bridge WORD

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<ipi-dhcp-snooping_dhcp-snooping-write-source-binding-database xmlns="http://  
www.ipinfusion.com/yang/ocnos/ipi-dhcp">  
  <bridge-id>WORD</bridge-id>  
</ipi-dhcp-snooping_dhcp-snooping-write-source-binding-database>
```

Command Syntax

```
ip dhcp snooping source database bridge WORD
```

renew ip dhcp snooping source binding database bridge WORD

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<ipi-dhcp-snooping_dhcp-snooping-renew-source-database xmlns="http://  
www.ipinfusion.com/yang/ocnos/ipi-dhcp">  
  <bridge-id>WORD</bridge-id>  
</ipi-dhcp-snooping_dhcp-snooping-renew-source-database>
```

Command Syntax

```
renew ip dhcp snooping source binding database bridge WORD
```

clear ip dhcp snooping source binding bridge WORD

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<ipi-dhcp-snooping_dhcp-snooping-clear-source-binding-database xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <bridge-id>WORD</bridge-id>
</ipi-dhcp-snooping_dhcp-snooping-clear-source-binding-database>
```

Command Syntax

```
clear ip dhcp snooping source binding bridge WORD
```

clear ip dhcp snooping binding bridge WORD

Attribute Name: bridge-id

Attribute Type: string

Netconf RPC payload

```
<ipi-dhcp-snooping_dhcp-snooping-clear-database xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <bridge-id>WORD</bridge-id>
</ipi-dhcp-snooping_dhcp-snooping-clear-database>
```

Command Syntax

```
clear ip dhcp snooping binding bridge WORD
```

debug ip dhcp snooping (event|rx|tx|packet|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (event|rx|tx|packet|all)

Netconf RPC payload

```
<ipi-dhcp-snooping_dhcp-snooping-terminal-debug-on xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <terminal-debug-options>event</terminal-debug-options>
</ipi-dhcp-snooping_dhcp-snooping-terminal-debug-on>
```

Command Syntax

```
debug ip dhcp snooping (event|rx|tx|packet|all)
```

no debug ip dhcp snooping (event|rx|tx|packet|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (event|rx|tx|packet|all)

Netconf RPC payload

```
<ipi-dhcp-snooping_dhcp-snooping-terminal-debug-off xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <terminal-debug-options>event</terminal-debug-options>
</ipi-dhcp-snooping_dhcp-snooping-terminal-debug-off>
```

Command Syntax

```
no debug ip dhcp snooping (event|rx|tx|packet|all)
```

IPI-DHCP-SNOOPING-INTERFACE

Configure snooping trust

Use this command to enable the snooping trust on the interface level.

Attribute Name: snooping-trust

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <trust>
          <config>
            </snooping-trust><!-- operation="delete"-->
          </config>
        </trust>
      </interface>
    </interfaces>
  </snooping>
</dhcp>
```

Command Syntax

```
ip dhcp snooping trust
```

Configure verify snooping vlan

Use this command to enable the IPSG feature at the interface level.

Attribute Name: verify-snooping-vlan

Attribute Type: empty

Netconf edit-config payload

```
<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
```

```

        <name>WORD</name>
    </config>
    <verify>
    <config>
        </verify-snooping-vlan>
    </config>
</verify>
</interface>
</interfaces>
</snooping>
</dhcp>

```

Command Syntax

```
ip verify source dhcp-snooping-vlan
```

Configure verify access group mode

Use this command to enable the snooping access-group on the interface level.

Attribute Name: verify-access-group-mode

Attribute Type: empty

Netconf edit-config payload

```

<dhcp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-dhcp">
  <snooping>
    <interfaces>
      <interface>
        <name>WORD</name>
        <config>
          <name>WORD</name>
        </config>
        <verify>
        <config>
          </verify-access-group-mode><!-- operation="delete"-->
        </config>
        </verify>
      </interface>
    </interfaces>
  </snooping>
</dhcp>

```

Command Syntax

```
ip verify source access-group mode merge
```

clear hsl ipc-stat VALUE VALUE

Attribute Name: start-value

Attribute Type: uint16

Attribute Name: end-value

Attribute Type: uint16

Netconf RPC payload

```
<platform-clear-hsl-ipc-stat-values xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-ras">
  <start-value>VALUE</start-value>
  <end-value>VALUE</end-value>
</platform-clear-hsl-ipc-stat-values>
```

Command Syntax

```
clear hsl ipc-stat VALUE VALUE
```

clear hsl ipc-stat

Netconf RPC payload

```
<platform-clear-hsl-ipc-stat xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
ras"/>
```

Command Syntax

```
clear hsl ipc-stat
```

clear hsl mlag mac-sync-count

Netconf RPC payload

```
<platform-clear-hsl-mlag-mac-sync xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-ras"/>
```

Command Syntax

```
clear hsl mlag mac-sync-count
```

clear hardware-discard-counters

Netconf RPC payload

```
<platform-clear-hardware-discard-counters xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-ras"/>
```

Command Syntax

```
clear hardware-discard-counters
```

clear hsl fdb debug-counters

Netconf RPC payload

```
<platform-clear-hsl-fdb-debug-counters xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-ras"/>
```

Command Syntax

```
clear hsl fdb debug-counters
```

IPI-UNICAST-RPF

Configure enable route lookup

Use this attribute to enable uRPF globally on the system

This command is supported when following feature are enabled Unicast Reverse Path Forwarding feature

Attribute Name: enable-route-lookup

Attribute Type: empty

Netconf edit-config payload

```
<unicast-rpf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-unicast-rpf">
  <global>
    <config>
      </enable-route-lookup><!-- operation="delete"-->
    </config>
  </global>
</unicast-rpf>
```

Command Syntax

```
ip urpf enable
```

Configure enable default route check

Use this attribute to enable default route to match when checking source IP address

This command is supported when following feature are enabled Unicast Reverse Path Forwarding feature

Attribute Name: enable-default-route-check

Attribute Type: empty

Netconf edit-config payload

```
<unicast-rpf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-unicast-rpf">
  <global>
    <config>
      </enable-default-route-check><!-- operation="delete"-->
    </config>
  </global>
</unicast-rpf>
```

Command Syntax

```
ip urpf allow-default
```

Configure source reachability mode

Use this attribute to enable uRPF for an interface with specified reachability mode

Attribute Name: source-reachability-mode

Attribute Type: enum (any|rx)

Netconf edit-config payload

```
<unicast-rpf xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-unicast-rpf">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <source-reachability-mode>any</source-reachability-mode> <!--
operation="delete"-->
    </interface>
  </interfaces>
</unicast-rpf>
```

Command Syntax

```
ip verify unicast source reachable-via (any|rx)
```

IPI-OSPF-INTERFACE-TRACKING

Configure event name

Attribute used to specify the event-name for OSPF interface tracking.

Attribute Name: event-name

Attribute Type: string

Attribute Name: event-match-criteria

Attribute Type: enum (all|any)

Netconf edit-config payload

```
<ospf-interfaces-events-tracking xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
ospf-interface-tracking">
  <ospf-interface-events-tracking> <!-- operation="delete"-->
    <event-name>NAME</event-name>
    <config>
      <event-name>NAME</event-name>
      <event-match-criteria>all</event-match-criteria>
    </config>
  </ospf-interface-events-tracking>
</ospf-interfaces-events-tracking>
```

Command Syntax

```
if-event-track ospf event NAME match (all|any)
```

Configure event neighbor ip address

Attribute used to specify the event neighbor IP address for OSPF interface tracking event.

Attribute Name: event-neighbor-ip-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ospf-interfaces-events-tracking xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
ospf-interface-tracking">
  <ospf-interface-events-tracking>
    <event-name>NAME</event-name>
    <config>
      <event-name>NAME</event-name>
    </config>
    <event-neighbor-ip-address>A.B.C.D</event-neighbor-ip-address> <!--
operation="delete"-->
  </ospf-interface-events-tracking>
</ospf-interfaces-events-tracking>
```

Command Syntax

```
event nbr A.B.C.D down
```

Configure name

Attribute used to specify the interface name for OSPF interface tracking event action.

Attribute Name: name

Attribute Type: string

Attribute Name: cost

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```
<ospf-interfaces-events-tracking xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
ospf-interface-tracking">
  <ospf-interface-events-tracking>
    <event-name>NAME</event-name>
    <config>
      <event-name>NAME</event-name>
    </config>
  <actions>
  <interfaces>
  <interface> <!-- operation="delete"-->
    <name>IFNAME</name>
    <config>
      <name>IFNAME</name>
      <cost>1</cost>
    </config>
  </interface>
```

```
</interfaces>
</actions>
</ospf-interface-events-tracking>
</ospf-interfaces-events-tracking>
```

Command Syntax

```
action interface IFNAME cost <1-65535>
```

IPI-PORT-MIRROR

Configure id

Port mirror session index

Attribute Name: id

Attribute Type: uint32

Attribute Range: 1-18

Attribute Name: type

Attribute Type: enum (local|remote)

Netconf edit-config payload

```
<port-mirror xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-mirror">
  <sessions>
    <session> <!-- operation="delete"-->
      <id>1</id>
      <config>
        <id>1</id>
        <type>local</type>
      </config>
    </session>
  </sessions>
</port-mirror>
```

Command Syntax

```
monitor session <1-18> (type (local|remote)|)
```

Configure enabled

Use this attribute to shut/unshut a port-mirror session

Attribute Name: enabled

Attribute Type: uint8

Netconf edit-config payload

```
<port-mirror xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-mirror">
  <sessions>
    <session>
```

```

    <id>1</id>
  <config>
    <id>1</id>
  </config>
</enabled><!-- operation="delete"-->
</session>
</sessions>
</port-mirror>

```

Command Syntax

```
no shut
```

Configure description

Use this attribute to add a description to port-mirror session

This command is supported when following feature are enabled advance mirror feature

Attribute Name: description

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```

<port-mirror xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-mirror">
  <sessions>
    <session>
      <id>1</id>
      <config>
        <id>1</id>
      </config>
      <description>LINE</description> <!-- operation="delete"-->
    </session>
  </sessions>
</port-mirror>

```

Command Syntax

```
description LINE
```

Configure source vlan

use this attribute to configure source-vlan

This command is supported when following feature are enabled advance mirror feature

Attribute Name: source-vlan

Attribute Type: string

Attribute Range: 2-4094

Netconf edit-config payload

```

<port-mirror xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-mirror">

```

```
<sessions>
<session>
  <id>1</id>
  <config>
    <id>1</id>
  </config>
  <source-vlan>VLAN_RANGE</source-vlan> <!-- operation="delete"-->
</session>
</sessions>
</port-mirror>
```

Command Syntax

```
source vlan VLAN_RANGE
```

Configure interface name

Use this attribute to configure port mirror local interface

This command is supported when following feature are enabled advance mirror feature

Attribute Name: interface-name

Attribute Type: string

Netconf edit-config payload

```
<port-mirror xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-mirror">
<sessions>
<session>
  <id>1</id>
  <config>
    <id>1</id>
  </config>
<destination>
<local>
<config>
  <interface-name>IFNAME</interface-name> <!-- operation="delete"-->
</config>
</local>
</destination>
</session>
</sessions>
</port-mirror>
```

Command Syntax

```
destination interface IFNAME
```

Configure reflector interface name

Use this attribute to configure port mirror remote reflector interface

This command is supported when following feature are enabled advance mirror feature

Attribute Name: reflector-interface-name

Attribute Type: string

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 2-4094

Netconf edit-config payload

```
<port-mirror xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-mirror">
  <sessions>
    <session>
      <id>1</id>
      <config>
        <id>1</id>
      </config>
    <destination>
      <remote>
        <config>
          <vlan-id>2</vlan-id>
          <reflector-interface-name>IFNAME</reflector-interface-name>
        </config>
      </remote>
    </destination>
  </session>
</sessions>
</port-mirror>
```

Command Syntax

```
destination remote vlan <2-4094> reflector-port IFNAME
```

Configure direction

Source interface direction

This command is supported when following feature are enabled advance mirror feature

Attribute Name: direction

Attribute Type: bits (rx|tx|both)

Netconf edit-config payload

```
<port-mirror xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-mirror">
  <sessions>
    <session>
      <id>1</id>
      <config>
        <id>1</id>
      </config>
    <source-interfaces>
      <source-interface>
        <name>IFNAME</name>
      </source-interface>
    </source-interfaces>
  </session>
</sessions>
</port-mirror>
```

```
    <name>IFNAME</name>
  </config>
  <direction>rx</direction>
</source-interface>
</source-interfaces>
</session>
</sessions>
</port-mirror>
```

Command Syntax

```
source interface IFNAME ((rx|tx|both)|)
```

IPI-RIPNG

Configure options

This attribute enables debugging for RIPng

Attribute Name: options

Attribute Type: bits (all|events|packet send|packet recv|packet|packet detail|nsm|rib)

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <debug>
  <config>
    <options>all</options> <!-- operation="delete"-->
  </config>
</debug>
</ripng>
```

Command Syntax

```
debug ipv6 rip (all|events|packet send|packet recv|packet|packet detail|nsm|rib|)
```

Configure split horizon

Use this attribute to perform the split-horizon action on the interface. Deleting this attribute would set the split-horizon to poisoned reverse which is the default value.

Attribute Name: split-horizon

Attribute Type: boolean

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <interfaces>
  <interface>
    <name>WORD</name>
    <config>
      <name>WORD</name>
```

```
    </config>
    <split-horizon>true</split-horizon> <!-- operation="delete"-->
</interface>
</interfaces>
</ripng>
```

Command Syntax

```
ipv6 rip split-horizon
```

Configure name

Use this attribute to perform the split-horizon action on the interface. Deleting this attribute would set the split-horizon to poisoned reverse which is the default value.

Attribute Name: split-horizon

Attribute Type: boolean

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <split-horizon>true</split-horizon> <!-- operation="delete"-->
</interface>
</interfaces>
</ripng>
```

Command Syntax

```
no ipv6 rip split-horizon
```

Configure enabled

Use this attribute to perform the router rip action on the interface

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </enabled><!-- operation="delete"-->
</interface>
```

```
</interfaces>
</ripng>
```

Command Syntax

```
ipv6 router rip
```

Configure metric offset

Use this attribute to perform the metric-offset action on the interface

Attribute Name: metric-offset

Attribute Type: uint8

Attribute Range: 1-16

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <metric-offset>1</metric-offset> <!-- operation="delete"-->
</interface>
</interfaces>
</ripng>
```

Command Syntax

```
ipv6 rip metric-offset <1-16>
```

Configure ripng enabled

Use this attribute to enable the router instance

Attribute Name: ripng-enabled

Attribute Type: uint8

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
<instance>
<config>
  </ripng-enabled>
</config>
</instance>
</ripng>
```

Command Syntax

```
router ipv6 rip
```

Configure enable cisco metric behavior

Use this attribute to enable the metric update consistent with Cisco

Attribute Name: enable-cisco-metric-behavior

Attribute Type: boolean

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <config>
      <enable-cisco-metric-behavior>true</enable-cisco-metric-behavior> <!--
operation="delete"-->
    </config>
  </instance>
</ripng>
```

Command Syntax

```
cisco-metric-behavior enable
```

Configure passive interfaces

Use this attribute to block RIP broadcast on the interface

Attribute Name: passive-interfaces

Attribute Type: string

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <config>
      <passive-interfaces>IFNAME</passive-interfaces> <!-- operation="delete"-->
    </config>
  </instance>
</ripng>
```

Command Syntax

```
passive-interface IFNAME
```

Configure distance

Use this attribute to set the administrative distance. The administrative distance is a feature used by the routers to select the path when there are two or more different routes to the same destination from two different routing protocols. A smaller administrative distance indicating a more reliable protocol

Attribute Name: distance

Attribute Type: uint8

Default Value: 120

Attribute Range: 1-255

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <config>
      <distance>1</distance> <!-- operation="delete"-->
    </config>
  </instance>
</ripng>
```

Command Syntax

```
distance <1-255>
```

Configure static routes

Use this attribute to configure static RIP routes

Attribute Name: static-routes

Attribute Type: string

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <config>
      <static-routes>X:X::X:X/M</static-routes> <!-- operation="delete"-->
    </config>
  </instance>
</ripng>
```

Command Syntax

```
route X:X::X:X/M
```

Configure aggregate prefixes

Use this attribute to configure aggregate prefixes

Attribute Name: aggregate-prefixes

Attribute Type: string

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <config>
      <aggregate-prefixes>X:X::X:X/M</aggregate-prefixes> <!-- operation="delete"-->
    </config>
  </instance>
</ripng>
```

Command Syntax

```
aggregate-address X:X::X:X/M
```

Configure default metric

Use this attribute to specify the metrics to be assigned to redistributed routers

Attribute Name: default-metric

Attribute Type: uint8

Default Value: 1

Attribute Range: 1-15

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <config>
      <default-metric>1</default-metric> <!-- operation="delete"-->
    </config>
  </instance>
</ripng>
```

Command Syntax

```
default-metric <1-15>
```

Configure originate default route

Use this attribute to add default routes to the RIP updates

Attribute Name: originate-default-route

Attribute Type: empty

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <config>
      </originate-default-route><!-- operation="delete"-->
    </config>
  </instance>
</ripng>
```

Command Syntax

```
default-information originate
```

Configure receive buffer size

Use this attribute to run-time configure the RIP UDP receive-buffer size

Attribute Name: receive-buffer-size

Attribute Type: uint32

Default Value: 8192

Attribute Range: 8192-2147483647

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <config>
      <receive-buffer-size>8192</receive-buffer-size> <!-- operation="delete"-->
    </config>
  </instance>
</ripng>
```

Command Syntax

```
recv-buffer-size <8192-2147483647>
```

Configure route type

Use this attribute to redistribute information from other routing protocols

Attribute Name: route-type

Attribute Type: enum (kernel|connected|static|ospf6|isis|bgp)

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <redistribute-policies>
      <redistribute-policy> <!-- operation="delete"-->
        <route-type>kernel</route-type>
      <config>
        <route-type>kernel</route-type>
      </config>
    </redistribute-policy>
  </redistribute-policies>
</instance>
</ripng>
```

Command Syntax

```
redistribute (kernel|connected|static|ospf6|isis|bgp)
```

Configure route map

Use this attribute to redistribute route-map from other routing protocols

Attribute Name: route-map

Attribute Type: string

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 0-16

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
```

```

<instance>
<redistribute-policies>
<redistribute-policy>
  <route-type>kernel</route-type>
  <config>
    <route-type>kernel</route-type>
    <metric>0</metric>
  </config>
  <route-map>WORD</route-map>
</redistribute-policy>
</redistribute-policies>
</instance>
</ripng>

```

Command Syntax

```
redistribute (kernel|connected|static|ospf6|isis|bgp) metric <0-16> route-map WORD
```

Configure metric

Use this attribute to redistribute metric information from other routing protocols

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 0-16

Netconf edit-config payload

```

<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
<instance>
<redistribute-policies>
<redistribute-policy>
  <route-type>kernel</route-type>
  <config>
    <route-type>kernel</route-type>
  </config>
  <metric>0</metric>
</redistribute-policy>
</redistribute-policies>
</instance>
</ripng>

```

Command Syntax

```
redistribute (kernel|connected|static|ospf6|isis|bgp) metric <0-16>
```

Configure route table update interval

Use this attribute to adjust basic routing protocol update timer interval

Attribute Name: route-table-update-interval

Attribute Type: uint32

Attribute Range: 5-2147483647

Attribute Name: route-info-timeout-interval

Attribute Type: uint32

Attribute Range: 5-2147483647

Attribute Name: garbage-collection-interval

Attribute Type: uint32

Attribute Range: 5-2147483647

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <timers>
      <config>
        <route-info-timeout-interval>5</route-info-timeout-interval>
        <garbage-collection-interval>5</garbage-collection-interval>
        <route-table-update-interval>5</route-table-update-interval>
      </config>
    </timers>
  </instance>
</ripng>
```

Command Syntax

```
timers basic <5-2147483647> <5-2147483647> <5-2147483647>
```

Configure address

Use this attribute to specify a link local address of neighbor router. It is used for each connected point-to-point link. This command exchanges non-broadcast routing information. It can be used multiple times for additional neighbors

Attribute Name: address

Attribute Type: inet:ipv6-address

Attribute Name: if-name

Attribute Type: string

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <neighbors>
      <neighbor> <!-- operation="delete"-->
        <address>X:X::X:X</address>
        <config>
          <address>X:X::X:X</address>
          <if-name>IFNAME</if-name>
        </config>
      </neighbor>
    </neighbors>
  </instance>
```

```
</ripng>
```

Command Syntax

```
neighbor X:X::X:X IFNAME
```

Configure type

Use this attribute to decide the type of packets to which the filtering is applied

Attribute Name: type

Attribute Type: enum (in|out)

Attribute Name: route-map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <interfaces>
      <interface>
        <name>IFNAME</name>
        <config>
          <name>WORD</name>
        </config>
        <filtering-route-maps>
          <filtering-route-map>
            <type>in</type>
            <config>
              <type>in</type>
              <route-map-name>WORD</route-map-name>
            </config>
          </filtering-route-map>
        </filtering-route-maps>
      </interface>
    </interfaces>
  </instance>
</ripng>
```

Command Syntax

```
route-map WORD (in|out) IFNAME
```

Configure access list name

This attribute describes the metric used for offset list

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 0-16

Attribute Name: access-list-name

Attribute Type: string

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <interfaces>
      <interface>
        <name>IFNAME</name>
        <config>
          <name>WORD</name>
        </config>
      <offset-lists>
      <offset-list>
        <direction>in</direction>
        <config>
          <direction>in</direction>
          <access-list-name>WORD</access-list-name>
        </config>
        <metric>0</metric>
      </offset-list>
    </offset-lists>
  </interface>
</interfaces>
</instance>
</ripng>
```

Command Syntax

```
offset-list WORD (in|out) <0-16> IFNAME
```

Configure direction

Use this attribute to decide the type of packets to which the distribute list is applied

Attribute Name: direction

Attribute Type: enum (in|out)

Attribute Name: access-list-name

Attribute Type: string

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <interfaces>
      <interface>
        <name>IFNAME</name>
        <config>
          <name>WORD</name>
        </config>
      <distribute-lists>
```



```

<distribute-list>
  <direction>in</direction>
  <config>
    <direction>in</direction>
    <access-list-name>WORD</access-list-name>
  </config>
</distribute-list>
</distribute-lists>
</interface>
</interfaces>
</instance>
</ripng>

```

Command Syntax

```
distribute-list WORD (in|out) IFNAME
```

Configure list name

Use this attribute to decide the type of packets to which the distribute list prefix is applied

Attribute Name: direction

Attribute Type: enum (in|out)

Attribute Name: list-name

Attribute Type: string

Netconf edit-config payload

```

<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <interfaces>
      <interface>
        <name>IFNAME</name>
        <config>
          <name>WORD</name>
        </config>
      <interface>
        <name>IFNAME</name>
        <config>
          <name>WORD</name>
        </config>
      </interface>
    </interfaces>
    <distribute-prefix-lists>
      <distribute-prefix-list>
        <direction>in</direction>
        <config>
          <direction>in</direction>
          <list-name>WORD</list-name>
        </config>
      </distribute-prefix-list>
    </distribute-prefix-lists>
  </instance>
</ripng>

```

Command Syntax

```
distribute-list prefix WORD (in|out) IFNAME
```

debug ipv6 rip (all|events|packet send|packet rcv|packet|packet detail|nsm|rib)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|events|packet send|packet rcv|packet|packet detail|nsm|rib)

Netconf RPC payload

```
<ripng-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <terminal-debug-options>all</terminal-debug-options>
</ripng-terminal-debug-on>
```

Command Syntax

```
debug ipv6 rip (all|events|packet send|packet rcv|packet|packet detail|nsm|rib)
```

no debug ipv6 rip (all|events|packet send|packet rcv|packet|packet detail|nsm|rib)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|events|packet send|packet rcv|packet|packet detail|nsm|rib)

Netconf RPC payload

```
<ripng-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <terminal-debug-options>all</terminal-debug-options>
</ripng-terminal-debug-off>
```

Command Syntax

```
no debug ipv6 rip (all|events|packet send|packet rcv|packet|packet detail|nsm|rib)
```

clear ipv6 rip route (kernel|connected|static|isis|ospf6|bgp|rip|all)

Attribute Name: type

Attribute Type: enum (kernel|connected|static|isis|ospf6|bgp|rip|all)

Netconf RPC payload

```
<ripng-clear-route xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <type>kernel</type>
</ripng-clear-route>
```

Command Syntax

```
clear ipv6 rip route (kernel|connected|static|isis|ospf6|bgp|rip|all)
```

clear ipv6 rip route X:X::X:X/M

Attribute Name: prefix

Attribute Type: string

Netconf RPC payload

```
<ripng-clear-route-prefix xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <prefix>X:X::X:X/M</prefix>
</ripng-clear-route-prefix>
```

Command Syntax

```
clear ipv6 rip route X:X::X:X/M
```

IPI-RIPNG-VRF

Configure vrf name

VRF Name

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf> <!-- operation="delete"-->
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
      </vrf>
    </vrfs>
  </instance>
</ripng>
```

Command Syntax

```
address-family ipv6 vrf NAME
```

Configure enable cisco metric behavior

Use this attribute to enable the metric update consistent with Cisco

Attribute Name: enable-cisco-metric-behavior

Attribute Type: boolean

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <enable-cisco-metric-behavior>true</enable-cisco-metric-behavior> <!--
operation="delete"-->
      </vrf>
    </vrfs>
  </instance>
</ripng>
```

Command Syntax

```
cisco-metric-behavior enable
```

Configure passive interfaces

Use this attribute to block RIP broadcast on the interface

Attribute Name: passive-interfaces

Attribute Type: string

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
          </config>
          <passive-interfaces>IFNAME</passive-interfaces> <!-- operation="delete"--
>
        </vrf>
      </vrfs>
    </instance>
  </ripng>
```

Command Syntax

```
passive-interface IFNAME
```

Configure distance

Use this attribute to set the administrative distance. The administrative distance is a feature used by the routers to select the path when there are two or more different routes to the same destination from two different routing protocols. A smaller administrative distance indicating a more reliable protocol

Attribute Name: distance

Attribute Type: uint8

Default Value: 120

Attribute Range: 1-255

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <distance>1</distance> <!-- operation="delete"-->
      </vrf>
    </vrfs>
  </instance>
</ripng>
```

Command Syntax

```
distance <1-255>
```

Configure static routes

Use this attribute to configure static RIP routes

Attribute Name: static-routes

Attribute Type: string

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <static-routes>X:X::X:X/M</static-routes> <!-- operation="delete"-->
      </vrf>
    </vrfs>
  </instance>
</ripng>
```

Command Syntax

```
route X:X::X:X/M
```

Configure aggregate prefixes

Use this attribute to configure aggregate prefixes

Attribute Name: aggregate-prefixes

Attribute Type: string

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <aggregate-prefixes>X:X::X:X/M</aggregate-prefixes> <!--
operation="delete"-->
      </vrf>
    </vrfs>
  </instance>
</ripng>
```

Command Syntax

```
aggregate-address X:X::X:X/M
```

Configure default metric

Use this attribute to specify the metrics to be assigned to redistributed routers

Attribute Name: default-metric

Attribute Type: uint8

Default Value: 1

Attribute Range: 1-15

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <default-metric>1</default-metric> <!-- operation="delete"-->
      </vrf>
    </vrfs>
  </instance>
</ripng>
```

Command Syntax

```
default-metric <1-15>
```

Configure originate default route

Use this attribute to add default routes to the RIP updates

Attribute Name: originate-default-route

Attribute Type: empty

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        </originate-default-route><!-- operation="delete"-->
      </vrf>
    </vrfs>
  </instance>
</ripng>
```

Command Syntax

```
default-information originate
```

Configure receive buffer size

Use this attribute to run-time configure the RIP UDP receive-buffer size

Attribute Name: receive-buffer-size

Attribute Type: uint32

Default Value: 8192

Attribute Range: 8192-2147483647

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <receive-buffer-size>8192</receive-buffer-size> <!-- operation="delete"-->
      </vrf>
    </vrfs>
  </instance>
</ripng>
```

```
</vrfs>  
</instance>  
</ripng>
```

Command Syntax

```
recv-buffer-size <8192-2147483647>
```

Configure route type

Use this attribute to redistribute information from other routing protocols

Attribute Name: route-type

Attribute Type: enum (connected|static|ospf6|bgp)

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">  
<instance>  
  <vrfs>  
    <vrf>  
      <vrf-name>NAME</vrf-name>  
      <config>  
        <vrf-name>WORD</vrf-name>  
      </config>  
      <redistribute-policies>  
        <redistribute-policy> <!-- operation="delete"-->  
          <route-type>connected</route-type>  
          <config>  
            <route-type>connected</route-type>  
          </config>  
        </redistribute-policy>  
      </redistribute-policies>  
    </vrf>  
  </vrfs>  
</instance>  
</ripng>
```

Command Syntax

```
redistribute (connected|static|ospf6|bgp)
```

Configure route map

Use this attribute to redistribute route-map from other routing protocols

Attribute Name: route-map

Attribute Type: string

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 0-16

Netconf edit-config payload

```

<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <redistribute-policies>
          <redistribute-policy>
            <route-type>connected</route-type>
            <config>
              <route-type>connected</route-type>
              <metric>0</metric>
            </config>
            <route-map>WORD</route-map>
          </redistribute-policy>
        </redistribute-policies>
      </vrf>
    </vrfs>
  </instance>
</ripng>

```

Command Syntax

```
redistribute (connected|static|ospf6|bgp) metric <0-16> route-map WORD
```

Configure metric

Use this attribute to redistribute metric information from other routing protocols

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 0-16

Netconf edit-config payload

```

<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <redistribute-policies>
          <redistribute-policy>
            <route-type>connected</route-type>
            <config>
              <route-type>connected</route-type>
            </config>
          </redistribute-policy>
        </redistribute-policies>
      </vrf>
    </vrfs>
  </instance>
</ripng>

```

```
        </config>
        <metric>0</metric>
    </redistribute-policy>
</redistribute-policies>
</vrf>
</vrfs>
</instance>
</ripng>
```

Command Syntax

```
redistribute (connected|static|ospf6|bgp) metric <0-16>
```

Configure route table update interval

Use this attribute to adjust basic routing protocol update timer interval

Attribute Name: route-table-update-interval

Attribute Type: uint32

Attribute Range: 5-2147483647

Attribute Name: route-info-timeout-interval

Attribute Type: uint32

Attribute Range: 5-2147483647

Attribute Name: garbage-collection-interval

Attribute Type: uint32

Attribute Range: 5-2147483647

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
<instance>
  <vrfs>
    <vrf>
      <vrf-name>NAME</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
      </config>
      <timers>
        <config>
          <route-info-timeout-interval>5</route-info-timeout-interval>
          <garbage-collection-interval>5</garbage-collection-interval>
          <route-table-update-interval>5</route-table-update-interval>
        </config>
      </timers>
    </vrf>
  </vrfs>
</instance>
</ripng>
```

Command Syntax

```
timers basic <5-2147483647> <5-2147483647> <5-2147483647>
```

Configure address

Use this attribute to specify a link local address of neighbor router. It is used for each connected point-to-point link. This command exchanges non-broadcast routing information. It can be used multiple times for additional neighbors

Attribute Name: address

Attribute Type: inet:ipv6-address

Attribute Name: if-name

Attribute Type: string

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <neighbors>
          <neighbor> <!-- operation="delete"-->
            <address>X:X::X:X</address>
            <config>
              <address>X:X::X:X</address>
              <if-name>IFNAME</if-name>
            </config>
          </neighbor>
        </neighbors>
      </vrf>
    </vrfs>
  </instance>
</ripng>
```

Command Syntax

```
neighbor X:X::X:X IFNAME
```

Configure type

Use this attribute to decide the type of packets to which the filtering is applied

Attribute Name: type

Attribute Type: enum (in|out)

Attribute Name: route-map-name

Attribute Type: string

Attribute Range: 1-63

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
        </config>
        <interfaces>
          <interface>
            <name>IFNAME</name>
            <config>
              <name>WORD</name>
            </config>
            <filtering-route-maps>
              <filtering-route-map>
                <type>in</type>
                <config>
                  <type>in</type>
                  <route-map-name>WORD</route-map-name>
                </config>
              </filtering-route-map>
            </filtering-route-maps>
          </interface>
        </interfaces>
      </vrf>
    </vrfs>
  </instance>
</ripng>
```

Command Syntax

```
route-map WORD (in|out) IFNAME
```

Configure access list name

This attribute describes the metric used for offset list

Attribute Name: metric

Attribute Type: uint8

Attribute Range: 0-16

Attribute Name: access-list-name

Attribute Type: string

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
      <vrf>
```

```

    <vrf-name>NAME</vrf-name>
    <config>
      <vrf-name>WORD</vrf-name>
    </config>
    <interfaces>
    <interface>
      <name>IFNAME</name>
      <config>
        <name>WORD</name>
      </config>
      <offset-lists>
      <offset-list>
        <direction>in</direction>
        <config>
          <direction>in</direction>
          <access-list-name>WORD</access-list-name>
        </config>
        <metric>0</metric>
      </offset-list>
    </offset-lists>
    </interface>
  </interfaces>
</vrf>
</vrfs>
</instance>
</ripng>

```

Command Syntax

```
offset-list WORD (in|out) <0-16> IFNAME
```

Configure direction

Use this attribute to decide the type of packets to which the distribute list is applied

Attribute Name: direction

Attribute Type: enum (in|out)

Attribute Name: access-list-name

Attribute Type: string

Netconf edit-config payload

```

<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
    <vrf>
      <vrf-name>NAME</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
      </config>
    </vrf>
  </vrfs>
  </instance>
</ripng>

```

```
<interface>
  <name>IFNAME</name>
  <config>
    <name>WORD</name>
  </config>
  <distribute-lists>
  <distribute-list>
    <direction>in</direction>
    <config>
      <direction>in</direction>
      <access-list-name>WORD</access-list-name>
    </config>
  </distribute-list>
</distribute-lists>
</interface>
</interfaces>
</vrf>
</vrfs>
</instance>
</ripng>
```

Command Syntax

```
distribute-list WORD (in|out) IFNAME
```

Configure list name

Use this attribute to decide the type of packets to which the distribute list prefix is applied

Attribute Name: direction

Attribute Type: enum (in|out)

Attribute Name: list-name

Attribute Type: string

Netconf edit-config payload

```
<ripng xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ripng">
  <instance>
    <vrfs>
    <vrf>
      <vrf-name>NAME</vrf-name>
      <config>
        <vrf-name>WORD</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <interfaces>
  <interface>
    <name>IFNAME</name>
    <config>
      <name>WORD</name>
    </config>
  </interface>
</interfaces>
</instance>
</ripng>
```

```

    <distributed-prefix-list>
      <direction>in</direction>
      <config>
        <direction>in</direction>
        <list-name>WORD</list-name>
      </config>
    </distributed-prefix-list>
  </distributed-prefix-lists>
</interface>
</interfaces>
</vrf>
</vrfs>
</instance>
</ripng>

```

Command Syntax

```
distributed-list prefix WORD (in|out) IFNAME
```

IPI-ARP

Configure ip address

Use this attribute to create a static ARP entry

Attribute Name: ip-address

Attribute Type: inet:ipv4-address

Attribute Name: mac-address

Attribute Type: string

Netconf edit-config payload

```

<arp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-arp">
  <entries>
    <entry> <!-- operation="delete"-->
      <ip-address>A.B.C.D</ip-address>
      <config>
        <ip-address>A.B.C.D</ip-address>
        <vrf-name>NAME</vrf-name>
        <mac-address>XXXX.XXXX.XXXX</mac-address>
      </config>
      <vrf-name>NAME</vrf-name>
    </entry>
  </entries>
</arp>

```

Command Syntax

```
ip arp (vrf NAME|) A.B.C.D XXXX.XXXX.XXXX
```

Configure respond to arp request

Use this attribute to set the response to ARP requests for the IP address

Attribute Name: respond-to-arp-request

Attribute Type: empty

Attribute Name: mac-address

Attribute Type: string

Netconf edit-config payload

```
<arp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-arp">
  <entries>
    <entry>
      <ip-address>A.B.C.D</ip-address>
      <config>
        <ip-address>A.B.C.D</ip-address>
        <vrf-name>NAME</vrf-name>
        <mac-address>XXXX.XXXX.XXXX</mac-address>
      </config>
      <vrf-name>NAME</vrf-name>
    </respond-to-arp-request>
  </entry>
</entries>
</arp>
```

Command Syntax

```
ip arp (vrf NAME|) A.B.C.D XXXX.XXXX.XXXX alias
```

Configure icmp redirect

Use this attribute to trap ICMP redirect packets to the CPU

This command is supported when following feature are enabled custom2 cli for DUNE board

Attribute Name: icmp-redirect

Attribute Type: empty

Netconf edit-config payload

```
<arp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-arp">
  <global>
    <config>
      </icmp-redirect><!-- operation="delete"-->
    </config>
  </global>
</arp>
```

Command Syntax

```
ip redirects
```

Configure enable

Enable/Disable arp event debug

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<arp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-arp">
  <debug>
  <config>
    </enable><!-- operation="delete"-->
  </config>
</debug>
</arp>
```

Command Syntax

```
debug ip arp event
```

Configure enable proxy arp

Use this attribute to enable the proxy ARP feature

Attribute Name: enable-proxy-arp

Attribute Type: empty

Netconf edit-config payload

```
<arp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-arp">
  <interfaces>
  <interface>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
    </enable-proxy-arp><!-- operation="delete"-->
  </interface>
</interfaces>
</arp>
```

Command Syntax

```
ip proxy-arp
```

Configure enable local proxy arp

Use this attribute to enable the local proxy ARP feature

Attribute Name: enable-local-proxy-arp

Attribute Type: empty

Netconf edit-config payload

```
<arp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-arp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </enable-local-proxy-arp><!-- operation="delete"-->
</interface>
</interfaces>
</arp>
```

Command Syntax

```
ip local-proxy-arp
```

Configure enable ip redirects

Use this attribute to enable ICMP redirects in kernel

Attribute Name: enable-ip-redirects

Attribute Type: empty

Netconf edit-config payload

```
<arp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-arp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  </enable-ip-redirects><!-- operation="delete"-->
</interface>
</interfaces>
</arp>
```

Command Syntax

```
ip redirects
```

Configure arp ageing timeout

Use this attribute to set the ARP aging timeout. The bridge aging time affects the ARP entries which are dependent upon the MAC addresses in hardware. If a MAC address ages out, it causes the corresponding ARP entry to refresh.

Attribute Name: arp-ageing-timeout

Attribute Type: uint16

Default Value: 1500

Attribute Range: 60-28800

Netconf edit-config payload

```
<arp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-arp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <arp-ageing-timeout>60</arp-ageing-timeout> <!-- operation="delete"-->
</interface>
</interfaces>
</arp>
```

Command Syntax

```
arp-ageing-timeout <60-28800>
```

Configure arp reachable time

Use this attribute to set the ARP reachable time.

Attribute Name: arp-reachable-time

Attribute Type: uint16

Default Value: 60

Attribute Range: 10-3600

Netconf edit-config payload

```
<arp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-arp">
<interfaces>
<interface>
  <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
  <arp-reachable-time>10</arp-reachable-time> <!-- operation="delete"-->
</interface>
</interfaces>
</arp>
```

Command Syntax

```
arp-reachable-time <10-3600>
```

debug ip arp event

Netconf RPC payload

```
<arp-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-arp"/>
```

Command Syntax

```
debug ip arp event
```

no debug ip arp event

Netconf RPC payload

```
<arp-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-arp"/>
```

Command Syntax

```
no debug ip arp event
```

clear arp (A.B.C.D|) (vrf (all|VRFNAME|default|))

Attribute Name: ip-address

Attribute Type: inet:ipv4-address

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<clear-arp-entry xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-arp">  
<ip-address>A.B.C.D</ip-address>  
<vrf-name>all</vrf-name>  
</clear-arp-entry>
```

Command Syntax

```
clear arp (A.B.C.D|) (vrf (all|VRFNAME|default|))
```

clear arp IFNAME (vrf (all|VRFNAME|default|))

Attribute Name: if-name

Attribute Type: string

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<clear-arp-entry-per-interface xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-  
arp">  
<if-name>IFNAME</if-name>  
<vrf-name>all</vrf-name>  
</clear-arp-entry-per-interface>
```

Command Syntax

```
clear arp IFNAME (vrf (all|VRFNAME|default|))
```

IPI-NEIGHBOR-DISCOVERY

Configure interface name

Use this attribute to add a static neighbor entry of the interface name

Attribute Name: interface-name

Attribute Type: string

Attribute Name: mac-address

Attribute Type: string

Netconf edit-config payload

```
<neighbor-discovery xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-neighbor-
discovery">
  <entries>
    <entry> <!-- operation="delete"-->
      <interface-name>IFNAME</interface-name>
      <config>
        <interface-name>IFNAME</interface-name>
        <ipv6-address>X:X::X:X</ipv6-address>
        <mac-address>XXXX.XXXX.XXXX</mac-address>
      </config>
      <ipv6-address>X:X::X:X</ipv6-address>
    </entry>
  </entries>
</neighbor-discovery>
```

Command Syntax

```
ipv6 neighbor X:X::X:X IFNAME XXXX.XXXX.XXXX
```

Configure ipv6 address

Use this attribute to add a static neighbor entry of the interface name

Attribute Name: interface-name

Attribute Type: string

Netconf edit-config payload

```
<neighbor-discovery xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-neighbor-
discovery">
  <entries>
    <entry>
      <interface-name>IFNAME</interface-name>
      <config>
        <interface-name>IFNAME</interface-name>
        <ipv6-address>X:X::X:X</ipv6-address>
      </config>
      <ipv6-address>X:X::X:X</ipv6-address>
    </entry>
  </entries>
</neighbor-discovery>
```

```
</entry>
</entries>
</neighbor-discovery>
```

Command Syntax

```
ipv6 neighbor X:X::X:X IFNAME IFNAME
```

Configure enable

Use this attribute to enable debugging for neighbor events.

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<neighbor-discovery xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-neighbor-
discovery">
  <debug>
    <config>
      </enable><!-- operation="delete"-->
    </config>
  </debug>
</neighbor-discovery>
```

Command Syntax

```
debug ipv6 nd event
```

Configure nd ageing timeout

Use this attribute to set the neighbor ageing timeout value.

Attribute Name: nd-ageing-timeout

Attribute Type: uint16

Default Value: 1500

Attribute Range: 60-28800

Netconf edit-config payload

```
<neighbor-discovery xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-neighbor-
discovery">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <nd-ageing-timeout>60</nd-ageing-timeout> <!-- operation="delete"-->
    </interface>
  </interfaces>
</neighbor-discovery>
```

Command Syntax

```
nd-ageing-timeout <60-28800>
```

Configure nd reachable time

Use this attribute to set neighbor reachable time value.

Attribute Name: nd-reachable-time

Attribute Type: uint32

Default Value: 60

Attribute Range: 10-3600

Netconf edit-config payload

```
<neighbor-discovery xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-neighbor-
discovery">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <nd-reachable-time>10</nd-reachable-time> <!-- operation="delete"-->
    </interface>
  </interfaces>
</neighbor-discovery>
```

Command Syntax

```
nd-reachable-time <10-3600>
```

debug ipv6 nd event

Netconf RPC payload

```
<nd-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-neighbor-
discovery"/>
```

Command Syntax

```
debug ipv6 nd event
```

no debug ipv6 nd event

Netconf RPC payload

```
<nd-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-neighbor-
discovery"/>
```

Command Syntax

```
no debug ipv6 nd event
```

clear ipv6 neighbors (X:X::X:X/M|) (vrf (all|VRFNAME|default|))

Attribute Name: ipv6-address

Attribute Type: string

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<clear-ipv6-nd-entry xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-neighbor-
discovery">
  <ipv6-address>X:X::X:X/M</ipv6-address>
  <vrf-name>all</vrf-name>
</clear-ipv6-nd-entry>
```

Command Syntax

```
clear ipv6 neighbors (X:X::X:X/M|) (vrf (all|VRFNAME|default|))
```

clear ipv6 neighbors IFNAME (vrf (all|VRFNAME|default|))

Attribute Name: if-name

Attribute Type: string

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<clear-ipv6-nd-entry-per-interface xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-neighbor-discovery">
  <if-name>IFNAME</if-name>
  <vrf-name>all</vrf-name>
</clear-ipv6-nd-entry-per-interface>
```

Command Syntax

```
clear ipv6 neighbors IFNAME (vrf (all|VRFNAME|default|))
```

IPI-USER-SESSION-MANAGEMENT

Configure console id

Attribute used to set line console identification.

Attribute Name: console-id

Attribute Type: enum (0)

Netconf edit-config payload

```
<user-session xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-session-
management">
```



```
<line-console>
<console> <!-- operation="delete"-->
  <console-id>0</console-id>
  <config>
    <console-id>0</console-id>
  </config>
</console>
</line-console>
</user-session>
```

Command Syntax

```
line console <0-0>
```

Configure privilege level

Attribute used to set line privilege level.

Attribute Name: privilege-level

Attribute Type: uint8

Attribute Range: 1-16

Netconf edit-config payload

```
<user-session xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-session-
management">
  <line-console>
  <console>
    <console-id>0</console-id>
    <config>
      <console-id>0</console-id>
    </config>
    <privilege-level>1</privilege-level> <!-- operation="delete"-->
  </console>
</line-console>
</user-session>
```

Command Syntax

```
privilege level <1-16>
```

Configure command history max limit

Attribute used to set line maximum limit to history commands.

Attribute Name: command-history-max-limit

Attribute Type: uint32

Attribute Range: 0-2147483647

Netconf edit-config payload

```
<user-session xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-session-
management">
  <line-console>
```

```
<console>
  <console-id>0</console-id>
  <config>
    <console-id>0</console-id>
  </config>
  <command-history-max-limit>0</command-history-max-limit> <!--
operation="delete"-->
</console>
</line-console>
</user-session>
```

Command Syntax

```
history max <0-2147483647>
```

Configure seconds

Attribute used to set line timeout in seconds. The default is 0.

Attribute Name: seconds

Attribute Type: uint32

Attribute Range: 0-2147483

Attribute Name: minutes

Attribute Type: uint32

Attribute Range: 0-35791

Netconf edit-config payload

```
<user-session xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-session-
management">
  <line-console>
    <console>
      <console-id>0</console-id>
      <config>
        <console-id>0</console-id>
      </config>
    </console>
  </line-console>
  <timeout>
    <config>
      <minutes>0</minutes> <!-- operation="delete"-->
      <seconds>0</seconds> <!-- operation="delete"-->
    </config>
  </timeout>
</user-session>
```

Command Syntax

```
exec-timeout <0-35791> <0-2147483>
```

Configure minutes

Attribute used to set line timeout in minutes. The default is 10 minutes.

Attribute Name: minutes

Attribute Type: uint32

Attribute Range: 0-35791

Netconf edit-config payload

```
<user-session xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-session-
management">
  <line-console>
    <console>
      <console-id>0</console-id>
      <config>
        <console-id>0</console-id>
      </config>
    <timeout>
      <config>
        <minutes>0</minutes>
      </config>
    </timeout>
  </console>
</line-console>
</user-session>
```

Command Syntax

```
exec-timeout <0-35791>
```

Configure vty id

Attribute used to set line privilege level.

Attribute Name: privilege-level

Attribute Type: uint8

Attribute Range: 1-16

Netconf edit-config payload

```
<user-session xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-session-
management">
  <line-vty>
    <vty>
      <vty-id>0</vty-id>
      <config>
        <vty-id>0</vty-id>
      </config>
      <privilege-level>1</privilege-level> <!-- operation="delete"-->
    </vty>
  </line-vty>
</user-session>
```

Command Syntax

```
privilege level <1-16>
```

clear line WORD

Attribute Name: line-name

Attribute Type: string

Attribute Range: 1-64

Netconf RPC payload

```
<clear-line xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-session-
management">
  <line-name>WORD</line-name>
</clear-line>
```

Command Syntax

```
clear line WORD
```

mem-info imi monitor-start

Attribute Name: mem-info-imi

Attribute Type: boolean

Netconf RPC payload

```
<mem-info-monitor-start xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-
session-management">
  <mem-info-imi>true</mem-info-imi/>
</mem-info-monitor-start>
```

Command Syntax

```
mem-info imi monitor-start
```

mem-info imi monitor-stop

Attribute Name: mem-info-imi

Attribute Type: boolean

Netconf RPC payload

```
<mem-info-monitor-stop xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-user-
session-management">
  <mem-info-imi>true</mem-info-imi/>
</mem-info-monitor-stop>
```

Command Syntax

```
mem-info imi monitor-stop
```

IPI-IPV6-ROUTER-ADV

Configure suppress ra

Use this attribute to suppress IPv6 Router Advertisements

Attribute Name: suppress-ra

Attribute Type: uint8

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </suppress-ra><!-- operation="delete"-->
    </interface>
  </interfaces>
</router-advertisement>
```

Command Syntax

```
ipv6 nd suppress-ra
```

Configure suppress ra mtu

Use this attribute to disable sending MTU in Router Advertisement messages

Attribute Name: suppress-ra-mtu

Attribute Type: uint8

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </suppress-ra-mtu><!-- operation="delete"-->
    </interface>
  </interfaces>
</router-advertisement>
```

Command Syntax

```
ipv6 nd suppress-ra mtu
```

Configure managed flag

Use this attribute to use DHCP for address config by host

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: managed-flag

Attribute Type: empty

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </managed-flag><!-- operation="delete"-->
    </interface>
  </interfaces>
</router-advertisement>
```

Command Syntax

```
ipv6 nd managed-config-flag
```

Configure other config flag

Use this attribute to use DHCP for non-address config by host

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: other-config-flag

Attribute Type: empty

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </other-config-flag><!-- operation="delete"-->
    </interface>
  </interfaces>
</router-advertisement>
```

Command Syntax

```
ipv6 nd other-config-flag
```

Configure current hop limit

Use this attribute to set advertised current hop limit

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: current-hop-limit

Attribute Type: uint8

Default Value: 64

Attribute Range: 0-255

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <current-hop-limit>0</current-hop-limit> <!-- operation="delete"-->
    </interface>
  </interfaces>
</router-advertisement>
```

Command Syntax

```
ipv6 nd current-hoplimit <0-255>
```

Configure link mtu

Use this attribute to set advertised link-mtu option

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: link-mtu

Attribute Type: uint32

Default Value: 1500

Attribute Range: 1280-65535

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
</router-advertisement>
```

```
    </config>
    <link-mtu>1280</link-mtu> <!-- operation="delete"-->
</interface>
</interfaces>
</router-advertisement>
```

Command Syntax

```
ipv6 nd link-mtu <1280-65535>
```

Configure dad attempts

Use this attribute to set number of attempts for duplicate address detection

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: dad-attempts

Attribute Type: uint16

Default Value: 1

Attribute Range: 0-600

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <dad-attempts>0</dad-attempts> <!-- operation="delete"-->
    </interface>
  </interfaces>
</router-advertisement>
```

Command Syntax

```
ipv6 nd dad attempts <0-600>
```

Configure off link

The IPV6 Router Advertisement prefix off-link flag

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: off-link

Attribute Type: empty

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
```



```

    <name>WORD</name>
  <config>
    <name>WORD</name>
  </config>
</ipv6-prefixes>
<config>
  </off-link><!-- operation="delete"-->
</config>
</ipv6-prefixes>
</interface>
</interfaces>
</router-advertisement>

```

Command Syntax

```
ipv6 nd prefix offlink
```

Configure no auto configuration

The IPV6 Router Advertisement prefix no auto-configuration flag

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: no-auto-configuration

Attribute Type: empty

Netconf edit-config payload

```

<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
  <ipv6-prefixes>
    <config>
      </no-auto-configuration><!-- operation="delete"-->
    </config>
  </ipv6-prefixes>
</router-advertisement>

```

Command Syntax

```
ipv6 nd prefix no-autoconf
```

Configure valid lifetime

The IPV6 Router Advertisement prefix valid lifetime

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: valid-lifetime

Attribute Type: uint32

Default Value: 2592000

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <ipv6-prefixes>
      <config>
        <valid-lifetime>0</valid-lifetime> <!-- operation="delete"-->
      </config>
    </ipv6-prefixes>
  </interface>
</interfaces>
</router-advertisement>
```

Command Syntax

```
ipv6 nd prefix valid-lifetime <0-4294967295>
```

Configure preferred lifetime

The IPV6 Router Advertisement prefix preferred lifetime

This command is supported when following feature are enabled IPV6 Router Advertisement

Attribute Name: preferred-lifetime

Attribute Type: uint32

Default Value: 604800

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <ipv6-prefixes>
      <config>
        <preferred-lifetime>0</preferred-lifetime> <!-- operation="delete"-->
      </config>
    </ipv6-prefixes>
  </interface>
</interfaces>
```

```

</config>
</ipv6-prefixes>
</interface>
</interfaces>
</router-advertisement>

```

Command Syntax

```
ipv6 nd prefix preferred-lifetime <0-4294967295>
```

Configure ipv6 address

The IPV6 Router Advertisement prefix address

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: ipv6-address

Attribute Type: string

Netconf edit-config payload

```

<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
  <ipv6-prefix> <!-- operation="delete"-->
    <ipv6-address>X:X::X:X/M</ipv6-address>
    <config>
      <ipv6-address>X:X::X:X/M</ipv6-address>
    </config>
  </ipv6-prefix>
</ipv6-prefixes>
</interface>
</interfaces>
</router-advertisement>

```

Command Syntax

```
ipv6 nd prefix X:X::X:X/M
```

Configure name

The IPV6 Router Advertisement prefix address preferred lifetime

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: preferred-lifetime

Attribute Type: uint32

Default Value: 604800

Attribute Range: 0-4294967295

Attribute Name: valid-lifetime

Attribute Type: uint32

Default Value: 2592000

Attribute Range: 0-4294967295

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <ipv6-prefixes>
      <ipv6-prefix>
        <ipv6-address>X:X::X:X/M</ipv6-address>
        <config>
          <ipv6-address>X:X::X:X/M</ipv6-address>
          <valid-lifetime>0</valid-lifetime>
        </config>
        <preferred-lifetime>0</preferred-lifetime>
      </ipv6-prefix>
    </ipv6-prefixes>
  </interface>
</interfaces>
</router-advertisement>
```

Command Syntax

```
ipv6 nd prefix X:X::X:X/M <0-4294967295> <0-4294967295>
```

Configure reachable time

Use this attribute to set advertised reachability time

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: reachable-time

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-3600000

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
```

```

    <config>
      <name>WORD</name>
    </config>
  </timers>
</config>
</timers>
</interface>
</interfaces>
</router-advertisement>

```

Command Syntax

```
ipv6 nd reachable-time <0-3600000>
```

Configure retransmission time

Use this attribute to set advertised retransmission timer

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: retransmission-time

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-4294967295

Netconf edit-config payload

```

<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
  <timers>
    <config>
      <retransmission-time>0</retransmission-time> <!-- operation="delete"-->
    </config>
  </timers>
</router-advertisement>

```

Command Syntax

```
ipv6 nd retransmission-time <0-4294967295>
```

Configure router lifetime

Use this attribute to set IPv6 router advertisement lifetime

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: router-lifetime

Attribute Type: uint16

Default Value: 1800

Attribute Range: 0-9000

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    </interface>
  </interfaces>
  <timers>
    <config>
      <router-lifetime>0</router-lifetime> <!-- operation="delete"-->
    </config>
  </timers>
</router-advertisement>
```

Command Syntax

```
ipv6 nd ra-lifetime <0-9000>
```

Configure max ra interval

Use this attribute to set maximum IPv6 router advertisement interval (min-ra-interval must be no greater than $0.75 * \text{max-ra-interval}$)

This command is supported when following feature are enabled IPv6 Router Advertisement

Attribute Name: max-ra-interval

Attribute Type: uint32

Attribute Range: 4-1800

Attribute Name: min-ra-interval

Attribute Type: uint32

Attribute Range: 3-1350

Netconf edit-config payload

```
<router-advertisement xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipv6-router-adv">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
```

```

        <name>WORD</name>
    </config>
</timers>
<ra-interval>
<config>
    <min-ra-interval>3</min-ra-interval>
    <max-ra-interval>4</max-ra-interval>
</config>
</ra-interval>
</timers>
</interface>
</interfaces>
</router-advertisement>

```

Command Syntax

```
ipv6 nd ra-interval <4-1800> (<3-1350>|)
```

IPI-NETWORK-ADDRESS-TRANSLATION

Configure generic timeout

Generic time-out for NAT translations

This command is supported when following feature are enabled NAT feature

Attribute Name: generic-timeout

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-536870

Netconf edit-config payload

```

<network-address-translation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
network-address-translation">
  <timeouts>
    <config>
      <generic-timeout>0</generic-timeout> <!-- operation="delete"-->
    </config>
  </timeouts>
</network-address-translation>

```

Command Syntax

```
ip nat translations time-out <0-536870>
```

Configure icmp timeout

ICMP timeout for NAT translations

This command is supported when following feature are enabled NAT feature

Attribute Name: icmp-timeout

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-536870

Netconf edit-config payload

```
<network-address-translation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
network-address-translation">
  <timeouts>
    <config>
      <icmp-timeout>0</icmp-timeout> <!-- operation="delete"-->
    </config>
  </timeouts>
</network-address-translation>
```

Command Syntax

```
ip nat translations icmp-timeout <0-536870>
```

Configure tcp timeout

TCP timeout for NAT translation

This command is supported when following feature are enabled NAT feature

Attribute Name: tcp-timeout

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-536870

Netconf edit-config payload

```
<network-address-translation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
network-address-translation">
  <timeouts>
    <config>
      <tcp-timeout>0</tcp-timeout> <!-- operation="delete"-->
    </config>
  </timeouts>
</network-address-translation>
```

Command Syntax

```
ip nat translations tcp-timeout <0-536870>
```

Configure udp timeout

UDP timeout for NAT translations

This command is supported when following feature are enabled NAT feature

Attribute Name: udp-timeout

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-536870

Netconf edit-config payload

```
<network-address-translation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-  
network-address-translation">  
  <timeouts>  
    <config>  
      <udp-timeout>0</udp-timeout> <!-- operation="delete"-->  
    </config>  
  </timeouts>  
</network-address-translation>
```

Command Syntax

```
ip nat translations udp-timeout <0-536870>
```

Configure tcp fin timeout

TCP FIN timeout for NAT translations

This command is supported when following feature are enabled NAT feature

Attribute Name: tcp-fin-timeout

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-536870

Netconf edit-config payload

```
<network-address-translation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-  
network-address-translation">  
  <timeouts>  
    <config>  
      <tcp-fin-timeout>0</tcp-fin-timeout> <!-- operation="delete"-->  
    </config>  
  </timeouts>  
</network-address-translation>
```

Command Syntax

```
ip nat translations tcp-fin-timeout <0-536870>
```

Configure global address

Network Address Translation Address global address

This command is supported when following feature are enabled NAT feature

Attribute Name: global-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<network-address-translation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
network-address-translation">
  <ip-rules>
    <incoming>
      <source-mapping-entries>
        <source-mapping-entry <!-- operation="delete"-->
          <global-address>A.B.C.D</global-address>
          <config>
            <global-address>A.B.C.D</global-address>
            <local-address>A.B.C.D</local-address>
          </config>
          <local-address>A.B.C.D</local-address>
        </source-mapping-entry>
      </source-mapping-entries>
    </incoming>
  </ip-rules>
</network-address-translation>
```

Command Syntax

```
ip nat inside source static A.B.C.D A.B.C.D
```

Configure local address

Network Address Translation Address global address

This command is supported when following feature are enabled NAT feature

Attribute Name: global-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<network-address-translation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
network-address-translation">
  <ip-rules>
    <incoming>
      <destination-mapping-entries>
        <destination-mapping-entry <!-- operation="delete"-->
          <global-address>A.B.C.D</global-address>
          <config>
            <global-address>A.B.C.D</global-address>
            <local-address>A.B.C.D</local-address>
          </config>
          <local-address>A.B.C.D</local-address>
        </destination-mapping-entry>
      </destination-mapping-entries>
    </incoming>
  </ip-rules>
</network-address-translation>
```

Command Syntax

```
ip nat inside destination static A.B.C.D A.B.C.D
```

Configure address

Network Address Translation global address

This command is supported when following feature are enabled NAT feature

Attribute Name: address

Attribute Type: inet:ipv4-address

Attribute Name: global-port

Attribute Type: uint16

Attribute Range: 0-65535

Netconf edit-config payload

```
<network-address-translation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
network-address-translation">
  <ip-rules>
    <outgoing>
      <protocol-rule-mapping-entries>
        <protocol-rule-mapping-entry>
          <port>0</port>
          <config>
            <port>0</port>
            <local-address>A.B.C.D</local-address>
            <protocol>tcp</protocol>
          </config>
          <local-address>A.B.C.D</local-address>
          <protocol>tcp</protocol>
        </protocol-rule-mapping-entry>
      </protocol-rule-mapping-entries>
    </outgoing>
  </ip-rules>
  <global-addresses>
    <global-address> <!-- operation="delete"-->
      <address>A.B.C.D</address>
      <config>
        <address>A.B.C.D</address>
        <global-port>0</global-port>
      </config>
    </global-address>
  </global-addresses>
</network-address-translation>
```

Command Syntax

```
ip nat outside destination static (tcp|udp) A.B.C.D <0-65535> A.B.C.D <0-65535>
```

IPI-NETWORK-ADDRESS-TRANSLATION-INTERFACE

Configure incoming

Incoming interface

Attribute Name: incoming

Attribute Type: empty

Netconf edit-config payload

```
<network-address-translation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
network-address-translation">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </incoming><!-- operation="delete"-->
    </interface>
  </interfaces>
</network-address-translation>
```

Command Syntax

```
ip nat inside
```

Configure outgoing

Outgoing interface

Attribute Name: outgoing

Attribute Type: empty

Netconf edit-config payload

```
<network-address-translation xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
network-address-translation">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      </outgoing><!-- operation="delete"-->
    </interface>
  </interfaces>
</network-address-translation>
```

Command Syntax

```
ip nat outside
```

IPI-ERPSV2

Configure ring name

G.8032 ring name. This attribute uniquely identifies a ring on the network device.

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: ring-name

Attribute Type: string

Attribute Range: 1-255

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <rings>
    <ring> <!-- operation="delete"-->
      <ring-name>RINGNAME</ring-name>
    <config>
      <ring-name>RINGNAME</ring-name>
    </config>
  </ring>
</rings>
</erpsv2>
```

Command Syntax

```
g8032 ring RINGNAME
```

Configure east interface

East port associated to the protection ring

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: east-interface

Attribute Type: string

Attribute Range: 1-33

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <rings>
    <ring>
      <ring-name>RINGNAME</ring-name>
    <config>
      <ring-name>RINGNAME</ring-name>
    </config>
  </ring>
</rings>
</erpsv2>
```

```
<east-interface>IFNAME</east-interface> <!-- operation="delete"-->
</ring>
</rings>
</erpsv2>
```

Command Syntax

```
east-interface IFNAME
```

Configure west interface

West port associated to the protection ring

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: west-interface

Attribute Type: string

Attribute Range: 1-33

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
<rings>
<ring>
  <ring-name>RINGNAME</ring-name>
  <config>
    <ring-name>RINGNAME</ring-name>
  </config>
  <west-interface>IFNAME</west-interface> <!-- operation="delete"-->
</ring>
</rings>
</erpsv2>
```

Command Syntax

```
west-interface IFNAME
```

Configure description

Textual description of the ring.

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: description

Attribute Type: string

Attribute Range: 1-255

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
<rings>
<ring>
  <ring-name>RINGNAME</ring-name>
  <config>
```

```

    <ring-name>RINGNAME</ring-name>
  </config>
  <description>1</description> <!-- operation="delete"-->
</ring>
</rings>
</erpsv2>

```

Command Syntax

```
description LINE
```

Configure profile name

G.8032 ring profile name

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```

<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <profiles>
    <profile> <!-- operation="delete"-->
      <profile-name>PROFILENAME</profile-name>
    </profile>
  </profiles>
</erpsv2>

```

Command Syntax

```
g8032 profile PROFILENAME
```

Configure wait to restore timer

In revertive mode the 'wait to restore' (WTR) timer is used to prevent frequent operation of the protection switching due to intermittent signal failure defects. When recovering from a Signal fail, the delay timer must be long enough to allow the recovering network to become stable. WTR timer is activated on RPL owner node. When WTR timer is expired RPL owner node initiates the reversion process by transmitting an R-APS (NR, RB) message.

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: wait-to-restore-timer

Attribute Type: uint8

Default Value: 5

Attribute Range: 1-12

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
<profiles>
<profile>
  <profile-name>PROFILENAME</profile-name>
  <config>
    <profile-name>PROFILENAME</profile-name>
  </config>
  <wait-to-restore-timer>1</wait-to-restore-timer> <!-- operation="delete"-->
</profile>
</profiles>
</erpsv2>
```

Command Syntax

```
timer wait-to-restore <1-12>
```

Configure hold off timer

The hold-off timer is used to coordinate the timing of protection switches. When a new defect or more severe defect occurs (new SF), this event is not to be reported immediately to protection switching if the provisioned hold-off timer value is non-zero. Instead, the hold-off timer is started. When the hold-off timer expires, the trail that started the timer is checked as to whether a defect still exists. If one does exist, that defect is reported to protection switching. Hold off timer values SHOULD be specified in multiple of 100.

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: hold-off-timer

Attribute Type: uint16

Default Value: 0

Attribute Range: 0-10000

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
<profiles>
<profile>
  <profile-name>PROFILENAME</profile-name>
  <config>
    <profile-name>PROFILENAME</profile-name>
  </config>
  <hold-off-timer>0</hold-off-timer> <!-- operation="delete"-->
</profile>
</profiles>
</erpsv2>
```

Command Syntax

```
timer hold-off <0-10000>
```

Configure guard time

The guard time is used to prevent Ethernet ring nodes from acting upon outdated R-APS messages and prevents the possibility of forming a closed loop. This timer period SHOULD be greater than the maximum expected forwarding delay in which an R-APS message traverses the entire ring. The period of the guard timer MAY be configured by the operator in 10 ms steps between 10 ms and 2 seconds.

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: guard-time

Attribute Type: uint16

Default Value: 500

Attribute Range: 10-2000

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <profiles>
    <profile>
      <profile-name>PROFILENAME</profile-name>
      <config>
        <profile-name>PROFILENAME</profile-name>
      </config>
      <guard-time>10</guard-time> <!-- operation="delete"-->
    </profile>
  </profiles>
</erpsv2>
```

Command Syntax

```
timer guard-time <10-2000>
```

Configure protection mode

This leaf defines G.8032 ring protection mode. A ring may operate in revertive or non-revertive mode. In revertive operation, after the condition(s) causing a switch has cleared, the traffic channel is restored to the working transport entity, i.e., blocked on the RPL. In non-revertive operation, the traffic channel continues to use the RPL, if it has not failed, after a switch condition has cleared.

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: protection-mode

Attribute Type: enum (revertive|non-revertive)

Default Value: revertive

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <profiles>
    <profile>
      <profile-name>PROFILENAME</profile-name>
      <config>
        <profile-name>PROFILENAME</profile-name>
      </config>
    </profile>
  </profiles>
</erpsv2>
```

```
<protection-mode>revertive</protection-mode> <!-- operation="delete"-->
</profile>
</profiles>
</erpsv2>
```

Command Syntax

```
switching mode (revertive|non-revertive)
```

Configure name

ERPS instance identifier

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: name

Attribute Type: string

Attribute Range: 1-255

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
<erp-instances>
<erp-instance> <!-- operation="delete"-->
  <name>INSTANCENAME</name>
  <config>
    <name>INSTANCENAME</name>
  </config>
</erp-instance>
</erp-instances>
</erpsv2>
```

Command Syntax

```
g8032 erp-instance INSTANCENAME
```

Configure mapped profile name

G.8032 ring profile name. If this profile exists in the profile configuration list, profile parameters will be imported from it, default values will be used otherwise.

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: mapped-profile-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
<erp-instances>
<erp-instance>
  <name>INSTANCENAME</name>
  <config>
```

```

    <name>INSTANCENAME</name>
  </config>
  <mapped-profile-name>PROFILENAME</mapped-profile-name> <!-- operation="delete"-->
>
</erp-instance>
</erp-instances>
</erpsv2>

```

Command Syntax

```
g8032-profile PROFILENAME
```

Configure ring type

Defines type of a ethernet ring. A ring can be configured as major ring where ring nodes are connected in closed loop or as a sub-ring when a ring may not have a complete closed loop

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: ring-type

Attribute Type: enum (major-ring|sub-ring|sub-ring-vc)

Default Value: major-ring

Netconf edit-config payload

```

<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <erp-instances>
    <erp-instance>
      <name>INSTANCENAME</name>
      <config>
        <name>INSTANCENAME</name>
      </config>
      <ring-type>major-ring</ring-type> <!-- operation="delete"-->
    </erp-instance>
  </erp-instances>
</erpsv2>

```

Command Syntax

```
ring-type (major-ring|sub-ring|sub-ring-vc)
```

Configure enable tcn propagation

Allows topology change notification (TCN) propagation to the ERPS ring if it is enabled

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: enable-tcn-propagation

Attribute Type: empty

Netconf edit-config payload

```

<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <erp-instances>
    <erp-instance>

```

```
<name>INSTANCENAME</name>
<config>
  <name>INSTANCENAME</name>
</config>
</enable-tcn-propagation><!-- operation="delete"-->
</erp-instance>
</erp-instances>
</erpsv2>
```

Command Syntax

```
enable-tcn-propagation
```

Configure tcn to instances

List of Instance that are to be notified when TCN occurs for this instance if topology change notification (TCN) propagation is enabled

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: tcn-to-instances

Attribute Type: string

Attribute Range: 1-255

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
<erp-instances>
<erp-instance>
  <name>INSTANCENAME</name>
  <config>
    <name>INSTANCENAME</name>
  </config>
  <tcn-to-instances>INSTANCENAME</tcn-to-instances> <!-- operation="delete"-->
</erp-instance>
</erp-instances>
</erpsv2>
```

Command Syntax

```
tcn-to-instance INSTANCENAME
```

Configure non virtual channel

Creates a non-virtual channel

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: non-virtual-channel

Attribute Type: empty

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
<erp-instances>
```

```
<erp-instance>
  <name>INSTANCENAME</name>
  <config>
    <name>INSTANCENAME</name>
  </config>
</non-virtual-channel><!-- operation="delete"-->
</erp-instance>
</erp-instances>
</erpsv2>
```

Command Syntax

```
non-virtual-channel
```

Configure ring id

G.8032 ring instance identifier (Ring ID).

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: ring-id

Attribute Type: uint8

Attribute Range: 1-239

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <erp-instances>
    <erp-instance>
      <name>INSTANCENAME</name>
      <config>
        <name>INSTANCENAME</name>
      </config>
      <ring-id>1</ring-id> <!-- operation="delete"-->
    </erp-instance>
  </erp-instances>
</erpsv2>
```

Command Syntax

```
ring-id <1-239>
```

Configure associate ring name

G.8032 ring name to be associate with.

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: associate-ring-name

Attribute Type: string

Attribute Range: 1-255

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <erp-instances>
    <erp-instance>
      <name>INSTANCENAME</name>
      <config>
        <name>INSTANCENAME</name>
      </config>
    <associate-rings>
      <associate-ring> <!-- operation="delete"-->
        <associate-ring-name>RINGNAME</associate-ring-name>
        <config>
          <associate-ring-name>RINGNAME</associate-ring-name>
        </config>
      </associate-ring>
    </associate-rings>
  </erp-instance>
</erp-instances>
</erpsv2>
```

Command Syntax

```
associate-ring RINGNAME
```

Configure owner port id

This identifies the ring port for which role is configured

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: owner-port-id

Attribute Type: enum (east-interface|west-interface)

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <erp-instances>
    <erp-instance>
      <name>INSTANCENAME</name>
      <config>
        <name>INSTANCENAME</name>
      </config>
    <instance-role>
      <config>
        <owner-port-id>east-interface</owner-port-id> <!-- operation="delete"-->
      </config>
    </instance-role>
  </erp-instance>
</erp-instances>
</erpsv2>
```

Command Syntax

```
rpl role owner (east-interface|west-interface)
```

Configure neighbor port id

This identifies the ring port for which role is configured

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: neighbor-port-id

Attribute Type: enum (east-interface|west-interface)

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <erp-instances>
    <erp-instance>
      <name>INSTANCENAME</name>
      <config>
        <name>INSTANCENAME</name>
      </config>
    <instance-role>
      <config>
        <neighbor-port-id>east-interface</neighbor-port-id> <!-- operation="delete"-->
      </config>
    </instance-role>
  </erp-instance>
</erp-instances>
</erpsv2>
```

Command Syntax

```
rpl role neighbor (east-interface|west-interface)
```

Configure next neighbor port id

This identifies the ring port for which role is configured

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: next-neighbor-port-id

Attribute Type: enum (east-interface|west-interface)

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <erp-instances>
    <erp-instance>
      <name>INSTANCENAME</name>
      <config>
        <name>INSTANCENAME</name>
      </config>
    <instance-role>
```

```
<config>
  <next-neighbor-port-id>east-interface</next-neighbor-port-id> <!--
operation="delete"-->
</config>
</instance-role>
</erp-instance>
</erp-instances>
</erpsv2>
```

Command Syntax

```
rpl role next-neighbor (east-interface|west-interface)
```

Configure non owner

This identifies the ring port for which role is configured

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: non-owner

Attribute Type: empty

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <erp-instances>
    <erp-instance>
      <name>INSTANCENAME</name>
      <config>
        <name>INSTANCENAME</name>
      </config>
    <instance-role>
      <config>
        </non-owner><!-- operation="delete"-->
      </config>
    </instance-role>
  </erp-instance>
</erp-instances>
</erpsv2>
```

Command Syntax

```
rpl role non-owner
```

Configure level

Maintenance Endpoint Level (MEL) at which R-APS PDU is transmitted. All nodes in the ring must be configured with same APS level value.

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: level

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```

<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
<erp-instances>
<erp-instance>
  <name>INSTANCENAME</name>
  <config>
    <name>INSTANCENAME</name>
  </config>
<aps-channel>
<config>
  <level>0</level> <!-- operation="delete"-->
</config>
</aps-channel>
</erp-instance>
</erp-instances>
</erpsv2>

```

Command Syntax

```
aps-channel level <0-7>
```

Configure vlan id

ERPS instance identifier

Attribute Name: name

Attribute Type: string

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 2-4094

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 2-4094

Netconf edit-config payload

```

<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
<erp-instances>
<erp-instance> <!-- operation="delete"-->
  <name>INSTANCENAME</name>
  <config>
    <name>INSTANCENAME</name>
  </config>
<aps-channel-vlans>
<aps-channel-vlan>
  <vlan-id>2</vlan-id>
  <config>
    <inner-vlan-id>2</inner-vlan-id>
  </config>
</aps-channel-vlan>

```

```
</aps-channel-vlans>  
</erp-instance>  
</erp-instances>  
</erpsv2>
```

Command Syntax

```
aps-channel vlan <2-4094> (inner-vlan <2-4094>|)
```

Configure data vlan

List of VLAN-IDs, protected by ring instance. For example '2, 3-7, 9, 10-100' VLAN-IDs MUST not overlap with VLAN-IDs of any other instance of the same ring.

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: data-vlan

Attribute Type: string

Attribute Range: 2-4094

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">  
<erp-instances>  
<erp-instance>  
  <name>INSTANCENAME</name>  
  <config>  
    <name>INSTANCENAME</name>  
  </config>  
<data>  
<config>  
  <data-vlan>VLAN_RANGE</data-vlan> <!-- operation="delete" -->  
</config>  
</data>  
</erp-instance>  
</erp-instances>  
</erpsv2>
```

Command Syntax

```
data vlan VLAN_RANGE
```

Configure attached instance

This parameter specifies the ERPS instance on major ring which allows the RAPS messages of Sub-ring, so RAPS message will be sent to other nodes in the sub-ring

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: attached-instance

Attribute Type: string

Attribute Range: 1-31

Attribute Name: channel-id

Attribute Type: uint16

Attribute Range: 2-4094

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <erp-instances>
    <erp-instance>
      <name>INSTANCENAME</name>
      <config>
        <name>INSTANCENAME</name>
      </config>
    <virtual-channel>
      <config>
        <channel-id>2</channel-id>
        <attached-instance>INSTANCENAME</attached-instance>
      </config>
    </virtual-channel>
  </erp-instance>
</erp-instances>
</erpsv2>
```

Command Syntax

```
virtual-channel (<2-4094>|) attached-to-instance INSTANCENAME
```

Configure options

Supported debug options for G.8032

This command is supported when following feature are enabled ERPS V2 feature

Attribute Name: options

Attribute Type: bits (all|tx|rx|fsm|timers|events|external|hal)

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <debug>
    <config>
      <options>all</options> <!-- operation="delete"-->
    </config>
  </debug>
</erpsv2>
```

Command Syntax

```
debug g8032 (all|tx|rx|fsm|timers|events|external|hal)
```

Configure instance name

This parameter specifies the ERPS instance being configured in the subinterface

This command is supported when following feature are enabled SUBINTERFACE feature,ERPS V2 feature

Attribute Name: instance-name

Attribute Type: union

Netconf edit-config payload

```
<erpsv2 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <subinterfaces>
    <subinterface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <instance-name>ERPSV2_SUBINTERFACE_INSTANCE_TYPE_T</instance-name>
    </subinterface>
  </subinterfaces>
</erpsv2>
```

Command Syntax

```
erps-instance (WORD)
```

g8032 erp-instance (INSTANCENAME|all) (force-switch|manual-switch) (east-interface|west-interface)

Attribute Name: instance-name

Attribute Type: string

Attribute Range: 1-255

Attribute Name: operation

Attribute Type: enum (force-switch|manual-switch)

Attribute Name: port-id

Attribute Type: enum (east-interface|west-interface)

Netconf RPC payload

```
<erpsv2-switch-erp-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <instance-name>INSTANCENAME</instance-name>
  <operation>force-switch</operation>
  <port-id>east-interface</port-id>
</erpsv2-switch-erp-instance>
```

Command Syntax

```
g8032 erp-instance (INSTANCENAME|all) (force-switch|manual-switch) (east-
  interface|west-interface)
```

clear g8032 erp-instance (INSTANCENAME|all)

Attribute Name: instance-name

Attribute Type: string

Attribute Range: 1-255

Netconf RPC payload

```
<erpsv2-clear-ring-erp-instance xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <instance-name>INSTANCENAME</instance-name>
</erpsv2-clear-ring-erp-instance>
```

Command Syntax

```
clear g8032 erp-instance (INSTANCENAME|all)
```

clear g8032 aps-statistics INSTANCENAME

Attribute Name: instance-name

Attribute Type: string

Attribute Range: 1-255

Netconf RPC payload

```
<erpsv2-clear-aps-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <instance-name>INSTANCENAME</instance-name>
</erpsv2-clear-aps-statistics>
```

Command Syntax

```
clear g8032 aps-statistics INSTANCENAME
```

debug g8032 (all|tx|rx|fsm|timers|events|external|hal)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|tx|rx|fsm|timers|events|external|hal)

Netconf RPC payload

```
<erpsv2-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
  <terminal-debug-options>all</terminal-debug-options>
</erpsv2-terminal-debug-on>
```

Command Syntax

```
debug g8032 (all|tx|rx|fsm|timers|events|external|hal)
```

no debug g8032 (all|tx|rx|fsm|timers|events|external|hal)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|tx|rx|fsm|timers|events|external|hal)

Netconf RPC payload

```
<erpsv2-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-erpsv2">
```

```
<terminal-debug-options>all</terminal-debug-options>
</erpsv2-terminal-debug-off>
```

Command Syntax

```
no debug g8032 (all|tx|rx|fsm|timers|events|external|hal)
```

IPI-G8031

Configure eps id

unique ID to identify a EPS Protection Group

This command is supported when following feature are enabled ELPS feature

Attribute Name: eps-id

Attribute Type: uint8

Attribute Range: 1-32

Attribute Name: bridge-id

Attribute Type: string

Attribute Range: 1-128

Netconf edit-config payload

```
<g8031 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
  <instances>
    <instance> <!-- operation="delete"-->
      <eps-id>1</eps-id>
      <config>
        <eps-id>1</eps-id>
        <bridge-id>1</bridge-id>
      </config>
    </instance>
  </instances>
</g8031>
```

Command Syntax

```
g8031 eps-id <1-32> bridge <1-32>
```

Configure working port

port for the working EPS path

This command is supported when following feature are enabled ELPS feature

Attribute Name: working-port

Attribute Type: string

Netconf edit-config payload

```
<g8031 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
```

```

<instances>
<instance>
  <eps-id>1</eps-id>
  <config>
    <eps-id>1</eps-id>
  </config>
  <working-port>IFNAME</working-port> <!-- operation="delete"-->
</instance>
</instances>
</g8031>

```

Command Syntax

```
working-port IFNAME
```

Configure protection port

port for the protection EPS path

This command is supported when following feature are enabled ELPS feature

Attribute Name: protection-port

Attribute Type: string

Netconf edit-config payload

```

<g8031 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
<instances>
<instance>
  <eps-id>1</eps-id>
  <config>
    <eps-id>1</eps-id>
  </config>
  <protection-port>IFNAME</protection-port> <!-- operation="delete"-->
</instance>
</instances>
</g8031>

```

Command Syntax

```
protection-port IFNAME
```

Configure elps instance id

MSTP Instance Identifier

This command is supported when following feature are enabled ELPS feature

Attribute Name: elps-instance-id

Attribute Type: uint8

Attribute Range: 1-63

Netconf edit-config payload

```
<g8031 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
```

```
<instances>
<instance>
  <eps-id>1</eps-id>
  <config>
    <eps-id>1</eps-id>
  </config>
  <elps-instance-id>1</elps-instance-id> <!-- operation="delete"-->
</instance>
</instances>
</g8031>
```

Command Syntax

```
instance <1-63>
```

Configure data vlans

VLAN Identifier

This command is supported when following feature are enabled ELPS feature

Attribute Name: data-vlans

Attribute Type: string

Attribute Range: 2-4094

Netconf edit-config payload

```
<g8031 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
<instances>
<instance>
  <eps-id>1</eps-id>
  <config>
    <eps-id>1</eps-id>
  </config>
  <data-vlans>VLAN_RANGE</data-vlans> <!-- operation="delete"-->
</instance>
</instances>
</g8031>
```

Command Syntax

```
vlan VLAN_RANGE
```

Configure primary vlan

Indicates if the given VLAN is primary VLAN of protection group

This command is supported when following feature are enabled ELPS feature

Attribute Name: primary-vlan

Attribute Type: uint16

Attribute Range: 2-4094

Netconf edit-config payload

```
<g8031 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
  <instances>
    <instance>
      <eps-id>1</eps-id>
      <config>
        <eps-id>1</eps-id>
      </config>
      <primary-vlan>2</primary-vlan> <!-- operation="delete"-->
    </instance>
  </instances>
</g8031>
```

Command Syntax

```
primary-vlan <2-4094>
```

IPI-G8031-ELPS

Configure wait to restore

EPS wait-to-restore timer

Attribute Name: wait-to-restore

Attribute Type: uint16

Attribute Range: 300-720

Netconf edit-config payload

```
<g8031 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
  <instances>
    <instance>
      <eps-id>1</eps-id>
      <config>
        <eps-id>1</eps-id>
      </config>
      <elps>
        <timers>
          <config>
            <wait-to-restore>300</wait-to-restore> <!-- operation="delete"-->
          </config>
        </timers>
      </elps>
    </instance>
  </instances>
</g8031>
```

Command Syntax

```
timer wait-to-restore <300-720>
```

Configure hold off

EPS hold-off timer

Attribute Name: hold-off

Attribute Type: uint8

Attribute Range: 0-10

Netconf edit-config payload

```
<g8031 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
  <instances>
    <instance>
      <eps-id>1</eps-id>
      <config>
        <eps-id>1</eps-id>
      </config>
      <elps>
      <timers>
      <config>
        <hold-off>0</hold-off> <!-- operation="delete"-->
      </config>
    </timers>
  </elps>
</instance>
</instances>
</g8031>
```

Command Syntax

```
timer hold-off-time <0-10>
```

Configure local freeze

Freezes the state of the protection group.

Attribute Name: local-freeze

Attribute Type: empty

Netconf edit-config payload

```
<g8031 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
  <instances>
    <instance>
      <eps-id>1</eps-id>
      <config>
        <eps-id>1</eps-id>
      </config>
      <elps>
      <traffic-switch>
      <config>
        </local-freeze><!-- operation="delete"-->
      </config>
    </instance>
  </instances>
</g8031>
```

```

    </traffic-switch>
  </elps>
</instance>
</instances>
</g8031>

```

Command Syntax

```
local-freeze
```

Configure protection type

protection bridge mode

Attribute Name: protection-type

Attribute Type: enum (one-plus-one-bidirectional|one-plus-one-unidirectional|one-and-one-bidirectional)

Netconf edit-config payload

```

<g8031 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
  <instances>
    <instance>
      <eps-id>1</eps-id>
      <config>
        <eps-id>1</eps-id>
      </config>
      <elps>
        <config>
          <protection-type>one-plus-one-bidirectional</protection-type> <!--
operation="delete"-->
        </config>
      </elps>
    </instance>
  </instances>
</g8031>

```

Command Syntax

```
mode (one-plus-one-bidirectional|one-plus-one-unidirectional|one-and-one-
bidirectional)
```

Configure enable revertive mode

protection restoration mode

Attribute Name: enable-revertive-mode

Attribute Type: empty

Netconf edit-config payload

```

<g8031 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
  <instances>
    <instance>
      <eps-id>1</eps-id>

```

```
<config>
  <eps-id>1</eps-id>
</config>
<elps>
<config>
  </enable-revertive-mode><!-- operation="delete"-->
</config>
</elps>
</instance>
</instances>
</g8031>
```

Command Syntax

```
revertive
```

Configure level identifier

Ethernet Linear Protection switching level

Attribute Name: level-identifier

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```
<g8031 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
<instances>
  <instance>
    <eps-id>1</eps-id>
    <config>
      <eps-id>1</eps-id>
    </config>
    <elps>
    <config>
      <level-identifier>0</level-identifier> <!-- operation="delete"-->
    </config>
    </elps>
  </instance>
</instances>
</g8031>
```

Command Syntax

```
level <0-7>
```

Configure options

Supported debug options for g8031

Attribute Name: options

Attribute Type: bits (all|rx|tx|fsm|events|hal)

Netconf edit-config payload

```
<g8031 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
  <debug>
  <config>
    <options>all</options> <!-- operation="delete"-->
  </config>
</debug>
</g8031>
```

Command Syntax

```
debug g8031 (all|rx|tx|fsm|events|hal)
```

lockout bridge WORD g8031 eps-id <1-32>

Attribute Name: bridge-id

Attribute Type: string

Attribute Name: eps-id

Attribute Type: uint8

Attribute Range: 1-32

Netconf RPC payload

```
<ipi-g8031-elps_g8031-lockout xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
g8031">
  <bridge-id>WORD</bridge-id>
  <eps-id>1</eps-id>
</ipi-g8031-elps_g8031-lockout>
```

Command Syntax

```
lockout bridge WORD g8031 eps-id <1-32>
```

force-switch bridge WORD g8031 eps-id <1-32>

Attribute Name: bridge-id

Attribute Type: string

Attribute Name: eps-id

Attribute Type: uint8

Attribute Range: 1-32

Netconf RPC payload

```
<ipi-g8031-elps_g8031-force-switch xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-g8031">
  <bridge-id>WORD</bridge-id>
  <eps-id>1</eps-id>
</ipi-g8031-elps_g8031-force-switch>
```

Command Syntax

```
force-switch bridge WORD g8031 eps-id <1-32>
```

manual-switch bridge WORD g8031 eps-id <1-32>

Attribute Name: bridge-id

Attribute Type: string

Attribute Name: eps-id

Attribute Type: uint8

Attribute Range: 1-32

Netconf RPC payload

```
<ipi-g8031-elps_g8031-manual-switch xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-g8031">
  <bridge-id>WORD</bridge-id>
  <eps-id>1</eps-id>
</ipi-g8031-elps_g8031-manual-switch>
```

Command Syntax

```
manual-switch bridge WORD g8031 eps-id <1-32>
```

exercise bridge WORD g8031 eps-id <1-32>

Attribute Name: bridge-id

Attribute Type: string

Attribute Name: eps-id

Attribute Type: uint8

Attribute Range: 1-32

Netconf RPC payload

```
<ipi-g8031-elps_g8031-exercise xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
g8031">
  <bridge-id>WORD</bridge-id>
  <eps-id>1</eps-id>
</ipi-g8031-elps_g8031-exercise>
```

Command Syntax

```
exercise bridge WORD g8031 eps-id <1-32>
```

clear bridge WORD g8031 eps-id <1-32>

Attribute Name: bridge-id

Attribute Type: string

Attribute Name: eps-id

Attribute Type: uint8

Attribute Range: 1-32

Netconf RPC payload

```
<ipi-g8031-elps_g8031-clear xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
  <bridge-id>WORD</bridge-id>
  <eps-id>1</eps-id>
</ipi-g8031-elps_g8031-clear>
```

Command Syntax

```
clear bridge WORD g8031 eps-id <1-32>
```

debug g8031 (all|rx|tx|fsm|events|hal)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|rx|tx|fsm|events|hal)

Netconf RPC payload

```
<ipi-g8031-elps_g8031-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
  <terminal-debug-options>all</terminal-debug-options>
</ipi-g8031-elps_g8031-terminal-debug-on>
```

Command Syntax

```
debug g8031 (all|rx|tx|fsm|events|hal)
```

no debug g8031 (all|rx|tx|fsm|events|hal)

Attribute Name: terminal-debug-options

Attribute Type: bits (all|rx|tx|fsm|events|hal)

Netconf RPC payload

```
<ipi-g8031-elps_g8031-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-g8031">
  <terminal-debug-options>all</terminal-debug-options>
</ipi-g8031-elps_g8031-terminal-debug-off>
```

Command Syntax

```
no debug g8031 (all|rx|tx|fsm|events|hal)
```

IPI-CFM

Configure cache enable

This attribute specifies the cache enable

Attribute Name: cache-enable

Attribute Type: uint8

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<global>
<linktrace>
<cache>
<config>
  </cache-enable>
</config>
</cache>
</linktrace>
</global>
</cfm>
```

Command Syntax

```
ethernet cfm traceroute cache
```

Configure cache size

This attribute specifies the cache size

Attribute Name: cache-size

Attribute Type: uint16

Default Value: 100

Attribute Range: 1-4095

Attribute Name: cache-enable

Attribute Type: empty

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<global>
<linktrace>
<cache>
<config>
  </cache-enable><!-- operation="delete"-->
  <cache-size>1</cache-size> <!-- operation="delete"-->
</config>
</cache>
</linktrace>
</global>
</cfm>
```

Command Syntax

```
ethernet cfm traceroute cache size <1-4095>
```

Configure options

This attribute enables debugging for CFM

This command is supported when following feature are enabled CFM feature

Attribute Name: options

Attribute Type: bits (events|rx|tx|loopback|traceroute|all)

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <debug>
  <config>
    <options>events</options> <!-- operation="delete"-->
  </config>
</debug>
</cfm>
```

Command Syntax

```
debug ethernet cfm (events|rx|tx|loopback|traceroute|all)
```

Configure type

Type discriminator for the value union described in the 'md-name' leaf

Attribute Name: type

Attribute Type: enum (no-name|character-string)

Attribute Name: level

Attribute Type: uint8

Attribute Range: 0-7

Attribute Name: mip-creation

Attribute Type: enum (none|default|explicit|static)

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <maintenance-domains>
  <maintenance-domain>
    <md-name>DOMAIN_NAME</md-name>
    <config>
      <md-name>DOMAIN_NAME</md-name>
      <level>0</level>
      <mip-creation>none</mip-creation>
    </config>
    <type>no-name</type>
  </maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
ethernet cfm domain-type (no-name|character-string) domain-name DOMAIN_NAME level
<0-7> (mip-creation (none|default|explicit|static)|)
```

Configure ma name

The value union for the Maintenance Association Name.

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Attribute Name: type

Attribute Type: enum (string|integer|itu-t)

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
<maintenance-domain>
  <md-name>DOMAIN_NAME</md-name>
  <config>
    <md-name>DOMAIN_NAME</md-name>
  </config>
</maintenance-domain>
</maintenance-domains>
<maintenance-associations>
<maintenance-association> <!-- operation="delete"-->
  <ma-name>MA_NAME</ma-name>
  <config>
    <ma-name>MA_NAME</ma-name>
    <type>string</type>
  </config>
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
service ma-type (string|integer|itu-t) ma-name MA_NAME
```

Configure enable rmep auto discovery

This attribute tells whether remote MEPs can be learnt from the peer

Attribute Name: enable-rmep-auto-discovery

Attribute Type: uint8

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
```

```

<maintenance-domain>
  <md-name>DOMAIN_NAME</md-name>
  <config>
    <md-name>DOMAIN_NAME</md-name>
  </config>
<maintenance-associations>
<maintenance-association>
  <ma-name>MA_NAME</ma-name>
  <config>
    <ma-name>MA_NAME</ma-name>
    </enable-rmep-auto-discovery><!-- operation="delete"-->
  </config>
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>

```

Command Syntax

```
rmep auto-discovery enable
```

Configure bridge id

This parameter indicates which bridge this maintenance association will be augmented to.

This command is supported when following feature are enabled CFM feature

Attribute Name: bridge-id

Attribute Type: string

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Netconf edit-config payload

```

<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
<maintenance-domain>
  <md-name>DOMAIN_NAME</md-name>
  <config>
    <md-name>DOMAIN_NAME</md-name>
  </config>
<maintenance-associations>
<maintenance-association>
  <ma-name>MA_NAME</ma-name>
  <config>
    <ma-name>MA_NAME</ma-name>
    <vlan-id>1</vlan-id> <!-- operation="delete"-->
    <bridge-id>1</bridge-id> <!-- operation="delete"-->
  </config>
</maintenance-association>

```

```
</maintenance-associations>  
</maintenance-domain>  
</maintenance-domains>  
</cfm>
```

Command Syntax

```
vlan <1-4095> (bridge <1-32>|)
```

Configure md name

This parameter indicates which bridge this maintenance association will be augmented to.

This command is supported when following feature are enabled CFM feature

Attribute Name: bridge-id

Attribute Type: string

Attribute Name: link-level-ma

Attribute Type: empty

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">  
<maintenance-domains>  
<maintenance-domain>  
  <md-name>DOMAIN_NAME</md-name>  
  <config>  
    <md-name>DOMAIN_NAME</md-name>  
  </config>  
</maintenance-domains>  
<maintenance-associations>  
<maintenance-association>  
  <ma-name>MA_NAME</ma-name>  
  <config>  
    <ma-name>MA_NAME</ma-name>  
    </link-level-ma><!-- operation="delete"-->  
  </config>  
  <bridge-id>1</bridge-id> <!-- operation="delete"-->  
</maintenance-association>  
</maintenance-associations>  
</maintenance-domain>  
</maintenance-domains>  
</cfm>
```

Command Syntax

```
link-level (bridge <1-32>|)
```

Configure mip creation

This parameter indicates whether the management entity can create MIPs for this MA

This command is supported when following feature are enabled CFM feature

Attribute Name: mip-creation

Attribute Type: enum (none|default|explicit|defer)

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
<maintenance-domain>
  <md-name>DOMAIN_NAME</md-name>
  <config>
    <md-name>DOMAIN_NAME</md-name>
  </config>
</maintenance-domain>
</maintenance-domains>
<maintenance-associations>
<maintenance-association>
  <ma-name>MA_NAME</ma-name>
  <config>
    <ma-name>MA_NAME</ma-name>
    <mip-creation>none</mip-creation> <!-- operation="delete"-->
  </config>
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
(mip-creation (none|default|explicit|defer) |)
```

Configure inner vlan id

The inner VLAN ID monitored by this MA

This command is supported when following feature are enabled CFM feature

Attribute Name: inner-vlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Attribute Name: vlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
<maintenance-domain>
  <md-name>DOMAIN_NAME</md-name>
  <config>
    <md-name>DOMAIN_NAME</md-name>
  </config>
</maintenance-domain>
</maintenance-domains>
<maintenance-associations>
<maintenance-association>
```

```
<ma-name>MA_NAME</ma-name>
<config>
  <ma-name>MA_NAME</ma-name>
  <vlan-id>1</vlan-id> <!-- operation="delete"-->
</config>
  <inner-vlan-id>1</inner-vlan-id> <!-- operation="delete"-->
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
vlan <1-4095> (inner-vlan <1-4095>|)
```

Configure link level ma

Use this attribute to set the Service as Link Level MA

This command is supported when following feature are enabled CFM feature

Attribute Name: link-level-ma

Attribute Type: empty

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
<maintenance-domain>
  <md-name>DOMAIN_NAME</md-name>
  <config>
    <md-name>DOMAIN_NAME</md-name>
  </config>
<maintenance-associations>
<maintenance-association>
  <ma-name>MA_NAME</ma-name>
  <config>
    <ma-name>MA_NAME</ma-name>
  </config>
  </link-level-ma><!-- operation="delete"-->
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
link-level
```

Configure mip interface name

A list of static MIPs configured on the specified interfaces

This command is supported when following feature are enabled CFM feature

Attribute Name: mip-interface-name

Attribute Type: string

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <maintenance-domains>
    <maintenance-domain>
      <md-name>DOMAIN_NAME</md-name>
      <config>
        <md-name>DOMAIN_NAME</md-name>
      </config>
    </maintenance-domain>
  </maintenance-domains>
  <maintenance-associations>
    <maintenance-association>
      <ma-name>MA_NAME</ma-name>
      <config>
        <ma-name>MA_NAME</ma-name>
        <mip-interface-name>IFNAME</mip-interface-name> <!-- operation="delete"-->
      </config>
    </maintenance-association>
  </maintenance-associations>
</cfm>
```

Command Syntax

```
ethernet ethernet cfm cfm mip interface IFNAME
```

Configure evpn id

Use this attribute to set the Service as EVPN MA

This command is supported when following feature are enabled CFM feature

Attribute Name: evpn-id

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <maintenance-domains>
    <maintenance-domain>
      <md-name>DOMAIN_NAME</md-name>
      <config>
        <md-name>DOMAIN_NAME</md-name>
      </config>
    </maintenance-domain>
  </maintenance-domains>
</cfm>
```

```
<maintenance-associations>
<maintenance-association>
  <ma-name>MA_NAME</ma-name>
  <config>
    <ma-name>MA_NAME</ma-name>
  </config>
  <evpn-id>1</evpn-id> <!-- operation="delete"-->
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
evpn <1-16777215>
```

Configure vpws vc name

This attribute uniquely identifies a VPWS circuit

This command is supported when following feature are enabled CFM feature

Attribute Name: vpws-vc-name

Attribute Type: string

Attribute Range: 1-30

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
<maintenance-domain>
  <md-name>DOMAIN_NAME</md-name>
  <config>
    <md-name>DOMAIN_NAME</md-name>
  </config>
<maintenance-associations>
<maintenance-association>
  <ma-name>MA_NAME</ma-name>
  <config>
    <ma-name>MA_NAME</ma-name>
  </config>
  <vpws-vc-name>VCNAME</vpws-vc-name> <!-- operation="delete"-->
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
vpws VCNAME
```

Configure ccm interval

The interval between CCM transmissions to be used by all MEPs in the MA

This command is supported when following feature are enabled CFM feature

Attribute Name: ccm-interval

Attribute Type: enum (3ms|10ms|100ms|1s|10s|1min|10min)

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <maintenance-domains>
    <maintenance-domain>
      <md-name>DOMAIN_NAME</md-name>
      <config>
        <md-name>DOMAIN_NAME</md-name>
      </config>
    </maintenance-domain>
  </maintenance-domains>
  <maintenance-associations>
    <maintenance-association>
      <ma-name>MA_NAME</ma-name>
      <config>
        <ma-name>MA_NAME</ma-name>
        <ccm-interval>3ms</ccm-interval> <!-- operation="delete"-->
      </config>
    </maintenance-association>
  </maintenance-associations>
</cfm>
```

Command Syntax

```
cc interval (3ms|10ms|100ms|1s|10s|1min|10min)
```

Configure static rmep identifiers

A list of static remote MEPs in a specified MA.

This command is supported when following feature are enabled CFM feature

Attribute Name: static-rmep-identifiers

Attribute Type: uint16

Attribute Range: 1-8191

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <maintenance-domains>
    <maintenance-domain>
      <md-name>DOMAIN_NAME</md-name>
      <config>
        <md-name>DOMAIN_NAME</md-name>
      </config>
    </maintenance-domain>
  </maintenance-domains>
</cfm>
```

```

<maintenance-associations>
<maintenance-association>
  <ma-name>MA_NAME</ma-name>
  <config>
    <ma-name>MA_NAME</ma-name>
  </config>
  <static-rmep-identifiers>1</static-rmep-identifiers> <!-- operation="delete"-
->
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>

```

Command Syntax

```
mep crosscheck mpid <1-8191>
```

Configure mep id

Integer that is unique among all the MEPs in the same MA. Other definition is: a small integer, unique over a given Maintenance Association, identifying a specific Maintenance association End Point

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: direction

Attribute Type: enum (down|up)

Attribute Name: administrative-state

Attribute Type: enum (false|true)

Attribute Name: interface-name

Attribute Type: string

Netconf edit-config payload

```

<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
<maintenance-domain>
  <md-name>DOMAIN_NAME</md-name>
  <config>
    <md-name>DOMAIN_NAME</md-name>
  </config>
<maintenance-associations>
<maintenance-association>
  <ma-name>MA_NAME</ma-name>
  <config>
    <ma-name>MA_NAME</ma-name>
  </config>
  <maintenance-end-points>
  <maintenance-end-point> <!-- operation="delete"-->

```

```

    <mep-id>1</mep-id>
  <config>
    <mep-id>1</mep-id>
    <direction>down</direction>
    <administrative-state>>false</administrative-state>
    <interface-name>IFNAME</interface-name>
  </config>
</maintenance-end-point>
</maintenance-end-points>
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>

```

Command Syntax

```

ethernet cfm mep (down|up) mpid <1-8191> active (false|true) IFNAME

```

Configure direction

Integer that is unique among all the MEPs in the same MA. Other definition is: a small integer, unique over a given Maintenance Association, identifying a specific Maintenance association End Point

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: direction

Attribute Type: enum (down|up)

Attribute Name: administrative-state

Attribute Type: enum (false|true)

Attribute Name: remote-vpws-vc-name

Attribute Type: string

Attribute Range: 1-30

Netconf edit-config payload

```

<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <maintenance-domains>
    <maintenance-domain>
      <md-name>DOMAIN_NAME</md-name>
      <config>
        <md-name>DOMAIN_NAME</md-name>
      </config>
    </maintenance-domain>
  </maintenance-domains>
  <maintenance-associations>
    <maintenance-association>
      <ma-name>MA_NAME</ma-name>
      <config>
        <ma-name>MA_NAME</ma-name>
      </config>
    </maintenance-association>
  </maintenance-associations>
</cfm>

```

```
</config>
<maintenance-end-points>
<maintenance-end-point> <!-- operation="delete"-->
  <mep-id>1</mep-id>
  <config>
    <mep-id>1</mep-id>
    <direction>down</direction>
    <administrative-state>>false</administrative-state>
    <remote-vpws-vc-name>VCNAME</remote-vpws-vc-name>
  </config>
</maintenance-end-point>
</maintenance-end-points>
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
ethernet cfm mep (down|up) mpid <1-8191> active (false|true) vpws VCNAME
```

Configure administrative state

Integer that is unique among all the MEPs in the same MA. Other definition is: a small integer, unique over a given Maintenance Association, identifying a specific Maintenance association End Point

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: direction

Attribute Type: enum (down|up)

Attribute Name: administrative-state

Attribute Type: enum (false|true)

Attribute Name: remote-evpn-id

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
<maintenance-domain>
  <md-name>DOMAIN_NAME</md-name>
  <config>
    <md-name>DOMAIN_NAME</md-name>
  </config>
</maintenance-associations>
<maintenance-association>
```

```

<ma-name>MA_NAME</ma-name>
<config>
  <ma-name>MA_NAME</ma-name>
</config>
<maintenance-end-points>
<maintenance-end-point> <!-- operation="delete"-->
  <mep-id>1</mep-id>
  <config>
    <mep-id>1</mep-id>
    <direction>down</direction>
    <administrative-state>>false</administrative-state>
    <remote-evpn-id>1</remote-evpn-id>
  </config>
</maintenance-end-point>
</maintenance-end-points>
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>

```

Command Syntax

```
ethernet cfm mep (down|up) mpid <1-8191> active (false|true) evpn <1-16777215>
```

Configure bw mapped interface

This attribute specifies interface where the bandwidth shapers are to be applied

This command is supported when following feature are enabled CFM feature

Attribute Name: bw-mapped-interface

Attribute Type: string

Netconf edit-config payload

```

<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
<maintenance-domain>
  <md-name>DOMAIN_NAME</md-name>
  <config>
    <md-name>DOMAIN_NAME</md-name>
  </config>
</maintenance-domain>
</maintenance-domains>
<maintenance-associations>
<maintenance-association>
  <ma-name>MA_NAME</ma-name>
  <config>
    <ma-name>MA_NAME</ma-name>
  </config>
</maintenance-association>
</maintenance-associations>
<maintenance-end-points>
<maintenance-end-point>
  <mep-id>1</mep-id>
  <config>

```

```
        <mep-id>1</mep-id>
    </config>
    <bw-mapped-interface>IFNAME</bw-mapped-interface> <!--
operation="delete"-->
    </maintenance-end-point>
</maintenance-end-points>
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
bw-mapped-interface IFNAME
```

Configure enable cc multicast

Integer that is unique among all the MEPs in the same MA. Other definition is: a small integer, unique over a given Maintenance Association, identifying a specific Maintenance association End Point

Attribute Name: mep-id

Attribute Type: uint16

Attribute Name: enable-cc-multicast

Attribute Type: empty

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
<maintenance-domain>
    <md-name>DOMAIN_NAME</md-name>
    <config>
        <md-name>DOMAIN_NAME</md-name>
    </config>
<maintenance-associations>
<maintenance-association>
    <ma-name>MA_NAME</ma-name>
    <config>
        <ma-name>MA_NAME</ma-name>
    </config>
<maintenance-end-points>
<maintenance-end-point>
    <mep-id>1</mep-id>
    <config>
        <mep-id>1</mep-id>
    </config>
    <continuity-check>
    <config>
        </enable-cc-multicast>
    </config>
</continuity-check>
```

```

</maintenance-end-point>
</maintenance-end-points>
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>

```

Command Syntax

```
cc multicast state enable
```

Configure lowest fault priority defect

The lowest priority defect that is allowed to generate a Fault Alarm. The non-existence of this leaf means that no defects are to be reported

This command is supported when following feature are enabled CFM feature

Attribute Name: lowest-fault-priority-defect

Attribute Type: enum (defRDICCM|defMACstatus|defRemoteCCM|defErrorCCM|defXconCCM)

Default Value: defMACstatus

Netconf edit-config payload

```

<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
<maintenance-domain>
  <md-name>DOMAIN_NAME</md-name>
  <config>
    <md-name>DOMAIN_NAME</md-name>
  </config>
</maintenance-domains>
<maintenance-associations>
<maintenance-association>
  <ma-name>MA_NAME</ma-name>
  <config>
    <ma-name>MA_NAME</ma-name>
  </config>
</maintenance-association>
<maintenance-end-points>
<maintenance-end-point>
  <mep-id>1</mep-id>
  <config>
    <mep-id>1</mep-id>
    </config>
    <continuity-check>
    <config>
      <lowest-fault-priority-defect>defMACstatus</lowest-fault-priority-
defect> <!-- operation="delete"-->
    </config>
    </continuity-check>
  </maintenance-end-point>
</maintenance-end-points>
</maintenance-association>

```

```
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
mep lowest-priority-defect
(defRDICCM|defMACstatus|defRemoteCCM|defErrorCCM|defXconCCM)
```

clear ethernet cfm maintenance-points remote domain DOMAIN_NAME

Attribute Name: domain-name

Attribute Type: string

Netconf RPC payload

```
<cfm-l2-clear-ethernet-remote-meps xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-cfm">
  <domain-name>DOMAIN_NAME</domain-name>
</cfm-l2-clear-ethernet-remote-meps>
```

Command Syntax

```
clear ethernet cfm maintenance-points remote domain DOMAIN_NAME
```

clear ethernet cfm statistics

Netconf RPC payload

```
<cfm-clear-all-mep-stats xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm"/>
```

Command Syntax

```
clear ethernet cfm statistics
```

clear ethernet cfm statistics mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: domain-name

Attribute Type: string

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<cfm-l2-clear-mep-stats xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
```



```
<mep-id>1</mep-id>
<domain-name>DOMAIN_NAME</domain-name>
<ma-name>MA_NAME</ma-name>
</cfm-l2-clear-mep-stats>
```

Command Syntax

```
clear ethernet cfm statistics mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

cfm snmp restart

Netconf RPC payload

```
<cfm-snmp-restart xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm"/>
```

Command Syntax

```
cfm snmp restart
```

debug ethernet cfm (events|rx|tx|loopback|traceroute|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (events|rx|tx|loopback|traceroute|all)

Netconf RPC payload

```
<cfm-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<terminal-debug-options>events</terminal-debug-options>
</cfm-terminal-debug-on>
```

Command Syntax

```
debug ethernet cfm (events|rx|tx|loopback|traceroute|all)
```

no debug ethernet cfm (events|rx|tx|loopback|traceroute|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (events|rx|tx|loopback|traceroute|all)

Netconf RPC payload

```
<cfm-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<terminal-debug-options>events</terminal-debug-options>
</cfm-terminal-debug-off>
```

Command Syntax

```
no debug ethernet cfm (events|rx|tx|loopback|traceroute|all)
```

clear ethernet cfm traceroute-cache

Netconf RPC payload

```
<cfm-l2-clear-linktrace-cache xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm"/>
```

Command Syntax

```
clear ethernet cfm traceroute-cache
```

IPI-CFM-Y1731

Configure enable receive

A unique identifier of a Maintenance Domain

Attribute Name: md-name

Attribute Type: string

Attribute Name: ma-name

Attribute Type: string

Attribute Name: mep-id

Attribute Type: uint16

Attribute Name: enable-receive

Attribute Type: uint8

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <maintenance-domains>
    <maintenance-domain> <!-- operation="delete"-->
      <md-name>DOMAIN_NAME</md-name>
      <config>
        <md-name>DOMAIN_NAME</md-name>
      </config>
    </maintenance-domain>
  </maintenance-domains>
  <maintenance-associations>
    <maintenance-association>
      <ma-name>MA_NAME</ma-name>
      <maintenance-end-points>
        <maintenance-end-point>
          <mep-id>1</mep-id>
          <ethernet-bandwidth-notification>
            <config>
              </enable-receive>
            </config>
          </ethernet-bandwidth-notification>
        </maintenance-end-point>
      </maintenance-end-points>
    </maintenance-association>
  </maintenance-associations>
</cfm>
```

Command Syntax

```
bn receive
```

Configure wait to restore timer

This attribute sets the time to wait before nominal bandwidth is set

This command is supported when following feature are enabled Broadcom DUNE platform specific features,CFM Y1731 feature

Attribute Name: wait-to-restore-timer

Attribute Type: uint32

Default Value: 10

Attribute Range: 0-86400

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <maintenance-domains>
    <maintenance-domain>
      <md-name>DOMAIN_NAME</md-name>
      <config>
        <md-name>DOMAIN_NAME</md-name>
      </config>
      <maintenance-associations>
        <maintenance-association>
          <ma-name>MA_NAME</ma-name>
          <config>
            <ma-name>MA_NAME</ma-name>
          </config>
          <maintenance-end-points>
            <maintenance-end-point>
              <mep-id>1</mep-id>
              <config>
                <mep-id>1</mep-id>
              </config>
              <ethernet-bandwidth-notification>
                <config>
                  <wait-to-restore-timer>0</wait-to-restore-timer> <!--
operation="delete"-->
                </config>
              </ethernet-bandwidth-notification>
            </maintenance-end-point>
          </maintenance-end-points>
        </maintenance-association>
      </maintenance-associations>
    </maintenance-domain>
  </maintenance-domains>
</cfm>
```

Command Syntax

```
wait-to-restore-timer <0-86400>
```

Configure peer port id

This attribute sets the peer port id used to map the received ETH-BN frame

This command is supported when following feature are enabled Broadcom DUNE platform specific features,CFM Y1731 feature

Attribute Name: peer-port-id

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
  <maintenance-domain>
    <md-name>DOMAIN_NAME</md-name>
    <config>
      <md-name>DOMAIN_NAME</md-name>
    </config>
    <maintenance-associations>
      <maintenance-association>
        <ma-name>MA_NAME</ma-name>
        <config>
          <ma-name>MA_NAME</ma-name>
        </config>
        <maintenance-end-points>
          <maintenance-end-point>
            <mep-id>1</mep-id>
            <config>
              <mep-id>1</mep-id>
            </config>
            <ethernet-bandwidth-notification>
              <config>
                <peer-port-id>1</peer-port-id> <!-- operation="delete"-->
              </config>
            </ethernet-bandwidth-notification>
          </maintenance-end-point>
        </maintenance-end-points>
      </maintenance-association>
    </maintenance-associations>
  </maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
peer-port-id <1-4294967295>
```

Configure md name

This attribute sets the time to wait before nominal bandwidth is set

This command is supported when following feature are enabled Broadcom DUNE platform specific features,CFM Y1731 feature

Attribute Name: wait-to-restore-timer

Attribute Type: uint32

Default Value: 10

Attribute Range: 0-86400

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <maintenance-domains>
    <maintenance-domain>
      <md-name>DOMAIN_NAME</md-name>
      <config>
        <md-name>DOMAIN_NAME</md-name>
      </config>
      <maintenance-associations>
        <maintenance-association>
          <ma-name>MA_NAME</ma-name>
          <config>
            <ma-name>MA_NAME</ma-name>
          </config>
          <maintenance-end-points>
            <maintenance-end-point>
              <mep-id>1</mep-id>
              <config>
                <mep-id>1</mep-id>
              </config>
              <ethernet-client-signal-fail>
                <config>
                  <wait-to-restore-timer>0</wait-to-restore-timer> <!--
operation="delete"-->
                </config>
              </ethernet-client-signal-fail>
            </maintenance-end-point>
          </maintenance-end-points>
        </maintenance-association>
      </maintenance-associations>
    </maintenance-domain>
  </maintenance-domains>
</cfm>
```

Command Syntax

```
wait-to-restore-timer <0-86400>
```

Configure lock state

This attribute specifies the locking state

Attribute Name: lock-state

Attribute Type: enum (unlock|lock)

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <maintenance-domains>
    <maintenance-domain>
      <md-name>DOMAIN_NAME</md-name>
      <config>
        <md-name>DOMAIN_NAME</md-name>
      </config>
      <maintenance-associations>
        <maintenance-association>
          <ma-name>MA_NAME</ma-name>
          <config>
            <ma-name>MA_NAME</ma-name>
          </config>
          <maintenance-end-points>
            <maintenance-end-point>
              <mep-id>1</mep-id>
              <config>
                <mep-id>1</mep-id>
              </config>
              <ethernet-locked-signal>
                <config>
                  <lock-state>unlock</lock-state>
                </config>
              </ethernet-locked-signal>
            </maintenance-end-point>
          </maintenance-end-points>
        </maintenance-association>
      </maintenance-associations>
    </maintenance-domain>
  </maintenance-domains>
</cfm>
```

Command Syntax

```
lck state (unlock|lock)
```

Configure client md level

The Maintenance Domain Level of the Client LCK PDU (transmitted level)

This command is supported when following feature are enabled Broadcom DUNE platform specific features,CFM Y1731 feature

Attribute Name: client-md-level

Attribute Type: uint8

Default Value: 0

Attribute Range: 0-7

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
  <maintenance-domain>
    <md-name>DOMAIN_NAME</md-name>
    <config>
      <md-name>DOMAIN_NAME</md-name>
    </config>
    <maintenance-associations>
      <maintenance-association>
        <ma-name>MA_NAME</ma-name>
        <config>
          <ma-name>MA_NAME</ma-name>
        </config>
        <maintenance-end-points>
          <maintenance-end-point>
            <mep-id>1</mep-id>
            <config>
              <mep-id>1</mep-id>
            </config>
            <ethernet-locked-signal>
              <config>
                <client-md-level>0</client-md-level> <!--
operation="delete"-->
              </config>
            </ethernet-locked-signal>
          </maintenance-end-point>
        </maintenance-end-points>
      </maintenance-association>
    </maintenance-associations>
  </maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
message level <0-7>
```

Configure interval

This attribute specifies the ETH-LCK transmission period

This command is supported when following feature are enabled Broadcom DUNE platform specific features,CFM Y1731 feature

Attribute Name: interval

Attribute Type: enum (1s|1min)

Default Value: 1s

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
  <maintenance-domain>
    <md-name>DOMAIN_NAME</md-name>
    <config>
      <md-name>DOMAIN_NAME</md-name>
    </config>
    <maintenance-associations>
      <maintenance-association>
        <ma-name>MA_NAME</ma-name>
        <config>
          <ma-name>MA_NAME</ma-name>
        </config>
        <maintenance-end-points>
          <maintenance-end-point>
            <mep-id>1</mep-id>
            <config>
              <mep-id>1</mep-id>
            </config>
            <ethernet-locked-signal>
              <config>
                <interval>1s</interval> <!-- operation="delete"-->
              </config>
            </ethernet-locked-signal>
          </maintenance-end-point>
        </maintenance-end-points>
      </maintenance-association>
    </maintenance-associations>
  </maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
interval (1s|1min)
```

Configure priority

This attribute specifies the priority of frames with ETH-LCK information

This command is supported when following feature are enabled Broadcom DUNE platform specific features,CFM Y1731 feature

Attribute Name: priority

Attribute Type: uint8

Default Value: 3

Attribute Range: 0-7

Netconf edit-config payload

```

<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
  <maintenance-domain>
    <md-name>DOMAIN_NAME</md-name>
    <config>
      <md-name>DOMAIN_NAME</md-name>
    </config>
    <maintenance-associations>
      <maintenance-association>
        <ma-name>MA_NAME</ma-name>
        <config>
          <ma-name>MA_NAME</ma-name>
        </config>
        <maintenance-end-points>
          <maintenance-end-point>
            <mep-id>1</mep-id>
            <config>
              <mep-id>1</mep-id>
            </config>
            <ethernet-locked-signal>
            <config>
              <priority>0</priority> <!-- operation="delete"-->
            </config>
            </ethernet-locked-signal>
          </maintenance-end-point>
        </maintenance-end-points>
      </maintenance-association>
    </maintenance-associations>
  </maintenance-domain>
</maintenance-domains>
</cfm>

```

Command Syntax

```
frame priority <0-7>
```

Configure enable status

This attribute specifies whether ETH-AIS transmission is enabled

Attribute Name: enable-status

Attribute Type: uint8

Attribute Name: client-md-level

Attribute Type: uint8

Attribute Range: 0-7

Netconf edit-config payload

```

<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>

```

```
<maintenance-domain>
  <md-name>DOMAIN_NAME</md-name>
  <config>
    <md-name>DOMAIN_NAME</md-name>
  </config>
  <maintenance-associations>
    <maintenance-association>
      <ma-name>MA_NAME</ma-name>
      <config>
        <ma-name>MA_NAME</ma-name>
      </config>
      <maintenance-end-points>
        <maintenance-end-point>
          <mep-id>1</mep-id>
          <config>
            <mep-id>1</mep-id>
          </config>
          <ethernet-alarm-indication-signal>
            <config>
              <client-md-level>0</client-md-level>
              </enable-status>
            </config>
          </ethernet-alarm-indication-signal>
        </maintenance-end-point>
      </maintenance-end-points>
    </maintenance-association>
  </maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
ais status enable level <0-7>
```

Configure ma name

This attribute specifies the ETH-AIS transmission period

This command is supported when following feature are enabled CFM Y1731 feature

Attribute Name: interval

Attribute Type: enum (1s|1min)

Default Value: 1s

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <maintenance-domains>
    <maintenance-domain>
      <md-name>DOMAIN_NAME</md-name>
      <config>
```

```

    <md-name>DOMAIN_NAME</md-name>
  </config>
  <maintenance-associations>
    <maintenance-association>
      <ma-name>MA_NAME</ma-name>
      <config>
        <ma-name>MA_NAME</ma-name>
      </config>
      <maintenance-end-points>
        <maintenance-end-point>
          <mep-id>1</mep-id>
          <config>
            <mep-id>1</mep-id>
          </config>
          <ethernet-alarm-indication-signal>
            <config>
              <interval>1s</interval> <!-- operation="delete"-->
            </config>
          </ethernet-alarm-indication-signal>
        </maintenance-end-point>
      </maintenance-end-points>
    </maintenance-association>
  </maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>

```

Command Syntax

```
ais interval (1s|1min)
```

Configure enable lm responder

Enable the MEP to respond for each Loss Measurement Message(LMM)

This command is supported when following feature are enabled CFM Y1731 feature

Attribute Name: enable-lm-responder

Attribute Type: enum (lmm|slm)

Default Value: slm

Netconf edit-config payload

```

<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <maintenance-domains>
    <maintenance-domain>
      <md-name>DOMAIN_NAME</md-name>
      <config>
        <md-name>DOMAIN_NAME</md-name>
      </config>
      <maintenance-associations>
        <maintenance-association>

```

```
<ma-name>MA_NAME</ma-name>
<config>
  <ma-name>MA_NAME</ma-name>
</config>
<maintenance-end-points>
  <maintenance-end-point>
    <mep-id>1</mep-id>
    <config>
      <mep-id>1</mep-id>
    </config>
    <y1731-responders>
      <config>
        <enable-lm-responder>slm</enable-lm-responder> <!--
operation="delete"-->
      </config>
    </y1731-responders>
  </maintenance-end-point>
</maintenance-end-points>
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>
```

Command Syntax

```
ethernet cfm loss-measurement reply (lmm|slm)
```

Configure enable dm responder

Enable the MEP to respond with Delay Measurement Reply(DMR) for each Delay Measurement Message(DMM) of the peer

This command is supported when following feature are enabled CFM Y1731 feature

Attribute Name: enable-dm-responder

Attribute Type: empty

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<maintenance-domains>
  <maintenance-domain>
    <md-name>DOMAIN_NAME</md-name>
    <config>
      <md-name>DOMAIN_NAME</md-name>
    </config>
  <maintenance-associations>
    <maintenance-association>
      <ma-name>MA_NAME</ma-name>
      <config>
        <ma-name>MA_NAME</ma-name>
      </config>
    </maintenance-association>
  </maintenance-associations>
</maintenance-domains>
</cfm>
```

```

    <maintenance-end-points>
      <maintenance-end-point>
        <mep-id>1</mep-id>
        <config>
          <mep-id>1</mep-id>
        </config>
        <y1731-responders>
        <config>
          </enable-dm-responder><!-- operation="delete"-->
        </config>
      </y1731-responders>
    </maintenance-end-point>
  </maintenance-end-points>
</maintenance-association>
</maintenance-associations>
</maintenance-domain>
</maintenance-domains>
</cfm>

```

Command Syntax

```
ethernet cfm delay-measurement reply dmm
```

Configure profile name

This attribute contains the profile name for the ETH-TST Session

This command is supported when following feature are enabled Broadcom DUNE platform specific features,CFM Y1731 Packets generated from hardware

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```

<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <ethernet-test-signal-profiles>
  <ethernet-test-signal-profile> <!-- operation="delete"-->
    <profile-name>WORD</profile-name>
    <config>
      <profile-name>WORD</profile-name>
    </config>
  </ethernet-test-signal-profile>
</ethernet-test-signal-profiles>
</cfm>

```

Command Syntax

```
ethernet cfm test-signal profile-name WORD
```

Configure mode

This attribute indicates the MEP is acting in the role of a generator or receiver or both

This command is supported when following feature are enabled Broadcom DUNE platform specific features,CFM Y1731 Packets generated from hardware

Attribute Name: mode

Attribute Type: enum (generator|receiver|both)

Default Value: receiver

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<ethernet-test-signal-profiles>
<ethernet-test-signal-profile>
  <profile-name>WORD</profile-name>
  <config>
    <profile-name>WORD</profile-name>
  </config>
  <mode>receiver</mode> <!-- operation="delete"-->
</ethernet-test-signal-profile>
</ethernet-test-signal-profiles>
</cfm>
```

Command Syntax

```
mode (generator|receiver|both)
```

Configure test type

This attribute specifies whether it is service interrupting or not

This command is supported when following feature are enabled Broadcom DUNE platform specific features,CFM Y1731 Packets generated from hardware

Attribute Name: test-type

Attribute Type: enum (in-service|out-of-service)

Default Value: in-service

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<ethernet-test-signal-profiles>
<ethernet-test-signal-profile>
  <profile-name>WORD</profile-name>
  <config>
    <profile-name>WORD</profile-name>
  </config>
  <test-type>in-service</test-type> <!-- operation="delete"-->
</ethernet-test-signal-profile>
</ethernet-test-signal-profiles>
</cfm>
```

Command Syntax

```
test-type (in-service|out-of-service)
```

Configure frame size

This attribute specifies the ETH-Test Ethernet frame size between 68 bytes and the maximum transmission unit of the EVC

This command is supported when following feature are enabled Broadcom DUNE platform specific features,CFM Y1731 Packets generated from hardware

Attribute Name: frame-size

Attribute Type: uint32

Default Value: 68

Attribute Range: 68-9600

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<ethernet-test-signal-profiles>
<ethernet-test-signal-profile>
  <profile-name>WORD</profile-name>
  <config>
    <profile-name>WORD</profile-name>
  </config>
  <frame-size>68</frame-size> <!-- operation="delete"-->
</ethernet-test-signal-profile>
</ethernet-test-signal-profiles>
</cfm>
```

Command Syntax

```
frame-size <68-9600>
```

Configure pattern type

This attribute specifies an arbitrary element to include in the Data TLV

This command is supported when following feature are enabled Broadcom DUNE platform specific features,CFM Y1731 Packets generated from hardware

Attribute Name: pattern-type

Attribute Type: enum (null-sig|null-sig-crc32|prbs|prbs-crc32)

Default Value: null-sig

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<ethernet-test-signal-profiles>
<ethernet-test-signal-profile>
  <profile-name>WORD</profile-name>
  <config>
    <profile-name>WORD</profile-name>
  </config>
</ethernet-test-signal-profile>
</ethernet-test-signal-profiles>
</cfm>
```

```
</config>
  <pattern-type>null-sig</pattern-type> <!-- operation="delete"-->
</ethernet-test-signal-profile>
</ethernet-test-signal-profiles>
</cfm>
```

Command Syntax

```
pattern-type (null-sig|null-sig-crc32|prbs|prbs-crc32)
```

Configure message period

This attribute specifies the message period for the SOAM LM Session

Attribute Name: message-period

Attribute Type: enum (3ms|10ms|100ms|1s|10s|1min|10min)

Default Value: 1s

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<ethernet-loss-measurement-profiles>
<ethernet-loss-measurement-profile>
  <profile-name>WORD</profile-name>
  <config>
    <profile-name>WORD</profile-name>
  </config>
  <message-period>1s</message-period> <!-- operation="delete"-->
</ethernet-loss-measurement-profile>
</ethernet-loss-measurement-profiles>
</cfm>
```

Command Syntax

```
message-period (100ms|1s|10s)
```

Configure measurement type

This attribute specifies the measurement type for the SOAM LM Session

This command is supported when following feature are enabled CFM Y1731 feature

Attribute Name: measurement-type

Attribute Type: enum (lmm|slm|ccm)

Default Value: slm

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<ethernet-loss-measurement-profiles>
<ethernet-loss-measurement-profile>
  <profile-name>WORD</profile-name>
  <config>
    <profile-name>WORD</profile-name>
  </config>
  <profile-name>WORD</profile-name>
</ethernet-loss-measurement-profile>
</ethernet-loss-measurement-profiles>
</cfm>
```



```

    </config>
      <measurement-type>slm</measurement-type> <!-- operation="delete"-->
</ethernet-loss-measurement-profile>
</ethernet-loss-measurement-profiles>
</cfm>

```

Command Syntax

```
measurement-type (lmm|slm|ccm)
```

Configure measurement interval

This attribute specifies the measurement interval for the SOAM LM Session

This command is supported when following feature are enabled CFM Y1731 feature

Attribute Name: measurement-interval

Attribute Type: uint32

Default Value: 15

Attribute Range: 1-525600

Netconf edit-config payload

```

<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<ethernet-loss-measurement-profiles>
<ethernet-loss-measurement-profile>
  <profile-name>WORD</profile-name>
  <config>
    <profile-name>WORD</profile-name>
  </config>
  <measurement-interval>1</measurement-interval> <!-- operation="delete"-->
</ethernet-loss-measurement-profile>
</ethernet-loss-measurement-profiles>
</cfm>

```

Command Syntax

```
measurement-interval <1-525600>
```

Configure intervals stored

This attribute specifies the stored interval for the SOAM LM Session

This command is supported when following feature are enabled CFM Y1731 feature

Attribute Name: intervals-stored

Attribute Type: uint16

Default Value: 32

Attribute Range: 2-1000

Netconf edit-config payload

```

<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<ethernet-loss-measurement-profiles>

```

```
<ethernet-loss-measurement-profile>
  <profile-name>WORD</profile-name>
  <config>
    <profile-name>WORD</profile-name>
  </config>
  <intervals-stored>2</intervals-stored> <!-- operation="delete"-->
</ethernet-loss-measurement-profile>
</ethernet-loss-measurement-profiles>
</cfm>
```

Command Syntax

```
intervals-stored <2-1000>
```

Configure bins per fd interval

This attribute specifies the bins per fd interval for the SOAM DM Session

This command is supported when following feature are enabled CFM Y1731 feature

Attribute Name: bins-per-fd-interval

Attribute Type: uint8

Default Value: 3

Attribute Range: 2-10

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <ethernet-delay-measurement-profiles>
  <ethernet-delay-measurement-profile>
    <profile-name>WORD</profile-name>
    <config>
      <profile-name>WORD</profile-name>
    </config>
    <bins-per-fd-interval>2</bins-per-fd-interval> <!-- operation="delete"-->
  </ethernet-delay-measurement-profile>
</ethernet-delay-measurement-profiles>
</cfm>
```

Command Syntax

```
bins-per-fd-interval <2-10>
```

Configure bins per ifdv interval

This attribute specifies the bins per ifdv interval for the SOAM DM Session

This command is supported when following feature are enabled CFM Y1731 feature

Attribute Name: bins-per-ifdv-interval

Attribute Type: uint8

Default Value: 2

Attribute Range: 2-10

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<ethernet-delay-measurement-profiles>
<ethernet-delay-measurement-profile>
  <profile-name>WORD</profile-name>
  <config>
    <profile-name>WORD</profile-name>
  </config>
  <bins-per-ifdv-interval>2</bins-per-ifdv-interval> <!-- operation="delete"-->
</ethernet-delay-measurement-profile>
</ethernet-delay-measurement-profiles>
</cfm>
```

Command Syntax

```
bins-per-ifdv-interval <2-10>
```

Configure bin number

This object specifies the bin number for the configured boundary

This command is supported when following feature are enabled CFM Y1731 feature

Attribute Name: bin-number

Attribute Type: uint8

Attribute Range: 2-10

Attribute Name: threshold

Attribute Type: uint32

Attribute Range: 1-4294967294

Netconf edit-config payload

```
<cfm xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
<ethernet-delay-measurement-profiles>
<ethernet-delay-measurement-profile>
  <profile-name>WORD</profile-name>
  <config>
    <profile-name>WORD</profile-name>
  </config>
  <bin-thresholds>
<bin-threshold> <!-- operation="delete"-->
  <bin-number>2</bin-number>
  <config>
    <bin-number>2</bin-number>
    <type>frame-delay</type>
    <threshold>1</threshold>
  </config>
  <type>frame-delay</type>
</bin-threshold>
</bin-thresholds>
</ethernet-delay-measurement-profile>
```

```
</ethernet-delay-measurement-profiles>
</cfm>
```

Command Syntax

```
bin-type (frame-delay|inter-frame-delay-variation) bin <2-10> threshold <1-4294967294>
```

abort test-signal domain DOMAIN_NAME ma MA_NAME mep <1-8191>

Attribute Name: domain-name

Attribute Type: string

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-abort-eth-test-signal xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-cfm">
  <domain-name>DOMAIN_NAME</domain-name>
  <ma-name>MA_NAME</ma-name>
  <mep-id>1</mep-id>
</ipi-cfm-y1731_cfm-l2-abort-eth-test-signal>
```

Command Syntax

```
abort test-signal domain DOMAIN_NAME ma MA_NAME mep <1-8191>
```

test-signal start-time (relative) <0-4294967295> stop-time (relative) <0-4294967295> tst-profile-name WORD domain DOMAIN_NAME ma MA_NAME mep <1-8191> target (mac-address MAC|<1-8191>)

Attribute Name: start-time-type

Attribute Type: enum (relative)

Attribute Name: start-time

Attribute Type: uint32

Attribute Range: 0-4294967295

Attribute Name: stop-time-type

Attribute Type: enum (relative)

Attribute Name: stop-time

Attribute Type: uint32

Attribute Range: 0-4294967295

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 1-64

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: test-target

Attribute Type: union

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-test-on-demand-start-relative-stop-relative
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <start-time-type>relative</start-time-type>
  <start-time>0</start-time>
  <stop-time-type>relative</stop-time-type>
  <stop-time>0</stop-time>
  <profile-name>WORD</profile-name>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
  <mep-id>1</mep-id>
  <test-target>CFM_RMEP_TYPE_T</test-target>
</ipi-cfm-y1731_cfm-l2-eth-test-on-demand-start-relative-stop-relative>
```

Command Syntax

```
test-signal start-time (relative) <0-4294967295> stop-time (relative) <0-
4294967295> tst-profile-name WORD domain DOMAIN_NAME ma MA_NAME mep <1-8191>
target (mac-address MAC|<1-8191>)
```

test-signal start-time (absolute) START-TIME stop-time (relative) <0-4294967295> tst-profile-name WORD domain DOMAIN_NAME ma MA_NAME mep <1-8191> target (mac-address MAC|<1-8191>)

Attribute Name: start-time-type

Attribute Type: enum (absolute)

Attribute Name: start-time

Attribute Type: string

Attribute Name: stop-time-type

Attribute Type: enum (relative)

Attribute Name: stop-time

Attribute Type: uint32

Attribute Range: 0-4294967295

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 1-64

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: test-target

Attribute Type: union

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-test-on-demand-start-absolute-stop-relative
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <start-time-type>absolute</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>relative</stop-time-type>
  <stop-time>0</stop-time>
  <profile-name>WORD</profile-name>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
  <mep-id>1</mep-id>
  <test-target>CFM_RMEP_TYPE_T</test-target>
</ipi-cfm-y1731_cfm-l2-eth-test-on-demand-start-absolute-stop-relative>
```

Command Syntax

```
test-signal start-time (absolute) START-TIME stop-time (relative) <0-4294967295>
tst-profile-name WORD domain DOMAIN_NAME ma MA_NAME mep <1-8191> target (mac-
address MAC|<1-8191>)
```

test-signal start-time (relative) <0-4294967295> stop-time (absolute) STOP-TIME tst-profile-name WORD domain DOMAIN_NAME ma MA_NAME mep <1-8191> target (mac-address MAC|<1-8191>)

Attribute Name: start-time-type

Attribute Type: enum (relative)
 Attribute Name: start-time
 Attribute Type: uint32
 Attribute Range: 0-4294967295
 Attribute Name: stop-time-type
 Attribute Type: enum (absolute)
 Attribute Name: stop-time
 Attribute Type: string
 Attribute Name: profile-name
 Attribute Type: string
 Attribute Range: 1-64
 Attribute Name: md-name
 Attribute Type: string
 Attribute Range: 5-7
 Attribute Name: ma-name
 Attribute Type: string
 Attribute Range: 1-6
 Attribute Name: mep-id
 Attribute Type: uint16
 Attribute Range: 1-8191
 Attribute Name: test-target
 Attribute Type: union

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-test-on-demand-start-relative-stop-absolute
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <start-time-type>relative</start-time-type>
  <start-time>0</start-time>
  <stop-time-type>absolute</stop-time-type>
  <stop-time>STOP-TIME</stop-time>
  <profile-name>WORD</profile-name>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
  <mep-id>1</mep-id>
  <test-target>CFM_RMEP_TYPE_T</test-target>
</ipi-cfm-y1731_cfm-l2-eth-test-on-demand-start-relative-stop-absolute>
```

Command Syntax

```
test-signal start-time (relative) <0-4294967295> stop-time (absolute) STOP-TIME
tst-profile-name WORD domain DOMAIN_NAME ma MA_NAME mep <1-8191> target (mac-
address MAC|<1-8191>)
```

**test-signal start-time (absolute) START-TIME stop-time (absolute) STOP-TIME
tst-profile-name WORD domain DOMAIN_NAME ma MA_NAME mep <1-8191>
target (mac-address MAC|<1-8191>)**

Attribute Name: start-time-type

Attribute Type: enum (absolute)

Attribute Name: start-time

Attribute Type: string

Attribute Name: stop-time-type

Attribute Type: enum (absolute)

Attribute Name: stop-time

Attribute Type: string

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 1-64

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: test-target

Attribute Type: union

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-test-on-demand-start-absolute-stop-absolute
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <start-time-type>absolute</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>absolute</stop-time-type>
  <stop-time>STOP-TIME</stop-time>
  <profile-name>WORD</profile-name>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
  <mep-id>1</mep-id>
  <test-target>CFM_RMEP_TYPE_T</test-target>
</ipi-cfm-y1731_cfm-l2-eth-test-on-demand-start-absolute-stop-absolute>
```


Command Syntax

```
test-signal start-time (absolute) START-TIME stop-time (absolute) STOP-TIME tst-
  profile-name WORD domain DOMAIN_NAME ma MA_NAME mep <1-8191> target (mac-address
  MAC|<1-8191>)
```

loss-measurement type proactive profile-name WORD rmep (mac-address MAC|<1-8191>) mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-lm-start-proactive xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-lm-start-proactive>
```

Command Syntax

```
loss-measurement type proactive profile-name WORD rmep (mac-address MAC|<1-8191>)
  mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (immediate) stop-time (none) repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (immediate)

Attribute Name: stop-time-type

Attribute Type: enum (none)

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-immediate-stop-none xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>immediate</start-time-type>
  <stop-time-type>none</stop-time-type>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-immediate-stop-none>
```

Command Syntax

```
loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (immediate) stop-time (none) repetition-period <6000-4294967295> mep
<1-8191> domain DOMAIN_NAME ma MA_NAME
```

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (immediate) stop-time (relative) STOP-TIME

repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (immediate)

Attribute Name: stop-time-type

Attribute Type: enum (relative)

Attribute Name: stop-time

Attribute Type: string

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-immediate-stop-relative
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>immediate</start-time-type>
  <stop-time-type>relative</stop-time-type>
  <stop-time>STOP-TIME</stop-time>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-immediate-stop-relative>
```

Command Syntax

```
loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)  
  start-time (immediate) stop-time (relative) STOP-TIME repetition-period <6000-  
  4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (immediate) stop-time (absolute) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (immediate)

Attribute Name: stop-time-type

Attribute Type: enum (absolute)

Attribute Name: stop-time

Attribute Type: string

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-immediate-stop-absolute  
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">  
  <profile-name>WORD</profile-name>  
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>  
  <start-time-type>immediate</start-time-type>  
  <stop-time-type>absolute</stop-time-type>
```

```

<stop-time>STOP-TIME</stop-time>
<repetition-period>6000</repetition-period>
<mep-id>1</mep-id>
<md-name>DOMAIN_NAME</md-name>
<ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-immediate-stop-absolute>

```

Command Syntax

```

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (immediate) stop-time (absolute) STOP-TIME repetition-period <6000-
4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

```

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (relative) START-TIME stop-time (none) repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (relative)

Attribute Name: start-time

Attribute Type: string

Attribute Name: stop-time-type

Attribute Type: enum (none)

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-relative-stop-none xmlns="http://www.ipinfusion.com/yaŋg/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>relative</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>none</stop-time-type>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-relative-stop-none>
```

Command Syntax

```
loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (relative) START-TIME stop-time (none) repetition-period <6000-
4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (relative) START-TIME stop-time (relative) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (relative)

Attribute Name: start-time

Attribute Type: string

Attribute Name: stop-time-type

Attribute Type: enum (relative)

Attribute Name: stop-time

Attribute Type: string

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-relative-stop-relative
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>relative</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>relative</stop-time-type>
  <stop-time>STOP-TIME</stop-time>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-relative-stop-relative>
```

Command Syntax

```
loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (relative) START-TIME stop-time (relative) STOP-TIME repetition-period
<6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (relative) START-TIME stop-time (absolute) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (relative)

Attribute Name: start-time

Attribute Type: string

Attribute Name: stop-time-type

Attribute Type: enum (absolute)

Attribute Name: stop-time

Attribute Type: string

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-relative-stop-absolute
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>relative</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>absolute</stop-time-type>
  <stop-time>STOP-TIME</stop-time>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-relative-stop-absolute>
```

Command Syntax

```
loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (relative) START-TIME stop-time (absolute) STOP-TIME repetition-period
<6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (absolute) START-TIME stop-time (none) repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64
 Attribute Name: rmep-id
 Attribute Type: union
 Attribute Name: start-time-type
 Attribute Type: enum (absolute)
 Attribute Name: start-time
 Attribute Type: string
 Attribute Name: stop-time-type
 Attribute Type: enum (none)
 Attribute Name: repetition-period
 Attribute Type: yang:timeticks
 Attribute Range: 6000-4294967295
 Attribute Name: mep-id
 Attribute Type: uint16
 Attribute Range: 1-8191
 Attribute Name: md-name
 Attribute Type: string
 Attribute Range: 5-7
 Attribute Name: ma-name
 Attribute Type: string
 Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-absolute-stop-none xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>absolute</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>none</stop-time-type>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-absolute-stop-none>
```

Command Syntax

```
loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (absolute) START-TIME stop-time (none) repetition-period <6000-
4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (absolute) START-TIME stop-time (relative) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (absolute)

Attribute Name: start-time

Attribute Type: string

Attribute Name: stop-time-type

Attribute Type: enum (relative)

Attribute Name: stop-time

Attribute Type: string

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-absolute-stop-relative
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>absolute</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>relative</stop-time-type>
  <stop-time>STOP-TIME</stop-time>
```

```

<repetition-period>6000</repetition-period>
<mep-id>1</mep-id>
<md-name>DOMAIN_NAME</md-name>
<ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-absolute-stop-relative>

```

Command Syntax

```

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
  start-time (absolute) START-TIME stop-time (relative) STOP-TIME repetition-period
  <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

```

loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (absolute) START-TIME stop-time (absolute) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (absolute)

Attribute Name: start-time

Attribute Type: string

Attribute Name: stop-time-type

Attribute Type: enum (absolute)

Attribute Name: stop-time

Attribute Type: string

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-absolute-stop-absolute
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>absolute</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>absolute</stop-time-type>
  <stop-time>STOP-TIME</stop-time>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-lm-on-demand-start-absolute-stop-absolute>
```

Command Syntax

```
loss-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (absolute) START-TIME stop-time (absolute) STOP-TIME repetition-period
<6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

abort loss-measurement mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-abort-eth-lm-test xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-cfm">
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-abort-eth-lm-test>
```

Command Syntax

```
abort loss-measurement mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

clear ethernet cfm loss-measurement history mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-clear-eth-lm-history-stats xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-clear-eth-lm-history-stats>
```

Command Syntax

```
clear ethernet cfm loss-measurement history mep <1-8191> domain DOMAIN_NAME ma
MA_NAME
```

delay-measurement type proactive profile-name WORD rmep (mac-address MAC|<1-8191>) mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-dm-start-proactive xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-dm-start-proactive>
```

Command Syntax

```
delay-measurement type proactive profile-name WORD rmep (mac-address MAC|<1-8191>)
mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (immediate) stop-time (none) repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (immediate)

Attribute Name: stop-time-type

Attribute Type: enum (none)

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-immediate-stop-none xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>immediate</start-time-type>
  <stop-time-type>none</stop-time-type>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-immediate-stop-none>
```

Command Syntax

```
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (immediate) stop-time (none) repetition-period <6000-4294967295> mep
<1-8191> domain DOMAIN_NAME ma MA_NAME
```

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (immediate) stop-time (relative) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (immediate)

Attribute Name: stop-time-type

Attribute Type: enum (relative)

Attribute Name: stop-time

Attribute Type: string

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-immediate-stop-relative
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>immediate</start-time-type>
  <stop-time-type>relative</stop-time-type>
  <stop-time>STOP-TIME</stop-time>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-immediate-stop-relative>
```

Command Syntax

```
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (immediate) stop-time (relative) STOP-TIME repetition-period <6000-
4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (immediate) stop-time (absolute) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (immediate)

Attribute Name: stop-time-type

Attribute Type: enum (absolute)

Attribute Name: stop-time

Attribute Type: string

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```

<ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-immediate-stop-absolute
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>immediate</start-time-type>
  <stop-time-type>absolute</stop-time-type>
  <stop-time>STOP-TIME</stop-time>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-immediate-stop-absolute>

```

Command Syntax

```

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (immediate) stop-time (absolute) STOP-TIME repetition-period <6000-
4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

```

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (relative) START-TIME stop-time (none) repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (relative)

Attribute Name: start-time

Attribute Type: string

Attribute Name: stop-time-type

Attribute Type: enum (none)

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-relative-stop-none xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>relative</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>none</stop-time-type>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-relative-stop-none>
```

Command Syntax

```
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (relative) START-TIME stop-time (none) repetition-period <6000-
4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (relative) START-TIME stop-time (relative) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union
 Attribute Name: start-time-type
 Attribute Type: enum (relative)
 Attribute Name: start-time
 Attribute Type: string
 Attribute Name: stop-time-type
 Attribute Type: enum (relative)
 Attribute Name: stop-time
 Attribute Type: string
 Attribute Name: repetition-period
 Attribute Type: yang:timeticks
 Attribute Range: 6000-4294967295
 Attribute Name: mep-id
 Attribute Type: uint16
 Attribute Range: 1-8191
 Attribute Name: md-name
 Attribute Type: string
 Attribute Range: 5-7
 Attribute Name: ma-name
 Attribute Type: string
 Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-relative-stop-relative
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>relative</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>relative</stop-time-type>
  <stop-time>STOP-TIME</stop-time>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-relative-stop-relative>
```

Command Syntax

```
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (relative) START-TIME stop-time (relative) STOP-TIME repetition-period
<6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (relative) START-TIME stop-time (absolute) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (relative)

Attribute Name: start-time

Attribute Type: string

Attribute Name: stop-time-type

Attribute Type: enum (absolute)

Attribute Name: stop-time

Attribute Type: string

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-relative-stop-absolute
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>relative</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>absolute</stop-time-type>
  <stop-time>STOP-TIME</stop-time>
```

```

<repetition-period>6000</repetition-period>
<mep-id>1</mep-id>
<md-name>DOMAIN_NAME</md-name>
<ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-relative-stop-absolute>

```

Command Syntax

```

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (relative) START-TIME stop-time (absolute) STOP-TIME repetition-period
<6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

```

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (absolute) START-TIME stop-time (none) repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (absolute)

Attribute Name: start-time

Attribute Type: string

Attribute Name: stop-time-type

Attribute Type: enum (none)

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-absolute-stop-none xmlns="http://www.ipinfusion.com/yaŋg/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>absolute</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>none</stop-time-type>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-absolute-stop-none>
```

Command Syntax

```
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (absolute) START-TIME stop-time (none) repetition-period <6000-
4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (absolute) START-TIME stop-time (relative) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (absolute)

Attribute Name: start-time

Attribute Type: string

Attribute Name: stop-time-type

Attribute Type: enum (relative)

Attribute Name: stop-time

Attribute Type: string

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-absolute-stop-relative
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>absolute</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>relative</stop-time-type>
  <stop-time>STOP-TIME</stop-time>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-absolute-stop-relative>
```

Command Syntax

```
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (absolute) START-TIME stop-time (relative) STOP-TIME repetition-period
<6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>) start-time (absolute) START-TIME stop-time (absolute) STOP-TIME repetition-period <6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: profile-name

Attribute Type: string

Attribute Range: 0-64

Attribute Name: rmep-id

Attribute Type: union

Attribute Name: start-time-type

Attribute Type: enum (absolute)

Attribute Name: start-time

Attribute Type: string

Attribute Name: stop-time-type

Attribute Type: enum (absolute)

Attribute Name: stop-time

Attribute Type: string

Attribute Name: repetition-period

Attribute Type: yang:timeticks

Attribute Range: 6000-4294967295

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-absolute-stop-absolute
xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <profile-name>WORD</profile-name>
  <rmep-id>CFM_RMEP_TYPE_T</rmep-id>
  <start-time-type>absolute</start-time-type>
  <start-time>START-TIME</start-time>
  <stop-time-type>absolute</stop-time-type>
  <stop-time>STOP-TIME</stop-time>
  <repetition-period>6000</repetition-period>
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-eth-dm-on-demand-start-absolute-stop-absolute>
```

Command Syntax

```
delay-measurement type on-demand profile-name WORD rmep (mac-address MAC|<1-8191>)
start-time (absolute) START-TIME stop-time (absolute) STOP-TIME repetition-period
<6000-4294967295> mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

abort delay-measurement mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```

    <ipi-cfm-y1731_cfm-l2-abort-eth-dm-test xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-cfm">
    <mep-id>1</mep-id>
    <md-name>DOMAIN_NAME</md-name>
    <ma-name>MA_NAME</ma-name>
    </ipi-cfm-y1731_cfm-l2-abort-eth-dm-test>

```

Command Syntax

```

abort delay-measurement mep <1-8191> domain DOMAIN_NAME ma MA_NAME

```

clear ethernet cfm delay-measurement history mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```

    <ipi-cfm-y1731_cfm-l2-clear-eth-dm-history-stats xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-cfm">
    <mep-id>1</mep-id>
    <md-name>DOMAIN_NAME</md-name>
    <ma-name>MA_NAME</ma-name>
    </ipi-cfm-y1731_cfm-l2-clear-eth-dm-history-stats>

```

Command Syntax

```

clear ethernet cfm delay-measurement history mep <1-8191> domain DOMAIN_NAME ma
MA_NAME

```

clear ethernet cfm statistics csf mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-clear-eth-csf-stats xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-clear-eth-csf-stats>
```

Command Syntax

```
clear ethernet cfm statistics csf mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

clear ethernet cfm statistics bn mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-clear-eth-bn-stats xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-clear-eth-bn-stats>
```

```
</ipi-cfm-y1731_cfm-l2-clear-eth-bn-stats>
```

Command Syntax

```
clear ethernet cfm statistics bn mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

clear ethernet cfm statistics lck mep <1-8191> domain DOMAIN_NAME ma MA_NAME

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-clear-eth-lck-stats xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cfm">
  <mep-id>1</mep-id>
  <md-name>DOMAIN_NAME</md-name>
  <ma-name>MA_NAME</ma-name>
</ipi-cfm-y1731_cfm-l2-clear-eth-lck-stats>
```

Command Syntax

```
clear ethernet cfm statistics lck mep <1-8191> domain DOMAIN_NAME ma MA_NAME
```

clear ethernet cfm statistics test-signal domain DOMAIN_NAME ma MA_NAME mep <1-8191> stats (gtf|ctf)

Attribute Name: md-name

Attribute Type: string

Attribute Range: 5-7

Attribute Name: ma-name

Attribute Type: string

Attribute Range: 1-6

Attribute Name: mep-id

Attribute Type: uint16

Attribute Range: 1-8191

Attribute Name: stats-type

Attribute Type: enum (gtf|ctf)

Netconf RPC payload

```
<ipi-cfm-y1731_cfm-l2-clear-eth-test-signal-stats xmlns="http://  
www.ipinfusion.com/yang/ocnos/ipi-cfm">  
  <md-name>DOMAIN_NAME</md-name>  
  <ma-name>MA_NAME</ma-name>  
  <mep-id>1</mep-id>  
  <stats-type>gtf</stats-type>  
</ipi-cfm-y1731_cfm-l2-clear-eth-test-signal-stats>
```

Command Syntax

```
clear ethernet cfm statistics test-signal domain DOMAIN_NAME ma MA_NAME mep <1-  
8191> stats (gtf|ctf)
```

IPI-UDLD

Configure enable

Use this attribute to enable UDLD

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<udld xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-udld">  
  <global>  
    <config>  
      </enable><!-- operation="delete"-->  
    </config>  
  </global>  
</udld>
```

Command Syntax

```
udld enable
```

Configure message time

Use this attribute to set UDLD message interval value

Attribute Name: message-time

Attribute Type: uint8

Attribute Range: 7-90

Netconf edit-config payload

```
<udld xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-udld">  
  <global>  
    <config>
```

```

    <message-time>7</message-time> <!-- operation="delete"-->
</config>
</global>
</udld>

```

Command Syntax

```
udld message-time <7-90>
```

Configure options

Use this attribute to enable or disable UDLD debugging at various levels

Attribute Name: options

Attribute Type: bits (event|packet|timer|nsm|hal|all)

Netconf edit-config payload

```

<udld xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-udld">
<debug>
<config>
    <options>event</options> <!-- operation="delete"-->
</config>
</debug>
</udld>

```

Command Syntax

```
debug udld (event|packet|timer|nsm|hal|all)
```

Configure mode

Use this attribute to configure UDLD mode for an interface

Attribute Name: mode

Attribute Type: enum (normal|aggressive)

Netconf edit-config payload

```

<udld xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-udld">
<interfaces>
<interface>
    <name>WORD</name>
    <config>
        <name>WORD</name>
    </config>
    <mode>normal</mode> <!-- operation="delete"-->
</interface>
</interfaces>
</udld>

```

Command Syntax

```
udld mode (normal|aggressive)
```

Configure administrative state

Use this attribute configure UDLD administrative state for an interface

Attribute Name: administrative-state

Attribute Type: enum (disable|enable)

Netconf edit-config payload

```
<udld xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-udld">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <administrative-state>disable</administrative-state> <!-- operation="delete"-->
    </interface>
  </interfaces>
</udld>
```

Command Syntax

```
udld state (disable|enable)
```

debug udld (event|packet|timer|nsm|hal|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (event|packet|timer|nsm|hal|all)

Netconf RPC payload

```
<udld-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-udld">
  <terminal-debug-options>event</terminal-debug-options>
</udld-terminal-debug-on>
```

Command Syntax

```
debug udld (event|packet|timer|nsm|hal|all)
```

no debug udld (event|packet|timer|nsm|hal|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (event|packet|timer|nsm|hal|all)

Netconf RPC payload

```
<udld-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-udld">
  <terminal-debug-options>event</terminal-debug-options>
</udld-terminal-debug-off>
```

Command Syntax

```
no debug udld (event|packet|timer|nsm|hal|all)
```

IPI-PTP

Configure instance type

PTP instance type

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: instance-type

Attribute Type: uint8

Attribute Range: 0-1

Attribute Name: profile

Attribute Type: enum (g8265.1|g8275.1|g8275.2|e2e-transparent|default|smpte)

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance> <!-- operation="delete"-->
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
        <profile>g8265.1</profile>
      </config>
    </ptp-instance>
  </ptp-instances>
</ptp>
```

Command Syntax

```
ptp clock <0-1> profile (g8265.1|g8275.1|g8275.2|e2e-transparent|default|smpte)
```

Configure color frame

setting color-frame

This command is supported when following feature are enabled Precision Time Protocol (PTP) custom feature, Precision Time Protocol (PTP) feature

Attribute Name: color-frame

Attribute Type: empty

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
</ptp>
```

```
<tlv>
<config>
  </color-frame><!-- operation="delete"-->
</config>
</tlv>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
sm-tlv time-address-flags color-frame
```

Configure drop frame

setting drop-frame

This command is supported when following feature are enabled Precision Time Protocol (PTP) custom feature, Precision Time Protocol (PTP) feature

Attribute Name: drop-frame

Attribute Type: empty

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
sm-tlv time-address-flags drop-frame
```

Configure denominator

Setting denominator for the default system frame rate

This command is supported when following feature are enabled Precision Time Protocol (PTP) custom feature, Precision Time Protocol (PTP) feature

Attribute Name: denominator

Attribute Type: uint32

Attribute Name: numerator

Attribute Type: uint32

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <tlv>
    <config>
      <numerator>0</numerator>
      <denominator>0</denominator>
    </config>
  </tlv>
</ptp>
```

Command Syntax

```
sm-tlv default-frame-rates <0-4294967295> <0-4294967295>
```

Configure I2 pkt forward

I2-pkt-forward

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: I2-pkt-forward

Attribute Type: empty

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <default-data-set>
    <config>
      </I2-pkt-forward><!-- operation="delete"-->
    </config>
  </default-data-set>
</ptp>
```

Command Syntax

```
l2-pkt-forward
```

Configure domain

The domain number of the current domain

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: domain

Attribute Type: uint8

Default Value: 24

Attribute Range: 0-127

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <ntp-instances>
    <ntp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    <default-data-set>
    <config>
      <domain>0</domain> <!-- operation="delete"-->
    </config>
    </default-data-set>
  </ntp-instance>
</ntp-instances>
</ntp>
```

Command Syntax

```
domain <0-127>
```

Configure servo config

servo config

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: servo-config

Attribute Type: enum (fts|fts-no-synce)

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <ntp-instances>
    <ntp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ntp-instance>
  </ntp-instances>
</ntp>
```

```

    </config>
  <default-data-set>
  <config>
    <servo-config>fts</servo-config> <!-- operation="delete"-->
  </config>
</default-data-set>
</ptp-instance>
</ptp-instances>
</ptp>

```

Command Syntax

```
servo (fts|fts-no-synce)
```

Configure external clock holdover duration

External clock holdover duration

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: external-clock-holdover-duration

Attribute Type: uint16

Default Value: 120

Attribute Range: 0-10080

Netconf edit-config payload

```

<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
  <ptp-instance>
    <instance-type>0</instance-type>
    <config>
      <instance-type>0</instance-type>
    </config>
  </ptp-instance>
  <default-data-set>
  <config>
    <external-clock-holdover-duration>0</external-clock-holdover-duration> <!--
operation="delete"-->
  </config>
</default-data-set>
</ptp-instance>
</ptp-instances>
</ptp>

```

Command Syntax

```
holdover <0-10080>
```

Configure system clock sync

External clock holdover duration

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: system-clock-sync

Attribute Type: uint16

Default Value: 30

Attribute Range: 5-600

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <default-data-set>
    <config>
      <system-clock-sync>5</system-clock-sync> <!-- operation="delete"-->
    </config>
  </default-data-set>
</ptp>
```

Command Syntax

```
system-clock-sync (<5-600>|)
```

Configure ptp clock sync

Initialise ptp clock from operating system clock

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: ptp-clock-sync

Attribute Type: empty

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <default-data-set>
    <config>
      </ptp-clock-sync><!-- operation="delete"-->
    </config>
  </default-data-set>
</ptp>
```

```
</ptp>
```

Command Syntax

```
ptp-clock-sync
```

Configure ptsf wtr duration

External clock holdover duration

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: ptsf-wtr-duration

Attribute Type: uint16

Default Value: 5

Attribute Range: 1-1440

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <default-data-set>
    <config>
      <ptsf-wtr-duration>1</ptsf-wtr-duration> <!-- operation="delete"-->
    </config>
  </default-data-set>
</ptp>
```

Command Syntax

```
ptsf-wait-to-restore <1-1440>
```

Configure g8265p1 wtr duration

g8265.1 master wtr

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: g8265p1-wtr-duration

Attribute Type: uint64

Default Value: 0

Attribute Range: 0-3600

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
```

```
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
</default-data-set>
<config>
  <g8265p1-wtr-duration>0</g8265p1-wtr-duration> <!-- operation="delete"-->
</config>
</default-data-set>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
g8265.1-wtr <0-3600>
```

Configure g8265p1 option

g8265.1 option

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: g8265p1-option

Attribute Type: enum (1|2)

Default Value: 1

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <default-data-set>
    <config>
      <g8265p1-option>1</g8265p1-option> <!-- operation="delete"-->
    </config>
  </default-data-set>
</ptp>
```

Command Syntax

```
g8265.1-option (1|2)
```

Configure reserved vlan base

Reserved vlan base index

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: reserved-vlan-base

Attribute Type: uint16

Default Value: 4064

Attribute Range: 1-4064

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
<ntp-instances>
<ntp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<default-data-set>
<config>
  <reserved-vlan-base>1</reserved-vlan-base> <!-- operation="delete"-->
</config>
</default-data-set>
</ntp-instance>
</ntp-instances>
</ntp>
```

Command Syntax

```
reserved-vlan-base-id <1-4064>
```

Configure two step

two step

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: two-step

Attribute Type: empty

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
<ntp-instances>
<ntp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<default-data-set>
<config>
  </two-step><!-- operation="delete"-->
</config>
</default-data-set>
</ntp-instance>
```

```
</ptp-instances>
</ptp>
```

Command Syntax

```
two-step
```

Configure clock type tgm

clock type as tgm

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: clock-type-tgm

Attribute Type: enum (tgm)

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <default-data-set>
    <config>
      <clock-type-tgm>tgm</clock-type-tgm> <!-- operation="delete"-->
    </config>
  </default-data-set>
</ptp>
```

Command Syntax

```
clock-type (tgm)
```

Configure one way

For G.8265.1 one-way ptp

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: one-way

Attribute Type: empty

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
</ptp>
```



```
    </config>
  <default-data-set>
  <config>
    </one-way><!-- operation="delete"-->
  </config>
</default-data-set>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
one-way
```

Configure number ports

Number of ports

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: number-ports

Attribute Type: uint8

Default Value: 1

Attribute Range: 1-31

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
  <ptp-instance>
    <instance-type>0</instance-type>
    <config>
      <instance-type>0</instance-type>
    </config>
  </ptp-instance>
  <default-data-set>
  <config>
    <number-ports>1</number-ports> <!-- operation="delete"-->
  </config>
</default-data-set>
</ptp-instances>
</ptp>
```

Command Syntax

```
number-ports <1-31>
```

Configure pps pulse offset

1pps Out Pulse Offset in nanoseconds

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: pps-pulse-offset

Attribute Type: int16

Default Value: 0

Attribute Range: -2048-2048

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<default-data-set>
<config>
  <pps-pulse-offset>-2048</pps-pulse-offset> <!-- operation="delete"-->
</config>
</default-data-set>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
lpps-out offset <-2048-2048>
```

Configure pps in smx tod type

1pps in SMX tod type

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: pps-in-smx-tod-type

Attribute Type: enum (smx|tod)

Default Value: tod

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<default-data-set>
<config>
  <pps-in-smx-tod-type>tod</pps-in-smx-tod-type> <!-- operation="delete"-->
</config>
</default-data-set>
</ptp-instance>
</ptp-instances>
```

```
</ptp>
```

Command Syntax

```
lpps-in (smx|tod)
```

Configure priority 1

The priority1 attribute of the local clock

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: priority-1

Attribute Type: uint8

Default Value: 128

Attribute Range: 0-255

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <default-data-set>
    <config>
      <priority-1>0</priority-1> <!-- operation="delete"-->
    </config>
  </default-data-set>
</ptp>
```

Command Syntax

```
priority1 <0-255>
```

Configure priority 2

The priority2 attribute of the local clock

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: priority-2

Attribute Type: uint8

Default Value: 128

Attribute Range: 0-255

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
```

```
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
</default-data-set>
<config>
  <priority-2>0</priority-2> <!-- operation="delete"-->
</config>
</default-data-set>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
priority2 <0-255>
```

Configure slave only

When set the clock is a slave-only clock

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: slave-only

Attribute Type: empty

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </default-data-set>
    <config>
      </slave-only><!-- operation="delete"-->
    </config>
  </default-data-set>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
slave-only
```

Configure local priority

The local priority attribute of the local clock

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: local-priority

Attribute Type: uint8

Default Value: 128

Attribute Range: 1-255

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <default-data-set>
    <config>
      <local-priority>1</local-priority> <!-- operation="delete"-->
    </config>
  </default-data-set>
</ptp>
```

Command Syntax

```
local-priority <1-255>
```

Configure max steps removed

The maximum number of communication paths between the local clock and the grandmaster clock

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: max-steps-removed

Attribute Type: uint8

Default Value: 255

Attribute Range: 1-255

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <default-data-set>
    <config>
      <max-steps-removed>1</max-steps-removed> <!-- operation="delete"-->
    </config>
  </default-data-set>
</ptp>
```

```
</ptp-instance>  
</ptp-instances>  
</ptp>
```

Command Syntax

```
max-steps-removed <1-255>
```

Configure start boundary hops

The maximum number of communication paths between the local clock and the grandmaster clock

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: start-boundary-hops

Attribute Type: uint8

Default Value: 255

Attribute Range: 0-255

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">  
<ptp-instances>  
<ptp-instance>  
  <instance-type>0</instance-type>  
  <config>  
    <instance-type>0</instance-type>  
  </config>  
<default-data-set>  
<config>  
  <start-boundary-hops>0</start-boundary-hops> <!-- operation="delete"-->  
</config>  
</default-data-set>  
</ptp-instance>  
</ptp-instances>  
</ptp>
```

Command Syntax

```
start-boundary-hops <0-255>
```

Configure servo history interval

PTP servo history interval

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: servo-history-interval

Attribute Type: uint8

Attribute Range: 1-60

Attribute Name: servo-history-enabled

Attribute Type: empty

Netconf edit-config payload

```

<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
<ntp-instances>
<ntp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<default-data-set>
<servo-history>
<config>
  </servo-history-enabled>
  <servo-history-interval>1</servo-history-interval>
</config>
</servo-history>
</default-data-set>
</ntp-instance>
</ntp-instances>
</ntp>

```

Command Syntax

```
servo-history <1-60>
```

Configure clock class

The clock-class denotes the traceability of the time or frequency distributed by the clock

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: clock-class

Attribute Type: uint8

Default Value: 248

Attribute Range: 0-255

Netconf edit-config payload

```

<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
<ntp-instances>
<ntp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<default-data-set>
<clock-quality>
<config>
  <clock-class>0</clock-class> <!-- operation="delete"-->
</config>
</clock-quality>
</default-data-set>
</ntp-instance>

```

```
</ptp-instances>  
</ptp>
```

Command Syntax

```
clock-class <0-255>
```

Configure clock accuracy

The clock-accuracy indicates the expected accuracy of the clock

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: clock-accuracy

Attribute Type: uint8

Default Value: 254

Attribute Range: 0-255

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">  
<ptp-instances>  
<ptp-instance>  
  <instance-type>0</instance-type>  
  <config>  
    <instance-type>0</instance-type>  
  </config>  
<default-data-set>  
<clock-quality>  
<config>  
  <clock-accuracy>0</clock-accuracy> <!-- operation="delete"-->  
</config>  
</clock-quality>  
</default-data-set>  
</ptp-instance>  
</ptp-instances>  
</ptp>
```

Command Syntax

```
clock-accuracy <0-255>
```

Configure offset scaled log variance

The offset-scaled-log-variance provides an estimate of the variations of the clock from a linear timescale when it is not synchronized to another clock using the protocol

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: offset-scaled-log-variance

Attribute Type: uint16

Default Value: 65535

Attribute Range: 0-65535

Netconf edit-config payload

```

<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
<ntp-instances>
<ntp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<default-data-set>
<clock-quality>
<config>
  <offset-scaled-log-variance>0</offset-scaled-log-variance> <!--
operation="delete"-->
</config>
</clock-quality>
</default-data-set>
</ntp-instance>
</ntp-instances>
</ntp>

```

Command Syntax

```
offset-log-variance <0-65535>
```

Configure offset nano seconds

GPS offset in ns

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: offset-nano-seconds

Attribute Type: int16

Attribute Range: -2048-2048

Attribute Name: offset-seconds

Attribute Type: int8

Attribute Range: -100-100

Netconf edit-config payload

```

<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
<ntp-instances>
<ntp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<default-data-set>
<gps-offset>
<config>
  <offset-seconds>-100</offset-seconds>
  <offset-nano-seconds>-2048</offset-nano-seconds>

```

```
</config>
</gps-offset>
</default-data-set>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
gps-offset { sec <-100-100>| nsec <-2048-2048> }
```

Configure port number

PTP port clock number. Default value is 1.

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: port-number

Attribute Type: uint16

Attribute Range: 1-31

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <ports>
    <port <!-- operation="delete"-->
      <port-number>1</port-number>
      <config>
        <port-number>1</port-number>
      </config>
    </port>
  </ports>
</ptp>
```

Command Syntax

```
clock-port <1-31>
```

Configure description

This parameter is used to set port clock description

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: description

Attribute Type: string

Attribute Range: 1-64

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
  <description>LINE</description> <!-- operation="delete"-->
</port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
description LINE
```

Configure transport type

Set transport type

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: transport-type

Attribute Type: enum (ipv4|ipv6|ipv4-multicast)

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
  <transport-type>ipv4</transport-type> <!-- operation="delete"-->
</port>
```

```
</ports>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
transport (ipv4|ipv6|ipv4-multicast)
```

Configure transport v6 type

Set transport type

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: transport-v6-type

Attribute Type: empty

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
</ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
  </transport-v6-type><!-- operation="delete"-->
</port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
transport ipv6-multicast
```

Configure transport v6 mulitcast type

Set transport type

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: transport-v6-multicast-type

Attribute Type: enum (site-local|interface-local|link-local|admin-local|organization-local|global-local)

Netconf edit-config payload

```

<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
  <transport-v6-multicast-type>site-local</transport-v6-multicast-type> <!--
operation="delete"-->
</port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>

```

Command Syntax

```

transport ipv6-multicast type (site-local|interface-local|link-local|admin-
local|organization-local|global-local)

```

Configure non forwardable mac addr

Set dst mac as non forwardable mac 01:80:C2:00:00:0E

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: non-forwardable-mac-addr

Attribute Type: empty

Netconf edit-config payload

```

<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
  </non-forwardable-mac-addr><!-- operation="delete"-->
</port>

```

```
</ports>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
multicast-dst-mac non-forwardable
```

Configure log min delay req interval

The base-two logarithm of the minDelayReqInterval (the minimum permitted mean time interval between successive Delay_Req messages)

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: log-min-delay-req-interval

Attribute Type: int8

Default Value: -6

Attribute Range: -7-5

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <ports>
    <port>
      <port-number>1</port-number>
      <config>
        <port-number>1</port-number>
        <log-min-delay-req-interval>-7</log-min-delay-req-interval> <!--
operation="delete"-->
      </config>
    </port>
  </ports>
</ptp>
```

Command Syntax

```
log-min-delay-req-interval <-7-5>
```

Configure log announce interval

The base-two logarithm of the mean announceInterval (mean time interval between successive Announce messages)

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: log-announce-interval

Attribute Type: int8

Default Value: -3

Attribute Range: -3-4

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    <ports>
      <port>
        <port-number>1</port-number>
        <config>
          <port-number>1</port-number>
        </config>
        <log-announce-interval>-3</log-announce-interval> <!-- operation="delete"-->
      </port>
    </ports>
  </ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
log-announce-interval <-3-4>
```

Configure announce receipt timeout

The number of announceInterval that have to pass without receipt of an Announce message before the occurrence of the event ANNOUNCE_RECEIPT_TIMEOUT_EXPIRES

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: announce-receipt-timeout

Attribute Type: uint8

Default Value: 3

Attribute Range: 2-10

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
</ptp>
```

```
<ports>
  <port>
    <port-number>1</port-number>
    <config>
      <port-number>1</port-number>
    </config>
    <announce-receipt-timeout>2</announce-receipt-timeout> <!--
operation="delete"-->
  </port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
announce-receipt-timeout <2-10>
```

Configure log sync interval

The base-two logarithm of the mean SyncInterval for multicast messages

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: log-sync-interval

Attribute Type: int8

Default Value: -6

Attribute Range: -7-4

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <ports>
    <port>
      <port-number>1</port-number>
      <config>
        <port-number>1</port-number>
        <log-sync-interval>-7</log-sync-interval> <!-- operation="delete"-->
      </config>
    </port>
  </ports>
</ptp>
```


Command Syntax

```
log-sync-interval <-7-4>
```

Configure time to live

The ttl value for clock-port

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: time-to-live

Attribute Type: uint8

Default Value: 64

Attribute Range: 1-255

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <ntp-instances>
    <ntp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    <ports>
      <port>
        <port-number>1</port-number>
        <config>
          <port-number>1</port-number>
          </config>
          <time-to-live>1</time-to-live> <!-- operation="delete"-->
        </port>
      </ports>
    </ntp-instance>
  </ntp-instances>
</ntp>
```

Command Syntax

```
ttl <1-255>
```

Configure ip dscp

The ip-dscp value for clock-port

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: ip-dscp

Attribute Type: uint8

Default Value: 56

Attribute Range: 0-63

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
  <ip-dscp>0</ip-dscp> <!-- operation="delete"-->
</port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
dscp <0-63>
```

Configure unicast grant duration

Unicast grant duration field in signalling messages

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: unicast-grant-duration

Attribute Type: uint16

Default Value: 300

Attribute Range: 60-1000

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
```

```

    <unicast-grant-duration>60</unicast-grant-duration> <!-- operation="delete"-->
>
  </port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>

```

Command Syntax

```
unicast-grant-duration <60-1000>
```

Configure master only

When set the port is a master-only port

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: master-only

Attribute Type: empty

Netconf edit-config payload

```

<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <ports>
    <port>
      <port-number>1</port-number>
      <config>
        <port-number>1</port-number>
        </master-only><!-- operation="delete"-->
      </config>
    </port>
  </ports>
</ptp>

```

Command Syntax

```
master-only
```

Configure grandmaster priority 2

The priority2 denotes priority2 attribute of grandmaster clock

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: grandmaster-priority-2

Attribute Type: uint8

Default Value: 128

Attribute Range: 0-255

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <ports>
    <port>
      <port-number>1</port-number>
      <config>
        <port-number>1</port-number>
        <grandmaster-priority-2>0</grandmaster-priority-2> <!-- operation="delete"-->
      </config>
    </port>
  </ports>
</ptp>
```

Command Syntax

```
grandmaster-priority2 <0-255>
```

Configure append

Appending TLV

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: append

Attribute Type: empty

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
  <ports>
    <port>
      <port-number>1</port-number>
      <config>
        <port-number>1</port-number>
      </config>
    </port>
  </ports>
</ptp>
```

```

    </config>
    </append><!-- operation="delete"-->
</port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>

```

Command Syntax

```
sm-tlv append disable
```

Configure process

Processing TLV

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: process

Attribute Type: empty

Netconf edit-config payload

```

<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
</ptp-instance>
</ptp-instances>
</ptp>

```

Command Syntax

```
sm-tlv process disable
```

Configure source ipv6 link local address

When set the clock source address is a linklocal address

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: source-ipv6-link-local-address

Attribute Type: empty

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
<ntp-instances>
<ntp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
  </source-ipv6-link-local-address><!-- operation="delete"-->
</port>
</ports>
</ntp-instance>
</ntp-instances>
</ntp>
```

Command Syntax

```
source-address ipv6 linklocal
```

Configure source ipv6 interface address

When set the clock source address as ipv6

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: source-ipv6-interface-address

Attribute Type: string

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
<ntp-instances>
<ntp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
  <source-ipv6-interface-address>IFNAME</source-ipv6-interface-address> <!--
operation="delete"-->
```

```

</port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>

```

Command Syntax

```
source-address ipv6 interface IFNAME
```

Configure source ipv4 interface address

When set the clock source address as ipv4

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: source-ipv4-interface-address

Attribute Type: string

Netconf edit-config payload

```

<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
</ptp-instance>
<ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
  <source-ipv4-interface-address>IFNAME</source-ipv4-interface-address> <!--
operation="delete"-->
</port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>

```

Command Syntax

```
source-address ipv4 interface IFNAME
```

Configure source ipv6 address

set the absolute source address as ipv6 for clock-port

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: source-ipv6-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
  <source-ipv6-address>X:X::X:X</source-ipv6-address> <!-- operation="delete"-->
>
</port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
source-address ipv6 address X:X::X:X
```

Configure source ipv4 address

set the absolute source address as ipv4 for clock-port

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: source-ipv4-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
<ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
  <source-ipv4-address>A.B.C.D</source-ipv4-address> <!-- operation="delete"-->
</port>
</ports>
```



```

</ptp-instance>
</ptp-instances>
</ptp>

```

Command Syntax

```
source-address ipv4 address A.B.C.D
```

Configure delay asymmetry nsec

Set delay-asymmetry in nanoseconds

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: delay-asymmetry-nsec

Attribute Type: int32

Attribute Range: -1000000-1000000

Attribute Name: delay-asymmetry-msec

Attribute Type: int8

Attribute Range: -100-100

Netconf edit-config payload

```

<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <ntp-instances>
    <ntp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ntp-instance>
  </ntp-instances>
  <ports>
    <port>
      <port-number>1</port-number>
      <config>
        <port-number>1</port-number>
        </config>
      <asymmetry-delay>
        <config>
          <delay-asymmetry-msec>-100</delay-asymmetry-msec>
          <delay-asymmetry-nsec>-1000000</delay-asymmetry-nsec>
        </config>
      </asymmetry-delay>
    </port>
  </ports>
</ntp-instance>
</ntp-instances>
</ntp>

```

Command Syntax

```
delay-asymmetry (msec <-100-100>|) (nsec <-1000000-1000000>|)
```

Configure network interface

Reference to the configured underlying interface that is used by this PTP Port

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: network-interface

Attribute Type: union

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
  <ntp-instances>
    <ntp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ntp-instance>
  </ntp-instances>
  <ports>
    <port>
      <port-number>1</port-number>
      <config>
        <port-number>1</port-number>
      </config>
      <network-interfaces>
        <network-interface> <!-- operation="delete"-->
          <network-interface>PTP_NETWORK_INTERFACE_T</network-interface>
          <config>
            <network-interface>PTP_NETWORK_INTERFACE_T</network-interface>
          </config>
        </network-interface>
      </network-interfaces>
    </port>
  </ports>
</ntp>
```

Command Syntax

```
network-interface (IFNAME|gps|prc)
```

Configure vlan physical interface name

Reference to the configured underlying interface that is used by this vlan interface PTP Port

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: vlan-physical-interface-name

Attribute Type: string

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
```

```

<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
</ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
<network-interfaces>
<network-interface>
  <network-interface>PTP_NETWORK_INTERFACE_T</network-interface>
  <config>
    <network-interface>PTP_NETWORK_INTERFACE_T</network-interface>
  </config>
  <vlan-physical-interface-name>IFNAME</vlan-physical-interface-name> <!--
operation="delete"-->
</network-interface>
</network-interfaces>
</port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>

```

Command Syntax

```
network-interface port IFNAME
```

Configure vlan physical dot1q vlan id

Reference to the configured underlying interface that is used by this PTP Port. The valid range for this attribute vlan-id is related to the value configured in reserved-vlan-base which defines a range of 31 reserved vlans for PTP from the configured value in reserved-vlan-base. By default the range reserved vlan values are 4064-4095. By default the maximum valid value for vlan-id is 4063.

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: vlan-physical-dot1q-vlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Attribute Name: vlan-physical-interface-name

Attribute Type: string

Netconf edit-config payload

```

<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>

```

```

    <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
</ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
  <network-interfaces>
  <network-interface>
    <network-interface>PTP_NETWORK_INTERFACE_T</network-interface>
    <config>
      <network-interface>PTP_NETWORK_INTERFACE_T</network-interface>
      <vlan-physical-interface-name>IFNAME</vlan-physical-interface-name> <!--
operation="delete"-->
    </config>
      <vlan-physical-dot1q-vlan-id>1</vlan-physical-dot1q-vlan-id> <!--
operation="delete"-->
    </network-interface>
  </network-interfaces>
</port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>

```

Command Syntax

```
network-interface port IFNAME (dot1q <1-4095>|)
```

Configure dot1q vlan id

Reference to the configured underlying interface that is used by this PTP Port. The valid range for this attribute vlan-id is related to the value configured in reserved-vlan-base which defines a range of 31 reserved vlans for PTP from the configured value in reserved-vlan-base. By default the range reserved vlan values are 4064-4095. By default the maximum valid value for vlan-id is 4063.

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: dot1q-vlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Netconf edit-config payload

```

<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
  <ptp-instance>
    <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>

```

```

    </config>
  <ports>
    <port>
      <port-number>1</port-number>
      <config>
        <port-number>1</port-number>
      </config>
    </network-interfaces>
    <network-interface>
      <network-interface>PTP_NETWORK_INTERFACE_T</network-interface>
      <config>
        <network-interface>PTP_NETWORK_INTERFACE_T</network-interface>
      </config>
      <dot1q-vlan-id>1</dot1q-vlan-id> <!-- operation="delete"-->
    </network-interface>
  </network-interfaces>
</port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>

```

Command Syntax

```
network-interface dot1q <1-4095>
```

Configure inner dot1q vlan id

Reference to the configured underlying interface that is used by this PTP Port. The valid range for this attribute vlan-id is related to the value configured in reserved-vlan-base which defines a range of 31 reserved vlans for PTP from the configured value in reserved-vlan-base. By default the range reserved vlan values are 4064-4095. By default the maximum valid value for vlan-id is 4063.

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: inner-dot1q-vlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Attribute Name: dot1ad-vlan-id

Attribute Type: uint16

Attribute Range: 1-4095

Netconf edit-config payload

```

<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    </ptp-instance>
  </ptp-instances>
</ptp>

```

```
<ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
</network-interfaces>
<network-interface>
  <network-interface>PTP_NETWORK_INTERFACE_T</network-interface>
  <config>
    <network-interface>PTP_NETWORK_INTERFACE_T</network-interface>
    <dot1ad-vlan-id>1</dot1ad-vlan-id> <!-- operation="delete"-->
  </config>
    <inner-dot1q-vlan-id>1</inner-dot1q-vlan-id> <!-- operation="delete"-->
  </network-interface>
</network-interfaces>
</port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
network-interface dot1ad <1-4095> (inner-dot1q <1-4095>|)
```

Configure master clock source ipv4 address

Set master clock ipv4 source address

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: master-clock-source-ipv4-address

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
<ptp-instances>
<ptp-instance>
  <instance-type>0</instance-type>
  <config>
    <instance-type>0</instance-type>
  </config>
</ports>
<port>
  <port-number>1</port-number>
  <config>
    <port-number>1</port-number>
  </config>
<master-ipv4-addresses>
<master-ipv4-address> <!-- operation="delete"-->
  <master-clock-source-ipv4-address>A.B.C.D</master-clock-source-ipv4-address>
```

```

    <config>
      <master-clock-source-ipv4-address>A.B.C.D</master-clock-source-ipv4-
address>
    </config>
  </master-ipv4-address>
</master-ipv4-addresses>
</port>
</ports>
</ptp-instance>
</ptp-instances>
</ptp>

```

Command Syntax

```
master ipv4 A.B.C.D
```

Configure master ipv4 address priority

Set master clock IPv4 source address priority

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: master-ipv4-address-priority

Attribute Type: uint8

Attribute Range: 0-15

Netconf edit-config payload

```

<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    <ports>
      <port>
        <port-number>1</port-number>
        <config>
          <port-number>1</port-number>
        </config>
        <master-ipv4-addresses>
          <master-ipv4-address>
            <master-clock-source-ipv4-address>A.B.C.D</master-clock-source-ipv4-address>
          <config>
            <master-clock-source-ipv4-address>A.B.C.D</master-clock-source-ipv4-
address>
          </config>
          <master-ipv4-address-priority>0</master-ipv4-address-priority> <!--
operation="delete"-->
        </master-ipv4-address>
      </master-ipv4-addresses>
    </port>

```

```
</ports>  
</ptp-instance>  
</ptp-instances>  
</ptp>
```

Command Syntax

```
master ipv4 A.B.C.D priority <0-15>
```

Configure master clock source ipv6 address

Set master clock IPv6 source address

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: master-clock-source-ipv6-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">  
<ptp-instances>  
<ptp-instance>  
  <instance-type>0</instance-type>  
  <config>  
    <instance-type>0</instance-type>  
  </config>  
<ports>  
<port>  
  <port-number>1</port-number>  
  <config>  
    <port-number>1</port-number>  
  </config>  
  <master-ipv6-addresses>  
  <master-ipv6-address> <!-- operation="delete"-->  
    <master-clock-source-ipv6-address>X:X::X:X</master-clock-source-ipv6-address>  
    <config>  
      <master-clock-source-ipv6-address>X:X::X:X</master-clock-source-ipv6-  
address>  
    </config>  
  </master-ipv6-address>  
</master-ipv6-addresses>  
</port>  
</ports>  
</ptp-instance>  
</ptp-instances>  
</ptp>
```

Command Syntax

```
master ipv6 X:X::X:X
```

Configure master ipv6 address priority

Set master clock IPv6 source address priority

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: master-ipv6-address-priority

Attribute Type: uint8

Attribute Range: 0-15

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    <ports>
      <port>
        <port-number>1</port-number>
        <config>
          <port-number>1</port-number>
        </config>
        <master-ipv6-addresses>
          <master-ipv6-address>
            <master-clock-source-ipv6-address>X:X::X:X</master-clock-source-ipv6-address>
            <config>
              <master-clock-source-ipv6-address>X:X::X:X</master-clock-source-ipv6-
address>
            </config>
            <master-ipv6-address-priority>0</master-ipv6-address-priority> <!--
operation="delete"-->
          </master-ipv6-address>
        </master-ipv6-addresses>
      </port>
    </ports>
  </ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
master ipv6 X:X::X:X priority <0-15>
```

Configure io type

Type of tod input/output. Default: output

This command is supported when following feature are enabled feature support on DUNE platform, Precision Time Protocol (PTP) feature

Attribute Name: io-type

Attribute Type: enum (input|output)

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    <time-of-day>
      <config>
        <io-type>input</io-type> <!-- operation="delete"-->
      </config>
    </time-of-day>
  </ptp-instance>
</ptp-instances>
</ptp>
```

Command Syntax

```
tod (input|output)
```

Configure utc date

UTC date when applying leap seconds

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: utc-date

Attribute Type: string

Attribute Name: offset-seconds

Attribute Type: uint8

Attribute Range: 0-99

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">
  <ptp-instances>
    <ptp-instance>
      <instance-type>0</instance-type>
      <config>
        <instance-type>0</instance-type>
      </config>
    <utc-offset-dates>
      <utc-offset-date> <!-- operation="delete"-->
        <utc-date>YYYY-MM-DD</utc-date>
      <config>
        <utc-date>WORD</utc-date>
        <offset-seconds>0</offset-seconds>
      </config>
    </utc-offset-date>
  </ptp-instance>
</ptp-instances>
</ptp>
```

```
</utc-offset-date>  
</utc-offset-dates>  
</ptp-instance>  
</ptp-instances>  
</ptp>
```

Command Syntax

```
utc-offset date YYYY-MM-DD <0-99>
```

Configure baseline seconds

UTC leap seconds baseline

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: baseline-seconds

Attribute Type: uint8

Attribute Range: 0-99

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ptp">  
<ptp-instances>  
<ptp-instance>  
  <instance-type>0</instance-type>  
  <config>  
    <instance-type>0</instance-type>  
  </config>  
<utc-offset-dates>  
<baseline>  
<config>  
  <baseline-seconds>0</baseline-seconds> <!-- operation="delete"-->  
</config>  
</baseline>  
</utc-offset-dates>  
</ptp-instance>  
</ptp-instances>  
</ptp>
```

Command Syntax

```
utc-offset baseline <0-99>
```

Configure enable

Use this attribute to debug the ptp process.

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<ptp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
<debug>
<config>
  </enable><!-- operation="delete"-->
</config>
</debug>
</ptp>
```

Command Syntax

```
debug ntp
```

Configure hw timestamp

Use this attribute to set the Hardware timestamp

This command is supported when following feature are enabled Precision Time Protocol (PTP) feature

Attribute Name: hw-timestamp

Attribute Type: empty

Netconf edit-config payload

```
<ntp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
<interfaces>
<interface>
  <interface-name>IFNAME</interface-name>
  <config>
    <interface-name>WORD</interface-name>
  </config>
  </hw-timestamp><!-- operation="delete"-->
</interface>
</interfaces>
</ntp>
```

Command Syntax

```
hw-timestamp
```

clear ntp clock <0-1> stats

Attribute Name: clear-clock

Attribute Type: uint8

Attribute Range: 0-1

Netconf RPC payload

```
<ntp-clear-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp">
<clear-clock>0</clear-clock>
</ntp-clear-statistics>
```

Command Syntax

```
clear ptp clock <0-1> stats
```

debug ptp

Netconf RPC payload

```
<ptp-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp"/>
```

Command Syntax

```
debug ptp
```

no debug ptp

Netconf RPC payload

```
<ptp-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ntp"/>
```

Command Syntax

```
no debug ptp
```

IPI-EVPN-MPLS

Configure enable evpn mpls

Use this attribute to enable EVPN-MPLS module. Without this attribute evpn mpls functionality can not be achieved

Attribute Name: enable-evpn-mpls

Attribute Type: empty

Netconf edit-config payload

```
<evpn-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls">
  <global>
    <config>
      </enable-evpn-mpls>
    </config>
  </global>
</evpn-mpls>
```

Command Syntax

```
evpn mpls enable
```

Configure vtep ipv4

Use this attribute to set source vtep global ip address. This will be treated at evpn mpls tunnel source address

Attribute Name: vtep-ipv4

Attribute Type: inet:ipv4-address

Netconf edit-config payload

```
<evpn-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls">
<global>
<config>
  <vtep-ipv4>A.B.C.D</vtep-ipv4> <!-- operation="delete"-->
</config>
</global>
</evpn-mpls>
```

Command Syntax

```
evpn mpls vtep-ip-global A.B.C.D
```

Configure mac ageing timer

Use this attribute to set the time till a learned mac address will persist after last update

Attribute Name: mac-ageing-timer

Attribute Type: uint32

Attribute Range: 10-572

Netconf edit-config payload

```
<evpn-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls">
<global>
<config>
  <mac-ageing-timer>10</mac-ageing-timer> <!-- operation="delete"-->
</config>
</global>
</evpn-mpls>
```

Command Syntax

```
evpn mpls mac-ageing-time <10-572>
```

Configure arp nd refresh time

Use this attribute to configure aging out the arp-cache and nd-cache entries

Attribute Name: arp-nd-refresh-time

Attribute Type: uint32

Attribute Range: 3-190

Netconf edit-config payload

```
<evpn-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls">
<arp-nd-global>
<config>
  <arp-nd-refresh-time>3</arp-nd-refresh-time> <!-- operation="delete"-->
</config>
</arp-nd-global>
</evpn-mpls>
```

Command Syntax

```
evpn mpls arp-nd refresh-timer <3-190>
```

Configure tenant identifier

Tenant Identifier

Attribute Name: tenant-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```
<evpn-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls">
  <mpls-tenants>
    <mpls-tenant> <!-- operation="delete"-->
      <tenant-identifier>1</tenant-identifier>
    <config>
      <tenant-identifier>1</tenant-identifier>
    </config>
  </mpls-tenant>
</mpls-tenants>
</evpn-mpls>
```

Command Syntax

```
evpn mpls id <1-16777215>
```

Configure control word

Tenant Identifier

Attribute Name: tenant-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Attribute Name: control-word

Attribute Type: uint8

Netconf edit-config payload

```
<evpn-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls">
  <mpls-tenants>
    <mpls-tenant>
      <tenant-identifier>1</tenant-identifier>
    <config>
      <tenant-identifier>1</tenant-identifier>
      </control-word>
    </config>
  </mpls-tenant>
</mpls-tenants>
</evpn-mpls>
```

Command Syntax

```
evpn mpls id <1-16777215> control-word
```

Configure vpws identifier

Tenant Identifier

Attribute Name: tenant-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Attribute Name: vpws-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```
<evpn-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls">
  <mpls-tenants>
    <mpls-tenant>
      <tenant-identifier>1</tenant-identifier>
      <config>
        <tenant-identifier>1</tenant-identifier>
        <vpws-identifier>1</vpws-identifier>
      </config>
    </mpls-tenant>
  </mpls-tenants>
</evpn-mpls>
```

Command Syntax

```
evpn mpls id <1-16777215> xconnect target-mpls-id <1-16777215>
```

Configure vrf name

Use this attribute to map vrf to carry EVPN routes

Attribute Name: vrf-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<evpn-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls">
  <mpls-tenants>
    <mpls-tenant>
      <tenant-identifier>1</tenant-identifier>
      <config>
        <tenant-identifier>1</tenant-identifier>
      </config>
      <vrf-name>VRF-NAME</vrf-name> <!-- operation="delete"-->
    </mpls-tenant>
  </mpls-tenants>
</evpn-mpls>
```



```
</mpls-tenants>
</evpn-mpls>
```

Command Syntax

```
host-reachability-protocol evpn-bgp VRF-NAME
```

Configure mac holdtime

Use this attribute to set the time a host mac entry will persist after unconfig

Attribute Name: mac-holdtime

Attribute Type: int32

Default Value: 0

Attribute Range: -1-300

Netconf edit-config payload

```
<evpn-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls">
<mpls-tenants>
<mpls-tenant>
  <tenant-identifier>1</tenant-identifier>
  <config>
    <tenant-identifier>1</tenant-identifier>
  </config>
  <mac-holdtime>-1</mac-holdtime> <!-- operation="delete"-->
</mpls-tenant>
</mpls-tenants>
</evpn-mpls>
```

Command Syntax

```
mac-holdtime <-1-300>
```

Configure tenant description

Use this attribute to set evpn-mpls tenant identifier name

Attribute Name: tenant-description

Attribute Type: string

Netconf edit-config payload

```
<evpn-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls">
<mpls-tenants>
<mpls-tenant>
  <tenant-identifier>1</tenant-identifier>
  <config>
    <tenant-identifier>1</tenant-identifier>
  </config>
  <tenant-description>WORD</tenant-description> <!-- operation="delete"-->
</mpls-tenant>
</mpls-tenants>
```

```
</evpn-mpls>
```

Command Syntax

```
evi-name WORD
```

Configure tunnel policy name

Transport Tunnel Selection Policy

Attribute Name: tunnel-policy-name

Attribute Type: string

Attribute Range: 1-127

Netconf edit-config payload

```
<evpn-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls">
  <mpls-tenants>
    <mpls-tenant>
      <tenant-identifier>1</tenant-identifier>
      <config>
        <tenant-identifier>1</tenant-identifier>
      </config>
      <tunnel-policy-name>WORD</tunnel-policy-name> <!-- operation="delete"-->
    </mpls-tenant>
  </mpls-tenants>
</evpn-mpls>
```

Command Syntax

```
tunnel-select-policy WORD
```

Configure irb name

Use this attribute to provide default gateway behavior on a VTEP for particular VNID.

Attribute Name: irb-name

Attribute Type: string

Netconf edit-config payload

```
<evpn-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls">
  <mpls-tenants>
    <mpls-tenant>
      <tenant-identifier>1</tenant-identifier>
      <config>
        <tenant-identifier>1</tenant-identifier>
      </config>
      <irb-name>NAME</irb-name> <!-- operation="delete"-->
    </mpls-tenant>
  </mpls-tenants>
</evpn-mpls>
```

Command Syntax

```
evpn irb NAME
```

Configure irb advertise host route

Use this attribute to set advertise host to route

Attribute Name: irb-advertise-host-route

Attribute Type: empty

Netconf edit-config payload

```
<evpn-mpls xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls">
  <mpls-tenants>
    <mpls-tenant>
      <tenant-identifier>1</tenant-identifier>
      <config>
        <tenant-identifier>1</tenant-identifier>
      </config>
    <irb>
      <config>
        </irb-advertise-host-route><!-- operation="delete"-->
      </config>
    </irb>
  </mpls-tenant>
</mpls-tenants>
</evpn-mpls>
```

Command Syntax

```
evpn irb-advertise-host-route
```

clear mac address-table dynamic evpn-mpls

Netconf RPC payload

```
<clear-nvo-mpls-dynamic-mac-address-table xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-mpls"/>
```

Command Syntax

```
clear mac address-table dynamic evpn-mpls
```

clear mac address-table dynamic evpn-mpls evid <1-16777215> (address MACADDR)

Attribute Name: tenant-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Attribute Name: mac-address

Attribute Type: string

Netconf RPC payload

```
<clear-nvo-mpls-dynamic-mac-address-table-evid xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-evpn-mpls">
  <tenant-identifier>1</tenant-identifier>
  <mac-address>MACADDR</mac-address>
</clear-nvo-mpls-dynamic-mac-address-table-evid>
```

Command Syntax

```
clear mac address-table dynamic evpn-mpls evid <1-16777215> (address MACADDR|)
```

clear evpn mpls counters (vpn-id <1-16777215>|) network (egress) (dst A.B.C.D|)

Attribute Name: tenant-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Attribute Name: egress-direction

Attribute Type: enum (egress)

Attribute Name: destination-ip

Attribute Type: inet:ipv4-address

Netconf RPC payload

```
<clear-evpn-mpls-egress-counters xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-evpn-mpls">
  <tenant-identifier>1</tenant-identifier>
  <egress-direction>egress</egress-direction>
  <destination-ip>A.B.C.D</destination-ip>
</clear-evpn-mpls-egress-counters>
```

Command Syntax

```
clear evpn mpls counters (vpn-id <1-16777215>|) network (egress) (dst A.B.C.D|)
```

clear evpn mpls counters (vpn-id <1-16777215>|) network (ingress)

Attribute Name: tenant-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Attribute Name: ingress-direction

Attribute Type: enum (ingress)

Netconf RPC payload

```
<clear-evpn-mpls-ingress-counters xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-evpn-mpls">
  <tenant-identifier>1</tenant-identifier>
  <ingress-direction>ingress</ingress-direction>
</clear-evpn-mpls-ingress-counters>
```

Command Syntax

```
clear evpn mpls counters (vpn-id <1-16777215>|) network (ingress)
```

IPI-TWAMP

Configure enable

Enables TWAMP Light Control

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <light>
    <control>
      <config>
        </enable>
      </config>
    </control>
  </light>
</twamp>
```

Command Syntax

```
twamp-light control
```

Configure administrative state

Sets TWAMP Light Control administrative state

Attribute Name: administrative-state

Attribute Type: enum (disable|enable)

Default Value: disable

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <light>
    <control>
      <config>
        <administrative-state>disable</administrative-state> <!-- operation="delete"-->
      </config>
    </control>
  </light>
</twamp>
```

Command Syntax

```
control-admin-state (disable|enable)
```

Configure vrf name

Use this attribute to set the session VRF name

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: sender-ip-address

Attribute Type: union

Attribute Name: sender-udp-port

Attribute Type: union

Attribute Name: reflector-ip-address

Attribute Type: union

Attribute Name: reflector-udp-port

Attribute Type: union

Attribute Name: dscp-value

Attribute Type: union

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <light>
    <control>
      <test-sessions>
        <test-session>
          <vrf-name>NAME</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <session-name>WORD</session-name>
            <sender-ip-address>TWAMP_HOSTNAME_T</sender-ip-address>
            <sender-udp-port>862</sender-udp-port>
            <reflector-ip-address>TWAMP_HOSTNAME_T</reflector-ip-address>
            <reflector-udp-port>862</reflector-udp-port>
            <dscp-value>default</dscp-value>
          </config>
          <session-name>WORD</session-name>
        </test-session>
      </test-sessions>
    </control>
  </light>
</twamp>
```

Command Syntax

```
test-session-name WORD sender-ip (ipv4 A.B.C.D|ipv6 X:X::X:X|HOSTNAME) (sender-port
(862|<1025-65535>)|) reflector-ip (ipv4 A.B.C.D|ipv6 X:X::X:X|HOSTNAME)
(reflector-port (862|<1025-65535>)|) (dscp
(default|cs1|af11|af12|af13|cs2|af21|af22|af23|cs3|af31|af32|af33|cs4|af41|af42|
af43|cs5|ef|cs6|cs7|<0-63>)|) (vrf WORD|)
```

Configure name

Use this attribute to set the Reflector VRF name

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: reflector-ip-address

Attribute Type: union

Attribute Name: reflector-udp-port

Attribute Type: union

Attribute Name: sender-ip-address

Attribute Type: union

Attribute Name: sender-udp-port

Attribute Type: union

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <light>
    <session-reflector>
      <sessions>
        <session>
          <vrf-name>NAME</vrf-name>
          <config>
            <vrf-name>WORD</vrf-name>
            <name>WORD</name>
            <reflector-ip-address>TWAMP_HOSTNAME_T</reflector-ip-address>
            <reflector-udp-port>862</reflector-udp-port>
            <sender-ip-address>TWAMP_HOSTNAME_T</sender-ip-address>
            <sender-udp-port>0</sender-udp-port>
          </config>
          <name>WORD</name>
        </session>
      </sessions>
    </session-reflector>
  </light>
</twamp>
```

Command Syntax

```
reflector-name WORD reflector-ip (ipv4 A.B.C.D|ipv6 X:X::X:X|HOSTNAME) (reflector-
port (862|<1025-65535>)|) (sender-ip (ipv4 A.B.C.D|ipv6 X:X::X:X|HOSTNAME)|)
(sender-port (0|862|<1025-65535>)|) (vrf WORD|)
```

Configure options

Use this attribute to debug the twamp session

Attribute Name: options

Attribute Type: enum (twamp)

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <debug>
  <config>
    <options>twamp</options> <!-- operation="delete"-->
  </config>
</debug>
</twamp>
```

Command Syntax

```
debug (twamp)
```

Configure port

Use this attribute to set Server TCP Port

Attribute Name: port

Attribute Type: union

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <server>
  <config>
    <port>862</port> <!-- operation="delete"-->
  </config>
</server>
</twamp>
```

Command Syntax

```
port (862|<1025-65535>)
```

Configure max connection duration

Set the maximum connection duration in hours, 0 to disable

Attribute Name: max-connection-duration

Attribute Type: uint8

Attribute Range: 0-120

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <server>
  <config>
    <max-connection-duration>0</max-connection-duration> <!-- operation="delete"-->
  </config>
</server>
</twamp>
```

Command Syntax

```
max-connection-duration <0-120>
```

Configure max connections

Set the maximum connections

Attribute Name: max-connections

Attribute Type: uint8

Attribute Range: 1-32

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <server>
    <config>
      <max-connections>1</max-connections> <!-- operation="delete"-->
    </config>
  </server>
</twamp>
```

Command Syntax

```
max-connections <1-32>
```

Configure max connections per client

Set the maximum number of connections per client

Attribute Name: max-connections-per-client

Attribute Type: uint8

Attribute Range: 1-4

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <server>
    <config>
      <max-connections-per-client>1</max-connections-per-client> <!--
operation="delete"-->
    </config>
  </server>
</twamp>
```

Command Syntax

```
max-connections-per-client <1-4>
```

Configure maximum sessions

Set the maximum number of test sessions for the server

Attribute Name: maximum-sessions

Attribute Type: uint8

Attribute Range: 1-64

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <server>
    <config>
      <maximum-sessions>1</maximum-sessions> <!-- operation="delete"-->
    </config>
  </server>
</twamp>
```

Command Syntax

```
maximum-sessions <1-64>
```

Configure maximum sessions per connection

Set the maximum number of test sessions per client connection

Attribute Name: maximum-sessions-per-connection

Attribute Type: uint8

Attribute Range: 1-64

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <server>
    <config>
      <maximum-sessions-per-connection>1</maximum-sessions-per-connection> <!--
operation="delete"-->
    </config>
  </server>
</twamp>
```

Command Syntax

```
maximum-sessions-per-connection <1-64>
```

Configure inactivity timeout

Set the control packet idle timeout value in minutes, 0 to disable

Attribute Name: inactivity-timeout

Attribute Type: uint8

Attribute Range: 0-30

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <server>
    <config>
      <inactivity-timeout>0</inactivity-timeout> <!-- operation="delete"-->
    </config>
  </server>
</twamp>
```

```

</config>
</server>
</twamp>

```

Command Syntax

```
inactivity-timeout <0-30>
```

twamp start test-session WORD packet-count <1-65535> (interval <500-10000>|) (delay-threshold <0-1000000>|)

Attribute Name: session-name

Attribute Type: string

Attribute Range: 1-128

Attribute Name: packet-count

Attribute Type: uint16

Attribute Range: 1-65535

Attribute Name: packet-interval

Attribute Type: uint16

Default Value: 1000

Attribute Range: 500-10000

Attribute Name: delay-threshold

Attribute Type: uint32

Default Value: 0

Attribute Range: 0-1000000

Netconf RPC payload

```

<twamp-test-session-start xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
twamp">
  <session-name>WORD</session-name>
  <packet-count>1</packet-count>
  <packet-interval>500</packet-interval>
  <delay-threshold>0</delay-threshold>
</twamp-test-session-start>

```

Command Syntax

```
twamp start test-session WORD packet-count <1-65535> (interval <500-10000>|)
(delay-threshold <0-1000000>|)
```

twamp stop test-session WORD

Attribute Name: session-name

Attribute Type: string

Attribute Range: 1-128

Netconf RPC payload

```
<twamp-test-session-stop xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">  
<session-name>WORD</session-name>  
</twamp-test-session-stop>
```

Command Syntax

```
twamp stop test-session WORD
```

debug (twamp)

Attribute Name: terminal-debug-options

Attribute Type: enum (twamp)

Netconf RPC payload

```
<twamp-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">  
<terminal-debug-options>twamp</terminal-debug-options>  
</twamp-terminal-debug-on>
```

Command Syntax

```
debug (twamp)
```

no debug (twamp)

Attribute Name: terminal-debug-options

Attribute Type: enum (twamp)

Netconf RPC payload

```
<twamp-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-  
twamp">  
<terminal-debug-options>twamp</terminal-debug-options>  
</twamp-terminal-debug-off>
```

Command Syntax

```
no debug (twamp)
```

IPI-ROLE-BASED-ACCESS-CONTROL

Configure policy name

Use this attribute to create a TACACS+ Role-Based Authorization (RBAC) policy and enter RBAC policy mode.

Attribute Name: policy-name

Attribute Type: string

Attribute Range: 2-16

Netconf edit-config payload

```

<role-based-access-control xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-role-
based-access-control">
  <policies>
  <policy> <!-- operation="delete"-->
    <policy-name>POLICY-NAME</policy-name>
    <config>
      <policy-name>POLICY-NAME</policy-name>
    </config>
  </policy>
</policies>
</role-based-access-control>

```

Command Syntax

```
policy POLICY-NAME
```

Configure command mode

Attribute to specify the mode in which CLI should be allowed/denied. Command prompt string such as 'config-router' or 'config-if', deny/Permit access to the command only in this mode.

Attribute Name: command-mode

Attribute Type: string

Attribute Name: rule-type

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```

<role-based-access-control xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-role-
based-access-control">
  <policies>
  <policy>
    <policy-name>POLICY-NAME</policy-name>
    <config>
      <policy-name>POLICY-NAME</policy-name>
    </config>
  </policy>
  <rules>
  <rule>
    <rule-name>RULE-STRING</rule-name>
    <config>
      <rule-name>RULE-STRING</rule-name>
      <rule-type>deny</rule-type> <!-- operation="delete"-->
    </config>
    <command-mode>MODE-NAME</command-mode> <!-- operation="delete"-->
  </rule>
</rules>
</policy>
</policies>
</role-based-access-control>

```

Command Syntax

```
(deny|permit) RULE-STRING mode MODE-NAME
```

Configure rule name

This attribute specifies rule string configured as regex-expression for cli authorization

Attribute Name: rule-name

Attribute Type: string

Attribute Range: 3-255

Attribute Name: rule-type

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```
<role-based-access-control xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-role-based-access-control">
  <policies>
    <policy>
      <policy-name>POLICY-NAME</policy-name>
      <config>
        <policy-name>POLICY-NAME</policy-name>
      </config>
    </policy>
  </policies>
  <rules>
    <rule>
      <rule-name>RULE-STRING</rule-name>
      <config>
        <rule-name>RULE-STRING</rule-name>
        <rule-type>deny</rule-type>
      </config>
    </rule>
  </rules>
</role-based-access-control>
```

Command Syntax

```
(deny|permit) RULE-STRING
```

Configure rule type

Attribute to specify the mode in which CLI should be allowed/denied. Command prompt string such as 'config-router' or 'config-if', deny/Permit access to the command only in this mode.

Attribute Name: command-mode

Attribute Type: string

Attribute Name: rule-type

Attribute Type: enum (deny|permit)

Netconf edit-config payload

```

<role-based-access-control xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-role-
based-access-control">
  <policies>
  <policy>
    <policy-name>POLICY-NAME</policy-name>
    <config>
      <policy-name>POLICY-NAME</policy-name>
    </config>
  </policy>
  </rules>
  <rule>
    <rule-name>RULE-STRING</rule-name>
    <config>
      <rule-name>RULE-STRING</rule-name>
      <rule-type>deny</rule-type>
    </config>
    <command-mode>MODE-NAME</command-mode>
  </rule>
  </rules>
  </policies>
</role-based-access-control>

```

Command Syntax

```
(deny|permit) RULE-STRING mode MODE-NAME
```

Configure role name

Use this attribute to create a TACACS+ Role-Based Authorization (RBAC) role and to switch to RBAC role mode. End-user cannot specify one of these roles already defined in OcNOS: network-admin network-user network-operator network-engineer For more about these built-in roles, see 'username' CLI configuration

Attribute Name: role-name

Attribute Type: string

Attribute Range: 2-16

Netconf edit-config payload

```

<role-based-access-control xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-role-
based-access-control">
  <roles>
  <role> <!-- operation="delete"-->
    <role-name>ROLE-NAME</role-name>
    <config>
      <role-name>ROLE-NAME</role-name>
    </config>
  </role>
  </roles>
</role-based-access-control>

```

Command Syntax

```
role ROLE-NAME
```

Configure default policy

Use this attribute to set the default rule for a TACACS+ Role-Based Access Control (RBAC) role.

Attribute Name: default-policy

Attribute Type: enum (deny-all|permit-all)

Default Value: deny-all

Netconf edit-config payload

```
<role-based-access-control xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-role-based-access-control">
  <roles>
    <role>
      <role-name>ROLE-NAME</role-name>
      <config>
        <role-name>ROLE-NAME</role-name>
      </config>
      <default-policy>deny-all</default-policy> <!-- operation="delete"-->
    </role>
  </roles>
</role-based-access-control>
```

Command Syntax

```
default (deny-all|permit-all)
```

Configure enable

Enable or disable the TACAS+ Role-Based Access Control of RBAC feature

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<role-based-access-control xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-role-based-access-control">
  <config>
    </enable><!-- operation="delete"-->
  </config>
</role-based-access-control>
```

Command Syntax

```
feature dynamic-rbac
```

IPI-PORT-BREAKOUT

Configure interface

Name of the interface to breakout

Attribute Name: interface

Attribute Type: string

Attribute Name: mode

Attribute Type: enum

(4X10g|4X25g|2X50g|4X100g|8X50g|8X25g|8X10g|2X200g|3X100g|2X100g|1X100g|1X200g|4X50g)

Netconf edit-config payload

```
<port-breakout xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-breakout">
  <breakouts>
    <breakout> <!-- operation="delete"-->
      <interface>IFNAME</interface>
      <config>
        <interface>WORD</interface>
        <mode>4X10g</mode>
      </config>
    </breakout>
  </breakouts>
</port-breakout>
```

Command Syntax

```
port IFNAME breakout
(4X10g|4X25g|2X50g|4X100g|8X50g|8X25g|8X10g|2X200g|3X100g|1X200g|4X50g)
```

Configure mode

Name of the interface to breakout

Attribute Name: interface

Attribute Type: string

Attribute Name: mode

Attribute Type: enum

(4X10g|4X25g|2X50g|4X100g|8X50g|8X25g|8X10g|2X200g|3X100g|2X100g|1X100g|1X200g|4X50g)

Attribute Name: serdes

Attribute Type: enum (25g)

Netconf edit-config payload

```
<port-breakout xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-breakout">
  <breakouts>
    <breakout> <!-- operation="delete"-->
      <interface>IFNAME</interface>
```

```
<config>
  <interface>WORD</interface>
  <mode>4X10g</mode>
  <serdes>25g</serdes>
</config>
</breakout>
</breakouts>
</port-breakout>
```

Command Syntax

```
port IFNAME breakout (2X100g|1X100g) (serdes (25g)|)
```

Configure name

Use this attribute to configure Port-breakout mode for an interface

Attribute Name: mode

Attribute Type: enum (4X10g|4X25g|2X50g)

Netconf edit-config payload

```
<port-breakout xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-port-breakout">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <mode>4X10g</mode> <!-- operation="delete"-->
    </interface>
  </interfaces>
</port-breakout>
```

Command Syntax

```
port breakout enable (4X10g|4X25g|2X50g)
```

IPI-PCEP

Configure entity id

PCEP Entity ID.

Attribute Name: entity-id

Attribute Type: uint32

Attribute Range: 1-255

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <entities>
```

```
<entity> <!-- operation="delete"-->
  <entity-id>1</entity-id>
  <config>
    <entity-id>1</entity-id>
  </config>
</entity>
</entities>
</pcep>
```

Command Syntax

```
pce configuration <1-255>
```

Configure keep alive interval

This attribute is used to set the keep alive transmission timer that this PCEP entity will propose in the initial OPEN message of each session it is involved in. This is the maximum time between two consecutive messages sent to a peer. Zero means that the PCEP entity prefers not to send Keepalives at all.

Attribute Name: keep-alive-interval

Attribute Type: uint8

Default Value: 30

Attribute Range: 0-255

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <entities>
    <entity>
      <entity-id>1</entity-id>
      <config>
        <entity-id>1</entity-id>
      </config>
      <keep-alive-interval>0</keep-alive-interval> <!-- operation="delete"-->
    </entity>
  </entities>
</pcep>
```

Command Syntax

```
keepalive <0-255>
```

Configure dead interval

This attribute is used to set the dead timer that this PCEP entity will propose in the initial OPEN message of each session it is involved in. This is the time after which a peer should declare a session down if it does not receive any PCEP messages.

Attribute Name: dead-interval

Attribute Type: uint8

Default Value: 120

Attribute Range: 1-255

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
<entities>
<entity>
  <entity-id>1</entity-id>
  <config>
    <entity-id>1</entity-id>
  </config>
  <dead-interval>1</dead-interval> <!-- operation="delete"-->
</entity>
</entities>
</pcep>
```

Command Syntax

```
deadtimer <1-255>
```

Configure request timeout

This attribute is used to set the maximum time that the PCEP entity will wait for a response to a PCReq message.

Attribute Name: request-timeout

Attribute Type: uint16

Default Value: 10

Attribute Range: 1-20

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
<entities>
<entity>
  <entity-id>1</entity-id>
  <config>
    <entity-id>1</entity-id>
    <request-timeout>1</request-timeout> <!-- operation="delete"-->
  </config>
</entity>
</entities>
</pcep>
```

Command Syntax

```
request-timeout <1-20>
```

Configure tolerance keepalive

This attribute is used to set the tolerance value for keep-alive timer.

Attribute Name: tolerance-keepalive

Attribute Type: uint32

Attribute Range: 1-255

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
<entities>
<entity>
  <entity-id>1</entity-id>
  <config>
    <entity-id>1</entity-id>
  </config>
  <tolerance-keepalive>1</tolerance-keepalive> <!-- operation="delete"-->
</entity>
</entities>
</pcep>
```

Command Syntax

```
tolerance keepalive <1-255>
```

Configure tolerance dead interval

This attribute is used to set the tolerance value for dead interval timer.

Attribute Name: tolerance-dead-interval

Attribute Type: uint32

Attribute Range: 1-255

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
<entities>
<entity>
  <entity-id>1</entity-id>
  <config>
    <entity-id>1</entity-id>
  </config>
  <tolerance-dead-interval>1</tolerance-dead-interval> <!-- operation="delete"-->
</entity>
</entities>
</pcep>
```

Command Syntax

```
tolerance deadtimer <1-255>
```

Configure cool off timeout

This attribute is used to set Flap dampening time.

Attribute Name: cool-off-timeout

Attribute Type: int32

Attribute Range: 1-300

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
<entities>
<entity>
  <entity-id>1</entity-id>
  <config>
    <entity-id>1</entity-id>
  </config>
  <cool-off-timeout>1</cool-off-timeout> <!-- operation="delete"-->
</entity>
</entities>
</pcep>
```

Command Syntax

```
cool-off-timeout <1-300>
```

Configure source address

This attribute is used to configure the local Internet address of this PCEP entity. If operating as a PCE server, the PCEP entity listens on this address. If operating as a PCC, the PCEP entity binds outgoing TCP connections to this address. It is possible for the PCEP entity to operate both as a PCC and a PCE Server, in which case it uses this address both to listen for incoming TCP connections and to bind outgoing TCP connections.

Attribute Name: source-address

Attribute Type: inet:ip-address

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
<entities>
<entity>
  <entity-id>1</entity-id>
  <config>
    <entity-id>1</entity-id>
    <source-address>CML_IP_ADDR_T</source-address>
  </config>
</entity>
</entities>
</pcep>
```

Command Syntax

```
update-source (A.B.C.D|X:X::X:X)
```

Configure recovery policy

This attribute is used to configure delegation recovery policy.

Attribute Name: recovery-policy

Attribute Type: enum (local-control|removal)

Default Value: removal

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <entities>
    <entity>
      <entity-id>1</entity-id>
      <config>
        <entity-id>1</entity-id>
      </config>
      <recovery-policy>removal</recovery-policy> <!-- operation="delete"-->
    </entity>
  </entities>
</pcep>
```

Command Syntax

```
delegation-recovery policy (local-control|removal)
```

Configure segment routing v6

This attribute is used to enable segment-routing ipv6 capability.

Attribute Name: segment-routing-v6

Attribute Type: empty

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <entities>
    <entity>
      <entity-id>1</entity-id>
      <config>
        <entity-id>1</entity-id>
      </config>
      <capability>
        <config>
          </segment-routing-v6><!-- operation="delete"-->
        </config>
      </capability>
    </entity>
  </entities>
</pcep>
```

Command Syntax

```
segment-routing srv6 pcep
```

Configure pce instantiate

This attribute is used to enable PCE-initiated LSP capability.

Attribute Name: pce-instantiate

Attribute Type: empty

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
<entities>
<entity>
  <entity-id>1</entity-id>
  <config>
    <entity-id>1</entity-id>
  </config>
<capability>
<config>
  </pce-instantiate><!-- operation="delete"-->
</config>
</capability>
</entity>
</entities>
</pcep>
```

Command Syntax

```
pce instantiation
```

Configure segment routing

This attribute is used to enable segment-routing capability.

Attribute Name: segment-routing

Attribute Type: empty

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
<entities>
<entity>
  <entity-id>1</entity-id>
  <config>
    <entity-id>1</entity-id>
  </config>
<capability>
<config>
  </segment-routing><!-- operation="delete"-->
</config>
</capability>
</entity>
</entities>
</pcep>
```

Command Syntax

```
segment-routing pcep
```

Configure redelegation timeout

This attribute is used to set the time period a PCC waits before revoking LSP delegation to a PCE and attempting to redelegate LSPs associated with the terminated PCEP session to an alternate PCE.

Attribute Name: redelegation-timeout

Attribute Type: uint32

Default Value: 60

Attribute Range: 1-600

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <entities>
    <entity>
      <entity-id>1</entity-id>
      <config>
        <entity-id>1</entity-id>
      </config>
    <stateful>
      <config>
        <redelegation-timeout>1</redelegation-timeout> <!-- operation="delete"-->
      </config>
    </stateful>
  </entity>
</entities>
</pcep>
```

Command Syntax

```
redelegation-timeout <1-600>
```

Configure lsp state timeout

This attribute is used to set the time period a PCC waits before flushing LSP state associated with the terminated PCEP session and reverting to operator-defined default parameters or behaviours.

Attribute Name: lsp-state-timeout

Attribute Type: union

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <entities>
    <entity>
      <entity-id>1</entity-id>
      <config>
        <entity-id>1</entity-id>
      </config>
    <stateful>
      <config>
        <lsp-state-timeout>PCEP_LSP_STATE_TIMEOUT_T</lsp-state-timeout>
      </config>
    </stateful>
  </entity>
</entities>
</pcep>
```

```
</config>  
</stateful>  
</entity>  
</entities>  
</pcep>
```

Command Syntax

```
lsp-state-timeout (infinity|<1-600>)
```

Configure flap interval

This attribute is used to set the flap interval time.

Attribute Name: flap-interval

Attribute Type: int32

Attribute Range: 10-36000

Attribute Name: flap-count

Attribute Type: int32

Attribute Range: 10-1000

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">  
<entities>  
<entity>  
  <entity-id>1</entity-id>  
  <config>  
    <entity-id>1</entity-id>  
  </config>  
<flap-limit>  
<config>  
  <flap-count>10</flap-count>  
  <flap-interval>10</flap-interval>  
</config>  
</flap-limit>  
</entity>  
</entities>  
</pcep>
```

Command Syntax

```
flap-limit <10-1000> <10-36000>
```

Configure interval

This attribute is used to set time unit for updates dampening.

Attribute Name: interval

Attribute Type: int32

Attribute Range: 10-36000

Attribute Name: count

Attribute Type: int32

Attribute Range: 1-1000

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <entities>
    <entity>
      <entity-id>1</entity-id>
      <config>
        <entity-id>1</entity-id>
      </config>
    <update-limit>
      <config>
        <count>1</count> <!-- operation="delete"-->
        <interval>10</interval> <!-- operation="delete"-->
      </config>
    </update-limit>
  </entity>
</entities>
</pcep>
```

Command Syntax

```
update-limit <1-1000> <10-36000>
```

Configure lsp limit

This attribute is used to set the starting Tunnel-id range for the PCE initiated LSP.

Attribute Name: lsp-limit

Attribute Type: uint32

Attribute Range: 1-1048575

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <init-lsp-limit>
    <config>
      <lsp-limit>1</lsp-limit>
    </config>
  </init-lsp-limit>
</pcep>
```

Command Syntax

```
pce init-lsp-limit <1-1048575>
```

Configure options

This attribute is used to enable/disable PCEP debug logs.

Attribute Name: options

Attribute Type: bits (events|error|packet|timer|update|report|instantiation|delegation|request|all)

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <debug>
  <config>
    <options>events</options> <!-- operation="delete"-->
  </config>
</debug>
</pcep>
```

Command Syntax

```
debug pcep
  (events|error|packet|timer|update|report|instantiation|delegation|request|all|)
```

Configure srv6 spirent comp

This attribute is used to enable/disable PCEP SRv6 spirent TLV value compliance.

Attribute Name: srv6-spirent-comp

Attribute Type: empty

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <srv6-spirent-comp>
  <config>
    </srv6-spirent-comp><!-- operation="delete"-->
  </config>
</srv6-spirent-comp>
</pcep>
```

Command Syntax

```
pcep srv6 spirent controller compliance
```

debug pcep

(events|error|packet|timer|update|report|instantiation|delegation|request|all|)

Attribute Name: terminal-debug-options

Attribute Type: bits (events|error|packet|timer|update|report|instantiation|delegation|request|all)

Netconf RPC payload

```
<pcep-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <terminal-debug-options>events</terminal-debug-options>
</pcep-terminal-debug-on>
```

Command Syntax

```
debug pcep
  (events|error|packet|timer|update|report|instantiation|delegation|request|all|)
```

no debug pcep (events|error|packet|timer|update|report|instantiation|delegation|request|all)

Attribute Name: terminal-debug-options

Attribute Type: bits (events|error|packet|timer|update|report|instantiation|delegation|request|all)

Netconf RPC payload

```
<pcep-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <terminal-debug-options>events</terminal-debug-options>
</pcep-terminal-debug-off>
```

Command Syntax

```
no debug pcep
  (events|error|packet|timer|update|report|instantiation|delegation|request|all|)
```

clear pcep request (<5001-65535>|all)

Attribute Name: tunnel-id

Attribute Type: string

Netconf RPC payload

```
<clear-pcep-requests xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <tunnel-id>5001</tunnel-id>
</clear-pcep-requests>
```

Command Syntax

```
clear pcep request (<5001-65535>|all)
```

IPI-PCEP-PEER

Configure address

The local Internet address of this PCEP peer.

Attribute Name: address

Attribute Type: union

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <entities>
    <entity>
      <entity-id>1</entity-id>
      <config>
        <entity-id>1</entity-id>
      </config>
    </entity>
  </entities>
</pcep>
```

```
<peer> <!-- operation="delete"-->
  <address>PCEP_IP_ADDR_T</address>
  <config>
    <address>PCEP_IP_ADDR_T</address>
  </config>
</peer>
</peers>
</entity>
</entities>
</pcep>
```

Command Syntax

```
peer-address (ipv4 A.B.C.D|ipv6 X:X::X:X)
```

Configure delegation preference

The PCE peer delegation preference.

Attribute Name: delegation-preference

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <entities>
    <entity>
      <entity-id>1</entity-id>
      <config>
        <entity-id>1</entity-id>
      </config>
      <peers>
        <peer>
          <address>PCEP_IP_ADDR_T</address>
          <config>
            <address>PCEP_IP_ADDR_T</address>
          </config>
          <delegation-preference>1</delegation-preference> <!--
operation="delete"-->
        </peer>
      </peers>
    </entity>
  </entities>
</pcep>
```

Command Syntax

```
peer-address delegation-priority <1-65535>
```

Configure authentication key

The authentication option.

Attribute Name: authentication-key

Attribute Type: string

Netconf edit-config payload

```
<pcep xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep">
  <entities>
    <entity>
      <entity-id>1</entity-id>
      <config>
        <entity-id>1</entity-id>
      </config>
      <peers>
        <peer>
          <address>PCEP_IP_ADDR_T</address>
          <config>
            <address>PCEP_IP_ADDR_T</address>
          </config>
          <authentication-key>WORD</authentication-key> <!-- operation="delete"-
->
        </peer>
      </peers>
    </entity>
  </entities>
</pcep>
```

Command Syntax

```
peer-address md5 WORD
```

clear pcep peer *

Netconf RPC payload

```
<ipi-pcep-peer_clear-pcep-peer-all xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-pcep"/>
```

Command Syntax

```
clear pcep peer *
```

clear pcep peer (A.B.C.D|X:X::X:X)

Attribute Name: address

Attribute Type: inet:ip-address

Netconf RPC payload

```
<ipi-pcep-peer_clear-pcep-peer xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
pcep">
  <address>CML_IP_ADDR_T</address>
</ipi-pcep-peer_clear-pcep-peer>
```

Command Syntax

```
clear pcep peer (A.B.C.D|X:X::X:X)
```

clear pcep statistics

Netconf RPC payload

```
<ipi-pcep-peer_clear-pcep-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-pcep"/>
```

Command Syntax

```
clear pcep statistics
```

IPI-SOURCE-INTERFACE

Configure protocol type

Protocol type to apply the source-interface.

This command is supported when following feature are enabled hostp feature

Attribute Name: protocol-type

Attribute Type: enum (tacacs+|ntp|snmp|syslog|radius)

Attribute Name: port-number

Attribute Type: union

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```
<source-interface xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-source-interface">
  <address-family-ipv4>
    <source-nat-mappings>
      <source-nat-mapping> <!-- operation="delete"-->
        <protocol-type>tacacs+</protocol-type>
        <config>
          <protocol-type>tacacs+</protocol-type>
          <interface-name>WORD</interface-name>
          <port-number>0</port-number>
          <vrf-name>VRF_NAME</vrf-name>
        </config>
      </source-nat-mapping>
    </source-nat-mappings>
  </address-family-ipv4>
</source-interface>
```


Command Syntax

```
ip source-interface IFNAME (tacacs+|ntp|snmp|syslog|radius) (port (0|<1025-65535>)|) (vrf VRF_NAME|)
```

Configure interface name

Protocol type to apply the source-interface.

This command is supported when following feature are enabled IPV6 feature,hostp feature

Attribute Name: protocol-type

Attribute Type: enum (tacacs+|ntp|snmp|syslog|radius)

Attribute Name: port-number

Attribute Type: union

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```
<source-interface xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-source-interface">
  <address-family-ipv6>
    <source-nat-mappings>
      <source-nat-mapping> <!-- operation="delete"-->
        <protocol-type>tacacs+</protocol-type>
        <config>
          <protocol-type>tacacs+</protocol-type>
          <interface-name>WORD</interface-name>
          <port-number>0</port-number>
          <vrf-name>VRF_NAME</vrf-name>
        </config>
      </source-nat-mapping>
    </source-nat-mappings>
  </address-family-ipv6>
</source-interface>
```

Command Syntax

```
ipv6 source-interface IFNAME (tacacs+|ntp|snmp|syslog|radius) (port (0|<1025-65535>)|) (vrf VRF_NAME|)
```

IPI-TACACS

Configure feature enable

Use this attribute to enable the TACACS+ feature

Attribute Name: feature-enable

Attribute Type: empty

Netconf edit-config payload

```
<tacacs xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tacacs">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </feature-enable>
  </vrf>
</vrfs>
</tacacs>
```

Command Syntax

```
feature tacacs+ (vrf management|)
```

Configure vrf name

VRF Name associated with this instance

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: key-type

Attribute Type: enum (0|7)

Attribute Name: secret-key-string

Attribute Type: string

Netconf edit-config payload

```
<tacacs xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tacacs">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
        <key-type>0</key-type>
        <secret-key-string>WORD</secret-key-string>
      </config>
    </vrf>
  </vrfs>
</tacacs>
```

Command Syntax

```
tacacs-server login key (0|7) WORD (vrf management|)
```

Configure key type

VRF Name associated with this instance

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: key-type

Attribute Type: enum (0|7)

Attribute Name: secret-key-string

Attribute Type: string

Netconf edit-config payload

```
<tacacs xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tacacs">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
        <key-type>0</key-type>
        <secret-key-string>WORD</secret-key-string>
      </config>
    </vrf>
  </vrfs>
</tacacs>
```

Command Syntax

```
tacacs-server login key (0|7) WORD (vrf management|)
```

Configure timeout

VRF Name associated with this instance

This command is supported when following feature are enabled hostp feature,aaa feature,tacacs-client feature

Attribute Name: vrf-name

Attribute Type: string

Attribute Name: timeout

Attribute Type: uint8

Default Value: 5

Attribute Range: 1-60

Netconf edit-config payload

```
<tacacs xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tacacs">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
</tacacs>
```

```
        <timeout>1</timeout> <!-- operation="delete"-->
    </config>
</vrf>
</vrfs>
</tacacs>
```

Command Syntax

```
tacacs-server login timeout <1-60> (vrf management|)
```

Configure host address

Use this attribute to set the TACACS+ server host name or IP address

Attribute Name: host-address

Attribute Type: union

Attribute Range: 1-63

Attribute Name: sequence-number

Attribute Type: uint8

Attribute Range: 1-8

Netconf edit-config payload

```
<tacacs xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tacacs">
  <vrfs>
    <vrf>
      <vrf-name>management</vrf-name>
      <config>
        <vrf-name>management</vrf-name>
      </config>
    </vrf>
  </vrfs>
  <remote-servers>
    <server> <!-- operation="delete"-->
      <host-address>A.B.C.D</host-address>
      <config>
        <host-address>A.B.C.D</host-address>
        <sequence-number>1</sequence-number>
      </config>
    </server>
  </remote-servers>
</tacacs>
```

Command Syntax

```
tacacs-server login host (A.B.C.D|X:X::X:X|HOSTNAME) (vrf management|) seq-num <1-8>
```

Configure secret key string

Shared key used between the authentication-server and the device

Attribute Name: secret-key-string

Attribute Type: string

Attribute Name: sequence-number

Attribute Type: uint8

Attribute Range: 1-8

Attribute Name: key-type

Attribute Type: enum (0|7)

Netconf edit-config payload

```
<tacacs xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tacacs">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
<remote-servers>
<server>
  <host-address>A.B.C.D</host-address>
  <config>
    <host-address>A.B.C.D</host-address>
    <sequence-number>1</sequence-number> <!-- operation="delete"-->
    <key-type>0</key-type> <!-- operation="delete"-->
  </config>
  <secret-key-string>WORD</secret-key-string> <!-- operation="delete"-->
</server>
</remote-servers>
</vrf>
</vrfs>
</tacacs>
```

Command Syntax

```
tacacs-server login host (A.B.C.D|X:X::X:X|HOSTNAME) (vrf management|) seq-num <1-8> key (0|7) WORD
```

Configure port

Port number used for TACACS+ Server Connection

Attribute Name: port

Attribute Type: uint32

Attribute Range: 1025-65535

Attribute Name: sequence-number

Attribute Type: uint8

Attribute Range: 1-8

Netconf edit-config payload

```
<tacacs xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tacacs">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
</remote-servers>
<server>
  <host-address>A.B.C.D</host-address>
  <config>
    <host-address>A.B.C.D</host-address>
    <sequence-number>1</sequence-number> <!-- operation="delete"-->
  </config>
  <port>1025</port> <!-- operation="delete"-->
</server>
</remote-servers>
</vrf>
</vrfs>
</tacacs>
```

Command Syntax

```
tacacs-server login host (A.B.C.D|X:X::X:X|HOSTNAME) (vrf management|) seq-num <1-8> port <1025-65535>
```

Configure sequence number

To represent the timeout configured by the user

Attribute Name: timeout

Attribute Type: uint32

Default Value: 5

Attribute Range: 1-60

Attribute Name: sequence-number

Attribute Type: uint8

Attribute Range: 1-8

Netconf edit-config payload

```
<tacacs xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tacacs">
<vrfs>
<vrf>
  <vrf-name>management</vrf-name>
  <config>
    <vrf-name>management</vrf-name>
  </config>
</remote-servers>
<server>
```

```

    <host-address>A.B.C.D</host-address>
  <config>
    <host-address>A.B.C.D</host-address>
    <sequence-number>1</sequence-number> <!-- operation="delete"-->
  </config>
    <timeout>1</timeout> <!-- operation="delete"-->
</server>
</remote-servers>
</vrf>
</vrfs>
</tacacs>

```

Command Syntax

```

tacacs-server login host (A.B.C.D|X:X::X:X|HOSTNAME) (vrf management|) seq-num <1-8> timeout <1-60>

```

Configure enable

This attribute is to enable/disable TACACS+ debug logging

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```

<tacacs xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tacacs">
  <debug>
  <config>
    </enable><!-- operation="delete"-->
  </config>
</debug>
</tacacs>

```

Command Syntax

```

debug tacacs+

```

clear tacacs-server counters (vrf management|)

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```

<clear-all-tacacs-server-counters xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-tacacs">
  <vrf-name>management</vrf-name>
</clear-all-tacacs-server-counters>

```

Command Syntax

```

clear tacacs-server counters (vrf management|)

```

clear tacacs-server (A.B.C.D|X:X::X:X|HOSTNAME) counters (vrf (management|all)|)

Attribute Name: hostname

Attribute Type: union

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<clear-tacacs-server-host-counters xmlns="http://www.ipinfusion.com/yang/ocnos/
ipi-tacacs">
  <hostname>A.B.C.D</hostname>
  <vrf-name>management</vrf-name>
</clear-tacacs-server-host-counters>
```

Command Syntax

```
clear tacacs-server (A.B.C.D|X:X::X:X|HOSTNAME) counters (vrf (management|all)|)
```

debug tacacs+

Netconf RPC payload

```
<tacacs-terminal-debug-on xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
tacacs"/>
```

Command Syntax

```
debug tacacs+
```

no debug tacacs+

Netconf RPC payload

```
<tacacs-terminal-debug-off xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
tacacs"/>
```

Command Syntax

```
no debug tacacs+
```

IPI-TIME-RANGE

Configure name

Time range name to be configured

Attribute Name: name

Attribute Type: string

Attribute Range: 1-60

Netconf edit-config payload

```
<time-ranges xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-time-range">
  <time-range> <!-- operation="delete"-->
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
  </time-range>
</time-ranges>
```

Command Syntax

```
time-range WORD
```

Configure absolute start time

Start time hour and minute

Attribute Name: absolute-start-time

Attribute Type: string

Netconf edit-config payload

```
<time-ranges xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-time-range">
  <time-range>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
  <start-time-options>
    <config>
      <absolute-start-time>TIME_RANGE_DATE_TIME_T</absolute-start-time>
    </config>
  </start-time-options>
</time-range>
</time-ranges>
```

Command Syntax

```
start-time HH:MM:SS <01-31> MONTH <1995-2035>
```

Configure relative start time

Configure the start-time of the time-range to be now or after sometime

Attribute Name: relative-start-time

Attribute Type: union

Netconf edit-config payload

```
<time-ranges xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-time-range">
  <time-range>
    <name>WORD</name>
  </config>
```

```
        <name>WORD</name>
    </config>
<start-time-options>
<config>
    <relative-start-time>TIME_RANGE_RELATIVE_TIME_T</relative-start-time>
</config>
</start-time-options>
</time-range>
</time-ranges>
```

Command Syntax

```
start-time (after (<1-129600>) |now)
```

Configure absolute end time

End time hour and minute

Attribute Name: absolute-end-time

Attribute Type: string

Netconf edit-config payload

```
<time-ranges xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-time-range">
<time-range>
    <name>WORD</name>
    <config>
        <name>WORD</name>
    </config>
</end-time-options>
<config>
    <absolute-end-time>TIME_RANGE_DATE_TIME_T</absolute-end-time>
</config>
</end-time-options>
</time-range>
</time-ranges>
```

Command Syntax

```
end-time HH:MM:SS <01-31> MONTH <1995-2035>
```

Configure relative end time

Relative time in minutes

Attribute Name: relative-end-time

Attribute Type: string

Netconf edit-config payload

```
<time-ranges xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-time-range">
<time-range>
    <name>WORD</name>
    <config>
```

```

        <name>WORD</name>
    </config>
</end-time-options>
<config>
    <relative-end-time>1</relative-end-time> <!-- operation="delete"-->
</config>
</end-time-options>
</time-range>
</time-ranges>

```

Command Syntax

```
end-time after <1-129600>
```

Configure frequency

Frequency (hourly, daily, weekly)

Attribute Name: frequency

Attribute Type: union

Netconf edit-config payload

```

<time-ranges xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-time-range">
  <time-range>
    <name>WORD</name>
    <config>
      <name>WORD</name>
    </config>
  <frequency-options>
    <config>
      <frequency>daily</frequency> <!-- operation="delete"-->
    </config>
  </frequency-options>
</time-range>
</time-ranges>

```

Command Syntax

```
frequency (daily|hourly|weekly|days WORD)
```

crypto pki generate rsa common-name ipv4 IPv4ADDR

Attribute Name: ipv4-addr

Attribute Type: inet:ipv4-address

Netconf RPC payload

```

<crypto-rsa-key-gen xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-crypto">
  <ipv4-addr>IPv4ADDR</ipv4-addr>
</crypto-rsa-key-gen>

```

Command Syntax

```
crypto pki generate rsa common-name ipv4 IPv4ADDR
```

IPI-IP-SLA

Configure identifier

Use this attribute to set the IPSLA.

Attribute Name: identifier

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<ip-sla xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ip-sla">
  <processes>
    <process> <!-- operation="delete"-->
      <identifier>1</identifier>
      <config>
        <identifier>1</identifier>
      </config>
    </process>
  </processes>
</ip-sla>
```

Command Syntax

```
ip sla <1-65535>
```

Configure host

Use this attribute to set the ICMP Echo host name or IP address.

Attribute Name: host

Attribute Type: union

Attribute Name: source-interface

Attribute Type: string

Netconf edit-config payload

```
<ip-sla xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ip-sla">
  <processes>
    <process>
      <identifier>1</identifier>
      <config>
        <identifier>1</identifier>
      </config>
    </process>
  </processes>
  <icmp-echo-processes>
    <icmp-echo-process> <!-- operation="delete"-->
```

```

    <host>IP_SLA_HOSTNAME_T</host>
  <config>
    <host>IP_SLA_HOSTNAME_T</host>
    <source-interface>IFNAME</source-interface>
  </config>
</icmp-echo-process>
</icmp-echo-processes>
</process>
</processes>
</ip-sla>

```

Command Syntax

```
icmp-echo (ipv4 A.B.C.D|ipv6 X:X::X:X|HOSTNAME) (source-interface IFNAME|)
```

Configure frequency

The frequency (interval) correlates to how often the ICMP packet is sent. The unit of this parameter is in seconds.

Attribute Name: frequency

Attribute Type: uint8

Attribute Range: 1-60

Netconf edit-config payload

```

<ip-sla xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ip-sla">
  <processes>
    <process>
      <identifier>1</identifier>
      <config>
        <identifier>1</identifier>
      </config>
    <icmp-echo-processes>
      <icmp-echo-process>
        <host>IP_SLA_HOSTNAME_T</host>
        <config>
          <host>IP_SLA_HOSTNAME_T</host>
          </config>
          <frequency>1</frequency> <!-- operation="delete"-->
        </icmp-echo-process>
      </icmp-echo-processes>
    </process>
  </processes>
</ip-sla>

```

Command Syntax

```
frequency <1-60>
```

Configure timeout

The timeout value correlates to how long the Ping application will wait for the response after sending packets ICMP Echo packets.

Attribute Name: timeout

Attribute Type: uint16

Attribute Range: 1000-60000

Netconf edit-config payload

```
<ip-sla xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ip-sla">
  <processes>
    <process>
      <identifier>1</identifier>
      <config>
        <identifier>1</identifier>
      </config>
    <icmp-echo-processes>
    <icmp-echo-process>
      <host>IP_SLA_HOSTNAME_T</host>
      <config>
        <host>IP_SLA_HOSTNAME_T</host>
      </config>
      <timeout>1000</timeout> <!-- operation="delete" -->
    </icmp-echo-process>
    </icmp-echo-processes>
  </process>
</processes>
</ip-sla>
```

Command Syntax

```
timeout <1000-60000>
```

Configure threshold

The threshold value correlates to the limit the administrator sets as what would be a successful test. Threshold can be configured in milli-seconds.

Attribute Name: threshold

Attribute Type: uint16

Attribute Range: 1000-60000

Netconf edit-config payload

```
<ip-sla xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ip-sla">
  <processes>
    <process>
      <identifier>1</identifier>
      <config>
        <identifier>1</identifier>
      </config>
    </process>
  </processes>
</ip-sla>
```

```

    </config>
  <icmp-echo-processes>
  <icmp-echo-process>
    <host>IP_SLA_HOSTNAME_T</host>
    <config>
      <host>IP_SLA_HOSTNAME_T</host>
    </config>
    <threshold>1000</threshold> <!-- operation="delete"-->
  </icmp-echo-process>
</icmp-echo-processes>
</process>
</processes>
</ip-sla>

```

Command Syntax

```
threshold <1000-60000>
```

Configure vrf name

VRF name

Attribute Name: vrf-name

Attribute Type: string

Netconf edit-config payload

```

<ip-sla xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ip-sla">
  <scheduled-processes>
  <scheduled-process>
    <time-range-name>WORD</time-range-name>
    <config>
      <time-range-name>WORD</time-range-name>
      <scheduled-pid>1</scheduled-pid>
    </config>
    <scheduled-pid>1</scheduled-pid>
    <vrf-name>NAME</vrf-name>
  </scheduled-process>
</scheduled-processes>
</ip-sla>

```

Command Syntax

```
ip sla schedule <1-65535> time-range WORD (vrf NAME|)
```

clear ip sla statistics (<1-65535>|)

Attribute Name: identifier

Attribute Type: uint16

Attribute Range: 1-65535

Netconf RPC payload

```
<ip-sla-clear-statistics xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ip-sla">
  <identifier>1</identifier>
</ip-sla-clear-statistics>
```

Command Syntax

```
clear ip sla statistics (<1-65535>|)
```

IPI-SERVICE-MAP

Configure name

Name for the tunnel policy

This command is supported when following feature are enabled SERVICE MAPPING feature

Attribute Name: name

Attribute Type: string

Attribute Range: 1-127

Netconf edit-config payload

```
<service-map xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-service-map">
  <tunnel-policies>
  <tunnel-policy> <!-- operation="delete"-->
    <name>NAME</name>
    <config>
      <name>WORD</name>
    </config>
  </tunnel-policy>
</tunnel-policies>
</service-map>
```

Command Syntax

```
tunnel-policy NAME
```

Configure color code

Use this attribute to configure color for tunnel policy

This command is supported when following feature are enabled SERVICE MAPPING feature

Attribute Name: color-code

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<service-map xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-service-map">
```



```

<tunnel-policies>
<tunnel-policy>
  <name>NAME</name>
  <config>
    <name>WORD</name>
  </config>
  <color-code>1</color-code> <!-- operation="delete"-->
</tunnel-policy>
</tunnel-policies>
</service-map>

```

Command Syntax

```
color <1-4294967295>
```

Configure selection mode

Use this attribute to configure selection mode as dedicated or best-effort for tunnel policy

This command is supported when following feature are enabled SERVICE MAPPING feature

Attribute Name: selection-mode

Attribute Type: enum (dedicated|best-effort)

Default Value: dedicated

Netconf edit-config payload

```

<service-map xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-service-map">
<tunnel-policies>
<tunnel-policy>
  <name>NAME</name>
  <config>
    <name>WORD</name>
  </config>
  <selection-mode>dedicated</selection-mode> <!-- operation="delete"-->
</tunnel-policy>
</tunnel-policies>
</service-map>

```

Command Syntax

```
mode (dedicated|best-effort)
```

Configure tunnel type

Use this attribute to configure selection mode as sr or srv6 or rsvp for tunnel policy

This command is supported when following feature are enabled SERVICE MAPPING feature

Attribute Name: tunnel-type

Attribute Type: enum (rsvp|sr-mpls|srv6)

Netconf edit-config payload

```
<service-map xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-service-map">
```

```
<tunnel-policies>
<tunnel-policy>
  <name>NAME</name>
  <config>
    <name>WORD</name>
  </config>
  <tunnel-type>rsvp</tunnel-type> <!-- operation="delete"-->
</tunnel-policy>
</tunnel-policies>
</service-map>
```

Command Syntax

```
tunnel-type (rsvp|sr-mps|srv6)
```

IPI-CROSS-CONNECT

Configure xc name

Network Instance Name. For VRF and MAC VRF, instance name can be up to 32 chars long. For VPWS and VPLS instances, instance name can be up to 128 chars long. For L2NI (bridge) instance, instance name has to be a number between (1-32). For Cross-Connect, instance name can be up to 30 chars long. For Bridge-domain, instance, instance name has to be a number between (1-2147483647).

Attribute Name: instance-name

Attribute Type: string

Attribute Name: xc-name

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance> <!-- operation="delete"-->
    <instance-type>cross-connect</instance-type>
    <config>
      <instance-type>cross-connect</instance-type>
      <instance-name>WORD</instance-name>
    </config>
    <instance-name>WORD</instance-name>
  <cross-connect>
  <config>
    <xc-name>WORD</xc-name>
  </config>
</cross-connect>
</network-instance>
</network-instances>
```

Command Syntax

```
cross-connect WORD
```

Configure description

This attribute specifies the description for cross-connect

Attribute Name: description

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>cross-connect</instance-type>
    </config>
    <instance-type>cross-connect</instance-type>
    <cross-connect xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cross-connect">
      <config>
        <description>LINE</description> <!-- operation="delete"-->
      </config>
    </cross-connect>
  </network-instance>
</network-instances>
```

Command Syntax

```
description LINE
```

Configure admin disable

This attribute is used to temporarily shutdown the cross-connect

Attribute Name: admin-disable

Attribute Type: empty

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>cross-connect</instance-type>
    </config>
    <instance-type>cross-connect</instance-type>
    <cross-connect xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cross-connect">
      <config>
        </admin-disable><!-- operation="delete"-->
      </config>
    </cross-connect>
```

```
</network-instance>  
</network-instances>
```

Command Syntax

```
disable
```

Configure endpoint if

This attribute specifies the endpoint for cross-connect

Attribute Name: endpoint-if

Attribute Type: string

Attribute Range: 1-33

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-  
instance">  
  <network-instance>  
    <instance-name>WORD</instance-name>  
    <config>  
      <instance-name>WORD</instance-name>  
      <instance-type>cross-connect</instance-type>  
    </config>  
    <instance-type>cross-connect</instance-type>  
    <cross-connect xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-cross-connect">  
      <cross-connect-interfaces>  
        <cross-connect-interface <!-- operation="delete"-->  
          <endpoint-if>IFNAME</endpoint-if>  
          <config>  
            <endpoint-if>WORD</endpoint-if>  
          </config>  
        </cross-connect-interface>  
      </cross-connect-interfaces>  
    </cross-connect>  
  </network-instance>  
</network-instances>
```

Command Syntax

```
interface IFNAME
```

IPI-BRIDGE-DOMAIN

Configure domain id

Network Instance Name. For VRF and MAC VRF, instance name can be up to 32 chars long. For VPWS and VPLS instances, instance name can be up to 128 chars long. For L2NI (bridge) instance, instance name has to be a number between (1-32). For Cross-Connect, instance name can be up to 30 chars long. For Bridge-domain, instance, instance name has to be a number between (1-2147483647).

Attribute Name: instance-name

Attribute Type: string

Attribute Name: domain-id

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance> <!-- operation="delete"-->
    <instance-type>bridge-domain</instance-type>
    <config>
      <instance-type>bridge-domain</instance-type>
      <instance-name>WORD</instance-name>
    </config>
    <instance-name>WORD</instance-name>
  <bridge-domain>
    <config>
      <domain-id>WORD</domain-id>
    </config>
  </bridge-domain>
</network-instance>
</network-instances>
```

Command Syntax

```
bridge-domain <1-2147483647>
```

Configure description

This attribute specifies the description for bridge domain

This command is supported when following feature are enabled subinterface feature and following feature are disabled
HAVE_SWFWDR feature is enabled

Attribute Name: description

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>bridge-domain</instance-type>
    </config>
    <instance-type>bridge-domain</instance-type>
  <bridge-domain xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge-domain">
    <config>
      <description>LINE</description> <!-- operation="delete"-->
    </config>
```

```
</bridge-domain>  
</network-instance>  
</network-instances>
```

Command Syntax

```
description LINE
```

Configure route interface

This attribute specifies the Logical L3 BVI interface for bridge-domain

This command is supported when following feature are enabled subinterface feature and following feature are disabled
HAVE_SWFWDR feature is enabled

Attribute Name: route-interface

Attribute Type: string

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-  
instance">  
  <network-instance>  
    <instance-name>WORD</instance-name>  
    <config>  
      <instance-name>WORD</instance-name>  
      <instance-type>bridge-domain</instance-type>  
    </config>  
    <instance-type>bridge-domain</instance-type>  
    <bridge-domain xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge-domain">  
      <config>  
        <route-interface>IFNAME</route-interface> <!-- operation="delete"-->  
      </config>  
    </bridge-domain>  
  </network-instance>  
</network-instances>
```

Command Syntax

```
routed-interface IFNAME
```

Configure bridge id

Map bridge mst instance to bridge-domain

This command is supported when following feature are enabled subinterface feature and following feature are disabled
HAVE_SWFWDR feature is enabled

Attribute Name: bridge-id

Attribute Type: string

Attribute Name: instance-id

Attribute Type: uint8

Attribute Range: 1-63

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>bridge-domain</instance-type>
    </config>
    <instance-type>bridge-domain</instance-type>
    <bridge-domain xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge-domain">
      <bridge-instance>
        <config>
          <instance-id>1</instance-id>
          <bridge-id>1</bridge-id>
        </config>
      </bridge-instance>
    </bridge-domain>
  </network-instance>
</network-instances>

```

Command Syntax

```
stp-instance <1-63> bridge <1-32>
```

Configure instance id

Value of instance id

This command is supported when following feature are enabled subinterface feature and following feature are disabled
HAVE_SWFWDR feature is enabled

Attribute Name: instance-id

Attribute Type: uint8

Attribute Range: 1-63

Attribute Name: bridge-id

Attribute Type: string

Netconf edit-config payload

```

<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>bridge-domain</instance-type>
    </config>
    <instance-type>bridge-domain</instance-type>
    <bridge-domain xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge-domain">
      <bridge-instance>
        <config>

```

```
        <bridge-id>1</bridge-id>
        <instance-id>1</instance-id>
    </config>
</bridge-instance>
</bridge-domain>
</network-instance>
</network-instances>
```

Command Syntax

```
stp-instance <1-63> bridge <1-32>
```

Configure name

This attribute specifies the subif for bridge-domain

This command is supported when following feature are enabled subinterface feature and following feature are disabled
HAVE_SWFWDR feature is enabled

Attribute Name: name

Attribute Type: string

Attribute Range: 1-33

Netconf edit-config payload

```
<network-instances xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-network-
instance">
  <network-instance>
    <instance-name>WORD</instance-name>
    <config>
      <instance-name>WORD</instance-name>
      <instance-type>bridge-domain</instance-type>
    </config>
    <instance-type>bridge-domain</instance-type>
  <bridge-domain xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-bridge-domain">
    <member-interfaces>
      <member-interface> <!-- operation="delete"-->
        <name>IFNAME</name>
        <config>
          <name>WORD</name>
        </config>
      </member-interface>
    </member-interfaces>
  </bridge-domain>
</network-instance>
</network-instances>
```

Command Syntax

```
interface IFNAME
```

clear mac address-table dynamic bridge-domain all

Netconf RPC payload

```
<clear-bridge-domain-mac-address-all-table xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-bridge-domain"/>
```

Command Syntax

```
clear mac address-table dynamic bridge-domain all
```

clear mac address-table dynamic bridge-domain id <1-2147483647> (interface IFNAME|) (address MACADDR|)

Attribute Name: bridge-domain

Attribute Type: string

Attribute Name: interface-name

Attribute Type: string

Attribute Range: 1-33

Attribute Name: mac-address

Attribute Type: string

Netconf RPC payload

```
<clear-bridge-domain-mac-address-table xmlns="http://www.ipinfusion.com/yang/
ocnos/ipi-bridge-domain">
  <bridge-domain>id 1</bridge-domain>
  <interface-name>IFNAME</interface-name>
  <mac-address>MACADDR</mac-address>
</clear-bridge-domain-mac-address-table>
```

Command Syntax

```
clear mac address-table dynamic bridge-domain id <1-2147483647> (interface IFNAME|)
(address MACADDR|)
```

IPI-OBJECT-TRACKING

Configure tracker id

Use this attribute for Object Tracking id.

Attribute Name: tracker-id

Attribute Type: uint16

Attribute Name: delay-up

Attribute Type: uint16

Attribute Range: 1-9999

Netconf edit-config payload

```
<object-tracking xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-object-tracking">
  <trackers>
    <tracker>
      <tracker-id>1</tracker-id>
      <config>
        <tracker-id>1</tracker-id>
        <delay-up>1</delay-up>
      </config>
    </tracker>
  </trackers>
</object-tracking>
```

Command Syntax

```
delay up <1-9999>
```

Configure delay down

Use this attribute for Object Tracking id.

Attribute Name: tracker-id

Attribute Type: uint16

Attribute Name: delay-down

Attribute Type: uint16

Attribute Range: 1-9999

Netconf edit-config payload

```
<object-tracking xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-object-tracking">
  <trackers>
    <tracker>
      <tracker-id>1</tracker-id>
      <config>
        <tracker-id>1</tracker-id>
        <delay-down>1</delay-down>
      </config>
    </tracker>
  </trackers>
</object-tracking>
```

Command Syntax

```
delay down <1-9999>
```

Configure delay up

Use this attribute for Object Tracking id.

Attribute Name: tracker-id

Attribute Type: uint16

Attribute Name: delay-up

Attribute Type: uint16

Attribute Range: 1-9999

Attribute Name: delay-down

Attribute Type: uint16

Attribute Range: 1-9999

Netconf edit-config payload

```
<object-tracking xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-object-tracking">
  <trackers>
    <tracker>
      <tracker-id>1</tracker-id>
      <config>
        <tracker-id>1</tracker-id>
        <delay-up>1</delay-up>
        <delay-down>1</delay-down>
      </config>
    </tracker>
  </trackers>
</object-tracking>
```

Command Syntax

```
delay up <1-9999> down <1-9999>
```

Configure select option

object tracking options

Attribute Name: select-option

Attribute Type: enum (all|any)

Netconf edit-config payload

```
<object-tracking xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-object-tracking">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
      <select-option>all</select-option> <!-- operation="delete"-->
    </interface>
  </interfaces>
</object-tracking>
```

Command Syntax

```
object-tracking (all|any)
```

Configure track id

Use this attribute for Object Tracking id.

Attribute Name: track-id

Attribute Type: uint32

Attribute Range: 1-500

Netconf edit-config payload

```
<object-tracking xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-object-tracking">
  <interfaces>
    <interface>
      <name>WORD</name>
      <config>
        <name>WORD</name>
      </config>
    <track-interfaces>
      <track-interface> <!-- operation="delete"-->
        <track-id>1</track-id>
        <config>
          <track-id>1</track-id>
        </config>
      </track-interface>
    </track-interfaces>
  </interface>
</interfaces>
</object-tracking>
```

Command Syntax

```
object-tracking <1-500>
```

IPI-DELAY-PROFILE

Configure profile type

The profile type for delay

Attribute Name: profile-type

Attribute Type: enum (interfaces)

Netconf edit-config payload

```
<delay-profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-delay-profile">
  <delay-profile> <!-- operation="delete"-->
    <profile-type>interfaces</profile-type>
    <config>
      <profile-type>interfaces</profile-type>
    </config>
  </delay-profile>
```

```
</delay-profiles>
```

Command Syntax

```
delay-profile (interfaces)
```

Configure mode

Set the measurement mode

Attribute Name: mode

Attribute Type: enum (one-way|two-way)

Netconf edit-config payload

```
<delay-profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-delay-profile">
<delay-profile>
  <profile-type>interfaces</profile-type>
  <config>
    <profile-type>interfaces</profile-type>
  </config>
<profile-parameters>
<config>
  <mode>one-way</mode> <!-- operation="delete"-->
</config>
</profile-parameters>
</delay-profile>
</delay-profiles>
```

Command Syntax

```
mode (one-way|two-way)
```

Configure sender port

Configure the computation interval

Attribute Name: sender-port

Attribute Type: uint16

Attribute Range: 1025-65535

Netconf edit-config payload

```
<delay-profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-delay-profile">
<delay-profile>
  <profile-type>interfaces</profile-type>
  <config>
    <profile-type>interfaces</profile-type>
  </config>
<profile-parameters>
<config>
  <sender-port>1025</sender-port> <!-- operation="delete"-->
</config>
```

```
</profile-parameters>
</delay-profile>
</delay-profiles>
```

Command Syntax

```
sender-port <1025-65535>
```

Configure burst interval

Configure the burst-interval

Attribute Name: burst-interval

Attribute Type: uint16

Attribute Range: 1000-15000

Netconf edit-config payload

```
<delay-profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-delay-profile">
<delay-profile>
  <profile-type>interfaces</profile-type>
  <config>
    <profile-type>interfaces</profile-type>
  </config>
<profile-parameters>
<config>
  <burst-interval>1000</burst-interval> <!-- operation="delete"-->
</config>
</profile-parameters>
</delay-profile>
</delay-profiles>
```

Command Syntax

```
burst-interval <1000-15000>
```

Configure burst count

Configure the burst-count

Attribute Name: burst-count

Attribute Type: uint8

Attribute Range: 1-5

Netconf edit-config payload

```
<delay-profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-delay-profile">
<delay-profile>
  <profile-type>interfaces</profile-type>
  <config>
    <profile-type>interfaces</profile-type>
  </config>
<profile-parameters>
```

```
<config>
  <burst-count>1</burst-count> <!-- operation="delete"-->
</config>
</profile-parameters>
</delay-profile>
</delay-profiles>
```

Command Syntax

```
burst-count <1-5>
```

Configure interval

Configure the computation interval

Attribute Name: interval

Attribute Type: uint16

Attribute Range: 30-3600

Netconf edit-config payload

```
<delay-profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-delay-profile">
<delay-profile>
  <profile-type>interfaces</profile-type>
  <config>
    <profile-type>interfaces</profile-type>
  </config>
<profile-parameters>
<config>
  <interval>30</interval> <!-- operation="delete"-->
</config>
</profile-parameters>
</delay-profile>
</delay-profiles>
```

Command Syntax

```
interval <30-3600>
```

Configure disable

Disable the periodic advertisement

Attribute Name: disable

Attribute Type: uint8

Netconf edit-config payload

```
<delay-profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-delay-profile">
<delay-profile>
  <profile-type>interfaces</profile-type>
  <config>
    <profile-type>interfaces</profile-type>
```

```
    </config>
  <periodic-advertisement>
    <config>
      </disable><!-- operation="delete"-->
    </config>
  </periodic-advertisement>
</delay-profile>
</delay-profiles>
```

Command Syntax

```
no advertisement periodic
```

Configure threshold

Configure the periodic advertisement threshold

Attribute Name: threshold

Attribute Type: uint8

Attribute Range: 1-100

Netconf edit-config payload

```
<delay-profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-delay-profile">
  <delay-profile>
    <profile-type>interfaces</profile-type>
    <config>
      <profile-type>interfaces</profile-type>
    </config>
  <periodic-advertisement>
    <config>
      <threshold>1</threshold> <!-- operation="delete"-->
    </config>
  </periodic-advertisement>
</delay-profile>
</delay-profiles>
```

Command Syntax

```
advertisement periodic threshold <1-100>
```

Configure minimum change

Configure the advertisement minimum-change in microseconds (default=1000)

Attribute Name: minimum-change

Attribute Type: uint16

Attribute Range: 0-10000

Netconf edit-config payload

```
<delay-profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-delay-profile">
  <delay-profile>
```



```

    <profile-type>interfaces</profile-type>
  <config>
    <profile-type>interfaces</profile-type>
  </config>
</periodic-advertisement>
<config>
  <minimum-change>0</minimum-change> <!-- operation="delete"-->
</config>
</periodic-advertisement>
</delay-profile>
</delay-profiles>

```

Command Syntax

```
advertisement periodic minimum-change <0-10000>
```

Configure enable

Enable the accelerated advertisement

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```

<delay-profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-delay-profile">
  <delay-profile>
    <profile-type>interfaces</profile-type>
    <config>
      <profile-type>interfaces</profile-type>
    </config>
  <accelerated-advertisement>
    <config>
      </enable>
    </config>
  </accelerated-advertisement>
</delay-profile>
</delay-profiles>

```

Command Syntax

```
advertisement accelerated
```

Configure delay profile enable

Enables TWAMP Client delay profile

Attribute Name: delay-profile-enable

Attribute Type: empty

Netconf edit-config payload

```

<delay-profiles xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-delay-profile">
  <delay-profile-clients>

```

```
<config>
  </delay-profile-enable>
</config>
</delay-profile-clients>
</delay-profiles>
```

Command Syntax

```
delay-profile clients
```

IPI-ELK

Configure password

Use this to configure ELK server password

Attribute Name: password

Attribute Type: string

Attribute Name: username

Attribute Type: string

Netconf edit-config payload

```
<elk xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-elk">
  <metricbeats>
    <metricbeat>
      <ip>A.B.C.D</ip>
      <config>
        <ip>A.B.C.D</ip>
        <username>USERNAME</username> <!-- operation="delete"-->
      </config>
      <password>PASSWORD</password> <!-- operation="delete"-->
    </metricbeat>
  </metricbeats>
</elk>
```

Command Syntax

```
elk server metricbeat A.B.C.D username USERNAME password PASSWORD
```

Configure certificate path

Used to configure Filebeat server path to certificate file

Attribute Name: certificate-path

Attribute Type: string

Netconf edit-config payload

```
<elk xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-elk">
  <filebeats>
```

```
<filebeat>
  <ip>A.B.C.D</ip>
  <config>
    <ip>A.B.C.D</ip>
  </config>
  <certificate-path>FILE-PATH</certificate-path> <!-- operation="delete"-->
</filebeat>
</filebeats>
</elk>
```

Command Syntax

```
elk server filebeat A.B.C.D FILE-PATH
```

service enable metricbeat (vrf management|)

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<elk-metricbeat-service-enable xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
elk">
  <vrf-name>management</vrf-name>
</elk-metricbeat-service-enable>
```

Command Syntax

```
service enable metricbeat (vrf management|)
```

service enable filebeat (vrf management|)

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<elk-filebeat-service-enable xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
elk">
  <vrf-name>management</vrf-name>
</elk-filebeat-service-enable>
```

Command Syntax

```
service enable filebeat (vrf management|)
```

service disable metricbeat (vrf management|)

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<elk-metricbeat-service-disable xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
elk">
  <vrf-name>management</vrf-name>
</elk-metricbeat-service-disable>
```

Command Syntax

```
service disable metricbeat (vrf management|)
```

service disable filebeat (vrf management|)

Attribute Name: vrf-name

Attribute Type: string

Netconf RPC payload

```
<elk-filebeat-service-disable xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-
elk">
  <vrf-name>management</vrf-name>
</elk-filebeat-service-disable>
```

Command Syntax

```
service disable filebeat (vrf management|)
```

IPI-IPSEC

Configure transform set name

IPsec transform-set name

This command is supported when following feature are enabled IPsec feature

Attribute Name: transform-set-name

Attribute Type: string

Attribute Range: 1-127

Netconf edit-config payload

```
<ipsec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipsec">
  <transform-sets>
  <transform-set> <!-- operation="delete"-->
    <transform-set-name>NAME</transform-set-name>
    <config>
      <transform-set-name>NAME</transform-set-name>
    </config>
  </transform-set>
</transform-sets>
</ipsec>
```

Command Syntax

```
crypto ipsec transform-set NAME
```

Configure transform set mode

This attribute is used to configure mode for a transform-set.

This command is supported when following feature are enabled IPsec feature

Attribute Name: transform-set-mode

Attribute Type: enum (transport)

Default Value: transport

Netconf edit-config payload

```
<ipsec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipsec">
  <transform-sets>
    <transform-set>
      <transform-set-name>NAME</transform-set-name>
      <config>
        <transform-set-name>NAME</transform-set-name>
      </config>
      <transform-set-mode>transport</transform-set-mode> <!-- operation="delete"-->
    </transform-set>
  </transform-sets>
</ipsec>
```

Command Syntax

```
crypto ipsec transform-set NAME mode (transport)
```

Configure ah authentication

This attribute configures IPsec AH authentication type.

This command is supported when following feature are enabled IPsec feature

Attribute Name: ah-authentication

Attribute Type: enum (none|ah-md5|ah-sha1|ah-sha256|ah-sha384|ah-sha512)

Netconf edit-config payload

```
<ipsec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipsec">
  <transform-sets>
    <transform-set>
      <transform-set-name>NAME</transform-set-name>
      <config>
        <transform-set-name>NAME</transform-set-name>
      </config>
      <ah-auth>
        <config>
          <ah-authentication>none</ah-authentication> <!-- operation="delete"-->
        </config>
      </ah-auth>
    </transform-set>
  </transform-sets>
</ipsec>
```

```
</ah-auth>  
</transform-set>  
</transform-sets>  
</ipsec>
```

Command Syntax

```
crypto ipsec transform-set NAME ah (none|ah-md5|ah-sha1|ah-sha256|ah-sha384|ah-  
sha512)
```

Configure esp encryption

This attribute configures IPsec ESP encryption type.

This command is supported when following feature are enabled IPsec feature

Attribute Name: esp-encryption

Attribute Type: enum (esp-null|esp-3des|esp-cast|esp-blf|esp-blf192|esp-blf256|esp-aes|esp-aes192|esp-aes256)

Attribute Name: esp-authentication

Attribute Type: enum (none|esp-md5|esp-sha1|esp-sha256|esp-sha384|esp-sha512)

Netconf edit-config payload

```
<ipsec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipsec">  
<transform-sets>  
<transform-set>  
  <transform-set-name>NAME</transform-set-name>  
  <config>  
    <transform-set-name>NAME</transform-set-name>  
  </config>  
<esp-auth>  
<config>  
  <esp-authentication>none</esp-authentication>  
  <esp-encryption>esp-null</esp-encryption>  
</config>  
</esp-auth>  
</transform-set>  
</transform-sets>  
</ipsec>
```

Command Syntax

```
crypto ipsec transform-set NAME esp-auth (none|esp-md5|esp-sha1|esp-sha256|esp-  
sha384|esp-sha512) esp-enc (esp-null|esp-3des|esp-cast|esp-blf|esp-blf192|esp-  
blf256|esp-aes|esp-aes192|esp-aes256)
```

Configure esp authentication

This attribute configures IPsec ESP authentication type.

This command is supported when following feature are enabled IPsec feature

Attribute Name: esp-authentication

Attribute Type: enum (none|esp-md5|esp-sha1|esp-sha256|esp-sha384|esp-sha512)

Attribute Name: esp-encryption

Attribute Type: enum (esp-null|esp-3des|esp-cast|esp-blf|esp-blf192|esp-blf256|esp-aes|esp-aes192|esp-aes256)

Netconf edit-config payload

```
<ipsec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipsec">
  <transform-sets>
    <transform-set>
      <transform-set-name>NAME</transform-set-name>
      <config>
        <transform-set-name>NAME</transform-set-name>
      </config>
    <esp-auth>
      <config>
        <esp-encryption>esp-null</esp-encryption>
        <esp-authentication>none</esp-authentication>
      </config>
    </esp-auth>
  </transform-set>
</transform-sets>
</ipsec>
```

Command Syntax

```
crypto ipsec transform-set NAME esp-auth (none|esp-md5|esp-sha1|esp-sha256|esp-
sha384|esp-sha512) esp-enc (esp-null|esp-3des|esp-cast|esp-blf|esp-blf192|esp-
blf256|esp-aes|esp-aes192|esp-aes256)
```

Configure name

IPsec Crypto Map name

This command is supported when following feature are enabled IPsec feature

Attribute Name: name

Attribute Type: string

Attribute Range: 1-127

Attribute Name: sa-type

Attribute Type: enum (ipsec-manual)

Netconf edit-config payload

```
<ipsec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipsec">
  <crypto-maps>
    <crypto-map> <!-- operation="delete"-->
      <name>MAP-NAME</name>
      <config>
        <name>WORD</name>
        <sa-type>ipsec-manual</sa-type>
      </config>
    </crypto-map>
  </crypto-maps>
```

```
</ipsec>
```

Command Syntax

```
crypto map MAP-NAME (ipsec-manual)
```

Configure sequence id

Map sequence-id

This command is supported when following feature are enabled IPsec feature

Attribute Name: sequence-id

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```
<ipsec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipsec">
  <crypto-maps>
    <crypto-map>
      <name>MAP-NAME</name>
      <config>
        <name>WORD</name>
      </config>
    <sessions>
      <session> <!-- operation="delete"-->
        <sequence-id>1</sequence-id>
        <config>
          <sequence-id>1</sequence-id>
        </config>
      </session>
    </sessions>
  </crypto-map>
</crypto-maps>
</ipsec>
```

Command Syntax

```
sequence <1-65535>
```

Configure peer

Map session peer IP address

This command is supported when following feature are enabled IPsec feature

Attribute Name: peer

Attribute Type: inet:ip-address

Attribute Name: spi

Attribute Type: uint16

Netconf edit-config payload

```
<ipsec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipsec">
  <crypto-maps>
  <crypto-map>
    <name>MAP-NAME</name>
    <config>
      <name>WORD</name>
    </config>
  </sessions>
  <session>
    <sequence-id>1</sequence-id>
    <config>
      <sequence-id>1</sequence-id>
    </config>
    <peer-addresses>
    <peer-address> <!-- operation="delete"-->
      <peer>A.B.C.D</peer>
      <config>
        <peer>CML_IP_ADDR_T</peer>
        <spi>0</spi>
      </config>
    </peer-address>
  </peer-addresses>
</session>
</sessions>
</crypto-map>
</crypto-maps>
</ipsec>
```

Command Syntax

```
set peer (A.B.C.D|X:X::X:X) (spi <0-4096>|)
```

Configure security parameter index

Crypto Map session key security parameter index (SPI)

This command is supported when following feature are enabled IPsec feature

Attribute Name: security-parameter-index

Attribute Type: uint16

Attribute Range: 0-4096

Attribute Name: cipher

Attribute Type: string

Attribute Range: 1-128

Attribute Name: authentication-key

Attribute Type: string

Attribute Range: 1-128

Netconf edit-config payload

```
<ipsec xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-ipsec">
  <crypto-maps>
    <crypto-map>
      <name>MAP-NAME</name>
      <config>
        <name>WORD</name>
      </config>
    </crypto-map>
  </crypto-maps>
  <sessions>
    <session>
      <sequence-id>1</sequence-id>
      <config>
        <sequence-id>1</sequence-id>
      </config>
      <session-keys>
        <session-key <!-- operation="delete"-->
          <security-parameter-index>0</security-parameter-index>
          <config>
            <security-parameter-index>0</security-parameter-index>
            <protocol>esp</protocol>
            <direction>inbound</direction>
            <cipher>HEX-KEY-DATA</cipher>
            <authentication-key>HEX-KEY-DATA</authentication-key>
          </config>
            <protocol>esp</protocol>
            <direction>inbound</direction>
          </session-key>
        </session-keys>
      </session>
    </sessions>
  </crypto-map>
</crypto-maps>
</ipsec>
```

Command Syntax

```
set session-key (inbound|outbound) (esp) <0-4096> cipher HEX-KEY-DATA authenticator
HEX-KEY-DATA
```

IPI-EVPN-SRV6

Configure enabled

Use this attribute to enable EVPN-SRV6 module. Without this attribute evpn srv6 functionality can not be achieved

Attribute Name: enabled

Attribute Type: empty

Netconf edit-config payload

```
<evpn-srv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-srv6">
<global>
<config>
  </enabled>
</config>
</global>
</evpn-srv6>
```

Command Syntax

```
evpn srv6 enable
```

Configure vtep ipv6 address

Use this attribute to set source vtep global ip address. This will be treated at evpn srv6 tunnel source address

Attribute Name: vtep-ipv6-address

Attribute Type: inet:ipv6-address

Netconf edit-config payload

```
<evpn-srv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-srv6">
<global>
<config>
  <vtep-ipv6-address>X:X::X:X</vtep-ipv6-address> <!-- operation="delete"-->
</config>
</global>
</evpn-srv6>
```

Command Syntax

```
evpn srv6 ip-global X:X::X:X
```

Configure tenant identifier

Tenant Identifier

Attribute Name: tenant-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```
<evpn-srv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-srv6">
<tenants>
<tenant> <!-- operation="delete"-->
  <tenant-identifier>1</tenant-identifier>
<config>
  <tenant-identifier>1</tenant-identifier>
</config>
</tenant>
</tenants>
```

```
</evpn-srv6>
```

Command Syntax

```
evpn srv6 id <1-16777215>
```

Configure vpws identifier

Tenant Identifier

Attribute Name: tenant-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Attribute Name: vpws-identifier

Attribute Type: uint32

Attribute Range: 1-16777215

Netconf edit-config payload

```
<evpn-srv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-srv6">
  <tenants>
    <tenant>
      <tenant-identifier>1</tenant-identifier>
      <config>
        <tenant-identifier>1</tenant-identifier>
        <vpws-identifier>1</vpws-identifier>
      </config>
    </tenant>
  </tenants>
</evpn-srv6>
```

Command Syntax

```
evpn srv6 id <1-16777215> xconnect target-srv6-id <1-16777215>
```

Configure vrf name

Use this attribute to map vrf to carry EVPN routes

Attribute Name: vrf-name

Attribute Type: string

Attribute Range: 1-32

Netconf edit-config payload

```
<evpn-srv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-srv6">
  <tenants>
    <tenant>
      <tenant-identifier>1</tenant-identifier>
      <config>
        <tenant-identifier>1</tenant-identifier>
      </config>
    </tenant>
  </tenants>
</evpn-srv6>
```

```

    <vrf-name>VRF-NAME</vrf-name> <!-- operation="delete"-->
  </tenant>
</tenants>
</evpn-srv6>

```

Command Syntax

```
host-reachability-protocol evpn-bgp VRF-NAME
```

Configure tenant description

Use this attribute to set evpn-srv6 tenant identifier name

Attribute Name: tenant-description

Attribute Type: string

Netconf edit-config payload

```

<evpn-srv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-srv6">
  <tenants>
    <tenant>
      <tenant-identifier>1</tenant-identifier>
      <config>
        <tenant-identifier>1</tenant-identifier>
      </config>
      <tenant-description>WORD</tenant-description> <!-- operation="delete"-->
    </tenant>
  </tenants>
</evpn-srv6>

```

Command Syntax

```
evi-name WORD
```

Configure tunnel policy name

Transport Tunnel Selection Policy

Attribute Name: tunnel-policy-name

Attribute Type: string

Attribute Range: 1-127

Netconf edit-config payload

```

<evpn-srv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-srv6">
  <tenants>
    <tenant>
      <tenant-identifier>1</tenant-identifier>
      <config>
        <tenant-identifier>1</tenant-identifier>
      </config>
      <tunnel-policy-name>WORD</tunnel-policy-name> <!-- operation="delete"-->
    </tenant>
  </tenants>
</evpn-srv6>

```

```
</tenants>  
</evpn-srv6>
```

Command Syntax

```
tunnel-select-policy WORD
```

Configure srv6 locator name

Locator name

Attribute Name: srv6-locator-name

Attribute Type: string

Netconf edit-config payload

```
<evpn-srv6 xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-evpn-srv6">  
<tenants>  
<tenant>  
  <tenant-identifier>1</tenant-identifier>  
  <config>  
    <tenant-identifier>1</tenant-identifier>  
  </config>  
  <srv6-locator-name>WORD</srv6-locator-name> <!-- operation="delete"-->  
</tenant>  
</tenants>  
</evpn-srv6>
```

Command Syntax

```
locator WORD
```

IPI-SEGMENT-ROUTING-ODN

Configure color

Color associated with ODN

Attribute Name: color

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">  
<traffic-engineering>  
  <on-demand-nexthops>  
    <on-demand-nexthop> <!-- operation="delete"-->  
      <color>1</color>  
    <config>  
      <color>1</color>  
    </config>
```

```

    </on-demand-nexthop>
</on-demand-nexthops>
</traffic-engineering>
</segment-routing>

```

Command Syntax

```
on-demand-nexthop <1-4294967295>
```

Configure cspf retry limit

Limit on the number of times a dynamic candidate path will retry to calculate segment-list

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: cspf-retry-limit

Attribute Type: uint16

Attribute Range: 1-65535

Netconf edit-config payload

```

<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <on-demand-nexthops>
      <on-demand-nexthop>
        <color>1</color>
        <config>
          <color>1</color>
        </config>
        <cspf-retry-limit>1</cspf-retry-limit> <!-- operation="delete"-->
      </on-demand-nexthop>
    </on-demand-nexthops>
  </traffic-engineering>
</segment-routing>

```

Command Syntax

```
cspf-retry-limit <1-65535>
```

Configure cspf retry interval

Interval between two successive retries for calculating segment list of a dynamic candidate path using CSPF

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: cspf-retry-interval

Attribute Type: uint16

Attribute Range: 1-600

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
```

```
<traffic-engineering>
  <on-demand-nexthops>
    <on-demand-nexthop>
      <color>1</color>
      <config>
        <color>1</color>
      </config>
      <cspf-retry-interval>1</cspf-retry-interval> <!-- operation="delete"-->
    </on-demand-nexthop>
  </on-demand-nexthops>
</traffic-engineering>
</segment-routing>
```

Command Syntax

```
cspf-retry-interval <1-600>
```

Configure pce lsp delegate

To delegate all the configured candidate path of policy to PCE controller

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: pce-lsp-delegate

Attribute Type: empty

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <on-demand-nexthops>
      <on-demand-nexthop>
        <color>1</color>
        <config>
          <color>1</color>
        </config>
        </pce-lsp-delegate><!-- operation="delete"-->
      </on-demand-nexthop>
    </on-demand-nexthops>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
pce lsp-delegate
```

Configure pce state report

To only report all the configured candidate path of policy to PCE controller

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: pce-state-report

Attribute Type: empty

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <on-demand-nexthops>
      <on-demand-nexthop>
        <color>1</color>
        <config>
          <color>1</color>
        </config>
      </on-demand-nexthop>
    </on-demand-nexthops>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
pce state-report
```

Configure pce entity id

Entity Id of PCEP entity to which this policy should be queried/reported/delegated

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: pce-entity-id

Attribute Type: uint8

Attribute Range: 1-255

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <on-demand-nexthops>
      <on-demand-nexthop>
        <color>1</color>
        <config>
          <color>1</color>
        </config>
      <pce-entity-id>1</pce-entity-id> <!-- operation="delete"-->
    </on-demand-nexthop>
  </on-demand-nexthops>
</traffic-engineering>
</segment-routing>
```

Command Syntax

```
pce entity <1-255>
```

Configure binding sid label

Configurable Value for static binding SID

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: binding-sid-label

Attribute Type: uint16

Attribute Range: 16-15999

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <on-demand-nexthops>
      <on-demand-nexthop>
        <color>1</color>
        <config>
          <color>1</color>
        </config>
        <binding-sid-label>16</binding-sid-label> <!-- operation="delete"-->
      </on-demand-nexthop>
    </on-demand-nexthops>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
binding-sid mpls label <16-15999>
```

Configure discriminator

Candidate path distinguisher, it's taken as a unique identifier for a Local candidate path

Attribute Name: discriminator

Attribute Type: uint32

Attribute Range: 1-65535

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <on-demand-nexthops>
      <on-demand-nexthop>
        <color>1</color>
        <config>
          <color>1</color>
        </config>
        <candidate-paths>
          <candidate-path> <!-- operation="delete"-->
            <originator>WORD</originator>
          </candidate-path>
        </candidate-paths>
      </on-demand-nexthop>
    </on-demand-nexthops>
  </traffic-engineering>
</segment-routing>
```

```

        <originator>WORD</originator>
        <protocol-origin>local</protocol-origin>
        <discriminator>1</discriminator>
    </config>
    <protocol-origin>local</protocol-origin>
    <discriminator>1</discriminator>
</candidate-path>
</candidate-paths>
</on-demand-nexthop>
</on-demand-nexthops>
</traffic-engineering>
</segment-routing>

```

Command Syntax

```
candidate-path <1-65535>
```

Configure preference

Candidate path preference

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: preference

Attribute Type: uint16

Default Value: 100

Attribute Range: 1-65535

Netconf edit-config payload

```

<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
<traffic-engineering>
  <on-demand-nexthops>
    <on-demand-nexthop>
      <color>1</color>
      <config>
        <color>1</color>
      </config>
      <candidate-paths>
        <candidate-path>
          <originator>WORD</originator>
          <config>
            <originator>WORD</originator>
            <protocol-origin>local</protocol-origin>
            <discriminator>1</discriminator>
          </config>
            <protocol-origin>pcep</protocol-origin>
            <discriminator>1</discriminator>
            <preference>1</preference> <!-- operation="delete"-->
        </candidate-path>
      </candidate-paths>

```

```
</on-demand-nexthop>  
</on-demand-nexthops>  
</traffic-engineering>  
</segment-routing>
```

Command Syntax

```
preference <1-65535>
```

Configure pcep

Dynamic candidate path properties of PCEP

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: pcep

Attribute Type: empty

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">  
<traffic-engineering>  
  <on-demand-nexthops>  
    <on-demand-nexthop>  
      <color>1</color>  
      <config>  
        <color>1</color>  
      </config>  
      <candidate-paths>  
        <candidate-path>  
          <originator>WORD</originator>  
          <config>  
            <originator>WORD</originator>  
            <protocol-origin>local</protocol-origin>  
            <discriminator>1</discriminator>  
          </config>  
          <protocol-origin>pcep</protocol-origin>  
          <discriminator>1</discriminator>  
          <dynamic>  
            <config>  
              </pcep><!-- operation="delete"-->  
            </config>  
          </dynamic>  
        </candidate-path>  
      </candidate-paths>  
    </on-demand-nexthop>  
  </on-demand-nexthops>  
</traffic-engineering>  
</segment-routing>
```

Command Syntax

```
dynamic-path pcep
```

Configure isis instance id

Dynamic candidate path properties of ISIS

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: isis-instance-id

Attribute Type: string

Default Value: ""

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <on-demand-nexthops>
      <on-demand-nexthop>
        <color>1</color>
        <config>
          <color>1</color>
        </config>
        <candidate-paths>
          <candidate-path>
            <originator>WORD</originator>
            <config>
              <originator>WORD</originator>
              <protocol-origin>local</protocol-origin>
              <discriminator>1</discriminator>
            </config>
            <protocol-origin>pcep</protocol-origin>
            <discriminator>1</discriminator>
            <dynamic>
              <config>
                <isis-instance-id>WORD</isis-instance-id> <!-- operation="delete"-->
              </config>
            </dynamic>
          </candidate-path>
        </candidate-paths>
      </on-demand-nexthop>
    </on-demand-nexthops>
  </traffic-engineering>
</segment-routing>
```

Command Syntax

```
dynamic-path isis (WORD|)
```

Configure ospf process id

Dynamic candidate path properties of OSPF with process-id

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: ospf-process-id

Attribute Type: int32

Attribute Range: 0-65535

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <on-demand-nexthops>
      <on-demand-nexthop>
        <color>1</color>
        <config>
          <color>1</color>
        </config>
        <candidate-paths>
          <candidate-path>
            <originator>WORD</originator>
            <config>
              <originator>WORD</originator>
              <protocol-origin>local</protocol-origin>
              <discriminator>1</discriminator>
            </config>
            <protocol-origin>pcep</protocol-origin>
            <discriminator>1</discriminator>
          <dynamic>
            <config>
              <ospf-process-id>0</ospf-process-id> <!-- operation="delete"-->
            </config>
          </dynamic>
        </candidate-path>
      </candidate-paths>
    </on-demand-nexthop>
  </on-demand-nexthops>
</traffic-engineering>
</segment-routing>
```

Command Syntax

```
dynamic-path ospf <0-65535>
```

Configure ospf empty

Dynamic candidate path properties of OSPF without process-id

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: ospf-empty

Attribute Type: empty

Netconf edit-config payload

```

<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
<traffic-engineering>
  <on-demand-nexthops>
  <on-demand-nexthop>
    <color>1</color>
    <config>
      <color>1</color>
    </config>
  <candidate-paths>
  <candidate-path>
    <originator>WORD</originator>
    <config>
      <originator>WORD</originator>
      <protocol-origin>local</protocol-origin>
      <discriminator>1</discriminator>
    </config>
    <protocol-origin>pcep</protocol-origin>
    <discriminator>1</discriminator>
    <dynamic>
    <config>
      </ospf-empty><!-- operation="delete"-->
    </config>
    </dynamic>
  </candidate-path>
</candidate-paths>
</on-demand-nexthop>
</on-demand-nexthops>
</traffic-engineering>
</segment-routing>

```

Command Syntax

```
dynamic-path ospf
```

Configure enable

Enable constraints for the candidate path

Attribute Name: enable

Attribute Type: uint8

Netconf edit-config payload

```

<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
<traffic-engineering>
  <on-demand-nexthops>
  <on-demand-nexthop>
    <color>1</color>
    <config>
      <color>1</color>
    </config>

```

```
<candidate-paths>
<candidate-path>
  <originator>WORD</originator>
  <config>
    <originator>WORD</originator>
    <protocol-origin>local</protocol-origin>
    <discriminator>1</discriminator>
  </config>
  <protocol-origin>local</protocol-origin>
  <discriminator>1</discriminator>
  <dynamic>
  <constraints>
  <config>
    </enable>
  </config>
  </constraints>
</dynamic>
</candidate-path>
</candidate-paths>
</on-demand-nexthop>
</on-demand-nexthops>
</traffic-engineering>
</segment-routing>
```

Command Syntax

constraints

Configure protocol origin

Enable constraints for the candidate path

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
<traffic-engineering>
  <on-demand-nexthops>
  <on-demand-nexthop>
    <color>1</color>
    <config>
      <color>1</color>
    </config>
  <candidate-paths>
  <candidate-path>
    <originator>WORD</originator>
    <config>
      <originator>WORD</originator>
```



```

        <protocol-origin>local</protocol-origin>
        <discriminator>1</discriminator>
    </config>
    <protocol-origin>pcep</protocol-origin>
    <discriminator>1</discriminator>
    <dynamic>
    <constraints>
    <config>
        </enable>
    </config>
    </constraints>
</dynamic>
</candidate-path>
</candidate-paths>
</on-demand-nexthop>
</on-demand-nexthops>
</traffic-engineering>
</segment-routing>

```

Command Syntax

enable

Configure admin group name

admin group name

Attribute Name: admin-group-name

Attribute Type: string

Attribute Name: affinity-type

Attribute Type: enum (exclude-any|include-any|include-all)

Netconf edit-config payload

```

<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
<traffic-engineering>
  <on-demand-nexthops>
  <on-demand-nexthop>
    <color>1</color>
    <config>
      <color>1</color>
    </config>
  <candidate-paths>
  <candidate-path>
    <originator>WORD</originator>
    <config>
      <originator>WORD</originator>
      <protocol-origin>local</protocol-origin>
      <discriminator>1</discriminator>
    </config>
    <protocol-origin>local</protocol-origin>

```

```

        <discriminator>1</discriminator>
    </dynamic>
    <constraints>
    <affinity-admin-groups>
    <affinity-admin-group> <!-- operation="delete"-->
        <admin-group-name>ADMIN-GROUP-NAME</admin-group-name>
        <config>
            <admin-group-name>ADMIN-GROUP-NAME</admin-group-name>
            <affinity-type>exclude-any</affinity-type>
        </config>
    </affinity-admin-group>
    </affinity-admin-groups>
</constraints>
</dynamic>
</candidate-path>
</candidate-paths>
</on-demand-nexthop>
</on-demand-nexthops>
</traffic-engineering>
</segment-routing>

```

Command Syntax

```
affinity (exclude-any|include-any|include-all) ADMIN-GROUP-NAME
```

Configure metric type

Metric type can be IGP or TE

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: metric-type

Attribute Type: enum (igp|te)

Netconf edit-config payload

```

<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
<traffic-engineering>
    <on-demand-nexthops>
    <on-demand-nexthop>
        <color>1</color>
        <config>
            <color>1</color>
        </config>
    </on-demand-nexthop>
    </on-demand-nexthops>
    <candidate-paths>
    <candidate-path>
        <originator>WORD</originator>
        <config>
            <originator>WORD</originator>
            <protocol-origin>local</protocol-origin>
            <discriminator>1</discriminator>
        </config>
    </candidate-path>
    </candidate-paths>
</traffic-engineering>
</segment-routing>

```

```

        <protocol-origin>pcep</protocol-origin>
        <discriminator>1</discriminator>
    <dynamic>
    <constraints>
    <bounds>
    <bound> <!-- operation="delete"-->
        <metric-type>igp</metric-type>
        <config>
            <metric-type>igp</metric-type>
        </config>
    </bound>
    </bounds>
    </constraints>
</dynamic>
</candidate-path>
</candidate-paths>
</on-demand-nexthop>
</on-demand-nexthops>
</traffic-engineering>
</segment-routing>

```

Command Syntax

```
metric-type (igp|te)
```

Configure bound

Path is invalid if its metric exceeds this value, If no value is specified

This command is supported when following feature are enabled Segment-Routing Traffic Engineering using SR-Policy Feature

Attribute Name: bound

Attribute Type: uint32

Attribute Range: 1-4294967295

Netconf edit-config payload

```

<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
<traffic-engineering>
    <on-demand-nexthops>
    <on-demand-nexthop>
        <color>1</color>
        <config>
            <color>1</color>
        </config>
    <candidate-paths>
    <candidate-path>
        <originator>WORD</originator>
        <config>
            <originator>WORD</originator>
            <protocol-origin>local</protocol-origin>

```

```
        <discriminator>1</discriminator>
    </config>
    <protocol-origin>pcep</protocol-origin>
    <discriminator>1</discriminator>
    <dynamic>
    <constraints>
    <bounds>
    <bound>
        <metric-type>igp</metric-type>
        <config>
            <metric-type>igp</metric-type>
        </config>
        <bound>1</bound> <!-- operation="delete"-->
    </bound>
    </bounds>
    </constraints>
</dynamic>
</candidate-path>
</candidate-paths>
</on-demand-nexthop>
</on-demand-nexthops>
</traffic-engineering>
</segment-routing>
```

Command Syntax

```
metric-type (igp|te) bound <1-4294967295>
```

Configure address

Hop address which needs to be included in the LSP

Attribute Name: address

Attribute Type: inet:ip-address

Attribute Name: type

Attribute Type: enum (loose|strict)

Netconf edit-config payload

```
<segment-routing xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-segment-routing">
  <traffic-engineering>
    <on-demand-nexthops>
      <on-demand-nexthop>
        <color>1</color>
        <config>
          <color>1</color>
        </config>
      <candidate-paths>
      <candidate-path>
        <originator>WORD</originator>
      </candidate-path>
    </on-demand-nexthops>
  </traffic-engineering>
</segment-routing>
```

```

        <originator>WORD</originator>
        <protocol-origin>local</protocol-origin>
        <discriminator>1</discriminator>
    </config>
    <protocol-origin>local</protocol-origin>
    <discriminator>1</discriminator>
    <dynamic>
    <constraints>
    <ip>
    <include-hops>
    <include-hop> <!-- operation="delete"-->
        <address>A.B.C.D/X:X::X:X</address>
        <config>
            <address>A.B.C.D/X:X::X:X</address>
            <type>loose</type>
        </config>
    </include-hop>
    </include-hops>
    </ip>
</constraints>
</dynamic>
</candidate-path>
</candidate-paths>
</on-demand-nexthop>
</on-demand-nexthops>
</traffic-engineering>
</segment-routing>

```

Command Syntax

```
A.B.C.D/X:X::X:X (loose|strict|)
```

IPI-HOST

Configure disable service advanced vty

Use this attribute to enable advanced mode vty interface.

Attribute Name: disable-service-advanced-vty

Attribute Type: uint8

Netconf edit-config payload

```

<system-host xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-host">
  <config>
    </disable-service-advanced-vty><!-- operation="delete"-->
  </config>
</system-host>

```

Command Syntax

```
no service advanced-vty
```

Configure service passwd encryption

Use this attribute to enable password encryption.

Attribute Name: service-passwd-encryption

Attribute Type: boolean

Netconf edit-config payload

```
<system-host xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-host">
  <config>
    <service-passwd-encryption>true</service-passwd-encryption> <!--
operation="delete"-->
  </config>
</system-host>
```

Command Syntax

```
service password-encryption
```

Configure passwd encrypted

Use this attribute to provide encrypted password.

Attribute Name: passwd-encrypted

Attribute Type: uint8

Attribute Name: system-enable-passwd

Attribute Type: string

Netconf edit-config payload

```
<system-host xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-host">
  <config>
    <system-enable-passwd>LINE</system-enable-passwd> <!-- operation="delete"-->
    </passwd-encrypted><!-- operation="delete"-->
  </config>
</system-host>
```

Command Syntax

```
enable password (8|) LINE
```

Configure banner motd

Use this attribute to set the login banner for the OcnOS device.

This command is supported when following feature are enabled IMI feature

Attribute Name: banner-motd

Attribute Type: union

Netconf edit-config payload

```
<system-host xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-host">
<config>
  <banner-motd>CML_BANNER_T</banner-motd>
</config>
</system-host>
```

Command Syntax

```
banner motd (LINE|default)
```

Configure service term length

Use this attribute to set system wide terminal length.

This command is supported when following feature are enabled IMI feature

Attribute Name: service-term-length

Attribute Type: uint16

Attribute Range: 0-512

Netconf edit-config payload

```
<system-host xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-host">
<config>
  <service-term-length>0</service-term-length> <!-- operation="delete"-->
</config>
</system-host>
```

Command Syntax

```
service terminal-length <0-512>
```

IPI-TWAMP-CLIENT

Configure enable

Enables TWAMP Client

Attribute Name: enable

Attribute Type: empty

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
<client>
<config>
  </enable>
</config>
</client>
</twamp>
```

Command Syntax

```
twamp client
```

Configure maximum sessions

Maximum number of test sessions for the whole client node (default = 64)

Attribute Name: maximum-sessions

Attribute Type: uint8

Attribute Range: 0-64

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <client>
    <config>
      <maximum-sessions>0</maximum-sessions> <!-- operation="delete"-->
    </config>
  </client>
</twamp>
```

Command Syntax

```
maximum-sessions <0-64>
```

Configure maximum connections

The maximum number of connections that can be created systemwide

Attribute Name: maximum-connections

Attribute Type: uint8

Attribute Range: 0-64

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <client>
    <config>
      <maximum-connections>0</maximum-connections> <!-- operation="delete"-->
    </config>
  </client>
</twamp>
```

Command Syntax

```
maximum-connections <0-64>
```

Configure maximum sessions per connection

Maximum number of test sessions per connection (default = 1)

Attribute Name: maximum-sessions-per-connection

Attribute Type: uint8

Attribute Range: 0-64

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <client>
    <config>
      <maximum-sessions-per-connection>0</maximum-sessions-per-connection> <!--
operation="delete"-->
    </config>
  </client>
</twamp>
```

Command Syntax

```
maximum-sessions-per-connection <0-64>
```

Configure connection name

Sets client connection Name

Attribute Name: connection-name

Attribute Type: string

Attribute Range: 1-128

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <client>
    <connections>
      <connection> <!-- operation="delete"-->
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
          <connection-name>NAME</connection-name>
        </config>
        <connection-name>NAME</connection-name>
      </connection>
    </connections>
  </client>
</twamp>
```

Command Syntax

```
connection NAME (vrf-name NAME|)
```

Configure server address

Configure twamp server address to connect with client

Attribute Name: server-address

Attribute Type: union

Attribute Name: server-port

Attribute Type: union

Netconf edit-config payload

```
<twamp xmlns="http://www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <client>
    <connections>
      <connection>
        <vrf-name>NAME</vrf-name>
        <config>
          <vrf-name>WORD</vrf-name>
          <connection-name>NAME</connection-name>
          <server-port>862</server-port> <!-- operation="delete"-->
        </config>
        <connection-name>NAME</connection-name>
        <server-address>TWAMP_HOSTNAME_T</server-address>
      </connection>
    </connections>
  </client>
</twamp>
```

Command Syntax

```
server (ipv4 A.B.C.D|ipv6 X:X::X:X|HOSTNAME) (port (862|<1025-65535>)|)
```

twamp client start connection NAME (vrf WORD|) packet-count <0-1000000>

Attribute Name: connection-name

Attribute Type: string

Attribute Range: 1-128

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Attribute Name: packet-count

Attribute Type: uint32

Attribute Range: 0-1000000

Netconf RPC payload

```
<ipi-twamp-client_twamp-client-start-connection xmlns="http://
www.ipinfusion.com/yang/ocnos/ipi-twamp">
  <connection-name>NAME</connection-name>
  <vrf-name>WORD</vrf-name>
  <packet-count>0</packet-count>
</ipi-twamp-client_twamp-client-start-connection>
```

Command Syntax

```
twamp client start connection NAME (vrf WORD|) packet-count <0-1000000>
```

twamp client stop connection NAME (vrf WORD|)

Attribute Name: connection-name

Attribute Type: string

Attribute Range: 1-128

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Netconf RPC payload

```
<ipi-twamp-client_twamp-client-stop-connection xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-twamp">
  <connection-name>NAME</connection-name>
  <vrf-name>WORD</vrf-name>
</ipi-twamp-client_twamp-client-stop-connection>
```

Command Syntax

```
twamp client stop connection NAME (vrf WORD|)
```

twamp client reset connection NAME (session NAME|) (vrf WORD|)

Attribute Name: connection-name

Attribute Type: string

Attribute Range: 1-128

Attribute Name: session-name

Attribute Type: string

Attribute Range: 1-128

Attribute Name: vrf-name

Attribute Type: string

Default Value: default

Netconf RPC payload

```
<ipi-twamp-client_twamp-client-reset-session xmlns="http://www.ipinfusion.com/
yang/ocnos/ipi-twamp">
  <connection-name>NAME</connection-name>
  <session-name>NAME</session-name>
  <vrf-name>WORD</vrf-name>
</ipi-twamp-client_twamp-client-reset-session>
```

Command Syntax

```
twamp client reset connection NAME (session NAME|) (vrf WORD|)
```

module: ipi-aaa

```
+--rw aaa
  +--rw vrfs
    | +--rw vrf* [vrf-name]
    |   +--rw vrf-name          -> ../config/vrf-name
    |   +--rw config
    |     | +--rw vrf-name?      -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
    |     | +--rw authentication-method-rule?  cml-data-types:cml_line_t
    |     | +--rw accounting-method-rule?     cml-data-types:cml_line_t
    |     | +--rw authorization-method-rule?  cml-data-types:cml_line_t
    |     | +--rw enable-fallback?           empty
    |     | +--rw non-existent?              boolean
    |     | +--rw error-enable?              empty
    |     +--ro state
    |     | +--ro vrf-name?                  -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
    |     | +--ro authentication-method-rule?  cml-data-types:cml_line_t
    |     | +--ro accounting-method-rule?     cml-data-types:cml_line_t
    |     | +--ro authorization-method-rule?  cml-data-types:cml_line_t
    |     | +--ro enable-fallback?           empty
    |     | +--ro non-existent?              boolean
    |     | +--ro error-enable?              empty
    |     +--rw server-groups
    |       +--rw server-group* [group-type group-name]
    |         +--rw group-type          -> ../config/group-type
    |         +--rw group-name          -> ../config/group-name
    |         +--rw config
    |           | +--rw group-type?  ipi-aaa-types:aaa_server_grp_type_t
    |           | +--rw group-name?  string
    |           +--ro state
    |           | +--ro group-type?  ipi-aaa-types:aaa_server_grp_type_t
    |           | +--ro group-name?  string
    |           +--rw server-addresses
    |             +--rw server-address* [host-address]
    |               +--rw host-address  -> ../config/host-address
    |               +--rw config
    |                 | +--rw host-address?  cml-data-types:cml_hostname_t
    |                 +--ro state
    |                   +--ro host-address?  cml-data-types:cml_hostname_t
    +--rw aaa-authentication-console
    | +--rw config
    | | +--rw authentication-method-rule?  cml-data-types:cml_line_t
```

```

| | +--rw enable-fallback?          boolean
| | +--rw user-non-existent?       boolean
| +--ro state
|   +--ro authentication-method-rule?  cml-data-types:cml_line_t
|   +--ro enable-fallback?           boolean
|   +--ro user-non-existent?         boolean
+--rw aaa-user
| +--rw config
| | +--rw authentication-max-failure-attempts?  uint8
| | +--rw local-user-unlock-timeout?           uint16
| +--ro state
|   +--ro authentication-max-failure-attempts?  uint8
|   +--ro local-user-unlock-timeout?           uint16
+--rw debug
  +--rw config
  | +--rw enable?    empty
  +--ro state
    +--ro enable?                empty
    +--ro terminal-debug-status?  cml-data-types:cml_on_off_t

```

rpcs:

```

+---x aaa-terminal-debug-on {feature-list:HAVE_HOSTPD,feature-list:HAVE_AAA}?
+---x aaa-terminal-debug-off {feature-list:HAVE_HOSTPD,feature-list:HAVE_AAA}?
+---x aaa-clear-local-user-lockout {feature-list:HAVE_AAA}?
  +---w input
    +---w username    string

```

module: ipi-acl

```

+--rw acl
  +--rw acl-sets
  | +--rw acl-set* [name type]
  |   +--rw name          -> ../config/name
  |   +--rw type          -> ../config/type
  |   +--rw config
  |     | +--rw name?          string
  |     | +--rw type?         ipi-acl-types:acl_types_t
  |     | +--rw description?  cml-data-types:cml_line_t
  |     | +--rw ipv6-disable-default-icmpv6-rule?  empty
  |     +--ro state
  |       | +--ro name?          string
  |       | +--ro type?         ipi-acl-types:acl_types_t

```

```

|      | +---ro description?                                cml-data-types:cml_line_t
|      | +---ro ipv6-disable-default-icmpv6-rule?         empty
|      +---rw default-actions
|      | +---rw config
types:acl_default_forwarding_action_t
|      | | +---rw forwarding-action-default?             ipi-acl-
|      | +---ro state
|      |   +---ro counters
|      |     | +---ro matched-packets?                   yang:counter64
|      |     +---ro forwarding-action-default?           ipi-acl-
types:acl_default_forwarding_action_t
|      +---rw acl-entries
|      | +---rw acl-entry* [sequence-id]
|      |   +---rw sequence-id   -> ../config/sequence-id
|      |   +---rw config
|      |     | +---rw sequence-id?                       uint32
|      |     +---ro state
|      |       | +---ro sequence-id?                     uint32
|      |       +---rw ipv4
|      |         | +---rw config
|      |         | | +---rw forwarding-action?           ipi-acl-
types:acl_forwarding_action_t
|      |         | | +---rw vlan-id?                     uint16
|      |         | | +---rw source-address?               ipi-acl-
types:acl_any_ipv4_src_addr_t
|      |         | | +---rw destination-address?         ipi-acl-
types:acl_any_ipv4_dest_addr_t
|      |         | | +---rw dscp?                         ipi-acl-types:acl_dscp_t
|      |         | | +---rw precedence?                   ipi-acl-
types:acl_precedence_t
|      |         | | +---rw inner-vlan-id?                uint16
|      |         | | +---rw (protocol)?
|      |         | | | +---:(tcp)
|      |         | | | +---rw protocol-tcp?              empty
|      |         | | | +---rw tcp-source-port?           ipi-acl-
types:acl_tcp_src_port_t
|      |         | | | +---rw tcp-destination-port?      ipi-acl-
types:acl_tcp_dest_port_t
|      |         | | | +---rw tcp-flags?                 ipi-acl-
types:acl_tcp_flags_t
|      |         | | | +---:(udp)
|      |         | | | +---rw protocol-udp?              empty
|      |         | | | +---rw udp-source-port?           ipi-acl-
types:acl_udp_src_port_t
|      |         | | | +---rw udp-destination-port?      ipi-acl-
types:acl_udp_dest_port_t
|      |         | | | +---:(icmp)
|      |         | | | +---rw protocol-icmp?            empty
|      |         | | | +---:(other-protocols)
|      |         | | | +---rw protocol-name?             ipi-acl-
types:acl_ip_protocols_t
|      |         | | +---rw source-port-operator?        ipi-acl-
types:acl_src_port_operations_t

```

				+++rw lower-source-port-in-range?	uint16
				+++rw upper-source-port-in-range?	uint16
				+++rw destination-port-operator?	ipi-acl-
types:acl_dest_port_operations_t				+++rw lower-destination-port-in-range?	uint16
				+++rw upper-destination-port-in-range?	uint16
				+++ro state	
				+++ro counters	
				+++ro matched-packets?	yang:counter64
				+++ro forwarding-action?	ipi-acl-
types:acl_forwarding_action_t				+++ro vlan-id?	uint16
				+++ro source-address?	ipi-acl-
types:acl_any_ipv4_src_addr_t				+++ro destination-address?	ipi-acl-
types:acl_any_ipv4_dest_addr_t				+++ro dscp?	ipi-acl-types:acl_dscp_t
				+++ro precedence?	ipi-acl-
types:acl_precedence_t				+++ro inner-vlan-id?	uint16
				+++ro (protocol)?	
				+++:(tcp)	
				+++ro protocol-tcp?	empty
				+++ro tcp-source-port?	ipi-acl-
types:acl_tcp_src_port_t				+++ro tcp-destination-port?	ipi-acl-
types:acl_tcp_dest_port_t				+++ro tcp-flags?	ipi-acl-
types:acl_tcp_flags_t				+++:(udp)	
				+++ro protocol-udp?	empty
				+++ro udp-source-port?	ipi-acl-
types:acl_udp_src_port_t				+++ro udp-destination-port?	ipi-acl-
types:acl_udp_dest_port_t				+++:(icmp)	
				+++ro protocol-icmp?	empty
				+++:(other-protocols)	
				+++ro protocol-name?	ipi-acl-
types:acl_ip_protocols_t				+++ro source-port-operator?	ipi-acl-
types:acl_src_port_operations_t				+++ro lower-source-port-in-range?	uint16
				+++ro upper-source-port-in-range?	uint16
				+++ro destination-port-operator?	ipi-acl-
types:acl_dest_port_operations_t				+++ro lower-destination-port-in-range?	uint16
				+++ro upper-destination-port-in-range?	uint16
				+++rw ipv6 {feature-list:HAVE_IPV6}?	
				+++rw config	
				+++rw forwarding-action?	ipi-acl-
types:acl_forwarding_action_t				+++rw vlan-id?	uint16

```

| | | | +--rw source-address? ipi-acl-
types:acl_any_ipv6_src_addr_t
| | | | +--rw destination-address? ipi-acl-
types:acl_any_ipv6_dest_addr_t
| | | | +--rw dscp? ipi-acl-types:acl_dscp_t
| | | | +--rw (protocol)?
| | | | | +--:(tcp)
| | | | | +--rw protocol-tcp? empty
| | | | | +--rw tcp-source-port? ipi-acl-
types:acl_tcp_src_port_t
| | | | | +--rw tcp-destination-port? ipi-acl-
types:acl_tcp_dest_port_t
| | | | +--:(udp)
| | | | | +--rw protocol-udp? empty
| | | | | +--rw udp-source-port? ipi-acl-
types:acl_udp_src_port_t
| | | | | +--rw udp-destination-port? ipi-acl-
types:acl_udp_dest_port_t
| | | | +--:(icmp)
| | | | | +--rw protocol-icmp? empty
| | | | +--:(sctp)
| | | | | +--rw protocol-sctp? empty
| | | | | +--rw sctp-source-port? uint16
| | | | | +--rw sctp-destination-port? uint16
| | | | +--:(other-protocols)
| | | | +--rw protocol-name? ipi-acl-
types:acl_ipv6_protocols_t
| | | | +--rw source-port-operator? ipi-acl-
types:acl_src_port_operations_t
| | | | +--rw lower-source-port-in-range? uint16
| | | | +--rw upper-source-port-in-range? uint16
| | | | +--rw destination-port-operator? ipi-acl-
types:acl_dest_port_operations_t
| | | | +--rw lower-destination-port-in-range? uint16
| | | | +--rw upper-destination-port-in-range? uint16
| | | | +--ro state
| | | | +--ro counters
| | | | | +--ro matched-packets? yang:counter64
| | | | +--ro forwarding-action? ipi-acl-
types:acl_forwarding_action_t
| | | | +--ro vlan-id? uint16
| | | | +--ro source-address? ipi-acl-
types:acl_any_ipv6_src_addr_t
| | | | +--ro destination-address? ipi-acl-
types:acl_any_ipv6_dest_addr_t
| | | | +--ro dscp? ipi-acl-types:acl_dscp_t
| | | | +--ro (protocol)?
| | | | | +--:(tcp)
| | | | | +--ro protocol-tcp? empty
| | | | | +--ro tcp-source-port? ipi-acl-
types:acl_tcp_src_port_t
| | | | | +--ro tcp-destination-port? ipi-acl-
types:acl_tcp_dest_port_t
| | | | +--:(udp)

```

```

| | | | | +--ro protocol-udp? empty
| | | | | +--ro udp-source-port? ipi-acl-
types:acl_udp_src_port_t
| | | | | +--ro udp-destination-port? ipi-acl-
types:acl_udp_dest_port_t
| | | | | +---:(icmp)
| | | | | | +--ro protocol-icmp? empty
| | | | | +---:(sctp)
| | | | | | +--ro protocol-sctp? empty
| | | | | | +--ro sctp-source-port? uint16
| | | | | | +--ro sctp-destination-port? uint16
| | | | | +---:(other-protocols)
| | | | | +--ro protocol-name? ipi-acl-
types:acl_ipv6_protocols_t
| | | | | +--ro source-port-operator? ipi-acl-
types:acl_src_port_operations_t
| | | | | +--ro lower-source-port-in-range? uint16
| | | | | +--ro upper-source-port-in-range? uint16
| | | | | +--ro destination-port-operator? ipi-acl-
types:acl_dest_port_operations_t
| | | | | +--ro lower-destination-port-in-range? uint16
| | | | | +--ro upper-destination-port-in-range? uint16
| | | | | +---rw arp
| | | | | +---rw config
| | | | | | +---rw forwarding-action? ipi-acl-
types:acl_forwarding_action_t
| | | | | +---rw vlan-id? uint16
| | | | | +---rw inner-vlan-id? uint16
| | | | | +---rw (source-mac-options)?
| | | | | | +---:(any-mac)
| | | | | | | +---rw source-mac-any? empty
| | | | | | +---:(host-mac)
| | | | | | | +---rw source-mac-host? ipi-acl-types:acl_mac_addr_t
| | | | | | | +---:(mac-with-mask)
| | | | | | | +---rw source-mac-address? ipi-acl-types:acl_mac_addr_t
| | | | | | | +---rw source-mac-mask? ipi-acl-types:acl_mac_addr_t
| | | | | | +---rw arp-packet-type? ipi-acl-types:acl_arp_type_t
| | | | | | +---rw source-ip-address? ipi-acl-
types:acl_any_ipv4_src_addr_t
| | | | | | +---rw destination-ip-address? ipi-acl-
types:acl_any_ipv4_dest_addr_t
| | | | | | +---rw (destination-mac-options)?
| | | | | | | +---:(any-mac)
| | | | | | | | +---rw destination-mac-any? empty
| | | | | | | +---:(host-mac)
| | | | | | | | +---rw destination-mac-host? ipi-acl-types:acl_mac_addr_t
| | | | | | | | +---:(mac-with-mask)
| | | | | | | | +---rw destination-mac-address? ipi-acl-
types:acl_mac_addr_t
| | | | | | | | +---rw destination-mac-mask? ipi-acl-types:acl_mac_addr_t
| | | | | | +---ro state
| | | | | | +---ro counters

```

```

| | | | +--ro matched-packets? yang:counter64
| | | | +--ro forwarding-action? ipi-acl-
types:acl_forwarding_action_t
| | | | +--ro vlan-id? uint16
| | | | +--ro inner-vlan-id? uint16
| | | | +--ro (source-mac-options)?
| | | | | +--:(any-mac)
| | | | | | +--ro source-mac-any? empty
| | | | | +--:(host-mac)
| | | | | | +--ro source-mac-host? ipi-acl-types:acl_mac_addr_t
| | | | | | +--:(mac-with-mask)
| | | | | | +--ro source-mac-address? ipi-acl-types:acl_mac_addr_t
| | | | | | +--ro source-mac-mask? ipi-acl-types:acl_mac_addr_t
| | | | | +--ro arp-packet-type? ipi-acl-types:acl_arp_type_t
| | | | | +--ro source-ip-address? ipi-acl-
types:acl_any_ipv4_src_addr_t
| | | | | +--ro destination-ip-address? ipi-acl-
types:acl_any_ipv4_dest_addr_t
| | | | | +--ro (destination-mac-options)?
| | | | | +--:(any-mac)
| | | | | | +--ro destination-mac-any? empty
| | | | | | +--:(host-mac)
| | | | | | | +--ro destination-mac-host? ipi-acl-types:acl_mac_addr_t
| | | | | | | +--:(mac-with-mask)
| | | | | | | +--ro destination-mac-address? ipi-acl-types:acl_mac_addr_t
| | | | | | | +--ro destination-mac-mask? ipi-acl-types:acl_mac_addr_t
| | | | +--rw mac
| | | | +--rw config
| | | | +--rw forwarding-action? ipi-acl-
types:acl_forwarding_action_t
| | | | +--rw vlan-id? uint16
| | | | +--rw inner-vlan-id? uint16
| | | | +--rw (source-mac-options)?
| | | | | +--:(any-mac)
| | | | | | +--rw source-mac-any? empty
| | | | | | +--:(host-mac)
| | | | | | | +--rw source-mac-host? ipi-acl-types:acl_mac_addr_t
| | | | | | | +--:(mac-with-mask)
| | | | | | | +--rw source-mac-address? ipi-acl-types:acl_mac_addr_t
| | | | | | | +--rw source-mac-mask? ipi-acl-types:acl_mac_addr_t
| | | | +--rw ethertype? ipi-acl-
types:acl_ether_type_t
| | | | +--rw arp-packet-type? ipi-acl-
types:acl_arp_packet_type_t
| | | | +--rw cos-value? uint8
| | | | +--rw (destination-mac-options)?
| | | | | +--:(any-mac)
| | | | | | +--rw destination-mac-any? empty
| | | | | | +--:(host-mac)
| | | | | | | +--rw destination-mac-host? ipi-acl-types:acl_mac_addr_t
| | | | | | | +--:(mac-with-mask)
| | | | | | | +--rw destination-mac-address? ipi-acl-types:acl_mac_addr_t

```

```

|      |      |      +--rw destination-mac-mask?      ipi-acl-types:acl_mac_addr_t
|      |      +--ro state
|      |      +--ro counters
|      |      | +--ro matched-packets?      yang:counter64
|      |      +--ro forwarding-action?      ipi-acl-
types:acl_forwarding_action_t
|      |      +--ro vlan-id?                uint16
|      |      +--ro inner-vlan-id?         uint16
|      |      +--ro (source-mac-options)?
|      |      | +--:(any-mac)
|      |      | | +--ro source-mac-any?      empty
|      |      | | +--:(host-mac)
|      |      | | +--ro source-mac-host?     ipi-acl-types:acl_mac_addr_t
|      |      | | +--:(mac-with-mask)
|      |      | +--ro source-mac-address?    ipi-acl-types:acl_mac_addr_t
|      |      | +--ro source-mac-mask?      ipi-acl-types:acl_mac_addr_t
|      |      +--ro ethertype?             ipi-acl-
types:acl_ether_type_t
|      |      +--ro arp-packet-type?        ipi-acl-
types:acl_arp_packet_type_t
|      |      +--ro cos-value?              uint8
|      |      +--ro (destination-mac-options)?
|      |      | +--:(any-mac)
|      |      | | +--ro destination-mac-any?  empty
|      |      | | +--:(host-mac)
|      |      | | +--ro destination-mac-host? ipi-acl-types:acl_mac_addr_t
|      |      | | +--:(mac-with-mask)
|      |      | +--ro destination-mac-address? ipi-acl-types:acl_mac_addr_t
|      |      | +--ro destination-mac-mask?   ipi-acl-types:acl_mac_addr_t
|      |      +--ro summary-info
|      |      +--ro state
|      |      | +--ro counters
|      |      | | +--ro total-acl-entries?    yang:counter32
|      |      | | +--ro statistics-enabled?   empty
|      |      +--ro interfaces
|      |      | +--ro interface* [interface-name]
|      |      | | +--ro interface-name      -> ../state/interface-name
|      |      | | +--ro state
name |      |      | +--ro interface-name?      -> /ipi-interface:interfaces/interface/
|      |      | +--ro filter-direction?     ipi-acl-types:acl_filter_direction_t
|      |      | +--ro interface-type?       ipi-acl-types:acl_interface_type_t
|      |      | +--ro interface-status?     ipi-acl-types:acl_interface_status_t
|      |      +--ro vty-line
|      |      +--ro state
|      |      +--ro filter-direction?       ipi-acl-types:acl_filter_direction_t
+--rw standard-acl-sets
| +--rw standard-acl-set* [name type]
|   +--rw name          -> ../config/name
|   +--rw type          -> ../config/type
|   +--rw config

```

```

|   |   +---rw name?   string
|   |   +---rw type?   ipi-acl-types:acl_standard_types_t
|   +---ro state
|   |   +---ro name?   string
|   |   +---ro type?   ipi-acl-types:acl_standard_types_t
| +---rw ipv4-acl-entries
|   |   +---rw ipv4-acl-entry* [source-address]
|   |   |   +---rw source-address   -> ../config/source-address
|   |   |   +---rw config
|   |   |   |   +---rw source-address?   ipi-acl-types:acl_any_ipv4_src_addr_t
|   |   |   |   +---rw forwarding-action   ipi-acl-types:acl_forwarding_action_t
|   |   |   +---ro state
|   |   |   |   +---ro source-address?   ipi-acl-types:acl_any_ipv4_src_addr_t
|   |   |   |   +---ro forwarding-action   ipi-acl-types:acl_forwarding_action_t
| +---rw ipv6-acl-entries {feature-list:HAVE_IPV6}?
|   |   +---rw ipv6-acl-entry* [source-address]
|   |   |   +---rw source-address   -> ../config/source-address
|   |   |   +---rw config
|   |   |   |   +---rw source-address?   ipi-acl-types:acl_any_ipv6_src_addr_t
|   |   |   |   +---rw forwarding-action   ipi-acl-types:acl_forwarding_action_t
|   |   |   +---ro state
|   |   |   |   +---ro source-address?   ipi-acl-types:acl_any_ipv6_src_addr_t
|   |   |   |   +---ro forwarding-action   ipi-acl-types:acl_forwarding_action_t
+---rw interfaces
|   +---rw interface* [name]
|   |   +---rw name           -> ../config/name
|   |   +---rw config
|   |   |   +---rw name?     -> /ipi-interface:interfaces/interface/name
|   |   +---ro state
|   |   |   +---ro name?     -> /ipi-interface:interfaces/interface/name
+---rw ingress-acl-sets
|   |   +---rw ingress-acl-set* [acl-type]
|   |   |   +---rw acl-type       -> ../config/acl-type
|   |   |   +---rw config
|   |   |   |   +---rw acl-type?   ipi-acl-types:acl_types_t
|   |   |   +---ro state
|   |   |   |   +---ro acl-type?   ipi-acl-types:acl_types_t
|   |   +---rw access-groups
|   |   |   +---rw access-group* [acl-name]
|   |   |   |   +---rw acl-name     -> ../config/acl-name
|   |   |   |   +---rw config
|   |   |   |   |   +---rw acl-name?   string
|   |   |   |   |   +---rw time-range?  string
|   |   |   |   +---ro state
|   |   |   |   |   +---ro acl-name?   string
|   |   |   |   |   +---ro time-range?  string
+---rw egress-acl-sets
|   |   +---rw egress-acl-set* [acl-type]
|   |   |   +---rw acl-type       -> ../config/acl-type
|   |   |   +---rw config

```

```

|         | +--rw acl-type?   ipi-acl-types:acl_types_t
|         +--ro state
|         | +--ro acl-type?   ipi-acl-types:acl_types_t
|         +--rw access-groups
|             +--rw access-group* [acl-name]
|                 +--rw acl-name   -> ../config/acl-name
|                 +--rw config
|                     | +--rw acl-name?   string
|                     | +--rw time-range? string
|                     +--ro state
|                         +--ro acl-name?   string
|                         +--ro time-range? string
+--rw vty-line
    +--rw ingress-acl-sets
        | +--rw ingress-acl-set* [acl-type]
        |     +--rw acl-type   -> ../config/acl-type
        |     +--rw config
        |         | +--rw acl-type?   ipi-acl-types:acl_vty_types_t
        |         | +--rw acl-name?   string
        |         +--ro state
        |             +--ro acl-type?   ipi-acl-types:acl_vty_types_t
        |             +--ro acl-name?   string
    +--rw egress-acl-sets
        +--rw egress-acl-set* [acl-type]
            +--rw acl-type   -> ../config/acl-type
            +--rw config
                | +--rw acl-type?   ipi-acl-types:acl_vty_types_t
                | +--rw acl-name?   string
            +--ro state
                +--ro acl-type?   ipi-acl-types:acl_vty_types_t
                +--ro acl-name?   string

rpcs:
+---x clear-access-list-counters-all {feature-list:HAVE_ACL}?
+---x clear-access-list-counters {feature-list:HAVE_ACL}?
| +---w input
|     +---w name   string
+---x clear-ip-access-list-counters-all {feature-list:HAVE_ACL}?
+---x clear-ip-access-list-counters {feature-list:HAVE_ACL}?
| +---w input
|     +---w name   string
+---x clear-ipv6-access-list-counters-all {feature-list:HAVE_IPV6}?
+---x clear-ipv6-access-list-counters {feature-list:HAVE_IPV6}?
| +---w input
|     +---w name   string
+---x clear-mac-access-list-counters-all {feature-list:HAVE_ACL}?
+---x clear-mac-access-list-counters {feature-list:HAVE_ACL}?
| +---w input
|     +---w name   string
+---x clear-arp-access-list-counters-all {feature-list:HAVE_ACL}?

```

```

+---x clear-arp-access-list-counters {feature-list:HAVE_ACL}?
  +---w input
    +---w name      string

```

module: ipi-alarms

```

+--rw alarms
  +--ro alarm* [id]
    +--ro id      -> ../state/id
    +--ro state
      +--ro id?           string
      +--ro resource?    string
      +--ro text?        string
      +--ro time-created? uint64
      +--ro alarm-reported-timestamp? ipi-alarms-types:alarm_date_time_t
      +--ro alarm-severity? ipi-alarms-types:alarm_severity_t
      +--ro type-id?     ipi-alarms-types:alarm_type_id_t

```

```

augment /ipi-platform:components/ipi-platform:component/ipi-platform:state:

```

```

  +--ro component-alarm
    +--ro equipment-failure?  boolean

```

```

notifications:

```

```

+---n alarm
  +--ro severity?           cml-data-types:cml_notif_severity_t
  +--ro eventClass?        cml-data-types:cml_notif_class_t
  +--ro id?                 string
  +--ro resource?          string
  +--ro text?               string
  +--ro time-created?      uint64
  +--ro alarm-reported-timestamp? ipi-alarms-types:alarm_date_time_t
  +--ro alarm-severity?    ipi-alarms-types:alarm_severity_t
  +--ro type-id?           ipi-alarms-types:alarm_type_id_t
  +--ro is-clear?          boolean

```

module: ipi-arp

```

+--rw arp
  +--rw entries
  | +--rw entry* [vrf-name ip-address]
  |   +--rw vrf-name      -> ../config/vrf-name
  |   +--rw ip-address    -> ../config/ip-address
  |   +--rw config
  |   | +--rw vrf-name?   -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name

```

```

|     | +--rw ip-address?          inet:ipv4-address
|     | +--rw mac-address          cml-data-types:cml_mac_addr_t
|     | +--rw respond-to-arp-request? empty
|     +--ro state
|       +--ro vrf-name?            -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
|       +--ro ip-address?          inet:ipv4-address
|       +--ro mac-address          cml-data-types:cml_mac_addr_t
|       +--ro respond-to-arp-request? empty
|       +--ro arp-age?             string
|       +--ro interface-name?      string
|       +--ro physical-interface-name? string
|       +--ro arp-state?           ipi-arp-types:ndd_arp_state_t
|       +--ro interface-state?     ipi-arp-types:ndd_arp_if_type_t
+--rw global {feature-list:HAVE_CUSTOM2_NDD}?
| +--rw config {feature-list:HAVE_CUSTOM2_NDD}?
| | +--rw icmp-redirect?          empty
| +--ro state {feature-list:HAVE_CUSTOM2_NDD}?
|   +--ro icmp-redirect?          empty
+--rw debug
| +--rw config
| | +--rw enable?                empty
| +--ro state
|   +--ro enable?                 empty
|   +--ro terminal-debug-status?  cml-data-types:cml_on_off_t
+--rw interfaces
| +--rw interface* [name]
|   +--rw name                    -> ../config/name
|   +--rw config
|     | +--rw name?              -> /ipi-interface:interfaces/interface/name
|     | +--rw enable-proxy-arp?  empty
|     | +--rw enable-local-proxy-arp? empty
|     | +--rw enable-ip-redirects? empty
|     | +--rw arp-ageing-timeout? uint16
|     | +--rw arp-reachable-time? uint16
|     +--ro state
|       +--ro name?              -> /ipi-interface:interfaces/interface/name
|       +--ro enable-proxy-arp?  empty
|       +--ro enable-local-proxy-arp? empty
|       +--ro enable-ip-redirects? empty
|       +--ro arp-ageing-timeout? uint16
|       +--ro arp-reachable-time? uint16
+--ro dynamic-arp* [vrf-name]
  +--ro vrf-name                  string
  +--ro entry* [ipv4-address]
    | +--ro ipv4-address          inet:ipv4-address
    | +--ro mac-address?         cml-data-types:cml_mac_addr_t
    | +--ro arp-age?             string
    | +--ro interface-name?      string
    | +--ro physical-interface-name? string
    | +--ro arp-state?           ipi-arp-types:ndd_arp_state_t

```



```

| +--ro interface-state?          ipi-arp-types:ndd_arp_if_type_t
+--ro adjacency-summary
  +--ro resolved-arp?             uint32
  +--ro incomplete-arp?          uint32
  +--ro unknown-arp?             uint32
  +--ro total-arp?               uint32

```

rpcs:

```

+---x arp-terminal-debug-on {feature-list:HAVE_L3,feature-list:HAVE_NDD}?
+---x arp-terminal-debug-off {feature-list:HAVE_L3,feature-list:HAVE_NDD}?
+---x clear-arp-entry {feature-list:HAVE_L3,feature-list:HAVE_NDD}?
| +---w input
|   +---w ip-address?            inet:ipv4-address
|   +---w vrf-name?             string
+---x clear-arp-entry-per-interface {feature-list:HAVE_L3,feature-list:HAVE_NDD}?
  +---w input
    +---w if-name                string
    +---w vrf-name?             string

```

module: ipi-authentication-radius

```

+--rw authentication-radius {feature-list:HAVE_ENCRYPT_CLEARTEXT}?
  +--rw global
  | +--rw config
  | | +--rw source-address?      inet:ipv4-address
  | | +--rw port?               uint16
  | | +--rw timeout?            uint8
  | | +--rw retransmit-max-retries? uint8
  | | +--rw (key-type)?
  | |   +--:(key-string)
  | |   | +--rw key-string?     string
  | |   +--:(encrypted)
  | |     +--rw encryption-key? string
  | +--ro state
  |   +--ro source-address?      inet:ipv4-address
  |   +--ro port?               uint16
  |   +--ro timeout?            uint8
  |   +--ro retransmit-max-retries? uint8
  |   +--ro (key-type)?
  |     +--:(key-string)
  |     | +--ro key-string?     string
  |     +--:(encrypted)
  |       +--ro encryption-key? string
  +--rw hosts
    +--rw host* [host-address]
      +--rw host-address        -> ../config/host-address

```

```

+--rw config
| +--rw host-address?          inet:ipv4-address
| +--rw host-port?            uint16
| +--rw host-timeout?         uint8
| +--rw host-retransmit-max-retries?  uint8
| +--rw (host-key-type)?
|   +--:(key-string)
|     | +--rw key-string?      string
|     +--:(encrypted)
|       +--rw encryption-key?  string
+--ro state
  +--ro host-address?          inet:ipv4-address
  +--ro host-port?            uint16
  +--ro host-timeout?         uint8
  +--ro host-retransmit-max-retries?  uint8
  +--ro (host-key-type)?
  | +--:(key-string)
  | | +--ro key-string?        string
  | +--:(encrypted)
  |   +--ro encryption-key?    string
  +--ro next-radius-message-id?  uint8
  +--ro encryption-key-operational?  string
  +--ro host-port-operational?    uint16
  +--ro host-timeout-operational?  uint8
  +--ro host-retransmit-max-retries-operational?  uint8

```

module: ipi-authentication

```

+--rw authentication {feature-list:HAVE_AUTHD}?
  +--rw global
  | +--rw config
  | | +--rw mac-authentication?  empty {feature-list:HAVE_MAC_AUTH}?
  | | +--rw dot1x-authentication?  empty
  | +--ro state
  |   +--ro mac-authentication?  empty {feature-list:HAVE_MAC_AUTH}?
  |   +--ro dot1x-authentication?  empty
+--rw dot1x-interfaces
| +--rw dot1x-interface* [name]
|   +--rw name              -> ../config/name
|   +--rw config
|     | +--rw name?          -> /ipi-interface:interfaces/interface/name
|     | +--rw dot1x-control  ipi-authentication-types:auth_dot1x_control_t
|     | +--rw protocol-version?  ipi-authentication-
types:auth_dot1x_eapol_version_t
|     +--ro state
|       | +--ro name?        -> /ipi-interface:interfaces/interface/name
|       | +--ro dot1x-control  ipi-authentication-types:auth_dot1x_control_t

```

```

| | +--ro protocol-version? ipi-authentication-
types:auth_dot1x_eapol_version_t
| | +--ro auth-dot1x-interface-operational
| | +--ro state
| | +--ro dot1x-control-operational? ipi-authentication-
types:auth_dot1x_control_t
| | +--ro supplicant-name? string
| | +--ro supplicant-mac-address? ipi-authentication-
types:auth_dot1x_mac_address_t
| | +--ro port-enabled? boolean
| | +--ro authentication-abort? boolean
| | +--ro authentication-fail? boolean
| | +--ro authentication-start? boolean
| | +--ro authentication-timeout? boolean
| | +--ro authentication-success? boolean
| | +--ro key-available? boolean
| | +--ro key-tx-enabled? boolean
| +--ro authentication-control-dir-operational
| | +--ro state
| | +--ro admin-controlled-directions? ipi-authentication-
types:auth_dot1x_control_dir_t
| | +--ro oper-controlled-directions? ipi-authentication-
types:auth_dot1x_control_dir_t
| | +--ro bridge-detected? boolean
| +--ro authentication-key-received-operational
| | +--ro state
| | +--ro rx-key? boolean
| +--rw authenticator-pae
| | +--rw config
| | | +--rw quiet-period? uint16
| | | +--rw max-reauth-value? uint8
| | | +--rw interval-period? uint16
| | +--ro state
| | +--ro quiet-period? uint16
| | +--ro max-reauth-value? uint8
| | +--ro interval-period? uint16
| +--ro auth-authenticator-pae-operational
| | +--ro state
| | +--ro quiet-period-operational? uint16
| | +--ro max-reauth-value-operational? uint8
| | +--ro interval-period-operational? uint16
| | +--ro port-status? ipi-authentication-
types:auth_dot1x_port_status_t
| | +--ro pae-state? ipi-authentication-
types:auth_dot1x_pae_state_t
| | +--ro port-mode? ipi-authentication-
types:auth_dot1x_port_ctrl_t
| | +--ro reauth-count? uint32
| | +--ro rx-response-id? uint32
| +--rw reauthentication-timer
| | +--rw config
| | | +--rw reauthentication-period? uint32

```

```

|      | | +--rw enable-reauthentication?    empty
|      | | +--rw enable-mac-auth-bypass?    ipi-authentication-
types:auth_dot1x_mac_auth_bypass_t {feature-list:HAVE_MAC_AUTH}?
|      | +--ro state
|      |   +--ro reauthentication-period?    uint32
|      |   +--ro enable-reauthentication?    empty
|      |   +--ro enable-mac-auth-bypass?    ipi-authentication-
types:auth_dot1x_mac_auth_bypass_t {feature-list:HAVE_MAC_AUTH}?
|      +--ro reauthentication-timer-operational
|      | +--ro state
|      |   +--ro reauthentication-period-operational?    uint32
|      |   +--ro enable-reauthentication-operational?    empty
|      |   +--ro dot1x-timer?                      ipi-authentication-
types:auth_mac_dot1x_timer_status_t {feature-list:HAVE_MAC_AUTH}?
|      |   +--ro mac-status?                        ipi-authentication-
types:auth_mac_status_t {feature-list:HAVE_MAC_AUTH}?
|      |   +--ro last-rejected-mac?                 ipi-authentication-
types:auth_dot1x_mac_address_t {feature-list:HAVE_MAC_AUTH}?
|      +--rw authenticator-be
|      | +--rw config
|      | | +--rw supplicant-timeout?    uint16
|      | | +--rw server-timeout?      uint16
|      | | +--ro state
|      | |   +--ro supplicant-timeout?    uint16
|      | |   +--ro server-timeout?      uint16
|      | +--ro authenticator-be-operational
|      |   +--ro state
|      |     +--ro supplicant-timeout-operational?    uint16
|      |     +--ro server-timeout-operational?      uint16
|      |     +--ro current-id?                      uint8
|      |     +--ro be-state?                        ipi-authentication-
types:auth_be_state_t
|      |     +--ro req-count?                        uint8
|      |     +--ro id-from-server?                  uint8
+--rw mac-interfaces {feature-list:HAVE_MAC_AUTH}?
| +--rw mac-interface* [name]
|   +--rw name      -> ../config/name
|   +--rw config
|   | +--rw name?          -> /ipi-interface:interfaces/interface/name
|   | +--rw mac-control    empty
|   | +--rw mac-mode?      ipi-authentication-types:auth_mac_mode_t
|   | +--rw dynamic-vlan-creation?    empty
|   | +--rw mac-address-aging?    empty
|   +--ro state
|     +--ro name?          -> /ipi-interface:interfaces/interface/name
|     +--ro mac-control    empty
|     +--ro mac-mode?      ipi-authentication-types:auth_mac_mode_t
|     +--ro dynamic-vlan-creation?    empty
|     +--ro mac-address-aging?    empty
+--rw debug
  +--rw config
  | +--rw options?    ipi-authentication-types:auth_dot1x_debug_t

```

```

+--ro state
  +--ro options?          ipi-authentication-types:auth_dot1x_debug_t
  +--ro terminal-debug-status? ipi-authentication-types:auth_dot1x_debug_t

rpcs:
+---x dot1x-authentication-initialize-interface {feature-list:HAVE_MAC_AUTH}?
| +---w input
|   +---w name      string
+---x dot1x-authentication-snmp-restart {feature-list:HAVE_SNMP}?
+---x dot1x-authentication-terminal-debug-on {feature-list:HAVE_AUTHD}?
| +---w input
|   +---w terminal-debug-options  ipi-authentication-types:auth_dot1x_debug_t
+---x dot1x-authentication-terminal-debug-off {feature-list:HAVE_AUTHD}?
  +---w input
    +---w terminal-debug-options  ipi-authentication-types:auth_dot1x_debug_t

```

module: ipi-bfd

```

+--rw bfd
  +--rw global
  | +--rw config
  | | +--rw notification-enabled?  boolean {feature-list:HAVE_BFD_MONO}?
  | | +--rw echo-mode-enabled?    empty {feature-list:HAVE_BFD_MONO}?
  | | +--rw slow-tx-interval?     uint32 {feature-list:HAVE_BFD_MONO}?
  | +--ro state
  | | +--ro notification-enabled?  boolean {feature-list:HAVE_BFD_MONO}?
  | | +--ro echo-mode-enabled?    empty {feature-list:HAVE_BFD_MONO}?
  | | +--ro slow-tx-interval?     uint32 {feature-list:HAVE_BFD_MONO}?
  | | +--ro start-time?           yang:timeticks {feature-
list:HAVE_BFD_MONO}?
  | | +--ro administrative-state?  ipi-bfd-types:oambfd_admin_state_t
{feature-list:HAVE_BFD_MONO}?
  | | +--ro image-type?           ipi-bfd-types:oambfd_image_type_t {feature-
list:HAVE_BFD_MONO}?
  | | +--ro next-session-discriminator?  string {feature-list:HAVE_BFD_MONO}?
  | | +--ro counters
  | |   +--ro total-sessions?  yang:counter32
  | +--rw intervals
  |   +--rw interval* [desired-minimum-tx-interval required-minimum-rx-interval
detection-multiplier] {feature-list:HAVE_BFD_MONO}?
  |     +--rw desired-minimum-tx-interval  -> ../config/desired-minimum-tx-
interval
  |     +--rw required-minimum-rx-interval -> ../config/required-minimum-rx-
interval
  |     +--rw detection-multiplier        -> ../config/detection-multiplier
  |     +--rw config

```

```

|         | +--rw desired-minimum-tx-interval?    uint32
|         | +--rw required-minimum-rx-interval?  uint32
|         | +--rw detection-multiplier?          uint8
|         +--ro state
|           +--ro desired-minimum-tx-interval?    uint32
|           +--ro required-minimum-rx-interval?  uint32
|           +--ro detection-multiplier?          uint8
+--rw peers
| +--rw peer* [remote-address]
|   +--rw remote-address  -> ../config/remote-address
|   +--rw config
|     | +--rw remote-address?  inet:ip-address
|     +--ro state
|     | +--ro remote-address?  inet:ip-address
|     +--rw intervals
|     | +--rw interval* [desired-minimum-tx-interval required-minimum-rx-interval
detection-multiplier] {feature-list:HAVE_BFD_MONO}?
|     |   +--rw desired-minimum-tx-interval      -> ../config/desired-minimum-tx-
interval
|     |   +--rw required-minimum-rx-interval    -> ../config/required-minimum-rx-
interval
|     |   +--rw detection-multiplier            -> ../config/detection-multiplier
|     |   +--rw config
|     |     | +--rw desired-minimum-tx-interval?    uint32
|     |     | +--rw required-minimum-rx-interval?  uint32
|     |     | +--rw detection-multiplier?          uint8
|     |     +--ro state
|     |       +--ro desired-minimum-tx-interval?    uint32
|     |       +--ro required-minimum-rx-interval?  uint32
|     |       +--ro detection-multiplier?          uint8
|     +--rw authentication
|       +--rw config
|         | +--rw key-type?          ipi-bfd-types:bfd_multihop_auth_type_t
|         | +--rw (key-option)?
|         |   +--:(key-id)
|         |     | +--rw key-id?      uint32
|         |     | +--rw key-encrypted? ipi-bfd-types:oambfd_encrypt_key_t
|         |     | +--rw key-string?  string
|         |     +--:(key-chain)
|         +--ro state
|           +--ro key-type?          ipi-bfd-types:bfd_multihop_auth_type_t
|           +--ro (key-option)?
|           +--:(key-id)
|             | +--ro key-id?      uint32
|             | +--ro key-encrypted? ipi-bfd-types:oambfd_encrypt_key_t
|             | +--ro key-string?  string
|             +--:(key-chain)
+--rw debug
| +--rw config
| | +--rw options?          ipi-bfd-types:bfd_debug_t
| | +--rw enable-oam-srv6? empty {feature-list:HAVE_SRV6}?

```

```

|   +--ro state
|     +--ro options?                ipi-bfd-types:bfd_debug_t
|     +--ro enable-oam-srv6?        empty {feature-list:HAVE_SRV6}?
|     +--ro terminal-debug-status?   ipi-bfd-types:bfd_debug_t
+--rw interfaces
|   +--rw interface* [name]
|     +--rw name                    -> ../config/name
|     +--rw config
|       | +--rw name?                -> /ipi-interface:interfaces/interface/name
|       | +--rw bfd-disabled?        empty
|       | +--rw bfd-session-type?    ipi-bfd-types:oambfd_session_type_t {feature-
list:HAVE_BFD_HW_OFFLOAD}?
|       +--ro state
|         | +--ro name?                -> /ipi-interface:interfaces/interface/name
|         | +--ro bfd-disabled?        empty
|         | +--ro bfd-session-type?    ipi-bfd-types:oambfd_session_type_t {feature-
list:HAVE_BFD_HW_OFFLOAD}?
|         | +--ro interface-index?    uint32
|         | +--ro interface-state?    ipi-bfd-types:oambfd_if_state_t
|         +--rw intervals
|           | +--rw interval* [desired-minimum-tx-interval required-minimum-rx-interval
detection-multiplier] {feature-list:HAVE_BFD_MONO}?
|           |   +--rw desired-minimum-tx-interval    -> ../config/desired-minimum-tx-
interval
|           |   +--rw required-minimum-rx-interval  -> ../config/required-minimum-rx-
interval
|           |   +--rw detection-multiplier          -> ../config/detection-multiplier
|           |   +--rw config
|           |     | +--rw desired-minimum-tx-interval?  uint32
|           |     | +--rw required-minimum-rx-interval?  uint32
|           |     | +--rw detection-multiplier?          uint8
|           |     +--ro state
|           |       +--ro desired-minimum-tx-interval?  uint32
|           |       +--ro required-minimum-rx-interval?  uint32
|           |       +--ro detection-multiplier?          uint8
|     +--rw echo
|       | +--rw config
|       |   | +--rw ipv4-source?                inet:ipv4-address
|       |   | +--rw required-minimum-tx-interval?  uint32
|       |   +--ro state
|       |     +--ro ipv4-source?                inet:ipv4-address
|       |     +--ro required-minimum-tx-interval?  uint32
|     +--rw authentication
|       | +--rw config
|       |   | +--rw key-type?                    ipi-bfd-types:bfd_multihop_auth_type_t
|       |   | +--rw (key-option)?
|       |   |   +--:(key-id)
|       |   |     | +--rw key-id?                uint32
|       |   |     | +--rw key-encrypted?        ipi-bfd-types:oambfd_encrypt_key_t
|       |   |     | +--rw key-string?          string
|       |   |     +--:(key-chain)

```

```

|   |   +---ro state
|   |     +---ro key-type?          ipi-bfd-types:bfd_multihop_auth_type_t
|   |     +---ro (key-option)?
|   |       +---:(key-id)
|   |         | +---ro key-id?      uint32
|   |         | +---ro key-encrypted? ipi-bfd-types:oambfd_encrypt_key_t
|   |         | +---ro key-string?   string
|   |         +---:(key-chain)
|   +---rw sessions
|     +---rw session* [local-address remote-address session-type]
|       +---rw local-address      -> ../config/local-address
|       +---rw remote-address     -> ../config/remote-address
|       +---rw session-type       -> ../config/session-type
|       +---rw config
|         | +---rw local-address?    inet:ip-address
|         | +---rw remote-address?   inet:ip-address
|         | +---rw session-type?     ipi-bfd-types:bfd_session_type_t
|         | +---rw administrative-down? empty
|         | +---rw non-persistent?   empty
|       +---ro state
|         +---ro local-address?      inet:ip-address
|         +---ro remote-address?     inet:ip-address
|         +---ro session-type?       ipi-bfd-types:bfd_session_type_t
|         +---ro administrative-down? empty
|         +---ro non-persistent?     empty
+---ro sessions
  +---ro session* [local-discriminator vrf-name]
    | +---ro local-discriminator  -> ../state/local-discriminator
    | +---ro vrf-name             -> ../state/vrf-name
    | +---ro state
    | | +---ro counters
    | | | +---ro packets
    | | | | +---ro ipv4
    | | | | | +---ro received?      yang:counter64
    | | | | | +---ro transmitted?   yang:counter64
    | | | | | +---ro echo-transmitted? yang:counter64
    | | | | +---ro ipv6 {feature-list:HAVE_IPV6}?
    | | | | | +---ro received?      yang:counter64
    | | | | | +---ro transmitted?   yang:counter64
    | | | | | +---ro echo-transmitted? yang:counter64
    | | | +---ro up-transitions?    yang:counter32
    | | +---ro lower-layer-type?    ipi-bfd-
types:oambfd_sess_lower_layer_t
    | | +---ro uptime?              yang:timeticks
    | | +---ro version?              uint32
    | | +---ro local-port?           inet:port-number
    | | +---ro remote-port?         inet:port-number
    | | +---ro negotiated-detection-multiplier? uint8
    | | +---ro forward-hello-timer-hits? uint32
    | | +---ro remote-heard?        empty
    | | +---ro fate-shared?         empty

```



```

| | +---ro remote-administrative-down?      empty
| | +---ro remote-demand-mode-enabled?     empty
| | +---ro remote-echo-enabled?            empty
| | +---ro poll-bit?                       empty
| | +---ro storage-type?                   ipi-bfd-types:bfd_storage_type_t
| | +---ro downtime?                       yang:timeticks
| | +---ro discontinuity-time?             yang:timeticks
| | +---ro authentication-key-id?         uint32
| | +---ro last-up-time?                   yang:timeticks
| | +---ro hold-down-timer?                uint32
| | +---ro hold-down-timer-hits?          uint32
| | +---ro session-type-status?           ipi-bfd-
types:oambfd_session_type_status_t
| | +---ro remote-address?                 inet:ip-address
| | +---ro local-address?                  inet:ip-address
| | +---ro vrf-name?                       string
| | +---ro interface-index?                uint32
| | +---ro interface-name?                 string
| | +---ro remote-discriminator?           string
| | +---ro local-discriminator?            string
| | +---ro session-state?                  ipi-bfd-
types:oambfd_session_state_t
| | +---ro session-type?                    ipi-bfd-
types:bfd_session_type_state_t
| | +---ro session-diagnostics?            ipi-bfd-
types:oambfd_perform_diag_t
| | +---ro negotiated-tx-interval?         uint32
| | +---ro negotiated-rx-interval?         uint32
| +---ro micro-bfd-sessions {feature-list:HAVE_BFD_HW_OFFLOAD}?
| | +---ro interface* [member-interface] {feature-list:HAVE_BFD_HW_OFFLOAD}?
| |     +---ro member-interface    -> ../state/member-interface
| |     +---ro state
| |     +---ro member-interface?       -> /ipi-interface:interfaces/
interface/name
| | +---ro remote-session-state?           ipi-bfd-
types:oambfd_session_state_t
| | +---ro remote-session-diagnostics?     ipi-bfd-
types:oambfd_perform_diag_t
| | +---ro interface-index?                uint32
| | +---ro interface-name?                 string
| | +---ro remote-discriminator?           string
| | +---ro local-discriminator?            string
| | +---ro session-state?                  ipi-bfd-
types:oambfd_session_state_t
| | +---ro session-type?                    ipi-bfd-
types:bfd_session_type_state_t
| | +---ro session-diagnostics?            ipi-bfd-
types:oambfd_perform_diag_t
| | +---ro negotiated-tx-interval?         uint32
| | +---ro negotiated-rx-interval?         uint32
| +---ro echo
| | +---ro state
| | +---ro local-echo-port?                inet:port-number

```

```

| |      +---ro echo-desired-minimum-tx-interval?    uint32
| |      +---ro echo-required-minimum-rx-interval?  uint32
| |      +---ro negotiated-interval?                uint32
| +---ro mpls {feature-list:HAVE_CUSTOM1_MPLS_BFD}?
| | +---ro state {feature-list:HAVE_MPLS_OAM}?
| | | +---ro fec-address?                          inet:ipv4-address
| | | +---ro lsp-type?                             ipi-bfd-types:oambfd_mpls_lsp_type_t
| | | +---ro tunnel-name?                          string
| | | +---ro tunnel-label?                         uint32
| | | +---ro ftn-index?                            uint32
| | | +---ro lsp-ping-interval?                    uint32
| | | +---ro minimum-tx?                           uint32
| | | +---ro minimum-rx?                           uint32
| | | +---ro detection-multiplier?                 uint8
| | +---ro virtual-circuit-connectivity-verification
| | | +---ro state {feature-list:HAVE_VCCV}?
| | |   +---ro vc-identifier?                       uint32
| | |   +---ro incoming-vc-label?                  uint32
| | |   +---ro outgoing-vc-label?                  uint32
| | |   +---ro control-channel-type?                ipi-bfd-
types:oambfd_mpls_cc_type_t
| | |   +---ro connectivity-verification-type?      ipi-bfd-
types:oambfd_mpls_cv_type_t
| | |   +---ro attachment-circuit-index?           uint32
| | |   +---ro tunnel-label?                       uint32
| | |   +---ro peer-address?                        inet:ipv4-address
| | +---ro transport-profile
| +---ro packet
| +---ro clients
|   +---ro client* [index]
|     +---ro index    -> ../state/index
|     +---ro state
|       +---ro index?  uint32
|       +---ro flags?  ipi-bfd-types:oambfd_client_flags_t
+---ro mpls-lsp
| +---ro summary
| | +---ro state
| | | +---ro number-of-sessions?                    uint32
| | | +---ro number-of-sessions-up?                 uint32
| | | +---ro number-of-sessions-down?               uint32
| | | +---ro number-of-sessions-admin-down?        uint32
| +---ro egress-sessions
| | +---ro egress-session* [local-discriminator]
| | | +---ro local-discriminator    -> ../state/local-discriminator
| | | +---ro state
| | |   +---ro local-multiplier?                uint32
| | |   +---ro fec-address?                     cml-data-types:cml_ipv4_addr_prefix_t
| | |   +---ro local-discriminator?             string
| | |   +---ro remote-discriminator?           string
| | |   +---ro source-port?                     inet:port-number
| | |   +---ro destination-port?               inet:port-number

```

```

|   +---ro session-groups
|       +---ro session-group* [lsp-type fec-address]
|           +---ro lsp-type      -> ../state/lsp-type
|           +---ro fec-address   -> ../state/fec-address
|           +---ro state
|               | +---ro lsp-type?      ipi-bfd-types:mpls_bfd_lsp_type_t
|               | +---ro fec-address?   cml-data-types:cml_ipv4_addr_prefix_t
|           +---ro sessions
|               +---ro session* [lsp-type]
|                   +---ro lsp-type      -> ../state/lsp-type
|                   +---ro state
|                       | +---ro lsp-type?      ipi-bfd-
types:mpls_bfd_all_lsp_type_t
|                       | +---ro ip-encapsulation?      empty
|                       | +---ro remote-multiplier?   uint32
|                       | +---ro fec-address?         cml-data-
types:cml_ipv4_addr_prefix_t
|                       | +---ro local-discriminator?  string
|                       | +---ro remote-discriminator? string
|                       | +---ro source-port?         inet:port-number
|                       | +---ro destination-port?    inet:port-number
|                       | +---ro session-index?       uint32
|                       | +---ro local-state?         ipi-bfd-
types:mpls_bfd_session_state_t
|                       | +---ro remote-state?        ipi-bfd-
types:mpls_bfd_session_state_t
|                       | +---ro local-diagnostic?    ipi-bfd-
types:mpls_bfd_diag_info_t
|                       | +---ro remote-diagnostic?   ipi-bfd-
types:mpls_bfd_diag_info_t
|                       | +---ro negotiated-tx-interval? uint32
|                       | +---ro negotiated-rx-interval? uint32
|                       +---ro statistics
|                           +---ro state
|                               +---ro create-time?      yang:timeticks
|                               +---ro last-down-time?   yang:timeticks
|                               +---ro last-up-time?     yang:timeticks
|                               +---ro down-count?       yang:counter32
|                               +---ro admin-down-count? yang:counter32
|                               +---ro receive-packet-count? yang:counter64
|                               +---ro send-packet-count? yang:counter64
+---ro mpls-te
    +---ro summary
        | +---ro state
        |     +---ro number-of-sessions?      uint32
        |     +---ro number-of-sessions-up?   uint32
        |     +---ro number-of-sessions-down?  uint32
        |     +---ro number-of-sessions-admin-down? uint32
    +---ro egress-sessions
        | +---ro egress-session* [fec-address]
        |     +---ro fec-address   -> ../state/fec-address
        |     +---ro state

```

```

|         +---ro local-multiplier?          uint32
|         +---ro fec-address?              cml-data-types:cml_ipv4_addr_prefix_t
|         +---ro local-discriminator?      string
|         +---ro remote-discriminator?     string
|         +---ro source-port?              inet:port-number
|         +---ro destination-port?         inet:port-number
+---ro mpls-tunnels
  +---ro mpls-tunnel* [lsp-type tunnel-name]
    +---ro lsp-type          -> ../state/lsp-type
    +---ro tunnel-name       -> ../state/tunnel-name
    +---ro state
      | +---ro lsp-type?      ipi-bfd-types:mpls_bfd_te_type_t
      | +---ro tunnel-name?  string
    +---ro sessions
      +---ro session* [lsp-type]
        +---ro lsp-type      -> ../state/lsp-type
        +---ro state
          | +---ro lsp-type?          ipi-bfd-
types:mpls_bfd_all_lsp_type_t
          | +---ro ip-encapsulation?  empty
          | +---ro remote-multiplier? uint32
          | +---ro fec-address?       cml-data-
types:cml_ipv4_addr_prefix_t
          | +---ro local-discriminator? string
          | +---ro remote-discriminator? string
          | +---ro source-port?       inet:port-number
          | +---ro destination-port?  inet:port-number
          | +---ro session-index?     uint32
          | +---ro local-state?       ipi-bfd-
types:mpls_bfd_session_state_t
          | +---ro remote-state?      ipi-bfd-
types:mpls_bfd_session_state_t
          | +---ro local-diagnostic?  ipi-bfd-
types:mpls_bfd_diag_info_t
          | +---ro remote-diagnostic? ipi-bfd-
types:mpls_bfd_diag_info_t
          | +---ro negotiated-tx-interval? uint32
          | +---ro negotiated-rx-interval? uint32
        +---ro statistics
          +---ro state
            +---ro create-time?       yang:timeticks
            +---ro last-down-time?    yang:timeticks
            +---ro last-up-time?      yang:timeticks
            +---ro down-count?        yang:counter32
            +---ro admin-down-count?  yang:counter32
            +---ro receive-packet-count? yang:counter64
            +---ro send-packet-count?  yang:counter64

rpcs:
  +---x bfd-snmp-restart {feature-list:HAVE_SNMP}?
  +---x bfd-terminal-debug-on {feature-list:HAVE_BFD}?
  | +---w input

```

```

|      +---w terminal-debug-options      ipi-bfd-types:bfd_debug_t
+---x bfd-terminal-debug-off {feature-list:HAVE_BFD}?
|  +---w input
|      +---w terminal-debug-options      ipi-bfd-types:bfd_debug_t
+---x debug-oam-srv6-on {feature-list:HAVE_SRV6}?
+---x debug-oam-srv6-off {feature-list:HAVE_SRV6}?

```

notifications:

```

+---n bfd-session-state-change
  +--ro severity?                cml-data-types:cml_notif_severity_t
  +--ro eventClass?              cml-data-types:cml_notif_class_t
  +--ro local-discriminator?     string
  +--ro vrf-name?                string
  +--ro session-state?           ipi-bfd-types:oambfd_session_state_t
  +--ro session-diagnostics?     ipi-bfd-types:oambfd_perform_diag_t

```

module: ipi-bgp-vrf

```

augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance/ipi-vrf:vrf:

```

```

+--rw bgp-vrf
  +--rw config
  |  +--rw import-map?   string
  |  +--rw export-map?  string
  |  +--rw rd-string?   string
  +--ro state
  |  +--ro counters
  |  |  +--ro neighbor-rx-tx-stat
  |  |  |  +--ro messages-sent?           uint32
  |  |  |  +--ro messages-received?      uint32
  |  |  |  +--ro bytes-sent?              uint32
  |  |  |  +--ro bytes-received?         uint32
  |  |  |  +--ro opens-sent?              uint32
  |  |  |  +--ro opens-received?         uint32
  |  |  |  +--ro updates-sent?            uint32
  |  |  |  +--ro updates-received?       uint32

```

```
| | | +---ro keepalive-sent?          uint32
| | | +---ro keepalive-received?      uint32
| | | +---ro notification-sent?       uint32
| | | +---ro notification-received?   uint32
| | | +---ro route-refresh-sent?      uint32
| | | +---ro route-refresh-received?  uint32
| | | +---ro capabilities-sent?       uint32
| | | +---ro capabilities-received?   uint32
| | +---ro local-input-output
| | | +---ro active-open?             uint16
| | | +---ro passive-open?           uint16
| | | +---ro open-loops?              uint16
| | | +---ro open-calls?              uint16
| | | +---ro open-received-calls?     uint16
| | | +---ro send-calls?              uint16
| | | +---ro received-calls?          uint16
| | | +---ro write-calls?             uint16
| | | +---ro write-loops?             uint16
| | | +---ro write-loops-yield?       uint16
| | | +---ro read-calls?              uint16
| | | +---ro read-loops?              uint16
| | | +---ro read-loop-yield?         uint16
| | | +---ro process-nlri-yields?     uint16
| | | +---ro process-withdraw-yields? uint16
| | | +---ro read-time-exceed?        uint16
| | | +---ro update-send-pending?     uint16
| | | +---ro update-buffer-not-available? uint16
| | | +---ro update-walk-suspend?     uint16
| | | +---ro yield-in-update?         uint16
| | | +---ro yield-in-pack?           uint16
| | | +---ro no-send-buffer-peer?     uint16
| | | +---ro no-withdraw-buffer-peer? uint16
| | | +---ro yields-in-update-peer-loop? uint16
| | | +---ro no-updates-pending-or-no-buffers? uint16
| | | +---ro no-data-to-write?        uint16
| | | +---ro message-queue-received-error? uint16
| | +---ro sockets
| | | +---ro created?                 uint32
| | | +---ro accepted?                uint32
| | | +---ro closed?                  uint32
| | | +---ro create-retries?          uint32
| | | +---ro create-failures?         uint32
| | | +---ro fd-close-session?        uint32
| +---ro import-map?   string
| +---ro export-map?   string
| +---ro rd-string?    string
+---ro next-hop-tracking
| +---ro state
| | +---ro bgp-as?          uint32
| | +---ro router-id?      inet:ipv4-address
```

```

|     +---ro configured?                boolean
|     +---ro delay-time?                uint32
|     +---ro received-message-count?    cml-data-types:cml_line_t
|     +---ro ipv4-count?                int32
|     +---ro ipv6-count?                int32
|     +---ro delay-time-remaining?      int32
+---rw route-targets
|   +---rw route-target* [rt-rd-string]
|     +---rw rt-rd-string    -> ../config/rt-rd-string
|     +---rw config
|       | +---rw rt-rd-string?    ipi-bgp-types:bgp_route_target_type_t
|       | +---rw direction       ipi-bgp-types:bgp_target_route_type_t
|       +---ro state
|         +---ro rt-rd-string?    ipi-bgp-types:bgp_route_target_type_t
|         +---ro direction       ipi-bgp-types:bgp_target_route_type_t
+---ro bgp-rd
  +---ro bgp-rd-as
  | +---ro state
  |   +---ro brd-as?            int32
  |   +---ro brd-as-number?    int32
  +---ro bgp-rd-as4
  | +---ro state
  |   +---ro brd-as4?          int32
  |   +---ro brd-as-num4?     int32
  +---ro bgp-rd-ip
  | +---ro state
  |   +---ro brd-ip?           int32
  |   +---ro brd-ip-number?    int32
augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance/ipi-vrf:vrf:
  +---rw evpn-service-type {feature-list:HAVE_MPLS,feature-list:HAVE_BGP_EVPN}?
  +---rw config
  | +---rw service-type?      cml-data-types:cml_evpn_service_type_t
  +---ro state
  | +---ro service-type?      cml-data-types:cml_evpn_service_type_t

```

module: ipi-bgp

```

+---rw bgp
  +---rw global
  | +---rw config
  | | +---rw enable-aggregate-nexthop?    empty
  | | +---rw enable-path-select?         empty
  | | +---rw disable-adj-out?            empty
  | | +---rw enable-extended-asn-capability? empty {feature-
list:HAVE_EXT_CAP_ASN}?
  | | +---rw enable-nexthop-tracking?     empty
  | | +---rw nexthop-tracking-delay?     uint8
  | | +---rw enable-rfc-1771-strict-origin? empty

```

```

| | +--rw config-type?                               ipi-bgp-types:bgp_config_t
| +--ro state
| | +--ro enable-aggregate-nexthop?                 empty
| | +--ro enable-path-select?                       empty
| | +--ro disable-adj-out?                           empty
| | +--ro enable-extended-asn-capability?           empty {feature-
list:HAVE_EXT_CAP_ASN}?
| | +--ro enable-nexthop-tracking?                   empty
| | +--ro nexthop-tracking-delay?                   uint8
| | +--ro enable-rfc-1771-strict-origin?            empty
| | +--ro config-type?                               ipi-bgp-types:bgp_config_t
| +--rw community-lists
| | +--rw numbered-lists
| | | +--rw numbered-list* [standard-number]
| | |   +--rw standard-number      -> ../config/standard-number
| | |   +--rw config
| | |     | +--rw standard-number?  uint32
| | |     +--ro state
| | |     | +--ro standard-number?  uint32
| | |     +--rw action-for-any
| | |     | +--rw config!
| | |     | | +--rw action-name     ipi-bgp-types:bgp_community_list_action_t
| | |     | +--ro state
| | |     | | +--ro action-name     ipi-bgp-types:bgp_community_list_action_t
| | |     +--rw action-list-values
| | |       +--rw action-list-value* [action-standard-number standard-number-
value]
| | |         +--rw action-standard-number  -> ../config/action-standard-
number
| | |         +--rw standard-number-value  -> ../config/standard-number-value
| | |         +--rw config
| | |         | +--rw action-standard-number?  ipi-bgp-
types:bgp_community_list_action_t
| | |         | +--rw standard-number-value?  string
| | |         +--ro state
| | |         +--ro action-standard-number?  ipi-bgp-
types:bgp_community_list_action_t
| | |         +--ro standard-number-value?  string
| | +--rw standards
| | | +--rw standard* [list-type name]
| | |   +--rw list-type      -> ../config/list-type
| | |   +--rw name           -> ../config/name
| | |   +--rw config
| | |     | +--rw list-type?  ipi-bgp-types:bgp_community_list_type_t
| | |     | +--rw name?      string
| | |     +--ro state
| | |     | +--ro list-type?  ipi-bgp-types:bgp_community_list_type_t
| | |     | +--ro name?      string
| | |     +--rw action-for-any
| | |     | +--rw config!
| | |     | | +--rw action-name     ipi-bgp-types:bgp_community_list_action_t

```



```

| | | | +--ro state
| | | | | +--ro action-name      ipi-bgp-types:bgp_community_list_action_t
| | | | +--rw action-values
| | | | | +--rw action-value* [action-name-standard community-value-standard]
| | | | | +--rw action-name-standard      -> ../config/action-name-standard
| | | | | +--rw community-value-standard  -> ../config/community-value-
standard
| | | | | +--rw config
| | | | | | +--rw action-name-standard?      ipi-bgp-
types:bgp_community_list_action_t
| | | | | | +--rw community-value-standard?  string
| | | | | +--ro state
| | | | | | +--ro action-name-standard?      ipi-bgp-
types:bgp_community_list_action_t
| | | | | | +--ro community-value-standard?  string
| | | | +--rw expanded-lists
| | | | | +--rw expanded-list* [list-type expanded-type]
| | | | | | +--rw list-type      -> ../config/list-type
| | | | | | +--rw expanded-type  -> ../config/expanded-type
| | | | | +--rw config
| | | | | | +--rw list-type?      ipi-bgp-types:bgp_expanded_list_t
| | | | | | +--rw expanded-type?  ipi-bgp-types:bgp_expanded_list_type_t
| | | | | +--ro state
| | | | | | +--ro list-type?      ipi-bgp-types:bgp_expanded_list_t
| | | | | | +--ro expanded-type?  ipi-bgp-types:bgp_expanded_list_type_t
| | | | | +--rw action-values
| | | | | | +--rw action-value* [action-expanded regular-expression-list]
| | | | | | +--rw action-expanded      -> ../config/action-expanded
| | | | | | +--rw regular-expression-list  -> ../config/regular-expression-
list
| | | | | +--rw config
| | | | | | +--rw action-expanded?      ipi-bgp-
types:bgp_community_list_action_t
| | | | | | +--rw regular-expression-list?  cml-data-types:cml_line_t
| | | | | +--ro state
| | | | | | +--ro action-expanded?      ipi-bgp-
types:bgp_community_list_action_t
| | | | | | +--ro regular-expression-list?  cml-data-types:cml_line_t
| | | | +--rw extended-community
| | | | | +--rw numbered-lists
| | | | | | +--rw numbered-list* [standard-number]
| | | | | | +--rw standard-number      -> ../config/standard-number
| | | | | +--rw config
| | | | | | +--rw standard-number?      uint32
| | | | | +--ro state
| | | | | | +--ro standard-number?      uint32
| | | | | +--rw action-values
| | | | | | +--rw action-value* [extended-action-number extended-value]
| | | | | | +--rw extended-action-number  -> ../config/extended-action-
number
| | | | | | +--rw extended-value      -> ../config/extended-value
| | | | | +--rw config

```

```

| | | | +--rw extended-action-number? ipi-bgp-
types:bgp_community_list_action_t
| | | | +--rw extended-value? cml-data-types:cml_line_t
| | | | +--ro state
| | | | +--ro extended-action-number? ipi-bgp-
types:bgp_community_list_action_t
| | | | +--ro extended-value? cml-data-types:cml_line_t
| | +--rw standards
| | | +--rw standard* [name]
| | | | +--rw name -> ../config/name
| | | | +--rw config
| | | | | +--rw name? string
| | | | +--ro state
| | | | | +--ro name? string
| | | | +--rw action-values
| | | | | +--rw action-value* [extended-action route-target-soo value]
| | | | | +--rw extended-action -> ../config/extended-action
| | | | | +--rw route-target-soo -> ../config/route-target-soo
| | | | | +--rw value -> ../config/value
| | | | +--rw config
| | | | | +--rw extended-action? ipi-bgp-
types:bgp_community_list_action_t
| | | | | +--rw route-target-soo? ipi-bgp-types:bgp_route_target_t
| | | | | +--rw value? string
| | | | | +--ro state
| | | | | +--ro extended-action? ipi-bgp-
types:bgp_community_list_action_t
| | | | | +--ro route-target-soo? ipi-bgp-types:bgp_route_target_t
| | | | | +--ro value? string
| | +--rw expanded-lists
| | | +--rw expanded-list* [list-type expanded-type]
| | | | +--rw list-type -> ../config/list-type
| | | | +--rw expanded-type -> ../config/expanded-type
| | | | +--rw config
| | | | | +--rw list-type? ipi-bgp-types:bgp_expanded_list_t
| | | | | +--rw expanded-type? ipi-bgp-types:bgp_expanded_list_type_t
| | | | +--ro state
| | | | | +--ro list-type? ipi-bgp-types:bgp_expanded_list_t
| | | | | +--ro expanded-type? ipi-bgp-types:bgp_expanded_list_type_t
| | | | +--rw action-values
| | | | | +--rw action-value* [action value]
| | | | | +--rw action -> ../config/action
| | | | | +--rw value -> ../config/value
| | | | +--rw config
| | | | | +--rw action? ipi-bgp-types:bgp_community_list_action_t
| | | | | +--rw value? cml-data-types:cml_line_t
| | | | +--ro state
| | | | | +--ro action? ipi-bgp-types:bgp_community_list_action_t
| | | | | +--ro value? cml-data-types:cml_line_t
| +--rw as-path-access-lists

```

```

| | +--rw as-path-access-list* [access-list-name access-list-action access-list-
regular-expression]
| |   +--rw access-list-name          -> ../config/access-list-name
| |   +--rw access-list-action        -> ../config/access-list-action
| |   +--rw access-list-regular-expression -> ../config/access-list-regular-
expression
| |   +--rw config
| |     | +--rw access-list-name?      string
| |     | +--rw access-list-action?    ipi-bgp-
types:bgp_community_list_action_t
| |     | +--rw access-list-regular-expression? cml-data-types:cml_line_t
| |     +--ro state
| |       +--ro access-list-name?      string
| |       +--ro access-list-action?    ipi-bgp-
types:bgp_community_list_action_t
| |       +--ro access-list-regular-expression? cml-data-types:cml_line_t
| +--rw mpls-l3vpn-label-modes
| | +--rw mpls-l3vpn-label-mode* [address-family-name vrf-name] {feature-
list:HAVE_MPLS}?
| |   +--rw address-family-name      -> ../config/address-family-name
| |   +--rw vrf-name                 -> ../config/vrf-name
| |   +--rw config
| |     | +--rw address-family-name?  ipi-bgp-types:bgp_af_config_t
| |     | +--rw vrf-name?             ipi-bgp-types:bgp_vrf_type_t {feature-
list:HAVE_MPLS}?
| |     | +--rw label-alloc-type      ipi-bgp-types:bgp_l3vpn_label_alloc_mode_t
| |     +--ro state
| |       +--ro address-family-name?  ipi-bgp-types:bgp_af_config_t
| |       +--ro vrf-name?             ipi-bgp-types:bgp_vrf_type_t {feature-
list:HAVE_MPLS}?
| |       +--ro label-alloc-type      ipi-bgp-types:bgp_l3vpn_label_alloc_mode_t
| +--rw mpls-6pe {feature-list:HAVE_MPLS,feature-list:HAVE_6PE}?
| | +--rw config
| | | +--rw enable-per-prefix-label-mode? empty
| | | +--ro state
| | |   +--ro enable-per-prefix-label-mode? empty
| +--rw debug
| | +--rw config
| | | +--rw options?                  ipi-bgp-types:bgp_debug_t
| | | +--rw update-options?          ipi-bgp-types:bgp_update_debug_t
| | +--ro state
| | | +--ro terminal-debug-status
| | | | +--ro terminal-debug-status?  ipi-bgp-types:bgp_debug_t
| | | | +--ro terminal-debug-update-status? ipi-bgp-types:bgp_update_debug_t
| | | +--ro options?                  ipi-bgp-types:bgp_debug_t
| | | +--ro update-options?           ipi-bgp-types:bgp_update_debug_t
+--rw bgp-instances
| +--rw bgp-instance* [bgp-as]
| | +--rw bgp-as                      -> ../config/bgp-as
| | +--rw config
| | | +--rw bgp-as?                    uint32
| | | +--rw router-id?                 inet:ipv4-address

```

```

|      | +--rw cluster-id?                               ipi-bgp-types:bgp_cluster_id_t
|      | +--rw local-preference?                       uint32
|      | +--rw graceful-shutdown-capable?             empty
|      | +--rw graceful-shutdown?                    empty
|      | +--rw graceful-shutdown-local-preference?    uint32
|      | +--rw inbound-route-filter-enable?          empty {feature-list:HAVE_VRF}?
|      | +--rw log-neighbor-changes?                 empty
|      | +--rw scan-interval?                        uint32
|      | +--rw best-path-dont-compare-originator?    empty
|      | +--rw no-best-path-tie-break?               empty
|      | +--rw enable-deterministic-med?             empty
|      | +--rw enforce-first-as-for-ebgp?            empty
|      | +--rw no-external-fail-over?                empty
|      | +--rw local-as-count?                       uint8
|      | +--rw no-client-route-reflection?           empty
|      | +--rw med-type?                             ipi-bgp-types:bgp_med_type_t
|      | +--rw multi-path-relax?                     empty
|      | +--rw enable-mpls-nexthop-tracking?        empty {feature-
list:HAVE_MPLS_LSP_TRACKING}?
|      | +--rw ignore-aigp-for-bestpath?             empty {feature-
list:HAVE_BGP_AIGP}?
|      | +--rw confederation
|      | | +--rw config
|      | | | +--rw identifier?                       uint32
|      | | | +--rw peer-as-number*                  uint32
|      | | +--ro state
|      | |   +--ro identifier?                       uint32
|      | |   +--ro peer-as-number*                  uint32
|      | +--rw view-lists
|      | | +--rw view-list* [view-name]
|      | |   +--rw view-name      -> ../config/view-name
|      | |   +--rw config
|      | | | +--rw view-name?   string
|      | |   +--ro state
|      | |   +--ro view-name?   string
|      | +--ro state
|      | +--ro version?                             ipi-bgp-types:bgp_version_t
|      | +--ro table-version?                       int32
|      | +--ro total-prefixes?                     int32
|      | +--ro router-run-time-ip-address?         inet:ipv4-address
|      | +--ro scan-remain-time?                   uint32
|      | +--ro bgp-as?                              uint32
|      | +--ro router-id?                          inet:ipv4-address
|      | +--ro cluster-id?                         ipi-bgp-types:bgp_cluster_id_t
|      | +--ro local-preference?                   uint32
|      | +--ro graceful-shutdown-capable?         empty
|      | +--ro graceful-shutdown?                 empty
|      | +--ro graceful-shutdown-local-preference? uint32
|      | +--ro inbound-route-filter-enable?        empty {feature-list:HAVE_VRF}?
|      | +--ro log-neighbor-changes?               empty
|      | +--ro scan-interval?                      uint32

```

```

|      | +---ro best-path-dont-compare-originator?    empty
|      | +---ro no-best-path-tie-break?              empty
|      | +---ro enable-deterministic-med?            empty
|      | +---ro enforce-first-as-for-ebgp?           empty
|      | +---ro no-external-fail-over?               empty
|      | +---ro local-as-count?                      uint8
|      | +---ro no-client-route-reflection?          empty
|      | +---ro med-type?                            ipi-bgp-types:bgp_med_type_t
|      | +---ro multi-path-relax?                    empty
|      | +---ro enable-mpls-nexthop-tracking?        empty {feature-
list:HAVE_MPLS_LSP_TRACKING}?
|      | +---ro ignore-aigp-for-bestpath?            empty {feature-
list:HAVE_BGP_AIGP}?
|      | +---rw graceful-restart
|      | | +---rw config
|      | | | +---rw enable-graceful-restart?         empty {feature-
list:HAVE_RESTART}?
|      | | | +---rw restart-time?                    uint32 {feature-
list:HAVE_RESTART}?
|      | | | +---rw stale-path-max-retention-time?   uint32 {feature-
list:HAVE_RESTART}?
|      | | | +---rw route-selection-max-defer-time?  uint32 {feature-
list:HAVE_RESTART}?
|      | | | +---rw graceful-reset?                  empty
|      | | +---ro state
|      | | +---ro enable-graceful-restart?           empty {feature-
list:HAVE_RESTART}?
|      | | +---ro restart-time?                      uint32 {feature-
list:HAVE_RESTART}?
|      | | +---ro stale-path-max-retention-time?     uint32 {feature-
list:HAVE_RESTART}?
|      | | +---ro route-selection-max-defer-time?   uint32 {feature-
list:HAVE_RESTART}?
|      | | +---ro graceful-reset?                    empty
|      | +---rw timers
|      | | +---rw config!
|      | | | +---rw keep-alive      uint16
|      | | | +---rw hold-time       uint16
|      | | +---ro state
|      | | +---ro keep-alive        uint16
|      | | +---ro hold-time         uint16
|      | +---rw route-selection
|      | | +---rw config
|      | | | +---rw always-compare-med?              empty
|      | | | +---rw ignore-as-path-length?           empty
|      | | | +---rw best-path-compare-confed?        empty
|      | | | +---rw external-compare-router-id?      empty
|      | | +---ro state
|      | | +---ro always-compare-med?                empty
|      | | +---ro ignore-as-path-length?             empty
|      | | +---ro best-path-compare-confed?         empty
|      | | +---ro external-compare-router-id?       empty
|      | +---ro route-flap-dampening

```

```

|     | +---ro state
|     |     +---ro maximum-penalty-ceil?   int32
|     |     +---ro minimum-penalty-ceil?  int32
|     +---rw administrative-distances
|     | +---rw administrative-distance* [source-ip-prefix]
|     |     +---rw source-ip-prefix    -> ../config/source-ip-prefix
|     |     +---rw config
|     |         +---rw source-ip-prefix?  cml-data-types:cml_ipv4_prefix_t
|     |         +---rw distance          uint8
|     |         +---rw access-list-name?  string
|     |     +---ro state
|     |         +---ro source-ip-prefix?  cml-data-types:cml_ipv4_prefix_t
|     |         +---ro distance          uint8
|     |         +---ro access-list-name?  string
|     +---ro rib
|     | +---ro address-family* [afi safi]
|     |     +---ro afi                -> ../state/afi
|     |     +---ro safi                -> ../state/safi
|     |     +---ro state
|     |         +---ro afi?            ipi-bgp-types:bgp_afi_type_t
|     |         +---ro safi?          ipi-bgp-types:bgp_safi_type_t
|     |     +---ro routes
|     |         +---ro route* [network-address route-distinguisher]
|     |             +---ro network-address    -> ../state/network-address
|     |             +---ro route-distinguisher -> ../state/route-distinguisher
|     |             +---ro next-hop* [next-hop-address]
|     |                 +---ro next-hop-address -> ../state/next-hop-address
|     |                 +---ro state
|     |                     +---ro next-hop-address?          ipi-bgp-
types:bgp_hostname_t
|     |                         +---ro peer-network-weight?    uint32
|     |                         +---ro flap-time-reuse-list?   string
|     |                         +---ro flap-record-duration?   string
|     |                         +---ro damp-time-to-reuse?     string
|     |                         +---ro bgp-med-value?          uint32
|     |                         +---ro bgp-as-path-string*     cml-data-
types:cml_line_t
|     |                             +---ro bgp-as-path-4-byte-string*  string
|     |                             +---ro bgp-as-path-4-byte-origin?  ipi-bgp-
types:bgp_origin_t
|     |                                 +---ro ibgp-metric-route?      int32
|     |                                 +---ro aggregate-as-route?    int32
|     |                                 +---ro aggregator-address-route? ipi-bgp-
types:bgp_hostname_t
|     |                                     +---ro network-remote-address-route? ipi-bgp-
types:bgp_hostname_t
|     |                                         +---ro originator-id-route?  ipi-bgp-
types:bgp_hostname_t
|     |                                             +---ro route-peer-address?  ipi-bgp-
types:bgp_hostname_t
|     |                                                 +---ro route-local-preference?  uint32
|     |                                                 +---ro route-prefix-label?    uint32

```

```

|         |         |         |         +---ro route-community-string?         string
|         |         |         |         +---ro cluster-list-route*           ipi-bgp-
types:bgp_hostname_t
|         |         |         |         +---ro route-penalty?                 int32
|         |         |         |         +---ro route-flap-count?             int32
|         |         |         |         +---ro last-update-route?           yang:date-and-time
|         |         |         |         +---ro reflector-client-route?       boolean
|         |         |         |         +---ro route-dampening-active?       boolean
|         |         |         |         +---ro history-route?                boolean
|         |         |         |         +---ro nexthop-valid-route?          boolean
|         |         |         |         +---ro med-flag-type-route?          boolean
|         |         |         |         +---ro valid-route?                  boolean
|         |         |         |         +---ro stale-route?                  boolean
types:bgp_ri_type_t
|         |         |         |         +---ro route-type?                 ipi-bgp-
|         |         |         |         +---ro ecmp-multi-candidate-route?    boolean
|         |         |         |         +---ro multi-installed-route?        boolean
|         |         |         |         +---ro route-synchronized-flag-route?  boolean
|         |         |         |         +---ro atomic-aggregate-route?        boolean
|         |         |         |         +---ro selected-route?               boolean
|         |         |         |         +---ro bgp-tx-path-id?                int16 {feature-
list:HAVE_BGP_ADD_PATH}?
|         |         |         |         +---ro bgp-rx-path-id?                int16 {feature-
list:HAVE_BGP_ADD_PATH}?
|         |         |         |         +---ro ipv4-multicast-capability?     string
|         |         |         |         +---ro vpnv4-unicast-capability?     string
|         |         |         |         +---ro rtfILTER-unicast-capability?   string
|         |         |         |         +---ro l2vpn-evpn-capability?         string
|         |         |         |         +---ro ipv6-unicast-capability?       string
|         |         |         |         +---ro ipv6-multicast-capability?     string
|         |         |         |         +---ro ipv6-label-unicast-capability? string
|         |         |         |         +---ro in-label?                      uint32 {feature-
list:HAVE_BGP_LU}?
|         |         |         |         +---ro out-label?                      uint32 {feature-
list:HAVE_BGP_LU}?
|         |         |         |         +---ro vrf-name?                      string {feature-
list:HAVE_MPLS}?
|         |         |         |         +---ro route-distinguisher?          string {feature-
list:HAVE_MPLS}?
|         |         |         |         +---ro state
|         |         |         |         +---ro network-address?             ipi-bgp-types:bgp_ip_network_t
|         |         |         |         +---ro route-distinguisher?         string
|         |         |         |         +---ro evpn-routes
|         |         |         |         +---ro evpn-route* [route-distinguisher]
|         |         |         |         +---ro route-distinguisher           -> ../state/route-
distinguisher
|         |         |         |         +---ro state
|         |         |         |         | +---ro route-distinguisher?       string
|         |         |         |         | +---ro vrf-name?                  string
|         |         |         |         +---ro mac-ip-route* [host-mac-address host-ip-address ethernet-
tag-identifier next-hop-address]
|         |         |         |         +---ro host-mac-address              -> ../state/host-mac-address
|         |         |         |         +---ro host-ip-address                -> ../state/host-ip-address

```

Pyang Tree

```

|       |       |       | +---ro ethernet-tag-identifier   -> ../state/ethernet-tag-
identifier
|       |       |       | +---ro next-hop-address       -> ../state/next-hop-address
|       |       |       | +---ro state
|       |       |       |   +---ro host-mac-address?         cml-data-
types:cml_mac_addr_t
|       |       |       |   +---ro host-ip-address?          inet:ip-address
|       |       |       |   +---ro ethernet-tag-identifier?   uint32
|       |       |       |   +---ro next-hop-address?         inet:ipv4-address
|       |       |       |   +---ro encapsulation-type?       string
|       |       |       |   +---ro ethernet-segment-identifier? string
|       |       |       |   +---ro l2-label?                 uint32
|       |       |       |   +---ro l3-label?                 uint32
|       |       |       | +---ro inclusive-multicast-route* [ethernet-tag-identifier
originating-router-ip-address]
|       |       |       | +---ro ethernet-tag-identifier     -> ../state/ethernet-
tag-identifier
|       |       |       | +---ro originating-router-ip-address -> ../state/originating-
router-ip-address
|       |       |       | +---ro state
|       |       |       |   +---ro ethernet-tag-identifier?   uint32
|       |       |       |   +---ro originating-router-ip-address? inet:ipv4-address
|       |       |       |   +---ro next-hop-address?         inet:ipv4-address
|       |       |       |   +---ro encapsulation-type?       string
|       |       |       | +---ro ethernet-segment-route* [ethernet-segment-identifier
originating-router-ip-address]
|       |       |       | +---ro ethernet-segment-identifier -> ../state/ethernet-
segment-identifier
|       |       |       | +---ro originating-router-ip-address -> ../state/originating-
router-ip-address
|       |       |       | +---ro state
|       |       |       |   +---ro ethernet-segment-identifier? string
|       |       |       |   +---ro originating-router-ip-address? inet:ipv4-address
|       |       |       |   +---ro next-hop-address?         inet:ipv4-address
|       |       |       |   +---ro encapsulation-type?       string
|       |       |       | +---ro ethernet-auto-discovery-route* [ethernet-segment-identifier
ethernet-tag-identifier next-hop-address]
|       |       |       | +---ro ethernet-segment-identifier -> ../state/ethernet-
segment-identifier
|       |       |       | +---ro ethernet-tag-identifier     -> ../state/ethernet-tag-
identifier
|       |       |       | +---ro next-hop-address           -> ../state/next-hop-
address
|       |       |       | +---ro state
|       |       |       |   +---ro ethernet-segment-identifier? string
|       |       |       |   +---ro ethernet-tag-identifier?   uint32
|       |       |       |   +---ro next-hop-address?         inet:ipv4-address
|       |       |       |   +---ro encapsulation-type?       string
|       |       |       |   +---ro label?                   uint32
|       |       |       | +---ro ip-prefix-route* [ethernet-segment-identifier ethernet-tag-
identifier originating-router-ip-address]
|       |       |       | +---ro ethernet-segment-identifier -> ../state/ethernet-
segment-identifier

```



```

tag-identifier |          +--ro ethernet-tag-identifier          -> ../state/ethernet-
router-ip-address |      +--ro originating-router-ip-address  -> ../state/originating-
|               |      +--ro state
|               |          +--ro ethernet-segment-identifier?  string
|               |          +--ro ethernet-tag-identifier?       uint32
|               |          +--ro originating-router-ip-address?  inet:ipv4-address
|               |          +--ro next-hop-address?               inet:ipv4-address
|               |          +--ro encapsulation-type?             string
|               |          +--ro l3-label?                       uint32
|               +--ro link-state {feature-list:HAVE_BGP_LS}?
|               |      +--ro node-nlris
|               |          +--ro node-nlri* [nlri-key]
|               |              +--ro nlri-key      -> ../state/nlri-key
|               |              +--ro state
|               |                  +--ro nlri-key?                string
|               |                  +--ro nlri-origin?            string
|               |                  +--ro protocol?               cml-data-types:cml_line_t
|               |                  +--ro nlri-identifier?        string
|               |                  +--ro nlri-bgp-as?            uint32
|               |                  +--ro bgp-router-id?          inet:ipv4-address
|               |                  +--ro local-bgp-router-id?    inet:ipv4-address {feature-
list:HAVE_BGP_EPE}?
|               |                  +--ro local-bgp-as?           uint32 {feature-
list:HAVE_BGP_EPE}?
|               |                  +--ro ospf-area-id?           inet:ipv4-address
|               |                  +--ro ospf-router-id?         inet:ipv4-address
|               |                  +--ro isis-lsp-identifier?    string
|               |                  +--ro designated-router-id?   inet:ipv4-address
|               |                  +--ro range-size?             uint32
|               |                  +--ro base-segment-identifier? uint32
|               +--ro link-nlris
|               |          +--ro link-nlri* [nlri-key]
|               |              +--ro nlri-key      -> ../state/nlri-key
|               |              +--ro state
|               |                  +--ro nlri-key?                string
|               |                  +--ro nlri-origin?            string
|               |                  +--ro protocol?               cml-data-
types:cml_line_t
|               |                  +--ro nlri-identifier?        string
|               |                  +--ro nlri-bgp-as?            uint32
|               |                  +--ro bgp-router-id?          inet:ipv4-address
|               |                  +--ro local-bgp-router-id?    inet:ipv4-address
{feature-list:HAVE_BGP_EPE}?
|               |                  +--ro local-bgp-as?           uint32 {feature-
list:HAVE_BGP_EPE}?
|               |                  +--ro ospf-area-id?           inet:ipv4-address
|               |                  +--ro ospf-router-id?         inet:ipv4-address
|               |                  +--ro isis-lsp-identifier?    string
|               |                  +--ro designated-router-id?   inet:ipv4-address
|               |                  +--ro ospf-remote-area-id?    inet:ipv4-address

```

```

|         |         |         +---ro ospf-remote-router-id?           inet:ipv4-address
|         |         |         +---ro remote-designated-router-id?    inet:ipv4-address
|         |         |         +---ro remote-isis-lsp-id?             string
list:HAVE_BGP_EPE}?
|         |         |         +---ro remote-bgp-as?                   uint32 {feature-
{feature-list:HAVE_BGP_EPE}?
|         |         |         +---ro remote-bgp-router-id?           inet:ipv4-address
|         |         |         +---ro local-interface-ip?             inet:ipv4-address
|         |         |         +---ro remote-interface-ip?           inet:ipv4-address
|         |         |         +---ro igp-metric-id?                   uint8
|         |         |         +---ro te-metric-id?                   uint8
|         |         |         +---ro adjacent-segment-identifier?     uint32
list:HAVE_BGP_EPE}?
|         |         |         +---ro peer-node-segment-identifier?    uint32 {feature-
list:HAVE_BGP_EPE}?
|         |         |         +---ro peer-set-segment-identifier?     uint32 {feature-
list:HAVE_BGP_EPE}?
|         |         |         +---ro peer-adjacency-segment-identifier? uint32 {feature-
|         |         |         +---ro prefix-nlris
|         |         |         +---ro prefix-nlri* [nlri-key]
|         |         |         +---ro nlri-key    -> ../state/nlri-key
|         |         |         +---ro state
|         |         |         +---ro nlri-key?           string
|         |         |         +---ro nlri-origin?       string
|         |         |         +---ro protocol?          cml-data-types:cml_line_t
|         |         |         +---ro nlri-identifier?   string
|         |         |         +---ro nlri-bgp-as?       uint32
|         |         |         +---ro bgp-router-id?     inet:ipv4-address
|         |         |         +---ro local-bgp-router-id? inet:ipv4-address
{feature-list:HAVE_BGP_EPE}?
|         |         |         +---ro local-bgp-as?      uint32 {feature-
list:HAVE_BGP_EPE}?
|         |         |         +---ro ospf-area-id?     inet:ipv4-address
|         |         |         +---ro ospf-router-id?   inet:ipv4-address
|         |         |         +---ro isis-lsp-identifier? string
|         |         |         +---ro ospf-route-type?   cml-data-types:cml_line_t
|         |         |         +---ro prefix?           inet:ipv4-address
|         |         |         +---ro prefix-length?    uint32
|         |         |         +---ro prefix-metric?    uint32
|         |         |         +---ro N-absolute-bit-flag? boolean
|         |         |         +---ro prefix-segment-identifier? uint32
|         +---rw allocate-label {feature-list:HAVE_BGP_LU}?
|         |         +---rw config
|         |         |         +---rw all-routes?        empty {feature-list:HAVE_BGP_LU}?
|         |         |         +---rw route-map-name?    string {feature-list:HAVE_BGP_LU}?
|         |         |         +---ro state
|         |         |         +---ro all-routes?        empty {feature-list:HAVE_BGP_LU}?
|         |         |         +---ro route-map-name?    string {feature-list:HAVE_BGP_LU}?
|         +---rw address-families
|         |         +---rw address-family* [afi safi]
|         |         +---rw afi                          -> ../config/afi
|         |         +---rw safi                         -> ../config/safi

```

```

|      |      +---rw config
|      |      |  +---rw enable-auto-summary?          empty
|      |      |  +---rw enable-additional-path-pic?    empty {feature-
list:HAVE_BGP_PIC_CORE_EDGE}?
|      |      |  +---rw enable-network-igp-sync?      empty
|      |      |  +---rw enable-igp-sync?              empty
|      |      |  +---rw afi?                            ipi-bgp-types:bgp_afi_type_t
|      |      |  +---rw safi?                            ipi-bgp-
types:bgp_safi_type_t
|      |      |  +---rw additional-path-fast-reroute?   empty {feature-
list:HAVE_BGP_PIC_CORE_EDGE}?
|      |      |  +---rw additional-paths-mode?         ipi-bgp-
types:bgp_additional_path_type_t {feature-list:HAVE_BGP_ADD_PATH}?
|      |      |  +---rw additional-path-select-all?    empty {feature-
list:HAVE_BGP_ADD_PATH}?
|      |      |  +---rw additional-paths-best-select-count? uint8 {feature-
list:HAVE_BGP_ADD_PATH}?
|      |      |  +---rw no-client-route-reflection?     empty
|      |      +---ro state
|      |      |  +---ro enable-auto-summary?          empty
|      |      |  +---ro enable-additional-path-pic?    empty {feature-
list:HAVE_BGP_PIC_CORE_EDGE}?
|      |      |  +---ro enable-network-igp-sync?      empty
|      |      |  +---ro enable-igp-sync?              empty
|      |      |  +---ro afi?                            ipi-bgp-types:bgp_afi_type_t
|      |      |  +---ro safi?                            ipi-bgp-
types:bgp_safi_type_t
|      |      |  +---ro additional-path-fast-reroute?   empty {feature-
list:HAVE_BGP_PIC_CORE_EDGE}?
|      |      |  +---ro additional-paths-mode?         ipi-bgp-
types:bgp_additional_path_type_t {feature-list:HAVE_BGP_ADD_PATH}?
|      |      |  +---ro additional-path-select-all?    empty {feature-
list:HAVE_BGP_ADD_PATH}?
|      |      |  +---ro additional-paths-best-select-count? uint8 {feature-
list:HAVE_BGP_ADD_PATH}?
|      |      |  +---ro no-client-route-reflection?     empty
|      |      +---rw network-lists
|      |      |  +---rw network-list* [local-network-prefix]
|      |      |      +---rw local-network-prefix      -> ../config/local-network-prefix
|      |      |      +---rw config
|      |      |      |  +---rw local-network-prefix?  ipi-bgp-types:bgp_ip_network_t
|      |      |      |  +---rw network-rmap-name?    string
|      |      |      |  +---rw backdoor?            empty
|      |      |      +---ro state
|      |      |          +---ro network-path-route-count?    int32
|      |      |          +---ro no-advertise-route?         string
|      |      |          +---ro no-export-route?            boolean
|      |      |          +---ro local-as-route?             boolean
|      |      |          +---ro suppress-route?             boolean
|      |      |          +---ro network-best-path-route-count? int32
|      |      |          +---ro ip-routing-table?          string
|      |      |          +---ro advertised-non-peer-group-address* ipi-bgp-
types:bgp_hostname_t

```

```

|         |         |         +---ro advertised-peer-group-name-route*   string
|         |         |         +---ro advertised-any-peer?             boolean
list:HAVE_MPLS}?
|         |         |         +---ro route-distinguisher-string?      string {feature-
types:bgp_ip_network_t
|         |         |         +---ro local-network-prefix?            ipi-bgp-
|         |         |         +---ro network-rmap-name?               string
|         |         |         +---ro backdoor?                         empty
|         |         +---rw aggregate-address-lists
|         |         |         +---rw aggregate-address-list* [aggregate-address]
|         |         |         +---rw aggregate-address    -> ../config/aggregate-address
|         |         |         +---rw config
|         |         |         |         +---rw aggregate-address?    cml-data-types:cml_ip_prefix_t
|         |         |         |         +---rw aggregate-type?      ipi-bgp-types:bgp_aggregate_type_t
|         |         |         +---ro state
|         |         |         +---ro aggregate-address?    cml-data-types:cml_ip_prefix_t
|         |         |         +---ro aggregate-type?      ipi-bgp-types:bgp_aggregate_type_t
|         |         +---rw distances
|         |         |         +---rw distance* [ebgp ibgp local]
|         |         |         +---rw ebgp      -> ../config/ebgp
|         |         |         +---rw ibgp      -> ../config/ibgp
|         |         |         +---rw local     -> ../config/local
|         |         |         +---rw config
|         |         |         |         +---rw ebgp?    uint8
|         |         |         |         +---rw ibgp?    uint8
|         |         |         |         +---rw local?   uint8
|         |         |         +---ro state
|         |         |         +---ro ebgp?    uint8
|         |         |         +---ro ibgp?    uint8
|         |         |         +---ro local?   uint8
|         |         +---rw maximum-paths
|         |         |         +---rw config
|         |         |         |         +---rw ebgp-max-path?    int32
|         |         |         |         +---rw ibgp-max-path?    int32
|         |         |         |         +---rw eibgp-max-path?   int32
|         |         |         +---ro state
|         |         |         +---ro ebgp-max-path?    int32
|         |         |         +---ro ibgp-max-path?    int32
|         |         |         +---ro eibgp-max-path?   int32
|         |         +---rw table-map {feature-list:HAVE_BGP_TABLE_MAP}?
|         |         |         +---rw config!
|         |         |         |         +---rw map-name          string {feature-list:HAVE_BGP_TABLE_MAP}?
list:HAVE_BGP_TABLE_MAP}?
|         |         |         +---ro state
|         |         |         +---ro map-name          string {feature-list:HAVE_BGP_TABLE_MAP}?
list:HAVE_BGP_TABLE_MAP}?
|         |         +---rw route-flap-dampenings
|         |         |         +---rw route-flap-dampening* [enable-dampening]
|         |         |         +---rw enable-dampening    -> ../config/enable-dampening

```

```

|         |         |         +---rw config
|         |         |         |   +---rw enable-dampening?      ipi-bgp-types:bgp_dampening_t
|         |         |         |   +---rw reach-half-life?      uint32
|         |         |         |   +---rw reuse-penalty?        uint32
|         |         |         |   +---rw suppress-penalty?     uint32
|         |         |         |   +---rw max-suppress-time?    uint32
|         |         |         |   +---rw unreach-half-life?    uint32
|         |         |         |   +---rw dampening-rmap-name?   string
|         |         |         +---ro state
|         |         |         |   +---ro enable-dampening?     ipi-bgp-types:bgp_dampening_t
|         |         |         |   +---ro reach-half-life?      uint32
|         |         |         |   +---ro reuse-penalty?        uint32
|         |         |         |   +---ro suppress-penalty?     uint32
|         |         |         |   +---ro max-suppress-time?    uint32
|         |         |         |   +---ro unreach-half-life?    uint32
|         |         |         |   +---ro dampening-rmap-name?   string
|         |         +---rw route-redistribute-lists
|         |         |   +---rw route-redistribute-list* [protocol-type]
|         |         |   +---rw protocol-type      -> ../config/protocol-type
|         |         |   +---rw config
|         |         |   |   +---rw protocol-type?          ipi-bgp-
types:bgp_redistribute_type_t
|         |         |   |   +---rw redistrib-route-map-name? string
|         |         |   +---ro state
|         |         |   |   +---ro protocol-type?          ipi-bgp-
types:bgp_redistribute_type_t
|         |         |   |   +---ro redistrib-route-map-name? string
|         |         +---rw bgp-redistributes-ospf
|         |         |   +---rw bgp-redistribute-ospf* [ospf-instance-number]
|         |         |   +---rw ospf-instance-number  -> ../config/ospf-instance-number
|         |         |   +---rw config
|         |         |   |   +---rw ospf-instance-number?    ipi-bgp-
types:cml_ospf_area_id_t
|         |         |   |   +---rw redistribute-ospf-route-map? string
|         |         |   +---ro state
|         |         |   |   +---ro ospf-instance-number?    ipi-bgp-
types:cml_ospf_area_id_t
|         |         |   |   +---ro redistribute-ospf-route-map? string
|         |         +---rw bgp-srv6 {feature-list:HAVE_SRV6}?
|         |         |   +---rw config!
|         |         |   |   +---rw bgpSRv6enable      empty
|         |         |   +---ro state
|         |         |   |   +---ro bgpSRv6enable      empty
|         |         |   +---rw locator* [bgpSRv6LocatorName]
|         |         |   |   +---rw bgpSRv6LocatorName  -> ../config/bgpSRv6LocatorName
|         |         |   |   +---rw config
|         |         |   |   |   +---rw bgpSRv6LocatorName? string
|         |         |   |   +---ro state
|         |         |   |   |   +---ro bgpSRv6LocatorName? string
|         |         +---rw peer-groups
|         |         |   +---rw peer-group* [peer-group-tag]

```

```

|      |      +---rw peer-group-tag      -> ../config/peer-group-tag
|      |      +---rw config
|      |      | +---rw peer-group-tag?      string
|      |      | +---rw peer-group-range     ipi-bgp-
types:bgp_peer_group_type_t
|      |      | +---rw group-limit?         uint8
|      |      | +---rw peer-as?            uint32
|      |      | +---rw graceful-shut?      empty
|      |      | +---rw enable-peer-bfd?    empty {feature-
list:HAVE_BFD}?
|      |      | +---rw enable-peer-bfd-multihop?  empty {feature-
list:HAVE_BFD}?
|      |      | +---rw graceful-shutdown-timer?  uint32
|      |      | +---rw peer-restart-time?      uint32 {feature-
list:HAVE_RESTART}?
|      |      | +---rw peer-description?       cml-data-types:cml_line_t
|      |      | +---rw peer-connect-interval?  uint32
|      |      | +---rw peer-as-origin-interval? uint32
|      |      | +---rw min-route-advertisement-interval? uint32
|      |      | +---rw enable-dynamic-capability? empty
|      |      | +---rw collide-established?    empty
|      |      | +---rw source-identifier?     string
|      |      | +---rw enforce-multi-hop?     empty
|      |      | +---rw neighbor-override-capability? empty
|      |      | +---rw neighbor-strict-capability-match? empty
|      |      | +---rw disallow-infinite-hold-time? empty
|      |      | +---rw disable-capability-negotiation? empty
|      |      | +---rw neighbor-passive?     empty
|      |      | +---rw peer-shutdown?        empty
|      |      | +---rw peer-shutdown-description? cml-data-types:cml_line_t
|      |      | +---rw peer-port?            uint16
|      |      | +---rw bgp-version?          uint8
|      |      | +---rw enable-ext-opt-param-len? empty
|      |      | +---rw tcp-adjust-mss?       uint16
|      |      +---ro state
|      |      | +---ro peer-group-tag?       string
|      |      | +---ro peer-group-range     ipi-bgp-
types:bgp_peer_group_type_t
|      |      | +---ro group-limit?         uint8
|      |      | +---ro peer-type?           ipi-bgp-types:bgp_peer_type_t
|      |      | +---ro peer-as?            uint32
|      |      | +---ro graceful-shut?      empty
|      |      | +---ro enable-peer-bfd?    empty {feature-
list:HAVE_BFD}?
|      |      | +---ro enable-peer-bfd-multihop?  empty {feature-
list:HAVE_BFD}?
|      |      | +---ro graceful-shutdown-timer?  uint32
|      |      | +---ro peer-restart-time?      uint32 {feature-
list:HAVE_RESTART}?
|      |      | +---ro peer-description?       cml-data-types:cml_line_t
|      |      | +---ro peer-connect-interval?  uint32
|      |      | +---ro peer-as-origin-interval? uint32

```

```

|         |         | +---ro min-route-advertisement-interval?   uint32
|         |         | +---ro enable-dynamic-capability?                       empty
|         |         | +---ro collide-established?                          empty
|         |         | +---ro source-identifier?                    string
|         |         | +---ro enforce-multi-hop?                  empty
|         |         | +---ro neighbor-override-capability?      empty
|         |         | +---ro neighbor-strict-capability-match?  empty
|         |         | +---ro disallow-infinite-hold-time?       empty
|         |         | +---ro disable-capability-negotiation?    empty
|         |         | +---ro neighbor-passive?                  empty
|         |         | +---ro peer-shutdown?                     empty
|         |         | +---ro peer-shutdown-description?         cml-data-types:cml_line_t
|         |         | +---ro peer-port?                          uint16
|         |         | +---ro bgp-version?                        uint8
|         |         | +---ro enable-ext-opt-param-len?          empty
|         |         | +---ro tcp-adjust-mss?                     uint16
|         |         +---rw timers
|         |         | +---rw config!
|         |         | | +---rw keep-alive      uint16
|         |         | | +---rw hold-time       uint16
|         |         | +---ro state
|         |         |   +---ro keep-alive      uint16
|         |         |   +---ro hold-time       uint16
|         |         +---rw ebgp-multihop
|         |         | +---rw config!
|         |         | | +---rw maximum-hop-count?  uint8
|         |         | | +---rw enabled              empty
|         |         | +---ro state
|         |         |   +---ro maximum-hop-count?  uint8
|         |         |   +---ro enabled              empty
|         |         +---rw bgp-passwords
|         |         | +---rw bgp-password* [password]
|         |         |   +---rw password  -> ../config/password
|         |         |   +---rw config
|         |         | | +---rw password?          ipi-bgp-types:bgp_md5_password_t
|         |         | | {feature-list:HAVE_TCP_MD5SIG}?
|         |         | |   +---rw auth-key-encrypt ipi-bgp-types:bgp_md5_t
|         |         | |   +---ro state
|         |         | |   +---ro password?        ipi-bgp-types:bgp_md5_password_t
|         |         | | {feature-list:HAVE_TCP_MD5SIG}?
|         |         | |   +---ro auth-key-encrypt ipi-bgp-types:bgp_md5_t
|         |         +---rw optional-as-lists
|         |         | +---rw optional-as-list* [optional-as]
|         |         |   +---rw optional-as  -> ../config/optional-as
|         |         |   +---rw config
|         |         | | +---rw optional-as?   uint32
|         |         | | +---ro state
|         |         | |   +---ro optional-as? uint32
|         |         +---rw local-as
|         |         | +---rw local-as-list* [peer-local-as]
|         |         |   +---rw peer-local-as  -> ../config/peer-local-as

```

```

|      |      |      +---rw config
|      |      |      |      +---rw peer-local-as?          uint32
|      |      |      |      +---rw no-prepend-local-as?     empty
|      |      |      |      +---rw replace-local-as?        empty
|      |      |      +---ro state
|      |      |      |      +---ro peer-local-as?          uint32
|      |      |      |      +---ro no-prepend-local-as?     empty
|      |      |      |      +---ro replace-local-as?        empty
|      |      +---rw address-families
|      |      |      +---rw address-family* [afi safi]
|      |      |      +---rw afi                             -> ../config/afi
|      |      |      +---rw safi                             -> ../config/safi
|      |      +---rw config
|      |      |      +---rw bgp-port?                        uint16
|      |      |      +---rw activate?                        empty
|      |      |      +---rw default-peer-route-map-name?    empty
|      |      |      +---rw peer-route-map-orig-name?       string
|      |      |      +---rw weight?                          uint16
|      |      |      +---rw flowspec-validation-disable?     empty {feature-
list:HAVE_BGP_FLOWSPEC}?
|      |      |      +---rw peer-route-reflector?            empty
|      |      |      +---rw peer-remove-private-as?          empty
|      |      |      +---rw no-send-community?                empty
|      |      |      +---rw no-send-community-type?           ipi-bgp-
types:bgp_send_commu_type_t
|      |      |      +---rw neighbor-attribute-unchanged?   ipi-bgp-
types:bgp_attribute_unchanged_type_t
|      |      |      +---rw orf-prefix-capability?           ipi-bgp-
types:bgp_orf_prefix_type_t
|      |      |      +---rw peer-allow-ebgp-vpn?              empty {feature-
list:HAVE_VRF}?
|      |      |      +---rw allow-as-number?                  uint32
|      |      |      +---rw capability-graceful-restart?     empty
|      |      |      +---rw unsuppress-route-map-name?       string
|      |      |      +---rw afi?                              ipi-bgp-
types:bgp_afi_type_t
|      |      |      +---rw safi?                              ipi-bgp-
types:bgp_safi_type_t
|      |      |      +---rw additional-paths-mode?           ipi-bgp-
types:bgp_peer_additional_path_type_t {feature-list:HAVE_BGP_ADD_PATH}?
|      |      |      +---rw additional-path-select-all?     empty {feature-
list:HAVE_BGP_ADD_PATH}?
|      |      |      +---rw additional-paths-best-select-count? uint8 {feature-
list:HAVE_BGP_ADD_PATH}?
|      |      |      +---rw route-server-client?             empty
|      |      |      +---rw next-hop-self?                    empty
|      |      +---ro state
|      |      |      +---ro bgp-port?                          uint16
|      |      |      +---ro activate?                          empty
|      |      |      +---ro default-peer-route-map-name?     empty
|      |      |      +---ro peer-route-map-orig-name?        string
|      |      |      +---ro weight?                            uint16

```



```

| | | | +--ro flowspec-validation-disable?          empty {feature-
list:HAVE_BGP_FLOWSPEC}?
| | | | +--ro peer-route-reflector?                empty
| | | | +--ro peer-remove-private-as?              empty
| | | | +--ro no-send-community?                   empty
| | | | +--ro no-send-community-type?              ipi-bgp-
types:bgp_send_commu_type_t
| | | | +--ro neighbor-attribute-unchanged?       ipi-bgp-
types:bgp_attribute_unchanged_type_t
| | | | +--ro orf-prefix-capability?                ipi-bgp-
types:bgp_orf_prefix_type_t
| | | | +--ro peer-allow-ebgp-vpn?                  empty {feature-
list:HAVE_VRF}?
| | | | +--ro allow-as-number?                      uint32
| | | | +--ro capability-graceful-restart?         empty
| | | | +--ro unsuppress-route-map-name?           string
| | | | +--ro afi?                                  ipi-bgp-
types:bgp_afi_type_t
| | | | +--ro safi?                                  ipi-bgp-
types:bgp_safi_type_t
| | | | +--ro additional-paths-mode?                ipi-bgp-
types:bgp_peer_additional_path_type_t {feature-list:HAVE_BGP_ADD_PATH}?
| | | | +--ro additional-path-select-all?          empty {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | +--ro additional-paths-best-select-count?   uint8 {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | +--ro route-server-client?                 empty
| | | | +--ro next-hop-self?                       empty
| | | | +--rw maximum-prefixes
| | | | | +--rw maximum-prefix* [prefix-count]
| | | | | | +--rw prefix-count    -> ../config/prefix-count
| | | | | | +--rw config
| | | | | | | +--rw prefix-count?      uint32
| | | | | | | +--rw stop-update?       empty
| | | | | | | +--rw maximum-prefix-warning? empty
| | | | | | | +--rw threshold-percentage? uint8
| | | | | | | +--rw warning-only?      empty
| | | | | +--ro state
| | | | | | +--ro prefix-count?        uint32
| | | | | | +--ro stop-update?         empty
| | | | | | +--ro maximum-prefix-warning? empty
| | | | | | +--ro threshold-percentage? uint8
| | | | | | +--ro warning-only?        empty
| | | | +--rw distribute-list-filters
| | | | | +--rw distribute-list-filter* [filter-direction]
| | | | | | +--rw filter-direction    -> ../config/filter-direction
| | | | | | +--rw config
| | | | | | | +--rw access-list-identifier string
| | | | | | | +--rw filter-direction?  ipi-bgp-
types:bgp_distribute_list_direction_t
| | | | | +--ro state
| | | | | | +--ro access-list-identifier string

```

```

|          |          |          +---ro filter-direction?          ipi-bgp-
types:bgp_distribute_list_direction_t
|          |          |          +---rw as-list-filters
|          |          |          +---rw as-list-filter* [as-list-direction]
|          |          |          +---rw as-list-direction    -> ../config/as-list-direction
|          |          |          +---rw config
|          |          |          |          +---rw as-access-list-identifier    string
|          |          |          |          +---rw as-list-direction?          ipi-bgp-
types:bgp_distribute_list_direction_t
|          |          |          +---ro state
|          |          |          +---ro as-access-list-identifier    string
|          |          |          +---ro as-list-direction?          ipi-bgp-
types:bgp_distribute_list_direction_t
|          |          |          +---rw prefix-list-filters
|          |          |          |          +---rw prefix-list-filter* [prefix-filter-direction]
|          |          |          |          +---rw prefix-filter-direction    -> ../config/prefix-filter-
direction
|          |          |          |          +---rw config
|          |          |          |          |          +---rw prefix-list-name        string
|          |          |          |          |          +---rw prefix-filter-direction? ipi-bgp-
types:bgp_distribute_list_direction_t
|          |          |          |          +---ro state
|          |          |          |          +---ro prefix-list-name        string
|          |          |          |          +---ro prefix-filter-direction? ipi-bgp-
types:bgp_distribute_list_direction_t
|          |          |          |          +---rw route-map-filters
|          |          |          |          |          +---rw route-map-filter* [route-map-direction]
|          |          |          |          |          +---rw route-map-direction    -> ../config/route-map-direction
|          |          |          |          |          +---rw config
|          |          |          |          |          |          +---rw route-map-name        string
|          |          |          |          |          |          +---rw route-map-direction? ipi-bgp-
types:bgp_distribute_list_direction_t
|          |          |          |          |          +---ro state
|          |          |          |          |          +---ro route-map-name        string
|          |          |          |          |          +---ro route-map-direction? ipi-bgp-
types:bgp_distribute_list_direction_t
|          |          |          |          +---rw peers
|          |          |          |          |          +---rw peer* [peer-address]
|          |          |          |          |          |          +---rw peer-address        -> ../config/peer-address
|          |          |          |          |          |          +---rw config
|          |          |          |          |          |          |          +---rw peer-address?          ipi-bgp-types:bgp_ip_addr_t
|          |          |          |          |          |          |          +---rw peer-as?          ipi-bgp-types:bgp_as_type_t
|          |          |          |          |          |          |          +---rw graceful-shut?          empty
|          |          |          |          |          |          |          +---rw enable-peer-bfd?          empty {feature-
list:HAVE_BFD}?
|          |          |          |          |          |          |          +---rw enable-peer-bfd-multihop?          empty {feature-
list:HAVE_BFD}?
|          |          |          |          |          |          |          +---rw graceful-shutdown-timer?          uint32
|          |          |          |          |          |          |          +---rw peer-restart-time?          uint32 {feature-
list:HAVE_RESTART}?
|          |          |          |          |          |          |          +---rw peer-description?          cml-data-types:cml_line_t
|          |          |          |          |          |          |          +---rw peer-connect-interval?          uint32
|          |          |          |          |          |          |          +---rw peer-as-origin-interval?          uint32

```

```

|         |         |   +---rw min-route-advertisement-interval?   uint32
|         |         |   +---rw enable-dynamic-capability?         empty
|         |         |   +---rw collide-established?         empty
|         |         |   +---rw source-identifier?           string
|         |         |   +---rw enforce-multi-hop?           empty
|         |         |   +---rw neighbor-override-capability? empty
|         |         |   +---rw neighbor-strict-capability-match? empty
|         |         |   +---rw disallow-infinite-hold-time?  empty
|         |         |   +---rw disable-capability-negotiation? empty
|         |         |   +---rw neighbor-passive?            empty
|         |         |   +---rw peer-shutdown?                empty
|         |         |   +---rw peer-shutdown-description?    cml-data-types:cml_line_t
|         |         |   +---rw peer-port?                    uint16
|         |         |   +---rw bgp-version?                  uint8
|         |         |   +---rw interface-name?               string
|         |         |   +---rw mapped-peer-group-tag?        string
|         |         |   +---rw enable-ext-opt-param-len?     empty
|         |         |   +---rw tcp-adjust-mss?                uint16
|         |         | +---ro state
|         |         | |   +---ro counters
|         |         | | |   +---ro notification-in?           int32
|         |         | | |   +---ro notification-out?          int32
|         |         | | |   +---ro update-message-in?         int32
|         |         | | |   +---ro update-message-out?        int32
|         |         | +---ro peer-address?                    ipi-bgp-types:bgp_ip_addr_t
|         |         | +---ro peer-as?                         ipi-bgp-types:bgp_as_type_t
|         |         |   +---ro graceful-shut?                 empty
|         |         |   +---ro enable-peer-bfd?               empty {feature-
list:HAVE_BFD}?
|         |         |   +---ro enable-peer-bfd-multihop?     empty {feature-
list:HAVE_BFD}?
|         |         |   +---ro graceful-shutdown-timer?      uint32
|         |         |   +---ro peer-restart-time?             uint32 {feature-
list:HAVE_RESTART}?
|         |         |   +---ro peer-description?              cml-data-types:cml_line_t
|         |         |   +---ro peer-connect-interval?        uint32
|         |         |   +---ro peer-as-origin-interval?      uint32
|         |         |   +---ro min-route-advertisement-interval? uint32
|         |         |   +---ro enable-dynamic-capability?    empty
|         |         |   +---ro collide-established?          empty
|         |         |   +---ro source-identifier?            string
|         |         |   +---ro enforce-multi-hop?            empty
|         |         |   +---ro neighbor-override-capability? empty
|         |         |   +---ro neighbor-strict-capability-match? empty
|         |         |   +---ro disallow-infinite-hold-time?  empty
|         |         |   +---ro disable-capability-negotiation? empty
|         |         |   +---ro neighbor-passive?            empty
|         |         |   +---ro peer-shutdown?                empty
|         |         |   +---ro peer-shutdown-description?    cml-data-types:cml_line_t
|         |         |   +---ro peer-port?                    uint16
|         |         |   +---ro bgp-version?                  uint8

```

```

|     |     | +---ro interface-name?                string
|     |     | +---ro mapped-peer-group-tag?         string
|     |     | +---ro enable-ext-opt-param-len?      empty
|     |     | +---ro tcp-adjust-mss?                uint16
|     |     | +---ro peer-type?                     ipi-bgp-types:bgp_peer_type_t
|     |     | +---ro dynamically-configured?        boolean
|     |     | +---ro connection-established-count?  int32
|     |     | +---ro error-notify-sent?             boolean
|     |     | +---ro notify-code-string?            cml-data-types:cml_line_t
|     |     | +---ro bgp-peer-state?                ipi-bgp-
types:bgp_peer_status_t
|     |     +---rw timers
|     |     | +---rw config!
|     |     | | +---rw keep-alive    uint16
|     |     | | +---rw hold-time    uint16
|     |     | +---ro state
|     |     |   +---ro keep-alive    uint16
|     |     |   +---ro hold-time    uint16
|     |     +---rw ebgp-multihop
|     |     | +---rw config!
|     |     | | +---rw maximum-hop-count?  uint8
|     |     | | +---rw enabled            empty
|     |     | +---ro state
|     |     |   +---ro maximum-hop-count?  uint8
|     |     |   +---ro enabled            empty
|     |     +---rw local-as
|     |     | +---rw local-as-list* [peer-local-as]
|     |     | +---rw peer-local-as    -> ../config/peer-local-as
|     |     | +---rw config
|     |     | | +---rw peer-local-as?      uint32
|     |     | | +---rw no-prepend-local-as? empty
|     |     | | +---rw replace-local-as?  empty
|     |     | +---ro state
|     |     |   +---ro peer-local-as?      uint32
|     |     |   +---ro no-prepend-local-as? empty
|     |     |   +---ro replace-local-as?  empty
|     |     +---rw bgp-passwords
|     |     | +---rw bgp-password* [password]
|     |     | +---rw password    -> ../config/password
|     |     | +---rw config
|     |     | | +---rw password?          ipi-bgp-types:bgp_md5_password_t
{feature-list:HAVE_TCP_MD5SIG}?
|     |     | | +---rw auth-key-encrypt    ipi-bgp-types:bgp_md5_t
|     |     | | +---ro state
|     |     | |   +---ro password?        ipi-bgp-types:bgp_md5_password_t
{feature-list:HAVE_TCP_MD5SIG}?
|     |     | |   +---ro auth-key-encrypt    ipi-bgp-types:bgp_md5_t
|     |     +---rw address-families
|     |     | +---rw address-family* [afi safi]
|     |     | +---rw afi                -> ../config/afi
|     |     | +---rw safi                -> ../config/safi

```

```

|         |         |         +---ro peer-adj-out-route* [network-address]
|         |         |         |   +---ro network-address    -> ../state/network-address
|         |         |         |   +---ro next-hop* [next-hop-address]
|         |         |         |   |   +---ro next-hop-address    -> ../state/next-hop-address
|         |         |         |   |   +---ro state
types:  |         |         |         |   |   +---ro next-hop-address?           ipi-bgp-
bgp_    |         |         |         |   |   +---ro peer-network-weight?       uint32
hostname_t |         |         |         |   |   +---ro flap-time-reuse-list?      string
|         |         |         |   |   +---ro flap-record-duration?          string
|         |         |         |   |   +---ro damp-time-to-reuse?            string
|         |         |         |   |   +---ro bgp-med-value?                 uint32
types:  |         |         |         |   |   +---ro bgp-as-path-string*        cml-data-
cml_line_t |         |         |         |   |   +---ro bgp-as-path-4-byte-string*    string
|         |         |         |   |   +---ro bgp-as-path-4-byte-origin?      ipi-bgp-
types:  |         |         |         |   |   +---ro ibgp-metric-route?         int32
bgp_origin_t |         |         |         |   |   +---ro aggregate-as-route?          int32
|         |         |         |   |   +---ro aggregator-address-route?       ipi-bgp-
types:  |         |         |         |   |   +---ro network-remote-address-route? ipi-bgp-
bgp_hostname_t |         |         |         |   |   +---ro originator-id-route?        ipi-bgp-
types:  |         |         |         |   |   +---ro route-peer-address?       ipi-bgp-
bgp_hostname_t |         |         |         |   |   +---ro route-local-preference?       uint32
types:  |         |         |         |   |   +---ro route-prefix-label?       uint32
bgp_hostname_t |         |         |         |   |   +---ro route-community-string?      string
types:  |         |         |         |   |   +---ro cluster-list-route*        ipi-bgp-
bgp_hostname_t |         |         |         |   |   +---ro route-penalty?                int32
|         |         |         |   |   +---ro route-flap-count?                int32
|         |         |         |   |   +---ro last-update-route?                yang:date-and-time
|         |         |         |   |   +---ro reflector-client-route?          boolean
|         |         |         |   |   +---ro route-dampening-active?         boolean
|         |         |         |   |   +---ro history-route?                  boolean
|         |         |         |   |   +---ro nexthop-valid-route?            boolean
|         |         |         |   |   +---ro med-flag-type-route?            boolean
|         |         |         |   |   +---ro valid-route?                    boolean
|         |         |         |   |   +---ro stale-route?                    boolean
types:  |         |         |         |   |   +---ro route-type?                ipi-bgp-
bgp_ri_type_t |         |         |         |   |   +---ro ecmp-multi-candidate-route?    boolean
|         |         |         |   |   +---ro multi-installed-route?          boolean
|         |         |         |   |   +---ro route-synchronized-flag-route?    boolean
|         |         |         |   |   +---ro atomic-aggregate-route?          boolean
|         |         |         |   |   +---ro selected-route?                 boolean
list:  |         |         |         |   |   +---ro bgp-tx-path-id?            int16 {feature-
HAVE_BGP_ADD_PATH}? |         |         |         |   |   +---ro bgp-rx-path-id?            int16 {feature-
list:  |         |         |         |   |   +---ro bgp-rx-path-id?            int16 {feature-
HAVE_BGP_ADD_PATH}?

```

Pyang Tree

```

| | | | | | +---ro ipv4-multicast-capability?      string
| | | | | | +---ro vpnv4-unicast-capability?        string
| | | | | | +---ro rtfILTER-unicast-capability?      string
| | | | | | +---ro l2vpn-evpn-capability?          string
| | | | | | +---ro ipv6-unicast-capability?        string
| | | | | | +---ro ipv6-multicast-capability?     string
| | | | | | +---ro ipv6-label-unicast-capability?  string
| | | | | | +---ro in-label?                       uint32 {feature-
list:HAVE_BGP_LU}?
| | | | | | +---ro out-label?                       uint32 {feature-
list:HAVE_BGP_LU}?
| | | | | | +---ro state
| | | | | | |   +---ro network-address?   ipi-bgp-types:bgp_ip_network_t
+---ro peer-adj-in-route* [network-address]
| | | | | | |   +---ro network-address   -> ../state/network-address
| | | | | | |   +---ro next-hop* [next-hop-address]
| | | | | | |   +---ro next-hop-address   -> ../state/next-hop-address
| | | | | | |   +---ro state
types:bgp_hostname_t | | | | | | +---ro next-hop-address?           ipi-bgp-
| | | | | | |   +---ro peer-network-weight?         uint32
| | | | | | |   +---ro flap-time-reuse-list?        string
| | | | | | |   +---ro flap-record-duration?        string
| | | | | | |   +---ro damp-time-to-reuse?          string
| | | | | | |   +---ro bgp-med-value?               uint32
types:cml_line_t | | | | | | +---ro bgp-as-path-string*          cml-data-
| | | | | | |   +---ro bgp-as-path-4-byte-string*    string
types:bgp_origin_t | | | | | | +---ro bgp-as-path-4-byte-origin?   ipi-bgp-
| | | | | | |   +---ro ibgp-metric-route?            int32
| | | | | | |   +---ro aggregate-as-route?          int32
types:bgp_hostname_t | | | | | | +---ro aggregator-address-route?    ipi-bgp-
| | | | | | |   +---ro network-remote-address-route? ipi-bgp-
types:bgp_hostname_t | | | | | | +---ro originator-id-route?        ipi-bgp-
types:bgp_hostname_t | | | | | | +---ro route-peer-address?         ipi-bgp-
| | | | | | |   +---ro route-local-preference?       uint32
| | | | | | |   +---ro route-prefix-label?          uint32
| | | | | | |   +---ro route-community-string?      string
types:bgp_hostname_t | | | | | | +---ro cluster-list-route*         ipi-bgp-
| | | | | | |   +---ro route-penalty?                int32
| | | | | | |   +---ro route-flap-count?             int32
| | | | | | |   +---ro last-update-route?            yang:date-and-time
| | | | | | |   +---ro reflector-client-route?       boolean
| | | | | | |   +---ro route-dampening-active?       boolean
| | | | | | |   +---ro history-route?                boolean
| | | | | | |   +---ro nexthop-valid-route?          boolean
| | | | | | |   +---ro med-flag-type-route?          boolean

```

```

| | | | | +--ro valid-route? boolean
| | | | | +--ro stale-route? boolean
types:bgp_ri_type_t | | | | | +--ro route-type? ipi-bgp-
| | | | | +--ro ecmp-multi-candidate-route? boolean
| | | | | +--ro multi-installed-route? boolean
| | | | | +--ro route-synchronized-flag-route? boolean
| | | | | +--ro atomic-aggregate-route? boolean
| | | | | +--ro selected-route? boolean
| | | | | +--ro bgp-tx-path-id? int16 {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | | +--ro bgp-rx-path-id? int16 {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | | +--ro ipv4-multicast-capability? string
| | | | | +--ro vpnv4-unicast-capability? string
| | | | | +--ro rtfILTER-unicast-capability? string
| | | | | +--ro l2vpn-evpn-capability? string
| | | | | +--ro ipv6-unicast-capability? string
| | | | | +--ro ipv6-multicast-capability? string
| | | | | +--ro ipv6-label-unicast-capability? string
list:HAVE_BGP_LU}? +--ro in-label? uint32 {feature-
list:HAVE_BGP_LU}? +--ro out-label? uint32 {feature-
| | | | | +--ro state
| | | | | +--ro network-address? ipi-bgp-types:bgp_ip_network_t
| | | | | +--rw config
| | | | | +--rw afi? ipi-bgp-
types:bgp_afi_type_t
| | | | | +--rw safi? ipi-bgp-
types:bgp_safi_type_t
| | | | | +--rw additional-paths-mode? ipi-bgp-
types:bgp_peer_additional_path_type_t {feature-list:HAVE_BGP_ADD_PATH}?
| | | | | +--rw additional-path-select-all? empty {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | | +--rw additional-paths-best-select-count? uint8 {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | | +--rw route-server-client? empty
| | | | | +--rw next-hop-self? empty
| | | | | +--rw bgp-port? uint16
| | | | | +--rw activate? empty
| | | | | +--rw de-activate? empty
| | | | | +--rw default-peer-route-map-name? empty
| | | | | +--rw peer-route-map-orig-name? string
| | | | | +--rw soft-reconfig? ipi-bgp-
types:bgp_update_clear_t
| | | | | +--rw weight? uint16
| | | | | +--rw flowspec-validation-disable? empty {feature-
list:HAVE_BGP_FLOWSPEC}?
| | | | | +--rw peer-route-reflector? empty
| | | | | +--rw peer-remove-private-as? empty
| | | | | +--rw no-send-community? empty

```

```

| | | | +---rw no-send-community-type? | ipi-bgp-
types:bgp_send_commu_type_t
| | | | +---rw neighbor-attribute-unchanged? | ipi-bgp-
types:bgp_attribute_unchanged_type_t
| | | | +---rw orf-prefix-capability? | ipi-bgp-
types:bgp_orf_prefix_type_t
| | | | +---rw peer-allow-ebgp-vpn? | empty {feature-
list:HAVE_VRF}?
| | | | +---rw allow-as-number? | uint32
| | | | +---rw capability-graceful-restart? | empty
| | | | +---rw extended-nexthop-encode? | empty
| | | | +---rw mapped-peer-group-tag-af? | string
| | | | +---rw unsuppress-route-map-name? | string
| | | | +---ro state
| | | | | +---ro counters
| | | | | | +---ro keepalive-in-messages? | int32
| | | | | | +---ro keepalive-out-messages? | int32
| | | | | | +---ro open-messages-in? | int32
| | | | | | +---ro open-messages-out? | int32
| | | | | | +---ro as-path-count? | int32
| | | | | | +---ro as-path-extended-count? | int32
| | | | | | +---ro received-packet-count? | int32
| | | | | | +---ro packet-in-queue? | int32
| | | | | | +---ro packet-out-queue? | int32
| | | | | | +---ro sent-packet-count? | int32
| | | | | | +---ro refresh-received-packet-count? | int32
| | | | | | +---ro refresh-sent-packet-count? | int32
| | | | +---ro afi? | ipi-bgp-
types:bgp_afi_type_t
| | | | +---ro safi? | ipi-bgp-
types:bgp_safi_type_t
| | | | +---ro additional-paths-mode? | ipi-bgp-
types:bgp_peer_additional_path_type_t {feature-list:HAVE_BGP_ADD_PATH}?
| | | | +---ro additional-path-select-all? | empty {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | +---ro additional-paths-best-select-count? | uint8 {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | +---ro route-server-client? | empty
| | | | +---ro next-hop-self? | empty
| | | | +---ro bgp-port? | uint16
| | | | +---ro activate? | empty
| | | | +---ro de-activate? | empty
| | | | +---ro default-peer-route-map-name? | empty
| | | | +---ro peer-route-map-orig-name? | string
| | | | +---ro soft-reconfig? | ipi-bgp-
types:bgp_update_clear_t
| | | | +---ro weight? | uint16
| | | | +---ro flowspec-validation-disable? | empty {feature-
list:HAVE_BGP_FLOWSPEC}?
| | | | +---ro peer-route-reflector? | empty
| | | | +---ro peer-remove-private-as? | empty
| | | | +---ro no-send-community? | empty

```

```

| | | | +---ro no-send-community-type? | ipi-bgp-
types:bgp_send_commu_type_t
| | | | +---ro neighbor-attribute-unchanged? | ipi-bgp-
types:bgp_attribute_unchanged_type_t
| | | | +---ro orf-prefix-capability? | ipi-bgp-
types:bgp_orf_prefix_type_t
| | | | +---ro peer-allow-ebgp-vpn? | empty {feature-
list:HAVE_VRF}?
| | | | +---ro allow-as-number? | uint32
| | | | +---ro capability-graceful-restart? | empty
| | | | +---ro extended-nexthop-encode? | empty
| | | | +---ro mapped-peer-group-tag-af? | string
| | | | +---ro unsuppress-route-map-name? | string
| | | | +---ro max-paths-ibgp? | int16
| | | | +---ro configured-max-paths-ebgp? | int16
| | | | +---ro max-paths-ebgp? | int16
| | | | +---ro configured-max-paths-ibgp? | int16
| | | | +---ro max-paths-eibgp? | int16
| | | | +---ro configured-max-paths-eibgp? | int16
| | | | +---ro community-count? | int32
| | | | +---ro confederation-id-check? | boolean
| | | | +---ro peer-and-extended-asn-capability? | ipi-bgp-
types:bgp_adv_rcv_type_t
| | | | +---ro address-family-capability? | ipi-bgp-
types:bgp_adv_rcv_type_t
| | | | +---ro ipv6-next-hop-global? | inet:ipv6-address
| | | | +---ro ipv6-next-hop-local? | inet:ipv6-address
| | | | +---ro remote-port? | int32
| | | | +---ro remote-address? | ipi-bgp-
types:bgp_hostname_t
| | | | +---ro local-host? | ipi-bgp-
types:bgp_hostname_t
| | | | +---ro ipv4-next-hop? | inet:ipv4-address
| | | | +---ro local-port? | int32
| | | | +---ro default-information-originate? | boolean
| | | | +---ro inbound-path-policy? | boolean
| | | | +---ro outbound-path-policy? | boolean
| | | | +---ro default-originate-information-sent? | cml-data-
types:cml_line_t
| | | | +---ro graceful-restart? | string
| | | | +---ro address-family-dependent-capability? | boolean
| | | | +---ro peer-address-family-table-version? | int32
| | | | +---ro address-family-table-version? | int32
| | | | +---ro forward-status-preserve? | string
| | | | +---ro orf-type-prefix? | cml-data-
types:cml_line_t
| | | | +---ro orf-type-prefix-send-mode? | string
| | | | +---ro orf-type-prefix-receive-mode? | string
| | | | +---ro orf-type-prefix-old? | cml-data-
types:cml_line_t
| | | | +---ro orf-type-prefix-send-mode-old? | string
| | | | +---ro orf-type-prefix-receive-mode-old? | string
| | | | +---ro prefix-count? | int32

```

					+++ro send-prefix-count?	int32
					+++ro flag-shut-down?	ipi-bgp-
types:bgp_peerflag_shutdown_t					+++ro count?	int32
					+++ro notify-info?	boolean
					+++ro notify-last-reset-time?	string
types:bgp_connection_type_t					+++ro connection-type?	ipi-bgp-
					+++ro next-connection-timer?	int32
					+++ro connection-dropped-count?	int32
					+++ro graceful-restart-status?	string
					+++ro graceful-restart-time?	int32
					+++ro bgp-established-up-time?	string
					+++ro last-read-time?	string
types:bgp_link_type_t					+++ro link-type?	ipi-bgp-
					+++ro ebgp-hop-away-count?	int32
					+++ro router-id?	inet:ipv4-address
					+++ro advertisement-interval?	int32
					+++ro calculated-hold-time?	int32
					+++ro calculated-keepalive?	int32
types:cml_line_t					+++ro dynamic-capability?	cml-data-
types:bgp_route_refresh_cap_type_t					+++ro route-refresh-capability?	ipi-bgp-
					+++ro no-interface-binding?	boolean
list:HAVE_BGP_ADD_PATH)?					+++ro additional-path-receive-capability?	string {feature-
list:HAVE_BGP_ADD_PATH)?					+++ro additional-path-send-capability?	string {feature-
types:bgp_capability_type_t					+++ro capability-ipv4-unicast?	ipi-bgp-
types:bgp_capability_type_t {feature-list:HAVE_BGP_LU)?					+++ro capability-label-unicast?	ipi-bgp-
types:bgp_capability_type_t					+++ro capability-ipv4-multicast?	ipi-bgp-
types:bgp_capability_type_t					+++ro capability-vpnv4-unicast?	ipi-bgp-
types:bgp_capability_type_t					+++ro capability-vpnv6-unicast?	ipi-bgp-
types:bgp_capability_type_t					+++ro capability-rtfilter-unicast?	ipi-bgp-
types:bgp_capability_type_t					+++ro capability-l2vpn-evpn?	ipi-bgp-
types:bgp_capability_type_t					+++ro capability-ipv6-unicast?	ipi-bgp-
types:bgp_capability_type_t					+++ro capability-ipv6-multicast?	ipi-bgp-
types:bgp_capability_type_t					+++ro capability-ipv6-label-unicast?	ipi-bgp-
list:HAVE_BGP_EVPN)?					+++ro evpn-ad-route-count?	uint32 {feature-
list:HAVE_BGP_EVPN)?					+++ro evpn-mac-ip-route-count?	uint32 {feature-

```

|         |         |         |         +---ro prefix-list-name           string
|         |         |         |         +---ro prefix-filter-direction?  ipi-bgp-
types:bgp_distribute_list_direction_t
|         |         |         |         +---rw route-map-filters
|         |         |         |         +---rw route-map-filter* [route-map-direction]
|         |         |         |         +---rw route-map-direction    -> ../config/route-map-direction
|         |         |         |         +---rw config
|         |         |         |         |         +---rw route-map-name           string
|         |         |         |         |         +---rw route-map-direction?  ipi-bgp-
types:bgp_distribute_list_direction_t
|         |         |         |         +---ro state
|         |         |         |         +---ro route-map-name           string
|         |         |         |         +---ro route-map-direction?  ipi-bgp-
types:bgp_distribute_list_direction_t
|         |         |         |         +---ro outbound-route-filter
|         |         |         |         +---ro state
|         |         |         |         +---ro orf-prefix-string?      boolean
|         |         |         |         +---ro orf-prefix-send?        string
|         |         |         |         +---ro orf-prefix-count?       string
|         |         |         |         +---ro orf-wait-refresh?       boolean
|         |         |         |         +---ro peer-prefix
|         |         |         |         |         +---ro state
|         |         |         |         +---ro entry-sequence?         int32
|         |         |         |         +---ro entry-type?            ipi-bgp-
types:bgp_prefix_entry_type_t
|         |         |         |         +---ro entry-max-length?      int32
|         |         |         |         +---ro entry-min-length?      int32
|         |         |         |         +---ro prefix-length?         int32
|         |         |         |         +---ro peer-index
|         |         |         |         |         +---ro state
|         |         |         |         +---ro peer-index?           int32
|         |         |         |         +---ro offset?                int32
|         |         |         |         +---ro mask?                  string
|         |         |         |         +---rw aigp {feature-list:HAVE_BGP_AIGP}?
|         |         |         |         +---rw config
|         |         |         |         +---rw admin-status?          cml-data-types:cml_enable_disable_t
{feature-list:HAVE_BGP_AIGP}?
|         |         |         |         |         +---rw aigp-send-med?  empty
|         |         |         |         +---ro state
|         |         |         |         +---ro admin-status?          cml-data-types:cml_enable_disable_t
{feature-list:HAVE_BGP_AIGP}?
|         |         |         |         |         +---ro aigp-send-med?  empty
|         |         |         |         +---rw cost-community {feature-list:HAVE_BGP_AIGP}?
|         |         |         |         +---rw config!
|         |         |         |         |         +---rw send-cost-community-id  uint8 {feature-
list:HAVE_BGP_AIGP}?
|         |         |         |         |         +---rw point-of-insertion    ipi-bgp-
types:bgp_aigp_metric_cost_community_poi_t {feature-list:HAVE_BGP_AIGP}?
|         |         |         |         |         +---rw enable-transitive?    empty {feature-
list:HAVE_BGP_AIGP}?
|         |         |         |         +---ro state
|         |         |         |         +---ro send-cost-community-id  uint8 {feature-
list:HAVE_BGP_AIGP}?

```

```

|         |         |         +---ro point-of-insertion          ipi-bgp-
types:bgp_aigp_metric_cost_community_poi_t {feature-list:HAVE_BGP_AIGP}?
|         |         |         +---ro enable-transitive?        empty {feature-
list:HAVE_BGP_AIGP}?
|         |         +---rw egress-engineering
|         |         +---rw peer-adjacency* [hop-address]
|         |         |         +---rw hop-address      -> ../config/hop-address
|         |         |         +---rw config
|         |         |         |         +---rw hop-address?   inet:ipv4-address
|         |         |         +---ro state
|         |         |         |         +---ro hop-address?   inet:ipv4-address
|         |         |         |         +---ro in-label?      uint32
|         |         |         |         +---ro nexthop-ip-address? inet:ipv4-address
|         |         |         |         +---ro out-interface?  string
|         |         |         +---rw backup
|         |         |         +---rw peer-node
|         |         |         |         +---rw config
|         |         |         |         |         +---rw address?   inet:ipv4-address
|         |         |         |         +---ro state
|         |         |         |         |         +---ro address?   inet:ipv4-address
|         |         |         |         |         +---ro nexthop-ip-address? inet:ipv4-address
|         |         |         |         |         +---ro out-interface?  string
|         |         |         +---rw adjacency
|         |         |         +---rw config!
|         |         |         |         +---rw adjacent-address  inet:ipv4-address
|         |         |         |         +---rw nexthop-address   inet:ipv4-address
|         |         |         +---ro state
|         |         |         |         +---ro adjacent-address  inet:ipv4-address
|         |         |         |         +---ro nexthop-address   inet:ipv4-address
|         |         |         |         +---ro nexthop-ip-address? inet:ipv4-address
|         |         |         |         +---ro out-interface?    string
|         |         +---rw config
|         |         |         +---rw enable-peer-node?   empty
|         |         +---ro state
|         |         |         +---ro enable-peer-node?   empty
|         |         |         +---ro in-label?           uint32
|         |         |         +---ro nexthop-ip-address? inet:ipv4-address
|         |         |         +---ro out-interface?      string
|         |         +---rw peer-set
|         |         |         +---rw config
|         |         |         |         +---rw set-name?    string
|         |         |         +---ro state
|         |         |         |         +---ro set-name?    string
|         |         |         |         +---ro in-label?    uint32
|         |         |         |         +---ro nexthop-ip-address? inet:ipv4-address
|         |         |         |         +---ro out-interface? string
|         |         +---rw backup
|         |         +---rw peer-node
|         |         |         +---rw config
|         |         |         |         +---rw address?   inet:ipv4-address
|         |         |         +---ro state

```

```

|         |         |         +--ro address?             inet:ipv4-address
|         |         |         +--ro nexthop-ip-address?  inet:ipv4-address
|         |         |         +--ro out-interface?       string
|         |         +--rw adjacency
|         |             +--rw config!
|         |                 | +--rw adjacent-address    inet:ipv4-address
|         |                 | +--rw nexthop-address     inet:ipv4-address
|         |                 +---ro state
|         |                     +--ro adjacent-address  inet:ipv4-address
|         |                     +--ro nexthop-address   inet:ipv4-address
|         |                     +--ro nexthop-ip-address? inet:ipv4-address
|         |                     +--ro out-interface?    string
|         +--rw address-family-vrfs
|             +---rw address-family-vrf* [afi safi vrf-name]
|                 +--rw afi                            -> ../config/afi
|                 +--rw safi                            -> ../config/safi
|                 +--rw vrf-name                        -> ../config/vrf-name
|                 +--rw config
|                     | +--rw enable-auto-summary?     empty
|                     | +--rw enable-additional-path-pic? empty {feature-
list:HAVE_BGP_PIC_CORE_EDGE}?
|                     | +--rw enable-network-igp-sync? empty
|                     | +--rw enable-igp-sync?         empty
|                     | +--rw afi?                     ipi-bgp-
types:bgp_vrf_afi_type_t
|                     | +--rw safi?                     ipi-bgp-
types:bgp_vrf_safi_type_t
|                     | +--rw vrf-name?                 string
|                     | +--rw multipath-relax?         empty
|                     | +--rw graceful-shutdown?       empty
|                     | +--rw graceful-shutdown-capable? empty
|                     | +--rw graceful-shutdown-local-preference? uint32
|                     | +--rw additional-paths-mode?   ipi-bgp-
types:bgp_additional_path_type_t {feature-list:HAVE_BGP_ADD_PATH}?
|                     | +--rw additional-path-select-all? empty {feature-
list:HAVE_BGP_ADD_PATH}?
|                     | +--rw additional-paths-best-select-count? uint8 {feature-
list:HAVE_BGP_ADD_PATH}?
|                     | +--rw enable-pic?              empty {feature-
list:HAVE_BGP_PIC_CORE_EDGE}?
|                     +---ro state
|                         | +--ro enable-auto-summary?  empty
|                         | +--ro enable-additional-path-pic? empty {feature-
list:HAVE_BGP_PIC_CORE_EDGE}?
|                         | +--ro enable-network-igp-sync? empty
|                         | +--ro enable-igp-sync?     empty
|                         | +--ro afi?                  ipi-bgp-
types:bgp_vrf_afi_type_t
|                         | +--ro safi?                  ipi-bgp-
types:bgp_vrf_safi_type_t
|                         | +--ro vrf-name?              string
|                         | +--ro multipath-relax?      empty
|                         | +--ro graceful-shutdown?    empty

```

```

|      |      | +---ro graceful-shutdown-capable?          empty
|      |      | +---ro graceful-shutdown-local-preference? uint32
|      |      | +---ro additional-paths-mode?              ipi-bgp-
types:bgp_additional_path_type_t {feature-list:HAVE_BGP_ADD_PATH}?
|      |      | +---ro additional-path-select-all?        empty {feature-
list:HAVE_BGP_ADD_PATH}?
|      |      | +---ro additional-paths-best-select-count?  uint8 {feature-
list:HAVE_BGP_ADD_PATH}?
|      |      | +---ro enable-pic?                          empty {feature-
list:HAVE_BGP_PIC_CORE_EDGE}?
|      |      +---rw confederation
|      |      | +---rw config
|      |      | | +---rw identifier?          uint32
|      |      | | +---rw peer-as-number*     uint32
|      |      | +---ro state
|      |      |   +---ro identifier?         uint32
|      |      |   +---ro peer-as-number*     uint32
|      |      +---rw distances
|      |      | +---rw distance* [ebgp ibgp local]
|      |      |   +---rw ebgp      -> ../config/ebgp
|      |      |   +---rw ibgp      -> ../config/ibgp
|      |      |   +---rw local     -> ../config/local
|      |      |   +---rw config
|      |      |   | +---rw ebgp?    uint8
|      |      |   | +---rw ibgp?    uint8
|      |      |   | +---rw local?   uint8
|      |      |   +---ro state
|      |      |     +---ro ebgp?    uint8
|      |      |     +---ro ibgp?    uint8
|      |      |     +---ro local?   uint8
|      |      +---rw maximum-paths
|      |      | +---rw config
|      |      | | +---rw ebgp-max-path?  int32
|      |      | | +---rw ibgp-max-path?  int32
|      |      | | +---rw eibgp-max-path? int32
|      |      | +---ro state
|      |      |   +---ro ebgp-max-path?  int32
|      |      |   +---ro ibgp-max-path?  int32
|      |      |   +---ro eibgp-max-path? int32
|      |      +---rw table-map {feature-list:HAVE_BGP_TABLE_MAP}?
|      |      | +---rw config!
|      |      | | +---rw map-name        string {feature-list:HAVE_BGP_TABLE_MAP}?
|      |      | | +---rw table-map-filter? boolean {feature-
list:HAVE_BGP_TABLE_MAP}?
|      |      | +---ro state
|      |      |   +---ro map-name        string {feature-list:HAVE_BGP_TABLE_MAP}?
|      |      |   +---ro table-map-filter? boolean {feature-
list:HAVE_BGP_TABLE_MAP}?
|      |      +---rw route-flap-dampenings
|      |      | +---rw route-flap-dampening* [enable-dampening]
|      |      |   +---rw enable-dampening -> ../config/enable-dampening
|      |      |   +---rw config

```

```

|         |         |         | +--rw enable-dampening?      ipi-bgp-types:bgp_dampening_t
|         |         |         | +--rw reach-half-life?      uint32
|         |         |         | +--rw reuse-penalty?       uint32
|         |         |         | +--rw suppress-penalty?    uint32
|         |         |         | +--rw max-suppress-time?   uint32
|         |         |         | +--rw unreach-half-life?   uint32
|         |         |         | +--rw dampening-rmap-name?   string
|         |         |         +--ro state
|         |         |         +--ro enable-dampening?      ipi-bgp-types:bgp_dampening_t
|         |         |         +--ro reach-half-life?      uint32
|         |         |         +--ro reuse-penalty?       uint32
|         |         |         +--ro suppress-penalty?    uint32
|         |         |         +--ro max-suppress-time?   uint32
|         |         |         +--ro unreach-half-life?   uint32
|         |         |         +--ro dampening-rmap-name?   string
|         |         +--rw route-redistribute-lists
|         |         | +--rw route-redistribute-list* [protocol-type]
|         |         | +--rw protocol-type    -> ../config/protocol-type
|         |         | +--rw config
|         |         | +--rw protocol-type?      ipi-bgp-
types: bgp_redistribute_type_t
|         |         | +--rw redist-route-map-name?   string
|         |         | +--ro state
|         |         | +--ro protocol-type?      ipi-bgp-
types: bgp_redistribute_type_t
|         |         | +--ro redist-route-map-name?   string
|         |         +--rw bgp-srv6 {feature-list:HAVE_SRV6}?
|         |         | +--rw config!
|         |         | | +--rw bgpSRv6enable    empty
|         |         | +--ro state
|         |         | | +--ro bgpSRv6enable    empty
|         |         | +--rw sid-alloc-mode
|         |         | +--rw config
|         |         | | +--rw sid-alloc-type?   ipi-bgp-types: bgp_sid_alloc_type_t
|         |         | +--ro state
|         |         | +--ro sid-alloc-type?   ipi-bgp-types: bgp_sid_alloc_type_t
|         |         +--rw bgp-redistribute-ospfs
|         |         | +--rw bgp-redistribute-ospf* [ospf-instance-number]
|         |         | +--rw ospf-instance-number -> ../config/ospf-instance-number
|         |         | +--rw config
|         |         | +--rw ospf-instance-number?      ipi-bgp-
types: cml_ospf_area_id_t
|         |         | +--rw redistribute-ospf-route-map?   string
|         |         | +--ro state
|         |         | +--ro ospf-instance-number?      ipi-bgp-
types: cml_ospf_area_id_t
|         |         | +--ro redistribute-ospf-route-map?   string
|         |         +--rw vrf-peers
|         |         | +--rw vrf-peer* [peer-address]
|         |         | +--rw peer-address                -> ../config/peer-address
|         |         | +--ro peer-adj-out-route* [network-address]

```


				+++ro network-address	-> ../state/network-address
				+++ro next-hop*	[next-hop-address]
				+++ro next-hop-address	-> ../state/next-hop-address
				+++ro state	
types:bgp_hostname_t				+++ro next-hop-address?	ipi-bgp-
				+++ro peer-network-weight?	uint32
				+++ro flap-time-reuse-list?	string
				+++ro flap-record-duration?	string
				+++ro damp-time-to-reuse?	string
				+++ro bgp-med-value?	uint32
types:cml_line_t				+++ro bgp-as-path-string*	cml-data-
				+++ro bgp-as-path-4-byte-string*	string
types:bgp_origin_t				+++ro bgp-as-path-4-byte-origin?	ipi-bgp-
				+++ro ibgp-metric-route?	int32
				+++ro aggregate-as-route?	int32
types:bgp_hostname_t				+++ro aggregator-address-route?	ipi-bgp-
types:bgp_hostname_t				+++ro network-remote-address-route?	ipi-bgp-
types:bgp_hostname_t				+++ro originator-id-route?	ipi-bgp-
types:bgp_hostname_t				+++ro route-peer-address?	ipi-bgp-
				+++ro route-local-preference?	uint32
				+++ro route-prefix-label?	uint32
				+++ro route-community-string?	string
types:bgp_hostname_t				+++ro cluster-list-route*	ipi-bgp-
				+++ro route-penalty?	int32
				+++ro route-flap-count?	int32
				+++ro last-update-route?	yang:date-and-time
				+++ro reflector-client-route?	boolean
				+++ro route-dampening-active?	boolean
				+++ro history-route?	boolean
				+++ro nexthop-valid-route?	boolean
				+++ro med-flag-type-route?	boolean
				+++ro valid-route?	boolean
				+++ro stale-route?	boolean
types:bgp_ri_type_t				+++ro route-type?	ipi-bgp-
				+++ro ecmp-multi-candidate-route?	boolean
				+++ro multi-installed-route?	boolean
				+++ro route-synchronized-flag-route?	boolean
				+++ro atomic-aggregate-route?	boolean
				+++ro selected-route?	boolean
list:HAVE_BGP_ADD_PATH)?				+++ro bgp-tx-path-id?	int16 {feature-
list:HAVE_BGP_ADD_PATH)?				+++ro bgp-rx-path-id?	int16 {feature-
				+++ro ipv4-multicast-capability?	string

Pyang Tree

					+++ro vpnv4-unicast-capability?	string
					+++ro rtfILTER-unicast-capability?	string
					+++ro l2vpn-evpn-capability?	string
					+++ro ipv6-unicast-capability?	string
					+++ro ipv6-multicast-capability?	string
					+++ro ipv6-label-unicast-capability?	string
list:HAVE_BGP_LU}?					+++ro in-label?	uint32 {feature-
list:HAVE_BGP_LU}?					+++ro out-label?	uint32 {feature-
					+++ro state	
					+++ro network-address? ipi-bgp-types:bgp_ip_network_t	
					+++ro peer-adj-in-route* [network-address]	
					+++ro network-address -> ../state/network-address	
					+++ro next-hop* [next-hop-address]	
					+++ro next-hop-address -> ../state/next-hop-address	
					+++ro state	
types:bgp_hostname_t					+++ro next-hop-address?	ipi-bgp-
					+++ro peer-network-weight?	uint32
					+++ro flap-time-reuse-list?	string
					+++ro flap-record-duration?	string
					+++ro damp-time-to-reuse?	string
					+++ro bgp-med-value?	uint32
types:cml_line_t					+++ro bgp-as-path-string*	cml-data-
					+++ro bgp-as-path-4-byte-string*	string
types:bgp_origin_t					+++ro bgp-as-path-4-byte-origin?	ipi-bgp-
					+++ro ibgp-metric-route?	int32
					+++ro aggregate-as-route?	int32
types:bgp_hostname_t					+++ro aggregator-address-route?	ipi-bgp-
types:bgp_hostname_t					+++ro network-remote-address-route?	ipi-bgp-
types:bgp_hostname_t					+++ro originator-id-route?	ipi-bgp-
types:bgp_hostname_t					+++ro route-peer-address?	ipi-bgp-
					+++ro route-local-preference?	uint32
					+++ro route-prefix-label?	uint32
					+++ro route-community-string?	string
types:bgp_hostname_t					+++ro cluster-list-route*	ipi-bgp-
					+++ro route-penalty?	int32
					+++ro route-flap-count?	int32
					+++ro last-update-route?	yang:date-and-time
					+++ro reflector-client-route?	boolean
					+++ro route-dampening-active?	boolean
					+++ro history-route?	boolean
					+++ro nexthop-valid-route?	boolean
					+++ro med-flag-type-route?	boolean
					+++ro valid-route?	boolean

```

| | | | | | +---ro stale-route? | | boolean
| | | | | | +---ro route-type? | | ipi-bgp-
types:bgp_ri_type_t
| | | | | | +---ro ecmp-multi-candidate-route? | | boolean
| | | | | | +---ro multi-installed-route? | | boolean
| | | | | | +---ro route-synchronized-flag-route? | | boolean
| | | | | | +---ro atomic-aggregate-route? | | boolean
| | | | | | +---ro selected-route? | | boolean
| | | | | | +---ro bgp-tx-path-id? | | int16 {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | | | +---ro bgp-rx-path-id? | | int16 {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | | | +---ro ipv4-multicast-capability? | | string
| | | | | | +---ro vpnv4-unicast-capability? | | string
| | | | | | +---ro rtfILTER-unicast-capability? | | string
| | | | | | +---ro l2vpn-evpn-capability? | | string
| | | | | | +---ro ipv6-unicast-capability? | | string
| | | | | | +---ro ipv6-multicast-capability? | | string
| | | | | | +---ro ipv6-label-unicast-capability? | | string
| | | | | | +---ro in-label? | | uint32 {feature-
list:HAVE_BGP_LU}?
| | | | | | +---ro out-label? | | uint32 {feature-
list:HAVE_BGP_LU}?
| | | | | | +---ro state
| | | | | | +---ro network-address? | ipi-bgp-types:bgp_ip_network_t
| | | | | +---rw config
| | | | | | +---rw peer-address? | | inet:ip-address
| | | | | | +---rw peer-as? | | uint32
| | | | | | +---rw source-identifier? | | string
| | | | | | +---rw bgp-version? | | uint8
| | | | | | +---rw peer-connection-interval? | | uint32
| | | | | | +---rw enforce-multihop? | | empty
| | | | | | +---rw peer-shutdown? | | empty
| | | | | | +---rw peer-shutdown-description? | | cml-data-
types:cml_line_t
| | | | | | +---rw neighbor-passive? | | empty
| | | | | | +---rw disable-capability-negotiation? | | empty
| | | | | | +---rw enable-dynamic-capability? | | empty
| | | | | | +---rw min-route-advertisement-interval? | | uint32
| | | | | | +---rw peer-as-origin-interval? | | uint32
| | | | | | +---rw neighbor-as-override? | | empty
| | | | | | +---rw peer-interface-name? | | string {feature-
list:HAVE_VRF}?
| | | | | | +---rw peer-description? | | cml-data-
types:cml_line_t
| | | | | | +---rw peer-restart-time? | | uint32 {feature-
list:HAVE_RESTART,feature-list:HAVE_VRF}?
| | | | | | +---rw site-origin-identifier? | | string {feature-
list:HAVE_VRF}?
| | | | | | +---rw graceful-shut? | | empty
| | | | | | +---rw graceful-shut-timer? | | uint32
| | | | | | +---rw enable-peer-bfd? | | empty {feature-
list:HAVE_BFD}?

```

```

| | | | +--rw enable-peer-bfd-multihop?          empty {feature-
list:HAVE_BFD}?
| | | | +--rw bgp-port?                          uint16
| | | | +--rw activate?                          empty
| | | | +--rw de-activate?                       empty
| | | | +--rw default-peer-route-map-name?      empty
| | | | +--rw peer-route-map-orig-name?        string
| | | | +--rw weight?                          uint16
| | | | +--rw flowspec-validation-disable?     empty {feature-
list:HAVE_BGP_FLOWSPEC}?
| | | | +--rw peer-route-reflector?            empty
| | | | +--rw peer-remove-private-as?         empty
| | | | +--rw no-send-community?              empty
| | | | +--rw no-send-community-type?         ipi-bgp-
types:bgp_send_commu_type_t
| | | | +--rw neighbor-attribute-unchanged?   ipi-bgp-
types:bgp_attribute_unchanged_type_t
| | | | +--rw orf-prefix-capability?           ipi-bgp-
types:bgp_orf_prefix_type_t
| | | | +--rw peer-allow-ebgp-vpn?            empty {feature-
list:HAVE_VRF}?
| | | | +--rw allow-as-number?                uint32
| | | | +--rw capability-graceful-restart?    empty
| | | | +--rw mapped-peer-group-tag-af?       string
| | | | +--rw unsuppress-route-map-name?     string
| | | | +--rw enable-ext-opt-param-len?      empty
| | | | +--rw additional-paths-mode?         ipi-bgp-
types:bgp_peer_additional_path_type_t {feature-list:HAVE_BGP_ADD_PATH}?
| | | | +--rw additional-path-select-all?    empty {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | +--rw additional-paths-best-select-count?  uint8 {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | +--rw tcp-adjust-mss?                uint16
| | | | +--ro state
| | | | +--ro counters
| | | | | +--ro keepalive-in-messages?        int32
| | | | | +--ro keepalive-out-messages?      int32
| | | | | +--ro open-messages-in?           int32
| | | | | +--ro open-messages-out?         int32
| | | | | +--ro as-path-count?             int32
| | | | | +--ro as-path-extended-count?    int32
| | | | | +--ro received-packet-count?     int32
| | | | | +--ro packet-in-queue?          int32
| | | | | +--ro packet-out-queue?         int32
| | | | | +--ro sent-packet-count?        int32
| | | | | +--ro refresh-received-packet-count? int32
| | | | | +--ro refresh-sent-packet-count?  int32
| | | | | +--ro notification-in?         int32
| | | | | +--ro notification-out?        int32
| | | | | +--ro update-message-in?       int32
| | | | | +--ro update-message-out?      int32
| | | | +--ro peer-address?                inet:ip-address

```

```

|         |         |         | +---ro peer-as?                uint32
|         |         |         | +---ro source-identifier?      string
|         |         |         | +---ro bgp-version?           uint8
|         |         |         | +---ro peer-connection-interval? uint32
|         |         |         | +---ro enforce-multihop?      empty
|         |         |         | +---ro peer-shutdown?        empty
|         |         |         | +---ro peer-shutdown-description? cml-data-
types:cml_line_t
|         |         |         | +---ro neighbor-passive?      empty
|         |         |         | +---ro disable-capability-negotiation? empty
|         |         |         | +---ro enable-dynamic-capability? empty
|         |         |         | +---ro min-route-advertisement-interval? uint32
|         |         |         | +---ro peer-as-origin-interval?   uint32
|         |         |         | +---ro neighbor-as-override?     empty
|         |         |         | +---ro peer-interface-name?      string {feature-
list:HAVE_VRF}?
|         |         |         | +---ro peer-description?          cml-data-
types:cml_line_t
|         |         |         | +---ro peer-restart-time?         uint32 {feature-
list:HAVE_RESTART,feature-list:HAVE_VRF}?
|         |         |         | +---ro site-origin-identifier?     string {feature-
list:HAVE_VRF}?
|         |         |         | +---ro graceful-shut?              empty
|         |         |         | +---ro graceful-shut-timer?       uint32
|         |         |         | +---ro enable-peer-bfd?            empty {feature-
list:HAVE_BFD}?
|         |         |         | +---ro enable-peer-bfd-multihop?   empty {feature-
list:HAVE_BFD}?
|         |         |         | +---ro bgp-port?                   uint16
|         |         |         | +---ro activate?                   empty
|         |         |         | +---ro de-activate?                empty
|         |         |         | +---ro default-peer-route-map-name? empty
|         |         |         | +---ro peer-route-map-orig-name?   string
|         |         |         | +---ro weight?                     uint16
|         |         |         | +---ro flowspec-validation-disable? empty {feature-
list:HAVE_BGP_FLOWSPEC}?
|         |         |         | +---ro peer-route-reflector?       empty
|         |         |         | +---ro peer-remove-private-as?     empty
|         |         |         | +---ro no-send-community?          empty
|         |         |         | +---ro no-send-community-type?     ipi-bgp-
types:bgp_send_commu_type_t
|         |         |         | +---ro neighbor-attribute-unchanged? ipi-bgp-
types:bgp_attribute_unchanged_type_t
|         |         |         | +---ro orf-prefix-capability?      ipi-bgp-
types:bgp_orf_prefix_type_t
|         |         |         | +---ro peer-allow-ebgp-vpn?        empty {feature-
list:HAVE_VRF}?
|         |         |         | +---ro allow-as-number?            uint32
|         |         |         | +---ro capability-graceful-restart? empty
|         |         |         | +---ro mapped-peer-group-tag-af?   string
|         |         |         | +---ro unsuppress-route-map-name?  string
|         |         |         | +---ro enable-ext-opt-param-len?   empty

```

```

| | | | +---ro additional-paths-mode? ipi-bgp-
types:bgp_peer_additional_path_type_t {feature-list:HAVE_BGP_ADD_PATH}?
| | | | +---ro additional-path-select-all? empty {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | +---ro additional-paths-best-select-count? uint8 {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | +---ro tcp-adjust-mss? uint16
| | | | +---ro connection-established-count? int32
| | | | +---ro error-notify-sent? boolean
| | | | +---ro notify-code-string? cml-data-
types:cml_line_t
| | | | +---ro bgp-peer-state? ipi-bgp-
types:bgp_peer_status_t
| | | | +---ro max-paths-ibgp? int16
| | | | +---ro configured-max-paths-ebgp? int16
| | | | +---ro max-paths-ebgp? int16
| | | | +---ro configured-max-paths-ibgp? int16
| | | | +---ro max-paths-eibgp? int16
| | | | +---ro configured-max-paths-eibgp? int16
| | | | +---ro community-count? int32
| | | | +---ro confederation-id-check? boolean
| | | | +---ro peer-and-extended-asn-capability? ipi-bgp-
types:bgp_adv_rcv_type_t
| | | | +---ro address-family-capability? ipi-bgp-
types:bgp_adv_rcv_type_t
| | | | +---ro ipv6-next-hop-global? inet:ipv6-address
| | | | +---ro ipv6-next-hop-local? inet:ipv6-address
| | | | +---ro remote-port? int32
| | | | +---ro remote-address? ipi-bgp-
types:bgp_hostname_t
| | | | +---ro local-host? ipi-bgp-
types:bgp_hostname_t
| | | | +---ro ipv4-next-hop? inet:ipv4-address
| | | | +---ro local-port? int32
| | | | +---ro default-information-originate? boolean
| | | | +---ro inbound-path-policy? boolean
| | | | +---ro outbound-path-policy? boolean
| | | | +---ro default-originate-information-sent? cml-data-
types:cml_line_t
| | | | +---ro graceful-restart? string
| | | | +---ro address-family-dependent-capability? boolean
| | | | +---ro peer-address-family-table-version? int32
| | | | +---ro address-family-table-version? int32
| | | | +---ro forward-status-preserve? string
| | | | +---ro orf-type-prefix? cml-data-
types:cml_line_t
| | | | +---ro orf-type-prefix-send-mode? string
| | | | +---ro orf-type-prefix-receive-mode? string
| | | | +---ro orf-type-prefix-old? cml-data-
types:cml_line_t
| | | | +---ro orf-type-prefix-send-mode-old? string
| | | | +---ro orf-type-prefix-receive-mode-old? string
| | | | +---ro prefix-count? int32

```

```

| | | | +--ro send-prefix-count? int32
| | | | +--ro flag-shut-down? ipi-bgp-
types:bgp_peerflag_shutdown_t
| | | | +--ro count? int32
| | | | +--ro notify-info? boolean
| | | | +--ro notify-last-reset-time? string
| | | | +--ro connection-type? ipi-bgp-
types:bgp_connection_type_t
| | | | +--ro next-connection-timer? int32
| | | | +--ro connection-dropped-count? int32
| | | | +--ro graceful-restart-status? string
| | | | +--ro graceful-restart-time? int32
| | | | +--ro bgp-established-up-time? string
| | | | +--ro last-read-time? string
| | | | +--ro link-type? ipi-bgp-
types:bgp_link_type_t
| | | | +--ro ebgp-hop-away-count? int32
| | | | +--ro router-id? inet:ipv4-address
| | | | +--ro advertisement-interval? int32
| | | | +--ro calculated-hold-time? int32
| | | | +--ro calculated-keepalive? int32
| | | | +--ro dynamic-capability? cml-data-
types:cml_line_t
| | | | +--ro route-refresh-capability? ipi-bgp-
types:bgp_route_refresh_cap_type_t
| | | | +--ro no-interface-binding? boolean
| | | | +--ro additional-path-receive-capability? string {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | +--ro additional-path-send-capability? string {feature-
list:HAVE_BGP_ADD_PATH}?
| | | | +--ro capability-ipv4-unicast? ipi-bgp-
types:bgp_capability_type_t
| | | | +--ro capability-label-unicast? ipi-bgp-
types:bgp_capability_type_t {feature-list:HAVE_BGP_LU}?
| | | | +--ro capability-ipv4-multicast? ipi-bgp-
types:bgp_capability_type_t
| | | | +--ro capability-vpnv4-unicast? ipi-bgp-
types:bgp_capability_type_t
| | | | +--ro capability-vpnv6-unicast? ipi-bgp-
types:bgp_capability_type_t
| | | | +--ro capability-rtfilter-unicast? ipi-bgp-
types:bgp_capability_type_t
| | | | +--ro capability-l2vpn-evpn? ipi-bgp-
types:bgp_capability_type_t
| | | | +--ro capability-ipv6-unicast? ipi-bgp-
types:bgp_capability_type_t
| | | | +--ro capability-ipv6-multicast? ipi-bgp-
types:bgp_capability_type_t
| | | | +--ro capability-ipv6-label-unicast? ipi-bgp-
types:bgp_capability_type_t
| | | | +--ro evpn-ad-route-count? uint32 {feature-
list:HAVE_BGP_EVPN}?
| | | | +--ro evpn-mac-ip-route-count? uint32 {feature-
list:HAVE_BGP_EVPN}?

```

```

|           |           |           |           | +---ro evpn-inclusive-multicast-route-count?   uint32 {feature-
list:HAVE_BGP_EVPN}?
|           |           |           |           | +---ro evpn-segment-route-count?               uint32 {feature-
list:HAVE_BGP_EVPN}?
|           |           |           |           | +---ro evpn-ip-prefix-route-count?             uint32 {feature-
list:HAVE_BGP_EVPN}?
|           |           |           |           | +---rw timers
|           |           |           |           | | +---rw config!
|           |           |           |           | | | +---rw keep-alive      uint16
|           |           |           |           | | | +---rw hold-time    uint16
|           |           |           |           | | +---ro state
|           |           |           |           | |   +---ro keep-alive    uint16
|           |           |           |           | |   +---ro hold-time    uint16
|           |           |           |           | +---rw ebgp-multihop
|           |           |           |           | | +---rw config!
|           |           |           |           | | | +---rw maximum-hop-count?  uint8
|           |           |           |           | | | +---rw enabled          empty
|           |           |           |           | | +---ro state
|           |           |           |           | |   +---ro maximum-hop-count?  uint8
|           |           |           |           | |   +---ro enabled          empty
|           |           |           |           | +---rw maximum-prefixes
|           |           |           |           | | +---rw maximum-prefix* [prefix-count]
|           |           |           |           | |   +---rw prefix-count    -> ../config/prefix-count
|           |           |           |           | |   +---rw config
|           |           |           |           | | | +---rw prefix-count?      uint32
|           |           |           |           | | | +---rw stop-update?        empty
|           |           |           |           | | | +---rw maximum-prefix-warning?  empty
|           |           |           |           | | | +---rw threshold-percentage?  uint8
|           |           |           |           | | | +---rw warning-only?        empty
|           |           |           |           | | +---ro state
|           |           |           |           | |   +---ro prefix-count?      uint32
|           |           |           |           | |   +---ro stop-update?        empty
|           |           |           |           | |   +---ro maximum-prefix-warning?  empty
|           |           |           |           | |   +---ro threshold-percentage?  uint8
|           |           |           |           | |   +---ro warning-only?        empty
|           |           |           |           | +---rw bgp-passwords
|           |           |           |           | | +---rw bgp-password* [password]
|           |           |           |           | |   +---rw password      -> ../config/password
|           |           |           |           | |   +---rw config
|           |           |           |           | | +---rw password?          ipi-bgp-types:bgp_md5_password_t
{feature-list:HAVE_TCP_MD5SIG}?
|           |           |           |           | | +---rw auth-key-encrypt    ipi-bgp-types:bgp_md5_t
|           |           |           |           | | +---ro state
|           |           |           |           | | +---ro password?          ipi-bgp-types:bgp_md5_password_t
{feature-list:HAVE_TCP_MD5SIG}?
|           |           |           |           | |   +---ro auth-key-encrypt    ipi-bgp-types:bgp_md5_t
|           |           |           |           | +---rw distribute-list-filters
|           |           |           |           | | +---rw distribute-list-filter* [filter-direction]
|           |           |           |           | |   +---rw filter-direction    -> ../config/filter-direction
|           |           |           |           | |   +---rw config
|           |           |           |           | | +---rw access-list-identifier    string

```



```

| | | | | +--rw filter-direction?          ipi-bgp-
types: bgp_distribute_list_direction_t
| | | | | +--ro state
| | | | | +--ro access-list-identifier      string
| | | | | +--ro filter-direction?          ipi-bgp-
types: bgp_distribute_list_direction_t
| | | | | +--rw as-list-filters
| | | | | +--rw as-list-filter* [as-list-direction]
| | | | | +--rw as-list-direction -> ../config/as-list-direction
| | | | | +--rw config
| | | | | | +--rw as-access-list-identifier  string
| | | | | | +--rw as-list-direction?       ipi-bgp-
types: bgp_distribute_list_direction_t
| | | | | +--ro state
| | | | | +--ro as-access-list-identifier  string
| | | | | +--ro as-list-direction?       ipi-bgp-
types: bgp_distribute_list_direction_t
| | | | | +--rw prefix-list-filters
| | | | | | +--rw prefix-list-filter* [prefix-filter-direction]
| | | | | | +--rw prefix-filter-direction -> ../config/prefix-filter-
direction
| | | | | | +--rw config
| | | | | | | +--rw prefix-list-name        string
| | | | | | | +--rw prefix-filter-direction? ipi-bgp-
types: bgp_distribute_list_direction_t
| | | | | +--ro state
| | | | | +--ro prefix-list-name          string
| | | | | +--ro prefix-filter-direction? ipi-bgp-
types: bgp_distribute_list_direction_t
| | | | | +--rw route-map-filters
| | | | | | +--rw route-map-filter* [route-map-direction]
| | | | | | +--rw route-map-direction -> ../config/route-map-direction
| | | | | | +--rw config
| | | | | | | +--rw route-map-name         string
| | | | | | | +--rw route-map-direction?  ipi-bgp-
types: bgp_distribute_list_direction_t
| | | | | +--ro state
| | | | | +--ro route-map-name          string
| | | | | +--ro route-map-direction?    ipi-bgp-
types: bgp_distribute_list_direction_t
| | | | | +--rw local-as
| | | | | | +--rw local-as-list* [peer-local-as]
| | | | | | +--rw peer-local-as -> ../config/peer-local-as
| | | | | | +--rw config
| | | | | | | +--rw peer-local-as?         uint32
| | | | | | | +--rw no-prepend-local-as?   empty
| | | | | | | +--rw replace-local-as?     empty
| | | | | | +--ro state
| | | | | | +--ro peer-local-as?         uint32
| | | | | | +--ro no-prepend-local-as?   empty
| | | | | | +--ro replace-local-as?     empty
| | | | | +--ro outbound-route-filter

```

```

|         |         |         | +---ro state
|         |         |         |   +---ro orf-prefix-string?   boolean
|         |         |         |   +---ro orf-prefix-send?     string
|         |         |         |   +---ro orf-prefix-count?    string
|         |         |         |   +---ro orf-wait-refresh?    boolean
|         |         |         | +---ro peer-prefix
|         |         |         |   +---ro state
|         |         |         |   +---ro entry-sequence?     int32
|         |         |         |   +---ro entry-type?         ipi-bgp-
types:bgp_prefix_entry_type_t
|         |         |         |   +---ro entry-max-length?   int32
|         |         |         |   +---ro entry-min-length?   int32
|         |         |         |   +---ro prefix-length?      int32
|         |         |         | +---ro peer-index
|         |         |         |   +---ro state
|         |         |         |   +---ro peer-index?       int32
|         |         |         |   +---ro offset?           int32
|         |         |         |   +---ro mask?             string
|         |         |         | +---rw network-lists
|         |         |         |   +---rw network-list* [local-network-prefix]
|         |         |         |   +---rw local-network-prefix  -> ../config/local-network-prefix
|         |         |         |   +---rw config
|         |         |         |   | +---rw local-network-prefix? ipi-bgp-types:bgp_ip_network_t
|         |         |         |   | +---rw network-rmap-name?   string
|         |         |         |   | +---rw backdoor?           empty
|         |         |         |   +---ro state
|         |         |         |   +---ro local-network-prefix? ipi-bgp-
types:bgp_ip_network_t
|         |         |         |   +---ro network-rmap-name?   string
|         |         |         |   +---ro backdoor?           empty
|         |         |         |   +---ro network-path-route-count? int32
|         |         |         |   +---ro no-advertise-route?   string
|         |         |         |   +---ro no-export-route?     boolean
|         |         |         |   +---ro local-as-route?       boolean
|         |         |         |   +---ro suppress-route?      boolean
|         |         |         |   +---ro network-best-path-route-count? int32
|         |         |         |   +---ro ip-routing-table?     string
|         |         |         |   +---ro advertised-non-peer-group-address* ipi-bgp-
types:bgp_hostname_t
|         |         |         |   +---ro advertised-peer-group-name-route* string
|         |         |         |   +---ro advertised-any-peer?   boolean
|         |         |         |   +---ro route-distinguisher-string? string {feature-
list:HAVE_MPLS}?
|         |         |         | +---rw peer-groups
|         |         |         |   +---rw peer-group* [peer-group-tag]
|         |         |         |   +---rw peer-group-tag         -> ../config/peer-group-tag
|         |         |         |   +---rw config
|         |         |         |   | +---rw bgp-port?           uint16
|         |         |         |   | +---rw activate?           empty
|         |         |         |   | +---rw default-peer-route-map-name? empty
|         |         |         |   | +---rw peer-route-map-orig-name? string

```

```

|          |          | +--rw weight?                               uint16
|          |          | +--rw flowspec-validation-disable?         empty {feature-
list:HAVE_BGP_FLOWSPEC}?
|          |          | +--rw peer-route-reflector?         empty
|          |          | +--rw peer-remove-private-as?       empty
|          |          | +--rw no-send-community?           empty
|          |          | +--rw no-send-community-type?       ipi-bgp-
types:bgp_send_commu_type_t
|          |          | +--rw neighbor-attribute-unchanged? ipi-bgp-
types:bgp_attribute_unchanged_type_t
|          |          | +--rw orf-prefix-capability?         ipi-bgp-
types:bgp_orf_prefix_type_t
|          |          | +--rw peer-allow-ebgp-vpn?          empty {feature-
list:HAVE_VRF}?
|          |          | +--rw allow-as-number?              uint32
|          |          | +--rw capability-graceful-restart?   empty
|          |          | +--rw unsuppress-route-map-name?     string
|          |          | +--rw additional-paths-mode?         ipi-bgp-
types:bgp_peer_additional_path_type_t {feature-list:HAVE_BGP_ADD_PATH}?
|          |          | +--rw additional-path-select-all?   empty {feature-
list:HAVE_BGP_ADD_PATH}?
|          |          | +--rw additional-paths-best-select-count? uint8 {feature-
list:HAVE_BGP_ADD_PATH}?
|          |          | +--rw peer-group-range               ipi-bgp-
types:bgp_peer_group_type_t
|          |          | +--rw group-limit?                   uint8
|          |          | +--rw peer-group-tag?                string
|          |          | +--rw peer-as?                       uint32
|          |          | +--rw source-identifier?              string
|          |          | +--rw bgp-version?                   uint8
|          |          | +--rw peer-connection-interval?      uint32
|          |          | +--rw enforce-multihop?              empty
|          |          | +--rw peer-shutdown?                  empty
|          |          | +--rw peer-shutdown-description?     cml-data-
types:cml_line_t
|          |          | +--rw neighbor-passive?              empty
|          |          | +--rw disable-capability-negotiation? empty
|          |          | +--rw connection-retry-interval?     int32
|          |          | +--rw enable-dynamic-capability?     empty
|          |          | +--rw min-route-advertisement-interval? uint32
|          |          | +--rw peer-as-origin-interval?       uint32
|          |          | +--rw neighbor-as-override?          empty
|          |          | +--rw peer-description?               cml-data-
types:cml_line_t
|          |          | +--rw peer-restart-time?             uint32 {feature-
list:HAVE_RESTART,feature-list:HAVE_VRF}?
|          |          | +--rw site-origin-identifier?        string {feature-
list:HAVE_VRF}?
|          |          | +--rw graceful-shut?                 empty
|          |          | +--rw graceful-shut-timer?           uint32
|          |          | +--rw enable-peer-bfd?               empty {feature-
list:HAVE_BFD}?
|          |          | +--rw enable-peer-bfd-multihop?     empty {feature-
list:HAVE_BFD}?

```

```

|         |         | +---rw enable-ext-opt-param-len?         empty
|         |         | +---rw tcp-adjust-mss?           uint16
|         |         | +---ro state
|         |         | +---ro bgp-port?             uint16
|         |         | +---ro activate?           empty
|         |         | +---ro default-peer-route-map-name?   empty
|         |         | +---ro peer-route-map-orig-name?      string
|         |         | +---ro weight?             uint16
|         |         | +---ro flowspec-validation-disable?    empty {feature-
list:HAVE_BGP_FLOWSPEC}?
|         |         | +---ro peer-route-reflector?         empty
|         |         | +---ro peer-remove-private-as?       empty
|         |         | +---ro no-send-community?           empty
|         |         | +---ro no-send-community-type?       ipi-bgp-
types:bgp_send_commu_type_t
|         |         | +---ro neighbor-attribute-unchanged?  ipi-bgp-
types:bgp_attribute_unchanged_type_t
|         |         | +---ro orf-prefix-capability?         ipi-bgp-
types:bgp_orf_prefix_type_t
|         |         | +---ro peer-allow-ebgp-vpn?          empty {feature-
list:HAVE_VRF}?
|         |         | +---ro allow-as-number?             uint32
|         |         | +---ro capability-graceful-restart?   empty
|         |         | +---ro unsuppress-route-map-name?     string
|         |         | +---ro additional-paths-mode?        ipi-bgp-
types:bgp_peer_additional_path_type_t {feature-list:HAVE_BGP_ADD_PATH}?
|         |         | +---ro additional-path-select-all?   empty {feature-
list:HAVE_BGP_ADD_PATH}?
|         |         | +---ro additional-paths-best-select-count?  uint8 {feature-
list:HAVE_BGP_ADD_PATH}?
|         |         | +---ro peer-group-range              ipi-bgp-
types:bgp_peer_group_type_t
|         |         | +---ro group-limit?                 uint8
|         |         | +---ro peer-group-tag?              string
|         |         | +---ro peer-as?                   uint32
|         |         | +---ro source-identifier?          string
|         |         | +---ro bgp-version?               uint8
|         |         | +---ro peer-connection-interval?    uint32
|         |         | +---ro enforce-multihop?           empty
|         |         | +---ro peer-shutdown?              empty
|         |         | +---ro peer-shutdown-description?    cml-data-
types:cml_line_t
|         |         | +---ro neighbor-passive?           empty
|         |         | +---ro disable-capability-negotiation?  empty
|         |         | +---ro connection-retry-interval?    int32
|         |         | +---ro enable-dynamic-capability?    empty
|         |         | +---ro min-route-advertisement-interval?  uint32
|         |         | +---ro peer-as-origin-interval?      uint32
|         |         | +---ro neighbor-as-override?        empty
|         |         | +---ro peer-description?            cml-data-
types:cml_line_t
|         |         | +---ro peer-restart-time?           uint32 {feature-
list:HAVE_RESTART,feature-list:HAVE_VRF}?

```

```

|         |         |         | +---ro site-origin-identifier?         string {feature-
list:HAVE_VRF}?
|         |         |         | +---ro graceful-shut?         empty
|         |         |         | +---ro graceful-shut-timer?    uint32
|         |         |         | +---ro enable-peer-bfd?       empty {feature-
list:HAVE_BFD}?
|         |         |         | +---ro enable-peer-bfd-multihop?  empty {feature-
list:HAVE_BFD}?
|         |         |         | +---ro enable-ext-opt-param-len?  empty
|         |         |         | +---ro tcp-adjust-mss?         uint16
|         |         |         | +---rw optional-as-lists
|         |         |         | | +---rw optional-as-list* [optional-as]
|         |         |         | |   +---rw optional-as    -> ../config/optional-as
|         |         |         | |   +---rw config
|         |         |         | |     | +---rw optional-as?    uint32
|         |         |         | |     +---ro state
|         |         |         | |       +---ro optional-as?    uint32
|         |         |         | +---rw bgp-passwords
|         |         |         | | +---rw bgp-password* [password]
|         |         |         | |   +---rw password    -> ../config/password
|         |         |         | |   +---rw config
|         |         |         | |     +---rw password?        ipi-bgp-types:bgp_md5_password_t
{feature-list:HAVE_TCP_MD5SIG}?
|         |         |         | |   +---rw auth-key-encrypt    ipi-bgp-types:bgp_md5_t
|         |         |         | |   +---ro state
|         |         |         | |     +---ro password?        ipi-bgp-types:bgp_md5_password_t
{feature-list:HAVE_TCP_MD5SIG}?
|         |         |         | |       +---ro auth-key-encrypt    ipi-bgp-types:bgp_md5_t
|         |         |         | +---rw timers
|         |         |         | | +---rw config!
|         |         |         | | | +---rw keep-alive    uint16
|         |         |         | | | +---rw hold-time    uint16
|         |         |         | | +---ro state
|         |         |         | |   +---ro keep-alive    uint16
|         |         |         | |   +---ro hold-time    uint16
|         |         |         | +---rw local-as
|         |         |         | | +---rw local-as-list* [peer-local-as]
|         |         |         | |   +---rw peer-local-as    -> ../config/peer-local-as
|         |         |         | |   +---rw config
|         |         |         | |     | +---rw peer-local-as?    uint32
|         |         |         | |     | +---rw no-prepend-local-as?  empty
|         |         |         | |     | +---rw replace-local-as?    empty
|         |         |         | |     +---ro state
|         |         |         | |       +---ro peer-local-as?    uint32
|         |         |         | |       +---ro no-prepend-local-as?  empty
|         |         |         | |       +---ro replace-local-as?    empty
|         |         |         | +---rw ebgp-multihop
|         |         |         | | +---rw config!
|         |         |         | | | +---rw maximum-hop-count?  uint8
|         |         |         | | | +---rw enabled            empty
|         |         |         | | +---ro state

```

```

|         |         |         +---ro maximum-hop-count?    uint8
|         |         |         +---ro enabled                empty
|         |         +---rw maximum-prefixes
|         |         |         +---rw maximum-prefix* [prefix-count]
|         |         |         +---rw prefix-count      -> ../config/prefix-count
|         |         |         +---rw config
|         |         |         |         +---rw prefix-count?          uint32
|         |         |         |         +---rw stop-update?          empty
|         |         |         |         +---rw maximum-prefix-warning? empty
|         |         |         |         +---rw threshold-percentage?  uint8
|         |         |         |         +---rw warning-only?         empty
|         |         |         +---ro state
|         |         |         +---ro prefix-count?          uint32
|         |         |         +---ro stop-update?          empty
|         |         |         +---ro maximum-prefix-warning? empty
|         |         |         +---ro threshold-percentage?  uint8
|         |         |         +---ro warning-only?         empty
|         |         +---rw distribute-list-filters
|         |         |         +---rw distribute-list-filter* [filter-direction]
|         |         |         +---rw filter-direction    -> ../config/filter-direction
|         |         |         +---rw config
|         |         |         |         +---rw access-list-identifier  string
|         |         |         |         +---rw filter-direction?      ipi-bgp-
types:bgp_distribute_list_direction_t
|         |         |         +---ro state
|         |         |         +---ro access-list-identifier  string
|         |         |         +---ro filter-direction?      ipi-bgp-
types:bgp_distribute_list_direction_t
|         |         +---rw as-list-filters
|         |         |         +---rw as-list-filter* [as-list-direction]
|         |         |         +---rw as-list-direction    -> ../config/as-list-direction
|         |         |         +---rw config
|         |         |         |         +---rw as-access-list-identifier  string
|         |         |         |         +---rw as-list-direction?      ipi-bgp-
types:bgp_distribute_list_direction_t
|         |         |         +---ro state
|         |         |         +---ro as-access-list-identifier  string
|         |         |         +---ro as-list-direction?      ipi-bgp-
types:bgp_distribute_list_direction_t
|         |         +---rw prefix-list-filters
|         |         |         +---rw prefix-list-filter* [prefix-filter-direction]
|         |         |         +---rw prefix-filter-direction    -> ../config/prefix-filter-
direction
|         |         |         +---rw config
|         |         |         |         +---rw prefix-list-name        string
|         |         |         |         +---rw prefix-filter-direction? ipi-bgp-
types:bgp_distribute_list_direction_t
|         |         |         +---ro state
|         |         |         +---ro prefix-list-name        string
|         |         |         +---ro prefix-filter-direction? ipi-bgp-
types:bgp_distribute_list_direction_t
|         |         +---rw route-map-filters

```

```

|      |      +--rw route-map-filter* [route-map-direction]
|      |      +--rw route-map-direction  -> ../config/route-map-direction
|      |      +--rw config
|      |      | +--rw route-map-name      string
|      |      | +--rw route-map-direction? ipi-bgp-
types:bgp_distribute_list_direction_t
|      |      +--ro state
|      |      +--ro route-map-name      string
|      |      +--ro route-map-direction? ipi-bgp-
types:bgp_distribute_list_direction_t
|      +--rw peer-engineering
|      +--rw config
|      | +--rw enable-epe?  empty
|      +--ro state
|      +--ro enable-epe?  empty
+--rw flowspec
+--rw controllers
+--rw controller* [enable-flowspec-controller]
+--rw enable-flowspec-controller  -> ../config/enable-flowspec-controller
+--rw config
| +--rw enable-flowspec-controller?  empty
| +--rw local-install?              ipi-bgp-flowspec-
types:flowspec_local_install_t
+--ro state
| +--ro enable-flowspec-controller?  empty
| +--ro local-install?              ipi-bgp-flowspec-
types:flowspec_local_install_t
+--rw address-families
| +--rw address-family* [afi-type]
|   +--rw afi-type          -> ../config/afi-type
|   +--rw service-policy* [attached-policy-map-name service-policy-type]
map-name
|     | +--rw attached-policy-map-name  -> ../config/attached-policy-
|     | +--rw service-policy-type      -> ../config/service-policy-type
|     | +--rw config
|     | | +--rw attached-policy-map-name?  string
|     | | +--rw service-policy-type?      ipi-enhanced-pbr-
types:epbr_policy_map_t
|     | +--ro state
|     | +--ro attached-policy-map-name?  string
|     | +--ro service-policy-type?      ipi-enhanced-pbr-
types:epbr_policy_map_t
|     +--rw config
|     | +--rw afi-type?                ipi-bgp-flowspec-types:flowspec_afi_type_t
|     | +--rw local-install?          ipi-bgp-flowspec-
types:flowspec_local_install_t
|     +--ro state
|     +--ro afi-type?                ipi-bgp-flowspec-types:flowspec_afi_type_t
|     +--ro local-install?          ipi-bgp-flowspec-
types:flowspec_local_install_t
+--rw vrfs
+--rw vrf* [vrf-name]

```

```

        +---rw vrf-name          -> ../config/vrf-name
        +---rw config
        |   +---rw vrf-name?      string
        |   +---rw local-install? ipi-bgp-flowspec-
types:flowspec_local_install_t
        +---ro state
        |   +---ro vrf-name?      string
        |   +---ro local-install? ipi-bgp-flowspec-
types:flowspec_local_install_t
        +---rw address-families
            +---rw address-family* [afi-type]
                +---rw afi-type          -> ../config/afi-type
                +---rw service-policy* [attached-policy-map-name service-policy-
type]
                    |   +---rw attached-policy-map-name  -> ../config/attached-
policy-map-name
                    |   +---rw service-policy-type       -> ../config/service-
policy-type
                    |   +---rw config
                    |   |   +---rw attached-policy-map-name?  string
                    |   |   +---rw service-policy-type?       ipi-enhanced-pbr-
types:epbr_policy_map_t
                    |   +---ro state
                    |   |   +---ro attached-policy-map-name?  string
                    |   |   +---ro service-policy-type?       ipi-enhanced-pbr-
types:epbr_policy_map_t
                    +---rw config
types:flowspec_afi_type_t
                    |   +---rw afi-type?          ipi-bgp-flowspec-
types:flowspec_local_install_t
                    |   +---rw local-install?      ipi-bgp-flowspec-
                    +---ro state
types:flowspec_afi_type_t
                    |   +---ro afi-type?          ipi-bgp-flowspec-
                    +---ro local-install?        ipi-bgp-flowspec-
types:flowspec_local_install_t

rpcs:
+---x clear-ip-bgp-peer {feature-list:HAVE_BGPD}?
|   +---w input
|       +---w arg          ipi-bgp-types:bgp_hostname_t
|       +---w peer-reset-description?  cml-data-types:cml_line_t
+---x clear-peer-group-l2vpn-evpn-soft-all {feature-list:HAVE_BGP_EVPN}?
|   +---w input
|       +---w peer-group-tag    string
|       +---w soft-reconfig     ipi-bgp-types:bgp_update_clear_t
+---x clear-ip-bgp-all-peer {feature-list:HAVE_BGPD}?
|   +---w input
|       +---w peer-reset-description?  cml-data-types:cml_line_t
+---x clear-bgp-l2vpn-evpn-soft-all {feature-list:HAVE_BGP_EVPN}?
|   +---w input
|       +---w soft-reconfig     ipi-bgp-types:bgp_update_clear_t
+---x clear-bgp-remote-as-l2vpn-evpn-soft-all {feature-list:HAVE_BGP_EVPN}?

```



```

| +---w input
|   +---w peer-as          uint32
|   +---w soft-reconfig    ipi-bgp-types:bgp_update_clear_t
+---x clear-bgp-peer-address-l2vpn-evpn-soft {feature-list:HAVE_BGP_EVPN}?
| +---w input
|   +---w peer-address      ipi-bgp-types:bgp_ip_addr_t
|   +---w soft-reconfig    ipi-bgp-types:bgp_update_clear_t
+---x clear-ip-bgp-all-vrf {feature-list:HAVE_BGPD}?
| +---w input
|   +---w vrf-name          string
|   +---w peer-reset-description? cml-data-types:cml_line_t
+---x clear-ip-bgp-vrf-peer {feature-list:HAVE_BGPD}?
| +---w input
|   +---w vrf-name          string
|   +---w address           ipi-bgp-types:bgp_hostname_t
|   +---w peer-reset-description? cml-data-types:cml_line_t
+---x bgp-graceful-restart {feature-list:HAVE_RESTART}?
+---x clear-bgp-statistics {feature-list:HAVE_BGPD}?
+---x bgp-snmp-restart {feature-list:HAVE_BGPD}?
+---x bgp-debug-on {feature-list:HAVE_BGPD}?
| +---w input
|   +---w terminal-debug-options ipi-bgp-types:bgp_debug_t
+---x bgp-debug-off {feature-list:HAVE_BGPD}?
| +---w input
|   +---w terminal-debug-options ipi-bgp-types:bgp_debug_t
+---x bgp-debug-updates-type-on {feature-list:HAVE_BGPD}?
| +---w input
|   +---w terminal-debug-options ipi-bgp-types:bgp_update_debug_t
+---x bgp-all-debug-off {feature-list:HAVE_BGPD}?

```

notifications:

```

+---n bgp-established-notification
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro peer-address?     ipi-bgp-types:bgp_ip_addr_t
| +--ro bgp-as?           uint32
| +--ro peer-state?       ipi-bgp-types:bgp_peer_status_t
+---n bgp-backward-transition-notification
  +--ro severity?          cml-data-types:cml_notif_severity_t
  +--ro eventClass?       cml-data-types:cml_notif_class_t
  +--ro peer-address?     ipi-bgp-types:bgp_ip_addr_t
  +--ro bgp-as?           uint32
  +--ro peer-state?       ipi-bgp-types:bgp_peer_status_t

```

module: ipi-bridge-domain

```

augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance:

```

```

+--rw bridge-domain {feature-list:HAVE_SUBINTERFACE,feature-list:NOT_HAVE_SWFWDR}?
  +--rw config
    | +--rw domain-id?          -> /ipi-network-instance:network-instances/network-
instance/instance-name
    | +--rw description?       cml-data-types:cml_line_t
    | +--rw route-interface?   -> /ipi-interface:interfaces/interface/name
+--rw bridge-instance
  | +--rw config!
  | | +--rw instance-id      uint8
  | | +--rw bridge-id       string
  | +--ro state
  |   +--ro instance-id     uint8
  |   +--ro bridge-id      string
+--ro state
  | +--ro domain-id?        -> /ipi-network-instance:network-instances/network-
instance/instance-name
  | +--ro description?     cml-data-types:cml_line_t
  | +--ro route-interface? -> /ipi-interface:interfaces/interface/name
+--rw member-interfaces
  +--rw member-interface* [name]
    +--rw name              -> ../config/name
    +--rw config
      | +--rw name?        -> /ipi-interface:interfaces/interface/name
    +--ro state
      +--ro name?        -> /ipi-interface:interfaces/interface/name

```

module: ipi-bridge

```

augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance:
  +--rw bridge
    +--rw config!
      | +--rw protocol                ipi-bridge-types:bridge_protocol_t
      | +--rw disable-dynamic-learning? empty
      | +--rw l2-protocol-destination-mac? cml-data-types:cml_mac_addr_t {feature-
list:HAVE_PROVIDER_BRIDGE}?
      | +--rw dot1ad-encapsulation?    empty {feature-list:HAVE_DUNE}?
    +--ro state
      | +--ro protocol                ipi-bridge-types:bridge_protocol_t
      | +--ro disable-dynamic-learning? empty
      | +--ro l2-protocol-destination-mac? cml-data-types:cml_mac_addr_t {feature-
list:HAVE_PROVIDER_BRIDGE}?
      | +--ro dot1ad-encapsulation?    empty {feature-list:HAVE_DUNE}?
    +--rw bridge-ports
      | +--rw interface* [name]
      |   +--rw name                  -> ../config/name
      |   +--rw config

```

```

    |      | +--rw name?                                -> /ipi-interface:interfaces/
interface/name
    |      | +--rw spanning-tree-protocol-status?      ipi-bridge-
types:bridge_spanningtree_enable_disable_t
    |      +--ro state
    |      +--ro name?                                  -> /ipi-interface:interfaces/
interface/name
    |      +--ro spanning-tree-protocol-status?      ipi-bridge-
types:bridge_spanningtree_enable_disable_t
    |      +--ro switchport-mode?                    ipi-port-vlan-
types:port_vlan_switch_port_mode_t
    +--rw fdb
    +--rw interfaces
    | +--rw interface* [interface-name]
    |   +--rw interface-name  -> ../config/interface-name
    |   +--rw config
    |   | +--rw interface-name?      -> /ipi-interface:interfaces/interface/
name
    |   | +--rw disable-mac-learning  empty
    |   +--ro state
    |   +--ro interface-name?        -> /ipi-interface:interfaces/interface/
name
    |   +--ro disable-mac-learning  empty
+--rw static-mac-table
| +--rw entry* [mac-address]
|   +--rw mac-address  -> ../config/mac-address
|   +--rw config
|   | +--rw interface-name  -> /ipi-interface:interfaces/interface/name
|   | +--rw mac-address?    cml-data-types:cml_mac_addr_t
|   | +--rw action          ipi-bridge-types:bridge_discardforward_t
|   +--ro state
|   +--ro interface-name  -> /ipi-interface:interfaces/interface/name
|   +--ro mac-address?    cml-data-types:cml_mac_addr_t
|   +--ro action          ipi-bridge-types:bridge_discardforward_t
+--rw dynamic-mac-table
  +--ro entry* [mac-address vlan-id] {feature-list:HAVE_HAL}?
  +--ro mac-address  -> ../state/mac-address
  +--ro vlan-id      -> ../state/vlan-id
  +--ro state {feature-list:HAVE_HAL}?
    +--ro mac-address?    cml-data-types:cml_mac_addr_t
    +--ro vlan-id?       uint16
    +--ro svlan-id?      uint16 {feature-list:HAVE_PROVIDER_BRIDGE}?
    +--ro interface-name? -> /ipi-interface:interfaces/interface/name
    +--ro action?        ipi-bridge-types:bridge_discardforward_t
    +--ro entry-time-out? uint32

rpcs:
+---x bridge-clear-provider-edge-mac-address-table {feature-list:HAVE_L2}?
| +---w input
|   +---w mac-type      ipi-bridge-types:bridge_mac_type_t
|   +---w cvlan-id      uint16
|   +---w svlan-id      uint16

```

```

|     +---w bridge-id      string
+---x bridge-clear-mac-address-table {feature-list:HAVE_L2}?
|   +---w input
|     +---w mac-type        ipi-bridge-types:bridge_mac_type_t
|     +---w bridge-id      string
|     +---w interface-name? string
|     +---w mac-address?    cml-data-types:cml_mac_addr_t
|     +---w vlan-id?        uint16
+---x bridge-clear-provider-edge-dynamic-mac-address-table {feature-list:HAVE_L2}?
|   +---w input
|     +---w cvlan-id        uint16
|     +---w svlan-id        uint16
|     +---w bridge-id      string
+---x bridge-clear-dynamic-mac-address-table {feature-list:HAVE_L2}?
|   +---w input
|     +---w bridge-id      string
|     +---w mac-address?    cml-data-types:cml_mac_addr_t
|     +---w interface-name? string
|     +---w vlan-id?        uint16
+---x bridge-clear-mstp-port-dynamic-mac-address-table {feature-list:HAVE_L2}?
|   +---w input
|     +---w interface-name  string
|     +---w instance-id     uint32
|     +---w bridge-id      string

```

module: ipi-cfm

```

+---rw cfm {feature-list:HAVE_CFM}?
|   +---rw global
|     | +---ro loopback
|     | | +---ro state
|     | |   +---ro counters
|     | |     +---ro messages-transmitted? yang:zero-based-counter32
|     | |     +---ro replies-received?     yang:zero-based-counter32
|     | |     +---ro out-of-order-replies-received? yang:zero-based-counter32
|     | |     +---ro bad-msdu?             yang:zero-based-counter32
|     +---rw linktrace
|       +---rw cache
|         | +---rw config!
|         | | +---rw cache-enable          empty
|         | | +---rw cache-size?          uint16
|         | | +---ro state
|         | |   +---ro cache-enable        empty
|         | |   +---ro cache-size?        uint16
|         +---ro state

```

```

|         +---ro counters
|             +---ro messages-transmitted?      yang:zero-based-counter32
|             +---ro replies-transmitted?       yang:zero-based-counter32
|             +---ro valid-replies-received?    yang:zero-based-counter32
|             +---ro unexpected-replies-received? yang:zero-based-counter32
+---rw debug
|   +---rw config
|   |   +---rw options?      ipi-cfm-data-types:cfm_debug_t
|   +---ro state
|       +---ro options?      ipi-cfm-data-types:cfm_debug_t
|       +---ro terminal-debug-status? ipi-cfm-data-types:cfm_debug_t
+---rw maintenance-domains
|   +---rw maintenance-domain* [md-name]
|       +---rw md-name          -> ../config/md-name
|       +---rw config
|           |   +---rw md-name?      string
|           |   +---rw type          ipi-cfm-data-types:cfm_md_type_t
|           |   +---rw level         uint8
|           |   +---rw mip-creation? ipi-cfm-data-types:cfm_mip_creation_mode_t {feature-
list:HAVE_PROVIDER_BRIDGE}?
|           +---ro state
|               |   +---ro md-name?      string
|               |   +---ro type          ipi-cfm-data-types:cfm_md_type_t
|               |   +---ro level         uint8
|               |   +---ro mip-creation? ipi-cfm-data-types:cfm_mip_creation_mode_t {feature-
list:HAVE_PROVIDER_BRIDGE}?
|               +---rw maintenance-associations
|                   +---rw maintenance-association* [ma-name]
|                       +---rw ma-name          -> ../config/ma-name
|                       +---rw config
|                           |   +---rw ma-name?      string
|                           |   +---rw type          ipi-cfm-data-types:cfm_ma_type_t
|                           |   +---rw ccm-interval? ipi-cfm-data-
types:cfm_msg_interval_t
|                           |   +---rw enable-rmep-auto-discovery? empty {feature-list:HAVE_DUNE}?
|                           |   +---rw static-rmep-identifiers*  uint16
|                           |   +---rw mip-creation? ipi-cfm-data-
types:cfm_ma_mip_creation_mode_t
|                           |   +---rw vlan-id?      uint16
|                           |   +---rw inner-vlan-id? uint16
|                           |   +---rw bridge-id?   -> /ipi-network-instance:network-
instances/network-instance/instance-name
|                           |   +---rw link-level-ma? empty
|                           |   +---rw mip-interface-name*     -> /ipi-interface:interfaces/
interface/name {feature-list:HAVE_PROVIDER_BRIDGE}?
|                           |   +---rw evpn-id?      uint32 {feature-
list:HAVE_BGP_EVPN,feature-list:NOT_HAVE_CUSTOM1_MPLS_OR_HAVE_NVO3_OAM}?
|                           |   +---rw vpws-vc-name? string {feature-
list:HAVE_MPLS_VC,feature-list:NOT_HAVE_CUSTOM1_MPLS}?
|                           +---ro state
|                               |   +---ro ma-name?      string
|                               |   +---ro type          ipi-cfm-data-types:cfm_ma_type_t

```

Pyang Tree

```
types:cfm_msg_interval_t
|
| +---ro ccm-interval? ipi-cfm-data-
|
| +---ro enable-rmep-auto-discovery? empty {feature-list:HAVE_DUNE}?
|
| +---ro static-rmep-identifiers* uint16
|
| +---ro mip-creation? ipi-cfm-data-
types:cfm_ma_mip_creation_mode_t
|
| +---ro vlan-id? uint16
|
| +---ro inner-vlan-id? uint16
|
| +---ro bridge-id? -> /ipi-network-instance:network-
instances/network-instance/instance-name
|
| +---ro link-level-ma? empty
|
| +---ro mip-interface-name* -> /ipi-interface:interfaces/
interface/name {feature-list:HAVE_PROVIDER_BRIDGE}?
|
| +---ro evpn-id? uint32 {feature-
list:HAVE_BGP_EVPN,feature-list:NOT_HAVE_CUSTOM1_MPLS_OR_HAVE_NVO3_OAM}?
|
| +---ro vpws-vc-name? string {feature-
list:HAVE_MPLS_VC,feature-list:NOT_HAVE_CUSTOM1_MPLS}?
|
| +---rw maintenance-end-points
|
| +---rw maintenance-end-point* [mep-id]
|
| +---rw mep-id -> ../config/mep-id
|
| +---rw config
|
| +---rw mep-id? uint16
|
| +---rw direction ipi-cfm-data-
types:cfm_mep_direction_t
|
| +---rw administrative-state ipi-cfm-data-
types:cfm_mep_state_t
|
| +---rw bw-mapped-interface? -> /ipi-interface:interfaces/
interface/name
|
| +---rw interface-name? -> /ipi-interface:interfaces/
interface/name
|
| +---rw remote-vpws-vc-name? string
|
| +---rw remote-evpn-id? uint32
|
| +---ro state
|
| +---ro mep-id? uint16
|
| +---ro direction ipi-cfm-data-
types:cfm_mep_direction_t
|
| +---ro administrative-state ipi-cfm-data-
types:cfm_mep_state_t
|
| +---ro interface-name? -> /ipi-interface:interfaces/
interface/name
|
| +---ro remote-vpws-vc-name? string
|
| +---ro remote-evpn-id? uint32
|
| +---ro mac-address? cml-data-types:cml_mac_addr_t
|
| +---ro ma-status? ipi-cfm-data-
types:cfm_ma_status_t
|
| +---ro mep-connectivity-status? ipi-cfm-data-
types:cfm_mep_connectivity_status_t
|
| +---ro bw-mapped-interface? -> /ipi-interface:interfaces/
interface/name
|
| +---rw continuity-check
|
| +---rw config
|
| +---rw enable-cc-multicast? empty
|
| +---rw lowest-fault-priority-defect? ipi-cfm-data-
types:cfm_mep_lowest_fault_priority_t
```

```

|
|
|      +---ro state
|
|      |      +---ro enable-cc-multicast?          empty
|      |      +---ro lowest-fault-priority-defect?  ipi-cfm-data-
types:cfm_mep_lowest_fault_priority_t
|      |      +---ro highest-priority-defect-found? ipi-cfm-data-
types:cfm_mep_highest_fault_defect_t
|      |      +---ro cc-received-defect?           ipi-cfm-data-
types:cfm_received_ccm_defect_t
|      |      +---ro cc-messages-received?         yang:zero-based-
counter32
|      |      +---ro cc-messages-sent?             yang:zero-based-
counter32
|      |      +---ro remote-mep-database
|      |      |      +---ro remote-mep* [rmep-id]
|      |      |      +---ro rmep-id    -> ../state/rmep-id
|      |      |      +---ro state
|      |      |      +---ro rmep-id?      uint16
|      |      |      +---ro mac-address?  cml-data-types:cml_mac_addr_t
|      |      |      +---ro rdi?         empty
|      |      +---ro loopback
|      |      +---ro last-test-result
|      |      +---ro state
|      |      |      +---ro target-mac-address?    ipi-cfm-data-
types:cfm_rmep_mac_addr_t
|      |      |      +---ro messages-transmitted?  yang:zero-based-counter32
|      |      |      +---ro replies-received?     yang:zero-based-counter32
|      |      +---ro linktrace-database
|      |      |      +---ro linktrace-entry* [transaction-id]
|      |      |      +---ro transaction-id    -> ../state/transaction-id
|      |      |      +---ro state
|      |      |      |      +---ro transaction-id?    uint32
|      |      |      |      +---ro target-mac-address? ipi-cfm-data-
types:cfm_rmep_mac_addr_t
|      |      |      +---ro replies
|      |      |      |      +---ro reply* [index]
|      |      |      |      +---ro index    -> ../state/index
|      |      |      |      +---ro state
|      |      |      |      +---ro index?      uint8
|      |      |      |      +---ro hops?      uint8
|      |      |      +---ro destination-mac-address? ipi-cfm-data-
types:cfm_rmep_mac_addr_t
|      |      |      +---ro relay-action?        ipi-cfm-data-
types:cfm_relay_action_t
|      |      +---rw ethernet-bandwidth-notification {feature-
list:HAVE_DUNE,feature-list:HAVE_CFM_Y1731}?
|      |      +---rw config!
|      |      |      +---rw enable-receive        empty
|      |      |      +---rw wait-to-restore-timer? uint32
|      |      |      +---rw peer-port-id?        uint32
|      |      +---ro state
|      |      |      +---ro enable-receive        empty
|      |      |      +---ro wait-to-restore-timer? uint32
|      |      |      +---ro peer-port-id?        uint32

```

Pyang Tree

```

    |
    |
    |      +---ro nominal-bandwidth?          string
    |      +---ro current-bandwidth?         string
    |      +---ro signal-state?              ipi-cfm-data-
types:cfm_bn_csf_signal_state_t
    |      +---ro messages-received?         yang:zero-based-
counter32
    |      +---ro messages-dropped?          yang:zero-based-
counter32
    |      +---ro last-message-received-time? string
    |      +---ro message-rx-interval?       uint8
    |      +---ro peer-mac-address?          cml-data-
types:cml_mac_addr_t
    |      +---ro mep-interface-name?        string
    |      +---ro wait-to-restore-time-remaining? uint32
    |      +---ro peer-port-identifier?      uint32
    |      +---ro curr-state-elapsed-time?   string
    |      +---rw ethernet-client-signal-fail {feature-list:HAVE_DUNE,feature-
list:HAVE_CFM_Y1731}?
    |      +---rw config!
    |      |      +---rw enable-receive          empty
    |      |      +---rw wait-to-restore-timer?  uint32
    |      |      +---ro state
    |      |      +---ro enable-receive          empty
    |      |      +---ro wait-to-restore-timer?  uint32
    |      |      +---ro signal-state?          ipi-cfm-data-
types:cfm_bn_csf_signal_state_t
    |      +---ro messages-received?         yang:zero-based-counter32
    |      +---ro last-message-received-time? string
    |      +---ro message-rx-interval?       uint8
    |      +---ro peer-mac-address?          cml-data-
types:cml_mac_addr_t
    |      +---ro mep-interface-name?        string
    |      +---rw ethernet-locked-signal {feature-list:HAVE_DUNE,feature-
list:HAVE_CFM_Y1731}?
    |      +---rw config!
    |      |      +---rw lock-state             ipi-cfm-data-types:cfm_mep_lck_t
    |      |      +---rw client-md-level?      uint8
    |      |      +---rw interval?             ipi-cfm-data-
types:cfm_y1731_tx_interval_t
    |      |      +---rw priority?             uint8
    |      |      +---ro state
    |      |      +---ro lock-state             ipi-cfm-data-types:cfm_mep_lck_t
    |      |      +---ro client-md-level?      uint8
    |      |      +---ro interval?             ipi-cfm-data-
types:cfm_y1731_tx_interval_t
    |      +---ro priority?                  uint8
    |      +---ro receive-status?             boolean
    |      +---ro transmit-status?            boolean
    |      +---ro messages-received?          yang:zero-based-counter32
    |      +---ro messages-transmitted?       yang:zero-based-counter32
    |      +---rw ethernet-alarm-indication-signal {feature-
list:HAVE_CFM_Y1731}?
    |      +---rw config!

```



```

| | | +---rw enable-status      empty
| | | +---rw client-md-level    uint8
| | | +---rw interval?         ipi-cfm-data-
types:cfm_y1731_tx_interval_t
| | | +---ro state
| | |   +---ro enable-status      empty
| | |   +---ro client-md-level    uint8
| | |   +---ro interval?         ipi-cfm-data-
types:cfm_y1731_tx_interval_t
| | |   +---ro is-ais-frame-received?  boolean
| | |   +---rw y1731-responders {feature-list:HAVE_CFM_Y1731}?
| | |   +---rw config
| | |   +---rw enable-lm-responder?  ipi-cfm-data-
types:cfm_lm_reply_type_t {feature-list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
| | |   +---rw enable-dm-responder?  empty {feature-
list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
| | |   +---ro state
| | |   +---ro enable-lm-responder?  ipi-cfm-data-
types:cfm_lm_reply_type_t {feature-list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
| | |   +---ro enable-dm-responder?  empty {feature-
list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
| | |   +---rw ethernet-test-signal {feature-list:HAVE_DUNE,feature-
list:Y1731_HW_OFFLOAD}?
| | |   +---ro state
| | |   +---ro rmp-id?            uint16
| | |   +---ro peer-mac-address?  cml-data-
types:cml_mac_addr_t
| | |   +---ro session-status?     ipi-cfm-data-
types:cfm_tst_session_status_t
| | |   +---ro start-time?        yang:date-and-time
| | |   +---ro end-time?         yang:date-and-time
| | |   +---ro elapsed-time?     uint32
| | |   +---ro in-test-frames?    yang:zero-based-counter64
| | |   +---ro in-out-of-order-frames?  yang:zero-based-
counter64
| | |   +---ro in-ber-error-frames?  yang:zero-based-
counter64
| | |   +---ro last-packet-sequence-number?  uint64
| | |   +---ro out-test-frames?    yang:zero-based-counter64
| | |   +---ro ethernet-loss-measurements {feature-list:Y1731_HW_OFFLOAD}?
| | |   +---ro current-measurement
| | |   +---ro state
| | |     +---ro counters
| | |       +---ro near-end-loss?    uint32
| | |       +---ro far-end-loss?    uint32
| | |       +---ro near-end-accumulated-loss?  uint32
| | |       +---ro far-end-accumulated-loss?  uint32
| | |     +---ro measurement-id?    uint16
| | |     +---ro suspect-status?    boolean
| | |     +---ro measurement-type?  ipi-cfm-data-
types:cfm_lm_measurement_type_t
| | |     +---ro elapsed-time?      uint32
| | |     +---ro start-time?       yang:date-and-time

```

```

| | | | +---ro session-status?      ipi-cfm-data-
types:cfm_pm_session_status_t
| | | | +---ro historic-measurements
| | | |   +---ro historic-measurement* [measurement-id]
| | | |   +---ro measurement-id    -> ../state/measurement-id
| | | |   +---ro state
| | | |     +---ro counters
| | | |       | +---ro near-end-loss?      uint32
| | | |       | +---ro far-end-loss?      uint32
| | | |       | +---ro near-end-accumulated-loss?  uint32
| | | |       | +---ro far-end-accumulated-loss?  uint32
| | | |     +---ro measurement-id?    uint16
| | | |     +---ro suspect-status?    boolean
| | | |     +---ro measurement-type?  ipi-cfm-data-
types:cfm_lm_measurement_type_t
| | | |     +---ro elapsed-time?      uint32
| | | |     +---ro end-time?        yang:date-and-time
| | | |   +---ro ethernet-delay-measurements {feature-list:Y1731_HW_OFFLOAD}?
| | | |     +---ro current-measurement
| | | |       | +---ro state
| | | |         | +---ro measurement-id?    uint16
| | | |         | +---ro suspect-status?    boolean
| | | |         | +---ro measurement-type?  ipi-cfm-data-
types:cfm_dm_measurement_type_t
| | | |         +---ro elapsed-time?      uint32
| | | |         +---ro start-time?      yang:date-and-time
| | | |         +---ro session-status?  ipi-cfm-data-
types:cfm_pm_session_status_t
| | | |   +---ro frame-delay {feature-list:Y1731_HW_OFFLOAD}?
| | | |     | +---ro min?   yang:gauge32
| | | |     | +---ro max?   yang:gauge32
| | | |     | +---ro avg?   yang:gauge32
| | | |     +---ro inter-frame-delay-variation {feature-
list:Y1731_HW_OFFLOAD}?
| | | |       | +---ro min?   yang:gauge32
| | | |       | +---ro max?   yang:gauge32
| | | |       | +---ro avg?   yang:gauge32
| | | |     +---ro frame-delay-bins {feature-list:Y1731_HW_OFFLOAD}?
| | | |       | +---ro frame-delay-bin* [bin-number]
| | | |       | +---ro bin-number    -> ../state/bin-number
| | | |       | +---ro state
| | | |         | +---ro bin-number?  uint8
| | | |         | +---ro threshold?  uint32
| | | |         | +---ro counter?   yang:gauge32
| | | |     +---ro inter-frame-delay-bins {feature-
list:Y1731_HW_OFFLOAD}?
| | | |       | +---ro inter-frame-delay-bin* [bin-number]
| | | |       | +---ro bin-number    -> ../state/bin-number
| | | |       | +---ro state
| | | |         | +---ro bin-number?  uint8
| | | |         | +---ro threshold?  uint32
| | | |         | +---ro counter?   yang:gauge32

```

```

|           |           +---ro historic-measurements
|           |           +---ro historic-measurement* [measurement-id]
|           |           +---ro measurement-id           -> ../state/measurement-id
|           |           +---ro state
|           |           | +---ro measurement-id?           uint16
|           |           | +---ro suspect-status?           boolean
|           |           | +---ro measurement-type?         ipi-cfm-data-
types:cfm_dm_measurement_type_t
|           |           | +---ro elapsed-time?           uint32
|           |           | +---ro end-time?               yang:date-and-time
|           |           | +---ro frame-delay {feature-list:Y1731_HW_OFFLOAD}?
|           |           | | +---ro min? yang:gauge32
|           |           | | +---ro max? yang:gauge32
|           |           | | +---ro avg? yang:gauge32
|           |           | +---ro inter-frame-delay-variation {feature-
list:Y1731_HW_OFFLOAD}?
|           |           | +---ro min? yang:gauge32
|           |           | +---ro max? yang:gauge32
|           |           | +---ro avg? yang:gauge32
|           |           +---ro frame-delay-bins {feature-list:Y1731_HW_OFFLOAD}?
|           |           | +---ro frame-delay-bin* [bin-number]
|           |           | +---ro bin-number           -> ../state/bin-number
|           |           | +---ro state
|           |           | +---ro bin-number? uint8
|           |           | +---ro threshold? uint32
|           |           | +---ro counter? yang:gauge32
|           |           +---ro inter-frame-delay-bins {feature-
list:Y1731_HW_OFFLOAD}?
|           |           +---ro inter-frame-delay-bin* [bin-number]
|           |           +---ro bin-number           -> ../state/bin-number
|           |           +---ro state
|           |           +---ro bin-number? uint8
|           |           +---ro threshold? uint32
|           |           +---ro counter? yang:gauge32
|           +---ro default-mips
|           +---ro default-mip* [interface-name]
|           +---ro interface-name           -> ../state/interface-name
|           +---ro state
|           +---ro interface-name? string
|           +---ro vlan-id? uint16
|           +---ro mac-address? cml-data-types:cml_mac_addr_t
+---rw ethernet-test-signal-profiles {feature-list:HAVE_DUNE,feature-
list:Y1731_HW_OFFLOAD}?
| +---rw ethernet-test-signal-profile* [profile-name]
| +---rw profile-name           -> ../config/profile-name
| +---rw config
| | +---rw profile-name? string
| | +---rw mode? ipi-cfm-data-types:cfm_test_mode_t
| | +---rw test-type? ipi-cfm-data-types:cfm_test_type_t
| | +---rw frame-size? uint32
| | +---rw pattern-type? ipi-cfm-data-types:cfm_test_pattern_type_t

```

```
|      +--ro state
|      +--ro profile-name?   string
|      +--ro mode?           ipi-cfm-data-types:cfm_test_mode_t
|      +--ro test-type?      ipi-cfm-data-types:cfm_test_type_t
|      +--ro frame-size?     uint32
|      +--ro pattern-type?   ipi-cfm-data-types:cfm_test_pattern_type_t
+--rw ethernet-loss-measurement-profiles {feature-list:HAVE_CFM_Y1731,feature-
list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
| +--rw ethernet-loss-measurement-profile* [profile-name]
|   +--rw profile-name      -> ../config/profile-name
|   +--rw config
|   | +--rw profile-name?    string
|   | +--rw measurement-type? ipi-cfm-data-types:cfm_lm_measurement_type_t
|   | +--rw measurement-interval? uint32
|   | +--rw message-period?   ipi-cfm-data-types:cfm_msg_interval_t
|   | +--rw intervals-stored? uint16
|   +--ro state
|   +--ro profile-name?      string
|   +--ro measurement-type?  ipi-cfm-data-types:cfm_lm_measurement_type_t
|   +--ro measurement-interval? uint32
|   +--ro message-period?    ipi-cfm-data-types:cfm_msg_interval_t
|   +--ro intervals-stored?  uint16
+--rw ethernet-delay-measurement-profiles {feature-list:HAVE_CFM_Y1731,feature-
list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
  +--rw ethernet-delay-measurement-profile* [profile-name]
  +--rw profile-name      -> ../config/profile-name
  +--rw config
  | +--rw profile-name?    string
  | +--rw measurement-interval? uint16
  | +--rw message-period?  ipi-cfm-data-types:cfm_msg_interval_t
  | +--rw intervals-stored? uint16
  | +--rw bins-per-fd-interval? uint8
  | +--rw bins-per-ifdv-interval? uint8
  +--ro state
  | +--ro profile-name?    string
  | +--ro measurement-interval? uint16
  | +--ro message-period?  ipi-cfm-data-types:cfm_msg_interval_t
  | +--ro intervals-stored? uint16
  | +--ro bins-per-fd-interval? uint8
  | +--ro bins-per-ifdv-interval? uint8
+--rw bin-thresholds
  +--rw bin-threshold* [type bin-number]
  +--rw type          -> ../config/type
  +--rw bin-number    -> ../config/bin-number
  +--rw config
  | +--rw type?        ipi-cfm-data-types:cfm_dm_measurement_bin_type_t
  | +--rw bin-number?  uint8
  | +--rw threshold    uint32
  +--ro state
  +--ro type?          ipi-cfm-data-types:cfm_dm_measurement_bin_type_t
  +--ro bin-number?    uint8
```

```

+--ro threshold      uint32

```

```

rpcs:
  +---x cfm-l2-abort-eth-test-signal {feature-list:Y1731_HW_OFFLOAD,feature-
list:HAVE_DUNE}?
  | +---w input
  |   +---w mep-id      uint16
  |   +---w ma-name     string
  |   +---w domain-name string
  +---x cfm-l2-eth-test-on-demand-start-relative-stop-relative {feature-
list:Y1731_HW_OFFLOAD,feature-list:HAVE_DUNE}?
  | +---w input
  |   +---w test-target  ipi-cfm-data-types:cfm_rmep_type_t
  |   +---w mep-id      uint16
  |   +---w ma-name     string
  |   +---w md-name     string
  |   +---w profile-name string
  |   +---w start-time-type ipi-cfm-data-types:cfm_relative_time_t
  |   +---w start-time  uint32
  |   +---w stop-time-type ipi-cfm-data-types:cfm_relative_time_t
  |   +---w stop-time   uint32
  +---x cfm-l2-eth-test-on-demand-start-absolute-stop-relative {feature-
list:Y1731_HW_OFFLOAD,feature-list:HAVE_DUNE}?
  | +---w input
  |   +---w test-target  ipi-cfm-data-types:cfm_rmep_type_t
  |   +---w mep-id      uint16
  |   +---w ma-name     string
  |   +---w md-name     string
  |   +---w profile-name string
  |   +---w start-time-type ipi-cfm-data-types:cfm_absolute_time_t
  |   +---w start-time  string
  |   +---w stop-time-type ipi-cfm-data-types:cfm_relative_time_t
  |   +---w stop-time   uint32
  +---x cfm-l2-eth-test-on-demand-start-relative-stop-absolute {feature-
list:Y1731_HW_OFFLOAD,feature-list:HAVE_DUNE}?
  | +---w input
  |   +---w test-target  ipi-cfm-data-types:cfm_rmep_type_t
  |   +---w mep-id      uint16
  |   +---w ma-name     string
  |   +---w md-name     string
  |   +---w profile-name string
  |   +---w start-time-type ipi-cfm-data-types:cfm_relative_time_t
  |   +---w start-time  uint32
  |   +---w stop-time-type ipi-cfm-data-types:cfm_absolute_time_t
  |   +---w stop-time   string
  +---x cfm-l2-eth-test-on-demand-start-absolute-stop-absolute {feature-
list:Y1731_HW_OFFLOAD,feature-list:HAVE_DUNE}?
  | +---w input
  |   +---w test-target  ipi-cfm-data-types:cfm_rmep_type_t
  |   +---w mep-id      uint16
  |   +---w ma-name     string

```

```

|     +---w md-name           string
|     +---w profile-name      string
|     +---w start-time-type   ipi-cfm-data-types:cfm_absolute_time_t
|     +---w start-time        string
|     +---w stop-time-type    ipi-cfm-data-types:cfm_absolute_time_t
|     +---w stop-time         string
+---x cfm-l2-eth-lm-start-proactive {feature-list:Y1731_HW_OFFLOAD}?
|   +---w input
|     +---w md-name           string
|     +---w ma-name           string
|     +---w mep-id            uint16
|     +---w profile-name      string
|     +---w rmep-id           ipi-cfm-data-types:cfm_rmep_type_t
+---x cfm-l2-eth-lm-on-demand-start-immediate-stop-none {feature-
list:Y1731_HW_OFFLOAD}?
|   +---w input
|     +---w md-name           string
|     +---w ma-name           string
|     +---w mep-id            uint16
|     +---w profile-name      string
|     +---w rmep-id           ipi-cfm-data-types:cfm_rmep_type_t
|     +---w start-time-type   ipi-cfm-data-types:cfm_start_time_immediate_t
|     +---w stop-time-type    ipi-cfm-data-types:cfm_stop_time_none_t
|     +---w repetition-period yang:timeticks
+---x cfm-l2-eth-lm-on-demand-start-immediate-stop-relative {feature-
list:Y1731_HW_OFFLOAD}?
|   +---w input
|     +---w md-name           string
|     +---w ma-name           string
|     +---w mep-id            uint16
|     +---w profile-name      string
|     +---w rmep-id           ipi-cfm-data-types:cfm_rmep_type_t
|     +---w start-time-type   ipi-cfm-data-types:cfm_start_time_immediate_t
|     +---w stop-time-type    ipi-cfm-data-types:cfm_relative_time_t
|     +---w stop-time         string
|     +---w repetition-period yang:timeticks
+---x cfm-l2-eth-lm-on-demand-start-immediate-stop-absolute {feature-
list:Y1731_HW_OFFLOAD}?
|   +---w input
|     +---w md-name           string
|     +---w ma-name           string
|     +---w mep-id            uint16
|     +---w profile-name      string
|     +---w rmep-id           ipi-cfm-data-types:cfm_rmep_type_t
|     +---w start-time-type   ipi-cfm-data-types:cfm_start_time_immediate_t
|     +---w stop-time-type    ipi-cfm-data-types:cfm_absolute_time_t
|     +---w stop-time         string
|     +---w repetition-period yang:timeticks
+---x cfm-l2-eth-lm-on-demand-start-relative-stop-none {feature-
list:Y1731_HW_OFFLOAD}?
|   +---w input

```

```

|     +---w md-name           string
|     +---w ma-name           string
|     +---w mep-id            uint16
|     +---w profile-name      string
|     +---w rmep-id           ipi-cfm-data-types:cfm_rmep_type_t
|     +---w start-time-type   ipi-cfm-data-types:cfm_relative_time_t
|     +---w start-time        string
|     +---w stop-time-type    ipi-cfm-data-types:cfm_stop_time_none_t
|     +---w repetition-period yang:timeticks
+---x cfm-l2-eth-lm-on-demand-start-relative-stop-relative {feature-
list:Y1731_HW_OFFLOAD}?
|   +---w input
|     +---w md-name           string
|     +---w ma-name           string
|     +---w mep-id            uint16
|     +---w profile-name      string
|     +---w rmep-id           ipi-cfm-data-types:cfm_rmep_type_t
|     +---w start-time-type   ipi-cfm-data-types:cfm_relative_time_t
|     +---w start-time        string
|     +---w stop-time-type    ipi-cfm-data-types:cfm_relative_time_t
|     +---w stop-time        string
|     +---w repetition-period yang:timeticks
+---x cfm-l2-eth-lm-on-demand-start-relative-stop-absolute {feature-
list:Y1731_HW_OFFLOAD}?
|   +---w input
|     +---w md-name           string
|     +---w ma-name           string
|     +---w mep-id            uint16
|     +---w profile-name      string
|     +---w rmep-id           ipi-cfm-data-types:cfm_rmep_type_t
|     +---w start-time-type   ipi-cfm-data-types:cfm_relative_time_t
|     +---w start-time        string
|     +---w stop-time-type    ipi-cfm-data-types:cfm_absolute_time_t
|     +---w stop-time        string
|     +---w repetition-period yang:timeticks
+---x cfm-l2-eth-lm-on-demand-start-absolute-stop-none {feature-
list:Y1731_HW_OFFLOAD}?
|   +---w input
|     +---w md-name           string
|     +---w ma-name           string
|     +---w mep-id            uint16
|     +---w profile-name      string
|     +---w rmep-id           ipi-cfm-data-types:cfm_rmep_type_t
|     +---w start-time-type   ipi-cfm-data-types:cfm_absolute_time_t
|     +---w start-time        string
|     +---w stop-time-type    ipi-cfm-data-types:cfm_stop_time_none_t
|     +---w repetition-period yang:timeticks
+---x cfm-l2-eth-lm-on-demand-start-absolute-stop-relative {feature-
list:Y1731_HW_OFFLOAD}?
|   +---w input
|     +---w md-name           string

```

```
|      +---w ma-name                string
|      +---w mep-id                 uint16
|      +---w profile-name           string
|      +---w rmep-id                ipi-cfm-data-types:cfm_rmep_type_t
|      +---w start-time-type        ipi-cfm-data-types:cfm_absolute_time_t
|      +---w start-time             string
|      +---w stop-time-type         ipi-cfm-data-types:cfm_relative_time_t
|      +---w stop-time              string
|      +---w repetition-period      yang:timeticks
+---x cfm-l2-eth-lm-on-demand-start-absolute-stop-absolute {feature-
list:Y1731_HW_OFFLOAD}?
|  +---w input
|    +---w md-name                 string
|    +---w ma-name                 string
|    +---w mep-id                 uint16
|    +---w profile-name           string
|    +---w rmep-id                ipi-cfm-data-types:cfm_rmep_type_t
|    +---w start-time-type        ipi-cfm-data-types:cfm_absolute_time_t
|    +---w start-time             string
|    +---w stop-time-type         ipi-cfm-data-types:cfm_absolute_time_t
|    +---w stop-time              string
|    +---w repetition-period      yang:timeticks
+---x cfm-l2-abort-eth-lm-test {feature-list:HAVE_CFM_Y1731,feature-
list:HAVE_CFM,feature-list:HAVE_ONMD,feature-list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|  +---w input
|    +---w md-name                 string
|    +---w ma-name                 string
|    +---w mep-id                 uint16
+---x cfm-l2-clear-eth-lm-history-stats {feature-list:HAVE_CFM_Y1731,feature-
list:HAVE_CFM,feature-list:HAVE_ONMD,feature-list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|  +---w input
|    +---w md-name                 string
|    +---w ma-name                 string
|    +---w mep-id                 uint16
+---x cfm-l2-eth-dm-start-proactive {feature-list:HAVE_CFM_Y1731,feature-
list:HAVE_CFM,feature-list:HAVE_ONMD,feature-list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|  +---w input
|    +---w md-name                 string
|    +---w ma-name                 string
|    +---w mep-id                 uint16
|    +---w profile-name           string
|    +---w rmep-id                ipi-cfm-data-types:cfm_rmep_type_t
+---x cfm-l2-eth-dm-on-demand-start-immediate-stop-none {feature-
list:HAVE_CFM_Y1731,feature-list:HAVE_CFM,feature-list:HAVE_ONMD,feature-
list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|  +---w input
|    +---w md-name                 string
|    +---w ma-name                 string
|    +---w mep-id                 uint16
|    +---w profile-name           string
|    +---w rmep-id                ipi-cfm-data-types:cfm_rmep_type_t
|    +---w start-time-type        ipi-cfm-data-types:cfm_start_time_immediate_t
```



```

|      +---w stop-time-type      ipi-cfm-data-types:cfm_stop_time_none_t
|      +---w repetition-period    yang:timeticks
+---x cfm-l2-eth-dm-on-demand-start-immediate-stop-relative {feature-
list:HAVE_CFM_Y1731,feature-list:HAVE_CFM,feature-list:HAVE_ONMD,feature-
list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|      +---w input
|      +---w md-name              string
|      +---w ma-name              string
|      +---w mep-id               uint16
|      +---w profile-name         string
|      +---w rmep-id              ipi-cfm-data-types:cfm_rmep_type_t
|      +---w start-time-type      ipi-cfm-data-types:cfm_start_time_immediate_t
|      +---w stop-time-type       ipi-cfm-data-types:cfm_relative_time_t
|      +---w stop-time            string
|      +---w repetition-period    yang:timeticks
+---x cfm-l2-eth-dm-on-demand-start-immediate-stop-absolute {feature-
list:HAVE_CFM_Y1731,feature-list:HAVE_CFM,feature-list:HAVE_ONMD,feature-
list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|      +---w input
|      +---w md-name              string
|      +---w ma-name              string
|      +---w mep-id               uint16
|      +---w profile-name         string
|      +---w rmep-id              ipi-cfm-data-types:cfm_rmep_type_t
|      +---w start-time-type      ipi-cfm-data-types:cfm_start_time_immediate_t
|      +---w stop-time-type       ipi-cfm-data-types:cfm_absolute_time_t
|      +---w stop-time            string
|      +---w repetition-period    yang:timeticks
+---x cfm-l2-eth-dm-on-demand-start-relative-stop-none {feature-
list:HAVE_CFM_Y1731,feature-list:HAVE_CFM,feature-list:HAVE_ONMD,feature-
list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|      +---w input
|      +---w md-name              string
|      +---w ma-name              string
|      +---w mep-id               uint16
|      +---w profile-name         string
|      +---w rmep-id              ipi-cfm-data-types:cfm_rmep_type_t
|      +---w start-time-type      ipi-cfm-data-types:cfm_relative_time_t
|      +---w start-time           string
|      +---w stop-time-type       ipi-cfm-data-types:cfm_stop_time_none_t
|      +---w repetition-period    yang:timeticks
+---x cfm-l2-eth-dm-on-demand-start-relative-stop-relative {feature-
list:HAVE_CFM_Y1731,feature-list:HAVE_CFM,feature-list:HAVE_ONMD,feature-
list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|      +---w input
|      +---w md-name              string
|      +---w ma-name              string
|      +---w mep-id               uint16
|      +---w profile-name         string
|      +---w rmep-id              ipi-cfm-data-types:cfm_rmep_type_t
|      +---w start-time-type      ipi-cfm-data-types:cfm_relative_time_t
|      +---w start-time           string

```

```
|      +---w stop-time-type          ipi-cfm-data-types:cfm_relative_time_t
|      +---w stop-time                string
|      +---w repetition-period        yang:timeticks
+---x cfm-l2-eth-dm-on-demand-start-relative-stop-absolute {feature-
list:HAVE_CFM_Y1731,feature-list:HAVE_CFM,feature-list:HAVE_ONMD,feature-
list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|  +---w input
|  +---w md-name                      string
|  +---w ma-name                      string
|  +---w mep-id                       uint16
|  +---w profile-name                 string
|  +---w rmep-id                      ipi-cfm-data-types:cfm_rmep_type_t
|  +---w start-time-type              ipi-cfm-data-types:cfm_relative_time_t
|  +---w start-time                   string
|  +---w stop-time-type               ipi-cfm-data-types:cfm_absolute_time_t
|  +---w stop-time                    string
|  +---w repetition-period            yang:timeticks
+---x cfm-l2-eth-dm-on-demand-start-absolute-stop-none {feature-
list:HAVE_CFM_Y1731,feature-list:HAVE_CFM,feature-list:HAVE_ONMD,feature-
list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|  +---w input
|  +---w md-name                      string
|  +---w ma-name                      string
|  +---w mep-id                       uint16
|  +---w profile-name                 string
|  +---w rmep-id                      ipi-cfm-data-types:cfm_rmep_type_t
|  +---w start-time-type              ipi-cfm-data-types:cfm_absolute_time_t
|  +---w start-time                   string
|  +---w stop-time-type               ipi-cfm-data-types:cfm_stop_time_none_t
|  +---w repetition-period            yang:timeticks
+---x cfm-l2-eth-dm-on-demand-start-absolute-stop-relative {feature-
list:HAVE_CFM_Y1731,feature-list:HAVE_CFM,feature-list:HAVE_ONMD,feature-
list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|  +---w input
|  +---w md-name                      string
|  +---w ma-name                      string
|  +---w mep-id                       uint16
|  +---w profile-name                 string
|  +---w rmep-id                      ipi-cfm-data-types:cfm_rmep_type_t
|  +---w start-time-type              ipi-cfm-data-types:cfm_absolute_time_t
|  +---w start-time                   string
|  +---w stop-time-type               ipi-cfm-data-types:cfm_relative_time_t
|  +---w stop-time                    string
|  +---w repetition-period            yang:timeticks
+---x cfm-l2-eth-dm-on-demand-start-absolute-stop-absolute {feature-
list:HAVE_CFM_Y1731,feature-list:HAVE_CFM,feature-list:HAVE_ONMD,feature-
list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|  +---w input
|  +---w md-name                      string
|  +---w ma-name                      string
|  +---w mep-id                       uint16
|  +---w profile-name                 string
```

```

|     +---w rmeq-id             ipi-cfm-data-types:cfm_rmeq_type_t
|     +---w start-time-type    ipi-cfm-data-types:cfm_absolute_time_t
|     +---w start-time        string
|     +---w stop-time-type     ipi-cfm-data-types:cfm_absolute_time_t
|     +---w stop-time         string
|     +---w repetition-period  yang:timeticks
+---x cfm-l2-abort-eth-dm-test {feature-list:HAVE_CFM_Y1731,feature-
list:HAVE_CFM,feature-list:HAVE_ONMD,feature-list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|   +---w input
|     +---w md-name          string
|     +---w ma-name          string
|     +---w mep-id           uint16
+---x cfm-l2-clear-eth-dm-history-stats {feature-list:HAVE_CFM_Y1731,feature-
list:HAVE_CFM,feature-list:HAVE_ONMD,feature-list:Y1731_HW_OFFLOAD_OR_HAVE_SWFWDR}?
|   +---w input
|     +---w md-name          string
|     +---w ma-name          string
|     +---w mep-id           uint16
+---x cfm-l2-clear-eth-csf-stats {feature-list:HAVE_DUNE,feature-
list:HAVE_CFM_Y1731}?
|   +---w input
|     +---w mep-id           uint16
|     +---w md-name          string
|     +---w ma-name          string
+---x cfm-l2-clear-eth-bn-stats {feature-list:HAVE_DUNE,feature-
list:HAVE_CFM_Y1731}?
|   +---w input
|     +---w mep-id           uint16
|     +---w md-name          string
|     +---w ma-name          string
+---x cfm-l2-clear-eth-lck-stats {feature-list:HAVE_DUNE,feature-
list:HAVE_CFM_Y1731}?
|   +---w input
|     +---w mep-id           uint16
|     +---w md-name          string
|     +---w ma-name          string
+---x cfm-l2-clear-eth-test-signal-stats {feature-list:Y1731_HW_OFFLOAD,feature-
list:HAVE_DUNE}?
|   +---w input
|     +---w md-name          string
|     +---w ma-name          string
|     +---w mep-id           uint16
|     +---w stats-type      ipi-cfm-data-types:cfm_test_stats_type_t
+---x cfm-l2-clear-ethernet-remote-meps {feature-list:HAVE_CFM,feature-
list:HAVE_ONMD}?
|   +---w input
|     +---w domain-name      string
+---x cfm-clear-all-mep-stats {feature-list:HAVE_CFM}?
+---x cfm-l2-clear-mep-stats {feature-list:HAVE_CFM}?
|   +---w input
|     +---w domain-name      string
|     +---w mep-id           uint16

```

```

|      +---w ma-name          string
+---x cfm-snmp-restart {feature-list:HAVE_CFM,feature-list:HAVE_ONMD}?
+---x cfm-terminal-debug-on {feature-list:HAVE_CFM,feature-list:HAVE_ONMD}?
|  +---w input
|      +---w terminal-debug-options      ipi-cfm-data-types:cfm_debug_t
+---x cfm-terminal-debug-off {feature-list:HAVE_CFM,feature-list:HAVE_ONMD}?
|  +---w input
|      +---w terminal-debug-options      ipi-cfm-data-types:cfm_debug_t
+---x cfm-l2-test-loopback {feature-list:HAVE_CFM,feature-list:HAVE_ONMD}?
|  +---w input
|      +---w md-name          string
|      +---w ma-name          string
|      +---w mep-id           uint16
|      +---w mac-address      ipi-cfm-data-types:cfm_lb_mac_addr_t
+---x cfm-l2-test-linktrace {feature-list:HAVE_CFM,feature-list:HAVE_ONMD}?
|  +---w input
|  |  +---w md-name          string
|  |  +---w ma-name          string
|  |  +---w mep-id           uint16
|  |  +---w mac-address      ipi-cfm-data-types:cfm_lb_mac_addr_t
|  +---ro output
|      +---ro transaction-id    uint32
+---x cfm-l2-clear-linktrace-cache {feature-list:HAVE_CFM,feature-list:HAVE_ONMD}?

notifications:
+---n cfm-l2-mep-ccm-highest-fault-info {feature-list:HAVE_CFM}?
|  +---ro severity?            cml-data-types:cml_notif_severity_t
|  +---ro eventClass?         cml-data-types:cml_notif_class_t
|  +---ro mep-id?             uint16
|  +---ro ma-name?            string
|  +---ro md-name?            string
|  +---ro highest-priority-defect-found? ipi-cfm-data-
types:cfm_mep_highest_fault_defect_t
+---n cfm-l2-ethernet-loopback-test-completed {feature-list:HAVE_CFM}?
|  +---ro severity?            cml-data-types:cml_notif_severity_t
|  +---ro eventClass?         cml-data-types:cml_notif_class_t
|  +---ro mep-id?             uint16
|  +---ro ma-name?            string
|  +---ro md-name?            string
|  +---ro target-mac-address? ipi-cfm-data-types:cfm_rmep_mac_addr_t
+---n cfm-l2-ethernet-linktrace-test-completed {feature-list:HAVE_CFM}?
|  +---ro severity?            cml-data-types:cml_notif_severity_t
|  +---ro eventClass?         cml-data-types:cml_notif_class_t
|  +---ro transaction-id?     uint32
|  +---ro mep-id?             uint16
|  +---ro ma-name?            string
|  +---ro md-name?            string
|  +---ro target-mac-address? ipi-cfm-data-types:cfm_rmep_mac_addr_t
+---n cfm-eth-csf-los-set {feature-list:HAVE_CFM,feature-list:HAVE_DUNE,feature-
list:HAVE_CFM_Y1731}?
|  +---ro severity?            cml-data-types:cml_notif_severity_t

```

```

| +--ro eventClass?      cml-data-types:cml_notif_class_t
| +--ro mep-id?         uint16
| +--ro ma-name?        string
| +--ro md-name?        string
| +--ro signal-state?   ipi-cfm-data-types:cfm_bn_csf_signal_state_t
+---n cfm-eth-csf-los-reset {feature-list:HAVE_CFM,feature-list:HAVE_DUNE,feature-
list:HAVE_CFM_Y1731}?
| +--ro severity?       cml-data-types:cml_notif_severity_t
| +--ro eventClass?     cml-data-types:cml_notif_class_t
| +--ro mep-id?         uint16
| +--ro ma-name?        string
| +--ro md-name?        string
| +--ro signal-state?   ipi-cfm-data-types:cfm_bn_csf_signal_state_t
+---n cfm-eth-bnm-bw-update {feature-list:HAVE_CFM,feature-list:HAVE_DUNE,feature-
list:HAVE_CFM_Y1731}?
  +--ro severity?       cml-data-types:cml_notif_severity_t
  +--ro eventClass?     cml-data-types:cml_notif_class_t
  +--ro mep-id?         uint16
  +--ro ma-name?        string
  +--ro md-name?        string
  +--ro nominal-bandwidth? string
  +--ro current-bandwidth? string

```

module: ipi-cross-connect

```

augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance:
  +--rw cross-connect
    +--rw config
      | +--rw xc-name?      -> /ipi-network-instance:network-instances/network-
instance/instance-name
      | +--rw description?  cml-data-types:cml_line_t
      | +--rw admin-disable? empty
      +--ro state
      | +--ro xc-name?      -> /ipi-network-instance:network-instances/network-
instance/instance-name
      | +--ro description?  cml-data-types:cml_line_t
      | +--ro admin-disable? empty
      | +--ro operational-state? ipi-cross-connect-types:xc_oper_status_t
    +--rw cross-connect-interfaces
      +--rw cross-connect-interface* [endpoint-if]
        +--rw endpoint-if  -> ../config/endpoint-if
        +--rw config
          | +--rw endpoint-if? -> /ipi-interface:interfaces/interface/name
          +--ro state
            +--ro endpoint-if? -> /ipi-interface:interfaces/interface/name

```

module: ipi-crypto

```

rpcs:
  +---x crypto-rsa-key-gen {feature-list:HAVE_HOSTPD}?
    +---w input
      +---w ipv4-addr    inet:ipv4-address

```

module: ipi-delay-profile

```

+--rw delay-profiles
  +--rw delay-profile* [profile-type]
    | +--rw profile-type          -> ../config/profile-type
    | +--rw config
    | | +--rw profile-type?      ipi-delay-profile-types:delay_profile_type_t
    | +--ro state
    | | +--ro profile-type?      ipi-delay-profile-types:delay_profile_type_t
    | +--rw profile-parameters
    | | +--rw config
    | | | +--rw burst-interval?  uint16
    | | | +--rw burst-count?     uint8
    | | | +--rw interval?        uint16
    | | | +--rw mode?            ipi-delay-profile-
types:delay_profile_measurement_mode_t
    | | | +--rw sender-port?     uint16
    | | +--ro state
    | |   +--ro burst-interval?  uint16
    | |   +--ro burst-count?     uint8
    | |   +--ro interval?        uint16
    | |   +--ro mode?            ipi-delay-profile-
types:delay_profile_measurement_mode_t
    | |   +--ro sender-port?     uint16
    | +--rw periodic-advertisement
    | | +--rw config
    | | | +--rw disable?         empty
    | | | +--rw threshold?       uint8
    | | | +--rw minimum-change?  uint16
    | | +--ro state
    | |   +--ro disable?         empty
    | |   +--ro threshold?       uint8
    | |   +--ro minimum-change?  uint16
    | +--rw accelerated-advertisement
    |   +--rw config!
    |   | +--rw enable           empty
    |   | +--rw threshold?       uint8
    |   | +--rw minimum-change?  uint16
    |   +--ro state

```

```

|         +---ro enable                empty
|         +---ro threshold?            uint8
|         +---ro minimum-change?       uint16
+---rw delay-profile-clients
  +---rw config!
    | +---rw delay-profile-enable       empty
    | +---rw burst-interval?           uint16
    | +---rw burst-count?              uint8
  +---ro state
    +---ro delay-profile-enable        empty
    +---ro burst-interval?             uint16
    +---ro burst-count?                uint8

```

module: ipi-dhcp

```

+---rw dhcp
  +---rw global
    | +---rw config
    | | +---rw disable-dhcp-feature?   empty
    | +---ro state
    | +---ro disable-dhcp-feature?     empty
  +---rw relay
    | +---rw global
    | | +---rw config
    | | | +---rw disable-dhcpv4-relay?  empty
    | | | +---rw disable-dhcpv6-relay?  empty
    | | +---ro state
    | | +---ro disable-dhcpv4-relay?    empty
    | | +---ro disable-dhcpv6-relay?    empty
    +---rw interfaces
    | +---rw interface* [name]
    | | +---rw name                    -> ../config/name
    | | +---rw config
    | | | +---rw name?                  -> /ipi-interface:interfaces/interface/
name
    | | | +---rw ipv4-relay-interface?  empty
    | | | +---rw ipv4-uplink-interface? empty
    | | | +---rw ipv4-group-name?       string
    | | | +---rw ipv6-relay-interface?  empty {feature-list:HAVE_IPV6}?
    | | | +---rw ipv6-uplink-interface? empty {feature-list:HAVE_IPV6}?
    | | | +---rw ipv6-group-name?       string
    | | +---ro state

```

```

name | | +---ro name? -> /ipi-interface:interfaces/interface/
| | +---ro ipv4-relay-interface? empty
| | +---ro ipv4-uplink-interface? empty
| | +---ro ipv4-group-name? string
| | +---ro ipv6-relay-interface? empty {feature-list:HAVE_IPV6}?
| | +---ro ipv6-uplink-interface? empty {feature-list:HAVE_IPV6}?
| | +---ro ipv6-group-name? string
| +---rw vrfs
| | +---rw vrf* [vrf-name]
| | | +---rw vrf-name -> ../config/vrf-name
| | | +---rw config
| | | | +---rw vrf-name? -> /ipi-network-
instance:network-instances/network-instance/ipi-vrf:vrf/config/vrf-name
| | | | +---rw link-selection-source-ip? inet:ipv4-address
| | | | +---rw enable-option82? empty
| | | | +---rw enable-option82-always-on? empty
| | | | +---rw enable-dhcpv6-pd-route-injection? empty {feature-
list:HAVE_IPV6}?
| | | | +---rw remote-id? ipi-dhcp-relay-
types:dhcp_remote_id_t
| | | | +---rw subscriber-id? string
| | | | +---ro state
| | | | +---ro vrf-name? -> /ipi-network-
instance:network-instances/network-instance/ipi-vrf:vrf/config/vrf-name
| | | | +---ro link-selection-source-ip? inet:ipv4-address
| | | | +---ro enable-option82? empty
| | | | +---ro enable-option82-always-on? empty
| | | | +---ro enable-dhcpv6-pd-route-injection? empty {feature-
list:HAVE_IPV6}?
| | | | +---ro remote-id? ipi-dhcp-relay-
types:dhcp_remote_id_t
| | | | +---ro subscriber-id? string
| | | | +---ro bogus-giaddr-drops? uint32
| | | | +---ro client-packets-relayed? uint32
| | | | +---ro server-packet-errors? uint32
| | | | +---ro server-packets-relayed? uint32
| | | | +---ro client-packet-errors? uint32
| | | | +---ro agent-option-errors? uint32
| | | | +---ro corrupt-agent-options? uint32
| | | | +---ro missing-agent-option? uint32
| | | | +---ro bad-circuit-id? uint32
| | | | +---ro missing-circuit-id? uint32
| | | | +---ro circuit-id? string
| | +---rw ipv4-vpn-links
| | | +---rw ipv4-vpn-link* [interface-type]
| | | | +---rw interface-type -> ../config/interface-type
| | | | +---rw config
| | | | | +---rw interface-type? ipi-dhcp-relay-
types:dhcp_vpn_interface_type_t
| | | | | +---rw interface-direction ipi-dhcp-relay-
types:dhcp_vpn_interface_direction_t

```



```

|         |         +---ro state
|         |         +---ro interface-type?           ipi-dhcp-relay-
types:dhcp_vpn_interface_type_t
|         |         +---ro interface-direction       ipi-dhcp-relay-
types:dhcp_vpn_interface_direction_t
|         |         +---rw ipv6-vpn-links
|         |         +---rw ipv6-vpn-link* [interface-type-v6] {feature-list:HAVE_IPV6}?
|         |         +---rw interface-type-v6        -> ../config/interface-type-v6
|         |         +---rw config
|         |         | +---rw interface-type-v6?           ipi-dhcp-relay-
types:dhcp_vpn_interface_type_t
|         |         | +---rw interface-direction-v6       ipi-dhcp-relay-
types:dhcp_vpn_interface_direction_t
|         |         +---ro state
|         |         +---ro interface-type-v6?         ipi-dhcp-relay-
types:dhcp_vpn_interface_type_t
|         |         +---ro interface-direction-v6     ipi-dhcp-relay-
types:dhcp_vpn_interface_direction_t
|         |         +---ro dhcpv6-delegated-prefixes* [interface-name] {feature-
list:HAVE_IPV6}?
|         |         +---ro interface-name            -> ../state/interface-name
|         |         +---ro state
|         |         +---ro interface-name?           string
|         |         +---ro next-hop?                 inet:ipv6-address
|         |         +---ro prefix?                   cml-data-types:cml_ipv6_prefix_t
|         |         +---ro preferred-lifetime?       uint32
|         |         +---ro maximum-lifetime?         uint32
|         |         +---ro prefix-start-time?        yang:date-and-time
|         |         +---ro prefix-expiry-time?       yang:date-and-time
|         |         +---ro state?                     ipi-dhcp-relay-
types:dhcp6_pd_route_state_t
|         |         +---rw ipv4-dhcp-servers
|         |         | +---rw ipv4-dhcp-server* [ip-address]
|         |         | +---rw ip-address              -> ../config/ip-address
|         |         | +---rw config
|         |         | | +---rw ip-address?             inet:ipv4-address
|         |         | | +---rw dhcpv4-server-global-vrf? -> /ipi-network-
instance:network-instances/network-instance/ipi-vrf:vrf/config/vrf-name
|         |         | +---ro state
|         |         | +---ro ip-address?             inet:ipv4-address
|         |         | +---ro dhcpv4-server-global-vrf? -> /ipi-network-
instance:network-instances/network-instance/ipi-vrf:vrf/config/vrf-name
|         |         | +---rw ipv6-dhcp-servers {feature-list:HAVE_IPV6}?
|         |         | +---rw ipv6-dhcp-server* [ipv6-address]
|         |         | +---rw ipv6-address            -> ../config/ipv6-address
|         |         | +---rw config
|         |         | | +---rw ipv6-address?           inet:ipv6-address {feature-
list:HAVE_IPV6}?
|         |         | | +---rw dhcpv6-server-global-vrf? -> /ipi-network-
instance:network-instances/network-instance/ipi-vrf:vrf/config/vrf-name
|         |         | +---ro state
|         |         | +---ro ipv6-address?           inet:ipv6-address {feature-
list:HAVE_IPV6}?

```

```

|           |           +---ro dhcpv6-server-global-vrf?  -> /ipi-network-
instance:network-instances/network-instance/ipi-vrf:vrf/config/vrf-name
|           |           +---rw dhcp-groups
|           |           |           +---rw dhcp-group* [group-name]
|           |           |           |           +---rw group-name      -> ../config/group-name
|           |           |           |           +---rw config
|           |           |           |           |           +---rw group-name?   string
|           |           |           |           |           +---rw server*       inet:ipv4-address
|           |           |           |           +---ro state
|           |           |           |           |           +---ro group-name?   string
|           |           |           |           |           +---ro server*       inet:ipv4-address
|           |           +---rw dhcpv6-groups {feature-list:HAVE_IPV6}?
|           |           |           +---rw dhcpv6-group* [group6-name]
|           |           |           |           +---rw group6-name      -> ../config/group6-name
|           |           |           |           +---rw config
|           |           |           |           |           +---rw group6-name?   string
|           |           |           |           |           +---rw server*       inet:ipv6-address
|           |           |           |           +---ro state
|           |           |           |           |           +---ro group6-name?   string
|           |           |           |           |           +---ro server*       inet:ipv6-address
+---rw client
|   +---rw interfaces
|       +---rw interface* [name]
|           +---rw name                -> ../config/name
|           +---rw config
name |           |           +---rw name?                -> /ipi-interface:interfaces/interface/
|           |           |           +---rw request-ipv4-dns?                empty
|           |           |           +---rw request-log-server?            empty {feature-list:HAVE_SYSLOG}?
|           |           |           +---rw request-host-name?            empty
|           |           |           +---rw request-ntp-server?            empty {feature-list:HAVE_HOSTP_NTP}?
|           |           |           +---rw request-ipv6-dns?              empty {feature-list:HAVE_IPV6}?
|           |           |           +---rw request-ipv6-domain-list?      empty {feature-list:HAVE_IPV6}?
|           |           |           +---rw request-ipv6-ntp-server?       empty {feature-list:HAVE_IPV6}?
|           |           |           +---rw request-ipv6-rapid-commit?     empty {feature-list:HAVE_IPV6}?
|           |           |           +---rw request-ipv6-vendor-opts?     empty {feature-list:HAVE_IPV6}?
|           |           |           +---rw ipv6-information-request?      empty {feature-list:HAVE_IPV6}?
|           |           |           +---rw ipv6-dad-wait-time?            uint16 {feature-list:HAVE_IPV6}?
|           |           |           +---rw ipv6-client-duid-type?        cml-data-types:dhcp6_duid_type_t
{feature-list:HAVE_IPV6}?
|           |           |           +---rw request-ipv6-prefix?            string {feature-list:HAVE_IPV6}?
|           |           |           +---ro state
name |           |           |           +---ro name?                -> /ipi-interface:interfaces/interface/
|           |           |           |           +---ro request-ipv4-dns?                empty
|           |           |           |           +---ro request-log-server?            empty {feature-list:HAVE_SYSLOG}?
|           |           |           |           +---ro request-host-name?            empty
|           |           |           |           +---ro request-ntp-server?            empty {feature-list:HAVE_HOSTP_NTP}?
|           |           |           |           +---ro request-ipv6-dns?              empty {feature-list:HAVE_IPV6}?
|           |           |           |           +---ro request-ipv6-domain-list?      empty {feature-list:HAVE_IPV6}?
|           |           |           |           +---ro request-ipv6-ntp-server?       empty {feature-list:HAVE_IPV6}?

```

```

|         | +---ro request-ipv6-rapid-commit?    empty {feature-list:HAVE_IPV6}?
|         | +---ro request-ipv6-vendor-opts?     empty {feature-list:HAVE_IPV6}?
|         | +---ro ipv6-information-request?     empty {feature-list:HAVE_IPV6}?
|         | +---ro ipv6-dad-wait-time?          uint16 {feature-list:HAVE_IPV6}?
|         | +---ro ipv6-client-duid-type?       cml-data-types:dhcp6_duid_type_t
{feature-list:HAVE_IPV6}?
|         | +---ro request-ipv6-prefix?         string {feature-list:HAVE_IPV6}?
|         +---ro learned-prefix
|         | +---ro state
|         |     +---ro learnt-prefix?           cml-data-types:cml_ipv6_prefix_t
|         |     +---ro max-lifetime?           uint32
|         |     +---ro preferred-lifetime?     uint32
|         +---rw prefix-ipv6-addresses {feature-list:HAVE_IPV6}?
|             +---rw prefix-ipv6-address* [prefix-name suffix-ipv6-addr]
|                 +---rw prefix-name           -> ../config/prefix-name
|                 +---rw suffix-ipv6-addr     -> ../config/suffix-ipv6-addr
|                 +---rw config
|                     | +---rw prefix-name?     string
|                     | +---rw suffix-ipv6-addr? string
|                     +---ro state
|                         +---ro prefix-name?   string
|                         +---ro suffix-ipv6-addr? string
+---rw server
|   +---rw interfaces
|   | +---rw interface* [name]
|   |   +---rw name           -> ../config/name
|   |   +---rw config
|   |   | +---rw name?         -> /ipi-interface:interfaces/interface/name
|   |   | +---rw enable-ipv4-server? empty
|   |   | +---rw enable-ipv6-server? empty {feature-list:HAVE_IPV6}?
|   |   +---ro state
|   |   | +---ro name?         -> /ipi-interface:interfaces/interface/name
|   |   | +---ro enable-ipv4-server? empty
|   |   | +---ro enable-ipv6-server? empty {feature-list:HAVE_IPV6}?
|   +---rw vrfs
|       +---rw vrf* [vrf-name]
|           +---rw vrf-name     -> ../config/vrf-name
|           +---rw config
|               | +---rw max-lease-time?     uint32
|               | +---rw default-lease-time? uint32
|               | +---rw rapid-commit?       empty
|               | +---rw preference?         empty
|               | +---rw vrf-name?           -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
|               +---ro state
|               | +---ro max-lease-time?     uint32
|               | +---ro default-lease-time? uint32
|               | +---ro rapid-commit?       empty
|               | +---ro preference?         empty
|               | +---ro vrf-name?           -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name

```

```
|      +---rw dhcp-pools
|      |      +---rw dhcp-pool* [pool-name]
|      |      |      +---rw pool-name      -> ../config/pool-name
|      |      |      +---rw config
|      |      |      |      +---rw pool-name?          string
|      |      |      |      +---rw host-name?         string
|      |      |      |      +---rw routers?           inet:ipv4-address
|      |      |      |      +---rw ntp-server*        inet:ipv4-address
|      |      |      |      +---rw boot-file?         string
|      |      |      |      +---rw tftp-server?       inet:ipv4-address
|      |      |      |      +---rw log-server*        inet:ipv4-address
|      |      |      |      +---rw dns-server*        inet:ipv4-address
|      |      |      |      +---rw network?           inet:ipv4-address
|      |      |      |      +---rw netmask?           inet:ipv4-address
|      |      |      |      +---rw low-address-in-range? inet:ipv4-address
|      |      |      |      +---rw high-address-in-range? inet:ipv4-address
|      |      |      +---ro state
|      |      |      |      +---ro pool-name?         string
|      |      |      |      +---ro host-name?         string
|      |      |      |      +---ro routers?           inet:ipv4-address
|      |      |      |      +---ro ntp-server*        inet:ipv4-address
|      |      |      |      +---ro boot-file?         string
|      |      |      |      +---ro tftp-server?       inet:ipv4-address
|      |      |      |      +---ro log-server*        inet:ipv4-address
|      |      |      |      +---ro dns-server*        inet:ipv4-address
|      |      |      |      +---ro network?           inet:ipv4-address
|      |      |      |      +---ro netmask?           inet:ipv4-address
|      |      |      |      +---ro low-address-in-range? inet:ipv4-address
|      |      |      |      +---ro high-address-in-range? inet:ipv4-address
|      +---rw dhcp6-pools {feature-list:HAVE_IPV6}?
|      |      +---rw dhcp6-pool* [pool6-name]
|      |      |      +---rw pool6-name      -> ../config/pool6-name
|      |      |      +---rw config
|      |      |      |      +---rw pool6-name?          string
|      |      |      |      +---rw domain-name?         string
|      |      |      |      +---rw vendor-options?      cml-data-types:cml_line_t
|      |      |      |      +---rw ntp-server*        inet:ipv6-address
|      |      |      |      +---rw dns-server*        inet:ipv6-address
|      |      |      |      +---rw ipv6-network?       inet:ipv6-address
|      |      |      |      +---rw ipv6-netmask?       uint8
|      |      |      |      +---rw low-address-in-range? inet:ipv6-address
|      |      |      |      +---rw high-address-in-range? inet:ipv6-address
|      |      |      |      +---rw temporary-address?   inet:ipv6-address
|      |      |      |      +---rw ipv6-prefix-high-address? inet:ipv6-address
|      |      |      |      +---rw ipv6-prefix-low-address? inet:ipv6-address
|      |      |      |      +---rw ipv6-prefix-netmask? uint8
|      |      |      +---ro state
|      |      |      |      +---ro pool6-name?          string
|      |      |      |      +---ro domain-name?         string
|      |      |      |      +---ro vendor-options?      cml-data-types:cml_line_t
```

```

|           +---ro ntp-server*           inet:ipv6-address
|           +---ro dns-server*          inet:ipv6-address
|           +---ro ipv6-network?        inet:ipv6-address
|           +---ro ipv6-netmask?        uint8
|           +---ro low-address-in-range? inet:ipv6-address
|           +---ro high-address-in-range? inet:ipv6-address
|           +---ro temporary-address?    inet:ipv6-address
|           +---ro ipv6-prefix-high-address? inet:ipv6-address
|           +---ro ipv6-prefix-low-address? inet:ipv6-address
|           +---ro ipv6-prefix-netmask?  uint8
+---rw snooping
  +---rw debug
    | +---rw config
    | | +---rw options?   ipi-dhcp-snooping-types:dhcp_snooping_debug_t
    | | +---ro state
    | | +---ro options?   ipi-dhcp-snooping-types:dhcp_snooping_debug_t
    | | +---ro terminal-debug-status? ipi-dhcp-snooping-
types:dhcp_snooping_debug_t
  +---rw snooping-bridges
    | +---rw snooping-bridge* [bridge-id]
    |   +---rw bridge-id      -> ../config/bridge-id
    |   +---rw config!
    |   | +---rw snooping-enable      empty
    |   | +---rw bridge-id?           -> /ipi-network-instance:network-instances/
network-instance/instance-name
    |   | +---rw verify-mac-address?   empty
    |   | +---rw option-82-enable?     empty
    |   | +---rw write-delay?          uint32
    |   | +---rw strict-validation?    empty
    |   | +---rw vlan-range?           cml-data-types:cml_range_t
    |   +---ro state
    |   | +---ro snooping-enable      empty
    |   | +---ro bridge-id?           -> /ipi-network-instance:network-instances/
network-instance/instance-name
    |   | +---ro verify-mac-address?   empty
    |   | +---ro option-82-enable?     empty
    |   | +---ro write-delay?          uint32
    |   | +---ro strict-validation?    empty
    |   | +---ro vlan-range?           cml-data-types:cml_range_t
    |   +---rw arp-inspection
    |   | +---rw config!
    |   | | +---rw enable              empty
    |   | | +---rw validate?           ipi-dhcp-snooping-
types:dhcp_snooping_validation_t
    |   | | +---rw vlan-range?         cml-data-types:cml_range_t
    |   | +---ro state
    |   |   +---ro enable              empty
    |   |   +---ro validate?           ipi-dhcp-snooping-
types:dhcp_snooping_validation_t
    |   |   +---ro vlan-range?         cml-data-types:cml_range_t
    |   |   +---ro counters

```

```

|         |         +---ro forwarded?   yang:counter32
|         |         +---ro dropped?    yang:counter32
|         +---rw vlans
|             +---rw vlan* [vlan-id]
|                 +---rw vlan-id        -> ../config/vlan-id
|                 +---rw config
|                     | +---rw vlan-id?  uint16
|                 +---ro state
|                     | +---ro vlan-id?  uint16
|                     | +---ro statistics
|                         | +---ro static-entries-ipv4?  yang:counter32
|                         | +---ro dynamic-entries-ipv4? yang:counter32
|                         | +---ro static-entries-ipv6?  yang:counter32 {feature-
list:HAVE_IPV6}?
|                         | +---ro dynamic-entries-ipv6?  yang:counter32 {feature-
list:HAVE_IPV6}?
|                 +---rw mac-addresses-ipv4
|                     | +---rw mac-address-ipv4* [mac-address]
|                     | +---rw mac-address  -> ../config/mac-address
|                     | +---rw config
|                 |         | +---rw if-name        -> /ipi-interface:interfaces/interface/
name
|                 |         | +---rw ipv4-address   inet:ipv4-address
|                 |         | +---rw mac-address?   cml-data-types:cml_mac_addr_t
|                 |         +---ro state
|                 |         +---ro if-name        -> /ipi-interface:interfaces/interface/
name
|                 |         | +---ro ipv4-address   inet:ipv4-address
|                 |         | +---ro mac-address?   cml-data-types:cml_mac_addr_t
|                 +---rw mac-addresses-ipv6 {feature-list:HAVE_IPV6}?
|                     | +---rw mac-address-ipv6* [mac-address]
|                     | +---rw mac-address  -> ../config/mac-address
|                     | +---rw config
|                 |         | +---rw if-name        -> /ipi-interface:interfaces/interface/
name
|                 |         | +---rw ipv6-address   inet:ipv6-address
|                 |         | +---rw mac-address?   cml-data-types:cml_mac_addr_t
|                 |         +---ro state
|                 |         +---ro if-name        -> /ipi-interface:interfaces/interface/
name
|                 |         | +---ro ipv6-address   inet:ipv6-address
|                 |         | +---ro mac-address?   cml-data-types:cml_mac_addr_t
|                 +---ro snooping-binding-info
|                     +---ro ipv4* [mac-address ip-address]
|                         | +---ro mac-address  -> ../state/mac-address
|                         | +---ro ip-address   -> ../state/ip-address
|                         | +---ro state
|                         |         | +---ro mac-address?  cml-data-types:cml_mac_addr_t
|                         |         | +---ro lease-time?  uint32
|                         |         | +---ro type?        ipi-dhcp-snooping-
types:dhcp_snooping_binding_type_t
|                         |         +---ro if-name?      string

```

```

|           |           +---ro ip-address?      inet:ipv4-address
|           +---ro ipv6* [mac-address ip-address] {feature-list:HAVE_IPV6}?
|           +---ro mac-address      -> ../state/mac-address
|           +---ro ip-address       -> ../state/ip-address
|           +---ro state
|           +---ro mac-address?     cml-data-types:cml_mac_addr_t
|           +---ro lease-time?     uint32
|           +---ro type?            ipi-dhcp-snooping-
types:dhcp_snooping_binding_type_t
|           +---ro if-name?         string
|           +---ro ip-address?     inet:ipv6-address
+---rw interfaces
  +---rw interface* [name]
    +---rw name                    -> ../config/name
    +---rw config
      | +---rw name?               -> /ipi-interface:interfaces/interface/name
    +---ro state
      | +---ro name?              -> /ipi-interface:interfaces/interface/name
    +---rw trust
      | +---rw config
      | | +---rw snooping-trust?   empty
      | +---ro state
      |   +---ro snooping-trust?   empty
    +---rw verify
      | +---rw config!
      | | +---rw verify-snooping-vlan      empty
      | | +---rw verify-access-group-mode? empty
      | +---ro state
      |   +---ro verify-snooping-vlan      empty
      |   +---ro verify-access-group-mode? empty
    +---ro snooping-binding-info
      | +---ro ipv4-entries
      | | +---ro ipv4-entry* [ip-address]
      | |   +---ro ip-address      -> ../state/ip-address
      | |   +---ro state
      | |     +---ro interface?    string
      | |     +---ro filter-type?  ipi-dhcp-snooping-
types:dhcp_snooping_filter_type_t
      | |       +---ro vlan-id?     uint16
      | |       +---ro mac-address? cml-data-types:cml_mac_addr_t
      | |       +---ro ip-address?  inet:ipv4-address
      | +---ro ipv6-entries {feature-list:HAVE_IPV6}?
      |   +---ro ipv6-entry* [ip-address]
      |     +---ro ip-address      -> ../state/ip-address
      |     +---ro state
      |       +---ro interface?    string
      |       +---ro filter-type?  ipi-dhcp-snooping-
types:dhcp_snooping_filter_type_t
      |         +---ro vlan-id?     uint16
      |         +---ro mac-address? cml-data-types:cml_mac_addr_t
      |         +---ro ip-address?  inet:ipv6-address

```

```

        +---ro source-binding-info
            +---ro ipv4-entries
                | +---ro ipv4-entry* [ip-address]
                |     +---ro ip-address    -> ../state/ip-address
                |     +---ro state
                |     +---ro interface?    string
                |     +---ro filter-type?  ipi-dhcp-snooping-
types:dhcp_snooping_filter_type_t
                |     +---ro vlan-id?      uint16
                |     +---ro mac-address?  cml-data-types:cml_mac_addr_t
                |     +---ro ip-address?   inet:ipv4-address
            +---ro ipv6-entries {feature-list:HAVE_IPV6}?
                +---ro ipv6-entry* [ip-address]
                +---ro ip-address    -> ../state/ip-address
                +---ro state
                    +---ro interface?    string
                    +---ro filter-type?  ipi-dhcp-snooping-
types:dhcp_snooping_filter_type_t
                    +---ro vlan-id?      uint16
                    +---ro mac-address?  cml-data-types:cml_mac_addr_t
                    +---ro ip-address?   inet:ipv6-address

rpcs:
    +---x clear-relay-stats {feature-list:HAVE_HOSTPD,feature-
list:HAVE_HOSTP_DHCP_RELAY,feature-
list:HAVE_DHCP_CLIENT_OR_HAVE_HOSTPD_OR_HAVE_DHCP_SNOOP}?
    +---x clear-relay-option-stats {feature-list:HAVE_HOSTPD,feature-
list:HAVE_HOSTP_DHCP_RELAY,feature-
list:HAVE_DHCP_CLIENT_OR_HAVE_HOSTPD_OR_HAVE_DHCP_SNOOP}?
    +---x clear-dhcpv6-pd-route {feature-list:HAVE_HOSTPD,feature-
list:HAVE_HOSTP_DHCP_RELAY,feature-
list:HAVE_DHCP_CLIENT_OR_HAVE_HOSTPD_OR_HAVE_DHCP_SNOOP}?
    | +---w input
    |     +---w vrf-name    string
    +---x dhcp-snooping-write-database {feature-list:HAVE_DHCP_SNOOP,feature-
list:HAVE_L2,feature-list:HAVE_DHCP_CLIENT_OR_HAVE_HOSTPD_OR_HAVE_DHCP_SNOOP}?
    | +---w input
    |     +---w bridge-id  string
    +---x dhcp-snooping-renew-database {feature-list:HAVE_DHCP_SNOOP,feature-
list:HAVE_L2,feature-list:HAVE_DHCP_CLIENT_OR_HAVE_HOSTPD_OR_HAVE_DHCP_SNOOP}?
    | +---w input
    |     +---w bridge-id  string
    +---x dhcp-snooping-write-source-binding-database {feature-
list:HAVE_DHCP_SNOOP,feature-list:HAVE_L2,feature-
list:HAVE_DHCP_CLIENT_OR_HAVE_HOSTPD_OR_HAVE_DHCP_SNOOP}?
    | +---w input
    |     +---w bridge-id  string
    +---x dhcp-snooping-renew-source-database {feature-list:HAVE_DHCP_SNOOP,feature-
list:HAVE_L2,feature-list:HAVE_DHCP_CLIENT_OR_HAVE_HOSTPD_OR_HAVE_DHCP_SNOOP}?
    | +---w input
    |     +---w bridge-id  string
    +---x dhcp-snooping-clear-source-binding-database {feature-
list:HAVE_DHCP_SNOOP,feature-list:HAVE_L2,feature-
list:HAVE_DHCP_CLIENT_OR_HAVE_HOSTPD_OR_HAVE_DHCP_SNOOP}?

```



```

| +---w input
|   +---w bridge-id    string
+---x dhcp-snooping-clear-database {feature-list:HAVE_DHCP_SNOOP,feature-
list:HAVE_L2,feature-list:HAVE_DHCP_CLIENT_OR_HAVE_HOSTPD_OR_HAVE_DHCP_SNOOP}?
| +---w input
|   +---w bridge-id    string
+---x dhcp-snooping-terminal-debug-on {feature-list:HAVE_DHCP_SNOOP,feature-
list:HAVE_L2,feature-list:HAVE_DHCP_CLIENT_OR_HAVE_HOSTPD_OR_HAVE_DHCP_SNOOP}?
| +---w input
|   +---w terminal-debug-options    ipi-dhcp-snooping-types:dhcp_snooping_debug_t
+---x dhcp-snooping-terminal-debug-off {feature-list:HAVE_DHCP_SNOOP,feature-
list:HAVE_L2,feature-list:HAVE_DHCP_CLIENT_OR_HAVE_HOSTPD_OR_HAVE_DHCP_SNOOP}?
+---w input
+---w terminal-debug-options    ipi-dhcp-snooping-types:dhcp_snooping_debug_t

```

notifications:

```

+---n dhcpv6-relay-pd-route
+--ro severity?          cml-data-types:cml_notif_severity_t
+--ro eventClass?       cml-data-types:cml_notif_class_t
+--ro vrf-name?         string
+--ro interface-name?   string
+--ro state?            ipi-dhcp-relay-types:dhcp6_pd_route_state_t
+--ro prefix?           cml-data-types:cml_ipv6_prefix_t
+--ro next-hop?         inet:ipv6-address

```

module: ipi-dns-client

```

+--rw dns
+--rw vrfs
| +--rw vrf* [vrf-name]
|   +--rw vrf-name      -> ../config/vrf-name
|   +--rw config
|     | +--rw vrf-name?   -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
|     | +--rw lookup-enabled?    boolean
|     | +--rw default-domain-name?  inet:domain-name
|     +--ro state
|     | +--ro vrf-name?           -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
|     | +--ro lookup-enabled?      boolean
|     | +--ro default-domain-name?  inet:domain-name
|   +--rw servers
|     | +--rw server* [address]
|     |   +--rw address  -> ../config/address
|     |   +--rw config
|     |     | +--rw address?  inet:ip-address
|     |     | +--ro state
|     |     | +--ro address?  inet:ip-address
|     +--rw search-domains

```

```

|   | +--rw search-domain* [domain-name]
|   |   +--rw domain-name    -> ../config/domain-name
|   |   +--rw config
|   |   | +--rw domain-name?  inet:domain-name
|   |   +--ro state
|   |     +--ro domain-name?  inet:domain-name
| +--rw host-entries
|   +--rw host-entry* [hostname]
|     +--rw hostname    -> ../config/hostname
|     +--rw config
|       | +--rw hostname?    cml-data-types:cml_host_string_t
|       | +--rw ipv4-address? inet:ipv4-address
|       | +--rw ipv6-address? inet:ipv6-address {feature-list:HAVE_IPV6}?
|       +--ro state
|         +--ro hostname?    cml-data-types:cml_host_string_t
|         +--ro ipv4-address? inet:ipv4-address
|         +--ro ipv6-address? inet:ipv6-address {feature-list:HAVE_IPV6}?
+--rw debug
  +--rw config
  | +--rw enable?    empty
  +--ro state
    +--ro enable?    empty
    +--ro terminal-debug-status? cml-data-types:cml_on_off_t

```

rpcs:

```

+---x dns-client-terminal-debug-on {feature-list:HAVE_DNS_CLIENT}?
+---x dns-client-terminal-debug-off {feature-list:HAVE_DNS_CLIENT}?

```

module: ipi-dns-relay

```

+--rw dns-relay
  +--rw config
  | +--rw enable-dns-feature?    empty
  | +--rw enable-dnsv4-relay?    empty
  | +--rw enable-dnsv6-relay?    empty {feature-list:HAVE_IPV6}?
  | +--rw dns-server-v4-addr*    inet:ipv4-address
  | +--rw dns-server-v6-addr*    inet:ipv6-address {feature-list:HAVE_IPV6}?
  +--ro state
  | +--ro enable-dns-feature?    empty
  | +--ro enable-dnsv4-relay?    empty
  | +--ro enable-dnsv6-relay?    empty {feature-list:HAVE_IPV6}?
  | +--ro dns-server-v4-addr*    inet:ipv4-address
  | +--ro dns-server-v6-addr*    inet:ipv6-address {feature-list:HAVE_IPV6}?
  +--rw interfaces
  | +--rw interface* [name]
  |   +--rw name    -> ../config/name
  |   +--rw config
  |     | +--rw name?    -> /ipi-interface:interfaces/interface/name

```

```

|     | +--rw enable-dnsv4-relay?    empty
|     | +--rw enable-dnsv6-relay?    empty {feature-list:HAVE_IPV6}?
|     | +--rw dns-relay-uplink?      empty
|     | +--rw dns-relay-v6-uplink?   empty {feature-list:HAVE_IPV6}?
|     +--ro state
|         +--ro name?                -> /ipi-interface:interfaces/interface/name
|         +--ro enable-dnsv4-relay?  empty
|         +--ro enable-dnsv6-relay?  empty {feature-list:HAVE_IPV6}?
|         +--ro dns-relay-uplink?    empty
|         +--ro dns-relay-v6-uplink?  empty {feature-list:HAVE_IPV6}?
+--rw vrfs {feature-list:HAVE_VRF}?
    +--rw vrf* [vrf-name]
        +--rw vrf-name    -> ../config/vrf-name
        +--rw config
            | +--rw vrf-name?    -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
            | +--rw dns-server-v4-addr*  inet:ipv4-address
            | +--rw dns-server-v6-addr*  inet:ipv6-address {feature-list:HAVE_IPV6}?
            +--ro state
                +--ro vrf-name?    -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
                +--ro dns-server-v4-addr*  inet:ipv4-address
                +--ro dns-server-v6-addr*  inet:ipv6-address {feature-list:HAVE_IPV6}?

```

module: ipi-elk

```

+--rw elk
    +--rw metricbeats
        | +--rw metricbeat* [ip]
        |     +--rw ip    -> ../config/ip
        |     +--rw config
        |         | +--rw ip?          inet:ipv4-address
        |         | +--rw username    string
        |         | +--rw password    string
        |         +--ro state
        |             +--ro ip?        inet:ipv4-address
        |             +--ro username    string
        |             +--ro password    string
    +--rw filebeats
        +--rw filebeat* [ip]
            +--rw ip    -> ../config/ip
            +--rw config
                | +--rw ip?          inet:ipv4-address
                | +--rw certificate-path?  string
            +--ro state
                +--ro ip?          inet:ipv4-address
                +--ro certificate-path?  string

```

```

rpcs:
  +---x elk-metricbeat-service-enable {feature-list:HAVE_HOSTPD}?
  | +---w input
  |   +---w vrf-name    string
  +---x elk-filebeat-service-enable {feature-list:HAVE_HOSTPD}?
  | +---w input
  |   +---w vrf-name    string
  +---x elk-metricbeat-service-disable {feature-list:HAVE_HOSTPD}?
  | +---w input
  |   +---w vrf-name    string
  +---x elk-filebeat-service-disable {feature-list:HAVE_HOSTPD}?
  | +---w input
  |   +---w vrf-name    string

```

module: ipi-enhanced-pbr

```

+--rw enhanced-pbr
  +--ro class-maps-default
  | +--ro class-map-default* [name]
  |   +--ro name      -> ../state/name
  |   +--ro state
  |     +--ro name?      string
  |     +--ro type?      ipi-enhanced-pbr-types:epbr_class_map_t
  |     +--ro match-criteria? ipi-enhanced-pbr-types:epbr_match_criteria_t
  +--rw class-maps
  | +--rw class-map* [name class-type]
  |   +--rw name      -> ../config/name
  |   +--rw class-type -> ../config/class-type
  |   +--rw config
  |     | +--rw name?      string
  |     | +--rw class-type? ipi-enhanced-pbr-types:epbr_class_map_t
  |     | +--rw match-criteria ipi-enhanced-pbr-types:epbr_match_criteria_t
  |     | +--rw reference-description? cml-data-types:cml_line_t
  |     +--ro state
  |       | +--ro name?      string
  |       | +--ro class-type? ipi-enhanced-pbr-types:epbr_class_map_t
  |       | +--ro match-criteria ipi-enhanced-pbr-types:epbr_match_criteria_t
  |       | +--ro reference-description? cml-data-types:cml_line_t
  |       +--rw match-filters
  |         +--rw config
  |           | +--rw protocol? cml-data-types:cml_range_t
  |           | +--rw port?     cml-data-types:cml_range_t
  |           | +--rw destination-port? cml-data-types:cml_range_t
  |           | +--rw source-port? cml-data-types:cml_range_t
  |           | +--rw packet-length? cml-data-types:cml_range_t
  |           | +--rw fragment-type? ipi-enhanced-pbr-types:epbr_fragment_type_t
  |           +--ro state

```

```

|         | +---ro protocol?          cml-data-types:cml_range_t
|         | +---ro port?              cml-data-types:cml_range_t
|         | +---ro destination-port?  cml-data-types:cml_range_t
|         | +---ro source-port?       cml-data-types:cml_range_t
|         | +---ro packet-length?     cml-data-types:cml_range_t
|         | +---ro fragment-type?     ipi-enhanced-pbr-types:epbr_fragment_type_t
| +---rw ipv4
|     | +---rw config
|     | | +---rw destination-prefix?  cml-data-types:cml_ipv4_addr_prefix_t
|     | | +---rw source-prefix?      cml-data-types:cml_ipv4_addr_prefix_t
|     | | +---ro state
|     | | | +---ro destination-prefix? cml-data-types:cml_ipv4_addr_prefix_t
|     | | | +---ro source-prefix?     cml-data-types:cml_ipv4_addr_prefix_t
|     | | +---rw icmp
|     | | | +---rw config
|     | | | | +---rw icmp-type?      cml-data-types:cml_range_t
|     | | | | +---rw icmp-code?     cml-data-types:cml_range_t
|     | | | | +---ro state
|     | | | | | +---ro icmp-type?    cml-data-types:cml_range_t
|     | | | | | +---ro icmp-code?   cml-data-types:cml_range_t
| +---rw tcp-flag
|     | +---rw config
|     | | +---rw value?              string
|     | | +---rw bit-mask?          string
|     | | +---ro state
|     | | | +---ro value?            string
|     | | | +---ro bit-mask?        string
| +---rw dscp
|     | +---rw config
|     | | +---rw match-dscp-value?   cml-data-types:cml_range_t
|     | | +---ro state
|     | | | +---ro match-dscp-value? cml-data-types:cml_range_t
+---rw policy-maps
    +---rw policy-map* [policy-map-name type]
        +---rw policy-map-name      -> ../config/policy-map-name
        +---rw type                  -> ../config/type
        +---rw config
            | +---rw policy-map-name?  string
            | +---rw type?             ipi-enhanced-pbr-types:epbr_policy_map_t
            | +---rw reference-description? cml-data-types:cml_line_t
        +---ro state
            | +---ro policy-map-name?  string
            | +---ro type?             ipi-enhanced-pbr-types:epbr_policy_map_t
            | +---ro reference-description? cml-data-types:cml_line_t
        +---rw classes
            +---rw class* [class-map-name class-type]
                +---rw class-map-name  -> ../config/class-map-name
                +---rw class-type      -> ../config/class-type
                +---rw config
                    | +---rw class-map-name?  string

```

```

| +--rw class-type?          ipi-enhanced-pbr-types:epbr_class_map_t
+--ro state
| +--ro class-map-name?     string
| +--ro class-type?        ipi-enhanced-pbr-types:epbr_class_map_t
+--rw policy-actions
  +--rw config
    | +--rw drop-traffic?    empty
    | +--rw dscp-set-value?  ipi-enhanced-pbr-types:epbr_hex_dscp_t
  +--ro state
    | +--ro drop-traffic?    empty
    | +--ro dscp-set-value?  ipi-enhanced-pbr-types:epbr_hex_dscp_t
  +--rw police
    | +--rw config
    | | +--rw rate?          uint64
    | | +--rw rate-unit?    ipi-enhanced-pbr-types:epbr_rate_unit_t
    | +--ro state
    |   +--ro rate?          uint64
    |   +--ro rate-unit?    ipi-enhanced-pbr-types:epbr_rate_unit_t
  +--rw redirect
    +--rw ipv4
      +--rw extcommunity
        +--rw config
          | +--rw route-target?  ipi-enhanced-pbr-types:epbr_vrf_rt_t
          +--ro state
            +--ro route-target?  ipi-enhanced-pbr-types:epbr_vrf_rt_t

```

module: ipi-erpsv2

```

+--rw erpsv2 {feature-list:HAVE_G8032V2}?
  +--rw rings
    | +--rw ring* [ring-name]
    |   +--rw ring-name    -> ../config/ring-name
    |   +--rw config
    |     | +--rw ring-name?      string
    |     | +--rw east-interface? -> /ipi-interface:interfaces/interface/name
    |     | +--rw west-interface? -> /ipi-interface:interfaces/interface/name
    |     | +--rw description?    cml-data-types:cml_line_t
    |     +--ro state
    |       +--ro ring-name?      string
    |       +--ro east-interface? -> /ipi-interface:interfaces/interface/name
    |       +--ro west-interface? -> /ipi-interface:interfaces/interface/name
    |       +--ro description?    cml-data-types:cml_line_t
  +--rw profiles
    | +--rw profile* [profile-name]
    |   +--rw profile-name    -> ../config/profile-name
    |   +--rw config
    |     | +--rw profile-name?   string

```

```

|   |   +---rw wait-to-restore-timer?   uint8
|   |   +---rw hold-off-timer?         uint16
|   |   +---rw guard-time?             uint16
|   |   +---rw protection-mode?        ipi-erpsv2-types:erpsv2_protection_mode_t
|   +---ro state
|       +---ro profile-name?           string
|       +---ro wait-to-restore-timer?  uint8
|       +---ro hold-off-timer?         uint16
|       +---ro guard-time?             uint16
|       +---ro protection-mode?        ipi-erpsv2-types:erpsv2_protection_mode_t
|       +---ro wait-to-block-time?     uint32
+---rw erp-instances
|   +---rw erp-instance* [name]
|       +---rw name                    -> ../config/name
|       +---rw config
|           |   +---rw name?           string
|           |   +---rw ring-name?     -> /erpsv2/rings/ring/ring-name
|           |   +---rw mapped-profile-name? -> /erpsv2/profiles/profile/profile-name
|           |   +---rw ring-type?     ipi-erpsv2-types:erpsv2_ring_type_t
|           |   +---rw enable-tcn-propagation? empty
|           |   +---rw tcn-to-instances* string
|           |   +---rw non-virtual-channel? empty
|           |   +---rw ring-id?       uint8
|           |   +---rw description?   cml-data-types:cml_line_t
|       +---ro state
|           |   +---ro name?           string
|           |   +---ro ring-name?     -> /erpsv2/rings/ring/ring-name
|           |   +---ro mapped-profile-name? -> /erpsv2/profiles/profile/profile-name
|           |   +---ro ring-type?     ipi-erpsv2-types:erpsv2_ring_type_t
|           |   +---ro enable-tcn-propagation? empty
|           |   +---ro tcn-to-instances* string
|           |   +---ro non-virtual-channel? empty
|           |   +---ro ring-id?       uint8
|           |   +---ro description?   cml-data-types:cml_line_t
|           |   +---ro current-state?  ipi-erpsv2-types:erpsv2_ring_state_t
|           |   +---ro previous-state? ipi-erpsv2-types:erpsv2_ring_state_t
|       +---rw associate-rings
|           |   +---rw associate-ring* [associate-ring-name]
|           |       +---rw associate-ring-name -> ../config/associate-ring-name
|           |       +---rw config
|           |           |   +---rw associate-ring-name? string
|           |           +---ro state
|           |               +---ro associate-ring-name? string
|       +---rw instance-role
|           |   +---rw config
|           |       |   +---rw (role-option)?
|           |       |       +---: (owner)
|           |       |           |   +---rw owner-port-id?         ipi-erpsv2-types:erpsv2_port_id_t
|           |       |           |   +---: (neighbor)
|           |       |           |   +---rw neighbor-port-id?     ipi-erpsv2-types:erpsv2_port_id_t

```

```

|   |   |   +---:(next-neighbor)
|   |   |   |   +---rw next-neighbor-port-id?   ipi-erpsv2-types:erpsv2_port_id_t
|   |   |   +---:(non-owner)
|   |   |       +---rw non-owner?               empty
|   |   +---ro state
|   |       +---ro (role-option)?
|   |           +---:(owner)
|   |               |   +---ro owner-port-id?   ipi-erpsv2-types:erpsv2_port_id_t
|   |               +---:(neighbor)
|   |                   |   +---ro neighbor-port-id?   ipi-erpsv2-types:erpsv2_port_id_t
|   |                   +---:(next-neighbor)
|   |                       |   +---ro next-neighbor-port-id?   ipi-erpsv2-types:erpsv2_port_id_t
|   |                       +---:(non-owner)
|   |                           +---ro non-owner?   empty
|   +---rw aps-channel
|   |   +---rw config
|   |       |   +---rw level?   uint8
|   |       +---ro state
|   |           +---ro level?   uint8
|   +---rw aps-channel-vlans
|   |   +---rw aps-channel-vlan* [vlan-id]
|   |       +---rw vlan-id   -> ../config/vlan-id
|   |       +---rw config
|   |           |   +---rw vlan-id?   uint16
|   |           |   +---rw inner-vlan-id?   uint16
|   |           +---ro state
|   |               +---ro vlan-id?   uint16
|   |               +---ro inner-vlan-id?   uint16
|   +---rw data
|   |   +---rw config
|   |       |   +---rw data-vlan?   cml-data-types:cml_range_t
|   |       +---ro state
|   |           +---ro data-vlan?   cml-data-types:cml_range_t
|   +---rw virtual-channel
|   |   +---rw config!
|   |       |   +---rw channel-id   uint16
|   |       |   +---rw attached-instance   -> /erpsv2/erp-instances/erp-instance/name
|   |       +---ro state
|   |           +---ro channel-id   uint16
|   |           +---ro attached-instance   -> /erpsv2/erp-instances/erp-instance/name
|   +---rw east-link
|   |   +---ro state
|   |       +---ro link-name?   string
|   |       +---ro link-state?   ipi-erpsv2-
types:erpsv2_link_state_t
|   |       +---ro remote-node-id?   cml-data-types:cml_mac_addr_t
|   |       +---ro remote-blocked-port-reference?   uint8
|   +---rw west-link
|   |   +---ro state
|   |       +---ro link-name?   string

```



```

|      |      +---ro link-state?                               ipi-erpsv2-
types:erpsv2_link_state_t
|      |      +---ro remote-node-id?                          cml-data-types:cml_mac_addr_t
|      |      +---ro remote-blocked-port-reference?          uint8
|      +---rw aps-statistics
|          +---ro state
|              +---ro tx-ring-aps-messages?   yang:counter32
|              +---ro rx-ring-aps-messages?   yang:counter32
+---rw debug
| +---rw config
| | +---rw options?   ipi-erpsv2-types:erpsv2_debug_t
| +---ro state
|     +---ro options?   ipi-erpsv2-types:erpsv2_debug_t
|     +---ro terminal-debug-status?   ipi-erpsv2-types:erpsv2_debug_t
+---rw subinterfaces
    +---rw subinterface* [name] {feature-list:HAVE_SUBINTERFACE,feature-
list:HAVE_G8032V2}?
        +---rw name      -> ../config/name
        +---rw config
            | +---rw name?          -> /ipi-interface:interfaces/interface/name
            | +---rw instance-name? ipi-erpsv2-
types:erpsv2_subinterface_instance_type_t
            +---ro state
                +---ro name?          -> /ipi-interface:interfaces/interface/name
                +---ro instance-name? ipi-erpsv2-
types:erpsv2_subinterface_instance_type_t

rpcs:
+---x erpsv2-switch-erp-instance {feature-list:HAVE_G8032V2,feature-
list:HAVE_ONMD}?
| +---w input
|     +---w instance-name   string
|     +---w operation       ipi-erpsv2-types:erpsv2_switch_operation_t
|     +---w port-id         ipi-erpsv2-types:erpsv2_port_id_t
+---x erpsv2-clear-ring-erp-instance {feature-list:HAVE_G8032V2,feature-
list:HAVE_ONMD}?
| +---w input
|     +---w instance-name   string
+---x erpsv2-clear-aps-statistics {feature-list:HAVE_G8032V2,feature-
list:HAVE_ONMD}?
| +---w input
|     +---w instance-name   string
+---x erpsv2-terminal-debug-on {feature-list:HAVE_G8032V2}?
| +---w input
|     +---w terminal-debug-options   ipi-erpsv2-types:erpsv2_debug_t
+---x erpsv2-terminal-debug-off {feature-list:HAVE_G8032V2}?
    +---w input
        +---w terminal-debug-options   ipi-erpsv2-types:erpsv2_debug_t

notifications:
+---n erpsv2-instance-state-change-notification {feature-list:HAVE_G8032V2}?
    +---ro severity?   cml-data-types:cml_notif_severity_t

```

```

+--ro eventClass?      cml-data-types:cml_notif_class_t
+--ro name?            string
+--ro current-state?   ipi-erpsv2-types:erpsv2_ring_state_t
+--ro previous-state? ipi-erpsv2-types:erpsv2_ring_state_t

```

module: ipi-ethernet-vpn

```

+--rw evpn
  +--rw multi-homing
    | +--rw config
    | | +--rw esi-hold-time?  uint32 {feature-list:HAVE_BGP_EVPN}?
    | | +--ro state
    | | +--ro esi-hold-time?  uint32 {feature-list:HAVE_BGP_EVPN}?
  +--rw global
    | +--rw config
    | | +--rw enable-vxlan-multihoming?      empty {feature-
list:HAVE_TUNNEL,feature-list:HAVE_NVO}?
    | | +--rw enable-evpn-mpls-multihoming?  empty {feature-list:HAVE_MPLS,feature-
list:HAVE_BGP_EVPN,feature-list:HAVE_NVO}?
    | | +--rw enable-evpn-srv6-multihoming?  empty {feature-list:HAVE_SRV6,feature-
list:HAVE_BGP_EVPN}?
    | | +--rw enable-irb?                    empty {feature-list:HAVE_TUNNEL,feature-
list:HAVE_NVO}?
    | | +--rw enable-mpls-irb?               empty {feature-list:HAVE_TUNNEL,feature-
list:HAVE_MPLS,feature-list:HAVE_BGP_EVPN,feature-list:HAVE_NVO}?
    | | +--ro state
    | | +--ro enable-vxlan-multihoming?      empty {feature-
list:HAVE_TUNNEL,feature-list:HAVE_NVO}?
    | | +--ro enable-evpn-mpls-multihoming?  empty {feature-list:HAVE_MPLS,feature-
list:HAVE_BGP_EVPN,feature-list:HAVE_NVO}?
    | | +--ro enable-evpn-srv6-multihoming?  empty {feature-list:HAVE_SRV6,feature-
list:HAVE_BGP_EVPN}?
    | | +--ro enable-irb?                    empty {feature-list:HAVE_TUNNEL,feature-
list:HAVE_NVO}?
    | | +--ro enable-mpls-irb?               empty {feature-list:HAVE_TUNNEL,feature-
list:HAVE_MPLS,feature-list:HAVE_BGP_EVPN,feature-list:HAVE_NVO}?
    +--rw irb-forwarding
      | +--rw config
      | | +--rw mac-address?  cml-data-types:cml_mac_addr_t {feature-
list:HAVE_TUNNEL,feature-list:HAVE_NVO,feature-list:HAVE_BGP_EVPN}?
      | | +--ro state
      | | +--ro mac-address?  cml-data-types:cml_mac_addr_t {feature-
list:HAVE_TUNNEL,feature-list:HAVE_NVO,feature-list:HAVE_BGP_EVPN}?
      | +--rw irb-interfaces
      | | +--rw irb-interface* [name]
      | | | +--rw name          -> ../config/name
      | | | +--rw config
      | | | | +--rw name?      -> /ipi-interface:interfaces/interface/name
{feature-list:HAVE_TUNNEL,feature-list:HAVE_NVO,feature-list:HAVE_BGP_EVPN}?
      | | | | +--rw gateway-mac?  empty {feature-list:HAVE_TUNNEL,feature-
list:HAVE_NVO,feature-list:HAVE_VXLAN,feature-list:HAVE_BGP_EVPN}?

```

```

|         +---ro state
|         +---ro name?           -> /ipi-interface:interfaces/interface/name
{feature-list:HAVE_TUNNEL,feature-list:HAVE_NVO,feature-list:HAVE_BGP_EVPN}?
|         +---ro gateway-mac?   empty {feature-list:HAVE_TUNNEL,feature-
list:HAVE_NVO,feature-list:HAVE_VXLAN,feature-list:HAVE_BGP_EVPN}?
+---rw interfaces
| +---rw interface* [name]
|   +---rw name                 -> ../config/name
|   +---rw config
|     | +---rw name?           -> /ipi-interface:interfaces/interface/name
|     | +---rw evpn-segment-id? string
|     | +---rw system-mac?     cml-data-types:cml_mac_addr_t
|     | +---rw redundancy-mode? ipi-ethernet-vpn-
types:evpn_esi_load_balance_mode_t
|     +---ro state
|       | +---ro name?         -> /ipi-interface:interfaces/interface/name
|       | +---ro evpn-segment-id? string
|       | +---ro system-mac?   cml-data-types:cml_mac_addr_t
|       | +---ro redundancy-mode? ipi-ethernet-vpn-
types:evpn_esi_load_balance_mode_t
|       +---rw mh-load-balance-esi
|         | +---rw config!
|         | | +---rw service-carving   ipi-ethernet-vpn-
types:evpn_esi_svc_carving_df_election_t
|         | | +---rw preference-weight? uint16
|         | | +---rw no-preempt?      empty
|         | | +---rw ac-driven?       empty
|         | +---ro state
|         | +---ro service-carving   ipi-ethernet-vpn-
types:evpn_esi_svc_carving_df_election_t
|         | +---ro preference-weight? uint16
|         | +---ro no-preempt?      empty
|         | +---ro ac-driven?       empty
|         +---rw access-interfaces
|           +---rw access-interface* [access-if] {feature-
list:HAVE_SUBINTERFACE,feature-list:HAVE_NVO}?
|             +---rw access-if       -> ../config/access-if
|             +---rw config
|               | +---rw access-if?   ipi-ethernet-vpn-types:evpn_acc_if_t
|               | +---rw evpn-identifier? uint32 {feature-
list:HAVE_BGP_EVPN,feature-list:HAVE_NVO,feature-
list:HAVE_MPLS_OR_HAVE_VXLAN_OR_HAVE_SRV6}?
|               | +---rw dynamic-learning-disable? empty
|               | +---rw arp-nd-flood-suppress?   empty
|               | +---rw arp-cache-disable?      empty
|               | +---rw nd-cache-disable?       empty
|               | +---rw mac-hold-time?          int16
|               | +---rw mac-address*           cml-data-types:cml_mac_addr_t
|               | +---rw garp-gna-enable?       empty {feature-list:HAVE_BGP_EVPN}?
|               +---ro state
|               | +---ro access-if?           ipi-ethernet-vpn-types:evpn_acc_if_t

```

```

| | | +---ro evpn-identifier?          uint32 {feature-
list:HAVE_BGP_EVPN,feature-list:HAVE_NVO,feature-
list:HAVE_MPLS_OR_HAVE_VXLAN_OR_HAVE_SRV6}?
| | | +---ro dynamic-learning-disable?  empty
| | | +---ro arp-nd-flood-suppress?     empty
| | | +---ro arp-cache-disable?        empty
| | | +---ro nd-cache-disable?         empty
| | | +---ro mac-hold-time?            int16
| | | +---ro mac-address*              cml-data-types:cml_mac_addr_t
| | | +---ro garp-gna-enable?          empty {feature-list:HAVE_BGP_EVPN}?
| | +---rw ipv4-host-mac-mappings
| | | +---rw ipv4-host-mac-mapping* [mac-address ipv4-address] {feature-
list:HAVE_SUBINTERFACE,feature-list:HAVE_NVO}?
| | | +---rw mac-address      -> ../config/mac-address
| | | +---rw ipv4-address     -> ../config/ipv4-address
| | | +---rw config
| | | | +---rw mac-address?   cml-data-types:cml_mac_addr_t
| | | | +---rw ipv4-address?  inet:ipv4-address
| | | +---ro state
| | | | +---ro mac-address?   cml-data-types:cml_mac_addr_t
| | | | +---ro ipv4-address?  inet:ipv4-address
| | +---rw ipv6-host-mac-mappings
| | | +---rw ipv6-host-mac-mapping* [mac-address ipv6-address] {feature-
list:HAVE_SUBINTERFACE,feature-list:HAVE_NVO,feature-list:HAVE_IPV6}?
| | | +---rw mac-address      -> ../config/mac-address
| | | +---rw ipv6-address     -> ../config/ipv6-address
| | | +---rw config
| | | | +---rw mac-address?   cml-data-types:cml_mac_addr_t
| | | | +---rw ipv6-address?  inet:ipv6-address
| | | +---ro state
| | | | +---ro mac-address?   cml-data-types:cml_mac_addr_t
| | | | +---ro ipv6-address?  inet:ipv6-address
+---rw vrfs
    +---rw vrf* [vrf-name]
        +---rw vrf-name      -> ../config/vrf-name
        +---rw config
            | +---rw vrf-name?      -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name
            | +---rw service-type?  cml-data-types:cml_evpn_service_type_t
            +---ro state
                +---ro vrf-name?      -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name
                +---ro service-type?  cml-data-types:cml_evpn_service_type_t

```

module: ipi-evpn-mpls

```

+---rw evpn-mpls
    +---rw global
        | +---rw config!

```

```

| | +--rw enable-evpn-mpls      empty
| | +--rw vtep-ipv4?           inet:ipv4-address
| | +--rw mac-ageing-timer?    uint32
| +--ro state
| | +--ro enable-evpn-mpls     empty
| | +--ro vtep-ipv4?           inet:ipv4-address
| | +--ro mac-ageing-timer?    uint32
| +--ro route-count
|   +--ro state
|     +--ro max_route?         uint32
|     +--ro active_route?     uint32
+--rw arp-nd-global
| +--rw config
| | +--rw arp-nd-refresh-time?  uint32
| +--ro state
|   +--ro arp-nd-refresh-time?  uint32
+--rw mpls-tenants
| +--rw mpls-tenant* [tenant-identifier]
|   +--rw tenant-identifier     -> ../config/tenant-identifier
|   +--rw config
|     | +--rw vrf-name?         -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
|     | +--rw mac-holdtime?     int32
|     | +--rw tenant-description? string
|     | +--rw tunnel-policy-name? string {feature-list:HAVE_SERVICE_MAPPING}?
|     | +--rw irb-name?        -> /ipi-interface:interfaces/interface/name
|     | +--rw tenant-identifier? uint32
|     | +--rw vpws-identifier?  uint32 {feature-list:HAVE_EVPN_VPWS}?
|     | +--rw control-word?     empty
|     +--ro state
|       | +--ro vrf-name?       -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
|       | +--ro mac-holdtime?    int32
|       | +--ro tenant-description? string
|       | +--ro tunnel-policy-name? string {feature-list:HAVE_SERVICE_MAPPING}?
|       | +--ro irb-name?       -> /ipi-interface:interfaces/interface/name
|       | +--ro tenant-identifier? uint32
|       | +--ro vpws-identifier? uint32 {feature-list:HAVE_EVPN_VPWS}?
|       | +--ro control-word?    empty
|       +--ro route-count-info
|         | +--ro state
|         |   +--ro total?       uint32
|         |   +--ro mac-only?    uint32
|         |   +--ro mac-ipv4?    uint32
|         |   +--ro mac-ipv6?    uint32 {feature-list:HAVE_IPV6}?
|         +--ro xconnect-mapping-info {feature-list:HAVE_EVPN_VPWS}?
|           | +--ro state
|           |   +--ro source-tenant-description? string
|           |   +--ro destination-vpws-identifier? uint32
|           |   +--ro source-interface? string
|           |   +--ro destination-interface? string

```

```

|      |      +---ro vtep-ip-address?          inet:ipv4-address
|      |      +---ro connection-type?         ipi-evpn-mpls-
types:evpn_mpls_xconnect_connection_type_t
|      |      +---ro connection-status?       ipi-evpn-mpls-
types:evpn_mpls_xconnect_connection_status_t
|      +---rw irb
|      |      +---rw config
|      |      |      +---rw irb-advertise-host-route?  empty
|      |      |      +---ro state
|      |      |      +---ro irb-advertise-host-route?  empty
|      +---ro arp-cache-info* [host-ip]
|      |      +---ro host-ip    -> ../state/host-ip
|      |      +---ro state
|      |      +---ro host-ip?    inet:ipv4-address
|      |      +---ro host-mac?   cml-data-types:cml_mac_addr_t
|      |      +---ro host-type?  ipi-evpn-mpls-types:evpn_mpls_host_t
|      +---ro nd-cache-info* [host-ip]
|      |      +---ro host-ip    -> ../state/host-ip
|      |      +---ro state
|      |      +---ro host-ip?    inet:ipv6-address
|      |      +---ro host-mac?   cml-data-types:cml_mac_addr_t
|      |      +---ro host-type?  ipi-evpn-mpls-types:evpn_mpls_host_t
|      +---ro mac-table-info* [mac-address]
|      |      +---ro mac-address  -> ../state/mac-address
|      |      +---ro state
|      |      +---ro mac-address?  cml-data-types:cml_mac_addr_t
|      |      +---ro interface-name? -> /ipi-interface:interfaces/interface/
name
|      |      +---ro vtep-ip-esi?          string
|      |      +---ro host-type?           ipi-evpn-mpls-types:evpn_mpls_host_t
|      |      +---ro host-status?         ipi-evpn-mpls-
types:evpn_mpls_host_status_t
|      |      +---ro access-port-description?  string
|      +---ro access-interface-info* [access-interface-name]
|      |      +---ro access-interface-name  -> ../state/access-interface-name
|      |      +---ro state
|      |      +---ro access-interface-name?  string
|      |      +---ro tenant-description?    string
|      |      +---ro ethernet-segment-id?   string
|      |      +---ro port-status?          string
+---ro tunnel* [destination-vtep-ip destination-evpn-identifier]
+---ro destination-vtep-ip    -> ../state/destination-vtep-ip
+---ro destination-evpn-identifier  -> ../state/destination-evpn-identifier
+---ro state
+---ro destination-vtep-ip?      inet:ipv4-address
+---ro destination-evpn-identifier?  uint32
+---ro source-vtep-ip?          inet:ipv4-address
+---ro up-down-time?           yang:timeticks
+---ro tunnel-status?          ipi-evpn-mpls-
types:evpn_mpls_tunnel_status_t
+---ro source-vpws-identifier?   uint32

```

```

    +---ro destination-vpws-identifier?   uint32
    +---ro local-multicast-label?        uint32
    +---ro local-unicast-label?          uint32
    +---ro remote-multicast-label?       uint32
    +---ro remote-unicast-label?         uint32
    +---ro is_xconnect?                  boolean
    +---ro mpls-multipath-grp-name?      string
    +---ro mpls-multipath-nhlfe-ix?     uint32
    +---ro tunnel-label?                 uint32
    +---ro network-interface?            -> /ipi-interface:interfaces/interface/
name
    +---ro counters
        +---ro out-bum-packets?          yang:counter64
        +---ro out-unicast-packets?     yang:counter64
        +---ro in-bum-packets?           yang:counter64
        +---ro in-unicast-packets?      yang:counter64

rpcs:
    +---x clear-nvo-mpls-dynamic-mac-address-table {feature-list:HAVE_MPLS,feature-
list:HAVE_SUBINTERFACE}?
    +---x clear-nvo-mpls-dynamic-mac-address-table-evid {feature-
list:HAVE_MPLS,feature-list:HAVE_SUBINTERFACE}?
    | +---w input
    |   +---w tenant-identifier          uint32
    |   +---w mac-address?              cml-data-types:cml_mac_addr_t
    +---x clear-evpn-mpls-egress-counters {feature-list:HAVE_MPLS,feature-
list:HAVE_SUBINTERFACE}?
    | +---w input
    |   +---w tenant-identifier?        uint32
    |   +---w egress-direction          ipi-evpn-mpls-types:evpn_mpls_egress_dir_t
    |   +---w destination-ip?          inet:ipv4-address
    +---x clear-evpn-mpls-ingress-counters {feature-list:HAVE_MPLS,feature-
list:HAVE_SUBINTERFACE}?
    | +---w input
    |   +---w tenant-identifier?        uint32
    |   +---w ingress-direction        ipi-evpn-mpls-types:evpn_mpls_ingress_dir_t

```

module: ipi-evpn-srv6

```

+---rw evpn-srv6
  +---rw global
  | +---rw config!
  | | +---rw enabled                    empty
  | | +---rw vtep-ipv6-address?        inet:ipv6-address
  | +---ro state
  |   +---ro enabled                    empty
  |   +---ro vtep-ipv6-address?        inet:ipv6-address
+---rw tenants
  +---rw tenant* [tenant-identifier]

```

```

    +--rw tenant-identifier    -> ../config/tenant-identifier
    +--rw config
      | +--rw vrf-name?        -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
      | +--rw tenant-description?  string
      | +--rw tunnel-policy-name?  string {feature-
list:HAVE_SERVICE_MAPPING_OR_HAVE_SRV6}?
      | +--rw srv6-locator-name?   string
      | +--rw tenant-identifier?   uint32
      | +--rw vpws-identifier?     uint32 {feature-list:HAVE_EVPN_VPWS}?
    +--ro state
      +--ro vrf-name?            -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
      +--ro tenant-description?  string
      +--ro tunnel-policy-name?  string {feature-
list:HAVE_SERVICE_MAPPING_OR_HAVE_SRV6}?
      +--ro srv6-locator-name?   string
      +--ro tenant-identifier?   uint32
      +--ro vpws-identifier?     uint32 {feature-list:HAVE_EVPN_VPWS}?

```

module: ipi-g8031

```

+--rw g8031
  +--rw instances
    | +--rw instance* [eps-id] {feature-list:HAVE_G8031}?
    |   +--rw eps-id    -> ../config/eps-id
    |   +--rw config
    |     | +--rw eps-id?          uint8
    |     | +--rw bridge-id       -> /ipi-network-instance:network-instances/
network-instance/instance-name
    |     | +--rw working-port?   -> /ipi-interface:interfaces/interface/name
    |     | +--rw protection-port? -> /ipi-interface:interfaces/interface/name
    |     | +--rw elps-instance-id? uint8
    |     | +--rw data-vlans?     cml-data-types:cml_range_t
    |     | +--rw primary-vlan?   -> /ipi-network-instance:network-instances/
network-instance/ipi-bridge:bridge/ipi-vlan:vlans/vlan/vlan-id
    |     +--ro state
    |       | +--ro eps-id?       uint8
    |       | +--ro bridge-id     -> /ipi-network-instance:network-instances/
network-instance/instance-name
    |       | +--ro working-port? -> /ipi-interface:interfaces/interface/name
    |       | +--ro protection-port? -> /ipi-interface:interfaces/interface/name
    |       | +--ro elps-instance-id? uint8
    |       | +--ro data-vlans?   cml-data-types:cml_range_t
    |       | +--ro primary-vlan? -> /ipi-network-instance:network-instances/
network-instance/ipi-bridge:bridge/ipi-vlan:vlans/vlan/vlan-id
    |       +--rw elps
    |       +--rw config

```



```

| | +---rw protection-type?      ipi-g8031-elps-
types:g8031_elps_protection_type_t
| | +---rw enable-revertive-mode?  empty
| | +---rw level-identifier?      uint8
| | +---ro state
| | +---ro protection-type?      ipi-g8031-elps-
types:g8031_elps_protection_type_t
| | +---ro enable-revertive-mode?  empty
| | +---ro level-identifier?      uint8
| | +---ro direction?            ipi-g8031-elps-
types:g8031_direction_type_t
| | +---ro active-path?           ipi-g8031-elps-
types:g8031_active_path_type_t
| | +---ro request-signal?        ipi-g8031-elps-
types:g8031_request_signal_type_t
| | +---ro current-state?         ipi-g8031-elps-
types:g8031_current_state_type_t
| | +---ro failure-of-protocol-state? ipi-g8031-elps-
types:g8031_failure_of_protocol_state_type_t
| | +---ro rx-lps-frame-count?    yang:counter32
| | +---ro tx-lps-frame-count?    yang:counter32
| | +---rw timers
| | | +---rw config
| | | | +---rw wait-to-restore?   uint16
| | | | +---rw hold-off?         uint8
| | | | +---ro state
| | | | | +---ro wait-to-restore?  uint16
| | | | | +---ro hold-off?        uint8
| | | +---rw traffic-switch
| | | | +---rw config
| | | | | +---rw local-freeze?    empty
| | | | +---ro state
| | | | | +---ro local-freeze?    empty
+---rw debug
  +---rw config
  | +---rw options?      ipi-g8031-elps-types:g8031_debug_t
  +---ro state
    +---ro options?      ipi-g8031-elps-types:g8031_debug_t
    +---ro terminal-debug-status? ipi-g8031-elps-types:g8031_debug_t

rpcs:
+---x g8031-lockout {feature-list:HAVE_G8031,feature-list:HAVE_ONMD}?
| +---w input
| | +---w bridge-id   string
| | +---w eps-id     uint8
+---x g8031-force-switch {feature-list:HAVE_G8031,feature-list:HAVE_ONMD}?
| +---w input
| | +---w bridge-id   string
| | +---w eps-id     uint8
+---x g8031-manual-switch {feature-list:HAVE_G8031,feature-list:HAVE_ONMD}?
| +---w input
| | +---w bridge-id   string

```

```
|      +---w eps-id      uint8
+---x g8031-exercise {feature-list:HAVE_G8031,feature-list:HAVE_ONMD}?
|  +---w input
|      +---w bridge-id  string
|      +---w eps-id     uint8
+---x g8031-clear {feature-list:HAVE_G8031,feature-list:HAVE_ONMD}?
|  +---w input
|      +---w bridge-id  string
|      +---w eps-id     uint8
+---x g8031-terminal-debug-on {feature-list:HAVE_G8031,feature-list:HAVE_ONMD}?
|  +---w input
|      +---w terminal-debug-options      ipi-g8031-elps-types:g8031_debug_t
+---x g8031-terminal-debug-off {feature-list:HAVE_G8031,feature-list:HAVE_ONMD}?
  +---w input
    +---w terminal-debug-options      ipi-g8031-elps-types:g8031_debug_t
```

module: ipi-global-te

```
+--rw admin-groups
  +--rw admin-group* [name id]
    +--rw name      -> ../config/name
    +--rw id        -> ../config/id
    +--rw config
      | +--rw name?  string
      | +--rw id?   uint8
    +--ro state
      +--ro name?  string
      +--ro id?   uint8
```

module: ipi-host

```
+--rw system-host {feature-list:HAVE_IMI}?
  +--rw config
    | +--rw banner-motd?          cml-data-types:cml_banner_t
    | +--rw service-passwd-encryption?  boolean
    | +--rw service-term-length?      uint16
    | +--rw system-enable-passwd?     cml-data-types:cml_line_t
    | +--rw passwd-encrypted?        empty
    | +--rw disable-service-advanced-vty?  empty
  +--ro state
    +--ro banner-motd?          cml-data-types:cml_banner_t
    +--ro service-passwd-encryption?  boolean
    +--ro service-term-length?      uint16
    +--ro system-enable-passwd?     cml-data-types:cml_line_t
    +--ro passwd-encrypted?        empty
    +--ro disable-service-advanced-vty?  empty
```

module: ipi-hwtable

```

notifications:
+---n hwtable-monitor-full-notification
| +--ro severity?      cml-data-types:cml_notif_severity_t
| +--ro eventClass?   cml-data-types:cml_notif_class_t
| +--ro message?      string
+---n hwtable-monitor-full-clear-notification
  +--ro severity?     cml-data-types:cml_notif_severity_t
  +--ro eventClass?   cml-data-types:cml_notif_class_t
  +--ro message?      string

```

module: ipi-if-aggregate

```

augment /ipi-interface:interfaces/ipi-interface:interface:
+--rw member-aggregation
  +--rw config!
  | +--rw agg-type      ipi-lag-types:lag_link_agg_type_t
  | +--rw aggregate-id  uint16
  | +--rw lacp-mode     ipi-lag-types:lacp_mode_t
  +--ro state
  | +--ro agg-type      ipi-lag-types:lag_link_agg_type_t
  | +--ro aggregate-id  uint16
  | +--ro lacp-mode     ipi-lag-types:lacp_mode_t
  +--rw port-channel-weight {feature-list:HAVE_DUNE}?
    +--rw config
    | +--rw weight?     uint16
    +--ro state
      +--ro weight?     uint16
augment /ipi-interface:interfaces/ipi-interface:interface:
+--rw aggregator
  +--rw config
  | +--rw min-links?    uint8 {feature-list:HAVE_LACP}?
  | +--rw min-bandwidth? string {feature-list:HAVE_LACP}?
  +--ro state
  | +--ro min-links?    uint8 {feature-list:HAVE_LACP}?
  | +--ro min-bandwidth? string {feature-list:HAVE_LACP}?
  | +--ro agg-min-links-state? ipi-lag-types:lag_agg_min_links_status
  +--ro members
    +--ro member* [link-name]
      +--ro link-name   -> ../state/link-name
      +--ro state
        +--ro link-name? string

```

```

    +--ro link-state?   ipi-lag-types:lag_member_link_status_t

```

```

notifications:

```

```

  +---n agg-min-links-state-update
    +--ro severity?      cml-data-types:cml_notif_severity_t
    +--ro eventClass?   cml-data-types:cml_notif_class_t
    +--ro name?         string
    +--ro agg-min-links-state? ipi-lag-types:lag_agg_min_links_status

```

module: ipi-if-ethernet

```

augment /ipi-interface:interfaces/ipi-interface:interface:

```

```

  +--rw ethernet
    +--rw config
      | +--rw duplex-mode?      ipi-if-types:if_duplex_t
      | +--rw secondary-mac-address? empty {feature-list:HAVE_MLAG}?
      | +--rw port-speed?      ipi-if-types:if_interface_speed_t {feature-
list:NOT_HAVE_TIBIT}?
    +--ro state
      | +--ro duplex-mode?      ipi-if-types:if_duplex_t
      | +--ro secondary-mac-address? empty {feature-list:HAVE_MLAG}?
      | +--ro port-speed?      ipi-if-types:if_interface_speed_t {feature-
list:NOT_HAVE_TIBIT}?
      | +--ro hw-mac-address?   cml-data-types:cml_mac_addr_t
      | +--ro negotiated-duplex-mode? ipi-if-types:if_duplex_t
      | +--ro negotiated-port-speed? ipi-if-types:if_interface_speed_t
      | +--ro counters
      |   +--ro in-mac-control-frames? yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
      |   +--ro in-mac-pause-frames? yang:counter64
      |   +--ro in-undersize-frames? yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
      |   +--ro in-oversize-frames? yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
      |   +--ro in-fragment-frames? yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
      |   +--ro in-jabber-frames? yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
      |   +--ro in-crc-errors? yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
      |   +--ro out-mac-control-frames? yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
      |   +--ro out-mac-pause-frames? yang:counter64
      |   +--ro in-distribution
      |     | +--ro in-frames-64-octets? yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
      |     | +--ro in-frames-65-127-octets? yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
      |     | +--ro in-frames-128-255-octets? yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?

```

```

| | | +--ro in-frames-256-511-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro in-frames-512-1023-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro in-frames-1024-1518-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro in-frames-1519-2047-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro in-frames-2048-4095-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro in-frames-4096-9216-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro in-frames-9217-16383-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | +--ro out-distribution
| | | +--ro out-frames-64-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro out-frames-65-127-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro out-frames-128-255-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro out-frames-256-511-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro out-frames-512-1023-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro out-frames-1024-1518-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro out-frames-1519-2047-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro out-frames-2048-4095-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro out-frames-4096-9216-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
| | | +--ro out-frames-9217-16383-octets? yang:counter64 {feature-
list:HAVE_BROADCAST,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
+--rw flow-control {feature-list:HAVE_L2}?
+--rw config
| +--rw enable-rcv? ipi-if-types:if_flowctrl_t {feature-list:HAVE_L2}?
| +--rw enable-snd? ipi-if-types:if_flowctrl_t {feature-list:HAVE_L2}?
+--ro state
+--ro enable-rcv? ipi-if-types:if_flowctrl_t {feature-list:HAVE_L2}?
+--ro enable-snd? ipi-if-types:if_flowctrl_t {feature-list:HAVE_L2}?
+--ro rcv-oper-status? ipi-if-types:if_flowctrl_t
+--ro snd-oper-status? ipi-if-types:if_flowctrl_t

```

module: ipi-if-extended

```

augment /ipi-interface:interfaces/ipi-interface:interface:
+--rw extended
+--rw l2-control-protocol* [l2cp-type] {feature-list:HAVE_L2}?
| +--rw l2cp-type -> ../config/l2cp-type

```

```

| +--rw config
| | +--rw l2cp-type?          ipi-if-types:if_l2cp_t
| | +--rw protocol-process   ipi-if-types:if_l2cp_process_t
| +--ro state
|   +--ro l2cp-type?         ipi-if-types:if_l2cp_t
|   +--ro protocol-process   ipi-if-types:if_l2cp_process_t
+--rw config
| +--rw link-flap-error-disable?    empty {feature-list:HAVE_L2}?
| +--rw mac-move-limit-error-disable? empty {feature-list:HAVE_L2}?
| +--rw disable-snmp-trap-link-status? empty
| +--rw mau-default-type?          ipi-if-types:if_mautype_t {feature-
list:HAVE_L2}?
| +--rw debounce-time?            uint16
| +--rw protected-port?          ipi-if-types:if_protected_port_type_t
+--ro state
| +--ro link-flap-error-disable?    empty {feature-list:HAVE_L2}?
| +--ro mac-move-limit-error-disable? empty {feature-list:HAVE_L2}?
| +--ro disable-snmp-trap-link-status? empty
| +--ro mau-default-type?          ipi-if-types:if_mautype_t {feature-
list:HAVE_L2}?
| +--ro debounce-time?            uint16
| +--ro protected-port?          ipi-if-types:if_protected_port_type_t
| +--ro properties?              ipi-if-types:if_iface_prop_t
| +--ro mapped-name?              string
| +--ro if-counter-discontinuity-time? yang:timestamp
| +--ro slot-id?                  uint32
| +--ro hardware-type?            ipi-if-types:if_hw_type_t
| +--ro metric?                    int32
| +--ro if-type?                  ipi-if-types:if_interface_type_t
| +--ro trust-state?              ipi-if-types:if_trust_state_t {feature-
list:HAVE_QOS}?
| +--ro monitor-port-grp?          boolean {feature-list:HAVE_TFO}?
| +--ro failover-link-type?        ipi-if-types:if_tfo_link_type_t
{feature-list:HAVE_TFO}?
| +--ro udld-flush-transmitted?    uint16 {feature-list:HAVE_UDLD}?
| +--ro debounce-flap-count?       uint16
| +--ro debounce-last-flap-time?   yang:date-and-time
| +--ro debounce-remain-time?      yang:counter32
| +--ro debounce-running-status?   ipi-if-types:if_debounce_running_state
| +--ro debounce-config-status?    ipi-if-types:if_debounce_running_state
| +--ro last-flapped?              ipi-if-types:if_last_clear_time_t
| +--ro auto-ipv6-link-local-address? cml-data-types:cml_ipv6_prefix_t
{feature-list:HAVE_IPV6}?
+--rw bandwidth-management
| +--rw config
|   +--rw enable-re-routing?    empty
+--rw port-monitor
| +--rw config
| | +--rw enable-speed?          empty
| | +--rw enable-queue-drops?    empty
| +--ro state

```

```

| | +--ro enable-speed?          empty
| | +--ro enable-queue-drops?    empty
| +--rw port-monitor-threshold
|   +--rw config!
|     | +--rw warning-threshold    uint8
|     | +--rw recovery-threshold   uint8
|     +--ro state
|       +--ro warning-threshold    uint8
|       +--ro recovery-threshold   uint8
+--ro capabilities {feature-list:HAVE_HAL}?
| +--ro state
|   +--ro speed-half-duplex?      string
|   +--ro speed-full-duplex?      string
|   +--ro pause?                  ipi-if-types:if_raw_string_t
|   +--ro interface-type?         ipi-if-types:if_raw_string_t
|   +--ro medium?                 ipi-if-types:if_raw_string_t
|   +--ro loopback?               ipi-if-types:if_raw_string_t
|   +--ro flags?                  string
|   +--ro eee?                    string
|   +--ro fcmap?                  string
|   +--ro encapsulation?          ipi-if-types:if_raw_string_t
|   +--ro fec?                    ipi-if-types:if_raw_string_t
+--rw service-queue {feature-list:HAVE_SUBINTERFACE}?
| +--rw config
| | +--rw subif-service-queue?    ipi-if-types:if_subif_sevice_queue_t
| +--ro state
|   +--ro subif-service-queue?    ipi-if-types:if_subif_sevice_queue_t
+--rw aclif
| +--rw config
| | +--rw aclif-type?             ipi-if-types:if_aclif_type_t
| +--ro state
|   +--ro aclif-type?             ipi-if-types:if_aclif_type_t
+--rw subinterface-encapsulation {feature-list:HAVE_SUBINTERFACE}?
| +--rw config
| | +--rw encap-default?          empty
| | +--rw encap-untagged?        empty
| +--ro state
| | +--ro encap-default?          empty
| | +--ro encap-untagged?        empty
| +--rw rewrite
| | +--rw config!
| | | +--rw vlan-action           ipi-if-
types:if_subif_l2_vlan_actiontype_t
| | | +--rw (vlan-action-type)?
| | |   +--:(pop)
| | |   | +--rw enable-pop        ipi-if-
types:if_subif_rewrite_pop_type_t
| | |   +--:(push)
| | |   | +--rw push-tpid         ipi-if-types:cml_outer_tpid_type_t
| | |   | +--rw push-outer-vlan-id uint16
| | |   | +--rw push-inner-vlan-id? uint16

```

```

| | | +---:(translate)
| | | +---rw rewrite-translate-action ipi-if-
types:if_subif_l2_rewrite_actiontype_t
| | | +---rw dot1q-dotlad-tpid ipi-if-types:cml_outer_tpid_type_t
| | | +---rw outer-vlan-id uint16
| | | +---rw i-dot1q-dotlad-tpid ipi-if-
types:cml_inner_tpid_type_t
| | | +---rw inner-vlan-id uint16
| | +---ro state
| | +---ro vlan-action ipi-if-
types:if_subif_l2_vlan_actiontype_t
| | +---ro (vlan-action-type)?
| | +---:(pop)
| | | +---ro enable-pop ipi-if-
types:if_subif_rewrite_pop_type_t
| | +---:(push)
| | | +---ro push-tpid ipi-if-types:cml_outer_tpid_type_t
| | | +---ro push-outer-vlan-id uint16
| | | +---ro push-inner-vlan-id? uint16
| | +---:(translate)
| | +---ro rewrite-translate-action ipi-if-
types:if_subif_l2_rewrite_actiontype_t
| | +---ro dot1q-dotlad-tpid ipi-if-types:cml_outer_tpid_type_t
| | +---ro outer-vlan-id uint16
| | +---ro i-dot1q-dotlad-tpid ipi-if-types:cml_inner_tpid_type_t
| | +---ro inner-vlan-id uint16
| +---rw single-tag-vlan-matches
| | +---rw single-tag-vlan-match* [encapsulation-type]
| | +---rw encapsulation-type -> ../config/encapsulation-type
| | +---rw config
| | | +---rw encapsulation-type? ipi-if-types:if_subif_encap_type_t
| | | +---rw outer-vlan-id* string
| | +---ro state
| | +---ro encapsulation-type? ipi-if-types:if_subif_encap_type_t
| | +---ro outer-vlan-id* string
| +---rw double-tag-vlan-matches
| | +---rw double-tag-vlan-match* [encap-type outer-vlan-id]
| | +---rw encap-type -> ../config/encap-type
| | +---rw outer-vlan-id -> ../config/outer-vlan-id
| | +---rw config
| | | +---rw encap-type? ipi-if-types:if_subif_encap_type_t
| | | +---rw outer-vlan-id? string
| | | +---rw inner-vlan-id* string
| | +---ro state
| | +---ro encap-type? ipi-if-types:if_subif_encap_type_t
| | +---ro outer-vlan-id? string
| | +---ro inner-vlan-id* string
+---rw subinterface-split-horizon {feature-list:HAVE_SUBINTERFACE,feature-
list:NOT_HAVE_DNX}?
| +---rw config
| | +---rw split-horizon-group? ipi-if-types:if_split_horizon_t
| +---ro state

```



```

|      +---ro split-horizon-group?   ipi-if-types:if_split_horizon_t
+---rw link-debounce-time
|  +---rw config!
|  |  +---rw linkup-debounce-time     uint16
|  |  +---rw linkdown-debounce-time  uint16
|  +---ro state
|      +---ro linkup-debounce-time    uint16
|      +---ro linkdown-debounce-time  uint16
+---rw minimum-bandwidth {feature-list:HAVE_TE}?
    +---rw config!
    |  +---rw rate                     uint32
    |  +---rw rate-unit                ipi_if_extended_rate_unit_t
    +---ro state
        +---ro rate                     uint32
        +---ro rate-unit                ipi_if_extended_rate_unit_t
augment /ipi-interface:interfaces/ipi-interface:interface/ipi-if-ethernet:ethernet:
+---rw extended-ethernet
+---rw config
|  +---rw forward-err-correction?     ipi-if-types:if_intf_fec_t
|  +---rw load-interval?              uint16 {feature-
list:HAVE_BROADCOM_OR_HAVE_MARVELL}?
+---ro state
    +---ro forward-err-correction?     ipi-if-types:if_intf_fec_t
    +---ro load-interval?              uint16 {feature-
list:HAVE_BROADCOM_OR_HAVE_MARVELL}?
    +---ro default-duplex-mode?       uint8
    +---ro default-speed?             string
augment /ipi-interface:interfaces/ipi-interface:interface/ipi-if-ethernet:ethernet:
+---rw storm-control {feature-list:HAVE_RATE_LIMIT}?
+---rw broadcast {feature-list:HAVE_RATE_LIMIT}?
|  +---rw config! {feature-list:HAVE_RATE_LIMIT}?
|  |  +---rw bcst-value                ipi-if-types:if_rate_limit_t
|  |  +---rw bcst-rate-limit-format    ipi-if-types:if_rate_limit_type
|  |  +---rw bcst-burst-value          uint32
|  +---ro state {feature-list:HAVE_RATE_LIMIT}?
|      +---ro bcst-value                ipi-if-types:if_rate_limit_t
|      +---ro bcst-rate-limit-format    ipi-if-types:if_rate_limit_type
|      +---ro bcst-burst-value          uint32
|      +---ro hardware-applied-bcst-value? decimal64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_RATE_LIMIT}?
+---rw multicast {feature-list:HAVE_RATE_LIMIT}?
|  +---rw config! {feature-list:HAVE_RATE_LIMIT}?
|  |  +---rw mcast-value                ipi-if-types:if_rate_limit_t
|  |  +---rw mcast-rate-limit-format    ipi-if-types:if_rate_limit_type
|  |  +---rw mcast-burst-value          uint32
|  +---ro state {feature-list:HAVE_RATE_LIMIT}?
|      +---ro mcast-value                ipi-if-types:if_rate_limit_t
|      +---ro mcast-rate-limit-format    ipi-if-types:if_rate_limit_type
|      +---ro mcast-burst-value          uint32
|      +---ro hardware-applied-mcast-value? decimal64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_RATE_LIMIT}?

```

```

+--rw dlf-broadcast {feature-list:HAVE_RATE_LIMIT}?
  +--rw config! {feature-list:HAVE_RATE_LIMIT}?
    | +--rw dlf-bcast-value                ipi-if-types:if_rate_limit_t
    | +--rw dlf-bcast-rate-limit-format    ipi-if-types:if_rate_limit_type
    | +--rw dlf-bcast-burst-value         uint32
  +--ro state {feature-list:HAVE_RATE_LIMIT}?
    +--ro dlf-bcast-value                ipi-if-types:if_rate_limit_t
    +--ro dlf-bcast-rate-limit-format    ipi-if-types:if_rate_limit_type
    +--ro dlf-bcast-burst-value         uint32
    +--ro hardware-applied-dlf-bcast-value? decimal64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_RATE_LIMIT}?
  augment /ipi-interface:interfaces/ipi-interface:interface/ipi-interface:state:
    +--ro custom-state
      +--ro current-bandwidth?   uint64
    augment /ipi-interface:interfaces/ipi-interface:interface/ipi-interface:state/ipi-
interface:counters:
      +--ro extended-counters
        +--ro in-compressed?      yang:counter64
        +--ro out-compressed?    yang:counter64
        +--ro collisions?       yang:counter64
        +--ro unicast-rpf-discard? yang:counter64
        +--ro in-length-errors?  yang:counter64
        +--ro in-oversize-errors? yang:counter64
        +--ro in-crc-errors?     yang:counter64
        +--ro in-frame-errors?   yang:counter64
        +--ro in-fifo-errors?    yang:counter64
        +--ro in-missed-errors?  yang:counter64
        +--ro out-aborted-errors? yang:counter64
        +--ro out-carrier-errors? yang:counter64
        +--ro out-fifo-errors?   yang:counter64
        +--ro out-heartbeat-errors? yang:counter64
        +--ro out-window-errors? yang:counter64
        +--ro l2-protocol-pkt-stat* [l2cp-counter-type] {feature-list:HAVE_HAL,feature-
list:HAVE_BROADCOM}?
          | +--ro lacp-counters?      yang:counter64
          | +--ro stp-counters?      yang:counter64
          | +--ro lldp-counters?     yang:counter64
          | +--ro efmCounters?       yang:counter64
          | +--ro elmi-counters?     yang:counter64
          | +--ro dot1x-counters?    yang:counter64
          | +--ro synce-counters?    yang:counter64
          | +--ro l2cp-counter-type  ipi-if-types:if_l2cp_stats_process_t
          +--ro error-disable-reason? ipi-if-types:if_errdisable_state_t
        augment /ipi-interface:interfaces/ipi-interface:interface/ipi-if-ethernet:ethernet/
ipi-if-ethernet:state/ipi-if-ethernet:counters:
          +--ro extended-ethernet-counters {feature-list:HAVE_BROADCOM,feature-
list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR,feature-list:NOT_HAVE_POND}?
            +--ro protocol-pkt-stats {feature-list:HAVE_HAL,feature-list:HAVE_BROADCOM}?
              | +--ro in-bgp-pkts?      yang:counter32
              | +--ro in-ospf-pkts?    yang:counter32
              | +--ro in-isis-pkts?    yang:counter32

```

```

| +--ro in-ldp-rsvp-pkts?      yang:counter32
| +--ro in-arp-pkts?         yang:counter32
| +--ro in-evpn-pkts?       yang:counter32
| +--ro in-igmp-pkts?       yang:counter32
| +--ro in-pim-pkts?        yang:counter32
| +--ro in-bpdu-pkts?       yang:counter32 {feature-list:HAVE_DUNE}?
| +--ro in-oamp-pkts?       yang:counter32 {feature-list:HAVE_DUNE}?
| +--ro in-bfd-pkts?        yang:counter32 {feature-list:HAVE_DUNE}?
| +--ro in-vrrp-rip-dhcp-pkts? yang:counter32 {feature-list:HAVE_DUNE}?
| +--ro in-rsvd-mc-pkts?    yang:counter32 {feature-list:HAVE_DUNE}?
| +--ro in-link-local-pkts? yang:counter32 {feature-list:HAVE_DUNE}?
| +--ro in-icmp-pkts?       yang:counter32 {feature-list:HAVE_DUNE}?
| +--ro in-icmp-redirect-pkts? yang:counter32 {feature-list:HAVE_DUNE}?
| +--ro in-misc-pkts?       yang:counter32 {feature-list:HAVE_DUNE}?
| +--ro in-total-pkts?      yang:counter32
+--ro in-good-octets?       yang:counter64
+--ro in-bad-octets?        yang:counter64
+--ro mac-transmit-error?   yang:counter64
+--ro in-good-pkts?        yang:counter64
+--ro in-bad-pkts?         yang:counter64
+--ro out-good-octets?     yang:counter64
+--ro out-good-pkts?       yang:counter64
+--ro excessive-collisions? yang:counter64
+--ro in-unrecognized-mac-control? yang:counter64
+--ro drop-events?        yang:counter64
+--ro in-mac-errors?       yang:counter64
+--ro in-dribble-errors?   yang:counter64
+--ro collisions-state?    yang:counter64
+--ro late-collisions?     yang:counter64
+--ro deferred-tx?         yang:counter64
+--ro mtu-exceed-discards? yang:counter64
+--ro in-jumbo-frames?     yang:counter64
+--ro out-jumbo-frames?    yang:counter64
+--ro receive-pkt-rate?    yang:counter64
+--ro receive-bit-rate?    yang:counter64
+--ro send-pkt-rate?       yang:counter64
+--ro send-bit-rate?       yang:counter64
augment /ipi-interface:interfaces:
+--rw global
+--rw error-disable
+--rw config
| +--rw reason?             ipi-if-types:if_err_reason_t
| +--rw error-disable-stp-bpdu-guard? boolean
| +--rw timeout-interval?  uint32 {feature-list:HAVE_L2}?
| +--rw link-flap-max-count? uint32 {feature-list:HAVE_L2}?
| +--rw link-flap-timer-interval? uint32 {feature-list:HAVE_L2}?
| +--rw mac-move-limit?    uint32 {feature-list:HAVE_L2}?
+--ro state
+--ro reason?              ipi-if-types:if_err_reason_t
+--ro error-disable-stp-bpdu-guard? boolean

```

```

        +--ro timeout-interval?          uint32 {feature-list:HAVE_L2}?
        +--ro link-flap-max-count?       uint32 {feature-list:HAVE_L2}?
        +--ro link-flap-timer-interval?  uint32 {feature-list:HAVE_L2}?
        +--ro mac-move-limit?            uint32 {feature-list:HAVE_L2}?
augment /ipi-interface:interfaces/ipi-interface:interface:
  +--rw tunnel {feature-list:HAVE_TUNNEL}?
    +--rw config
      | +--rw mode?                      ipi-if-types:if_tunnel_mode_t
      | +--rw src?                       inet:ipv4-address
      | +--rw multicast-interface?       string {feature-list:HAVE_VXLAN}?
      | +--rw dst?                       inet:ipv4-address
      | +--rw checksum-enable?           empty
      | +--rw tos-byte?                  uint16
      | +--rw ttl?                       uint16
      | +--rw path-mtu-enable?           empty
      | +--rw dst-mac-address?           string {feature-list:HAVE_USER_HSL}?
      | +--rw gre-key?                   ipi-if-types:if_tunnel_key_t {feature-
list:HAVE_GRE_KEY}?
    +--ro state
      +--ro mode?                        ipi-if-types:if_tunnel_mode_t
      +--ro src?                          inet:ipv4-address
      +--ro multicast-interface?          string {feature-list:HAVE_VXLAN}?
      +--ro dst?                          inet:ipv4-address
      +--ro checksum-enable?              empty
      +--ro tos-byte?                     uint16
      +--ro ttl?                           uint16
      +--ro path-mtu-enable?               empty
      +--ro dst-mac-address?               string {feature-list:HAVE_USER_HSL}?
      +--ro gre-key?                       ipi-if-types:if_tunnel_key_t {feature-
list:HAVE_GRE_KEY}?
    augment /ipi-interface:interfaces:
      +--rw port-group-speed-map* [group-index] {feature-list:HAVE_DUNE,feature-
list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
      +--rw group-index    -> ../config/group-index
      +--rw config
        | +--rw group-index?    uint8
        | +--rw group-speed     ipi-if-types:if_port_group_speed_t {feature-
list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
      +--ro state
        +--ro group-index?     uint8
        +--ro group-speed      ipi-if-types:if_port_group_speed_t {feature-
list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?

rpcs:
  +---x clear-interface-forward-error-correction-counters
  | +---w input
  |   +---w if-name    string
  +---x clear-interface-error-disable
  | +---w input
  |   +---w if-name    string
  +---x interface-sniff-enable {feature-list:HAVE_SNIFF_INTF}?

```

```

| +---w input
|   +---w interface-name    string
|   +---w sniffTime        uint8
|   +---w sniffAction       ipi-if-types:if_sniff_action_t
|   +---w sniff1            boolean
+---x interface-sniff-disable {feature-list:HAVE_SNIFF_INTF}?
    +---w input
        +---w interface-name    string

```

notifications:

```

+---n interface-error-disable-notification
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro error-disable-reason? ipi-if-types:if_errdisable_state_t
+---n interface-bandwidth-start
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro current-bandwidth? uint64
+---n interface-bandwidth-upgrade
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro current-bandwidth? uint64
+---n interface-bandwidth-downgrade
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro current-bandwidth? uint64
+---n interface-bandwidth-close
    +--ro severity?          cml-data-types:cml_notif_severity_t
    +--ro eventClass?        cml-data-types:cml_notif_class_t
    +--ro name?              string
    +--ro current-bandwidth? uint64

```

module: ipi-if-flowspec

```

augment /ipi-interface:interfaces/ipi-interface:interface:
  +--rw interface-flowspec
    +--rw ipv4
      +--rw flowspec
        +--rw disable?    empty

```

module: ipi-if-ip

```

+--rw ip-global
  +--rw vrf* [vrf-name] {feature-list:HAVE_VRF}?
    | +--rw vrf-name    -> ../config/vrf-name
    | +--rw config
    | | +--rw vrf-name?          -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
    | | +--rw disable-ip-vrf-forwarding?    empty
    | | +--rw disable-ipv6-vrf-forwarding?  empty {feature-list:HAVE_IPV6}?
    | | +--rw enable-icmp-broadcast?        empty
    | +--ro state
    |   +--ro vrf-name?          -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
    |   +--ro disable-ip-vrf-forwarding?    empty
    |   +--ro disable-ipv6-vrf-forwarding?  empty {feature-list:HAVE_IPV6}?
    |   +--ro enable-icmp-broadcast?        empty
+--rw config
  | +--rw router-id?                string
  | +--rw enable-auto-router-id-selection?  empty
  | +--rw disable-ip-forwarding?          empty
  | +--rw disable-ipv6-forwarding?        empty {feature-list:HAVE_IPV6}?
  | +--rw default-vrf-enable-icmp-broadcast?  empty
+--ro state
  +--ro router-id?                string
  +--ro enable-auto-router-id-selection?  empty
  +--ro disable-ip-forwarding?          empty
  +--ro disable-ipv6-forwarding?        empty {feature-list:HAVE_IPV6}?
  +--ro default-vrf-enable-icmp-broadcast?  empty

augment /ipi-interface:interfaces/ipi-interface:interface:
+--rw ipv4
  +--rw secondary-addresses* [ip-address]
    | +--rw ip-address    -> ../config/ip-address
    | +--rw config
    | | +--rw ip-address?      cml-data-types:cml_ipv4_prefix_t
    | | +--rw ip-label?       cml-data-types:cml_line_t
    | | +--rw secondary-anycast?  empty
    | +--ro state
    |   +--ro ip-address?      cml-data-types:cml_ipv4_prefix_t
    |   +--ro ip-label?       cml-data-types:cml_line_t
    |   +--ro secondary-anycast?  empty
+--rw config
  | +--rw primary-ip-addr?      cml-data-types:cml_ipv4_prefix_t
  | +--rw enable-dhcp-ip-address?  empty {feature-list:HAVE_DHCP_CLIENT}?
  | +--rw prefix-length?        uint8
  | +--rw ip-addr-label?        cml-data-types:cml_line_t
  | +--rw ipv4-unnumbered-if-name?  string {feature-list:HAVE_NSM_IF_UNNUMBERED}?
  | +--rw remote-address?        string {feature-list:HAVE_NSM_IF_UNNUMBERED}?
  | +--rw primary-anycast?      empty

```

```

+--ro state
  +--ro primary-ip-addr?          cml-data-types:cml_ipv4_prefix_t
  +--ro enable-dhcp-ip-address?   empty {feature-list:HAVE_DHCP_CLIENT}?
  +--ro prefix-length?           uint8
  +--ro ip-addr-label?           cml-data-types:cml_line_t
  +--ro ipv4-unnumbered-if-name?  string {feature-list:HAVE_NSM_IF_UNNUMBERED}?
  +--ro remote-address?          string {feature-list:HAVE_NSM_IF_UNNUMBERED}?
  +--ro primary-anycast?         empty
  +--ro dhcp-ip-address?         cml-data-types:cml_ipv4_prefix_t {feature-
list:HAVE_DHCP_CLIENT}?
  +--ro ipv4-enabled-status?      boolean
augment /ipi-interface:interfaces/ipi-interface:interface:
  +--rw ipv6 {feature-list:HAVE_IPV6}?
    +--rw addresses* [ipv6-address] {feature-list:HAVE_IPV6}?
      | +--rw ipv6-address   -> ../config/ipv6-address
      | +--rw config
      | | +--rw ipv6-address? cml-data-types:cml_ipv6_prefix_t
      | | +--rw anycast?     empty
      | +--ro state
      |   +--ro ipv6-address? cml-data-types:cml_ipv6_prefix_t
      |   +--ro anycast?     empty
    +--rw config
      | +--rw ipv6-unnumbered-if-name? string {feature-
list:HAVE_NSM_IF_UNNUMBERED,feature-list:HAVE_IPV6}?
      | +--rw enable-dhcp-ipv6-address? empty {feature-
list:HAVE_DHCP_CLIENT}?
      | +--rw enable-dhcp-temporary-ipv6-address? empty {feature-
list:HAVE_DHCP_CLIENT}?
      | +--rw dhcp-address-prefix-length? uint8 {feature-
list:HAVE_DHCP_CLIENT}?
      | +--rw enable-auto-config?      boolean {feature-list:HAVE_IPV6}?
    +--ro state
      | +--ro ipv6-unnumbered-if-name? string {feature-
list:HAVE_NSM_IF_UNNUMBERED,feature-list:HAVE_IPV6}?
      | +--ro enable-dhcp-ipv6-address? empty {feature-
list:HAVE_DHCP_CLIENT}?
      | +--ro enable-dhcp-temporary-ipv6-address? empty {feature-
list:HAVE_DHCP_CLIENT}?
      | +--ro dhcp-address-prefix-length? uint8 {feature-
list:HAVE_DHCP_CLIENT}?
      | +--ro enable-auto-config?      boolean {feature-list:HAVE_IPV6}?
      | +--ro dhcp-ipv6-address?       cml-data-types:cml_ipv6_prefix_t
{feature-list:HAVE_DHCP_CLIENT}?
      | +--ro forwarding-status?       boolean {feature-list:HAVE_IPV6}?
    +--ro auto-addresses {feature-list:HAVE_IPV6}?
      +--ro auto-address* [ipv6-address]
        +--ro ipv6-address   -> ../state/ipv6-address
        +--ro state
          +--ro ipv6-address? cml-data-types:cml_ipv6_prefix_t
          +--ro anycast?     empty
          +--ro virtual?     empty
          +--ro vrrp?        empty {feature-list:HAVE_VRRP_V3}?

```

module: ipi-igmp-snooping

```

+--rw igmp-snooping
  +--rw global
    | +--rw config
    | | +--rw disable-igmp-snooping?          empty
    | | +--rw disable-report-suppression?    empty
    | | +--rw unknown-multicast-action?      ipi-igmp-snooping-
types:igmp_snoop_unknown_mcast_action_t
    | +--ro state
    |   +--ro disable-igmp-snooping?          empty
    |   +--ro disable-report-suppression?    empty
    |   +--ro unknown-multicast-action?      ipi-igmp-snooping-
types:igmp_snoop_unknown_mcast_action_t
  +--rw debug
    | +--rw config
    | | +--rw options?      ipi-igmp-snooping-types:igmp_snoop_debug_options_t
    | +--ro state
    |   +--ro options?          ipi-igmp-snooping-
types:igmp_snoop_debug_options_t
    |   +--ro terminal-debug-status?  ipi-igmp-snooping-
types:igmp_snoop_debug_options_t
  +--rw interfaces
    +--rw interface* [name]
      +--rw name          -> ../config/name
      +--rw config
      | +--rw name?          -> /ipi-interface:interfaces/interface/name
      | +--rw igmp-snooping?    cml-data-types:cml_enable_disable_t
      | +--rw enable-fast-leave?  empty
      | +--rw report-suppression? cml-data-types:cml_enable_disable_t
      | +--rw mrouter-interface-name* -> /ipi-interface:interfaces/interface/
name
      | +--rw enable-querier?    empty
      +--ro state
      | +--ro name?          -> /ipi-interface:interfaces/interface/name
      | +--ro igmp-snooping?    cml-data-types:cml_enable_disable_t
      | +--ro enable-fast-leave?  empty
      | +--ro report-suppression? cml-data-types:cml_enable_disable_t
      | +--ro mrouter-interface-name* -> /ipi-interface:interfaces/interface/
name
      | +--ro enable-querier?    empty
    +--rw static-groups
      +--rw ssm-groups
      | +--rw ssm-group* [group-address source-address interface-name]
      |   +--rw group-address  -> ../config/group-address
      |   +--rw source-address -> ../config/source-address

```



```

|     +--rw interface-name   -> ../config/interface-name
|     +--rw config
|     |   +--rw group-address?  inet:ipv4-address
|     |   +--rw interface-name? string
|     |   +--rw source-address? inet:ipv4-address
|     +--ro state
|         +--ro group-address?  inet:ipv4-address
|         +--ro interface-name? string
|         +--ro source-address? inet:ipv4-address
+--rw asm-groups
    +--rw asm-group* [group-address interface-name]
        +--rw group-address     -> ../config/group-address
        +--rw interface-name    -> ../config/interface-name
        +--rw config
        |   +--rw group-address?  inet:ipv4-address
        |   +--rw interface-name? string
        +--ro state
            +--ro group-address?  inet:ipv4-address
            +--ro interface-name?  string

rpcs:
+---x igmp-snooping-clear-group-interface {feature-list:HAVE_L2MRIBD}?
| +---w input
|   +---w group-address     inet:ipv4-address
|   +---w interface-name    string
+---x igmp-snooping-clear-interface {feature-list:HAVE_L2MRIBD}?
| +---w input
|   +---w interface-name    string
+---x igmp-snooping-clear-all {feature-list:HAVE_L2MRIBD}?
+---x igmp-snooping-clear-group {feature-list:HAVE_L2MRIBD}?
| +---w input
|   +---w group-address     inet:ipv4-address
+---x igmp-snooping-terminal-debug-on {feature-list:HAVE_L2MRIBD}?
| +---w input
|   +---w terminal-debug-options  ipi-igmp-snooping-
types:igmp_snoop_debug_options_t
+---x igmp-snooping-terminal-debug-off {feature-list:HAVE_L2MRIBD}?
| +---w input
|   +---w terminal-debug-options  ipi-igmp-snooping-
types:igmp_snoop_debug_options_t

```

module: ipi-igmp

```

+--rw igmp
  +--rw vrfs
  |   +--rw vrf* [vrf-name]
  |       +--rw vrf-name           -> ../config/vrf-name
  |       +--rw config

```

```

|      | +--rw vrf-name?          -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
|      | +--rw disable-ssm-map?   empty
|      | +--rw disable-tos-check? empty
|      +--ro state
|      | +--ro vrf-name?          -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
|      | +--ro disable-ssm-map?   empty
|      | +--ro disable-tos-check? empty
|      +--rw group-membership-control
|      | +--rw config
|      | | +--rw member-limit?    uint32
|      | | +--rw limit-exception-acl? string
|      | +--ro state
|      |   +--ro member-limit?    uint32
|      |   +--ro limit-exception-acl? string
|      |   +--ro current-states-count? uint32
|      +--rw ssm
|      | +--rw static-mappings
|      |   +--rw static-mapping* [group-ranges-acl source]
|      |     +--rw group-ranges-acl -> ../config/group-ranges-acl
|      |     +--rw source           -> ../config/source
|      |     +--rw config
|      |       | +--rw group-ranges-acl? string
|      |       | +--rw source?           inet:ipv4-address
|      |       +--ro state
|      |         +--ro group-ranges-acl? string
|      |         +--ro source?           inet:ipv4-address
|      +--rw debug
|      | +--rw config
|      | | +--rw options?         ipi-igmp-types:igmp_debug_options_t
|      | +--ro state
|      |   +--ro options?         ipi-igmp-types:igmp_debug_options_t
|      |   +--ro terminal-debug-status? ipi-igmp-types:igmp_debug_options_t
+--rw interfaces
| +--rw interface* [name]
|   +--rw name           -> ../config/name
|   +--rw config
|     | +--rw name?      -> /ipi-interface:interfaces/interface/
name
|     | +--rw enabled?   empty
|     | +--rw last-member-query-count? uint8
|     | +--rw last-member-query-interval? uint16
|     | +--rw querier-timeout? uint16
|     | +--rw query-interval? uint16
|     | +--rw query-max-response-time? uint8
|     | +--rw startup-query-interval? uint16
|     | +--rw startup-query-count? uint8
|     | +--rw robustness-variable? uint8
|     | +--rw version?   uint8
|     | +--rw require-router-alert-option? empty

```

```

|     | +--rw allow-offlink-host?           empty
| +--ro state
|     | +--ro counters
|     | | +--ro v1-reports-received?       yang:counter32
|     | | +--ro v2-reports-received?       yang:counter32
|     | | +--ro v2-leaves-received?        yang:counter32
|     | | +--ro v3-reports-received?       yang:counter32
|     | | +--ro current-group-records?     yang:counter32
|     | +--ro internet-address?           inet:ipv4-address
|     | +--ro oper-status?                 ipi-igmp-types:igmp_if_oper_status_t
|     | +--ro host-version?                uint8
|     | +--ro is-querier?                  boolean
|     | +--ro querying-router?             inet:ipv4-address
|     | +--ro group-membership-interval?   uint32
name | +--ro name?                           -> /ipi-interface:interfaces/interface/
|     | +--ro enabled?                     empty
|     | +--ro last-member-query-count?     uint8
|     | +--ro last-member-query-interval?  uint16
|     | +--ro querier-timeout?              uint16
|     | +--ro query-interval?              uint16
|     | +--ro query-max-response-time?     uint8
|     | +--ro startup-query-interval?      uint16
|     | +--ro startup-query-count?         uint8
|     | +--ro robustness-variable?         uint8
|     | +--ro version?                     uint8
|     | +--ro require-router-alert-option? empty
|     | +--ro allow-offlink-host?          empty
| +--rw proxy
|     | +--rw config
|     | | +--rw enable-proxy-service?      empty
|     | | +--rw mroute-proxy-interface?    string
|     | | +--rw unsolicited-report-interval? uint16
|     | +--ro state
|     | | +--ro enable-proxy-service?      empty
|     | | +--ro mroute-proxy-interface?    string
|     | | +--ro unsolicited-report-interval? uint16
types:igmp_proxy_if_oper_status_t | +--ro oper-status?                 ipi-igmp-
| +--rw group-membership-control
|     | +--rw config
|     | | +--rw access-group-name?         string
|     | | +--rw immediate-leave-groups-list? string
|     | | +--rw member-limit?              uint32
|     | | +--rw limit-exception-acl?        string
|     | +--ro state
|     | | +--ro access-group-name?         string
|     | | +--ro immediate-leave-groups-list? string
|     | | +--ro member-limit?              uint32
|     | | +--ro limit-exception-acl?        string
| +--rw asm-static-groups

```

```
| | +--rw asm-static-group* [group-address]
| |   +--rw group-address   -> ../config/group-address
| |   +--rw config
| |     | +--rw group-address?  inet:ipv4-address
| |     +--ro state
| |       +--ro group-address?  inet:ipv4-address
+--rw ssm-static-groups
| | +--rw ssm-static-group* [group-address source]
| |   +--rw group-address   -> ../config/group-address
| |   +--rw source         -> ../config/source
| |   +--rw config
| |     | +--rw group-address?  inet:ipv4-address
| |     | +--rw source?        ipi-igmp-types:igmp_static_ssm_source_t
| |     +--ro state
| |       +--ro group-address?  inet:ipv4-address
| |       +--ro source?        ipi-igmp-types:igmp_static_ssm_source_t
+--rw asm-join-groups
| | +--rw asm-join-group* [group-address]
| |   +--rw group-address   -> ../config/group-address
| |   +--rw config
| |     | +--rw group-address?  inet:ipv4-address
| |     +--ro state
| |       +--ro group-address?  inet:ipv4-address
+--rw ssm-join-groups
| | +--rw ssm-join-group* [group-address source]
| |   +--rw group-address   -> ../config/group-address
| |   +--rw source         -> ../config/source
| |   +--rw config
| |     | +--rw group-address?  inet:ipv4-address
| |     | +--rw source?        inet:ipv4-address
| |     +--ro state
| |       +--ro group-address?  inet:ipv4-address
| |       +--ro source?        inet:ipv4-address
+--ro group-membership-tree
  +--ro igmp-instances
    +--ro igmp-instance* [vrf-name]
      +--ro vrf-name      -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name
      +--ro interfaces
        +--ro interface* [if-name]
          +--ro if-name    -> /ipi-interface:interfaces/interface/name
          +--ro member-groups
            | +--ro member-group* [group-address]
            |   +--ro group-address   -> ../state/group-address
            |   +--ro state
            |     | +--ro group-address?  inet:ipv4-address
            |     | +--ro dynamic-remote? empty
            |     | +--ro static-group?  empty
            |     | +--ro local?        empty
            |     | +--ro ssm-mapped?   empty
            |     +--ro static-source?  empty
```

```

|     | +--ro up-time?          string
|     | +--ro group-mode?      ipi-igmp-types:igmp_ssm_group_mode_t
|     | +--ro expiry?         string
|     | +--ro last-reporter?   inet:ipv4-address
|     +--ro include-sources
|     | +--ro include-source* [source-address]
|     |   +--ro source-address  -> ../state/source-address
|     |   +--ro state
|     |     +--ro source-address? inet:ipv4-address
|     |     +--ro dynamic-remote? empty
|     |     +--ro static-source?  empty
|     |     +--ro local?          empty
|     |     +--ro ssm-mapped?     empty
|     |     +--ro up-time?       string
|     |     +--ro expiry?       string
|     |     +--ro is-forwarded?   ipi-igmp-types:igmp_yes_no_t
|     +--ro exclude-sources
|     | +--ro exclude-source* [source-address]
|     |   +--ro source-address  -> ../state/source-address
|     |   +--ro state
|     |     +--ro source-address? inet:ipv4-address
|     |     +--ro dynamic-remote? empty
|     |     +--ro static-source?  empty
|     |     +--ro local?          empty
|     |     +--ro ssm-mapped?     empty
|     |     +--ro up-time?       string
|     |     +--ro expiry?       string
|     |     +--ro is-forwarded?   ipi-igmp-types:igmp_yes_no_t
+--ro proxy-groups
  +--ro proxy-group* [group-address]
    +--ro group-address  -> ../state/group-address
    +--ro state
      +--ro group-address?      inet:ipv4-address
      +--ro proxy-interface?   string
      +--ro group-mode?        ipi-igmp-
types:igmp_ssm_group_mode_t
      +--ro state?             ipi-igmp-types:igmp_if_state_t
      +--ro membership-state?  ipi-igmp-
types:igmp_proxy_grp_membership_state_t
      +--ro multicast-sources* inet:ipv4-address

rpcs:
+---x igmp-terminal-debug-on {feature-list:HAVE_MRIBD}?
| +---w input
|   +---w vrf-name?          string
|   +---w terminal-debug-options ipi-igmp-types:igmp_debug_options_t
+---x igmp-terminal-debug-off {feature-list:HAVE_MRIBD}?
| +---w input
|   +---w vrf-name?          string
|   +---w terminal-debug-options ipi-igmp-types:igmp_debug_options_t
+---x igmp-clear-all-groups {feature-list:HAVE_MRIBD}?

```

```

| +---w input
|   +---w vrf-name?    string
|   +---w clear-all  empty
+---x igmp-clear-group-on-interface {feature-list:HAVE_MRIBD}?
| +---w input
|   +---w vrf-name?    string
|   +---w group-address inet:ipv4-address
|   +---w if-name      string
+---x igmp-clear-all-groups-on-interface {feature-list:HAVE_MRIBD}?
| +---w input
|   +---w vrf-name?    string
|   +---w if-name      string
+---x igmp-clear-group {feature-list:HAVE_MRIBD}?
  +---w input
    +---w vrf-name?    string
    +---w group-address inet:ipv4-address

```

module: ipi-igp-te

```

+--rw igp-te
  +--rw interfaces
    +--rw interface* [name]
      +--rw name          -> ../config/name
      +--rw config
        | +--rw name?     -> /ipi-interface:interfaces/interface/name
        +--ro state
          | +--ro name?   -> /ipi-interface:interfaces/interface/name
          +--rw uni-link
            +--rw config
              | +--rw delay?          uint32
              | +--rw delay-variation? uint32
              | +--rw loss-percentage? decimal64
            +--ro state
              | +--ro delay?          uint32
              | +--ro delay-variation? uint32
              | +--ro loss-percentage? decimal64
            +--rw twamp-loss-parameter {feature-list:HAVE_TWAMP}?
              | +--rw config
              | | +--rw loss-dynamic? empty
              | +--ro state
              |   +--ro loss-dynamic? empty
            +--rw irb-twamp-loss-parameter {feature-list:HAVE_TWAMP}?
              | +--rw config
              | | +--rw loss-dynamic? empty
              | +--ro state
              |   +--ro loss-dynamic? empty
            +--rw twamp-session-parameters {feature-list:HAVE_TWAMP}?
              | +--rw twamp-session-parameter* [delay-dynamic-twamp reflector-ip]

```

```

| | +--rw delay-dynamic-twamp -> ../config/delay-dynamic-twamp
| | +--rw reflector-ip -> ../config/reflector-ip
| | +--rw config
| | | +--rw delay-dynamic-twamp? empty
| | | +--rw reflector-ip? cml-data-types:cml_hostpname_t
| | | +--rw reflector-port? uint16
| | | +--rw sender-ip? cml-data-types:cml_hostpname_t
| | | +--rw sender-port? uint16
| | | +--rw dscp? string
| | +--ro state
| | | +--ro delay-dynamic-twamp? empty
| | | +--ro reflector-ip? cml-data-types:cml_hostpname_t
| | | +--ro reflector-port? uint16
| | | +--ro sender-ip? cml-data-types:cml_hostpname_t
| | | +--ro sender-port? uint16
| | | +--ro dscp? string
| | +--ro statistics
| | +--ro state
time | | +--ro last-advertised-calculation-time? yang:date-and-
| | +--ro last-advertised-minimum-delay? uint64
| | +--ro last-advertised-maximum-delay? uint64
| | +--ro last-advertised-average-delay? uint64
| | +--ro last-advertised-minimum-delay-variation? uint64
| | +--ro last-advertised-maximum-delay-variation? uint64
| | +--ro last-advertised-average-delay-variation? uint64
| | +--ro last-advertised-packets-sent? yang:counter64
| | +--ro last-advertised-packets-received? yang:counter64
| | +--ro last-advertised-packets-timeout? yang:counter64
| | +--ro last-advertised-packet-loss? decimal64
time | | +--ro last-calculated-calculation-time? yang:date-and-
| | +--ro last-calculated-minimum-delay? uint64
| | +--ro last-calculated-maximum-delay? uint64
| | +--ro last-calculated-average-delay? uint64
| | +--ro last-calculated-minimum-delay-variation? uint64
| | +--ro last-calculated-maximum-delay-variation? uint64
| | +--ro last-calculated-average-delay-variation? uint64
| | +--ro last-calculated-packets-sent? yang:counter64
| | +--ro last-calculated-packets-received? yang:counter64
| | +--ro last-calculated-packets-timeout? yang:counter64
| | +--ro last-calculated-packet-loss? decimal64
| +--rw irb-twamp-session-parameter* [delay-dynamic-twamp reflector-ip]
| +--rw delay-dynamic-twamp -> ../config/delay-dynamic-twamp
| +--rw reflector-ip -> ../config/reflector-ip
| +--rw config
| | +--rw delay-dynamic-twamp? empty
| | +--rw reflector-ip? cml-data-types:cml_hostpname_t
| | +--rw reflector-port? uint16
| | +--rw sender-ip? cml-data-types:cml_hostpname_t
| | +--rw sender-port? uint16

```

```

|     | +--rw dscp?                string
|     +---ro state
|     | +--ro delay-dynamic-twamp? empty
|     | +--ro reflector-ip?       cml-data-types:cml_hostpname_t
|     | +--ro reflector-port?    uint16
|     | +--ro sender-ip?        cml-data-types:cml_hostpname_t
|     | +--ro sender-port?      uint16
|     | +--ro dscp?              string
|     +---ro statistics
|     +---ro state
time |     +---ro last-advertised-calculation-time?    yang:date-and-
|     +---ro last-advertised-minimum-delay?        uint64
|     +---ro last-advertised-maximum-delay?        uint64
|     +---ro last-advertised-average-delay?         uint64
|     +---ro last-advertised-minimum-delay-variation? uint64
|     +---ro last-advertised-maximum-delay-variation? uint64
|     +---ro last-advertised-average-delay-variation? uint64
|     +---ro last-advertised-packets-sent?          yang:counter64
|     +---ro last-advertised-packets-received?     yang:counter64
|     +---ro last-advertised-packets-timeout?      yang:counter64
|     +---ro last-advertised-packet-loss?          decimal64
time |     +---ro last-calculated-calculation-time?    yang:date-and-
|     +---ro last-calculated-minimum-delay?        uint64
|     +---ro last-calculated-maximum-delay?        uint64
|     +---ro last-calculated-average-delay?         uint64
|     +---ro last-calculated-minimum-delay-variation? uint64
|     +---ro last-calculated-maximum-delay-variation? uint64
|     +---ro last-calculated-average-delay-variation? uint64
|     +---ro last-calculated-packets-sent?          yang:counter64
|     +---ro last-calculated-packets-received?     yang:counter64
|     +---ro last-calculated-packets-timeout?      yang:counter64
|     +---ro last-calculated-packet-loss?          decimal64
+---rw delay-threshold
| +---rw a-bit* [a-bit-min a-bit-max]
|   +---rw a-bit-min   -> ../config/a-bit-min
|   +---rw a-bit-max   -> ../config/a-bit-max
|   +---rw config
|     | +---rw a-bit-min?  uint32
|     | +---rw a-bit-max?  uint32
|     +---ro state
|       +---ro a-bit-min?  uint32
|       +---ro a-bit-max?  uint32
+---rw min-max-delay
| +---rw delay* [min-value max-value]
|   +---rw min-value   -> ../config/min-value
|   +---rw max-value   -> ../config/max-value
|   +---rw config
|     | +---rw min-value?  uint32
|     | +---rw max-value?  uint32

```



```

|     +--ro state
|         +--ro min-value?    uint32
|         +--ro max-value?    uint32
+--rw loss
| +--rw threshold* [loss-a-bit-min loss-a-bit-max]
|     +--rw loss-a-bit-min    -> ../config/loss-a-bit-min
|     +--rw loss-a-bit-max    -> ../config/loss-a-bit-max
|     +--rw config
|         | +--rw loss-a-bit-min?    decimal64
|         | +--rw loss-a-bit-max?    decimal64
|         +--ro state
|             +--ro loss-a-bit-min?    decimal64
|             +--ro loss-a-bit-max?    decimal64
+--rw min-max-delay-threshold
    +--rw a-bit* [a-bit-min-range-minimum a-bit-min-range-maximum a-bit-max-
range-minimum a-bit-max-range-maximum]
        +--rw a-bit-min-range-minimum    -> ../config/a-bit-min-range-minimum
        +--rw a-bit-min-range-maximum    -> ../config/a-bit-min-range-maximum
        +--rw a-bit-max-range-minimum    -> ../config/a-bit-max-range-minimum
        +--rw a-bit-max-range-maximum    -> ../config/a-bit-max-range-maximum
        +--rw config
            | +--rw a-bit-min-range-minimum?    uint32
            | +--rw a-bit-min-range-maximum?    uint32
            | +--rw a-bit-max-range-minimum?    uint32
            | +--rw a-bit-max-range-maximum?    uint32
            +--ro state
                +--ro a-bit-min-range-minimum?    uint32
                +--ro a-bit-min-range-maximum?    uint32
                +--ro a-bit-max-range-minimum?    uint32
                +--ro a-bit-max-range-maximum?    uint32

rpcs:
+---x twamp-clear-measurement-intf {feature-list:HAVE_TWAMP}?
| +---w input
|     +---w interface-name    string
+---x twamp-clear-measurement-all {feature-list:HAVE_TWAMP}?

notifications:
+---n delay-measurement-status {feature-list:HAVE_TWAMP}?
    +--ro severity?          cml-data-types:cml_notif_severity_t
    +--ro eventClass?       cml-data-types:cml_notif_class_t
    +--ro message?          string

```

module: ipi-interface

```

+--rw interfaces
  +--rw interface* [name]
    +--rw name          -> ../config/name
    +--rw config

```

```

|   +--rw name?                string
|   +--rw enable-switchport?   empty
|   +--rw vrf-name?            -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
|   +--rw vr-name?            string {feature-list:HAVE_VR}?
|   +--rw type?               ipi-if-types:if_iana_if_type_t
|   +--rw mtu?                uint32
|   +--rw dotlad-ether-type?   string {feature-list:HAVE_VLAN_STACK,feature-
list:NOT_HAVE_SWFWDR}?
|   +--rw protected-port?     ipi-if-types:if_protected_port_type_t {feature-
list:HAVE_DUNE}?
|   +--rw bridge-domain-forward? empty {feature-list:HAVE_DUNE}?
|   +--rw description?        cml-data-types:cml_line_t
|   +--rw shutdown?          empty
+--ro state
|   +--ro name?                string
|   +--ro enable-switchport?   empty
|   +--ro vrf-name?            -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
|   +--ro vr-name?            string {feature-list:HAVE_VR}?
|   +--ro type?               ipi-if-types:if_iana_if_type_t
|   +--ro mtu?                uint32
|   +--ro dotlad-ether-type?   string {feature-list:HAVE_VLAN_STACK,feature-
list:NOT_HAVE_SWFWDR}?
|   +--ro protected-port?     ipi-if-types:if_protected_port_type_t {feature-
list:HAVE_DUNE}?
|   +--ro bridge-domain-forward? empty {feature-list:HAVE_DUNE}?
|   +--ro description?        cml-data-types:cml_line_t
|   +--ro shutdown?          empty
|   +--ro ifindex?            uint32
|   +--ro admin-status?       ipi-if-types:if_interface_admin_status_t
|   +--ro oper-status?        ipi-if-types:if_interface_oper_status_t
|   +--ro last-change?        yang:timeticks
|   +--ro logical?            boolean
|   +--ro counters
|     +--ro in-octets?         yang:counter64
|     +--ro in-pkts?          yang:counter64
|     +--ro in-unicast-pkts?   yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
|     +--ro in-broadcast-pkts? yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
|     +--ro in-multicast-pkts? yang:counter64
|     +--ro in-discards?       yang:counter64
|     +--ro in-errors?        yang:counter64
|     +--ro in-fcs-errors?     yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
|     +--ro out-octets?        yang:counter64
|     +--ro out-pkts?         yang:counter64
|     +--ro out-unicast-pkts?  yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
|     +--ro out-broadcast-pkts? yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?

```

```

|      +---ro out-multicast-pkts?   yang:counter64 {feature-
list:HAVE_BROADCOM,feature-list:HAVE_HAL,feature-list:NOT_HAVE_SWFWDR}?
|      +---ro out-discards?         yang:counter64
|      +---ro out-errors?           yang:counter64
|      +---ro last-clear?           ipi-if-types:if_last_clear_time_t
+---rw interface-loopback
  +---rw config!
  |   +---rw if-loopback             ipi-if-types:if_loopback_dir_type_t
  |   +---rw if-loopback-level      ipi-if-types:if_loopback_type_t
  +---ro state
    +---ro if-loopback              ipi-if-types:if_loopback_dir_type_t
    +---ro if-loopback-level        ipi-if-types:if_loopback_type_t

rpcs:
  +---x clear-interface-counters
  +---w input
  +---w name      string

notifications:
  +---n interface-link-state-change-notification
  +---ro severity?      cml-data-types:cml_notif_severity_t
  +---ro eventClass?   cml-data-types:cml_notif_class_t
  +---ro name?         string
  +---ro oper-status?  ipi-if-types:if_interface_oper_status_t

```

module: ipi-ip-sla

```

+---rw ip-sla
  +---rw processes
  |   +---rw process* [identifier]
  |   |   +---rw identifier      -> ../config/identifier
  |   |   +---rw config
  |   |   |   +---rw identifier?  uint16
  |   |   +---ro state
  |   |   |   +---ro identifier?  uint16
  |   |   +---ro ip-sla-statistics
  |   |   |   +---ro state
  |   |   |   |   +---ro start-time?      yang:date-and-time
  |   |   |   |   +---ro elapsed-time?    uint64
  |   |   |   |   +---ro packets-sent?    uint32
  |   |   |   |   +---ro packets-received? uint32
  |   |   |   |   +---ro packets-lost?    decimal64
  |   |   |   |   +---ro invalid-tests?   uint32
  |   |   |   |   +---ro minimum-round-trip-delay? uint64
  |   |   |   |   +---ro maximum-round-trip-delay? uint64
  |   |   |   |   +---ro average-round-trip-delay? uint64
  |   |   +---rw icmp-echo-processes
  |   |   |   +---rw icmp-echo-process* [host]
  |   |   |   +---rw host      -> ../config/host

```

```
|          +--rw config
|          |  +--rw host?          ip_sla_hostname_t
|          |  +--rw source-interface? string
|          |  +--rw frequency?    uint8
|          |  +--rw timeout?      uint16
|          |  +--rw threshold?    uint16
|          +--ro state
|          |  +--ro host?          ip_sla_hostname_t
|          |  +--ro source-interface? string
|          |  +--ro frequency?    uint8
|          |  +--ro timeout?      uint16
|          |  +--ro threshold?    uint16
+--rw scheduled-processes
  +--rw scheduled-process* [scheduled-pid time-range-name]
    +--rw scheduled-pid    -> ../config/scheduled-pid
    +--rw time-range-name  -> ../config/time-range-name
    +--rw config
      |  +--rw scheduled-pid?    uint16
      |  +--rw time-range-name? string
      |  +--rw vrf-name?        string
    +--ro state
      +--ro scheduled-pid?    uint16
      +--ro time-range-name? string
      +--ro vrf-name?        string

rpcs:
  +---x ip-sla-clear-statistics {feature-list:HAVE_IPSLA,feature-list:HAVE_BFD}?
    +---w input
      +---w identifier    uint16

notifications:
  +---n icmp-echo-threshold {feature-list:HAVE_IPSLA}?
    |  +--ro severity?      cml-data-types:cml_notif_severity_t
    |  +--ro eventClass?   cml-data-types:cml_notif_class_t
    |  +--ro host?         ip_sla_hostname_t
    |  +--ro identifier?   uint16
    |  +--ro threshold?    uint16
  +---n icmp-echo-timeout {feature-list:HAVE_IPSLA}?
    |  +--ro severity?      cml-data-types:cml_notif_severity_t
    |  +--ro eventClass?   cml-data-types:cml_notif_class_t
    |  +--ro host?         ip_sla_hostname_t
    |  +--ro identifier?   uint16
    |  +--ro timeout?      uint16
  +---n icmp-echo-disconnect {feature-list:HAVE_IPSLA}?
    +--ro severity?      cml-data-types:cml_notif_severity_t
    +--ro eventClass?   cml-data-types:cml_notif_class_t
    +--ro identifier?   uint16
```

module: ipi-ipsec

```

+--rw ipsec {feature-list:HAVE_IPSEC}?
  +--rw transform-sets
    | +--rw transform-set* [transform-set-name]
    |   +--rw transform-set-name    -> ../config/transform-set-name
    |   +--rw config
    |     | +--rw transform-set-name?  string
    |     | +--rw transform-set-mode?  ipi-ipsec-types:ipsec_ts_mode_t
    |     +--ro state
    |       | +--ro transform-set-name?    string
    |       | +--ro transform-set-mode?    ipi-ipsec-types:ipsec_ts_mode_t
    |       | +--ro transform-set-protocol? ipi-ipsec-types:ipsec_ts_protocol_t
    |     +--rw ah-auth
    |       | +--rw config
    |       |   | +--rw ah-authentication? ipi-ipsec-types:ipsec_ah_authentication_t
    |       |   | +--ro state
    |       |   |   +--ro ah-authentication? ipi-ipsec-types:ipsec_ah_authentication_t
    |     +--rw esp-auth
    |       +--rw config!
    |         | +--rw esp-authentication  ipi-ipsec-types:ipsec_esp_authentication_t
    |         | +--rw esp-encryption     ipi-ipsec-types:ipsec_esp_encryption_t
    |         +--ro state
    |           +--ro esp-authentication  ipi-ipsec-types:ipsec_esp_authentication_t
    |           +--ro esp-encryption     ipi-ipsec-types:ipsec_esp_encryption_t
    +--rw crypto-maps
      +--rw crypto-map* [name]
        +--rw name          -> ../config/name
        +--rw config
        | +--rw name?      string
        | +--rw sa-type   ipi-ipsec-types:ipsec_sa_type_t
        +--ro state
        | +--ro name?     string
        | +--ro sa-type   ipi-ipsec-types:ipsec_sa_type_t
        +--rw sessions
          +--rw session* [sequence-id]
            +--rw sequence-id    -> ../config/sequence-id
            +--rw config
            | +--rw sequence-id?  uint16
            +--ro state
            | +--ro sequence-id?  uint16
            +--rw transform-sets
            | +--rw transform-set* [transform-set-name]
            |   +--rw transform-set-name    -> ../config/transform-set-name
            |   +--rw config
            |     | +--rw transform-set-name?  -> /ipsec/transform-sets/transform-
set/transform-set-name
            |     +--ro state
            |       +--ro transform-set-name?  -> /ipsec/transform-sets/transform-
set/transform-set-name

```

```

    +--rw peer-addresses
    | +--rw peer-address* [peer]
    |   +--rw peer      -> ../config/peer
    |   +--rw config
    |     | +--rw peer?   inet:ip-address
    |     | +--rw spi     ipi-ipsec-types:ipsec_peer_spi_t
    |     +--ro state
    |       +--ro peer?   inet:ip-address
    |       +--ro spi     ipi-ipsec-types:ipsec_peer_spi_t
    +--rw session-keys
    |   +--rw session-key* [direction protocol security-parameter-index]
    |     +--rw direction      -> ../config/direction
    |     +--rw protocol       -> ../config/protocol
    |     +--rw security-parameter-index -> ../config/security-parameter-
index
    |       +--rw config
    |         | +--rw direction?           ipi-ipsec-
types:ipsec_session_key_direction_t
    |         | +--rw protocol?           ipi-ipsec-
types:ipsec_session_key_protocol_t
    |         | +--rw security-parameter-index? uint16
    |         | +--rw cipher              string
    |         | +--rw authentication-key   string
    |         +--ro state
    |           +--ro direction?           ipi-ipsec-
types:ipsec_session_key_direction_t
    |           +--ro protocol?           ipi-ipsec-
types:ipsec_session_key_protocol_t
    |           +--ro security-parameter-index? uint16
    |           +--ro cipher              string
    |           +--ro authentication-key   string

```

module: ipi-ipv6-router-adv

```

+--rw router-advertisement {feature-list:HAVE_RTADV}?
+--rw interfaces
  +--rw interface* [name]
    +--rw name      -> ../config/name
    +--rw config
    | +--rw name?      -> /ipi-interface:interfaces/interface/name
    | +--rw suppress-ra?      empty
    | +--rw suppress-ra-mtu?   empty
    | +--rw managed-flag?     empty
    | +--rw other-config-flag? empty
    | +--rw current-hop-limit? uint8
    | +--rw link-mtu?         uint32
    | +--rw dad-attempts?     uint16
    +--ro state
    | +--ro name?           -> /ipi-interface:interfaces/interface/name

```

```

|  +--ro suppress-ra?          empty
|  +--ro suppress-ra-mtu?      empty
|  +--ro managed-flag?         empty
|  +--ro other-config-flag?    empty
|  +--ro current-hop-limit?    uint8
|  +--ro link-mtu?             uint32
|  +--ro dad-attempts?         uint16
+--rw ipv6-prefixes
|  +--rw config
|  |  +--rw off-link?          empty
|  |  +--rw no-auto-configuration?  empty
|  |  +--rw valid-lifetime?      uint32
|  |  +--rw preferred-lifetime?   uint32
|  +--ro state
|  |  +--ro off-link?          empty
|  |  +--ro no-auto-configuration?  empty
|  |  +--ro valid-lifetime?      uint32
|  |  +--ro preferred-lifetime?   uint32
|  +--rw ipv6-prefix* [ipv6-address]
|  |  +--rw ipv6-address      -> ../config/ipv6-address
|  |  +--rw config
|  |  |  +--rw ipv6-address?      cml-data-types:cml_ipv6_prefix_t
|  |  |  +--rw valid-lifetime?    uint32
|  |  |  +--rw preferred-lifetime?  uint32
|  |  |  +--rw off-link?          empty
|  |  |  +--rw no-auto-configuration?  empty
|  |  +--ro state
|  |  |  +--ro ipv6-address?      cml-data-types:cml_ipv6_prefix_t
|  |  |  +--ro valid-lifetime?    uint32
|  |  |  +--ro preferred-lifetime?  uint32
|  |  |  +--ro off-link?          empty
|  |  |  +--ro no-auto-configuration?  empty
+--rw timers
  +--rw config
  |  +--rw reachable-time?      uint32
  |  +--rw retransmission-time?  uint32
  |  +--rw router-lifetime?     uint16
  +--ro state
  |  +--ro reachable-time?      uint32
  |  +--ro retransmission-time?  uint32
  |  +--ro router-lifetime?     uint16
  |  +--ro random-interval?     uint32
  |  +--ro time-remaining?      uint32
  +--rw ra-interval
  |  +--rw config!
  |  |  +--rw max-ra-interval    uint32
  |  |  +--rw min-ra-interval    uint32
  |  +--ro state
  |  |  +--ro max-ra-interval    uint32
  |  |  +--ro min-ra-interval    uint32

```

module: ipi-isis

```

+--rw isis
  +--rw isis-instances
    | +--rw isis-instance* [instance]
    |   +--rw instance -> ../config/instance
    |   +--ro ipv4-route* [destination-prefix]
    |     | +--ro destination-prefix -> ../state/destination-prefix
    |     | +--ro nexthop* [nexthop-ip]
    |     | | +--ro nexthop-ip -> ../state/nexthop-ip
    |     | | +--ro state
    |     | |   +--ro nexthop-ip?          inet:ipv4-address
    |     | |   +--ro outgoing-interface?  string
    |     | |   +--ro redistribute-map-tag? uint32
    |     | |   +--ro source-identifier?   string
    |     | +--ro state
    |     | +--ro destination-prefix?      cml-data-
types:cml_ipv4_addr_prefix_t
    |     |   +--ro destination-path-metric?  uint32
    |     |   +--ro destination-path-type?    string
    |     |   +--ro is-destination-path-type-external? boolean
    |     |   +--ro tunnel-lsp-metric?       uint32 {feature-
list:HAVE_MPLS}?
    |     |   +--ro tunnel-lsp-tunnel-identifier? uint32 {feature-
list:HAVE_MPLS}?
    |     |   +--ro tunnel-lsp-tunnel-endpoint? cml-data-
types:cml_ipv4_addr_prefix_t {feature-list:HAVE_MPLS}?
    |     | +--ro ipv6-route* [destination-prefix]
    |     | | +--ro destination-prefix -> ../state/destination-prefix
    |     | | +--ro nexthop* [nexthop-ip]
    |     | | | +--ro nexthop-ip -> ../state/nexthop-ip
    |     | | | +--ro state
    |     | | |   +--ro nexthop-ip?          inet:ipv6-address
    |     | | |   +--ro outgoing-interface?  string
    |     | | |   +--ro redistribute-map-tag? uint32
    |     | | +--ro state
    |     | | +--ro destination-prefix?      cml-data-
types:cml_ipv6_prefix_t
    |     | |   +--ro destination-path-metric?  uint32
    |     | |   +--ro destination-path-type?    string
    |     | |   +--ro is-destination-path-type-external? boolean
    |     +--rw config

```



```

|      | +--rw instance?                string
|      | +--rw distance?                uint8
|      | +--rw vrf-name                  -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
|      | +--rw dynamic-host-name?      ipi-isis-types:isis_dynamic_hostanme_t
|      | +--rw disable-adjacency-check? empty
|      | +--rw ignore-lsp-errors?      empty
|      | +--rw lfa-hold-timer?          int32 {feature-list:HAVE_ISIS_LFA}?
|      | +--rw protocol-topology?      empty {feature-
list:HAVE_PROTOCOL_TOPOLOGY}?
|      | +--rw level-capability?        ipi-isis-types:isis_is_type_t
|      | +--rw authentication-send-only? ipi-isis-types:isis_auth_level_type_t
|      | +--rw incremental-spf-levels?  ipi-isis-types:isis_is_type_t
|      | +--rw priority-tag?            uint32 {feature-list:HAVE_WIDE_METRIC}?
|      | +--rw enable-cspf-capability?  empty {feature-list:HAVE_ISIS_CSPF}?
|      | +--rw disable-gr-capability?   empty {feature-list:HAVE_RESTART}?
|      | +--rw enable-bfd-all-interfaces? empty {feature-list:HAVE_BFD}?
|      | +--rw maximum-area-addresses?  uint8
|      | +--rw distribute-bgp-ls?       ipi-isis-types:isis_bgp_ls_type_t
{feature-list:HAVE_BGP_LS}?
|      | +--rw context-name?            string {feature-list:HAVE_SNMP}?
|      +--ro state
|      | +--ro counters
|      | | +--ro system-level-1-adjacency-count?  uint32
|      | | +--ro system-level-2-adjacency-count?  uint32
|      | | +--ro system-total-adjacency-count?    uint32
|      | +--ro next-global-update-level-1?      uint32
|      | +--ro next-global-update-level-2?      uint32
|      | +--ro overload?                         ipi-isis-types:isis_overload_state_t
|      | +--ro instance?                         string
|      | +--ro distance?                         uint8
|      | +--ro vrf-name                          -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
|      | +--ro dynamic-host-name?               ipi-isis-types:isis_dynamic_hostanme_t
|      | +--ro disable-adjacency-check?         empty
|      | +--ro ignore-lsp-errors?               empty
|      | +--ro lfa-hold-timer?                  int32 {feature-list:HAVE_ISIS_LFA}?
|      | +--ro protocol-topology?              empty {feature-
list:HAVE_PROTOCOL_TOPOLOGY}?
|      | +--ro level-capability?                ipi-isis-types:isis_is_type_t
|      | +--ro authentication-send-only?       ipi-isis-types:isis_auth_level_type_t
|      | +--ro incremental-spf-levels?         ipi-isis-types:isis_is_type_t
|      | +--ro priority-tag?                    uint32 {feature-list:HAVE_WIDE_METRIC}?
|      | +--ro enable-cspf-capability?         empty {feature-list:HAVE_ISIS_CSPF}?
|      | +--ro disable-gr-capability?          empty {feature-list:HAVE_RESTART}?
|      | +--ro enable-bfd-all-interfaces?     empty {feature-list:HAVE_BFD}?
|      | +--ro maximum-area-addresses?         uint8
|      | +--ro distribute-bgp-ls?              ipi-isis-types:isis_bgp_ls_type_t
{feature-list:HAVE_BGP_LS}?
|      | +--ro context-name?                    string {feature-list:HAVE_SNMP}?
|      +--ro vrf
|      | +--ro igp-shortcut-lsp* [index]

```

```

| | | +---ro index      -> ../state/index
| | | +---ro state
| | |   +---ro index?          uint32
| | |   +---ro metric?         uint16
| | |   +---ro tunnel-id?      uint32
| | |   +---ro tunnel-endpoint? string
| | |   +---ro lock?           uint16
| | |   +---ro status?         ipi-isis-types:isis_igp_shortcut_lsp_status_t
| +---rw partial-route-computations
| | +---rw partial-route-computation* [minimum-delay maximum-delay]
| | +---rw minimum-delay      -> ../config/minimum-delay
| | +---rw maximum-delay     -> ../config/maximum-delay
| | +---rw config
| | | +---rw minimum-delay?    uint32
| | | +---rw maximum-delay?    uint32
| | | +---ro state
| | |   +---ro minimum-delay?   uint32
| | |   +---ro maximum-delay?   uint32
| +---rw area-authentication
| | +---rw config!
| | | +---rw area-password      string
| | | +---rw sequence-number-packet? ipi-isis-types:isis_snp_t
| | | +---ro state
| | |   +---ro area-password    string
| | |   +---ro sequence-number-packet? ipi-isis-types:isis_snp_t
| +---rw network-entity-title
| | +---rw config
| | | +---rw net*      string
| | | +---ro state
| | |   +---ro net*    string
| +---rw domain-authentication
| | +---rw config!
| | | +---rw domain-password    string
| | | +---rw domain-snp?       ipi-isis-types:isis_snp_t
| | | +---ro state
| | |   +---ro domain-password  string
| | |   +---ro domain-snp?     ipi-isis-types:isis_snp_t
| +---rw metrics
| | +---rw metric* [style level-number] {feature-list:HAVE_WIDE_METRIC}?
| | +---rw style      -> ../config/style
| | +---rw level-number -> ../config/level-number
| | +---rw config
| | | +---rw style?          ipi-isis-types:isis_metric_style_t {feature-
list:HAVE_WIDE_METRIC}?
| | | +---rw level-number?  ipi-isis-types:isis_level3_t {feature-
list:HAVE_WIDE_METRIC}?
| | | +---ro state
| | |   +---ro style?       ipi-isis-types:isis_metric_style_t {feature-
list:HAVE_WIDE_METRIC}?
| | |   +---ro level-number? ipi-isis-types:isis_level3_t {feature-
list:HAVE_WIDE_METRIC}?

```

```

|     +---rw manual-area-addresses
|     |     +---ro state
|     |     |     +---ro address*    string
|     +---rw receive-area-addresses
|     |     +---ro state
|     |     |     +---ro address*    string
|     +---rw timers
|     |     +---rw config
|     |     |     +---rw lsp-refresh-interval?    uint16
|     |     |     +---rw lsp-lifetime-interval?  uint16
|     |     |     +---ro state
|     |     |     |     +---ro lsp-refresh-interval?    uint16
|     |     |     |     +---ro lsp-lifetime-interval?  uint16
|     +---rw traffic-engineering
|     |     +---rw config
|     |     |     +---rw ipv4-router-id?    inet:ipv4-address {feature-list:HAVE_ISIS_TE}?
|     |     |     +---rw ipv6-router-id?    inet:ipv6-address {feature-
list:HAVE_ISIS_TE,feature-list:HAVE_IPV6}?
|     |     |     +---ro state
|     |     |     |     +---ro ipv4-router-id?    inet:ipv4-address {feature-list:HAVE_ISIS_TE}?
|     |     |     |     +---ro ipv6-router-id?    inet:ipv6-address {feature-
list:HAVE_ISIS_TE,feature-list:HAVE_IPV6}?
|     |     +---rw address-family-ipv6
|     |     |     +---rw level-1-into-2-redistributes
|     |     |     |     +---rw redistribute-level-1-into-2* [enable]
|     |     |     |     |     +---rw enable    -> ../config/enable
|     |     |     |     |     +---rw config
|     |     |     |     |     |     +---rw enable?        empty
|     |     |     |     |     |     +---rw level-1-acl?    string
|     |     |     |     |     +---ro state
|     |     |     |     |     |     +---ro enable?        empty
|     |     |     |     |     |     +---ro level-1-acl?    string
|     |     |     +---rw level-2-into-1-redistributes
|     |     |     |     +---rw redistribute-level-2-into-1* [enable]
|     |     |     |     |     +---rw enable    -> ../config/enable
|     |     |     |     |     +---rw config
|     |     |     |     |     |     +---rw enable?        empty
|     |     |     |     |     |     +---rw level-2-acl?    string
|     |     |     |     |     +---ro state
|     |     |     |     |     |     +---ro enable?        empty
|     |     |     |     |     |     +---ro level-2-acl?    string
|     |     +---rw default-route-informations
|     |     |     +---rw default-route-information* [originate]
|     |     |     |     +---rw originate    -> ../config/originate
|     |     |     |     +---rw config
|     |     |     |     |     +---rw originate?        ipi-isis-types:isis_origin_type_t
|     |     |     |     |     +---rw route-map-name?    string
|     |     |     |     |     +---ro state
|     |     |     |     |     |     +---ro originate?        ipi-isis-types:isis_origin_type_t
|     |     |     |     |     |     +---ro route-map-name?    string
|     |     +---rw config!

```

```

|   | |   +---rw afi-name                               ipi-isis-types:isis_address_ipv6_t
|   | |   +---rw administrative-distance?             uint32
|   | |   +---rw disable-adjacency-check?           empty
|   | |   +---ro state
|   | |   |   +---ro afi-name                           ipi-isis-types:isis_address_ipv6_t
|   | |   |   +---ro administrative-distance?         uint32
|   | |   |   +---ro disable-adjacency-check?       empty
|   | |   +---rw redistributions
|   | |   |   +---rw redistribute* [ipv6-protocol-type]
|   | |   |   |   +---rw ipv6-protocol-type          -> ../config/ipv6-protocol-type
|   | |   |   |   +---rw config
|   | |   |   |   |   +---rw ipv6-protocol-type?     ipi-isis-types:isis_redistribute_t
|   | |   |   |   |   +---rw ipv6-level?            ipi-isis-types:isis_is_type3_t
|   | |   |   |   |   +---rw ipv6-metric-value?     uint32
|   | |   |   |   |   +---rw ipv6-metric-type?     ipi-isis-types:isis_metric_t
|   | |   |   |   |   +---rw ipv6-route-map?       string
|   | |   |   |   +---ro state
|   | |   |   |   |   +---ro ipv6-protocol-type?    ipi-isis-types:isis_redistribute_t
|   | |   |   |   |   +---ro ipv6-level?            ipi-isis-types:isis_is_type3_t
|   | |   |   |   |   +---ro ipv6-metric-value?     uint32
|   | |   |   |   |   +---ro ipv6-metric-type?     ipi-isis-types:isis_metric_t
|   | |   |   |   |   +---ro ipv6-route-map?       string
|   | |   +---rw summary-prefixes
|   | |   |   +---rw summary-prefix* [prefix]
|   | |   |   |   +---rw prefix          -> ../config/prefix
|   | |   |   |   +---rw config
|   | |   |   |   |   +---rw prefix?      cml-data-types:cml_ipv6_prefix_t
|   | |   |   |   |   +---rw level        ipi-isis-types:isis_summary_level_t
|   | |   |   |   |   +---rw metric?     uint8
|   | |   |   |   +---ro state
|   | |   |   |   |   +---ro prefix?     cml-data-types:cml_ipv6_prefix_t
|   | |   |   |   |   +---ro level        ipi-isis-types:isis_summary_level_t
|   | |   |   |   |   +---ro metric?     uint8
|   | |   +---rw multi-topologies
|   | |   |   +---rw multi-topology* [level] {feature-list:HAVE_MULTI_TOPOLOGY}?
|   | |   |   |   +---rw level          -> ../config/level
|   | |   |   |   +---rw config
|   | |   |   |   |   +---rw level?     ipi-isis-types:isis_multi_topology_level_type_t
|   | |   |   |   +---ro state
|   | |   |   |   |   +---ro level?     ipi-isis-types:isis_multi_topology_level_type_t
|   | |   +---rw isis-srv6 {feature-list:HAVE_SRV6}?
|   | |   |   +---rw config!
|   | |   |   |   +---rw isisSRv6enable    empty
|   | |   |   +---ro state
|   | |   |   |   +---ro isisSRv6enable    empty
|   | |   +---rw locator-lists
|   | |   |   +---rw locator-list* [isisSRv6LocatorName]
|   | |   |   |   +---rw isisSRv6LocatorName -> ../config/isisSRv6LocatorName
|   | |   |   |   +---rw config
|   | |   |   |   |   +---rw isisSRv6LocatorName?  string

```

```

|         |         +---ro state
|         |         +---ro isisSRv6LocatorName?  string
| +---rw distances
| | +---rw distance* [system-id]
| |   +---rw system-id  -> ../config/system-id
| |   +---rw config
| |     | +---rw system-id?          string
| |     | +---rw value                uint8
| |     | +---rw access-list-name?   string
| |     +---ro state
| |       +---ro system-id?          string
| |       +---ro value                uint8
| |       +---ro access-list-name?   string
| +---rw lsp-over-load
| | +---rw config!
| | | +---rw enabled                  empty
| | | +---rw suppress-type?          ipi-isis-types:isis_suppress_t
| | | +---rw set-bit-on-boot?       ipi-isis-types:isis_onstartup_t
| | +---ro state
| | | +---ro enabled                  empty
| | | +---ro suppress-type?          ipi-isis-types:isis_suppress_t
| | | +---ro set-bit-on-boot?       ipi-isis-types:isis_onstartup_t
| +---rw address-family-ipv4
| | +---ro state
| | | +---ro existence-state?        uint8
| | | +---ro redistribute-update?    int32
| | | +---ro redistribute-timer-value? string
| | +---rw level-1-into-2-redistributes
| | | +---rw redistribute-level-1-into-2* [enable]
| | |   +---rw enable  -> ../config/enable
| | |   +---rw config
| | |     | +---rw enable?            empty
| | |     | +---rw level-1-acl?       string
| | |     +---ro state
| | |       +---ro enable?            empty
| | |       +---ro level-1-acl?       string
| | +---rw level-2-into-1-redistributes
| | | +---rw redistribute-level-2-into-1* [enable]
| | |   +---rw enable  -> ../config/enable
| | |   +---rw config
| | |     | +---rw enable?            empty
| | |     | +---rw level-2-acl?       string
| | |     +---ro state
| | |       +---ro enable?            empty
| | |       +---ro level-2-acl?       string
| | +---rw default-route-informations
| | | +---rw default-route-information* [originate]
| | |   +---rw originate  -> ../config/originate
| | |   +---rw config
| | |     | +---rw originate?         ipi-isis-types:isis_origin_type_t

```

```
| | | | +---rw route-map-name? string
| | | | +---ro state
| | | |   +---ro originate? ipi-isis-types:isis_origin_type_t
| | | |   +---ro route-map-name? string
| | +---rw redistributions
| | | +---rw redistribute* [protocol-type]
| | | | +---rw protocol-type -> ../config/protocol-type
| | | | +---rw config
| | | | | +---rw protocol-type? ipi-isis-types:isis_redistribute_t
| | | | | +---rw level? ipi-isis-types:isis_is_type3_t
| | | | | +---rw metric-value? uint32
| | | | | +---rw metric-type? ipi-isis-types:isis_metric_t
| | | | | +---rw route-map? string
| | | | +---ro state
| | | | | +---ro protocol-type? ipi-isis-types:isis_redistribute_t
| | | | | +---ro level? ipi-isis-types:isis_is_type3_t
| | | | | +---ro metric-value? uint32
| | | | | +---ro metric-type? ipi-isis-types:isis_metric_t
| | | | | +---ro route-map? string
| | +---rw summary-addresses
| | | +---rw summary-address* [prefix]
| | | | +---rw prefix -> ../config/prefix
| | | | +---rw config
| | | | | +---rw prefix? cml-data-types:cml_ipv4_prefix_t
| | | | | +---rw level ipi-isis-types:isis_summary_level_t
| | | | | +---rw metric? uint8
| | | | +---ro state
| | | | | +---ro prefix? cml-data-types:cml_ipv4_prefix_t
| | | | | +---ro level ipi-isis-types:isis_summary_level_t
| | | | | +---ro metric? uint8
| | +---rw redistribute-isis-instances
| | | +---rw redistribute-isis-instance* [id]
| | | | +---rw id -> ../config/id
| | | | +---rw config
| | | | | +---rw id? string
| | | | | +---rw level? ipi-isis-types:isis_is_type3_t
| | | | | +---rw metric-value? uint32
| | | | | +---rw metric-type? ipi-isis-types:isis_metric_t
| | | | | +---rw route-map? string
| | | | +---ro state
| | | | | +---ro id? string
| | | | | +---ro level? ipi-isis-types:isis_is_type3_t
| | | | | +---ro metric-value? uint32
| | | | | +---ro metric-type? ipi-isis-types:isis_metric_t
| | | | | +---ro route-map? string
| +---rw passive-interfaces
| | +---rw config
| | | +---rw passive-interface-all? empty
| | +---ro state
| | | +---ro passive-interface-all? empty
```

```

|   |   +---rw passive-interface* [name]
|   |   |   +---rw name          -> ../config/name
|   |   |   +---rw config
|   |   |   |   +---rw name?     -> /ipi-interface:interfaces/interface/name
|   |   |   +---ro state
|   |   |       +---ro name?     -> /ipi-interface:interfaces/interface/name
|   |   +---rw disable-passive-interfaces
|   |       +---rw disable-passive-interface* [name]
|   |           +---rw name          -> ../config/name
|   |           +---rw config
|   |           |   +---rw name?     -> /ipi-interface:interfaces/interface/name
|   |           +---ro state
|   |               +---ro name?     -> /ipi-interface:interfaces/interface/name
| +---rw microloop-avoidances {feature-list:HAVE_ISIS_LFA_OR_HAVE_ISIS_TI_LFA}?
|   +---rw microloop-avoidance* [level-type]
|       +---rw level-type      -> ../config/level-type
|       +---rw config
|           |   +---rw hold-timer?   uint8
|           |   +---rw max-fib?      uint8
|           |   +---rw level-type?   ipi-isis-types:isis_level2_t
|           |   +---rw enable?       empty
|           +---ro state
|               +---ro hold-timer?   uint8
|               +---ro max-fib?      uint8
|               +---ro level-type?   ipi-isis-types:isis_level2_t
|               +---ro enable?       empty
| +---rw mpls-traffic-engg
|   +---rw config
|       |   +---rw enable-level-1?   empty {feature-list:HAVE_ISIS_TE}?
|       |   +---rw enable-level-2?   empty {feature-list:HAVE_ISIS_TE}?
|       +---ro state
|           +---ro enable-level-1?   empty {feature-list:HAVE_ISIS_TE}?
|           +---ro enable-level-2?   empty {feature-list:HAVE_ISIS_TE}?
| +---ro level-runtime* [type]
|   +---ro type                  -> ../state/type
|   +---ro lspdb* [lsp-identifier]
|       |   +---ro lsp-identifier    -> ../state/lsp-identifier
|       |   +---ro tlvs* [index]
|       |       |   +---ro index                -> ../state/index
|       |       |   +---ro is-neighbors* [system-id]
|       |       |       |   +---ro system-id    -> ../state/system-id
|       |       |       +---ro state
|       |       |           +---ro system-id?   string
|       |       |           +---ro metric?     uint32
|       |       +---ro es-neighbors* [system-id]
|       |           |   +---ro system-id    -> ../state/system-id
|       |           +---ro state
|       |               +---ro system-id?   string
|       |               +---ro metric?     uint32
|       +---ro ip-internal-reachability-information* [prefix]

```

```

| | | | | +--ro prefix -> ../state/prefix
| | | | | +--ro state
| | | | |   +--ro prefix? cml-data-types:cml_line_t
| | | | |   +--ro metric? string
| | | | | +--ro ip-external-reachability-information* [prefix]
| | | | |   +--ro prefix -> ../state/prefix
| | | | |   +--ro state
| | | | |     +--ro prefix? cml-data-types:cml_line_t
| | | | |     +--ro metric? string
| | | | | +--ro extended-is-reachability* [extended-is-index] {feature-
list:HAVE_WIDE_METRIC}?
| | | | |   +--ro extended-is-index -> ../state/extended-is-index
| | | | |   +--ro subtlv* [subtlv-index]
| | | | |     +--ro subtlv-index -> ../state/subtlv-index
| | | | |     +--ro state
| | | | |       +--ro subtlv-index? uint16
| | | | | +--ro protocols-supported {feature-
list:HAVE_PROTOCOL_TOPOLOGY}?
| | | | |   +--ro state
| | | | |     +--ro nlp-id* ipi-isis-types:isis_level_proto_t
| | | | |   +--ro admin-group-info {feature-list:HAVE_ISIS_TE}?
| | | | |     +--ro state
| | | | |       +--ro admin-group? string
| | | | |       +--ro mismatch-length? uint16
| | | | |   +--ro ipv4-interface-address {feature-list:HAVE_ISIS_TE}?
| | | | |     +--ro state
| | | | |       +--ro address? inet:ipv4-address
| | | | |       +--ro mismatch-length? uint16
| | | | |   +--ro ipv4-neighbor-address {feature-list:HAVE_ISIS_TE}?
| | | | |     +--ro state
| | | | |       +--ro address? inet:ipv4-address
| | | | |       +--ro mismatch-length? uint16
| | | | |   +--ro ipv6-interface-address {feature-
list:HAVE_ISIS_TE,feature-list:HAVE_IPV6}?
| | | | |     +--ro state
| | | | |       +--ro address? inet:ipv6-address
| | | | |       +--ro mismatch-length? uint16
| | | | |   +--ro ipv6-neighbor-address {feature-list:HAVE_ISIS_TE,feature-
list:HAVE_IPV6}?
| | | | |     +--ro state
| | | | |       +--ro address? inet:ipv6-address
| | | | |       +--ro mismatch-length? uint16
| | | | |   +--ro max-link-bandwidth {feature-list:HAVE_ISIS_TE}?
| | | | |     +--ro state
| | | | |       +--ro bandwidth? string
| | | | |       +--ro mismatch-length? uint16
| | | | |   +--ro max-reserve-link-bandwidth {feature-list:HAVE_ISIS_TE}?
| | | | |     +--ro state
| | | | |       +--ro bandwidth? ipi-isis-
types:isis_ieee_float32_t
| | | | |       +--ro mismatch-length? uint16

```



```

| | | | | | | | +--ro state
| | | | | | | |   +--ro system-id?          string
| | | | | | | |   +--ro value?              uint32
| | | | | | | |   +--ro flag?                cml-data-types:cml_line_t
| | | | | | | |   +--ro mismatch-length?    uint16
| | | | | | | | +--ro link-ids {feature-list:HAVE_GMPLS}?
| | | | | | | | | +--ro state
| | | | | | | | |   +--ro local?              uint32
| | | | | | | | |   +--ro remote?            uint32
| | | | | | | | |   +--ro mismatch-length?    uint16
| | | | | | | | +--ro link-protection-type {feature-list:HAVE_GMPLS}?
| | | | | | | | | +--ro state
| | | | | | | | |   +--ro type?                string
| | | | | | | | |   +--ro mismatch-length?    uint16
| | | | | | | | +--ro link-switch-capability {feature-list:HAVE_GMPLS}?
| | | | | | | | | +--ro state
| | | | | | | | |   +--ro type?                string
| | | | | | | | |   +--ro encoding-type?       string
| | | | | | | | |   +--ro max-lsp-bandwidth-at-priority? ipi-isis-
types:isis_ieee_float32_t
| | | | | | | | |   +--ro min-lsp-bandwidth?     ipi-isis-
types:isis_ieee_float32_t
| | | | | | | | |   +--ro interface-mtu?         string
| | | | | | | | |   +--ro sonet-sdh-indication?     string
| | | | | | | | |   +--ro mismatch-length?       uint16
| | | | | | | | +--ro endx-sid {feature-list:HAVE_SRV6}?
| | | | | | | | | +--ro state
| | | | | | | | |   +--ro endx-sid?           inet:ipv6-address
| | | | | | | | |   +--ro endx-algo?           uint32
| | | | | | | | |   +--ro endx-flags?           uint32
| | | | | | | | |   +--ro endx-behavior?        string
| | | | | | | | |   +--ro endx-flavor?         uint32
| | | | | | | | |   +--ro endx-weight?         uint32
| | | | | | | | |   +--ro mismatch-length?    uint16
| | | | | | | | +--ro lan-endx-sid {feature-list:HAVE_SRV6}?
| | | | | | | | | +--ro state
| | | | | | | | |   +--ro lan-endx-sid?         inet:ipv6-address
| | | | | | | | |   +--ro lan-endx-behavior?       string
| | | | | | | | |   +--ro lan-endx-flavor?       uint32
| | | | | | | | |   +--ro lan-endx-sysid?       string
| | | | | | | | |   +--ro lan-endx-algo?       uint32
| | | | | | | | |   +--ro lan-endx-weight?     uint32
| | | | | | | | |   +--ro mismatch-length?     uint16
| | | | | | | | +--ro state
| | | | | | | | | +--ro extended-is-index?   uint32
| | | | | | | | | +--ro system-id?           string
| | | | | | | | | +--ro metric?             uint32
| | | | | | | | +--ro extended-ipv4-reachability* [ipv4-reach-index] {feature-
list:HAVE_WIDE_METRIC}?
| | | | | | | | | +--ro ipv4-reach-index    -> ../state/ipv4-reach-index
| | | | | | | | | +--ro subtlv* [stlv-reach-index]

```

```

| | | | | | +--ro stlv-reach-index -> ../state/stlv-reach-index
| | | | | | +--ro state
| | | | | | | +--ro stlv-reach-index? uint16
| | | | | | +--ro admin-tag-info
| | | | | | | +--ro state
| | | | | | | +--ro admin-tag? uint32
| | | | | | | +--ro mismatch-length? uint16
| | | | | | +--ro prefix-sid {feature-list:HAVE_ISIS_SR}?
| | | | | | | +--ro state
| | | | | | | +--ro value? uint32
| | | | | | | +--ro rnpev-flags? cml-data-types:cml_line_t
| | | | | | | +--ro mismatch-length? uint16
| | | | | | +--ro state
| | | | | | | +--ro ipv4-reach-index? uint32
| | | | | | +--ro prefix? cml-data-types:cml_ipv4_addr_prefix_t
| | | | | | +--ro metric? uint32
| | | | | | +--ro ipv6-reachability* [ipv6-reach-index] {feature-
list:HAVE_IPV6}?
| | | | | | +--ro ipv6-reach-index -> ../state/ipv6-reach-index
| | | | | | +--ro subtlv* [stlv-reach-index]
| | | | | | | +--ro stlv-reach-index -> ../state/stlv-reach-index
| | | | | | | +--ro state
| | | | | | | | +--ro stlv-reach-index? uint16
| | | | | | | +--ro admin-tag-info
| | | | | | | | +--ro state
| | | | | | | | +--ro admin-tag? uint32
| | | | | | | | +--ro mismatch-length? uint16
| | | | | | | +--ro prefix-sid {feature-list:HAVE_ISIS_SR}?
| | | | | | | | +--ro state
| | | | | | | | +--ro value? uint32
| | | | | | | | +--ro rnpev-flags? cml-data-types:cml_line_t
| | | | | | | | +--ro mismatch-length? uint16
| | | | | | | +--ro state
| | | | | | | +--ro ipv6-reach-index? uint32
| | | | | | | +--ro prefix? cml-data-types:cml_ipv6_prefix_t
| | | | | | | +--ro metric? cml-data-types:cml_line_t
| | | | | | | +--ro up-down? boolean
| | | | | | +--ro multi-topology* [id] {feature-list:HAVE_MULTI_TOPOLOGY}?
| | | | | | | +--ro id -> ../state/id
| | | | | | | +--ro state
| | | | | | | | +--ro id? string
| | | | | | | +--ro multi-topology-is-reachability* [multi-is-index] {feature-
list:HAVE_MULTI_TOPOLOGY}?
| | | | | | | +--ro multi-is-index -> ../state/multi-is-index
| | | | | | | +--ro subtlv* [subtlv-index]
| | | | | | | | +--ro subtlv-index -> ../state/subtlv-index
| | | | | | | | +--ro state
| | | | | | | | +--ro subtlv-index? uint16
| | | | | | | +--ro protocols-supported {feature-
list:HAVE_PROTOCOL_TOPOLOGY}?
| | | | | | | | +--ro state

```



```

types:isis_ieee_float32_t      +--ro max-lsp-bandwidth-at-priority?  ipi-isis-
types:isis_ieee_float32_t      +--ro min-lsp-bandwidth?                ipi-isis-
                                +--ro interface-mtu?                          string
                                +--ro sonet-sdh-indication?                     string
                                +--ro mismatch-length?                          uint16
                                +--ro state
                                +--ro multi-is-index?      uint32
                                +--ro system-id?           string
                                +--ro metric?              uint32
                                +--ro multi-topology-ipv6-reachability* [id] {feature-
list:HAVE_MULTI_TOPOLOGY,feature-list:HAVE_IPV6}?
                                +--ro id                  -> ../state/id
                                +--ro subtlv* [stlv-reach-index]
                                | +--ro stlv-reach-index   -> ../state/stlv-reach-index
                                | +--ro state
                                | | +--ro stlv-reach-index? uint16
                                | +--ro admin-tag-info
                                | | +--ro state
                                | | +--ro admin-tag?       uint32
                                | | +--ro mismatch-length? uint16
                                | +--ro prefix-sid {feature-list:HAVE_ISIS_SR}?
                                | +--ro state
                                | +--ro value?             uint32
                                | +--ro rnpev-flags?      cml-data-types:cml_line_t
                                | +--ro mismatch-length?   uint16
                                +--ro state
                                +--ro prefix?      inet:ipv6-address
                                +--ro metric?     string
                                +--ro up-down?    boolean
                                +--ro id?        uint16
                                +--ro multi-topology-ipv4-reachability* [id] {feature-
list:HAVE_MULTI_TOPOLOGY}?
                                +--ro id                  -> ../state/id
                                +--ro subtlv* [stlv-reach-index]
                                | +--ro stlv-reach-index   -> ../state/stlv-reach-index
                                | +--ro state
                                | | +--ro stlv-reach-index? uint16
                                | +--ro admin-tag-info
                                | | +--ro state
                                | | +--ro admin-tag?       uint32
                                | | +--ro mismatch-length? uint16
                                | +--ro prefix-sid {feature-list:HAVE_ISIS_SR}?
                                | +--ro state
                                | +--ro value?             uint32
                                | +--ro rnpev-flags?      cml-data-types:cml_line_t
                                | +--ro mismatch-length?   uint16
                                +--ro state
                                +--ro prefix?      inet:ipv4-address
                                +--ro metric?     uint32

```



```

| | | | | | +--ro segment-routing {feature-list:HAVE_ISIS_SR}?
| | | | | | | +--ro state
| | | | | | | | +--ro range?          uint32
| | | | | | | | +--ro sid?            uint32
| | | | | | | | +--ro mismatch-length?  uint16
| | | | | | | +--ro segment-routing-algorithm {feature-list:HAVE_ISIS_SR}?
| | | | | | | | +--ro state
| | | | | | | | | +--ro algorithm-type?  ipi-isis-types:isis_spf_t
| | | | | | | | | +--ro mismatch-length?  uint16
| | | | | | | +--ro segment-routing-mapping-server-preference {feature-
list:HAVE_ISIS_SR}?
| | | | | | | | +--ro state
| | | | | | | | | +--ro preference?      uint32
| | | | | | | | | +--ro mismatch-length?  uint16
| | | | | | | +--ro segment-routing-v6 {feature-list:HAVE_SRV6}?
| | | | | | | | +--ro state
| | | | | | | | | +--ro srv6-flags?      uint32
| | | | | | | | | +--ro mismatch-length?  uint16
| | | | | | | +--ro max-sid-depth {feature-list:HAVE_SRV6}?
| | | | | | | | +--ro state
| | | | | | | | | +--ro segments-left?    uint32
| | | | | | | | | +--ro end-pop?          uint32
| | | | | | | | | +--ro h-encaps?          uint32
| | | | | | | | | +--ro decap-sids?       uint32
| | | | | | | | | +--ro mismatch-length?  uint16
| | | | | | | | +--ro state
| | | | | | | | | +--ro router-id?    inet:ipv4-address
| | | | | | | +--ro srv6-locator {feature-list:HAVE_SRV6}?
| | | | | | | | +--ro stlv* [stlv-index stlv-endpoint-function]
| | | | | | | | | +--ro stlv-index      -> ../state/stlv-index
| | | | | | | | | +--ro stlv-endpoint-function -> ../state/stlv-endpoint-
function
| | | | | | | | +--ro state
| | | | | | | | | +--ro stlv-index?      uint16
| | | | | | | | | +--ro stlv-endpoint-function?  uint16
| | | | | | | +--ro srv6-end-sid {feature-list:HAVE_SRV6}?
| | | | | | | | +--ro state
| | | | | | | | | +--ro end-sid?        inet:ipv6-address
| | | | | | | | | +--ro sid-flags?      uint32
| | | | | | | | | +--ro end-point-behavior?  string
| | | | | | | | | +--ro mismatch-length?  uint16
| | | | | | | | +--ro state
| | | | | | | | | +--ro locator-algorithm?  uint32
| | | | | | | | | +--ro locator-flag?      uint32
| | | | | | | | | +--ro locator-metric?   uint32
| | | | | | | | | +--ro locator-prefix?   cml-data-types:cml_ipv6_prefix_t
| | | | | | | +--ro state
| | | | | | | | +--ro lsp-identifier?    string
| | | | | | | | +--ro is-self-lsp?      string
| | | | | | | | +--ro checksum?        string
| | | | | | | | +--ro remaining-lifetime?  uint16

```



```

|     | |     +---ro flags?                uint8
|     | |     +---ro partition-repair?     boolean
|     | |     +---ro over-loaded?         boolean
|     | |     +---ro sequence-number?     string
|     | |     +---ro pdu-length?         uint32
|     | +---ro protocol-data* [index]
|     | |     +---ro index                uint8
|     | |     +---ro vertex* [destination-system-id]
|     | | |     +---ro destination-system-id -> ../state/destination-system-id
|     | | |     +---ro vertex-nexthop* [nexthop-interface nexthop-system-id]
|     | | | |     +---ro nexthop-interface -> ../state/nexthop-interface
|     | | | |     +---ro nexthop-system-id -> ../state/nexthop-system-id
|     | | | |     +---ro state
|     | | | | |     +---ro nexthop-interface? string
|     | | | | |     +---ro nexthop-system-id? string
|     | | | | |     +---ro snpa-mac-address? cml-data-types:cml_mac_addr_t
|     | | |     +---ro state
|     | | |     +---ro distance?          uint32
|     | | |     +---ro destination-system-id? string
|     | +---ro state
|     | |     +---ro counters
|     | | |     +---ro authentication-type-fails? uint32
|     | | |     +---ro authentication-fails?     uint32
|     | | |     +---ro corrupted-lsps?          uint32
|     | | |     +---ro database-overloads?      uint32
|     | | |     +---ro manual-address-drop-from-areas? uint32
|     | | |     +---ro attempt-to-exceed-maximum-sequence-numbers? uint32
|     | | |     +---ro sequence-number-skips?   uint32
|     | | |     +---ro own-lsp-purges?         uint32
|     | | |     +---ro lsp-sourced?           uint32
|     | | |     +---ro maximum-area-address-mismatches? uint32
|     | | |     +---ro id-length-mismatch?     uint32
|     | | |     +---ro partition-changes?      uint32
|     | | |     +---ro spf-runs?              uint32
|     | | |     +---ro partial-route-calculation-count? uint32
|     | | |     +---ro lan-designated-is-changes? uint32
|     | |     +---ro type?                    ipi-isis-types:isis_level2_t
|     | |     +---ro topology-type?          uint8
| +---rw spf-levels
| |     +---rw spf-level* [level]
| | |     +---rw level                        -> ../config/level
| | |     +---rw spf-delays
| | | |     +---rw spf-delay* [spf-min-delay spf-max-delay]
| | | | |     +---rw spf-min-delay          -> ../config/spf-min-delay
| | | | |     +---rw spf-max-delay          -> ../config/spf-max-delay
| | | | |     +---rw config
| | | | | |     +---rw spf-min-delay?      uint32
| | | | | |     +---rw spf-max-delay?      uint32
| | | |     +---ro state
| | | |     +---ro spf-min-delay?          uint32

```

```
| | | +---ro spf-max-delay? uint32
| | +---rw config
| | | +---rw level? ipi-isis-types:isis_level3_t
| | +---ro state
| | | +---ro level? ipi-isis-types:isis_level3_t
+---rw levels
| | +---rw level* [type]
| | | +---rw type -> ../config/type
| | | +---rw config
| | | | +---rw type? ipi-isis-types:isis_level3_t
| | | | +---rw wait-timer? uint16
| | | | +---rw restart-timer? uint16
| | | | +---rw lsp-max-wait-interval? uint32
| | | | +---rw lsp-mtu-size? uint16
| | | +---ro state
| | | | +---ro type? ipi-isis-types:isis_level3_t
| | | | +---ro wait-timer? uint16
| | | | +---ro restart-timer? uint16
| | | | +---ro lsp-max-wait-interval? uint32
| | | | +---ro lsp-mtu-size? uint16
| | | +---rw authentication
| | | | +---rw config!
| | | | | +---rw key-chain? string
| | | | | +---rw mode ipi-isis-types:isis_auth_mode_t
| | | | +---ro state
| | | | | +---ro key-chain? string
| | | | | +---ro mode ipi-isis-types:isis_auth_mode_t
+---ro cspf {feature-list:HAVE_ISIS_CSPF}?
| | +---ro lsp* [setup-priority]
| | | +---ro setup-priority -> ../state/setup-priority
| | | +---ro lsp-status* [lsp-id]
| | | | +---ro lsp-id -> ../state/lsp-id
| | | | +---ro path-constraint* [index]
| | | | | +---ro index -> ../state/index
| | | | | +---ro state
| | | | | | +---ro index? uint32
| | | | | | +---ro ip-address? inet:ipv4-address
| | | | | | +---ro path-type? ipi-isis-types:isis_cspf_path_type_t
| | | | | +---ro exclude-path-constraint* [ip-address]
| | | | | | +---ro ip-address -> ../state/ip-address
| | | | | | +---ro state
| | | | | | | +---ro ip-address? inet:ipv4-address
| | | | | | | +---ro interface-id? uint32 {feature-list:HAVE_GMPLS}?
| | | | | | +---ro type? ipi-isis-types:isis_cspf_constraint_type_t
| | | | | +---ro path-computed-ero* [local-ip-address]
| | | | | | +---ro local-ip-address -> ../state/local-ip-address
| | | | | | +---ro state
| | | | | | | +---ro local-ip-address? inet:ipv4-address
| | | | | | | +---ro remote-ip-address? inet:ipv4-address
| | | | +---ro state
```

```

|         |         |         +---ro lsp-id?                uint32
|         |         |         +---ro metric?              uint32
|         |         |         +---ro retry-interval?       uint16
|         |         |         +---ro retry-limit?         uint16
|         |         |         +---ro tunnel-egress-ip?     inet:ipv4-address
|         |         |         +---ro tunnel-ingress-ip?    inet:ipv4-address
|         |         |         +---ro extended-tunnel-id?   inet:ipv4-address
|         |         |         +---ro status?              string
|         |         |         +---ro client-id?           uint8
|         |         |         +---ro hop-limit?           int16
|         |         |         +---ro include-mask?        int8
|         |         |         +---ro exclude-mask?        int8
|         |         |         +---ro hold-priority?       uint8
|         |         |         +---ro retry-count?         uint16
|         |         |         +---ro bandwidth?          string
|         |         |         +---ro trunk-id?            uint32
|         |         |         +---ro lsp-type?            ipi-isis-types:isis_cspf_lsp_type_t
|         |         +---ro state
|         |             +---ro setup-priority?    int8
|         +---ro ipv4-lfa-route* [destination-prefix]
|         |         +---ro destination-prefix    -> ../state/destination-prefix
|         |         +---ro route-nexthop* [primary-nexthop nexthop-type]
|         |         |         +---ro primary-nexthop    -> ../state/primary-nexthop
|         |         |         +---ro nexthop-type      -> ../state/nexthop-type
|         |         |         +---ro state
|         |         |             +---ro primary-nexthop?    inet:ipv4-address
|         |         |             +---ro nexthop-type?      ipi-isis-
types:isis_lfa_nexthop_type_t
|         |         |             +---ro primary-nexthop-interface-name?    string
|         |         |             +---ro remote-router-id?    inet:ipv4-address
|         |         |             +---ro lfa-nexthop?          inet:ipv4-address
|         |         |             +---ro lfa-nexthop-interface-name?    string
|         |         |             +---ro lfa-path-metric?      uint32
|         |         |             +---ro protection-provided?  cml-data-types:cml_line_t
|         |         +---ro state
|         |             +---ro destination-prefix?    cml-data-types:cml_ipv4_addr_prefix_t
|         |             +---ro destination-path-type?    string
|         +---ro ipv6-lfa-route* [destination-prefix]
|         |         +---ro destination-prefix    -> ../state/destination-prefix
|         |         +---ro route-nexthop* [primary-nexthop]
|         |         |         +---ro primary-nexthop    -> ../state/primary-nexthop
|         |         |         +---ro state
|         |         |             +---ro primary-nexthop?    inet:ipv6-address
|         |         |             +---ro primary-nexthop-interface-name?    string
|         |         |             +---ro lfa-nexthop?          inet:ipv6-address
|         |         |             +---ro lfa-nexthop-interface-name?    string
|         |         |             +---ro lfa-path-metric?      uint32
|         |         |             +---ro protection-provided?  string
|         |         +---ro state
|         |             +---ro destination-prefix?    cml-data-types:cml_ipv6_prefix_t
|         |             +---ro destination-path-type?    string

```

```

|      +---rw fast-reroute-levels
|      |      +---rw fast-reroute* [level-type]
|      |      |      +---rw level-type          -> ../config/level-type
|      |      |      +---rw config
|      |      |      |      +---rw level-type?          ipi-isis-types:isis_level2_t
|      |      |      |      +---rw remote-lfa-protocol* ipi-isis-types:isis_lfa_level_proto_t
{feature-list:HAVE_LDPPD,feature-list:HAVE_ISIS_LFA}?
|      |      |      +---ro state
|      |      |      |      +---ro level-type?          ipi-isis-types:isis_level2_t
|      |      |      |      +---ro remote-lfa-protocol* ipi-isis-types:isis_lfa_level_proto_t
{feature-list:HAVE_LDPPD,feature-list:HAVE_ISIS_LFA}?
|      |      |      +---rw route-maps
|      |      |      |      +---rw route-map* [protocol] {feature-list:HAVE_ISIS_LFA}?
|      |      |      |      |      +---rw protocol      -> ../config/protocol
|      |      |      |      |      +---rw config
|      |      |      |      |      |      +---rw protocol?          ipi-isis-
types:isis_lfa_level_proto_t
|      |      |      |      |      |      +---rw name?          string
|      |      |      |      |      |      +---rw enable-all-prefixes? ipi-isis-types:isis_frr_enum_t
|      |      |      |      |      |      +---ro state
|      |      |      |      |      |      +---ro protocol?          ipi-isis-
types:isis_lfa_level_proto_t
|      |      |      |      |      |      +---ro name?          string
|      |      |      |      |      |      +---ro enable-all-prefixes? ipi-isis-types:isis_frr_enum_t
|      |      |      |      +---rw ti-lfas
|      |      |      |      |      +---rw ti-lfa* [protocol] {feature-list:HAVE_ISIS_TI_LFA}?
|      |      |      |      |      |      +---rw protocol      -> ../config/protocol
|      |      |      |      |      |      +---rw config
|      |      |      |      |      |      |      +---rw protocol? ipi-isis-types:isis_lfa_level_proto_t
|      |      |      |      |      |      +---ro state
|      |      |      |      |      |      +---ro protocol? ipi-isis-types:isis_lfa_level_proto_t
|      |      |      |      +---rw protocols
|      |      |      |      |      +---rw protocol* [lfa-protocol preference-value] {feature-
list:HAVE_ISIS_LFA}?
|      |      |      |      |      |      +---rw lfa-protocol      -> ../config/lfa-protocol
|      |      |      |      |      |      +---rw preference-value  -> ../config/preference-value
|      |      |      |      |      |      +---rw config
|      |      |      |      |      |      |      +---rw lfa-protocol? ipi-isis-types:isis_lfa_level_proto_t
|      |      |      |      |      |      |      +---rw preference-value? ipi-isis-
types:isis_frr_tie_break_val_t
|      |      |      |      |      |      |      +---rw preference-index  uint32
|      |      |      |      |      |      |      +---ro state
|      |      |      |      |      |      |      +---ro lfa-protocol? ipi-isis-types:isis_lfa_level_proto_t
|      |      |      |      |      |      |      +---ro preference-value? ipi-isis-
types:isis_frr_tie_break_val_t
|      |      |      |      |      |      |      +---ro preference-index  uint32
|      |      |      |      +---rw ipv4-tilfa-routes
|      |      |      |      |      +---ro ipv4-tilfa-route* [destination-prefix]
|      |      |      |      |      |      +---ro destination-prefix  -> ../state/destination-prefix
|      |      |      |      |      |      +---ro state
|      |      |      |      |      |      +---ro destination-prefix?  inet:ipv4-address
|      |      |      |      |      |      +---ro path-type?          ipi-isis-types:isis_path_type_t

```

```

|         |         |         +---ro nexthops
|         |         |         |   +---ro nexthop* [primary-nexthop]
|         |         |         |     +---ro primary-nexthop   -> ../state/primary-nexthop
|         |         |         |     +---ro state
|         |         |         |       +---ro primary-nexthop?       inet:ipv4-address
|         |         |         |       +---ro protection-type?       ipi-isis-
types:isis_tilfa_protection_type_t
|         |         |         |       +---ro backup-nexthop?       inet:ipv4-address
|         |         |         |       +---ro pq-node-router-id?     inet:ipv4-address
|         |         |         |       +---ro pq-trunk-id?           uint32
|         |         |         |       +---ro primary-outgoing-label? uint32
|         |         |         |       +---ro primary-incoming-label? uint32
|         |         |         |       +---ro backup-outgoing-label?  uint32
|         |         |         |       +---ro backup-outgoing-interface? string
|         |         |         +---ro pq-trunks
|         |         |         |   +---ro pq-trunk* [trunk-id]
|         |         |         |     +---ro trunk-id   -> ../state/trunk-id
|         |         |         |     +---ro state
|         |         |         |       +---ro trunk-id?       uint32
|         |         |         |       +---ro trunk-name?     string
|         |         |         |       +---ro nexthop?        inet:ipv4-address
|         |         |         |       +---ro outgoing-label?  uint32
|         |         +---rw tilfa-pq-nodes
|         |         |   +---rw circuit-levels
|         |         |     +---ro circuit-level* [level]
|         |         |       +---ro level   -> ../state/level
|         |         |       +---ro state
|         |         |       | +---ro level?   ipi-isis-types:isis_level2_t
|         |         |     +---ro vertices
|         |         |       +---ro vertex* [destination-vertex]
|         |         |       +---ro destination-vertex   -> ../state/destination-vertex
|         |         |       +---ro state
|         |         |       | +---ro destination-vertex? string
|         |         |     +---ro interfaces
|         |         |       +---ro interface* [name]
|         |         |         +---ro name   -> ../state/name
|         |         |         +---ro state
|         |         |         | +---ro name?  string
|         |         |         +---ro link-protection
|         |         |         | +---ro state
|         |         |         |   +---ro pnodes*   string
|         |         |         |   +---ro qnodes*   string
|         |         |         |   +---ro pq-node?   string
|         |         |         |   +---ro q-node-disjoint? string
|         |         |         +---ro node-protection
|         |         |           +---ro state
|         |         |             +---ro pnodes*   string
|         |         |             +---ro qnodes*   string
|         |         |             +---ro pq-node?   string
|         |         |             +---ro q-node-disjoint? string
|         +---ro segment-routing-capability* [advertising-router-ip]

```

```
| | +---ro advertising-router-ip    -> ../state/advertising-router-ip
| | +---ro range-info* [index]
| | | +---ro index    -> ../state/index
| | | +---ro state
| | |   +---ro start?   uint32
| | |   +---ro end?     uint32
| | |   +---ro index?   uint32
| | +---ro state
| |   +---ro advertising-router-ip?   inet:ipv4-address
| |   +---ro algorithm?               ipi-isis-types:isis_spf_t
| |   +---ro mapping-server-preference? uint32
| |   +---ro total-sid-count?         uint32
| |   +---ro sid-range-list-count?    uint8
+---ro segment-routing-mapping-server-ipv4* [type]
| +---ro type    -> ../state/type
| +---ro ipv4-table* [prefix-length]
| | +---ro prefix-length    -> ../state/prefix-length
| | +---ro entry* [index]
| | | +---ro index    -> ../state/index
| | | +---ro state
| | | | +---ro index?           uint32
| | | | +---ro label-options?   uint8
| | | | +---ro system-id?       string
| | | | +---ro status?          string
| | | | +---ro preference?      uint8
| | | | +---ro attached?        string
| | | | +---ro last-system-id-index? uint32
| | | | +---ro last-prefix?     cml-data-types:cml_ip_prefix_addr_t
| | | | +---ro prefix-range?    uint32
| | | | +---ro entry-prefix?    cml-data-types:cml_ip_prefix_addr_t
| | | +---ro state
| | |   +---ro prefix-length?   uint32
| | +---ro state
| |   +---ro type?             ipi-isis-types:isis_srms_type_t
| |   +---ro entry-count?      uint32
| |   +---ro conflict-resolution-policy? string
+---ro segment-routing-mapping-server-ipv6* [type]
| +---ro type    -> ../state/type
| +---ro ipv6-table* [prefix-length]
| | +---ro prefix-length    -> ../state/prefix-length
| | +---ro entry* [index]
| | | +---ro index    -> ../state/index
| | | +---ro state
| | | | +---ro index?           uint32
| | | | +---ro label-options?   uint8
| | | | +---ro system-id?       string
| | | | +---ro status?          string
| | | | +---ro preference?      uint8
| | | | +---ro attached?        string
| | | | +---ro last-system-id-index? uint32
```

```

|   |   |   +---ro last-prefix?           cml-data-types:cml_ip_prefix_addr_t
|   |   |   +---ro prefix-range?         uint32
|   |   |   +---ro entry-prefix?         cml-data-types:cml_ip_prefix_addr_t
|   |   |   +---ro state
|   |   |   +---ro prefix-length?    uint32
|   |   |   +---ro state
|   |   |   +---ro type?               ipi-isis-types:isis_srms_type_t
|   |   |   +---ro entry-count?         uint32
|   |   |   +---ro conflict-resolution-policy? string
|   +---rw segment-routing
|       +---rw config!
|           | +---rw enabled             empty {feature-list:HAVE_ISIS_SR}?
|           | +---rw advertise-local?    empty {feature-list:HAVE_ISIS_SR}?
|           | +---rw receive-disable?    empty {feature-list:HAVE_ISIS_SR}?
|           | +---rw entropy-capability? empty {feature-list:HAVE_ISIS_SR}?
|           +---ro state
|               | +---ro enabled         empty {feature-list:HAVE_ISIS_SR}?
|               | +---ro advertise-local? empty {feature-list:HAVE_ISIS_SR}?
|               | +---ro receive-disable? empty {feature-list:HAVE_ISIS_SR}?
|               | +---ro entropy-capability? empty {feature-list:HAVE_ISIS_SR}?
|           +---rw global-blocks
|               +---rw global-block* [global-block-base global-block-range]
|                   +---rw global-block-base    -> ../config/global-block-base
|                   +---rw global-block-range    -> ../config/global-block-range
|                   +---rw config
|                       | +---rw global-block-base?    int32
|                       | +---rw global-block-range?    int32 {feature-list:HAVE_ISIS_SR}?
|                       +---ro state
|                           +---ro global-block-base?    int32
|                           +---ro global-block-range?    int32 {feature-list:HAVE_ISIS_SR}?
+---rw debug
|   +---rw config
|       | +---rw options?                 ipi-isis-types:isis_debug_t
|       | +---rw enable-hello?           empty
|       | +---rw interface-hello*        string
|       | +---rw system-id-hello*        string
|       | +---rw cspf?                   ipi-isis-types:isis_cspf_debug_t {feature-
list:HAVE_ISIS_CSPF}?
|       +---ro state
|           +---ro options?               ipi-isis-types:isis_debug_t
|           +---ro enable-hello?         empty
|           +---ro interface-hello*      string
|           +---ro system-id-hello*      string
|           +---ro cspf?                 ipi-isis-types:isis_cspf_debug_t {feature-
list:HAVE_ISIS_CSPF}?
|       +---ro terminal-debug
|           +---ro terminal-debug-status? ipi-isis-types:isis_debug_t
|           +---ro terminal-debug-status-hello? cml-data-types:cml_on_off_t
|           +---ro terminal-debug-status-interface-hello* string
|           +---ro terminal-debug-status-system-id-hello* string

```

```

|           +--ro terminal-debug-status-cspf?           ipi-isis-
types:isis_cspf_debug_t {feature-list:HAVE_ISIS_CSPF}?
+--ro state
| +--ro host-name*           string
| +--ro lsp-identifier?      -> /isis/isis-instances/isis-instance/level-runtime/
lspdb/state/lsp-identifier
| +--ro overload?           -> /isis/isis-instances/isis-instance/state/overload
| +--ro pdu-length?         -> /isis/isis-instances/isis-instance/level-runtime/
lspdb/state/pdu-length
| +--ro raw-pdu?            string
| +--ro pdu-field-len?      uint8
| +--ro max-area-addresses? uint8
| +--ro protocol-version?   uint8
| +--ro reason?             string
| +--ro protocols?          uint8
| +--ro error-offset?       uint32
| +--ro tlv-type?           uint8
| +--ro global-block-base?   int32 {feature-list:HAVE_ISIS_SR}?
| +--ro global-block-range? int32 {feature-list:HAVE_ISIS_SR}?
| +--ro received-index?     uint32 {feature-list:HAVE_ISIS_SR}?
| +--ro routing-protocol?   string {feature-list:HAVE_ISIS_SR}?
+--rw graceful-restart
| +--rw config
| | +--rw grace-period?      uint16
| | +--rw enable-helper-only? empty
| | +--rw suppress-adjacency? empty
| +--ro state
|   +--ro grace-period?      uint16
|   +--ro enable-helper-only? empty
|   +--ro suppress-adjacency? empty
+--rw interfaces
+--rw interface* [name]
+--rw name                  -> ../config/name
+--ro bandwidth-priority* [priority]
| +--ro priority            -> ../state/priority
| +--ro state
|   +--ro priority?         uint8
|   +--ro available-bandwidth? string
+--ro neighbor-lan* [system-id]
| +--ro system-id           -> ../state/system-id
| +--ro adjacency* [level]
| | +--ro level             -> ../state/level
| | +--ro state
| |   +--ro level?          ipi-isis-types:isis_level_t
| |   +--ro adjacency-state? ipi-isis-types:isis_state_t
| |   +--ro adjacency-id?   uint32
| |   +--ro remaining-hold-time? string
| |   +--ro priority?       uint8
| +--ro state
| | +--ro system-id?        string
| | +--ro adjacency-type?   ipi-isis-types:isis_level_t

```



```

| | +---ro adjacency-advertisement? ipi-isis-types:isis_nbr_adj_t
| | +---ro neighbor-snpa? string
| | +---ro level-1-nlp-id* ipi-isis-types:isis_level_proto_t
| | +---ro level-2-nlp-id* ipi-isis-types:isis_level_proto_t
| | +---ro multi-topology-type? ipi-isis-
types:isis_multi_topology_types_t
| | +---ro up-time? string
| | +---ro adjacency-sid? uint32 {feature-list:HAVE_ISIS_SR}?
| | +---ro ilm-id? uint32 {feature-list:HAVE_ISIS_SR}?
| | +---ro bypass-trunk-id? uint32 {feature-list:HAVE_ISIS_SR}?
| | +---ro backup-ilm-id? uint32 {feature-
list:HAVE_ISIS_SR,feature-list:HAVE_ISIS_TI_LFA}?
| | +---ro backup-ilm-msg-id? uint32 {feature-
list:HAVE_ISIS_SR,feature-list:HAVE_ISIS_TI_LFA}?
| | +---ro p-router-id? inet:ipv4-address {feature-
list:HAVE_ISIS_SR,feature-list:HAVE_ISIS_TI_LFA}?
| | +---ro q-router-id? inet:ipv4-address {feature-
list:HAVE_ISIS_SR,feature-list:HAVE_ISIS_TI_LFA}?
| | +---ro pq-router-id? inet:ipv4-address {feature-
list:HAVE_ISIS_SR,feature-list:HAVE_ISIS_TI_LFA}?
| | +---ro neighbor-protocol? ipi-isis-
types:isis_neighbour_protocol_t
| | +---ro area-address* string
| +---ro ipv4-addresses
| | +---ro state
| | +---ro address* inet:ipv4-address
| +---ro ipv6-addresses
| | +---ro state
| | +---ro address* inet:ipv6-address
+---ro level* [level-number]
| +---ro level-number -> ../state/level-number
| +---ro state
| | +---ro level-number? ipi-isis-types:isis_iflevel_t
| | +---ro next-hello-interval? cml-data-types:cml_line_t
| | +---ro mtu? uint32
| | +---ro circuit-id? string
| | +---ro active-adjancency-count? int32
| | +---ro csnp-interval? cml-data-types:cml_line_t
| | +---ro adjacency-changes? uint32
| | +---ro adjacency-number? uint32
| | +---ro init-fails? uint32
| | +---ro rejected-adjacency? uint32
| | +---ro id-field-length-mismatches? uint32
| | +---ro max-area-address-mismatches? uint32
| | +---ro authentication-type-fails? uint32
| | +---ro authentication-fails? uint32
| | +---ro lan-dis-changes? uint32
| +---ro isis-hellos
| | +---ro state
| | +---ro received? uint32
| | +---ro sent? uint32
| +---ro link-state-pdu

```

```
| | +--ro state
| |   +--ro received?   uint32
| |   +--ro sent?      uint32
| +--ro complete-sequence-number-pdu
| | +--ro state
| |   +--ro received?   uint32
| |   +--ro sent?      uint32
| +--ro partial-sequence-number-pdu
| | +--ro state
| |   +--ro received?   uint32
| |   +--ro sent?      uint32
| +--ro unknown
|   +--ro state
|     +--ro received?   uint32
|     +--ro sent?      uint32
+--rw config
| +--rw name?           -> /ipi-interface:interfaces/interface/name
| +--rw minimal?       ipi-isis-types:isis_auth_level_type_t
| +--rw send-only?     ipi-isis-types:isis_auth_level_type_t
+--ro state
| +--ro name?          -> /ipi-interface:interfaces/interface/name
| +--ro minimal?       ipi-isis-types:isis_auth_level_type_t
| +--ro send-only?     ipi-isis-types:isis_auth_level_type_t
| +--ro isis-tag?      string
| +--ro network-type?  string
| +--ro circuit-type?  ipi-isis-types:isis_circuit_type_t
| +--ro local-circuit-id? string
| +--ro extended-circuit-id? string
| +--ro local-snpa?    cml-data-types:cml_mac_addr_t
+--ro bandwidth
| +--ro state
|   +--ro value?       string {feature-list:HAVE_ISIS_TE}?
|   +--ro maximum-resverable? string {feature-list:HAVE_ISIS_TE}?
+--ro p2p-circuit-counters
| +--ro state
|   +--ro adjacency-changes?   uint32
|   +--ro adjacency-number?    uint32
|   +--ro init-fails?          uint32
|   +--ro rejected-adjacency?  uint32
|   +--ro id-field-length-mismatches? uint32
|   +--ro max-area-address-mismatches? uint32
|   +--ro authentication-type-fails?  uint32
|   +--ro authentication-fails?      uint32
|   +--ro lan-dis-changes?          uint32
+--rw connected-ipv4
| +--ro state
|   +--ro address*   cml-data-types:cml_ipv4_addr_prefix_t
+--rw connected-ipv6
| +--ro state
|   +--ro address*   cml-data-types:cml_ipv6_prefix_t
```

```

+--ro neighbor-P2P
| +--ro ipv4-addresses* [address]
| | +--ro address -> ../state/address
| | +--ro state
| |   +--ro address* inet:ipv4-address
| +--ro ipv6-addresses* [address]
| | +--ro address -> ../state/address
| | +--ro state
| |   +--ro address* inet:ipv6-address
| +--ro state
|   +--ro system-id? string
|   +--ro circuit-id? string
|   +--ro adjacency-state? ipi-isis-types:isis_state_t
|   +--ro remaining-hold-time? string
|   +--ro adjacency-type? string
|   +--ro adjacency-advertisement? ipi-isis-types:isis_nbr_adj_t
|   +--ro neighbor-snpa? string
|   +--ro level-1-nlp-id* ipi-isis-types:isis_level_proto_t
|   +--ro level-2-nlp-id* ipi-isis-types:isis_level_proto_t
|   +--ro multi-topology-type? ipi-isis-
types:isis_multi_topology_types_t
|   +--ro up-time? string
|   +--ro adjacency-sid? uint32 {feature-list:HAVE_ISIS_SR}?
|   +--ro ilm-id? uint32 {feature-list:HAVE_ISIS_SR}?
|   +--ro bypass-trunk-id? uint32 {feature-list:HAVE_ISIS_SR}?
|   +--ro backup-ilm-id? uint32 {feature-
list:HAVE_ISIS_SR,feature-list:HAVE_ISIS_TI_LFA}?
|   +--ro backup-ilm-msg-id? uint32 {feature-
list:HAVE_ISIS_SR,feature-list:HAVE_ISIS_TI_LFA}?
|   +--ro p-router-id? inet:ipv4-address {feature-
list:HAVE_ISIS_SR,feature-list:HAVE_ISIS_TI_LFA}?
|   +--ro q-router-id? inet:ipv4-address {feature-
list:HAVE_ISIS_SR,feature-list:HAVE_ISIS_TI_LFA}?
|   +--ro pq-router-id? inet:ipv4-address {feature-
list:HAVE_ISIS_SR,feature-list:HAVE_ISIS_TI_LFA}?
|   +--ro neighbor-protocol? ipi-isis-
types:isis_neighbour_protocol_t
|   +--ro area-address* string
+--rw interface-parameters
| +--rw config
| | +--rw network-type? ipi-isis-types:isis_network_t
| | +--rw circuit-type? ipi-isis-types:isis_circuit_type_t
| | +--rw ipv4-instance-tag? string
| | +--rw ipv6-instance-tag? string {feature-list:HAVE_IPV6}?
| | +--rw lsp-interval? uint32
| | +--rw retransmit-interval? uint16
| | +--rw disable-padding? empty
| | +--rw mesh-group-id? ipi-isis-types:isis_mesh_type_t
| +--ro state
| | +--ro network-type? ipi-isis-types:isis_network_t
| | +--ro circuit-type? ipi-isis-types:isis_circuit_type_t
| | +--ro ipv4-instance-tag? string

```

```

| | +--ro ipv6-instance-tag?    string {feature-list:HAVE_IPV6}?
| | +--ro lsp-interval?        uint32
| | +--ro retransmit-interval? uint16
| | +--ro disable-padding?     empty
| | +--ro mesh-group-id?      ipi-isis-types:isis_mesh_type_t
+--rw bfd {feature-list:HAVE_BFD}?
| | +--rw config
| | | +--rw enable?           empty
| | | +--rw disable?         empty
| | +--ro state
| |   +--ro enable?           empty
| |   +--ro disable?         empty
+--rw fast-re-route
| | +--rw config
| | | +--rw disable-level-1?   empty {feature-list:HAVE_ISIS_LFA}?
| | | +--rw disable-level-2?   empty {feature-list:HAVE_ISIS_LFA}?
| | +--ro state
| |   +--ro disable-level-1?   empty {feature-list:HAVE_ISIS_LFA}?
| |   +--ro disable-level-2?   empty {feature-list:HAVE_ISIS_LFA}?
+--rw level-infos
|   +--rw level-info* [level]
|   +--rw level                -> ../config/level
|   +--rw config
|   | +--rw level?              ipi-isis-types:isis_level_t
|   | +--rw hello-interval?    uint16
|   | +--rw hello-multiplier?  uint8
|   | +--rw csnp-interval?     uint16
|   | +--rw priority?          uint8
|   | +--rw metric?            uint8
|   | +--rw password?          string
|   | +--rw tag?                uint32
|   | +--rw wide-metric?       uint32
|   | +--rw te-metric?          uint32 {feature-list:HAVE_ISIS_TE}?
|   | +--rw restart-hello-interval? uint16
|   +--ro state
|   | +--ro level?              ipi-isis-types:isis_level_t
|   | +--ro hello-interval?    uint16
|   | +--ro hello-multiplier?  uint8
|   | +--ro csnp-interval?     uint16
|   | +--ro priority?          uint8
|   | +--ro metric?            uint8
|   | +--ro password?          string
|   | +--ro tag?                uint32
|   | +--ro wide-metric?       uint32
|   | +--ro te-metric?          uint32 {feature-list:HAVE_ISIS_TE}?
|   | +--ro restart-hello-interval? uint16
|   +--rw authentication
|   | +--rw config!
|   | | +--rw mode              ipi-isis-types:isis_auth_mode_t
|   | | +--rw key-chain?       string

```

```

|           +---ro state
|           +---ro mode          ipi-isis-types:isis_auth_mode_t
|           +---ro key-chain?   string
+---rw igp-ldp-sync {feature-list:HAVE_LDPD}?
  +---rw config!
  | +---rw level          ipi-isis-types:isis_level_igp_sync_t
  | +---rw hold-timer    uint32
  +---ro state
    +---ro level          ipi-isis-types:isis_level_igp_sync_t
    +---ro hold-timer    uint32
    +---ro interface-name? string

```

rpcs:

```

+---x isis-restart-graceful {feature-list:HAVE_RESTART}?
| +---w input
|   +---w grace-period?  uint16
+---x isis-clear-interface-counters {feature-list:HAVE_ISISD}?
| +---w input
|   +---w name?         string
+---x isis-clear-is-neighbors {feature-list:HAVE_ISISD}?
| +---w input
|   +---w system-id     string
+---x isis-clear-clns-neighbors {feature-list:HAVE_ISISD}?
+---x isis-clear-ip-route {feature-list:HAVE_ISISD}?
| +---w input
|   +---w instance?     string
|   +---w ipv4-route    ipi-isis-types:isis_route_t
+---x isis-clear-ipv6-route {feature-list:HAVE_ISISD}?
| +---w input
|   +---w instance?     string
|   +---w ipv6-route    ipi-isis-types:isis_route_t
+---x isis-process-clear {feature-list:HAVE_ISISD}?
| +---w input
|   +---w instance      string
+---x isis-clear-counters {feature-list:HAVE_ISISD}?
+---x isis-clear-adjacency-all {feature-list:HAVE_ISISD}?
| +---w input
|   +---w adjacency-vrf-name? string
+---x isis-process-clear-adjacency-all {feature-list:HAVE_ISISD}?
| +---w input
|   +---w tag-name          string
|   +---w adjacency-vrf-name? string
+---x isis-process-clear-adjacency-interface {feature-list:HAVE_ISISD}?
| +---w input
|   +---w tag-name          string
|   +---w tag-if-name?     string
|   +---w adjacency-vrf-name? string
+---x isis-clear-adjacency-interface {feature-list:HAVE_ISISD}?
| +---w input
|   +---w adjacency-if-name? string

```

```

|     +---w adjacency-vrf-name?  string
+---x isis-process-clear-adjacency-system-id {feature-list:HAVE_ISISD}?
|   +---w input
|     +---w tag-name            string
|     +---w tag-system-id       ipi-isis-types:isis_systemid_t
|     +---w tag-vrf-name?       string
+---x isis-clear-adjacency-system-id {feature-list:HAVE_ISISD}?
|   +---w input
|     +---w adjacency-system-id  ipi-isis-types:isis_systemid_t
|     +---w adjacency-vrf-name?  string
+---x isis-restart-snmp {feature-list:HAVE_SNMP}?
+---x isis-terminal-debug-all-on {feature-list:HAVE_ISISD}?
+---x isis-terminal-debug-all-off {feature-list:HAVE_ISISD}?
+---x isis-terminal-debug-on {feature-list:HAVE_ISISD}?
|   +---w input
|     +---w terminal-debug-options ipi-isis-types:isis_debug_t
+---x isis-debug-off {feature-list:HAVE_ISISD}?
|   +---w input
|     +---w terminal-debug-options ipi-isis-types:isis_debug_t
+---x isis-debug-hello-on {feature-list:HAVE_ISISD}?
+---x isis-debug-hello-off {feature-list:HAVE_ISISD}?
+---x isis-debug-interface-hello-on {feature-list:HAVE_ISISD}?
|   +---w input
|     +---w interface            string
+---x isis-debug-interface-hello-off {feature-list:HAVE_ISISD}?
|   +---w input
|     +---w interface            string
+---x isis-debug-system-id-hello-on {feature-list:HAVE_ISISD}?
|   +---w input
|     +---w system-id            string
+---x isis-debug-system-id-hello-off {feature-list:HAVE_ISISD}?
|   +---w input
|     +---w system-id            string
+---x isis-all-debug-off {feature-list:HAVE_ISISD}?
+---x isis-debug-cspf-on {feature-list:HAVE_ISIS_CSPF}?
|   +---w input
|     +---w cspf-debug           ipi-isis-types:isis_cspf_debug_t
+---x isis-debug-cspf-off {feature-list:HAVE_ISIS_CSPF}?
|   +---w input
|     +---w cspf-debug           ipi-isis-types:isis_cspf_debug_t

```

notifications:

```

+---n isis-database-overload
|   +---ro severity?            cml-data-types:cml_notif_severity_t
|   +---ro eventClass?         cml-data-types:cml_notif_class_t
|   +---ro overload?           ipi-isis-types:isis_overload_state_t
+---n isis-lsp-too-large
|   +---ro severity?            cml-data-types:cml_notif_severity_t
|   +---ro eventClass?         cml-data-types:cml_notif_class_t
|   +---ro lsp-identifier?     string

```

```
| +--ro pdu-length?          uint32
+---n isis-corrupted-lsp-detected
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro lsp-identifier?    string
+---n isis-attempt-to-exceed-max-sequence
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro lsp-identifier?    string
+---n isis-id-len-mismatch
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro pdu-field-len?    uint8
| +--ro raw-pdu?          string
+---n isis-max-area-addresses-mismatch
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro max-area-addresses? uint8
| +--ro raw-pdu?          string
+---n isis-own-lsp-purge
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro lsp-identifier?    string
+---n isis-sequence-number-skipped
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro lsp-identifier?    string
+---n isis-authentication-type-failure
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro raw-pdu?          string
+---n isis-authentication-failure
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro raw-pdu?          string
+---n isis-version-skew
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro protocol-version?  uint8
| +--ro raw-pdu?          string
+---n isis-area-mismatch
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro raw-pdu?          string
+---n isis-rejected-adjacency
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro raw-pdu?          string
| +--ro reason?           string
+---n isis-protocols-supported-mismatch
```

```

| +--ro severity?      cml-data-types:cml_notif_severity_t
| +--ro eventClass?   cml-data-types:cml_notif_class_t
| +--ro raw-pdu?      string
| +--ro protocols?    uint8
+---n isis-lsp-error-detected
| +--ro severity?      cml-data-types:cml_notif_severity_t
| +--ro eventClass?   cml-data-types:cml_notif_class_t
| +--ro lsp-identifier? string
| +--ro raw-pdu?      string
| +--ro error-offset? uint32
| +--ro tlv-type?     uint8
+---n isis-segment-routing-index-out-of-range {feature-list:HAVE_ISIS_SR}?
  +--ro severity?      cml-data-types:cml_notif_severity_t
  +--ro eventClass?   cml-data-types:cml_notif_class_t
  +--ro global-block-base? int32
  +--ro global-block-range? int32
  +--ro received-index? uint32
  +--ro routing-protocol? string

```

module: ipi-keychain

```

+--rw key-chains
  +--rw key-chain* [name]
    +--rw name      -> ../config/name
    +--rw config
      | +--rw name?  string
    +--ro state
      | +--ro name?  string
    +--rw keys
      +--rw key-list* [key-id]
        +--rw key-id      -> ../config/key-id
        +--rw config
          | +--rw key-id?          uint32
          | +--rw (key-style)?
          |   +--:(key-string)
          |   | +--rw key-string?  string
          |   +--:(hexadecimal)
          |   +--rw encrypted?     keychain_hex_string_t
        +--ro state
          | +--ro key-id?          uint32
          | +--ro (key-style)?
          |   +--:(key-string)
          |   | +--ro key-string?  string
          |   +--:(hexadecimal)
          |   +--ro encrypted?     keychain_hex_string_t
        +--rw accept-lifetime
          | +--rw config
          | | +--rw start-date-time-for-accept?      keychain_date_time_t

```



```

| | +--rw (end-time)?
| |   +---:(end-time)
| |     | +--rw end-date-time-for-accept?   keychain_date_time_t
| |     +---:(infinite)
| |     | +--rw infinite-for-accept?        empty
| |     +---:(duration)
| |       +--rw duration-for-accept?        uint32
| +--ro state
|   +--ro start-date-time-for-accept?       keychain_date_time_t
|   +--ro (end-time)?
|     +---:(end-time)
|       | +--ro end-date-time-for-accept?   keychain_date_time_t
|       +---:(infinite)
|       | +--ro infinite-for-accept?        empty
|       +---:(duration)
|         +--ro duration-for-accept?        uint32
+--rw send-lifetime
  +--rw config
  | +--rw start-date-time-for-send?         keychain_date_time_t
  | +--rw (end-time)?
  |   +---:(end-time)
  |     | +--rw end-date-time-for-send?     keychain_date_time_t
  |     +---:(infinite)
  |     | +--rw infinite-for-send?          empty
  |     +---:(duration)
  |       +--rw duration-for-send?          uint32
  +--ro state
  | +--ro start-date-time-for-send?         keychain_date_time_t
  | +--ro (end-time)?
  |   +---:(end-time)
  |     | +--ro end-date-time-for-send?     keychain_date_time_t
  |     +---:(infinite)
  |     | +--ro infinite-for-send?          empty
  |     +---:(duration)
  |       +--ro duration-for-send?          uint32

```

module: ipi-l2vpn-vpls

```

+--rw vpls
  +--rw attachment-circuit
  | +--rw service-template-mappings
  |   +--rw service-template-mapping* [interface-name vpls-name service-template-
name]
  |     +--rw interface-name                -> ../config/interface-name
  |     +--rw vpls-name                     -> ../config/vpls-name
  |     +--rw service-template-name         -> ../config/service-template-name
  |     +--rw config
  |     | +--rw interface-name?             -> /ipi-interface:interfaces/
interface/name

```

```

| | | | +--rw service-template-name? -> /ipi-mpls:mpls/l2vpn/
customer-service-templates/customer-service-template/config/name
| | | | +--rw vpls-name? string
| | | | +--rw admin-status? ipi-vpls-
types:vpls_ac_admin_status_t
| | | | +--rw attachment-circuit-description? cml-data-types:cml_line_t
| | | | +--rw mac-learning? ipi-vpls-
types:vpls_mac_learning_t
| | | | +--rw split-horizon? ipi-if-types:if_split_horizon_t
{feature-list:HAVE_CUSTOM2_MPLS,feature-list:NOT_HAVE_DNX}?
| | | | +--rw static-mac-address* cml-data-types:cml_mac_addr_t
| | | | +--ro state
| | | | +--ro interface-name? -> /ipi-interface:interfaces/
interface/name
| | | | +--ro service-template-name? -> /ipi-mpls:mpls/l2vpn/
customer-service-templates/customer-service-template/config/name
| | | | +--ro vpls-name? string
| | | | +--ro admin-status? ipi-vpls-
types:vpls_ac_admin_status_t
| | | | +--ro attachment-circuit-description? cml-data-types:cml_line_t
| | | | +--ro mac-learning? ipi-vpls-
types:vpls_mac_learning_t
| | | | +--ro split-horizon? ipi-if-types:if_split_horizon_t
{feature-list:HAVE_CUSTOM2_MPLS,feature-list:NOT_HAVE_DNX}?
| | | | +--ro static-mac-address* cml-data-types:cml_mac_addr_t
| | | | +--rw quality-of-service-profiles
| | | | +--rw quality-of-service-profile* [profile-type profile-name] {feature-
list:HAVE_QOS}?
| | | | | +--rw profile-type -> ../config/profile-type
| | | | | +--rw profile-name -> ../config/profile-name
| | | | | +--rw config
| | | | | | +--rw profile-type? ipi-vpls-types:vpls_qos_map_profile_type_t
| | | | | | +--rw profile-name? string
| | | | | +--ro state
| | | | | | +--ro profile-type? ipi-vpls-types:vpls_qos_map_profile_type_t
| | | | | | +--ro profile-name? string
+--rw static-forwarding
| +--rw vpls-entries
| | +--rw vpls-entry* [vpls-identifier peer-address]
| | | +--rw vpls-identifier -> ../config/vpls-identifier
| | | +--rw peer-address -> ../config/peer-address
| | | +--rw config
| | | | +--rw in-label uint32
| | | | +--rw out-label uint32
| | | | +--rw out-interface-name string
| | | | +--rw vpls-identifier? -> /ipi-network-instance:network-instances/
network-instance/vpls-instance/config/vpls-identifier
| | | | +--rw peer-address? -> /ipi-network-instance:network-instances/
network-instance/vpls-instance/vpls-peers/vpls-peer/config/peer-address
| | | | +--ro state
| | | | +--ro in-label uint32
| | | | +--ro out-label uint32
| | | | +--ro out-interface-name string

```

```

| |      +--ro vpls-identifier?      -> /ipi-network-instance:network-instances/
network-instance/vpls-instance/config/vpls-identifier
| |      +--ro peer-address?        -> /ipi-network-instance:network-instances/
network-instance/vpls-instance/vpls-peers/vpls-peer/config/peer-address
| +--rw hierarchical-vpls-entries
|   +--rw hierarchical-vpls-entry* [vpls-identifier spoke-pseudowire-name]
|     +--rw vpls-identifier          -> ../config/vpls-identifier
|     +--rw spoke-pseudowire-name    -> ../config/spoke-pseudowire-name
|     +--rw config
|       | +--rw in-label              uint32
|       | +--rw out-label             uint32
|       | +--rw out-interface-name    string
|       | +--rw vpls-identifier?      -> /ipi-network-instance:network-
instances/network-instance/vpls-instance/config/vpls-identifier
|       | +--rw spoke-pseudowire-name? -> /ipi-network-instance:network-
instances/network-instance/vpls-instance/spoke-pseudowires/spoke-pseudowire/config/
pseudowire-name
|       +--ro state
|         +--ro in-label              uint32
|         +--ro out-label             uint32
|         +--ro out-interface-name    string
|         +--ro vpls-identifier?      -> /ipi-network-instance:network-
instances/network-instance/vpls-instance/config/vpls-identifier
|         +--ro spoke-pseudowire-name? -> /ipi-network-instance:network-
instances/network-instance/vpls-instance/spoke-pseudowires/spoke-pseudowire/config/
pseudowire-name
+--rw interfaces
| +--rw interface* [name]
|   +--rw name                      -> ../config/name
|   +--rw config
|     | +--rw name?                  -> /ipi-interface:interfaces/interface/name
|     +--ro state
|     | +--ro name?                  -> /ipi-interface:interfaces/interface/name
|     +--rw vpls-access {feature-list:HAVE_SUBINTERFACE}?
|     +--rw config!
|       | +--rw enable                empty
|       | +--rw vpls-name?            string
|       | +--rw disable-mac-learning? empty
|       | +--rw static-mac-address*   cml-data-types:cml_mac_addr_t
|     +--ro state
|       +--ro enable                  empty
|       +--ro vpls-name?              string
|       +--ro disable-mac-learning?   empty
|       +--ro static-mac-address*     cml-data-types:cml_mac_addr_t
+--rw global
+--ro state
+--ro counters
+--ro total-instances?               yang:counter32
+--ro total-peers?                   yang:counter32
+--ro active-peer-instances?         yang:counter32
+--ro inactive-peer-instances?       yang:counter32

```

```

augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance:
  +--rw vpls-instance
    +--rw config!
      | +--rw vpls-identifier                uint32
      | +--rw service-transport-identifier? ipi-vpls-types:vpls_svc_tpid_t
      | +--rw maximum-transmission-unit?    uint16
      | +--rw vpls-description?             cml-data-types:cml_line_t
      | +--rw control-word?                 empty
      | +--rw mac-learning-disable?         empty
      | +--rw mac-learning-limit?          uint32 {feature-
list:NOT_HAVE_TRIDENT2,feature-list:NOT_HAVE_TRIDENT2PLUS}?
      | +--rw attachment-circuit-group-name? -> /ipi-mpls:mpls/l2vpn/access-circuit-
groups/access-circuit-group/config/group-name
    +--ro state
      | +--ro vpls-identifier                uint32
      | +--ro service-transport-identifier? ipi-vpls-types:vpls_svc_tpid_t
      | +--ro maximum-transmission-unit?    uint16
      | +--ro vpls-description?             cml-data-types:cml_line_t
      | +--ro control-word?                 empty
      | +--ro mac-learning-disable?         empty
      | +--ro mac-learning-limit?          uint32 {feature-
list:NOT_HAVE_TRIDENT2,feature-list:NOT_HAVE_TRIDENT2PLUS}?
      | +--ro attachment-circuit-group-name? -> /ipi-mpls:mpls/l2vpn/access-circuit-
groups/access-circuit-group/config/group-name
      | +--ro signaling-protocol?           ipi-vpls-types:vpls_signaling_type_t
      | +--ro route-distinguisher?         string
      | +--ro route-target?                string
      | +--ro vpls-edge-id?                 uint32
      | +--ro attachment-circuit-status?    ipi-vpls-types:vpls_ac_status_t
      | +--ro vpls-type?                    ipi-vpls-types:vpls_vc_type_t
      | +--ro service-vlan-id?              uint16
      | +--ro group-identifier?             uint32
      | +--ro total-mac-addresses-learnt?  uint32
    +--rw spoke-pseudowires
      | +--rw spoke-pseudowire* [pseudowire-name]
      |   +--rw pseudowire-name    -> ../config/pseudowire-name
      |   +--rw config
      |     | +--rw pseudowire-name?  string
      |     | +--rw pseudowire-type?  ipi-vpls-types:vpls_vc_spoke_type_t
      |     +--ro state
      |       +--ro pseudowire-name?  string
      |       +--ro pseudowire-type?  ipi-vpls-types:vpls_vc_spoke_type_t
    +--rw fat-label
      | +--rw config!
      | | +--rw enable-flow-label          empty
      | | +--rw flow-label-direction?     ipi-vpls-
types:vpls_mpls_flow_label_direction_t
      | | +--rw enable-static-flow-label?  empty
      | | +--rw enable-interface-parameter-tlv? empty
      | +--ro state
      | +--ro enable-flow-label            empty

```

```

|      +---ro flow-label-direction?          ipi-vpls-
types:vpls_mpls_flow_label_direction_t
|      +---ro enable-static-flow-label?      empty
|      +---ro enable-interface-parameter-tlv? empty
+---rw vpls-peers
|  +---rw vpls-peer* [peer-address]
|  |  +---rw peer-address    -> ../config/peer-address
|  |  +---rw config
|  |  |  +---rw peer-address?          inet:ipv4-address
|  |  |  +---rw tunnel-name?          string
|  |  |  +---rw tunnel-policy?        string {feature-list:HAVE_SERVICE_MAPPING}?
|  |  |  +---rw tunnel-identifier?    uint32
|  |  |  +---rw peer-type?            ipi-vpls-types:vpls_peer_type_t
|  |  +---ro state
|  |  |  +---ro peer-address?          inet:ipv4-address
|  |  |  +---ro tunnel-name?          string
|  |  |  +---ro tunnel-policy?        string {feature-list:HAVE_SERVICE_MAPPING}?
|  |  |  +---ro tunnel-identifier?    uint32
|  |  |  +---ro peer-type?            ipi-vpls-types:vpls_peer_type_t
|  |  +---rw fec129s
|  |  |  +---rw fec129* [attachment-group-identifier source-attachment-individual-
attachment-group-identifier target-attachment-individual-identifier]
|  |  |  |  +---rw attachment-group-identifier          -> ../config/
attachment-group-identifier
|  |  |  |  +---rw source-attachment-individual-identifier -> ../config/source-
attachment-individual-identifier
|  |  |  |  +---rw target-attachment-individual-identifier -> ../config/target-
attachment-individual-identifier
|  |  |  |  +---rw config
|  |  |  |  |  +---rw attachment-group-identifier?      string
|  |  |  |  |  +---rw source-attachment-individual-identifier? string
|  |  |  |  |  +---rw target-attachment-individual-identifier? string
|  |  |  |  |  +---rw tunnel-name?                      string
|  |  |  |  |  +---rw tunnel-policy?                    string {feature-
list:HAVE_SERVICE_MAPPING}?
|  |  |  |  |  +---rw tunnel-identifier?                string
|  |  |  +---ro state
|  |  |  |  +---ro attachment-group-identifier?        string
|  |  |  |  +---ro source-attachment-individual-identifier? string
|  |  |  |  +---ro target-attachment-individual-identifier? string
|  |  |  |  +---ro tunnel-name?                        string
|  |  |  |  +---ro tunnel-policy?                      string {feature-
list:HAVE_SERVICE_MAPPING}?
|  |  |  |  +---ro tunnel-identifier?                  string
|  |  +---rw config!
|  |  |  +---rw signaling-protocol-ldp    empty
|  |  |  +---rw disable-mac-withdrawal?   empty
|  |  |  +---rw vpls-encapsulation-type?   ipi-vpls-types:vpls_vc_type_t
|  +---ro state
|  |  +---ro signaling-protocol-ldp    empty
|  |  +---ro disable-mac-withdrawal?   empty
|  |  +---ro vpls-encapsulation-type?   ipi-vpls-types:vpls_vc_type_t

```

```

+--rw bgp-signaling {feature-list:HAVE_BGP_VPLS}?
| +--rw config!
| | +--rw signaling-protocol-bgp    empty
| | +--rw vpls-edge-identifier?    uint16
| | +--rw tunnel-policy?           string {feature-list:HAVE_SERVICE_MAPPING}?
| +--ro state
|   +--ro signaling-protocol-bgp    empty
|   +--ro vpls-edge-identifier?     uint16
|   +--ro tunnel-policy?            string {feature-list:HAVE_SERVICE_MAPPING}?
+--rw quality-of-service-profiles
| +--rw quality-of-service-profile* [profile-type profile-name] {feature-
list:HAVE_QOS}?
|   +--rw profile-type      -> ../config/profile-type
|   +--rw profile-name      -> ../config/profile-name
|   +--rw config
|   | +--rw profile-type?    ipi-vpls-types:vpls_qos_map_profile_type_t
|   | +--rw profile-name?   string
|   +--ro state
|     +--ro profile-type?    ipi-vpls-types:vpls_qos_map_profile_type_t
|     +--ro profile-name?   string
+--ro mac-learning-table* [mac-address]
| +--ro mac-address      -> ../state/mac-address
| +--ro state
|   +--ro mac-address?    cml-data-types:cml_mac_addr_t
|   +--ro vpls-identifier? uint32
|   +--ro learning-source-interface? string
|   +--ro matched-vlan?   uint16
|   +--ro peer-address?   inet:ipv4-address
|   +--ro ageing-timeout? uint32
+--ro peer-list* [peer-address]
| +--ro peer-address      -> ../state/peer-address
| +--ro state
|   +--ro peer-address?    inet:ipv4-address
|   +--ro vpls-identifier? uint32
|   +--ro tunnel-label?    uint32
|   +--ro pseudowire-in-label? uint32
|   +--ro pseudowire-out-label? uint32
|   +--ro peer-state?      ipi-vpls-types:vpls_peer_state_t
|   +--ro pseudowire-status? ipi-vpls-types:vpls_pseudowire_status_t
|   +--ro network-interface? string
|   +--ro signaling-protocol? ipi-vpls-types:vpls_signaling_type_t
+--ro access-interface-counters* [interface-name] {feature-list:HAVE_MPLS_STATS}?
| +--ro interface-name      -> ../state/interface-name
| +--ro state
|   +--ro interface-name?    -> /ipi-interface:interfaces/interface/name
|   +--ro vpls-identifier?   uint32
|   +--ro service-template-name? string
|   +--ro in-packets?        uint64
|   +--ro in-bytes?         uint64
|   +--ro out-packets?      uint64
|   +--ro out-bytes?        uint64

```

```

+--ro network-interface-counters* [peer-address] {feature-list:HAVE_MPLS_STATS}?
  +--ro peer-address    -> ../state/peer-address
  +--ro state
    +--ro peer-address?    inet:ipv4-address
    +--ro vpls-identifier?  uint32
    +--ro peer-state?      ipi-vpls-types:vpls_peer_state_t
    +--ro interface-name?  -> /ipi-interface/interfaces/interface/name
    +--ro in-packets?      uint64
    +--ro in-bytes?        uint64
    +--ro out-packets?     uint64
    +--ro out-bytes?       uint64

rpcs:
  +---x clear-mpls-vpls-name-statistics-port-type {feature-
list:HAVE_MPLS_STATS,feature-list:HAVE_VPLS}?
  | +---w input
  |   +---w port-type      ipi-vpls-types:vpls_port_type_t
  |   +---w port-circuit-name  string
  +---x clear-mpls-vpls-name-statistics-network-port-peer {feature-
list:HAVE_MPLS_STATS,feature-list:HAVE_VPLS}?
  | +---w input
  |   +---w port-circuit-name  string
  |   +---w vc-circuit-type    ipi-vpls-types:vpls_peer_address_type_t
  +---x clear-mpls-vpls-name-statistics-network-port-spoke {feature-
list:HAVE_MPLS_STATS,feature-list:HAVE_VPLS}?
  | +---w input
  |   +---w port-circuit-name  string
  |   +---w vc-circuit-type    ipi-vpls-types:vpls_spoke_vc_type_t
  +---x clear-mpls-vpls-name-statistics-access-port {feature-
list:HAVE_MPLS_STATS,feature-list:HAVE_VPLS}?
  | +---w input
  |   +---w port-circuit-name  string
  |   +---w vc-interface-name  string
  |   +---w vc-access-type     ipi-vpls-types:vpls_mpls_access_type_t
  +---x clear-mpls-vpls-name-statistics {feature-list:HAVE_VPLS,feature-
list:HAVE_MPLS_STATS}?
  | +---w input
  |   +---w vpls-circuit-name  string
  +---x clear-mpls-vpls-mac-addresses-for-instance {feature-list:HAVE_VPLS}?
  | +---w input
  |   +---w name      string
  +---x clear-mpls-vpls-mac-addresses-all {feature-list:HAVE_VPLS}?

```

module: ipi-l2vpn-vpws

```

+--rw vpws
  +--rw interfaces
  | +--rw interface* [name]
  |   +--rw name          -> ../config/name

```

```

|     +--rw config
|     |   +--rw name?   -> /ipi-interface:interfaces/interface/name
|     +--ro state
|     |   +--ro name?   -> /ipi-interface:interfaces/interface/name
|     +--rw pseudowire-modes
|     |   +--rw pseudowire-mode* [service-template]
|     |     +--rw service-template   -> ../config/service-template
|     |     +--rw config
|     |       | +--rw service-template?  string
|     |       | +--rw mode                ipi-vpws-types:vpws_mpls_vcmode_t
|     |       +--ro state
|     |         +--ro service-template?  string
|     |         +--ro mode                ipi-vpws-types:vpws_mpls_vcmode_t
|     +--rw vpws-access {feature-list:HAVE_SUBINTERFACE}?
|     |   +--rw config!
|     |     | +--rw enable                empty
|     |     | +--rw enable-revertive-mode? empty
|     |     +--ro state
|     |       | +--ro enable                empty
|     |       | +--ro enable-revertive-mode? empty
|     |     +--rw bindings
|     |       +--rw binding* [vpws-name]
|     |         +--rw vpws-name   -> ../config/vpws-name
|     |         +--rw config
|     |           | +--rw vpws-name?      string
|     |           | +--rw pseudowire-link-mode  ipi-vpws-
types:vpws_mpls_vclinkmode_t
|     |           +--ro state
|     |             +--ro vpws-name?      string
|     |             +--ro pseudowire-link-mode  ipi-vpws-
types:vpws_mpls_vclinkmode_t
|     +--rw service-template-mappings
|     |   +--rw service-template-mapping* [pseudowire-name]
|     |     +--rw pseudowire-name   -> ../config/pseudowire-name
|     |     +--rw config
|     |       | +--rw pseudowire-name?    string
|     |       | +--rw service-template-name -> /ipi-mpls:mpls/l2vpn/customer-
service-templates/customer-service-template/name
|     |       | +--rw pseudowire-link-mode  ipi-vpws-
types:vpws_mpls_vclinkmode_t
|     |       | +--rw cos-to-queue-profile-name?  string {feature-
list:HAVE_QOS_MAPPING_PROFILE}?
|     |       | +--rw queue-to-cos-profile-name?  string {feature-
list:HAVE_QOS_MAPPING_PROFILE,feature-list:NOT_HAVE_CUSTOM1_MPLS}?
|     |       +--ro state
|     |         +--ro pseudowire-name?    string
|     |         +--ro service-template-name -> /ipi-mpls:mpls/l2vpn/customer-
service-templates/customer-service-template/name
|     |         +--ro pseudowire-link-mode  ipi-vpws-
types:vpws_mpls_vclinkmode_t
|     |         +--ro cos-to-queue-profile-name?  string {feature-
list:HAVE_QOS_MAPPING_PROFILE}?

```



```

|           +--ro queue-to-cos-profile-name?  string {feature-
list:HAVE_QOS_MAPPING_PROFILE,feature-list:NOT_HAVE_CUSTOM1_MPLS}?
+--rw static-forwarding
|   +--rw forwarding-information-bases
|       +--rw forwarding-information-base* [pseudowire-identifier]
|           +--rw pseudowire-identifier      -> ../config/pseudowire-identifier
|           +--rw config
|               | +--rw pseudowire-identifier?      -> /ipi-network-instance:network-
instances/network-instance/vpws-instance/pseudowires/pseudowire/config/pseudowire-
identifier
|               | +--rw incoming-label              uint32
|               | +--rw outgoing-label              uint32
|               | +--rw nexthop-address             inet:ip-address
name |               | +--rw provider-interface-name  -> /ipi-interface:interfaces/interface/
|               | +--rw access-interface-name      -> /vpws/interfaces/interface/name
|               +--ro state
|                   +--ro pseudowire-identifier?  -> /ipi-network-instance:network-
instances/network-instance/vpws-instance/pseudowires/pseudowire/config/pseudowire-
identifier
|                   +--ro incoming-label          uint32
|                   +--ro outgoing-label          uint32
|                   +--ro nexthop-address         inet:ip-address
name |                   +--ro provider-interface-name -> /ipi-interface:interfaces/interface/
|                   +--ro access-interface-name   -> /vpws/interfaces/interface/name
+--ro global
    +--ro state
        +--ro counters
            +--ro total-pseudowires?      uint32
            +--ro active-pseudowires?     uint32
            +--ro inactive-pseudowires?   uint32
            +--ro oam-pseudowires?        uint32

augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance:
+--rw vpws-instance
+--rw pseudowires
|   +--rw pseudowire* [pseudowire-identifier peer-address]
|       +--rw pseudowire-identifier      -> ../config/pseudowire-identifier
|       +--rw peer-address                -> ../config/peer-address
|       +--rw config
|           | +--rw pseudowire-identifier?  uint32
|           | +--rw peer-address?          ipi-vpws-types:vpws_ip_addr_t
|           +--ro state
|               | +--ro pseudowire-identifier?  uint32
|               | +--ro peer-address?          ipi-vpws-types:vpws_ip_addr_t
|               | +--ro vc-admin-status?      ipi-vpws-
types:vpws_mpls_vc_admin_status_t {feature-list:HAVE_UNI_CLI}?
|               | +--ro up-time?              yang:date-and-time
|               | +--ro last-change-time?    yang:date-and-time
|               | +--ro create-time?         yang:date-and-time

```

```

|      | +--ro owner?                               ipi-vpws-types:vpws_mpls_vc_owner_t
|      | +--ro non-te-mapping-direction?           ipi-vpws-
types:vpws_mpls_mapping_dir_t
|      | +--ro remote-pseudowire-status?          ipi-vpws-
types:vpws_mpls_pw_status_t
|      | +--ro pseudowire-state?                  ipi-vpws-
types:vpws_mpls_pw_state_t
|      | +--ro pseudowire-index?                  uint32
|      | +--ro pseudowire-type?                   ipi-vpws-types:vpws_mpls_pw_type_t
|      | +--ro pseudowire-mode?                   ipi-vpws-types:vpws_mpls_pw_mode_t
|      | +--ro pseudowire-label?                  uint32
|      | +--ro tunnel-label?                       uint32
|      | +--ro network-interface-name?            string
|      | +--ro customer-service-template-name?    string
|      | +--ro ldp-ecmp-svc?                       string {feature-
list:HAVE_MPLS_ECMP}?
|      | +--ro rsvp-multipath-svc?                 string {feature-
list:HAVE_RSVP_MULTIPATH}?
|      | +--rw default-tagged
|      | +--rw config!
|      | | +--rw group-name?                        string
|      | | +--rw group-identifier?                 uint32
|      | | +--rw enable-control-word?              empty
|      | | +--rw tunnel-name?                      string
|      | | +--rw tunnel-policy?                    string {feature-
list:HAVE_SERVICE_MAPPING}?
|      | | +--rw tunnel-identifier?                uint32
|      | | +--rw enable-default-tagged-mode         empty
|      | | +--rw enable-flow-label?                empty
|      | | +--rw flow-label-direction?             ipi-vpws-
types:vpws_mpls_flow_label_direction_t
|      | | +--rw enable-static-flow-label?         empty
|      | | +--rw enable-interface-parameter-tlv?   empty
|      | | +--rw service-tpid?                     ipi-vpws-types:vpws_svc_tpid_t
|      | | +--rw enable-manual-pseudowire?         empty
|      | | +--rw control-channel-type?             ipi-vpws-
types:vpws_mpls_vccv_cc_type_t {feature-list:HAVE_VCCV,feature-
list:HAVE_CUSTOM1_MPLS_BFD}?
|      | | +--rw control-verification-type?        ipi-vpws-
types:vpws_mpls_vccv_cv_type_t {feature-list:HAVE_VCCV,feature-
list:HAVE_CUSTOM1_MPLS_BFD}?
|      | +--ro state
|      | +--ro group-name?                          string
|      | +--ro group-identifier?                    uint32
|      | +--ro enable-control-word?                 empty
|      | +--ro tunnel-name?                         string
|      | +--ro tunnel-policy?                       string {feature-
list:HAVE_SERVICE_MAPPING}?
|      | +--ro tunnel-identifier?                    uint32
|      | +--ro enable-default-tagged-mode           empty
|      | +--ro enable-flow-label?                   empty
|      | +--ro flow-label-direction?               ipi-vpws-
types:vpws_mpls_flow_label_direction_t

```

```

|         |         +---ro enable-static-flow-label?         empty
|         |         +---ro enable-interface-parameter-tlv?  empty
|         |         +---ro service-tpid?                    ipi-vpws-types:vpws_svc_tpid_t
|         |         +---ro enable-manual-pseudowire?        empty
|         |         +---ro control-channel-type?            ipi-vpws-
types:vpws_mpls_vccv_cc_type_t {feature-list:HAVE_VCCV,feature-
list:HAVE_CUSTOM1_MPLS_BFD}?
|         |         +---ro control-verification-type?        ipi-vpws-
types:vpws_mpls_vccv_cv_type_t {feature-list:HAVE_VCCV,feature-
list:HAVE_CUSTOM1_MPLS_BFD}?
|         |         +---rw tagged
|         |         +---rw config!
|         |         |         +---rw group-name?             string
|         |         |         +---rw group-identifier?        uint32
|         |         |         +---rw enable-control-word?     empty
|         |         |         +---rw tunnel-name?             string
|         |         |         +---rw tunnel-policy?           string {feature-
list:HAVE_SERVICE_MAPPING}?
|         |         |         +---rw tunnel-identifier?        uint32
|         |         |         +---rw enable-flow-label?        empty
|         |         |         +---rw flow-label-direction?     ipi-vpws-
types:vpws_mpls_flow_label_direction_t
|         |         |         +---rw enable-static-flow-label?  empty
|         |         |         +---rw enable-interface-parameter-tlv?  empty
|         |         |         +---rw enable-manual-pseudowire?  empty
|         |         |         +---rw enable-tagged-mode         empty
|         |         |         +---rw control-channel-type?     ipi-vpws-
types:vpws_mpls_vccv_cc_type_t {feature-list:HAVE_VCCV,feature-
list:HAVE_CUSTOM1_MPLS_BFD}?
|         |         |         +---rw control-verification-type? ipi-vpws-
types:vpws_mpls_vccv_cv_type_t {feature-list:HAVE_VCCV,feature-
list:HAVE_CUSTOM1_MPLS_BFD}?
|         |         |         +---ro state
|         |         |         +---ro group-name?             string
|         |         |         +---ro group-identifier?        uint32
|         |         |         +---ro enable-control-word?     empty
|         |         |         +---ro tunnel-name?             string
|         |         |         +---ro tunnel-policy?           string {feature-
list:HAVE_SERVICE_MAPPING}?
|         |         |         +---ro tunnel-identifier?        uint32
|         |         |         +---ro enable-flow-label?        empty
|         |         |         +---ro flow-label-direction?     ipi-vpws-
types:vpws_mpls_flow_label_direction_t
|         |         |         +---ro enable-static-flow-label?  empty
|         |         |         +---ro enable-interface-parameter-tlv?  empty
|         |         |         +---ro enable-manual-pseudowire?  empty
|         |         |         +---ro enable-tagged-mode         empty
|         |         |         +---ro control-channel-type?     ipi-vpws-
types:vpws_mpls_vccv_cc_type_t {feature-list:HAVE_VCCV,feature-
list:HAVE_CUSTOM1_MPLS_BFD}?
|         |         |         +---ro control-verification-type? ipi-vpws-
types:vpws_mpls_vccv_cv_type_t {feature-list:HAVE_VCCV,feature-
list:HAVE_CUSTOM1_MPLS_BFD}?
|         |         +---rw raw

```

```

|         +---rw config!
|         |   +---rw group-name?                string
|         |   +---rw group-identifier?          uint32
|         |   +---rw enable-control-word?      empty
|         |   +---rw tunnel-name?              string
|         |   +---rw tunnel-policy?            string {feature-
list:HAVE_SERVICE_MAPPING}?
|         |   +---rw tunnel-identifier?        uint32
|         |   +---rw enable-flow-label?        empty
|         |   +---rw flow-label-direction?     ipi-vpws-
types:vpws_mpls_flow_label_direction_t
|         |   +---rw enable-static-flow-label? empty
|         |   +---rw enable-interface-parameter-tlv? empty
|         |   +---rw enable-raw-mode           empty
|         |   +---rw enable-manual-pseudowire? empty
|         |   +---rw control-channel-type?     ipi-vpws-
types:vpws_mpls_vccv_cc_type_t {feature-list:HAVE_VCCV,feature-
list:HAVE_CUSTOM1_MPLS_BFD}?
|         |   +---rw control-verification-type? ipi-vpws-
types:vpws_mpls_vccv_cv_type_t {feature-list:HAVE_VCCV,feature-
list:HAVE_CUSTOM1_MPLS_BFD}?
|         +---ro state
|         |   +---ro group-name?                string
|         |   +---ro group-identifier?          uint32
|         |   +---ro enable-control-word?      empty
|         |   +---ro tunnel-name?              string
|         |   +---ro tunnel-policy?            string {feature-
list:HAVE_SERVICE_MAPPING}?
|         |   +---ro tunnel-identifier?        uint32
|         |   +---ro enable-flow-label?        empty
|         |   +---ro flow-label-direction?     ipi-vpws-
types:vpws_mpls_flow_label_direction_t
|         |   +---ro enable-static-flow-label? empty
|         |   +---ro enable-interface-parameter-tlv? empty
|         |   +---ro enable-raw-mode           empty
|         |   +---ro enable-manual-pseudowire? empty
|         |   +---ro control-channel-type?     ipi-vpws-
types:vpws_mpls_vccv_cc_type_t {feature-list:HAVE_VCCV,feature-
list:HAVE_CUSTOM1_MPLS_BFD}?
|         |   +---ro control-verification-type? ipi-vpws-
types:vpws_mpls_vccv_cv_type_t {feature-list:HAVE_VCCV,feature-
list:HAVE_CUSTOM1_MPLS_BFD}?
+---ro access-interface-counters* [interface-name] {feature-list:HAVE_MPLS_STATS}?
| +---ro interface-name    -> ../state/interface-name
| +---ro state
|   +---ro interface-name?    -> /ipi-interface:interfaces/interface/name
|   +---ro pseudowire-identifier?  uint32
|   +---ro service-template-name?  string
|   +---ro in-packets?            uint64
|   +---ro in-bytes?              uint64
|   +---ro out-packets?           uint64
|   +---ro out-bytes?             uint64
+---ro network-interface-counters* [peer-address] {feature-list:HAVE_MPLS_STATS}?

```

```

+--ro peer-address    -> ../state/peer-address
+--ro state
  +--ro peer-address?      inet:ipv4-address
  +--ro pseudowire-identifier?  uint32
  +--ro interface-name?    -> /ipi-interface:interfaces/interface/name
  +--ro in-packets?        uint64
  +--ro in-bytes?          uint64
  +--ro out-packets?       uint64
  +--ro out-bytes?        uint64

rpcs:
  +---x pseudowire-trap-configuration {feature-list:HAVE_SNMP}?
  | +---w input
  |   +---w status-notification      boolean
  |   +---w delete-notification      boolean
  |   +---w configure-notification   cml-data-types:cml_enable_disable_t
  +---x clear-mpls-l2-circuit-statistics {feature-list:HAVE_MPLS_STATS,feature-
list:HAVE_MPLS_VC}?
  | +---w input
  |   +---w pseudowire-name      string
  +---x clear-mpls-l2-circuit-port-statistics {feature-list:HAVE_MPLS_STATS,feature-
list:HAVE_MPLS_VC}?
  | +---w input
  |   +---w port-type            ipi-vpws-types:vpws_mpls_port_type_t
  |   +---w port-pseudowire-name  string
  +---x pseudowire-manual-switchover {feature-list:HAVE_MPLS_VC}?
  | +---w input
  |   +---w primary-pseudowire    string
  |   +---w secondary-pseudowire  string

notifications:
  +---n mpls-pseudowire-up
  | +--ro severity?              cml-data-types:cml_notif_severity_t
  | +--ro eventClass?            cml-data-types:cml_notif_class_t
  | +--ro pseudowire-identifier?  uint32
  | +--ro peer-address?          ipi-vpws-types:vpws_ip_addr_t
  | +--ro instance-type?         ipi-network-instance-types:net_inst_type_t
  | +--ro instance-name?        string
  | +--ro pseudowire-state?      ipi-vpws-types:vpws_mpls_pw_state_t
  +---n mpls-pseudowire-down
  | +--ro severity?              cml-data-types:cml_notif_severity_t
  | +--ro eventClass?            cml-data-types:cml_notif_class_t
  | +--ro pseudowire-identifier?  uint32
  | +--ro peer-address?          ipi-vpws-types:vpws_ip_addr_t
  | +--ro instance-type?         ipi-network-instance-types:net_inst_type_t
  | +--ro instance-name?        string
  | +--ro pseudowire-state?      ipi-vpws-types:vpws_mpls_pw_state_t
  +---n mpls-pseudowire-deleted
  | +--ro severity?              cml-data-types:cml_notif_severity_t
  | +--ro eventClass?            cml-data-types:cml_notif_class_t
  | +--ro pseudowire-identifier?  uint32

```

```
+++ro peer-address?          ipi-vpws-types:vpws_ip_addr_t
+++ro instance-type?         ipi-network-instance-types:net_inst_type_t
+++ro instance-name?         string
+++ro pseudowire-state?     ipi-vpws-types:vpws_mpls_pw_state_t
```

module: ipi-lacp

```
+++rw lacp
  +++rw global
    | +++rw config
    | | +++rw system-priority?  uint32
    | +++ro state
    |   +++ro system-priority?  uint32
    |   +++ro system-id?        cml-data-types:cml_mac_addr_t
  +++rw debug
    | +++rw config
    | | +++rw options?          ipi-lacp-types:lacp_debug_t
    | +++ro state
    |   +++ro options?          ipi-lacp-types:lacp_debug_t
    |   +++ro terminal-debug-status? ipi-lacp-types:lacp_debug_t
  +++ro aggregators
    | +++ro aggregator* [agg-name]
    |   +++ro agg-name      -> ../state/agg-name
    |   +++ro state
    |     | +++ro agg-name?          string
    |     | +++ro interface-index?   uint32
    |     | +++ro type?              ipi-lag-types:lag_aggregator_type_t
    |     | +++ro mac-address?       cml-data-types:cml_mac_addr_t
    |     | +++ro rx-link-count?     yang:counter32
    |     | +++ro tx-link-count?     yang:counter32
    |     | +++ro individual-aggregator? ipi-lacp-types:lacp_individual_aggregator_t
    |     | +++ro aggregator-ready?  empty
    |   +++ro actor
    |     | +++ro state
    |     |   +++ro admin-key?      uint16
    |     |   +++ro oper-key?       uint16
    |     |   +++ro system-priority? uint16
    |     |   +++ro system-id?      cml-data-types:cml_mac_addr_t
    |   +++ro partner
    |     | +++ro state
    |     |   +++ro oper-key?       uint16
    |     |   +++ro system-priority? uint16
    |     |   +++ro system-id?      cml-data-types:cml_mac_addr_t
    |   +++ro members
    |     | +++ro member* [link-name]
    |     |   +++ro link-name      -> ../state/link-name
    |     |   +++ro state
```

```

|           | +--ro link-name?           string
|           | +--ro sync-state?         ipi-lacp-
types:lacp_synchronization_type_t
|           | +--ro receive-state?      ipi-lacp-types:lacp_rcv_state_t
|           | +--ro periodic-transmission-state? ipi-lacp-
types:lacp_periodic_tx_state_t
|           | +--ro mux-machine-state?   ipi-lacp-types:lacp_mux_state_t
|           | +--ro admin-key?          uint16
|           | +--ro counters
|           |   +--ro lacp-out-pkts?     yang:counter32
|           |   +--ro lacp-in-pkts?     yang:counter32
|           |   +--ro lacp-in-marker-pdu? yang:counter32
|           |   +--ro lacp-out-marker-pdu? yang:counter32
|           |   +--ro lacp-tx-errors?   yang:counter32
|           |   +--ro lacp-rx-errors?   yang:counter32
|           |   +--ro lacp-in-marker-pdu-response? yang:counter32
|           |   +--ro lacp-out-marker-pdu-response? yang:counter32
|           | +--ro actor
|           |   +--ro state
|           |     +--ro operational
|           |       +--ro activity?      ipi-lacp-types:lacp_activity_type_t
|           |       +--ro timeout?      ipi-lacp-types:lacp_timeout_type_t
|           |       +--ro aggregatable?  boolean
|           |       +--ro synchronization? ipi-lacp-
types:lacp_synchronization_type_t
|           |         +--ro collecting?   boolean
|           |         +--ro distributing? boolean
|           |         +--ro defaulted?    boolean
|           |         +--ro expired?      boolean
|           |         +--ro port-key?     uint16
|           |         +--ro admin
|           |           +--ro activity?   ipi-lacp-types:lacp_activity_type_t
|           |           +--ro timeout?   ipi-lacp-types:lacp_timeout_type_t
|           |           +--ro aggregatable? boolean
|           |           +--ro synchronization? ipi-lacp-
types:lacp_synchronization_type_t
|           |             +--ro collecting?   boolean
|           |             +--ro distributing? boolean
|           |             +--ro defaulted?    boolean
|           |             +--ro expired?      boolean
|           |             +--ro port-key?     uint16
|           |             +--ro system-id?    cml-data-types:cml_mac_addr_t
|           |             +--ro system-priority? uint16
|           |             +--ro port-number?  uint16
|           |             +--ro port-priority? uint16
|           | +--ro partner
|           |   +--ro state
|           |     +--ro operational
|           |       +--ro activity?      ipi-lacp-types:lacp_activity_type_t
|           |       +--ro timeout?      ipi-lacp-types:lacp_timeout_type_t
|           |       +--ro aggregatable?  boolean

```

```

| | | | | +---ro synchronization? ipi-lacp-
types:lacp_synchronization_type_t
| | | | | +---ro collecting? boolean
| | | | | +---ro distributing? boolean
| | | | | +---ro defaulted? boolean
| | | | | +---ro expired? boolean
| | | | | +---ro system-id? cml-data-types:cml_mac_addr_t
| | | | | +---ro system-priority? uint16
| | | | | +---ro port-number? uint16
| | | | | +---ro port-priority? uint16
| | | | | +---ro port-key? uint16
| | | | | +---ro admin
| | | | | +---ro activity? ipi-lacp-types:lacp_activity_type_t
| | | | | +---ro timeout? ipi-lacp-types:lacp_timeout_type_t
| | | | | +---ro aggregatable? boolean
| | | | | +---ro synchronization? ipi-lacp-
types:lacp_synchronization_type_t
| | | | | +---ro collecting? boolean
| | | | | +---ro distributing? boolean
| | | | | +---ro defaulted? boolean
| | | | | +---ro expired? boolean
| | | | | +---ro system-id? cml-data-types:cml_mac_addr_t
| | | | | +---ro system-priority? uint16
| | | | | +---ro port-number? uint16
| | | | | +---ro port-priority? uint16
+---rw interfaces
+---rw interface* [name]
+---rw name -> ../config/name
+---rw config
| +---rw name? -> /ipi-interface:interfaces/interface/name
+---ro state
| +---ro name? -> /ipi-interface:interfaces/interface/name
+---rw member-aggregation
| +---rw config
| | +---rw port-priority? uint32
| | +---rw timeout? ipi-lacp-types:lacp_timeout_type_t
| | +---rw bridge-type? ipi-lacp-types:lacp_bridgetype_t
| | +---rw force-up? empty
| +---ro state
| +---ro port-priority? uint32
| +---ro timeout? ipi-lacp-types:lacp_timeout_type_t
| +---ro bridge-type? ipi-lacp-types:lacp_bridgetype_t
| +---ro force-up? empty
+---rw aggregator
+---rw config
+---ro state

rpcs:
+---x lacp-snmp-restart {feature-list:HAVE_SNMP}?
+---x clear-lacp-counters {feature-list:HAVE_LAGD}?
| +----w input

```



```

|      +---w aggregate-id      uint16
+---x lacp-terminal-debug-on {feature-list:HAVE_LAGD}?
| +---w input
|      +---w terminal-debug-options      ipi-lacp-types:lacp_debug_t
+---x lacp-terminal-debug-off {feature-list:HAVE_LAGD}?
      +---w input
          +---w terminal-debug-options      ipi-lacp-types:lacp_debug_t

```

module: ipi-ldp

```

+--rw ldp
  +--rw global
    | +--rw config!
    | | +--rw ldp-instance                ipi-ldp-types:ldp_instance_t
    | | +--rw router-identifier?          inet:ipv4-address
    | | +--rw pseudowire-status-tlv?     boolean {feature-
list:HAVE_MPLS_VC}?
    | | +--rw rlfa-ilm-optimization?     boolean
    | | +--rw entropy-label-capability-enable? boolean {feature-
list:NOT_HAVE_CUSTOM1_MPLS}?
    | | +--rw multicast-hello-disable?   empty
    | | +--rw advertise-label-for-default-route? empty
    | | +--rw import-bgp-routes?        boolean
    | | +--rw ldp-optimization?         boolean
    | | +--rw explicit-null?            boolean
    | | +--rw global-merge?             ipi-ldp-types:ldp_merge_capable_t
    | | +--rw propagate-release?        boolean
    | | +--rw fast-reroute?             empty {feature-list:HAVE_LDP_LFA}?
    | | +--rw auto-targeted-session?    empty {feature-list:HAVE_LDP_LFA}?
    | +--ro state
    | | +--ro ldp-instance                ipi-ldp-types:ldp_instance_t
    | | +--ro router-identifier?          inet:ipv4-address
    | | +--ro pseudowire-status-tlv?     boolean {feature-
list:HAVE_MPLS_VC}?
    | | +--ro rlfa-ilm-optimization?     boolean
    | | +--ro entropy-label-capability-enable? boolean {feature-
list:NOT_HAVE_CUSTOM1_MPLS}?
    | | +--ro multicast-hello-disable?   empty
    | | +--ro advertise-label-for-default-route? empty
    | | +--ro import-bgp-routes?        boolean
    | | +--ro ldp-optimization?         boolean
    | | +--ro explicit-null?            boolean
    | | +--ro global-merge?             ipi-ldp-types:ldp_merge_capable_t

```

```

| | +--ro propagate-release?          boolean
| | +--ro fast-reroute?              empty {feature-list:HAVE_LDP_LFA}?
| | +--ro auto-targeted-session?     empty {feature-list:HAVE_LDP_LFA}?
| +--rw label-management
| | +--rw config
| | | +--rw control-mode?            ipi-ldp-types:ldp_controlmode_t
| | | +--rw retention-mode?         ipi-ldp-types:ldp_retention_mode_t
| | | +--rw advertisement-mode?     ipi-ldp-types:ldp_advertise_mode_t
| | +--ro state
| |   +--ro control-mode?           ipi-ldp-types:ldp_controlmode_t
| |   +--ro retention-mode?         ipi-ldp-types:ldp_retention_mode_t
| |   +--ro advertisement-mode?     ipi-ldp-types:ldp_advertise_mode_t
| +--rw timers
| | +--rw config
| | | +--rw hello-interval?         uint16
| | | +--rw hello-holdtime?        uint16
| | | +--rw keepalive-timeout?     uint16
| | | +--rw keepalive-interval?    uint16
| | +--ro state
| |   +--ro hello-interval?        uint16
| |   +--ro hello-holdtime?        uint16
| |   +--ro keepalive-timeout?     uint16
| |   +--ro keepalive-interval?    uint16
| +--rw label-request-policy
| | +--rw config
| | | +--rw request-retry-timeout?  uint16
| | | +--rw request-retry?         boolean
| | | +--rw label-request-policy-ipv4? string
| | +--ro state
| |   +--ro request-retry-timeout?  uint16
| |   +--ro request-retry?         boolean
| |   +--ro label-request-policy-ipv4? string
| +--rw loop-detection-policy
| | +--rw config!
| | | +--rw loop-detection-enable   empty
| | | +--rw path-vector-limit?     uint32
| | | +--rw hop-count-limit?       uint32
| | +--ro state
| |   +--ro loop-detection-enable   empty
| |   +--ro path-vector-limit?     uint32
| |   +--ro hop-count-limit?       uint32
| +--rw session-protection {feature-list:HAVE_LDP_SESS_PROT}?
|   +--rw config!
|   | +--rw session-protection-enable   empty
|   | +--rw duration?                  ipi-ldp-
types:ldp_sess_prot_duration_t
|   | +--rw session-protection-prefix-list-name? ipi-ldp-
types:ldp_sess_prot_pfx_lst_t
|   +--ro state
|     +--ro session-protection-enable   empty

```

```

|          +--ro duration?                               ipi-ldp-
types:ldp_sess_prot_duration_t
|          +--ro session-protection-prefix-list-name?   ipi-ldp-
types:ldp_sess_prot_pfx_lst_t
+--rw debug
|  +--rw config
|  |  +--rw ldp?    ipi-ldp-types:ldp_debug_t
|  +--ro state
|     +--ro ldp?          ipi-ldp-types:ldp_debug_t
|     +--ro terminal-debug-options? ipi-ldp-types:ldp_debug_t
+--rw graceful-restart {feature-list:HAVE_RESTART}?
|  +--rw config!
|  |  +--rw enable          ipi-ldp-types:ldp_gr_mode_t
|  |  +--rw neighbor-liveness-time? uint16
|  |  +--rw max-recovery-time?  uint16
|  +--ro state
|     +--ro enable          ipi-ldp-types:ldp_gr_mode_t
|     +--ro neighbor-liveness-time? uint16
|     +--ro max-recovery-time?  uint16
|     +--ro restart-count?    uint32
+--rw lfa {feature-list:HAVE_LDP_LFA}?
|  +--ro fecs
|     +--ro fec* [prefix-address]
|         +--ro prefix-address    -> ../state/prefix-address
|         +--ro state
|             |  +--ro prefix-address?  inet:ip-address
|         +--ro primary-paths
|             +--ro primary-path* [nexthop-address nexthop-interface-name]
|                 +--ro nexthop-address        -> ../state/nexthop-address
|                 +--ro nexthop-interface-name  -> ../state/nexthop-interface-name
|                 +--ro state
|                     |  +--ro nexthop-address?    inet:ip-address
|                     |  +--ro nexthop-interface-name? string
|                 +--ro backup-path
|                     +--ro state
|                         +--ro backup-address?    inet:ip-address
|                         +--ro backup-interface-name? string
+--rw transport-addresses
|  +--rw transport-address* [label-space-identifier]
|     +--rw label-space-identifier    -> ../config/label-space-identifier
|     +--rw config
|         |  +--rw label-space-identifier? ipi-ldp-types:ldp_label_space_identifier_t
|         |  +--rw transport-address-ipv4? inet:ipv4-address
|         +--ro state
|             +--ro label-space-identifier? ipi-ldp-types:ldp_label_space_identifier_t
|             +--ro transport-address-ipv4? inet:ipv4-address
+--rw peer-authentication
|  +--rw peer-authentication-lists
|     |  +--rw peer-authentication-list* [peer-address] {feature-
list:HAVE_TCP_MD5SIG}?
|     |  +--rw peer-address    -> ../config/peer-address

```

```

| |      +---rw config
| |      | +---rw peer-address?      ipi-ldp-types:ldp_auth_neighbor_type_t
| |      | +---rw password-type      ipi-ldp-types:ldp_md5_encrypt_password_t
| |      | +---rw password            ipi-ldp-types:ldp_md5_password_t
| |      +---ro state
| |          +---ro peer-address?      ipi-ldp-types:ldp_auth_neighbor_type_t
| |          +---ro password-type      ipi-ldp-types:ldp_md5_encrypt_password_t
| |          +---ro password            ipi-ldp-types:ldp_md5_password_t
| +---rw authentication-exclusions
| | +---rw config
| | | +---rw peer-address*      inet:ipv4-address
| | | +---ro state
| | | +---ro peer-address*      inet:ipv4-address
| +---rw authentication-groups
| | +---rw authentication-group* [group-name]
| | | +---rw group-name      -> ../config/group-name
| | | +---rw config
| | | | +---rw group-name?      string
| | | | +---rw prefix-list?      string
| | | | +---rw authentication-group-passwords
| | | | | +---rw authentication-group-password* [auth]
| | | | | +---rw auth      -> ../config/auth
| | | | | +---rw config
| | | | | | +---rw auth?      ipi-ldp-types:ldp_auth_group_type_t
| | | | | | | +---rw password-type      ipi-ldp-types:ldp_md5_encrypt_password_t
| | | | | | | +---rw password            ipi-ldp-types:ldp_md5_password_t
| | | | | | +---ro state
| | | | | | +---ro auth?      ipi-ldp-types:ldp_auth_group_type_t
| | | | | | +---ro password-type      ipi-ldp-types:ldp_md5_encrypt_password_t
| | | | | | +---ro password            ipi-ldp-types:ldp_md5_password_t
| | | | +---ro state
| | | | +---ro group-name?      string
| | | | +---ro prefix-list?      string
| +---rw label-mapping-access-lists
| | +---rw label-mapping-access-list* [peer-access-control-list-name prefix-access-
control-list-name]
| | | +---rw peer-access-control-list-name      -> ../config/peer-access-control-
list-name
| | | +---rw prefix-access-control-list-name      -> ../config/prefix-access-control-
list-name
| | | +---rw config
| | | | +---rw prefix-access-control-list-name?      string
| | | | +---rw peer-access-control-list-name?      string
| | | | +---ro state
| | | | | +---ro prefix-access-control-list-name?      string
| | | | | +---ro peer-access-control-list-name?      string
| | | | | +---ro advertisement-type?      ipi-ldp-
types:ldp_advertisement_type_t
| | | | +---ro statistics
| | | | +---ro state
| | | | +---ro label-deny-mapping?      uint32

```

```

|           +---ro label-deny-request?   uint32
+---rw tcp-mss-lists
|   +---rw tcp-mss-list* [peer-address]
|       +---rw peer-address   -> ../config/peer-address
|       +---rw config
|           | +---rw peer-address?   ipi-ldp-types:ldp_neighbor_type_t
|           | +---rw tcp-mss-range?  uint32
|       +---ro state
|           +---ro peer-address?   ipi-ldp-types:ldp_neighbor_type_t
|           +---ro tcp-mss-range?  uint32
+---rw interfaces
|   +---rw interface* [name]
|       +---rw name             -> ../config/name
|       +---rw config
|           | +---rw name?          -> /ipi-interface:interfaces/interface/
name
|           | +---rw enable-ldp-ipv4?      empty
|           | +---rw multicast-hello-disable?  empty
|           | +---rw maximum-pdu-length?    uint32
|           | +---rw ldp-igp-sync-delay-interval?  uint32
|       +---ro state
name
|           | +---ro name?          -> /ipi-interface:interfaces/interface/
|           | +---ro enable-ldp-ipv4?      empty
|           | +---ro multicast-hello-disable?  empty
|           | +---ro maximum-pdu-length?    uint32
|           | +---ro ldp-igp-sync-delay-interval?  uint32
|           | +---ro primary-address-ipv4?    string
|           | +---ro primary-address-ipv6?    string
|           | +---ro counters
|           |     +---ro packets
|           |         +---ro received
|           |             | +---ro notification?    yang:counter32
|           |             | +---ro hello?          yang:counter32
|           |             | +---ro initialization?  yang:counter32
|           |             | +---ro keepalive?      yang:counter32
|           |             | +---ro address-message? yang:counter32
|           |             | +---ro address-withdraw? yang:counter32
|           |             | +---ro label-mapping?  yang:counter32
|           |             | +---ro label-request?  yang:counter32
|           |             | +---ro label-withdraw? yang:counter32
|           |             | +---ro label-release?  yang:counter32
|           |             | +---ro request-abort?  yang:counter32
|           |             +---ro sent
|           |                 +---ro notification?  yang:counter32
|           |                 +---ro hello?        yang:counter32
|           |                 +---ro initialization? yang:counter32
|           |                 +---ro keepalive?    yang:counter32
|           |                 +---ro address-message? yang:counter32
|           |                 +---ro address-withdraw? yang:counter32
|           |                 +---ro label-mapping? yang:counter32

```

```

|   |   |   +---ro label-request?      yang:counter32
|   |   |   +---ro label-withdraw?    yang:counter32
|   |   |   +---ro label-release?     yang:counter32
|   |   |   +---ro request-abort?     yang:counter32
|   |   +---ro events
|   |       +---ro ldp-shutdown-notification-received? yang:counter32
|   |       +---ro ldp-shutdown-notification-sent?    yang:counter32
|   |       +---ro ldp-sessions-attempted?           yang:counter32
|   |       +---ro ldp-session-rejected-no-hello-errors? yang:counter32
|   |       +---ro ldp-session-rejected-advertisement-errors? yang:counter32
|   |       +---ro ldp-session-rejected-maximum-pdu-errors? yang:counter32
|   |       +---ro ldp-session-rejected-label-range-errors? yang:counter32
|   |       +---ro ldp-bad-ldp-identifier-errors?     yang:counter32
|   |       +---ro ldp-bad-pdu-length-errors?        yang:counter32
|   |       +---ro ldp-bad-message-length-errors?   yang:counter32
|   |       +---ro ldp-bad-tlv-length-errors?       yang:counter32
|   |       +---ro ldp-malformed-tlv-value-errors?  yang:counter32
|   |       +---ro ldp-keepalive-timer-expired-errors? yang:counter32
|   +---rw hello-timers
|   |   +---rw config
|   |   |   +---rw hello-interval?    uint16
|   |   |   +---rw hello-holdtime?   uint16
|   |   |   +---ro state
|   |   |       +---ro hello-interval?    uint16
|   |   |       +---ro hello-holdtime?   uint16
|   +---rw session-timers
|   |   +---rw config
|   |   |   +---rw keepalive-timeout?    uint16
|   |   |   +---rw keepalive-interval?  uint16
|   |   |   +---ro state
|   |   |       +---ro keepalive-timeout?    uint16
|   |   |       +---ro keepalive-interval?  uint16
|   +---rw label-management
|   |   +---rw config
|   |   |   +---rw interface-advertisement-mode?    ipi-ldp-
types:ldp_advertise_mode_t
|   |   |   +---rw interface-retention-mode?        ipi-ldp-types:ldp_retention_mode_t
|   |   |   +---ro state
|   |   |       +---ro interface-advertisement-mode?    ipi-ldp-types:ldp_advertise_mode_t
|   |   |       +---ro interface-retention-mode?        ipi-ldp-types:ldp_retention_mode_t
|   |   |       +---ro label-merge-capability?        ipi-ldp-
types:ldp_label_merge_capability_t
|   |   |       +---ro ldp-identifier?                string
+---ro l2vpn
|   +---ro vpls-list* [vpls-identifier] {feature-list:HAVE_VPLS}?
|   |   +---ro vpls-identifier    -> ../state/vpls-identifier
|   |   +---ro state
|   |   |   +---ro vpls-identifier?    uint32
|   |   |   +---ro mesh-vc-count?     uint32
|   |   +---ro virtual-circuit-list* [neighbor-address]
|   |       +---ro neighbor-address    -> ../state/neighbor-address

```

```

| |      +---ro state
| |          +---ro virtual-circuit-identifier?      uint32
| |          +---ro neighbor-address?                inet:ipv4-address
| |          +---ro virtual-circuit-state?           ipi-ldp-types:ldp_vc_state_t
| |          +---ro local-pseudowire-status?         uint32
| |          +---ro remote-pseudowire-status?        uint32
| |          +---ro virtual-circuit-label-sent?       uint32
| |          +---ro virtual-circuit-label-received?  uint32
| +---ro state
| | +---ro counters {feature-list:HAVE_VPLS}?
| |     +---ro total-vpls-instances?                 yang:counter32
| |     +---ro total-virtual-circuit-instances?      yang:counter32
| |     +---ro active-virtual-circuit-instances?     yang:counter32
| |     +---ro inactive-virtual-circuit-instances?   yang:counter32
| +---ro virtual-circuit-list* [virtual-circuit-identifier] {feature-
list:HAVE_MPLS_VC}?
| |     +---ro virtual-circuit-identifier    -> ../state/virtual-circuit-identifier
| |     +---ro state
| |         +---ro virtual-circuit-identifier?      uint32
| |         +---ro neighbor-address?                inet:ipv4-address
| |         +---ro virtual-circuit-state?           ipi-ldp-types:ldp_vc_state_t
| |         +---ro local-pseudowire-status?         uint32
| |         +---ro remote-pseudowire-status?        uint32
| |         +---ro virtual-circuit-label-sent?       uint32
| |         +---ro virtual-circuit-label-received?  uint32
+---rw targeted-peers
| +---rw global-timers
| | +---rw config
| | | +---rw targeted-global-hello-interval?      uint16
| | | +---rw targeted-global-hello-holdtime?     uint16
| | | +---ro state
| | |     +---ro targeted-global-hello-interval?   uint16
| | |     +---ro targeted-global-hello-holdtime?   uint16
| +---rw targeted-peer* [target-address]
| | +---rw target-address    -> ../config/target-address
| | +---rw config
| | | +---rw target-address?  ipi-ldp-types:ldp_ip_addr_t
| | | +---rw hello-interval?  uint16
| | | +---rw hello-holdtime?  uint16
| | | +---ro state
| | |     +---ro target-address?  ipi-ldp-types:ldp_ip_addr_t
| | |     +---ro hello-interval?  uint16
| | |     +---ro hello-holdtime?  uint16
| | |     +---ro counters
| | |         +---ro packets
| | |         | +---ro received
| | |         | | +---ro notification?      yang:counter32
| | |         | | +---ro hello?            yang:counter32
| | |         | | +---ro initialization?    yang:counter32
| | |         | | +---ro keepalive?        yang:counter32
| | |         | | +---ro address-message?   yang:counter32

```

```

|         | | +--ro address-withdraw?   yang:counter32
|         | | +--ro label-mapping?     yang:counter32
|         | | +--ro label-request?     yang:counter32
|         | | +--ro label-withdraw?    yang:counter32
|         | | +--ro label-release?     yang:counter32
|         | | +--ro request-abort?     yang:counter32
|         | +--ro sent
|         |   +--ro notification?       yang:counter32
|         |   +--ro hello?              yang:counter32
|         |   +--ro initialization?     yang:counter32
|         |   +--ro keepalive?         yang:counter32
|         |   +--ro address-message?   yang:counter32
|         |   +--ro address-withdraw?  yang:counter32
|         |   +--ro label-mapping?     yang:counter32
|         |   +--ro label-request?     yang:counter32
|         |   +--ro label-withdraw?    yang:counter32
|         |   +--ro label-release?     yang:counter32
|         |   +--ro request-abort?     yang:counter32
|         +--ro events
|           +--ro ldp-shutdown-notification-received? yang:counter32
|           +--ro ldp-shutdown-notification-sent?    yang:counter32
|           +--ro ldp-sessions-attempted?            yang:counter32
|           +--ro ldp-session-rejected-no-hello-errors? yang:counter32
|           +--ro ldp-session-rejected-advertisement-errors? yang:counter32
|           +--ro ldp-session-rejected-maximum-pdu-errors? yang:counter32
|           +--ro ldp-session-rejected-label-range-errors? yang:counter32
|           +--ro ldp-bad-ldp-identifier-errors?      yang:counter32
|           +--ro ldp-bad-pdu-length-errors?         yang:counter32
|           +--ro ldp-bad-message-length-errors?    yang:counter32
|           +--ro ldp-bad-tlv-length-errors?        yang:counter32
|           +--ro ldp-malformed-tlv-value-errors?   yang:counter32
|           +--ro ldp-keepalive-timer-expired-errors? yang:counter32
+--ro peers
  +--ro peer* [peer-address]
    +--ro peer-address      -> ../state/peer-address
    +--ro adjacency-list* [adjacency-prefix]
      | +--ro adjacency-prefix  -> ../state/adjacency-prefix
      | +--ro state
      |   +--ro adjacency-prefix?  inet:ipv4-address
      |   +--ro is-targeted-peer?  boolean
      |   +--ro name?              -> /ipi-interface:interfaces/interface/name
      |   +--ro local-address?     inet:ipv4-address
    +--ro received-label-list* [fec-prefix]
      | +--ro fec-prefix      -> ../state/fec-prefix
      | +--ro state
      |   +--ro fec-prefix?     cml-data-types:cml_ipv4_addr_prefix_t
      |   +--ro label?         string
    +--ro sent-label-list* [fec-prefix]
      | +--ro fec-prefix      -> ../state/fec-prefix
      | +--ro state

```



```

|      +---ro fec-prefix?   cml-data-types:cml_ipv4_addr_prefix_t
|      +---ro label?       string
+---ro state
    +---ro peer-address?   inet:ipv4-address
    +---ro ldp-identifier? string
    +---ro label-space?    uint16
    +---ro keepalive-timeout? uint32
    +---ro session-up-time? string
    +---ro session-state?  ipi-ldp-
types:ldp_session_state_t
    +---ro session-role?   ipi-ldp-
types:ldp_session_role_t
    +---ro advertisement-mode? ipi-ldp-
types:ldp_advertise_mode_t
    +---ro retention-mode?   ipi-ldp-
types:ldp_retention_mode_t
    +---ro tcp-established? ipi-ldp-
types:ldp_tcp_status_t
    +---ro ldp-interface-name? string
    +---ro discontinuity-time? uint32
    +---ro unknown-message-type-errors? uint32
    +---ro unknown-tlv-type-errors?   uint32
    +---ro initialization-session-threshold-limit? uint32
    +---ro entity-path-vector-limit?   uint32
    +---ro peer-path-vector-limit?     uint32
    +---ro session-protection-status?  ipi-ldp-
types:ldp_sess_prot_status_t {feature-list:HAVE_LDP_SESS_PROT}?

rpcs:
+---x clear-ldp-statistics {feature-list:HAVE_LDPPD}?
+---x clear-ldp-statistics-advertise-labels {feature-list:HAVE_LDPPD}?
+---x clear-ldp-statistics-advertise-labels-prefix {feature-list:HAVE_LDPPD}?
| +---w input
|   +---w prefix   string
+---x clear-ldp-statistics-advertise-labels-prefix-peer {feature-list:HAVE_LDPPD}?
| +---w input
|   +---w prefix   string
|   +---w peer     string
+---x clear-ldp-session-all {feature-list:HAVE_LDPPD}?
+---x clear-ldp-session-ipv4 {feature-list:HAVE_LDPPD}?
| +---w input
|   +---w addr     inet:ipv4-address
+---x clear-ldp-adjacency-all {feature-list:HAVE_LDPPD}?
+---x clear-ldp-adjacency-ipv4 {feature-list:HAVE_LDPPD}?
| +---w input
|   +---w addr     inet:ipv4-address
+---x snmp-restart-ldp {feature-list:HAVE_SNMP}?
+---x ldp-terminal-debug-on {feature-list:HAVE_LDPPD}?
| +---w input
|   +---w terminal-debug-options ipi-ldp-types:ldp_debug_t
+---x ldp-terminal-debug-off {feature-list:HAVE_LDPPD}?
| +---w input

```

```

| +---w terminal-debug-options      ipi-ldp-types:ldp_debug_t
+---x restart-ldp-graceful {feature-list:HAVE_RESTART}?

```

notifications:

```

+---n mpls-ldp-session-up
| +--ro severity?                  cml-data-types:cml_notif_severity_t
| +--ro eventClass?               cml-data-types:cml_notif_class_t
| +--ro peer-address?             inet:ipv4-address
| +--ro session-state?            ipi-ldp-types:ldp_session_state_t
| +--ro discontinuity-time?       uint32
| +--ro unknown-message-type-errors? uint32
| +--ro unknown-tlv-type-errors?  uint32
+---n mpls-ldp-session-down
| +--ro severity?                  cml-data-types:cml_notif_severity_t
| +--ro eventClass?               cml-data-types:cml_notif_class_t
| +--ro peer-address?             inet:ipv4-address
| +--ro session-state?            ipi-ldp-types:ldp_session_state_t
| +--ro discontinuity-time?       uint32
| +--ro unknown-message-type-errors? uint32
| +--ro unknown-tlv-type-errors?  uint32
+---n mpls-ldp-init-session-threshold-exceeded
| +--ro severity?                  cml-data-types:cml_notif_severity_t
| +--ro eventClass?               cml-data-types:cml_notif_class_t
| +--ro peer-address?             inet:ipv4-address
| +--ro initialization-session-threshold-limit? uint32
+---n mpls-ldp-path-vector-limit-mismatch
  +--ro severity?                  cml-data-types:cml_notif_severity_t
  +--ro eventClass?               cml-data-types:cml_notif_class_t
  +--ro peer-address?             inet:ipv4-address
  +--ro entity-path-vector-limit?  uint32
  +--ro peer-path-vector-limit?    uint32

```

module: ipi-lldpv2

```

+--rw lldp
  +--rw global
    | +--rw config
    | | +--rw enable?              empty
    | | +--rw notification-interval? uint16 {feature-list:HAVE_SNMP}?
    | +--ro state
    | | +--ro enable?              empty
    | | +--ro notification-interval? uint16 {feature-list:HAVE_SNMP}?
    | | +--ro system-capabilities-enabled? cml-data-types:cml_line_t
    | | +--ro host-name-information? string
    | | +--ro counters
    | | +--ro remote-inserts?      yang:counter32

```

```

| |      +---ro remote-deletes?   yang:counter32
| |      +---ro remote-drops?     yang:counter32
| |      +---ro remote-ageouts?   yang:counter32
| +---rw global-tlv-control
| |   +---rw global-basic-management
| | |   +---rw config
| | | |  +---rw port-description?   empty
| | | |  +---rw system-description? empty
| | | |  +---rw system-name?       empty
| | | |  +---rw system-capabilities? empty
| | | |  +---rw management-address? empty
| | |   +---ro state
| | | |  +---ro port-description?   empty
| | | |  +---ro system-description? empty
| | | |  +---ro system-name?       empty
| | | |  +---ro system-capabilities? empty
| | | |  +---ro management-address? empty
| |   +---rw global-ieee-8021-org-specific
| | |   +---rw config
| | | |  +---rw port-vlan-id?       empty
| | | |  +---rw port-protocol-vlan-id? empty
| | | |  +---rw vlan-name?         empty
| | | |  +---rw protocol-identifier? empty
| | | |  +---rw vid-digest?        empty
| | | |  +---rw management-vlan-id? empty
| | | |  +---rw link-aggregation?   empty
| | |   +---ro state
| | | |  +---ro port-vlan-id?       empty
| | | |  +---ro port-protocol-vlan-id? empty
| | | |  +---ro vlan-name?         empty
| | | |  +---ro protocol-identifier? empty
| | | |  +---ro vid-digest?        empty
| | | |  +---ro management-vlan-id? empty
| | | |  +---ro link-aggregation?   empty
| |   +---rw global-ieee-8023-org-specific
| | |   +---rw config
| | | |  +---rw mac-phy?           empty
| | | |  +---rw max-mtu-size?     empty
| | |   +---ro state
| | | |  +---ro mac-phy?           empty
| | | |  +---ro max-mtu-size?     empty
| +---rw management-if
| |   +---rw config
| | |   +---rw locally-assigned-chassis-id? string
| | |   +---ro state
| | | |  +---ro locally-assigned-chassis-id? string
+---rw debug
| +---rw config
| |   +---rw options?   ipi-lldp-types:lldp_debug_t
| |   +---ro state

```

```
|     +--ro options?                ipi-lldp-types:lldp_debug_t
|     +--ro terminal-debug-status?  ipi-lldp-types:lldp_debug_t
+--rw interfaces
  +--rw interface* [name]
    +--rw name                    -> ../config/name
    +--rw config
      | +--rw name?                -> /ipi-interface:interfaces/interface/name
      | +--rw disable-lldp-agent?  empty
      | +--rw agent-circuit-id?    string
      | +--rw med-device-type?     ipi-lldp-types:lldp_meddev_t
      | +--rw local-name?         string
    +--ro state
      | +--ro name?               -> /ipi-interface:interfaces/interface/name
      | +--ro disable-lldp-agent?  empty
      | +--ro agent-circuit-id?    string
      | +--ro med-device-type?     ipi-lldp-types:lldp_meddev_t
      | +--ro local-name?         string
    +--ro neighbors
      | +--ro agent* [agent-type]
      |   +--ro agent-type        ipi-lldp-types:lldp_agent_t
      |   +--ro neighbor* [mac-address]
      |     +--ro mac-address      -> ../state/mac-address
      |     +--ro state
      |       +--ro mac-address?   cml-data-types:cml_mac_addr_t
      |       +--ro system-name?   string
      |       +--ro chassis-component? string
      |       +--ro chassis-id-type? uint8
      |       +--ro port-component? string
      |       +--ro port-id?       string
      |       +--ro port-description? string
      |       +--ro port-sub-type?  uint16
      |       +--ro interface-alias? string
      |       +--ro interface-agent-circuit-id? string
      |       +--ro ttl?           uint16
      |       +--ro interface-number? uint32
      |       +--ro interface-number-sub-type? string
      |       +--ro port-vlan-id?   uint16
      |       +--ro pp-vlanid?     uint16
      |     +--ro protocol?        ipi-lldp-types:lldp_protoid_t
      |       +--ro vid-usage-digest? uint32
      |       +--ro management-vlan?  uint16
      |       +--ro auto-negotiation-support? uint8
      |       +--ro auto-negotiation-capability? uint16
      |       +--ro operational-mau-type? uint16
      |       +--ro link-aggregate-capability? cml-data-types:cml_line_t
      |       +--ro link-aggregate-id? uint32
      |       +--ro max-frame-size?  uint16
      |       +--ro system-description? string
      |       +--ro system-capabilities? cml-data-types:cml_line_t
      |       +--ro system-capabilities-enabled? cml-data-types:cml_line_t
```

```

|         +---ro vlan-list* [vlan-id]
|         |   +---ro vlan-id      uint16
|         |   +---ro vlan-name?   string
|         +---ro management-list* [address]
|             +---ro address                string
|             +---ro address-sub-type?      cml-data-types:cml_line_t
|             +---ro interface-number-sub-type? string
|             +---ro interface-number?      uint32
|             +---ro oid?                   string
+---rw agents
  +---rw agent* [agent-type]
    +---rw agent-type      -> ../config/agent-type
    +---rw config
      | +---rw agent-type?    ipi-lldp-types:lldp_agent_t
      | +---rw enable-tx-rx?  ipi-lldp-types:lldp_enable_t
    +---ro state
      | +---ro agent-type?    ipi-lldp-types:lldp_agent_t
      | +---ro enable-tx-rx?  ipi-lldp-types:lldp_enable_t
    +---rw transmit
      | +---rw config
      | | +---rw reinit-delay?          uint32
      | | +---rw message-tx-interval?   uint32
      | | +---rw message-tx-hold-multiplier? uint32
      | | +---rw message-fast-tx?       uint32
      | | +---rw tx-credit-max?         uint32
      | | +---rw tx-fast-init?          uint32
      | +---ro state
      |   +---ro reinit-delay?          uint32
      |   +---ro message-tx-interval?   uint32
      |   +---ro message-tx-hold-multiplier? uint32
      |   +---ro message-fast-tx?       uint32
      |   +---ro tx-credit-max?         uint32
      |   +---ro tx-fast-init?          uint32
      |   +---ro tx-ttl?                uint16
      |   +---ro counters
      |     +---ro frames-out?          yang:counter32
    +---rw receive
      | +---rw config
      | | +---rw neighbor-limit?        uint32
      | | +---rw neighbor-timer?        uint32
      | | +---rw port-mac?              cml-data-types:cml_mac_addr_t
      | | +---rw port-timer?            uint32
      | +---ro state
      |   +---ro neighbor-limit?        uint32
      |   +---ro neighbor-timer?        uint32
      |   +---ro port-mac?              cml-data-types:cml_mac_addr_t
      |   +---ro port-timer?            uint32
      |   +---ro frames-aged-out?        yang:counter32
      |   +---ro frames-discarded?      yang:counter32
      |   +---ro frames-invalid?        yang:counter32

```

```

|      +--ro frames-valid?          yang:counter32
|      +--ro tlvs-discarded?       yang:counter32
|      +--ro tlvs-unrecognized?    yang:counter32
+--rw agent-tlv
|  +--rw config
|  |  +--rw port-address?          ipi-lldp-types:lldp_mgmt_addr_t
|  |  +--rw chassis-id?           ipi-lldp-types:lldp_chassis_t
|  |  +--rw port-id?              ipi-lldp-types:lldp_port_t
|  +--ro state
|  |  +--ro port-address?          ipi-lldp-types:lldp_mgmt_addr_t
|  |  +--ro chassis-id?           ipi-lldp-types:lldp_chassis_t
|  |  +--ro port-id?              ipi-lldp-types:lldp_port_t
+--rw tlv-control
    +--rw basic-management
    |  +--rw config
    |  |  +--rw port-description?    ipi-lldp-types:lldp_tlv_select_type
    |  |  +--rw system-description? ipi-lldp-
types:lldp_tlv_select_type
    |  |  +--rw system-name?         ipi-lldp-types:lldp_tlv_select_type
    |  |  +--rw system-capabilities? ipi-lldp-
types:lldp_tlv_select_type
    |  |  +--rw management-address?  ipi-lldp-
types:lldp_tlv_select_type
    |  +--ro state
    |  |  +--ro port-description?    ipi-lldp-types:lldp_tlv_select_type
    |  |  +--ro system-description?  ipi-lldp-types:lldp_tlv_select_type
    |  |  +--ro system-name?         ipi-lldp-types:lldp_tlv_select_type
    |  |  +--ro system-capabilities? ipi-lldp-
types:lldp_tlv_select_type
    |  |  +--ro management-address?  ipi-lldp-types:lldp_tlv_select_type
    +--rw ieee-8021-org-specific
    |  +--rw config
    |  |  +--rw port-vlan-id?        ipi-lldp-
types:lldp_tlv_select_type
    |  |  +--rw port-protocol-vlan-id? ipi-lldp-
types:lldp_tlv_select_type
    |  |  +--rw vlan-name?          ipi-lldp-
types:lldp_tlv_select_type
    |  |  +--rw protocol-identifier? ipi-lldp-
types:lldp_tlv_select_type
    |  |  +--rw vid-digest?         ipi-lldp-
types:lldp_tlv_select_type
    |  |  +--rw management-vlan-id?  ipi-lldp-
types:lldp_tlv_select_type
    |  |  +--rw link-aggregation?    ipi-lldp-
types:lldp_tlv_select_type
    |  +--ro state
    |  |  +--ro port-vlan-id?        ipi-lldp-
types:lldp_tlv_select_type
    |  |  +--ro port-protocol-vlan-id? ipi-lldp-
types:lldp_tlv_select_type
    |  |  +--ro vlan-name?          ipi-lldp-
types:lldp_tlv_select_type

```

```

|      +--ro protocol-identifier?      ipi-lldp-
types:lldp_tlv_select_type
|      +--ro vid-digest?                ipi-lldp-
types:lldp_tlv_select_type
|      +--ro management-vlan-id?       ipi-lldp-
types:lldp_tlv_select_type
|      +--ro link-aggregation?         ipi-lldp-
types:lldp_tlv_select_type
+--rw ieee-8023-org-specific
| +--rw config
| | +--rw mac-phy?                      ipi-lldp-types:lldp_tlv_select_type
| | +--rw max-mtu-size?                ipi-lldp-types:lldp_tlv_select_type
| +--ro state
|   +--ro mac-phy?                      ipi-lldp-types:lldp_tlv_select_type
|   +--ro max-mtu-size?                ipi-lldp-types:lldp_tlv_select_type
+--rw tlv-media-capabilities
  +--rw config
  | +--rw network-policy?               ipi-lldp-types:lldp_tlv_select_type
  | +--rw location?                    ipi-lldp-types:lldp_tlv_select_type
  | +--rw inventory?                   ipi-lldp-types:lldp_tlv_select_type
  | +--rw media-capabilities?          ipi-lldp-types:lldp_tlv_select_type
  +--ro state
    +--ro network-policy?               ipi-lldp-types:lldp_tlv_select_type
    +--ro location?                     ipi-lldp-types:lldp_tlv_select_type
    +--ro inventory?                     ipi-lldp-types:lldp_tlv_select_type
    +--ro media-capabilities?           ipi-lldp-types:lldp_tlv_select_type

```

rpcs:

```

+---x lldp-terminal-debug-on {feature-list:HAVE_ONMD,feature-list:HAVE_LLDPV2}?
| +---w input
|   +---w terminal-debug-options      ipi-lldp-types:lldp_debug_t
+---x lldp-terminal-debug-off {feature-list:HAVE_ONMD,feature-list:HAVE_LLDPV2}?
| +---w input
|   +---w terminal-debug-options      ipi-lldp-types:lldp_debug_t
+---x clear-lldp-counter {feature-list:HAVE_ONMD,feature-list:HAVE_LLDPV2}?
| +---w input
|   +---w interface-name?            string
+---x lldp-snmp-restart {feature-list:HAVE_SNMP}?

```

notifications:

```

+---n lldp-remote-inserts-notification
| +--ro severity?                      cml-data-types:cml_notif_severity_t
| +--ro eventClass?                    cml-data-types:cml_notif_class_t
| +--ro remote-inserts?                yang:counter32
+---n lldp-remote-deletes-notification
  +--ro severity?                      cml-data-types:cml_notif_severity_t
  +--ro eventClass?                    cml-data-types:cml_notif_class_t
  +--ro remote-deletes?                yang:counter32

```

module: ipi-logging

```
+--rw logging
  +--rw logging-modules
    | +--rw module-logging* [module-name]
    |   +--rw module-name    -> ../config/module-name
    |   +--rw config
    |     | +--rw module-name?      ipi-logging-types:module_names_t
    |     | +--rw severity-level    ipi-logging-types:log_severity_t
    |     +--ro state
    |       +--ro module-name?      ipi-logging-types:module_names_t
    |       +--ro severity-level    ipi-logging-types:log_severity_t
  +--rw monitor-logging
    | +--rw config!
    | | +--rw enable-logging      cml-data-types:cml_enable_disable_t
    | | +--rw severity-level?    ipi-logging-types:log_severity_t
    | +--ro state
    |   +--ro enable-logging      cml-data-types:cml_enable_disable_t
    |   +--ro severity-level?    ipi-logging-types:log_severity_t
  +--rw console-logging
    | +--rw config!
    | | +--rw enable-logging      cml-data-types:cml_enable_disable_t
    | | +--rw severity-level?    ipi-logging-types:log_severity_t
    | +--ro state
    |   +--ro enable-logging      cml-data-types:cml_enable_disable_t
    |   +--ro severity-level?    ipi-logging-types:log_severity_t
  +--rw logfile
    | +--rw config!
    | | +--rw file-name          string
    | | +--rw severity-level    ipi-logging-types:log_severity_t
    | | +--rw max-file-size     uint32
    | +--ro state
    |   +--ro file-name          string
    |   +--ro severity-level    ipi-logging-types:log_severity_t
    |   +--ro max-file-size     uint32
  +--rw debug-logfile
    | +--rw config!
    | | +--rw file-name          string
    | | +--rw max-file-size     uint32
    | +--ro state
    |   +--ro file-name          string
    |   +--ro max-file-size     uint32
  +--rw syslog {feature-list:HAVE_SYSLOG}?
    | +--rw config
    | | +--rw enable-syslog?      empty
    | | +--rw timestamp-granularity? ipi-logging-types:timestamp_units_t
```



```

|   +--ro state
|     +--ro enable-syslog?          empty
|     +--ro timestamp-granularity?  ipi-logging-types:timestamp_units_t
+--rw remote-logging
|   +--rw rsyslog* [vrf]
|     +--rw vrf                    -> ../config/vrf
|     +--rw config
|       | +--rw vrf?                -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name
|       | +--rw enable-rsyslog      boolean
|       +--ro state
|         | +--ro vrf?              -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name
|         | +--ro enable-rsyslog    boolean
|         +--rw remote-servers
|           +--rw remote-server* [address]
|             +--rw address        -> ../config/address
|             +--rw config
|               | +--rw address?    cml-data-types:cml_hostname_t
|               | +--rw severity    ipi-logging-types:log_severity_t
|               | +--rw port?       uint16
|               +--ro state
|                 +--ro address?    cml-data-types:cml_hostname_t
|                 +--ro severity    ipi-logging-types:log_severity_t
|                 +--ro port?       uint16
+--rw global
|   +--rw config
|     | +--rw remote-server-facility? ipi-logging-types:log_facility_t
|     +--ro state
|       +--ro remote-server-facility? ipi-logging-types:log_facility_t
+--rw cli-logging
|   +--rw config
|     | +--rw enable-logging?      empty
|     +--ro state
|       | +--ro enable-logging?    empty
|       +--rw max-session-limit
|         +--rw config
|           | +--rw max-session-limit? uint8
|           +--ro state
|             +--ro max-session-limit? uint8
+--rw fault-management
  +--rw config
    | +--rw enable-fault-management? empty
  +--ro state
    +--ro enable-fault-management? empty

rpcs:
+---x logging-fms-flush-db {feature-list:HAVE_FMS}?
+---x logging-fms-shelve {feature-list:HAVE_FMS}?
| +---w input
|   +---w alarm-type      string

```

```

+---x logging-fms-close {feature-list:HAVE_FMS}?
| +---w input
|   +---w active-alarm-id    string
+---x terminal-debug-all-off
+---x logging-clear-debug-logfile
+---x logging-clear-logging-logfile
+---x remove-file
    +---w input
        +---w file_type      ipi-logging-types:remove_files_t
        +---w filename       ipi-logging-types:file_type_t

```

module: ipi-management-server

```

+--rw netconf-server {feature-list:HAVE_NETCONF}?
| +--rw callhome {feature-list:HAVE_NETCONF}?
| | +--rw config!
| | | +--rw feature-enabled    empty
| | | +--rw management-port?  -> /ipi-interface:interfaces/interface/name
| | | +--ro state
| | | +--ro feature-enabled    empty
| | | +--ro management-port?  -> /ipi-interface:interfaces/interface/name
| | | +--rw netconf-clients
| | | | +--rw netconf-client* [name]
| | | | | +--rw name          -> ../config/name
| | | | | +--rw config
| | | | | | +--rw name?       string
| | | | | | +--rw address    string
| | | | | | +--rw port?      inet:port-number
| | | | | +--ro state
| | | | | | +--ro name?       string
| | | | | | +--ro address    string
| | | | | | +--ro port?      inet:port-number
| | | +--rw reconnect
| | | | +--rw config!
| | | | | +--rw enable          empty
| | | | | +--rw retry-max-attempts?  uint8
| | | | | +--rw retry-interval?    uint32
| | | | +--ro state
| | | | | +--ro enable          empty
| | | | | +--ro retry-max-attempts?  uint8
| | | | | +--ro retry-interval?    uint32
| | +--rw netconf-translation {feature-list:HAVE_NETCONF_OC_TRANSLATION}?
| | | +--rw config
| | | | +--rw translation-mode?  ipi-management-server-
types:management_server_translation_type_t
| | | +--ro state

```

```

| |      +---ro translation-mode?  ipi-management-server-
types:management_server_translation_type_t
| +---rw debug
| | +---rw config
| | | +---rw enable?  empty
| | +---ro state
| |   +---ro enable?  empty
| +---rw vrfs {feature-list:HAVE_VRF}?
|   +---rw vrf* [vrf-name]
|     +---rw vrf-name          -> ../config/vrf-name
|     +---rw config
|       | +---rw vrf-name?  -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
|       +---ro state
|         | +---ro vrf-name?  -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
|         +---rw netconf-ssh-config
|           | +---rw config!
|           | | +---rw feature-netconf-ssh  boolean {feature-list:HAVE_NETCONF}?
|           | | +---rw ssh-port?          uint32 {feature-list:HAVE_NETCONF}?
|           | +---ro state
|           |   +---ro feature-netconf-ssh  boolean {feature-list:HAVE_NETCONF}?
|           |   +---ro ssh-port?          uint32 {feature-list:HAVE_NETCONF}?
|           +---rw netconf-tls-config
|             +---rw config!
|             | +---rw feature-netconf-tls  boolean {feature-list:HAVE_NETCONF}?
|             | +---rw tls-port?          uint32 {feature-list:HAVE_NETCONF}?
|             +---ro state
|               +---ro feature-netconf-tls  boolean {feature-list:HAVE_NETCONF}?
|               +---ro tls-port?          uint32 {feature-list:HAVE_NETCONF}?
+---rw management-server
  +---rw module-notifications
    +---rw module-notification* [module-name]
      +---rw module-name  -> ../config/module-name
      +---rw config
        | +---rw module-name?  ipi-management-server-notification-
types:notif_module_names_t
        | +---rw enable      cml-data-types:cml_enable_disable_t
        | +---rw severity?   cml-data-types:cml_notif_severity_t
        +---ro state
          +---ro module-name?  ipi-management-server-notification-
types:notif_module_names_t
          +---ro enable      cml-data-types:cml_enable_disable_t
          +---ro severity?   cml-data-types:cml_notif_severity_t

notifications:
+---n suppress-bulk-notification
  +---ro severity?   cml-data-types:cml_notif_severity_t
  +---ro eventClass? cml-data-types:cml_notif_class_t
  +---ro message?   string

```

module: ipi-mcec

```

+--rw mcec
  +--rw debug
    | +--rw config
    | | +--rw options?    ipi-mcec-types:mcec_debug_t
    | +--ro state
    | | +--ro options?          ipi-mcec-types:mcec_debug_t
    | | +--ro terminal-debug-status? ipi-mcec-types:mcec_debug_t
  +--rw domain
    | +--rw config
    | | +--rw system-number?    uint8
    | | +--rw address?          ipi-mcec-types:mcec_domain_addr_t
    | | +--rw priority?         uint16
    | | +--rw hello-timeout?    ipi-mcec-types:mcec_hello_t
    | +--ro state
    | | +--ro system-number?      uint8
    | | +--ro address?            ipi-mcec-types:mcec_domain_addr_t
    | | +--ro priority?          uint16
    | | +--ro hello-timeout?     ipi-mcec-types:mcec_hello_t
    | | +--ro domain-sync?       ipi-mcec-types:mcec_domain_sync_status_t
    | | +--ro domain-adjacency?  ipi-mcec-types:mcec_domain_adjacency_state_t
    | | +--ro mcec-invalid-pdu-rx? uint32
  +--ro mcec-instance* [mlag-id]
    | +--ro mlag-id    -> ../state/mlag-id
    | +--ro state
    | | +--ro mlag-id?                uint16
    | | +--ro interface?              string
    | | +--ro administrative-aggregation-key? uint16
    | | +--ro operational-aggregation-key? uint16
    | | +--ro physical-properties-digest? string
    | | +--ro operational-partner-aggregation-key? uint16
    | | +--ro partner-system?         string
    | | +--ro partner-system-priority? uint16
    | | +--ro member-interface-bandwidth? string
    | | +--ro member-interface-state?  ipi-mcec-types:mcec_if_state_t
    | | +--ro mlag-sync?              ipi-mcec-types:mcec_sync_state_t
    | | +--ro flood-enabled?          ipi-mcec-types:mcec_flood_state_t
    | | +--ro mlag-port-state?        ipi-mcec-types:mcec_if_state_t
    | | +--ro mlag-interface-state?   ipi-mcec-types:mcec_if_state_t
    | | +--ro aggregation-mapped?     boolean
    | | +--ro mlag-bandwidth?         string
    | | +--ro info-receive-state?     ipi-mcec-
types:mcec_info_receive_state_t
    | | +--ro info-periodic-tx-state? ipi-mcec-
types:mcec_info_periodic_tx_state_t
    | | +--ro valid-info-pdu-rx?      uint32
    | | +--ro valid-info-pdu-tx?      uint32

```

```

|   +--ro neighbor
|     +--ro state
|       +--ro administrative-aggregation-key?      uint16
|       +--ro physical-properties-digest?         string
|       +--ro operational-partner-aggregation-key? uint16
|       +--ro partner-system?                     string
|       +--ro partner-system-priority?            uint16
|       +--ro member-interface-bandwidth?        string
|       +--ro member-interface-state?             ipi-mcec-types:mcec_if_state_t
|       +--ro mlag-sync?                          ipi-mcec-types:mcec_sync_state_t
+--rw intra-domain
|   +--rw peer-link
|     | +--rw config
|     | | +--rw interface?  -> /ipi-interface:interfaces/interface/name
|     | | +--ro state
|     | |   +--ro interface?  -> /ipi-interface:interfaces/interface/name
|     | +--rw peer-address
|     | | +--rw config!
|     | | | +--rw peer-address    inet:ipv4-address
|     | | | +--rw local-address   inet:ipv4-address
|     | | | +--rw vrf             -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
|     | | +--ro state
|     | | | +--ro peer-address    inet:ipv4-address
|     | | | +--ro local-address   inet:ipv4-address
|     | | | +--ro vrf             -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
|     | +--ro neighbor-info
|     | | +--ro state
|     | | | +--ro domain-address?    ipi-mcec-types:mcec_domain_addr_t
|     | | | +--ro domain-priority?   uint32
|     | | | +--ro domain-system-number? uint16
|     | | | +--ro domain-sync?       ipi-mcec-types:mcec_domain_sync_status_t
|     | | | +--ro hello-timeout?     uint16
|     | +--ro intra-domain-peer-info
|     | | +--ro state
|     | | | +--ro mcec-hello-periodic-tx-state? ipi-mcec-
types:mcec_hello_periodic_tx_state_t
|     | | | +--ro mcec-valid-hello-pdu-rx?    uint32
|     | | | +--ro mcec-valid-hello-pdu-tx?    uint32
|     | | | +--ro mcec-valid-info-pdu-rx?     uint32
|     | | | +--ro mcec-valid-info-pdu-tx?     uint32
|     | | | +--ro mcec-valid-mac-sync-pdu-rx? uint32
|     | | | +--ro mcec-valid-mac-sync-pdu-tx? uint32
+--ro mac-sync
|   +--ro local-mac-table* [mac-address vlan-id]
|     | +--ro mac-address  -> ../state/mac-address
|     | +--ro vlan-id      -> ../state/vlan-id
|     | +--ro state
|     | | +--ro mac-address?    string
|     | | +--ro vlan-id?       uint16

```

```

| |      +---ro output-interface?  string
| +---ro remote-mac-table* [mac-address vlan-id]
|   +---ro mac-address      -> ../state/mac-address
|   +---ro vlan-id         -> ../state/vlan-id
|   +---ro state
|     +---ro mac-address?      string
|     +---ro vlan-id?         uint16
|     +---ro output-interface? string
+---ro stp-sync
| +---ro state
| | +---ro bridge-priority?    uint16
| | +---ro path-cost-method?  uint8
| | +---ro domain-digest?     string
| | +---ro neighbor-domain-digest? string
| +---ro mlag-interface-sync-entry* [mlag-id]
|   +---ro mlag-id      -> ../state/mlag-id
|   +---ro state
|     +---ro mlag-id?      uint16
|     +---ro port-priority? uint16
|     +---ro path-cost?   uint32
|     +---ro interface-digest? string
|     +---ro neighbor-interface-digest? string
+---rw mlag-interfaces
  +---rw mlag-interface* [name]
    +---rw name          -> ../config/name
    +---rw config
    | +---rw name?      -> /ipi-interface:interfaces/interface/name
    | +---rw interface-mode? ipi-mcec-types:mcec_mode_type_t
    +---ro state
    | +---ro name?      -> /ipi-interface:interfaces/interface/name
    | +---ro interface-mode? ipi-mcec-types:mcec_mode_type_t
    +---rw switchover-type
      +---rw config
      | +---rw revertive-timer?    uint8
      | +---rw enable-non-revertive? empty
      +---ro state
      | +---ro revertive-timer?    uint8
      | +---ro enable-non-revertive? empty

rpcs:
+---x mcec-terminal-debug-on {feature-list:HAVE_LAGD,feature-list:HAVE_MCEC}?
| +---w input
|   +---w terminal-debug-options    ipi-mcec-types:mcec_debug_t
+---x mcec-terminal-debug-off {feature-list:HAVE_LAGD,feature-list:HAVE_MCEC}?
| +---w input
|   +---w terminal-debug-options    ipi-mcec-types:mcec_debug_t
+---x clear-mcec-statistics {feature-list:HAVE_LAGD,feature-list:HAVE_MCEC}?

```

module: ipi-mlag

```

+--ro mlag
  +--ro mlag-interface* [mlag-id]
  | +--ro mlag-id    -> ../state/mlag-id
  | +--ro state
  |   +--ro mlag-id?          uint16
  |   +--ro interface-flags? ipi-mlag-types:mlag_interface_flags_t
  |   +--ro bandwidth?       string
+--ro intra-domain-port
  | +--ro state
  |   +--ro interface-name?   string
  |   +--ro interface-index?  uint32
  |   +--ro interface-type?   ipi-mlag-types:mlag_idp_interface_type_t
  |   +--ro bridge-name?      string
+--ro mstp-sync-info
  +--ro state
  | +--ro bridge-priority?    uint16
  | +--ro path-cost-method?   uint8
  | +--ro num-of-interfaces?  uint16
  | +--ro domain-digest*      string
+--ro interface-sync-info* [interface-mlag-id]
  +--ro interface-mlag-id    -> ../state/interface-mlag-id
  +--ro state
  |   +--ro interface-mlag-id?  uint16
  |   +--ro interface-priority? uint16
  |   +--ro path-cost?          uint32
  |   +--ro interface-digest*   string

augment /ipi-interface:interfaces/ipi-interface:interface:
+--rw mlag-aggregation!
  +--rw config!
  | +--rw mlag-id    uint16
  +--ro state
  | +--ro mlag-id    uint16

```

module: ipi-mld-snooping

```

+--rw mld-snooping
  +--rw global
  | +--rw config
  | | +--rw disable-mld-snooping?    empty
  | | +--rw disable-report-suppression? empty
  | +--ro state
  |   +--ro disable-mld-snooping?    empty
  |   +--ro disable-report-suppression? empty

```

```

    +--rw debug
    | +--rw config
    | | +--rw options?   ipi-mld-snooping-types:mld_snoop_debug_options_t
    | +--ro state
    |   +--ro options?           ipi-mld-snooping-
types:mld_snoop_debug_options_t
    |   +--ro terminal-debug-status? ipi-mld-snooping-
types:mld_snoop_debug_options_t
    +--rw interfaces
    | +--rw interface* [name]
    |   +--rw name          -> ../config/name
    |   +--rw config
    |   | +--rw name?          -> /ipi-interface:interfaces/interface/name
    |   | +--rw mld-snooping?   cml-data-types:cml_enable_disable_t
    |   | +--rw enable-fast-leave? empty
    |   | +--rw report-suppression? cml-data-types:cml_enable_disable_t
    |   | +--rw mrouter-interface-name* -> /ipi-interface:interfaces/interface/
name
    |   | +--rw enable-querier?   empty
    |   +--ro state
    |   | +--ro name?           -> /ipi-interface:interfaces/interface/name
    |   | +--ro mld-snooping?   cml-data-types:cml_enable_disable_t
    |   | +--ro enable-fast-leave? empty
    |   | +--ro report-suppression? cml-data-types:cml_enable_disable_t
    |   | +--ro mrouter-interface-name* -> /ipi-interface:interfaces/interface/
name
    |   | +--ro enable-querier?   empty

rpcs:
  +---x mld-snooping-terminal-debug-on {feature-list:HAVE_MLD_SNOOP}?
  | +---w input
  |   +---w terminal-debug-options   ipi-mld-snooping-
types:mld_snoop_debug_options_t
  +---x mld-snooping-terminal-debug-off {feature-list:HAVE_MLD_SNOOP}?
  | +---w input
  |   +---w terminal-debug-options   ipi-mld-snooping-
types:mld_snoop_debug_options_t
  +---x mld-snooping-clear-group-on-interface {feature-list:HAVE_MLD_SNOOP}?
  | +---w input
  |   +---w group-address   string
  |   +---w interface-name  string
  +---x mld-snooping-clear-all-groups-on-interface {feature-list:HAVE_MLD_SNOOP}?
  | +---w input
  |   +---w interface-name  string
  +---x mld-snooping-clear-group {feature-list:HAVE_MLD_SNOOP}?
  | +---w input
  |   +---w group-address   string
  +---x mld-snooping-clear-all-groups {feature-list:HAVE_MLD_SNOOP}?

```

module: ipi-mpls-bfd

```

augment /ipi-bfd:bfd:
  +--rw mpls-lsp
    +--rw session-groups
      +--rw session-group* [lsp-type fec-address]
        +--rw lsp-type          -> ../config/lsp-type
        +--rw fec-address       -> ../config/fec-address
        +--rw config
          | +--rw lsp-type?      ipi-bfd-types:mpls_bfd_lsp_type_t
          | +--rw fec-address?   cml-data-types:cml_ipv4_addr_prefix_t
        +--ro state
          | +--ro lsp-type?      ipi-bfd-types:mpls_bfd_lsp_type_t
          | +--ro fec-address?   cml-data-types:cml_ipv4_addr_prefix_t
        +--rw session-attributes
          +--rw config
            | +--rw lsp-ping-interval?  uint16
            | +--rw admin-down?         empty
          +--ro state
            | +--ro lsp-ping-interval?  uint16
            | +--ro admin-down?         empty
          +--rw intervals
            +--rw interval* [minimum-tx minimum-rx detection-multiplier]
              +--rw minimum-tx          -> ../config/minimum-tx
              +--rw minimum-rx          -> ../config/minimum-rx
              +--rw detection-multiplier -> ../config/detection-multiplier
            +--rw config
              | +--rw minimum-tx?      uint32
              | +--rw minimum-rx?     uint32
              | +--rw detection-multiplier?  uint8
            +--ro state
              +--ro minimum-tx?      uint32
              +--ro minimum-rx?     uint32
              +--ro detection-multiplier?  uint8

augment /ipi-bfd:bfd:
  +--rw mpls-all-lsps
    +--rw mpls-all-lsp* [lsp-type]
      +--rw lsp-type          -> ../config/lsp-type
      +--rw config
        | +--rw lsp-type?      ipi-bfd-types:mpls_bfd_all_lsp_type_t
      +--ro state
        | +--ro lsp-type?      ipi-bfd-types:mpls_bfd_all_lsp_type_t
      +--rw session-attributes
        +--rw config
          | +--rw lsp-ping-interval?  uint16
          | +--rw admin-down?         empty
        +--ro state
          | +--ro lsp-ping-interval?  uint16

```

```
| +--ro admin-down?          empty
+--rw intervals
  +--rw interval* [minimum-tx minimum-rx detection-multiplier]
    +--rw minimum-tx          -> ../config/minimum-tx
    +--rw minimum-rx          -> ../config/minimum-rx
    +--rw detection-multiplier -> ../config/detection-multiplier
    +--rw config
      | +--rw minimum-tx?      uint32
      | +--rw minimum-rx?      uint32
      | +--rw detection-multiplier? uint8
    +--ro state
      +--ro minimum-tx?        uint32
      +--ro minimum-rx?        uint32
      +--ro detection-multiplier? uint8
augment /ipi-bfd:bfd:
  +--rw mpls-tunnels
    +--rw mpls-tunnel* [lsp-type tunnel-name]
      +--rw lsp-type          -> ../config/lsp-type
      +--rw tunnel-name       -> ../config/tunnel-name
      +--rw config
        | +--rw lsp-type?      ipi-bfd-types:mpls_bfd_te_type_t
        | +--rw tunnel-name?   string
      +--ro state
        | +--ro lsp-type?      ipi-bfd-types:mpls_bfd_te_type_t
        | +--ro tunnel-name?   string
    +--rw session-attributes
      +--rw config
        | +--rw lsp-ping-interval? uint16
        | +--rw admin-down?        empty
      +--ro state
        | +--ro lsp-ping-interval? uint16
        | +--ro admin-down?        empty
    +--rw intervals
      +--rw interval* [minimum-tx minimum-rx detection-multiplier]
        +--rw minimum-tx          -> ../config/minimum-tx
        +--rw minimum-rx          -> ../config/minimum-rx
        +--rw detection-multiplier -> ../config/detection-multiplier
        +--rw config
          | +--rw minimum-tx?      uint32
          | +--rw minimum-rx?      uint32
          | +--rw detection-multiplier? uint8
        +--ro state
          +--ro minimum-tx?        uint32
          +--ro minimum-rx?        uint32
          +--ro detection-multiplier? uint8
```

module: ipi-mpls-rib

```

augment /ipi-mpls:mpls:
  +--rw rib
    +--ro global-ftn-table
      | +--ro ipv4-ftn-entry* [fec-prefix owner lsp-type tunnel-id] {feature-
list:HAVE_VRF}?
      | | +--ro fec-prefix      -> ../state/fec-prefix
      | | +--ro owner          -> ../state/owner
      | | +--ro lsp-type       -> ../state/lsp-type
      | | +--ro tunnel-id      -> ../state/tunnel-id
      | | +--ro nhlfe-entry* [out-interface out-label administrative-status]
      | | | +--ro out-interface  -> ../state/out-interface
      | | | +--ro out-label      -> ../state/out-label
      | | | +--ro administrative-status -> ../state/administrative-status
      | | | +--ro state
      | | | +--ro out-interface?  -> /ipi-interface:interfaces/interface/
name
      | | | +--ro out-label?      uint32
      | | | +--ro nexthop-address? inet:ipv4-address
      | | | +--ro nhlfe-type?     ipi-mpls-types:mpls_rib_nhlfe_type_t
      | | | +--ro administrative-status? ipi-mpls-
types:mpls_rib_entry_admin_status_t
      | | | +--ro oper-status?    ipi-mpls-
types:mpls_rib_entry_oper_status_t
      | | | +--ro nhlfe-owner?    ipi-mpls-types:mpls_rib_entry_owner_t
      | | | +--ro nhlfe-index?    uint32
      | | | +--ro is-stale?       boolean
      | | | +--ro label-op-code?  ipi-mpls-types:mpls_rib_label_op_code_t
      | | +--ro state
      | | +--ro fec-prefix?       cml-data-types:cml_ipv4_addr_prefix_t
      | | +--ro owner?            ipi-mpls-types:mpls_rib_entry_owner_t
      | | +--ro lsp-type?         ipi-mpls-types:mpls_rib_lsp_type_t
      | | +--ro unique-nhlfe-ix?  uint32
      | | +--ro ftn-index?        uint32
      | | +--ro is-primary?       boolean
      | | +--ro route-distance?   uint8
      | | +--ro redirect-action-type? ipi-mpls-types:mpls_rib_action_type_t
      | | +--ro qos-exp-bits?     uint8
      | | +--ro is-entropy-label?  boolean
      | | +--ro in-dscp-class-name? string
      | | +--ro tunnel-id?        uint32
      | | +--ro protected-lsp-id?  uint32
      | | +--ro qos-resource-id?   uint32
      | | +--ro color?            uint32 {feature-list:HAVE_SERVICE_MAPPING}?
      | | +--ro tunnel-policy-name? string {feature-list:HAVE_SERVICE_MAPPING}?
      | | +--ro rsvp-multipath-name? string {feature-list:HAVE_RSVP_MULTIPATH}?
      | +--ro ipv6-ftn-entry* [fec-prefix6 owner lsp-type tunnel-id] {feature-
list:HAVE_IPV6}?

```

```

|     +---ro fec-prefix6      -> ../state/fec-prefix6
|     +---ro owner           -> ../state/owner
|     +---ro lsp-type        -> ../state/lsp-type
|     +---ro tunnel-id       -> ../state/tunnel-id
|     +---ro nhlfe-entry* [out-interface out-label administrative-status]
|     |   +---ro out-interface      -> ../state/out-interface
|     |   +---ro out-label         -> ../state/out-label
|     |   +---ro administrative-status -> ../state/administrative-status
|     |   +---ro state
name |   |   +---ro out-interface?      -> /ipi-interface:interfaces/interface/
|     |   +---ro out-label?          uint32
|     |   +---ro nexthop-address?    inet:ip-address
|     |   +---ro nhlfe-type?        ipi-mpls-types:mpls_rib_nhlfe_type_t
types:mpls_rib_entry_admin_status_t |     |   +---ro administrative-status? ipi-mpls-
types:mpls_rib_entry_oper_status_t |     |   +---ro oper-status?          ipi-mpls-
|     |   +---ro nhlfe-owner?        ipi-mpls-types:mpls_rib_entry_owner_t
|     |   +---ro nhlfe-index?        uint32
|     |   +---ro is-stale?           boolean
|     |   +---ro label-op-code?      ipi-mpls-types:mpls_rib_label_op_code_t
|     +---ro state
|     +---ro fec-prefix6?           cml-data-types:cml_ipv6_prefix_t
|     +---ro owner?                 ipi-mpls-types:mpls_rib_entry_owner_t
|     +---ro lsp-type?              ipi-mpls-types:mpls_rib_lsp_type_t
|     +---ro unique-nhlfe-ix?       uint32
|     +---ro ftn-index?             uint32
|     +---ro is-primary?            boolean
|     +---ro route-distance?        uint8
|     +---ro redirect-action-type?  ipi-mpls-types:mpls_rib_action_type_t
|     +---ro qos-exp-bits?          uint8
|     +---ro is-entropy-label?      boolean
|     +---ro in-dscp-class-name?    string
|     +---ro tunnel-id?             uint32
|     +---ro protected-lsp-id?      uint32
|     +---ro qos-resource-id?       uint32
|     +---ro color?                 uint32 {feature-list:HAVE_SERVICE_MAPPING}?
|     +---ro tunnel-policy-name?    string {feature-list:HAVE_SERVICE_MAPPING}?
|     +---ro rsvp-multipath-name?   string {feature-list:HAVE_RSVP_MULTIPATH}?
+---ro ilm-table
|   +---ro ip-ilm-entry* [in-interface in-label] {feature-list:HAVE_VRF}?
|   +---ro in-interface      -> ../state/in-interface
|   +---ro in-label          -> ../state/in-label
|   +---ro nhlfe-entry* [out-interface out-label xc-type]
|   |   +---ro out-interface      -> ../state/out-interface
|   |   +---ro out-label         -> ../state/out-label
|   |   +---ro xc-type           -> ../state/xc-type
|   |   +---ro state
|   |   +---ro out-interface?    -> /ipi-interface:interfaces/interface/name
|   |   +---ro out-label?       uint32

```

```

|     |     +---ro xc-type?           ipi-mpls-types:mpls_rib_xc_type_t
|     |     +---ro nexthop-address?   inet:ip-address
|     |     +---ro nhlfe-owner?       ipi-mpls-types:mpls_rib_entry_owner_t
|     |     +---ro nhlfe-index?       uint32
|     |     +---ro label-op-code?     ipi-mpls-types:mpls_rib_label_op_code_t
|     +---ro state
|         +---ro in-interface?        -> /ipi-interface:interfaces/interface/name
|         +---ro in-label?            uint32
|         +---ro vrf-name?            -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
|         +---ro owner?               ipi-mpls-types:mpls_rib_entry_owner_t
|         +---ro ilm-index?           uint32
|         +---ro is-stitched-to-ftn?   boolean
|         +---ro is-installed-in-fib?  boolean
|         +---ro is-selected?         boolean
|         +---ro is-stale?            boolean
|         +---ro fec-prefix?          cml-data-types:cml_ip_prefix_t
|         +---ro label-op-code?       ipi-mpls-types:mpls_rib_label_op_code_t
|         +---ro pseudowire-id?       uint32
|         +---ro evpn-id?             uint32 {feature-list:HAVE_BGP_EVPN,feature-
list:HAVE_NVO}?
+---ro rsvp-multipath-table {feature-list:HAVE_RSVP_MULTIPATH}?
|   +---ro rsvp-multipath-entry* [multipath-identifier]
|     +---ro multipath-identifier     -> ../state/multipath-identifier
|     +---ro state
|         +---ro multipath-identifier?  uint16
|         +---ro multipath-name?       string
|         +---ro multipath-nhlfe-index? uint32
|         +---ro fec-prefix?           cml-data-types:cml_ipv4_addr_prefix_t
|         +---ro active-member-count?  uint16
+---rw map-route
|   +---rw static-ipv4-map-routes
|     +---rw static-ipv4-map-route* [route-prefix]
|       +---rw route-prefix          -> ../config/route-prefix
|       +---rw config
|         | +---rw route-prefix?       cml-data-types:cml_ipv4_prefix_t
|         | +---rw mapped-fec          cml-data-types:cml_ipv4_prefix_t
|         +---ro state
|           +---ro route-prefix?       cml-data-types:cml_ipv4_prefix_t
|           +---ro mapped-fec          cml-data-types:cml_ipv4_prefix_t
+---rw static-lsps
  +---rw ipv4-static-ftn-entries
    | +---rw ipv4-static-ftn-entry* [fec-prefix pushed-label nexthop-ip-address
out-interface-name]
    |   +---rw fec-prefix              -> ../config/fec-prefix
    |   +---rw pushed-label            -> ../config/pushed-label
    |   +---rw nexthop-ip-address      -> ../config/nexthop-ip-address
    |   +---rw out-interface-name      -> ../config/out-interface-name
    |   +---rw config
    |     | +---rw fec-prefix?          cml-data-types:cml_ipv4_prefix_t
    |     | +---rw pushed-label?        uint32

```

Pyang Tree

```

|     |   +---rw nexthop-ip-address?   inet:ipv4-address
|     |   +---rw out-interface-name?   -> /ipi-interface:interfaces/interface/
name
|     +---ro state
|         +---ro fec-prefix?           cml-data-types:cml_ipv4_prefix_t
|         +---ro pushed-label?        uint32
|         +---ro nexthop-ip-address?   inet:ipv4-address
|         +---ro out-interface-name?   -> /ipi-interface:interfaces/interface/
name
+---rw static-ftn-tunnels
|   +---rw static-ftn-tunnel* [tunnel-id fec-prefix pushed-label nexthop-ip-
address out-interface-name is-primary] {feature-list:NOT_HAVE_MPLS_TUNNEL}?
|     +---rw tunnel-id                 -> ../config/tunnel-id
|     +---rw fec-prefix                 -> ../config/fec-prefix
|     +---rw pushed-label               -> ../config/pushed-label
|     +---rw nexthop-ip-address         -> ../config/nexthop-ip-address
|     +---rw out-interface-name         -> ../config/out-interface-name
|     +---rw is-primary                 -> ../config/is-primary
|     +---rw config
|         |   +---rw tunnel-id?         uint32
|         |   +---rw fec-prefix?       cml-data-types:cml_ip_prefix_t
|         |   +---rw pushed-label?     uint32
|         |   +---rw nexthop-ip-address? inet:ip-address
|         |   +---rw out-interface-name? -> /ipi-interface:interfaces/interface/
name
|         |   +---rw is-primary?       ipi-mpls-
types:mpls_vpls_ftn_entry_lsp_type_t
|         +---ro state
|         +---ro tunnel-id?           uint32
|         +---ro fec-prefix?         cml-data-types:cml_ip_prefix_t
|         +---ro pushed-label?       uint32
|         +---ro nexthop-ip-address? inet:ip-address
|         +---ro out-interface-name? -> /ipi-interface:interfaces/interface/
name
|         +---ro is-primary?         ipi-mpls-
types:mpls_vpls_ftn_entry_lsp_type_t
+---rw static-ilm-entries
+---rw static-ilm-entry* [incoming-label]
+---rw incoming-label   -> ../config/incoming-label
+---rw config
|   +---rw incoming-label? uint32
+---ro state
|   +---ro incoming-label? uint32
+---rw pop
|   +---rw config!
|     |   +---rw enable-pop-label   empty
|     |   +---ro state
|     |   +---ro enable-pop-label   empty
+---rw swaps
+---rw swap* [in-interface-name swapped-label out-interface-name
nexthop-ip-address fec-prefix]
+---rw in-interface-name   -> ../config/in-interface-name
```

```

    +--rw swapped-label          -> ../config/swapped-label
    +--rw out-interface-name     -> ../config/out-interface-name
    +--rw nexthop-ip-address     -> ../config/nexthop-ip-address
    +--rw fec-prefix             -> ../config/fec-prefix
    +--rw config
      | +--rw in-interface-name?  string
      | +--rw swapped-label?     uint32
      | +--rw out-interface-name? -> /ipi-interface:interfaces/
interface/name
      | +--rw nexthop-ip-address? inet:ip-address
      | +--rw fec-prefix?        cml-data-types:cml_ip_prefix_t
    +--ro state
      +--ro in-interface-name?   string
      +--ro swapped-label?       uint32
      +--ro out-interface-name?  -> /ipi-interface:interfaces/
interface/name
      +--ro nexthop-ip-address?  inet:ip-address
      +--ro fec-prefix?          cml-data-types:cml_ip_prefix_t
augment /ipi-mpls:mpls:
  +--ro vrf* [vrf-name] {feature-list:HAVE_VRF}?
    +--ro vrf-name      -> ../rib/vrf-name
    +--ro rib
      +--ro ftn-table
        | +--ro ipv4-ftn-entry* [fec-prefix owner lsp-type tunnel-id]
        | | +--ro fec-prefix      -> ../state/fec-prefix
        | | +--ro owner           -> ../state/owner
        | | +--ro lsp-type        -> ../state/lsp-type
        | | +--ro tunnel-id       -> ../state/tunnel-id
        | | +--ro nhlfe-entry* [out-interface out-label]
        | | | +--ro out-interface  -> ../state/out-interface
        | | | +--ro out-label      -> ../state/out-label
        | | | +--ro state
        | | |   +--ro out-interface? -> /ipi-interface:interfaces/
interface/name
        | | |   +--ro out-label?     uint32
        | | |   +--ro nexthop-address? inet:ipv4-address
        | | |   +--ro nhlfe-type?    ipi-mpls-types:mpls_rib_nhlfe_type_t
        | | |   +--ro administrative-status? ipi-mpls-
types:mpls_rib_entry_admin_status_t
        | | |   +--ro oper-status?    ipi-mpls-
types:mpls_rib_entry_oper_status_t
        | | |   +--ro nhlfe-owner?    ipi-mpls-types:mpls_rib_entry_owner_t
        | | |   +--ro nhlfe-index?    uint32
        | | |   +--ro is-stale?       boolean
        | | |   +--ro label-op-code?  ipi-mpls-
types:mpls_rib_label_op_code_t
        | | +--ro state
        | |   +--ro fec-prefix?       cml-data-types:cml_ipv4_addr_prefix_t
        | |   +--ro owner?            ipi-mpls-types:mpls_rib_entry_owner_t
        | |   +--ro lsp-type?         ipi-mpls-types:mpls_rib_lsp_type_t
        | |   +--ro unique-nhlfe-ix?  uint32
        | |   +--ro ftn-index?        uint32

```

```

| |      +---ro is-primary?          boolean
| |      +---ro route-distance?     uint8
| |      +---ro redirect-action-type? ipi-mpls-types:mpls_rib_action_type_t
| |      +---ro qos-exp-bits?       uint8
| |      +---ro is-entropy-label?   boolean
| |      +---ro in-dscp-class-name?  string
| |      +---ro tunnel-id?          uint32
| |      +---ro protected-lsp-id?   uint32
| |      +---ro qos-resource-id?    uint32
| |      +---ro color?              uint32 {feature-
list:HAVE_SERVICE_MAPPING}?
| |      +---ro tunnel-policy-name?  string {feature-
list:HAVE_SERVICE_MAPPING}?
| |      +---ro rsvp-multipath-name? string {feature-
list:HAVE_RSVP_MULTIPATH}?
| |      +---ro ipv6-ftn-entry* [fec-prefix6 owner lsp-type tunnel-id] {feature-
list:HAVE_IPV6}?
| |      +---ro fec-prefix6      -> ../state/fec-prefix6
| |      +---ro owner            -> ../state/owner
| |      +---ro lsp-type         -> ../state/lsp-type
| |      +---ro tunnel-id       -> ../state/tunnel-id
| |      +---ro nhlfe-entry* [out-interface out-label]
| |      | +---ro out-interface   -> ../state/out-interface
| |      | +---ro out-label      -> ../state/out-label
| |      | +---ro state
interface/name | |      +---ro out-interface?     -> /ipi-interface:interfaces/
| |      +---ro out-label?        uint32
| |      +---ro nexthop-address?  inet:ip-address
| |      +---ro nhlfe-type?       ipi-mpls-types:mpls_rib_nhlfe_type_t
| |      +---ro administrative-status? ipi-mpls-
types:mpls_rib_entry_admin_status_t
| |      +---ro oper-status?      ipi-mpls-
types:mpls_rib_entry_oper_status_t
| |      +---ro nhlfe-owner?      ipi-mpls-types:mpls_rib_entry_owner_t
| |      +---ro nhlfe-index?     uint32
| |      +---ro is-stale?        boolean
| |      +---ro label-op-code?   ipi-mpls-
types:mpls_rib_label_op_code_t
| |      +---ro state
| |      +---ro fec-prefix6?     cml-data-types:cml_ipv6_prefix_t
| |      +---ro owner?           ipi-mpls-types:mpls_rib_entry_owner_t
| |      +---ro lsp-type?        ipi-mpls-types:mpls_rib_lsp_type_t
| |      +---ro unique-nhlfe-ix? uint32
| |      +---ro ftn-index?       uint32
| |      +---ro is-primary?      boolean
| |      +---ro route-distance?  uint8
| |      +---ro redirect-action-type? ipi-mpls-types:mpls_rib_action_type_t
| |      +---ro qos-exp-bits?    uint8
| |      +---ro is-entropy-label? boolean
| |      +---ro in-dscp-class-name? string
| |      +---ro tunnel-id?       uint32

```



```

        |          +---ro protected-lsp-id?          uint32
        |          +---ro qos-resource-id?          uint32
        |          +---ro color?                    uint32 {feature-
list:HAVE_SERVICE_MAPPING}?
        |          +---ro tunnel-policy-name?       string {feature-
list:HAVE_SERVICE_MAPPING}?
        |          +---ro rsvp-multipath-name?      string {feature-
list:HAVE_RSVP_MULTIPATH}?
        +---ro vrf-name?        -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?

```

module: ipi-mpls

```

+---rw mpls
  +---rw l2vpn
    | +---rw customer-service-templates
    | | +---rw customer-service-template* [name] {feature-
list:HAVE_VPLS_OR_HAVE_MPLS_VC}?
    | |   +---rw name                -> ../config/name
    | |   +---rw config
    | |   | +---rw name?              string
    | |   | +---rw match-all?        empty
    | |   | +---rw match-single-tag-outer-vlan-range* string
    | |   | +---rw match-untagged?    empty
    | |   +---ro state
    | |   | +---ro name?              string
    | |   | +---ro match-all?        empty
    | |   | +---ro match-single-tag-outer-vlan-range* string
    | |   | +---ro match-untagged?    empty
    | |   +---rw double-tags
    | |   | +---rw double-tag* [match-outer-vlan-id]
    | |   |   +---rw match-outer-vlan-id -> ../config/match-outer-vlan-id
    | |   |   +---rw config
    | |   |   | +---rw match-outer-vlan-id? uint16
    | |   |   | +---rw match-inner-vlan-id* string
    | |   |   +---ro state
    | |   |     +---ro match-outer-vlan-id? uint16
    | |   |     +---ro match-inner-vlan-id* string
    | |   +---rw action-types
    | |   | +---rw action-type* [vlan-action-type]
    | |   |   +---rw vlan-action-type -> ../config/vlan-action-type
    | |   |   +---rw config
    | |   |   | +---rw vlan-action-type? ipi-mpls-
types:mpls_l2vpn_vlan_action_type_t
    | |   |   | +---rw outer-vlan-identifier? uint16
    | |   |   | +---rw tag-protocol-identifier? ipi-mpls-types:mpls_svc_tpid_t
    | |   |   +---ro state
    | |   |     +---ro vlan-action-type? ipi-mpls-
types:mpls_l2vpn_vlan_action_type_t

```

```

| | | +--ro outer-vlan-identifier? uint16
| | | +--ro tag-protocol-identifier? ipi-mpls-types:mpls_svc_tpid_t
| | +--ro map-list* [vpls-name] {feature-list:HAVE_VPLS}?
| | +--ro vpls-name -> ../state/vpls-name
| | +--ro state
| | +--ro vpls-name? string
| | +--ro error-status? ipi-mpls-
types:mpls_l2vpn_serv_temp_error_status_t
| | +--ro binding-interface-name? string
| +--rw access-circuit-groups
| +--rw access-circuit-group* [group-name] {feature-list:HAVE_MPLS_VC}?
| +--rw group-name -> ../config/group-name
| +--rw config
| | +--rw group-name? string
| | +--rw group-identifier uint32
| +--ro state
| +--ro group-name? string
| +--ro group-identifier uint32
+--rw global
| +--rw config
| | +--rw local-packet-handling? empty
| | +--rw lsp-stitching? empty
| | +--rw propagate-ttl? empty
| | +--rw ingress-ttl-value? uint8
| | +--rw lsp-model-uniform? empty
| +--ro state
| | +--ro local-packet-handling? empty
| | +--ro lsp-stitching? empty
| | +--ro propagate-ttl? empty
| | +--ro ingress-ttl-value? uint8
| | +--ro lsp-model-uniform? empty
| +--ro graceful-restart {feature-list:HAVE_RESTART}?
| +--ro rsvp
| | +--ro state
| | +--ro graceful-restart-state? ipi-mpls-
types:mpls_graceful_restart_status_t
| | +--ro remaining-restart-time? uint32
| | +--ro disconnected-time? yang:date-and-time
| +--ro ldp
| +--ro state
| +--ro graceful-restart-state? ipi-mpls-
types:mpls_graceful_restart_status_t
| +--ro remaining-restart-time? uint32
| +--ro disconnected-time? yang:date-and-time
+--rw interfaces
| +--rw interface* [name]
| +--rw name -> ../config/name
| +--rw config
| | +--rw name? -> /ipi-interface:interfaces/interface/name
| +--rw label-switching
| | +--rw config!

```

```

|     | | +--rw enable          empty
|     | | +--rw label-space?   uint16
|     | +--ro state
|     |   +--ro enable          empty
|     |   +--ro label-space?   uint16
|   +--rw mpls-interface-bandwidth
|     +--rw config
|       | +--rw admin-group-name*   -> /ipi-global-te:admin-groups/admin-
group/name {feature-list:HAVE_TE}?
|       | +--rw bandwidth?         string {feature-list:HAVE_TE,feature-
list:NOT_IF_BANDWIDTH_INFO}?
|       | +--rw reservable-bandwidth? string {feature-list:HAVE_TE}?
|       | +--rw shared-risk-link-group* uint32 {feature-list:HAVE_SRLG}?
|       | +--rw uni-available-bandwidth? string {feature-list:HAVE_TE,feature-
list:NOT_IF_BANDWIDTH_INFO}?
|       | +--rw uni-residual-bandwidth? string {feature-list:HAVE_TE,feature-
list:NOT_IF_BANDWIDTH_INFO}?
|       | +--rw uni-utilized-bandwidth? string {feature-list:HAVE_TE,feature-
list:NOT_IF_BANDWIDTH_INFO}?
|       +--ro state
|         +--ro admin-group-name*   -> /ipi-global-te:admin-groups/admin-
group/name {feature-list:HAVE_TE}?
|         +--ro bandwidth?         string {feature-list:HAVE_TE,feature-
list:NOT_IF_BANDWIDTH_INFO}?
|         +--ro reservable-bandwidth? string {feature-list:HAVE_TE}?
|         +--ro shared-risk-link-group* uint32 {feature-list:HAVE_SRLG}?
|         +--ro uni-available-bandwidth? string {feature-list:HAVE_TE,feature-
list:NOT_IF_BANDWIDTH_INFO}?
|         +--ro uni-residual-bandwidth? string {feature-list:HAVE_TE,feature-
list:NOT_IF_BANDWIDTH_INFO}?
|         +--ro uni-utilized-bandwidth? string {feature-list:HAVE_TE,feature-
list:NOT_IF_BANDWIDTH_INFO}?
+--rw label-spaces
| +--rw label-space* [label-space-name]
|   +--rw label-space-name   -> ../config/label-space-name
|   +--rw config
|     | +--rw label-space-name?   uint16
|   +--ro state
|     | +--ro label-space-name?   uint16
|   +--rw global-label-range
|     | +--rw config!
|     | | +--rw min-label        uint32
|     | | +--rw max-label        uint32
|     | +--ro state
|     |   +--ro min-label        uint32
|     |   +--ro max-label        uint32
|   +--rw module-label-ranges
|     +--rw module-label-range* [module-name]
|       +--rw module-name   -> ../config/module-name
|       +--rw config
|         | +--rw module-name?   ipi-mpls-types:mpls_module_t
|         | +--rw min-label      uint32
|         | +--rw max-label      uint32

```

```

|           +---ro state
|           +---ro module-name?   ipi-mpls-types:mpls_module_t
|           +---ro min-label      uint32
|           +---ro max-label      uint32
+---rw ecmp
| +---rw config
| | +---rw ftn-ecmp-protocol?     ipi-mpls-types:mpls_ecmp_protocol_t {feature-
list:HAVE_MPLS_ECMP}?
| | +---rw ilm-ecmp-protocol?     ipi-mpls-types:mpls_ecmp_protocol_t {feature-
list:HAVE_MPLS_ECMP}?
| +---ro state
|   +---ro ftn-ecmp-protocol?     ipi-mpls-types:mpls_ecmp_protocol_t {feature-
list:HAVE_MPLS_ECMP}?
|   +---ro ilm-ecmp-protocol?     ipi-mpls-types:mpls_ecmp_protocol_t {feature-
list:HAVE_MPLS_ECMP}?
+---rw six-pe-tunnel-policies {feature-list:HAVE_SERVICE_MAPPING,feature-
list:HAVE_6PE}?
| +---rw six-pe-tunnel-policy* [name]
|   +---rw name      -> ../config/name
|   +---rw config
|     | +---rw name?  string
|     +---ro state
|       +---ro name?  string
+---rw bandwidth-classes
  +---rw bandwidth-class* [name] {feature-list:HAVE_TE}?
  +---rw name      -> ../config/name
  +---rw config
  | +---rw name?   string
  +---ro state
  | +---ro name?   string
  +---rw properties
    +---rw config!
    | +---rw max-bandwidth      string
    | +---rw setup-priority     uint8
    | +---rw hold-priority      uint8
    +---ro state
      +---ro max-bandwidth      string
      +---ro setup-priority     uint8
      +---ro hold-priority      uint8

```

module: ipi-mrib

```

+---rw mrib
  +---rw ipv4
  | +---rw vrfs

```

```

| | +--rw vrf* [vrf-name]
| |   +--rw vrf-name          -> ../config/vrf-name
| |   +--rw config
| |     +--rw vrf-name?      -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
| |       +--rw multicast-routing-enable?  empty
| |       +--ro state
| |         +--ro counters
| |           +--ro total-multicast-routes?  yang:counter32
| |           +--ro dense-mode-multicast-routes?  yang:counter32
| |           +--ro sparse-mode-multicast-routes?  yang:counter32
| |           +--ro no-cache-received?          yang:counter32
| |           +--ro no-cache-sent?              yang:counter32
| |           +--ro wrong-VIF-received?         yang:counter32
| |           +--ro wrong-VIF-sent?            yang:counter32
| |           +--ro whole-packet-received?     yang:counter32
| |           +--ro whole-packet-sent?        yang:counter32
| |           +--ro immediate-stat-updates-sent? yang:counter32
| |           +--ro timed-stat-updates-sent?   yang:counter32
| |           +--ro register-packets-sent?     yang:counter32
| |           +--ro register-acks-received?    yang:counter32
| |           +--ro register-nacks-received?   yang:counter32
| |           +--ro no-cache-receive-rate?     decimal64
| |           +--ro register-packet-sent-rate? decimal64
| |       +--ro vrf-name?      -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
| |         +--ro multicast-routing-enable?  empty
| |         +--ro stats-poll-expiry-time?   string
| |       +--rw route-limit
| |         +--rw config
| |           +--rw maximum-routes?        uint32
| |           +--rw warning-threshold?     uint32
| |           +--ro state
| |             +--ro maximum-routes?      uint32
| |             +--ro warning-threshold?   uint32
| |       +--rw debug
| |         +--rw config
| |           +--rw options?   ipi-mrib-types:mrib_debug_t
| |           +--ro state
| |             +--ro options?          ipi-mrib-types:mrib_debug_t
| |             +--ro terminal-debug-status? ipi-mrib-types:mrib_debug_t
| |       +--ro multicast-routes
| |         +--ro multicast-route* [source group]
| |           +--ro source          -> ../state/source
| |           +--ro group          -> ../state/group
| |           +--ro state
| |             +--ro counters
| |               +--ro packets-forwarded?  yang:counter32
| |               +--ro bytes-forwarded?    yang:counter32
| |               +--ro wrong-VIF-sent?     yang:counter32
| |               +--ro wrong-VIF-received? yang:counter32

```

```

| | | | +--ro source? inet:ip-address
| | | | +--ro group? inet:ip-address
| | | | +--ro incoming-interface? string
| | | | +--ro rpf-address? inet:ip-address
| | | | +--ro route-type? ipi-mrib-types:mrib_route_type_t
| | | | +--ro uptime? string
| | | | +--ro stats-poll-expiry-time? string
| | | | +--ro immediate-stats? empty
| | | | +--ro timed-stats? empty
| | | | +--ro forwarder-installed? empty
| | | +--ro outgoing-interfaces
| | | | +--ro outgoing-interface* [name]
| | | | | +--ro name -> ../state/name
| | | | | +--ro state
name | | | | | +--ro name? -> /ipi-interface:interfaces/interface/
| | | | | +--ro time-to-live? uint8
| +--rw interfaces
| | +--rw interface* [name]
| | | +--rw name -> ../config/name
| | | +--rw config
| | | | +--rw name? -> /ipi-interface:interfaces/interface/name
| | | | +--rw ttl-threshold? uint8
| | | +--ro state
| | | | +--ro name? -> /ipi-interface:interfaces/interface/name
| | | | +--ro ttl-threshold? uint8
| | | | +--ro local-address? inet:ip-address {feature-list:HAVE_MRIB_IPV4}?
| | | | +--ro remote-address? inet:ip-address {feature-list:HAVE_MRIB_IPV4}?
| | | | +--ro uptime? string
| | | | +--ro module-name? string
| | | | +--ro vif-index? uint32
+--rw ipv6
+--rw vrfs
| | +--rw vrf* [vrf-name]
| | | +--rw vrf-name -> ../config/vrf-name
| | | +--rw config
instances/network-instance/ipi-vrf:vrf/config/vrf-name | | | | +--rw vrf-name? -> /ipi-network-instance:network-
| | | | +--rw multicast-routing-enable? empty
| | | +--ro state
| | | | +--ro counters
| | | | | +--ro total-multicast-routes? yang:counter32
| | | | | +--ro dense-mode-multicast-routes? yang:counter32
| | | | | +--ro sparse-mode-multicast-routes? yang:counter32
| | | | | +--ro no-cache-received? yang:counter32
| | | | | +--ro no-cache-sent? yang:counter32
| | | | | +--ro wrong-VIF-received? yang:counter32
| | | | | +--ro wrong-VIF-sent? yang:counter32
| | | | | +--ro whole-packet-received? yang:counter32
| | | | | +--ro whole-packet-sent? yang:counter32
| | | | | +--ro immediate-stat-updates-sent? yang:counter32

```

```

|     | | +---ro timed-stat-updates-sent?      yang:counter32
|     | | +---ro register-packets-sent?        yang:counter32
|     | | +---ro register-acks-received?       yang:counter32
|     | | +---ro register-nacks-received?      yang:counter32
|     | | +---ro no-cache-receive-rate?       decimal64
|     | | +---ro register-packet-sent-rate?    decimal64
|     | +---ro vrf-name?                       -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
|     | +---ro multicast-routing-enable?      empty
|     | +---ro stats-poll-expiry-time?        string
|     +---rw route-limit
|     | +---rw config
|     | | +---rw maximum-routes?              uint32
|     | | +---rw warning-threshold?           uint32
|     | +---ro state
|     |   +---ro maximum-routes?              uint32
|     |   +---ro warning-threshold?           uint32
|     +---rw debug
|     | +---rw config
|     | | +---rw options?                      ipi-mrib-types:mrib_debug_t
|     | +---ro state
|     |   +---ro options?                      ipi-mrib-types:mrib_debug_t
|     |   +---ro terminal-debug-status?        ipi-mrib-types:mrib_debug_t
|     +---ro multicast-routes
|     | +---ro multicast-route* [source group]
|     |   +---ro source                        -> ../state/source
|     |   +---ro group                        -> ../state/group
|     |   +---ro state
|     |     | +---ro counters
|     |     | | +---ro packets-forwarded?      yang:counter32
|     |     | | +---ro bytes-forwarded?        yang:counter32
|     |     | | +---ro wrong-VIF-sent?         yang:counter32
|     |     | | +---ro wrong-VIF-received?     yang:counter32
|     |     | +---ro source?                    inet:ip-address
|     |     | +---ro group?                     inet:ip-address
|     |     | +---ro incoming-interface?        string
|     |     | +---ro rpf-address?               inet:ip-address
|     |     | +---ro route-type?                ipi-mrib-types:mrib_route_type_t
|     |     | +---ro uptime?                    string
|     |     | +---ro stats-poll-expiry-time?    string
|     |     | +---ro immediate-stats?           empty
|     |     | +---ro timed-stats?               empty
|     |     | +---ro forwarder-installed?       empty
|     |     +---ro outgoing-interfaces
|     |       +---ro outgoing-interface* [name]
|     |         +---ro name                    -> ../state/name
|     |         +---ro state
|     |         +---ro name?                    -> /ipi-interface:interfaces/interface/
name
|     |         +---ro time-to-live?            uint8
+---rw interfaces

```

```
+--rw interface* [name]
  +--rw name      -> ../config/name
  +--rw config
  | +--rw name?          -> /ipi-interface:interfaces/interface/name
  | +--rw ttl-threshold? uint8
  +--ro state
    +--ro name?          -> /ipi-interface:interfaces/interface/name
    +--ro ttl-threshold? uint8
    +--ro local-address? inet:ip-address {feature-list:HAVE_MRIB_IPV4}?
    +--ro remote-address? inet:ip-address {feature-list:HAVE_MRIB_IPV4}?
    +--ro uptime?       string
    +--ro module-name?  string
    +--ro vif-index?    uint32
```

rpcs:

```
----x mrib-ipv4-terminal-debug-on {feature-list:HAVE_MRIBD}?
| +---w input
|   +---w vrf-name?          string
|   +---w terminal-debug-options ipi-mrib-types:mrib_debug_t
----x mrib-ipv4-terminal-debug-off {feature-list:HAVE_MRIBD}?
| +---w input
|   +---w vrf-name?          string
|   +---w terminal-debug-options ipi-mrib-types:mrib_debug_t
----x mrib-ipv4-clear-mroute-all {feature-list:HAVE_MRIBD}?
| +---w input
|   +---w vrf-name?          string
|   +---w all-routes         empty
----x mrib-ipv4-clear-mroute-group {feature-list:HAVE_MRIBD}?
| +---w input
|   +---w vrf-name?          string
|   +---w group-address      inet:ipv4-address
----x mrib-ipv4-clear-mroute-source-group {feature-list:HAVE_MRIBD}?
| +---w input
|   +---w vrf-name?          string
|   +---w source-address      inet:ipv4-address
|   +---w group-address      inet:ipv4-address
----x mrib-ipv4-clear-mroute-statistics-all {feature-list:HAVE_MRIBD}?
| +---w input
|   +---w vrf-name?          string
|   +---w all-routes         empty
----x mrib-ipv4-clear-mroute-statistics-group {feature-list:HAVE_MRIBD}?
| +---w input
|   +---w vrf-name?          string
|   +---w group-address      inet:ipv4-address
----x mrib-ipv4-clear-mroute-statistics-source-group {feature-list:HAVE_MRIBD}?
| +---w input
|   +---w vrf-name?          string
|   +---w source-address      inet:ipv4-address
|   +---w group-address      inet:ipv4-address
----x mrib-ipv4-snmp-restart {feature-list:HAVE_SNMP}?
```



```

+---x mrib-ipv6-terminal-debug-on {feature-list:HAVE_MRIBD,feature-
list:HAVE_MCAST_IPV6}?
| +---w input
|   +---w vrf-name?                string
|   +---w terminal-debug-options    ipi-mrib-types:mrib_debug_t
+---x mrib-ipv6-terminal-debug-off {feature-list:HAVE_MRIBD,feature-
list:HAVE_MCAST_IPV6}?
| +---w input
|   +---w vrf-name?                string
|   +---w terminal-debug-options    ipi-mrib-types:mrib_debug_t
+---x mrib-ipv6-clear-mroute-all {feature-list:HAVE_MRIBD,feature-
list:HAVE_MCAST_IPV6}?
| +---w input
|   +---w vrf-name                string
|   +---w all-routes              empty
+---x mrib-ipv6-clear-mroute-group {feature-list:HAVE_MRIBD,feature-
list:HAVE_MCAST_IPV6}?
| +---w input
|   +---w vrf-name                string
|   +---w group-address           inet:ipv6-address
+---x mrib-ipv6-clear-mroute-source-group {feature-list:HAVE_MRIBD,feature-
list:HAVE_MCAST_IPV6}?
| +---w input
|   +---w vrf-name                string
|   +---w source-address          inet:ipv6-address
|   +---w group-address           inet:ipv6-address
+---x mrib-ipv6-clear-mroute-statistics-all {feature-list:HAVE_MRIBD,feature-
list:HAVE_MCAST_IPV6}?
| +---w input
|   +---w vrf-name                string
|   +---w all-routes              empty
+---x mrib-ipv6-clear-mroute-statistics-group {feature-list:HAVE_MRIBD,feature-
list:HAVE_MCAST_IPV6}?
| +---w input
|   +---w vrf-name                string
|   +---w group-address           inet:ipv6-address
+---x mrib-ipv6-clear-mroute-statistics-source-group {feature-
list:HAVE_MRIBD,feature-list:HAVE_MCAST_IPV6}?
+---w input
+---w vrf-name                    string
+---w source-address              inet:ipv6-address
+---w group-address              inet:ipv6-address

```

module: ipi-neighbor-discovery

```

+--rw neighbor-discovery
+--rw entries
| +--rw entry* [ipv6-address interface-name]
|   +--rw ipv6-address            -> ../config/ipv6-address

```

```

|     +---rw interface-name    -> ../config/interface-name
|     +---rw config
|     |   +---rw ipv6-address?  inet:ipv6-address
|     |   +---rw interface-name? -> /ipi-interface:interfaces/interface/name
|     |   +---rw mac-address    cml-data-types:cml_mac_addr_t
|     +---ro state
|         +---ro ipv6-address?  inet:ipv6-address
|         +---ro interface-name? -> /ipi-interface:interfaces/interface/name
|         +---ro mac-address    cml-data-types:cml_mac_addr_t
|         +---ro neighbor-age?  string
|         +---ro neighbor-source? ipi-nd-types:ndd_nd_src_type_t
|         +---ro neighbor-state? ipi-nd-types:ndd_nd_state_t
|         +---ro neighbor-if-state? ipi-nd-types:ndd_nd_if_type_t
+---rw debug
|   +---rw config
|   |   +---rw enable?    empty
|   +---ro state
|       +---ro enable?    empty
|       +---ro terminal-debug-status? cml-data-types:cml_on_off_t
+---rw interfaces
|   +---rw interface* [name]
|   |   +---rw name        -> ../config/name
|   |   +---rw config
|   |   |   +---rw name?    -> /ipi-interface:interfaces/interface/name
|   |   |   +---rw nd-ageing-timeout? uint16
|   |   |   +---rw nd-reachable-time? uint32
|   |   +---ro state
|   |       +---ro name?    -> /ipi-interface:interfaces/interface/name
|   |       +---ro nd-ageing-timeout? uint16
|   |       +---ro nd-reachable-time? uint32
+---ro dynamic-neighbor-discovery* [vrf-name]
    +---ro vrf-name        string
    +---ro entry* [ipv6-address]
    |   +---ro ipv6-address    inet:ipv6-address
    |   +---ro mac-address?    cml-data-types:cml_mac_addr_t
    |   +---ro interface-name? string
    |   +---ro neighbor-age?   string
    |   +---ro neighbor-source? ipi-nd-types:ndd_nd_src_type_t
    |   +---ro neighbor-state? ipi-nd-types:ndd_nd_state_t
    |   +---ro neighbor-if-state? ipi-nd-types:ndd_nd_if_type_t
    +---ro adjacency-summary
        +---ro resolved-arp?    uint32
        +---ro incomplete-arp?  uint32
        +---ro unknown-arp?     uint32
        +---ro total-arp?       uint32

rpcs:
    +---x nd-terminal-debug-on {feature-list:HAVE_L3,feature-list:HAVE_IPV6,feature-
list:HAVE_NDD}?
    +---x nd-terminal-debug-off {feature-list:HAVE_L3,feature-list:HAVE_IPV6,feature-
list:HAVE_NDD}?

```

```

+---x clear-ipv6-nd-entry {feature-list:HAVE_L3,feature-list:HAVE_IPV6,feature-
list:HAVE_NDD}?
| +---w input
|   +---w ipv6-address?   cml-data-types:cml_ipv6_prefix_t
|   +---w vrf-name?      string
+---x clear-ipv6-nd-entry-per-interface {feature-list:HAVE_L3,feature-
list:HAVE_IPV6,feature-list:HAVE_NDD}?
+---w input
+---w if-name      string
+---w vrf-name?   string

```

module: ipi-network-address-translation

```

+--rw network-address-translation {feature-list:HAVE_NAT}?
+--rw timeouts
| +--rw config
| | +--rw generic-timeout?   uint32
| | +--rw icmp-timeout?     uint32
| | +--rw tcp-timeout?      uint32
| | +--rw udp-timeout?      uint32
| | +--rw tcp-fin-timeout?   uint32
| +--ro state
|   +--ro generic-timeout?   uint32
|   +--ro icmp-timeout?     uint32
|   +--ro tcp-timeout?      uint32
|   +--ro udp-timeout?      uint32
|   +--ro tcp-fin-timeout?   uint32
+--rw ip-rules
| +--rw incoming
| | +--rw source-mapping-entries
| | | +--rw source-mapping-entry* [local-address global-address]
| | |   +--rw local-address      -> ../config/local-address
| | |   +--rw global-address     -> ../config/global-address
| | |   +--rw config
| | |   | +--rw local-address?   inet:ipv4-address
| | |   | +--rw global-address?  inet:ipv4-address
| | |   +--ro state
| | |   | +--ro local-address?   inet:ipv4-address
| | |   | +--ro global-address?  inet:ipv4-address
| | +--rw destination-mapping-entries
| |   +--rw destination-mapping-entry* [local-address global-address]
| |   +--rw local-address      -> ../config/local-address
| |   +--rw global-address     -> ../config/global-address
| |   +--rw config
| |   | +--rw local-address?   inet:ipv4-address
| |   | +--rw global-address?  inet:ipv4-address
| |   +--ro state

```

```

| |          +---ro local-address?    inet:ipv4-address
| |          +---ro global-address?   inet:ipv4-address
| +---rw outgoing
|   +---rw source-mapping-entries
|     | +---rw source-mapping-entry* [local-address global-address]
|     |   +---rw local-address      -> ../config/local-address
|     |   +---rw global-address     -> ../config/global-address
|     |   +---rw config
|     |     | +---rw local-address?   inet:ipv4-address
|     |     | +---rw global-address?  inet:ipv4-address
|     |     +---ro state
|     |       +---ro local-address?   inet:ipv4-address
|     |       +---ro global-address?  inet:ipv4-address
|   +---rw destination-mapping-entries
|     | +---rw destination-mapping-entry* [local-address global-address]
|     |   +---rw local-address      -> ../config/local-address
|     |   +---rw global-address     -> ../config/global-address
|     |   +---rw config
|     |     | +---rw local-address?   inet:ipv4-address
|     |     | +---rw global-address?  inet:ipv4-address
|     |     +---ro state
|     |       +---ro local-address?   inet:ipv4-address
|     |       +---ro global-address?  inet:ipv4-address
|   +---rw protocol-rule-mapping-entries
|     +---rw protocol-rule-mapping-entry* [protocol local-address port]
|       +---rw protocol              -> ../config/protocol
|       +---rw local-address         -> ../config/local-address
|       +---rw port                  -> ../config/port
|       +---rw config
|         | +---rw protocol?          ipi-network-address-translation-
types:nat_protocol_t
|         | +---rw local-address?     inet:ipv4-address
|         | +---rw port?              uint16
|         +---ro state
|         | +---ro protocol?          ipi-network-address-translation-
types:nat_protocol_t
|         | +---ro local-address?     inet:ipv4-address
|         | +---ro port?              uint16
|       +---rw global-addresses
|         +---rw global-address* [address]
|           +---rw address            -> ../config/address
|           +---rw config
|             | +---rw address?        inet:ipv4-address
|             | +---rw global-port     uint16
|             +---ro state
|               +---ro address?       inet:ipv4-address
|               +---ro global-port    uint16
+---rw interfaces
  +---rw interface* [name]
    +---rw name      -> ../config/name
    +---rw config

```

```

| +--rw name?      string
| +--rw incoming?  empty
| +--rw outgoing?  empty
+--ro state
  +--ro name?      string
  +--ro incoming?  empty
  +--ro outgoing?  empty

```

module: ipi-network-instance

```

+--rw network-instances
  +--rw network-instance* [instance-name instance-type]
    +--rw instance-name   -> ../config/instance-name
    +--rw instance-type   -> ../config/instance-type
    +--rw config
      | +--rw instance-name?  string
      | +--rw instance-type?  ipi-network-instance-types:net_inst_type_t
    +--ro state
      +--ro instance-name?    string
      +--ro instance-type?    ipi-network-instance-types:net_inst_type_t

```

module: ipi-network-services-manager

```

+--rw network-services-manager
  +--rw debug
    +--rw nsm
      | +--rw config
      | | +--rw options?  ipi-network-services-manager-types:nsm_debug_t
      | +--ro state
      | +--ro options?    ipi-network-services-manager-types:nsm_debug_t
    +--rw pkt-mgr
      | +--rw config
      | | +--rw options?  ipi-network-services-manager-types:nsm_pkt_mgr_debug_t
    {feature-list:HAVE_L2}?
      | +--ro state
      | +--ro options?    ipi-network-services-manager-types:nsm_pkt_mgr_debug_t
    {feature-list:HAVE_L2}?
      +--rw hsl {feature-list:HAVE_USER_HSL}?
        | +--rw hsl-module* [module-name]
        | +--rw module-name   -> ../config/module-name
        | +--rw config
        | | +--rw module-name?  ipi-network-services-manager-
types:hsl_debug_module_t
        | | +--rw level          ipi-network-services-manager-
types:hsl_debug_level_t

```

```

    |      +---ro state
    |      +---ro module-name?   ipi-network-services-manager-
types:hsl_debug_module_t
    |      +---ro level           ipi-network-services-manager-
types:hsl_debug_level_t
    +---ro terminal
        +---ro nsm
            | +---ro state
            | +---ro terminal-debug-status?   ipi-network-services-manager-
types:nsm_debug_t
            +---ro pkt-mgr
                +---ro state
                    +---ro terminal-debug-status?   ipi-network-services-manager-
types:nsm_pkt_mgr_debug_t {feature-list:HAVE_L2}?

rpcs:
  +---x nsm-terminal-debug-on
  | +---w input
  | +---w terminal-debug-options   ipi-network-services-manager-
types:nsm_exec_debug_t
  +---x nsm-terminal-debug-off
  | +---w input
  | +---w terminal-debug-options   ipi-network-services-manager-
types:nsm_exec_debug_t
  +---x hsl-terminal-debug-on {feature-list:NOT_HAVE_SWFWDR,feature-list:HAVE_HAL}?
  | +---w input
  | +---w module-name   ipi-network-services-manager-types:hsl_debug_module_t
  | +---w level         ipi-network-services-manager-types:hsl_debug_level_t
  +---x hsl-terminal-debug-off {feature-list:NOT_HAVE_SWFWDR,feature-list:HAVE_HAL}?
  | +---w input
  | +---w module-name   ipi-network-services-manager-types:hsl_debug_module_t
  | +---w level         ipi-network-services-manager-types:hsl_debug_level_t
  +---x pktmgr-terminal-debug-on {feature-list:HAVE_L2}?
  | +---w input
  | +---w terminal-debug-options   ipi-network-services-manager-
types:nsm_pkt_mgr_debug_t
  +---x pktmgr-terminal-debug-off {feature-list:HAVE_L2}?
  +---x pktmgr-debug-statistics-enable
  +---x pktmgr-debug-statistics-disable
  +---x pktmgr-debug-statistics-get
  +---x pktmgr-debug-error-statistics-get
  | +---w input
  | +---w debug-error-statistics   ipi-network-services-manager-
types:nsm_pktmgr_statistics_type_t
  +---x clear-nsm-ipc-statistics {feature-list:HAVE_ASYNC}?
  +---x nsm-snmp-restart {feature-list:HAVE_SNMP}?

```

module: ipi-ntp

```

+--rw ntp
  +--rw vrfs
    | +--rw vrf* [vrf-name]
    |   +--rw vrf-name          -> ../config/vrf-name
    |   +--rw config
    |     | +--rw vrf-name?      -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name
    |     | +--rw feature-enable?  boolean
    |     | +--rw enable-ntp?     boolean
    |     | +--rw enable-logging?  empty
    |     +--ro state
    |     | +--ro vrf-name?       -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name
    |     | +--ro feature-enable?  boolean
    |     | +--ro enable-ntp?     boolean
    |     | +--ro enable-logging?  empty
    |     +--rw ref-clock-master
    |     | +--rw config!
    |     |   | +--rw enable-local-master  empty
    |     |   | +--rw local-stratum?      uint8
    |     |   +--ro state
    |     |     +--ro enable-local-master  empty
    |     |     +--ro local-stratum?      uint8
    |     +--rw authentication
    |     | +--rw config
    |     |   | +--rw enable-ntp-auth?    empty
    |     |   | +--rw ntp-trusted-keys*  uint32
    |     |   | +--rw ntp-request-key?   uint32
    |     |   +--ro state
    |     |     | +--ro enable-ntp-auth?  empty
    |     |     | +--ro ntp-trusted-keys* uint32
    |     |     | +--ro ntp-request-key?  uint32
    |     |     +--rw ntp-keys
    |     |       +--rw ntp-key* [key-id]
    |     |         +--rw key-id   -> ../config/key-id
    |     |         +--rw config
    |     |           | +--rw key-id?    uint32
    |     |           | +--rw key-value  string
    |     |           | +--rw key-type   ipi-ntp-types:ntp_hostp_key_type_t
    |     |           +--ro state
    |     |             +--ro key-id?    uint32
    |     |             +--ro key-value  string
    |     |             +--ro key-type   ipi-ntp-types:ntp_hostp_key_type_t
    |     +--rw servers
    |     | +--rw server* [server-address]
    |     |   +--rw server-address  -> ../config/server-address
    |     |   +--rw config
    |     |     | +--rw server-address?  string

```

```
| | | +---rw prefer?          empty
| | | +---rw auth-key?        uint32
| | | +---rw minpoll?         uint16
| | | +---rw maxpoll?         uint16
| |   +---ro state
| |     +---ro server-address? string
| |     +---ro prefer?        empty
| |     +---ro auth-key?      uint32
| |     +---ro minpoll?       uint16
| |     +---ro maxpoll?       uint16
| +---rw peers
| | +---rw peer* [peer-address]
| |   +---rw peer-address    -> ../config/peer-address
| |   +---rw config
| |     | +---rw peer-address? string
| |     | +---rw prefer?      empty
| |     | +---rw auth-key?    uint32
| |     | +---rw minpoll?     uint16
| |     | +---rw maxpoll?     uint16
| |     +---ro state
| |       +---ro peer-address? string
| |       +---ro prefer?      empty
| |       +---ro auth-key?    uint32
| |       +---ro minpoll?     uint16
| |       +---ro maxpoll?     uint16
| +---rw rate-limiting
| | +---rw config
| | | +---rw minimum-pkt-spacing? uint16
| | +---ro state
| |   +---ro minimum-pkt-spacing? uint16
| +---rw access-control-entries
| | +---rw access-control-entry* [client-ip-address]
| |   +---rw client-ip-address  -> ../config/client-ip-address
| |   +---rw config
| |     | +---rw client-ip-address? inet:ip-address
| |     | +---rw netmask?          ipi-ntp-types:ntp_client_ip_net_mask_t
| |     | +---rw access-options?   ipi-ntp-types:ntp_acl_options_t
| |     +---ro state
| |       +---ro client-ip-address? inet:ip-address
| |       +---ro netmask?          ipi-ntp-types:ntp_client_ip_net_mask_t
| |       +---ro access-options?   ipi-ntp-types:ntp_acl_options_t
+---rw debug
| +---rw config
| | +---rw enable?    empty
| +---ro state
|   +---ro enable?          empty
|   +---ro terminal-debug-status? cml-data-types:cml_on_off_t
+---ro peer-info
  +---ro peers
    +---ro peer* [peer-address]
```



```

    +--ro peer-address    -> ../state/peer-address
    +--ro state
      +--ro peer-address?  cml-data-types:cml_hostname_t
      +--ro stratum?       uint8
      +--ro poll-interval? uint32
      +--ro reach-value?   uint16
      +--ro root-delay?    decimal64
      +--ro offset?        decimal64

rpcs:
  +---x ntp-clear-statistics {feature-list:HAVE_HOSTPD,feature-list:HAVE_HOSTP_NTP}?
  | +---w input
  |   +---w statistics-type   ipi-ntp-types:ntp_statistics_type_t
  +---x ntp-retry-server-synchronization {feature-list:HAVE_HOSTPD,feature-
list:HAVE_HOSTP_NTP}?
  | +---w input
  |   +---w vrf-name         string
  +---x ntp-terminal-debug-on {feature-list:HAVE_HOSTPD,feature-list:HAVE_HOSTP_NTP}?
  +---x ntp-terminal-debug-off {feature-list:HAVE_HOSTPD,feature-
list:HAVE_HOSTP_NTP}?

```

module: ipi-object-tracking

```

+--rw object-tracking
  +--rw trackers
  | +--rw tracker* [tracker-id]
  |   +--rw tracker-id    -> ../config/tracker-id
  |   +--rw config
  |     | +--rw tracker-id?  uint16
  |     | +--rw ip-sla-id    uint16
  |     | +--rw delay-up?    uint16
  |     | +--rw delay-down?  uint16
  |     +--ro state
  |       +--ro tracker-id?   uint16
  |       +--ro ip-sla-id     uint16
  |       +--ro delay-up?     uint16
  |       +--ro delay-down?   uint16
  |       +--ro reachability-status? ipi-object-tracking-
types:object_tracking_reachability_status_t {feature-list:HAVE_OBJ_TRACKING}?
  +--rw interfaces
  | +--rw interface* [name]
  |   +--rw name           -> ../config/name
  |   +--rw config
  |     | +--rw name?       -> /ipi-interface:interfaces/interface/name
  |     | +--rw select-option? ipi-object-tracking-
types:object_tracking_select_option_t
  |     +--ro state
  |     | +--ro name?       -> /ipi-interface:interfaces/interface/name

```

```

| +--ro select-option?  ipi-object-tracking-
types:object_tracking_select_option_t
+--rw track-interfaces
  +--rw track-interface* [track-id]
    +--rw track-id      -> ../config/track-id
    +--rw config
      | +--rw track-id?  uint32
    +--ro state
      +--ro track-id?   uint32

```

module: ipi-ospf-interface-tracking

```

+--rw ospf-interfaces-events-tracking
  +--rw ospf-interface-events-tracking* [event-name]
    +--rw event-name      -> ../config/event-name
    +--rw config
      | +--rw event-name?          string
      | +--rw event-match-criteria ipi-ospf-interface-tracking-
types:intf_track_match_type_t
      | +--rw event-neighbor-ip-address* inet:ipv4-address
    +--ro state
      | +--ro event-name?          string
      | +--ro event-match-criteria ipi-ospf-interface-tracking-
types:intf_track_match_type_t
      | +--ro event-neighbor-ip-address* inet:ipv4-address
    +--rw actions
      +--rw interfaces
        +--rw interface* [name]
          +--rw name      -> ../config/name
          +--rw config
            | +--rw name?      -> /ipi-interface:interfaces/interface/name
            | +--rw cost      uint32
          +--ro state
            +--ro name?      -> /ipi-interface:interfaces/interface/name
            +--ro cost      uint32

```

module: ipi-ospf

```

+--rw ospfv2
  +--rw global
    | +--rw config
    | | +--rw area-interface-config-mode?          empty
    | | +--rw enable-multi-instance-capability?    empty {feature-
list:HAVE_OSPF_MULTI_INST}?
    | +--ro state
    | | +--ro area-interface-config-mode?          empty
    | | +--ro enable-multi-instance-capability?    empty {feature-
list:HAVE_OSPF_MULTI_INST}?
    | +--rw graceful-restart {feature-list:HAVE_RESTART}?
    | | +--rw config
    | | | +--rw grace-period?      uint16
    | | +--ro state
    | | | +--ro grace-period?      uint16
    | | +--rw helper
    | |   +--rw config
    | |     | +--rw max-grace-period?      uint16
    | |     | +--rw disable-all-neighbors? empty
    | |     | +--rw disable-neighbor*     inet:ipv4-address
    | |     +--ro state
    | |       +--ro max-grace-period?      uint16
    | |       +--ro disable-all-neighbors? empty
    | |       +--ro disable-neighbor*     inet:ipv4-address
    | +--rw cspf {feature-list:HAVE_OSPF_CSPF}?
    |   +--rw config
    |     | +--rw tie-break-method?        ipi-ospf-types:ospf_cspf_tie_break_t
    |     | +--rw default-retry-interval?  uint16
    |     | +--rw enable-better-protection? empty {feature-list:HAVE_GMPLS}?
    |     +--ro state
    |       +--ro tie-break-method?        ipi-ospf-types:ospf_cspf_tie_break_t
    |       +--ro default-retry-interval?  uint16
    |       +--ro enable-better-protection? empty {feature-list:HAVE_GMPLS}?
  +--rw processes
    | +--rw process* [ospf-id]
    |   +--rw ospf-id          -> ../config/ospf-id
    |   +--rw config
    |     | +--rw ospf-id?          uint16
    |     | +--rw vrf-name          -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
    |     | +--rw router-id?        inet:ipv4-address
    |     | +--rw flood-reduction?   empty
    |     | +--rw rfc1583-compatibility? empty
    |     | +--rw database-summary?  empty
    |     | +--rw bfd-enable-all-interfaces? empty {feature-list:HAVE_BFD}?
    |     | +--rw log-adjacency-changes? ipi-ospf-types:ospf_log_adj_opt_t

```

```
| | +---rw shutdown? empty
| | +---rw area-border-type? ipi-ospf-types:ospf_abr_type_t
| | +---rw reference-bandwidth? uint32
| | +---rw max-database-descriptors? uint16
| | +---rw p2p-rfc-incompatible? empty
| | +---rw context-name? string
+---ro state
| | +---ro statistics
| | | +---ro router
| | | | +---ro area-counter? yang:counter64
| | | | +---ro database-description-exchanges
| | | | | +---ro in? yang:counter64
| | | | | +---ro out? yang:counter64
| | | | +---ro link-state-advertisement
| | | | | +---ro originate? yang:counter64
| | | | | +---ro received? yang:counter64
| | | | | +---ro external? yang:counter64
| | | | | +---ro opaque? yang:counter64
| | | | | +---ro non-default-external? yang:counter64
| | | | +---ro router-event
| | | | | +---ro packet
| | | | | | +---ro packets-send-buffer? yang:counter64
| | | | | | +---ro unused-packets? yang:counter64
| | | | | | +---ro max-unused-packets? yang:counter64
| | | | | +---ro lsa
| | | | | | +---ro older-lsa-received? yang:counter64
| | | | | | +---ro lsa-buffer? uint32
| | | | | +---ro spf
| | | | | | +---ro full? yang:counter64
| | | | | | +---ro summary? yang:counter64
| | | | | | +---ro external? yang:counter64
| | | | | +---ro neighbor
| | | | | | +---ro state-change? yang:counter64
| | | | | | +---ro dead-interval-expiration? yang:counter64
| | | | | | +---ro bad-link-state-request? yang:counter64
| | | | | | +---ro sequence-number-mismatch? yang:counter64
| | | | | +---ro router-id-changes? yang:counter64
| | | | | +---ro designated-router-election? yang:counter64
| | | | +---ro error
| | | | | +---ro discarded-in? yang:counter64
| | | | | +---ro discarded-out? yang:counter64
| | | | | +---ro hello-in? yang:counter64
| | | | | +---ro database-descriptor-in? yang:counter64
| | | | | +---ro ls-request-in? yang:counter64
| | | | | +---ro ls-update-in? yang:counter64
| | | | | +---ro ls-acknowledge-in? yang:counter64
| | | | | +---ro unknown-in? yang:counter64
| | | | | +---ro unknown-out? yang:counter64
| | | | | +---ro bad-version? yang:counter64
| | | | | +---ro bad-crc? yang:counter64
```

```

|         |         |         | +---ro invalid-source?           yang:counter64
|         |         |         | +---ro invalid-destination?       yang:counter64
|         |         |         | +---ro no-neighbor?           yang:counter64
|         |         |         | +---ro passive?               yang:counter64
|         |         |         | +---ro wrong-area?             yang:counter64
|         |         |         | +---ro packets-length?         yang:counter64
|         |         |         | +---ro bad-authentication?     yang:counter64
|         |         | +---ro traffic
|         |         |         | +---ro total-packets-in?         yang:counter64
|         |         |         | +---ro total-packets-out?       yang:counter64
|         |         |         | +---ro hello-packets-in?        yang:counter64
|         |         |         | +---ro hello-packets-out?       yang:counter64
|         |         |         | +---ro database-descriptor-packets-in? yang:counter64
|         |         |         | +---ro database-descriptor-packets-out? yang:counter64
|         |         |         | +---ro ls-request-packets-in?    yang:counter64
|         |         |         | +---ro ls-request-packets-out?   yang:counter64
|         |         |         | +---ro ls-update-packets-in?     yang:counter64
|         |         |         | +---ro ls-update-packets-out?    yang:counter64
|         |         |         | +---ro ls-acknowledge-packets-in? yang:counter64
|         |         |         | +---ro ls-acknowledge-packets-out? yang:counter64
|         |         | +---ro up-time?                          string
|         | +---ro ospf-id?                                    uint16
|         | +---ro vrf-name                                    -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
|         | +---ro router-id?                                  inet:ipv4-address
|         | +---ro flood-reduction?                            empty
|         | +---ro rfc1583-compatibility?                       empty
|         | +---ro database-summary?                            empty
|         | +---ro bfd-enable-all-interfaces?                 empty {feature-list:HAVE_BFD}?
|         | +---ro log-adjacency-changes?                      ipi-ospf-types:ospf_log_adj_opt_t
|         | +---ro shutdown?                                    empty
|         | +---ro area-border-type?                            ipi-ospf-types:ospf_abr_type_t
|         | +---ro reference-bandwidth?                         uint32
|         | +---ro max-database-descriptors?                   uint16
|         | +---ro p2p-rfc-incompatible?                        empty
|         | +---ro context-name?                                string
|         | +---ro dste-status?                                  ipi-ospf-types:ospf_dste_status
| +---ro link-state-database
|   | +---ro state
|   |   | +---ro external-checksum?   yang:phys-address
|   |   | +---ro opaque-checksum?     yang:phys-address
| +---rw passive-interfaces
|   | +---rw config
|   | | +---rw passive-interface-all? empty
|   | +---ro state
|   | | +---ro passive-interface-all? empty
|   | +---rw passive-interface* [name]
|   |   | +---rw name                    -> ../config/name
|   |   | +---rw config
|   |   | | +---rw name?                  -> /ipi-interface:interfaces/interface/name
|   |   | | +---rw passive-mode?         ipi-ospf-types:ospf_passive_mode_t

```

```
| | | +---ro state
| | | | +---ro name? -> /ipi-interface:interfaces/interface/name
| | | | +---ro passive-mode? ipi-ospf-types:ospf_passive_mode_t
| | | +---rw passive-addresses
| | | | +---rw passive-address* [address]
| | | | | +---rw address -> ../config/address
| | | | | +---rw config
| | | | | | +---rw address? inet:ipv4-address
| | | | | | +---rw passive-mode ipi-ospf-types:ospf_passive_addr_mode_t
| | | | +---ro state
| | | | | +---ro address? inet:ipv4-address
| | | | | +---ro passive-mode ipi-ospf-types:ospf_passive_addr_mode_t
| | +---rw default-information
| | | +---rw config
| | | | +---rw originate? empty
| | | | +---rw always-advertise-default-route? empty
| | | | +---rw metric? uint32
| | | | +---rw metric-type? ipi-ospf-types:ospf_metric_type_t
| | | | +---rw route-map? string
| | | +---ro state
| | | | +---ro originate? empty
| | | | +---ro always-advertise-default-route? empty
| | | | +---ro metric? uint32
| | | | +---ro metric-type? ipi-ospf-types:ospf_metric_type_t
| | | | +---ro route-map? string
| | +---rw segment-routing {feature-list:HAVE_SR_MPLS}?
| | | +---rw config
| | | | +---rw mpls? empty
| | | +---ro state
| | | | +---ro mpls? empty
| | +---rw global-blocks {feature-list:HAVE_SR_MPLS}?
| | | +---rw global-block* [block-base-value block-range-size]
| | | | +---rw block-base-value -> ../config/block-base-value
| | | | +---rw block-range-size -> ../config/block-range-size
| | | | | +---rw config
| | | | | | +---rw block-base-value? uint32
| | | | | | +---rw block-range-size? uint32
| | | | | +---ro state
| | | | | | +---ro block-base-value? uint32
| | | | | | +---ro block-range-size? uint32
| | +---rw prefix-sid-map {feature-list:HAVE_SR_MPLS}?
| | | +---rw config
| | | | +---rw advertise-local? empty
| | | | +---rw disable-receive? empty
| | | +---ro state
| | | | +---ro advertise-local? empty
| | | | +---ro disable-receive? empty
| | +---ro announce-lists
| | | +---ro announce-list* [area-id]
| | | | +---ro area-id -> ../state/area-id
```

```

|         |         |         +---ro state
|         |         |         | +---ro area-id?      inet:ipv4-address
|         |         |         | +---ro instance?   uint32
|         |         |         +---ro external-prefixes-lsa
|         |         |         | +---ro external-prefix-lsa* [prefix]
|         |         |         |     +---ro prefix    -> ../state/prefix
|         |         |         |     +---ro state
|         |         |         |         +---ro prefix?          cml-data-
types:cml_ipv4_addr_prefix_t
|         |         |         |         +---ro advertising-router?  inet:ipv4-address
|         |         |         |         +---ro route-type?         ipi-ospf-
types:ospf_prefix_route_type_t
|         |         |         +---ro external-prefixes-range
|         |         |         | +---ro external-prefix-range* [ls-id]
|         |         |         |     +---ro ls-id      -> ../state/ls-id
|         |         |         |     +---ro state
|         |         |         |         +---ro ls-id?          inet:ipv4-address
|         |         |         |         +---ro prefix?          cml-data-
types:cml_ipv4_addr_prefix_t
|         |         |         |         +---ro advertising-router?  inet:ipv4-address
|         |         |         |         +---ro range-size?         uint16
|         |         |         |         +---ro mapping-servers
|         |         |         |         +---ro state
|         |         |         |         | +---ro active-entries-count?  yang:counter32
|         |         |         |         | +---ro inactive-entries-count?  yang:counter32
|         |         |         |         | +---ro conflict-resolution-policy? ipi-ospf-
types:ospf_resolution_policy_t
|         |         |         |         +---ro active-servers
|         |         |         |         | +---ro active-server* [prefix]
|         |         |         |         |     +---ro prefix    -> ../state/prefix
|         |         |         |         |     +---ro state
|         |         |         |         |         +---ro prefix?          cml-data-
types:cml_ipv4_addr_prefix_t
|         |         |         |         |         +---ro sid-index?      uint32
|         |         |         |         |         +---ro range-size?      uint32
|         |         |         |         |         +---ro last-prefix?      cml-data-
types:cml_ipv4_addr_prefix_t
|         |         |         |         |         +---ro last-sid-index?    uint32
|         |         |         |         |         +---ro binding-flags?    empty
|         |         |         |         |         +---ro preference?        uint8
|         |         |         |         |         +---ro status?            ipi-ospf-
types:ospf_sr_mapping_server_status_t
|         |         |         |         |         +---ro advertising-router?  inet:ipv4-address
|         |         |         |         |         +---ro flags?            uint8
|         |         |         |         |         +---ro inactive-servers
|         |         |         |         |         | +---ro inactive-server* [prefix]
|         |         |         |         |         |     +---ro prefix    -> ../state/prefix
|         |         |         |         |         |     +---ro state
|         |         |         |         |         |         +---ro prefix?          cml-data-
types:cml_ipv4_addr_prefix_t
|         |         |         |         |         |         +---ro sid-index?      uint32
|         |         |         |         |         |         +---ro range-size?      uint32

```

```

| | | +---ro last-prefix? cml-data-
types:cml_ipv4_addr_prefix_t
| | | +---ro last-sid-index? uint32
| | | +---ro binding-flags? empty
| | | +---ro preference? uint8
| | | +---ro status? ipi-ospf-
types:ospf_sr_mapping_server_status_t
| | | +---ro advertising-router? inet:ipv4-address
| | | +---ro flags? uint8
| | +---rw sr-capability-entropy {feature-list:HAVE_SR_MPLS}?
| | | +---rw config
| | | | +---rw entropy-capability? empty
| | | | +---ro state
| | | | +---ro entropy-capability? empty
| | | +---ro capabilities
| | | +---ro capability* [advertising-router]
| | | +---ro advertising-router -> ../state/advertising-router
| | | +---ro state
| | | | +---ro advertising-router? inet:ipv4-address
| | | | +---ro algorithms* ipi-ospf-
types:ospf_sr_algorithm_t
| | | | +---ro entropy-capability? empty
| | | | +---ro entropy-readable-label-depth? uint8
| | | | +---ro mapping-server-preference? uint8
| | | +---ro segment-identifier
| | | | +---ro state
| | | | | +---ro total-supported? uint32
| | | | | +---ro range-count? uint32
| | | | +---ro sid-ranges
| | | | | +---ro sid-range* [start end]
| | | | | +---ro start -> ../state/start
| | | | | +---ro end -> ../state/end
| | | | | +---ro state
| | | | | +---ro start? uint32
| | | | | +---ro end? uint32
| | +---rw capability
| | | +---rw config
| | | | +---rw disable-cspf? empty {feature-list:HAVE_OSPF_CSPF}?
| | | | +---rw enable-vrf-lite? empty {feature-list:HAVE_VRF_OSPF}?
| | | | +---rw disable-opaque-lsa? empty {feature-
list:HAVE_OPAQUE_LSA}?
| | | | +---rw disable-traffic-engineering? empty {feature-list:HAVE_OSPF_TE}?
| | | | +---rw disable-graceful-restart? empty {feature-list:HAVE_RESTART}?
| | | | +---rw link-local-signaling? empty {feature-list:HAVE_RESTART}?
| | | | +---ro state
| | | | +---ro disable-cspf? empty {feature-list:HAVE_OSPF_CSPF}?
| | | | +---ro enable-vrf-lite? empty {feature-list:HAVE_VRF_OSPF}?
| | | | +---ro disable-opaque-lsa? empty {feature-
list:HAVE_OPAQUE_LSA}?
| | | | +---ro disable-traffic-engineering? empty {feature-list:HAVE_OSPF_TE}?
| | | | +---ro disable-graceful-restart? empty {feature-list:HAVE_RESTART}?

```



```

|      |      +---ro link-local-signaling?          empty {feature-list:HAVE_RESTART}?
|      +---rw areas
|      |      +---rw area* [area-id]
|      |      |      +---rw area-id                  -> ../config/area-id
|      |      |      +---rw config
|      |      |      |      +---rw area-id?          ipi-ospf-types:ospf_area_t
|      |      |      |      +---rw authentication-type? ipi-ospf-
types:ospf_area_authentication_type_t
|      |      |      |      +---rw default-cost?      uint32
|      |      |      |      +---rw shortcut?          ipi-ospf-types:ospf_area_shortcut_type_t
|      |      |      +---ro state
|      |      |      |      +---ro area-id?          ipi-ospf-types:ospf_area_t
|      |      |      |      +---ro authentication-type? ipi-ospf-
types:ospf_area_authentication_type_t
|      |      |      |      +---ro default-cost?      uint32
|      |      |      |      +---ro shortcut?          ipi-ospf-
types:ospf_area_shortcut_type_t
|      |      |      |      +---ro interface-count?   yang:counter64
|      |      |      |      +---ro neighbor-count?   yang:counter64
|      |      |      |      +---ro spf-last-execution-time? string
|      |      |      |      +---ro spf-execution-count? yang:counter64
|      |      |      |      +---ro lsa-count?         yang:counter64
|      |      |      |      +---ro lsa-checksum?     yang:phys-address
|      |      |      +---rw interfaces
|      |      |      |      +---rw interface* [name]
|      |      |      |      |      +---rw name          -> ../config/name
|      |      |      |      |      +---rw config
|      |      |      |      |      |      +---rw name?      string
|      |      |      |      |      |      +---rw cost?      uint16
|      |      |      |      |      |      +---rw network-type? ipi-ospf-types:ospf_network_t
|      |      |      |      |      |      +---rw passive?    empty
|      |      |      |      |      |      +---rw priority?   uint8
|      |      |      |      |      |      +---rw authentication-type? ipi-ospf-
types:ospf_if_authentication_type_t
|      |      |      |      |      +---rw key?          ipi-ospf-types:ospf_md5_password_t
|      |      |      |      |      +---ro state
|      |      |      |      |      |      +---ro name?      string
|      |      |      |      |      |      +---ro cost?      uint16
|      |      |      |      |      |      +---ro network-type? ipi-ospf-types:ospf_network_t
|      |      |      |      |      |      +---ro passive?    empty
|      |      |      |      |      |      +---ro priority?   uint8
|      |      |      |      |      |      +---ro authentication-type? ipi-ospf-
types:ospf_if_authentication_type_t
|      |      |      |      |      +---ro key?          ipi-ospf-types:ospf_md5_password_t
|      |      |      |      |      +---rw enable-bfd {feature-list:HAVE_BFD}?
|      |      |      |      |      +---rw config
|      |      |      |      |      |      +---rw enabled?   ipi-ospf-types:ospf_bfd_state
|      |      |      |      |      |      +---ro state
|      |      |      |      |      |      |      +---ro enabled?   ipi-ospf-types:ospf_bfd_state
|      |      |      |      |      +---rw lsa-filter
|      |      |      |      |      +---rw config

```



```

|      | | | |      +---ro state
|      | | | |      +---ro nssa-enable?                ipi-ospf-types:ospf_nssa_t
|      | | | |      +---ro no-summary?                 empty
|      | | | |      +---ro stability-interval?         uint32
|      | | | |      +---ro translator-role?            ipi-ospf-
types:ospf_translator_role_t
|      | | | |      +---ro no-redistribution?           empty
|      | | | |      +---ro default-information-originate? empty
|      | | | |      +---ro metric?                     uint32
|      | | | |      +---ro metric-type?                ipi-ospf-
types:ospf_metric_type_t
|      | | | |      +---ro route-map?                   string
|      | | | |      +---ro translator-count?            yang:counter64
|      | | | |      +---ro translator-state?            ipi-ospf-
types:ospf_nssa_translator_state_t
|      | | | | +---rw filter-list {feature-list:HAVE_ACL}?
|      | | | |   +---rw prefix-list {feature-list:HAVE_ACL}?
|      | | | |     | +---rw filter-in
|      | | | |     | | +---rw config
|      | | | |     | | | +---rw name?    string
|      | | | |     | | | +---ro state
|      | | | |     | |   +---ro name?    string
|      | | | |     | +---rw filter-out
|      | | | |     |   +---rw config
|      | | | |     |   | +---rw name?    string
|      | | | |     |   +---ro state
|      | | | |     |     +---ro name?    string
|      | | | |   +---rw access-control-list {feature-list:HAVE_ACL}?
|      | | | |     +---rw filter-in
|      | | | |     | +---rw config
|      | | | |     | | +---rw name?    string
|      | | | |     | +---ro state
|      | | | |     |   +---ro name?    string
|      | | | |     +---rw filter-out
|      | | | |     | +---rw config
|      | | | |     | | +---rw name?    string
|      | | | |     | +---ro state
|      | | | |     |   +---ro name?    string
|      | | | |   +---rw hosts
|      | | | |     +---rw host* [ip-address]
|      | | | |       +---rw ip-address  -> ../config/ip-address
|      | | | |       +---rw config
|      | | | |       | +---rw ip-address? inet:ipv4-address
|      | | | |       | +---rw cost?      uint16
|      | | | |       +---ro state
|      | | | |         +---ro ip-address? inet:ipv4-address
|      | | | |         +---ro cost?      uint16
|      | | | |   +---rw networks
|      | | | |     +---rw network* [prefix]
|      | | | |       +---rw prefix      -> ../config/prefix
|      | | | |       +---rw config

```

```

| | | | | +---rw prefix?          cml-data-types:cml_ipv4_prefix_t
| | | | | +---rw instance-id      uint8 {feature-list:HAVE_OSPF_MULTI_INST}?
| | | | | +---ro state
| | | | | +---ro prefix?          cml-data-types:cml_ipv4_prefix_t
| | | | | +---ro instance-id      uint8 {feature-list:HAVE_OSPF_MULTI_INST}?
| | | +---rw area-ranges
| | | | +---rw area-range* [address]
| | | | +---rw address    -> ../config/address
| | | | +---rw config
| | | | | +---rw address?          cml-data-types:cml_ipv4_prefix_t
| | | | | +---rw disable-advertise? empty
| | | | | +---ro state
| | | | | +---ro address?          cml-data-types:cml_ipv4_prefix_t
| | | | | +---ro disable-advertise? empty
| | | +---rw virtual-links
| | | | +---rw virtual-link* [remote-router-id]
| | | | +---rw remote-router-id          -> ../config/remote-
router-id
| | | | | +---rw config
| | | | | +---rw remote-router-id?      inet:ipv4-address
| | | | | +---ro state
| | | | | +---ro remote-router-id?          inet:ipv4-address
| | | | | +---ro name?                      string
| | | | | +---ro interface?                 string
| | | | | +---ro virtual-link-interface-state? ipi-ospf-
types:ospf_vlink_interface_state_t
| | | | | +---ro link-state?                 ipi-ospf-
types:ospf_vlink_status_t
| | | | | +---ro adjacency-state?           ipi-ospf-
types:ospf_vlink_adj_state_t
| | | | | +---ro hello-packet-due-in?       string
| | | | | +---ro local-address?            cml-data-
types:cml_ipv4_prefix_t
| | | | | +---ro remote-address?           cml-data-
types:cml_ipv4_prefix_t
| | | | | +---rw bfd
| | | | | +---rw config
| | | | | | +---rw fall-over?      empty {feature-list:HAVE_BFD}?
| | | | | | +---ro state
| | | | | | +---ro fall-over?      empty {feature-list:HAVE_BFD}?
| | | | | +---rw authentication
| | | | | +---rw config
| | | | | | +---rw authentication-type?      ipi-ospf-
types:ospf_if_authentication_type_t
| | | | | | +---rw key?                      ipi-ospf-
types:ospf_md5_password_t
| | | | | | +---ro state
| | | | | | +---ro authentication-type?      ipi-ospf-
types:ospf_if_authentication_type_t
| | | | | | +---ro key?                      ipi-ospf-
types:ospf_md5_password_t
| | | | | +---rw message-digests
| | | | | +---rw message-digest* [message-digest-id]

```

```

|         |         |         |         |         +---rw message-digest-id    -> ../config/message-digest-id
|         |         |         |         |         +---rw config
|         |         |         |         |         | +---rw message-digest-id?          uint8
|         |         |         |         |         | +---rw message-digest-encryption-type  ipi-ospf-
types:ospf_cipher_type_t
|         |         |         |         |         | +---rw message-digest-key          ipi-ospf-
types:ospf_md5_password_t
|         |         |         |         |         +---ro state
|         |         |         |         |         +---ro message-digest-id?          uint8
|         |         |         |         |         +---ro message-digest-encryption-type  ipi-ospf-
types:ospf_cipher_type_t
|         |         |         |         |         +---ro message-digest-key          ipi-ospf-
types:ospf_md5_password_t
|         |         |         |         +---rw timers
|         |         |         |         | +---rw config
|         |         |         |         | | +---rw dead-interval?          uint16
|         |         |         |         | | +---rw hello-interval?          uint16
|         |         |         |         | | +---rw transmit-delay?          uint16
|         |         |         |         | | +---rw retransmission-interval?  uint16
|         |         |         |         | +---ro state
|         |         |         |         | +---ro dead-interval?          uint16
|         |         |         |         | +---ro hello-interval?          uint16
|         |         |         |         | +---ro transmit-delay?          uint16
|         |         |         |         | +---ro retransmission-interval?  uint16
|         |         |         |         +---ro virtual-link-interface-state-change
|         |         |         |         | +---ro router-id?          inet:ipv4-address
|         |         |         |         | +---ro interface-state?    ipi-ospf-types:ospf_interface_state_t
|         |         |         |         +---ro virtual-neighbor-state-change
|         |         |         |         | +---ro router-id?          inet:ipv4-address
|         |         |         |         | +---ro neighbor-state?    ipi-ospf-
types:ospf_neighbor_state_change_t
|         |         |         |         +---ro virtual-link-interface-rx-bad-packet
|         |         |         |         | +---ro router-id?          inet:ipv4-address
|         |         |         |         | +---ro packet-type?    ipi-ospf-types:ospf_packet_type_t
|         |         |         |         +---ro virtual-link-interface-tx-retransmit
|         |         |         |         | +---ro router-id?          inet:ipv4-address
|         |         |         |         | +---ro packet-type?    ipi-ospf-types:ospf_packet_type_t
|         |         |         |         | +---ro lsdB-type?          ipi-ospf-types:ospf_lsdB_type_t
|         |         |         |         | +---ro lsdB-lsid?          inet:ipv4-address
|         |         |         |         | +---ro lsdB-router-id?    inet:ipv4-address
|         |         |         |         +---ro virtual-link-interface-config-error
|         |         |         |         | +---ro router-id?          inet:ipv4-address
|         |         |         |         | +---ro error-type?          ipi-ospf-types:ospf_config_error_type_t
|         |         |         |         | +---ro packet-type?    ipi-ospf-types:ospf_packet_type_t
|         |         |         +---rw sham-links {feature-list:HAVE_VRF_OSPF,feature-list:HAVE_MPLS}?
|         |         |         | +---rw sham-link* [source-id destination-id]
|         |         |         | +---rw source-id          -> ../config/source-id
|         |         |         | +---rw destination-id      -> ../config/destination-id
|         |         |         | +---rw config
|         |         |         | +---rw source-id?          inet:ipv4-address
|         |         |         | +---rw destination-id?     inet:ipv4-address

```

```

|         |         |         |         +---rw cost?                uint16
|         |         |         | +---ro traffic-engineering-database {feature-list:HAVE_OSPF_CSPF}?
|         |         |         |         +---ro link* [advertising-router link-id]
|         |         |         |         | +---ro advertising-router    -> ../state/advertising-router
|         |         |         |         | +---ro link-id                -> ../state/link-id
|         |         |         |         | +---ro state
|         |         |         |         | | +---ro link-id?                inet:ipv4-address
|         |         |         |         | | +---ro advertising-router?    inet:ipv4-address
|         |         |         |         | | +---ro ls-options?            string
|         |         |         |         | | +---ro ls-opaque-type?        uint32
|         |         |         |         | | +---ro ls-age?                uint16
|         |         |         |         | | +---ro ls-type?                ipi-ospf-types:ospf_lsdb_type_t
|         |         |         |         | | +---ro ls-instance?           string
|         |         |         |         | | +---ro ls-sequence-number?    string
|         |         |         |         | | +---ro ls-checksum?           string
|         |         |         |         | | +---ro ls-length?            uint16
|         |         |         |         | +---ro tlv
|         |         |         |         |         +---ro state
|         |         |         |         |         | +---ro type?                ipi-ospf-
types:ospf_tlv_type_t
|         |         |         |         |         | +---ro link-type?            ipi-ospf-
types:ospf_tlv_link_type_t
|         |         |         |         |         | +---ro local-interface-addresses*  inet:ipv4-address
|         |         |         |         |         | +---ro remote-interface-addresses*  inet:ipv4-address
|         |         |         |         |         | +---ro local-ids*            inet:ipv4-address
{feature-list:HAVE_GMPLS}?
|         |         |         |         |         | +---ro remote-ids*            inet:ipv4-address
{feature-list:HAVE_GMPLS}?
|         |         |         |         |         | +---ro local-interface-id?        uint32 {feature-
list:HAVE_GMPLS}?
|         |         |         |         |         | +---ro local-remote-interface-id?  uint32 {feature-
list:HAVE_GMPLS}?
|         |         |         |         |         | +---ro metric?                uint32
|         |         |         |         |         | +---ro maximum-bandwidth?        string
|         |         |         |         |         | +---ro maximum-reservable-bandwidth?  string
|         |         |         |         |         | +---ro resource-color-values*      decimal64
|         |         |         |         |         | +---ro protection-type?          cml-data-
types:cml_gmpls_protection_type_t
|         |         |         |         |         | +---ro shared-risk-link-groups?    uint32
|         |         |         |         |         | +---ro capability
|         |         |         |         |         | +---ro state
|         |         |         |         |         | | +---ro type?                cml-data-
types:cml_gmpls_capability_type_t {feature-list:HAVE_GMPLS}?
|         |         |         |         |         | | +---ro encoding-type?          cml-data-
types:cml_gmpls_encoding_type_t {feature-list:HAVE_GMPLS}?
|         |         |         |         |         | | +---ro mtu?                uint16
|         |         |         |         |         | | +---ro minimum-lsp-bandwidth?  string {feature-
list:HAVE_GMPLS}?
|         |         |         |         |         | +---ro maximum-lsp-bandwidths
|         |         |         |         |         |         +---ro maximum-lsp-bandwidth* [priority]
|         |         |         |         |         |         | +---ro priority    -> ../state/priority
|         |         |         |         |         |         | +---ro state
|         |         |         |         |         |         | +---ro priority?    uint8

```

```

|         |         |         |         |         +--ro bandwidth?   string
|         |         |         |         +--ro unreserved-bandwidths
|         |         |         |         |   +--ro unreserved-bandwidth* [priority]
|         |         |         |         |     +--ro priority   -> ../state/priority
|         |         |         |         |     +--ro state
|         |         |         |         |         +--ro priority?   uint8
|         |         |         |         |         +--ro bandwidth?  string
|         |         |         |         +--ro link-delay
|         |         |         |         |   +--ro state
|         |         |         |         |     +--ro anomalous-bit?  empty
|         |         |         |         |     +--ro delay?          uint32
|         |         |         |         +--ro link-min-max-delay
|         |         |         |         |   +--ro state
|         |         |         |         |     +--ro anomalous-bit?  empty
|         |         |         |         |     +--ro minimum-delay?  uint32
|         |         |         |         |     +--ro maximum-delay?  uint32
|         |         |         |         +--ro link-delay-variation
|         |         |         |         |   +--ro state
|         |         |         |         |     +--ro delay-variation?  uint32
|         |         |         |         +--ro link-loss
|         |         |         |         |   +--ro state
|         |         |         |         |     +--ro anomalous-bit?  empty
|         |         |         |         |     +--ro loss?          string
|         |         |         |         +--ro link-bandwidth
|         |         |         |         |   +--ro state
|         |         |         |         |     +--ro residual-bandwidth?  string
|         |         |         |         |     +--ro available-bandwidth?  string
|         |         |         |         |     +--ro utilized-bandwidth?  string
|         |         |         +--ro router* [router-id]
|         |         |         |   +--ro router-id   -> ../state/router-id
|         |         |         |   +--ro state
|         |         |         |     +--ro router-id?          inet:ipv4-address
|         |         |         |     +--ro advertising-router?  inet:ipv4-address
|         |         |         |     +--ro ls-options?          string
|         |         |         |     +--ro ls-opaque-type?      uint32
|         |         |         |     +--ro ls-age?              uint16
|         |         |         |     +--ro ls-type?            ipi-ospf-types:ospf_lsdb_type_t
|         |         |         |     +--ro ls-instance?         string
|         |         |         |     +--ro ls-sequence-number?  string
|         |         |         |     +--ro ls-checksum?         string
|         |         |         |     +--ro ls-length?           uint16
|         |         |         +--rw config
|         |         |         |   +--rw maximum-areas-number?  uint32
|         |         |         |   +--ro state
|         |         |         |     +--ro maximum-areas-number?  uint32
|         +--rw lsdb
|         |   +--rw overflow
|         |     +--rw normal-lsa
|         |       |   +--rw config!
|         |       |     +--rw max-limit      uint32

```

```

|     |     | | +--rw limit-type      ipi-ospf-types:ospf_db_limit_type_t
|     |     | +--ro state
|     |     |   +--ro max-limit      uint32
|     |     |   +--ro limit-type     ipi-ospf-types:ospf_db_limit_type_t
|     |     +--rw external-lsa {feature-list:HAVE_OSPF_DB_OVERFLOW}?
|     |     | +--rw config!
|     |     | | +--rw max-limit      uint32
|     |     | | +--rw exit-interval  uint16
|     |     | +--ro state
|     |     |   +--ro max-limit      uint32
|     |     |   +--ro exit-interval  uint16
|     |     +--ro lsdb-overflow-external-lsa
|     |         +--ro router-id?    -> /ospfv2/processes/process/state/router-id
|     |         +--ro max-limit?    uint32
|     +--rw lfa {feature-list:HAVE_OSPF_LFA}?
|     | +--rw fast-reroute
|     | +--rw config
|     | | +--rw keep-all-paths?    empty
|     | | +--rw remote-lfa-areas*  ipi-ospf-types:ospf_area_t {feature-
list:HAVE_LDPD}?
|     | | +--rw route-map?         string
|     | | +--ro state
|     | | +--ro keep-all-paths?    empty
|     | | +--ro remote-lfa-areas*  ipi-ospf-types:ospf_area_t {feature-
list:HAVE_LDPD}?
|     | | +--ro route-map?         string
|     | +--rw tie-breaks
|     | | +--rw tie-break* [type]
|     | |   +--rw type            -> ../config/type
|     | |   +--rw config
|     | | | +--rw type?          ipi-ospf-types:ospf_frr_tie_break_t
|     | | | +--rw idx           uint8
|     | | +--ro state
|     | | | +--ro type?          ipi-ospf-types:ospf_frr_tie_break_t
|     | | | +--ro idx           uint8
|     | +--rw topologies-independent-lfa
|     | | +--rw topology-independent-lfa* [area-id] {feature-
list:HAVE_OSPF_TI_LFA}?
|     | | +--rw area-id          -> ../config/area-id
|     | | +--rw config
|     | | | +--rw area-id?      ipi-ospf-types:ospf_area_t
|     | | +--ro state
|     | | | +--ro area-id?      ipi-ospf-types:ospf_area_t
|     | | +--ro routes {feature-list:HAVE_OSPF_TI_LFA}?
|     | | | +--ro route* [prefix]
|     | | |   +--ro prefix      -> ../state/prefix
|     | | |   +--ro state
|     | | | | +--ro prefix?     cml-data-types:cml_ipv4_addr_prefix_t
|     | | | | +--ro p-node?     inet:ipv4-address
|     | | | | +--ro pq-node?    inet:ipv4-address
|     | | | | +--ro q-node?     inet:ipv4-address

```



```

|         |         | +--ro segment-routing-incoming-label?      uint32
|         |         | +--ro segment-routing-outgoing-label?     uint32
|         |         | +--ro backup-outgoing-label?             uint32
|         |         | +--ro bypass-trunk-id?                   uint32
|         |         | +--ro backup-interface-name?             string
|         |         +--ro segment-routing-trunks
|         |             +--ro segment-routing-trunk* [trunk-name]
|         |                 +--ro trunk-name      -> ../state/trunk-name
|         |                 +--ro state
|         |                     +--ro trunk-name?      string
|         |                     +--ro trunk-id?        uint32
|         |                     +--ro ftn-id?          uint32
|         |                     +--ro outgoing-label-count? yang:counter32
|         |                     +--ro outgoing-labels*  uint32
|         |                     +--ro next-hop?         inet:ipv4-address
| +--rw administrative-distance
| | +--rw config
| | | +--rw default-distance?  uint8
| | +--ro state
| | | +--ro default-distance?  uint8
| | +--rw ospf
| | | +--rw config
| | | | +--rw intra-area-distance?  uint8
| | | | +--rw inter-area-distance?  uint8
| | | | +--rw external-routes-distance?  uint8
| | | +--ro state
| | | | +--ro intra-area-distance?  uint8
| | | | +--ro inter-area-distance?  uint8
| | | | +--ro external-routes-distance?  uint8
| | +--rw networks
| | | +--rw network* [prefix]
| | | | +--rw prefix      -> ../config/prefix
| | | | +--rw config
| | | | | +--rw prefix?      cml-data-types:cml_ipv4_addr_prefix_t
| | | | | +--rw distance?    uint8
| | | | | +--rw access-control-list?  string
| | | | +--ro state
| | | | | +--ro prefix?      cml-data-types:cml_ipv4_addr_prefix_t
| | | | | +--ro distance?    uint8
| | | | | +--ro access-control-list?  string
| +--rw summary-addresses
| | +--rw summary-address* [address]
| | | +--rw address      -> ../config/address
| | | +--rw config
| | | | +--rw address?      cml-data-types:cml_ipv4_prefix_t
| | | | +--rw not-advertise?  empty
| | | | +--rw tag?          uint32
| | | +--ro state
| | | | +--ro address?      cml-data-types:cml_ipv4_prefix_t
| | | | +--ro not-advertise?  empty

```

```

|         |         +---ro tag?                uint32
| +---rw distribute-list {feature-list:HAVE_ACL}?
|         | +---rw filter-in
|         | | +---rw config
|         | | | +---rw access-control-list?   string
|         | | | +---ro state
|         | |   +---ro access-control-list?   string
|         | +---rw filter-out
|         |   +---rw config
|         |   | +---rw access-control-list-isis?   string
|         |   | +---rw access-control-list-bgp?   string
|         |   | +---rw access-control-list-rip?   string
|         |   | +---rw access-control-list-static? string
|         |   | +---rw access-control-list-connected? string
|         |   | +---rw access-control-list-kernel? string
|         |   +---ro state
|         |   | +---ro access-control-list-isis?   string
|         |   | +---ro access-control-list-bgp?   string
|         |   | +---ro access-control-list-rip?   string
|         |   | +---ro access-control-list-static? string
|         |   | +---ro access-control-list-connected? string
|         |   | +---ro access-control-list-kernel? string
|         | +---rw ospfv2-processes
|         |   +---rw ospfv2-process* [ospf-process-id]
|         |     +---rw ospf-process-id   -> ../config/ospf-process-id
|         |     +---rw config
|         |     | +---rw ospf-process-id?   uint16
|         |     | +---rw access-control-list-out-ospf? string
|         |     +---ro state
|         |     | +---ro ospf-process-id?   uint16
|         |     | +---ro access-control-list-out-ospf? string
| +---rw domain-id
|   | +---rw primary-domain {feature-list:HAVE_VRF_OSPF}?
|   | | +---rw config
|   | | | +---rw primary-domain-id-address?  inet:ipv4-address
|   | | | +---ro state
|   | | | +---ro primary-domain-id-address?  inet:ipv4-address
|   | | +---rw hexes
|   | | | +---rw hex* [primary-hex-type primary-domain-id-hex] {feature-
list:HAVE_VRF_OSPF}?
|   | | |   +---rw primary-hex-type         -> ../config/primary-hex-type
|   | | |   +---rw primary-domain-id-hex    -> ../config/primary-domain-id-hex
|   | | |   +---rw config
|   | | |   | +---rw primary-hex-type?      ipi-ospf-types:ospf_domain_type_t
|   | | |   | +---rw primary-domain-id-hex? ipi-ospf-
types:ospf_domain_id_hex_string_t
|   | | |   +---ro state
|   | | |   | +---ro primary-hex-type?      ipi-ospf-types:ospf_domain_type_t
|   | | |   | +---ro primary-domain-id-hex? ipi-ospf-
types:ospf_domain_id_hex_string_t
|   | | +---rw secondary-domain

```

```

|      |      +--rw addresses
|      |      | +--rw address* [secondary-domain-id-address] {feature-
list:HAVE_VRF_OSPF}?
|      |      | +--rw secondary-domain-id-address    -> ../config/secondary-
domain-id-address
|      |      | +--rw config
|      |      | | +--rw secondary-domain-id-address?  inet:ipv4-address
|      |      | +--ro state
|      |      |   +--ro secondary-domain-id-address?  inet:ipv4-address
|      |      +--rw hexes
|      |      | +--rw hex* [secondary-hex-type secondary-domain-id-hex] {feature-
list:HAVE_VRF_OSPF}?
|      |      | +--rw secondary-hex-type              -> ../config/secondary-hex-type
|      |      | +--rw secondary-domain-id-hex         -> ../config/secondary-domain-
id-hex
|      |      | +--rw config
|      |      | | +--rw secondary-hex-type?           ipi-ospf-
types:ospf_domain_type_t
|      |      | | +--rw secondary-domain-id-hex?     ipi-ospf-
types:ospf_domain_id_hex_string_t
|      |      | +--ro state
|      |      |   +--ro secondary-hex-type?         ipi-ospf-
types:ospf_domain_type_t
|      |      |   +--ro secondary-domain-id-hex?     ipi-ospf-
types:ospf_domain_id_hex_string_t
|      |      +--rw distribute {feature-list:HAVE_BGP_LS}?
|      |      | +--rw bgp-link-state
|      |      | +--rw config
|      |      | | +--rw enabled?                      empty
|      |      | | +--rw throttle-timer?             uint8
|      |      | +--ro state
|      |      |   +--ro enabled?                      empty
|      |      |   +--ro throttle-timer?             uint8
|      |      +--rw neighbors
|      |      | +--rw neighbor* [address]
|      |      | +--rw address                          -> ../config/address
|      |      | +--rw config
|      |      | | +--rw address?                      inet:ipv4-address
|      |      | | +--rw cost?                        uint16
|      |      | | +--rw priority?                   uint8
|      |      | | +--rw poll-interval?              uint32
|      |      | +--ro state
|      |      | | +--ro address?                      inet:ipv4-address
|      |      | | +--ro cost?                        uint16
|      |      | | +--ro priority?                   uint8
|      |      | | +--ro poll-interval?              uint32
|      |      | +--ro neighbor-state-change
|      |      | | +--ro router-id?                   inet:ipv4-address
|      |      | | +--ro address?                     inet:ipv4-address
|      |      | | +--ro neighbor-address-less-index? uint32
|      |      | | +--ro neighbor-router-id?         inet:ipv4-address

```

```

| | | | +---ro neighbor-state? | ipi-ospf-
types:ospf_neighbor_state_change_t
| | | | +---ro tx-retransmit
| | | | +---ro router-id? | inet:ipv4-address
| | | | +---ro address? | inet:ipv4-address
| | | | +---ro neighbor-address-less-index? uint32
| | | | +---ro neighbor-router-id? | inet:ipv4-address
| | | | +---ro packet-type? | ipi-ospf-types:ospf_packet_type_t
| | | | +---ro lsdB-type? | ipi-ospf-types:ospf_lsdB_type_t
| | | | +---ro lsdB-lsid? | inet:ipv4-address
| | | | +---ro lsdB-router-id? | inet:ipv4-address
| | +---rw timers
| | | +---rw config
| | | +---ro state
| | | +---rw lfa
| | | | +---rw config
| | | | | +---rw termination-hold-interval? | uint32 {feature-
list:HAVE_OSPF_LFA}?
| | | | | +---ro state
| | | | | +---ro termination-hold-interval? | uint32 {feature-
list:HAVE_OSPF_LFA}?
| | | | +---rw lsa
| | | | | +---rw config
| | | | | | +---rw min-arrival-interval? | uint32
| | | | | | +---ro state
| | | | | | | +---ro min-arrival-interval? | uint32
| | | | | +---rw delays
| | | | | | +---rw delay* [start-delay min-delay max-delay]
| | | | | | | +---rw start-delay -> ../config/start-delay
| | | | | | | +---rw min-delay -> ../config/min-delay
| | | | | | | +---rw max-delay -> ../config/max-delay
| | | | | | +---rw config
| | | | | | | +---rw start-delay? | uint32
| | | | | | | +---rw min-delay? | uint32
| | | | | | | +---rw max-delay? | uint32
| | | | | | +---ro state
| | | | | | | +---ro start-delay? | uint32
| | | | | | | +---ro min-delay? | uint32
| | | | | | | +---ro max-delay? | uint32
| | | | +---rw spf
| | | | | +---rw delay
| | | | | | +---rw config!
| | | | | | | +---rw min-delay | uint32
| | | | | | | +---rw max-delay | uint32
| | | | | | +---ro state
| | | | | | | +---ro min-delay | uint32
| | | | | | | +---ro max-delay | uint32
| | +---rw redistribute
| | | +---rw config
| | | | +---rw default-metric? | uint32
| | | +---ro state

```

```
| | | +--ro default-metric? uint32
| | +--rw routing-protocols
| | | +--rw routing-protocol* [protocol]
| | |   +--rw protocol -> ../config/protocol
| | |   +--rw config
| | |     +--rw metric? uint32
| | |     +--rw metric-type? ipi-ospf-types:ospf_metric_type_t
| | |     +--rw route-map? string
| | |     +--rw tag? uint32
| | |     +--rw protocol? ipi-ospf-types:ospf_route_source_type_t
| | |   +--ro state
| | |     +--ro metric? uint32
| | |     +--ro metric-type? ipi-ospf-types:ospf_metric_type_t
| | |     +--ro route-map? string
| | |     +--ro tag? uint32
| | |     +--ro protocol? ipi-ospf-types:ospf_route_source_type_t
| | +--rw ospf-processes
| | | +--rw ospf-process* [ospf-process-id]
| | |   +--rw ospf-process-id -> ../config/ospf-process-id
| | |   +--rw config
| | |     +--rw metric? uint32
| | |     +--rw metric-type? ipi-ospf-types:ospf_metric_type_t
| | |     +--rw route-map? string
| | |     +--rw tag? uint32
| | |     +--rw ospf-process-id? uint16
| | |   +--ro state
| | |     +--ro metric? uint32
| | |     +--ro metric-type? ipi-ospf-types:ospf_metric_type_t
| | |     +--ro route-map? string
| | |     +--ro tag? uint32
| | |     +--ro ospf-process-id? uint16
| | +--rw isis-processes
| | | +--rw isis-process* [isis-process-id]
| | |   +--rw isis-process-id -> ../config/isis-process-id
| | |   +--rw config
| | |     +--rw metric? uint32
| | |     +--rw metric-type? ipi-ospf-types:ospf_metric_type_t
| | |     +--rw route-map? string
| | |     +--rw tag? uint32
| | |     +--rw isis-process-id? string
| | |   +--ro state
| | |     +--ro metric? uint32
| | |     +--ro metric-type? ipi-ospf-types:ospf_metric_type_t
| | |     +--ro route-map? string
| | |     +--ro tag? uint32
| | |     +--ro isis-process-id? string
| +--ro originate-lsa
| | +--ro router-id? -> /ospfv2/processes/process/state/router-id
| | +--ro lsdbs-area-id? inet:ipv4-address
| | +--ro lsdbs-type? ipi-ospf-types:ospf_lsdbs_type_t
```

```

|   |   +---ro lsdb-id?          inet:ipv4-address
|   |   +---ro lsdb-router-id?  inet:ipv4-address
| +---rw max-metric {feature-list:HAVE_OSPF_STUB_ROUTER}?
|   |   +---rw config!
|   |   |   +---rw enable-max-router-lsa    empty
|   |   |   +---rw max-external-lsa?      uint32
|   |   |   +---rw max-summary-lsa?       uint32
|   |   |   +---rw include-stub?          empty
|   |   +---ro state
|   |       +---ro enable-max-router-lsa    empty
|   |       +---ro max-external-lsa?      uint32
|   |       +---ro max-summary-lsa?       uint32
|   |       +---ro include-stub?          empty
| +---rw max-metric-on-startup {feature-list:HAVE_OSPF_STUB_ROUTER}?
|   |   +---rw config!
|   |   |   +---rw max-on-startup          uint32
|   |   |   +---rw max-on-startup-external-lsa?  uint32
|   |   |   +---rw max-on-startup-summary-lsa?  uint32
|   |   |   +---rw on-startup-include-stub?    empty
|   |   +---ro state
|   |       +---ro max-on-startup          uint32
|   |       +---ro max-on-startup-external-lsa?  uint32
|   |       +---ro max-on-startup-summary-lsa?  uint32
|   |       +---ro on-startup-include-stub?    empty
| +---rw traffic-engineering-links {feature-list:HAVE_OSPF_TE,feature-
list:HAVE_GMPLS}?
|   +---rw traffic-engineering-link* [teName]
|     +---rw teName      -> ../config/teName
|     +---rw config
|     |   +---rw teName?      string
|     |   +---rw metric?     uint16
|     |   +---rw link-local-exchange?  empty
|     +---ro state
|     |   +---ro teName?     string
|     |   +---ro metric?    uint16
|     |   +---ro link-local-exchange?  empty
|     +---rw flooding
|     +---rw ospfv2-processes
|     +---rw ospfv2-process* [ospf-process-id area-id]
|       +---rw ospf-process-id  -> ../config/ospf-process-id
|       +---rw area-id         -> ../config/area-id
|       +---rw config
|       |   +---rw ospf-process-id?  uint16
|       |   +---rw area-id?         ipi-ospf-types:ospf_area_t
|       +---ro state
|       +---ro ospf-process-id?  uint16
|       +---ro area-id?         ipi-ospf-types:ospf_area_t
| +---rw multi-area-interfaces {feature-list:HAVE_OSPF_MULTI_AREA}?
|   +---rw multi-area-interface* [name]
|     +---rw name              -> ../config/name
|     +---rw config

```

```

|     | +--rw name?   -> /ipi-interface:interfaces/interface/name
|     +--ro state
|     | +--ro name?   -> /ipi-interface:interfaces/interface/name
|     +--rw ospfv2-processes
|         +--rw ospfv2-process* [ospf-process-id]
|             +--rw ospf-process-id       -> ../config/ospf-process-id
|             +--rw config
|                 | +--rw ospf-process-id? uint16
|                 +--ro state
|                 | +--ro ospf-process-id? uint16
|                 +--rw multi-areas
|                     | +--rw multi-area* [area-id]
|                     |     +--rw area-id   -> ../config/area-id
|                     |     +--rw config
|                     |         | +--rw area-id? ipi-ospf-types:ospf_area_t
|                     |         +--ro state
|                     |         +--ro area-id? ipi-ospf-types:ospf_area_t
|                     +--rw multi-areas-neighbors
|                         +--rw multi-area-neighbor* [area-id]
|                             +--rw area-id   -> ../config/area-id
|                             +--rw config
|                                 | +--rw area-id? ipi-ospf-types:ospf_area_t
|                                 | +--rw neighbor inet:ipv4-address
|                                 +--ro state
|                                     +--ro area-id? ipi-ospf-types:ospf_area_t
|                                     +--ro neighbor inet:ipv4-address
+--rw debug
| +--rw config
| | +--rw bfd?                empty {feature-list:HAVE_BFD}?
| | +--rw rate-limit?        empty
| | +--rw segment-routing?    empty {feature-list:HAVE_SR_MPLS}?
| | +--rw route?             ipi-ospf-types:ospf_debug_route_t
| | +--rw rib?                ipi-ospf-types:ospf_debug_rib_t {feature-
list:HAVE_RIBD}?
| | +--rw nsm?                ipi-ospf-types:ospf_debug_nsm_t
| | +--rw nfsm?               ipi-ospf-types:ospf_debug_nfsm_t
| | +--rw lsa?                ipi-ospf-types:ospf_debug_lsa_t
| | +--rw ifsm?               ipi-ospf-types:ospf_debug_ifsm_t
| | +--rw events?             ipi-ospf-types:ospf_debug_event_t
| | +--rw cspf-events?        empty {feature-list:HAVE OSPF_CSPF}?
| | +--rw cspf-hexdump?       empty {feature-list:HAVE OSPF_CSPF}?
| | +--rw retransmission?     empty
| | +--rw distribute?         empty {feature-list:HAVE_BGP_LS}?
| | +--rw topology-independent-lfa? empty {feature-list:HAVE OSPF_TI_LFA}?
| | +--rw lfa?                empty {feature-list:HAVE OSPF_LFA}?
| | +--rw policy?             empty
| | +--rw redistribute?       ipi-ospf-types:ospf_debug_redist_t
| | +--rw graceful-restart?    ipi-ospf-types:ospf_debug_graceful_t
| | +--rw packet-hello?       ipi-ospf-types:ospf_debug_packet_options_t
| | +--rw packet-dd?          ipi-ospf-types:ospf_debug_packet_options_t
| | +--rw packet-ls-request?   ipi-ospf-types:ospf_debug_packet_options_t

```



```

| | +--rw packet-ls-update?      ipi-ospf-types:ospf_debug_packet_options_t
| | +--rw packet-ls-ack?        ipi-ospf-types:ospf_debug_packet_options_t
| +--ro state
|   +--ro bfd?                  empty {feature-list:HAVE_BFD}?
|   +--ro rate-limit?           empty
|   +--ro segment-routing?      empty {feature-list:HAVE_SR_MPLS}?
|   +--ro route?                ipi-ospf-types:ospf_debug_route_t
|   +--ro rib?                  ipi-ospf-types:ospf_debug_rib_t {feature-
list:HAVE_RIBD}?
|   +--ro nsm?                  ipi-ospf-types:ospf_debug_nsm_t
|   +--ro nfsm?                 ipi-ospf-types:ospf_debug_nfsm_t
|   +--ro lsa?                  ipi-ospf-types:ospf_debug_lsa_t
|   +--ro ifsm?                 ipi-ospf-types:ospf_debug_ifsm_t
|   +--ro events?               ipi-ospf-types:ospf_debug_event_t
|   +--ro cspf-events?          empty {feature-list:HAVE_OSPF_CSPF}?
|   +--ro cspf-hexdump?         empty {feature-list:HAVE_OSPF_CSPF}?
|   +--ro retransmission?       empty
|   +--ro distribute?           empty {feature-list:HAVE_BGP_LS}?
|   +--ro topology-independent-lfa? empty {feature-list:HAVE_OSPF_TI_LFA}?
|   +--ro lfa?                  empty {feature-list:HAVE_OSPF_LFA}?
|   +--ro policy?               empty
|   +--ro redistribute?         ipi-ospf-types:ospf_debug_redist_t
|   +--ro graceful-restart?     ipi-ospf-types:ospf_debug_graceful_t
|   +--ro packet-hello?         ipi-ospf-types:ospf_debug_packet_options_t
|   +--ro packet-dd?            ipi-ospf-types:ospf_debug_packet_options_t
|   +--ro packet-ls-request?    ipi-ospf-types:ospf_debug_packet_options_t
|   +--ro packet-ls-update?     ipi-ospf-types:ospf_debug_packet_options_t
|   +--ro packet-ls-ack?        ipi-ospf-types:ospf_debug_packet_options_t
|   +--ro terminal-debug-status
|     +--ro bfd?                 cml-data-types:cml_on_off_t {feature-
list:HAVE_BFD}?
|     +--ro rate-limit?         cml-data-types:cml_on_off_t
|     +--ro segment-routing?    cml-data-types:cml_on_off_t {feature-
list:HAVE_SR_MPLS}?
|     +--ro route?              ipi-ospf-types:ospf_debug_route_t
|     +--ro rib?                ipi-ospf-types:ospf_debug_rib_t {feature-
list:HAVE_RIBD}?
|     +--ro nsm?                ipi-ospf-types:ospf_debug_nsm_t
|     +--ro nfsm?               ipi-ospf-types:ospf_debug_nfsm_t
|     +--ro lsa?                ipi-ospf-types:ospf_debug_lsa_t
|     +--ro ifsm?               ipi-ospf-types:ospf_debug_ifsm_t
|     +--ro events?             ipi-ospf-types:ospf_debug_event_t
|     +--ro cspf-events?        cml-data-types:cml_on_off_t {feature-
list:HAVE_OSPF_CSPF}?
|     +--ro cspf-hexdump?       cml-data-types:cml_on_off_t {feature-
list:HAVE_OSPF_CSPF}?
|     +--ro retransmission?     cml-data-types:cml_on_off_t
|     +--ro distribute?         cml-data-types:cml_on_off_t {feature-
list:HAVE_BGP_LS}?
|     +--ro topology-independent-lfa? cml-data-types:cml_on_off_t {feature-
list:HAVE_OSPF_TI_LFA}?

```

```

|         +---ro lfa?                               cml-data-types:cml_on_off_t {feature-
list:HAVE_OSPF_LFA}?
|         +---ro policy?                           cml-data-types:cml_on_off_t
|         +---ro redistribute?                     ipi-ospf-types:ospf_debug_redist_t
|         +---ro graceful-restart?                 ipi-ospf-types:ospf_debug_graceful_t
|         +---ro packet-hello?                     ipi-ospf-
types:ospf_debug_packet_options_t
|         +---ro packet-dd?                         ipi-ospf-types:ospf_debug_packet_options_t
|         +---ro packet-ls-request?                 ipi-ospf-
types:ospf_debug_packet_options_t
|         +---ro packet-ls-update?                  ipi-ospf-
types:ospf_debug_packet_options_t
|         +---ro packet-ls-ack?                     ipi-ospf-
types:ospf_debug_packet_options_t
+---rw interfaces
  +---rw interface* [name]
    +---rw name                                     -> ../config/name
    +---rw config
      | +---rw cost?                               uint16
      | +---rw priority?                           uint8
      | +---rw mtu-ignore?                          empty
      | +---rw name?                                -> /ipi-interface:interfaces/interface/
name
      | +---rw network-type?                        ipi-ospf-types:ospf_network_t
      | +---rw disable-all-ospf?                   empty
      | +---rw traffic-engineering-metric?          uint16 {feature-list:HAVE_OSPF_TE}?
      | +---rw mtu?                                  uint16
      | +---rw enable-flood-reduction?              empty
      | +---rw enable-demand-circuit?               empty {feature-
list:HAVE_OSPF_OD,feature-list:HAVE_OSPF_MULTI_INST}?
      | +---rw enable-bfd?                           ipi-ospf-types:ospf_bfd_state {feature-
list:HAVE_BFD}?
      | +---rw disable-fast-reroute?                 empty {feature-list:HAVE_OSPF_LFA}?
+---ro state
  | +---ro cost?                                    uint16
  | +---ro priority?                                uint8
  | +---ro mtu-ignore?                              empty
  | +---ro name?                                    -> /ipi-interface:interfaces/interface/
name
  | +---ro network-type?                            ipi-ospf-types:ospf_network_t
  | +---ro disable-all-ospf?                        empty
  | +---ro traffic-engineering-metric?              uint16 {feature-list:HAVE_OSPF_TE}?
  | +---ro mtu?                                      uint16
  | +---ro enable-flood-reduction?                  empty
  | +---ro enable-demand-circuit?                   empty {feature-
list:HAVE_OSPF_OD,feature-list:HAVE_OSPF_MULTI_INST}?
  | +---ro enable-bfd?                              ipi-ospf-types:ospf_bfd_state {feature-
list:HAVE_BFD}?
  | +---ro disable-fast-reroute?                     empty {feature-list:HAVE_OSPF_LFA}?
  | +---ro link-state-change
  | | +---ro router-id?                              inet:ipv4-address
  | | +---ro name?                                    string
  | | +---ro interface-address?                      inet:ipv4-address

```

```

| | +--ro address-less-interface? uint32
| | +--ro interface-state?      ipi-ospf-types:ospf_interface_state_t
| +--ro rx-bad-packet
| | +--ro router-id?           inet:ipv4-address
| | +--ro name?                string
| | +--ro interface-address?   inet:ipv4-address
| | +--ro address-less-interface? uint32
| | +--ro packet-src?          inet:ipv4-address
| | +--ro packet-type?         ipi-ospf-types:ospf_packet_type_t
| +--ro interface-config-error
| | +--ro router-id?           inet:ipv4-address
| | +--ro name?                string
| | +--ro interface-address?   inet:ipv4-address
| | +--ro address-less-interface? uint32
| | +--ro error-type?          ipi-ospf-types:ospf_config_error_type_t
| | +--ro packet-type?         ipi-ospf-types:ospf_packet_type_t
+--ro interface-states
| +--ro state
| | +--ro interface-state?      int32
| | +--ro lsa-count?            int32
| | +--ro lsa-checksum?         int32
| | +--ro interface-events?     int32
| | +--ro addressless-interface? int32
| +--ro statistics
| | +--ro errors
| | | +--ro discarded-in?       yang:counter64
| | | +--ro discarded-out?     yang:counter64
| | | +--ro hello-in?          yang:counter64
| | | +--ro database-descriptor-in? yang:counter64
| | | +--ro ls-request-in?     yang:counter64
| | | +--ro ls-update-in?      yang:counter64
| | | +--ro ls-acknowledge-in?  yang:counter64
| | | +--ro unknown-in?        yang:counter64
| | | +--ro unknown-out?       yang:counter64
| | | +--ro bad-version?       yang:counter64
| | | +--ro bad-crc?           yang:counter64
| | | +--ro invalid-source?    yang:counter64
| | | +--ro invalid-destination? yang:counter64
| | | +--ro no-neighbor?       yang:counter64
| | | +--ro passive?           yang:counter64
| | | +--ro wrong-area?        yang:counter64
| | | +--ro packet-length?     yang:counter64
| | | +--ro authentication?    yang:counter64
| | +--ro traffic
| | | +--ro total-packets-in?   yang:counter64
| | | +--ro total-packets-out?  yang:counter64
| | | +--ro hello-packets-in?  yang:counter64
| | | +--ro hello-packets-out? yang:counter64
| | | +--ro database-descriptor-packets-in? yang:counter64
| | | +--ro database-descriptor-packets-out? yang:counter64

```

```

| |      +---ro ls-request-packets-in?          yang:counter64
| |      +---ro ls-request-packets-out?         yang:counter64
| |      +---ro ls-update-packets-in?          yang:counter64
| |      +---ro ls-update-packets-out?         yang:counter64
| |      +---ro ls-acknowledge-packets-in?     yang:counter64
| |      +---ro ls-acknowledge-packets-out?    yang:counter64
| +---ro designated-router
| |   +---ro state
| |     +---ro router-id?    inet:ipv4-address
| |     +---ro address?     inet:ipv4-address
| +---ro backup-designated-router
| |   +---ro state
| |     +---ro router-id?    inet:ipv4-address
| |     +---ro address?     inet:ipv4-address
| +---ro timers
|   +---ro state
|     +---ro runtime-dead-interval?    uint32
+---rw authentication
| +---rw config
| | +---rw authentication-type?    ipi-ospf-
types:ospf_if_authentication_type_t
| | +---rw key?                    ipi-ospf-types:ospf_md5_password_t
| +---ro state
| | +---ro authentication-type?    ipi-ospf-
types:ospf_if_authentication_type_t
| | +---ro key?                    ipi-ospf-types:ospf_md5_password_t
| +---rw message-digests
|   +---rw message-digest* [message-digest-id]
|     +---rw message-digest-id    -> ../config/message-digest-id
|     +---rw config
|       | +---rw message-digest-id?    uint8
|       | +---rw message-digest-encryption-type    ipi-ospf-
types:ospf_cipher_type_t
|       | +---rw message-digest-key      ipi-ospf-
types:ospf_md5_password_t
|       +---ro state
|         +---ro message-digest-id?    uint8
|         +---ro message-digest-encryption-type    ipi-ospf-
types:ospf_cipher_type_t
|         +---ro message-digest-key      ipi-ospf-
types:ospf_md5_password_t
+---rw database-filter
| +---rw lsa
|   +---rw config
|     | +---rw filter-out?    empty
|     +---ro state
|       +---ro filter-out?    empty
+---rw timers
| +---rw config
| | +---rw ldp-igp-sync-enable?    empty {feature-list:HAVE_LDPD}?
| | +---rw dead-interval?          uint16
| | +---rw hello-interval?         uint16

```

```

| | +--rw retransmission-interval?   uint16
| | +--rw holddown-timer?            uint32 {feature-list:HAVE_LDPD}?
| | +--rw transmit-delay?           uint16
| | +--rw resync-timeout?            uint16
| +--ro state
|   +--ro ldp-igp-sync-enable?       empty {feature-list:HAVE_LDPD}?
|   +--ro dead-interval?             uint16
|   +--ro hello-interval?           uint16
|   +--ro retransmission-interval?   uint16
|   +--ro holddown-timer?            uint32 {feature-list:HAVE_LDPD}?
|   +--ro transmit-delay?           uint16
|   +--ro resync-timeout?            uint16
+--rw addresses
  +--rw address* [interface-address]
    +--rw interface-address   -> ../config/interface-address
    +--rw config
      | +--rw interface-address?   inet:ipv4-address
      | +--rw cost?                uint16
      | +--rw priority?           uint8
      | +--rw mtu-ignore?         empty
    +--ro state
      | +--ro interface-address?   inet:ipv4-address
      | +--ro cost?                uint16
      | +--ro priority?           uint8
      | +--ro mtu-ignore?         empty
      | +--ro designated-router
      | | +--ro state
      | |   +--ro router-id?       inet:ipv4-address
      | |   +--ro address?         inet:ipv4-address
      | +--ro backup-designated-router
      | | +--ro state
      | |   +--ro router-id?       inet:ipv4-address
      | |   +--ro address?         inet:ipv4-address
      | +--ro timers
      |   +--ro state
      |     +--ro runtime-dead-interval?   uint32
    +--rw authentication
      | +--rw config
      | | +--rw authentication-type?   ipi-ospf-
types:ospf_if_authentication_type_t
      | | +--rw key?                   ipi-ospf-types:ospf_md5_password_t
      | +--ro state
      | | +--ro authentication-type?   ipi-ospf-
types:ospf_if_authentication_type_t
      | | +--ro key?                   ipi-ospf-types:ospf_md5_password_t
      | +--rw message-digests
      |   +--rw message-digest* [message-digest-id]
      |     +--rw message-digest-id   -> ../config/message-digest-id
      |     +--rw config
      |     | +--rw message-digest-id?   uint8

```

```

| | +--rw message-digest-encryption-type ipi-ospf-
types:ospf_cipher_type_t
| | +--rw message-digest-key ipi-ospf-
types:ospf_md5_password_t
| | +--ro state
| | +--ro message-digest-id? uint8
| | +--ro message-digest-encryption-type ipi-ospf-
types:ospf_cipher_type_t
| | +--ro message-digest-key ipi-ospf-
types:ospf_md5_password_t
+--rw timers
| +--rw config
| | +--rw dead-interval? uint16
| | +--rw hello-interval? uint16
| | +--rw retransmission-interval? uint16
| | +--rw transmit-delay? uint16
| | +--rw resync-timeout? uint16
| +--ro state
| | +--ro dead-interval? uint16
| | +--ro hello-interval? uint16
| | +--ro retransmission-interval? uint16
| | +--ro transmit-delay? uint16
| | +--ro resync-timeout? uint16
+--rw database-filter
+--rw lsa
+--rw config
| +--rw filter-out? empty
+--ro state
+--ro filter-out? empty

```

rpcs:

```

+---x ospfv2-terminal-debug-ospf-all-on {feature-list:HAVE_OSPFD}?
+---x ospfv2-terminal-debug-ospf-all-off {feature-list:HAVE_OSPFD}?
+---x ospfv2-terminal-debug-bfd-on {feature-list:HAVE_BFD}?
+---x ospfv2-terminal-debug-bfd-off {feature-list:HAVE_BFD}?
+---x ospfv2-terminal-debug-rate-limit-on {feature-list:HAVE_OSPFD}?
+---x ospfv2-terminal-debug-rate-limit-off {feature-list:HAVE_OSPFD}?
+---x ospfv2-terminal-debug-sr-on {feature-list:HAVE_SR_MPLS}?
+---x ospfv2-terminal-debug-sr-off {feature-list:HAVE_SR_MPLS}?
+---x ospfv2-terminal-debug-route-on {feature-list:HAVE_OSPFD}?
| +---w input
|   +---w route ipi-ospf-types:ospf_debug_route_t
+---x ospfv2-terminal-debug-route-off {feature-list:HAVE_OSPFD}?
| +---w input
|   +---w route ipi-ospf-types:ospf_debug_route_t
+---x ospfv2-terminal-debug-rib-on {feature-list:HAVE_RIBD}?
| +---w input
|   +---w rib ipi-ospf-types:ospf_debug_rib_t
+---x ospfv2-terminal-debug-rib-off {feature-list:HAVE_RIBD}?
| +---w input
|   +---w rib ipi-ospf-types:ospf_debug_rib_t

```

```

+---x ospfv2-terminal-debug-packet-all-on {feature-list:HAVE OSPFD}?
| +---w input
|   +---w all      ipi-ospf-types:ospf_debug_packet_options_t
+---x ospfv2-terminal-debug-packet-all-off {feature-list:HAVE OSPFD}?
| +---w input
|   +---w all      ipi-ospf-types:ospf_debug_packet_options_t
+---x ospfv2-terminal-debug-packet-hello-on {feature-list:HAVE OSPFD}?
| +---w input
|   +---w hello    ipi-ospf-types:ospf_debug_packet_options_t
+---x ospfv2-terminal-debug-packet-hello-off {feature-list:HAVE OSPFD}?
| +---w input
|   +---w hello    ipi-ospf-types:ospf_debug_packet_options_t
+---x ospfv2-terminal-debug-packet-dd-on {feature-list:HAVE OSPFD}?
| +---w input
|   +---w dd       ipi-ospf-types:ospf_debug_packet_options_t
+---x ospfv2-terminal-debug-packet-dd-off {feature-list:HAVE OSPFD}?
| +---w input
|   +---w dd       ipi-ospf-types:ospf_debug_packet_options_t
+---x ospfv2-terminal-debug-packet-ls-request-on {feature-list:HAVE OSPFD}?
| +---w input
|   +---w ls-request ipi-ospf-types:ospf_debug_packet_options_t
+---x ospfv2-terminal-debug-packet-ls-request-off {feature-list:HAVE OSPFD}?
| +---w input
|   +---w ls-request ipi-ospf-types:ospf_debug_packet_options_t
+---x ospfv2-terminal-debug-packet-ls-update-on {feature-list:HAVE OSPFD}?
| +---w input
|   +---w ls-update ipi-ospf-types:ospf_debug_packet_options_t
+---x ospfv2-terminal-debug-packet-ls-update-off {feature-list:HAVE OSPFD}?
| +---w input
|   +---w ls-update ipi-ospf-types:ospf_debug_packet_options_t
+---x ospfv2-terminal-debug-packet-ls-ack-on {feature-list:HAVE OSPFD}?
| +---w input
|   +---w ls-ack    ipi-ospf-types:ospf_debug_packet_options_t
+---x ospfv2-terminal-debug-packet-ls-ack-off {feature-list:HAVE OSPFD}?
| +---w input
|   +---w ls-ack    ipi-ospf-types:ospf_debug_packet_options_t
+---x ospfv2-terminal-debug-nsm-on {feature-list:HAVE OSPFD}?
| +---w input
|   +---w nsm       ipi-ospf-types:ospf_debug_nsm_t
+---x ospfv2-terminal-debug-nsm-off {feature-list:HAVE OSPFD}?
| +---w input
|   +---w nsm       ipi-ospf-types:ospf_debug_nsm_t
+---x ospfv2-terminal-debug-nfsm-on {feature-list:HAVE OSPFD}?
| +---w input
|   +---w nfsm      ipi-ospf-types:ospf_debug_nfsm_t
+---x ospfv2-terminal-debug-nfsm-off {feature-list:HAVE OSPFD}?
| +---w input
|   +---w nfsm      ipi-ospf-types:ospf_debug_nfsm_t
+---x ospfv2-terminal-debug-lsa-on {feature-list:HAVE OSPFD}?
| +---w input

```

```
|      +---w lsa      ipi-ospf-types:ospf_debug_lsa_t
+---x ospfv2-terminal-debug-lsa-off {feature-list:HAVE_OSPFD}?
|      +---w input
|      +---w lsa      ipi-ospf-types:ospf_debug_lsa_t
+---x ospfv2-terminal-debug-ifsm-on {feature-list:HAVE_OSPFD}?
|      +---w input
|      +---w ifsm     ipi-ospf-types:ospf_debug_ifsm_t
+---x ospfv2-terminal-debug-ifsm-off {feature-list:HAVE_OSPFD}?
|      +---w input
|      +---w ifsm     ipi-ospf-types:ospf_debug_ifsm_t
+---x ospfv2-terminal-debug-events-on {feature-list:HAVE_OSPFD}?
|      +---w input
|      +---w events   ipi-ospf-types:ospf_debug_event_t
+---x ospfv2-terminal-debug-events-off {feature-list:HAVE_OSPFD}?
|      +---w input
|      +---w events   ipi-ospf-types:ospf_debug_event_t
+---x ospfv2-terminal-debug-cspf-all-on {feature-list:HAVE_OSPF_CSPF}?
+---x ospfv2-terminal-debug-cspf-all-off {feature-list:HAVE_OSPF_CSPF}?
+---x ospfv2-terminal-debug-cspf-events-on {feature-list:HAVE_OSPF_CSPF}?
+---x ospfv2-terminal-debug-cspf-events-off {feature-list:HAVE_OSPF_CSPF}?
+---x ospfv2-terminal-debug-cspf-hexdump-on {feature-list:HAVE_OSPF_CSPF}?
+---x ospfv2-terminal-debug-cspf-hexdump-off {feature-list:HAVE_OSPF_CSPF}?
+---x ospfv2-terminal-debug-all-on {feature-list:HAVE_OSPFD}?
+---x ospfv2-terminal-debug-all-off {feature-list:HAVE_OSPFD}?
+---x ospfv2-terminal-debug-retransmission-on {feature-list:HAVE_OSPFD}?
+---x ospfv2-terminal-debug-retransmission-off {feature-list:HAVE_OSPFD}?
+---x ospfv2-terminal-debug-dist-ls-on {feature-list:HAVE_BGP_LS}?
+---x ospfv2-terminal-debug-dist-ls-off {feature-list:HAVE_BGP_LS}?
+---x ospfv2-terminal-debug-topology-independent-lfa-on {feature-
list:HAVE_OSPF_TI_LFA}?
+---x ospfv2-terminal-debug-topology-independent-lfa-off {feature-
list:HAVE_OSPF_TI_LFA}?
+---x ospfv2-terminal-debug-lfa-on {feature-list:HAVE_OSPF_LFA}?
+---x ospfv2-terminal-debug-lfa-off {feature-list:HAVE_OSPF_LFA}?
+---x ospfv2-terminal-debug-policy-on {feature-list:HAVE_OSPFD}?
+---x ospfv2-terminal-debug-policy-off {feature-list:HAVE_OSPFD}?
+---x ospfv2-terminal-debug- redistribute-on {feature-list:HAVE_OSPFD}?
|      +---w input
|      +---w redistribute ipi-ospf-types:ospf_debug_redist_t
+---x ospfv2-terminal-debug- redistribute-off {feature-list:HAVE_OSPFD}?
|      +---w input
|      +---w redistribute ipi-ospf-types:ospf_debug_redist_t
+---x ospfv2-terminal-debug-graceful-restart-on {feature-list:HAVE_OSPFD}?
|      +---w input
|      +---w graceful-restart ipi-ospf-types:ospf_debug_graceful_t
+---x ospfv2-terminal-debug-graceful-restart-off {feature-list:HAVE_OSPFD}?
|      +---w input
|      +---w graceful-restart ipi-ospf-types:ospf_debug_graceful_t
+---x ospfv2-clear-process {feature-list:HAVE_OSPFD}?
|      +---w input
|      +---w process-id   uint16
```



```

+---x ospfv2-clear-process-all {feature-list:HAVE OSPFD}?
+---x ospfv2-restart-graceful {feature-list:HAVE_RESTART}?
| +---w input
|     +---w grace-period      uint16
+---x ospfv2-snmp-restart {feature-list:HAVE_SNMP}?

```

notifications:

```

+---n ospfv2-neighbor-state-change
| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro address?                inet:ipv4-address
| +--ro ospf-id?                uint16
| +--ro router-id?              inet:ipv4-address
| +--ro neighbor-address-less-index? uint32
| +--ro neighbor-router-id?     inet:ipv4-address
| +--ro neighbor-state?         ipi-ospf-types:ospf_neighbor_state_change_t
+---n ospfv2-tx-retransmit
| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro address?                inet:ipv4-address
| +--ro ospf-id?                uint16
| +--ro router-id?              inet:ipv4-address
| +--ro neighbor-address-less-index? uint32
| +--ro neighbor-router-id?     inet:ipv4-address
| +--ro packet-type?            ipi-ospf-types:ospf_packet_type_t
| +--ro lsdB-type?              ipi-ospf-types:ospf_lsdB_type_t
| +--ro lsdB-lsid?              inet:ipv4-address
| +--ro lsdB-router-id?         inet:ipv4-address
+---n ospfv2-originate-lsa
| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro ospf-id?                uint16
| +--ro router-id?              inet:ipv4-address
| +--ro lsdB-area-id?           inet:ipv4-address
| +--ro lsdB-type?              ipi-ospf-types:ospf_lsdB_type_t
| +--ro lsdB-id?                inet:ipv4-address
| +--ro lsdB-router-id?         inet:ipv4-address
+---n ospfv2-lsdB-overflow-external-lsa
| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro ospf-id?                uint16
| +--ro router-id?              inet:ipv4-address
| +--ro max-limit?              uint32
+---n ospfv2-virtual-link-interface-config-error
| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro remote-router-id?       inet:ipv4-address
| +--ro area-id?                ipi-ospf-types:ospf_area_t
| +--ro ospf-id?                uint16
| +--ro router-id?              inet:ipv4-address

```

```
| +--ro error-type?          ipi-ospf-types:ospf_config_error_type_t
| +--ro packet-type?        ipi-ospf-types:ospf_packet_type_t
+---n ospfv2-virtual-link-interface-state-change
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro remote-router-id?  inet:ipv4-address
| +--ro area-id?           ipi-ospf-types:ospf_area_t
| +--ro ospf-id?           uint16
| +--ro router-id?         inet:ipv4-address
| +--ro interface-state?   ipi-ospf-types:ospf_interface_state_t
+---n ospfv2-virtual-neighbor-state-change
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro remote-router-id?  inet:ipv4-address
| +--ro area-id?           ipi-ospf-types:ospf_area_t
| +--ro ospf-id?           uint16
| +--ro router-id?         inet:ipv4-address
| +--ro neighbor-state?    ipi-ospf-types:ospf_neighbor_state_change_t
+---n ospfv2-virtual-link-interface-rx-bad-packet
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro remote-router-id?  inet:ipv4-address
| +--ro area-id?           ipi-ospf-types:ospf_area_t
| +--ro ospf-id?           uint16
| +--ro router-id?         inet:ipv4-address
| +--ro packet-type?       ipi-ospf-types:ospf_packet_type_t
+---n ospfv2-virtual-link-interface-tx-retransmit
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro remote-router-id?  inet:ipv4-address
| +--ro area-id?           ipi-ospf-types:ospf_area_t
| +--ro ospf-id?           uint16
| +--ro router-id?         inet:ipv4-address
| +--ro packet-type?       ipi-ospf-types:ospf_packet_type_t
| +--ro lsdB-type?         ipi-ospf-types:ospf_lsdB_type_t
| +--ro lsdB-lsid?         inet:ipv4-address
| +--ro lsdB-router-id?    inet:ipv4-address
+---n ospfv2-interface-link-state-change
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro router-id?         inet:ipv4-address
| +--ro interface-address? inet:ipv4-address
| +--ro address-less-interface? uint32
| +--ro interface-state?   ipi-ospf-types:ospf_interface_state_t
+---n ospfv2-interface-rx-bad-packet
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro router-id?         inet:ipv4-address
```

```

| +--ro interface-address?      inet:ipv4-address
| +--ro address-less-interface? uint32
| +--ro packet-src?            inet:ipv4-address
| +--ro packet-type?           ipi-ospf-types:ospf_packet_type_t
+---n ospfv2-interface-config-error
  +--ro severity?              cml-data-types:cml_notif_severity_t
  +--ro eventClass?           cml-data-types:cml_notif_class_t
  +--ro name?                  string
  +--ro router-id?            inet:ipv4-address
  +--ro interface-address?     inet:ipv4-address
  +--ro address-less-interface? uint32
  +--ro error-type?           ipi-ospf-types:ospf_config_error_type_t
  +--ro packet-type?          ipi-ospf-types:ospf_packet_type_t

```

module: ipi-ospfv3

```

+--rw ospfv3
  +--rw global
    | +--rw config
    | | +--rw display-route-on-single-line?  empty
    | +--ro state
    | | +--ro display-route-on-single-line?  empty
    | +--rw graceful-restart {feature-list:HAVE_RESTART}?
    |   +--rw config
    |   | +--rw grace-period?                uint16
    |   | +--rw controlled-restarts-only?    empty
    |   +--ro state
    |   | +--ro grace-period?                uint16
    |   | +--ro controlled-restarts-only?    empty
    |   +--rw helper
    |   | +--rw config
    |   | | +--rw max-grace-period?          uint16
    |   | | +--rw disable-all-neighbors?   empty
    |   | | +--rw disable-neighbor*        inet:ipv4-address
    |   | +--ro state
    |   |   +--ro max-grace-period?          uint16
    |   |   +--ro disable-all-neighbors?   empty

```

```

|           +---ro disable-neighbor*           inet:ipv4-address
+---rw processes
|   +---rw process* [ospfv3-id]
|       +---rw ospfv3-id                       -> ../config/ospfv3-id
|       +---rw config
|           | +---rw ospfv3-id?                 ipi-ospfv3-types:ospfv3_string_t
|           | +---rw vrf-name                   -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
|           | +---rw router-id?                 inet:ipv4-address
|           | +---rw bfd-enable-all-interfaces? empty {feature-list:HAVE_BFD}?
|           | +---rw database-summary?         empty
|           | +---rw area-border-type?         ipi-ospfv3-types:ospfv3_abr_type_t
|           | +---rw default-metric?           uint32
|           | +---rw shutdown?                 empty
|           | +---rw log-adjacency-changes?    ipi-ospfv3-types:ospfv3_log_adj_opt_t
|           | +---rw reference-bandwidth?      uint32
|           | +---rw max-database-descriptors? uint16
|       +---ro state
|           | +---ro statistics
|           | | +---ro up-time?                 string
|           | | +---ro database-description-in? yang:counter64
|           | | +---ro database-description-out? yang:counter64
|           | | +---ro external-lsa-count?      yang:counter64
|           | | +---ro external-lsa-checksum?   string
|           | | +---ro unknown-lsa-count?      yang:counter64
|           | | +---ro lsa-out?                 yang:counter64
|           | | +---ro lsa-in?                 yang:counter64
|           | | +---ro area-count?             yang:counter64
|           | +---ro ospfv3-id?                 ipi-ospfv3-types:ospfv3_string_t
|           | +---ro vrf-name                   -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
|           | +---ro router-id?                 inet:ipv4-address
|           | +---ro bfd-enable-all-interfaces? empty {feature-list:HAVE_BFD}?
|           | +---ro database-summary?         empty
|           | +---ro area-border-type?         ipi-ospfv3-types:ospfv3_abr_type_t
|           | +---ro default-metric?           uint32
|           | +---ro shutdown?                 empty
|           | +---ro log-adjacency-changes?    ipi-ospfv3-types:ospfv3_log_adj_opt_t
|           | +---ro reference-bandwidth?      uint32
|           | +---ro max-database-descriptors? uint16
|       +---ro link-state-database
|           | +---ro link* [link-index]
|           | | +---ro link-index             -> ../state/link-index
|           | | +---ro lsa-prefix* [prefix]
|           | | | +---ro prefix                 -> ../state/prefix
|           | | | +---ro state
|           | | | | +---ro prefix?             cml-data-types:cml_ipv6_prefix_t
|           | | | | +---ro no-unicast-bit?     empty
|           | | | | +---ro prefix-options?     ipi-ospfv3-types:ospfv3_prefix_options_t
|           | | +---ro state
|           | | | +---ro link-index?           uint32

```

```

|         |         |         +---ro link-local-address?    inet:ipv6-address
|         |         |         +---ro priority?            uint8
|         |         |         +---ro interface-name?       string
|         |         |         +---ro prefix-count?         uint32
|         |         |         +---ro advertising-router?    inet:ipv4-address
|         |         |         +---ro ls-age?               uint16
|         |         |         +---ro ls-type?              ipi-ospfv3-types:ospfv3_ls_type_t
|         |         |         +---ro ls-id?                string
|         |         |         +---ro ls-sequence-number?    string
|         |         |         +---ro ls-checksum?           string
|         |         |         +---ro ls-length?            uint16
|         |         |         +---ro ls-options?           ipi-ospfv3-types:ospfv3_ls_options_t
|         |         +---ro router* [router-index]
|         |         |         +---ro router-index      -> ../state/router-index
|         |         |         +---ro link* [link-index]
|         |         |         |         +---ro link-index      -> ../state/link-index
|         |         |         |         +---ro state
|         |         |         |         |         +---ro link-index?            uint32
|         |         |         |         |         +---ro neighbor-router-id?    inet:ipv4-address
|         |         |         |         |         +---ro neighbor-interface-id?  uint32
|         |         |         |         |         +---ro interface-id?          uint32
|         |         |         |         |         +---ro metric?                uint16
|         |         |         |         |         +---ro metric-type?          ipi-ospfv3-
types:ospfv3_link_metric_type_t
|         |         |         |         +---ro state
|         |         |         |         |         +---ro router-index?          uint32
|         |         |         |         |         +---ro area-id?              inet:ipv4-address
|         |         |         |         +---ro ls-router-properties?          ipi-ospfv3-
types:ospfv3_router_properties_t
|         |         |         |         |         +---ro advertising-router?    inet:ipv4-address
|         |         |         |         |         +---ro ls-age?               uint16
|         |         |         |         |         +---ro ls-type?              ipi-ospfv3-types:ospfv3_ls_type_t
|         |         |         |         |         +---ro ls-id?                string
|         |         |         |         |         +---ro ls-sequence-number?    string
|         |         |         |         |         +---ro ls-checksum?           string
|         |         |         |         |         +---ro ls-length?            uint16
|         |         |         |         |         +---ro ls-options?           ipi-ospfv3-types:ospfv3_ls_options_t
|         |         |         +---ro network* [advertising-router]
|         |         |         |         +---ro advertising-router      -> ../state/advertising-router
|         |         |         |         +---ro state
|         |         |         |         |         +---ro advertising-router?    inet:ipv4-address
|         |         |         |         |         +---ro ls-age?               uint16
|         |         |         |         |         +---ro ls-type?              ipi-ospfv3-types:ospfv3_ls_type_t
|         |         |         |         |         +---ro ls-id?                string
|         |         |         |         |         +---ro ls-sequence-number?    string
|         |         |         |         |         +---ro ls-checksum?           string
|         |         |         |         |         +---ro ls-length?            uint16
|         |         |         |         |         +---ro ls-options?           ipi-ospfv3-types:ospfv3_ls_options_t
|         |         |         |         |         +---ro attached-router*      inet:ipv4-address
|         |         +---ro intra-prefix* [intra-prefix-index]
|         |         |         +---ro intra-prefix-index      -> ../state/intra-prefix-index

```

```

| | | +---ro lsa-prefix* [prefix]
| | | | +---ro prefix    -> ../state/prefix
| | | | +---ro state
| | | |   +---ro prefix?      cml-data-types:cml_ipv6_prefix_t
| | | |   +---ro no-unicast-bit? empty
| | | |   +---ro prefix-options? ipi-ospfv3-types:ospfv3_prefix_options_t
| | | |   +---ro metric?      uint16
| | | +---ro state
| | | |   +---ro intra-prefix-index? uint32
| | | |   +---ro area-id?          inet:ipv4-address
| | | |   +---ro referenced-ls-advertising-router? inet:ipv4-address
| | | |   +---ro referenced-ls-id?   string
| | | |   +---ro referenced-ls-type? string
| | | |   +---ro prefix-count?      uint32
| | | |   +---ro advertising-router? inet:ipv4-address
| | | |   +---ro ls-age?            uint16
| | | |   +---ro ls-type?          ipi-ospfv3-
types:ospfv3_ls_type_t
| | | |   +---ro ls-id?            string
| | | |   +---ro ls-sequence-number? string
| | | |   +---ro ls-checksum?      string
| | | |   +---ro ls-length?        uint16
| | | +---ro inter-prefix* [inter-prefix-index]
| | | | +---ro inter-prefix-index  -> ../state/inter-prefix-index
| | | | +---ro lsa-prefix* [prefix]
| | | | | +---ro prefix    -> ../state/prefix
| | | | | +---ro state
| | | | |   +---ro prefix?      cml-data-types:cml_ipv6_prefix_t
| | | | |   +---ro no-unicast-bit? empty
| | | | |   +---ro prefix-options? ipi-ospfv3-types:ospfv3_prefix_options_t
| | | | |   +---ro metric?      uint16
| | | | +---ro state
| | | | |   +---ro inter-prefix-index? uint32
| | | | |   +---ro area-id?          inet:ipv4-address
| | | | |   +---ro advertising-router? inet:ipv4-address
| | | | |   +---ro ls-age?            uint16
| | | | |   +---ro ls-type?          ipi-ospfv3-types:ospfv3_ls_type_t
| | | | |   +---ro ls-id?            string
| | | | |   +---ro ls-sequence-number? string
| | | | |   +---ro ls-checksum?      string
| | | | |   +---ro ls-length?        uint16
| | | +---ro inter-router* [inter-router-index]
| | | | +---ro inter-router-index  -> ../state/inter-router-index
| | | | +---ro state
| | | | |   +---ro inter-router-index? uint32
| | | | |   +---ro area-id?          inet:ipv4-address
| | | | |   +---ro router-id?        inet:ipv4-address
| | | | |   +---ro advertising-router? inet:ipv4-address
| | | | |   +---ro ls-age?            uint16
| | | | |   +---ro ls-type?          ipi-ospfv3-types:ospfv3_ls_type_t
| | | | |   +---ro ls-id?            string

```

```

|   |   |   +---ro ls-sequence-number?   string
|   |   |   +---ro ls-checksum?         string
|   |   |   +---ro ls-length?          uint16
|   |   |   +---ro metric?             uint16
|   |   |   +---ro ls-options?         ipi-ospfv3-types:ospfv3_ls_options_t
|   | +---ro external* [external-index]
|   | |   +---ro external-index    -> ../state/external-index
|   | |   +---ro lsa-prefix* [prefix]
|   | | |   +---ro prefix          -> ../state/prefix
|   | | |   +---ro state
|   | | | |   +---ro prefix?       cml-data-types:cml_ipv6_prefix_t
|   | | | |   +---ro no-unicast-bit? empty
|   | | | |   +---ro prefix-options? ipi-ospfv3-types:ospfv3_prefix_options_t
|   | | +---ro state
|   | | |   +---ro external-index?   uint32
|   | | |   +---ro referenced-ls-id?  string
|   | | |   +---ro referenced-ls-type? uint32
|   | | |   +---ro route-tag?        uint32
|   | | |   +---ro forwarding-address? inet:ip-address
|   | | |   +---ro metric?           uint16
|   | | |   +---ro metric-type?      ipi-ospfv3-types:ospfv3_ls_metric_type_t
|   | | |   +---ro advertising-router? inet:ipv4-address
|   | | |   +---ro ls-age?           uint16
|   | | |   +---ro ls-type?         ipi-ospfv3-types:ospfv3_ls_type_t
|   | | |   +---ro ls-id?           string
|   | | |   +---ro ls-sequence-number? string
|   | | |   +---ro ls-checksum?     string
|   | | |   +---ro ls-length?       uint16
|   | +---ro not-so-stubby-area* [nssa-index]
|   | |   +---ro nssa-index    -> ../state/nssa-index
|   | |   +---ro lsa-prefix* [prefix]
|   | | |   +---ro prefix      -> ../state/prefix
|   | | |   +---ro state
|   | | | |   +---ro prefix?    cml-data-types:cml_ipv6_prefix_t
|   | | | |   +---ro no-unicast-bit? empty
|   | | | |   +---ro prefix-options? ipi-ospfv3-types:ospfv3_prefix_options_t
|   | | +---ro state
|   | | |   +---ro nssa-index?     uint32
|   | | |   +---ro referenced-ls-id? string
|   | | |   +---ro referenced-ls-type? uint32
|   | | |   +---ro route-tag?      uint32
|   | | |   +---ro forwarding-address? inet:ip-address
|   | | |   +---ro metric?         uint16
|   | | |   +---ro metric-type?    ipi-ospfv3-types:ospfv3_ls_metric_type_t
|   | | |   +---ro advertising-router? inet:ipv4-address
|   | | |   +---ro ls-age?         uint16
|   | | |   +---ro ls-type?       ipi-ospfv3-types:ospfv3_ls_type_t
|   | | |   +---ro ls-id?         string
|   | | |   +---ro ls-sequence-number? string
|   | | |   +---ro ls-checksum?   string

```

```
|      |      +---ro ls-length?          uint16
|  +---ro route* [prefix]
|      |      +---ro prefix          -> ../state/prefix
|      |      +---ro next-hop* [address]
|      |      |      +---ro address    -> ../state/address
|      |      |      +---ro state
|      |      |      |      +---ro address?          inet:ip-address
|      |      |      |      +---ro interface-name?   string
|      |      |      |      +---ro transit-area?     empty
|      |      |      |      +---ro area-id?          inet:ipv4-address
|      |      |      |      +---ro connected?        empty
|      |      |      |      +---ro invalid?          empty
|      |      |      |      +---ro code?             string
|      |      |      +---ro state
|      |      |      |      +---ro prefix?          cml-data-types:cml_ip_prefix_t
|      |      |      |      +---ro distance?        uint8
|      |      |      +---ro route-path
|      |      |      |      +---ro state
|      |      |      |      |      +---ro type?          ipi-ospfv3-types:ospfv3_path_type_t
|      |      |      |      |      +---ro code?          string
|      |      |      |      |      +---ro discard-connection? empty
|      |      |      |      |      +---ro cost?          uint32
|      |      |      |      |      +---ro type-2-cost?    uint32
|      |      |      |      |      +---ro path-flags?     ipi-ospfv3-types:ospfv3_path_flags_t
|  +---rw administrative-distance
|      |      +---rw config
|      |      |      +---rw default-distance?    uint8
|      |      |      +---ro state
|      |      |      |      +---ro default-distance?    uint8
|      |      |      +---rw ospf
|      |      |      |      +---rw config
|      |      |      |      |      +---rw intra-area-distance?    uint8
|      |      |      |      |      +---rw inter-area-distance?    uint8
|      |      |      |      |      +---rw external-routes-distance? uint8
|      |      |      |      +---ro state
|      |      |      |      |      +---ro intra-area-distance?    uint8
|      |      |      |      |      +---ro inter-area-distance?    uint8
|      |      |      |      |      +---ro external-routes-distance? uint8
|  +---rw capability
|      |      +---rw config
|      |      |      +---rw traffic-engineering?    empty {feature-list:HAVE_OSPF6_TE}?
|      |      |      +---rw disable-graceful-restart? empty {feature-list:HAVE_RESTART}?
|      |      |      +---ro state
|      |      |      |      +---ro traffic-engineering?    empty {feature-list:HAVE_OSPF6_TE}?
|      |      |      |      +---ro disable-graceful-restart? empty {feature-list:HAVE_RESTART}?
|  +---rw timers
|      |      +---rw spf
|      |      |      +---rw config!
|      |      |      |      +---rw exponential-min-delay    uint32
|      |      |      |      +---rw exponential-max-delay    uint32
```



```

|     |     +---ro state
|     |     +---ro exponential-min-delay    uint32
|     |     +---ro exponential-max-delay    uint32
| +---rw ospfv3-srv6 {feature-list:HAVE_SRV6}?
|     | +---rw config!
|     | | +---rw ospf6SRv6enable    empty
|     | +---ro state
|     | | +---ro ospf6SRv6enable    empty
|     | +---rw locator-lists
|     |   +---rw locator-list* [ospf6SRv6LocatorName]
|     |     +---rw ospf6SRv6LocatorName  -> ../config/ospf6SRv6LocatorName
|     |     +---rw config
|     |       | +---rw ospf6SRv6LocatorName?  string
|     |       +---ro state
|     |         +---ro ospf6SRv6LocatorName?  string
| +---rw passive-interfaces
|     | +---rw config
|     | | +---rw all-interfaces?    empty
|     | +---ro state
|     | | +---ro all-interfaces?    empty
|     | +---rw passive-interface* [name]
|     |   +---rw name                -> ../config/name
|     |   +---rw config
|     |     | +---rw name?            string
|     |     | +---rw passive-mode     ipi-ospfv3-types:ospfv3_passive_mode_t
|     |     +---ro state
|     |       +---ro name?            string
|     |       +---ro passive-mode     ipi-ospfv3-types:ospfv3_passive_mode_t
| +---rw summary-addresses
|     | +---rw summary-address* [address]
|     |   +---rw address              -> ../config/address
|     |   +---rw config
|     |     | +---rw address?          cml-data-types:cml_ipv6_prefix_t
|     |     | +---rw not-advertise?    empty
|     |     | +---rw translate-tag?    uint32
|     |     | +---rw all-tag?          uint32
|     |     +---ro state
|     |       +---ro address?          cml-data-types:cml_ipv6_prefix_t
|     |       +---ro not-advertise?    empty
|     |       +---ro translate-tag?    uint32
|     |       +---ro all-tag?          uint32
| +---rw default-information
|     | +---rw config
|     | | +---rw originate?            empty
|     | | +---rw always-advertise-default-route?  empty
|     | | +---rw metric?              uint32
|     | | +---rw metric-type?         ipi-ospfv3-
types:ospfv3_metric_type_t
|     | | +---rw route-map?           string
|     | +---ro state
|     |   +---ro originate?          empty

```

```

|     |     +---ro always-advertise-default-route?    empty
|     |     +---ro metric?                            uint32
|     |     +---ro metric-type?                       ipi-ospfv3-
types:ospfv3_metric_type_t
|     |     +---ro route-map?                         string
|     +---rw distribute-list {feature-list:HAVE_ACL}?
|     |     +---rw filter-in
|     |     |     +---rw config
|     |     |     |     +---rw access-control-list?    string
|     |     |     |     +---ro state
|     |     |     |     +---ro access-control-list?    string
|     |     |     +---rw filter-out
|     |     |     +---rw routing-protocols
|     |     |     |     +---rw routing-protocol* [protocol]
|     |     |     |     +---rw protocol    -> ../config/protocol
|     |     |     |     +---rw config
|     |     |     |     |     +---rw protocol?         ipi-ospfv3-
types:ospfv3_route_source_type_t
|     |     |     |     |     +---rw access-control-list    string
|     |     |     |     |     +---ro state
|     |     |     |     |     +---ro protocol?             ipi-ospfv3-
types:ospfv3_route_source_type_t
|     |     |     |     |     +---ro access-control-list    string
|     |     |     +---rw ospf-processes
|     |     |     |     +---rw ospf-process* [ospf-process-id]
|     |     |     |     +---rw ospf-process-id    -> ../config/ospf-process-id
|     |     |     |     +---rw config
|     |     |     |     |     +---rw ospf-process-id?      ipi-ospfv3-types:ospfv3_string_t
|     |     |     |     |     +---rw access-control-list    string
|     |     |     |     |     +---ro state
|     |     |     |     |     +---ro ospf-process-id?      ipi-ospfv3-types:ospfv3_string_t
|     |     |     |     |     +---ro access-control-list    string
|     +---rw redistribute
|     |     +---rw routing-protocols
|     |     |     +---rw routing-protocol* [protocol]
|     |     |     +---rw protocol    -> ../config/protocol
|     |     |     +---rw config
|     |     |     |     +---rw metric?                uint32
|     |     |     |     +---rw metric-type?           ipi-ospfv3-types:ospfv3_metric_type_t
|     |     |     |     +---rw route-map?            string
|     |     |     |     +---rw route-tag?            uint32
|     |     |     |     +---rw protocol?             ipi-ospfv3-types:ospfv3_route_source_type_t
|     |     |     |     +---ro state
|     |     |     |     +---ro metric?                uint32
|     |     |     |     +---ro metric-type?           ipi-ospfv3-types:ospfv3_metric_type_t
|     |     |     |     +---ro route-map?            string
|     |     |     |     +---ro route-tag?            uint32
|     |     |     |     +---ro protocol?             ipi-ospfv3-types:ospfv3_route_source_type_t
|     |     +---rw ospf-processes
|     |     |     +---rw ospf-process* [ospf-process-id]
|     |     |     +---rw ospf-process-id    -> ../config/ospf-process-id

```

```

|     |         +---rw config
|     |         | +---rw metric?             uint32
|     |         | +---rw metric-type?        ipi-ospfv3-types:ospfv3_metric_type_t
|     |         | +---rw route-map?         string
|     |         | +---rw route-tag?         uint32
|     |         | +---rw ospf-process-id?    ipi-ospfv3-types:ospfv3_string_t
|     |         +---ro state
|     |         | +---ro metric?             uint32
|     |         | +---ro metric-type?        ipi-ospfv3-types:ospfv3_metric_type_t
|     |         | +---ro route-map?         string
|     |         | +---ro route-tag?         uint32
|     |         | +---ro ospf-process-id?    ipi-ospfv3-types:ospfv3_string_t
|     +---rw areas
|     | +---rw area* [area-id]
|     |     +---rw area-id             -> ../config/area-id
|     |     +---rw config
|     |         | +---rw area-id?         ipi-ospfv3-types:ospfv3_area_t
|     |         | +---rw default-cost?     uint32
|     |         +---ro state
|     |         | +---ro area-id?         ipi-ospfv3-types:ospfv3_area_t
|     |         | +---ro default-cost?     uint32
|     |         +---rw stub
|     |         | +---rw config!
|     |         | | +---rw enable         empty
|     |         | | +---rw no-summary?    empty
|     |         | +---ro state
|     |         |     +---ro enable         empty
|     |         |     +---ro no-summary?    empty
|     |         +---rw nssa {feature-list:HAVE_NSSA}?
|     |         | +---rw config!
|     |         | | +---rw enable         empty
|     |         | | +---rw no-summary?    empty
|     |         | | +---rw stability-interval? uint32
|     |         | | +---rw translator-role? ipi-ospfv3-
types:ospfv3_translator_role_t
|     |         | | +---rw no-redistribution? empty
|     |         | | +---rw default-information-originate? empty
|     |         | | +---rw metric?         uint32
|     |         | | +---rw metric-type?    ipi-ospfv3-
types:ospfv3_metric_type_t
|     |         | | +---rw route-map?     string
|     |         | +---ro state
|     |         |     +---ro enable         empty
|     |         |     +---ro no-summary?    empty
|     |         |     +---ro stability-interval? uint32
|     |         |     +---ro translator-role? ipi-ospfv3-
types:ospfv3_translator_role_t
|     |         |     +---ro no-redistribution? empty
|     |         |     +---ro default-information-originate? empty
|     |         |     +---ro metric?         uint32

```

```

| | | | +---ro metric-type? | ipi-ospfv3-
types:ospfv3_metric_type_t
| | | | +---ro route-map? | string
| | | | +---rw virtual-links
| | | | +---rw virtual-link* [remote-router-id]
| | | | +---rw remote-router-id -> ../config/remote-router-id
| | | | +---rw config
| | | | | +---rw remote-router-id? | inet:ipv4-address
| | | | | +---rw bfd-fall-over? | empty {feature-list:HAVE_BFD}?
| | | | | +---rw instance-id? | uint8
| | | | | +---rw authentication-cryptomap? -> /ipi-ipsec:ipsec/crypto-
maps/crypto-map/config/name {feature-list:HAVE_IPSEC,feature-list:HAVE_TUNNEL}?
| | | | +---ro state
| | | | | +---ro remote-router-id? | inet:ipv4-address
| | | | | +---ro bfd-fall-over? | empty {feature-
list:HAVE_BFD}?
| | | | | +---ro instance-id? | uint8
| | | | | +---ro authentication-cryptomap? -> /ipi-ipsec:ipsec/
crypto-maps/crypto-map/config/name {feature-list:HAVE_IPSEC,feature-list:HAVE_TUNNEL}?
| | | | | +---ro name? | string
| | | | | +---ro status? | ipi-ospfv3-
types:ospfv3_link_status_t
| | | | | +---ro interface-name? | string
| | | | | +---ro virtual-link-interface-state? | string
| | | | | +---ro local-address? | inet:ipv4-address
| | | | | +---ro remote-address? | inet:ipv4-address
| | | | | +---ro virtual-link-instance-id? | uint32
| | | | | +---ro hello-suppression-enable? | empty
| | | | | +---ro do-not-age-lsa-enable? | empty
| | | | | +---ro hello-due-in? | yang:date-and-time
| | | | | +---ro adjacency-state? | string
| | | | | +---ro virtual-link-config-error
| | | | | | +---ro router-id? | inet:ipv4-address
| | | | | | +---ro instance-id? | uint8
| | | | | | +---ro error-type? | ipi-ospfv3-
types:ospfv3_config_error_type_t
| | | | | | +---ro packet-type? | ipi-ospfv3-types:ospfv3_packet_type_t
| | | | | | +---ro virtual-link-state-change
| | | | | | | +---ro router-id? | inet:ipv4-address
| | | | | | | +---ro instance-id? | uint8
| | | | | | +---ro virtual-link-state? | ipi-ospfv3-
types:ospfv3_interface_state_t
| | | | | | | +---ro virtual-link-neighbor-state-change
| | | | | | | | +---ro router-id? | inet:ipv4-address
| | | | | | | | +---ro instance-id? | uint8
| | | | | | | | +---ro neighbor-state? | ipi-ospfv3-
types:ospfv3_interface_state_t
| | | | | | | | +---ro virtual-link-tx-retransmit
| | | | | | | | | +---ro router-id? | inet:ipv4-address
| | | | | | | | | +---ro instance-id? | uint8
| | | | | | | | | +---ro packet-type? | ipi-ospfv3-types:ospfv3_packet_type_t
| | | | | | | | | +---ro lsdB-type? | uint32

```

```

| | | | +---ro lsdb-lsid?          uint32
| | | | +---ro lsdb-router-id?    inet:ipv4-address
| | | | +---ro virtual-link-rx-bad-packet
| | | |   +---ro router-id?       inet:ipv4-address
| | | |   +---ro instance-id?     uint8
| | | |   +---ro packet-type?     ipi-ospfv3-types:ospfv3_packet_type_t
| | | | +---rw timers
| | | |   +---rw config
| | | |     | +---rw dead-interval?      uint16
| | | |     | +---rw hello-interval?    uint16
| | | |     | +---rw transmission-delay?  uint16
| | | |     | +---rw retransmission-interval?  uint16
| | | |   +---ro state
| | | |     +---ro dead-interval?      uint16
| | | |     +---ro hello-interval?    uint16
| | | |     +---ro transmission-delay?  uint16
| | | |     +---ro retransmission-interval?  uint16
| | | +---rw address-ranges
| | |   +---rw address-range* [address]
| | |     +---rw address    -> ../config/address
| | |     +---rw config
| | |       | +---rw address?          cml-data-types:cml_ipv6_prefix_t
| | |       | +---rw not-advertise?    empty
| | |       +---ro state
| | |         +---ro address?          cml-data-types:cml_ipv6_prefix_t
| | |         +---ro not-advertise?    empty
| +---ro area-info* [area-id]
| | +---ro area-id    -> ../state/area-id
| | +---ro state
| | | +---ro statistics
| | | | +---ro active-interface-count?  yang:counter64
| | | | +---ro interface-count?        yang:counter64
| | | | +---ro spf-algorithm-executed-count?  yang:counter64
| | | | +---ro lsa-count?               yang:counter64
| | | | +---ro lsa-checksum?            string
| | | | +---ro unknown-lsa-count?      yang:counter64
| | | | +---ro area-id?                 inet:ipv4-address
| | | | +---ro interface-name*          string
| | | | +---ro backbone?                empty
| | | | +---ro active?                  empty
| | | | +---ro asbr?                    empty
| | +---ro vertex* [router-id]
| | | +---ro router-id    -> ../state/router-id
| | | +---ro next-hop* [address]
| | | | +---ro address    -> ../state/address
| | | | +---ro state
| | | |   +---ro address?          inet:ip-address
| | | |   +---ro interface-name?  string
| | | |   +---ro transit-area?    empty
| | | |   +---ro area-id?         inet:ipv4-address

```

```

|         |         |         +---ro connected?         empty
|         |         |         +---ro invalid?          empty
|         |         |         +---ro code?             string
|         |         |         +---ro state
|         |         |         |         +---ro router-id?  inet:ipv4-address
|         |         |         |         +---ro distance?  uint8
|     +---rw address-family
|         |     +---rw ipv4
|         |         |     +---rw config
|         |         |         |     +---rw enable-af?    empty
|         |         |         |     +---ro state
|         |         |         |         |     +---ro enable-af?    empty
|         |         |         |     +---rw areas
|         |         |         |         |     +---rw area* [area-id]
|         |         |         |         |         |     +---rw area-id         -> ../config/area-id
|         |         |         |         |         |     +---rw config
|         |         |         |         |         |         |     +---rw area-id?    ipi-ospfv3-types:ospfv3_area_t
|         |         |         |         |         |         |     +---ro state
|         |         |         |         |         |         |         |     +---ro area-id?    ipi-ospfv3-types:ospfv3_area_t
|         |         |         |         |     +---rw address-ranges
|         |         |         |         |         |     +---rw address-range* [address]
|         |         |         |         |         |         |     +---rw address      -> ../config/address
|         |         |         |         |         |         |     +---rw config
|         |         |         |         |         |         |         |     +---rw address?    cml-data-
types:cml_ipv4_addr_prefix_t
|         |         |         |         |         |         |         |         |     +---rw not-advertise?    empty
|         |         |         |         |         |         |         |         |     +---ro state
|         |         |         |         |         |         |         |         |         |     +---ro address?    cml-data-
types:cml_ipv4_addr_prefix_t
|         |         |         |         |         |         |         |         |         |     +---ro not-advertise?    empty
|         |         |     +---rw summary-addresses
|         |         |         |     +---rw summary-address* [address]
|         |         |         |         |     +---rw address      -> ../config/address
|         |         |         |         |     +---rw config
|         |         |         |         |         |     +---rw address?    cml-data-types:cml_ipv4_prefix_t
|         |         |         |         |         |         |     +---rw not-advertise?    empty
|         |         |         |         |         |         |         |     +---rw tag?          uint32
|         |         |         |         |         |         |     +---ro state
|         |         |         |         |         |         |         |     +---ro address?    cml-data-types:cml_ipv4_prefix_t
|         |         |         |         |         |         |         |     +---ro not-advertise?    empty
|         |         |         |         |         |         |         |     +---ro tag?          uint32
|         |         |     +---rw default-information
|         |         |         |     +---rw config
|         |         |         |         |     +---rw originate?          empty
|         |         |         |         |     +---rw always-advertise-default-route?    empty
|         |         |         |         |     +---rw metric?            uint32
|         |         |         |         |         |     +---rw metric-type?    ipi-ospfv3-
types:ospfv3_metric_type_t
|         |         |         |         |         |         |         |     +---rw route-map?    string
|         |         |         |         |         |         |         |     +---ro state
|         |         |         |         |         |         |         |     +---ro originate?    empty

```

```

|         |         |         +---ro always-advertise-default-route?   empty
|         |         |         +---ro metric?                          uint32
|         |         |         +---ro metric-type?                       ipi-ospfv3-
types:ospfv3_metric_type_t
|         |         |         +---ro route-map?                          string
|         |         |         +---rw redistribute
|         |         |         +---rw routing-protocols
|         |         |         |         +---rw routing-protocol* [protocol-af]
|         |         |         |         +---rw protocol-af      -> ../config/protocol-af
|         |         |         |         +---rw config
|         |         |         |         +---rw protocol-af?       ipi-ospfv3-
types:ospfv3_af_route_source_type_t
|         |         |         |         +---rw metric?                uint32
|         |         |         |         +---rw metric-type?          ipi-ospfv3-types:ospfv3_metric_type_t
|         |         |         |         +---rw route-map?            string
|         |         |         |         +---rw route-tag?            uint32
|         |         |         |         +---ro state
|         |         |         |         +---ro protocol-af?         ipi-ospfv3-
types:ospfv3_af_route_source_type_t
|         |         |         |         +---ro metric?                uint32
|         |         |         |         +---ro metric-type?          ipi-ospfv3-types:ospfv3_metric_type_t
|         |         |         |         +---ro route-map?            string
|         |         |         |         +---ro route-tag?            uint32
|         |         |         |         +---rw ospf-processes
|         |         |         |         +---rw ospf-process* [ospfv2-process-id]
|         |         |         |         +---rw ospfv2-process-id     -> ../config/ospfv2-process-id
|         |         |         |         +---rw config
|         |         |         |         |         +---rw ospfv2-process-id?  uint16
|         |         |         |         |         +---rw metric?          uint32
|         |         |         |         |         +---rw metric-type?     ipi-ospfv3-
types:ospfv3_metric_type_t
|         |         |         |         |         +---rw route-map?      string
|         |         |         |         |         +---rw route-tag?      uint32
|         |         |         |         |         +---ro state
|         |         |         |         |         +---ro ospfv2-process-id? uint16
|         |         |         |         |         +---ro metric?          uint32
|         |         |         |         |         +---ro metric-type?     ipi-ospfv3-
types:ospfv3_metric_type_t
|         |         |         |         |         +---ro route-map?      string
|         |         |         |         |         +---ro route-tag?      uint32
|         |         |         |         +---ro originate-lsa
|         |         |         |         |         +---ro router-id?       -> /ospfv3/processes/process/state/router-id
|         |         |         |         |         +---ro lsdB-area-id?     inet:ipv4-address
|         |         |         |         |         +---ro lsdB-type?       uint32
|         |         |         |         |         +---ro lsdB-id?         uint32
|         |         |         |         |         +---ro lsdB-router-id?   inet:ipv4-address
|         |         |         |         +---ro tx-retransmit
|         |         |         |         |         +---ro router-id?       inet:ipv4-address
|         |         |         |         |         +---ro if-index?        int32
|         |         |         |         |         +---ro instance-id?     uint8
|         |         |         |         |         +---ro neighbor-router-id? inet:ipv4-address

```

```

|   |   +---ro packet-type?           ipi-ospfv3-types:ospfv3_packet_type_t
|   |   +---ro lsdb-type?             uint32
|   |   +---ro lsdb-lsid?             uint32
|   |   +---ro lsdb-router-id?        inet:ipv4-address
|   +---ro neighbor-state-change
|   |   +---ro router-id?             inet:ipv4-address
|   |   +---ro if-index?              int32
|   |   +---ro instance-id?          uint8
|   |   +---ro neighbor-router-id?    inet:ipv4-address
|   |   +---ro neighbor-state?        ipi-ospfv3-types:ospfv3_neighbor_state_change_t
|   +---rw bgp-link-state {feature-list:HAVE_BGP_LS}?
|       +---rw distribute
|           +---rw config
|               |   +---rw enabled?      empty
|               |   +---rw throttle-timer? uint8
|           +---ro state
|               +---ro enabled?          empty
|               +---ro throttle-timer?  uint8
+---rw debug
|   +---rw config
|   |   +---rw bfd?                    empty {feature-list:HAVE_BFD}?
|   |   +---rw retransmission?         empty
|   |   +---rw dist-ls?                empty {feature-list:HAVE_BGP_LS}?
|   |   +---rw events?                 ipi-ospfv3-types:ospfv3_debug_event_t
|   |   +---rw ifsm?                  ipi-ospfv3-types:ospfv3_debug_ifsm_t
|   |   +---rw lsa?                    ipi-ospfv3-types:ospfv3_debug_lsa_t
|   |   +---rw nfsm?                  ipi-ospfv3-types:ospfv3_debug_nfsm_t
|   |   +---rw nsm?                    ipi-ospfv3-types:ospfv3_debug_nsm_t
|   |   +---rw rib?                    ipi-ospfv3-types:ospfv3_debug_rib_t {feature-
list:HAVE_RIBD}?
|   |   +---rw route?                  ipi-ospfv3-types:ospfv3_debug_route_t
|   |   +---rw packet-hello?           ipi-ospfv3-types:ospfv3_debug_packet_options_t
|   |   +---rw packet-dd?              ipi-ospfv3-types:ospfv3_debug_packet_options_t
|   |   +---rw packet-ls-request?      ipi-ospfv3-types:ospfv3_debug_packet_options_t
|   |   +---rw packet-ls-update?       ipi-ospfv3-types:ospfv3_debug_packet_options_t
|   |   +---rw packet-ls-ack?          ipi-ospfv3-types:ospfv3_debug_packet_options_t
|   +---ro state
|       +---ro bfd?                    empty {feature-list:HAVE_BFD}?
|       +---ro retransmission?         empty
|       +---ro dist-ls?                empty {feature-list:HAVE_BGP_LS}?
|       +---ro events?                 ipi-ospfv3-types:ospfv3_debug_event_t
|       +---ro ifsm?                  ipi-ospfv3-types:ospfv3_debug_ifsm_t
|       +---ro lsa?                    ipi-ospfv3-types:ospfv3_debug_lsa_t
|       +---ro nfsm?                  ipi-ospfv3-types:ospfv3_debug_nfsm_t
|       +---ro nsm?                    ipi-ospfv3-types:ospfv3_debug_nsm_t
|       +---ro rib?                    ipi-ospfv3-types:ospfv3_debug_rib_t {feature-
list:HAVE_RIBD}?
|       +---ro route?                  ipi-ospfv3-types:ospfv3_debug_route_t
|       +---ro packet-hello?           ipi-ospfv3-types:ospfv3_debug_packet_options_t
|       +---ro packet-dd?              ipi-ospfv3-types:ospfv3_debug_packet_options_t
|       +---ro packet-ls-request?      ipi-ospfv3-types:ospfv3_debug_packet_options_t

```



```

|     +---ro packet-ls-update?      ipi-ospfv3-types:ospfv3_debug_packet_options_t
|     +---ro packet-ls-ack?        ipi-ospfv3-types:ospfv3_debug_packet_options_t
|     +---ro terminal-debug-status
|     +---ro bfd?                  cml-data-types:cml_on_off_t {feature-
list:HAVE_BFD}?
|     +---ro retransmission?       cml-data-types:cml_on_off_t
|     +---ro dist-ls?              empty {feature-list:HAVE_BGP_LS}?
|     +---ro events?               ipi-ospfv3-types:ospfv3_debug_event_t
|     +---ro ifsm?                 ipi-ospfv3-types:ospfv3_debug_ifsm_t
|     +---ro lsa?                  ipi-ospfv3-types:ospfv3_debug_lsa_t
|     +---ro n fsm?                ipi-ospfv3-types:ospfv3_debug_n fsm_t
|     +---ro nsm?                  ipi-ospfv3-types:ospfv3_debug_nsm_t
|     +---ro rib?                  ipi-ospfv3-types:ospfv3_debug_rib_t {feature-
list:HAVE_RIBD}?
|     +---ro route?                ipi-ospfv3-types:ospfv3_debug_route_t
|     +---ro packet-hello?         ipi-ospfv3-types:ospfv3_debug_packet_options_t
|     +---ro packet-dd?           ipi-ospfv3-types:ospfv3_debug_packet_options_t
|     +---ro packet-ls-request?    ipi-ospfv3-types:ospfv3_debug_packet_options_t
|     +---ro packet-ls-update?    ipi-ospfv3-types:ospfv3_debug_packet_options_t
|     +---ro packet-ls-ack?       ipi-ospfv3-types:ospfv3_debug_packet_options_t
+---rw interfaces
    +---rw interface* [interface-name]
        +---rw interface-name      -> ../config/interface-name
        +---rw config
            | +---rw interface-name? -> /ipi-interface:interfaces/interface/name
            | +---rw shutdown?      empty
        +---ro state
            | +---ro interface-name? -> /ipi-interface:interfaces/interface/
name
            | +---ro shutdown?      empty
            | +---ro interface-config-error
            | | +---ro router-id?    inet:ipv4-address
            | | +---ro interface-index? uint32
            | | +---ro interface-instance-id? uint8
            | | +---ro error-type?   ipi-ospfv3-
types:ospfv3_config_error_type_t
            | | +---ro packet-type?  ipi-ospfv3-types:ospfv3_packet_type_t
            | +---ro interface-state-change
            | | +---ro router-id?    inet:ipv4-address
            | | +---ro interface-index? uint32
            | | +---ro interface-instance-id? uint8
            | | +---ro interface-state? ipi-ospfv3-types:ospfv3_interface_state_t
            | +---ro interface-rx-bad-packet
            | +---ro router-id?      inet:ipv4-address
            | +---ro interface-index? uint32
            | +---ro interface-instance-id? uint8
            | +---ro packet-src?     inet:ipv6-address
            | +---ro packet-type?   ipi-ospfv3-types:ospfv3_packet_type_t
        +---rw instances
            +---rw instance* [instance-id]
                +---rw instance-id  -> ../config/instance-id

```

```

    +--rw config
      | +--rw instance-id?          uint8
      | +--rw network-type?        ipi-ospfv3-
types:ospfv3_network_type_t
      | +--rw cost?                uint16
      | +--rw priority?            uint8
      | +--rw traffic-engineering-metric?  uint16 {feature-
list:HAVE_OSPF6_TE}?
      | +--rw mtu?                 uint16
      | +--rw mtu-ignore?          empty
      | +--rw enable-link-lsa-suppression? empty
      | +--rw enable-bfd?          boolean {feature-list:HAVE_BFD}?
      | +--rw authentication-cryptomap?  -> /ipi-ipsec:ipsec/crypto-maps/
crypto-map/config/name {feature-list:HAVE_IPSEC,feature-list:HAVE_TUNNEL}?
    +--ro state
      | +--ro statistics
      | | +--ro neighbor-count?      uint32
      | | +--ro adjacent-neighbor-count?  uint32
      | | +--ro hello-due-in?        string
      | | +--ro hello-in?            yang:counter64
      | | +--ro hello-out?           yang:counter64
      | | +--ro database-description-in? yang:counter64
      | | +--ro database-description-out? yang:counter64
      | | +--ro ls-request-in?       yang:counter64
      | | +--ro ls-request-out?      yang:counter64
      | | +--ro ls-update-in?        yang:counter64
      | | +--ro ls-update-out?       yang:counter64
      | | +--ro ls-ack-in?           yang:counter64
      | | +--ro ls-ack-out?          yang:counter64
      | | +--ro ls-ack-discarded?     yang:counter64
      | +--ro instance-id?          uint8
      | +--ro network-type?         ipi-ospfv3-
types:ospfv3_network_type_t
      | +--ro cost?                 uint16
      | +--ro priority?             uint8
      | +--ro traffic-engineering-metric?  uint16 {feature-
list:HAVE_OSPF6_TE}?
      | +--ro mtu?                  uint16
      | +--ro mtu-ignore?           empty
      | +--ro enable-link-lsa-suppression? empty
      | +--ro enable-bfd?           boolean {feature-list:HAVE_BFD}?
      | +--ro authentication-cryptomap?  -> /ipi-ipsec:ipsec/crypto-maps/
crypto-map/config/name {feature-list:HAVE_IPSEC,feature-list:HAVE_TUNNEL}?
      | +--ro administrative-state?    ipi-ospfv3-
types:ospfv3_interface_admin_state_t
      | +--ro interface-index?        uint32
      | +--ro interface-state?        ipi-ospfv3-
types:ospfv3_interface_state_t
      | +--ro address?               inet:ipv6-address
      | +--ro link-local-address?     inet:ipv6-address
      | +--ro router-id?              inet:ipv4-address
    +--rw routers

```

```

| +--rw router* [ospfv3-id area-id]
|   +--rw ospfv3-id   -> ../config/ospfv3-id
|   +--rw area-id     -> ../config/area-id
|   +--rw config
|     | +--rw ospfv3-id?   ipi-ospfv3-types:ospfv3_string_t
|     | +--rw area-id?    ipi-ospfv3-types:ospfv3_area_t
|     +--ro state
|       +--ro ospfv3-id?   ipi-ospfv3-types:ospfv3_string_t
|       +--ro area-id?    ipi-ospfv3-types:ospfv3_area_t
+--rw timers
| +--rw config
| | +--rw dead-interval?      uint16
| | +--rw hello-interval?    uint16
| | +--rw transmission-delay? uint16
| | +--rw retransmission-interval? uint16
| +--ro state
|   +--ro dead-interval?      uint16
|   +--ro hello-interval?    uint16
|   +--ro transmission-delay? uint16
|   +--ro retransmission-interval? uint16
+--rw neighbors-static
| +--rw neighbor-static* [address]
|   +--rw address   -> ../config/address
|   +--rw config
|     | +--rw address?      inet:ipv6-address
|     | +--rw cost?         uint16
|     | +--rw priority?     uint8
|     | +--rw poll-interval? uint32
|     +--ro state
|       +--ro address?      inet:ipv6-address
|       +--ro cost?         uint16
|       +--ro priority?     uint8
|       +--ro poll-interval? uint32
|       +--ro interface-state? string
+--ro designated-router
| +--ro state
|   +--ro router-id?   inet:ipv4-address
|   +--ro address?    inet:ipv6-address
+--ro backup-designated-router
| +--ro state
|   +--ro router-id?   inet:ipv4-address
|   +--ro address?    inet:ipv6-address
+--ro neighbor* [router-id]
  +--ro router-id   -> ../state/router-id
  +--ro state
  | +--ro statistics
  | | +--ro dead-timer-due-in?   string
  | | +--ro timer-dump?         string
  | | +--ro state-changes?      yang:counter64
  | | +--ro database-summary-count? yang:counter64

```

```

    | | +--ro ls-request-count?          yang:counter64
    | | +--ro ls-retransmission-count?   yang:counter64
    | +--ro router-id?                  inet:ipv4-address
    | +--ro address?                    inet:ipv6-address
    | +--ro area-id?                    inet:ipv4-address
    | +--ro state?                      string
    | +--ro state-message?              string
    | +--ro bfd-enable?                 empty {feature-
list:HAVE_BFD}?
    | +--ro priority?                  uint8
    | +--ro neighbor-options?          ipi-ospfv3-
types:ospfv3_ls_options_t
    | +--ro designated-router-router-id?  inet:ipv4-address
    | +--ro backup-designated-router-router-id?  inet:ipv4-address
+--ro route* [prefix]
    +--ro prefix          -> ../state/prefix
    +--ro next-hop* [address]
    | +--ro address      -> ../state/address
    | +--ro state
    |   +--ro address?    inet:ip-address
    |   +--ro interface-name?  string
    |   +--ro transit-area?  empty
    |   +--ro area-id?     inet:ipv4-address
    |   +--ro connected?   empty
    |   +--ro invalid?     empty
    |   +--ro code?        string
    +--ro state
    | +--ro prefix?      cml-data-types:cml_ip_prefix_t
    | +--ro distance?   uint8
+--ro route-path
    +--ro state
    +--ro type?         ipi-ospfv3-
types:ospfv3_path_type_t
    +--ro code?        string
    +--ro discard-connection?  empty
    +--ro cost?        uint32
    +--ro type-2-cost?  uint32
    +--ro path-flags?  ipi-ospfv3-
types:ospfv3_path_flags_t

rpcs:
  +---x ospfv3-terminal-debug-ospf-all-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
  +---x ospfv3-terminal-debug-ospf-all-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
  +---x ospfv3-terminal-debug-bfd-on {feature-list:HAVE_BFD}?
  +---x ospfv3-terminal-debug-bfd-off {feature-list:HAVE_BFD}?
  +---x ospfv3-terminal-debug-retransmission-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
  +---x ospfv3-terminal-debug-retransmission-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
  +---x ospfv3-terminal-debug-dist-ls-on {feature-list:HAVE_BGP_LS}?

```

```
+---x ospfv3-terminal-debug-dist-ls-off {feature-list:HAVE_BGP_LS}?
+---x ospfv3-terminal-debug-events-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
| +---w input
|   +---w events      ipi-ospfv3-types:ospfv3_debug_event_t
+---x ospfv3-terminal-debug-events-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
| +---w input
|   +---w events      ipi-ospfv3-types:ospfv3_debug_event_t
+---x ospfv3-terminal-debug-ifsm-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
| +---w input
|   +---w ifsm        ipi-ospfv3-types:ospfv3_debug_ifsm_t
+---x ospfv3-terminal-debug-ifsm-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
| +---w input
|   +---w ifsm        ipi-ospfv3-types:ospfv3_debug_ifsm_t
+---x ospfv3-terminal-debug-lsa-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
| +---w input
|   +---w lsa         ipi-ospfv3-types:ospfv3_debug_lsa_t
+---x ospfv3-terminal-debug-lsa-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
| +---w input
|   +---w lsa         ipi-ospfv3-types:ospfv3_debug_lsa_t
+---x ospfv3-terminal-debug-nfsm-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
| +---w input
|   +---w nfsm        ipi-ospfv3-types:ospfv3_debug_nfsm_t
+---x ospfv3-terminal-debug-nfsm-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
| +---w input
|   +---w nfsm        ipi-ospfv3-types:ospfv3_debug_nfsm_t
+---x ospfv3-terminal-debug-nsm-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
| +---w input
|   +---w nsm         ipi-ospfv3-types:ospfv3_debug_nsm_t
+---x ospfv3-terminal-debug-nsm-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
| +---w input
|   +---w nsm         ipi-ospfv3-types:ospfv3_debug_nsm_t
+---x ospfv3-terminal-debug-packet-all-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
| +---w input
|   +---w all         ipi-ospfv3-types:ospfv3_debug_packet_options_t
+---x ospfv3-terminal-debug-packet-all-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
| +---w input
|   +---w all         ipi-ospfv3-types:ospfv3_debug_packet_options_t
+---x ospfv3-terminal-debug-packet-hello-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
| +---w input
|   +---w hello       ipi-ospfv3-types:ospfv3_debug_packet_options_t
```

```

    +---x ospfv3-terminal-debug-packet-hello-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
    | +---w input
    |   +---w hello      ipi-ospfv3-types:ospfv3_debug_packet_options_t
    +---x ospfv3-terminal-debug-packet-dd-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
    | +---w input
    |   +---w dd        ipi-ospfv3-types:ospfv3_debug_packet_options_t
    +---x ospfv3-terminal-debug-packet-dd-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
    | +---w input
    |   +---w dd        ipi-ospfv3-types:ospfv3_debug_packet_options_t
    +---x ospfv3-terminal-debug-packet-ls-request-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
    | +---w input
    |   +---w ls-request  ipi-ospfv3-types:ospfv3_debug_packet_options_t
    +---x ospfv3-terminal-debug-packet-ls-request-off {feature-
list:HAVE_OSPF6D,feature-list:HAVE_IPV6}?
    | +---w input
    |   +---w ls-request  ipi-ospfv3-types:ospfv3_debug_packet_options_t
    +---x ospfv3-terminal-debug-packet-ls-update-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
    | +---w input
    |   +---w ls-update   ipi-ospfv3-types:ospfv3_debug_packet_options_t
    +---x ospfv3-terminal-debug-packet-ls-update-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
    | +---w input
    |   +---w ls-update   ipi-ospfv3-types:ospfv3_debug_packet_options_t
    +---x ospfv3-terminal-debug-packet-ls-ack-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
    | +---w input
    |   +---w ls-ack      ipi-ospfv3-types:ospfv3_debug_packet_options_t
    +---x ospfv3-terminal-debug-packet-ls-ack-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
    | +---w input
    |   +---w ls-ack      ipi-ospfv3-types:ospfv3_debug_packet_options_t
    +---x ospfv3-terminal-debug-rib-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
    | +---w input
    |   +---w rib         ipi-ospfv3-types:ospfv3_debug_rib_t
    +---x ospfv3-terminal-debug-rib-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
    | +---w input
    |   +---w rib         ipi-ospfv3-types:ospfv3_debug_rib_t
    +---x ospfv3-terminal-debug-route-on {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
    | +---w input
    |   +---w route       ipi-ospfv3-types:ospfv3_debug_route_t
    +---x ospfv3-terminal-debug-route-off {feature-list:HAVE_OSPF6D,feature-
list:HAVE_IPV6}?
    | +---w input
    |   +---w route       ipi-ospfv3-types:ospfv3_debug_route_t
    +---x ospfv3-clear-process {feature-list:HAVE_OSPF6D,feature-list:HAVE_IPV6}?

```

```

| +---w input
|   +---w process-id    string
+---x ospfv3-clear-process-all {feature-list:HAVE_OSPF6D,feature-list:HAVE_IPV6}?
+---x ospfv3-graceful-restart {feature-list:HAVE_OSPF6D,feature-list:HAVE_IPV6}?
| +---w input
|   +---w grace-period  uint16
+---x ospfv3-snmp-restart {feature-list:HAVE_SNMP}?

```

notifications:

```

+---n ospfv3-originate-lsa
| +--ro severity?      cml-data-types:cml_notif_severity_t
| +--ro eventClass?   cml-data-types:cml_notif_class_t
| +--ro ospfv3-id?    ipi-ospfv3-types:ospfv3_string_t
| +--ro router-id?    inet:ipv4-address
| +--ro lsdB-area-id? inet:ipv4-address
| +--ro lsdB-type?    uint32
| +--ro lsdB-id?      uint32
| +--ro lsdB-router-id? inet:ipv4-address
+---n ospfv3-tx-retransmit
| +--ro severity?      cml-data-types:cml_notif_severity_t
| +--ro eventClass?   cml-data-types:cml_notif_class_t
| +--ro ospfv3-id?    ipi-ospfv3-types:ospfv3_string_t
| +--ro router-id?    inet:ipv4-address
| +--ro if-index?     int32
| +--ro instance-id?  uint8
| +--ro neighbor-router-id? inet:ipv4-address
| +--ro packet-type?  ipi-ospfv3-types:ospfv3_packet_type_t
| +--ro lsdB-type?    uint32
| +--ro lsdB-lsid?    uint32
| +--ro lsdB-router-id? inet:ipv4-address
+---n ospfv3-neighbor-state-change
| +--ro severity?      cml-data-types:cml_notif_severity_t
| +--ro eventClass?   cml-data-types:cml_notif_class_t
| +--ro ospfv3-id?    ipi-ospfv3-types:ospfv3_string_t
| +--ro router-id?    inet:ipv4-address
| +--ro if-index?     int32
| +--ro instance-id?  uint8
| +--ro neighbor-router-id? inet:ipv4-address
| +--ro neighbor-state? ipi-ospfv3-types:ospfv3_neighbor_state_change_t
+---n ospfv3-virtual-link-config-error
| +--ro severity?      cml-data-types:cml_notif_severity_t
| +--ro eventClass?   cml-data-types:cml_notif_class_t
| +--ro remote-router-id? inet:ipv4-address
| +--ro area-id?      ipi-ospfv3-types:ospfv3_area_t
| +--ro ospfv3-id?    ipi-ospfv3-types:ospfv3_string_t
| +--ro router-id?    inet:ipv4-address
| +--ro instance-id?  uint8
| +--ro error-type?    ipi-ospfv3-types:ospfv3_config_error_type_t
| +--ro packet-type?  ipi-ospfv3-types:ospfv3_packet_type_t
+---n ospfv3-virtual-link-state-change

```

```
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro remote-router-id? inet:ipv4-address
| +--ro area-id?          ipi-ospfv3-types:ospfv3_area_t
| +--ro ospfv3-id?        ipi-ospfv3-types:ospfv3_string_t
| +--ro router-id?        inet:ipv4-address
| +--ro instance-id?      uint8
| +--ro virtual-link-state? ipi-ospfv3-types:ospfv3_interface_state_t
+---n ospfv3-virtual-link-neighbor-state-change
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro remote-router-id? inet:ipv4-address
| +--ro area-id?          ipi-ospfv3-types:ospfv3_area_t
| +--ro ospfv3-id?        ipi-ospfv3-types:ospfv3_string_t
| +--ro router-id?        inet:ipv4-address
| +--ro instance-id?      uint8
| +--ro neighbor-state?   ipi-ospfv3-types:ospfv3_interface_state_t
+---n ospfv3-virtual-link-rx-bad-packet
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro remote-router-id? inet:ipv4-address
| +--ro area-id?          ipi-ospfv3-types:ospfv3_area_t
| +--ro ospfv3-id?        ipi-ospfv3-types:ospfv3_string_t
| +--ro router-id?        inet:ipv4-address
| +--ro instance-id?      uint8
| +--ro packet-type?      ipi-ospfv3-types:ospfv3_packet_type_t
+---n ospfv3-virtual-link-tx-retransmit
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro remote-router-id? inet:ipv4-address
| +--ro area-id?          ipi-ospfv3-types:ospfv3_area_t
| +--ro ospfv3-id?        ipi-ospfv3-types:ospfv3_string_t
| +--ro router-id?        inet:ipv4-address
| +--ro instance-id?      uint8
| +--ro packet-type?      ipi-ospfv3-types:ospfv3_packet_type_t
| +--ro lsdB-type?        uint32
| +--ro lsdB-lsid?        uint32
| +--ro lsdB-router-id?   inet:ipv4-address
+---n ospfv3-interface-config-error
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro interface-name?   string
| +--ro router-id?        inet:ipv4-address
| +--ro interface-index?  uint32
| +--ro interface-instance-id? uint8
| +--ro error-type?       ipi-ospfv3-types:ospfv3_config_error_type_t
| +--ro packet-type?      ipi-ospfv3-types:ospfv3_packet_type_t
+---n ospfv3-interface-state-change
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
```



```

| +--ro interface-name?          string
| +--ro router-id?              inet:ipv4-address
| +--ro interface-index?       uint32
| +--ro interface-instance-id?  uint8
| +--ro interface-state?       ipi-ospfv3-types:ospfv3_interface_state_t
+---n ospfv3-interface-rx-bad-packet
  +--ro severity?              cml-data-types:cml_notif_severity_t
  +--ro eventClass?            cml-data-types:cml_notif_class_t
  +--ro interface-name?        string
  +--ro router-id?            inet:ipv4-address
  +--ro interface-index?       uint32
  +--ro interface-instance-id? uint8
  +--ro packet-src?            inet:ipv6-address
  +--ro packet-type?           ipi-ospfv3-types:ospfv3_packet_type_t

```

module: ipi-pbr

```

+--rw pbr
  +--rw config
  | +--rw enabled?  empty
  +--ro state
  | +--ro enabled?  empty
  +--rw interfaces
  | +--rw interface* [name]
  | | +--rw name      -> ../config/name
  | | +--rw config
  | | | +--rw name?          -> /ipi-interface:interfaces/interface/name
  | | | +--rw route-map-name? string
  | | | +--rw route-map-v6-name? string {feature-list:HAVE_IPV6}?
  | | +--ro state
  | | | +--ro name?          -> /ipi-interface:interfaces/interface/name
  | | | +--ro route-map-name? string
  | | | +--ro route-map-v6-name? string {feature-list:HAVE_IPV6}?
  rpcs:
  +---x clear-route-map-pbr-statistics {feature-list:HAVE_PBR}?
  | +---w input
  | | +---w route-map-name  string

```

module: ipi-pcep

```

+--rw pcep

```

```
+--rw entities
| +--rw entity* [entity-id]
|   +--rw entity-id      -> ../config/entity-id
|   +--rw config
|     | +--rw entity-id?          uint32
|     | +--rw keep-alive-interval? uint8
|     | +--rw dead-interval?      uint8
|     | +--rw request-timeout?    uint16
|     | +--rw tolerance-keepalive? uint32
|     | +--rw tolerance-dead-interval? uint32
|     | +--rw cool-off-timeout?   int32
|     | +--rw source-address?     inet:ip-address
|     | +--rw recovery-policy?    ipi-pcep-types:pcep_dlg_recovery_type_t
|   +--ro state
|     | +--ro entity-id?          uint32
|     | +--ro keep-alive-interval? uint8
|     | +--ro dead-interval?      uint8
|     | +--ro request-timeout?    uint16
|     | +--ro tolerance-keepalive? uint32
|     | +--ro tolerance-dead-interval? uint32
|     | +--ro cool-off-timeout?   int32
|     | +--ro source-address?     inet:ip-address
|     | +--ro recovery-policy?    ipi-pcep-types:pcep_dlg_recovery_type_t
|     | +--ro role?              ipi-pcep-types:pcep_role_t
|     | +--ro connect-timer?      uint32
|     | +--ro connect-max-retry?  uint32
|     | +--ro init-backoff-timer? uint32
|     | +--ro max-backoff-timer?  uint32
|     | +--ro open-wait-timer?    uint32
|     | +--ro keep-wait-timer?    uint32
|   +--rw capability
|     | +--rw config
|     |   | +--rw pce-instantiate? empty
|     |   | +--rw segment-routing? empty {feature-list:HAVE_PCEP_SR}?
|     |   | +--rw segment-routing-v6? empty {feature-list:HAVE_PCEP_SRV6}?
|     |   +--ro state
|     |     | +--ro pce-instantiate? empty
|     |     | +--ro segment-routing? empty {feature-list:HAVE_PCEP_SR}?
|     |     | +--ro segment-routing-v6? empty {feature-list:HAVE_PCEP_SRV6}?
|   +--rw stateful
|     | +--rw config
|     |   | +--rw redelegation-timeout? uint32
|     |   | +--rw lsp-state-timeout? ipi-pcep-types:pcep_lsp_state_timeout_t
|     |   +--ro state
|     |     | +--ro redelegation-timeout? uint32
|     |     | +--ro lsp-state-timeout? ipi-pcep-types:pcep_lsp_state_timeout_t
|   +--rw flap-limit
|     | +--rw config!
|     |   | +--rw flap-count      int32
|     |   | +--rw flap-interval  int32
```

```

|     |   +---ro state
|     |     +---ro flap-count          int32
|     |     +---ro flap-interval       int32
|   +---rw update-limit
|     |   +---rw config!
|     |     |   +---rw count          int32
|     |     |   +---rw interval       int32
|     |     +---ro state
|     |       +---ro count          int32
|     |       +---ro interval       int32
|   +---rw lsp-database
|     |   +---ro ingress-tunnel* [plsp-id]
|     |     +---ro plsp-id            -> ../state/plsp-id
|     |     +---ro lsp* [lsp-id]
|     |       |   +---ro lsp-id        -> ../state/lsp-id
|     |       |   +---ro state
|     |       |     |   +---ro lsp-id?      uint32
|     |       |     |   +---ro operational-state? ipi-pcep-types:pcep_lsp_oper_status_t
|     |       |     |   +---ro last-lsp-error? ipi-pcep-types:pcep_lsp_error_t
|     |       |     +---ro binding-label-status
|     |       |       +---ro state
|     |       |         +---ro label-value?    uint32
|     |       |         +---ro allocation-mode? ipi-pcep-
types:pcep_binding_alloc_mode_t
|     |       +---ro state
|     |         |   +---ro plsp-id?          uint32
|     |         |   +---ro tunnel-id?        uint32
|     |         |   +---ro candidate-path-id? uint32 {feature-list:HAVE_PCEP_SR}?
|     |         |   +---ro source?           inet:ipv4-address
|     |         |   +---ro destination?      inet:ipv4-address
|     |         |   +---ro extended-tunnel-id? inet:ipv4-address
|     |         |   +---ro admin-state?      boolean
|     |         |   +---ro symbolic-name?    string
|     |         |   +---ro tunnel-name?      string
|     |         |   +---ro setup-type?       ipi-pcep-types:pcep_lsp_setup_type_t
|     |         |   +---ro local-policy-active? empty
|     |         |   +---ro request-id?       uint32
|     |         |   +---ro request-state?    ipi-pcep-
types:pcep_tunnel_request_state_t
|     |         |   +---ro request-flags?    ipi-pcep-
types:pcep_tunnel_request_flags_t
|     |         |     +---ro error-flags?    ipi-pcep-types:pcep_tunnel_err_flags_t
|     |         |     +---ro recent-lsp-id?  uint32 {feature-list:HAVE_PCEP_RSVP}?
|     |         |     +---ro pending-updates? empty
|     |         |   +---ro last-event?       ipi-pcep-types:pcep_tunnel_recent_event_t
|     |         +---ro pce-delegation
|     |           |   +---ro state
|     |           |     +---ro enabled?      empty
|     |           |     +---ro address?      inet:ipv4-address
|     |           |     +---ro stateful-request-parameter-id? uint32
|     |           +---ro initiation

```

```
| | | +---ro state
| | | | +---ro enabled? empty
| | | | +---ro address? inet:ipv4-address
| +---rw peers
| | +---rw peer* [address]
| | | +---rw address -> ../config/address
| | | +---rw config
| | | | +---rw address? ipi-pcep-types:pcep_ip_addr_t
| | | | +---rw delegation-preference? uint32
| | | | +---rw authentication-key? string {feature-list:HAVE_TCP_MD5SIG}?
| | +---ro state
| | | +---ro address? ipi-pcep-types:pcep_ip_addr_t
| | | +---ro delegation-preference? uint32
| | | +---ro authentication-key? string {feature-list:HAVE_TCP_MD5SIG}?
| | | +---ro role? ipi-pcep-types:pcep_role_t
| | | +---ro session-exists? empty
| | | +---ro session-up-time? yang:timestamp
| | | +---ro session-fail-time? yang:timestamp
| | | +---ro counters
| | | | +---ro stateful
| | | | | +---ro tx-path-reports? yang:counter32
| | | | | +---ro tx-reports? yang:counter32
| | | | | +---ro rx-path-updates? yang:counter32
| | | | | +---ro rx-updates? yang:counter32
| | | | | +---ro rx-pc-initiate? yang:counter32
| | | | | +---ro rx-lsp-initiate? yang:counter32
| | | | +---ro session-setup-fail? yang:counter32
| | | | +---ro tx-open-message? yang:counter32
| | | | +---ro tx-keep-alive? yang:counter32
| | | | +---ro tx-pc-notifications? yang:counter32
| | | | +---ro tx-path-request-errors? yang:counter32
| | | | +---ro tx-path-request? yang:counter32
| | | | +---ro tx-request? yang:counter32
| | | | +---ro tx-request-for-pending-reply? yang:counter32
| | | | +---ro tx-request-for-error-received? yang:counter32
| | | | +---ro tx-request-for-nopath-receive? yang:counter32
| | | | +---ro tx-request-for-cancel-receive? yang:counter32
| | | | +---ro tx-request-for-ero-received? yang:counter32
| | | | +---ro tx-request-timed-out? yang:counter32
| | | | +---ro tx-request-sent-cancel-sent? yang:counter32
| | | | +---ro tx-request-sent-closed? yang:counter32
| | | | +---ro rx-open-message? yang:counter32
| | | | +---ro rx-keep-alive? yang:counter32
| | | | +---ro rx-pc-notifications? yang:counter32
| | | | +---ro rx-path-request-errors? yang:counter32
| | | | +---ro rx-path-reply? yang:counter32
| | | | +---ro rx-unknown? yang:counter32
| | | | +---ro rx-corrupt? yang:counter32
| | +---ro capability
| | | +---ro state
```

```

|         |         +---ro pce-instantiate?    empty
|         |         +---ro segment-routing?    empty {feature-list:HAVE_PCEP_SR}?
|         |         +---ro lsp-update?        empty
|         +---ro session
|             +---ro state
|                 +---ro initiator?            ipi-pcep-types:pcep_initiator_t
|                 +---ro state?                ipi-pcep-
types:pcep_session_state_t
|             +---ro state-changes?            uint32
|             +---ro state-last-change?        yang:timestamp
|             +---ro creation-time?            yang:timestamp
|             +---ro connect-retry?            yang:counter32
|             +---ro open-retry?                uint8
|             +---ro local-id?                  uint8
|             +---ro remote-id?                 uint8
|             +---ro peer-overloaded?           boolean
|             +---ro peer-overload-time?        uint32
|             +---ro keepalive-timer?           uint8
|             +---ro peer-keepalive-timer?      uint8
|             +---ro dead-timer?                uint8
|             +---ro peer-dead-timer?           uint8
|             +---ro keepalive-hold-timer-remain? uint8
|             +---ro max-unknown-message?       uint32
+---rw init-lsp-limit
| +---rw config!
| | +---rw lsp-limit    uint32
| +---ro state
|     +---ro lsp-limit    uint32
+---rw debug
| +---rw config
| | +---rw options?    ipi-pcep-types:pcep_debug_t
| +---ro state
|     +---ro options?            ipi-pcep-types:pcep_debug_t
|     +---ro terminal-debug-status? ipi-pcep-types:pcep_debug_t
+---rw srv6-spirent-comp
    +---rw config
    | +---rw srv6-spirent-comp?    empty
    +---ro state
    | +---ro srv6-spirent-comp?    empty

rpcs:
+---x clear-pcep-peer-all {feature-list:HAVE_PCEP}?
+---x clear-pcep-peer {feature-list:HAVE_PCEP}?
| +---w input
|     +---w address    inet:ip-address
+---x clear-pcep-statistics {feature-list:HAVE_PCEP}?
+---x debug-pcep-all {feature-list:HAVE_PCEP}?
+---x pcep-terminal-debug-on {feature-list:HAVE_PCEP}?
| +---w input
|     +---w terminal-debug-options    ipi-pcep-types:pcep_debug_t
+---x pcep-terminal-debug-off {feature-list:HAVE_PCEP}?

```

```

| +---w input
|   +---w terminal-debug-options   ipi-pcep-types:pcep_debug_t
+---x clear-pcep-requests {feature-list:HAVE_PCEP}?
    +---w input
        +---w tunnel-id   string

```

notifications:

```

+---n pcep-session-up
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro address?           ipi-pcep-types:pcep_ip_addr_t
| +--ro entity-id?         uint32
| +--ro initiator?         ipi-pcep-types:pcep_initiator_t
| +--ro state-last-change? yang:timestamp
| +--ro state?             ipi-pcep-types:pcep_session_state_t
+---n pcep-session-down
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro address?           ipi-pcep-types:pcep_ip_addr_t
| +--ro entity-id?         uint32
| +--ro initiator?         ipi-pcep-types:pcep_initiator_t
| +--ro state-last-change? yang:timestamp
| +--ro state?             ipi-pcep-types:pcep_session_state_t
+---n pcep-session-peer-overload
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro address?           ipi-pcep-types:pcep_ip_addr_t
| +--ro entity-id?         uint32
| +--ro initiator?         ipi-pcep-types:pcep_initiator_t
| +--ro peer-overloaded?   boolean
| +--ro peer-overload-time? uint32
+---n pcep-session-peer-overload-clear
    +--ro severity?           cml-data-types:cml_notif_severity_t
    +--ro eventClass?        cml-data-types:cml_notif_class_t
    +--ro address?           ipi-pcep-types:pcep_ip_addr_t
    +--ro entity-id?         uint32
    +--ro initiator?         ipi-pcep-types:pcep_initiator_t
    +--ro peer-overloaded?   boolean

```

module: ipi-pim

```

+--rw pim
  +--rw debug {feature-list:HAVE_BFD}?
  | +--rw config
  | | +--rw bfd? empty
  | +--ro state
  |   +--ro bfd? empty
  |   +--ro terminal-debug-status? cml-data-types:cml_on_off_t
+--rw ipv4
  +--rw instances
  | +--rw instance* [vrf-name]
  | | +--rw vrf-name -> ../config/vrf-name
  | | +--rw config
  | | | +--rw vrf-name? -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
  | | | +--rw router-id? inet:ipv4-address {feature-
list:HAVE_PIM_SM}?
  | | | +--rw join-prune-interval? uint16 {feature-list:HAVE_PIM_SM}?
  | | | +--rw ecmp-bundle* string {feature-
list:HAVE_PIM_ECMP_REDIRECT}?
  | | | +--rw enable-bfd-all-interfaces? empty {feature-list:HAVE_BFD}?
  | | | +--ro state
  | | | +--ro vrf-name? -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
  | | | +--ro router-id? inet:ipv4-address {feature-
list:HAVE_PIM_SM}?
  | | | +--ro join-prune-interval? uint16 {feature-list:HAVE_PIM_SM}?
  | | | +--ro ecmp-bundle* string {feature-
list:HAVE_PIM_ECMP_REDIRECT}?
  | | | +--ro enable-bfd-all-interfaces? empty {feature-list:HAVE_BFD}?
  | | | +--ro counters
  | | | | +--ro joins-sent? yang:counter64
  | | | | +--ro joins-received? yang:counter64
  | | | +--ro rp-sets
  | | | | +--ro rp-set* [group-address]
  | | | | | +--ro group-address -> ../state/group-address
  | | | | | +--ro state
  | | | | | | +--ro group-address? cml-data-types:cml_ipv4_addr_prefix_t
  | | | | | | +--ro fragment-tag? uint16
  | | | | | | +--ro number-of-rp? uint32
  | | | | | | +--ro expiration-time? string
  | | | +--ro rps
  | | | | +--ro rp* [rp-address]
  | | | | | +--ro rp-address -> ../state/rp-address
  | | | | | +--ro state
  | | | | | | +--ro rp-address? inet:ipv4-address
  | | | | | | +--ro from? inet:ipv4-address

```

```

| | | | +--ro mode? ipi-pim-ipv4-
types:pim_ipv4_rp_mode_t
| | | | +--ro type? ipi-pim-ipv4-
types:pim_ipv4_rp_type_t
| | | | +--ro priority? uint8
| | | | +--ro hold-time? uint16
| | | | +--ro up-time? string
| | | | +--ro expiration-time? string
| | | +--ro next-hop-destinations
| | | | +--ro next-hop-destination* [destination-address]
| | | | +--ro destination-address -> ../state/destination-address
| | | | +--ro state
| | | | | +--ro destination-address? inet:ipv4-address
| | | | | +--ro destination-type? ipi-pim-ipv4-
types:pim_ipv4_next_hop_flags_t
| | | | | +--ro next-hop-count? uint32
| | | | | +--ro preference? uint16
| | | | | +--ro metric? uint32
| | | | | +--ro reference-count? uint32
| | | | | +--ro route-type? ipi-pim-ipv4-
types:pim_ipv4_route_type_t
| | | | | +--ro route-sub-type? ipi-pim-ipv4-
types:pim_ipv4_route_sub_type_t
| | | | | +--ro subaddress-family-identifier? uint32
| | | | | +--ro interface-index? uint16
| | | | | +--ro next-hops
| | | | | +--ro next-hop* [ipv4-address]
| | | | | +--ro ipv4-address -> ../state/ipv4-address
| | | | | +--ro state
| | | | | +--ro ipv4-address? inet:ipv4-address
| | | | | +--ro type? ipi-pim-ipv4-
types:pim_ipv4_next_hop_type_t
| | | | | +--ro recursive-active-next-hop? uint8
| | | | | +--ro recursive-type? ipi-pim-ipv4-
types:pim_ipv4_next_hop_type_t
| | | | | +--ro recursive-interface-id? uint8
| | | | | +--ro interface-index? uint16
| | | | | +--ro bfd-interface-index? uint16
| | | | | +--ro interface-name? string
| | | +--rw register-packet {feature-list:HAVE_PIM_SM}?
| | | | +--rw config
| | | | | +--rw register-reachability-check? cml-data-
types:cml_enable_disable_t
| | | | | +--rw rate-limit? uint16
| | | | | +--rw suppress-interval? uint16
| | | | | +--rw keep-alive-interval? uint16
| | | | | +--rw source-address? ipi-pim-ipv4-
types:pim_ipv4_reg_source_t
| | | | | +--rw accept-register? string
| | | | | +--ro state
| | | | | +--ro register-reachability-check? cml-data-
types:cml_enable_disable_t
| | | | | +--ro rate-limit? uint16

```



```

| | | | +---ro suppress-interval?      uint16
| | | | +---ro keep-alive-interval?    uint16
| | | | +---ro source-address?         ipi-pim-ipv4-
types:pim_ipv4_reg_source_t
| | | | +---ro accept-register?        string
| | | | +---ro counters
| | | | | +---ro register-packet-received? yang:counter64
| | | | | +---ro register-null-received?  yang:counter64
| | | | | +---ro register-stop-sent?     yang:counter64
| | | | | +---ro register-stop-received? yang:counter64
| | | +---rw interop
| | | | +---rw config
| | | | | +---rw ignore-rp-set-priority?  empty {feature-list:HAVE_PIM_SM}?
| | | | | +---rw cisco-bsr-interop-enable? empty {feature-list:HAVE_PIM_SM}?
| | | | +---ro state
| | | | | +---ro ignore-rp-set-priority?  empty {feature-list:HAVE_PIM_SM}?
| | | | | +---ro cisco-bsr-interop-enable? empty {feature-list:HAVE_PIM_SM}?
| | | | +---rw register-packet
| | | | | +---rw config!
| | | | | +---rw cisco-register-checksum-enable  empty {feature-
list:HAVE_PIM_SM}?
| | | | | +---rw access-control-list?         string {feature-
list:HAVE_PIM_SM}?
| | | | +---ro state
| | | | | +---ro cisco-register-checksum-enable  empty {feature-
list:HAVE_PIM_SM}?
| | | | | +---ro access-control-list?         string {feature-
list:HAVE_PIM_SM}?
| | | | +---rw spt-switch
| | | | | +---rw config!
| | | | | | +---rw enable                  empty {feature-list:HAVE_PIM_SM}?
| | | | | | +---rw access-control-list?    string {feature-list:HAVE_PIM_SM}?
| | | | | +---ro state
| | | | | | +---ro enable                  empty {feature-list:HAVE_PIM_SM}?
| | | | | | +---ro access-control-list?    string {feature-list:HAVE_PIM_SM}?
| | | | +---rw ssm {feature-list:HAVE_PIM_SSM}?
| | | | | +---rw config
| | | | | | +---rw range-policy?          ipi-pim-ipv4-
types:pim_ipv4_ssm_range_policy_type_t
| | | | | +---ro state
| | | | | | +---ro range-policy?          ipi-pim-ipv4-
types:pim_ipv4_ssm_range_policy_type_t
| | | | +---rw anycast-rps {feature-list:HAVE_PIM_SM}?
| | | | | +---rw anycast-rp* [anycast-rp-address member-rp-address]
| | | | | +---rw anycast-rp-address      -> ../config/anycast-rp-address
| | | | | +---rw member-rp-address       -> ../config/member-rp-address
| | | | | +---rw config
| | | | | | +---rw anycast-rp-address?    inet:ipv4-address
| | | | | | +---rw member-rp-address?    inet:ipv4-address
| | | | | +---ro state
| | | | | | +---ro anycast-rp-address?    inet:ipv4-address
| | | | | | +---ro member-rp-address?    inet:ipv4-address

```

```

| |      +---rw rendezvous-point
| |      | +---rw static-rps
| |      | | +---rw static-rps-default
| |      | |   +---rw static-rp-default* [rp-address]
| |      | |     +---rw rp-address    -> ../config/rp-address
| |      | |     +---rw config
| |      | |       | +---rw rp-address?          inet:ipv4-address
| |      | |       | +---rw access-control-list?  string
| |      | |       | +---rw override-dynamically-learned-rp? empty
| |      | |       +---ro state
| |      | |         +---ro rp-address?          inet:ipv4-address
| |      | |         +---ro access-control-list?  string
| |      | |         +---ro override-dynamically-learned-rp? empty
| |      | +---rw bootstrap-router
| |      | | +---rw bsr-candidate
| |      | |   +---rw config
| |      | |     | +---rw interface-name?      -> /ipi-interface:interfaces/
interface/name
| |      | |     | +---rw hash-mask-length?    uint8
| |      | |     | +---rw priority?           uint8
| |      | |     +---ro state
| |      | |       +---ro interface-name?      -> /ipi-interface:interfaces/
interface/name
| |      | |       +---ro hash-mask-length?    uint8
| |      | |       +---ro priority?           uint8
| |      | +---rw rp-candidates
| |      | |   +---rw rp-candidate* [interface-name]
| |      | |     +---rw interface-name    -> ../config/interface-name
| |      | |     +---rw config
| |      | |       | +---rw interface-name?    -> /ipi-interface:interfaces/
interface/name
| |      | |       | +---rw access-control-list?  string
| |      | |       | +---rw advertisement-interval? uint16
| |      | |       | +---rw priority?           uint8
| |      | |       +---ro state
| |      | |         +---ro interface-name?    -> /ipi-interface:interfaces/
interface/name
| |      | |         +---ro access-control-list?  string
| |      | |         +---ro advertisement-interval? uint16
| |      | |         +---ro priority?           uint8
| |      +---rw msdp {feature-list:HAVE_PIM_MSDP}?
| |      | +---rw config
| |      | | +---rw originator-id?    string
| |      | +---ro state
| |      | | +---ro originator-id?      string
| |      | | +---ro source-active-entries-entries-count? uint32
| |      +---rw source-active-entries
| |      | | +---rw source-active-entry* [source-address group-address]
| |      | |   +---rw source-address    -> ../config/source-address
| |      | |   +---rw group-address     -> ../config/group-address
| |      | |   +---rw config

```

```

| | | | | +--rw source-address? inet:ipv4-address
| | | | | +--rw group-address? inet:ipv4-address
| | | | | +--rw rp-address inet:ipv4-address
| | | | | +--ro state
| | | | | +--ro source-address? inet:ipv4-address
| | | | | +--ro group-address? inet:ipv4-address
| | | | | +--ro rp-address inet:ipv4-address
| | | | | +--ro static-configured? empty
| | | | | +--ro uptime? string
| | | | | +--ro expire-time? uint32
| | | | | +--ro stopped? empty
| | | | | +--ro sa-rp-forward-count? yang:counter64
| | | | | +--ro reverse-path-forwarding-peer? inet:ipv4-address
| | | | +--rw peers
| | | | | +--rw peer* [address]
| | | | | +--rw address -> ../config/address
| | | | | +--rw config
| | | | | | +--rw address? inet:ipv4-address
| | | | | | +--rw source-address? ipi-pim-ipv4-
types:pim_ipv4_reg_source_t
| | | | | +--rw mesh-group? string
| | | | | +--rw default-peer? empty
| | | | | +--rw prefix-list? ipi-pim-ipv4-
types:pim_ipv4_msdp_peer_acl_t
| | | | | +--ro state
| | | | | | +--ro counters
| | | | | | | +--ro keepalives-sent? yang:counter64
| | | | | | | +--ro keepalives-received? yang:counter64
| | | | | | | +--ro connection-retries? yang:counter64
| | | | | | +--ro address? inet:ipv4-address
| | | | | | +--ro source-address? ipi-pim-ipv4-
types:pim_ipv4_reg_source_t
| | | | | +--ro mesh-group? string
| | | | | +--ro default-peer? empty
| | | | | +--ro prefix-list? ipi-pim-ipv4-
types:pim_ipv4_msdp_peer_acl_t
| | | | | +--ro peer-state? ipi-pim-ipv4-
types:pim_ipv4_msdp_peer_state_t
| | | | | +--ro peer-role? ipi-pim-ipv4-
types:pim_ipv4_msdp_peer_role_t
| | | | | +--rw authentication
| | | | | +--rw config
| | | | | | +--rw password? string {feature-list:HAVE_TCP_MD5SIG}?
| | | | | +--ro state
| | | | | | +--ro password? string {feature-list:HAVE_TCP_MD5SIG}?
| | | +--rw debug
| | | | +--rw config
| | | | | +--rw options? ipi-pim-ipv4-types:pim_ipv4_debug_t
| | | | +--ro state
| | | | | +--ro options? ipi-pim-ipv4-types:pim_ipv4_debug_t
| | | | | +--ro terminal-debug-status? ipi-pim-ipv4-types:pim_ipv4_debug_t
| | | +--ro multicast-route-table

```

```

| |      +---ro state
| |      | +---ro counters
| |      |   +---ro xxrp-entries?      yang:counter32
| |      |   +---ro g-prefix-entries?  yang:counter32
| |      |   +---ro xg-entries?        yang:counter32
| |      |   +---ro sg-entries?        yang:counter32
| |      |   +---ro sg-rpt-entries?    yang:counter32
| |      |   +---ro fcr-entries?      yang:counter32
| |      +---ro multicast-routes
| |          +---ro multicast-route* [source-address group-address type]
| |          +---ro source-address      -> ../state/source-address
| |          +---ro group-address       -> ../state/group-address
| |          +---ro type                 -> ../state/type
| |          +---ro state
| |              +---ro source-address?  inet:ipv4-address
| |              +---ro group-address?   inet:ipv4-address
| |              +---ro mode?            ipi-pim-ipv4-
types:pim_ipv4_multicast_route_mode_t
| |              +---ro type?            ipi-pim-ipv4-
types:pim_ipv4_multicast_route_type_t
| |              +---ro uptime?          string
| |              +---ro next-hop-address? inet:ipv4-address
| |              +---ro next-hop-interface-name? string
| |              +---ro last-rendezvous-point? inet:ipv4-address
| |              +---ro spt-switch?      empty
| |              +---ro local-olist*     string
| |              +---ro joined-olist*    string
| |              +---ro inherited-olist* string
| |              +---ro pruned-olist*    string
| |          +---ro upstream-xxrp
| |              +---ro state
| |                  +---ro route-state? ipi-pim-ipv4-
types:pim_ipv4_multicast_route_upstream_state_t
| |                  +---ro join-prune-timer? uint32
| |                  +---ro last-rpf-neighbor-address? inet:ipv4-address
| |                  +---ro last-rpf-next-hop-address? inet:ipv4-address
| |                  +---ro macro-state?     ipi-pim-ipv4-
types:pim_ipv4_multicast_route_upstream_macro_state_t {feature-list:HAVE_PIM_SM}?
| |          +---ro upstream-xg
| |              +---ro state
| |                  +---ro route-state? ipi-pim-ipv4-
types:pim_ipv4_multicast_route_upstream_state_t
| |                  +---ro join-prune-timer? uint32
| |                  +---ro last-rpf-neighbor-address? inet:ipv4-address
| |                  +---ro macro-state?     ipi-pim-ipv4-
types:pim_ipv4_multicast_route_upstream_macro_state_t {feature-list:HAVE_PIM_SM}?
| |          +---ro upstream-sg
| |              +---ro state
| |                  +---ro route-state? ipi-pim-ipv4-
types:pim_ipv4_multicast_route_upstream_state_t
| |                  +---ro join-prune-timer? uint32
| |                  +---ro last-rpf-neighbor-address? inet:ipv4-address

```

```

| | | | | +---ro keep-alive-timer? uint32
| | | | | +---ro spt-switch? empty
| | | | | +---ro macro-state? ipi-pim-ipv4-
types:pim_ipv4_multicast_route_upstream_macro_state_t {feature-list:HAVE_PIM_SM}?
| | | | | +---ro upstream-sg-rpt
| | | | | +---ro state
| | | | | +---ro route-state? ipi-pim-ipv4-
types:pim_ipv4_multicast_route_upstream_sg_rpt_mode_t
| | | | | +---ro override-timer? uint32
| | | | | +---ro forwarding-cache-registers
| | | | | +---ro forwarding-cache-register* [address]
| | | | | +---ro address -> ../state/address
| | | | | +---ro state
| | | | | +---ro address? inet:ipv4-address
| | | | | +---ro keep-alive-timer? uint32
| | | | | +---ro inherited-olist* string
| | | | | +---ro downstream-interfaces
| | | | | +---ro downstream-interface* [interface-name]
| | | | | +---ro interface-name -> ../state/interface-name
| | | | | +---ro state
| | | | | | +---ro interface-name? string
| | | | | +---ro downstream-xg-sg
| | | | | | +---ro state
| | | | | | +---ro route-state? ipi-pim-ipv4-
types:pim_ipv4_multicast_route_downstream_state_t
| | | | | +---ro expiry-timer? uint32
| | | | | +---ro prune-pending-timer? uint32
| | | | | +---ro assert-state? ipi-pim-ipv4-
types:pim_ipv4_multicast_route_downstream_assert_state_t
| | | | | +---ro assert-timer? uint32
| | | | | +---ro winner-address? inet:ipv4-address
| | | | | +---ro metric? uint32
| | | | | +---ro preference? uint32
| | | | | +---ro rpt-bit? empty
| | | | | +---ro macro-state? ipi-pim-ipv4-
types:pim_ipv4_multicast_route_downstream_macro_state_t
| | | | | +---ro downstream-xxrp-sg-rpt
| | | | | +---ro state
| | | | | +---ro route-state? ipi-pim-ipv4-
types:pim_ipv4_multicast_route_downstream_state_t
| | | | | +---ro rpt-state? ipi-pim-ipv4-
types:pim_ipv4_multicast_route_downstream_rpt_state_t
| | | | | +---ro expiry-timer? uint32
| | | | | +---ro prune-pending-timer? uint32
| | | | | +---rw interfaces
| | | | | | +---rw interface* [name]
| | | | | | +---rw name -> ../config/name
| | | | | | +---rw config
| | | | | | +---rw name? -> /ipi-interface:interfaces/
interface/name
| | | | | | +---rw pim-mode? ipi-pim-ipv4-
types:pim_ipv4_mode_t

```

```

| | | +---rw bsr-border?                empty {feature-
list:HAVE_PIM_SM}?
| | | +---rw dr-priority?                uint32
| | | +---rw hello-interval?            uint16
| | | +---rw hello-holdtime?           uint16
| | | +---rw passive-enable?           empty
| | | +---rw exclude-generated-id?     empty {feature-
list:HAVE_PIM_SM}?
| | | +---rw unicast-bootstrap-router?  empty {feature-
list:HAVE_PIM_SM}?
| | | +---rw neighbor-access-control-list-filter?  string
| | | +---rw state-refresh-origination-interval?  uint16 {feature-
list:HAVE_PIM_DM}?
| | | +---rw ecmp-bundle?               string {feature-
list:HAVE_PIM_ECMP_REDIRECT}?
| | | +---rw propagation-delay?         uint16
| | | +---rw enable-bfd?                cml-data-
types:cml_enable_disable_t {feature-list:HAVE_BFD}?
| | | +---ro state
| | | +---ro name?                      -> /ipi-interface:interfaces/
interface/name
| | | +---ro pim-mode?                  ipi-pim-ipv4-
types:pim_ipv4_mode_t
| | | +---ro bsr-border?                empty {feature-
list:HAVE_PIM_SM}?
| | | +---ro dr-priority?                uint32
| | | +---ro hello-interval?            uint16
| | | +---ro hello-holdtime?           uint16
| | | +---ro passive-enable?           empty
| | | +---ro exclude-generated-id?     empty {feature-
list:HAVE_PIM_SM}?
| | | +---ro unicast-bootstrap-router?  empty {feature-
list:HAVE_PIM_SM}?
| | | +---ro neighbor-access-control-list-filter?  string
| | | +---ro state-refresh-origination-interval?  uint16 {feature-
list:HAVE_PIM_DM}?
| | | +---ro ecmp-bundle?               string {feature-
list:HAVE_PIM_ECMP_REDIRECT}?
| | | +---ro propagation-delay?         uint16
| | | +---ro enable-bfd?                cml-data-
types:cml_enable_disable_t {feature-list:HAVE_BFD}?
| | | +---ro next-hello?                string
| | | +---ro router-id?                  inet:ipv4-address
| | | +---ro local-id?                   uint32
| | | +---ro dr-address?                 inet:ipv4-address
| | | +---ro neighbors
| | | | +---ro neighbor* [address]
| | | | | +---ro address    -> ../state/address
| | | | | +---ro state
| | | | | | +---ro address?          inet:ipv4-address
| | | | | | +---ro designated-router?  empty
| | | | | | +---ro neighbor-established?  string
| | | | | | +---ro neighbor-expires?    string
| | | | | | +---ro secondary-address*   inet:ipv4-address

```

```

|         |         +---ro hello-holdtime?          uint16
|         |         +---ro lan-delay?              uint16
|         |         +---ro override-interval?      uint32
|         |         +---ro dr-priority?            uint32 {feature-list:HAVE_PIM_SM}?
|         |         +---ro generated-id?          uint32
|         |         +---ro router-id?              inet:ipv4-address
|         |         +---ro local-id?              uint32
|         |         +---ro tracking-support?       empty
|         |         +---ro ecmp-redirect-enabled?  empty {feature-
list:HAVE_PIM_ECMP_REDIRECT}?
|         |         +---rw pim-redundancy
|         |         +---rw vrrp {feature-list:HAVE_PIM_SM_VRRP_AWARE}?
|         |         +---rw config!
|         |         | +---rw virtual-router-id      uint8
|         |         | +---rw dr-priority            uint32
|         |         +---ro state
|         |         +---ro virtual-router-id       uint8
|         |         +---ro dr-priority             uint32
|         |         +---ro selected-dr-priority?   uint32
|         |         +---ro vrrp-master?           boolean
+---rw ipv6
+---rw instances
|   +---rw instance* [vrf-name]
|     +---rw vrf-name          -> ../config/vrf-name
|     +---rw config
|       | +---rw vrf-name?      -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
|       | +---rw router-id?    inet:ipv4-address {feature-
list:HAVE_PIM_SM}?
|       | +---rw join-prune-interval?  uint16 {feature-list:HAVE_PIM_SM}?
|       | +---rw ecmp-bundle*        string {feature-
list:HAVE_PIM_ECMP_REDIRECT}?
|       | +---rw enable-bfd-all-interfaces?  empty {feature-list:HAVE_BFD}?
|       | +---ro state
|       | +---ro vrf-name?          -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
|       | +---ro router-id?        inet:ipv4-address {feature-
list:HAVE_PIM_SM}?
|       | +---ro join-prune-interval?  uint16 {feature-list:HAVE_PIM_SM}?
|       | +---ro ecmp-bundle*        string {feature-
list:HAVE_PIM_ECMP_REDIRECT}?
|       | +---ro enable-bfd-all-interfaces?  empty {feature-list:HAVE_BFD}?
|       | +---ro counters
|       | | +---ro joins-sent?        yang:counter64
|       | | +---ro joins-received?    yang:counter64
|       | +---ro rp-sets
|       |   +---ro rp-set* [group-address]
|       |     +---ro group-address    -> ../state/group-address
|       |     +---ro state
|       |     | +---ro group-address?  cml-data-types:cml_ipv6_prefix_t
|       |     | +---ro fragment-tag?  uint16
|       |     | +---ro number-of-rp?  uint32

```

```

|         |         | +--ro expiration-time?  string
|         |         +--ro rps
|         |             +--ro rp* [rp-address]
|         |                 +--ro rp-address    -> ../state/rp-address
|         |                 +--ro state
|         |                     +--ro rp-address?      inet:ipv6-address
|         |                     +--ro from?           inet:ipv6-address
|         |                     +--ro mode?           ipi-pim-ipv6-
types:pim_ipv6_rp_mode_t
|         |         +--ro type?           ipi-pim-ipv6-
types:pim_ipv6_rp_type_t
|         |             +--ro priority?          uint8
|         |             +--ro hold-time?        uint16
|         |             +--ro up-time?         string
|         |             +--ro expiration-time?  string
|         +--ro next-hop-destinations
|         |     +--ro next-hop-destination* [destination-address]
|         |         +--ro destination-address  -> ../state/destination-address
|         |         +--ro state
|         |             +--ro destination-address?  inet:ipv6-address
|         |             +--ro destination-type?    ipi-pim-ipv6-
types:pim_ipv6_next_hop_flags_t
|         |         +--ro next-hop-count?      uint32
|         |         +--ro preference?         uint16
|         |         +--ro metric?            uint32
|         |         +--ro reference-count?    uint32
|         |         +--ro route-type?        ipi-pim-ipv6-
types:pim_ipv6_route_type_t
|         |         +--ro route-sub-type?     ipi-pim-ipv6-
types:pim_ipv6_route_sub_type_t
|         |             +--ro subaddress-familiy-identifrier?  uint32
|         |             +--ro interface-index?    uint16
|         |         +--ro next-hops
|         |             +--ro next-hop* [ipv6-address]
|         |                 +--ro ipv6-address    -> ../state/ipv6-address
|         |                 +--ro state
|         |                     +--ro ipv6-address?  inet:ipv6-address
|         |                     +--ro type?         ipi-pim-ipv6-
types:pim_ipv6_next_hop_type_t
|         |         +--ro recursive-active-next-hop?  uint8
|         |         +--ro recursive-type?           ipi-pim-ipv6-
types:pim_ipv6_next_hop_type_t
|         |             +--ro recursive-interface-id?  uint8
|         |             +--ro interface-index?        uint16
|         |             +--ro bfd-interface-index?    uint16
|         |             +--ro interface-name?        string
|         +--rw register-packet {feature-list:HAVE_PIM_SM}?
|         |     +--rw config
|         |         +--rw register-reachability-check?  cml-data-
types:cml_enable_disable_t
|         |         +--rw rate-limit?                  uint16
|         |         +--rw suppress-interval?          uint16

```



```

|      | | +---rw keep-alive-interval?      uint16
|      | | +---rw source-address?           ipi-pim-ipv6-
types:pim_ipv6_reg_source_t
|      | | +---rw accept-register?         string
|      | | +---ro state
|      | | +---ro register-reachability-check? cml-data-
types:cml_enable_disable_t
|      | | +---ro rate-limit?              uint16
|      | | +---ro suppress-interval?       uint16
|      | | +---ro keep-alive-interval?     uint16
|      | | +---ro source-address?         ipi-pim-ipv6-
types:pim_ipv6_reg_source_t
|      | | +---ro accept-register?         string
|      | | +---ro counters
|      | |     +---ro register-packet-received? yang:counter64
|      | |     +---ro register-null-received?  yang:counter64
|      | |     +---ro register-stop-sent?     yang:counter64
|      | |     +---ro register-stop-received? yang:counter64
|      | +---rw interop
|      | | +---rw config
|      | | | +---rw ignore-rp-set-priority?   empty {feature-list:HAVE_PIM_SM}?
|      | | | +---rw cisco-bsr-interop-enable? empty {feature-list:HAVE_PIM_SM}?
|      | | +---ro state
|      | | | +---ro ignore-rp-set-priority?   empty {feature-list:HAVE_PIM_SM}?
|      | | | +---ro cisco-bsr-interop-enable? empty {feature-list:HAVE_PIM_SM}?
|      | | +---rw register-packet
|      | | +---rw config!
|      | | | +---rw cisco-register-checksum-enable empty {feature-
list:HAVE_PIM_SM}?
|      | | | +---rw access-control-list?     string {feature-
list:HAVE_PIM_SM}?
|      | | +---ro state
|      | | | +---ro cisco-register-checksum-enable empty {feature-
list:HAVE_PIM_SM}?
|      | | | +---ro access-control-list?     string {feature-
list:HAVE_PIM_SM}?
|      | +---rw spt-switch
|      | | +---rw config!
|      | | | +---rw enable                   empty {feature-list:HAVE_PIM_SM}?
|      | | | +---rw access-control-list?     string {feature-list:HAVE_PIM_SM}?
|      | | +---ro state
|      | | | +---ro enable                   empty {feature-list:HAVE_PIM_SM}?
|      | | | +---ro access-control-list?     string {feature-list:HAVE_PIM_SM}?
|      | +---rw ssm {feature-list:HAVE_PIM_SSM}?
|      | | +---rw config
|      | | | +---rw range-policy?           ipi-pim-ipv6-
types:pim_ipv6_ssm_range_policy_type_t
|      | | +---ro state
|      | | | +---ro range-policy?           ipi-pim-ipv6-
types:pim_ipv6_ssm_range_policy_type_t
|      | +---rw anycast-rps {feature-list:HAVE_PIM_SM}?
|      | | +---rw anycast-rp* [anycast-rp-address member-rp-address]

```

```

|      |      +---rw anycast-rp-address    -> ../config/anycast-rp-address
|      |      +---rw member-rp-address    -> ../config/member-rp-address
|      |      +---rw config
|      |      |  +---rw anycast-rp-address?  inet:ipv6-address
|      |      |  +---rw member-rp-address?  inet:ipv6-address
|      |      +---ro state
|      |          +---ro anycast-rp-address?  inet:ipv6-address
|      |          +---ro member-rp-address?  inet:ipv6-address
|  +---rw rendezvous-point
|      |  +---rw config
|      |      |  +---rw embed-rp?    cml-data-types:cml_enable_disable_t
|      |      +---ro state
|      |          |  +---ro embed-rp?    cml-data-types:cml_enable_disable_t
|      |  +---rw static-rps
|      |      |  +---rw static-rps-default
|      |          +---rw static-rp-default* [rp-address]
|      |              +---rw rp-address    -> ../config/rp-address
|      |              +---rw config
|      |                  |  +---rw rp-address?                inet:ipv6-address
|      |                  |  +---rw access-control-list?        string
|      |                  |  +---rw override-dynamically-learned-rp?  empty
|      |                  +---ro state
|      |                      +---ro rp-address?                inet:ipv6-address
|      |                      +---ro access-control-list?        string
|      |                      +---ro override-dynamically-learned-rp?  empty
|      |  +---rw bootstrap-router
|      |      |  +---rw bsr-candidate
|      |          +---rw config
|      |              |  +---rw interface-name?    -> /ipi-interface:interfaces/
interface/name
|      |          |  +---rw hash-mask-length?    uint8
|      |          |  +---rw priority?            uint8
|      |          +---ro state
|      |              +---ro interface-name?    -> /ipi-interface:interfaces/
interface/name
|      |          +---ro hash-mask-length?    uint8
|      |          +---ro priority?            uint8
|      |  +---rw rp-candidates
|      |      +---rw rp-candidate* [interface-name]
|      |          +---rw interface-name    -> ../config/interface-name
|      |          +---rw config
|      |              |  +---rw interface-name?    -> /ipi-interface:interfaces/
interface/name
|      |          |  +---rw access-control-list?    string
|      |          |  +---rw advertisement-interval?  uint16
|      |          |  +---rw priority?                uint8
|      |          +---ro state
|      |              +---ro interface-name?    -> /ipi-interface:interfaces/
interface/name
|      |          +---ro access-control-list?    string
|      |          +---ro advertisement-interval?  uint16

```

```

|         |         +--ro priority?                uint8
|         +--rw debug
|         |         +--rw config
|         |         |         +--rw options?      ipi-pim-ipv6-types:pim_ipv6_debug_t
|         |         +--ro state
|         |         |         +--ro options?      ipi-pim-ipv6-types:pim_ipv6_debug_t
|         |         |         +--ro terminal-debug-status? ipi-pim-ipv6-types:pim_ipv6_debug_t
|         +--ro multicast-route-table
|         |         +--ro state
|         |         |         +--ro counters
|         |         |         |         +--ro xxrp-entries?      yang:counter32
|         |         |         |         +--ro g-prefix-entries?  yang:counter32
|         |         |         |         +--ro xg-entries?      yang:counter32
|         |         |         |         +--ro sg-entries?      yang:counter32
|         |         |         |         +--ro sg-rpt-entries?   yang:counter32
|         |         |         |         +--ro fcr-entries?      yang:counter32
|         |         +--ro multicast-routes
|         |         |         +--ro multicast-route* [source-address group-address type]
|         |         |         |         +--ro source-address      -> ../state/source-address
|         |         |         |         +--ro group-address       -> ../state/group-address
|         |         |         |         +--ro type                -> ../state/type
|         |         |         |         +--ro state
|         |         |         |         |         +--ro source-address?  inet:ipv6-address
|         |         |         |         |         +--ro group-address?  inet:ipv6-address
|         |         |         |         |         +--ro mode?          ipi-pim-ipv6-
types:pim_ipv6_multicast_route_mode_t
|         |         |         |         |         +--ro type?          ipi-pim-ipv6-
types:pim_ipv6_multicast_route_type_t
|         |         |         |         |         +--ro uptime?      string
|         |         |         |         |         +--ro next-hop-address?  inet:ipv6-address
|         |         |         |         |         +--ro next-hop-interface-name? string
|         |         |         |         |         +--ro last-rendezvous-point?  inet:ipv6-address
|         |         |         |         |         +--ro spt-switch?      empty
|         |         |         |         |         +--ro local-olist*     string
|         |         |         |         |         +--ro joined-olist*    string
|         |         |         |         |         +--ro inherited-olist*  string
|         |         |         |         |         +--ro pruned-olist*   string
|         |         |         +--ro upstream-xxrp
|         |         |         |         +--ro state
|         |         |         |         |         +--ro route-state?    ipi-pim-ipv6-
types:pim_ipv6_multicast_route_upstream_state_t
|         |         |         |         |         +--ro join-prune-timer?  uint32
|         |         |         |         |         +--ro last-rpf-neighbor-address?  inet:ipv6-address
|         |         |         |         |         +--ro last-rpf-next-hop-address?  inet:ipv6-address
|         |         |         |         |         +--ro macro-state?      ipi-pim-ipv6-
types:pim_ipv6_multicast_route_upstream_macro_state_t {feature-list:HAVE_PIM_SM}?
|         |         |         +--ro upstream-xg
|         |         |         |         +--ro state
|         |         |         |         |         +--ro route-state?    ipi-pim-ipv6-
types:pim_ipv6_multicast_route_upstream_state_t
|         |         |         |         |         +--ro join-prune-timer?  uint32

```

```

|
|      +---ro last-rpf-neighbor-address?  inet:ipv6-address
|      +---ro macro-state?                ipi-pim-ipv6-
types:pim_ipv6_multicast_route_upstream_macro_state_t {feature-list:HAVE_PIM_SM}?
|      +---ro upstream-sg
|      +---ro state
|      +---ro route-state?                ipi-pim-ipv6-
types:pim_ipv6_multicast_route_upstream_state_t
|      +---ro join-prune-timer?           uint32
|      +---ro last-rpf-neighbor-address?  inet:ipv6-address
|      +---ro keep-alive-timer?          uint32
|      +---ro spt-switch?                 empty
|      +---ro macro-state?                ipi-pim-ipv6-
types:pim_ipv6_multicast_route_upstream_macro_state_t {feature-list:HAVE_PIM_SM}?
|      +---ro upstream-sg-rpt
|      +---ro state
|      +---ro route-state?                ipi-pim-ipv6-
types:pim_ipv6_multicast_route_upstream_sgrpt_mode_t
|      +---ro override-timer?            uint32
|      +---ro forwarding-cache-registers
|      +---ro forwarding-cache-register* [address]
|      +---ro address                    -> ../state/address
|      +---ro state
|      +---ro address?                    inet:ipv6-address
|      +---ro keep-alive-timer?          uint32
|      +---ro inherited-olist*           string
|      +---ro downstream-interfaces
|      +---ro downstream-interface* [interface-name]
|      +---ro interface-name              -> ../state/interface-name
|      +---ro state
|      | +---ro interface-name?          string
|      +---ro downstream-xg-sg
|      | +---ro state
|      | +---ro route-state?             ipi-pim-ipv6-
types:pim_ipv6_multicast_route_downstream_state_t
|      | +---ro expiry-timer?            uint32
|      | +---ro prune-pending-timer?     uint32
|      | +---ro assert-state?            ipi-pim-ipv6-
types:pim_ipv6_multicast_route_downstream_assert_state_t
|      | +---ro assert-timer?            uint32
|      | +---ro winner-address?          inet:ipv6-address
|      | +---ro metric?                  uint32
|      | +---ro preference?              uint32
|      | +---ro rpt-bit?                  empty
|      | +---ro macro-state?             ipi-pim-ipv6-
types:pim_ipv6_multicast_route_downstream_macro_state_t
|      +---ro downstream-xxrp-sg-rpt
|      +---ro state
|      +---ro route-state?               ipi-pim-ipv6-
types:pim_ipv6_multicast_route_downstream_state_t
|      +---ro rpt-state?                  ipi-pim-ipv6-
types:pim_ipv6_multicast_route_downstream_rpt_state_t
|      +---ro expiry-timer?              uint32

```

```

|                                     +--ro prune-pending-timer?   uint32
+--rw interfaces
  +--rw interface* [name]
    +--rw name                       -> ../config/name
    +--rw config
      | +--rw name?
interface/name                       -> /ipi-interface:interfaces/
      | +--rw pim-mode?
types:pim_ipv6_mode_t                ipi-pim-ipv6-
      | +--rw bsr-border?
list:HAVE_PIM_SM}?                   empty {feature-
      | +--rw dr-priority?
uint32
      | +--rw hello-interval?
uint16
      | +--rw hello-holdtime?
uint16
      | +--rw passive-enable?
empty
      | +--rw exclude-generated-id?
list:HAVE_PIM_SM}?                   empty {feature-
      | +--rw unicast-bootstrap-router?
list:HAVE_PIM_SM}?                   empty {feature-
      | +--rw neighbor-access-control-list-filter?
string
      | +--rw state-refresh-origination-interval?
list:HAVE_PIM_DM}?                   uint16 {feature-
      | +--rw ecmp-bundle?
list:HAVE_PIM_ECMP_REDIRECT}?        string {feature-
      | +--rw propagation-delay?
uint16
      | +--rw enable-bfd?
types:cml_enable_disable_t {feature-list:HAVE_BFD}?
      +--ro state
      | +--ro name?
interface/name                       -> /ipi-interface:interfaces/
      | +--ro pim-mode?
types:pim_ipv6_mode_t                ipi-pim-ipv6-
      | +--ro bsr-border?
list:HAVE_PIM_SM}?                   empty {feature-
      | +--ro dr-priority?
uint32
      | +--ro hello-interval?
uint16
      | +--ro hello-holdtime?
uint16
      | +--ro passive-enable?
empty
      | +--ro exclude-generated-id?
list:HAVE_PIM_SM}?                   empty {feature-
      | +--ro unicast-bootstrap-router?
list:HAVE_PIM_SM}?                   empty {feature-
      | +--ro neighbor-access-control-list-filter?
string
      | +--ro state-refresh-origination-interval?
list:HAVE_PIM_DM}?                   uint16 {feature-
      | +--ro ecmp-bundle?
list:HAVE_PIM_ECMP_REDIRECT}?        string {feature-
      | +--ro propagation-delay?
uint16
      | +--ro enable-bfd?
types:cml_enable_disable_t {feature-list:HAVE_BFD}?
      | +--ro next-hello?
string
      | +--ro router-id?
inet:ipv4-address
      | +--ro local-id?
uint32
      | +--ro dr-address?
inet:ipv6-address

```

```

+--ro neighbors
  +--ro neighbor* [address]
    +--ro address    -> ../state/address
    +--ro state
      +--ro address?          inet:ipv6-address
      +--ro designated-router? empty
      +--ro neighbor-established? string
      +--ro neighbor-expires?  string
      +--ro secondary-address*  inet:ipv6-address
      +--ro hello-holdtime?     uint16
      +--ro lan-delay?          uint16
      +--ro override-interval?  uint32
      +--ro dr-priority?        uint32 {feature-list:HAVE_PIM_SM}?
      +--ro generated-id?       uint32
      +--ro router-id?          inet:ipv4-address
      +--ro local-id?           uint32
      +--ro tracking-support?    empty
      +--ro ecmp-redirect-enabled? empty {feature-
list:HAVE_PIM_ECMP_REDIRECT}?

rpcs:
  +---x pim-snmpp-restart {feature-list:HAVE_SNMP}?
  +---x pim-ipv4-clear-bsr-rendezvous-point {feature-list:HAVE_PIM_IPV4,feature-
list:HAVE_PIM_SM}?
  | +---w input
  |   +---w vrf-name?    string
  |   +---w pim-mode     ipi-pim-ipv4-types:pim_ipv4_mode_clear_bsr_rp_t
  +---x pim-ipv4-clear-multicast-route {feature-list:HAVE_PIM_IPV4}?
  | +---w input
  |   +---w vrf-name?    string
  |   +---w pim-mode     ipi-pim-ipv4-types:pim_ipv4_mode_t
  +---x pim-ipv4-clear-multicast-route-source-group {feature-list:HAVE_PIM_IPV4}?
  | +---w input
  |   +---w vrf-name?    string
  |   +---w group-address inet:ipv4-address
  +---x pim-ipv4-clear-multicast-route-source-group-mode {feature-
list:HAVE_PIM_IPV4}?
  | +---w input
  |   +---w vrf-name?    string
  |   +---w group-address inet:ipv4-address
  |   +---w source-address inet:ipv4-address
  |   +---w pim-mode     ipi-pim-ipv4-types:pim_ipv4_mode_t
  +---x pim-ipv4-clear-msdp-peer {feature-list:HAVE_PIM_IPV4,feature-
list:HAVE_PIM_MSDP_API}?
  | +---w input
  |   +---w vrf-name?    string
  |   +---w address      inet:ipv4-address
  +---x pim-ipv4-clear-msdp-sa-cache {feature-list:HAVE_PIM_IPV4,feature-
list:HAVE_PIM_MSDP_API}?
  | +---w input
  |   +---w vrf-name?    string

```

```

|     +---w group-address      inet:ipv4-address
+---x pim-ipv4-terminal-debug-on {feature-list:HAVE_PIM_IPV4}?
|   +---w input
|     +---w vrf-name?          string
|     +---w terminal-debug-options ipi-pim-ipv4-types:pim_ipv4_debug_t
+---x pim-ipv4-terminal-debug-off {feature-list:HAVE_PIM_IPV4}?
|   +---w input
|     +---w vrf-name?          string
|     +---w terminal-debug-options ipi-pim-ipv4-types:pim_ipv4_debug_t
+---x pim-ipv4-terminal-debug-all-on {feature-list:HAVE_PIM_IPV4}?
|   +---w input
|     +---w vrf-name?          string
+---x pim-ipv4-terminal-debug-all-off {feature-list:HAVE_PIM_IPV4}?
|   +---w input
|     +---w vrf-name?          string
+---x pim-ipv6-clear-bsr-rendezvous-point {feature-list:HAVE_PIM_IPV6,feature-
list:HAVE_PIM_SM}?
|   +---w input
|     +---w vrf-name?          string
|     +---w pim-mode           ipi-pim-ipv6-types:pim_ipv6_mode_clear_bsr_rp_t
+---x pim-ipv6-clear-multicast-route {feature-list:HAVE_PIM_IPV6}?
|   +---w input
|     +---w vrf-name?          string
|     +---w pim-mode           ipi-pim-ipv6-types:pim_ipv6_mode_t
+---x pim-ipv6-clear-multicast-route-source-group {feature-list:HAVE_PIM_IPV6}?
|   +---w input
|     +---w vrf-name?          string
|     +---w group-address      inet:ipv6-address
+---x pim-ipv6-clear-multicast-route-source-group-mode {feature-
list:HAVE_PIM_IPV6}?
|   +---w input
|     +---w vrf-name?          string
|     +---w group-address      inet:ipv6-address
|     +---w source-address     inet:ipv6-address
|     +---w pim-mode           ipi-pim-ipv6-types:pim_ipv6_mode_t
+---x pim-terminal-debug-bfd-on {feature-list:HAVE_PIMD,feature-
list:HAVE_PIM_IPV4,feature-list:HAVE_PIM_IPV4_OR_HAVE_PIM_IPV6}?
+---x pim-terminal-debug-bfd-off {feature-list:HAVE_PIMD,feature-
list:HAVE_PIM_IPV4,feature-list:HAVE_PIM_IPV4_OR_HAVE_PIM_IPV6}?
+---x pim-ipv6-terminal-debug-on {feature-list:HAVE_PIM_IPV6}?
|   +---w input
|     +---w vrf-name?          string
|     +---w terminal-debug-options ipi-pim-ipv6-types:pim_ipv6_debug_t
+---x pim-ipv6-terminal-debug-off {feature-list:HAVE_PIM_IPV6}?
|   +---w input
|     +---w vrf-name?          string
|     +---w terminal-debug-options ipi-pim-ipv6-types:pim_ipv6_debug_t
+---x pim-ipv6-terminal-debug-all-on {feature-list:HAVE_PIM_IPV6}?
|   +---w input
|     +---w vrf-name?          string
+---x pim-ipv6-terminal-debug-all-off {feature-list:HAVE_PIM_IPV6}?

```

```
+---w input
  +---w vrf-name?   string
```

module: ipi-ping

```
+--rw ping
  +--ro test-result* [test-name]
    +--ro test-name      -> ../state/test-name
    +--ro replies* [sequence-number]
      | +--ro sequence-number  -> ../state/sequence-number
      | +--ro state
      |   +--ro sequence-number?   uint32
      |   +--ro ttl-or-hop-limit?  uint8
      |   +--ro round-trip-time?   decimal64
      |   +--ro result?            ipi-ping-types:ping_packet_result_t
    +--ro state
      | +--ro test-name?         string
      | +--ro test-status?      ipi-ping-types:ping_test_status_t
      | +--ro start-time?       yang:date-and-time
      | +--ro end-time?         yang:date-and-time
    +--ro test-parameters
      | +--ro state
      |   +--ro destination?     string
      |   +--ro protocol?        ipi-ping-types:ping_ip_protocol_t
      |   +--ro vrf-name?        string
      |   +--ro repeat-count?    uint32
      |   +--ro interval?        uint16
      |   +--ro time-to-live?    uint8
      |   +--ro datagram-size?   uint32
      |   +--ro timeout?         uint32
      |   +--ro deadline?        uint32
    +--ro summary-info
      +--ro state
        +--ro packets-transmitted?  uint32
        +--ro packets-received?     uint32
        +--ro success-rate?         uint8
        +--ro loss-rate?            uint8
        +--ro min-rtt?              decimal64
        +--ro rtt-avg?              decimal64
        +--ro max-rtt?              decimal64

rpcs:
  +---x ping-start-test {feature-list:HAVE_HOSTPD}?
    | +---w input
    |   +---w test-name      string
    |   +---w destination   string
    |   +---w protocol       ipi-ping-types:ping_ip_protocol_t
```

```
|      +---w vrf-name?          string
|      +---w repeat-count?     uint32
|      +---w interval?         uint16
|      +---w time-to-live?     uint8
|      +---w datagram-size?    uint32
|      +---w timeout?          uint32
|      +---w deadline?         uint32
+---x ping-stop {feature-list:HAVE_HOSTPD}?
    +---w input
        +---w test-name        string
```

notifications:

```
+---n ping-test-completed
    +--ro severity?            cml-data-types:cml_notif_severity_t
    +--ro eventClass?         cml-data-types:cml_notif_class_t
    +--ro test-name?          string
    +--ro test-status?        ipi-ping-types:ping_test_status_t
    +--ro destination?        string
```

module: ipi-platform-port

```
augment /ipi-platform:components/ipi-platform:component:
    +--ro port
```

module: ipi-platform-transceiver-smart-sfp

```

+--rw smart-sfp
  +--rw interfaces
    | +--rw interface* [interface-name]
    |   +--rw interface-name   -> ../config/interface-name
    |   +--rw config
    |     | +--rw interface-name?   -> /ipi-interface:interfaces/interface/name
    |     | +--rw xcvr-loopback-remote?  cmm_xcvr_direction_t
    |     +--ro state
    |       +--ro interface-name?   -> /ipi-interface:interfaces/interface/name
    |       +--ro xcvr-loopback-remote?  cmm_xcvr_direction_t
  +--rw components
    +--ro component* [name]
      +--ro name   -> ../state/name
      +--ro state
        +--ro name?  string

rpcs:
  +---x smart-sfp-xcvr-txdisable-duration {feature-list:HAVE_CMMD}?
  | +---w input
  |   +---w if-name   string
  |   +---w xcvr-tx-disable-duration  uint16
  +---x smart-sfp-xcvr-reset-remote {feature-list:HAVE_CMMD}?
  | +---w input
  |   +---w if-name   string

```

module: ipi-platform

```

+--rw components
  | +--ro component* [name]
  | | +--ro name   -> ../state/name
  | | +--ro state
  | | | +--ro name?   string
  | | | +--ro type?   ipi-platform-types:cmm_component_type_t
  | | | +--ro location?   string {feature-list:NOT_HAVE_TIBIT}?
  | | | +--ro mfg-name?   string {feature-list:NOT_HAVE_TIBIT}?
  | | | +--ro mfg-date?   yang:date-and-time {feature-
list:NOT_HAVE_TIBIT}?
  | | | +--ro description?   string {feature-list:NOT_HAVE_TIBIT}?
  | | | +--ro hardware-version?   string {feature-list:NOT_HAVE_TIBIT}?
  | | | +--ro firmware-version?   string {feature-list:NOT_HAVE_TIBIT}?

```

```

| | | +--ro software-version?          string {feature-list:NOT_HAVE_TIBIT}?
| | | +--ro serial-no?                 string {feature-list:NOT_HAVE_TIBIT}?
| | | +--ro part-no?                   string {feature-list:NOT_HAVE_TIBIT}?
| | | +--ro removable?                  boolean {feature-list:NOT_HAVE_TIBIT}?
| | | +--ro oper-status?                ipi-platform-
types:cmm_component_oper_status_t {feature-list:NOT_HAVE_TIBIT}?
| | | +--ro product-name?               string {feature-list:NOT_HAVE_TIBIT}?
| | | +--ro asset-tag?                  string {feature-list:NOT_HAVE_TIBIT}?
| | | +--ro component-additional-details* string {feature-list:NOT_HAVE_TIBIT}?
| | | +--ro parent?                     -> /components/component/state/name
{feature-list:NOT_HAVE_TIBIT}?
| | | +--ro empty?                       boolean {feature-list:NOT_HAVE_TIBIT}?
| | | +--ro memory {feature-list:NOT_HAVE_TIBIT}?
| | | | +--ro available?                uint64
| | | | +--ro utilized?                 uint64
| | | +--ro board-fru {feature-list:NOT_HAVE_TIBIT}?
| | | | +--ro board-name?                string
| | | | +--ro board-serial-no?           string
| | | | +--ro board-mfg-name?            string
| | | | +--ro board-mfg-date?            yang:date-and-time
| | | +--ro temperature
| | | | +--ro instant?                   decimal64
| | | | +--ro min?                       decimal64
| | | | +--ro max?                       decimal64
| | | | +--ro avg?                       decimal64
| | | | +--ro interval?                  uint32
| | | | +--ro sensor-name?               string
| | | | +--ro sensor-index?              uint8
| | | | +--ro alarm-status?               boolean
| | | | +--ro alarm-threshold?            decimal64
| | | | +--ro alarm-severity?             cml_alarm_severity_t
| | | | +--ro minimum-emergency-temperature? decimal64
| | | | +--ro maximum-emergency-temperature? decimal64
| | | | +--ro minimum-alert-temperature?  decimal64
| | | | +--ro maximum-alert-temperature?  decimal64
| | | | +--ro minimum-critical-temperature? decimal64
| | | | +--ro maximum-critical-temperature? decimal64
| | | +--ro bmc-sensor-data-record {feature-list:NOT_HAVE_TIBIT}?
| | | | +--ro state
| | | | | +--ro sensor-name?              string
| | | | | +--ro value?                    ipi-platform-types:cmm_bmc_value_t
| | | | | +--ro units?                     string
| | | | | +--ro lower-non-recoverable?     decimal64
| | | | | +--ro lower-non-critical?        decimal64
| | | | | +--ro lower-critical?            decimal64
| | | | | +--ro upper-non-critical?        decimal64
| | | | | +--ro upper-critical?            decimal64
| | | | | +--ro upper-non-recoverable?     decimal64
| | | | | +--ro operational-status?        string
| | | | | +--ro threshold?                 decimal64
| | | | | +--ro event-type?                ipi-platform-types:cmm_bmc_event_type_t

```

```

| | +--ro subcomponents
| | | +--ro subcomponent* [subcomponent-name]
| | |   +--ro subcomponent-name    -> ../state/subcomponent-name
| | |   +--ro state
| | |     +--ro subcomponent-name?  -> /components/component/state/name
| | +--ro cpu
| | | +--ro state
| | |   +--ro processor-count?      uint32
| | |   +--ro cpu-1min-load-percentage? decimal64
| | |   +--ro cpu-5min-load-percentage? decimal64
| | |   +--ro cpu-15min-load-percentage? decimal64
| | |   +--ro cpu-1min-alert-threshold? uint8
| | |   +--ro cpu-1min-critical-threshold? uint8
| | |   +--ro cpu-5min-alert-threshold? uint8
| | |   +--ro cpu-15min-alert-threshold? uint8
| | |   +--ro cpu-utilization?      decimal64
| | |   +--ro cpu-utilization-alert? uint8
| | |   +--ro cpu-utilization-critical? uint8
| | +--ro storage
| | | +--ro state
| | | | +--ro serial-number?        string
| | | | +--ro model-number?         string
| | | | +--ro firmware-revision?    string
| | | | +--ro cylinder-count?       uint16
| | | | +--ro head-count?           uint16
| | | | +--ro sector-count?         uint32
| | | | +--ro unformatted-bytes-or-track? uint16
| | | | +--ro unformatted-bytes-or-sector? uint16
| | | | +--ro revision-number?      string
| | | | +--ro total-memory?         uint64
| | | | +--ro used-memory?          uint64
| | | | +--ro free-memory?          uint64
| | | | +--ro usage-critical-threshold? int32
| | | | +--ro usage-alert-threshold? int32
| | | | +--ro remaining-life?       int32
| | | | +--ro remain-life-critical-threshold? int32
| | | | +--ro remain-life-alert-threshold? int32
| | | | +--ro available-reserved-space? int32
| | | | +--ro available-reserved-space-critical-threshold? int32
| | | | +--ro available-reserved-space-alert-threshold? int32
| | | | +--ro reallocated-sector-count? int32
| | | | +--ro uncorrectable-sector-count? int32
| | | | +--ro manufacturer-id?      string
| | | | +--ro manufacture-date?     string
| | | | +--ro device-type?          string
| | | | +--ro cache-size?           uint64
| | | | +--ro storage-status?       ipi-platform-
types:cml_cmm_storage_status_t
| | | | +--ro harddisk-monitoring
| | | | | +--ro state
| | | | | +--ro interval?           int32

```

```

| | | | +--ro read-average?      int32
| | | | +--ro write-average?     int32
| | | | +--ro read-current?      int32
| | | | +--ro write-current?     int32
| | | | +--ro read-threshold?    int32
| | | | +--ro write-threshold?   int32
| | | +--ro mounted-fileSYSTEMS
| | |   +--ro mounted-fileSYSTEM* [mount-point]
| | |     +--ro mount-point      -> ../state/mount-point
| | |     +--ro state
| | |       +--ro mount-point?    string
| | |       +--ro total?         uint64
| | |       +--ro used?          uint64
| | |       +--ro free?          uint64
| | |       +--ro usage?         uint8
| | +--ro ram
| | | +--ro state
| | |   +--ro total-memory?      uint64
| | |   +--ro used-memory?      uint64
| | |   +--ro available-memory?  uint64
| | |   +--ro shared-memory?     uint64
| | |   +--ro buffers?          uint64
| | |   +--ro total-swap?        uint64
| | |   +--ro free-swap?        uint64
| | |   +--ro current-process-count? uint16
| | |   +--ro total-high-memory?  uint64
| | |   +--ro available-high-memory? uint64
| | |   +--ro unit-size?         uint32
| | |   +--ro usage-critical-threshold? uint32
| | |   +--ro usage-alert-threshold? uint32
| | +--ro transceiver {feature-list:NOT_HAVE_TIBIT}?
| | | +--ro state
| | | | +--ro port-no?          uint8
| | | | +--ro presence?        ipi-platform-transceiver-
types:ddm_cmm_trans_presence_t
| | | | +--ro type?            ipi-platform-transceiver-
types:ddm_cmm_trans_type_t
| | | | +--ro channel-count?    int32
| | | | +--ro transceiver-identifier? ipi-platform-transceiver-
types:ddm_cmm_trans_identifier_t
| | | | +--ro connector-type?   ipi-platform-transceiver-
types:ddm_cmm_trans_connector_type_t
| | | | +--ro ethernet-compliance-code? ipi-platform-transceiver-
types:ddm_cmm_trans_eth_compliance_t
| | | | +--ro extended-ethernet-compliance-code? ipi-platform-transceiver-
types:ddm_cmm_trans_ext_eth_compliance_t
| | | | +--ro sonet-compliance-code? ipi-platform-transceiver-
types:ddm_cmm_trans_sonet_compliance_t
| | | | +--ro fiber-channel-link-length? ipi-platform-transceiver-
types:ddm_cmm_trans_fiber_channel_linklen_t
| | | | +--ro fiber-channel-transmission-technology? ipi-platform-transceiver-
types:ddm_cmm_trans_fiber_channel_transmittech_t

```

```

| | | | +--ro fiber-channel-transmission-media?          ipi-platform-transceiver-
types:ddm_cmm_trans_fiber_channel_transmitmedia_t
| | | | +--ro serial-encoding-algorithm?                ipi-platform-transceiver-
types:ddm_cmm_trans_encoding_t
| | | | +--ro link-length-kilometer?                    int32
| | | | +--ro link-length-meter?                        int32
| | | | +--ro om1-link-length?                          int32
| | | | +--ro om2-link-length?                          int32
| | | | +--ro om3-link-length?                          int32
| | | | +--ro om4-link-length?                          int32
| | | | +--ro vendor-name?                              string
| | | | +--ro vendor-ieee-id?                           string
| | | | +--ro vendor-part-number?                       string
| | | | +--ro vendor-revision-number?                   string
| | | | +--ro check-code?                               string
| | | | +--ro extended-check-code?                     string
| | | | +--ro nominal-signalling-rate?                  int32
| | | | +--ro maximum-signalling-rate?                  int32
| | | | +--ro minimum-signalling-rate?                  int32
| | | | +--ro vendor-serial-number?                     string
| | | | +--ro vendor-manufacturing-date?                string
| | | | +--ro ddm-type?                                 ipi-platform-transceiver-
types:ddm_cmm_trans_ddm_support_t
| | | | +--ro maximum-case-temperature?                 decimal64
| | | | +--ro grid-spacing?                             decimal64
| | | | +--ro first-frequency?                          decimal64
| | | | +--ro last-frequency?                           decimal64
| | | | +--ro frequency-error?                          decimal64
| | | | +--ro frequency-error-critical-min-threshold?   decimal64
| | | | +--ro frequency-error-critical-max-threshold?   decimal64
| | | | +--ro frequency-error-alert-min-threshold?      decimal64
| | | | +--ro frequency-error-alert-max-threshold?      decimal64
| | | | +--ro wavelength-error?                         decimal64
| | | | +--ro wavelength-error-critical-min-threshold?   decimal64
| | | | +--ro wavelength-error-critical-max-threshold?   decimal64
| | | | +--ro wavelength-error-alert-min-threshold?      decimal64
| | | | +--ro wavelength-error-alert-max-threshold?      decimal64
| | | | +--ro tx-tune-ready?                             boolean
| | | | +--ro thermoelectric-cooler-fault?              boolean
| | | | +--ro wavelength-locked?                        boolean
| | | | +--ro transceiver-temperature?                  decimal64
| | | | +--ro temperature-alert-max-threshold?          decimal64
| | | | +--ro temperature-critical-max-threshold?        decimal64
| | | | +--ro temperature-critical-min-threshold?        decimal64
| | | | +--ro temperature-alert-min-threshold?          decimal64
| | | | +--ro transceiver-voltage?                      decimal64
| | | | +--ro voltage-alert-max-threshold?              decimal64
| | | | +--ro voltage-critical-max-threshold?            decimal64
| | | | +--ro voltage-critical-min-threshold?            decimal64
| | | | +--ro voltage-alert-min-threshold?              decimal64
| | | +--ro sfp

```

```

| | | | +--ro state
| | | | +---ro transmit-status? ipi-platform-transceiver-
types:ddm_tx_rx_state_t
| | | | +---ro recieve-loss-status? ipi-platform-transceiver-
types:ddm_tx_rx_state_t
| | | | +---ro sfp-identifier? ipi-platform-transceiver-
types:ddm_cmm_trans_sfp_extended_identifier_t
| | | | +---ro sfp-options-implemented? ipi-platform-transceiver-
types:ddm_cmm_trans_sfp_options_implemented_t
| | | | +---ro fiber-channel-sfp-speed? ipi-platform-transceiver-
types:ddm_cmm_trans_fiber_channel_speed_t
| | | | +---ro sfp-infiniband-compliance-code? ipi-platform-transceiver-
types:ddm_cmm_trans_sfp_infiniband_compliance_t
| | | | +---ro sfp-escon-compliance-code? ipi-platform-transceiver-
types:ddm_cmm_trans_sfp_escon_compliance_t
| | | | +---ro sfp-plus-cable-technology? ipi-platform-transceiver-
types:ddm_cmm_trans_sfp_plus_cable_tech_t
| | | +---ro xfp
| | | | +--ro state
| | | | +---ro transmit-status? ipi-platform-
transceiver-types:ddm_tx_rx_state_t
| | | | +---ro recieve-loss-status? ipi-platform-
transceiver-types:ddm_tx_rx_state_t
| | | | +---ro xsfp-identifier? ipi-platform-
transceiver-types:ddm_cmm_trans_xfp_extended_identifier_t
| | | | +---ro xfp-10g-ethernet-compliance-code? ipi-platform-
transceiver-types:ddm_cmm_trans_xfp_10g_eth_compliance_t
| | | | +---ro xfp-10g-fiber-channel-compliance-code? ipi-platform-
transceiver-types:ddm_cmm_trans_xfp_10g_fiber_chn_compliance_t
| | | | +---ro xfp-10g-copper-link-compliance-code? ipi-platform-
transceiver-types:ddm_cmm_trans_xfp_10g_copper_links_rsvd_t
| | | | +---ro xfp-lower-speed-link-compliance-code? ipi-platform-
transceiver-types:ddm_cmm_trans_xfp_lower_speed_links_t
| | | | +---ro xfp-sonet-interconnect-compliance-code? ipi-platform-
transceiver-types:ddm_cmm_trans_xfp_sonet_interconnect_t
| | | | +---ro xfp-sonet-short-haul-compliance-code? ipi-platform-
transceiver-types:ddm_cmm_trans_xfp_sonet_short_haul_t
| | | | +---ro xfp-sonet-long-haul-compliance-code? ipi-platform-
transceiver-types:ddm_cmm_trans_xfp_sonet_long_haul_t
| | | | +---ro xfp-sonet-very-long-haul-compliance-code? ipi-platform-
transceiver-types:ddm_cmm_trans_xfp_sonet_very_long_haul_t
| | | | +---ro xfp-serial-encoding-algorithm? ipi-platform-
transceiver-types:ddm_cmm_trans_xfp_encoding_t
| | | | +---ro xsfp-options-implemented? ipi-platform-
transceiver-types:ddm_cmm_trans_xfp_options_implemented_t
| | | | +---ro xfp-auxillary-voltage? ipi-platform-
transceiver-types:ddm_cmm_trans_xfp_voltage_aux_monitor_t
| | | +---ro qsfp
| | | | +--ro state
| | | | +---ro reset-status? ipi-platform-transceiver-
types:ddm_cmm_trans_reset_t
| | | | +---ro power? ipi-platform-transceiver-
types:ddm_cmm_trans_power_t
| | | | +---ro lanel-transmission? ipi-platform-transceiver-
types:ddm_tx_rx_state_t

```

```

| | | |      +---ro lane1-transmission-loss?      ipi-platform-transceiver-
types:ddm_tx_rx_state_t
| | | |      +---ro lane1-recieve-loss?           ipi-platform-transceiver-
types:ddm_tx_rx_state_t
| | | |      +---ro lane2-transmission?           ipi-platform-transceiver-
types:ddm_tx_rx_state_t
| | | |      +---ro lane2-transmission-loss?      ipi-platform-transceiver-
types:ddm_tx_rx_state_t
| | | |      +---ro lane2-recieve-loss?           ipi-platform-transceiver-
types:ddm_tx_rx_state_t
| | | |      +---ro lane3-transmission?           ipi-platform-transceiver-
types:ddm_tx_rx_state_t
| | | |      +---ro lane3-transmission-loss?      ipi-platform-transceiver-
types:ddm_tx_rx_state_t
| | | |      +---ro lane3-recieve-loss?           ipi-platform-transceiver-
types:ddm_tx_rx_state_t
| | | |      +---ro lane4-transmission?           ipi-platform-transceiver-
types:ddm_tx_rx_state_t
| | | |      +---ro lane4-transmission-loss?      ipi-platform-transceiver-
types:ddm_tx_rx_state_t
| | | |      +---ro lane4-recieve-loss?           ipi-platform-transceiver-
types:ddm_tx_rx_state_t
| | | |      +---ro qsfp-identififer?             ipi-platform-transceiver-
types:ddm_cmm_qsfp_extended_identififer_t
| | | |      +---ro fiber-channel-qsfp-speed?     ipi-platform-transceiver-
types:ddm_cmm_trans_fiber_channel_speed_t
| | | |      +---ro qsfp-options-implemented?     ipi-platform-transceiver-
types:ddm_cmm_trans_qsfp_options_implemented_t
| | |      +---ro channels
| | | |      +---ro channel* [index]
| | | |      +---ro index      -> ../state/index
| | | |      +---ro state
| | | |      +---ro index?                          uint8
| | | |      +---ro input-power?                    decimal64
| | | |      +---ro input-power-alert-max-threshold? decimal64
| | | |      +---ro input-power-critical-max-threshold? decimal64
| | | |      +---ro input-power-critical-min-threshold? decimal64
| | | |      +---ro input-power-alert-min-threshold? decimal64
| | | |      +---ro output-power?                  decimal64
| | | |      +---ro output-power-alert-max-threshold? decimal64
| | | |      +---ro output-power-critical-max-threshold? decimal64
| | | |      +---ro output-power-critical-min-threshold? decimal64
| | | |      +---ro output-power-alert-min-threshold? decimal64
| | | |      +---ro laser-bias-current?            decimal64
| | | |      +---ro laser-bias-current-alert-max-threshold? decimal64
| | | |      +---ro laser-bias-current-critical-max-threshold? decimal64
| | | |      +---ro laser-bias-current-critical-min-threshold? decimal64
| | | |      +---ro laser-bias-current-alert-min-threshold? decimal64
| | |      +---ro tibit-olt-microplug
| | |      +---ro state
| | | |      +---ro interface-name?                -> /ipi-interface:interfaces/
interface/name
| | | |      +---ro warranty-seal?                  ipi-platform-transceiver-tibit-
types:trans_tibit_cmm_warranty_seal_t

```



```

| | | | +--ro operational-management? ipi-platform-transceiver-tibit-
types:trans_tibit_cmm_oper_mode_t
| | | | +--ro pon-mode? ipi-platform-transceiver-tibit-
types:trans_tibit_cmm_pon_mode_t
| | | | +--ro active-firmware-bank-id? uint8
| | | | +--ro next-active-firmware-bank-id? uint8
| | | | +--ro management-vlan-tpid? string
| | | | +--ro management-vlan-id? uint16
| | | | +--ro pon-mac-address? string
| | | | +--ro ethernet-mac-address? string
| | | | +--ro pon-port-administrative-state? ipi-platform-transceiver-tibit-
types:trans_tibit_cmm_pon_status_t
| | | | +--ro pon-port-operational-status? ipi-platform-transceiver-tibit-
types:trans_tibit_cmm_pon_status_t
| | | | +--ro pon-link-count? uint16
| | | | +--ro firmware-banks
| | | | +--ro bank* [bank-id]
| | | | +--ro bank-id -> ../state/bank-id
| | | | +--ro state
| | | | +--ro bank-id? uint8
| | | | +--ro release-type? string
| | | | +--ro major-version? uint8
| | | | +--ro minor-version? uint8
| | | | +--ro maintenance-version? uint8
| | | | +--ro suffix-build-tag? ipi-platform-transceiver-tibit-
types:trans_tibit_cmm_string_t
| | | | +--ro suffix-build-number? uint16
| | | | +--ro build-sha? ipi-platform-transceiver-tibit-
types:trans_tibit_cmm_string_t
| | | | +--ro application-type? ipi-platform-transceiver-tibit-
types:trans_tibit_cmm_application_type_t
| | | | +--ro created-timestamp? yang:date-and-time
| | | | +--ro updated-timestamp? yang:date-and-time
| | | +--ro power-supply
| | | | +--ro state
| | | | +--ro operational-status? cml_cmm_power_supply_operstatus_t
| | | | +--ro hot-swap-state? ipi-platform-
types:cml_cmm_power_rail_t
| | | | +--ro capacity? decimal164
| | | | +--ro power-consumption? decimal164
| | | | +--ro input-power? decimal164
| | | | +--ro input-voltage? decimal164
| | | | +--ro output-voltage? decimal164
| | | | +--ro input-current? decimal164
| | | | +--ro output-current? decimal164
| | | | +--ro temperature-sensor1? decimal164
| | | | +--ro temperature-sensor2? decimal164
| | | | +--ro temperature-sensor3? decimal164
| | | | +--ro fan1-rpm? uint32
| | | | +--ro fan2-rpm? uint32
| | | | +--ro fan3-rpm? uint32
| | | | +--ro fan4-rpm? uint32

```

	+++ro input-power-status?	ipi-platform-
types:cml_cmm_power_rail_t		
	+++ro output-power-status?	ipi-platform-
types:cml_cmm_power_rail_t		
	+++ro supported-parameters?	cml_cmm_psu_pmbus_param_support_t
	+++ro vin-alert-threshold-min?	decimal64
	+++ro vin-alert-threshold-max?	decimal64
	+++ro vin-critical-threshold-min?	decimal64
	+++ro vin-critical-threshold-max?	decimal64
	+++ro vout-alert-threshold-min?	decimal64
	+++ro vout-alert-threshold-max?	decimal64
	+++ro vout-critical-threshold-min?	decimal64
	+++ro vout-critical-threshold-max?	decimal64
	+++ro pout-alert-threshold-min?	decimal64
	+++ro pout-alert-threshold-max?	decimal64
	+++ro pout-critical-threshold-min?	decimal64
	+++ro pout-critical-threshold-max?	decimal64
	+++ro pin-alert-threshold-min?	decimal64
	+++ro pin-alert-threshold-max?	decimal64
	+++ro pin-critical-threshold-min?	decimal64
	+++ro pin-critical-threshold-max?	decimal64
	+++ro iin-alert-threshold-min?	decimal64
	+++ro iin-alert-threshold-max?	decimal64
	+++ro iin-critical-threshold-min?	decimal64
	+++ro iin-critical-threshold-max?	decimal64
	+++ro iout-alert-threshold-min?	decimal64
	+++ro iout-alert-threshold-max?	decimal64
	+++ro iout-critical-threshold-min?	decimal64
	+++ro iout-critical-threshold-max?	decimal64
	+++ro temp1-alert-threshold-min?	decimal64
	+++ro temp1-alert-threshold-max?	decimal64
	+++ro temp1-critical-threshold-min?	decimal64
	+++ro temp1-critical-threshold-max?	decimal64
	+++ro temp2-alert-threshold-min?	decimal64
	+++ro temp2-alert-threshold-max?	decimal64
	+++ro temp2-critical-threshold-min?	decimal64
	+++ro temp2-critical-threshold-max?	decimal64
	+++ro vin-hw-shut-max-threshold?	decimal64
	+++ro vin-hw-shut-min-threshold?	decimal64
	+++ro vin-hw-resume_max_threshold?	decimal64
	+++ro vin-hw-resume_min_threshold?	decimal64
	+++ro vout-hw-shut-max-threshold?	decimal64
	+++ro vout-hw-shut-min-threshold?	decimal64
	+++ro vout-hw-resume_max_threshold?	decimal64
	+++ro vout-hw-resume_min_threshold?	decimal64
	+++ro pin-hw-shut-max-threshold?	decimal64
	+++ro pin-hw-shut-min-threshold?	decimal64
	+++ro pin-hw-resume_max_threshold?	decimal64
	+++ro pin-hw-resume_min_threshold?	decimal64
	+++ro pout-hw-shut-max-threshold?	decimal64
	+++ro pout-hw-shut-min-threshold?	decimal64

```

| | | +---ro pout-hw-resume_max_threshold? decimal64
| | | +---ro pout-hw-resume_min_threshold? decimal64
| | | +---ro iin-hw-shut-max-threshold? decimal64
| | | +---ro iin-hw-shut-min-threshold? decimal64
| | | +---ro iin-hw-resume_max_threshold? decimal64
| | | +---ro iin-hw-resume_min_threshold? decimal64
| | | +---ro iout-hw-shut-max-threshold? decimal64
| | | +---ro iout-hw-shut-min-threshold? decimal64
| | | +---ro iout-hw-resume_max_threshold? decimal64
| | | +---ro iout-hw-resume_min_threshold? decimal64
| | | +---ro temp1-hw-shut-max-threshold? decimal64
| | | +---ro temp1-hw-shut-min-threshold? decimal64
| | | +---ro temp1-hw-resume_max_threshold? decimal64
| | | +---ro temp1-hw-resume_min_threshold? decimal64
| | | +---ro temp2-hw-shut-max-threshold? decimal64
| | | +---ro temp2-hw-shut-min-threshold? decimal64
| | | +---ro temp2-hw-resume_max_threshold? decimal64
| | | +---ro temp2-hw-resume_min_threshold? decimal64
| | | +---ro temp3-alert-threshold-min? decimal64
| | | +---ro temp3-alert-threshold-max? decimal64
| | | +---ro temp3-critical-threshold-min? decimal64
| | | +---ro temp3-critical-threshold-max? decimal64
| | | +---ro temp3-hw-shut-max-threshold? decimal64
| | | +---ro temp3-hw-shut-min-threshold? decimal64
| | | +---ro temp3-hw-resume_max_threshold? decimal64
| | | +---ro temp3-hw-resume_min_threshold? decimal64
| | +---ro fan
| | | +---ro state
| | | | +---ro fan-index? uint8
| | | | +---ro rpm? uint32
| | | | +---ro minimum-rpm? uint32
| | | | +---ro maximum-rpm? uint32
| | | | +---ro fan-status? cml_cmm_fan_status_t
| | | | +---ro fan-location? cml_cmm_fan_location_t
| | +---ro fan-tray
| | | +---ro state
| | | | +---ro tray-number? uint8
| | | | +---ro status? cml_cmm_fan_tray_status_t
| | | | +---ro led-color? cml_cmm_led_color_code_t
| | | | +---ro fan-count? uint32
| | +---ro chassis
| | | +---ro state
| | | | +---ro up-time? yang:timeticks
| | | | +---ro mac-address? yang:mac-address
| | | | +---ro label-revision? string
| | | | +---ro country-code? string
| | | | +---ro fan-tray-count? uint32
| | | | +---ro power-supplies-count? uint32
| | | | +---ro chassis-fast-ethernet-count? uint32
| | | | +---ro chassis-1g-ethernet-count? uint32

```

```

| | | +---ro chassis-10g-ethernet-count? uint32
| | | +---ro chassis-25g-ethernet-count? uint32
| | | +---ro chassis-40g-ethernet-count? uint32
| | | +---ro chassis-50g-ethernet-count? uint32
| | | +---ro chassis-100g-ethernet-count? uint32
| | | +---ro service-tag? string
| | | +---ro platform-name? string
| | | +---ro onie-version? string
| | | +---ro vendor-name? string
| | | +---ro diagnostic-version? string
| | | +---ro cyclic-redundancy-32bit-value? string
| | | +---ro switch-chip-revision? string
| | | +---ro fan-board-id? string
| | | +---ro supported-label-revision? string
| | | +---ro supported-switch-chip-revision? string
| | | +---ro system_status? ipi-platform-
types:platform_system_status_type_t
| | | +---ro cpu_status? ipi-platform-
types:platform_system_status_type_t
| | | +---ro ram_status? ipi-platform-
types:platform_system_status_type_t
| | | +---ro storage_status? ipi-platform-
types:platform_system_status_type_t
| | | +---ro temperature_status? ipi-platform-
types:platform_system_status_type_t
| | | +---ro fan_status? ipi-platform-
types:platform_system_status_type_t
| | | +---ro psu_status? ipi-platform-
types:platform_system_status_type_t
| | | +---ro software_status? ipi-platform-
types:platform_system_status_type_t
| | +---ro linecard
| | | +---ro state
| | | +---ro slot-id? string
| | +---ro power-rail
| | | +---ro state
| | | +---ro power-vddr-status? ipi-platform-
types:cml_cmm_power_rail_t
| | | +---ro power-core-status? ipi-platform-
types:cml_cmm_power_rail_t
| | | +---ro vlpl-power-rail? ipi-platform-
types:cml_cmm_power_rail_t
| | | +---ro main-board-power-rail? ipi-platform-
types:cml_cmm_power_rail_t
| | | +---ro vcc-5v-power-status? ipi-platform-
types:cml_cmm_power_rail_t
| | | +---ro vcc-3v-power-status? ipi-platform-
types:cml_cmm_power_rail_t
| | | +---ro vcc-1v-mac-power-status? ipi-platform-
types:cml_cmm_power_rail_t
| | | +---ro vcc-1v-mac-avs-power-status? ipi-platform-
types:cml_cmm_power_rail_t
| | | +---ro vccv1p05-power-status? ipi-platform-
types:cml_cmm_power_rail_t

```

```

| | |      +---ro vccv1p5-power-status?      ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro vccv1p8-power-status?      ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro v1p05-power-rail?          ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro vcc-power-rail?            ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro sbv1p5-power-rail?         ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro v1p0-power-rail?           ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro v1p5-power-rail?           ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro v3p3-power-rail?           ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro v1p8-power-rail?           ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro v1p9-power-rail?           ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro v1p35-power-rail?          ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro vcc-avs-1v-power-status?   ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro ddrvtt-power-status?       ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro vcc-mac-v1p25-power-status? ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro mac-v1p8-power-status?     ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro power-supply-1-power-status? ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro power-supply-2-power-status? ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro power-supply-1-power-rail? ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro power-supply-2-power-rail? ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro power-supply-1-v12-power-rail? ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro power-supply-2-v12-power-rail? ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro power-supply-1-ac-alert-power-rail? ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro power-supply-2-ac-alert-power-rail? ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro power-vccp-status?         ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro v5a-power-rail?            ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro v3p3a-power-rail?         ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro hot-swap-1-power-rail?     ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro hot-swap-2-power-rail?     ipi-platform-
types:cml_cmm_power_rail_t

```

```

| | |      +---ro xp0r-v75-power-rail?          ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro xplr-v07-cp-power-rail?       ipi-platform-
types:cml_cmm_power_rail_t
| | |      +---ro ceragon
| | |      +---ro cpld-attr
| | |      | +---ro state
| | |      |   +---ro usb-over-current-status?   uint8
| | |      |   +---ro loss-of-input-clock-status? uint8
| | |      +---ro poe
| | |      +---ro state
| | |      +---ro port-index?   uint8
| | |      +---ro port-name?    string
| | |      +---ro port-state?   ipi-platform-ceragon-types:cmm_poe_port_status_t
| | |      +---ro cmis-modules
| | |      +---ro cmis-module* [type port]
| | |      +---ro type          -> ../state/type
| | |      +---ro port          -> ../state/port
| | |      +---ro state
| | |      | +---ro type?      ipi-platform-cmis-types:cmm_cmis_port_type_t
| | |      | +---ro port?     uint8
| | |      +---ro eeprom
| | |      | +---ro state
| | |      |   +---ro identifier?                ipi-platform-sff8024-
types:cmm_sff8024_identifier_t
| | |      |   +---ro vendor-name?              string
| | |      |   +---ro vendor-oui?              string
| | |      |   +---ro part-number?             string
| | |      |   +---ro revision-level?          string
| | |      |   +---ro serial-number?           string
| | |      |   +---ro manufacturing-date?      string
| | |      |   +---ro clei-code?              string
| | |      |   +---ro module-power-class?     ipi-platform-cmis-
types:cmm_cmis_module_power_class_t
| | |      |   +---ro module-max-power?        decimal64
| | |      |   +---ro cooling-implemented?     ipi-platform-cmis-
types:cmm_cmis_yes_no_t
| | |      |   +---ro temperature-max?         int16
| | |      |   +---ro temperature-min?        int16
| | |      |   +---ro operatin-voltage-min?   decimal64
| | |      |   +---ro optical-detector?       ipi-platform-cmis-
types:cmm_cmis_optical_detector_t
| | |      |   +---ro rx-power-measurement?   ipi-platform-cmis-
types:cmm_cmis_rx_power_measur_t
| | |      |   +---ro tx-disable-module-wide? ipi-platform-cmis-
types:cmm_cmis_yes_no_t
| | |      |   +---ro cable-assembly-link-length? int16
| | |      |   +---ro connector-type?         ipi-platform-sff8024-
types:cmm_sff8024_connector_type_t
| | |      |   +---ro cca-5ghz?               uint8
| | |      |   +---ro cca-7ghz?               uint8
| | |      |   +---ro cca-12p9ghz?           uint8

```

```

| | | | | +---ro cca-25p8ghz? uint8
| | | | | +---ro media-interface-technology? ipi-platform-cmis-
types:cmm_cmis_media_intf_tech_t
| | | | | +---ro cmis-revision? string
| | | | | +---ro memory-model? ipi-platform-cmis-
types:cmm_cmis_memory_model_t
| | | | | +---ro mci-max-speed? ipi-platform-cmis-
types:cmm_cmis_mci_max_speed_t
| | | | | +---ro active-firmware-revision? string
| | | | | +---ro inactive-firmware-revision? string
| | | | | +---ro hardware-revision? string
| | | | | +---ro media-type? ipi-platform-cmis-
types:cmm_cmis_media_type_t
| | | | | +---ro max-smf-link-length? decimal64
| | | | | +---ro max-mmfm-om2-link-length? uint8
| | | | | +---ro max-mmfm-om3-link-length? uint16
| | | | | +---ro max-mmfm-om4-link-length? uint16
| | | | | +---ro max-mmfm-om5-link-length? uint16
| | | | | +---ro wavelength-nominal? decimal64
| | | | | +---ro wavelength-tolerance? decimal64
| | | | +---ro module-state
| | | | | +---ro fault-state? ipi-platform-cmis-
types:cmm_cmis_module_fault_state_t
| | | | | +---ro current-state? ipi-platform-cmis-types:cmm_cmis_module_state_t
| | | | | +---ro datapaths
| | | | | +---ro datapath* [lane]
| | | | | +---ro lane -> ../state/lane
| | | | | +---ro state
| | | | | +---ro lane? uint8
| | | | | +---ro current-state? ipi-platform-cmis-
types:cmm_cmis_datapath_states_t
| | | | +---ro module-monitors
| | | | | +---ro monitors
| | | | | | +---ro monitor* [id]
| | | | | | +---ro id -> ../state/id
| | | | | | +---ro state
| | | | | | +---ro id? ipi-platform-cmis-
types:cmm_cmis_module_monitor_id_t
| | | | | | +---ro description? string
| | | | | | +---ro value? decimal64
| | | | | | +---ro high-alarm? decimal64
| | | | | | +---ro high-warning? decimal64
| | | | | | +---ro low-warning? decimal64
| | | | | | +---ro low-alarm? decimal64
| | | | | +---ro monitor-alarm
| | | | | +---ro state
| | | | | +---ro alarm-id? ipi-platform-cmis-
types:cmm_cmis_module_monitor_id_t
| | | | | +---ro alarm-type? ipi-platform-cmis-
types:cmm_cmis_threshold_alarm_t
| | | | | +---ro current-value? decimal64
| | | | | +---ro threshold-minimum? decimal64

```

```

| | | | |      +---ro threshold-maximum?  decimal64
| | | | |      +---ro host-monitors
| | | | |      |  +---ro lanes
| | | | |      |      +---ro lane* [number]
| | | | |      |      +---ro number          -> ../state/number
| | | | |      |      +---ro state
| | | | |      |      |  +---ro number?  uint8
| | | | |      |      +---ro monitors
| | | | |      |      |  +---ro monitor* [id]
| | | | |      |      |      +---ro id          -> ../state/id
| | | | |      |      |      +---ro state
| | | | |      |      |      +---ro id?          ipi-platform-cmis-
types:cmm_cmis_host_monitor_id_t
| | | | |      |      |      +---ro description?  string
| | | | |      |      |      +---ro value?      decimal64
| | | | |      |      |      +---ro high-alarm?  decimal64
| | | | |      |      |      +---ro high-warning? decimal64
| | | | |      |      |      +---ro low-warning? decimal64
| | | | |      |      |      +---ro low-alarm?  decimal64
| | | | |      |      +---ro flags
| | | | |      |      |  +---ro flag* [id]
| | | | |      |      |      +---ro id          -> ../state/id
| | | | |      |      |      +---ro state
| | | | |      |      |      +---ro id?          ipi-platform-cmis-
types:cmm_cmis_host_flag_id_t
| | | | |      |      |      +---ro description?  string
| | | | |      |      |      +---ro value?      boolean
| | | | |      |      +---ro monitor-alarm
| | | | |      |      |  +---ro state
| | | | |      |      |      +---ro alarm-id?     ipi-platform-cmis-
types:cmm_cmis_host_monitor_id_t
| | | | |      |      |      +---ro alarm-type?     ipi-platform-cmis-
types:cmm_cmis_threshold_alarm_t
| | | | |      |      |      +---ro current-value?  decimal64
| | | | |      |      |      +---ro threshold-minimum? decimal64
| | | | |      |      |      +---ro threshold-maximum? decimal64
| | | | |      |      +---ro flag-alarm
| | | | |      |      |  +---ro state
| | | | |      |      |      +---ro alarm-id?     ipi-platform-cmis-
types:cmm_cmis_host_flag_id_t
| | | | |      +---ro media-monitors
| | | | |      |  +---ro lanes
| | | | |      |      +---ro lane* [number]
| | | | |      |      +---ro number          -> ../state/number
| | | | |      |      +---ro state
| | | | |      |      |  +---ro number?  uint8
| | | | |      |      +---ro monitors
| | | | |      |      |  +---ro monitor* [id]
| | | | |      |      |      +---ro id          -> ../state/id
| | | | |      |      |      +---ro state
| | | | |      |      |      +---ro id?          ipi-platform-cmis-
types:cmm_cmis_media_monitor_id_t

```



```

| | | | | +--ro description? string
| | | | | +--ro value? decimal64
| | | | | +--ro high-alarm? decimal64
| | | | | +--ro high-warning? decimal64
| | | | | +--ro low-warning? decimal64
| | | | | +--ro low-alarm? decimal64
| | | | | +--ro flags
| | | | | | +--ro flag* [id]
| | | | | | +--ro id -> ../state/id
| | | | | | +--ro state
| | | | | | +--ro id? ipi-platform-cmis-
types:cmm_cmis_media_flag_id_t
| | | | | +--ro description? string
| | | | | +--ro value? boolean
| | | | | +--ro monitor-alarm
| | | | | | +--ro state
| | | | | | +--ro alarm-id? ipi-platform-cmis-
types:cmm_cmis_media_monitor_id_t
| | | | | | +--ro alarm-type? ipi-platform-cmis-
types:cmm_cmis_threshold_alarm_t
| | | | | | +--ro current-value? decimal64
| | | | | | +--ro threshold-minimum? decimal64
| | | | | | +--ro threshold-maximum? decimal64
| | | | | +--ro flag-alarm
| | | | | | +--ro state
| | | | | | +--ro alarm-id? ipi-platform-cmis-
types:cmm_cmis_media_flag_id_t
| | | +--ro edfas
| | | | +--ro edfa* [port]
| | | | +--ro port -> ../state/port
| | | | +--ro state
| | | | | +--ro port? uint8
| | | | +--ro monitors
| | | | | +--ro monitor* [id]
| | | | | +--ro id -> ../state/id
| | | | | +--ro state
| | | | | +--ro id? ipi-platform-transceiver-
types:cmm_edfa_ddm_monitor_id_t
| | | | | +--ro description? string
| | | | | +--ro value? decimal64
| | | | | +--ro high-alarm? decimal64
| | | | | +--ro high-warning? decimal64
| | | | | +--ro low-warning? decimal64
| | | | | +--ro low-alarm? decimal64
| | | | | +--ro monitor-alarm
| | | | | +--ro state
| | | | | +--ro alarm-id? ipi-platform-transceiver-
types:cmm_edfa_ddm_monitor_id_t
| | | | | +--ro alarm-type? ipi-platform-transceiver-
types:cmm_ddm_threshold_alarm_t
| | | | | +--ro current-value? decimal64
| | | | | +--ro threshold-minimum? decimal64

```

```

| | |          +---ro threshold-maximum?  decimal64
| | +---ro remote-sfps
| |     +---ro remote-sfp* [port]
| |         +---ro port          -> ../state/port
| |         +---ro state
| |             | +---ro port?    uint8
| |             +---ro eeprom
| |             | +---ro state
| |             | +---ro identifier?
transceiver-types:ddm_cmm_trans_identifier_t      ipi-platform-
| |             | +---ro sfp-extended-identifier?
transceiver-types:ddm_cmm_trans_sfp_extended_identifier_t  ipi-platform-
| |             | +---ro connector-type?
transceiver-types:ddm_cmm_trans_connector_type_t          ipi-platform-
| |             | +---ro ethernet-compliance-code?
transceiver-types:ddm_cmm_trans_eth_compliance_t          ipi-platform-
| |             | +---ro extended-ethernet-compliance-code?
transceiver-types:ddm_cmm_trans_ext_eth_compliance_t      ipi-platform-
| |             | +---ro sonet-compliance-code?
transceiver-types:ddm_cmm_trans_sonet_compliance_t        ipi-platform-
| |             | +---ro fiber-channel-link-length?
transceiver-types:ddm_cmm_trans_fiber_channel_linklen_t   ipi-platform-
| |             | +---ro fiber-channel-transmission-technology?
transceiver-types:ddm_cmm_trans_fiber_channel_transmittech_t  ipi-platform-
| |             | +---ro fiber-channel-transmission-media?
transceiver-types:ddm_cmm_trans_fiber_channel_transmitmedia_t ipi-platform-
| |             | +---ro fiber-channel-sfp-speed?
transceiver-types:ddm_cmm_trans_fiber_channel_speed_t      ipi-platform-
| |             | +---ro sfp-infiniband-compliance-code?
transceiver-types:ddm_cmm_trans_sfp_infiniband_compliance_t ipi-platform-
| |             | +---ro sfp-escon-compliance-code?
transceiver-types:ddm_cmm_trans_sfp_escon_compliance_t     ipi-platform-
| |             | +---ro sfp-plus-cable-technology?
transceiver-types:ddm_cmm_trans_sfp_plus_cable_tech_t      ipi-platform-
| |             | +---ro serial-encoding-algorithm?
transceiver-types:ddm_cmm_trans_encoding_t                 ipi-platform-
| |             | +---ro link-length-kilometer?
| |             | +---ro link-length-meter?
| |             | +---ro om1-link-length?
| |             | +---ro om2-link-length?
| |             | +---ro om3-link-length?
| |             | +---ro om4-link-length?
| |             | +---ro vendor-name?
| |             | +---ro vendor-ieee-id?
| |             | +---ro vendor-part-number?
| |             | +---ro vendor-revision-number?
| |             | +---ro check-code?
| |             | +---ro extended-check-code?
| |             | +---ro nominal-signalling-rate?
| |             | +---ro maximum-signalling-rate?
| |             | +---ro minimum-signalling-rate?
| |             | +---ro vendor-serial-number?
| |             | +---ro vendor-manufacturing-date?

```

```

| | | +--ro ddm-type? ipi-platform-transceiver-
types:ddm_cmm_trans_ddm_support_t
| | | +--ro maximum-case-temperature? decimal64
| | | +--ro sfp-options-implemented? ipi-platform-
transceiver-types:ddm_cmm_trans_sfp_options_implemented_t
| | | +--ro monitors
| | | | +--ro monitor* [id]
| | | | +--ro id -> ../state/id
| | | | +--ro state
| | | | +--ro id? ipi-platform-transceiver-
types:cmm_smart_sfp_ddm_monitor_id_t
| | | | +--ro description? string
| | | | +--ro value? decimal64
| | | | +--ro high-alarm? decimal64
| | | | +--ro high-warning? decimal64
| | | | +--ro low-warning? decimal64
| | | | +--ro low-alarm? decimal64
| | | | +--ro monitor-alarm
| | | | +--ro state
| | | | +--ro alarm-id? ipi-platform-transceiver-
types:cmm_smart_sfp_ddm_monitor_id_t
| | | | +--ro alarm-type? ipi-platform-transceiver-
types:cmm_ddm_threshold_alarm_t
| | | | +--ro current-value? decimal64
| | | | +--ro threshold-minimum? decimal64
| | | | +--ro threshold-maximum? decimal64
| | | | +--ro protocol
| | | | +--ro state
| | | | +--ro protocol-running-state? ipi-platform-transceiver-
types:cmm_smart_sfp_protocol_running_state_t
| | | | +--ro protocol-local-status? ipi-platform-transceiver-
types:cmm_smart_sfp_protocol_status_t
| | | | +--ro protocol-remote-status? ipi-platform-transceiver-
types:cmm_smart_sfp_protocol_status_t
| | | | +--ro packets-rx? int32
| | | | +--ro packets-tx? int32
| | | | +--ro packets-error? int32
| | | | +--ro alarm
| | | | +--ro state
| | | | +--ro alarm-id? ipi-platform-transceiver-
types:cmm_smart_sfp_protocol_alarm_id_t
| | | | +--ro current-status? ipi-platform-transceiver-
types:cmm_smart_sfp_protocol_status_t
| | +--rw debug
| | | +--rw config
| | | | +--rw enable-cmm? empty
| | | | +--rw enable-ddm? empty {feature-list:NOT_HAVE_TIBIT}?
| | | +--ro state
| | | +--ro enable-cmm? empty
| | | +--ro enable-ddm? empty {feature-list:NOT_HAVE_TIBIT}?
| | | +--ro terminal-debug-status-cmm? cml-data-types:cml_on_off_t
| | | +--ro terminal-debug-status-ddm? cml-data-types:cml_on_off_t {feature-
list:NOT_HAVE_TIBIT}?

```

```

|  +--rw global
|  |  +--rw config
|  |  |  +--rw warning-repeat?                empty
|  |  |  +--rw locator-led-enable?            empty {feature-list:NOT_HAVE_TIBIT}?
|  |  |  +--rw ddm-monitor-time-interval?     uint16 {feature-
list:NOT_HAVE_TIBIT}?
|  |  |  +--rw service-unsupported-transceiver? empty {feature-list:NOT_HAVE_TIBIT}?
|  |  |  +--rw enable-ddm-monitor?           empty {feature-list:NOT_HAVE_TIBIT}?
|  |  +--ro state
|  |  |  +--ro warning-repeat?                empty
|  |  |  +--ro locator-led-enable?            empty {feature-list:NOT_HAVE_TIBIT}?
|  |  |  +--ro ddm-monitor-time-interval?     uint16 {feature-
list:NOT_HAVE_TIBIT}?
|  |  |  +--ro service-unsupported-transceiver? empty {feature-list:NOT_HAVE_TIBIT}?
|  |  |  +--ro enable-ddm-monitor?           empty {feature-list:NOT_HAVE_TIBIT}?
|  |  +--rw system-load-average-thresholds
|  |  |  +--rw system-load-average-threshold* [system-1min-load-avg-warning-threshold
system-1min-load-avg-alarm system-5min-load-avg-alarm system-15min-load-avg-alarm]
|  |  |  |  +--rw system-1min-load-avg-warning-threshold    -> ../config/system-1min-
load-avg-warning-threshold
|  |  |  |  +--rw system-1min-load-avg-alarm                -> ../config/system-1min-
load-avg-alarm
|  |  |  |  +--rw system-5min-load-avg-alarm                -> ../config/system-5min-
load-avg-alarm
|  |  |  |  +--rw system-15min-load-avg-alarm                -> ../config/system-15min-
load-avg-alarm
|  |  |  +--rw config
|  |  |  |  +--rw system-1min-load-avg-warning-threshold?   uint8
|  |  |  |  +--rw system-1min-load-avg-alarm?               uint8
|  |  |  |  +--rw system-5min-load-avg-alarm?               uint8
|  |  |  |  +--rw system-15min-load-avg-alarm?              uint8
|  |  |  +--ro state
|  |  |  |  +--ro system-1min-load-avg-warning-threshold?   uint8
|  |  |  |  +--ro system-1min-load-avg-alarm?               uint8
|  |  |  |  +--ro system-5min-load-avg-alarm?               uint8
|  |  |  |  +--ro system-15min-load-avg-alarm?              uint8
|  |  +--rw cpu-core-usage-thresholds
|  |  |  +--rw cpu-core-usage-threshold* [warning-threshold alarm-threshold]
|  |  |  |  +--rw warning-threshold    -> ../config/warning-threshold
|  |  |  |  +--rw alarm-threshold      -> ../config/alarm-threshold
|  |  |  +--rw config
|  |  |  |  +--rw warning-threshold?   uint8
|  |  |  |  +--rw alarm-threshold?     uint8
|  |  |  +--ro state
|  |  |  |  +--ro warning-threshold?   uint8
|  |  |  |  +--ro alarm-threshold?     uint8
|  |  +--rw gps-position {feature-list:HAVE_PTP_HW_OFFLOAD}?
|  |  |  +--rw config
|  |  |  |  +--rw (gps-position-option)?
|  |  |  |  +--:(gps-position-disable)
|  |  |  |  |  +--rw gps-position-disable?                empty
|  |  |  |  +--:(gps-survey-in-observation-time)

```

```

| | | | +---rw gps-survey-in-observation-time? uint32
| | | | +---rw gps-survey-in-position-accuracy? uint32
| | | | +---:(gps-fixed-latitude)
| | | | +---rw gps-fixed-latitude? decimal64
| | | | +---rw gps-fixed-longitude? decimal64
| | | | +---rw gps-fixed-altitude? decimal64
| | +---ro state
| | | +---ro (gps-position-option)?
| | | | +---:(gps-position-disable)
| | | | | +---ro gps-position-disable? empty
| | | | +---:(gps-survey-in-observation-time)
| | | | | +---ro gps-survey-in-observation-time? uint32
| | | | | +---ro gps-survey-in-position-accuracy? uint32
| | | | +---:(gps-fixed-latitude)
| | | | | +---ro gps-fixed-latitude? decimal64
| | | | | +---ro gps-fixed-longitude? decimal64
| | | | | +---ro gps-fixed-altitude? decimal64
| +---rw interfaces {feature-list:NOT_HAVE_TIBIT}?
| | +---rw interface* [interface-name]
| | | +---rw interface-name -> ../config/interface-name
| | | +---rw config
| | | | +---rw interface-name? -> /ipi-interface:interfaces/interface/
name
| | | | +---rw monitor-port? ipi-platform-types:cmm_monitor_state
| | | | +---rw poe-enable? empty
| | | | +---rw raon-aodu-port? ipi-platform-types:cmm_raon_aodu_state
{feature-list:HAVE_DUNE}?
| | | | +---rw transceiver-code? ipi-platform-transceiver-
types:ddm_transceiver_t
| | | | | +---rw wavelength? ipi-platform-types:cml_wavelength_t
| | | | | +---rw tx-disable? empty
| | | | | +---rw edfa-operating-mode? ipi-platform-types:edfa_operating_mode_t
| | | | | +---rw edfa-target-output-power? decimal64
| | | | | +---rw edfa-target-gain? decimal64
| | | | +---ro state
| | | | | +---ro interface-name? -> /ipi-interface:interfaces/interface/
name
| | | | | +---ro monitor-port? ipi-platform-types:cmm_monitor_state
| | | | | +---ro poe-enable? empty
| | | | | +---ro raon-aodu-port? ipi-platform-types:cmm_raon_aodu_state
{feature-list:HAVE_DUNE}?
| | | | | +---ro transceiver-code? ipi-platform-transceiver-
types:ddm_transceiver_t
| | | | | +---ro wavelength? ipi-platform-types:cml_wavelength_t
| | | | | +---ro tx-disable? empty
| | | | | +---ro edfa-operating-mode? ipi-platform-types:edfa_operating_mode_t
| | | | | +---ro edfa-target-output-power? decimal64
| | | | | +---ro edfa-target-gain? decimal64
| +---rw disk-activity-monitoring
| | +---rw config
| | | +---rw interval? uint16
| | | +---rw read-threshold? uint32

```

```
|      | +--rw write-threshold?   uint32
|      +--ro state
|      +--ro interval?           uint16
|      +--ro read-threshold?     uint32
|      +--ro write-threshold?    uint32
+--rw profiles
| +--rw hardware-profile
| | +--rw config
| | | +--rw flow-control?         empty {feature-
list:HAVE_BCM_UFT,feature-list:HAVE_DUNE}?
| | | +--rw micro-bfd?           empty {feature-
list:HAVE_CUSTOM1_HW_BFD,feature-list:NOT_HAVE_DNX}?
| | | +--rw aclif?               ipi-platform-types:platform_aclif_type_t
| | | +--rw seamless-bfd?       empty {feature-
list:HAVE_CUSTOM1_HW_BFD,feature-list:HAVE_SBFDF}?
| | | +--rw ufis9510-28dc-port-mode? ipi-platform-
types:platform_ufis9510_28dc_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--rw ufis9600-64x-port-mode? ipi-platform-
types:platform_ufis9600_64x_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--rw as7315_27x-port-mode?  ipi-platform-
types:platform_as7315_27x_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--rw as5916_as5912_54x-port-mode? ipi-platform-
types:platform_as5916_as5912_54x_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--rw as7316_26xb-port-mode?  ipi-platform-
types:platform_as7316_26xb_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--rw s9500_30xs-port-mode?   ipi-platform-
types:platform_s9500_30xs_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--rw ufis9600-32x-port-mode?  ipi-platform-
types:platform_ufis9600_32x_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--rw ufis9600-56dx-port-mode? ipi-platform-
types:platform_ufis9600_56dx_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--rw ufis9610-36d-port-mode?  ipi-platform-
types:platform_ufis9610_36d_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--rw custom-service-queue-profile? ipi-platform-
types:platform_qos_queue_profile_type_t {feature-list:HAVE_DUNE}?
| | | +--rw bgp-flowspec-mode?      ipi-platform-
types:platform_bgp_flowspec_mode_t {feature-list:HAVE_DUNE,feature-
list:HAVE_BGP_FLOWSPEC}?
| | +--ro state
| | | +--ro flow-control?         empty {feature-
list:HAVE_BCM_UFT,feature-list:HAVE_DUNE}?
| | | +--ro micro-bfd?           empty {feature-
list:HAVE_CUSTOM1_HW_BFD,feature-list:NOT_HAVE_DNX}?
| | | +--ro aclif?               ipi-platform-types:platform_aclif_type_t
| | | +--ro seamless-bfd?       empty {feature-
list:HAVE_CUSTOM1_HW_BFD,feature-list:HAVE_SBFDF}?
| | | +--ro ufis9510-28dc-port-mode? ipi-platform-
types:platform_ufis9510_28dc_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--ro ufis9600-64x-port-mode?  ipi-platform-
types:platform_ufis9600_64x_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--ro as7315_27x-port-mode?    ipi-platform-
types:platform_as7315_27x_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--ro as5916_as5912_54x-port-mode? ipi-platform-
types:platform_as5916_as5912_54x_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--ro as7316_26xb-port-mode?   ipi-platform-
types:platform_as7316_26xb_port_mode_type_t {feature-list:HAVE_DUNE}?
```

```

| | | +--ro s9500_30xs-port-mode? ipi-platform-
types:platform_s9500_30xs_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--ro ufis9600-32x-port-mode? ipi-platform-
types:platform_ufis9600_32x_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--ro ufis9600-56dx-port-mode? ipi-platform-
types:platform_ufis9600_56dx_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--ro ufis9610-36d-port-mode? ipi-platform-
types:platform_ufis9610_36d_port_mode_type_t {feature-list:HAVE_DUNE}?
| | | +--ro custom-service-queue-profile? ipi-platform-
types:platform_qos_queue_profile_type_t {feature-list:HAVE_DUNE}?
| | | +--ro bgp-flowspec-mode? ipi-platform-
types:platform_bgp_flowspec_mode_t {feature-list:HAVE_DUNE,feature-
list:HAVE_BGP_FLOWSPEC}?
| | +--rw filters
| | | +--rw config
| | | | +--rw ingress-ipv6? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw ingress-ipv6-extended? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw ingress-ipv6-extended-vlan? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw ingress-ipv4? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw ingress-ipv4-extended? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw ingress-ipv4-subif? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw ingress-ipv4-qos? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw ingress-arp? empty {feature-list:HAVE_ACL}?
| | | | +--rw ingress-ipv6-qos? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw ipv4-bgp-flowspec? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE,feature-list:HAVE_BGP_FLOWSPEC}?
| | | | +--rw ipv6-bgp-flowspec? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE,feature-list:HAVE_BGP_FLOWSPEC}?
| | | | +--rw qos? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw qos-extended? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw qos-policer? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw qos-ipv6? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw egress-ipv4? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_CUSTOM3_ACL}?
| | | | +--rw egress-layer2? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_CUSTOM3_ACL}?
| | | | +--rw ingress-layer2? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw ingress-layer2-extended? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw ingress-layer2-subif? empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--rw cfm-domain-name-string? empty {feature-list:HAVE_CFM,feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?

```

```
| | | | +--rw twamp-ipv4?                    empty {feature-
list:HAVE_TWAMP_HW_OFFLOAD,feature-list:HAVE_TWAMP,feature-list:HAVE_DUNE}?
| | | | +--rw twamp-ipv6?                    empty {feature-
list:HAVE_TWAMP_HW_OFFLOAD,feature-list:HAVE_TWAMP,feature-list:HAVE_DUNE}?
| | | | +--rw twamp-ipv6-mpls?               empty {feature-
list:HAVE_TWAMP_HW_OFFLOAD,feature-list:HAVE_TWAMP,feature-list:HAVE_DUNE}?
| | | | +--rw vxlan-arp-nd?                  empty {feature-list:HAVE_VXLAN,feature-
list:HAVE_DUNE}?
| | | | +--rw vxlan-multi-homing?           empty {feature-list:HAVE_VXLAN,feature-
list:HAVE_DUNE}?
| | | | +--rw evpn-mpls-multi-homing?       empty {feature-list:HAVE_NVO,feature-
list:HAVE_MPLS,feature-list:HAVE_DUNE}?
| | | | +--rw evpn-mpls-control-word?       empty {feature-list:HAVE_NVO,feature-
list:HAVE_MPLS,feature-list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| | | | +--rw dhcp-snoop?                   empty {feature-
list:HAVE_DHCP_SNOOP,feature-list:HAVE_DUNE}?
| | | | +--rw dhcp-snoop-ipv6?             empty {feature-
list:HAVE_DHCP_SNOOP,feature-list:HAVE_DUNE}?
| | | | +--rw ipsg?                         empty {feature-
list:HAVE_DHCP_SNOOP,feature-list:HAVE_DUNE}?
| | | | +--rw ipsg-ipv6?                   empty {feature-
list:HAVE_DHCP_SNOOP,feature-list:HAVE_BROADCOM}?
| | | | +--ro state
| | | | +--ro ingress-ipv6?                 empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro ingress-ipv6-extended?       empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro ingress-ipv6-extended-vlan?  empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro ingress-ipv4?                 empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro ingress-ipv4-extended?       empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro ingress-ipv4-subif?          empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro ingress-ipv4-qos?            empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro ingress-arp?                 empty {feature-list:HAVE_ACL}?
| | | | +--ro ingress-ipv6-qos?            empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro ipv4-bgp-flowspec?            empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE,feature-list:HAVE_BGP_FLOWSPEC}?
| | | | +--ro ipv6-bgp-flowspec?            empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE,feature-list:HAVE_BGP_FLOWSPEC}?
| | | | +--ro qos?                          empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro qos-extended?                empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro qos-policer?                 empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro qos-ipv6?                    empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro egress-ipv4?                  empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_CUSTOM3_ACL}?
| | | | +--ro egress-layer2?                empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_CUSTOM3_ACL}?
```

```

| | | | +--ro ingress-layer2?                empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro ingress-layer2-extended?       empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro ingress-layer2-subif?          empty {feature-list:HAVE_ACL,feature-
list:HAVE_DUNE}?
| | | | +--ro cfm-domain-name-string?        empty {feature-list:HAVE_CFM,feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| | | | +--ro twamp-ipv4?                    empty {feature-
list:HAVE_TWAMP_HW_OFFLOAD,feature-list:HAVE_TWAMP,feature-list:HAVE_DUNE}?
| | | | +--ro twamp-ipv6?                    empty {feature-
list:HAVE_TWAMP_HW_OFFLOAD,feature-list:HAVE_TWAMP,feature-list:HAVE_DUNE}?
| | | | +--ro twamp-ipv6-mpls?               empty {feature-
list:HAVE_TWAMP_HW_OFFLOAD,feature-list:HAVE_TWAMP,feature-list:HAVE_DUNE}?
| | | | +--ro vxlan-arp-nd?                  empty {feature-list:HAVE_VXLAN,feature-
list:HAVE_DUNE}?
| | | | +--ro vxlan-multi-homing?            empty {feature-list:HAVE_VXLAN,feature-
list:HAVE_DUNE}?
| | | | +--ro evpn-mpls-multi-homing?        empty {feature-list:HAVE_NVO,feature-
list:HAVE_MPLS,feature-list:HAVE_DUNE}?
| | | | +--ro evpn-mpls-control-word?        empty {feature-list:HAVE_NVO,feature-
list:HAVE_MPLS,feature-list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| | | | +--ro dhcp-snoop?                    empty {feature-
list:HAVE_DHCP_SNOOP,feature-list:HAVE_DUNE}?
| | | | +--ro dhcp-snoop-ipv6?              empty {feature-
list:HAVE_DHCP_SNOOP,feature-list:HAVE_DUNE}?
| | | | +--ro ipsg?                          empty {feature-
list:HAVE_DHCP_SNOOP,feature-list:HAVE_DUNE}?
| | | | +--ro ipsg-ipv6?                     empty {feature-
list:HAVE_DHCP_SNOOP,feature-list:HAVE_BROADCOM}?
| | |   +--ro tcam-utilization {feature-list:HAVE_ACL}?
| | |     +--ro state
| | |       | +--ro warning-threshold-level?   int32
| | |       | +--ro critical-alert-threshold-level? int32
| | |       +--ro filter-groups
| | |         +--ro filter-group* [group-id]
| | |           +--ro group-id    -> ../state/group-id
| | |           +--ro state
| | |             +--ro group-id?      uint32
| | |             +--ro group-name?    cml-data-types:cml_line_t
| | |             +--ro free-entries?  int32
| | |             +--ro used-entries?  int32
| | |             +--ro used-percentage? int32
| | |             +--ro total-entries? int32
| | |             +--ro dedicated-entries? int32
| | |             +--ro shared-entries? int32
| |   +--rw statistics
| |     +--rw config
| |       | +--rw ingress-acl?              empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| |       | +--rw egress-acl?               empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| |       | +--rw ingress-qos?              empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?

```

```

| | | +--rw attachment-circuit-logical-if?      empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| | | +--rw tunnel-logical-if?                  empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| | | +--rw evpn-mpls-stats?                    empty {feature-
list:HAVE_NVO,feature-list:HAVE_MPLS,feature-list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| | | +--rw mpls-pseudowire?                    empty {feature-
list:HAVE_DUNE,feature-list:HAVE_MPLS_STATS,feature-list:NOT_HAVE_DNX}?
| | | +--rw cfm-frame-loss-measurements?        empty {feature-
list:HAVE_DUNE,feature-list:HAVE_CFM}?
| | | +--rw cfm-continuity-check-messages?      empty {feature-
list:HAVE_DUNE,feature-list:CCM_HW_OFFLOAD,feature-list:NOT_HAVE_DNX}?
| | | +--rw virtual-output-queue-full-color?    empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| | | +--rw virtual-output-queue-forward-drop?  empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| |   +--ro state
| |     +--ro ingress-acl?                       empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| |     +--ro egress-acl?                       empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| |     +--ro ingress-qos?                      empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| |     +--ro attachment-circuit-logical-if?    empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| |     +--ro tunnel-logical-if?                empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| |     +--ro evpn-mpls-stats?                  empty {feature-
list:HAVE_NVO,feature-list:HAVE_MPLS,feature-list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| |     +--ro mpls-pseudowire?                  empty {feature-
list:HAVE_DUNE,feature-list:HAVE_MPLS_STATS,feature-list:NOT_HAVE_DNX}?
| |     +--ro cfm-frame-loss-measurements?      empty {feature-
list:HAVE_DUNE,feature-list:HAVE_CFM}?
| |     +--ro cfm-continuity-check-messages?    empty {feature-
list:HAVE_DUNE,feature-list:CCM_HW_OFFLOAD,feature-list:NOT_HAVE_DNX}?
| |     +--ro virtual-output-queue-full-color?  empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
| |     +--ro virtual-output-queue-forward-drop? empty {feature-
list:HAVE_DUNE,feature-list:NOT_HAVE_DNX}?
|   +--rw forwarding-profiles
|     +--rw kaps {feature-list:HAVE_DUNE,feature-list:HAVE_BCM_UFT,feature-
list:NOT_HAVE_DNX}?
|       +--rw config
|         +--rw profile-type?   ipi-platform-types:platform_kaps_profile_type_t
|         +--ro state
|         +--ro profile-type?   ipi-platform-types:platform_kaps_profile_type_t
|       +--rw external-tcam {feature-list:HAVE_DUNE,feature-list:HAVE_BCM_UFT,feature-
list:NOT_HAVE_DNX}?
|         +--rw config
|           +--rw profile-type?   ipi-platform-types:platform_ext_tcam_profile_type_t
|           +--ro state
|           +--ro profile-type?   ipi-platform-types:platform_ext_tcam_profile_type_t
|         +--rw custom-tcam {feature-list:HAVE_DUNE,feature-list:HAVE_BCM_UFT,feature-
list:NOT_HAVE_DNX}?
|           +--rw config!

```

```

| | | +--rw profile-type      ipi-platform-types:platform_tcam_custom_profile_t
| | | +--rw ipv4-percentage   uint8
| | | +--rw ipv6-percentage   uint8
| | | +--ro state
| | |   +--ro profile-type     ipi-platform-types:platform_tcam_custom_profile_t
| | |   +--ro ipv4-percentage   uint8
| | |   +--ro ipv6-percentage   uint8
| | +--ro table-limit {feature-list:HAVE_BCM_UFT}?
| |   +--ro kaps* [profile] {feature-list:HAVE_DUNE}?
| |   | +--ro profile    -> ../state/profile
| |   | +--ro state
| |   | +--ro profile?      ipi-platform-
types:platform_kaps_forwading_profile_t
| |   |   +--ro is-active?   boolean
| |   |   +--ro public-db-size? uint32
| |   |   +--ro private-db-size? uint32
| |   +--ro external-tcam* [profile] {feature-list:HAVE_DUNE,feature-
list:HAVE_ELK_TCAM}?
| |   | +--ro profile    -> ../state/profile
| |   | +--ro state
| |   | +--ro profile?      ipi-platform-
types:platform_elk_tcam_forwading_profile_t
| |   |   +--ro is-active?   boolean
| |   |   +--ro ipv4-db-size? uint32
| |   |   +--ro ipv6-db-size? uint32
| |   +--ro state {feature-list:HAVE_BCM_UFT}?
+--rw hardware
| +--rw load-balance {feature-list:HAVE_BROADCOM}?
| | +--rw config!
| | | +--rw enable          empty
| | | +--rw mpls-label-based? empty
| | | +--ro state
| | | | +--ro enable          empty
| | | | +--ro mpls-label-based? empty
| | +--rw l2 {feature-list:HAVE_L2}?
| | | +--rw config
| | | | +--rw dest-mac-based?   empty {feature-list:NOT_HAVE_DNX}?
| | | | +--rw src-mac-based?    empty {feature-list:NOT_HAVE_DNX}?
| | | | +--rw ether-type-based? empty
| | | | +--rw vlan-based?       empty
| | | | +--ro state
| | | |   +--ro dest-mac-based?   empty {feature-list:NOT_HAVE_DNX}?
| | | |   +--ro src-mac-based?    empty {feature-list:NOT_HAVE_DNX}?
| | | |   +--ro ether-type-based? empty
| | | |   +--ro vlan-based?       empty
| | +--rw ipv4 {feature-list:HAVE_L3}?
| | | +--rw config
| | | | +--rw src-ipv4-address-based?   empty {feature-list:NOT_HAVE_DNX}?
| | | | +--rw dest-ipv4-address-based?  empty {feature-list:NOT_HAVE_DNX}?
| | | | +--rw src-l4-port-based?        empty {feature-list:NOT_HAVE_DNX}?
| | | | +--rw dest-l4-port-based?       empty {feature-list:NOT_HAVE_DNX}?

```

```

| | | | +--rw protocol-id-based?          empty
| | | +--ro state
| | |   +--ro src-ipv4-address-based?     empty {feature-list:NOT_HAVE_DNX}?
| | |   +--ro dest-ipv4-address-based?    empty {feature-list:NOT_HAVE_DNX}?
| | |   +--ro src-l4-port-based?          empty {feature-list:NOT_HAVE_DNX}?
| | |   +--ro dest-l4-port-based?         empty {feature-list:NOT_HAVE_DNX}?
| | |   +--ro protocol-id-based?         empty
| | +--rw ipv6 {feature-list:HAVE_L3}?
| | | +--rw config
| | | | +--rw src-ipv6-address-based?     empty {feature-list:NOT_HAVE_DNX}?
| | | | +--rw dest-ipv6-address-based?    empty {feature-list:NOT_HAVE_DNX}?
| | | | +--rw src-l4-port-based?          empty {feature-list:NOT_HAVE_DNX}?
| | | | +--rw dest-l4-port-based?         empty {feature-list:NOT_HAVE_DNX}?
| | | | +--rw next-header-based?         empty
| | | +--ro state
| | |   +--ro src-ipv6-address-based?     empty {feature-list:NOT_HAVE_DNX}?
| | |   +--ro dest-ipv6-address-based?    empty {feature-list:NOT_HAVE_DNX}?
| | |   +--ro src-l4-port-based?          empty {feature-list:NOT_HAVE_DNX}?
| | |   +--ro dest-l4-port-based?         empty {feature-list:NOT_HAVE_DNX}?
| | |   +--ro next-header-based?         empty
| | +--rw port-channel
| +--ro dram-tune {feature-list:HAVE_BROADCOM}?
| | +--ro state
| |   +--ro dram-tune-status?  int32 {feature-list:HAVE_BROADCOM}?
| +--rw cpu-queue {feature-list:HAVE_BROADCOM}?
| | +--rw rate-limits
| |   +--rw rate-limit* [queue-name]
| |     +--rw queue-name      -> ../config/queue-name
| |     +--rw config
| |       | +--rw queue-name?    ipi-platform-types:platform_cpu_queue_name_t
| |       | +--rw rate?          int32
| |       | +--rw monitor-status? ipi-platform-types:platform_cpu_queue_monitor_t
| |       | {feature-list:HAVE_DUNE}?
| |       | +--ro state
| |       |   +--ro queue-name?    ipi-platform-types:platform_cpu_queue_name_t
| |       |   +--ro rate?          int32
| |       |   +--ro monitor-status? ipi-platform-types:platform_cpu_queue_monitor_t
| |       | {feature-list:HAVE_DUNE}?
| |     +--rw mac-ageing
| |     | +--rw config
| |     | +--ro state
| |     +--rw platform
| |       +--rw config
| |         +--rw soc?  ipi-platform-types:platform_soc_type_t
+--rw qsfp-dds
  +--rw qsfp-dd* [fp-port]
    +--rw fp-port      -> ../config/fp-port
    +--rw config
      | +--rw fp-port?          uint8
      | +--rw application?     uint8
      | +--rw service-disable? empty

```

```

+--ro state
| +--ro fp-port?          uint8
| +--ro application?     uint8
| +--ro service-disable? empty
+--rw host
| +--rw prbs
| | +--rw generator
| | | +--rw config
| | | | +--rw type?      ipi-platform-cmis-types:cmm_cmis_prbs_type_t
| | | | +--rw location?  ipi-platform-cmis-types:cmm_cmis_prbs_location_t
| | | | +--ro state
| | | |   +--ro type?    ipi-platform-cmis-types:cmm_cmis_prbs_type_t
| | | |   +--ro location? ipi-platform-cmis-types:cmm_cmis_prbs_location_t
| | | +--rw checker
| | |   +--rw config
| | | | +--rw type?      ipi-platform-cmis-types:cmm_cmis_prbs_type_t
| | | | +--rw location?  ipi-platform-cmis-types:cmm_cmis_prbs_location_t
| | |   +--ro state
| | |     +--ro type?    ipi-platform-cmis-types:cmm_cmis_prbs_type_t
| | |     +--ro location? ipi-platform-cmis-types:cmm_cmis_prbs_location_t
| | +--rw loopback
| | | +--rw config
| | | | +--rw type?      ipi-platform-cmis-types:cmm_cmis_loopback_type_t
| | | | +--ro state
| | | |   +--ro type?    ipi-platform-cmis-types:cmm_cmis_loopback_type_t
| | +--rw lanes
| | | +--rw lane* [lane-number]
| | |   +--rw lane-number  -> ../config/lane-number
| | |   +--rw config
| | | | +--rw lane-number?  uint8
| | |   +--ro state
| | | | +--ro lane-number?  uint8
| | |   +--rw thresholds
| | | | +--rw threshold* [id]
| | | |   +--rw id          -> ../config/id
| | | |   +--rw config
| | | | | +--rw id?        ipi-platform-cmis-
types:cmm_ccmis_host_lane_thres_id_t
| | | | | +--rw high-alarm?  decimal64
| | | | | +--rw low-alarm?   decimal64
| | | | | +--rw high-warning? decimal64
| | | | | +--rw low-warning? decimal64
| | | |   +--ro state
| | | |     +--ro id?        ipi-platform-cmis-
types:cmm_ccmis_host_lane_thres_id_t
| | | |     +--ro high-alarm?  decimal64
| | | |     +--ro low-alarm?   decimal64
| | | |     +--ro high-warning? decimal64
| | | |     +--ro low-warning? decimal64
+--rw media
| +--rw prbs

```

```

| | +--rw generator
| | | +--rw config
| | | | +--rw type?      ipi-platform-cmis-types:cmm_cmis_prbs_type_t
| | | | +--rw location? ipi-platform-cmis-types:cmm_cmis_prbs_location_t
| | | | +--ro state
| | | |   +--ro type?      ipi-platform-cmis-types:cmm_cmis_prbs_type_t
| | | |   +--ro location? ipi-platform-cmis-types:cmm_cmis_prbs_location_t
| | +--rw checker
| | | +--rw config
| | | | +--rw type?      ipi-platform-cmis-types:cmm_cmis_prbs_type_t
| | | | +--rw location? ipi-platform-cmis-types:cmm_cmis_prbs_location_t
| | | | +--ro state
| | | |   +--ro type?      ipi-platform-cmis-types:cmm_cmis_prbs_type_t
| | | |   +--ro location? ipi-platform-cmis-types:cmm_cmis_prbs_location_t
| +--rw loopback
| | +--rw config
| | | +--rw type?      ipi-platform-cmis-types:cmm_cmis_loopback_type_t
| | | +--ro state
| | |   +--ro type?      ipi-platform-cmis-types:cmm_cmis_loopback_type_t
| +--rw lanes
| | +--rw lane* [lane-number]
| | | +--rw lane-number -> ../config/lane-number
| | | +--rw config
| | | | +--rw lane-number? uint8
| | | | +--ro state
| | | | | +--ro lane-number? uint8
| | | | +--rw laser
| | | | | +--rw config
| | | | | | +--rw channel?      int16
| | | | | | +--rw grid?        ipi-platform-cmis-
types:cmm_cmis_laser_grid_spacing_t
| | | | | | | +--rw fine-tune-freq? decimal64
| | | | | | | +--rw output-power? decimal64
| | | | | | +--ro state
| | | | | | |   +--ro channel?      int16
| | | | | | |   +--ro grid?        ipi-platform-cmis-
types:cmm_cmis_laser_grid_spacing_t
| | | | | | |   +--ro fine-tune-freq? decimal64
| | | | | | |   +--ro output-power? decimal64
| | | | +--rw thresholds
| | | | | +--rw threshold* [id]
| | | | | | +--rw id          -> ../config/id
| | | | | | +--rw config
| | | | | | | +--rw id?        ipi-platform-cmis-
types:cmm_ccmis_media_lane_thres_id_t
| | | | | | | +--rw high-alarm?   decimal64
| | | | | | | +--rw low-alarm?    decimal64
| | | | | | | +--rw high-warning? decimal64
| | | | | | | +--rw low-warning?  decimal64
| | | | | +--ro state

```

```

|          +--ro id?          ipi-platform-cmis-
types:cmm_ccmis_media_lane_thres_id_t
|          +--ro high-alarm?  decimal64
|          +--ro low-alarm?   decimal64
|          +--ro high-warning? decimal64
|          +--ro low-warning? decimal64
+--rw laser
| +--rw config
| | +--rw channel?          int16
| | +--rw grid?            ipi-platform-cmis-
types:cmm_ccmis_laser_grid_spacing_t
| | +--rw fine-tune-freq?   decimal64
| | +--rw output-power?     decimal64
| +--ro state
|   +--ro channel?          int16
|   +--ro grid?             ipi-platform-cmis-
types:cmm_ccmis_laser_grid_spacing_t
|     +--ro fine-tune-freq?  decimal64
|     +--ro output-power?    decimal64
+--rw thresholds
  +--rw threshold* [id]
    +--rw id                -> ../config/id
    +--rw config
      | +--rw id?            ipi-platform-cmis-types:cmm_ccmis_thres_id_t
      | +--rw high-alarm?   decimal64
      | +--rw low-alarm?    decimal64
      | +--rw high-warning? decimal64
      | +--rw low-warning?  decimal64
      +--ro state
        +--ro id?            ipi-platform-cmis-types:cmm_ccmis_thres_id_t
        +--ro high-alarm?   decimal64
        +--ro low-alarm?    decimal64
        +--ro high-warning? decimal64
        +--ro low-warning?  decimal64

rpcs:
  +---x tibit-olt-microplug-set-management-vlan-tpid {feature-list:NOT_HAVE_TIBIT}?
  | +---w input
  |   +---w interface-name  string
  |   +---w vlan-tpid       ipi-platform-transceiver-tibit-
types:trans_tibit_cmm_tpid_t
  +---x tibit-olt-microplug-set-management-vlan-id {feature-list:NOT_HAVE_TIBIT}?
  | +---w input
  |   +---w interface-name  string
  |   +---w vlan-id         uint16
  +---x tibit-olt-microplug-set-ethernet-mac-address {feature-list:NOT_HAVE_TIBIT}?
  | +---w input
  |   +---w interface-name  string
  |   +---w mac-address     yang:mac-address
  +---x tibit-olt-microplug-set-next-active-firmware-bank {feature-
list:NOT_HAVE_TIBIT}?

```

```
| +---w input
|   +---w interface-name    string
|   +---w bank-id          uint8
+---x tibit-olt-microplug-reboot {feature-list:NOT_HAVE_TIBIT}?
| +---w input
|   +---w interface-name    string
+---x ddm-clear-transceiver-alarm-all {feature-list:NOT_HAVE_TIBIT}?
+---x ddm-clear-transceiver-alarm {feature-list:NOT_HAVE_TIBIT}?
| +---w input
|   +---w name              string
+---x cmm-terminal-debug-ddm-on {feature-list:NOT_HAVE_TIBIT}?
+---x cmm-terminal-debug-ddm-off {feature-list:NOT_HAVE_TIBIT}?
+---x cmm-terminal-debug-cmm-on {feature-list:HAVE_CMMD}?
+---x cmm-terminal-debug-cmm-off {feature-list:HAVE_CMMD}?

notifications:
  +---n bmc-lower-non-critical-low-threshold-notification {feature-
list:NOT_HAVE_TIBIT}?
  | +--ro severity?          cml-data-types:cml_notif_severity_t
  | +--ro eventClass?       cml-data-types:cml_notif_class_t
  | +--ro name?             string
  | +--ro lower-non-critical? decimal64
  | +--ro threshold?        decimal64
  | +--ro units?            string
  | +--ro event-type?       ipi-platform-types:cmm_bmc_event_type_t
  +---n bmc-lower-non-critical-high-threshold-notification {feature-
list:NOT_HAVE_TIBIT}?
  | +--ro severity?          cml-data-types:cml_notif_severity_t
  | +--ro eventClass?       cml-data-types:cml_notif_class_t
  | +--ro name?             string
  | +--ro lower-non-critical? decimal64
  | +--ro threshold?        decimal64
  | +--ro units?            string
  | +--ro event-type?       ipi-platform-types:cmm_bmc_event_type_t
  +---n bmc-lower-critical-low-threshold-notification {feature-list:NOT_HAVE_TIBIT}?
  | +--ro severity?          cml-data-types:cml_notif_severity_t
  | +--ro eventClass?       cml-data-types:cml_notif_class_t
  | +--ro name?             string
  | +--ro lower-critical?   decimal64
  | +--ro threshold?        decimal64
  | +--ro units?            string
  | +--ro event-type?       ipi-platform-types:cmm_bmc_event_type_t
  +---n bmc-lower-critical-high-threshold-notification {feature-list:NOT_HAVE_TIBIT}?
  | +--ro severity?          cml-data-types:cml_notif_severity_t
  | +--ro eventClass?       cml-data-types:cml_notif_class_t
  | +--ro name?             string
  | +--ro lower-critical?   decimal64
  | +--ro threshold?        decimal64
  | +--ro units?            string
  | +--ro event-type?       ipi-platform-types:cmm_bmc_event_type_t
```



```

+---n bmc-lower-non-recoverable-low-threshold-notification {feature-
list:NOT_HAVE_TIBIT}?
| +---ro severity?          cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro name?             string
| +---ro lower-non-recoverable? decimal64
| +---ro threshold?        decimal64
| +---ro units?            string
| +---ro event-type?       ipi-platform-types:cmm_bmc_event_type_t
+---n bmc-lower-non-recoverable-high-threshold-notification {feature-
list:NOT_HAVE_TIBIT}?
| +---ro severity?          cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro name?             string
| +---ro lower-non-recoverable? decimal64
| +---ro threshold?        decimal64
| +---ro units?            string
| +---ro event-type?       ipi-platform-types:cmm_bmc_event_type_t
+---n bmc-upper-non-critical-low-threshold-notification {feature-
list:NOT_HAVE_TIBIT}?
| +---ro severity?          cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro name?             string
| +---ro upper-non-critical? decimal64
| +---ro threshold?        decimal64
| +---ro units?            string
| +---ro event-type?       ipi-platform-types:cmm_bmc_event_type_t
+---n bmc-upper-non-critical-high-threshold-notification {feature-
list:NOT_HAVE_TIBIT}?
| +---ro severity?          cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro name?             string
| +---ro upper-non-critical? decimal64
| +---ro threshold?        decimal64
| +---ro units?            string
| +---ro event-type?       ipi-platform-types:cmm_bmc_event_type_t
+---n bmc-upper-critical-low-threshold-notification {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?          cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro name?             string
| +---ro upper-critical?   decimal64
| +---ro threshold?        decimal64
| +---ro units?            string
| +---ro event-type?       ipi-platform-types:cmm_bmc_event_type_t
+---n bmc-upper-critical-high-threshold-notification {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?          cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro name?             string
| +---ro upper-critical?   decimal64
| +---ro threshold?        decimal64
| +---ro units?            string

```

```
| +--ro event-type?          ipi-platform-types:cmm_bmc_event_type_t
+---n bmc-upper-non-recoverable-low-threshold-notification {feature-
list:NOT_HAVE_TIBIT}?
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?             string
| +--ro upper-non-recoverable? decimal64
| +--ro threshold?        decimal64
| +--ro units?            string
| +--ro event-type?       ipi-platform-types:cmm_bmc_event_type_t
+---n bmc-upper-non-recoverable-high-threshold-notification {feature-
list:NOT_HAVE_TIBIT}?
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?             string
| +--ro upper-non-recoverable? decimal64
| +--ro threshold?        decimal64
| +--ro units?            string
| +--ro event-type?       ipi-platform-types:cmm_bmc_event_type_t
+---n bmc-device-state-notification {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?             string
| +--ro operational-status? string
+---n cpu-load-15min-alert
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?             string
| +--ro cpu-15min-load-percentage? decimal64
| +--ro cpu-15min-alert-threshold? uint8
+---n cpu-load-15min-alert-recovery
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?             string
| +--ro cpu-15min-load-percentage? decimal64
| +--ro cpu-15min-alert-threshold? uint8
+---n cpu-load-5min-alert
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?             string
| +--ro cpu-5min-load-percentage? decimal64
| +--ro cpu-5min-alert-threshold? uint8
+---n cpu-load-5min-alert-recovery
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?             string
| +--ro cpu-5min-load-percentage? decimal64
| +--ro cpu-5min-alert-threshold? uint8
+---n cpu-load-1min-critical
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
```

```

| +--ro name? string
| +--ro cpu-lmin-load-percentage? decimal64
| +--ro cpu-lmin-critical-threshold? uint8
+---n cpu-load-lmin-critical-recovery
| +--ro severity? cml-data-types:cml_notif_severity_t
| +--ro eventClass? cml-data-types:cml_notif_class_t
| +--ro name? string
| +--ro cpu-lmin-load-percentage? decimal64
| +--ro cpu-lmin-critical-threshold? uint8
+---n cpu-load-lmin-alert
| +--ro severity? cml-data-types:cml_notif_severity_t
| +--ro eventClass? cml-data-types:cml_notif_class_t
| +--ro name? string
| +--ro cpu-lmin-load-percentage? decimal64
| +--ro cpu-lmin-alert-threshold? uint8
+---n cpu-load-lmin-alert-recovery
| +--ro severity? cml-data-types:cml_notif_severity_t
| +--ro eventClass? cml-data-types:cml_notif_class_t
| +--ro name? string
| +--ro cpu-lmin-load-percentage? decimal64
| +--ro cpu-lmin-alert-threshold? uint8
+---n storage-usage-rising-alert
| +--ro severity? cml-data-types:cml_notif_severity_t
| +--ro eventClass? cml-data-types:cml_notif_class_t
| +--ro name? string
| +--ro used-memory? uint64
| +--ro usage-alert-threshold? int32
| +--ro mount-point? string
+---n storage-usage-critical-alert
| +--ro severity? cml-data-types:cml_notif_severity_t
| +--ro eventClass? cml-data-types:cml_notif_class_t
| +--ro name? string
| +--ro used-memory? uint64
| +--ro usage-critical-threshold? int32
| +--ro mount-point? string
+---n storage-usage-recovery-from-alert-level
| +--ro severity? cml-data-types:cml_notif_severity_t
| +--ro eventClass? cml-data-types:cml_notif_class_t
| +--ro name? string
| +--ro used-memory? uint64
| +--ro usage-alert-threshold? int32
| +--ro mount-point? string
+---n storage-usage-recovery-from-critical-level
| +--ro severity? cml-data-types:cml_notif_severity_t
| +--ro eventClass? cml-data-types:cml_notif_class_t
| +--ro name? string
| +--ro used-memory? uint64
| +--ro usage-critical-threshold? int32
| +--ro mount-point? string
+---n storage-remaining-life-rising-alert

```

```

| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro name?                   string
| +--ro remaining-life?         int32
| +--ro remain-life-alert-threshold? int32
+---n storage-remaining-life-rising-critical
| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro name?                   string
| +--ro remaining-life?         int32
| +--ro remain-life-critical-threshold? int32
+---n storage-available-reserved-space-rising-alert
| +--ro severity?                cml-data-
types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro name?                   string
| +--ro available-reserved-space? int32
| +--ro available-reserved-space-alert-threshold? int32
+---n storage-available-reserved-space-rising-critical
| +--ro severity?                cml-data-
types:cml_notif_severity_t
| +--ro eventClass?             cml-data-
types:cml_notif_class_t
| +--ro name?                   string
| +--ro available-reserved-space? int32
| +--ro available-reserved-space-critical-threshold? int32
+---n storage-reallocated-sector-count-rising-alert
| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro name?                   string
| +--ro reallocated-sector-count? int32
+---n storage-uncorrectable-sector-count-rising-critical
| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro name?                   string
| +--ro uncorrectable-sector-count? int32
+---n storage-harddisk-monitoring-read-alert
| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro name?                   string
| +--ro read-average?           int32
| +--ro read-threshold?        int32
+---n storage-harddisk-recovery-from-read-alert-level
| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro name?                   string
| +--ro read-average?           int32
| +--ro read-threshold?        int32
+---n storage-harddisk-monitoring-write-alert
| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t

```

```

| +--ro name?                string
| +--ro write-average?      int32
| +--ro write-threshold?   int32
+---n storage-harddisk-recovery-from-write-alert-level
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro write-average?     int32
| +--ro write-threshold?   int32
+---n storage-storage-status-alert
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro storage-status?    ipi-platform-types:cml_cmm_storage_status_t
+---n storage-storage-status-critical
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro storage-status?    ipi-platform-types:cml_cmm_storage_status_t
+---n ram-usage-rising-critical
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro used-memory?       uint64
| +--ro usage-critical-threshold? uint32
+---n ram-usage-rising-alert
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro used-memory?       uint64
| +--ro usage-alert-threshold? uint32
+---n ram-usage-recovery-from-critical-level
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro used-memory?       uint64
| +--ro usage-critical-threshold? uint32
+---n ram-usage-recovery-from-alert-level
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro used-memory?       uint64
| +--ro usage-alert-threshold? uint32
+---n transceiver-inserted {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro port-no?           uint8
| +--ro type?              ipi-platform-transceiver-types:ddm_cmm_trans_type_t
| +--ro vendor-name?       string

```

```
| +--ro vendor-serial-number?  string
| +--ro connector-type?        ipi-platform-transceiver-
types:dmm_cmm_trans_connector_type_t
+---n transceiver-removed {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?              cml-data-types:cml_notif_severity_t
| +--ro eventClass?           cml-data-types:cml_notif_class_t
| +--ro name?                  string
| +--ro port-no?               uint8
| +--ro type?                  ipi-platform-transceiver-types:dmm_cmm_trans_type_t
| +--ro vendor-name?           string
| +--ro vendor-serial-number?  string
| +--ro connector-type?        ipi-platform-transceiver-
types:dmm_cmm_trans_connector_type_t
+---n faulty-transceiver-inserted {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?              cml-data-types:cml_notif_severity_t
| +--ro eventClass?           cml-data-types:cml_notif_class_t
| +--ro name?                  string
| +--ro port-no?               uint8
| +--ro type?                  ipi-platform-transceiver-types:dmm_cmm_trans_type_t
+---n incompatible-transceiver-inserted {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?              cml-data-types:cml_notif_severity_t
| +--ro eventClass?           cml-data-types:cml_notif_class_t
| +--ro name?                  string
| +--ro port-no?               uint8
+---n incompatible-transceiver-removed {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?              cml-data-types:cml_notif_severity_t
| +--ro eventClass?           cml-data-types:cml_notif_class_t
| +--ro name?                  string
| +--ro port-no?               uint8
+---n frequency-error-high-critical {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?              cml-data-types:cml_notif_severity_t
| +--ro eventClass?           cml-data-types:cml_notif_class_t
| +--ro name?                  string
| +--ro frequency-error?       decimal64
| +--ro frequency-error-critical-min-threshold?  decimal64
| +--ro frequency-error-critical-max-threshold?  decimal64
+---n frequency-error-low-critical {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?              cml-data-types:cml_notif_severity_t
| +--ro eventClass?           cml-data-types:cml_notif_class_t
| +--ro name?                  string
| +--ro frequency-error?       decimal64
| +--ro frequency-error-critical-min-threshold?  decimal64
| +--ro frequency-error-critical-max-threshold?  decimal64
+---n frequency-error-high-alert {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?              cml-data-types:cml_notif_severity_t
| +--ro eventClass?           cml-data-types:cml_notif_class_t
| +--ro name?                  string
| +--ro frequency-error?       decimal64
| +--ro frequency-error-alert-min-threshold?    decimal64
| +--ro frequency-error-alert-max-threshold?    decimal64
+---n frequency-error-low-alert {feature-list:NOT_HAVE_TIBIT}?
```

```

| +--ro severity?                               cml-data-types:cml_notif_severity_t
| +--ro eventClass?                             cml-data-types:cml_notif_class_t
| +--ro name?                                   string
| +--ro frequency-error?                       decimal64
| +--ro frequency-error-alert-min-threshold?   decimal64
| +--ro frequency-error-alert-max-threshold?   decimal64
+---n frequency-error-recovery {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?                               cml-data-types:cml_notif_severity_t
| +--ro eventClass?                             cml-data-types:cml_notif_class_t
| +--ro name?                                   string
| +--ro frequency-error?                       decimal64
+---n wavelength-error-high-critical {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?                               cml-data-types:cml_notif_severity_t
| +--ro eventClass?                             cml-data-types:cml_notif_class_t
| +--ro name?                                   string
| +--ro wavelength-error?                     decimal64
| +--ro wavelength-error-critical-min-threshold? decimal64
| +--ro wavelength-error-critical-max-threshold? decimal64
+---n wavelength-error-low-critical {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?                               cml-data-types:cml_notif_severity_t
| +--ro eventClass?                             cml-data-types:cml_notif_class_t
| +--ro name?                                   string
| +--ro wavelength-error?                     decimal64
| +--ro wavelength-error-critical-min-threshold? decimal64
| +--ro wavelength-error-critical-max-threshold? decimal64
+---n wavelength-error-high-alert {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?                               cml-data-types:cml_notif_severity_t
| +--ro eventClass?                             cml-data-types:cml_notif_class_t
| +--ro name?                                   string
| +--ro wavelength-error?                     decimal64
| +--ro wavelength-error-alert-min-threshold?   decimal64
| +--ro wavelength-error-alert-max-threshold?   decimal64
+---n wavelength-error-low-alert {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?                               cml-data-types:cml_notif_severity_t
| +--ro eventClass?                             cml-data-types:cml_notif_class_t
| +--ro name?                                   string
| +--ro wavelength-error?                     decimal64
| +--ro wavelength-error-alert-min-threshold?   decimal64
| +--ro wavelength-error-alert-max-threshold?   decimal64
+---n wavelength-error-recovery {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?                               cml-data-types:cml_notif_severity_t
| +--ro eventClass?                             cml-data-types:cml_notif_class_t
| +--ro name?                                   string
| +--ro wavelength-error?                     decimal64
+---n thermoelectric-cooler-fault-alert {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?                               cml-data-types:cml_notif_severity_t
| +--ro eventClass?                             cml-data-types:cml_notif_class_t
| +--ro name?                                   string
| +--ro thermoelectric-cooler-fault?           boolean
+---n thermoelectric-cooler-fault-recovery {feature-list:NOT_HAVE_TIBIT}?

```

```
| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro name?                   string
| +--ro thermoelectric-cooler-fault? boolean
+---n rx-loss-of-signal {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?              cml-data-types:cml_notif_severity_t
| +--ro eventClass?           cml-data-types:cml_notif_class_t
| +--ro index?                uint8
| +--ro name?                 string
+---n rx-loss-of-signal-recovery {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?             cml-data-types:cml_notif_severity_t
| +--ro eventClass?          cml-data-types:cml_notif_class_t
| +--ro index?               uint8
| +--ro name?                string
+---n input-power-error-high-critical {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?            cml-data-types:cml_notif_severity_t
| +--ro eventClass?         cml-data-types:cml_notif_class_t
| +--ro index?              uint8
| +--ro name?               string
| +--ro input-power?         decimal64
| +--ro input-power-critical-min-threshold? decimal64
| +--ro input-power-critical-max-threshold? decimal64
+---n input-power-error-low-critical {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro index?             uint8
| +--ro name?              string
| +--ro input-power?       decimal64
| +--ro input-power-critical-min-threshold? decimal64
| +--ro input-power-critical-max-threshold? decimal64
+---n input-power-error-high-alert {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro index?            uint8
| +--ro name?             string
| +--ro input-power?      decimal64
| +--ro input-power-alert-min-threshold? decimal64
| +--ro input-power-alert-max-threshold? decimal64
+---n input-power-error-low-alert {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?         cml-data-types:cml_notif_severity_t
| +--ro eventClass?      cml-data-types:cml_notif_class_t
| +--ro index?           uint8
| +--ro name?            string
| +--ro input-power?     decimal64
| +--ro input-power-alert-min-threshold? decimal64
| +--ro input-power-alert-max-threshold? decimal64
+---n input-power-error-recovery {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?        cml-data-types:cml_notif_severity_t
| +--ro eventClass?     cml-data-types:cml_notif_class_t
| +--ro index?          uint8
```



```

| +---ro name?          string
| +---ro input-power?  decimal64
+---n output-power-error-high-critical {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?          cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro index?            uint8
| +---ro name?             string
| +---ro output-power?     decimal64
| +---ro output-power-critical-min-threshold? decimal64
| +---ro output-power-critical-max-threshold? decimal64
+---n output-power-error-low-critical {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?          cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro index?            uint8
| +---ro name?             string
| +---ro output-power?     decimal64
| +---ro output-power-critical-min-threshold? decimal64
| +---ro output-power-critical-max-threshold? decimal64
+---n output-power-error-high-alert {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?          cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro index?            uint8
| +---ro name?             string
| +---ro output-power?     decimal64
| +---ro output-power-alert-min-threshold? decimal64
| +---ro output-power-alert-max-threshold? decimal64
+---n output-power-error-low-alert {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?          cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro index?            uint8
| +---ro name?             string
| +---ro output-power?     decimal64
| +---ro output-power-alert-min-threshold? decimal64
| +---ro output-power-alert-max-threshold? decimal64
+---n output-power-error-recovery {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?          cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro index?            uint8
| +---ro name?             string
| +---ro output-power?     decimal64
+---n laser-bias-current-error-high-critical {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?          cml-data-
types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro index?            uint8
| +---ro name?             string
| +---ro laser-bias-current? decimal64
| +---ro laser-bias-current-critical-min-threshold? decimal64
| +---ro laser-bias-current-critical-max-threshold? decimal64
+---n laser-bias-current-error-low-critical {feature-list:NOT_HAVE_TIBIT}?

```

```
| +--ro severity?                                cml-data-
types:cml_notif_severity_t
| +--ro eventClass?                              cml-data-types:cml_notif_class_t
| +--ro index?                                   uint8
| +--ro name?                                    string
| +--ro laser-bias-current?                      decimal64
| +--ro laser-bias-current-critical-min-threshold? decimal64
| +--ro laser-bias-current-critical-max-threshold? decimal64
+---n laser-bias-current-error-high-alert {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?                                cml-data-types:cml_notif_severity_t
| +--ro eventClass?                              cml-data-types:cml_notif_class_t
| +--ro index?                                   uint8
| +--ro name?                                    string
| +--ro laser-bias-current?                      decimal64
| +--ro laser-bias-current-alert-min-threshold? decimal64
| +--ro laser-bias-current-alert-max-threshold? decimal64
+---n laser-bias-current-error-low-alert {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?                                cml-data-types:cml_notif_severity_t
| +--ro eventClass?                              cml-data-types:cml_notif_class_t
| +--ro index?                                   uint8
| +--ro name?                                    string
| +--ro laser-bias-current?                      decimal64
| +--ro laser-bias-current-alert-min-threshold? decimal64
| +--ro laser-bias-current-alert-max-threshold? decimal64
+---n laser-bias-current-error-recovery {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?                                cml-data-types:cml_notif_severity_t
| +--ro eventClass?                              cml-data-types:cml_notif_class_t
| +--ro index?                                   uint8
| +--ro name?                                    string
| +--ro laser-bias-current?                      decimal64
+---n transceiver-temperature-error-high-critical {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?                                cml-data-types:cml_notif_severity_t
| +--ro eventClass?                              cml-data-types:cml_notif_class_t
| +--ro name?                                    string
| +--ro transceiver-temperature?                decimal64
| +--ro temperature-critical-min-threshold?     decimal64
| +--ro temperature-critical-max-threshold?     decimal64
+---n transceiver-temperature-error-low-critical {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?                                cml-data-types:cml_notif_severity_t
| +--ro eventClass?                              cml-data-types:cml_notif_class_t
| +--ro name?                                    string
| +--ro transceiver-temperature?                decimal64
| +--ro temperature-critical-min-threshold?     decimal64
| +--ro temperature-critical-max-threshold?     decimal64
+---n transceiver-temperature-error-high-alert {feature-list:NOT_HAVE_TIBIT}?
| +--ro severity?                                cml-data-types:cml_notif_severity_t
| +--ro eventClass?                              cml-data-types:cml_notif_class_t
| +--ro name?                                    string
| +--ro transceiver-temperature?                decimal64
| +--ro temperature-alert-min-threshold?        decimal64
| +--ro temperature-alert-max-threshold?        decimal64
```

```
+---n transceiver-temperature-error-low-alert {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?                cml-data-types:cml_notif_severity_t
| +---ro eventClass?              cml-data-types:cml_notif_class_t
| +---ro name?                    string
| +---ro transceiver-temperature? decimal64
| +---ro temperature-alert-min-threshold? decimal64
| +---ro temperature-alert-max-threshold? decimal64
+---n transceiver-temperature-error-recovery {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?                cml-data-types:cml_notif_severity_t
| +---ro eventClass?              cml-data-types:cml_notif_class_t
| +---ro name?                    string
| +---ro transceiver-temperature? decimal64
+---n transceiver-voltage-error-high-critical {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?                cml-data-types:cml_notif_severity_t
| +---ro eventClass?              cml-data-types:cml_notif_class_t
| +---ro name?                    string
| +---ro transceiver-voltage?     decimal64
| +---ro voltage-critical-min-threshold? decimal64
| +---ro voltage-critical-max-threshold? decimal64
+---n transceiver-voltage-error-low-critical {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?                cml-data-types:cml_notif_severity_t
| +---ro eventClass?              cml-data-types:cml_notif_class_t
| +---ro name?                    string
| +---ro transceiver-voltage?     decimal64
| +---ro voltage-critical-min-threshold? decimal64
| +---ro voltage-critical-max-threshold? decimal64
+---n transceiver-voltage-error-high-alert {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?                cml-data-types:cml_notif_severity_t
| +---ro eventClass?              cml-data-types:cml_notif_class_t
| +---ro name?                    string
| +---ro transceiver-voltage?     decimal64
| +---ro voltage-alert-min-threshold? decimal64
| +---ro voltage-alert-max-threshold? decimal64
+---n transceiver-voltage-error-low-alert {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?                cml-data-types:cml_notif_severity_t
| +---ro eventClass?              cml-data-types:cml_notif_class_t
| +---ro name?                    string
| +---ro transceiver-voltage?     decimal64
| +---ro voltage-alert-min-threshold? decimal64
| +---ro voltage-alert-max-threshold? decimal64
+---n transceiver-voltage-error-recovery {feature-list:NOT_HAVE_TIBIT}?
| +---ro severity?                cml-data-types:cml_notif_severity_t
| +---ro eventClass?              cml-data-types:cml_notif_class_t
| +---ro name?                    string
| +---ro transceiver-voltage?     decimal64
+---n temperature-high
| +---ro severity?                cml-data-types:cml_notif_severity_t
| +---ro eventClass?              cml-data-types:cml_notif_class_t
| +---ro name?                    string
| +---ro alarm-status?            boolean
```

```
| +--ro alarm-threshold?    decimal64
| +--ro instant?           decimal64
+---n temperature-low
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro alarm-status?     boolean
| +--ro alarm-threshold?  decimal64
| +--ro instant?          decimal64
+---n power-supply-inserted
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
+---n power-supply-removed
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
+---n power-supply-ac-failed
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
+---n power-supply-ac-recovery
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
+---n power-supply-12v-failed
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
+---n power-supply-12v-recovery
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
+---n psu-vin-low-alert
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro input-voltage?     decimal64
| +--ro vin-alert-threshold-min? decimal64
| +--ro vin-alert-threshold-max? decimal64
+---n psu-vin-high-alert
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro input-voltage?     decimal64
| +--ro vin-alert-threshold-min? decimal64
| +--ro vin-alert-threshold-max? decimal64
+---n psu-vin-low-critical
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
```

```

| +--ro name?                string
| +--ro input-voltage?      decimal64
| +--ro vin-critical-threshold-min? decimal64
| +--ro vin-critical-threshold-max? decimal64
+---n psu-vin-high-critical
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?         cml-data-types:cml_notif_class_t
| +--ro name?               string
| +--ro input-voltage?      decimal64
| +--ro vin-critical-threshold-min? decimal64
| +--ro vin-critical-threshold-max? decimal64
+---n psu-vin-low-alert-recovery
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?         cml-data-types:cml_notif_class_t
| +--ro name?               string
| +--ro input-voltage?      decimal64
| +--ro vin-alert-threshold-min? decimal64
| +--ro vin-alert-threshold-max? decimal64
+---n psu-vin-high-alert-recovery
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?         cml-data-types:cml_notif_class_t
| +--ro name?               string
| +--ro input-voltage?      decimal64
| +--ro vin-alert-threshold-min? decimal64
| +--ro vin-alert-threshold-max? decimal64
+---n psu-vin-low-critical-recovery
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?         cml-data-types:cml_notif_class_t
| +--ro name?               string
| +--ro input-voltage?      decimal64
| +--ro vin-critical-threshold-min? decimal64
| +--ro vin-critical-threshold-max? decimal64
+---n psu-vin-high-critical-recovery
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?         cml-data-types:cml_notif_class_t
| +--ro name?               string
| +--ro input-voltage?      decimal64
| +--ro vin-critical-threshold-min? decimal64
| +--ro vin-critical-threshold-max? decimal64
+---n psu-vout-low-alert
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?         cml-data-types:cml_notif_class_t
| +--ro name?               string
| +--ro output-voltage?     decimal64
| +--ro vout-alert-threshold-min? decimal64
| +--ro vout-alert-threshold-max? decimal64
+---n psu-vout-high-alert
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?         cml-data-types:cml_notif_class_t
| +--ro name?               string

```

```
|  +--ro output-voltage?          decimal64
|  +--ro vout-alert-threshold-min? decimal64
|  +--ro vout-alert-threshold-max? decimal64
+---n psu-vout-low-critical
|  +--ro severity?                cml-data-types:cml_notif_severity_t
|  +--ro eventClass?              cml-data-types:cml_notif_class_t
|  +--ro name?                    string
|  +--ro output-voltage?          decimal64
|  +--ro vout-critical-threshold-min? decimal64
|  +--ro vout-critical-threshold-max? decimal64
+---n psu-vout-high-critical
|  +--ro severity?                cml-data-types:cml_notif_severity_t
|  +--ro eventClass?              cml-data-types:cml_notif_class_t
|  +--ro name?                    string
|  +--ro output-voltage?          decimal64
|  +--ro vout-critical-threshold-min? decimal64
|  +--ro vout-critical-threshold-max? decimal64
+---n psu-vout-low-alert-recovery
|  +--ro severity?                cml-data-types:cml_notif_severity_t
|  +--ro eventClass?              cml-data-types:cml_notif_class_t
|  +--ro name?                    string
|  +--ro output-voltage?          decimal64
|  +--ro vout-alert-threshold-min? decimal64
|  +--ro vout-alert-threshold-max? decimal64
+---n psu-vout-high-alert-recovery
|  +--ro severity?                cml-data-types:cml_notif_severity_t
|  +--ro eventClass?              cml-data-types:cml_notif_class_t
|  +--ro name?                    string
|  +--ro output-voltage?          decimal64
|  +--ro vout-alert-threshold-min? decimal64
|  +--ro vout-alert-threshold-max? decimal64
+---n psu-vout-low-critical-recovery
|  +--ro severity?                cml-data-types:cml_notif_severity_t
|  +--ro eventClass?              cml-data-types:cml_notif_class_t
|  +--ro name?                    string
|  +--ro output-voltage?          decimal64
|  +--ro vout-critical-threshold-min? decimal64
|  +--ro vout-critical-threshold-max? decimal64
+---n psu-vout-high-critical-recovery
|  +--ro severity?                cml-data-types:cml_notif_severity_t
|  +--ro eventClass?              cml-data-types:cml_notif_class_t
|  +--ro name?                    string
|  +--ro output-voltage?          decimal64
|  +--ro vout-critical-threshold-min? decimal64
|  +--ro vout-critical-threshold-max? decimal64
+---n psu-pin-low-alert
|  +--ro severity?                cml-data-types:cml_notif_severity_t
|  +--ro eventClass?              cml-data-types:cml_notif_class_t
|  +--ro name?                    string
|  +--ro input-power?             decimal64
```

```

| +---ro pin-alert-threshold-min?    decimal64
| +---ro pin-alert-threshold-max?    decimal64
+---n psu-pin-high-alert
| +---ro severity?                  cml-data-types:cml_notif_severity_t
| +---ro eventClass?                cml-data-types:cml_notif_class_t
| +---ro name?                       string
| +---ro input-power?                decimal64
| +---ro pin-alert-threshold-min?    decimal64
| +---ro pin-alert-threshold-max?    decimal64
+---n psu-pin-low-critical
| +---ro severity?                  cml-data-types:cml_notif_severity_t
| +---ro eventClass?                cml-data-types:cml_notif_class_t
| +---ro name?                       string
| +---ro input-power?                decimal64
| +---ro pin-critical-threshold-min? decimal64
| +---ro pin-critical-threshold-max? decimal64
+---n psu-pin-high-critical
| +---ro severity?                  cml-data-types:cml_notif_severity_t
| +---ro eventClass?                cml-data-types:cml_notif_class_t
| +---ro name?                       string
| +---ro input-power?                decimal64
| +---ro pin-critical-threshold-min? decimal64
| +---ro pin-critical-threshold-max? decimal64
+---n psu-pin-low-alert-recovery
| +---ro severity?                  cml-data-types:cml_notif_severity_t
| +---ro eventClass?                cml-data-types:cml_notif_class_t
| +---ro name?                       string
| +---ro input-power?                decimal64
| +---ro pin-alert-threshold-min?    decimal64
| +---ro pin-alert-threshold-max?    decimal64
+---n psu-pin-high-alert-recovery
| +---ro severity?                  cml-data-types:cml_notif_severity_t
| +---ro eventClass?                cml-data-types:cml_notif_class_t
| +---ro name?                       string
| +---ro input-power?                decimal64
| +---ro pin-alert-threshold-min?    decimal64
| +---ro pin-alert-threshold-max?    decimal64
+---n psu-pin-low-critical-recovery
| +---ro severity?                  cml-data-types:cml_notif_severity_t
| +---ro eventClass?                cml-data-types:cml_notif_class_t
| +---ro name?                       string
| +---ro input-power?                decimal64
| +---ro pin-critical-threshold-min? decimal64
| +---ro pin-critical-threshold-max? decimal64
+---n psu-pin-high-critical-recovery
| +---ro severity?                  cml-data-types:cml_notif_severity_t
| +---ro eventClass?                cml-data-types:cml_notif_class_t
| +---ro name?                       string
| +---ro input-power?                decimal64
| +---ro pin-critical-threshold-min? decimal64

```

```
| +--ro pin-critical-threshold-max?    decimal64
+---n psu-pout-low-alert
| +--ro severity?                    cml-data-types:cml_notif_severity_t
| +--ro eventClass?                  cml-data-types:cml_notif_class_t
| +--ro name?                         string
| +--ro power-consumption?           decimal64
| +--ro pout-alert-threshold-min?    decimal64
| +--ro pout-alert-threshold-max?    decimal64
+---n psu-pout-high-alert
| +--ro severity?                    cml-data-types:cml_notif_severity_t
| +--ro eventClass?                  cml-data-types:cml_notif_class_t
| +--ro name?                         string
| +--ro power-consumption?           decimal64
| +--ro pout-alert-threshold-min?    decimal64
| +--ro pout-alert-threshold-max?    decimal64
+---n psu-pout-low-critical
| +--ro severity?                    cml-data-types:cml_notif_severity_t
| +--ro eventClass?                  cml-data-types:cml_notif_class_t
| +--ro name?                         string
| +--ro power-consumption?           decimal64
| +--ro pout-critical-threshold-min? decimal64
| +--ro pout-critical-threshold-max? decimal64
+---n psu-pout-high-critical
| +--ro severity?                    cml-data-types:cml_notif_severity_t
| +--ro eventClass?                  cml-data-types:cml_notif_class_t
| +--ro name?                         string
| +--ro power-consumption?           decimal64
| +--ro pout-critical-threshold-min? decimal64
| +--ro pout-critical-threshold-max? decimal64
+---n psu-pout-low-alert-recovery
| +--ro severity?                    cml-data-types:cml_notif_severity_t
| +--ro eventClass?                  cml-data-types:cml_notif_class_t
| +--ro name?                         string
| +--ro power-consumption?           decimal64
| +--ro pout-alert-threshold-min?    decimal64
| +--ro pout-alert-threshold-max?    decimal64
+---n psu-pout-high-alert-recovery
| +--ro severity?                    cml-data-types:cml_notif_severity_t
| +--ro eventClass?                  cml-data-types:cml_notif_class_t
| +--ro name?                         string
| +--ro power-consumption?           decimal64
| +--ro pout-alert-threshold-min?    decimal64
| +--ro pout-alert-threshold-max?    decimal64
+---n psu-pout-low-critical-recovery
| +--ro severity?                    cml-data-types:cml_notif_severity_t
| +--ro eventClass?                  cml-data-types:cml_notif_class_t
| +--ro name?                         string
| +--ro power-consumption?           decimal64
| +--ro pout-critical-threshold-min? decimal64
| +--ro pout-critical-threshold-max? decimal64
```

```

+---n psu-pout-high-critical-recovery
| +--ro severity?                cml-data-types:cml_notif_severity_t
| +--ro eventClass?             cml-data-types:cml_notif_class_t
| +--ro name?                   string
| +--ro power-consumption?      decimal64
| +--ro pout-critical-threshold-min? decimal64
| +--ro pout-critical-threshold-max? decimal64
+---n psu-iout-low-alert
| +--ro severity?               cml-data-types:cml_notif_severity_t
| +--ro eventClass?            cml-data-types:cml_notif_class_t
| +--ro name?                  string
| +--ro output-current?        decimal64
| +--ro iout-alert-threshold-min? decimal64
| +--ro iout-alert-threshold-max? decimal64
+---n psu-iout-high-alert
| +--ro severity?               cml-data-types:cml_notif_severity_t
| +--ro eventClass?            cml-data-types:cml_notif_class_t
| +--ro name?                  string
| +--ro output-current?        decimal64
| +--ro iout-alert-threshold-min? decimal64
| +--ro iout-alert-threshold-max? decimal64
+---n psu-iout-low-critical
| +--ro severity?               cml-data-types:cml_notif_severity_t
| +--ro eventClass?            cml-data-types:cml_notif_class_t
| +--ro name?                  string
| +--ro output-current?        decimal64
| +--ro iout-critical-threshold-min? decimal64
| +--ro iout-critical-threshold-max? decimal64
+---n psu-iout-high-critical
| +--ro severity?               cml-data-types:cml_notif_severity_t
| +--ro eventClass?            cml-data-types:cml_notif_class_t
| +--ro name?                  string
| +--ro output-current?        decimal64
| +--ro iout-critical-threshold-min? decimal64
| +--ro iout-critical-threshold-max? decimal64
+---n psu-iout-low-alert-recovery
| +--ro severity?               cml-data-types:cml_notif_severity_t
| +--ro eventClass?            cml-data-types:cml_notif_class_t
| +--ro name?                  string
| +--ro output-current?        decimal64
| +--ro iout-alert-threshold-min? decimal64
| +--ro iout-alert-threshold-max? decimal64
+---n psu-iout-high-alert-recovery
| +--ro severity?               cml-data-types:cml_notif_severity_t
| +--ro eventClass?            cml-data-types:cml_notif_class_t
| +--ro name?                  string
| +--ro output-current?        decimal64
| +--ro iout-alert-threshold-min? decimal64
| +--ro iout-alert-threshold-max? decimal64
+---n psu-iout-low-critical-recovery

```

```
| ---ro severity?                cml-data-types:cml_notif_severity_t
| ---ro eventClass?             cml-data-types:cml_notif_class_t
| ---ro name?                   string
| ---ro output-current?         decimal64
| ---ro iout-critical-threshold-min? decimal64
| ---ro iout-critical-threshold-max? decimal64
+---n psu-iout-high-critical-recovery
| ---ro severity?                cml-data-types:cml_notif_severity_t
| ---ro eventClass?             cml-data-types:cml_notif_class_t
| ---ro name?                   string
| ---ro output-current?         decimal64
| ---ro iout-critical-threshold-min? decimal64
| ---ro iout-critical-threshold-max? decimal64
+---n psu-iin-low-alert
| ---ro severity?                cml-data-types:cml_notif_severity_t
| ---ro eventClass?             cml-data-types:cml_notif_class_t
| ---ro name?                   string
| ---ro input-current?          decimal64
| ---ro iin-alert-threshold-min? decimal64
| ---ro iin-alert-threshold-max? decimal64
+---n psu-iin-high-alert
| ---ro severity?                cml-data-types:cml_notif_severity_t
| ---ro eventClass?             cml-data-types:cml_notif_class_t
| ---ro name?                   string
| ---ro input-current?          decimal64
| ---ro iin-alert-threshold-min? decimal64
| ---ro iin-alert-threshold-max? decimal64
+---n psu-iin-low-critical
| ---ro severity?                cml-data-types:cml_notif_severity_t
| ---ro eventClass?             cml-data-types:cml_notif_class_t
| ---ro name?                   string
| ---ro input-current?          decimal64
| ---ro iin-critical-threshold-min? decimal64
| ---ro iin-critical-threshold-max? decimal64
+---n psu-iin-high-critical
| ---ro severity?                cml-data-types:cml_notif_severity_t
| ---ro eventClass?             cml-data-types:cml_notif_class_t
| ---ro name?                   string
| ---ro input-current?          decimal64
| ---ro iin-critical-threshold-min? decimal64
| ---ro iin-critical-threshold-max? decimal64
+---n psu-iin-low-alert-recovery
| ---ro severity?                cml-data-types:cml_notif_severity_t
| ---ro eventClass?             cml-data-types:cml_notif_class_t
| ---ro name?                   string
| ---ro input-current?          decimal64
| ---ro iin-alert-threshold-min? decimal64
| ---ro iin-alert-threshold-max? decimal64
+---n psu-iin-high-alert-recovery
| ---ro severity?                cml-data-types:cml_notif_severity_t
```

```

| +--ro eventClass?          cml-data-types:cml_notif_class_t
| +--ro name?                string
| +--ro input-current?      decimal64
| +--ro iin-alert-threshold-min? decimal64
| +--ro iin-alert-threshold-max? decimal64
+---n psu-iin-low-critical-recovery
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro input-current?    decimal64
| +--ro iin-critical-threshold-min? decimal64
| +--ro iin-critical-threshold-max? decimal64
+---n psu-iin-high-critical-recovery
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro input-current?    decimal64
| +--ro iin-critical-threshold-min? decimal64
| +--ro iin-critical-threshold-max? decimal64
+---n psu-temp1-low-alert
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro temperature-sensor1? decimal64
| +--ro temp1-alert-threshold-min? decimal64
| +--ro temp1-alert-threshold-max? decimal64
+---n psu-temp1-high-alert
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro temperature-sensor1? decimal64
| +--ro temp1-alert-threshold-min? decimal64
| +--ro temp1-alert-threshold-max? decimal64
+---n psu-temp1-low-critical
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro temperature-sensor1? decimal64
| +--ro temp1-critical-threshold-min? decimal64
| +--ro temp1-critical-threshold-max? decimal64
+---n psu-temp1-high-critical
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro temperature-sensor1? decimal64
| +--ro temp1-critical-threshold-min? decimal64
| +--ro temp1-critical-threshold-max? decimal64
+---n psu-temp1-low-alert-recovery
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t

```

```
| +--ro name?                string
| +--ro temperature-sensor1? decimal64
| +--ro temp1-alert-threshold-min? decimal64
| +--ro temp1-alert-threshold-max? decimal64
+---n psu-temp1-high-alert-recovery
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro temperature-sensor1? decimal64
| +--ro temp1-alert-threshold-min? decimal64
| +--ro temp1-alert-threshold-max? decimal64
+---n psu-temp1-low-critical-recovery
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro temperature-sensor1? decimal64
| +--ro temp1-critical-threshold-min? decimal64
| +--ro temp1-critical-threshold-max? decimal64
+---n psu-temp1-high-critical-recovery
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro temperature-sensor1? decimal64
| +--ro temp1-critical-threshold-min? decimal64
| +--ro temp1-critical-threshold-max? decimal64
+---n psu-temp2-low-alert
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro temperature-sensor2? decimal64
| +--ro temp2-alert-threshold-min? decimal64
| +--ro temp2-alert-threshold-max? decimal64
+---n psu-temp2-high-alert
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro temperature-sensor2? decimal64
| +--ro temp2-alert-threshold-min? decimal64
| +--ro temp2-alert-threshold-max? decimal64
+---n psu-temp2-low-critical
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
| +--ro temperature-sensor2? decimal64
| +--ro temp2-critical-threshold-min? decimal64
| +--ro temp2-critical-threshold-max? decimal64
+---n psu-temp2-high-critical
| +--ro severity?           cml-data-types:cml_notif_severity_t
| +--ro eventClass?        cml-data-types:cml_notif_class_t
| +--ro name?              string
```

```
| ---ro temperature-sensor2?          decimal64
| ---ro temp2-critical-threshold-min?  decimal64
| ---ro temp2-critical-threshold-max?  decimal64
+---n psu-temp2-low-alert-recovery
| ---ro severity?                     cml-data-types:cml_notif_severity_t
| ---ro eventClass?                   cml-data-types:cml_notif_class_t
| ---ro name?                          string
| ---ro temperature-sensor2?          decimal64
| ---ro temp2-alert-threshold-min?     decimal64
| ---ro temp2-alert-threshold-max?     decimal64
+---n psu-temp2-high-alert-recovery
| ---ro severity?                     cml-data-types:cml_notif_severity_t
| ---ro eventClass?                   cml-data-types:cml_notif_class_t
| ---ro name?                          string
| ---ro temperature-sensor2?          decimal64
| ---ro temp2-alert-threshold-min?     decimal64
| ---ro temp2-alert-threshold-max?     decimal64
+---n psu-temp2-low-critical-recovery
| ---ro severity?                     cml-data-types:cml_notif_severity_t
| ---ro eventClass?                   cml-data-types:cml_notif_class_t
| ---ro name?                          string
| ---ro temperature-sensor2?          decimal64
| ---ro temp2-critical-threshold-min?  decimal64
| ---ro temp2-critical-threshold-max?  decimal64
+---n psu-temp2-high-critical-recovery
| ---ro severity?                     cml-data-types:cml_notif_severity_t
| ---ro eventClass?                   cml-data-types:cml_notif_class_t
| ---ro name?                          string
| ---ro temperature-sensor2?          decimal64
| ---ro temp2-critical-threshold-min?  decimal64
| ---ro temp2-critical-threshold-max?  decimal64
+---n psu-temp3-low-alert
| ---ro severity?                     cml-data-types:cml_notif_severity_t
| ---ro eventClass?                   cml-data-types:cml_notif_class_t
| ---ro name?                          string
| ---ro temperature-sensor3?          decimal64
| ---ro temp3-alert-threshold-min?     decimal64
| ---ro temp3-alert-threshold-max?     decimal64
+---n psu-temp3-high-alert
| ---ro severity?                     cml-data-types:cml_notif_severity_t
| ---ro eventClass?                   cml-data-types:cml_notif_class_t
| ---ro name?                          string
| ---ro temperature-sensor3?          decimal64
| ---ro temp3-alert-threshold-min?     decimal64
| ---ro temp3-alert-threshold-max?     decimal64
+---n psu-temp3-low-critical
| ---ro severity?                     cml-data-types:cml_notif_severity_t
| ---ro eventClass?                   cml-data-types:cml_notif_class_t
| ---ro name?                          string
| ---ro temperature-sensor3?          decimal64
```

```
| +--ro temp3-critical-threshold-min?    decimal64
| +--ro temp3-critical-threshold-max?    decimal64
+---n psu-temp3-high-critical
| +--ro severity?                       cml-data-types:cml_notif_severity_t
| +--ro eventClass?                     cml-data-types:cml_notif_class_t
| +--ro name?                            string
| +--ro temperature-sensor3?            decimal64
| +--ro temp3-critical-threshold-min?    decimal64
| +--ro temp3-critical-threshold-max?    decimal64
+---n psu-temp3-low-alert-recovery
| +--ro severity?                       cml-data-types:cml_notif_severity_t
| +--ro eventClass?                     cml-data-types:cml_notif_class_t
| +--ro name?                            string
| +--ro temperature-sensor3?            decimal64
| +--ro temp3-alert-threshold-min?       decimal64
| +--ro temp3-alert-threshold-max?       decimal64
+---n psu-temp3-high-alert-recovery
| +--ro severity?                       cml-data-types:cml_notif_severity_t
| +--ro eventClass?                     cml-data-types:cml_notif_class_t
| +--ro name?                            string
| +--ro temperature-sensor3?            decimal64
| +--ro temp3-alert-threshold-min?       decimal64
| +--ro temp3-alert-threshold-max?       decimal64
+---n psu-temp3-low-critical-recovery
| +--ro severity?                       cml-data-types:cml_notif_severity_t
| +--ro eventClass?                     cml-data-types:cml_notif_class_t
| +--ro name?                            string
| +--ro temperature-sensor3?            decimal64
| +--ro temp3-critical-threshold-min?    decimal64
| +--ro temp3-critical-threshold-max?    decimal64
+---n psu-temp3-high-critical-recovery
| +--ro severity?                       cml-data-types:cml_notif_severity_t
| +--ro eventClass?                     cml-data-types:cml_notif_class_t
| +--ro name?                            string
| +--ro temperature-sensor3?            decimal64
| +--ro temp3-critical-threshold-min?    decimal64
| +--ro temp3-critical-threshold-max?    decimal64
+---n fan-status-alarm
| +--ro severity?                       cml-data-types:cml_notif_severity_t
| +--ro eventClass?                     cml-data-types:cml_notif_class_t
| +--ro name?                            string
| +--ro fan-index?                       uint8
| +--ro fan-status?                      cml_cmm_fan_status_t
+---n fan-status-alarm-recovery
| +--ro severity?                       cml-data-types:cml_notif_severity_t
| +--ro eventClass?                     cml-data-types:cml_notif_class_t
| +--ro name?                            string
| +--ro fan-index?                       uint8
| +--ro fan-status?                      cml_cmm_fan_status_t
+---n fan-rpm-max-alert
```

```

| +---ro severity?          cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro name?             string
| +---ro maximum-rpm?      uint32
+---n fan-rpm-decreased-notify
| +---ro severity?         cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro name?             string
| +---ro rpm?              uint32
+---n fan-rpm-increased-notify
| +---ro severity?         cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro name?             string
| +---ro rpm?              uint32
+---n fan-tray-inserted
| +---ro severity?         cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro name?             string
+---n fan-tray-removed
| +---ro severity?         cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro name?             string
+---n hardware-tcam-util-warning-notification
| +---ro severity?         cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro group-id?         uint32
| +---ro group-name?       cml-data-types:cml_line_t
| +---ro used-percentage?  int32
| +---ro free-entries?     int32
+---n hardware-tcam-util-critical-notification
| +---ro severity?         cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro group-id?         uint32
| +---ro group-name?       cml-data-types:cml_line_t
| +---ro used-percentage?  int32
| +---ro free-entries?     int32
+---n loss-of-input-clock
| +---ro severity?         cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro name?             string
| +---ro loss-of-input-clock-status?  uint8
+---n usb-over-current
| +---ro severity?         cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro name?             string
| +---ro usb-over-current-status?  uint8
+---n cmis-module-monitor-alarm-notification
| +---ro severity?         cml-data-types:cml_notif_severity_t
| +---ro eventClass?       cml-data-types:cml_notif_class_t
| +---ro type?             ipi-platform-cmis-types:cmm_cmis_port_type_t

```

```
| ---ro port?          uint8
| ---ro name?         string
| ---ro alarm-id?    ipi-platform-cmis-types:cmm_cmis_module_monitor_id_t
| ---ro alarm-type?  ipi-platform-cmis-types:cmm_cmis_threshold_alarm_t
| ---ro current-value? decimal64
| ---ro threshold-minimum? decimal64
| ---ro threshold-maximum? decimal64
+---n cmis-module-monitor-recovery-notification
| ---ro severity?    cml-data-types:cml_notif_severity_t
| ---ro eventClass?  cml-data-types:cml_notif_class_t
| ---ro type?        ipi-platform-cmis-types:cmm_cmis_port_type_t
| ---ro port?        uint8
| ---ro name?        string
| ---ro alarm-id?    ipi-platform-cmis-types:cmm_cmis_module_monitor_id_t
| ---ro current-value? decimal64
| ---ro threshold-minimum? decimal64
| ---ro threshold-maximum? decimal64
+---n cmis-module-host-monitor-alarm-notification
| ---ro severity?    cml-data-types:cml_notif_severity_t
| ---ro eventClass?  cml-data-types:cml_notif_class_t
| ---ro number?      uint8
| ---ro type?        ipi-platform-cmis-types:cmm_cmis_port_type_t
| ---ro port?        uint8
| ---ro name?        string
| ---ro alarm-id?    ipi-platform-cmis-types:cmm_cmis_host_monitor_id_t
| ---ro alarm-type?  ipi-platform-cmis-types:cmm_cmis_threshold_alarm_t
| ---ro current-value? decimal64
| ---ro threshold-minimum? decimal64
| ---ro threshold-maximum? decimal64
+---n cmis-module-host-monitor-recovery-notification
| ---ro severity?    cml-data-types:cml_notif_severity_t
| ---ro eventClass?  cml-data-types:cml_notif_class_t
| ---ro number?      uint8
| ---ro type?        ipi-platform-cmis-types:cmm_cmis_port_type_t
| ---ro port?        uint8
| ---ro name?        string
| ---ro alarm-id?    ipi-platform-cmis-types:cmm_cmis_host_monitor_id_t
| ---ro current-value? decimal64
| ---ro threshold-minimum? decimal64
| ---ro threshold-maximum? decimal64
+---n cmis-module-host-flag-alarm-notification
| ---ro severity?    cml-data-types:cml_notif_severity_t
| ---ro eventClass?  cml-data-types:cml_notif_class_t
| ---ro number?      uint8
| ---ro type?        ipi-platform-cmis-types:cmm_cmis_port_type_t
| ---ro port?        uint8
| ---ro name?        string
| ---ro alarm-id?    ipi-platform-cmis-types:cmm_cmis_host_flag_id_t
+---n cmis-module-host-flag-recovery-notification
| ---ro severity?    cml-data-types:cml_notif_severity_t
```

```
| ---ro eventClass?    cml-data-types:cml_notif_class_t
| ---ro number?       uint8
| ---ro type?         ipi-platform-cmis-types:cmm_cmis_port_type_t
| ---ro port?         uint8
| ---ro name?         string
| ---ro alarm-id?     ipi-platform-cmis-types:cmm_cmis_host_flag_id_t
+---n cmis-module-media-monitor-alarm-notification
| ---ro severity?     cml-data-types:cml_notif_severity_t
| ---ro eventClass?   cml-data-types:cml_notif_class_t
| ---ro number?       uint8
| ---ro type?         ipi-platform-cmis-types:cmm_cmis_port_type_t
| ---ro port?         uint8
| ---ro name?         string
| ---ro alarm-id?     ipi-platform-cmis-types:cmm_cmis_media_monitor_id_t
| ---ro alarm-type?   ipi-platform-cmis-types:cmm_cmis_threshold_alarm_t
| ---ro current-value? decimal64
| ---ro threshold-minimum? decimal64
| ---ro threshold-maximum? decimal64
+---n cmis-module-media-monitor-recovery-notification
| ---ro severity?     cml-data-types:cml_notif_severity_t
| ---ro eventClass?   cml-data-types:cml_notif_class_t
| ---ro number?       uint8
| ---ro type?         ipi-platform-cmis-types:cmm_cmis_port_type_t
| ---ro port?         uint8
| ---ro name?         string
| ---ro alarm-id?     ipi-platform-cmis-types:cmm_cmis_media_monitor_id_t
| ---ro current-value? decimal64
| ---ro threshold-minimum? decimal64
| ---ro threshold-maximum? decimal64
+---n cmis-module-media-flag-alarm-notification
| ---ro severity?     cml-data-types:cml_notif_severity_t
| ---ro eventClass?   cml-data-types:cml_notif_class_t
| ---ro number?       uint8
| ---ro type?         ipi-platform-cmis-types:cmm_cmis_port_type_t
| ---ro port?         uint8
| ---ro name?         string
| ---ro alarm-id?     ipi-platform-cmis-types:cmm_cmis_media_flag_id_t
+---n cmis-module-media-flag-recovery-notification
| ---ro severity?     cml-data-types:cml_notif_severity_t
| ---ro eventClass?   cml-data-types:cml_notif_class_t
| ---ro number?       uint8
| ---ro type?         ipi-platform-cmis-types:cmm_cmis_port_type_t
| ---ro port?         uint8
| ---ro name?         string
| ---ro alarm-id?     ipi-platform-cmis-types:cmm_cmis_media_flag_id_t
+---n edfa-alarm-notification
| ---ro severity?     cml-data-types:cml_notif_severity_t
| ---ro eventClass?   cml-data-types:cml_notif_class_t
| ---ro port?         uint8
| ---ro name?         string
```

```

    | +--ro alarm-id?          ipi-platform-transceiver-
types:cmm_edfa_ddm_monitor_id_t
    | +--ro alarm-type?       ipi-platform-transceiver-
types:cmm_ddm_threshold_alarm_t
    | +--ro current-value?    decimal64
    | +--ro threshold-minimum? decimal64
    | +--ro threshold-maximum? decimal64
+---n edfa-alarm-recovery-notification
    | +--ro severity?         cml-data-types:cml_notif_severity_t
    | +--ro eventClass?      cml-data-types:cml_notif_class_t
    | +--ro port?            uint8
    | +--ro name?            string
    | +--ro alarm-id?        ipi-platform-transceiver-
types:cmm_edfa_ddm_monitor_id_t
    | +--ro current-value?    decimal64
    | +--ro threshold-minimum? decimal64
    | +--ro threshold-maximum? decimal64
+---n smart-sfp-ddm-alarm-notification
    | +--ro severity?         cml-data-types:cml_notif_severity_t
    | +--ro eventClass?      cml-data-types:cml_notif_class_t
    | +--ro port?            uint8
    | +--ro name?            string
    | +--ro alarm-id?        ipi-platform-transceiver-
types:cmm_smart_sfp_ddm_monitor_id_t
    | +--ro alarm-type?       ipi-platform-transceiver-
types:cmm_ddm_threshold_alarm_t
    | +--ro current-value?    decimal64
    | +--ro threshold-minimum? decimal64
    | +--ro threshold-maximum? decimal64
+---n smart-sfp-ddm-alarm-recovery-notification
    | +--ro severity?         cml-data-types:cml_notif_severity_t
    | +--ro eventClass?      cml-data-types:cml_notif_class_t
    | +--ro port?            uint8
    | +--ro name?            string
    | +--ro alarm-id?        ipi-platform-transceiver-
types:cmm_smart_sfp_ddm_monitor_id_t
    | +--ro current-value?    decimal64
    | +--ro threshold-minimum? decimal64
    | +--ro threshold-maximum? decimal64
+---n smart-sfp-descrete-alarm-notification
    | +--ro severity?         cml-data-types:cml_notif_severity_t
    | +--ro eventClass?      cml-data-types:cml_notif_class_t
    | +--ro port?            uint8
    | +--ro name?            string
    | +--ro alarm-id?        ipi-platform-transceiver-
types:cmm_smart_sfp_protocol_alarm_id_t
    | +--ro current-status?   ipi-platform-transceiver-
types:cmm_smart_sfp_protocol_status_t
+---n smart-sfp-descrete-alarm-recovery-notification
    +--ro severity?          cml-data-types:cml_notif_severity_t
    +--ro eventClass?        cml-data-types:cml_notif_class_t
    +--ro port?              uint8

```

```

    +--ro name?                string
    +--ro alarm-id?            ipi-platform-transceiver-
types:cmm_smart_sfp_protocol_alarm_id_t
    +--ro current-status?     ipi-platform-transceiver-
types:cmm_smart_sfp_protocol_status_t

```

module: ipi-port-breakout

```

+--rw port-breakout
  +--rw breakouts
    | +--rw breakout* [interface]
    |   +--rw interface      -> ../config/interface
    |   +--rw config
    |     | +--rw interface?  string
    |     | +--rw mode        ipi-port-breakout-types:port_breakout_mode_t
    |     | +--rw serdes?     ipi-port-breakout-types:port_breakout_serdes_type_t
    |     +--ro state
    |       +--ro interface?  string
    |       +--ro mode        ipi-port-breakout-types:port_breakout_mode_t
    |       +--ro serdes?     ipi-port-breakout-types:port_breakout_serdes_type_t
    |       +--ro block?     uint8
  +--rw groups-speed
  +--rw interfaces
    +--rw interface* [name]
      +--rw name          -> ../config/name
      +--rw config
      | +--rw name?       -> /ipi-interface:interfaces/interface/name
      | +--rw mode?      ipi-port-breakout-types:port_breakout_if_mode_t
      +--ro state
        +--ro name?     -> /ipi-interface:interfaces/interface/name
        +--ro mode?     ipi-port-breakout-types:port_breakout_if_mode_t

```

module: ipi-port-mirror

```

+--rw port-mirror
  +--rw sessions
    | +--rw session* [id] {feature-list:HAVE_ADVANCE_MIRROR}?
    |   +--rw id          -> ../config/id
    |   +--rw config
    |     | +--rw id?       uint32
    |     | +--rw type      ipi-port-mirror-types:pmirror_sess_type_t
    |     | +--rw enabled?  empty
    |     | +--rw description? cml-data-types:cml_line_t
    |     | +--rw source-vlan? cml-data-types:cml_range_t

```

```

|     +--ro state
|     |   +--ro counters
|     |   |   +--ro filter-count?      yang:counter32
|     |   |   +--ro tx-source-count?   yang:counter32
|     |   +--ro id?                    uint32
|     |   +--ro type                    ipi-port-mirror-types:pmirror_sess_type_t
|     |   +--ro enabled?                empty
|     |   +--ro description?           cml-data-types:cml_line_t
|     |   +--ro source-vlan?           cml-data-types:cml_range_t
|     +--rw destination
|     |   +--rw local
|     |   |   +--rw config
|     |   |   |   +--rw interface-name?  -> /ipi-interface:interfaces/interface/name
|     |   |   |   +--ro state
|     |   |   |   |   +--ro interface-name?  -> /ipi-interface:interfaces/interface/name
|     |   |   +--rw remote
|     |   |   |   +--rw config!
|     |   |   |   |   +--rw vlan-id          uint16
|     |   |   |   |   +--rw reflector-interface-name  -> /ipi-interface:interfaces/
interface/name
|     |   |   |   +--ro state
|     |   |   |   |   +--ro vlan-id          uint16
|     |   |   |   |   +--ro reflector-interface-name  -> /ipi-interface:interfaces/
interface/name
|     |   +--rw source-interfaces
|     |   |   +--rw source-interface* [name]
|     |   |   |   +--rw name          -> ../config/name
|     |   |   |   +--rw config!
|     |   |   |   |   +--rw name?      -> /ipi-interface:interfaces/interface/name
|     |   |   |   |   +--rw direction  ipi-port-mirror-types:pmirror_dir_t
|     |   |   |   +--ro state
|     |   |   |   |   +--ro name?      -> /ipi-interface:interfaces/interface/name
|     |   |   |   |   +--ro direction  ipi-port-mirror-types:pmirror_dir_t
|     |   +--rw session-filters
|     |   |   +--rw session-filter* [seq-id]
|     |   |   |   +--rw seq-id      -> ../config/seq-id
|     |   |   |   +--rw config
|     |   |   |   |   +--rw seq-id?   uint32
|     |   |   |   +--ro state
|     |   |   |   |   +--ro seq-id?   uint32
|     |   |   +--rw filters
|     |   |   |   +--rw config
|     |   |   |   |   +--rw (destination-mac-options)?
|     |   |   |   |   |   +--:(host-mac)
|     |   |   |   |   |   |   +--rw destination-mac-address-host?  ipi-port-mirror-
types:pmirror_mac_addr_t
|     |   |   |   |   |   |   +--:(mac-with-mask)
|     |   |   |   |   |   |   |   +--rw destination-mac-address?    ipi-port-mirror-
types:pmirror_mac_addr_t
|     |   |   |   |   |   |   |   +--rw destination-mac-mask?      ipi-port-mirror-
types:pmirror_mac_addr_t

```

```

| | +--rw frame-type? | ipi-port-mirror-
types:pmirror_ethertype_t
| | +--rw arp-type? | ipi-port-mirror-
types:pmirror_arp_type_t
| | +--rw sender-ip-address? | inet:ipv4-address
| | +--rw target-ip-address? | inet:ipv4-address
| | +--rw cos? | uint8
| | +--rw vlan? | cml-data-
types:cml_range_t
| | +--rw source-ipv4-address? | cml-data-
types:cml_ipv4_addr_or_prefix_t
| | +--rw destination-ipv4-address? | cml-data-
types:cml_ipv4_addr_or_prefix_t
| | +--rw source-ipv6-address? | cml-data-
types:cml_ipv6_prefix_t
| | +--rw destination-ipv6-address? | cml-data-
types:cml_ipv6_prefix_t
| | +--rw (source-mac-options)?
| | +---:(host-mac)
| | | +--rw source-mac-address-host? | ipi-port-mirror-
types:pmirror_mac_addr_t
| | | +---:(mac-with-mask)
| | | +--rw source-mac-address? | ipi-port-mirror-
types:pmirror_mac_addr_t
| | | +--rw source-mac-mask? | ipi-port-mirror-
types:pmirror_mac_addr_t
| | +--ro state
| | +--ro (destination-mac-options)?
| | | +---:(host-mac)
| | | | +--ro destination-mac-address-host? | ipi-port-mirror-
types:pmirror_mac_addr_t
| | | | +---:(mac-with-mask)
| | | | +--ro destination-mac-address? | ipi-port-mirror-
types:pmirror_mac_addr_t
| | | | +--ro destination-mac-mask? | ipi-port-mirror-
types:pmirror_mac_addr_t
| | +--ro frame-type? | ipi-port-mirror-
types:pmirror_ethertype_t
| | +--ro arp-type? | ipi-port-mirror-
types:pmirror_arp_type_t
| | +--ro sender-ip-address? | inet:ipv4-address
| | +--ro target-ip-address? | inet:ipv4-address
| | +--ro cos? | uint8
| | +--ro vlan? | cml-data-
types:cml_range_t
| | +--ro source-ipv4-address? | cml-data-
types:cml_ipv4_addr_or_prefix_t
| | +--ro destination-ipv4-address? | cml-data-
types:cml_ipv4_addr_or_prefix_t
| | +--ro source-ipv6-address? | cml-data-
types:cml_ipv6_prefix_t
| | +--ro destination-ipv6-address? | cml-data-
types:cml_ipv6_prefix_t
| | +--ro (source-mac-options)?
| | +---:(host-mac)

```

```

| | | | +--ro source-mac-address-host? ipi-port-mirror-
types:pmirror_mac_addr_t
| | | | +---:(mac-with-mask)
| | | | +--ro source-mac-address? ipi-port-mirror-
types:pmirror_mac_addr_t
| | | | +--ro source-mac-mask? ipi-port-mirror-
types:pmirror_mac_addr_t
| | | | +--rw interfaces

```

module: ipi-port-vlan

```

augment /ipi-interface:interfaces/ipi-interface:interface:
  +--rw port-vlan
    +--rw global
      | +--rw config
        | | +--rw isolated-vlan-id? cml-data-types:cml_range_t {feature-
list:NOT_HAVE_SWFWDR}?
        | | +--rw cvlan-registration-table? -> /ipi-network-instance:network-
instances/network-instance/ipi-bridge:bridge/ipi-vlan:cvlan-registration-tables/cvlan-
registration-table/config/table-name {feature-list:HAVE_PROVIDER_BRIDGE}?
        | | +--ro state
        | | +--ro isolated-vlan-id? cml-data-types:cml_range_t {feature-
list:NOT_HAVE_SWFWDR}?
        | | +--ro cvlan-registration-table? -> /ipi-network-instance:network-
instances/network-instance/ipi-bridge:bridge/ipi-vlan:cvlan-registration-tables/cvlan-
registration-table/config/table-name {feature-list:HAVE_PROVIDER_BRIDGE}?
        +--rw ennis
        +--rw switched-vlans
          | +--rw switched-vlan* [interface-mode]
          |   +--rw interface-mode -> ../config/interface-mode
          |   +--rw config
          |     | +--rw interface-mode? ipi-port-vlan-
types:port_vlan_switch_port_mode_t
          |     | +--rw acceptable-frame-type? ipi-port-vlan-
types:port_vlan_frame_type_t
          |     | +--rw disable-native-vlan? empty
          |     | +--rw remove-default-vlan? empty
          |     | +--ro state
          |     | +--ro interface-mode? ipi-port-vlan-
types:port_vlan_switch_port_mode_t
          |     | +--ro acceptable-frame-type? ipi-port-vlan-
types:port_vlan_frame_type_t
          |     | +--ro disable-native-vlan? empty
          |     | +--ro remove-default-vlan? empty
          |     +--rw vlans
          |       | +--rw config
          |       | | +--rw vlan-id? uint16
          |       | | +--rw native-vlan-id? uint16
          |       | +--ro state

```

```

|     |     +---ro vlan-id?          uint16
|     |     +---ro native-vlan-id?   uint16
|     +---rw allowed-vlan
|     |     +---rw config
|     |     |     +---rw allowed-vlan-id?          cml-data-types:cml_range_t
|     |     |     +---rw egress-tagging-disabled-vlans?  cml-data-types:cml_range_t
|     |     +---ro state
|     |     +---ro allowed-vlan-id?          cml-data-types:cml_range_t
|     |     +---ro egress-tagging-disabled-vlans?  cml-data-types:cml_range_t
|     +---rw ce-vlan-translations
|     +---rw svlan-translations
|     |     +---rw svlan-translation* [original-svlan-id] {feature-
list:HAVE_PROVIDER_BRIDGE}?
|     |     +---rw original-svlan-id   -> ../config/original-svlan-id
|     |     +---rw config
|     |     |     +---rw translated-svlan-id?   uint16
|     |     |     +---rw original-svlan-id?    uint16
|     |     |     +---rw translated-cvlan-id?  uint16
|     |     +---ro state
|     |     +---ro translated-svlan-id?   uint16
|     |     +---ro original-svlan-id?    uint16
|     |     +---ro translated-cvlan-id?   uint16
|     +---rw cvlan-svlan-translations
|     |     +---rw cvlan-svlan-translation* [cvlan-id svlan-id] {feature-
list:HAVE_PROVIDER_BRIDGE}?
|     |     +---rw cvlan-id   -> ../config/cvlan-id
|     |     +---rw svlan-id   -> ../config/svlan-id
|     |     +---rw config
|     |     |     +---rw cvlan-id?          uint16
|     |     |     +---rw svlan-id?         uint16
|     |     |     +---rw translated-cvlan-id?  uint16
|     |     |     +---rw translated-svlan-id  uint16
|     |     +---ro state
|     |     +---ro cvlan-id?          uint16
|     |     +---ro svlan-id?         uint16
|     |     +---ro translated-cvlan-id?  uint16
|     |     +---ro translated-svlan-id  uint16
+---rw port-security
|   +---rw config!
|   |   +---rw mode          ipi-port-vlan-types:port_vlan_port_sec_mode_t
|   |   +---rw maximum-limit?  uint16
|   |   +---rw logging?      empty
|   +---ro state
|   |   +---ro mode          ipi-port-vlan-types:port_vlan_port_sec_mode_t
|   |   +---ro maximum-limit?  uint16
|   |   +---ro logging?      empty
+---rw secure-mac {feature-list:HAVE_PROVIDER_BRIDGE}?
|   +---rw default-vlan-mappings
|   |   +---rw default-vlan-mapping* [mac-address]
|   |   |   +---rw mac-address   -> ../config/mac-address
|   |   +---rw config

```

```

|     |     | +--rw mac-address?    cml-data-types:cml_mac_addr_t
|     |     +--ro state
|     |         +--ro mac-address?    cml-data-types:cml_mac_addr_t
| +--rw vlan-mappings
|     | +--rw vlan-mapping* [mac-address]
|     |     +--rw mac-address    -> ../config/mac-address
|     |     +--rw config
|     |         | +--rw mac-address?    cml-data-types:cml_mac_addr_t
|     |         | +--rw cvlan-id*      uint16
|     |         | +--rw svlan-id*     uint16
|     |         +--ro state
|     |             +--ro mac-address?    cml-data-types:cml_mac_addr_t
|     |             +--ro cvlan-id*      uint16
|     |             +--ro svlan-id*     uint16
| +--rw cvlan-svlan-mappings
|     +--rw cvlan-svlan-mapping* [mac-address cvlan-id svlan-id]
|     +--rw mac-address    -> ../config/mac-address
|     +--rw cvlan-id      -> ../config/cvlan-id
|     +--rw svlan-id      -> ../config/svlan-id
|     +--rw config
|     | +--rw mac-address?    cml-data-types:cml_mac_addr_t
|     | +--rw cvlan-id?      uint16
|     | +--rw svlan-id?     uint16
|     +--ro state
|         +--ro mac-address?    cml-data-types:cml_mac_addr_t
|         +--ro cvlan-id?      uint16
|         +--ro svlan-id?     uint16
+--rw private-vlan {feature-list:HAVE_PVLAN}?
| +--rw config!
| | +--rw mode    ipi-port-vlan-types:port_vlan_pvlan_mode_t
| +--ro state
| | +--ro mode    ipi-port-vlan-types:port_vlan_pvlan_mode_t
| +--rw associations
|     +--rw association* [vlan-id]
|         +--rw vlan-id    -> ../config/vlan-id
|         +--rw config
|         | +--rw vlan-id?                uint16
|         | +--rw associate-vlan-id?     uint16
|         | +--rw mapping-vlan-id?      cml-data-types:cml_range_t
|         | +--rw association-trunk-vlan-id? uint16
|         +--ro state
|             +--ro vlan-id?                uint16
|             +--ro associate-vlan-id?     uint16
|             +--ro mapping-vlan-id?      cml-data-types:cml_range_t
|             +--ro association-trunk-vlan-id? uint16
+--rw oep-mappings
augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance/ipi-bridge:bridge:
+--rw vlan-static-fdb
+--rw entries
+--rw entry* [mac-address vlan-id]

```



```

+--rw mac-address    -> ../config/mac-address
+--rw vlan-id        -> ../config/vlan-id
+--rw config
| +--rw interface-name    -> /ipi-interface:interfaces/interface/name
| +--rw mac-address?      cml-data-types:cml_mac_addr_t
| +--rw action            ipi-port-vlan-types:port_vlan_l2_fdb_action_t
| +--rw vlan-id?         uint16
| +--rw svlan-id?        uint16 {feature-
list:HAVE_PB_STATIC_FDB_CUSTOM_CONFIG}?
+--ro state
  +--ro interface-name    -> /ipi-interface:interfaces/interface/name
  +--ro mac-address?      cml-data-types:cml_mac_addr_t
  +--ro action            ipi-port-vlan-types:port_vlan_l2_fdb_action_t
  +--ro vlan-id?         uint16
  +--ro svlan-id?        uint16 {feature-
list:HAVE_PB_STATIC_FDB_CUSTOM_CONFIG}?

```

module: ipi-prefix-list

```

+--rw prefixes
  +--rw prefix* [prefix-list-name prefix-list-type]
    +--rw prefix-list-name    -> ../config/prefix-list-name
    +--rw prefix-list-type    -> ../config/prefix-list-type
    +--rw config
    | +--rw prefix-list-name?  string
    | +--rw prefix-list-type?  ipi-prefix-list-types:prefix_list_type_t
    | +--rw description?       cml-data-types:cml_line_t
    +--ro state
    | +--ro prefix-list-name?  string
    | +--ro prefix-list-type?  ipi-prefix-list-types:prefix_list_type_t
    | +--ro description?       cml-data-types:cml_line_t
    +--rw prefix-entries
      +--rw prefix-entry* [sequence-id]
        +--rw sequence-id    -> ../config/sequence-id
        +--rw config
        | +--rw sequence-id?   uint32
        +--ro state
        | +--ro sequence-id?   uint32
        +--rw ipv4
        | +--rw entry* [action prefix-addr]
        |   +--rw action        -> ../config/action
        |   +--rw prefix-addr   -> ../config/prefix-addr
        |   +--rw config
        |   | +--rw action?      ipi-prefix-list-
types:prefix_list_action_t
        |   | +--rw minimum-prefix-length-match?  uint8
        |   | +--rw maximum-prefix-length-match?  uint8

```

```

types:prefix_list_ipv4_network_t
    |      | +--rw prefix-addr?                ipi-prefix-list-
    |      | +--rw exact-prefix-length-match?  uint8
    |      +--ro state
types:prefix_list_action_t
    |      +--ro action?                       ipi-prefix-list-
    |      +--ro minimum-prefix-length-match?  uint8
    |      +--ro maximum-prefix-length-match?  uint8
types:prefix_list_ipv4_network_t
    |      +--ro prefix-addr?                 ipi-prefix-list-
    |      +--ro exact-prefix-length-match?   uint8
    +--rw ipv6 {feature-list:HAVE_IPV6}?
        +--rw entry* [action ipv6-prefix-addr] {feature-list:HAVE_IPV6}?
            +--rw action                      -> ../config/action
            +--rw ipv6-prefix-addr           -> ../config/ipv6-prefix-addr
            +--rw config {feature-list:HAVE_IPV6}?
                | +--rw ipv6-prefix-addr?     ipi-prefix-list-
types:prefix_list_ipv6_network_t
                | +--rw action?               ipi-prefix-list-
types:prefix_list_action_t
                | +--rw minimum-prefix-length-match?  uint8
                | +--rw maximum-prefix-length-match?  uint8
                +--ro state {feature-list:HAVE_IPV6}?
                    +--ro ipv6-prefix-addr?         ipi-prefix-list-
types:prefix_list_ipv6_network_t
                    +--ro action?                   ipi-prefix-list-
types:prefix_list_action_t
                    +--ro minimum-prefix-length-match?  uint8
                    +--ro maximum-prefix-length-match?  uint8

rpcs:
  +---x clear-prefix-list-all
  |   +---w input
  |   +---w type      ipi-prefix-list-types:prefix_list_type_t
  +---x clear-ipv4-prefix-list
  |   +---w input
  |   +---w prefix-list-name      string
  |   +---w prefix?               cml-data-types:cml_ipv4_addr_prefix_t
  +---x clear-ipv6-prefix-list {feature-list:HAVE_IPV6}?
  |   +---w input
  |   +---w prefix-list-name      string
  |   +---w prefix?               cml-data-types:cml_ipv6_prefix_t

```

module: ipi-ntp

```

+--rw ntp {feature-list:HAVE_PTP_HW_OFFLOAD}?
  +--rw ntp-instances
  |   +--rw ntp-instance* [instance-type]

```

```

|     +---rw instance-type          -> ../config/instance-type
|     +---rw config
|     |     +---rw instance-type?   uint8
|     |     +---rw profile           ipi-ptp-types:ptp_profile_t
|     +---rw tlv {feature-list:HAVE_PTP_HW_OFFLOAD_CUSTOM1}?
|     |     +---rw config
|     |     |     +---rw color-frame?  empty
|     |     |     +---rw drop-frame?   empty
|     |     |     +---rw numerator?    uint32
|     |     |     +---rw denominator?  uint32
|     |     +---ro state
|     |     |     +---ro color-frame?  empty
|     |     |     +---ro drop-frame?   empty
|     |     |     +---ro numerator?    uint32
|     |     |     +---ro denominator?  uint32
|     +---rw default-data-set {feature-list:HAVE_DUNE_OR_HAVE_MARVELL}?
|     |     +---rw config
|     |     |     +---rw l2-pkt-forward?  empty
|     |     |     +---rw domain?         uint8
|     |     |     +---rw servo-config?   ipi-ptp-
types:ptp_servo_config_type_t
|     |     |     +---rw external-clock-holdover-duration?  uint16
|     |     |     +---rw system-clock-sync?                uint16
|     |     |     +---rw ptp-clock-sync?                  empty
|     |     |     +---rw ptsf-wtr-duration?               uint16
|     |     |     +---rw g8265p1-wtr-duration?           uint64
|     |     |     +---rw g8265p1-option?                 ipi-ptp-
types:ptp_g8265p1_option_type_t
|     |     |     +---rw reserved-vlan-base?              uint16
|     |     |     +---rw two-step?                        empty {feature-
list:HAVE_PTP_HW_OFFLOAD_CUSTOM1}?
|     |     |     +---rw clock-type-tgm?                  ipi-ptp-
types:ptp_clock_type_tgm_t
|     |     |     +---rw one-way?                          empty
|     |     |     +---rw number-ports?                    uint8
|     |     |     +---rw pps-pulse-offset?                int16
|     |     |     +---rw pps-in-smx-tod-type?            ipi-ptp-
types:ptp_lpss_in_smx_tod_type_t
|     |     |     +---rw priority-1?                      uint8
|     |     |     +---rw priority-2?                      uint8
|     |     |     +---rw slave-only?                     empty
|     |     |     +---rw local-priority?                  uint8
|     |     |     +---rw max-steps-removed?              uint8
|     |     |     +---rw start-boundary-hops?            uint8
|     |     +---ro state
|     |     |     +---ro l2-pkt-forward?                  empty
|     |     |     +---ro domain?                          uint8
|     |     |     +---ro servo-config?                    ipi-ptp-
types:ptp_servo_config_type_t
|     |     |     +---ro external-clock-holdover-duration?  uint16
|     |     |     +---ro system-clock-sync?                uint16
|     |     |     +---ro ptp-clock-sync?                  empty

```

```

|      | | | +---ro ptsf-wtr-duration?                uint16
|      | | | +---ro g8265p1-wtr-duration?            uint64
|      | | | +---ro g8265p1-option?                  ipi-ptp-
types:ptp_g8265p1_option_type_t
|      | | | +---ro reserved-vlan-base?              uint16
|      | | | +---ro two-step?                        empty {feature-
list:HAVE_PTP_HW_OFFLOAD_CUSTOM1}?
|      | | | +---ro clock-type-tgm?                  ipi-ptp-
types:ptp_clock_type_tgm_t
|      | | | +---ro one-way?                          empty
|      | | | +---ro number-ports?                    uint8
|      | | | +---ro pps-pulse-offset?                int16
|      | | | +---ro pps-in-smx-tod-type?             ipi-ptp-
types:ptp_lpss_in_smx_tod_type_t
|      | | | +---ro priority-1?                      uint8
|      | | | +---ro priority-2?                      uint8
|      | | | +---ro slave-only?                      empty
|      | | | +---ro local-priority?                  uint8
|      | | | +---ro max-steps-removed?              uint8
|      | | | +---ro start-boundary-hops?            uint8
|      | | | +---ro clock-identity?                  string
|      | | +---rw servo-history
|      | | | +---rw config!
|      | | | | +---rw servo-history-enabled          empty
|      | | | | +---rw servo-history-interval        uint8
|      | | | +---ro state
|      | | |   +---ro servo-history-enabled          empty
|      | | |   +---ro servo-history-interval        uint8
|      | | +---rw clock-quality
|      | | | +---rw config
|      | | | | +---rw clock-class?                   uint8
|      | | | | +---rw clock-accuracy?                uint8
|      | | | | +---rw offset-scaled-log-variance?    uint16
|      | | | +---ro state
|      | | |   +---ro clock-class?                   uint8
|      | | |   +---ro clock-accuracy?                uint8
|      | | |   +---ro offset-scaled-log-variance?    uint16
|      | | +---rw gps-offset
|      | | | +---rw config!
|      | | | | +---rw offset-seconds                  int8
|      | | | | +---rw offset-nano-seconds            int16
|      | | | +---ro state
|      | | |   +---ro offset-seconds                  int8
|      | | |   +---ro offset-nano-seconds            int16
|      +---rw ports {feature-list:HAVE_DUNE_OR_HAVE_MARVELL}?
|      | +---rw port* [port-number]
|      | | +---rw port-number                        -> ../config/port-number
|      | | +---rw config
|      | | | +---rw port-number?                      uint16
|      | | | +---rw local-priority?                  uint8
|      | | | +---rw description?                     cml-data-types:cml_line_t

```

```

|      |      | +---rw transport-type?                ipi-ptp-types:ptp_encap_type_t
|      |      | +---rw transport-v6-type?            empty
|      |      | +---rw transport-v6-multicast-type?  ipi-ptp-
types:ptp_v6_multicast_type_t
|      |      | +---rw non-forwardable-mac-addr?    empty
|      |      | +---rw log-min-delay-req-interval?   int8
|      |      | +---rw log-announce-interval?        int8
|      |      | +---rw announce-receipt-timeout?     uint8
|      |      | +---rw log-sync-interval?            int8
|      |      | +---rw time-to-live?                  uint8
|      |      | +---rw ip-dscp?                       uint8
|      |      | +---rw unicast-grant-duration?        uint16
|      |      | +---rw delay-mechanism?               ipi-ptp-
types:ptp_delay_mechanism_t
|      |      | +---rw version-number?                int8
|      |      | +---rw master-only?                   empty
|      |      | +---rw grandmaster-priority-2?        uint8
|      |      | +---rw append?                         empty {feature-
list:HAVE_PTP_HW_OFFLOAD_CUSTOM1}?
|      |      | +---rw process?                         empty {feature-
list:HAVE_PTP_HW_OFFLOAD_CUSTOM1}?
|      |      | +---rw source-ipv6-link-local-address? empty {feature-
list:HAVE_IPV6}?
|      |      | +---rw source-ipv6-interface-address? string {feature-
list:HAVE_IPV6}?
|      |      | +---rw source-ipv4-interface-address? string
|      |      | +---rw source-ipv6-address?            inet:ipv6-address {feature-
list:HAVE_IPV6}?
|      |      | +---rw source-ipv4-address?            inet:ipv4-address
|      |      | +---ro state
|      |      | +---ro port-number?                    uint16
|      |      | +---ro local-priority?                 uint8
|      |      | +---ro description?                    cml-data-types:cml_line_t
|      |      | +---ro transport-type?                 ipi-ptp-types:ptp_encap_type_t
|      |      | +---ro transport-v6-type?              empty
|      |      | +---ro transport-v6-multicast-type?    ipi-ptp-
types:ptp_v6_multicast_type_t
|      |      | +---ro non-forwardable-mac-addr?      empty
|      |      | +---ro log-min-delay-req-interval?    int8
|      |      | +---ro log-announce-interval?         int8
|      |      | +---ro announce-receipt-timeout?      uint8
|      |      | +---ro log-sync-interval?              int8
|      |      | +---ro time-to-live?                   uint8
|      |      | +---ro ip-dscp?                        uint8
|      |      | +---ro unicast-grant-duration?        uint16
|      |      | +---ro delay-mechanism?                ipi-ptp-
types:ptp_delay_mechanism_t
|      |      | +---ro version-number?                 int8
|      |      | +---ro master-only?                    empty
|      |      | +---ro grandmaster-priority-2?        uint8
|      |      | +---ro append?                         empty {feature-
list:HAVE_PTP_HW_OFFLOAD_CUSTOM1}?

```

```

| | | +---ro process? empty {feature-
list:HAVE_PTP_HW_OFFLOAD_CUSTOM1}?
| | | +---ro port-state? ipi-ptp-types:ptp_port_state_t
| | | +---ro peer-mean-path-delay? ipi-ptp-
types:ptp_time_interval_t
| | | +---ro signal-fail? boolean
| | | +---ro port-identity? string
| | +---rw clock-quality
| | | +---rw config
| | | | +---rw clock-class? uint8
| | | | +---rw clock-accuracy? uint8
| | | | +---rw offset-scaled-log-variance? uint16
| | | +---ro state
| | | | +---ro clock-class? uint8
| | | | +---ro clock-accuracy? uint8
| | | | +---ro offset-scaled-log-variance? uint16
| | +---rw asymmetry-delay
| | | +---rw config!
| | | | +---rw delay-asymmetry-msec int8
| | | | +---rw delay-asymmetry-nsec int32
| | | +---ro state
| | | | +---ro delay-asymmetry-msec int8
| | | | +---ro delay-asymmetry-nsec int32
| | +---rw network-interfaces
| | | +---rw network-interface* [network-interface]
| | | +---rw network-interface -> ../config/network-interface
| | | +---rw config
| | | | +---rw network-interface? ipi-ptp-
types:ptp_network_interface_t
| | | +---rw vlan-physical-interface-name? cml-data-
types:cml_ifname_t
| | | | +---rw vlan-physical-dot1q-vlan-id? uint16
| | | | +---rw dot1q-vlan-id? uint16
| | | | +---rw dot1ad-vlan-id? uint16
| | | | +---rw inner-dot1q-vlan-id? uint16
| | | +---ro state
| | | | +---ro network-interface? ipi-ptp-
types:ptp_network_interface_t
| | | +---ro vlan-physical-interface-name? cml-data-
types:cml_ifname_t
| | | | +---ro vlan-physical-dot1q-vlan-id? uint16
| | | | +---ro dot1q-vlan-id? uint16
| | | | +---ro dot1ad-vlan-id? uint16
| | | | +---ro inner-dot1q-vlan-id? uint16
| | | +---rw master-ipv4-addresses
| | | | +---rw master-ipv4-address* [master-clock-source-ipv4-address]
| | | | +---rw master-clock-source-ipv4-address -> ../config/master-
clock-source-ipv4-address
| | | | +---rw config
| | | | | +---rw master-clock-source-ipv4-address? inet:ipv4-address
| | | | | +---rw master-ipv4-address-priority? uint8
| | | +---ro state

```

```

|         |         |         +---ro master-clock-source-ipv4-address?   inet:ipv4-address
|         |         |         +---ro master-ipv4-address-priority?   uint8
|         |         |         +---rw master-ipv6-addresses
|         |         |         +---rw master-ipv6-address* [master-clock-source-ipv6-address]
|         |         |         +---rw master-clock-source-ipv6-address   -> ../config/master-
clock-source-ipv6-address
|         |         |         +---rw config
|         |         |         |         +---rw master-clock-source-ipv6-address?   inet:ipv6-address
|         |         |         |         +---rw master-ipv6-address-priority?   uint8
|         |         |         +---ro state
|         |         |         +---ro master-clock-source-ipv6-address?   inet:ipv6-address
|         |         |         +---ro master-ipv6-address-priority?   uint8
|         |         |         +---rw statistics
|         |         |         +---ro state
|         |         |         +---ro packets-transmitted?   yang:counter32
|         |         |         +---ro packets-received?   yang:counter32
|         |         |         +---ro packets-discarded?   yang:counter32
|         |         |         +---ro foreign-data-sets
|         |         |         +---ro foreign-data-set* [foreign-master-id]
|         |         |         +---ro foreign-master-id   -> ../state/foreign-master-id
|         |         |         +---ro state
|         |         |         +---ro foreign-master-id?   uint8
|         |         |         +---ro current?   boolean
|         |         |         +---ro ipv4-address?   inet:ipv4-address
|         |         |         +---ro ipv6-address?   inet:ipv6-address {feature-
list:HAVE_IPV6}?
|         |         |         +---ro l2-address?   yang:mac-address
|         |         |         +---ro clock-identity?   string
|         |         |         +---ro port-id?   string
|         |         |         +---ro clock-class?   uint8
|         |         |         +---ro clock-accuracy?   uint8
|         |         |         +---ro offset-scaled-log-variance?   uint16
|         |         |         +---ro priority-1?   uint8
|         |         |         +---ro priority-2?   uint8
|         |         |         +---ro steps-removed?   uint16
|         |         |         +---ro pdv-scaled-allan-variance?   uint64
|         |         |         +---ro peer-data-sets
|         |         |         +---ro peer-data-set* [peer-id]
|         |         |         +---ro peer-id   -> ../state/peer-id
|         |         |         +---ro state
|         |         |         +---ro peer-id?   uint8
|         |         |         +---ro ipv4-address?   inet:ipv4-address
|         |         |         +---ro ipv6-address?   inet:ipv6-address {feature-
list:HAVE_IPV6}?
|         |         |         +---ro l2-address?   yang:mac-address
|         |         |         +---ro clock-identity?   string
|         |         |         +---ro received-announce?   yang:counter64
|         |         |         +---ro received-sync?   yang:counter64
|         |         |         +---ro received-followup?   yang:counter64
|         |         |         +---ro received-reject?   yang:counter64
|         |         |         +---ro received-delay-request?   yang:counter64

```

```

| | | +---ro received-delay-response? yang:counter64
| | | +---ro received-management? yang:counter64
| | | +---ro received-signaling? yang:counter64
| | | +---ro transmitted-announce? yang:counter64
| | | +---ro transmitted-sync? yang:counter64
| | | +---ro transmitted-followup? yang:counter64
| | | +---ro transmitted-delay-request? yang:counter64
| | | +---ro transmitted-delay-response? yang:counter64
| | | +---ro transmitted-management? yang:counter64
| | | +---ro transmitted-signaling? yang:counter64
| | +---ro master-data-sets
| | | +---ro master-data-set* [master-id]
| | | +---ro master-id -> ../state/master-id
| | | +---ro state
| | | | +---ro master-id? uint8
| | | | +---ro ipv4-address? inet:ipv4-address
| | | | +---ro ipv6-address? inet:ipv6-address {feature-
list:HAVE_IPV6}?
| | +---ro slave-data-sets
| | | +---ro slave-data-set* [slave-id]
| | | +---ro slave-id -> ../state/slave-id
| | | +---ro state
| | | | +---ro slave-id? uint8
| | | | +---ro ipv4-address? inet:ipv4-address
| | | | +---ro ipv6-address? inet:ipv6-address {feature-
list:HAVE_IPV6}?
| | | +---ro clock-identity? string
| | | +---ro delay-mechanism? ipi-ptp-
types:ptp_delay_mechanism_t
| | | +---ro log-announce-interval? int8
| | | +---ro log-sync-interval? int8
| | | +---ro log-delay-request-interval? int8
| | +---rw drop-counters
| | | +---ro state
| | | | +---ro domain-mismatch? yang:counter32
| | | | +---ro memory-alloc-failure? yang:counter32
| | | | +---ro pkt-len-too-short? yang:counter32
| | | | +---ro pkt-rcvd-on-bad-port-state? yang:counter32
| | | | +---ro pkt-profile-mismatch? yang:counter32
| | | | +---ro clock-port-mismatch? yang:counter32
| | | | +---ro ptp-packet-parsing-failure? yang:counter32
| | | | +---ro delreq-from-unknown-slave? yang:counter32
| | | | +---ro announce-on-master-only-port? yang:counter32
| | | | +---ro invalid-steps-removed-field? yang:counter32
| | | | +---ro unknown-unicast-master? yang:counter32
| | | | +---ro announce-on-gps-ptp-port? yang:counter32
| | | | +---ro sync-rcvd-invalid? yang:counter32
| | | | +---ro sync-rcvd-without-master? yang:counter32
| | +---rw time-of-day {feature-list:HAVE_DUNE}?
| | | +---rw config
| | | | +---rw io-type? ipi-ptp-types:ptp_clock_io_type_t

```



```

|      | +---ro state
|      |   +---ro io-type?   ipi-ptp-types:ptp_clock_io_type_t
|      +---rw ptp-servo {feature-list:HAVE_DUNE}?
|      | +---ro state
|      |   +---ro config-state?           ipi-ptp-types:ptp_config_state_t
|      |   +---ro servo-config?          string {feature-
list:HAVE_PTP_HW_OFFLOAD_CUSTOM1}?
|      |   +---ro previous-state?        ipi-ptp-types:ptp_servo_state_t
|      |   +---ro current-state?        ipi-ptp-types:ptp_servo_state_t
|      |   +---ro previous-servo-state?  ipi-ptp-types:ptp_servo_state_custom_t
{feature-list:HAVE_PTP_HW_OFFLOAD_CUSTOM1_OR_HAVE_PTP_HW_OFFLOAD_CUSTOM2}?
|      |   +---ro current-servo-state?  ipi-ptp-types:ptp_servo_state_custom_t
{feature-list:HAVE_PTP_HW_OFFLOAD_CUSTOM1_OR_HAVE_PTP_HW_OFFLOAD_CUSTOM2}?
|      |   +---ro duration?             string
|      |   +---ro apts-mode?            ipi-ptp-types:ptp_servo_apts_mode_t
|      |   +---ro freq-correction?      decimal64
|      |   +---ro phase-correction?     decimal64
|      |   +---ro mean-path-delay?      ipi-ptp-types:ptp_time_interval_t
|      |   +---ro apts-gps-to-ptp-offset? ipi-ptp-types:ptp_time_interval_t
|      |   +---ro offset-from-master?   decimal64
|      |   +---ro sync-packet-rate?    uint32
|      |   +---ro delay-packet-rate?    uint32
|      +---rw current-data-set {feature-list:HAVE_DUNE}?
|      | +---ro state
|      |   +---ro steps-removed?        uint8
|      |   +---ro offset-from-master?   ipi-ptp-types:ptp_time_interval_t
|      |   +---ro offset-from-master-in-nsec? decimal64
|      |   +---ro mean-path-delay?      ipi-ptp-types:ptp_time_interval_t
|      +---rw parent-data-set {feature-list:HAVE_DUNE_OR_HAVE_MARVELL}?
|      | +---ro state
|      | | +---ro parent-stats-enabled?  boolean
|      | | +---ro parent-offset-scaled-log-variance? uint16
|      | | +---ro parent-phase-change-rate? uint32
|      | | +---ro grandmaster-identity?  ipi-ptp-
types:ptp_clock_identity_t
|      | | +---ro grandmaster-priority-1? uint8
|      | | +---ro grandmaster-priority-2? uint8
|      | | +---ro port-identity
|      | | | +---ro clock-identity?  string
|      | | | +---ro port-number?    uint16
|      | | +---ro grandmaster-clock-quality
|      | |   +---ro clock-class?      uint8
|      | |   +---ro clock-accuracy?   uint8
|      | |   +---ro offset-scaled-log-variance? uint16
|      | +---rw port-identity
|      | | +---ro state
|      | | | +---ro clock-identity?  string
|      | | | +---ro port-number?    uint16
|      | +---rw grandmaster-clock-quality
|      |   +---ro state
|      |   +---ro clock-class?        uint8

```

```
| | | +---ro clock-accuracy?          uint8
| | | +---ro offset-scaled-log-variance?  uint16
| +---rw time-properties {feature-list:HAVE_DUNE}?
| | +---ro state
| | | +---ro current-utc-offset-valid?  boolean
| | | +---ro current-utc-offset?       int16
| | | +---ro leap59?                   empty
| | | +---ro leap61?                   empty
| | | +---ro time-traceable?           empty
| | | +---ro frequency-traceable?     empty
| | | +---ro ptp-timescale?           empty
| | | +---ro time-source?             ipi-ptp-types:ptp_time_source_t
| | | +---ro ptp-time-of-day?         string
| +---rw statistics {feature-list:HAVE_DUNE}?
| | +---ro state
| | | +---ro packets-transmitted?      yang:counter32
| | | +---ro packets-received?        yang:counter32
| | | +---ro packets-discarded?      yang:counter32
| | | +---ro ipv4-packets-received?   yang:counter32
| | | +---ro ipv6-packets-received?   yang:counter32 {feature-list:HAVE_IPV6}?
| | | +---ro l2-packets-received?     yang:counter32
| | | +---ro rx-queue-overflows?     yang:counter32
| +---ro servo-history-data {feature-list:HAVE_DUNE}?
| | +---ro servo-history-data-entry* [entry-id]
| | | +---ro entry-id    -> ../state/entry-id
| | | +---ro state
| | | | +---ro entry-id?          uint8
| | | | +---ro timestamp?        string
| | | | +---ro phase-correction?  decimal64
| | | | +---ro frequency-correction? decimal64
| +---rw utc-offset-dates
| | +---rw utc-offset-date* [utc-date]
| | | +---rw utc-date    -> ../config/utc-date
| | | +---rw config
| | | | +---rw utc-date?      string
| | | | +---rw offset-seconds  uint8
| | | +---ro state
| | | | +---ro utc-date?      string
| | | | +---ro offset-seconds  uint8
| | +---rw baseline
| | | +---rw config
| | | | +---rw baseline-seconds?  uint8
| | | +---ro state
| | | | +---ro baseline-seconds?  uint8
+---rw debug
| +---rw config
| | +---rw enable?    empty
| +---ro state
| | +---ro enable?          empty
| | +---ro terminal-debug-status?  cml-data-types:cml_on_off_t
```

```

+--rw interfaces
  +--rw interface* [interface-name]
    +--rw interface-name    -> ../config/interface-name
    +--rw config
      | +--rw interface-name?  -> /ipi-interface:interfaces/interface/name
      | +--rw hw-timestamp?    empty {feature-list:HAVE_DUNE}?
    +--ro state
      +--ro interface-name?   -> /ipi-interface:interfaces/interface/name
      +--ro hw-timestamp?    empty {feature-list:HAVE_DUNE}?

rpcs:
  +---x ptp-clear-statistics {feature-list:HAVE_PTP_HW_OFFLOAD,feature-
list:HAVE_PTPD,feature-list:HAVE_DUNE_OR_HAVE_MARVELL}?
  | +---w input
  |   +---w clear-clock      uint8
  +---x ptp-terminal-debug-on {feature-list:HAVE_PTP_HW_OFFLOAD,feature-
list:HAVE_DUNE}?
  +---x ptp-terminal-debug-off {feature-list:HAVE_PTP_HW_OFFLOAD,feature-
list:HAVE_DUNE}?

notifications:
  +---n ptp-servo-state-change-notify {feature-list:HAVE_PTP_HW_OFFLOAD,feature-
list:HAVE_DUNE}?
  | +--ro severity?          cml-data-types:cml_notif_severity_t
  | +--ro eventClass?       cml-data-types:cml_notif_class_t
  | +--ro instance-type?    uint8
  | +--ro previous-state?   ipi-ptp-types:ptp_servo_state_t
  | +--ro current-state?    ipi-ptp-types:ptp_servo_state_t
  +---n ptp-servo-state-change-custom1-notify {feature-list:HAVE_DUNE,feature-
list:HAVE_PTP_HW_OFFLOAD_CUSTOM1_OR_HAVE_PTP_HW_OFFLOAD_CUSTOM2}?
  +--ro severity?          cml-data-types:cml_notif_severity_t
  +--ro eventClass?       cml-data-types:cml_notif_class_t
  +--ro instance-type?    uint8
  +--ro previous-servo-state? ipi-ptp-types:ptp_servo_state_custom_t
  +--ro current-servo-state? ipi-ptp-types:ptp_servo_state_custom_t

```

module: ipi-qos-if

```

augment /ipi-qos:qos:
  +--rw interfaces
    +--rw interface* [name]
      +--rw name          -> ../config/name
      +--rw config
        | +--rw name?      -> /ipi-interface:interfaces/interface/name
        | +--rw untagged-priority? uint8
        | +--rw trust-dscp?  empty
      +--ro state
        | +--ro name?      -> /ipi-interface:interfaces/interface/name

```

```

|  +--ro untagged-priority?  uint8
|  +--ro trust-dscp?        empty
+--rw remark
|  +--rw config
|  |  +--rw cos?            ipi-qos-types:cml_remark_state_t
|  |  +--rw dscp?          ipi-qos-types:cml_remark_state_t
|  +--ro state
|     +--ro cos?            ipi-qos-types:cml_remark_state_t
|     +--ro dscp?          ipi-qos-types:cml_remark_state_t
+--rw traffic-shape
|  +--rw config!
|  |  +--rw rate             uint64
|  |  +--rw rate-unit       ipi-qos-types:qos_shape_rate_unit_t
|  +--ro state
|     +--ro rate             uint64
|     +--ro rate-unit       ipi-qos-types:qos_shape_rate_unit_t
+--rw map-profile {feature-list:HAVE_QOS_MAPPING_PROFILE}?
|  +--rw config
|  |  +--rw cos-to-queue?    string
|  |  +--rw dscp-to-dscp?   string {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
|  |  +--rw precedence-to-precedence?  string {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
|  |  +--rw dscp-to-queue?   string
|  |  +--rw precedence-to-queue?       string
|  |  +--rw exp-encapsulation?    -> /ipi-qos:qos/global/map-profile/exp-
encapsulation-profiles/exp-encapsulation-profile/name {feature-
list:HAVE_DIFFSERV,feature-list:HAVE_CUSTOM2_QOS,feature-list:NOT_HAVE_CUSTOM3_QOS}?
|  |  +--rw dscp-encapsulation?   string {feature-list:HAVE_CUSTOM2_QOS}?
|  |  +--rw queue-color-to-cos?   string
|  +--ro state
|     +--ro cos-to-queue?          string
|     +--ro dscp-to-dscp?          string {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
|     +--ro precedence-to-precedence?  string {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
|     +--ro dscp-to-queue?          string
|     +--ro precedence-to-queue?     string
|     +--ro exp-encapsulation?      -> /ipi-qos:qos/global/map-profile/exp-
encapsulation-profiles/exp-encapsulation-profile/name {feature-
list:HAVE_DIFFSERV,feature-list:HAVE_CUSTOM2_QOS,feature-list:NOT_HAVE_CUSTOM3_QOS}?
|     +--ro dscp-encapsulation?     string {feature-list:HAVE_CUSTOM2_QOS}?
|     +--ro queue-color-to-cos?     string
+--rw service-policy
  +--rw ingress
  |  +--rw config
  |  |  +--rw type-qos-policy-map-name?  string
  |  +--ro state
  |  |  +--ro type-qos-policy-map-name?  string
  |  +--ro class-maps-level-1
  |     +--ro class-map-level-1* [class-map-name-level-1]
  |     +--ro class-map-name-level-1    -> ../state/class-map-name-level-1

```

```

|         +---ro state
|         | +---ro class-map-name-level-1?  string
|         | +---ro counters
|         |   +---ro matched-packets?      yang:counter64
|         |   +---ro matched-octets?      yang:counter64
|         |   +---ro transmitted-packets?  yang:counter64
|         |   +---ro transmitted-octets?   yang:counter64
|         |   +---ro dropped-packets?     yang:counter64
|         |   +---ro dropped-octets?      yang:counter64
|         +---ro class-maps-level-2
|         | +---ro class-map-level-2* [class-map-name-level-2]
|         | +---ro class-map-name-level-2  -> ../state/class-map-name-
level-2
|         |
|         | +---ro state
|         | | +---ro class-map-name-level-2?  string
|         | | +---ro counters
|         | |   +---ro matched-packets?      yang:counter64
|         | |   +---ro matched-octets?      yang:counter64
|         | |   +---ro transmitted-packets?  yang:counter64
|         | |   +---ro transmitted-octets?   yang:counter64
|         | |   +---ro dropped-packets?     yang:counter64
|         | |   +---ro dropped-octets?      yang:counter64
|         | +---ro class-maps-level-3
|         | | +---ro class-map-level-3* [class-map-name-level-3]
|         | | +---ro class-map-name-level-3  -> ../state/class-map-
name-level-3
|         | |
|         | | +---ro state
|         | | | +---ro class-map-name-level-3?  string
|         | | | +---ro counters
|         | | |   +---ro matched-packets?      yang:counter64
|         | | |   +---ro matched-octets?      yang:counter64
|         | | |   +---ro transmitted-packets?  yang:counter64
|         | | |   +---ro transmitted-octets?   yang:counter64
|         | | |   +---ro dropped-packets?     yang:counter64
|         | | |   +---ro dropped-octets?      yang:counter64
|         +---rw egress
|         | +---rw config
|         | | +---rw type-queuing-policy-map-name?  string
|         | +---ro state
|         | | +---ro type-queuing-policy-map-name?  string
|         | +---ro class-maps-level-1
|         | | +---ro class-map-level-1* [class-map-name-level-1]
|         | | +---ro class-map-name-level-1  -> ../state/class-map-name-level-1
|         | | +---ro state
|         | | | +---ro class-map-name-level-1?  string
|         | | | +---ro queues
|         | | | | +---ro queue* [id]
|         | | | |   +---ro id                uint8
|         | | | |   +---ro counters
|         | | | |   +---ro total-transmitted-packets?  yang:counter64
|         | | | |   +---ro total-transmitted-octets?   yang:counter64

```

```

|         +---ro total-dropped-packets?           yang:counter64
|         +---ro total-dropped-octets?           yang:counter64
|         +---ro green-transmitted-packets?      yang:counter64
|         +---ro non-green-transmitted-packets?  yang:counter64
|         +---ro green-dropped-packets?         yang:counter64
|         +---ro yellow-dropped-packets?        yang:counter64
|         +---ro red-dropped-packets?           yang:counter64
|         +---ro rate-kbps?                      decimal64
|         +---ro rate-mbps?                      decimal64
|         +---ro rate-gbps?                      decimal64
+---ro class-maps-level-2
    +---ro class-map-level-2* [class-map-name-level-2]
        +---ro class-map-name-level-2    -> ../state/class-map-name-
level-2
            +---ro state
                | +---ro class-map-name-level-2?    string
                | +---ro queues
                |     +---ro queue* [id]
                |         +---ro id                uint8
                |         +---ro counters
                |             +---ro total-transmitted-packets?
yang:counter64
                |             +---ro total-transmitted-octets?
yang:counter64
                |             +---ro total-dropped-packets?
yang:counter64
                |             +---ro total-dropped-octets?
yang:counter64
                |             +---ro green-transmitted-packets?
yang:counter64
                |             +---ro non-green-transmitted-packets?
yang:counter64
                |             +---ro green-dropped-packets?
yang:counter64
                |             +---ro yellow-dropped-packets?
yang:counter64
                |             +---ro red-dropped-packets?
yang:counter64
                |             +---ro rate-kbps?          decimal64
                |             +---ro rate-mbps?          decimal64
                |             +---ro rate-gbps?          decimal64
                +---ro class-maps-level-3
                    +---ro class-map-level-3* [class-map-name-level-3]
                        +---ro class-map-name-level-3    -> ../state/class-map-
name-level-3
                            +---ro state
                                +---ro class-map-name-level-3?    string
                                +---ro queues
                                | +---ro queue* [id]
                                |     +---ro id                uint8
                                |     +---ro counters
                                |         +---ro total-transmitted-packets?
yang:counter64

```

```

yang:counter64          +---ro total-transmitted-octets?
yang:counter64          +---ro total-dropped-packets?
yang:counter64          +---ro total-dropped-octets?
yang:counter64          +---ro green-transmitted-packets?
yang:counter64          +---ro non-green-transmitted-packets?
yang:counter64          +---ro green-dropped-packets?
yang:counter64          +---ro yellow-dropped-packets?
yang:counter64          +---ro red-dropped-packets?
                        +---ro rate-kbps?                decimal64
                        +---ro rate-mbps?                decimal64
                        +---ro rate-gbps?                decimal64

notifications:
+---n qos-subinterface-default-policy-add-notification
| +---ro severity?      cml-data-types:cml_notif_severity_t
| +---ro eventClass?    cml-data-types:cml_notif_class_t
| +---ro message?       string
+---n qos-subinterface-default-policy-delete-notification
| +---ro severity?      cml-data-types:cml_notif_severity_t
| +---ro eventClass?    cml-data-types:cml_notif_class_t
| +---ro message?       string
+---n qos-subinterface-traffic-shape-add-notification
| +---ro severity?      cml-data-types:cml_notif_severity_t
| +---ro eventClass?    cml-data-types:cml_notif_class_t
| +---ro message?       string
+---n qos-subinterface-traffic-shape-delete-notification
+---ro severity?        cml-data-types:cml_notif_severity_t
+---ro eventClass?      cml-data-types:cml_notif_class_t
+---ro message?         string

```

module: ipi-qos

```

+---rw qos
  +---rw global
    +---rw config
      | +---rw enable-qos?          cml-data-types:cml_enable_disable_t
      | +---rw red-drop-disabled?  empty {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
      | +---rw statistics-enabled? empty
      +---ro state
        | +---ro enable-qos?        cml-data-types:cml_enable_disable_t

```

```

|   +---ro red-drop-disabled?    empty {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
|   +---ro statistics-enabled?   empty
+---rw map-profile {feature-list:HAVE_QOS_MAPPING_PROFILE}?
|   +---rw cos-to-queue-profiles
|   |   +---rw cos-to-queue-profile* [name]
|   |       +---rw name             -> ../config/name
|   |       +---rw config
|   |           | +---rw name?    string
|   |           +---ro state
|   |           | +---ro name?    string
|   |           +---rw cos-to-queues {feature-list:HAVE_CUSTOM2_QOS}?
|   |               +---rw cos-to-queue* [cos-value]
|   |                   +---rw cos-value    -> ../config/cos-value
|   |                   +---rw config
|   |                       | +---rw cos-value?    uint8
|   |                       | +---rw queue-id      uint8
|   |                       +---ro state
|   |                           +---ro cos-value?    uint8
|   |                           +---ro queue-id      uint8
|   +---rw dscp-to-dscp-profiles {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
|   |   +---rw dscp-to-dscp-profile* [name]
|   |       +---rw name             -> ../config/name
|   |       +---rw config
|   |           | +---rw name?    string
|   |           +---ro state
|   |           | +---ro name?    string
|   |           +---rw dscp-to-dscps
|   |               +---rw dscp-to-dscp* [dscp-value color]
|   |                   +---rw dscp-value    -> ../config/dscp-value
|   |                   +---rw color        -> ../config/color
|   |                   +---rw config
|   |                       | +---rw dscp-value?    uint8
|   |                       | +---rw color?         ipi-qos-types:qos_color_key_t
|   |                       | +---rw remark-dscp-value    uint8
|   |                       +---ro state
|   |                           +---ro dscp-value?    uint8
|   |                           +---ro color?         ipi-qos-types:qos_color_key_t
|   |                           +---ro remark-dscp-value    uint8
|   +---rw precedence-to-precedence-profiles {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
|   |   +---rw precedence-to-precedence-profile* [name]
|   |       +---rw name             -> ../config/name
|   |       +---rw config
|   |           | +---rw name?    string
|   |           +---ro state
|   |           | +---ro name?    string
|   |           +---rw precedence-to-precedences
|   |               +---rw precedence-to-precedence* [precedence-value]
|   |                   +---rw precedence-value    -> ../config/precedence-value

```



```

| |          +---rw config
| |          | +---rw precedence-value?          uint8
| |          | +---rw remark-precedence-value    uint8
| |          +---ro state
| |          +---ro precedence-value?            uint8
| |          +---ro remark-precedence-value      uint8
| +---rw dscp-to-queue-profiles
| |   +---rw dscp-to-queue-profile* [name]
| |     +---rw name          -> ../config/name
| |     +---rw config
| |     | +---rw name?      string
| |     +---ro state
| |     | +---ro name?     string
| |     +---rw dscp-to-queues
| |       +---rw dscp-to-queue* [dscp-value]
| |       +---rw dscp-value  -> ../config/dscp-value
| |       +---rw config
| |       | +---rw dscp-value?          uint8
| |       | +---rw queue-id            uint8
| |       | +---rw color?              ipi-qos-types:qos_color_t
| |       | +---rw remark-dscp-value?   uint8 {feature-
list:HAVE_CUSTOM2_QOS}?
| |       +---ro state
| |       +---ro dscp-value?            uint8
| |       +---ro queue-id              uint8
| |       +---ro color?                ipi-qos-types:qos_color_t
| |       +---ro remark-dscp-value?     uint8 {feature-
list:HAVE_CUSTOM2_QOS}?
| +---rw dscp-encapsulation-profiles {feature-list:HAVE_CUSTOM2_QOS}?
| |   +---rw dscp-encapsulation-profile* [name]
| |     +---rw name          -> ../config/name
| |     +---rw config
| |     | +---rw name?      string
| |     +---ro state
| |     | +---ro name?     string
| |     +---rw layer-2
| |     | +---rw queue-color-to-dscps
| |     | | +---rw queue-color-to-dscp* [queue-id color]
| |     | | +---rw queue-id  -> ../config/queue-id
| |     | | +---rw color    -> ../config/color
| |     | | +---rw config
| |     | | | +---rw queue-id?    uint8
| |     | | | +---rw color?      ipi-qos-types:qos_color_key_t
| |     | | | +---rw dscp-value   uint8
| |     | | +---ro state
| |     | | +---ro queue-id?     uint8
| |     | | +---ro color?       ipi-qos-types:qos_color_key_t
| |     | | +---ro dscp-value    uint8
| |     +---rw layer-3
| |     +---rw dscp-to-dscp-encaps
| |     +---rw dscp-to-dscp-encap* [dscp-value]

```



```

| | | | +--rw color?          ipi-qos-types:qos_color_t
| | | | +---ro state
| | | | | +--ro exp-value?    uint8
| | | | | +--ro queue-id      uint8
| | | | | +--ro color?       ipi-qos-types:qos_color_t
| +---rw queue-color-to-cos-profiles
| | +---rw queue-color-to-cos-profile* [name]
| | | +---rw name              -> ../config/name
| | | +---rw config
| | | | +--rw name?          string
| | | +---ro state
| | | | +--ro name?          string
| | | +---rw queue-color-to-coses
| | | | +---rw queue-color-to-cos* [queue-id color]
| | | | | +--rw queue-id      -> ../config/queue-id
| | | | | +--rw color          -> ../config/color
| | | | | +---rw config
| | | | | | +--rw queue-id?    uint8
| | | | | | +--rw color?      ipi-qos-types:qos_color_key_t
| | | | | | +--rw cos-value    uint8
| | | | | +---ro state
| | | | | | +--ro queue-id?    uint8
| | | | | | +--ro color?      ipi-qos-types:qos_color_key_t
| | | | | | +--ro cos-value    uint8
| +---rw precedence-to-queue-profiles
| | +---rw precedence-to-queue-profile* [name]
| | | +---rw name              -> ../config/name
| | | +---rw config
| | | | +--rw name?          string
| | | +---ro state
| | | | +--ro name?          string
| | | +---rw precedence-to-queues
| | | | +---rw precedence-to-queue* [precedence-value]
| | | | | +--rw precedence-value -> ../config/precedence-value
| | | | | +---rw config
| | | | | | +--rw precedence-value?    uint8
| | | | | | +--rw queue-id            uint8
| | | | | | +--rw remark-precedence-value? uint8 {feature-
list:HAVE_CUSTOM2_QOS}?
| | | | | +---ro state
| | | | | | +--ro precedence-value?    uint8
| | | | | | +--ro queue-id            uint8
| | | | | | +--ro remark-precedence-value? uint8 {feature-
list:HAVE_CUSTOM2_QOS}?
| | +---rw queue-color-to-dscp-profiles
| | | +---rw queue-color-to-dscp-profile* [name]
| | | | +---rw name              -> ../config/name
| | | | +---rw config
| | | | | +--rw name?          string
| | | | +---ro state
| | | | | +--ro name?          string

```

```

|         +---rw queue-color-to-dscps
|             +---rw queue-color-to-dscp* [queue-id color]
|                 +---rw queue-id    -> ../config/queue-id
|                 +---rw color       -> ../config/color
|                 +---rw config
|                     | +---rw queue-id?    uint8
|                     | +---rw color?      ipi-qos-types:qos_color_key_t
|                     | +---rw dscp-value  uint8
|                 +---ro state
|                     +---ro queue-id?    uint8
|                     +---ro color?      ipi-qos-types:qos_color_key_t
|                     +---ro dscp-value  uint8
+---rw remark
|   +---rw config
|   |   +---rw cos?    empty
|   |   +---rw dscp?  empty
|   +---ro state
|       +---ro cos?    empty
|       +---ro dscp?  empty
+---ro class-maps-default
|   +---ro class-map-default* [name]
|       +---ro name      -> ../state/name
|       +---ro state
|           +---ro name?          string
|           +---ro type?         ipi-qos-types:qos_class_map_default_t
|           +---ro match-criteria? ipi-qos-types:qos_match_criteria_t
+---rw class-maps
|   +---rw class-map* [name]
|       +---rw name          -> ../config/name
|       +---rw config
|           | +---rw name?          string
|           | +---rw type           ipi-qos-types:qos_class_map_t
|           | +---rw match-criteria ipi-qos-types:qos_match_criteria_t
|           | +---rw reference-description? cml-data-types:cml_line_t
|       +---ro state
|           | +---ro name?          string
|           | +---ro type           ipi-qos-types:qos_class_map_t
|           | +---ro match-criteria ipi-qos-types:qos_match_criteria_t
|           | +---ro reference-description? cml-data-types:cml_line_t
|       +---rw match-any-conditions
|           | +---rw config
|           | | +---rw access-control-list-name?  string
|           | | +---rw ethertype*                string
|           | | +---rw traffic-type*             ipi-qos-types:qos_traffic_type_t
|           | | +---rw cos?                       cml-data-types:cml_range_t
|           | | +---rw inner-cos?                 cml-data-types:cml_range_t
|           | | +---rw vlan?                     cml-data-types:cml_range_t
|           | | +---rw inner-vlan?               cml-data-types:cml_range_t
|           | | +---rw rtp?                      cml-data-types:cml_range_t
|           | | | +---rw mpls-exp?               cml-data-types:cml_range_t {feature-
list:HAVE_DIFFSERV}?

```

```

|         | | +--rw dscp?                               cml-data-types:cml_range_t
|         | | +--rw ipv6-dscp?                         cml-data-types:cml_range_t {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
|         | | +--rw precedence?                       cml-data-types:cml_range_t
|         | | +--rw ipv6-precedence?                 cml-data-types:cml_range_t {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
|         | +--ro state
|         | | +--ro access-control-list-name?        string
|         | | +--ro ethertype*                       string
|         | | +--ro traffic-type*                   ipi-qos-types:qos_traffic_type_t
|         | | +--ro cos?                             cml-data-types:cml_range_t
|         | | +--ro inner-cos?                      cml-data-types:cml_range_t
|         | | +--ro vlan?                           cml-data-types:cml_range_t
|         | | +--ro inner-vlan?                    cml-data-types:cml_range_t
|         | | +--ro rtp?                             cml-data-types:cml_range_t
|         | | +--ro mpls-exp?                       cml-data-types:cml_range_t {feature-
list:HAVE_DIFFSERV}?
|         | | +--ro dscp?                             cml-data-types:cml_range_t
|         | | +--ro ipv6-dscp?                       cml-data-types:cml_range_t {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
|         | | +--ro precedence?                     cml-data-types:cml_range_t
|         | | +--ro ipv6-precedence?                cml-data-types:cml_range_t {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
|         | +--rw ipv4
|         | | +--rw layer4-match* [protocol port-type]
|         | | | +--rw protocol      -> ../config/protocol
|         | | | +--rw port-type     -> ../config/port-type
|         | | | +--rw config
|         | | | | +--rw protocol?   ipi-qos-types:qos_layer4_protocol_t
|         | | | | +--rw port-type?  ipi-qos-types:qos_layer4_port_t
|         | | | | +--rw port       cml-data-types:cml_range_t
|         | | | +--ro state
|         | | | | +--ro protocol?   ipi-qos-types:qos_layer4_protocol_t
|         | | | | +--ro port-type?  ipi-qos-types:qos_layer4_port_t
|         | | | | +--ro port       cml-data-types:cml_range_t
|         | | +--rw ipv6
|         | | | +--rw layer4-match* [protocol port-type] {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
|         | | | | +--rw protocol      -> ../config/protocol
|         | | | | +--rw port-type     -> ../config/port-type
|         | | | | +--rw config
|         | | | | | +--rw protocol?   ipi-qos-types:qos_layer4_protocol_t
|         | | | | | +--rw port-type?  ipi-qos-types:qos_layer4_port_t
|         | | | | | +--rw port       cml-data-types:cml_range_t
|         | | | | +--ro state
|         | | | | | +--ro protocol?   ipi-qos-types:qos_layer4_protocol_t
|         | | | | | +--ro port-type?  ipi-qos-types:qos_layer4_port_t
|         | | | | | +--ro port       cml-data-types:cml_range_t
|         | +--rw match-all-conditions
|         | | +--rw config
|         | | | +--rw ethertype-all?                string
|         | | | +--rw traffic-type-all?            ipi-qos-types:qos_traffic_type_t

```

```

|         | +---rw cos-all?                uint8
|         | +---rw inner-cos-all?          uint8
|         | +---rw vlan-all?              uint16
|         | +---rw inner-vlan-all?        uint16
|         | +---rw rtp-all?               uint32
|         | +---rw mpls-exp-all?          uint8 {feature-list:HAVE_DIFFSERV}?
|         | +---rw dscp-all?              string
|         | +---rw ipv6-dscp-all?         string {feature-list:HAVE_CUSTOM2_QOS}?
|         | +---rw precedence-all?        string
|         | +---rw ipv6-precedence-all?   string {feature-list:HAVE_CUSTOM2_QOS}?
|         +---ro state
|         | +---ro ethertype-all?         string
|         | +---ro traffic-type-all?     ipi-qos-types:qos_traffic_type_t
|         | +---ro cos-all?               uint8
|         | +---ro inner-cos-all?         uint8
|         | +---ro vlan-all?              uint16
|         | +---ro inner-vlan-all?        uint16
|         | +---ro rtp-all?               uint32
|         | +---ro mpls-exp-all?          uint8 {feature-list:HAVE_DIFFSERV}?
|         | +---ro dscp-all?              string
|         | +---ro ipv6-dscp-all?         string {feature-list:HAVE_CUSTOM2_QOS}?
|         | +---ro precedence-all?        string
|         | +---ro ipv6-precedence-all?   string {feature-list:HAVE_CUSTOM2_QOS}?
|         +---rw layer4-matches-ipv4
|         | +---rw layer4-match-ipv4* [protocol-all port-type-all port-all]
|         |   +---rw protocol-all        -> ../config/protocol-all
|         |   +---rw port-type-all        -> ../config/port-type-all
|         |   +---rw port-all            -> ../config/port-all
|         |   +---rw config
|         |     | +---rw protocol-all?    ipi-qos-types:qos_layer4_protocol_t
|         |     | +---rw port-type-all?   ipi-qos-types:qos_layer4_port_t
|         |     | +---rw port-all?        uint16
|         |     +---ro state
|         |       +---ro protocol-all?    ipi-qos-types:qos_layer4_protocol_t
|         |       +---ro port-type-all?   ipi-qos-types:qos_layer4_port_t
|         |       +---ro port-all?        uint16
|         +---rw layer4-matches-ipv6 {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
|         | +---rw layer4-match-ipv6* [protocol-all port-type-all port-all]
|         |   +---rw protocol-all        -> ../config/protocol-all
|         |   +---rw port-type-all        -> ../config/port-type-all
|         |   +---rw port-all            -> ../config/port-all
|         |   +---rw config
|         |     | +---rw protocol-all?    ipi-qos-types:qos_layer4_protocol_t
|         |     | +---rw port-type-all?   ipi-qos-types:qos_layer4_port_t
|         |     | +---rw port-all?        uint16
|         |     +---ro state
|         |       +---ro protocol-all?    ipi-qos-types:qos_layer4_protocol_t
|         |       +---ro port-type-all?   ipi-qos-types:qos_layer4_port_t
|         |       +---ro port-all?        uint16
+---rw class-maps-queuing

```

```

| +--rw class-map-queuing* [name]
|   +--rw name          -> ../config/name
|   +--rw config
|     | +--rw name?          string
|     | +--rw type          ipi-qos-types:qos_class_map_t
|     | +--rw reference-description? cml-data-types:cml_line_t
|     +--ro state
|       | +--ro name?       string
|       | +--ro type        ipi-qos-types:qos_class_map_t
|       | +--ro reference-description? cml-data-types:cml_line_t
|     +--rw match-conditions
|       +--rw config
|         | +--rw vlan-queue?    uint16
|         | +--rw queue*        uint8 {feature-
list:HAVE_SERVICE_QUEUING_2}?
|         | +--rw service-template-name? string {feature-
list:HAVE_SERVICE_QUEUING_2}?
|         | +--rw interface?    string {feature-
list:HAVE_SERVICE_QUEUING_2}?
|         +--ro state
|           +--ro vlan-queue?    uint16
|           +--ro queue*        uint8 {feature-
list:HAVE_SERVICE_QUEUING_2}?
|           +--ro service-template-name? string {feature-
list:HAVE_SERVICE_QUEUING_2}?
|           +--ro interface?    string {feature-
list:HAVE_SERVICE_QUEUING_2}?
|     +--rw policy-maps
|       +--rw policy-map* [policy-map-name]
|         +--rw policy-map-name  -> ../config/policy-map-name
|         +--rw config
|           | +--rw policy-map-name?    string
|           | +--rw type                ipi-qos-types:qos_policy_map_t
|           | +--rw reference-description? cml-data-types:cml_line_t
|           +--ro state
|             | +--ro policy-map-name?    string
|             | +--ro type                ipi-qos-types:qos_policy_map_t
|             | +--ro reference-description? cml-data-types:cml_line_t
|           +--rw classes
|             +--rw class* [class-map-name]
|               +--rw class-map-name  -> ../config/class-map-name
|               +--rw config
|                 | +--rw class-map-name?    ipi-qos-
types:qos_policy_map_class_t
|                 | +--rw type                ipi-qos-types:qos_policy_map_t
|                 | +--rw child-service-policy-name? -> /qos/global/policy-maps/
policy-map/policy-map-name
|                 | +--rw reference-description?    cml-data-types:cml_line_t
|                 +--ro state
|                   | +--ro class-map-name?    ipi-qos-
types:qos_policy_map_class_t
|                   | +--ro type                ipi-qos-types:qos_policy_map_t

```

```

| +--ro child-service-policy-name? -> /qos/global/policy-maps/
policy-map/policy-map-name
| +--ro reference-description?      cml-data-types:cml_line_t
+--rw queue-mode
| +--rw config
| | +--rw byte-compensation?        int8 {feature-
list:HAVE_CUSTOM2_QOS}?
| | +--rw delay-tolerance?          empty {feature-
list:HAVE_CUSTOM2_QOS}?
| | +--rw priority-level?           uint8 {feature-
list:HAVE_CUSTOM2_QOS}?
| | +--rw weighted-fair-queueing-queue-weight? uint8 {feature-
list:HAVE_CUSTOM2_QOS}?
| +--ro state
| | +--ro byte-compensation?        int8 {feature-
list:HAVE_CUSTOM2_QOS}?
| | +--ro delay-tolerance?          empty {feature-
list:HAVE_CUSTOM2_QOS}?
| | +--ro priority-level?           uint8 {feature-
list:HAVE_CUSTOM2_QOS}?
| | +--ro weighted-fair-queueing-queue-weight? uint8 {feature-
list:HAVE_CUSTOM2_QOS}?
| +--rw red
| | +--rw config
| | | +--rw weight?      uint8
| | +--ro state
| | | +--ro weight?      uint8
| | +--rw wreds {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
| | | +--rw wred* [color]
| | | +--rw color      -> ../config/color
| | | +--rw config!
| | | | +--rw color?          ipi-qos-
types:qos_color_key_t
| | | | +--rw min-threshold    uint32
| | | | +--rw min-threshold-unit ipi-qos-
types:qos_threshold_t
| | | | +--rw max-threshold    uint32
| | | | +--rw max-threshold-unit ipi-qos-
types:qos_threshold_t
| | | | +--rw drop-probability? uint8
| | | +--ro state
| | | +--ro color?            ipi-qos-types:qos_color_key_t
| | | +--ro min-threshold    uint32
| | | +--ro min-threshold-unit ipi-qos-
types:qos_threshold_t
| | | +--ro max-threshold    uint32
| | | +--ro max-threshold-unit ipi-qos-
types:qos_threshold_t
| | | +--ro drop-probability? uint8
| +--rw tail-drops
| | +--rw tail-drop* [max-threshold max-threshold-type]
| | +--rw max-threshold      -> ../config/max-threshold
| | +--rw max-threshold-type -> ../config/max-threshold-type

```



```

    | |      +---rw config
    | |      | +---rw max-threshold?          uint32
    | |      | +---rw max-threshold-type?    ipi-qos-types:qos_threshold_t
    | |      +---ro state
    | |          +---ro max-threshold?      uint32
    | |          +---ro max-threshold-type? ipi-qos-types:qos_threshold_t
    | +---rw shapes
    |     +---rw shape* [rate-value rate-unit]
    |         +---rw rate-value      -> ../config/rate-value
    |         +---rw rate-unit      -> ../config/rate-unit
    |         +---rw config
    |             | +---rw rate-value?    uint32
    |             | +---rw rate-unit?    ipi-qos-
types:qos_shape_rate_unit_extended_t
    |             +---ro state
    |                 +---ro rate-value?  uint32
    |                 +---ro rate-unit?  ipi-qos-
types:qos_shape_rate_unit_extended_t
    +---rw qos-mode
        +---rw config
            | +---rw priority?            uint16
            | +---rw (set-option)?
            |     +---:(port-action)
            |     +---:(precedence)
            |     | +---rw precedence-remark?  string
            |     +---:(bridge-precedence)
            |     +---:(cos)
            |     | +---rw cos-value?          uint8
            |     +---:(bridge-cos)
            |     +---:(dscp)
            |     | +---rw dscp-value-remark?  string
            |     +---:(bridge-dscp)
            |     +---:(queue)
            |     | +---rw queue-id?          uint8
            |     +---:(bridge-queue)
            |     +---:(qos-group)
        +---ro state
            | +---ro priority?            uint16
            | +---ro (set-option)?
            |     +---:(port-action)
            |     +---:(precedence)
            |     | +---ro precedence-remark?  string
            |     +---:(bridge-precedence)
            |     +---:(cos)
            |     | +---ro cos-value?          uint8
            |     +---:(bridge-cos)
            |     +---:(dscp)
            |     | +---ro dscp-value-remark?  string
            |     +---:(bridge-dscp)
            |     +---:(queue)
            |     | +---ro queue-id?          uint8

```

```

|      +---:(bridge-queue)
|      +---:(qos-group)
+---rw police
    +---rw config
        | +---rw type?          ipi-qos-types:qos_police_t
        | +---rw cir?           uint64
        | +---rw cir-unit?     ipi-qos-types:qos_rate_unit_t
        | +---rw bc?           uint64
        | +---rw bc-unit?     ipi-qos-types:qos_burst_rate_unit_t
        | +---rw eir?          uint64 {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
        | +---rw eir-unit?     ipi-qos-types:qos_rate_unit_t {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
        | +---rw be?           uint32
        | +---rw be-unit?     ipi-qos-types:qos_burst_rate_unit_t
    +---ro state
        +---ro type?          ipi-qos-types:qos_police_t
        +---ro cir?           uint64
        +---ro cir-unit?     ipi-qos-types:qos_rate_unit_t
        +---ro bc?           uint64
        +---ro bc-unit?     ipi-qos-types:qos_burst_rate_unit_t
        +---ro eir?          uint64 {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
        +---ro eir-unit?     ipi-qos-types:qos_rate_unit_t {feature-
list:HAVE_CUSTOM2_QOS_OR_HAVE_CUSTOM4_QOS}?
        +---ro be?           uint32
        +---ro be-unit?     ipi-qos-types:qos_burst_rate_unit_t

rpcs:
+---x qos-clear-statistics {feature-list:HAVE_QOS}?
+---w input
    +---w interface-name?    string
    +---w type?              ipi-qos-types:qos_clear_stats_t

```

module: ipi-radius

```

+---rw radius
    +---rw vrfs
        | +---rw vrf* [vrf-name] {feature-list:HAVE_AAA}?
        | +---rw vrf-name      -> ../config/vrf-name
        | +---rw config
        | | +---rw vrf-name?    -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
        | | +---rw key-type?    ipi-radius-types:radius_hostp_key_type_t
        | | +---rw secret-key-string? string
        | | +---rw timeout?    uint8
        | +---ro state
        | | +---ro vrf-name?    -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name

```

```

|     | +---ro key-type?          ipi-radius-types:radius_hostp_key_type_t
|     | +---ro secret-key-string? string
|     | +---ro timeout?          uint8
| +---rw remote-servers
|     +---rw server* [host-address] {feature-list:HAVE_AAA}?
|         +---rw host-address    -> ../config/host-address
|         +---rw config
|             +---rw host-address?    cml-data-types:cml_hostname_t
|             +---rw sequence-number  uint8
|             | +---rw key-type?      ipi-radius-types:radius_hostp_key_type_t
|             | +---rw secret-key-string? string
|             | +---rw accounting-port? uint16
|             | +---rw authentication-port? uint16
|             | +---rw timeout?      uint8
|             +---ro state
|                 +---ro host-address?    cml-data-
types:cml_hostname_t
|                 +---ro sequence-number  uint8
|                 +---ro key-type?      ipi-radius-
types:radius_hostp_key_type_t
|                 +---ro secret-key-string? string
|                 +---ro accounting-port? uint16
|                 +---ro authentication-port? uint16
|                 +---ro timeout?      uint8
|                 +---ro last-successful-authentication-time? yang:date-and-time
|                 +---ro counters
|                     +---ro successful-authentications? yang:counter64
|                     +---ro authentication-failures?   yang:counter64
|                     +---ro connection-failures?      yang:counter64
+---rw debug
    +---rw config
        | +---rw enable?    empty
    +---ro state
        +---ro enable?      empty
        +---ro terminal-debug-status? cml-data-types:cml_on_off_t

rpcs:
+---x radius-clear-all-server-counters {feature-list:HAVE_HOSTPD,feature-
list:HAVE_RADIUS_CLIENT}?
| +---w input
|     +---w vrf-name    string
+---x radius-clear-server-counters {feature-list:HAVE_HOSTPD,feature-
list:HAVE_RADIUS_CLIENT}?
| +---w input
|     +---w hostname    cml-data-types:cml_hostname_t
|     +---w vrf-name    string
+---x radius-terminal-debug-on {feature-list:HAVE_HOSTPD,feature-
list:HAVE_RADIUS_CLIENT}?
+---x radius-terminal-debug-off {feature-list:HAVE_HOSTPD,feature-
list:HAVE_RADIUS_CLIENT}?

```

module: ipi-ras

```

rpcs:
  +---x platform-clear-hsl-ipc-stat-values {feature-list:HAVE_HAL,feature-
list:HAVE_PLATFORM_RAS}?
  | +---w input
  |   +---w start-value      uint16
  |   +---w end-value       uint16
  +---x platform-clear-hsl-ipc-stat {feature-list:HAVE_HAL,feature-
list:HAVE_PLATFORM_RAS}?
  +---x platform-clear-hsl-mlag-mac-sync {feature-list:HAVE_MLAG}?
  +---x platform-clear-hardware-discard-counters {feature-list:HAVE_HAL,feature-
list:HAVE_PLATFORM_RAS}?
  +---x platform-clear-hsl-fdb-debug-counters {feature-list:HAVE_HAL,feature-
list:HAVE_PLATFORM_RAS}?

```

module: ipi-rib-vrf

```

augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance/ipi-vrf:vrf:
  +--rw global
  | +--rw config
  | | +--rw ipv4-enable-bfd-all-interfaces?  empty {feature-list:HAVE_BFD}?
  | | +--rw ipv6-enable-bfd-all-interfaces?  empty {feature-list:HAVE_BFD,feature-
list:HAVE_IPV6}?
  | +--ro state
  | | +--ro ipv4-enable-bfd-all-interfaces?  empty {feature-list:HAVE_BFD}?
  | | +--ro ipv6-enable-bfd-all-interfaces?  empty {feature-list:HAVE_BFD,feature-
list:HAVE_IPV6}?
  augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance/ipi-vrf:vrf:
    +--rw static-routes
    | +--rw ipv4
    | | +--rw gateway-interface-routes-global
    | | | +--rw gateway-interface-route-global* [destination-prefix interface-name
enable-global-table-lookup]
    | | | | +--rw destination-prefix          -> ../config/destination-prefix
    | | | | +--rw interface-name              -> ../config/interface-name
    | | | | +--rw enable-global-table-lookup  -> ../config/enable-global-table-
lookup
    | | | | +--rw config
    | | | | | +--rw destination-prefix?      cml-data-types:cml_ipv4_prefix_t
    | | | | | +--rw interface-name?         string
    | | | | | +--rw enable-global-table-lookup?  empty
    | | | | | +--rw track-id?                uint16 {feature-
list:HAVE_OBJ_TRACKING}?

```

```

| |      +---ro state
| |      +---ro destination-prefix?      cml-data-types:cml_ipv4_prefix_t
| |      +---ro interface-name?          string
| |      +---ro enable-global-table-lookup?  empty
| |      +---ro track-id?                 uint16 {feature-
list:HAVE_OBJ_TRACKING}?
| +---rw routes
| | +---rw route* [destination-prefix gateway-address]
| | +---rw destination-prefix            -> ../config/destination-prefix
| | +---rw gateway-address                -> ../config/gateway-address
| | +---rw config
| | | +---rw bfd-state?                  ipi-rib-
types:rib_static_bfd_enable_disable_t {feature-list:HAVE_BFD}?
| | | +---rw destination-prefix?         cml-data-types:cml_ipv4_prefix_t
| | | +---rw gateway-address?           inet:ipv4-address
| | | +---ro state
| | | +---ro bfd-state?                  ipi-rib-
types:rib_static_bfd_enable_disable_t {feature-list:HAVE_BFD}?
| | | +---ro destination-prefix?         cml-data-types:cml_ipv4_prefix_t
| | | +---ro gateway-address?           inet:ipv4-address
| | | +---rw gateway-interface-routes
| | | +---rw gateway-interface-route* [interface-name]
| | | | +---rw interface-name           -> ../config/interface-name
| | | | +---rw config
| | | | | +---rw distance?              uint32
| | | | | +---rw tag?                  uint32
| | | | | +---rw track-id?             uint16 {feature-list:HAVE_OBJ_TRACKING}?
| | | | | +---rw description?          cml-data-types:cml_line_t
| | | | | +---rw interface-name?       string
| | | | +---ro state
| | | | | +---ro distance?              uint32
| | | | | +---ro tag?                  uint32
| | | | | +---ro track-id?             uint16 {feature-list:HAVE_OBJ_TRACKING}?
| | | | | +---ro description?          cml-data-types:cml_line_t
| | | | | +---ro interface-name?       string
| | | +---rw interface-routes-global
| | | +---rw interface-route-global* [interface-name enable-global-table-
lookup]
| | | | +---rw interface-name           -> ../config/interface-name
| | | | +---rw enable-global-table-lookup -> ../config/enable-global-
table-lookup
| | | | +---rw config
| | | | | +---rw interface-name?         string
| | | | | +---rw enable-global-table-lookup?  empty
| | | | | +---rw track-id?             uint16 {feature-
list:HAVE_OBJ_TRACKING}?
| | | | +---ro state
| | | | | +---ro interface-name?         string
| | | | | +---ro enable-global-table-lookup?  empty
| | | | | +---ro track-id?             uint16 {feature-
list:HAVE_OBJ_TRACKING}?
| | | +---rw interface-routes

```

```

| | +--rw interface-route* [destination-prefix interface-name]
| |   +--rw destination-prefix -> ../config/destination-prefix
| |   +--rw interface-name -> ../config/interface-name
| |   +--rw config
| |     | +--rw destination-prefix? cml-data-types:cml_ipv4_prefix_t
| |     | +--rw interface-name? string
| |     | +--rw distance? uint32
| |     | +--rw tag? uint32
| |     | +--rw track-id? uint16 {feature-list:HAVE_OBJ_TRACKING}?
| |     | +--rw description? cml-data-types:cml_line_t
| |   +--ro state
| |     +--ro destination-prefix? cml-data-types:cml_ipv4_prefix_t
| |     +--ro interface-name? string
| |     +--ro distance? uint32
| |     +--ro tag? uint32
| |     +--ro track-id? uint16 {feature-list:HAVE_OBJ_TRACKING}?
| |     +--ro description? cml-data-types:cml_line_t
| +--rw multicast-routes
|   +--rw multicast-route* [source-prefix protocol-type]
|     +--rw source-prefix -> ../config/source-prefix
|     +--rw protocol-type -> ../config/protocol-type
|     +--rw config
|       | +--rw source-prefix? cml-data-types:cml_ipv4_prefix_t
|       | +--rw protocol-type? ipi-rib-types:rib_mroute_route_type_t
|       | +--rw gateway-address inet:ipv4-address
|       | +--rw distance? uint32
|     +--ro state
|       +--ro source-prefix? cml-data-types:cml_ipv4_prefix_t
|       +--ro protocol-type? ipi-rib-types:rib_mroute_route_type_t
|       +--ro gateway-address inet:ipv4-address
|       +--ro distance? uint32
+--rw ipv6 {feature-list:HAVE_IPV6}?
  +--rw interface-routes-global
  | +--rw interface-route-global* [destination-prefix interface-name enable-
  | ipv6-global-table-lookup]
  |   +--rw destination-prefix -> ../config/destination-prefix
  |   +--rw interface-name -> ../config/interface-name
  |   +--rw enable-ipv6-global-table-lookup -> ../config/enable-ipv6-global-
  | table-lookup
  |   +--rw config
  |     | +--rw destination-prefix? cml-data-
  |     | types:cml_ipv6_prefix_t
  |     | +--rw interface-name? string
  |     | +--rw enable-ipv6-global-table-lookup? empty
  |     | +--rw track-id? uint16 {feature-
  |     | list:HAVE_OBJ_TRACKING}?
  |   +--ro state
  |     +--ro destination-prefix? cml-data-
  |     | types:cml_ipv6_prefix_t
  |     +--ro interface-name? string
  |     +--ro enable-ipv6-global-table-lookup? empty

```

```

|           +--ro track-id?                               uint16 {feature-
list:HAVE_OBJ_TRACKING}?
|           +--rw gateway-interface-routes-global
|           | +--rw gateway-interface-route-global* [destination-prefix gateway-address
interface-name enable-ipv6-global-table-lookup]
|           | +--rw destination-prefix                   -> ../config/destination-prefix
|           | +--rw gateway-address                       -> ../config/gateway-address
|           | +--rw interface-name                       -> ../config/interface-name
|           | +--rw enable-ipv6-global-table-lookup      -> ../config/enable-ipv6-global-
table-lookup
|           | +--rw config
|           | | +--rw destination-prefix?                 cml-data-
types:cml_ipv6_prefix_t
|           | | +--rw gateway-address?                   inet:ipv6-address
|           | | +--rw interface-name?                   string
|           | | +--rw enable-ipv6-global-table-lookup?  empty
|           | | +--rw track-id?                         uint16 {feature-
list:HAVE_OBJ_TRACKING}?
|           | +--ro state
|           | +--ro destination-prefix?                 cml-data-
types:cml_ipv6_prefix_t
|           | +--ro gateway-address?                   inet:ipv6-address
|           | +--ro interface-name?                   string
|           | +--ro enable-ipv6-global-table-lookup?  empty
|           | +--ro track-id?                         uint16 {feature-
list:HAVE_OBJ_TRACKING}?
|           +--rw routes
|           | +--rw route* [destination-prefix gateway-address]
|           | +--rw destination-prefix                 -> ../config/destination-prefix
|           | +--rw gateway-address                   -> ../config/gateway-address
|           | +--rw config
|           | | +--rw bfd-state?                       ipi-rib-
types:rib_static_bfd_enable_disable_t {feature-list:HAVE_BFD}?
|           | | +--rw destination-prefix?                 cml-data-
types:cml_ipv6_prefix_t
|           | | +--rw gateway-address?                   inet:ipv6-address
|           | | +--rw enable-ipv6-global-table-lookup?  empty
|           | +--ro state
|           | | +--ro bfd-state?                       ipi-rib-
types:rib_static_bfd_enable_disable_t {feature-list:HAVE_BFD}?
|           | | +--ro destination-prefix?                 cml-data-
types:cml_ipv6_prefix_t
|           | | +--ro gateway-address?                   inet:ipv6-address
|           | | +--ro enable-ipv6-global-table-lookup?  empty
|           | +--rw out-interfaces
|           | +--rw out-interface* [interface-name]
|           | | +--rw interface-name                   -> ../config/interface-name
|           | | +--rw config
|           | | | +--rw interface-name?                 string
|           | | | +--rw track-id?                       uint16 {feature-list:HAVE_OBJ_TRACKING}?
|           | | | +--rw description?                   cml-data-types:cml_line_t
|           | | +--ro state
|           | | +--ro interface-name?                 string

```

```

|           +---ro track-id?           uint16 {feature-list:HAVE_OBJ_TRACKING}?
|           +---ro description?       cml-data-types:cml_line_t
+---rw interface-routes
| +---rw interface-route* [destination-prefix interface-name]
|   +---rw destination-prefix   -> ../config/destination-prefix
|   +---rw interface-name      -> ../config/interface-name
|   +---rw config
|     | +---rw destination-prefix?   cml-data-types:cml_ipv6_prefix_t
|     | +---rw interface-name?      string
|     | +---rw track-id?            uint16 {feature-list:HAVE_OBJ_TRACKING}?
|     | +---rw description?         cml-data-types:cml_line_t
|     +---ro state
|       +---ro destination-prefix?   cml-data-types:cml_ipv6_prefix_t
|       +---ro interface-name?      string
|       +---ro track-id?            uint16 {feature-list:HAVE_OBJ_TRACKING}?
|       +---ro description?         cml-data-types:cml_line_t
+---rw multicast-routes
  +---rw multicast-route* [source-prefix protocol-type]
  +---rw source-prefix   -> ../config/source-prefix
  +---rw protocol-type   -> ../config/protocol-type
  +---rw config
  | +---rw source-prefix?   cml-data-types:cml_ipv6_prefix_t
  | +---rw protocol-type?   ipi-rib-types:rib_mroute_ipv6_route_type_t
  +---ro state
  | +---ro source-prefix?   cml-data-types:cml_ipv6_prefix_t
  | +---ro protocol-type?   ipi-rib-types:rib_mroute_ipv6_route_type_t
  +---rw nexthop
    +---rw config!
    | +---rw gateway-mroute   inet:ipv6-address
    | +---rw distance?       uint32
    +---ro state
      +---ro gateway-mroute   inet:ipv6-address
      +---ro distance?       uint32
augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance/ipi-vrf:vrf:
  +---ro ribs
  +---ro ipv4
  | +---ro ecmp-path-summary* [path-count]
  | | +---ro path-count   -> ../state/path-count
  | | +---ro state
  | |   +---ro counters
  | |     | +---ro number-of-routes?   yang:counter32
  | |     +---ro path-count?   uint32
  | +---ro protocol-rib-summary* [protocol-type]
  | | +---ro protocol-type   -> ../state/protocol-type
  | | +---ro state
  | |   +---ro counters
  | |     | +---ro number-of-routes?   yang:counter32
  | |     +---ro protocol-type?   ipi-rib-types:rib_route_type_t
  | +---ro routes
  | | +---ro route* [destination-prefix protocol-type]

```



```

| | | +--ro destination-prefix -> ../state/destination-prefix
| | | +--ro protocol-type -> ../state/protocol-type
| | | +--ro next-hop* [gateway-address]
| | | | +--ro gateway-address -> ../state/gateway-address
| | | | +--ro state
| | | | | +--ro gateway-address? string
| | | | | +--ro recursive-hop* string
| | | | | +--ro interface-name? string
| | | | | +--ro active? empty
| | | | | +--ro fib-installed? empty
| | | | | +--ro object-tracking-reachability? ipi-rib-
types:rib_object_tracking_reachability_status_t {feature-list:HAVE_OBJ_TRACKING}?
| | | +--ro state
| | | | +--ro destination-prefix? cml-data-types:cml_ipv4_prefix_t
| | | | +--ro protocol-type? ipi-rib-types:rib_route_type_t
| | | | +--ro sub-type? ipi-rib-types:rib_route_sub_type_t
| | | | +--ro distance? uint8
| | | | +--ro metric? uint32
| | | | +--ro black-hole? empty
| | | | +--ro up-time? string
| | | | +--ro selected? empty
| | | | +--ro stale? empty
| | +--ro state
| | | +--ro gateway-last-resort? string
| +--ro state
| | +--ro counters
| | | +--ro total-routes? yang:counter32
| | | +--ro total-paths? yang:counter32
| | | +--ro total-routes-in-fib? yang:counter32
| | | +--ro ecmp-routes? yang:counter32
| | | +--ro ecmp-paths? yang:counter32
+--ro ipv6 {feature-list:HAVE_IPV6}?
+--ro ecmp-path-summary* [path-count]
| +--ro path-count -> ../state/path-count
| +--ro state
| | +--ro counters
| | | +--ro number-of-routes? yang:counter32
| | +--ro path-count? uint32
+--ro protocol-rib-summary* [protocol-type]
| +--ro protocol-type -> ../state/protocol-type
| +--ro state
| | +--ro counters
| | | +--ro number-of-routes? yang:counter32
| | +--ro protocol-type? ipi-rib-types:rib_route_type_t
+--ro routes
| +--ro route* [destination-prefix protocol-type]
| | +--ro destination-prefix -> ../state/destination-prefix
| | +--ro protocol-type -> ../state/protocol-type
| | +--ro next-hop* [gateway-address]
| | | +--ro gateway-address -> ../state/gateway-address
| | | +--ro state

```

```

|      |      +---ro gateway-address?          string
|      |      +---ro recursive-hop*           string
|      |      +---ro interface-name?         string
|      |      +---ro active?                  empty
|      |      +---ro fib-installed?          empty
|      |      +---ro object-tracking-reachability?  ipi-rib-
types:rib_object_tracking_reachability_status_t {feature-list:HAVE_OBJ_TRACKING}?
|      +---ro state
|          +---ro destination-prefix?    cml-data-types:cml_ipv6_prefix_t
|          +---ro protocol-type?        ipi-rib-types:rib_route_type_t
|          +---ro sub-type?             ipi-rib-types:rib_route_sub_type_t
|          +---ro distance?             uint8
|          +---ro metric?               uint32
|          +---ro black-hole?           empty
|          +---ro up-time?              string
|          +---ro selected?             empty
|          +---ro stale?                empty
+---ro state
    +---ro counters
        +---ro total-routes?            yang:counter32
        +---ro total-paths?            yang:counter32
        +---ro total-routes-in-fib?    yang:counter32
        +---ro ecmp-routes?            yang:counter32
        +---ro ecmp-paths?            yang:counter32

rpcs:
+---x clear-ip-vrf-route-all {feature-list:HAVE_VRF}?
| +---w input
|   +---w vrf-name      string
+---x clear-ip-vrf-route {feature-list:HAVE_VRF}?
| +---w input
|   +---w vrf-name      string
|   +---w prefix-address  cml-data-types:cml_ipv4_prefix_t
+---x clear-ipv6-vrf-route-all {feature-list:HAVE_VRF,feature-list:HAVE_IPV6}?
| +---w input
|   +---w vrf-name      string
+---x clear-ipv6-vrf-route {feature-list:HAVE_VRF,feature-list:HAVE_IPV6}?
+---w input
+---w vrf-name          string
+---w prefix-ipv6-address  cml-data-types:cml_ipv6_prefix_t

```

module: ipi-rib

```

+--rw routing
  +--rw global
    | +--rw config
    | | +--rw ipv4-enable-bfd-all-interfaces?  empty {feature-list:HAVE_BFD}?
    | | +--rw ipv6-enable-bfd-all-interfaces?  empty {feature-list:HAVE_BFD,feature-
list:HAVE_IPV6}?

```

```

| | +--rw fib-retain? ipi-rib-types:rib_fib_retain_t
{feature-list:HAVE_L3}?
| | +--rw max-ecmp-paths? uint8 {feature-list:HAVE_MULTIPATH}?
| | +--rw max-static-routes? uint32
| | +--rw max-fib-routes? uint32
| +--ro state
|   +--ro ipv4-enable-bfd-all-interfaces? empty {feature-list:HAVE_BFD}?
|   +--ro ipv6-enable-bfd-all-interfaces? empty {feature-list:HAVE_BFD,feature-
list:HAVE_IPV6}?
|   +--ro fib-retain? ipi-rib-types:rib_fib_retain_t
{feature-list:HAVE_L3}?
|   +--ro max-ecmp-paths? uint8 {feature-list:HAVE_MULTIPATH}?
|   +--ro max-static-routes? uint32
|   +--ro max-fib-routes? uint32
+--rw debug
| +--rw config
| | +--rw rib-options? ipi-rib-types:rib_conf_debug_t
| | +--rw ipv4-routing-options? ipi-rib-types:rib_debug_routing_t
| | +--rw ipv6-routing-options? ipi-rib-types:rib_debug_routing_t
| +--ro state
|   +--ro terminal-debug-status
|   | +--ro rib-options? ipi-rib-types:rib_debug_t
|   | +--ro ip-routing-options? ipi-rib-types:rib_debug_routing_t
|   | +--ro ipv6-routing-options? ipi-rib-types:rib_debug_routing_t
|   +--ro rib-options? ipi-rib-types:rib_conf_debug_t
|   +--ro ipv4-routing-options? ipi-rib-types:rib_debug_routing_t
|   +--ro ipv6-routing-options? ipi-rib-types:rib_debug_routing_t
+--rw static-routes
| +--rw ipv4
| | +--rw route-vrfs
| | | +--rw route-vrf* [destination-prefix gateway-address interface-name]
| | |   +--rw destination-prefix -> ../config/destination-prefix
| | |   +--rw gateway-address -> ../config/gateway-address
| | |   +--rw interface-name -> ../config/interface-name
| | |   +--rw config
| | |     +--rw destination-prefix? cml-data-types:cml_ipv4_prefix_t
| | |     +--rw gateway-address? inet:ipv4-address
| | |     +--rw interface-name? string
| | |     +--ro state
| | |       +--ro destination-prefix? cml-data-types:cml_ipv4_prefix_t
| | |       +--ro gateway-address? inet:ipv4-address
| | |       +--ro interface-name? string
| | +--rw routes
| | | +--rw route* [destination-prefix gateway-address]
| | |   +--rw destination-prefix -> ../config/destination-prefix
| | |   +--rw gateway-address -> ../config/gateway-address
| | |   +--rw config
| | |     +--rw bfd-state? ipi-rib-
types:rib_static_bfd_enable_disable_t {feature-list:HAVE_BFD}?
| | |     +--rw destination-prefix? cml-data-types:cml_ipv4_prefix_t
| | |     +--rw gateway-address? inet:ipv4-address

```

```

| | | | +--rw distance?          uint32
| | | | +--rw tag?                uint32
| | | | +--rw track-id?          uint16 {feature-list:HAVE_OBJ_TRACKING}?
| | | | +--rw description?       cml-data-types:cml_line_t
| | | | +--ro state
| | | | +--ro bfd-state?         ipi-rib-
types:rib_static_bfd_enable_disable_t {feature-list:HAVE_BFD}?
| | | | +--ro destination-prefix? cml-data-types:cml_ipv4_prefix_t
| | | | +--ro gateway-address?   inet:ipv4-address
| | | | +--ro distance?         uint32
| | | | +--ro tag?              uint32
| | | | +--ro track-id?         uint16 {feature-list:HAVE_OBJ_TRACKING}?
| | | | +--ro description?      cml-data-types:cml_line_t
| | +--rw interface-routes
| | | +--rw interface-route* [destination-prefix interface-name]
| | | | +--rw destination-prefix -> ../config/destination-prefix
| | | | +--rw interface-name    -> ../config/interface-name
| | | | +--rw config
| | | | | +--rw destination-prefix? cml-data-types:cml_ipv4_prefix_t
| | | | | +--rw interface-name?    string
| | | | | +--rw distance?         uint32
| | | | | +--rw tag?              uint32
| | | | | +--rw track-id?         uint16 {feature-list:HAVE_OBJ_TRACKING}?
| | | | | +--rw description?      cml-data-types:cml_line_t
| | | | | +--ro state
| | | | | +--ro destination-prefix? cml-data-types:cml_ipv4_prefix_t
| | | | | +--ro interface-name?    string
| | | | | +--ro distance?         uint32
| | | | | +--ro tag?              uint32
| | | | | +--ro track-id?         uint16 {feature-list:HAVE_OBJ_TRACKING}?
| | | | | +--ro description?      cml-data-types:cml_line_t
| | +--rw multicast-routes
| | | +--rw multicast-route* [source-prefix protocol-type]
| | | | +--rw source-prefix    -> ../config/source-prefix
| | | | +--rw protocol-type   -> ../config/protocol-type
| | | | +--rw config
| | | | | +--rw source-prefix?   cml-data-types:cml_ipv4_prefix_t
| | | | | +--rw protocol-type?  ipi-rib-types:rib_mroute_route_type_t
| | | | | +--rw gateway-address inet:ipv4-address
| | | | | +--rw distance?      uint32
| | | | | +--ro state
| | | | | +--ro source-prefix?   cml-data-types:cml_ipv4_prefix_t
| | | | | +--ro protocol-type?  ipi-rib-types:rib_mroute_route_type_t
| | | | | +--ro gateway-address inet:ipv4-address
| | | | | +--ro distance?      uint32
| +--rw ipv6 {feature-list:HAVE_IPV6}?
| | +--rw routes
| | | +--rw route* [destination-prefix gateway-address]
| | | | +--rw destination-prefix -> ../config/destination-prefix
| | | | +--rw gateway-address   -> ../config/gateway-address
| | | | +--rw config

```

```

| | | +--rw bfd-state? ipi-rib-
types:rib_static_bfd_enable_disable_t {feature-list:HAVE_BFD}?
| | | +--rw destination-prefix? cml-data-types:cml_ipv6_prefix_t
| | | +--rw gateway-address? inet:ipv6-address
| | | +--rw distance? uint32
| | | +--rw track-id? uint16 {feature-list:HAVE_OBJ_TRACKING}?
| | | +--rw description? cml-data-types:cml_line_t
| | +--ro state
| | +--ro bfd-state? ipi-rib-
types:rib_static_bfd_enable_disable_t {feature-list:HAVE_BFD}?
| | +--ro destination-prefix? cml-data-types:cml_ipv6_prefix_t
| | +--ro gateway-address? inet:ipv6-address
| | +--ro distance? uint32
| | +--ro track-id? uint16 {feature-list:HAVE_OBJ_TRACKING}?
| | +--ro description? cml-data-types:cml_line_t
| +--rw interface-routes
| | +--rw interface-route* [destination-prefix interface-name]
| | +--rw destination-prefix -> ../config/destination-prefix
| | +--rw interface-name -> ../config/interface-name
| | +--rw config
| | | +--rw destination-prefix? cml-data-types:cml_ipv6_prefix_t
| | | +--rw interface-name? string
| | | +--rw distance? uint32
| | | +--rw track-id? uint16 {feature-list:HAVE_OBJ_TRACKING}?
| | | +--rw description? cml-data-types:cml_line_t
| | +--ro state
| | +--ro destination-prefix? cml-data-types:cml_ipv6_prefix_t
| | +--ro interface-name? string
| | +--ro distance? uint32
| | +--ro track-id? uint16 {feature-list:HAVE_OBJ_TRACKING}?
| | +--ro description? cml-data-types:cml_line_t
| +--rw gateway-interface-routes
| | +--rw gateway-interface-route* [destination-prefix gateway-address
interface-name]
| | +--rw destination-prefix -> ../config/destination-prefix
| | +--rw gateway-address -> ../config/gateway-address
| | +--rw interface-name -> ../config/interface-name
| | +--rw config
| | | +--rw destination-prefix? cml-data-types:cml_ipv6_prefix_t
| | | +--rw gateway-address? inet:ipv6-address
| | | +--rw interface-name? string
| | | +--rw distance? uint32
| | | +--rw track-id? uint16 {feature-list:HAVE_OBJ_TRACKING}?
| | | +--rw description? cml-data-types:cml_line_t
| | +--ro state
| | +--ro destination-prefix? cml-data-types:cml_ipv6_prefix_t
| | +--ro gateway-address? inet:ipv6-address
| | +--ro interface-name? string
| | +--ro distance? uint32
| | +--ro track-id? uint16 {feature-list:HAVE_OBJ_TRACKING}?
| | +--ro description? cml-data-types:cml_line_t

```

```
|      +--rw multicast-routes
|      +--rw multicast-route* [source-prefix protocol-type]
|      +--rw source-prefix    -> ../config/source-prefix
|      +--rw protocol-type    -> ../config/protocol-type
|      +--rw config
|      | +--rw source-prefix?  cml-data-types:cml_ipv6_prefix_t
|      | +--rw protocol-type?  ipi-rib-types:rib_mroute_ipv6_route_type_t
|      +--ro state
|      | +--ro source-prefix?  cml-data-types:cml_ipv6_prefix_t
|      | +--ro protocol-type?  ipi-rib-types:rib_mroute_ipv6_route_type_t
|      +--rw nexthop
|      +--rw config!
|      | +--rw gateway-mroute  inet:ipv6-address
|      | +--rw distance?       uint32
|      +--ro state
|      +--ro gateway-mroute    inet:ipv6-address
|      +--ro distance?         uint32
+--ro srv6-sid-entries {feature-list:HAVE_SRV6}?
| +--ro srv6-sid-entry* [sid]
| +--ro sid          -> ../state/sid
| +--ro state
| +--ro sid?         inet:ipv6-address
| +--ro action?     string
| +--ro ipv6-nexthop? inet:ipv6-address
| +--ro originator? string
| +--ro type?       string
| +--ro uptime?    string
+--rw interfaces
  +--rw interface* [name] {feature-list:HAVE_BFD}?
  +--rw name      -> ../config/name
  +--rw config
  | +--rw name?   -> /ipi-interface:interfaces/interface/name
  +--rw state
  | +--rw name?   -> /ipi-interface:interfaces/interface/name
  +--rw bfd {feature-list:HAVE_BFD}?
  +--rw config
  | +--rw ipv4-enable-bfd?  ipi-rib-types:rib_bfd_state {feature-
list:HAVE_BFD}?
  | +--rw ipv6-enable-bfd?  ipi-rib-types:rib_bfd_state {feature-
list:HAVE_BFD,feature-list:HAVE_IPV6}?
  +--ro state
  +--ro ipv4-enable-bfd?  ipi-rib-types:rib_bfd_state {feature-
list:HAVE_BFD}?
  +--ro ipv6-enable-bfd?  ipi-rib-types:rib_bfd_state {feature-
list:HAVE_BFD,feature-list:HAVE_IPV6}?

rpcs:
  +---x rib-snmp-restart {feature-list:HAVE_SNMP}?
  +---x clear-ip-stale-kernel-routes {feature-list:HAVE_RIBD}?
  +---x clear-ipv6-stale-kernel-routes {feature-list:HAVE_IPV6}?
  +---x clear-ip-route-all {feature-list:HAVE_RIBD}?
```

```

+---x clear-ip-route {feature-list:HAVE_RIBD}?
| +---w input
|   +---w prefix-address    cml-data-types:cml_ipv4_prefix_t
+---x clear-ipv6-route-all {feature-list:HAVE_IPV6}?
+---x clear-ipv6-route {feature-list:HAVE_IPV6}?
| +---w input
|   +---w prefix-ipv6-address    cml-data-types:cml_ipv6_prefix_t
+---x rib-terminal-debug-on {feature-list:HAVE_RIBD}?
| +---w input
|   +---w terminal-debug-options    ipi-rib-types:rib_debug_t
+---x rib-terminal-debug-off {feature-list:HAVE_RIBD}?
| +---w input
|   +---w terminal-debug-options    ipi-rib-types:rib_debug_t
+---x rib-terminal-debug-ipv4-routing-on {feature-list:HAVE_RIBD}?
| +---w input
|   +---w terminal-debug-options    ipi-rib-types:rib_debug_routing_t
+---x rib-terminal-debug-ipv4-routing-off {feature-list:HAVE_RIBD}?
| +---w input
|   +---w terminal-debug-options    ipi-rib-types:rib_debug_routing_t
+---x rib-terminal-debug-ipv6-routing-on {feature-list:HAVE_IPV6}?
| +---w input
|   +---w terminal-debug-options    ipi-rib-types:rib_debug_routing_t
+---x rib-terminal-debug-ipv6-routing-off {feature-list:HAVE_IPV6}?
| +---w input
|   +---w terminal-debug-options    ipi-rib-types:rib_debug_routing_t

```

module: ipi-rip

```

+--rw rip
| +--rw global
| | +--rw config
| | +--ro state
+--rw debug
| +--rw config
| | +--rw options?    ipi-rip-types:rip_debug_t
| | +--ro state
| | +--ro options?
| | +--ro terminal-debug-status?    ipi-rip-types:rip_debug_t
+--rw interfaces
| +--rw interface* [name]
| | +--rw name        -> ../config/name
| | +--rw config
| | | +--rw name?
| | | +--rw disable-receive-packet?    empty
| | | +--rw disable-send-packet?      empty
| | +--rw name?
| | +--rw disable-receive-packet?    empty
| | +--rw disable-send-packet?      empty

```

```

|     | +--rw receive-version?      ipi-rip-types:rip_version_t
|     | +--rw send-version?         ipi-rip-types:rip_version_t
|     | +--rw auth-mode?           ipi-rip-types:rip_auth_mode_t
|     | +--rw auth-string?         cml-data-types:cml_line_t
|     | +--rw auth-keychain?       string
|     | +--rw split-horizon?       boolean
|     +--ro state
|         +--ro name?               -> /ipi-interface:interfaces/interface/name
|         +--ro disable-receive-packet? empty
|         +--ro disable-send-packet? empty
|         +--ro receive-version?   ipi-rip-types:rip_version_t
|         +--ro send-version?      ipi-rip-types:rip_version_t
|         +--ro auth-mode?         ipi-rip-types:rip_auth_mode_t
|         +--ro auth-string?       cml-data-types:cml_line_t
|         +--ro auth-keychain?     string
|         +--ro split-horizon?     boolean
|         +--ro statistics
|             +--ro sent-mcast-updates? yang:counter32
|             +--ro sent-mcast-requests? yang:counter32
|             +--ro sent-unicast-updates? yang:counter32
|             +--ro sent-unicast-requests? yang:counter32
|             +--ro received-mcast-updates? yang:counter32
|             +--ro received-mcast-requests? yang:counter32
|             +--ro received-unicast-updates? yang:counter32
|             +--ro received-unicast-requests? yang:counter32
|             +--ro received-bad-packets? yang:counter32
|             +--ro received-bad-routes? yang:counter32
+--rw instance
    +--rw config!
        | +--rw enable-cisco-metric-behavior? cml-data-types:cml_enable_disable_t
        | +--rw default-metric?              uint8
        | +--rw version?                     uint8
        | +--rw distance?                    uint8
name    | +--rw network-interfaces*           -> /ipi-interface:interfaces/interface/
        | +--rw network-routes*             cml-data-types:cml_ipv4_prefix_t
        | +--rw rip-enabled                  empty
        | +--rw bfd-enable?                  empty {feature-list:HAVE_BFD}?
        | +--rw receive-buffer-size?        uint32
name    | +--rw passive-interfaces*         -> /ipi-interface:interfaces/interface/
        | +--rw static-routes*              cml-data-types:cml_ipv4_prefix_t
        | +--rw neighbors*                  inet:ipv4-address
        | +--rw neighbor-fall-over-bfd*    inet:ipv4-address {feature-
list:HAVE_BFD}?
        +--ro state
            | +--ro enable-cisco-metric-behavior? cml-data-types:cml_enable_disable_t
            | +--ro default-metric?              uint8
            | +--ro version?                     uint8
            | +--ro distance?                    uint8

```



```

name | +--ro network-interfaces*                    -> /ipi-interface:interfaces/interface/
    | +--ro network-routes*                      cml-data-types:cml_ipv4_prefix_t
    | +--ro rip-enabled                          empty
    | +--ro bfd-enable?                          empty {feature-list:HAVE_BFD}?
    | +--ro receive-buffer-size?                 uint32
name | +--ro passive-interfaces*                  -> /ipi-interface:interfaces/interface/
    | +--ro static-routes*                       cml-data-types:cml_ipv4_prefix_t
    | +--ro neighbors*                           inet:ipv4-address
    | +--ro neighbor-fall-over-bfd*              inet:ipv4-address {feature-
list:HAVE_BFD}?
+--rw distances
  | +--rw distance* [source-prefix]
  |   +--rw source-prefix   -> ../config/source-prefix
  |   +--rw config
  |     | +--rw source-prefix?   cml-data-types:cml_ipv4_prefix_t
  |     | +--rw distance         uint8
  |     | +--rw access-list-name? string
  |     +--ro state
  |       +--ro source-prefix?   cml-data-types:cml_ipv4_prefix_t
  |       +--ro distance         uint8
  |       +--ro access-list-name? string
+--rw timers
  | +--rw config!
  | | +--rw route-table-update-interval   uint32
  | | +--rw route-info-timeout-interval   uint32
  | | +--rw garbage-collection-interval   uint32
  | +--ro state
  |   +--ro route-table-update-interval   uint32
  |   +--ro route-info-timeout-interval   uint32
  |   +--ro garbage-collection-interval   uint32
+--rw maximum-prefix
  | +--rw config!
  | | +--rw max-routes                uint32
  | | +--rw warning-threshold-percentage? uint32
  | +--ro state
  |   +--ro max-routes                uint32
  |   +--ro warning-threshold-percentage? uint32
+--rw redistribute-policies
  | +--rw redistribute-policy* [route-type]
  |   +--rw route-type   -> ../config/route-type
  |   +--rw config
  |     | +--rw route-type?   ipi-rip-types:rip_redistribute_proto_t
  |     | +--rw metric?       uint8
  |     | +--rw route-map?    string
  |     +--ro state
  |       +--ro route-type?   ipi-rip-types:rip_redistribute_proto_t
  |       +--ro metric?       uint8
  |       +--ro route-map?    string
+--rw default-information

```

```
| +--rw config!  
| | +--rw originate          empty  
| | +--rw always-advertise?  empty  
| | +--rw route-map?         string  
| +--ro state  
|   +--ro originate          empty  
|   +--ro always-advertise?  empty  
|   +--ro route-map?         string  
+--rw offset-lists  
| +--rw offset-list* [direction]  
|   +--rw direction    -> ../config/direction  
|   +--rw config  
|   | +--rw direction?    ipi-rip-types:rip_direction_t  
|   | +--rw access-list-name  string  
|   | +--rw metric         uint8  
|   +--ro state  
|     +--ro direction?      ipi-rip-types:rip_direction_t  
|     +--ro access-list-name  string  
|     +--ro metric          uint8  
+--rw distribute-filter-lists  
| +--rw distribute-filter-list* [direction]  
|   +--rw direction    -> ../config/direction  
|   +--rw config  
|   | +--rw direction?    ipi-rip-types:rip_direction_t  
|   | +--rw access-list-name  string  
|   +--ro state  
|     +--ro direction?      ipi-rip-types:rip_direction_t  
|     +--ro access-list-name  string  
+--rw distribute-prefix-lists  
| +--rw distribute-prefix-list* [direction]  
|   +--rw direction    -> ../config/direction  
|   +--rw config  
|   | +--rw direction?    ipi-rip-types:rip_direction_t  
|   | +--rw access-list-name  string  
|   +--ro state  
|     +--ro direction?      ipi-rip-types:rip_direction_t  
|     +--ro access-list-name  string  
+--rw interfaces  
| +--rw interface* [name]  
|   +--rw name          -> ../config/name  
|   +--rw config  
|   | +--rw name?      -> /ipi-interface:interfaces/interface/name  
|   +--ro state  
|   | +--ro name?      -> /ipi-interface:interfaces/interface/name  
|   +--rw offset-lists  
|   | +--rw offset-list* [direction]  
|   |   +--rw direction    -> ../config/direction  
|   |   +--rw config  
|   |   | +--rw direction?    ipi-rip-types:rip_direction_t  
|   |   | +--rw access-list-name  string
```

```

|     |     | +--rw metric                uint8
|     |     +--ro state
|     |         +--ro direction?          ipi-rip-types:rip_direction_t
|     |         +--ro access-list-name    string
|     |         +--ro metric              uint8
| +--rw distribute-filter-lists
|     | +--rw distribute-filter-list* [direction]
|     |     +--rw direction    -> ../config/direction
|     |     +--rw config
|     |         | +--rw direction?          ipi-rip-types:rip_direction_t
|     |         | +--rw access-list-name    string
|     |         +--ro state
|     |             +--ro direction?          ipi-rip-types:rip_direction_t
|     |             +--ro access-list-name    string
| +--rw distribute-prefix-lists
|     | +--rw distribute-prefix-list* [direction]
|     |     +--rw direction    -> ../config/direction
|     |     +--rw config
|     |         | +--rw direction?          ipi-rip-types:rip_direction_t
|     |         | +--rw access-list-name    string
|     |         +--ro state
|     |             +--ro direction?          ipi-rip-types:rip_direction_t
|     |             +--ro access-list-name    string
+--ro routes
| +--ro route* [prefix]
|     +--ro prefix    -> ../state/prefix
|     +--ro state
|         | +--ro prefix?                cml-data-types:cml_ipv4_prefix_t
|         | +--ro type?                  ipi-rip-types:rip_route_type_t
|         | +--ro rip-sub-type?          ipi-rip-types:rip_route_subtype_t
|         | +--ro tag?                   uint16
|         +--ro nexthops
|             +--ro nexthop* [address]
|                 +--ro address    -> ../state/address
|                 +--ro state
|                     +--ro address?    inet:ipv4-address
|                     +--ro if-name?    string
|                     +--ro metric?     uint8
|                     +--ro up-time?    string
+--rw vrfs
    +--rw vrf* [vrf-name]
        +--rw vrf-name                    -> ../config/vrf-name
        +--rw config
            | +--rw enable-cisco-metric-behavior?    cml-data-
types:cml_enable_disable_t
            | +--rw default-metric?                uint8
            | +--rw version?                        uint8
            | +--rw distance?                       uint8
            | +--rw network-interfaces*             -> /ipi-interface:interfaces/
interface/name
            | +--rw network-routes*                cml-data-types:cml_ipv4_prefix_t

```

```

| +--rw vrf-name?                                -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
+--ro state
| +--ro enable-cisco-metric-behavior?  cml-data-
types:cml_enable_disable_t
| +--ro default-metric?                uint8
| +--ro version?                       uint8
| +--ro distance?                      uint8
| +--ro network-interfaces*            -> /ipi-interface:interfaces/
interface/name
| +--ro network-routes*                cml-data-types:cml_ipv4_prefix_t
| +--ro vrf-name?                      -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
+--rw distances
| +--rw distance* [source-prefix]
|   +--rw source-prefix  -> ../config/source-prefix
|   +--rw config
|     | +--rw source-prefix?  cml-data-types:cml_ipv4_prefix_t
|     | +--rw distance       uint8
|     | +--rw access-list-name? string
|     +--ro state
|       +--ro source-prefix?  cml-data-types:cml_ipv4_prefix_t
|       +--ro distance       uint8
|       +--ro access-list-name? string
+--rw redistribute-policies
| +--rw redistribute-policy* [route-type]
|   +--rw route-type  -> ../config/route-type
|   +--rw config
|     | +--rw route-type?  ipi-rip-types:rip_vrf_redistribute_proto_t
|     | +--rw metric?     uint8
|     | +--rw route-map?  string
|     +--ro state
|       +--ro route-type?  ipi-rip-types:rip_vrf_redistribute_proto_t
|       +--ro metric?     uint8
|       +--ro route-map?  string
+--rw default-information
| +--rw config!
| | +--rw originate          empty
| | +--rw always-advertise?  empty
| | +--rw route-map?        string
| +--ro state
|   +--ro originate          empty
|   +--ro always-advertise?  empty
|   +--ro route-map?        string
+--rw offset-lists
| +--rw offset-list* [direction]
|   +--rw direction  -> ../config/direction
|   +--rw config
|     | +--rw direction?    ipi-rip-types:rip_direction_t
|     | +--rw access-list-name  string
|     | +--rw metric         uint8

```

```

|     +---ro state
|     +---ro direction?          ipi-rip-types:rip_direction_t
|     +---ro access-list-name    string
|     +---ro metric              uint8
+---rw distribute-filter-lists
| +---rw distribute-filter-list* [direction]
|   +---rw direction    -> ../config/direction
|   +---rw config
|   | +---rw direction?          ipi-rip-types:rip_direction_t
|   | +---rw access-list-name    string
|   +---ro state
|     +---ro direction?          ipi-rip-types:rip_direction_t
|     +---ro access-list-name    string
+---rw distribute-prefix-lists
| +---rw distribute-prefix-list* [direction]
|   +---rw direction    -> ../config/direction
|   +---rw config
|   | +---rw direction?          ipi-rip-types:rip_direction_t
|   | +---rw access-list-name    string
|   +---ro state
|     +---ro direction?          ipi-rip-types:rip_direction_t
|     +---ro access-list-name    string
+---rw interfaces
| +---rw interface* [name]
|   +---rw name              -> ../config/name
|   +---rw config
|   | +---rw name?            -> /ipi-interface:interfaces/interface/name
|   +---ro state
|     +---ro name?            -> /ipi-interface:interfaces/interface/name
+---rw offset-lists
| | +---rw offset-list* [direction]
| |   +---rw direction    -> ../config/direction
| |   +---rw config
| |   | +---rw direction?          ipi-rip-types:rip_direction_t
| |   | +---rw access-list-name    string
| |   | +---rw metric              uint8
| |   +---ro state
| |     +---ro direction?          ipi-rip-types:rip_direction_t
| |     +---ro access-list-name    string
| |     +---ro metric              uint8
+---rw distribute-filter-lists
| | +---rw distribute-filter-list* [direction]
| |   +---rw direction    -> ../config/direction
| |   +---rw config
| |   | +---rw direction?          ipi-rip-types:rip_direction_t
| |   | +---rw access-list-name    string
| |   +---ro state
| |     +---ro direction?          ipi-rip-types:rip_direction_t
| |     +---ro access-list-name    string
+---rw distribute-prefix-lists

```

```

|         +---rw distribute-prefix-list* [direction]
|         +---rw direction      -> ../config/direction
|         +---rw config
|         |   +---rw direction?          ipi-rip-types:rip_direction_t
|         |   +---rw access-list-name    string
|         +---ro state
|         +---ro direction?             ipi-rip-types:rip_direction_t
|         +---ro access-list-name       string
+---ro routes
  +---ro route* [prefix]
    +---ro prefix      -> ../state/prefix
    +---ro state
    |   +---ro prefix?          cml-data-types:cml_ipv4_prefix_t
    |   +---ro type?            ipi-rip-types:rip_route_type_t
    |   +---ro rip-sub-type?    ipi-rip-types:rip_route_subtype_t
    |   +---ro tag?             uint16
    +---ro nexthops
      +---ro nexthop* [address]
        +---ro address      -> ../state/address
        +---ro state
        +---ro address?     inet:ipv4-address
        +---ro if-name?     string
        +---ro metric?      uint8
        +---ro up-time?     string

```

rpcs:

```

+---x rip-vrf-clear-route {feature-list:HAVE_VRF_RIP,feature-list:HAVE_RIPD}?
|   +---w input
|     +---w vrf-name      string
|     +---w prefix        cml-data-types:cml_ipv4_prefix_t
+---x rip-vrf-clear-route-all {feature-list:HAVE_VRF_RIP,feature-list:HAVE_RIPD}?
|   +---w input
|     +---w vrf-name      string
+---x rip-clear-route {feature-list:HAVE_RIPD}?
|   +---w input
|     +---w route-type    ipi-rip-types:rip_redistribute_proto_clear_t
+---x rip-clear-route-prefix {feature-list:HAVE_RIPD}?
|   +---w input
|     +---w prefix-address cml-data-types:cml_ipv4_prefix_t
+---x rip-clear-statistics {feature-list:HAVE_RIPD}?
|   +---w input
|     +---w name          string
+---x rip-snmp-restart {feature-list:HAVE_SNMP}?
+---x rip-terminal-debugging-on {feature-list:HAVE_RIPD}?
|   +---w input
|     +---w terminal-debug-options ipi-rip-types:rip_debug_t
+---x rip-terminal-debugging-off {feature-list:HAVE_RIPD}?
  +---w input
    +---w terminal-debug-options ipi-rip-types:rip_debug_t

```

module: ipi-ripng

```

+--rw ripng
  +--rw debug
  |   +--rw config
  |   |   +--rw options?    ipi-ripng-types:ripng_debug_t
  |   |   +--ro state
  |   |       +--ro options?                ipi-ripng-types:ripng_debug_t
  |   |       +--ro terminal-debug-status?  ipi-ripng-types:ripng_debug_t
  +--rw interfaces
  |   +--rw interface* [name]
  |   |   +--rw name          -> ../config/name
  |   |   +--rw config
  |   |   |   +--rw name?          -> /ipi-interface:interfaces/interface/name
  |   |   |   +--rw enabled?       empty
  |   |   |   +--rw split-horizon? boolean
  |   |   |   +--rw metric-offset? uint8
  |   |   +--ro state
  |   |       +--ro name?          -> /ipi-interface:interfaces/interface/name
  |   |       +--ro enabled?       empty
  |   |       +--ro split-horizon? boolean
  |   |       +--ro metric-offset? uint8
  +--rw instance
  |   +--rw config!
  |   |   +--rw passive-interfaces*          -> /ipi-interface:interfaces/interface/
  name |   |   +--rw distance?                uint8
  |   |   +--rw static-routes*              cml-data-types:cml_ipv6_prefix_t
  |   |   +--rw aggregate-prefixes*         cml-data-types:cml_ipv6_prefix_t
  |   |   +--rw default-metric?             uint8
  |   |   +--rw originate-default-route?    empty
  |   |   +--rw enable-cisco-metric-behavior? boolean
  |   |   +--rw receive-buffer-size?       uint32
  |   |   +--rw ripng-enabled               empty
  |   +--ro state
  name |   |   +--ro passive-interfaces*      -> /ipi-interface:interfaces/interface/
  |   |   +--ro distance?                   uint8
  |   |   +--ro static-routes*              cml-data-types:cml_ipv6_prefix_t
  |   |   +--ro aggregate-prefixes*         cml-data-types:cml_ipv6_prefix_t
  |   |   +--ro default-metric?             uint8
  |   |   +--ro originate-default-route?    empty
  |   |   +--ro enable-cisco-metric-behavior? boolean
  |   |   +--ro receive-buffer-size?       uint32
  |   |   +--ro ripng-enabled               empty
  +--rw redistribute-policies

```

```
| +--rw redistribute-policy* [route-type]
|   +--rw route-type    -> ../config/route-type
|   +--rw config
|     | +--rw metric?      uint8
|     | +--rw route-map?   string
|     | +--rw route-type?  ipi-ripng-types:ripng_redistribute_proto_t
|     +--ro state
|       +--ro metric?      uint8
|       +--ro route-map?   string
|       +--ro route-type?  ipi-ripng-types:ripng_redistribute_proto_t
+--rw timers
| +--rw config!
| | +--rw route-table-update-interval  uint32
| | +--rw route-info-timeout-interval  uint32
| | +--rw garbage-collection-interval  uint32
| +--ro state
|   +--ro route-table-update-interval  uint32
|   +--ro route-info-timeout-interval  uint32
|   +--ro garbage-collection-interval  uint32
+--rw neighbors
| +--rw neighbor* [address]
|   +--rw address    -> ../config/address
|   +--rw config
|     | +--rw address?   inet:ipv6-address
|     | +--rw if-name    -> /ipi-interface:interfaces/interface/name
|     +--ro state
|       +--ro address?   inet:ipv6-address
|       +--ro if-name    -> /ipi-interface:interfaces/interface/name
+--rw interfaces
| +--rw interface* [name]
|   +--rw name          -> ../config/name
|   +--rw config
|     | +--rw name?     -> /ipi-interface:interfaces/interface/name
|     +--ro state
|       | +--ro name?   -> /ipi-interface:interfaces/interface/name
+--rw filtering-route-maps
| | +--rw filtering-route-map* [type]
| |   +--rw type          -> ../config/type
| |   +--rw config
| |     | +--rw type?      ipi-ripng-types:ripng_direction_t
| |     | +--rw route-map-name  string
| |     +--ro state
| |       +--ro type?      ipi-ripng-types:ripng_direction_t
| |       +--ro route-map-name  string
+--rw offset-lists
| | +--rw offset-list* [direction]
| |   +--rw direction    -> ../config/direction
| |   +--rw config
| |     | +--rw direction?  ipi-ripng-types:ripng_direction_t
| |     | +--rw access-list-name  string
```



```

|     |     | +--rw metric                uint8
|     |     +--ro state
|     |         +--ro direction?          ipi-ripng-types:ripng_direction_t
|     |         +--ro access-list-name    string
|     |         +--ro metric              uint8
| +--rw distribute-lists
|   | +--rw distribute-list* [direction]
|   |   +--rw direction    -> ../config/direction
|   |   +--rw config
|   |     | +--rw direction?          ipi-ripng-types:ripng_direction_t
|   |     | +--rw access-list-name    string
|   |     +--ro state
|   |       +--ro direction?          ipi-ripng-types:ripng_direction_t
|   |       +--ro access-list-name    string
| +--rw distribute-prefix-lists
|   +--rw distribute-prefix-list* [direction]
|     +--rw direction    -> ../config/direction
|     +--rw config
|       | +--rw direction?          ipi-ripng-types:ripng_direction_t
|       | +--rw list-name          string
|       +--ro state
|         +--ro direction?          ipi-ripng-types:ripng_direction_t
|         +--ro list-name          string
+--rw offset-lists
| +--rw offset-list* [direction]
|   +--rw direction    -> ../config/direction
|   +--rw config
|     | +--rw direction?          ipi-ripng-types:ripng_direction_t
|     | +--rw access-list-name    string
|     | +--rw metric              uint8
|     +--ro state
|       +--ro direction?          ipi-ripng-types:ripng_direction_t
|       +--ro access-list-name    string
|       +--ro metric              uint8
+--rw distribute-lists
| +--rw distribute-list* [direction]
|   +--rw direction    -> ../config/direction
|   +--rw config
|     | +--rw direction?          ipi-ripng-types:ripng_direction_t
|     | +--rw access-list-name    string
|     +--ro state
|       +--ro direction?          ipi-ripng-types:ripng_direction_t
|       +--ro access-list-name    string
+--rw distribute-prefix-lists
| +--rw distribute-prefix-list* [direction]
|   +--rw direction    -> ../config/direction
|   +--rw config
|     | +--rw direction?          ipi-ripng-types:ripng_direction_t
|     | +--rw list-name          string
|     +--ro state

```

```

|         +---ro direction?   ipi-ripng-types:ripng_direction_t
|         +---ro list-name    string
+---ro routes
|   +---ro route* [prefix]
|     +---ro prefix           -> ../state/prefix
|     +---ro state
|       | +---ro prefix?      cml-data-types:cml_ipv6_prefix_t
|       | +---ro type?        ipi-ripng-types:ripng_route_type_t
|       | +---ro sub-type?    ipi-ripng-types:ripng_route_sub_type_t
|       | +---ro tag?         uint16
|     +---ro next-hops
|       | +---ro next-hop* [address]
|       |   +---ro address    -> ../state/address
|       |   +---ro state
|       |     +---ro address?  inet:ipv6-address
|       |     +---ro if-name?  string
|       |     +---ro metric?   uint8
|       |     +---ro up-time?  string
|     +---ro aggregate-route
|       +---ro state
|         +---ro count?      uint32
|         +---ro metric?     uint8
|         +---ro tag?        uint16
+---rw vrfs
  +---rw vrf* [vrf-name]
    +---rw vrf-name          -> ../config/vrf-name
    +---rw config
  interface/name
    | +---rw passive-interfaces*          -> /ipi-interface:interfaces/
    | +---rw distance?                   uint8
    | +---rw static-routes*              cml-data-types:cml_ipv6_prefix_t
    | +---rw aggregate-prefixes*         cml-data-types:cml_ipv6_prefix_t
    | +---rw default-metric?             uint8
    | +---rw originate-default-route?    empty
    | +---rw enable-cisco-metric-behavior? boolean
    | +---rw receive-buffer-size?        uint32
    | +---rw vrf-name?                   -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
    +---ro state
  interface/name
    | +---ro passive-interfaces*          -> /ipi-interface:interfaces/
    | +---ro distance?                   uint8
    | +---ro static-routes*              cml-data-types:cml_ipv6_prefix_t
    | +---ro aggregate-prefixes*         cml-data-types:cml_ipv6_prefix_t
    | +---ro default-metric?             uint8
    | +---ro originate-default-route?    empty
    | +---ro enable-cisco-metric-behavior? boolean
    | +---ro receive-buffer-size?        uint32
    | +---ro vrf-name?                   -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
    +---rw redistribute-policies

```

```

| +--rw redistribute-policy* [route-type]
|   +--rw route-type   -> ../config/route-type
|   +--rw config
|     | +--rw metric?      uint8
|     | +--rw route-map?   string
|     | +--rw route-type?  ipi-ripng-types:ripng_vrf_redistribute_proto_t
|     +--ro state
|       +--ro metric?      uint8
|       +--ro route-map?   string
|       +--ro route-type?  ipi-ripng-types:ripng_vrf_redistribute_proto_t
+--rw timers
| +--rw config!
| | +--rw route-table-update-interval  uint32
| | +--rw route-info-timeout-interval  uint32
| | +--rw garbage-collection-interval  uint32
| +--ro state
|   +--ro route-table-update-interval  uint32
|   +--ro route-info-timeout-interval  uint32
|   +--ro garbage-collection-interval  uint32
+--rw neighbors
| +--rw neighbor* [address]
|   +--rw address   -> ../config/address
|   +--rw config
|     | +--rw address?  inet:ipv6-address
|     | +--rw if-name   -> /ipi-interface:interfaces/interface/name
|     +--ro state
|       +--ro address?  inet:ipv6-address
|       +--ro if-name   -> /ipi-interface:interfaces/interface/name
+--rw interfaces
| +--rw interface* [name]
|   +--rw name           -> ../config/name
|   +--rw config
|     | +--rw name?     -> /ipi-interface:interfaces/interface/name
|     +--ro state
|       | +--ro name?   -> /ipi-interface:interfaces/interface/name
+--rw filtering-route-maps
| | +--rw filtering-route-map* [type]
| |   +--rw type           -> ../config/type
| |   +--rw config
| |     | +--rw type?      ipi-ripng-types:ripng_direction_t
| |     | +--rw route-map-name  string
| |     +--ro state
| |       +--ro type?      ipi-ripng-types:ripng_direction_t
| |       +--ro route-map-name  string
+--rw offset-lists
| | +--rw offset-list* [direction]
| |   +--rw direction     -> ../config/direction
| |   +--rw config
| |     | +--rw direction?  ipi-ripng-types:ripng_direction_t
| |     | +--rw access-list-name  string

```

```

|     |     |  +--rw metric                uint8
|     |     +---ro state
|     |         +---ro direction?          ipi-ripng-types:ripng_direction_t
|     |         +---ro access-list-name    string
|     |         +---ro metric              uint8
|  +---rw distribute-lists
|     |  +---rw distribute-list* [direction]
|     |     +---rw direction    -> ../config/direction
|     |     +---rw config
|     |     |  +---rw direction?          ipi-ripng-types:ripng_direction_t
|     |     |  +---rw access-list-name    string
|     |     +---ro state
|     |         +---ro direction?          ipi-ripng-types:ripng_direction_t
|     |         +---ro access-list-name    string
|  +---rw distribute-prefix-lists
|     +---rw distribute-prefix-list* [direction]
|     +---rw direction    -> ../config/direction
|     +---rw config
|     |  +---rw direction?          ipi-ripng-types:ripng_direction_t
|     |  +---rw list-name          string
|     +---ro state
|     +---ro direction?          ipi-ripng-types:ripng_direction_t
|     +---ro list-name          string
+---rw offset-lists
|  +---rw offset-list* [direction]
|     +---rw direction    -> ../config/direction
|     +---rw config
|     |  +---rw direction?          ipi-ripng-types:ripng_direction_t
|     |  +---rw access-list-name    string
|     |  +---rw metric              uint8
|     +---ro state
|     +---ro direction?          ipi-ripng-types:ripng_direction_t
|     +---ro access-list-name    string
|     +---ro metric              uint8
+---rw distribute-lists
|  +---rw distribute-list* [direction]
|     +---rw direction    -> ../config/direction
|     +---rw config
|     |  +---rw direction?          ipi-ripng-types:ripng_direction_t
|     |  +---rw access-list-name    string
|     +---ro state
|     +---ro direction?          ipi-ripng-types:ripng_direction_t
|     +---ro access-list-name    string
+---rw distribute-prefix-lists
|  +---rw distribute-prefix-list* [direction]
|     +---rw direction    -> ../config/direction
|     +---rw config
|     |  +---rw direction?          ipi-ripng-types:ripng_direction_t
|     |  +---rw list-name          string
|     +---ro state

```

```

|         +---ro direction?   ipi-ripng-types:ripng_direction_t
|         +---ro list-name    string
+---ro routes
  +---ro route* [prefix]
    +---ro prefix              -> ../state/prefix
    +---ro state
      | +---ro prefix?        cml-data-types:cml_ipv6_prefix_t
      | +---ro type?          ipi-ripng-types:ripng_route_type_t
      | +---ro sub-type?      ipi-ripng-types:ripng_route_sub_type_t
      | +---ro tag?           uint16
    +---ro next-hops
      | +---ro next-hop* [address]
      |   +---ro address      -> ../state/address
      |   +---ro state
        |   +---ro address?    inet:ipv6-address
        |   +---ro if-name?    string
        |   +---ro metric?     uint8
        |   +---ro up-time?    string
    +---ro aggregate-route
      +---ro state
        +---ro count?         uint32
        +---ro metric?         uint8
        +---ro tag?           uint16

```

rpcs:

```

+---x ripng-terminal-debug-on {feature-list:HAVE_RIPNGD}?
| +---w input
|   +---w terminal-debug-options   ipi-ripng-types:ripng_debug_t
+---x ripng-terminal-debug-off {feature-list:HAVE_RIPNGD}?
| +---w input
|   +---w terminal-debug-options   ipi-ripng-types:ripng_debug_t
+---x ripng-clear-route {feature-list:HAVE_RIPNGD}?
| +---w input
|   +---w type   ipi-ripng-types:ripng_clear_route_type_t
+---x ripng-clear-route-prefix {feature-list:HAVE_RIPNGD}?
  +---w input
    +---w prefix   cml-data-types:cml_ipv6_prefix_t

```

module: ipi-role-based-access-control

```

+---rw role-based-access-control
  +---rw config
  | +---rw enable?   empty
  +---ro state
  | +---ro enable?   empty
  +---rw policies
  | +---rw policy* [policy-name]

```

```

|     +---rw policy-name    -> ../config/policy-name
|     +---rw config
|     |   +---rw policy-name?  string
|     +---ro state
|     |   +---ro policy-name?  string
|     +---rw rules
|         +---rw rule* [rule-name]
|             +---rw rule-name    -> ../config/rule-name
|             +---rw config
|                 |   +---rw rule-name?      cml-data-types:cml_line_t
|                 |   +---rw rule-type      ipi-role-based-access-control-
types:rbac_rule_type_t
|                 |   +---rw command-mode*  string
|                 +---ro state
|                     +---ro rule-name?    cml-data-types:cml_line_t
|                     +---ro rule-type    ipi-role-based-access-control-
types:rbac_rule_type_t
|                 +---ro command-mode*  string
+---rw roles
    +---rw role* [role-name]
        +---rw role-name    -> ../config/role-name
        +---rw config
            |   +---rw role-name?          string
            |   +---rw default-policy?    ipi-role-based-access-control-
types:rbac_default_rule_type_t
            +---ro state
            |   +---ro role-name?          string
            |   +---ro default-policy?    ipi-role-based-access-control-
types:rbac_default_rule_type_t
            +---rw policies
                +---rw policy* [policy-name]
                    +---rw policy-name    -> ../config/policy-name
                    +---rw config
policy-name            |   +---rw policy-name?    -> /role-based-access-control/policies/policy/
                    +---ro state
policy-name            +---ro policy-name?    -> /role-based-access-control/policies/policy/

```

module: ipi-routemap

```

+---rw routemaps
    +---rw routemap* [routemap-name sequence-id]
        +---rw routemap-name    -> ../config/routemap-name
        +---rw sequence-id      -> ../config/sequence-id
        +---rw config
            |   +---rw routemap-name?  string
            |   +---rw action          ipi-routemap-types:rmap_action_type_t
            |   +---rw sequence-id?    uint32

```

```

+--ro state
| +--ro routemap-name?   string
| +--ro action            ipi-routemap-types:rmap_action_type_t
| +--ro sequence-id?     uint32
+--rw continue-on-match
| +--rw config
| | +--rw continue-to-next-sequence?  empty
| | +--rw next-sequence-number?      uint32
| +--ro state
|   +--ro continue-to-next-sequence?  empty
|   +--ro next-sequence-number?      uint32
+--rw match-condition
| +--rw config
| | +--rw interface-name?             -> /ipi-interface:interfaces/interface/name
| | +--rw metric?                    uint32
| | +--rw vlan-id?                  cml-data-types:cml_range_t {feature-
list:HAVE_VLAN,feature-list:HAVE_PBR}?
| | +--rw mac-access-list-name?     string {feature-list:HAVE_PBR}?
| | +--rw tag?                      uint32
| | +--rw route-type?              ipi-routemap-types:rmap_route_type_t
| | +--rw as-path-name?            string
| | +--rw route-origin?            ipi-routemap-types:rmap_origin_type_t
| +--ro state
| | +--ro interface-name?           -> /ipi-interface:interfaces/interface/name
| | +--ro metric?                  uint32
| | +--ro vlan-id?                cml-data-types:cml_range_t {feature-
list:HAVE_VLAN,feature-list:HAVE_PBR}?
| | +--ro mac-access-list-name?     string {feature-list:HAVE_PBR}?
| | +--ro tag?                    uint32
| | +--ro route-type?             ipi-routemap-types:rmap_route_type_t
| | +--ro as-path-name?           string
| | +--ro route-origin?          ipi-routemap-types:rmap_origin_type_t
| +--rw route-filter {feature-list:HAVE_PBR}?
| | +--rw packet-length-constraints* [packet-min-length packet-max-length]
{feature-list:HAVE_PBR}?
| |   +--rw packet-min-length      -> ../config/packet-min-length
| |   +--rw packet-max-length      -> ../config/packet-max-length
| |   +--rw config
| |     | +--rw packet-min-length?  uint16
| |     | +--rw packet-max-length?  uint16
| |     +--ro state
| |       +--ro packet-min-length?  uint16
| |       +--ro packet-max-length?  uint16
| +--rw communities
| | +--rw community* [community-identifier]
| |   +--rw community-identifier   -> ../config/community-identifier
| |   +--rw config
| |     | +--rw community-identifier? ipi-routemap-
types:rmap_community_string_t
| |     | +--rw match-type          ipi-routemap-types:rmap_community_type_t
| |     +--ro state

```

```

| |      +---ro community-identifier?   ipi-routemap-
types:rmap_community_string_t
| |      +---ro match-type               ipi-routemap-types:rmap_community_type_t
| |      +---rw extended-communities
| |      +---rw extended-community* [extended-community-identifier]
| |      +---rw extended-community-identifier  -> ../config/extended-community-
identifier
| |      +---rw config
| |      | +---rw extended-community-identifier?   ipi-routemap-
types:rmap_community_string_t
| |      | +---rw match-type                       ipi-routemap-
types:rmap_community_type_t
| |      +---ro state
| |      +---ro extended-community-identifier?   ipi-routemap-
types:rmap_community_string_t
| |      +---ro match-type                       ipi-routemap-
types:rmap_community_type_t
| |      +---rw ipv4
| |      +---rw config
| |      | +---rw ip-access-list-name?           string
| |      | +---rw ip-prefix-list-name?          string
| |      | +---rw peer-access-list-name?        string
| |      | +---rw next-hop-prefix-list-name?    string
| |      | +---rw next-hop-access-list-name?    string
| |      +---ro state
| |      +---ro ip-access-list-name?           string
| |      +---ro ip-prefix-list-name?          string
| |      +---ro peer-access-list-name?        string
| |      +---ro next-hop-prefix-list-name?    string
| |      +---ro next-hop-access-list-name?    string
| |      +---rw ipv6 {feature-list:HAVE_IPV6}?
| |      +---rw config {feature-list:HAVE_IPV6}?
| |      | +---rw ipv6-address-access-list-name? string
| |      | +---rw ipv6-prefix-list-name?       string
| |      | +---rw peer-access-list-name?       string
| |      | +---rw next-hop-prefix-list-name?   string
| |      | +---rw next-hop-match-string?       ipi-routemap-
types:rmap_ipv6_nexthop_t
| |      +---ro state
| |      +---ro ipv6-address-access-list-name? string
| |      +---ro ipv6-prefix-list-name?        string
| |      +---ro peer-access-list-name?        string
| |      +---ro next-hop-prefix-list-name?    string
| |      +---ro next-hop-match-string?        ipi-routemap-
types:rmap_ipv6_nexthop_t
| |      +---rw large-match-community
| |      +---rw config!
| |      | +---rw large-community-number-match? cml-data-types:cml_line_t
| |      +---ro state
| |      +---ro large-community-number-match? cml-data-types:cml_line_t
+---rw set-action
+---rw config

```



```

| +--rw forward-interface-type?          ipi-routemap-
types:rmap_forward_interface_type_t
| +--rw metric-value?                    string
| +--rw route-tag?                       uint32
| +--rw weight?                          uint32
| +--rw local-preference?                uint32
| +--rw route-origin-type?              ipi-routemap-types:rmap_origin_type_t
| +--rw metric-type?                     ipi-routemap-types:rmap_metric_type_t
| +--rw aigp-metric?                     ipi-routemap-types:aigp_metric_type_t
{feature-list:HAVE_BGP_AIGP}?
| +--rw level-type?                      ipi-routemap-types:rmap_level_type_t
| +--rw enable-as-path-tag?              empty
| +--rw atomic-aggregate?                empty
| +--rw delete-community-value?          ipi-routemap-
types:rmap_community_string_t
| +--rw bgp-originator-id?               inet:ipv4-address
| +--rw as-path-prepend?                  cml-data-types:cml_line_t
| +--rw ext-community-site-of-origin?     cml-data-types:cml_line_t
| +--rw ext-community-color?             uint32
+--ro state
| +--ro forward-interface-type?          ipi-routemap-
types:rmap_forward_interface_type_t
| +--ro metric-value?                    string
| +--ro route-tag?                       uint32
| +--ro weight?                          uint32
| +--ro local-preference?                uint32
| +--ro route-origin-type?              ipi-routemap-types:rmap_origin_type_t
| +--ro metric-type?                     ipi-routemap-types:rmap_metric_type_t
| +--ro aigp-metric?                     ipi-routemap-types:aigp_metric_type_t
{feature-list:HAVE_BGP_AIGP}?
| +--ro level-type?                      ipi-routemap-types:rmap_level_type_t
| +--ro enable-as-path-tag?              empty
| +--ro atomic-aggregate?                empty
| +--ro delete-community-value?          ipi-routemap-
types:rmap_community_string_t
| +--ro bgp-originator-id?               inet:ipv4-address
| +--ro as-path-prepend?                  cml-data-types:cml_line_t
| +--ro ext-community-site-of-origin?     cml-data-types:cml_line_t
| +--ro ext-community-color?             uint32
+--rw ipv4
| +--rw config
| | +--rw ip-nexthop-address?             inet:ipv4-address
| | +--rw use-peer-address?              empty
| | +--rw default-nexthop-address?       inet:ipv4-address {feature-
list:HAVE_PBR}?
| | +--rw vpnv4-nexthop-address?         inet:ipv4-address {feature-
list:HAVE_VRF}?
| +--ro state
|   +--ro ip-nexthop-address?             inet:ipv4-address
|   +--ro use-peer-address?              empty
|   +--ro default-nexthop-address?       inet:ipv4-address {feature-
list:HAVE_PBR}?

```

```

|         +---ro vpvv4-nexthop-address?      inet:ipv4-address {feature-
list:HAVE_VRF}?
|         +---rw ipv6
|         | +---rw config
|         | | +---rw ipv6-nexthop-address?      inet:ipv6-address {feature-
list:HAVE_IPV6}?
|         | | +---rw default-ipv6-nexthop-address?  inet:ipv6-address {feature-
list:HAVE_PBR,feature-list:HAVE_IPV6}?
|         | | +---rw local-ipv6-nexthop-address?    inet:ipv6-address {feature-
list:HAVE_IPV6}?
|         | +---ro state
|         | +---ro ipv6-nexthop-address?      inet:ipv6-address {feature-
list:HAVE_IPV6}?
|         | +---ro default-ipv6-nexthop-address?  inet:ipv6-address {feature-
list:HAVE_PBR,feature-list:HAVE_IPV6}?
|         | +---ro local-ipv6-nexthop-address?    inet:ipv6-address {feature-
list:HAVE_IPV6}?
|         +---rw bgp-aggregator-attributes
|         | +---rw bgp-aggregator-attribute* [as-number aggregator-ip-address]
|         | +---rw as-number                    -> ../config/as-number
|         | +---rw aggregator-ip-address        -> ../config/aggregator-ip-address
|         | +---rw config
|         | | +---rw as-number?                  uint32
|         | | +---rw aggregator-ip-address?      inet:ipv4-address
|         | +---ro state
|         | +---ro as-number?                    uint32
|         | +---ro aggregator-ip-address?        inet:ipv4-address
+---rw extended-community
| +---rw route-targets
| | +---rw route-target* [ext-community-rt]
| | +---rw ext-community-rt    -> ../config/ext-community-rt
| | +---rw config
| | | +---rw ext-community-rt?  cml-data-types:cml_line_t
| | | | +---rw additive-type    ipi-routemap-types:rmap_additive_type_t
| | | +---ro state
| | | +---ro ext-community-rt?  cml-data-types:cml_line_t
| | | +---ro additive-type      ipi-routemap-types:rmap_additive_type_t
| +---rw costs
| +---rw cost* [comparison-type community-id cost-value]
| +---rw comparison-type    -> ../config/comparison-type
| +---rw community-id       -> ../config/community-id
| +---rw cost-value         -> ../config/cost-value
| +---rw config
| | +---rw comparison-type?  ipi-routemap-types:rmap_ext_cost_type_t
| | +---rw community-id?     uint8
| | +---rw cost-value?       uint32
| +---ro state
| +---ro comparison-type?    ipi-routemap-types:rmap_ext_cost_type_t
| +---ro community-id?      uint8
| +---ro cost-value?        uint32
+---rw dampening
| +---rw config!

```

```

| | +--rw enable-dampening          empty
| | +--rw reachability-half-life-time?  uint8
| | +--rw reuse-time-limit?          uint16
| | +--rw suppress-time-limit?       uint16
| | +--rw max-suppress-time-limit?    uint8
| | +--rw unreachability-half-life-time? uint8
| +--ro state
|   +--ro enable-dampening          empty
|   +--ro reachability-half-life-time?  uint8
|   +--ro reuse-time-limit?          uint16
|   +--ro suppress-time-limit?       uint16
|   +--ro max-suppress-time-limit?    uint8
|   +--ro unreachability-half-life-time? uint8
+--rw communities
| +--rw config
| | +--rw enable-internet?          empty
| | +--rw enable-local-as?         empty
| | +--rw enable-no-advertise?     empty
| | +--rw enable-no-export?        empty
| | +--rw no-community-attribute?   empty
| | +--rw additive-set?            empty
| | +--rw community-number?        cml-data-types:cml_line_t
| | +--rw community-with-as-number? cml-data-types:cml_line_t
| +--ro state
|   +--ro enable-internet?          empty
|   +--ro enable-local-as?         empty
|   +--ro enable-no-advertise?     empty
|   +--ro enable-no-export?        empty
|   +--ro no-community-attribute?   empty
|   +--ro additive-set?            empty
|   +--ro community-number?        cml-data-types:cml_line_t
|   +--ro community-with-as-number? cml-data-types:cml_line_t
+--rw large-community
  +--rw config!
  | +--rw large-community-number-set? cml-data-types:cml_line_t
  +--ro state
    +--ro large-community-number-set? cml-data-types:cml_line_t

```

module: ipi-rsvp

```

+--rw rsvp-te
  +--ro admin-group* [name]
  | +--ro name      -> ../state/name
  | +--ro state

```

```
|     +---ro name?      string
|     +---ro value?    uint32
+---rw debug
| +---rw config
| | +---rw options?    ipi-rsvp-types:rsvp_debug_t
| +---ro state
|     +---ro options?                ipi-rsvp-types:rsvp_debug_t
|     +---ro terminal-debug-status?  ipi-rsvp-types:rsvp_debug_t
+---rw snmp-configuration
| +---rw config
| | +---rw enable-rsvp-trap?  empty {feature-list:HAVE_SNMP}?
| +---ro state
|     +---ro enable-rsvp-trap?  empty {feature-list:HAVE_SNMP}?
+---ro dscp
| +---ro state
|     +---ro class-exp-mapping*      uint32 {feature-list:NOT_HAVE_SWFWDR}?
|     +---ro class-exp-mapping-value* uint8 {feature-list:NOT_HAVE_SWFWDR}?
+---rw rsvp-instance
| +---ro summary-refresh* [address]
| | +---ro address    -> ../state/address
| | +---ro state
| |     +---ro address?          inet:ip-address
| |     +---ro trunk-id?        uint32
| |     +---ro lsp-id?          uint16
| |     +---ro session-frr-type? ipi-rsvp-types:rsvp_session_frr_type_t
| |     +---ro ingress?         inet:ip-address
| |     +---ro egress?         inet:ip-address
| |     +---ro trunk-session-type? ipi-rsvp-types:rsvp_sess_type_t
| +---ro local-address-ipv4* [addr]
| | +---ro addr    -> ../state/addr
| | +---ro state
| |     +---ro if-name?  -> /ipi-interface:interfaces/interface/name
| |     +---ro family?  ipi-rsvp-types:rsvp_addr_family_t
| |     +---ro addr?    inet:ip-address
| +---ro local-address-ipv6* [addr]
| | +---ro addr    -> ../state/addr
| | +---ro state
| |     +---ro if-name?  -> /ipi-interface:interfaces/interface/name
| |     +---ro family?  ipi-rsvp-types:rsvp_addr_family_t
| |     +---ro addr?    inet:ip-address
| +---ro rsvp-nexthop* [prefix]
| | +---ro prefix    -> ../state/prefix
| | +---ro state
| |     +---ro prefix?                cml-data-types:cml_ip_prefix_addr_t
| |     +---ro number-of-sessions?    uint32
| |     +---ro ip-addr?               inet:ip-address
| |     +---ro if-name?               -> /ipi-interface:interfaces/interface/name
| +---rw config!
| | +---rw rsvp                    ipi-rsvp-types:rsvp_instance_t
| | +---rw enable-explicit-null?   empty
```

```

| | +--rw enable-local-protection?          empty
| | +--rw enable-php?                      empty
| | +--rw enable-entropy-label-capability?  empty {feature-
list:NOT_HAVE_CUSTOM1_MPLS}?
| | +--rw disable-refresh-resv-parsing?     empty
| | +--rw disable-refresh-path-parsing?    empty
| | +--rw disable-loop-detection?          empty
| | +--rw revert-timer?                    uint32
| | +--rw enable-bundle-send?              empty
| | +--rw ingress?                         inet:ipv4-address
| +--ro state
| | +--ro counters
| | | +--ro in-path-messages?              uint32
| | | +--ro in-path-error-messages?       uint32
| | | +--ro in-path-tear-messages?        uint32
| | | +--ro in-reservation-fixed-filter-messages?  uint32
| | | +--ro in-reservation-wildcard-filter-messages?  uint32
| | | +--ro in-reservation-shared-explicit-messages?  uint32
| | | +--ro in-reservation-error-messages?  uint32
| | | +--ro in-reservation-tear-messages?    uint32
| | | +--ro in-reservation-conform-messages?  uint32
| | | +--ro in-hello-messages?            uint32
| | | +--ro in-bundle-messages?           uint32
| | | +--ro in-acknowledge-messages?       uint32
| | | +--ro in-srefresh-messages?         uint32
| | | +--ro in-notify-messages?          uint32
| | | +--ro out-path-messages?            uint32
| | | +--ro out-path-error-messages?       uint32
| | | +--ro out-path-tear-messages?        uint32
| | | +--ro out-reservation-fixed-filter-messages?  uint32
| | | +--ro out-reservation-wildcard-filter-messages?  uint32
| | | +--ro out-reservatoion-shared-explicit-messages?  uint32
| | | +--ro out-reservation-error-messages?  uint32
| | | +--ro out-reservation-tear-messages?    uint32
| | | +--ro out-reservation-conform-messages?  uint32
| | | +--ro out-hello-messages?            uint32
| | | +--ro out-bundle-messages?           uint32
| | | +--ro out-acknowledge-messages?       uint32
| | | +--ro out-srefresh-messages?         uint32
| | | +--ro out-notify-messages?          uint32
| | | +--ro total-number-of-sessions?      int32
| | | +--ro active-sessions?               int32
| | | +--ro total-ingress-sessions?        int32
| | | +--ro active-ingress-sessions?       int32
| | | +--ro total-transit-sessions?        int32
| | | +--ro active-transit-sessions?       int32
| | | +--ro total-egress-sessions?         int32
| | | +--ro active-egress-sessions?        int32
| | +--ro rsvp                             ipi-rsvp-types:rsvp_instance_t
| | +--ro enable-explicit-null?            empty
| | +--ro enable-local-protection?         empty

```

```

    | | +--ro enable-php? empty
    | | +--ro enable-entropy-label-capability? empty {feature-
list:NOT_HAVE_CUSTOM1_MPLS}?
    | | +--ro disable-refresh-resv-parsing? empty
    | | +--ro disable-refresh-path-parsing? empty
    | | +--ro disable-loop-detection? empty
    | | +--ro revert-timer? uint32
    | | +--ro enable-bundle-send? empty
    | | +--ro ingress? inet:ipv4-address
    | | +--ro rsvp-version? uint16
    | | +--ro rsvp-state? ipi-rsvp-types:rsvp_status_t
    | | +--ro refresh-timer? uint32
    | | +--ro keep-multiplier? uint32
    | | +--ro preemption-type? ipi-rsvp-types:rsvp_preemption_type_t
    | | +--ro selected-ingress-ipv4? inet:ipv4-address
    | | +--ro selected-ingress-ipv6? inet:ipv6-address {feature-
list:HAVE_IPV6}?
    | +--rw route-refresh
    | | +--rw config
    | | | +--rw enable-message-ack? empty
    | | | +--rw disable-refresh-reduction? empty
    | | | +--rw ack-wait-timeout? uint32
    | | | +--rw refresh-time? uint16
    | | | +--rw keep-multiplier? int32
    | | | +--rw ack-send-timer? uint16
    | | +--ro state
    | |   +--ro enable-message-ack? empty
    | |   +--ro disable-refresh-reduction? empty
    | |   +--ro ack-wait-timeout? uint32
    | |   +--ro refresh-time? uint16
    | |   +--ro keep-multiplier? int32
    | |   +--ro ack-send-timer? uint16
    | +--rw fast-reroute {feature-list:HAVE_MPLS_FRR}?
    | | +--rw config
    | | | +--rw default-frr-protection? ipi-rsvp-
types:rsvp_frr_protection_t {feature-list:HAVE_MPLS_FRR}?
    | | | +--rw preemption-type? ipi-rsvp-types:rsvp_preemp_t
{feature-list:HAVE_MPLS_FRR}?
    | | | +--rw bypass-lsp-addr-query-interval? uint8 {feature-
list:HAVE_MPLS_FRR}?
    | | | +--rw detour-id? ipi-rsvp-types:rsvp_detour_iden_t
{feature-list:HAVE_MPLS_FRR}?
    | | | +--rw detour-allow-primary-upstream-path? empty {feature-
list:HAVE_MPLS_FRR}?
    | | +--ro state
    | |   +--ro default-frr-protection? ipi-rsvp-
types:rsvp_frr_protection_t {feature-list:HAVE_MPLS_FRR}?
    | |   +--ro preemption-type? ipi-rsvp-types:rsvp_preemp_t
{feature-list:HAVE_MPLS_FRR}?
    | |   +--ro bypass-lsp-addr-query-interval? uint8 {feature-
list:HAVE_MPLS_FRR}?
    | |   +--ro detour-id? ipi-rsvp-types:rsvp_detour_iden_t
{feature-list:HAVE_MPLS_FRR}?

```

```

| |      +---ro detour-allow-primary-upstream-path?    empty {feature-
list:HAVE_MPLS_FRR}?
| |      +---rw cspf {feature-list:HAVE_CSPF}?
| |      |      +---rw config
| |      |      |      +---rw disable-cspf?            empty
| |      |      |      +---rw cspf-lsp-reoptimization-time?  uint32
| |      |      +---ro state
| |      |      +---ro disable-cspf?                    empty
| |      |      +---ro cspf-lsp-reoptimization-time?    uint32
| |      +---rw global
| |      |      +---rw hellos
| |      |      |      +---rw config
| |      |      |      |      +---rw enable-hello-receipt?  empty
| |      |      |      |      +---rw hello-interval?        int32
| |      |      |      |      +---rw hello-timeout?         int32
| |      |      |      +---ro state
| |      |      |      +---ro enable-hello-receipt?        empty
| |      |      |      +---ro hello-interval?              int32
| |      |      |      +---ro hello-timeout?              int32
| |      |      +---rw graceful-restart {feature-list:HAVE_RSVP_GRST}?
| |      |      |      +---rw config!
| |      |      |      |      +---rw enable-graceful-restart  empty
| |      |      |      |      +---rw restart-time?           uint32
| |      |      |      |      +---rw recovery-time?          uint32
| |      |      |      +---ro state
| |      |      |      +---ro enable-graceful-restart        empty
| |      |      |      +---ro restart-time?                  uint32
| |      |      |      +---ro recovery-time?                 uint32
| |      +---rw gmpls {feature-list:HAVE_GMPLS}?
| |      |      +---rw config
| |      |      |      +---rw enable-gmpls-notification?    empty
| |      |      |      +---rw enable-pre-program-suggested-label?  empty
| |      |      +---ro state
| |      |      +---ro enable-gmpls-notification?            empty
| |      |      +---ro enable-pre-program-suggested-label?  empty
| |      +---rw srlg {feature-list:HAVE_SRLG}?
| |      |      +---rw config
| |      |      |      +---rw srlg-disjoint?    ipi-rsvp-types:rsvp_te_srlg_disjoint_type_t
{feature-list:HAVE_SRLG}?
| |      |      |      +---ro state
| |      |      |      +---ro srlg-disjoint?    ipi-rsvp-types:rsvp_te_srlg_disjoint_type_t
{feature-list:HAVE_SRLG}?
| |      +---rw diff-serv {feature-list:HAVE_DIFFSERV}?
| |      |      +---rw config
| |      |      |      +---rw enable-override-diff-serv?    empty {feature-list:HAVE_DIFFSERV}?
| |      |      +---ro state
| |      |      +---ro enable-override-diff-serv?    empty {feature-list:HAVE_DIFFSERV}?
| |      +---rw neighbors
| |      |      +---rw neighbor* [address]
| |      |      |      +---rw address    -> ../config/address
| |      |      +---rw config

```

```

|   | | +--rw address?   inet:ip-address
|   | +--ro state
|   |   +--ro address?   inet:ip-address
|   +--ro protocol-neighbor* [neighbor-ip-address]
|       +--ro neighbor-ip-address   -> ../state/neighbor-ip-address
|       +--ro state
|           +--ro neighbor-ip-address?   inet:ip-address
|           +--ro session-count?        uint32
|           +--ro refresh-reduction?     ipi-rsvp-
types:rsvp_neighbor_refresh_reduction_status_t
|           +--ro upstream-lsp-count?    uint32
|           +--ro downstream-lsp-count?  uint32
|           +--ro neighbor-state?        ipi-rsvp-
types:rsvp_neighbor_hello_state_t
|           +--ro srefresh-remaining-time?  uint32
|           +--ro neighbor-type?          ipi-rsvp-
types:rsvp_neighbor_type_t
|           +--ro max-acknowledge-packet?  uint16
|           +--ro used-acknowledge-packet? uint16
|           +--ro max-bundle-packet?      uint16
|           +--ro used-bundle-packet?     uint16
|           +--ro lsp-id?                 uint16
|           +--ro session-frr-type?        ipi-rsvp-
types:rsvp_session_frr_type_t
|           +--ro ingress?                inet:ip-address
|           +--ro egress?                 inet:ip-address
|           +--ro trunk-session-type?     ipi-rsvp-types:rsvp_sess_type_t
|           +--ro trunk-id?              uint32
|           +--ro graceful-restart-state? ipi-rsvp-
types:rsvp_graceful_restart_status_t {feature-list:HAVE_RSVP_GRST}?
|           +--ro graceful-restart-set-recovery? ipi-rsvp-
types:rsvp_graceful_restart_recovery_status_t {feature-list:HAVE_RSVP_GRST}?
|           +--ro restart-time?           uint32 {feature-
list:HAVE_RSVP_GRST}?
|           +--ro recovery-time?          uint32 {feature-
list:HAVE_RSVP_GRST}?
|           +--ro remaining-restart-time? uint32 {feature-
list:HAVE_RSVP_GRST}?
|           +--ro remaining-recovery-time? uint32 {feature-
list:HAVE_RSVP_GRST}?
+--rw rsvp-paths {feature-list:NOT_HAVE_MPLS_TUNNEL}?
| +--rw rsvp-path* [path-name]
|   +--rw path-name           -> ../config/path-name
|   +--rw config
|       | +--rw path-name?     string
|       | +--rw path-type      ipi-rsvp-types:rsvp_path_type_t
|       | +--rw description?   cml-data-types:cml_line_t
|       +--ro state
|           | +--ro path-name?     string
|           | +--ro path-type      ipi-rsvp-types:rsvp_path_type_t
|           | +--ro description?   cml-data-types:cml_line_t
|           | +--ro path-identifier? uint16
|           | +--ro hop-count?     uint16

```



```

|     +---rw explicit-route-object
|         +---rw mpls-hops
|             | +---rw mpls-hop* [hop-address hop-type]
|                 | +---rw hop-address    -> ../config/hop-address
|                 | +---rw hop-type      -> ../config/hop-type
|                 | +---rw config
|                 |     | +---rw hop-address?    inet:ipv4-address
|                 |     | +---rw hop-type?      ipi-rsvp-types:rsvp_path_status_t
|                 |     +---ro state
|                 |         +---ro hop-address?    inet:ipv4-address
|                 |         +---ro hop-type?      ipi-rsvp-types:rsvp_path_status_t
|         +---rw gmpls-strict-hops
|             | +---rw gmpls-strict-hop* [strict-hop-address]
|                 | +---rw strict-hop-address    -> ../config/strict-hop-address
|                 | +---rw config
|                 |     | +---rw strict-hop-address?    inet:ipv4-address
|                 |     +---ro state
|                 |         +---ro strict-hop-address?    inet:ipv4-address
|         +---rw gmpls-unnumbered-entry
|             +---rw gmpls-unnumbered-hop* [unnumbered-ip-addr link-id]
|                 +---rw unnumbered-ip-addr    -> ../config/unnumbered-ip-addr
|                 +---rw link-id              -> ../config/link-id
|                 +---rw config
|                 | +---rw unnumbered-ip-addr?    inet:ipv4-address
|                 | +---rw link-id?              uint32
|                 +---ro state
|                     +---ro unnumbered-ip-addr?    inet:ipv4-address
|                     +---ro link-id?              uint32
+---rw multipaths {feature-list:HAVE_RSVP_MULTIPATH}?
| +---rw multipath* [multipath-name]
|     +---rw multipath-name    -> ../config/multipath-name
|     +---rw config
|         | +---rw description?    cml-data-types:cml_line_t
|         | +---rw destination?    inet:ipv4-address
|         | +---rw multipath-name?  string
|         +---ro state
|             | +---ro description?    cml-data-types:cml_line_t
|             | +---ro destination?    inet:ipv4-address
|             | +---ro multipath-name?  string
|             | +---ro multipath-identifier?  uint16
|             | +---ro member-trunk-count?  uint16
|         +---ro member-trunks
|             +---ro member-trunk* [trunk-name]
|                 +---ro trunk-name    -> ../state/trunk-name
|                 +---ro state
|                     +---ro trunk-name?    string
|                     +---ro trunk-identifier?  uint32
|                     +---ro trunk-status?    ipi-rsvp-types:rsvp_trunk_status_t
+---rw trunks
| +---rw bypass-trunks

```

```

| | +--rw bypass-trunk* [bypass-name] {feature-list:HAVE_MPLS_FRR}?
| |   +--rw bypass-name   -> ../config/bypass-name
| |   +--rw config
| |     | +--rw bypass-name?           string
| |     | +--rw backup-bandwidth-type? ipi-rsvp-
types:rsvp_backup_bandwidth_type
| |     | +--rw ingress?               inet:ipv4-address
| |     | +--rw egress?                inet:ipv4-address
| |     | +--rw ext-tunnel-id?         inet:ipv4-address
| |     | +--rw update-type?          ipi-rsvp-types:rsvp_update_type_t
| |     | +--rw description?          cml-data-types:cml_line_t
| |     +--ro state
| |     | +--ro bypass-name?          string
| |     | +--ro backup-bandwidth-type? ipi-rsvp-
types:rsvp_backup_bandwidth_type
| |     | +--ro ingress?              inet:ipv4-address
| |     | +--ro egress?               inet:ipv4-address
| |     | +--ro ext-tunnel-id?        inet:ipv4-address
| |     | +--ro update-type?          ipi-rsvp-types:rsvp_update_type_t
| |     | +--ro description?          cml-data-types:cml_line_t
| |     +--rw session
| |       +--rw config
| |         | +--rw traffic-type?      ipi-rsvp-types:rsvp_traffic_type_t
| |         | +--rw retry-count?      uint16
| |         | +--rw retry-interval?   uint16
| |         | +--rw disable-route-record? empty
| |         | +--rw enable-reuse-route-record? empty
| |         | +--rw cspf-retry-count?  uint16 {feature-list:HAVE_CSPF}?
| |         | +--rw cspf-retry-interval? uint16 {feature-list:HAVE_CSPF}?
| |         +--ro state
| |         | +--ro traffic-type?      ipi-rsvp-types:rsvp_traffic_type_t
| |         | +--ro retry-count?      uint16
| |         | +--ro retry-interval?   uint16
| |         | +--ro disable-route-record? empty
| |         | +--ro enable-reuse-route-record? empty
| |         | +--ro cspf-retry-count?  uint16 {feature-list:HAVE_CSPF}?
| |         | +--ro cspf-retry-interval? uint16 {feature-list:HAVE_CSPF}?
| |         +--rw exclude-path {feature-list:HAVE_MPLS_FRR}?
| |           +--rw config!
| |             | +--rw exclude-type   ipi-rsvp-types:rsvp_exclude_path_type_t
| |             | +--rw exclude-addr  inet:ipv4-address
| |             +--ro state
| |             | +--ro exclude-type   ipi-rsvp-types:rsvp_exclude_path_type_t
| |             | +--ro exclude-addr  inet:ipv4-address
| |           +--rw path-state-block
| |             +--rw config
| |               | +--rw bandwidth?  string
| |               | +--rw path-name?  string
| |               +--ro state
| |               | +--ro bandwidth?  string
| |               | +--ro path-name?  string

```

```

| | | | +--rw session-attributes
| | | | | +--rw config
| | | | | | +--rw bandwidth? string
| | | | | | +--rw hold-priority? uint8
| | | | | | +--rw setup-priority? uint8
| | | | | | +--rw enable-label-record? empty
| | | | | | +--rw hop-limit? uint16
| | | | | | +--rw filter-type? ipi-rsvp-types:rsvp_filter_type_t
| | | | | +--ro state
| | | | | | +--ro bandwidth? string
| | | | | | +--ro hold-priority? uint8
| | | | | | +--ro setup-priority? uint8
| | | | | | +--ro enable-label-record? empty
| | | | | | +--ro hop-limit? uint16
| | | | | | +--ro filter-type? ipi-rsvp-types:rsvp_filter_type_t
| | | | +--rw diff-serv-info {feature-list:HAVE_MPLS_FRR,feature-
list:HAVE_DIFFSERV}?
| | | | | +--rw config
| | | | | +--ro state
| | | | | +--rw dscp-exp-maps
| | | | | | +--rw dscp-exp-map* [dscp-exp-map-exp-val]
| | | | | | | +--rw dscp-exp-map-exp-val -> ../config/dscp-exp-map-exp-val
| | | | | | | +--rw config
| | | | | | | | +--rw dscp-exp-map-exp-val? int32
| | | | | | | | +--rw dscp-exp-map-class-name string
| | | | | | | +--ro state
| | | | | | | | +--ro dscp-exp-map-exp-val? int32
| | | | | | | | +--ro dscp-exp-map-class-name string
| | +--rw ingress-trunks
| | | +--rw ingress-trunk* [trunk-name]
| | | | +--rw trunk-name -> ../config/trunk-name
| | | | +--rw config
| | | | | +--rw bsid-value? uint32
| | | | | +--rw trunk-color? uint32 {feature-list:HAVE_SERVICE_MAPPING}?
| | | | | | +--rw ingress? inet:ipv4-address
| | | | | | +--rw egress? inet:ipv4-address
| | | | | | +--rw ext-tunnel-id? inet:ipv4-address
| | | | | | +--rw update-type? ipi-rsvp-types:rsvp_update_type_t
| | | | | | +--rw description? cml-data-types:cml_line_t
| | | | | | +--rw trunk-name? string
| | | | | | +--rw trunk-family ipi-rsvp-types:rsvp_trunk_family_t
| | | | | | +--rw enable-igp-shortcut? empty
| | | | | | +--rw absolute-metric? uint32
| | | | | | +--rw relative-metric? int32
| | | | | | +--rw revert-timer? uint32
| | | | | | +--rw enable-reoptimize? empty
| | | | | | +--rw multipath-group? -> /rsvp-te/multipaths/multipath/config/
multipath-name {feature-list:HAVE_RSVP_MULTIPATH}?
| | | | | | +--ro state
| | | | | | | +--ro bsid-value? uint32
| | | | | | | +--ro trunk-color? uint32 {feature-list:HAVE_SERVICE_MAPPING}?

```

```

| | | +--ro ingress?          inet:ipv4-address
| | | +--ro egress?           inet:ipv4-address
| | | +--ro ext-tunnel-id?    inet:ipv4-address
| | | +--ro update-type?      ipi-rsvp-types:rsvp_update_type_t
| | | +--ro description?     cml-data-types:cml_line_t
| | | +--ro trunk-name?      string
| | | +--ro trunk-family     ipi-rsvp-types:rsvp_trunk_family_t
| | | +--ro enable-igp-shortcut? empty
| | | +--ro absolute-metric?  uint32
| | | +--ro relative-metric? int32
| | | +--ro revert-timer?    uint32
| | | +--ro enable-reoptimize? empty
| | | +--ro multipath-group?  -> /rsvp-te/multipaths/multipath/config/
multipath-name {feature-list:HAVE_RSVP_MULTIPATH}?
| | | +--rw path-computation-element {feature-list:HAVE_PCEP_RSVP}?
| | | | +--rw config
| | | | | +--rw path-option-dynamic?    cml-data-types:cml_pcep_path_dyn_t
{feature-list:HAVE_PCEP_RSVP}?
| | | | | +--rw pce-entity-identifier?  uint8 {feature-list:HAVE_PCEP_RSVP}?
| | | | | +--rw pce-state-report?      empty {feature-list:HAVE_PCEP_RSVP}?
| | | | | +--rw pce-lsp-delegate?     empty {feature-list:HAVE_PCEP_RSVP}?
| | | | +--ro state
| | | | | +--ro path-option-dynamic?    cml-data-types:cml_pcep_path_dyn_t
{feature-list:HAVE_PCEP_RSVP}?
| | | | | +--ro pce-entity-identifier?  uint8 {feature-list:HAVE_PCEP_RSVP}?
| | | | | +--ro pce-state-report?      empty {feature-list:HAVE_PCEP_RSVP}?
| | | | | +--ro pce-lsp-delegate?     empty {feature-list:HAVE_PCEP_RSVP}?
| | | +--rw mapped-ip-routes
| | | | +--rw mapped-ip-route* [address]
| | | | | +--rw address -> ../config/address
| | | | | +--rw config
| | | | | | +--rw address?    cml-data-types:cml_ipv4_prefix_t
| | | | | +--ro state
| | | | | | +--ro address?    cml-data-types:cml_ipv4_prefix_t
| | | +--rw mapped-prefix-class-routes
| | | | +--rw mapped-prefix-class-route* [dst-addr]
| | | | | +--rw dst-addr -> ../config/dst-addr
| | | | | +--rw config
| | | | | | +--rw dst-addr    cml-data-types:cml_ipv4_prefix_t
| | | | | | +--rw name       string {feature-list:HAVE_DIFFSERV}?
| | | | | +--ro state
| | | | | | +--ro dst-addr    cml-data-types:cml_ipv4_prefix_t
| | | | | | +--ro name       string {feature-list:HAVE_DIFFSERV}?
| | | +--rw secondary-priorities
| | | | +--rw secondary-priority* [priority-value]
| | | | | +--rw priority-value -> ../config/priority-value
| | | | | +--rw config
| | | | | | +--rw bandwidth?    string
| | | | | | +--rw priority-value? int32
| | | | | | +--rw priority-path? string

```

```

| | | | +--rw secondary-priority-srlg-disjoint? ipi-rsvp-
types:rsvp_te_srlg_disjoint_type_t {feature-list:HAVE_SRLG}?
| | | | +--rw hold-priority? uint8
| | | | +--rw setup-priority? uint8
| | | | +--rw enable-label-record? empty
| | | | +--rw hop-limit? uint16
| | | | +--ro state
| | | | +--ro bandwidth? string
| | | | +--ro priority-value? int32
| | | | +--ro priority-path? string
| | | | +--ro secondary-priority-srlg-disjoint? ipi-rsvp-
types:rsvp_te_srlg_disjoint_type_t {feature-list:HAVE_SRLG}?
| | | | +--ro hold-priority? uint8
| | | | +--ro setup-priority? uint8
| | | | +--ro enable-label-record? empty
| | | | +--ro hop-limit? uint16
| | +--rw sessions
| | +--rw session* [trunk-session-type]
| | | +--rw trunk-session-type -> ../config/trunk-session-type
| | | +--rw config
| | | | +--rw traffic-type? ipi-rsvp-
types:rsvp_traffic_type_t
| | | | +--rw retry-count? uint16
| | | | +--rw retry-interval? uint16
| | | | +--rw disable-route-record? empty
| | | | +--rw enable-reuse-route-record? empty
| | | | +--rw cspf-retry-count? uint16 {feature-list:HAVE_CSPF}?
| | | | +--rw cspf-retry-interval? uint16 {feature-list:HAVE_CSPF}?
| | | | +--rw trunk-session-type? ipi-rsvp-types:rsvp_sess_type_t
| | | | +--rw disable-cspf? empty {feature-list:HAVE_CSPF}?
| | | | +--rw disable-affinity? empty {feature-list:HAVE_TE}?
| | | | +--rw enable-local-protection? empty
| | | | +--ro state
| | | | +--ro traffic-type? ipi-rsvp-
types:rsvp_traffic_type_t
| | | | +--ro retry-count? uint16
| | | | +--ro retry-interval? uint16
| | | | +--ro disable-route-record? empty
| | | | +--ro enable-reuse-route-record? empty
| | | | +--ro cspf-retry-count? uint16 {feature-list:HAVE_CSPF}?
| | | | +--ro cspf-retry-interval? uint16 {feature-list:HAVE_CSPF}?
| | | | +--ro trunk-session-type? ipi-rsvp-types:rsvp_sess_type_t
| | | | +--ro disable-cspf? empty {feature-list:HAVE_CSPF}?
| | | | +--ro disable-affinity? empty {feature-list:HAVE_TE}?
| | | | +--ro enable-local-protection? empty
| | | +--rw admin-groups
| | | +--rw admin-group* [name] {feature-list:HAVE_TE}?
| | | | +--rw name -> ../config/name
| | | | +--rw config
| | | | | +--rw name? string
| | | | | +--rw type? ipi-rsvp-types:rsvp_admin_type_t

```

```

| | | | +---ro state
| | | | | +---ro name? string
| | | | | +---ro type? ipi-rsvp-types:rsvp_admin_type_t
| | | | +---rw path-state-block
| | | | | +---rw config
| | | | | | +---rw bandwidth? string
| | | | | | +---rw path-name? -> /rsvp-te/rsvp-paths/rsvp-path/config/
path-name
| | | | +---ro state
| | | | | +---ro bandwidth? string
| | | | | +---ro path-name? -> /rsvp-te/rsvp-paths/rsvp-path/config/
path-name
| | | | +---rw session-attributes
| | | | | +---rw config
| | | | | | +---rw bandwidth? string
| | | | | | +---rw hold-priority? uint8
| | | | | | +---rw setup-priority? uint8
| | | | | | +---rw enable-label-record? empty
| | | | | | +---rw hop-limit? uint16
| | | | | | +---rw filter-type? ipi-rsvp-
types:rsvp_filter_type_t
| | | | +---ro state
| | | | | +---ro bandwidth? string
| | | | | +---ro hold-priority? uint8
| | | | | +---ro setup-priority? uint8
| | | | | +---ro enable-label-record? empty
| | | | | +---ro hop-limit? uint16
| | | | | +---ro filter-type? ipi-rsvp-
types:rsvp_filter_type_t
| | | | +---rw diff-serv-info {feature-list:HAVE_DIFFSERV}?
| | | | | +---rw config
| | | | | +---ro state
| | | | | +---rw dscp-exp-maps
| | | | | | +---rw dscp-exp-map* [dscp-exp-map-exp-val]
val
| | | | | | +---rw dscp-exp-map-exp-val -> ../config/dscp-exp-map-exp-
| | | | | | +---rw config
| | | | | | | +---rw dscp-exp-map-exp-val? int32
| | | | | | | +---rw dscp-exp-map-class-name string
| | | | | | +---ro state
| | | | | | | +---ro dscp-exp-map-exp-val? int32
| | | | | | | +---ro dscp-exp-map-class-name string
| | | | | +---rw elsp-class
| | | | | | +---rw config
| | | | | | | +---rw elsp-signal? empty
| | | | | | | +---rw elsp-signal-class1? string
| | | | | | | +---rw elsp-signal-class2? string
| | | | | | | +---rw elsp-signal-class3? string
| | | | | | | +---rw elsp-signal-class4? string
| | | | | | | +---rw elsp-signal-class5? string
| | | | | | | +---rw elsp-signal-class6? string

```

```

| | | | | +--rw elsp-signal-class7? string
| | | | | +--ro state
| | | | | +--ro elsp-signal? empty
| | | | | +--ro elsp-signal-class1? string
| | | | | +--ro elsp-signal-class2? string
| | | | | +--ro elsp-signal-class3? string
| | | | | +--ro elsp-signal-class4? string
| | | | | +--ro elsp-signal-class5? string
| | | | | +--ro elsp-signal-class6? string
| | | | | +--ro elsp-signal-class7? string
| | | +--rw fast-reroute {feature-list:HAVE_MPLS_FRR}?
| | | | +--rw config
| | | | | +--rw fast-reroute-bandwidth? string
| | | | | +--rw protection? ipi-rsvp-
types:rsvp_frr_protection_t {feature-list:HAVE_MPLS_FRR}?
| | | | | +--rw enable-node-protection? empty {feature-
list:HAVE_MPLS_FRR}?
| | | | | +--rw frr-hold-priority? uint32
| | | | | +--rw frr-setup-priority? uint32
| | | | | +--rw frr-hop-limit? uint32
| | | | | +--ro state
| | | | | +--ro fast-reroute-bandwidth? string
| | | | | +--ro protection? ipi-rsvp-
types:rsvp_frr_protection_t {feature-list:HAVE_MPLS_FRR}?
| | | | | +--ro enable-node-protection? empty {feature-
list:HAVE_MPLS_FRR}?
| | | | | +--ro frr-hold-priority? uint32
| | | | | +--ro frr-setup-priority? uint32
| | | | | +--ro frr-hop-limit? uint32
| | | | | +--rw frr-admin-groups
| | | | | +--rw frr-admin-group* [admin-group-name] {feature-
list:HAVE_MPLS_FRR}?
| | | | | +--rw admin-group-name -> ../config/admin-group-name
| | | | | +--rw config
| | | | | | +--rw admin-group-name? string
| | | | | | +--rw admin-group-type? ipi-rsvp-
types:rsvp_frr_admin_type_t
| | | | | +--ro state
| | | | | +--ro admin-group-name? string
| | | | | +--ro admin-group-type? ipi-rsvp-
types:rsvp_frr_admin_type_t
| | | | | +--rw srlg {feature-list:HAVE_SRLG}?
| | | | | +--rw config
| | | | | | +--rw srlg-disjoint-secondary? ipi-rsvp-
types:rsvp_te_srlg_disjoint_type_t {feature-list:HAVE_SRLG}?
| | | | | +--ro state
| | | | | +--ro srlg-disjoint-secondary? ipi-rsvp-
types:rsvp_te_srlg_disjoint_type_t {feature-list:HAVE_SRLG}?
| | | | | +--ro trunk* [trunk-id extended-tunnel-id egress]
| | | | | +--ro trunk-id -> ../sessions/session/state/trunk-id
| | | | | +--ro extended-tunnel-id -> ../sessions/session/state/extended-
tunnel-id
| | | | | +--ro egress -> ../sessions/session/state/egress

```

```

|     +---ro multipath-group-name?      string {feature-list:HAVE_RSVP_MULTIPATH}?
|     +---ro multipath-group-identifier? uint16 {feature-
list:HAVE_RSVP_MULTIPATH}?
|     +---ro sessions
|         +---ro session* [session-name]
|             +---ro session-name      -> ../state/session-name
|             +---ro state
|                 +---ro received-explicit-route-object* [link-address]
|                     | +---ro link-address      -> ../state/link-address
|                     | +---ro state
|                     |     +---ro link-address?  inet:ip-address
|                     |     +---ro link-type?    ipi-rsvp-types:rsvp_path_status_t
|                 +---ro explicit-route-object* [link-address]
|                     | +---ro link-address      -> ../state/link-address
|                     | +---ro state
|                     |     +---ro link-address?  inet:ip-address
|                     |     +---ro link-type?    ipi-rsvp-types:rsvp_path_status_t
|                 +---ro constrained-shortest-path
|                     | +---ro state
|                     |     +---ro cspf-state?          ipi-rsvp-types:rsvp_status_t
|                     |     +---ro lsp-reoptimization-state? ipi-rsvp-types:rsvp_status_t
|                     |     +---ro lsp-reoptimization-timer? uint32
|                     |     +---ro cspf-client?         ipi-rsvp-
types:rsvp_cspf_client_t
|                     +---ro fast-reroute {feature-list:HAVE_MPLS_FRR}?
|                         | +---ro state
|                         |     +---ro lsp-protection?      ipi-rsvp-
types:rsvp_frr_protection_t {feature-list:HAVE_MPLS_FRR}?
|                         |     +---ro bypass-trunk-name?   string {feature-
list:HAVE_MPLS_FRR}?
|                         |     +---ro merge-point-address?  inet:ipv4-address {feature-
list:HAVE_MPLS_FRR}?
|                         |     +---ro merge-point-label?   uint32 {feature-
list:HAVE_MPLS_FRR}?
|                     +---ro upstream-downstream-state
|                         | +---ro state
|                         |     +---ro upstream-ip-address?  inet:ip-address
|                         |     +---ro upstream-interface-name? string
|                         |     +---ro downstream-ip-address? inet:ip-address
|                         |     +---ro downstream-interface-name? string
|                     +---ro traffic-flow-specification
|                         | +---ro state
|                         |     +---ro traffic-specification-rate? uint32
|                         |     +---ro filter-specification-rate? uint32
|                     +---ro session-priority
|                         | +---ro state
|                         |     +---ro setup-priority?      uint8
|                         |     +---ro hold-priority?      uint8
|                         |     +---ro hop-limit?          uint8
|                         |     +---ro bandwidth?         string
|                     +---ro path-refresh-timers
|                         | +---ro state

```



```

|         |         +---ro path-refresh-time?           uint32
|         |         +---ro remaining-path-refresh-time?  uint32
|         |         +---ro path-lifetime?               uint32
|         |         +---ro remaining-path-lifetime?     uint32
|         +---ro reserve-refresh-timers
|         |   +---ro state
|         |     +---ro reserve-refresh-time?           uint32
|         |     +---ro remaining-reserve-refresh-time? uint32
|         |     +---ro reserve-lifetime?               uint32
|         |     +---ro remaining-reserve-lifetime?     uint32
|         +---ro retry-timers
|         |   +---ro state
|         |     +---ro remaining-retry-time?           uint32
|         |     +---ro next-retry-time?                uint32
|         +---ro upstream-route-record-object
|         |   +---ro state
|         |     +---ro address*   inet:ip-address
|         +---ro downstream-route-record-object
|         |   +---ro state
|         |     +---ro address*   inet:ip-address
|         +---ro trunk-id?                               uint32
|         +---ro extended-tunnel-id?                    inet:ip-address
|         +---ro lsp-id?                                 uint16
|         +---ro session-frr-type?                      ipi-rsvp-
types:rsvp_session_frr_type_t
|         +---ro ingress?                               inet:ip-address
|         +---ro egress?                               inet:ip-address
|         +---ro trunk-session-type?                   ipi-rsvp-
types:rsvp_sess_type_t
|         +---ro session-name?                          string
|         +---ro session-role?                         ipi-rsvp-
types:rsvp_session_role_t
|         +---ro is-pseudo-primary?                    ipi-rsvp-types:rsvp_yes_no_t
|         +---ro lsp-state?                            string
|         +---ro fsm-state?                            string
|         +---ro transit-downstream-fsm-state?        string
|         +---ro establishment-time?                  cml-data-types:cml_line_t
|         +---ro revert-hold-timer?                   ipi-rsvp-types:rsvp_yes_no_t
|         +---ro remaining-revert-time?                uint32
|         +---ro session-filter-style?                ipi-rsvp-
types:rsvp_filter_state_type_t
|         +---ro in-label?                             uint32
|         +---ro out-label?                            uint32
|         +---ro bypass-out-label?                    uint32
|         +---ro bypass-out-interface?                 string
|         +---ro gmpls-label-type?                    ipi-rsvp-
types:rsvp_gmpls_label_type_t
|         +---ro qos-traffic-type?                    ipi-rsvp-
types:rsvp_traffic_type_state_t
|         +---ro minimum-path-mtu?                    uint32
+---rw interfaces
    +---rw interface* [name]

```

```

    +--rw name                               -> ../config/name
    +--rw config
    |   +--rw name?                          -> /ipi-interface:interfaces/interface/
name
    |   +--rw enable-rsvp?                   empty
    |   +--rw enable-iana-hello-config?     empty
    +--ro state
name
    |   +--ro name?                          -> /ipi-interface:interfaces/interface/
    |   +--ro enable-rsvp?                   empty
    |   +--ro enable-iana-hello-config?     empty
    |   +--ro selected-ipv4-address?        inet:ipv4-address
    |   +--ro selected-ipv6-address?        inet:ipv6-address
    |   +--ro interface-type?               ipi-rsvp-types:rsvp_interface_type_t
    |   +--ro interface-index?              uint32
    |   +--ro rsvp-status?                  ipi-rsvp-types:rsvp_status_t
    |   +--ro administrative-group-name*    string
    |   +--ro bundle-buffer-size?          uint16
    |   +--ro epoch?                        uint32
    +--rw refresh-reduction
    |   +--rw config
    |   |   +--rw enable-message-ack?        empty
    |   |   +--rw disable-refresh-reduction? empty
    |   |   +--rw ack-wait-timeout?          uint32
    |   |   +--rw refresh-time?              uint16
    |   |   +--rw keep-multiplier?          int32
    |   +--ro state
    |   |   +--ro enable-message-ack?        empty
    |   |   +--ro disable-refresh-reduction? empty
    |   |   +--ro ack-wait-timeout?          uint32
    |   |   +--ro refresh-time?              uint16
    |   |   +--ro keep-multiplier?          int32
    +--rw hellos
    |   +--rw config
    |   |   +--rw enable-hello-receipt?     empty
    |   |   +--rw hello-interval?          int32
    |   |   +--rw hello-timeout?           int32
    |   +--ro state
    |   |   +--ro enable-hello-receipt?     empty
    |   |   +--ro hello-interval?          int32
    |   |   +--ro hello-timeout?           int32
rpcs:
    +---x clear-rsvp-session {feature-list:HAVE_RSVPD}?
    +---x clear-rsvp-trunk {feature-list:HAVE_RSVPD}?
    |   +---w input
    |   |   +---w trunk-name    string
    +---x clear-rsvp-primary-trunk {feature-list:HAVE_RSVPD}?
    |   +---w input
    |   |   +---w trunk-name    string
    +---x clear-rsvp-secondary-trunk {feature-list:HAVE_RSVPD}?

```

```

| +---w input
|   +---w trunk-name    string
+---x clear-rsvp-ingress-trunk {feature-list:HAVE_RSVPD}?
| +---w input
|   +---w trunk-name    string
+---x clear-rsvp-non-ingress-trunk {feature-list:HAVE_RSVPD}?
| +---w input
|   +---w trunk-name    string
+---x rsvp-trunk-force-reoptimize-on {feature-list:HAVE_RSVPD}?
| +---w input
|   +---w trunk-name    string
+---x rsvp-trunk-force-switchover-secondary {feature-list:HAVE_RSVPD}?
| +---w input
|   +---w trunk-name    string
|   +---w action        ipi-rsvp-types:rsvp_force_secondary_t
+---x rsvp-trunk-restart {feature-list:HAVE_RSVPD}?
| +---w input
|   +---w trunk-name    string
+---x rsvp-session-reset {feature-list:HAVE_RSVPD}?
| +---w input
|   +---w tunnel-id     uint32
|   +---w lsp-id        uint32
|   +---w ingress       inet:ipv4-address
|   +---w egress        inet:ipv4-address
+---x clear-rsvp-statistics {feature-list:HAVE_RSVPD}?
+---x rsvp-snmp-restart {feature-list:HAVE_SNMP}?
+---x rsvp-terminal-debug-on {feature-list:HAVE_RSVPD}?
| +---w input
|   +---w terminal-debug-options    ipi-rsvp-types:rsvp_debug_t
+---x rsvp-terminal-debug-off {feature-list:HAVE_RSVPD}?
| +---w input
|   +---w terminal-debug-options    ipi-rsvp-types:rsvp_debug_t
+---x restart-rsvp-graceful {feature-list:HAVE_RSVP_GRST}?

```

notifications:

```

+---n rsvp-session-up
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro session-name?     string
| +--ro trunk-id?         uint32
| +--ro extended-tunnel-id? inet:ip-address
| +--ro egress?           inet:ip-address
| +--ro lsp-id?           uint16
| +--ro ingress?          inet:ip-address
| +--ro trunk-session-type? ipi-rsvp-types:rsvp_sess_type_t
+---n rsvp-session-down
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro session-name?     string
| +--ro trunk-id?         uint32

```

```

| +--ro extended-tunnel-id?   inet:ip-address
| +--ro egress?               inet:ip-address
| +--ro lsp-id?               uint16
| +--ro ingress?              inet:ip-address
| +--ro trunk-session-type?   ipi-rsvp-types:rsvp_sess_type_t
+---n rsvp-session-force-switchover
| +--ro severity?             cml-data-types:cml_notif_severity_t
| +--ro eventClass?           cml-data-types:cml_notif_class_t
| +--ro session-name?         string
| +--ro trunk-id?             uint32
| +--ro extended-tunnel-id?   inet:ip-address
| +--ro egress?               inet:ip-address
| +--ro lsp-id?               uint16
| +--ro ingress?              inet:ip-address
| +--ro trunk-session-type?   ipi-rsvp-types:rsvp_sess_type_t
+---n rsvp-tunnel-reoptimized
  +--ro severity?             cml-data-types:cml_notif_severity_t
  +--ro eventClass?           cml-data-types:cml_notif_class_t
  +--ro session-name?         string
  +--ro trunk-id?             uint32
  +--ro extended-tunnel-id?   inet:ip-address
  +--ro egress?               inet:ip-address
  +--ro lsp-id?               uint16
  +--ro ingress?              inet:ip-address
  +--ro trunk-session-type?   ipi-rsvp-types:rsvp_sess_type_t

```

module: ipi-seamless-bfd

```

+--rw seamless-bfd
  +--ro state
  | +--ro remote-discriminator*  string
+--rw sr-policies
  | +--rw sr-policy* [lsp-type sr-policy-name]
  |   +--rw lsp-type              -> ../config/lsp-type
  |   +--rw sr-policy-name        -> ../config/sr-policy-name
  |   +--rw config
  |   | +--rw lsp-type?           ipi-sbfd-types:sbfd_sr_type_t
  |   | +--rw sr-policy-name?    string
  |   +--ro state
  |   | +--ro lsp-type?           ipi-sbfd-types:sbfd_sr_type_t
  |   | +--ro sr-policy-name?    string
  |   +--rw session-attributes
  |   | +--rw config
  |   | | +--rw admin-down?      empty
  |   | +--ro state
  |   | | +--ro admin-down?      empty
  |   +--rw intervals

```

```

|         +---rw interval* [minimum-tx detection-multiplier]
|         +---rw minimum-tx          -> ../config/minimum-tx
|         +---rw detection-multiplier -> ../config/detection-multiplier
|         +---rw config
|         | +---rw minimum-tx?          uint32
|         | +---rw detection-multiplier? uint8
|         +---ro state
|         +---ro minimum-tx?          uint32
|         +---ro detection-multiplier? uint8
+---rw local-discriminators
+---rw local-discriminator* [discriminator]
+---rw discriminator  -> ../config/discriminator
+---rw config
| +---rw discriminator?          string
| +---rw required-min-rx-interval? uint32
+---ro state
+---ro discriminator?          string
+---ro required-min-rx-interval? uint32

```

module: ipi-segment-routing

```

+---rw segment-routing {feature-list:HAVE_SRV6_OR_HAVE_SR_MPLS}?
+---rw config!
| +---rw enable    empty
+---ro state
| +---ro enable    empty
+---rw interfaces {feature-list:HAVE_SR_MPLS}?
| +---rw interface* [name]
|   +---rw name          -> ../config/name
|   +---rw config
|   | +---rw name?      -> /ipi-interface:interfaces/interface/name
|   +---rw adjacency-segment {feature-list:HAVE_SR_MPLS}?
|   | +---rw config
|   | | +---rw adj-sid-absolute?  uint32
|   | | +---rw adj-sid-index?    uint32
|   | +---ro state
|   | +---ro adj-sid-absolute?  uint32
|   | +---ro adj-sid-index?    uint32
|   +---rw prefix-segment {feature-list:HAVE_SR_MPLS}?
|   +---rw config
|   | +---rw sid-absolute?  uint32
|   | +---rw sid-index?    uint32
|   | +---rw exp-null?     ipi-sr-types:if_sr_prefix_flag_t
|   | +---rw n-flag-clear? ipi-sr-types:if_sr_n_flag_clear_t
|   +---ro state
|   +---ro sid-absolute?  uint32
|   +---ro sid-index?    uint32

```

```
|          +---ro exp-null?          ipi-sr-types:if_sr_prefix_flag_t
|          +---ro n-flag-clear?     ipi-sr-types:if_sr_n_flag_clear_t
+---rw sr-mpls {feature-list:HAVE_SR_MPLS}?
| +---rw sr-prefer-over-ldp
| | +---rw config
| | | +---rw enable-preference?     empty
| | +---ro state
| |   +---ro enable-preference?     empty
| +---rw bindings
| | +---rw mapping-server
| |   +---rw config!
| |   | +---rw enable      empty
| |   +---ro state
| |   | +---ro enable      empty
| |   +---rw srms-preferenece
| |   | +---rw config
| |   | | +---rw preference?  uint8
| |   | | +---ro state
| |   | |   +---ro preference?  uint8
| |   +---rw prefix-sid-map-ipv4
| |     +---rw config!
| |     | +---rw enable      empty
| |     +---ro state
| |     | +---ro enable      empty
| |     +---rw mapping-entries
| |       +---rw mapping-entry* [start-address start-sid]
| |         +---rw start-address  -> ../config/start-address
| |         +---rw start-sid      -> ../config/start-sid
| |         +---rw config
| |         | +---rw start-address?  cml-data-types:cml_ipv4_prefix_t
| |         | +---rw start-sid?     uint32
| |         | +---rw range?         uint32
| |         | +---rw attached?      boolean
| |         +---ro state
| |         | +---ro start-address?  cml-data-types:cml_ipv4_prefix_t
| |         | +---ro start-sid?     uint32
| |         | +---ro range?         uint32
| |         | +---ro attached?      boolean
| |         +---ro ipv4-table
| |         +---ro state
| |         | +---ro start-prefix?   cml-data-types:cml_ip_prefix_addr_t
| |         | +---ro start-sid-index? uint16
| |         | +---ro range?         uint16
| |         +---ro end-prefix?     cml-data-types:cml_ip_prefix_addr_t
| |         +---ro end-sid-index?  uint16
| |         +---ro attached?       empty
| |         +---ro preference?     uint8
| +---rw global-block {feature-list:HAVE_SR_MPLS}?
| | +---rw config!
| | | +---rw start      uint32
```

```

| | | +--rw end          uint32
| | +--ro state
| |   +--ro start      uint32
| |   +--ro end        uint32
| +--rw local-block {feature-list:HAVE_SR_MPLS}?
|   +--rw config!
|     | +--rw start      uint32
|     | +--rw end        uint32
|     +--ro state
|       +--ro start      uint32
|       +--ro end        uint32
+--rw traffic-engineering {feature-list:HAVE_SR_POLICY_OR_HAVE_SRV6}?
| +--rw config!
| | +--rw fast-reroute-enable?  empty {feature-list:HAVE_SR_POLICY}?
| | +--rw enable                 empty
| +--ro state
| | +--ro fast-reroute-enable?  empty {feature-list:HAVE_SR_POLICY}?
| | +--ro enable                 empty
| +--rw attributes
| | +--rw segment-lists {feature-list:HAVE_SR_POLICY_OR_HAVE_SRV6}?
| |   +--rw segment-list* [list-name]
| |     +--rw list-name      -> ../config/list-name
| |     +--rw config
| |       | +--rw list-name?  string
| |       +--ro state
| |       | +--ro list-name?  string
| |       +--rw segments
| |         +--rw segment* [segment-index type]
| |           | +--rw segment-index      -> ../config/segment-index
| |           | +--rw type                -> ../config/type
| |           | +--rw config
| |             | | +--rw segment-index?  uint32
| |             | | +--rw type?           ipi-sr-types:srte_segment_type_t
| |             | +--ro state
| |             | | +--ro segment-index?  uint32
| |             | | +--ro type?           ipi-sr-types:srte_segment_type_t
| |             | +--rw segment-type-1 {feature-list:HAVE_SR_MPLS}?
| |             |   +--rw config
| |             |     | +--rw sid-value?  uint32
| |             |     +--ro state
| |             |       +--ro sid-value?  uint32
| |             +--rw segment-v6* [segment-index type]
| |               +--rw segment-index      -> ../config/segment-index
| |               +--rw type                -> ../config/type
| |               +--rw config
| |                 | +--rw segment-index?  uint32
| |                 | +--rw type?         ipi-sr-types:srte_segment_type_2_t
| |                 +--ro state
| |                 | +--ro segment-index?  uint32
| |                 | +--ro type?         ipi-sr-types:srte_segment_type_2_t

```



```

| | | | +---ro is-best-candidate-path?  boolean
| | | | +---ro forwarding-paths
| | | | | +---ro forwarding-path
| | | | | +---ro state
| | | | | | +---ro path-id?                uint8
| | | | | | +---ro next-hop-address?     inet:ip-address
| | | | | | +---ro outgoing-interface?   string
| | | | | | +---ro path-type?           string
| | | | | +---ro label-stack
| | | | | +---ro labels
| | | | | +---ro state
| | | | | | +---ro label?    string
| | | | +---rw dynamic {feature-list:HAVE_SR_POLICY_OR_HAVE_PCEP_SRV6}?
| | | | | +---rw config
| | | | | | +---rw pcep?                empty {feature-
list:HAVE_PCEP_SR_OR_HAVE_PCEP_SRV6}?
| | | | | | +---rw isis?                string
| | | | | | +---rw ospf?                int32
| | | | | | +---rw ospf-empty?         empty
| | | | | | +---ro state
| | | | | | +---ro pcep?                empty {feature-
list:HAVE_PCEP_SR_OR_HAVE_PCEP_SRV6}?
| | | | | | +---ro isis?                string
| | | | | | +---ro ospf?                int32
| | | | | | +---ro ospf-empty?         empty
| | | | | +---rw constraints
| | | | | | +---rw config!
| | | | | | | +---rw enable    empty
| | | | | | +---ro state
| | | | | | | +---ro enable    empty
| | | | | | +---rw admin-groups {feature-
list:HAVE_SR_POLICY_OR_HAVE_PCEP_SRV6}?
| | | | | | | +---rw admin-group* [admin-group-name] {feature-
list:HAVE_SR_POLICY_OR_HAVE_PCEP_SRV6}?
| | | | | | | +---rw admin-group-name    -> ../config/admin-group-name
| | | | | | | +---rw config
| | | | | | | +---rw affinity-type?     ipi-sr-
types:sr_te_admin_group_type_t
| | | | | | | | +---rw admin-group-name? string
| | | | | | | | +---ro state
| | | | | | | | +---ro affinity-type?   ipi-sr-
types:sr_te_admin_group_type_t
| | | | | | | | +---ro admin-group-name? string
| | | | | | | +---rw bounds
| | | | | | | | +---rw bound* [metric-type]
| | | | | | | | +---rw metric-type    -> ../config/metric-type
| | | | | | | | +---rw config
| | | | | | | | | +---rw metric-type?   ipi-sr-
types:srte_cp_metric_type_t
| | | | | | | | | +---rw bound?        uint32
| | | | | | | | | +---rw segment-bound? uint32
| | | | | | | | +---ro state

```

```

| | | | | +---ro metric-type? ipi-sr-
types:srte_cp_metric_type_t
| | | | | +---ro bound? uint32
| | | | | +---ro segment-bound? uint32
| | | | | +---rw ip
| | | | | +---rw include-hop* [address]
| | | | | +---rw address -> ../config/address
| | | | | +---rw config
| | | | | | +---rw address? inet:ip-address
| | | | | | +---rw type? ipi-sr-
types:srte_ip_constraint_hop_type_t
| | | | | +---ro state
| | | | | +---ro address? inet:ip-address
| | | | | +---ro type? ipi-sr-
types:srte_ip_constraint_hop_type_t
| | | | | +---rw explicit
| | | | | +---rw segment-lists {feature-list:HAVE_SR_POLICY_OR_HAVE_SRV6}?
| | | | | +---rw segment-list* [list-name]
| | | | | +---rw list-name -> ../config/list-name
| | | | | +---rw config
| | | | | +---rw list-name? string
| | | | | +---ro state
| | | | | +---ro statistics {feature-list:HAVE_SR_POLICY}?
| | | | | | +---ro tx-bytes? uint64
| | | | | | +---ro rx-bytes? uint64
| | | | | | +---ro tx-packets? uint64
| | | | | | +---ro rx-packets? uint64
| | | | | +---ro name? string
| | | | | +---ro admin-state? empty
| | | | | +---ro explicit-null? ipi-sr-types:srte_explicite_null_type_t
{feature-list:HAVE_SR_POLICY}?
| | | | | +---ro cspf-retry-limit? uint32 {feature-list:HAVE_SR_POLICY}?
| | | | | +---ro cspf-retry-interval? uint32 {feature-list:HAVE_SR_POLICY}?
| | | | | +---ro entropy-erld? uint8 {feature-list:HAVE_SR_POLICY}?
| | | | | +---ro pce-lsp-delegate? empty {feature-
list:HAVE_PCEP_SR_OR_HAVE_PCEP_SRV6}?
| | | | | +---ro pce-state-report? empty {feature-
list:HAVE_PCEP_SR_OR_HAVE_PCEP_SRV6}?
| | | | | +---ro pce-entity-id? uint32 {feature-
list:HAVE_PCEP_SR_OR_HAVE_PCEP_SRV6}?
| | | | | +---ro bsid-value? uint32 {feature-list:HAVE_SR_POLICY}?
| | | | | +---ro oper-state? ipi-sr-types:srte_policy_oper_state_t
| | | | | +---ro transition-count? uint32
| | | | | +---ro up-time? string
| | | | | +---ro down-time? string
| | | | | +---ro bsid-alloc-mode? string
| | | | | +---ro bsid-oper-state? ipi-sr-types:sr_policy_bsid_oper_state
| +---rw on-demand-nexthops {feature-list:HAVE_SR_POLICY}?
| +---rw on-demand-nexthop* [color]
| +---rw color -> ../config/color
| +---rw config
| | +---rw color? uint32

```

```

|         | +--rw cspf-retry-limit?          uint16
|         | +--rw cspf-retry-interval?      uint16
|         | +--rw pce-lsp-delegate?        empty {feature-list:HAVE_PCEP_SR}?
|         | +--rw pce-state-report?        empty {feature-list:HAVE_PCEP_SR}?
|         | +--rw pce-entity-id?           uint8 {feature-list:HAVE_PCEP_SR}?
|         | +--rw binding-sid-label?       uint16
|         +--ro state
|         | +--ro color?                    uint32
|         | +--ro cspf-retry-limit?        uint16
|         | +--ro cspf-retry-interval?     uint16
|         | +--ro pce-lsp-delegate?        empty {feature-list:HAVE_PCEP_SR}?
|         | +--ro pce-state-report?        empty {feature-list:HAVE_PCEP_SR}?
|         | +--ro pce-entity-id?           uint8 {feature-list:HAVE_PCEP_SR}?
|         | +--ro binding-sid-label?       uint16
|         +--rw candidate-paths
|             +--rw candidate-path* [discriminator protocol-origin originator]
|                 +--rw discriminator      -> ../config/discriminator
|                 +--rw protocol-origin    -> ../config/protocol-origin
|                 +--rw originator        -> ../config/originator
|                 +--rw config
|                     | +--rw discriminator?    uint32
|                     | +--rw protocol-origin? ipi-sr-
types:srte_protocol_origin_type_type_t
|                     | +--rw originator?      string
|                     | +--rw preference?     uint16
|                     +--ro state
|                     | +--ro discriminator?   uint32
|                     | +--ro protocol-origin? ipi-sr-
types:srte_protocol_origin_type_type_t
|                     | +--ro originator?     string
|                     | +--ro preference?     uint16
|                     +--rw dynamic {feature-list:HAVE_SR_POLICY}?
|                         +--rw config
|                             | +--rw pcep?          empty {feature-list:HAVE_PCEP_SR}?
|                             | +--rw isis-instance-id? string
|                             | +--rw ospf-process-id? int32
|                             | +--rw ospf-empty?   empty
|                             +--ro state
|                             | +--ro pcep?          empty {feature-list:HAVE_PCEP_SR}?
|                             | +--ro isis-instance-id? string
|                             | +--ro ospf-process-id? int32
|                             | +--ro ospf-empty?   empty
|                             +--rw constraints
|                                 +--rw config!
|                                     | +--rw enable    empty
|                                     +--ro state
|                                         | +--ro enable    empty
|                                         +--rw affinity-admin-groups
|                                             | +--rw affinity-admin-group* [admin-group-name] {feature-
list:HAVE_SR_POLICY}?
|                                             |         +--rw admin-group-name    -> ../config/admin-group-name

```

```

|
|      +---rw config
types:sr_te_admin_group_type_t | | +---rw affinity-type?      ipi-sr-
| | +---rw admin-group-name?  string
| | +---ro state
types:sr_te_admin_group_type_t | | +---ro affinity-type?      ipi-sr-
| | +---ro admin-group-name?  string
| | +---rw bounds
| | +---rw bound* [metric-type]
| | +---rw metric-type      -> ../config/metric-type
| | +---rw config
| | | +---rw metric-type?    ipi-sr-types:srte_cp_metric_type_t
| | | +---rw bound?         uint32
| | | +---ro state
| | | +---ro metric-type?    ipi-sr-types:srte_cp_metric_type_t
| | | +---ro bound?         uint32
| | +---rw ip
| | +---rw include-hops
| | +---rw include-hop* [address]
| | +---rw address      -> ../config/address
| | +---rw config
| | | +---rw address?      inet:ip-address
| | | +---rw type?        ipi-sr-
types:srte_ip_constraint_hop_type_t | | +---ro state
| | +---ro address?      inet:ip-address
| | +---ro type?        ipi-sr-
types:srte_ip_constraint_hop_type_t
+---rw srv6 {feature-list:HAVE_SRV6}?
| +---rw config!
| | +---rw enable      empty
| | +---ro state
| | +---ro enable      empty
| +---rw locators {feature-list:HAVE_SRV6}?
| | +---rw config!
| | | +---rw enable      empty
| | | +---ro state
| | | +---ro enable      empty
| | +---rw locator* [locator-name]
| | | +---rw locator-name  -> ../config/locator-name
| | | +---rw config
| | | | +---rw locator-name?  string
| | | | +---rw prefix?        cml-data-types:cml_ipv6_prefix_t
| | | +---ro state
| | | +---ro locator-name?  string
| | | +---ro prefix?        cml-data-types:cml_ipv6_prefix_t
| | | +---ro uptime?        string
| +---ro services-entries
| | +---ro services-entry* [fec-ipv4-prefix service-vrf-id]
| | +---ro fec-ipv4-prefix  -> ../state/fec-ipv4-prefix

```

```

| |     +---ro service-vrf-id      -> ../state/service-vrf-id
| |     +---ro state
| |         +---ro fec-ipv4-prefix?    cml-data-types:cml_ipv4_prefix_t
| |         +---ro service-vrf-id?    uint32
| |         +---ro service-vrf-name?  string
| |         +---ro service-type?      string
| |         +---ro flags?             string
| |         +---ro address-family?    uint32
| |         +---ro sid?               inet:ipv6-address
| |         +---ro nexthop-ipv6-prefix? inet:ipv6-address
| |         +---ro service-policy-name? string
| +---ro transport-entries
| |     +---ro transport-entry* [fec]
| |         +---ro fec                -> ../state/fec
| |         +---ro state
| |             | +---ro fec?          inet:ipv6-address
| |             | +---ro policy-name?  string
| |             | +---ro policy-id?    uint32
| |             | +---ro transport-color? uint32
| |             | +---ro code?         string
| |             | +---ro is-primary?   boolean
| |             | +---ro out-sid?      inet:ipv6-address
| |             | +---ro out-interface? string
| |             | +---ro nexthop?     inet:ipv6-address
| |         +---ro ftn-entries
| |             +---ro ftn-entry* [vrf-id fec-prefix]
| |                 +---ro vrf-id      -> ../state/vrf-id
| |                 +---ro fec-prefix  -> ../state/fec-prefix
| |                 +---ro state
| |                     +---ro vrf-id?    uint32
| |                     +---ro fec-prefix? cml-data-types:cml_ipv4_addr_prefix_t
| |                     +---ro vrf-name?  string
| |                     +---ro ftn-nexthop? inet:ipv6-address
| |                     +---ro tunnel-policy? string
| |                     +---ro ftn-color?  uint32
| +---ro manager-entries {feature-list:HAVE_SRV6}?
|     +---ro state
|         +---ro protocol-state?      ipi-sr-
types:srv6_protocol_state_t
|         +---ro srv6-locator-name?   string
|         +---ro platform-capabilities-end-function* string
|         +---ro platform-capabilities-ingress-function* string
|         +---ro platform-capabilities-ingress-sr-policy* string
+---rw debug {feature-list:HAVE_SR_POLICY_OR_HAVE_SRV6}?
+---rw config
| +---rw options?    ipi-sr-types:sr_te_debug_t
+---ro state
+---ro options?      ipi-sr-types:sr_te_debug_t
+---ro terminal-debug-status? ipi-sr-types:sr_te_debug_t

```

rpcs:

```

+---x sr-policy-terminal-debug-all-on {feature-
list:HAVE_SR_POLICY_OR_HAVE_SRV6_OR_HAVE_SR_MPLS}?
+---x sr-policy-terminal-debug-on {feature-
list:HAVE_SR_POLICY_OR_HAVE_SRV6_OR_HAVE_SR_MPLS}?
| +---w input
|   +---w terminal-debug-options      ipi-sr-types:sr_te_debug_t
+---x sr-policy-terminal-debug-off {feature-
list:HAVE_SR_POLICY_OR_HAVE_SRV6_OR_HAVE_SR_MPLS}?
+---w input
+---w terminal-debug-options      ipi-sr-types:sr_te_debug_t

notifications:
+---n sr-policy-oper-state-down
| +--ro severity?      cml-data-types:cml_notif_severity_t
| +--ro eventClass?   cml-data-types:cml_notif_class_t
| +--ro name?         string
| +--ro oper-state?   ipi-sr-types:srte_policy_oper_state_t
+---n sr-policy-oper-state-up
| +--ro severity?      cml-data-types:cml_notif_severity_t
| +--ro eventClass?   cml-data-types:cml_notif_class_t
| +--ro name?         string
| +--ro oper-state?   ipi-sr-types:srte_policy_oper_state_t
+---n sr-policy-cp-active
| +--ro severity?      cml-data-types:cml_notif_severity_t
| +--ro eventClass?   cml-data-types:cml_notif_class_t
| +--ro discriminator? uint32
| +--ro protocol-origin? ipi-sr-types:srte_protocol_origin_type_type_t
| +--ro originator?   string
| +--ro name?         string
| +--ro is-valid?     boolean
+---n sr-policy-cp-inactive
| +--ro severity?      cml-data-types:cml_notif_severity_t
| +--ro eventClass?   cml-data-types:cml_notif_class_t
| +--ro discriminator? uint32
| +--ro protocol-origin? ipi-sr-types:srte_protocol_origin_type_type_t
| +--ro originator?   string
| +--ro name?         string
| +--ro is-valid?     boolean
+---n sr-policy-binding-sid-unavailable-event {feature-list:HAVE_SR_POLICY}?
+--ro severity?      cml-data-types:cml_notif_severity_t
+--ro eventClass?   cml-data-types:cml_notif_class_t
+--ro name?         string
+--ro bsid-value?   uint32

```

module: ipi-service-map

```

+--rw service-map {feature-list:HAVE_SERVICE_MAPPING}?
+--rw tunnel-policies

```

```

+--rw tunnel-policy* [name]
  +--rw name          -> ../config/name
  +--rw config
    | +--rw name?          string
    | +--rw color-code*   uint32
    | +--rw selection-mode? ipi-service-map-types:tunnel_selection_mode_t
    | +--rw tunnel-type?  ipi-service-map-types:tunnel_selection_type_t
  {feature-list:HAVE_SRV6_OR_HAVE_SR_MPLS_OR_HAVE_MPLS}?
  +--ro state
    +--ro name?          string
    +--ro color-code*   uint32
    +--ro selection-mode? ipi-service-map-types:tunnel_selection_mode_t
    +--ro tunnel-type?  ipi-service-map-types:tunnel_selection_type_t
  {feature-list:HAVE_SRV6_OR_HAVE_SR_MPLS_OR_HAVE_MPLS}?

```

module: ipi-sflow-interface

```

augment /ipi-sflow:sampling/ipi-sflow:sflow:
  +--rw interfaces
    +--rw interface* [name]
      +--rw name          -> ../config/name
      +--rw config
        | +--rw name?          -> /ipi-interface:interfaces/interface/name
        | +--rw enabled?      empty
        | +--rw polling-interval? uint8
      +--ro state
        | +--ro name?          -> /ipi-interface:interfaces/interface/name
        | +--ro enabled?      empty
        | +--ro polling-interval? uint8
        | +--ro polling-count? yang:counter32
      +--rw ingress
        | +--rw config!
        | | +--rw sampling-rate  uint32
        | | +--rw sample-size    uint16
        | +--ro state
        | | +--ro sampling-rate  uint32
        | | +--ro sample-size    uint16
        | | +--ro sampling-status? ipi-sflow-types:sflow_egress_ingress_t
        | | +--ro sampled-packet-count? yang:counter32
      +--rw egress
        +--rw config!
        | +--rw sampling-rate  uint32
        | +--rw sample-size    uint16
        +--ro state
          +--ro sampling-rate  uint32
          +--ro sample-size    uint16
          +--ro sampling-status? ipi-sflow-types:sflow_egress_ingress_t
          +--ro sampled-packet-count? yang:counter32

```

```
rpcs:
  +---x sflow-clear-statistics {feature-list:HAVE_SFLOW}?
    +---w input
      +---w interface    string
```

module: ipi-sflow

```
+--rw sampling
  +--rw sflow
    +--rw config!
      | +--rw enabled          empty
      | +--rw source-address?  inet:ipv4-address
    +--ro state
      | +--ro enabled          empty
      | +--ro source-address?  inet:ipv4-address
      | +--ro sflow-version?   string
      | +--ro datagram-version? uint8
    +--rw collectors
      | +--rw collector* [address port]
      |   +--rw address      -> ../config/address
      |   +--rw port         -> ../config/port
      |   +--rw config
      |     | +--rw address?    inet:ipv4-address
      |     | +--rw port?       inet:port-number
      |     | +--rw receiver-timeout  uint32
      |     | +--rw max-datagram-size  uint16
      |     +--ro state
      |       +--ro address?    inet:ipv4-address
      |       +--ro port?       inet:port-number
      |       +--ro receiver-timeout  uint32
      |       +--ro max-datagram-size  uint16
    +--rw debug
      +--rw config
        | +--rw options?      ipi-sflow-types:sflow_debug_t
      +--ro state
        +--ro options?        ipi-sflow-types:sflow_debug_t
        +--ro terminal-debug-status?  ipi-sflow-types:sflow_debug_t
```

```
rpcs:
  +---x sflow-terminal-debug-on {feature-list:HAVE_SFLOW}?
    | +---w input
    |   +---w terminal-debug-options      ipi-sflow-types:sflow_debug_t
  +---x sflow-terminal-debug-off {feature-list:HAVE_SFLOW}?
    +---w input
      +---w terminal-debug-options      ipi-sflow-types:sflow_debug_t
```



```

notifications:
  +---n sflow-receiver-timeout-alarm-message
    +---ro severity?      cml-data-types:cml_notif_severity_t
    +---ro eventClass?    cml-data-types:cml_notif_class_t
    +---ro message?      string

```

module: ipi-snmp-server-extended

```

augment /ipi-snmp:snmp/ipi-snmp-server:servers:
  +---rw debug {feature-list:HAVE_SNMP_AGENT}?
    +---rw config
      | +---rw enable?    empty
    +---ro state
      +---ro enable?      empty
      +---ro terminal-debug-status? cml-data-types:cml_on_off_t
augment /ipi-snmp:snmp/ipi-snmp-server:servers/ipi-snmp-server:server:
  +---rw snmp-views {feature-list:HAVE_SNMP_AGENT}?
    +---rw snmp-view* [view-name] {feature-list:HAVE_SNMP_AGENT}?
      +---rw view-name    -> ../config/view-name
      +---rw config
        | +---rw view-name?  string
      +---ro state
        | +---ro view-name?  string
      +---rw oid-trees
        +---rw oid-tree* [oid] {feature-list:HAVE_SNMP_AGENT}?
          +---rw oid        -> ../config/oid
          +---rw config!
            | +---rw oid?      string
            | +---rw filter-type ipi-snmp-server-extended-
types:snmp_server_oid_tree_t
          +---ro state
            +---ro oid?      string
            +---ro filter-type ipi-snmp-server-extended-
types:snmp_server_oid_tree_t
augment /ipi-snmp:snmp:
  +---rw engine-id {feature-list:HAVE_SNMP_V3,feature-list:HAVE_SNMP_AGENT}?
  +---rw config
    | +---rw engine-id?    string
  +---ro state
    +---ro engine-id?    string
augment /ipi-snmp:snmp/ipi-snmp-server:servers/ipi-snmp-server:server:
  +---rw smux-port {feature-list:HAVE_SNMP_AGENT}?
  +---rw config
    | +---rw smux-port-enable? empty
  +---ro state
    +---ro smux-port-enable? empty
augment /ipi-snmp:snmp/ipi-snmp-server:servers/ipi-snmp-server:server:

```

```

+--rw hosts {feature-list:HAVE_SNMP_AGENT}?
  +--rw host* [host-name] {feature-list:HAVE_SNMP_AGENT}?
    +--rw host-name    -> ../config/host-name
    +--rw config
      | +--rw host-name?          string
      | +--rw snmp-version?      ipi-snmp-server-extended-
types:snmp_server_version_t
      | +--rw notification-type? ipi-snmp-server-extended-
types:snmp_server_notification_t
      | +--rw udp-port?          uint32
      | +--rw (host-option)?
      |   +---:(use-community)
      |   | +--rw community?     -> /ipi-snmp:snmp/ipi-snmp-server:servers/
server/communities/community/community-name
      |   +---:(use-snmpv3-user)
      |   | +--rw snmpv3-auth-type? ipi-snmp-server-extended-
types:snmp_server_version3_auth_type_t
      |   | +--rw snmpv3-user?    -> /ipi-snmp:snmp/ipi-snmp-server:servers/
server/users/user/config/user-name
      |   +---:(use-host-user)
      |   +--rw host-user?       string
    +--ro state
      +--ro host-name?          string
      +--ro snmp-version?      ipi-snmp-server-extended-
types:snmp_server_version_t
      +--ro notification-type? ipi-snmp-server-extended-
types:snmp_server_notification_t
      +--ro udp-port?          uint32
      +--ro (host-option)?
        +---:(use-community)
        | +--ro community?     -> /ipi-snmp:snmp/ipi-snmp-server:servers/
server/communities/community/community-name
        +---:(use-snmpv3-user)
        | +--ro snmpv3-auth-type? ipi-snmp-server-extended-
types:snmp_server_version3_auth_type_t
        | +--ro snmpv3-user?    -> /ipi-snmp:snmp/ipi-snmp-server:servers/
server/users/user/config/user-name
        +---:(use-host-user)
        +--ro host-user?       string
  augment /ipi-snmp:snmp/ipi-snmp-server:servers/ipi-snmp-server:server:
    +--rw users {feature-list:HAVE_SNMP_AGENT}?
      +--rw user* [user-name] {feature-list:HAVE_SNMP_AGENT,feature-list:HAVE_SNMP_V3}?
        +--rw user-name    -> ../config/user-name
        +--rw config
          | +--rw user-name?          string
          | +--rw user-type?          ipi-snmp-server-extended-
types:snmp_server_group_name_t
          | +--rw user-group?        string
          | +--rw encryption-type?   ipi-snmp-server-extended-
types:snmp_server_key_type_t
          | +--rw authentication-type? ipi-snmp-server-extended-
types:snmp_server_auth_t
          | +--rw authentication-password? string

```

```

    | +--rw privilege-type?          ipi-snmp-server-extended-
types:snmp_server_priv_t
    | +--rw privilege-password?     string
    +--ro state
        +--ro user-name?            string
        +--ro user-type?            ipi-snmp-server-extended-
types:snmp_server_group_name_t
        +--ro user-group?           string
        +--ro encryption-type?      ipi-snmp-server-extended-
types:snmp_server_key_type_t
        +--ro authentication-type?  ipi-snmp-server-extended-
types:snmp_server_auth_t
        +--ro authentication-password? string
        +--ro privilege-type?       ipi-snmp-server-extended-
types:snmp_server_priv_t
        +--ro privilege-password?   string
augment /ipi-snmp:snmp/ipi-snmp-server:servers/ipi-snmp-server:server:
+--rw contexts {feature-list:HAVE_SNMP_AGENT}?
+--rw context* [context-name]
+--rw context-name -> ../config/context-name
+--rw config
| +--rw context-name? string
+--ro state
    +--ro context-name? string
augment /ipi-snmp:snmp/ipi-snmp-server:servers/ipi-snmp-server:server:
+--rw communities {feature-list:HAVE_SNMP_AGENT}?
+--rw community* [community-name] {feature-list:HAVE_SNMP_AGENT}?
+--rw community-name -> ../config/community-name
+--rw config
| +--rw community-name? string
| +--rw acl-name? -> /ipi-acl:acl/standard-acl-sets/standard-
acl-set/name
| +--rw community-view-name? -> /ipi-snmp:snmp/ipi-snmp-server:servers/
server/snmp-views/snmp-view/view-name
| +--rw version? ipi-snmp-server-extended-
types:snmp_server_view_version_t
| +--rw access? ipi-snmp-server-extended-
types:snmp_server_access_t
| +--rw (community-option)?
|   +--:(use-group)
|   | +--rw snmp-group? ipi-snmp-server-extended-
types:snmp_server_group_t
|   +--:(use-access)
|   +--rw access-privileges? ipi-snmp-server-extended-
types:snmp_server_access_t
+--ro state
| +--ro community-name? string
| +--ro acl-name? -> /ipi-acl:acl/standard-acl-sets/standard-
acl-set/name
| +--ro community-view-name? -> /ipi-snmp:snmp/ipi-snmp-server:servers/
server/snmp-views/snmp-view/view-name
| +--ro version? ipi-snmp-server-extended-
types:snmp_server_view_version_t

```

```

    | +--ro access?                               ipi-snmp-server-extended-
types:snmp_server_access_t
    | +--ro (community-option)?
    |   +---:(use-group)
    |   | +--ro snmp-group?                       ipi-snmp-server-extended-
types:snmp_server_group_t
    |   |   +---:(use-access)
    |   |   +--ro access-privileges?             ipi-snmp-server-extended-
types:snmp_server_access_t
    +--rw community-context-mapping
    +--rw config
    | +--rw community-context?   string
    | +--rw community-user?     string
    +--ro state
    | +--ro community-context?   string
    | +--ro community-user?     string
augment /ipi-snmp:snmp/ipi-snmp-server:servers/ipi-snmp-server:server:
  +--rw server-groups {feature-list:HAVE_SNMP_AGENT}?
  +--rw server-group* [group-name] {feature-list:HAVE_SNMP_AGENT}?
  +--rw group-name    -> ../config/group-name
  +--rw config
  | +--rw group-name?           string
  | +--rw group-version?       ipi-snmp-server-extended-
types:snmp_server_version_t
  | +--rw snmpv3-group-auth-type? ipi-snmp-server-extended-
types:snmp_v3_server_group_auth_type_t
  | +--rw context*             ipi-snmp-server-extended-
types:snmp_server_context_name_t
  +--ro state
  | +--ro group-name?           string
  | +--ro group-version?       ipi-snmp-server-extended-
types:snmp_server_version_t
  | +--ro snmpv3-group-auth-type? ipi-snmp-server-extended-
types:snmp_v3_server_group_auth_type_t
  | +--ro context*             ipi-snmp-server-extended-
types:snmp_server_context_name_t
  augment /ipi-snmp:snmp:
    +--ro statistics {feature-list:HAVE_SNMP_AGENT}?
    +--ro state
    +--ro engine-id?   cml-data-types:cml_line_t
  augment /ipi-snmp:snmp:
    +--ro default-global-values {feature-list:HAVE_SNMP_AGENT}?
    +--ro state
    +--ro system-default-contact? ipi-snmp-server-extended-
types:cml_line_without_pattern_t {feature-list:HAVE_SNMP_AGENT}?
    +--ro system-default-location? ipi-snmp-server-extended-
types:cml_line_without_pattern_t {feature-list:HAVE_SNMP_AGENT}?

rpcs:
  +---x snmp-server-terminal-debug-on {feature-list:HAVE_HOSTPD}?
  +---x snmp-server-terminal-debug-off {feature-list:HAVE_HOSTPD}?

```

module: ipi-snmp-server

```

augment /ipi-snmp:snmp:
  +--rw servers {feature-list:HAVE_SNMP_AGENT}?
    +--rw server* [vrf-name]
      | +--rw vrf-name -> ../config/vrf-name
      | +--rw config!
      | | +--rw vrf-name? -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
      | | +--rw enabled empty
      | +--ro state
      | | +--ro vrf-name? -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
      | | +--ro enabled empty
      | +--rw global
      |   +--rw config
      |     | +--rw system-contact? cml-data-types:cml_line_t {feature-
list:HAVE_SNMP_AGENT}?
      |     | +--rw system-location? cml-data-types:cml_line_t {feature-
list:HAVE_SNMP_AGENT}?
      |     | +--rw tcp-session-enabled? empty {feature-list:HAVE_SNMP_AGENT}?
      |     | +--ro state
      |     | +--ro system-contact? cml-data-types:cml_line_t {feature-
list:HAVE_SNMP_AGENT}?
      |     | +--ro system-location? cml-data-types:cml_line_t {feature-
list:HAVE_SNMP_AGENT}?
      |     | +--ro tcp-session-enabled? empty {feature-list:HAVE_SNMP_AGENT}?
      +--rw default-instance
        +--rw config
          | +--rw disable-default-instance? empty
        +--ro state
          +--ro disable-default-instance? empty

```

module: ipi-snmp

```

+--rw snmp {feature-list:HAVE_SNMP_AGENT}?
  +--rw server-traps
    +--rw config
      | +--rw enable-traps? ipi-snmp-types:snmp_trap_protocols
      | +--rw enable-link-down-trap? boolean
      | +--rw enable-link-up-trap? boolean
      | +--rw include-interface-name? empty
    +--ro state
      +--ro enable-traps? ipi-snmp-types:snmp_trap_protocols
      +--ro enable-link-down-trap? boolean
      +--ro enable-link-up-trap? boolean

```

```

+--ro include-interface-name?  empty

```

```

rpcs:

```

```

+---x snmp-agentx-enable-terminal-debugging {feature-list:HAVE_AGENTX}?
| +---w input
|   +---w debug    ipi-snmp-types:snmp_agentx_debug_type_t
+---x snmp-agentx-disable-terminal-debugging {feature-list:HAVE_AGENTX}?
+---w input
+---w debug    ipi-snmp-types:snmp_agentx_debug_type_t

```

module: ipi-source-interface

```

+--rw source-interface {feature-list:HAVE_HOSTPD}?
+--rw address-family-ipv4
| +--rw source-nat-mappings
|   +--rw source-nat-mapping* [interface-name protocol-type]
|     +--rw interface-name    -> ../config/interface-name
|     +--rw protocol-type     -> ../config/protocol-type
|     +--rw config
|       | +--rw interface-name? -> /ipi-interface:interfaces/interface/name
|       | +--rw protocol-type?  ipi-source-interface-
types:src_intf_proto_types_t
|       | +--rw port-number      ipi-source-interface-
types:src_intf_port_number_t
|       | +--rw vrf-name         -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
|       +--ro state
|         +--ro interface-name? -> /ipi-interface:interfaces/interface/name
|         +--ro protocol-type?  ipi-source-interface-
types:src_intf_proto_types_t
|         +--ro port-number      ipi-source-interface-
types:src_intf_port_number_t
|         +--ro vrf-name         -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
|         +--ro address?        inet:ip-address
|         +--ro status?         ipi-source-interface-types:src_intf_status_t
+--rw address-family-ipv6 {feature-list:HAVE_IPV6}?
+--rw source-nat-mappings
+--rw source-nat-mapping* [interface-name protocol-type]
+--rw interface-name    -> ../config/interface-name
+--rw protocol-type     -> ../config/protocol-type
+--rw config
| +--rw interface-name? -> /ipi-interface:interfaces/interface/name
| +--rw protocol-type?  ipi-source-interface-
types:src_intf_proto_types_t
| +--rw port-number      ipi-source-interface-
types:src_intf_port_number_t
| +--rw vrf-name         -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?

```

```

    +---ro state
      +---ro interface-name?  -> /ipi-interface:interfaces/interface/name
      +---ro protocol-type?   ipi-source-interface-
types:src_intf_proto_types_t
      +---ro port-number      ipi-source-interface-
types:src_intf_port_number_t
      +---ro vrf-name         -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_VRF}?
      +---ro address?        inet:ip-address
      +---ro status?         ipi-source-interface-types:src_intf_status_t

```

module: ipi-ssh

```

+---rw ssh-server
  +---rw debug
  | +---rw config
  | | +---rw enable?   empty
  | +---ro state
  |   +---ro enable?   empty
  |   +---ro terminal-debug-status?  cml-data-types:cml_on_off_t
+---rw vrfs
  +---rw vrf* [vrf-name]
  +---rw vrf-name      -> ../config/vrf-name
  +---rw config
  | +---rw vrf-name?   -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
  | +---rw enable     boolean {feature-list:HAVE_SSH_SERVER}?
  | +---rw port?      uint32 {feature-list:HAVE_SSH_SERVER}?
  | +---rw session-limit?  uint8 {feature-list:HAVE_SSH_SERVER}?
  | +---rw max-login-attempts?  uint8 {feature-list:HAVE_SSH_SERVER}?
  +---ro state
  | +---ro vrf-name?   -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
  | +---ro enable     boolean {feature-list:HAVE_SSH_SERVER}?
  | +---ro port?      uint32 {feature-list:HAVE_SSH_SERVER}?
  | +---ro session-limit?  uint8 {feature-list:HAVE_SSH_SERVER}?
  | +---ro max-login-attempts?  uint8 {feature-list:HAVE_SSH_SERVER}?
  +---rw encryption-algorithms {feature-list:HAVE_SSH_SERVER}?
  +---rw config
  | +---rw aes128-ctr?   empty
  | +---rw aes192-ctr?   empty
  | +---rw aes256-ctr?   empty
  | +---rw aes128-cbc?   empty
  | +---rw aes192-cbc?   empty
  | +---rw aes256-cbc?   empty
  | +---rw triple-des-cbc?  empty
  +---ro state

```

```

    +---ro aes128-ctr?      empty
    +---ro aes192-ctr?     empty
    +---ro aes256-ctr?     empty
    +---ro aes128-cbc?     empty
    +---ro aes192-cbc?     empty
    +---ro aes256-cbc?     empty
    +---ro triple-des-cbc? empty

```

```

augment /ipi-user-management:user-management/ipi-user-management:users/ipi-user-
management:user:

```

```

+---rw ssh-keys
  +---rw config
  | +---rw public-key*   ipi-ssh-types:ssh_public_key_t
  +---ro state
    +---ro public-key*   ipi-ssh-types:ssh_public_key_t
    +---ro rsa-key?      ipi-ssh-types:ssh_public_key_t
    +---ro dsa-key?      ipi-ssh-types:ssh_public_key_t
    +---ro fingerprint-rsa? ipi-ssh-types:ssh_public_key_t
    +---ro fingerprint-dsa? ipi-ssh-types:ssh_public_key_t

```

```

rpcs:

```

```

+---x ssh-terminal-debug-on {feature-list:HAVE_HOSTPD}?
+---x ssh-terminal-debug-off {feature-list:HAVE_HOSTPD}?
+---x ssh-clear-hosts {feature-list:HAVE_HOSTPD}?
+---x ssh-generate-server-dsa-key {feature-list:HAVE_SSH_SERVER}?
| +---w input
|   +---w vrf-name?   string
|   +---w force?      boolean
+---x ssh-generate-server-rsa-key {feature-list:HAVE_SSH_SERVER}?
| +---w input
|   +---w length?     uint32
|   +---w vrf-name?   string
|   +---w force?      boolean
+---x ssh-generate-server-ecdsa-key {feature-list:HAVE_SSH_SERVER}?
| +---w input
|   +---w length?     ipi-ssh-types:ssh_ecdsa_key_len_t
|   +---w vrf-name?   string
|   +---w force?      boolean
+---x ssh-generate-server-ed25519-key {feature-list:HAVE_SSH_SERVER}?
| +---w input
|   +---w vrf-name?   string
|   +---w force?      boolean
+---x ssh-clear-server-keys {feature-list:HAVE_SSH_SERVER}?
| +---w input
|   +---w type?       ipi-ssh-types:ssh_host_key_type_t
|   +---w vrf-name?   string
+---x ssh-generate-user-rsa-key {feature-list:HAVE_SSH_SERVER}?
| +---w input
|   +---w user-name   string
|   +---w length?     uint32
|   +---w force?      boolean

```



```

+---x ssh-generate-user-dsa-key {feature-list:HAVE_SSH_SERVER}?
| +---w input
|   +---w user-name      string
|   +---w force?         boolean
+---x ssh-clear-user-keys {feature-list:HAVE_SSH_SERVER}?
  +---w input
    +---w user-name      string

```

module: ipi-streaming-telemetry

```

+--rw telemetry-system
  +--rw streaming-telemetry
  | +--rw config
  | | +--rw feature-enabled?  empty
  | +--ro state
  | | +--ro feature-enabled?  empty
  | +--rw debug
  |   +--rw config
  |   | +--rw gnmi-debug?     empty
  |   | +--rw gnmi-severity?  cml-data-types:cml_gnmi_debug_severity_t
  |   +--ro state
  |   | +--ro gnmi-debug?     empty
  |   | +--ro gnmi-severity?  cml-data-types:cml_gnmi_debug_severity_t
  +--ro dynamic-subscriptions
    +--ro dynamic-subscription* [id]
      +--ro id                    -> ../state/id
      +--ro state
      | +--ro id?                  uint64
      | +--ro client-address?     string
      | +--ro sample-interval?    uint64
      | +--ro encoding?           cml-data-types:cml_data_encode_t
      +--ro sensor-paths
        +--ro sensor-path* [path]
          +--ro path                -> ../state/path
          +--ro state
            +--ro path?            string

```

module: ipi-synce

```

+--rw synce {feature-list:HAVE_SYNCED}?
  +--rw globals
  | +--rw config!
  | | +--rw enable                empty
  | | +--rw network-option?       ipi-synce-types:synce_sync_option_t
  | | +--rw clock-selection-mode? ipi-synce-types:synce_clk_selection_mode_t

```

```

| | +--rw dp113-select-10mhz-in? empty
| | +--rw holdover-timer? uint16
| +--ro state
|   +--ro enable empty
|   +--ro network-option? ipi-synce-types:synce_sync_option_t
|   +--ro clock-selection-mode? ipi-synce-types:synce_clk_selection_mode_t
|   +--ro dp113-select-10mhz-in? empty
|   +--ro holdover-timer? uint16
|   +--ro equipment-clock? string
|   +--ro locked-interface? string
|   +--ro esmc-state? ipi-synce-types:synce_esmc_state_t
|   +--ro is-source-selected? ipi-synce-types:synce_is_src_selected_t
|   +--ro quality-level? string
|   +--ro current-clock-state? ipi-synce-types:synce_clock_state_t
|   +--ro dp11-clock-state? ipi-synce-types:synce_clock_state_t
|   +--ro state-duration? ipi-synce-types:synce_uptime_t
|   +--ro selected-clock-src-id? uint32
+--rw interfaces
| +--rw interface* [name]
|   +--rw name -> ../config/name
|   +--rw config!
|     | +--rw name? -> /ipi-interface:interfaces/interface/name
|     | +--rw enable empty
|     | +--rw synchronous-mode? ipi-synce-types:synce_mode_option_t
|     | +--rw input-source-priority? uint8
|     | +--rw is-output-source? boolean
|     | +--rw wait-to-restore-timer? uint8
|     | +--rw vlan-id? uint16
|     | +--rw hold-off-timer? uint16
|     | +--rw quality-level? string
|     | +--rw clock-source-id? uint8
|     | +--rw auto-neg-mode? ipi-synce-types:synce_autoneg_mode_t
|     +--ro state
name |       +--ro name? -> /ipi-interface:interfaces/interface/
|       +--ro enable empty
|       +--ro synchronous-mode? ipi-synce-types:synce_mode_option_t
|       +--ro input-source-priority? uint8
|       +--ro is-output-source? boolean
|       +--ro wait-to-restore-timer? uint8
|       +--ro vlan-id? uint16
|       +--ro hold-off-timer? uint16
|       +--ro quality-level? string
|       +--ro clock-source-id? uint8
|       +--ro auto-neg-mode? ipi-synce-types:synce_autoneg_mode_t
|       +--ro esmc-state? ipi-synce-types:synce_esmc_state_t
types:synce_is_src_selected_t |       +--ro is-source-selected? ipi-synce-
|       +--ro esmc-received? uint64
|       +--ro esmc-sent? uint64
|       +--ro quality-level-received-esmc? string

```

```

|         +---ro operational-quality-level?      string
|         +---ro configured-quality-level?      string
|         +---ro interface-config-priority?    uint8
|         +---ro signal-fail?                  ipi-synce-types:synce_is_sf_t
|         +---ro external-command?             ipi-synce-types:synce_external_cmds_t
|         +---ro wtr-timer-status?             ipi-synce-
types:synce_is_timer_running_t
|         +---ro hold-off-timer-status?        ipi-synce-
types:synce_is_timer_running_t
|         +---ro link-state?                   ipi-synce-types:synce_link_state_t
+---rw external-interfaces
| +---rw external-interface* [external-synce-interface]
|   +---rw external-synce-interface    -> ../config/external-synce-interface
|   +---rw config
|     | +---rw external-synce-interface?    ipi-synce-
types:synce_external_interface_t
|     | +---rw synchronous-mode?           ipi-synce-types:synce_mode_option_t
|     | +---rw input-source-priority?      uint8
|     | +---rw wait-to-restore-timer?      uint8
|     | +---rw hold-off-timer?            uint16
|     | +---rw quality-level?              string
|     +---ro state
|       +---ro external-synce-interface?    ipi-synce-
types:synce_external_interface_t
|       +---ro synchronous-mode?           ipi-synce-types:synce_mode_option_t
|       +---ro input-source-priority?      uint8
|       +---ro wait-to-restore-timer?      uint8
|       +---ro hold-off-timer?            uint16
|       +---ro quality-level?              string
|       +---ro esmc-state?                 ipi-synce-types:synce_esmc_state_t
|       +---ro is-source-selected?         ipi-synce-
types:synce_is_src_selected_t
|       +---ro esmc-received?              uint64
|       +---ro esmc-sent?                  uint64
|       +---ro quality-level-received-esmc? string
|       +---ro operational-quality-level?   string
|       +---ro configured-quality-level?    string
|       +---ro interface-config-priority?  uint8
|       +---ro signal-fail?                ipi-synce-types:synce_is_sf_t
|       +---ro external-command?           ipi-synce-types:synce_external_cmds_t
|       +---ro wtr-timer-status?           ipi-synce-
types:synce_is_timer_running_t
|       +---ro hold-off-timer-status?      ipi-synce-
types:synce_is_timer_running_t
|       +---ro link-state?                 ipi-synce-types:synce_link_state_t
+---rw debug
  +---rw config
  | +---rw options?    ipi-synce-types:synce_debug_t
  +---ro state
    +---ro options?          ipi-synce-types:synce_debug_t
    +---ro terminal-debug-status? ipi-synce-types:synce_debug_t

```

```
rpcs:
  +---x clear-synce-stats {feature-list:HAVE_SYNCED}?
  | +---w input
  |   +---w interface-name    string
  +---x synce-terminal-debug-on {feature-list:HAVE_SYNCED}?
  | +---w input
  |   +---w debug-options     ipi-synce-types:synce_debug_t
  +---x synce-terminal-debug-off {feature-list:HAVE_SYNCED}?
  | +---w input
  |   +---w debug-options     ipi-synce-types:synce_debug_t
```

notifications:

```
+---n synce-clock-status {feature-list:HAVE_SYNCED}?
| +--ro severity?       cml-data-types:cml_notif_severity_t
| +--ro eventClass?    cml-data-types:cml_notif_class_t
| +--ro message?       string
+---n synce-clock-state-change-notify {feature-list:HAVE_SYNCED}?
| +--ro severity?      cml-data-types:cml_notif_severity_t
| +--ro eventClass?   cml-data-types:cml_notif_class_t
| +--ro previous-clock-state? ipi-synce-types:synce_clock_state_t
| +--ro current-clock-state? ipi-synce-types:synce_clock_state_t
+---n synce-clock-state-transition-locked-interface {feature-list:HAVE_SYNCED}?
  +--ro severity?      cml-data-types:cml_notif_severity_t
  +--ro eventClass?   cml-data-types:cml_notif_class_t
  +--ro previous-clock-state? ipi-synce-types:synce_clock_state_t
  +--ro current-clock-state? ipi-synce-types:synce_clock_state_t
  +--ro locked-interface? string
```

module: ipi-sys-mgmt

```
rpcs:
  +---x sys-shutdown {feature-list:HAVE_PSERVD}?
  | +---w input
  |   +---w save-config    boolean
```

module: ipi-sys-notifications

notifications:

```
+---n lock-forcibly-released
| +--ro severity?       cml-data-types:cml_notif_severity_t
| +--ro eventClass?    cml-data-types:cml_notif_class_t
| +--ro message?       string
+---n config-sync-completion-status
| +--ro severity?      cml-data-types:cml_notif_severity_t
```

```

| +--ro eventClass?    cml-data-types:cml_notif_class_t
| +--ro message?      string
+---n config-change
| +--ro message?      string
+---n system-shutdown-or-reload
  +--ro severity?     cml-data-types:cml_notif_severity_t
  +--ro eventClass?   cml-data-types:cml_notif_class_t
  +--ro message?      string

```

module: ipi-sys-update

```

+--rw system-update
  +--rw docker
    | +--ro images
    | | +--ro image* [name]
    | |   +--ro name      -> ../state/name
    | |   +--ro state
    | |   +--ro name?     string
    | +--ro info
    | | +--ro state
    | |   +--ro version?  string
    | |   +--ro status?  string
    | +--ro download-status
    |   +--ro state
    |   +--ro inprogress? boolean
+--ro installers
| +--ro installer* [name]
|   +--ro name      -> ../state/name
|   +--ro state
|   +--ro name?     string
+--ro system-update-details
  +--ro state
    +--ro previous-version?    cml-data-types:cml_line_t
    +--ro current-version?     cml-data-types:cml_line_t
    +--ro last-upgraded-time?   cml-data-types:cml_line_t
    +--ro auto-rollback-end-time? cml-data-types:cml_line_t

```

rpcs:

```

+---x sys-update-install {feature-list:HAVE_PSERVD,feature-list:NOT_HAVE_TIBIT}?
| +---w input
|   +---w installer-name      string
|   +---w ignore-feature-check boolean
+---x sys-update-uninstall {feature-list:HAVE_PSERVD,feature-list:NOT_HAVE_TIBIT}?
+---x sys-update-get {feature-list:HAVE_PSERVD,feature-list:NOT_HAVE_TIBIT}?
| +---w input
|   +---w source-interface    string
|   +---w source-ip?         inet:ip-address

```

```

|     +---w url                string
|     +---w known-hosts-add?   boolean
+---x sys-update-delete {feature-list:HAVE_PSERVD,feature-list:NOT_HAVE_TIBIT}?
|   +---w input
|     +---w image-name        string
+---x sys-update-cancel-download {feature-list:HAVE_PSERVD,feature-
list:NOT_HAVE_TIBIT}?
+---x sys-container-install {feature-list:HAVE_PSERVD,feature-list:NOT_HAVE_TIBIT}?
|   +---w input
|     +---w type                ipi-sys-update-types:system_container_type_t
|     +---w upgrade-type        ipi-sys-update-types:system_container_upgrade_t
|     +---w file                string
+---x sys-container-uninstall {feature-list:HAVE_PSERVD,feature-
list:NOT_HAVE_TIBIT}?
|   +---w input
|     +---w type                ipi-sys-update-types:system_container_type_t
|     +---w un-install          boolean
+---x sys-container-boot {feature-list:HAVE_PSERVD,feature-list:NOT_HAVE_TIBIT}?
|   +---w input
|     +---w type                ipi-sys-update-types:system_container_type_t
|     +---w boot-type           ipi-sys-update-types:system_container_boot_t
+---x sys-container-get {feature-list:HAVE_PSERVD,feature-list:NOT_HAVE_TIBIT}?
|   +---w input
|     +---w type                ipi-sys-update-types:system_container_type_t
|     +---w url                 string
|     +---w source-interface    string
+---x sys-container-remove {feature-list:HAVE_PSERVD,feature-list:NOT_HAVE_TIBIT}?
|   +---w input
|     +---w type                ipi-sys-update-types:system_container_type_t
|     +---w file                string
+---x sys-container-verify {feature-list:HAVE_PSERVD,feature-list:NOT_HAVE_TIBIT}?
|   +---w input
|     +---w type                ipi-sys-update-types:system_container_type_t
|     +---w image               string
|     +---w signature           string
+---x sys-update-verify {feature-list:HAVE_PSERVD,feature-list:NOT_HAVE_TIBIT}?
|   +---w input
|     +---w image               string
+---x sys-container-cancel-download {feature-list:HAVE_PSERVD,feature-
list:NOT_HAVE_TIBIT}?

notifications:
+---n sys-update-installation-status
|   +---ro severity?            cml-data-types:cml_notif_severity_t
|   +---ro eventClass?         cml-data-types:cml_notif_class_t
|   +---ro message?            string
+---n sys-update-download-status
|   +---ro severity?            cml-data-types:cml_notif_severity_t
|   +---ro eventClass?         cml-data-types:cml_notif_class_t
|   +---ro message?            string
+---n sys-container-download-status

```

```

| +--ro severity?      cml-data-types:cml_notif_severity_t
| +--ro eventClass?   cml-data-types:cml_notif_class_t
| +--ro message?      string
+---n sys-update-verify-status
  +--ro severity?     cml-data-types:cml_notif_severity_t
  +--ro eventClass?   cml-data-types:cml_notif_class_t
  +--ro message?      string

```

module: ipi-system

```

+--rw system-info
  +--rw config
  | +--rw hostname?   string
  +--ro state
  | +--ro hostname?   string
  | +--ro software-version? string
  | +--ro system-uptime? system_time_duration
  | +--ro boot-time?   uint64
  | +--ro current-datetime? yang:date-and-time
  +--rw clock
  +--rw config
  | +--rw timezone-name? system_timezone_name_t
  +--ro state
  | +--ro timezone-name? system_timezone_name_t

```

module: ipi-tacacs

```

+--rw tacacs
  +--rw vrfs
  | +--rw vrf* [vrf-name] {feature-list:HAVE_HOSTPD,feature-list:HAVE_AAA,feature-
list:HAVE_TACACS_CLIENT}?
  |   +--rw vrf-name      -> ../config/vrf-name
  |   +--rw config
  |   | +--rw vrf-name?    -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
  |   | +--rw feature-enable    empty
  |   | +--rw timeout?         uint8
  |   | +--rw key-type?        ipi-tacacs-types:tacacs_hostp_key_type_t
  |   | +--rw secret-key-string? string
  |   +--ro state
  |   | +--ro vrf-name?        -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name
  |   | +--ro feature-enable    empty
  |   | +--ro timeout?         uint8
  |   | +--ro key-type?        ipi-tacacs-types:tacacs_hostp_key_type_t
  |   | +--ro secret-key-string? string

```

```

    |      +---rw remote-servers
    |      +---rw server* [host-address] {feature-list:HAVE_HOSTPD,feature-
list:HAVE_AAA,feature-list:HAVE_TACACS_CLIENT}?
    |      +---rw host-address    -> ../config/host-address
    |      +---rw config
    |      |      +---rw host-address?      cml-data-types:cml_hostname_t
    |      |      +---rw sequence-number    uint8
    |      |      +---rw port?              uint32
    |      |      +---rw timeout?           uint32
    |      |      +---rw key-type?          ipi-tacacs-types:tacacs_hostp_key_type_t
    |      |      +---rw secret-key-string? string
    |      +---ro state
    |      +---ro host-address?              cml-data-
types:cml_hostname_t
    |      +---ro sequence-number            uint8
    |      +---ro port?                      uint32
    |      +---ro timeout?                   uint32
    |      +---ro key-type?                  ipi-tacacs-
types:tacacs_hostp_key_type_t
    |      +---ro secret-key-string?         string
    |      +---ro last-successful-authentication-time? yang:date-and-time
    |      +---ro counters
    |      +---ro successful-authentications? yang:counter64
    |      +---ro authentication-failures?   yang:counter64
    |      +---ro connection-failures?       yang:counter64
+---rw debug
    +---rw config
    | +---rw enable?    empty
    +---ro state
    +---ro enable?      empty
    +---ro terminal-debug-status? cml-data-types:cml_on_off_t

rpcs:
+---x clear-all-tacacs-server-counters {feature-list:HAVE_HOSTPD}?
| +---w input
| +---w vrf-name    string
+---x clear-tacacs-server-host-counters {feature-list:HAVE_HOSTPD}?
| +---w input
| +---w hostname    cml-data-types:cml_hostname_t
| +---w vrf-name    string
+---x tacacs-terminal-debug-on {feature-list:HAVE_HOSTPD}?
+---x tacacs-terminal-debug-off {feature-list:HAVE_HOSTPD}?

```

module: ipi-telnet

```

+---rw telnet-server
    +---rw debug
    | +---rw config
    | | +---rw enable?    empty

```



```

| +--ro state
|   +--ro enable?                empty
|   +--ro terminal-debug-status?  cml-data-types:cml_on_off_t
+--rw vrfs
  +--rw vrf* [vrf-name]
    +--rw vrf-name    -> ../config/vrf-name
    +--rw config
      | +--rw vrf-name?      -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name
      | +--rw enable        boolean
      | +--rw port?         uint32 {feature-list:HAVE_TELNET_SERVER}?
      | +--rw session-limit? uint8 {feature-list:HAVE_TELNET_SERVER}?
      +--ro state
        +--ro vrf-name?     -> /ipi-network-instance:network-instances/network-
instance/ipi-vrf:vrf/config/vrf-name
        +--ro enable        boolean
        +--ro port?         uint32 {feature-list:HAVE_TELNET_SERVER}?
        +--ro session-limit? uint8 {feature-list:HAVE_TELNET_SERVER}?

rpcs:
+---x telnet-terminal-debug-on {feature-list:HAVE_HOSTPD}?
+---x telnet-terminal-debug-off {feature-list:HAVE_HOSTPD}?

```

module: ipi-tfo

```

+--rw trigger-failover
  +--rw config
    | +--rw admin-status?  cml-data-types:cml_enable_disable_t
  +--ro state
    | +--ro admin-status?  cml-data-types:cml_enable_disable_t
  +--rw interfaces
    | +--rw interface* [name]
    |   +--rw name          -> ../config/name
    |   +--rw config
    |     | +--rw name?      -> /ipi-interface:interfaces/interface/name
    |     | +--rw link-type? ipi-tfo-types:tfo_fog_link_type_t
    |     +--ro state
    |       | +--ro name?    -> /ipi-interface:interfaces/interface/name
    |       | +--ro link-type? ipi-tfo-types:tfo_fog_link_type_t
    |     +--rw tfo-groups
    |       +--rw tfo-group* [group-id]
    |         +--rw group-id  -> ../config/group-id
    |         +--rw config
    |           | +--rw group-id?    uint32
    |           | +--rw group-type   ipi-tfo-types:tfo_fog_group_type_t
    |           +--ro state
    |             +--ro group-id?    uint32
    |             +--ro group-type   ipi-tfo-types:tfo_fog_group_type_t

```

```

+--rw failover-groups
  +--rw failover-group* [group-id]
    +--rw group-id    -> ../config/group-id
    +--rw config
      | +--rw group-id?          uint32
      | +--rw admin-status      cml-data-types:cml_enable_disable_t
      | +--rw failover-trigger-count?  uint32
    +--ro state
      | +--ro group-id?          uint32
      | +--ro admin-status      cml-data-types:cml_enable_disable_t
      | +--ro failover-trigger-count?  uint32
      | +--ro cpg-disable-status?  boolean
      | +--ro mpg-disable-status?  boolean
    +--ro counters
      +--ro mpg-link-failure-count?  uint64
      +--ro mpg-link-recover-count?  uint64
      +--ro cpg-auto-disable-count?  uint64
      +--ro cpg-auto-enable-count?   uint64

rpcs:
  +---x tfo-clear-counters-all {feature-list:HAVE_TFO}?
  +---x tfo-clear-fog-counters {feature-list:HAVE_TFO}?
    +---w input
      +---w group-id    uint32

```

module: ipi-time-range

```

+--rw time-ranges
  +--rw time-range* [name]
    +--rw name          -> ../config/name
    +--rw config
      | +--rw name?    string
    +--ro state
      | +--ro name?    string
    +--rw start-time-options
      | +--rw config
      | | +--rw (start-time)?
      | |   +--:(absolute-start-time)
      | |   | +--rw absolute-start-time?  time_range_date_time_t
      | |   +--:(relative-start-time)
      | |   +--rw relative-start-time?    time_range_relative_time_t
      | +--ro state
      |   +--ro (start-time)?
      |   +--:(absolute-start-time)
      |   | +--ro absolute-start-time?    time_range_date_time_t
      |   +--:(relative-start-time)
      |   +--ro relative-start-time?     time_range_relative_time_t
    +--rw end-time-options

```

```

| +--rw config
| | +--rw (end-time)?
| |   +--:(absolute-end-time)
| |   | +--rw absolute-end-time?   time_range_date_time_t
| |   +--:(relative-end-time)
| |     +--rw relative-end-time?   string
| +--ro state
|   +--ro (end-time)?
|   +--:(absolute-end-time)
|   | +--ro absolute-end-time?   time_range_date_time_t
|   +--:(relative-end-time)
|     +--ro relative-end-time?   string
+--rw frequency-options
  +--rw config
  | +--rw frequency?   time_range_frequency_t
  +--ro state
    +--ro frequency?   time_range_frequency_t

```

module: ipi-twamp

```

+--rw twamp
  +--rw light
  | +--rw control
  | | +--rw config!
  | | | +--rw enable           empty
  | | | +--rw administrative-state? cml-data-types:cml_enable_disable_t
  | | +--ro state
  | | | +--ro enable           empty
  | | | +--ro administrative-state? cml-data-types:cml_enable_disable_t
  | | +--rw test-sessions
  | |   +--rw test-session* [session-name vrf-name]
  | |     +--rw session-name   -> ../config/session-name
  | |     +--rw vrf-name       -> ../config/vrf-name
  | |     +--rw config
  | |       | +--rw session-name?   string
  | |       | +--rw sender-ip-address ipi-twamp-types:twamp_hostname_t
  | |       | +--rw sender-udp-port  ipi-twamp-types:twamp_udp_port_t
  | |       | +--rw reflector-ip-address ipi-twamp-types:twamp_hostname_t
  | |       | +--rw reflector-udp-port ipi-twamp-types:twamp_udp_port_t
  | |       | +--rw dscp-value?     ipi-twamp-types:twamp_dscp_t
  | |       | +--rw vrf-name?       string
  | |     +--ro state
  | |       +--ro session-name?     string
  | |       +--ro sender-ip-address ipi-twamp-types:twamp_hostname_t
  | |       +--ro sender-udp-port   ipi-twamp-types:twamp_udp_port_t
  | |       +--ro reflector-ip-address ipi-twamp-types:twamp_hostname_t

```

```

| |      +---ro reflector-udp-port      ipi-twamp-types:twamp_udp_port_t
| |      +---ro dscp-value?             ipi-twamp-types:twamp_dscp_t
| |      +---ro vrf-name?              string
| |      +---ro start-time?            yang:date-and-time
| |      +---ro elapsed-time?          uint32
| |      +---ro statistics
| |          +---ro packets-sent?      yang:counter64
| |          +---ro packets-received?  yang:counter64
| |          +---ro packet-loss?       decimal64
| |          +---ro round-trip-delay
| |              | +---ro minimum?    uint64
| |              | +---ro maximum?    uint64
| |              | +---ro average?    uint64
| |          +---ro forward-delay
| |              | +---ro minimum?    uint64
| |              | +---ro maximum?    uint64
| |              | +---ro average?    uint64
| |          +---ro reverse-delay
| |              | +---ro minimum?    uint64
| |              | +---ro maximum?    uint64
| |              | +---ro average?    uint64
| |          +---ro round-trip-delay-variation
| |              | +---ro minimum?    uint64
| |              | +---ro maximum?    uint64
| |              | +---ro average?    uint64
| |          +---ro forward-delay-variation
| |              | +---ro minimum?    uint64
| |              | +---ro maximum?    uint64
| |              | +---ro average?    uint64
| |          +---ro reverse-delay-variation
| |              +---ro minimum?    uint64
| |              +---ro maximum?    uint64
| |              +---ro average?    uint64
| +---rw session-reflector
|     +---rw config!
|         | +---rw enable              empty
|         | +---rw administrative-state? cml-data-types:cml_enable_disable_t
|     +---ro state
|         | +---ro enable              empty
|         | +---ro administrative-state? cml-data-types:cml_enable_disable_t
|     +---rw sessions
|         +---rw session* [name vrf-name]
|             +---rw name              -> ../config/name
|             +---rw vrf-name          -> ../config/vrf-name
|         +---rw config
|             | +---rw name?            string
|             | +---rw reflector-ip-address ipi-twamp-types:twamp_hostname_t
|             | +---rw reflector-udp-port ipi-twamp-types:twamp_udp_port_t
|             | +---rw sender-ip-address ipi-twamp-types:twamp_hostname_t
|             | +---rw sender-udp-port   ipi-twamp-
types:twamp_ref_src_udp_port_t

```

```

|         | +--rw vrf-name?           string
|         +--ro state
|           +--ro name?               string
|           +--ro reflector-ip-address ipi-twamp-types:twamp_hostname_t
|           +--ro reflector-udp-port  ipi-twamp-types:twamp_udp_port_t
|           +--ro sender-ip-address   ipi-twamp-types:twamp_hostname_t
|           +--ro sender-udp-port     ipi-twamp-
types:twamp_ref_src_udp_port_t
|           +--ro vrf-name?           string
+--rw debug
| +--rw config
| | +--rw options?   ipi-twamp-types:twamp_debug_t
| | +--ro state
| |   +--ro options?               ipi-twamp-types:twamp_debug_t
| |   +--ro terminal-debug-status? ipi-twamp-types:twamp_debug_t
+--rw server
| +--rw config
| | +--rw port?               ipi-twamp-types:twamp_udp_port_t
| | +--rw max-connection-duration? uint8
| | +--rw max-connections?      uint8
| | +--rw max-connections-per-client? uint8
| | +--rw maximum-sessions?     uint8
| | +--rw maximum-sessions-per-connection? uint8
| | +--rw inactivity-timeout?   uint8
| | +--rw vrf-name*            -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
| | +--ro state
| | | +--ro port?               ipi-twamp-types:twamp_udp_port_t
| | | +--ro max-connection-duration? uint8
| | | +--ro max-connections?      uint8
| | | +--ro max-connections-per-client? uint8
| | | +--ro maximum-sessions?     uint8
| | | +--ro maximum-sessions-per-connection? uint8
| | | +--ro inactivity-timeout?   uint8
| | | +--ro vrf-name*            -> /ipi-network-instance:network-
instances/network-instance/ipi-vrf:vrf/config/vrf-name
| | | +--ro nb-connections?      yang:counter32
| | | +--ro nb-sessions?         yang:counter32
| | | +--ro nb-running-sessions? yang:counter32
| | +--ro connections
| | | +--ro connection* [connection-id]
| | |   +--ro connection-id      -> ../state/connection-id
| | |   +--ro state
| | |     +--ro connection-id?   uint32
| | |     +--ro client-address?  inet:ip-address
| | |     +--ro client-port?     uint16
| | |     +--ro client-vrf?      string
| | |     +--ro connection-state? string
| | |     +--ro connection-time? yang:date-and-time
| | |     +--ro last-activity-time? yang:date-and-time
| | |     +--ro nb-session-requests? yang:counter32

```

```
| |          +---ro nb-accepted-sessions?  yang:counter32
| +---ro sessions
| |   +---ro session* [session-id]
| |     +---ro session-id    -> ../state/session-id
| |     +---ro state
| |       +---ro session-id?      string
| |       +---ro connection-id?   uint32
| |       +---ro session-state?   string
| |       +---ro sender-address?  inet:ip-address
| |       +---ro sender-port?    uint16
| |       +---ro receiver-address? inet:ip-address
| |       +---ro receiver-port?  uint16
| |       +---ro receiver-vrf?   string
| |       +---ro start-time?     yang:date-and-time
| |       +---ro timeout?       uint32
| +---rw admin
|   +---rw config!
|   |   +---rw enable                empty
|   |   +---rw administrative-state? cml-data-types:cml_enable_disable_t
|   +---ro state
|     +---ro enable                empty
|     +---ro administrative-state? cml-data-types:cml_enable_disable_t
+---rw client
  +---rw config!
  |   +---rw enable                empty
  |   +---rw maximum-sessions?    uint8
  |   +---rw maximum-connections? uint8
  |   +---rw maximum-sessions-per-connection? uint8
  +---ro state
  |   +---ro enable                empty
  |   +---ro maximum-sessions?    uint8
  |   +---ro maximum-connections? uint8
  |   +---ro maximum-sessions-per-connection? uint8
  +---rw connections
    +---rw connection* [connection-name vrf-name]
      +---rw connection-name    -> ../config/connection-name
      +---rw vrf-name           -> ../config/vrf-name
      +---rw config
      |   +---rw connection-name?  string
      |   +---rw server-address?   ipi-twamp-types:twamp_hostname_t
      |   +---rw server-port?     ipi-twamp-types:twamp_udp_port_t
      |   +---rw vrf-name?        string
      +---ro state
      |   +---ro connection-name?  string
      |   +---ro server-address?   ipi-twamp-types:twamp_hostname_t
      |   +---ro server-port?     ipi-twamp-types:twamp_udp_port_t
      |   +---ro vrf-name?        string
      |   +---ro client-port?     uint32
      |   +---ro client-address?   inet:ip-address
      |   +---ro connection-time? yang:date-and-time
```

```

| +---ro last-activity-time?      yang:date-and-time
| +---ro connection-state?       string
| +---ro nb-session-requested?   yang:counter32
| +---ro nb-sessions-accepted?   yang:counter32
+---rw sessions
  +---rw session* [session-name]
    +---rw session-name    -> ../config/session-name
    +---rw config
      | +---rw session-name?      string
      | +---rw sender-port?      uint32
      | +---rw receiver-port?    uint32
      | +---rw sender-address?   ipi-twamp-types:twamp_hostname_t
      | +---rw receiver-address? ipi-twamp-types:twamp_hostname_t
      | +---rw start-time?       ipi-twamp-types:twamp_date_time_t
      | +---rw interface-name?   string
    +---ro state
      +---ro session-name?      string
      +---ro sender-port?      uint32
      +---ro receiver-port?    uint32
      +---ro sender-address?   ipi-twamp-types:twamp_hostname_t
      +---ro receiver-address? ipi-twamp-types:twamp_hostname_t
      +---ro start-time?       ipi-twamp-types:twamp_date_time_t
      +---ro interface-name?   string
      +---ro requested-receiver-port? uint32
      +---ro session-id?      string

```

rpcs:

```

+---x twamp-client-start-connection {feature-list:HAVE_TWAMP}?
| +---w input
|   +---w connection-name    string
|   +---w vrf-name?         string
|   +---w packet-count      uint32
+---x twamp-client-stop-connection {feature-list:HAVE_TWAMP}?
| +---w input
|   +---w connection-name    string
|   +---w vrf-name?         string
+---x twamp-client-reset-session {feature-list:HAVE_TWAMP}?
| +---w input
|   +---w connection-name    string
|   +---w session-name      string
|   +---w vrf-name?         string
+---x twamp-test-session-start {feature-list:HAVE_TWAMP}?
| +---w input
|   +---w session-name      string
|   +---w packet-count     uint16
|   +---w packet-interval?  uint16
|   +---w delay-threshold?  uint32
+---x twamp-test-session-stop {feature-list:HAVE_TWAMP}?
| +---w input
|   +---w session-name      string

```

```

+---x twamp-terminal-debug-on {feature-list:HAVE_TWAMP}?
| +---w input
|   +---w terminal-debug-options      ipi-twamp-types:twamp_debug_t
+---x twamp-terminal-debug-off {feature-list:HAVE_TWAMP}?
    +---w input
        +---w terminal-debug-options      ipi-twamp-types:twamp_debug_t

```

notifications:

```

+---n twamp-delay-threshold-breached {feature-list:HAVE_TWAMP}?
  +--ro severity?          cml-data-types:cml_notif_severity_t
  +--ro eventClass?       cml-data-types:cml_notif_class_t
  +--ro session-name?     string
  +--ro vrf-name?         string
  +--ro average?          uint64

```

module: ipi-udld

```

+--rw udld
  +--rw global
  | +--rw config
  | | +--rw enable?          empty
  | | +--rw message-time?   uint8
  | +--ro state
  |   +--ro enable?         empty
  |   +--ro message-time?   uint8
+--rw debug
  | +--rw config
  | | +--rw options?        ipi-udld-types:udld_debug_t
  | +--ro state
  |   +--ro options?        ipi-udld-types:udld_debug_t
  |   +--ro terminal-debug-status? ipi-udld-types:udld_debug_t
+--rw interfaces
  +--rw interface* [name]
  | +--rw name              -> ../config/name
  | +--rw config
  | | +--rw name?          -> /ipi-interface:interfaces/interface/name
  | | +--rw mode?          ipi-udld-types:udld_mode_type_t
  | | +--rw administrative-state? cml-data-types:cml_enable_disable_t
  | +--ro state
  |   +--ro name?          -> /ipi-interface:interfaces/interface/name
  |   +--ro mode?          ipi-udld-types:udld_mode_type_t
  |   +--ro administrative-state? cml-data-types:cml_enable_disable_t
  |   +--ro link-state?    ipi-udld-types:udld_link_state_type_t

```

rpcs:

```

+---x udld-terminal-debug-on {feature-list:HAVE_UDLD}?

```



```

| +---w input
|   +---w terminal-debug-options    ipi-udld-types:udld_debug_t
+---x udld-terminal-debug-off {feature-list:HAVE_UDLD}?
    +---w input
        +---w terminal-debug-options    ipi-udld-types:udld_debug_t

```

module: ipi-unicast-rpf

```

+--rw unicast-rpf {feature-list:HAVE_RPF}?
  +--rw global
    | +--rw config
    | | +--rw enable-route-lookup?      empty
    | | +--rw enable-default-route-check?  empty {feature-list:HAVE_DUNE,feature-
list:HAVE_GLOBAL_URPF_ALLOW_DEFAULT}?
    | +--ro state
    |   +--ro enable-route-lookup?      empty
    |   +--ro enable-default-route-check?  empty {feature-list:HAVE_DUNE,feature-
list:HAVE_GLOBAL_URPF_ALLOW_DEFAULT}?
    +--rw interfaces
      +--rw interface* [name]
        +--rw name          -> ../config/name
        +--rw config
        | +--rw name?              -> /ipi-interface:interfaces/interface/
name
        | +--rw source-reachability-mode  ipi-unicast-rpf-
types:urpf_src_reachability_mode_t
        +--ro state
          +--ro name?              -> /ipi-interface:interfaces/interface/
name
          +--ro source-reachability-mode  ipi-unicast-rpf-
types:urpf_src_reachability_mode_t

```

module: ipi-user-management

```

+--rw user-management
  +--rw debug
    | +--rw config
    | | +--rw enable?    empty
    | +--ro state
    |   +--ro enable?      empty
    |   +--ro terminal-debug-status?  cml-data-types:cml_on_off_t
  +--rw global
    | +--rw config
    | | +--rw disable-default-user?  empty
    | +--ro state
    |   +--ro disable-default-user?  empty

```

```

+--rw users
  +--rw user* [username]
    +--rw username -> ../config/username
    +--rw config
      | +--rw username? string
      | +--rw role? ipi-user-management-
types:user_mgmt_role_types_t
      | +--rw rbac-role? ipi-user-management-
types:user_mgmt_rbac_role_t {feature-list:HAVE_RBAC}?
      | +--rw (password-type)?
      |   +--:(plain-text)
      |   | +--rw password? string
      |   +--:(hashed)
      |   +--rw password-hashed? string
    +--ro state
      +--ro username? string
      +--ro role? ipi-user-management-
types:user_mgmt_role_types_t
      +--ro rbac-role? ipi-user-management-
types:user_mgmt_rbac_role_t {feature-list:HAVE_RBAC}?
      +--ro (password-type)?
      +--:(plain-text)
      | +--ro password? string
      +--:(hashed)
      +--ro password-hashed? string

rpcs:
  +---x user-management-terminal-debug-on {feature-list:HAVE_HOSTPD,feature-
list:HAVE_USER_MGMT}?
  +---x user-management-terminal-debug-off {feature-list:HAVE_HOSTPD,feature-
list:HAVE_USER_MGMT}?

```

module: ipi-user-session-management

```

+--rw user-session
  +--rw line-console
    | +--rw console* [console-id]
    |   +--rw console-id -> ../config/console-id
    |   +--rw config
    |     | +--rw privilege-level? uint8
    |     | +--rw command-history-max-limit? uint32
    |     | +--rw console-id? ipi-user-session-management-
types:line_console_id_t
    |     +--ro state
    |     | +--ro privilege-level? uint8
    |     | +--ro command-history-max-limit? uint32
    |     | +--ro console-id? ipi-user-session-management-
types:line_console_id_t
    |     +--rw timeout

```

```

|         +---rw config!
|         | +---rw minutes      uint32
|         | +---rw seconds?    uint32
|         +---ro state
|             +---ro minutes      uint32
|             +---ro seconds?    uint32
+---rw line-vty
| +---rw vty* [vty-id]
|   +---rw vty-id      -> ../config/vty-id
|   +---rw config
|   | +---rw privilege-level?    uint8
|   | +---rw command-history-max-limit?  uint32
|   | +---rw vty-id?            cml-data-types:cml_range_t
|   +---ro state
|   | +---ro privilege-level?    uint8
|   | +---ro command-history-max-limit?  uint32
|   | +---ro vty-id?            cml-data-types:cml_range_t
|   +---rw timeout
|       +---rw config!
|       | +---rw minutes      uint32
|       | +---rw seconds?    uint32
|       +---ro state
|           +---ro minutes      uint32
|           +---ro seconds?    uint32
+---ro sessions
  +---ro session* [id]
    +---ro id      -> ../state/id
    +---ro state
      +---ro id?          string
      +---ro line?       string
      +---ro user-name?  string
      +---ro client-type? ipi-user-session-types:user_session_user_type_t
      +---ro idle-time?  string
      +---ro process-identifier?  uint32
      +---ro type?       ipi-user-session-types:user_session_type_t
      +---ro user-role?  ipi-user-session-
types:user_session_user_role_type_t
      +---ro remote-ip?  string

rpcs:
+---x clear-line {feature-list:HAVE_IMI}?
+---w input
  +---w line-name  string

```

module: ipi-vlan

```

+--rw vlan-classifier {feature-list:HAVE_VLAN_CLASS}?
| +--rw classifier-rules
| | +--rw classifier-rule* [rule-id]
| |   +--rw rule-id      -> ../config/rule-id
| |   +--rw config
| |     | +--rw rule-id?  uint16
| |     +--ro state
| |       | +--ro rule-id? uint16
| |       +--rw rule-criteria
| |         +--rw config
| |           | +--rw mac-address?  cml-data-types:cml_mac_addr_t
| |           | +--rw ipv4-address? cml-data-types:cml_ipv4_prefix_t
| |           | +--rw ether-type?   ipi-vlan-types:vlan_classifier_ethertype_t
| |           +--ro state
| |             +--ro mac-address?  cml-data-types:cml_mac_addr_t
| |             +--ro ipv4-address? cml-data-types:cml_ipv4_prefix_t
| |             +--ro ether-type?   ipi-vlan-types:vlan_classifier_ethertype_t
| +--rw classifier-groups
| | +--rw classifier-group* [group-id rule-id]
| |   +--rw group-id      -> ../config/group-id
| |   +--rw rule-id       -> ../config/rule-id
| |   +--rw config
| |     | +--rw group-id?  uint8
| |     | +--rw rule-id?   -> /vlan-classifier/classifier-rules/classifier-rule/
rule-id
| |     +--ro state
| |       +--ro group-id?  uint8
| |       +--ro rule-id?   -> /vlan-classifier/classifier-rules/classifier-rule/
rule-id
| +--rw ports
|   +--rw port* [port-name group-id]
|     +--rw port-name      -> ../config/port-name
|     +--rw group-id       -> ../config/group-id
|     +--rw config
|       | +--rw port-name?  -> /ipi-interface:interfaces/interface/name
|       | +--rw group-id?   -> /vlan-classifier/classifier-groups/classifier-group/
group-id
|       | +--rw vlan-id      -> /ipi-network-instance:network-instances/network-
instance/ipi-bridge:bridge/vlans/vlan/vlan-id
|       +--ro state
|         +--ro port-name?  -> /ipi-interface:interfaces/interface/name
|         +--ro group-id?   -> /vlan-classifier/classifier-groups/classifier-group/
group-id
|         +--ro vlan-id      -> /ipi-network-instance:network-instances/network-
instance/ipi-bridge:bridge/vlans/vlan/vlan-id
+--rw layer2-global
+--rw config
| +--rw disable-vlan-classifier-feature?  empty {feature-list:HAVE_VLAN_CLASS}?

```

```

| +--rw disable-port-security?          empty
+--ro state
  +--ro disable-vlan-classifier-feature? empty {feature-list:HAVE_VLAN_CLASS}?
  +--ro disable-port-security?          empty

augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance/ipi-bridge:bridge:
+--rw vlans
  +--rw vlan* [vlan-id]
    +--rw vlan-id          -> ../config/vlan-id
    +--rw config
      | +--rw vlan-id?      cml-data-types:cml_range_t
      | +--rw disable-mac-learning? empty
    +--ro state
      | +--ro vlan-id?      cml-data-types:cml_range_t
      | +--ro disable-mac-learning? empty
    +--rw customer-vlan
      | +--rw config
      | | +--rw type?       ipi-vlan-types:cvlan_type_t
      | | +--rw name?       string
      | | +--rw state?      ipi-vlan-types:vlan_state_t
      | +--ro state
      | +--ro type?         ipi-vlan-types:cvlan_type_t
      | +--ro name?         string
      | +--ro state?        ipi-vlan-types:vlan_state_t
      | +--ro operational-status? ipi-vlan-types:vlan_oper_status_t
      | +--ro tagged-interface* string
    +--rw service-vlan {feature-list:HAVE_PROVIDER_BRIDGE}?
      | +--rw config
      | | +--rw type?       ipi-vlan-types:svlan_type_t
      | | +--rw name?       string
      | | +--rw state?      ipi-vlan-types:vlan_state_t
      | +--ro state
      | +--ro type?         ipi-vlan-types:svlan_type_t
      | +--ro name?         string
      | +--ro state?        ipi-vlan-types:vlan_state_t
      | +--ro operational-status? ipi-vlan-types:vlan_oper_status_t
      | +--ro tagged-interface* string
    +--rw private-vlan {feature-list:HAVE_PVLAN}?
      +--rw config!
      | +--rw type          ipi-vlan-types:vlan_pvlan_type_t
      +--ro state
      | +--ro type          ipi-vlan-types:vlan_pvlan_type_t
      +--rw association
        +--rw config
          | +--rw secondary-vlan? cml-data-types:cml_range_t
        +--ro state
          +--ro secondary-vlan? cml-data-types:cml_range_t

augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance/ipi-bridge:bridge:

```

```

    +--rw cvlan-registration-tables {feature-list:HAVE_VLAN,feature-
list:HAVE_PROVIDER_BRIDGE}?
      +--rw cvlan-registration-table* [table-name]
        +--rw table-name      -> ../config/table-name
        +--rw config
          | +--rw table-name?  string
        +--ro state
          | +--ro table-name?  string
        +--rw cvlan-mappings
          +--rw cvlan-mapping* [svlan-id cvlan-id]
            +--rw svlan-id    -> ../config/svlan-id
            +--rw cvlan-id    -> ../config/cvlan-id
            +--rw config
              | +--rw svlan-id?          uint16
              | +--rw cvlan-id?         cml-data-types:cml_range_t
              | +--rw untagged-ep?     ipi-vlan-types:cvlan_config_t
              | +--rw translated-cvlan-id? uint16
              | +--rw cos-to-queue?    -> /ipi-qos:qos/global/map-profile/cos-
to-queue-profiles/cos-to-queue-profile/name {feature-list:HAVE_CUSTOM2_QOS}?
              | +--rw remark-cos?     empty {feature-
list:HAVE_CUSTOM2_QOS,feature-list:HAVE_QOS}?
            +--ro state
              +--ro svlan-id?          uint16
              +--ro cvlan-id?         cml-data-types:cml_range_t
              +--ro untagged-ep?     ipi-vlan-types:cvlan_config_t
              +--ro translated-cvlan-id? uint16
              +--ro cos-to-queue?    -> /ipi-qos:qos/global/map-profile/cos-
to-queue-profiles/cos-to-queue-profile/name {feature-list:HAVE_CUSTOM2_QOS}?
              +--ro remark-cos?     empty {feature-
list:HAVE_CUSTOM2_QOS,feature-list:HAVE_QOS}?

```

module: ipi-vrf

```

augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance:
  +--rw vrf
    +--rw config
      | +--rw vrf-name?          -> /ipi-network-instance:network-instances/
network-instance/instance-name
      | +--rw description?      cml-data-types:cml_line_t
      | +--rw tunnel-select-policy? string {feature-
list:HAVE_SERVICE_MAPPING_OR_HAVE_SRV6}?
      | +--rw router-id?        inet:ipv4-address
      | +--rw evpn-layer3-network-id? uint32 {feature-list:HAVE_BGP_EVPN,feature-
list:HAVE_NVO}?
    +--ro state

```

```

    | +--ro vrf-name?                -> /ipi-network-instance:network-instances/
network-instance/instance-name
    | +--ro description?            cml-data-types:cml_line_t
    | +--ro tunnel-select-policy?   string {feature-
list:HAVE_SERVICE_MAPPING_OR_HAVE_SRV6}?
    | +--ro router-id?              inet:ipv4-address
    | +--ro evpn-layer3-network-id? uint32 {feature-list:HAVE_BGP_EVPN,feature-
list:HAVE_NVO}?
    | +--ro vrf-id?                 uint32
    | +--ro fib-id?                 uint32
+--rw snmp {feature-list:HAVE_SNMP}?
  +--rw config
  | +--rw snmp-context-name?       string
+--ro state
  +--ro snmp-context-name?         string

rpcs:
+---x clear-default-router-id {feature-list:HAVE_L3}?
+---x clear-vrf-router-id {feature-list:HAVE_VRF}?
  +---w input
    +---w vrfName                 string

```

module: ipi-vrrp

```

+--rw vrrp
  +--rw global
  | +--rw config
  | | +--rw disable-virtual-router-mac-address?  empty
  | | +--rw vrrp-v2-compatible?                 empty
  | | +--rw ipv4-exclude-pseudo-header?         empty
  | +--ro state
  | | +--ro disable-virtual-router-mac-address?  empty
  | | +--ro vrrp-v2-compatible?                 empty
  | | +--ro ipv4-exclude-pseudo-header?         empty
  | | +--ro notification-control?               empty
  | +--ro session
  | | +--ro state
  | |   +--ro session-table-maximum?             uint32
  | |   +--ro session-table-size?               uint32
  | |   +--ro ipv4-session-count?               uint32
  | |   +--ro ipv6-session-count?               uint32
  | +--ro new-master
  | | +--ro operational-master-address?         inet:ip-address

```

```

| | +--ro virtual-router-id?          uint8
| | +--ro new-master-reason?         ipi-vrrp-types:vrrp_new_master_reason_t
| | +--ro uptime?                   string
| +--ro protocol-error
| | +--ro operational-master-address? inet:ip-address
| | +--ro virtual-router-id?        uint8
| | +--ro error-reason?             ipi-vrrp-types:vrrp_error_reason_t
| | +--ro uptime?                   string
| +--ro packet-error
| | +--ro error-reason?             ipi-vrrp-types:vrrp_error_reason_t
| +--ro errors
|   +--ro state
|     +--ro checksum-error?          yang:counter64
|     +--ro version-error?          yang:counter64
|     +--ro invalid-virtual-router-id? yang:counter64
+--rw debug
| +--rw config
| | +--rw options?                  ipi-vrrp-types:vrrp_debug_t
| +--ro state
|   +--ro options?                  ipi-vrrp-types:vrrp_debug_t
|   +--ro terminal-debug-status?    ipi-vrrp-types:vrrp_debug_t
+--rw ipv4-instances
| +--rw ipv4-instance* [virtual-router-id]
|   +--rw virtual-router-id        -> ../config/virtual-router-id
|   +--rw config
|     | +--rw virtual-router-id?    uint8
|     +--ro state
|       | +--ro virtual-router-id?  uint8
|     +--rw interfaces
|       +--rw interface* [interface-name]
|         +--rw interface-name      -> ../config/interface-name
|         +--rw config
|           | +--rw interface-name?  -> /ipi-interface:interfaces/
interface/name
|     | +--rw disable-preempt-mode?  empty
|     | +--rw priority?              uint8
|     | +--rw preempt-delay?        uint32
|     | +--rw advertisement-interval? uint16
|     | +--rw disable-accept-mode?   empty
|     | +--rw vrrp-v2-compatible?    empty
|     | +--rw ipv4-exclude-pseudo-header? empty
|     | +--rw authentication-data?   string
|     | +--rw primary-ip-address?    inet:ipv4-address
|     | +--rw mlag-active-standby?   empty {feature-list:HAVE_MLAG}?
|     +--ro state
|       | +--ro interface-name?      -> /ipi-interface:interfaces/
interface/name
|     | +--ro disable-preempt-mode?  empty
|     | +--ro priority?              uint8
|     | +--ro preempt-delay?        uint32
|     | +--ro advertisement-interval? uint16

```



```

|         | +--ro disable-accept-mode?          empty
|         | +--ro vrrp-v2-compatible?          empty
|         | +--ro ipv4-exclude-pseudo-header?  empty
|         | +--ro authentication-data?        string
|         | +--ro primary-ip-address?         inet:ipv4-address
|         | +--ro mlag-active-standby?        empty {feature-list:HAVE_MLAG}?
| +--rw protocol-enable
|   | +--rw config
|   | | +--rw enable?    empty
|   | | +--ro state
|   | |   +--ro enable?  empty
| +--rw virtual-ip
|   | +--rw config!
|   | | +--rw virtual-ip-address    inet:ipv4-address
|   | | +--rw ip-address-owner      boolean
|   | | +--ro state
|   | |   +--ro virtual-ip-address  inet:ipv4-address
|   | |   +--ro ip-address-owner    boolean
| +--rw interfaces-tracking
|   | +--rw interface-tracking* [interface-tracking-name]
|   | | +--rw interface-tracking-name  -> ../config/interface-tracking-
name
|   | |   +--rw config
|   | | | +--rw interface-tracking-name? -> /ipi-interface:interfaces/
interface/name
|   | | | +--rw priority-decrement      uint8
|   | | | +--ro state
|   | | | +--ro interface-tracking-name? -> /ipi-interface:interfaces/
interface/name
|   | | | +--ro priority-decrement      uint8
|   | | | +--ro interface-status?       ipi-vrrp-
types:vrrp_iface_status_t
|   | | |   +--ro interface-down-events? uint32
|   | | +--ro addresses
|   | | | +--ro state
|   | | |   +--ro operational-primary-address?  inet:ipv4-address
|   | | |   +--ro operational-master-address?  inet:ipv4-address
|   | +--ro session-info
|   | | +--ro state
|   | |   +--ro multicast-membership?    ipi-vrrp-types:vrrp_member_state_t
|   | |   +--ro address-family?         ipi-vrrp-types:vrrp_addr_family_t
|   | |   +--ro running-priority?       uint8
|   | |   +--ro virtual-mac-mbyte-word?  cml-data-types:cml_mac_addr_t
|   | |   +--ro administrative-state?    ipi-vrrp-types:vrrp_admin_state_t
|   | |   +--ro init-message-code?      ipi-vrrp-
types:vrrp_init_message_code_t
|   | +--ro reasons
|   | | +--ro state
|   | |   +--ro new-master-reason?      ipi-vrrp-types:vrrp_new_master_reason_t
|   +--ro session-status
|     | +--ro state

```

```

|         |         +---ro vrrp-state?                ipi-vrrp-types:vrrp_session_state_t
|         |         +---ro virtual-address-status?   ipi-vrrp-types:vrrp_ip_status_t
|         +---ro timers
|         |         +---ro state
|         |         |         +---ro switchback-delay-timer?      uint32
|         |         |         +---ro countdown-timer?             uint32
|         |         |         +---ro skew-time?                   uint32
|         |         |         +---ro garp-packet-delay?           uint32
|         |         |         +---ro master-advertise-interval?   uint32
|         |         |         +---ro refresh-rate-interval?       uint32
|         +---ro statistics
|         |         +---ro state
|         |         |         +---ro transitions-to-master?       yang:counter64
|         |         |         +---ro advertise-received?          yang:counter64
|         |         |         +---ro priority-zero-received-packets? yang:counter64
|         |         |         +---ro priority-zero-sent-packets?  yang:counter64
|         |         |         +---ro disconnection-time?          string
|         |         |         +---ro monitored-circuit-up-events?  yang:counter64
|         |         |         +---ro monitored-circuit-down-events? yang:counter64
|         +---ro errors
|         |         +---ro state
|         |         |         +---ro ttl-error-packets?           yang:counter64
|         |         |         +---ro invalid-type-packets?        yang:counter64
|         |         |         +---ro address-list-errors?         yang:counter64
|         |         |         +---ro invalid-authentication-type?  yang:counter64
|         |         |         +---ro authentication-type-mismatch? yang:counter64
|         |         |         +---ro wrong-authentication-password? yang:counter64
|         |         |         +---ro address-mismatch-packets?     yang:counter64
|         |         |         +---ro packet-length-errors?        yang:counter64
|         +---rw objects-tracking {feature-list:HAVE_OBJ_TRACKING}?
|         |         +---rw object-tracking* [tracking-id]
|         |         |         +---rw tracking-id    -> ../config/tracking-id
|         |         |         +---rw config
|         |         |         |         +---rw tracking-id?    uint16
|         |         |         |         +---rw decrement      uint8
|         |         |         +---ro state
|         |         |         |         +---ro tracking-id?    uint16
|         |         |         |         +---ro decrement      uint8
|         |         |         |         +---ro object-status?  ipi-vrrp-types:vrrp_iface_status_t
|         |         |         |         +---ro object-down-events? uint32
+---rw ipv6-instances
+---rw ipv6-instance* [virtual-router-id]
+---rw virtual-router-id    -> ../config/virtual-router-id
+---rw config
| +---rw virtual-router-id?  uint8
+---ro state
| +---ro virtual-router-id?  uint8
+---rw interfaces
+---rw interface* [interface-name]
+---rw interface-name      -> ../config/interface-name

```

```

+--rw config
|   +--rw interface-name?          -> /ipi-interface:interfaces/
interface/name
|   +--rw disable-preempt-mode?    empty
|   +--rw priority?                uint8
|   +--rw preempt-delay?           uint32
|   +--rw advertisement-interval?  uint16
|   +--rw disable-accept-mode?     empty
|   +--rw primary-ip-address?      inet:ipv6-address
+--ro state
|   +--ro interface-name?          -> /ipi-interface:interfaces/
interface/name
|   +--ro disable-preempt-mode?    empty
|   +--ro priority?                uint8
|   +--ro preempt-delay?           uint32
|   +--ro advertisement-interval?  uint16
|   +--ro disable-accept-mode?     empty
|   +--ro primary-ip-address?      inet:ipv6-address
+--rw protocol-enable
|   +--rw config
|   |   +--rw enable?              empty
|   +--ro state
|   |   +--ro enable?              empty
+--rw virtual-ip-addresses {feature-list:HAVE_IPV6}?
|   +--rw virtual-ip-address* [virtual-ip-address]
|   |   +--rw virtual-ip-address   -> ../config/virtual-ip-address
|   |   +--rw config
|   |   |   +--rw virtual-ip-address?  inet:ipv6-address
|   |   |   +--rw ip-address-owner?   boolean
|   |   +--ro state
|   |   |   +--ro virtual-ip-address?  inet:ipv6-address
|   |   |   +--ro ip-address-owner?   boolean
+--rw interfaces-tracking
|   +--rw interface-tracking* [interface-tracking-name]
name
|   |   +--rw interface-tracking-name -> ../config/interface-tracking-
|   |   +--rw config
|   |   |   +--rw interface-tracking-name? -> /ipi-interface:interfaces/
interface/name
|   |   |   +--rw priority-decrement    uint8
|   |   +--ro state
|   |   |   +--ro interface-tracking-name? -> /ipi-interface:interfaces/
interface/name
|   |   |   +--ro priority-decrement    uint8
|   |   |   +--ro interface-status?     ipi-vrrp-
types:vrrp_iface_status_t
|   |   |   +--ro interface-down-events? uint32
+--ro addresses
|   +--ro state
|   |   +--ro operational-primary-ipv6? inet:ipv6-address
|   |   +--ro operational-master-ipv6? inet:ipv6-address
+--ro session-info

```

```

    | +--ro state
  |   +--ro multicast-membership?   ipi-vrrp-types:vrrp_member_state_t
  |   +--ro address-family?        ipi-vrrp-types:vrrp_addr_family_t
  |   +--ro running-priority?       uint8
  |   +--ro virtual-mac-mbyte-word? cml-data-types:cml_mac_addr_t
  |   +--ro administrative-state?   ipi-vrrp-types:vrrp_admin_state_t
  |   +--ro init-message-code?     ipi-vrrp-
types:vrrp_init_message_code_t
  +--ro reasons
  |   +--ro state
  |   +--ro new-master-reason?     ipi-vrrp-types:vrrp_new_master_reason_t
+--ro session-status
  |   +--ro state
  |   +--ro vrrp-state?            ipi-vrrp-types:vrrp_session_state_t
  |   +--ro virtual-address-status? ipi-vrrp-types:vrrp_ip_status_t
+--ro timers
  |   +--ro state
  |   +--ro switchback-delay-timer? uint32
  |   +--ro countdown-timer?       uint32
  |   +--ro skew-time?             uint32
  |   +--ro garp-packet-delay?     uint32
  |   +--ro master-advertise-interval? uint32
  |   +--ro refresh-rate-interval?  uint32
+--ro statistics
  |   +--ro state
  |   +--ro transitions-to-master?  yang:counter64
  |   +--ro advertise-received?    yang:counter64
  |   +--ro priority-zero-received-packets? yang:counter64
  |   +--ro priority-zero-sent-packets? yang:counter64
  |   +--ro disconnection-time?     string
  |   +--ro monitored-circuit-up-events? yang:counter64
  |   +--ro monitored-circuit-down-events? yang:counter64
+--ro errors
  |   +--ro state
  |   +--ro ttl-error-packets?      yang:counter64
  |   +--ro invalid-type-packets?   yang:counter64
  |   +--ro address-list-errors?    yang:counter64
  |   +--ro invalid-authentication-type? yang:counter64
  |   +--ro authentication-type-mismatch? yang:counter64
  |   +--ro wrong-authentication-password? yang:counter64
  |   +--ro address-mismatch-packets? yang:counter64
  |   +--ro packet-length-errors?   yang:counter64
+--rw objects-tracking {feature-list:HAVE_OBJ_TRACKING}?
  +--rw object-tracking* [tracking-id]
  +--rw tracking-id    -> ../config/tracking-id
  +--rw config
  |   +--rw tracking-id?  uint16
  |   +--rw decrement   uint8
  +--ro state
  |   +--ro tracking-id?  uint16
  |   +--ro decrement   uint8

```

```

    +--ro object-status?          ipi-vrrp-types:vrrp_iface_status_t
    +--ro object-down-events?    uint32

```

rpcs:

```

+---x vrrp-snmp-restart {feature-list:HAVE_SNMP}?
+---x vrrp-clear-statistics {feature-list:HAVE_VRRPD}?
+---x vrrp-clear-ipv4-statistics {feature-list:HAVE_VRRPD}?
+---x vrrp-clear-ipv6-statistics {feature-list:HAVE_VRRPD}?
+---x vrrp-clear-session-ipv4-statistics {feature-list:HAVE_VRRPD}?
| +---w input
|   +---w vrrp-id          uint8
|   +---w interface-name  string
+---x vrrp-clear-session-ipv6-statistics {feature-list:HAVE_VRRPD}?
| +---w input
|   +---w vrrp-id          uint8
|   +---w interface-name  string
+---x vrrp-terminal-debug-all-on {feature-list:HAVE_VRRPD}?
+---x vrrp-terminal-debug-all-off {feature-list:HAVE_VRRPD}?
+---x vrrp-terminal-debug-on {feature-list:HAVE_VRRPD}?
| +---w input
|   +---w terminal-debug-options  ipi-vrrp-types:vrrp_debug_t
+---x vrrp-terminal-debug-off {feature-list:HAVE_VRRPD}?
    +---w input
        +---w terminal-debug-options  ipi-vrrp-types:vrrp_debug_t

```

notifications:

```

+---n vrrp-new-master
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro operational-master-address?  inet:ip-address
| +--ro virtual-router-id?  uint8
| +--ro new-master-reason?  ipi-vrrp-types:vrrp_new_master_reason_t
| +--ro uptime?           string
+---n vrrp-protocol-error
| +--ro severity?          cml-data-types:cml_notif_severity_t
| +--ro eventClass?       cml-data-types:cml_notif_class_t
| +--ro operational-master-address?  inet:ip-address
| +--ro virtual-router-id?  uint8
| +--ro error-reason?      ipi-vrrp-types:vrrp_error_reason_t
| +--ro uptime?           string
+---n vrrp-packet-error
    +--ro severity?        cml-data-types:cml_notif_severity_t
    +--ro eventClass?      cml-data-types:cml_notif_class_t
    +--ro error-reason?    ipi-vrrp-types:vrrp_error_reason_t

```

module: ipi-vxlan

```

+--rw vxlan
  +--rw global
    | +--rw config!
    | | +--rw enable-vxlan          empty
    | | +--rw vtep-ipv4?           inet:ipv4-address
    | | +--rw mac-ageing-timer?    uint32
    | | +--rw arp-nd-refresh-timer? uint32 {feature-list:HAVE_BGP_EVPN}?
    | | +--rw mac-address?         cml-data-types:cml_mac_addr_t
    | +--ro state
    |   +--ro enable-vxlan          empty
    |   +--ro vtep-ipv4?           inet:ipv4-address
    |   +--ro mac-ageing-timer?    uint32
    |   +--ro arp-nd-refresh-timer? uint32 {feature-list:HAVE_BGP_EVPN}?
    |   +--ro mac-address?         cml-data-types:cml_mac_addr_t
  +--rw qos-tunnel-mappings
    | +--rw qos-tunnel-mapping* [qos-map-mode traffic-direction] {feature-
list:HAVE_QOS}?
    |   +--rw qos-map-mode         -> ../config/qos-map-mode
    |   +--rw traffic-direction    -> ../config/traffic-direction
    |   +--rw config
    |   | +--rw traffic-direction? ipi-vxlan-types:vxlan_qos_dir_t
    |   | +--rw qos-map-mode?      ipi-vxlan-types:vxlan_qos_global_mode_t
    |   | +--rw profile-name       string
    |   +--ro state
    |     +--ro traffic-direction? ipi-vxlan-types:vxlan_qos_dir_t
    |     +--ro qos-map-mode?      ipi-vxlan-types:vxlan_qos_global_mode_t
    |     +--ro profile-name       string
  +--rw vxlan-tenants
    | +--rw vxlan-tenant* [vxlan-identifier]
    |   +--rw vxlan-identifier     -> ../config/vxlan-identifier
    |   +--rw config
    |   | +--rw vrf-name?          -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_BGP_EVPN}?
    |   | +--rw map-network*       string
    |   | +--rw mac-hold-timer?    int32 {feature-list:HAVE_BGP_EVPN}?
    |   | +--rw tenant-description? string
    |   | +--rw irb-name?         -> /ipi-interface:interfaces/interface/name
{feature-list:HAVE_BGP_EVPN}?
    |   | +--rw vxlan-identifier?  uint32
    |   | +--rw tenant-type?       ipi-vxlan-types:vxlan_tenant_type_t
    |   | +--rw xconnect-identifier? uint32 {feature-list:HAVE_EVPN_VPWS}?
    |   | +--rw tenant-xconnect-type? ipi-vxlan-types:vxlan_tenant_xconnect_type_t
    |   +--ro state
    |     +--ro vrf-name?          -> /ipi-network-instance:network-instances/
network-instance/ipi-vrf:vrf/config/vrf-name {feature-list:HAVE_BGP_EVPN}?
    |     +--ro map-network*       string
    |     +--ro mac-hold-timer?    int32 {feature-list:HAVE_BGP_EVPN}?
    |     +--ro tenant-description? string

```

```

| | | +--ro irb-name? -> /ipi-interface:interfaces/interface/name
{feature-list:HAVE_BGP_EVPN}?
| | | +--ro vxlan-identifier? uint32
| | | +--ro tenant-type? ipi-vxlan-types:vxlan_tenant_type_t
| | | +--ro xconnect-identifier? uint32 {feature-list:HAVE_EVPN_VPWS}?
| | | +--ro tenant-xconnect-type? ipi-vxlan-types:vxlan_tenant_xconnect_type_t
| +--ro route-count-info
| | +--ro state
| | | +--ro total? uint32
| | | +--ro mac-only? uint32
| | | +--ro mac-ipv4? uint32
| | | +--ro mac-ipv6? uint32 {feature-list:HAVE_IPV6}?
| +--ro xconnect-mapping-info {feature-list:HAVE_EVPN_VPWS}?
| | +--ro state
| | | +--ro source-tenant-description? string
| | | +--ro destination-vpws-identifier? uint32
| | | +--ro vlan-id? string
| | | +--ro inner-vlan-id? uint32
| | | +--ro source-interface? string
| | | +--ro destination-interface? string
| | | +--ro vtep-ip-address? inet:ipv4-address
| | | +--ro connection-type? ipi-vxlan-
types:vxlan_tenant_xconnect_connection_type_t
| | | +--ro connection-status? ipi-vxlan-
types:vxlan_tenant_xconnect_connection_status_t
| +--rw irb
| | +--rw config
| | | +--rw irb-advertise-host-route? empty {feature-list:HAVE_BGP_EVPN}?
| | | +--ro state
| | | +--ro irb-advertise-host-route? empty {feature-list:HAVE_BGP_EVPN}?
| +--rw static-tenants
| | +--rw static-tenant* [mac-address]
| | | +--rw mac-address -> ../config/mac-address
| | | +--rw config
| | | | +--rw mac-address? cml-data-types:cml_mac_addr_t
| | | | +--rw remote-vtep-ipv4 inet:ipv4-address
| | | +--ro state
| | | +--ro mac-address? cml-data-types:cml_mac_addr_t
| | | +--ro remote-vtep-ipv4 inet:ipv4-address
| +--ro arp-cache-info* [host-ip]
| | +--ro host-ip -> ../state/host-ip
| | +--ro state
| | | +--ro host-ip? inet:ipv4-address
| | | +--ro host-mac? cml-data-types:cml_mac_addr_t
| | | +--ro host-type? ipi-vxlan-types:vxlan_host_t
| | | +--ro interface-index? uint32
| +--ro nd-cache-info* [host-ip]
| | +--ro host-ip -> ../state/host-ip
| | +--ro state
| | | +--ro host-ip? inet:ipv6-address
| | | +--ro host-mac? cml-data-types:cml_mac_addr_t

```

```

|   |   +---ro host-type?          ipi-vxlan-types:vxlan_host_t
|   |   +---ro interface-index?   uint32
|   +---ro mac-table-info* [mac-address]
|   |   +---ro mac-address        -> ../state/mac-address
|   |   +---ro state
|   |   |   +---ro mac-address?    cml-data-types:cml_mac_addr_t
|   |   +---ro interface-name?    -> /ipi-interface:interfaces/interface/
name
|   |   +---ro vlan-id?            string
|   |   +---ro inner-vlan-id?     uint32
|   |   +---ro vtep-ip-esi?       string
|   |   +---ro host-type?         ipi-vxlan-types:vxlan_host_t
|   |   +---ro host-status?       ipi-vxlan-types:vxlan_host_status_t
|   |   +---ro access-port-description? string
|   +---ro static-host-info* [mac-address host-ipv4]
|   |   +---ro mac-address        -> ../state/mac-address
|   |   +---ro host-ipv4         -> ../state/host-ipv4
|   |   +---ro state
|   |   |   +---ro mac-address?    cml-data-types:cml_mac_addr_t
|   |   |   +---ro static-host-state? ipi-vxlan-types:vxlan_static_host_state_t
|   |   |   +---ro host-ipv4?     inet:ipv4-address
|   +---ro static-host-ipv6-info* [mac-address host-ipv6]
|   |   +---ro mac-address        -> ../state/mac-address
|   |   +---ro host-ipv6         -> ../state/host-ipv6
|   |   +---ro state
|   |   |   +---ro mac-address?    cml-data-types:cml_mac_addr_t
|   |   |   +---ro static-host-state? ipi-vxlan-types:vxlan_static_host_state_t
|   |   |   +---ro host-ipv6?     inet:ipv6-address {feature-list:HAVE_IPV6}?
+---ro tunnel* [destination-vtep-ip]
|   +---ro destination-vtep-ip    -> ../state/destination-vtep-ip
|   +---ro state
|   |   +---ro destination-vtep-ip? inet:ipv4-address
|   |   +---ro source-vtep-ip?    inet:ipv4-address
|   |   +---ro up-down-time?      yang:timeticks
|   |   +---ro tunnel-status?     ipi-vxlan-types:vxlan_tunnel_status_t
|   +---ro counters
|   |   +---ro out-bytes?          yang:counter64
|   |   +---ro out-packets?       yang:counter64
|   |   +---ro in-bytes?          yang:counter64
|   |   +---ro in-packets?        yang:counter64
|   |   +---ro tx-arp-discard-packets? yang:counter64
|   |   +---ro tx-nd-discard-packets? yang:counter64
|   |   +---ro tx-arp-request-packets? yang:counter64
|   |   +---ro tx-arp-reply-packets? yang:counter64
|   |   +---ro tx-neighbor-solicitation-packets? yang:counter64
|   |   +---ro tx-neighbor-advertisement-packets? yang:counter64
|   |   +---ro tx-garp-packets?   yang:counter64
|   |   +---ro tx-gna-packets?    yang:counter64
+---rw untagged-access-interfaces
|   +---rw untagged-access-interface* [untagged-interface-name] {feature-
list:NOT_HAVE_DNX}?

```



```

name |      +--rw untagged-interface-name          -> ../config/untagged-interface-
name |      +--rw config
name |      |      +--rw interface-name?          -> /ipi-interface:interfaces/interface/
name |      |      |      +--rw admin-shutdown?    empty
name |      |      |      +--rw description?       cml-data-types:cml_line_t
name |      |      |      +--rw dynamic-learning-disable? empty
name |      |      |      +--rw access-mac-hold-time? int32
name |      |      |      +--rw arp-nd-flood-suppress? empty {feature-list:HAVE_BGP_EVPN}?
name |      |      |      +--rw garp-gna-enable?   empty {feature-list:HAVE_BGP_EVPN}?
name |      |      |      +--rw mac-address*       cml-data-types:cml_mac_addr_t
name |      |      |      +--rw default-access-interface? empty
name |      |      |      +--rw untagged-interface-name? -> /ipi-interface:interfaces/interface/
name |      +--ro state
name |      |      +--ro interface-name?          -> /ipi-interface:interfaces/interface/
name |      |      |      +--ro admin-shutdown?    empty
name |      |      |      +--ro description?       cml-data-types:cml_line_t
name |      |      |      +--ro dynamic-learning-disable? empty
name |      |      |      +--ro access-mac-hold-time? int32
name |      |      |      +--ro arp-nd-flood-suppress? empty {feature-list:HAVE_BGP_EVPN}?
name |      |      |      +--ro garp-gna-enable?   empty {feature-list:HAVE_BGP_EVPN}?
name |      |      |      +--ro mac-address*       cml-data-types:cml_mac_addr_t
name |      |      |      +--ro default-access-interface? empty
name |      |      |      +--ro untagged-interface-name? -> /ipi-interface:interfaces/interface/
name |      +--rw cache
name |      |      +--rw config
name |      |      |      +--rw arp-cache-disable? empty {feature-list:HAVE_BGP_EVPN}?
name |      |      |      +--rw nd-cache-disable? empty {feature-list:HAVE_BGP_EVPN}?
name |      |      |      +--ro state
name |      |      |      |      +--ro arp-cache-disable? empty {feature-list:HAVE_BGP_EVPN}?
name |      |      |      |      +--ro nd-cache-disable? empty {feature-list:HAVE_BGP_EVPN}?
name |      +--rw map
name |      |      +--rw config
name |      |      |      +--rw vxlan-identifier? -> /vxlan/vxlan-tenants/vxlan-tenant/config/
vxlan-identifier |      |      |      +--rw tenant-description? -> /vxlan/vxlan-tenants/vxlan-tenant/
config/tenant-description |      |      |      +--ro state
name |      |      |      |      +--ro vxlan-identifier? -> /vxlan/vxlan-tenants/vxlan-tenant/config/
vxlan-identifier |      |      |      |      +--ro tenant-description? -> /vxlan/vxlan-tenants/vxlan-tenant/config/
tenant-description |      |      |      |      +--rw host-macs-ipv4
name |      |      |      |      |      +--rw host-mac-ipv4* [mac-address ipv4-address] {feature-
list:NOT_HAVE_DNX}?
name |      |      |      |      |      +--rw mac-address -> ../config/mac-address
name |      |      |      |      |      +--rw ipv4-address -> ../config/ipv4-address
name |      |      |      |      |      +--rw config
name |      |      |      |      |      |      +--rw mac-address? cml-data-types:cml_mac_addr_t

```

```

|     |     | +--rw ipv4-address?   inet:ipv4-address
|     |     +--ro state
|     |         +--ro mac-address?   cml-data-types:cml_mac_addr_t
|     |         +--ro ipv4-address?   inet:ipv4-address
|     +--rw host-macs-ipv6
|     | +--rw host-mac-ipv6* [mac-address ipv6-address] {feature-
list:HAVE_IPV6,feature-list:NOT_HAVE_DNX}?
|     |     +--rw mac-address   -> ../config/mac-address
|     |     +--rw ipv6-address  -> ../config/ipv6-address
|     |     +--rw config
|     |         | +--rw mac-address?   cml-data-types:cml_mac_addr_t
|     |         | +--rw ipv6-address?   inet:ipv6-address
|     |         +--ro state
|     |             +--ro mac-address?   cml-data-types:cml_mac_addr_t
|     |             +--ro ipv6-address?   inet:ipv6-address
|     +--rw access-interface-qos-type-mappings
|     | +--rw access-interface-qos-type-mapping* [profile-map-type] {feature-
list:HAVE_QOS}?
|     |     +--rw profile-map-type   -> ../config/profile-map-type
|     |     +--rw config
|     |         | +--rw profile-map-type?   ipi-vxlan-
types:vxlan_qos_map_profile_type_t
|     |         | +--rw profile-name       string
|     |         +--ro state
|     |             +--ro profile-map-type?   ipi-vxlan-
types:vxlan_qos_map_profile_type_t
|     |             +--ro profile-name       string
+--rw tagged-access-interfaces
| +--rw tagged-access-interface* [interface-name vlan-identifier] {feature-
list:NOT_HAVE_DNX}?
|     +--rw interface-name           -> ../config/interface-name
|     +--rw vlan-identifier           -> ../config/vlan-identifier
|     +--rw config
|     | +--rw tag-protocol-identifier?   string
|     | +--rw interface-name?           -> /ipi-interface:interfaces/interface/
name
|     | +--rw admin-shutdown?           empty
|     | +--rw description?              cml-data-types:cml_line_t
|     | +--rw dynamic-learning-disable?  empty
|     | +--rw access-mac-hold-time?     int32
|     | +--rw arp-nd-flood-suppress?    empty {feature-list:HAVE_BGP_EVPN}?
|     | +--rw garp-gna-enable?          empty {feature-list:HAVE_BGP_EVPN}?
|     | +--rw mac-address*              cml-data-types:cml_mac_addr_t
|     | +--rw vlan-identifier?          string
|     +--ro state
|     | +--ro tag-protocol-identifier?   string
|     | +--ro interface-name?           -> /ipi-interface:interfaces/interface/
name
|     | +--ro admin-shutdown?           empty
|     | +--ro description?              cml-data-types:cml_line_t
|     | +--ro dynamic-learning-disable?  empty
|     | +--ro access-mac-hold-time?     int32

```

```

|     |   +---ro arp-nd-flood-suppress?      empty {feature-list:HAVE_BGP_EVPN}?
|     |   +---ro garp-gna-enable?           empty {feature-list:HAVE_BGP_EVPN}?
|     |   +---ro mac-address*               cml-data-types:cml_mac_addr_t
|     |   +---ro vlan-identifier?           string
|   +---rw cache
|     |   +---rw config
|     |     |   +---rw arp-cache-disable?    empty {feature-list:HAVE_BGP_EVPN}?
|     |     |   +---rw nd-cache-disable?    empty {feature-list:HAVE_BGP_EVPN}?
|     |     |   +---ro state
|     |     |     +---ro arp-cache-disable?  empty {feature-list:HAVE_BGP_EVPN}?
|     |     |     +---ro nd-cache-disable?  empty {feature-list:HAVE_BGP_EVPN}?
|     |   +---rw map
|     |     +---rw config
|   |   |   +---rw vxlan-identifier?         -> /vxlan/vxlan-tenants/vxlan-tenant/config/
vxlan-identifier
|   |   |   +---rw tenant-description?      -> /vxlan/vxlan-tenants/vxlan-tenant/
config/tenant-description
|   |   |   +---ro state
|   |   |     +---ro vxlan-identifier?      -> /vxlan/vxlan-tenants/vxlan-tenant/config/
vxlan-identifier
|   |   |     +---ro tenant-description?    -> /vxlan/vxlan-tenants/vxlan-tenant/config/
tenant-description
|     +---rw host-macs-ipv4
|     |   +---rw host-mac-ipv4* [mac-address ipv4-address]
|     |     +---rw mac-address             -> ../config/mac-address
|     |     +---rw ipv4-address           -> ../config/ipv4-address
|     |     +---rw config
|     |       |   +---rw mac-address?       cml-data-types:cml_mac_addr_t
|     |       |   +---rw ipv4-address?     inet:ipv4-address
|     |       +---ro state
|     |         +---ro mac-address?       cml-data-types:cml_mac_addr_t
|     |         +---ro ipv4-address?     inet:ipv4-address
|   +---rw host-macs-ipv6
|     |   +---rw host-mac-ipv6* [mac-address ipv6-address] {feature-list:HAVE_IPV6}?
|     |     +---rw mac-address             -> ../config/mac-address
|     |     +---rw ipv6-address           -> ../config/ipv6-address
|     |     +---rw config
|     |       |   +---rw mac-address?       cml-data-types:cml_mac_addr_t
|     |       |   +---rw ipv6-address?     inet:ipv6-address
|     |       +---ro state
|     |         +---ro mac-address?       cml-data-types:cml_mac_addr_t
|     |         +---ro ipv6-address?     inet:ipv6-address
|   +---rw access-interface-qos-type-mappings
|     +---rw access-interface-qos-type-mapping* [profile-map-type] {feature-
list:HAVE_QOS}?
|     |   +---rw profile-map-type         -> ../config/profile-map-type
|     |   +---rw config
|     |     |   +---rw profile-map-type?    ipi-vxlan-
types:vxlan_qos_map_profile_type_t
|     |     |   +---rw profile-name         string
|     |     +---ro state

```

```

|          +---ro profile-map-type?   ipi-vxlan-
types:vxlan_qos_map_profile_type_t
|          +---ro profile-name        string
+---rw double-tagged-access-interfaces
| +---rw double-tagged-access-interface* [interface-name vlan-identifier inner-
vlan-identifier] {feature-list:NOT_HAVE_DNX}?
|   +---rw interface-name              -> ../config/interface-name
|   +---rw vlan-identifier              -> ../config/vlan-identifier
|   +---rw inner-vlan-identifier        -> ../config/inner-vlan-identifier
|   +---rw config
|     | +---rw tag-protocol-identifier? string
|     | +---rw interface-name?         -> /ipi-interface:interfaces/interface/
name
|     | +---rw admin-shutdown?         empty
|     | +---rw description?            cml-data-types:cml_line_t
|     | +---rw dynamic-learning-disable? empty
|     | +---rw access-mac-hold-time?   int32
|     | +---rw arp-nd-flood-suppress?  empty {feature-list:HAVE_BGP_EVPN}?
|     | +---rw garp-gna-enable?        empty {feature-list:HAVE_BGP_EVPN}?
|     | +---rw mac-address*            cml-data-types:cml_mac_addr_t
|     | +---rw vlan-identifier?        string
|     | +---rw inner-vlan-identifier?  uint32
|   +---ro state
|     | +---ro tag-protocol-identifier? string
|     | +---ro interface-name?         -> /ipi-interface:interfaces/interface/
name
|     | +---ro admin-shutdown?         empty
|     | +---ro description?            cml-data-types:cml_line_t
|     | +---ro dynamic-learning-disable? empty
|     | +---ro access-mac-hold-time?   int32
|     | +---ro arp-nd-flood-suppress?  empty {feature-list:HAVE_BGP_EVPN}?
|     | +---ro garp-gna-enable?        empty {feature-list:HAVE_BGP_EVPN}?
|     | +---ro mac-address*            cml-data-types:cml_mac_addr_t
|     | +---ro vlan-identifier?        string
|     | +---ro inner-vlan-identifier?  uint32
|   +---rw map
|     | +---rw config
|     | | +---rw vxlan-identifier?     -> /vxlan/vxlan-tenants/vxlan-tenant/config/
vxlan-identifier
|     | | +---rw tenant-description?   -> /vxlan/vxlan-tenants/vxlan-tenant/
config/tenant-description
|     | | +---ro state
|     | |   +---ro vxlan-identifier?   -> /vxlan/vxlan-tenants/vxlan-tenant/config/
vxlan-identifier
|     | |   +---ro tenant-description? -> /vxlan/vxlan-tenants/vxlan-tenant/config/
tenant-description
|     | +---rw cache
|     | | +---rw config
|     | | | +---rw arp-cache-disable?  empty {feature-list:HAVE_BGP_EVPN}?
|     | | | +---rw nd-cache-disable?   empty {feature-list:HAVE_BGP_EVPN}?
|     | | +---ro state
|     | |   +---ro arp-cache-disable?  empty {feature-list:HAVE_BGP_EVPN}?

```

```

|     |     +---ro nd-cache-disable?     empty {feature-list:HAVE_BGP_EVPN}?
|     +---rw host-macs-ipv4
|     |     +---rw host-mac-ipv4* [mac-address ipv4-address] {feature-
list:NOT_HAVE_DNX}?
|     |     +---rw mac-address           -> ../config/mac-address
|     |     +---rw ipv4-address         -> ../config/ipv4-address
|     |     +---rw config
|     |     |     +---rw mac-address?     cml-data-types:cml_mac_addr_t
|     |     |     +---rw ipv4-address?   inet:ipv4-address
|     |     +---ro state
|     |         +---ro mac-address?     cml-data-types:cml_mac_addr_t
|     |         +---ro ipv4-address?   inet:ipv4-address
|     +---rw host-macs-ipv6
|     |     +---rw host-mac-ipv6* [mac-address ipv6-address] {feature-list:HAVE_IPV6}?
|     |     +---rw mac-address         -> ../config/mac-address
|     |     +---rw ipv6-address       -> ../config/ipv6-address
|     |     +---rw config
|     |     |     +---rw mac-address?     cml-data-types:cml_mac_addr_t
|     |     |     +---rw ipv6-address?   inet:ipv6-address
|     |     +---ro state
|     |         +---ro mac-address?     cml-data-types:cml_mac_addr_t
|     |         +---ro ipv6-address?   inet:ipv6-address
|     +---rw access-interface-qos-type-mappings
|         +---rw access-interface-qos-type-mapping* [profile-map-type] {feature-
list:HAVE_QOS}?
|             +---rw profile-map-type   -> ../config/profile-map-type
|             +---rw config
|             |     +---rw profile-map-type?   ipi-vxlan-
types:vxlan_qos_map_profile_type_t
|             |     +---rw profile-name       string
|             +---ro state
|                 +---ro profile-map-type?   ipi-vxlan-
types:vxlan_qos_map_profile_type_t
|                 +---ro profile-name       string
+---ro access-interfaces
    +---ro access-interface* [interface-index]
        +---ro interface-index   -> ../state/interface-index
        +---ro state
            +---ro interface-index?   uint32
            +---ro if-name?           cml-data-types:cml_line_t
            +---ro access-counters
                +---ro rx-arp-discard-packets?   yang:counter64
                +---ro tx-arp-discard-packet?   yang:counter64
                +---ro rx-arp-request-packets?   yang:counter64
                +---ro rx-arp-reply-packets?     yang:counter64
                +---ro tx-arp-request-packet?   yang:counter64
                +---ro tx-arp-reply-packet?     yang:counter64
                +---ro rx-nd-discard-packets?   yang:counter64
                +---ro tx-nd-discard-packet?   yang:counter64
                +---ro rx-neighbor-solicitation-packets? yang:counter64
                +---ro rx-neighbor-advertisement-packets? yang:counter64

```

```

    +---ro tx-neighbor-solicitation-packet?      yang:counter64
    +---ro tx-neighbor-advertisement-packet?    yang:counter64
    +---ro rx-gratuitous-arp-packets?           yang:counter64
    +---ro tx-gratuitous-arp-packets?           yang:counter64
    +---ro rx-gratuitous-na-packets?            yang:counter64
    +---ro tx-gratuitous-na-packets?            yang:counter64
    +---ro rx-data-packets?                     yang:counter64
    +---ro rx-data-bytes?                       yang:counter64
    +---ro tx-data-packets?                     yang:counter64
    +---ro tx-data-bytes?                       yang:counter64

```

rpcs:

```

+---x clear-nvo-vxlan-dynamic-mac-address-table {feature-list:HAVE_VXLAN}?
+---x clear-nvo-vxlan-dynamic-mac-address-table-vnid {feature-list:HAVE_VXLAN}?
| +---w input
|   +---w vxlan-identifier      uint32
|   +---w mac-address?         cml-data-types:cml_mac_addr_t
+---x clear-nvo-vxlan-tunnels {feature-list:HAVE_VXLAN}?
+---x clear-nvo-id-vxlan-tunnels-destip {feature-list:HAVE_VXLAN}?
| +---w input
|   +---w destination-vtep-ip   inet:ipv4-address
+---x clear-nvo-vxlan-mac-stale-entries {feature-list:HAVE_VXLAN}?
| +---w input
|   +---w vxlan-identifier?     uint32
+---x clear-vxlan-untagged-access-port-counters {feature-list:HAVE_VXLAN}?
| +---w input
|   +---w interface-name       string
+---x clear-vxlan-single-tagged-access-port-counters {feature-list:NOT_HAVE_DNX}?
| +---w input
|   +---w interface-name       string
|   +---w vlan-identifier       string
+---x clear-vxlan-double-tagged-access-port-counters {feature-list:NOT_HAVE_DNX}?
| +---w input
|   +---w interface-name       string
|   +---w outer-vlan-identifier uint32
|   +---w inner-vlan-identifier uint32
+---x clear-vxlan-access-port-counters-all {feature-list:HAVE_VXLAN}?
+---x clear-vxlan-network-port-counters {feature-list:HAVE_VXLAN}?
| +---w input
|   +---w destination-vtep-ip   inet:ipv4-address
+---x clear-vxlan-network-port-counters-all {feature-list:HAVE_VXLAN}?

```

notifications:

```

+---n vxlan-tunnel-status-change-notification
  +---ro severity?              cml-data-types:cml_notif_severity_t
  +---ro eventClass?            cml-data-types:cml_notif_class_t
  +---ro destination-vtep-ip?    inet:ipv4-address
  +---ro tunnel-status?         ipi-vxlan-types:vxlan_tunnel_status_t

```

module: ipi-watchdog

```

+--rw watchdog {feature-list:HAVE_PSERVD}?
  +--rw config
    | +--rw watchdog-disabled?    empty
    | +--rw keepalive-interval?   uint16
  +--ro state
    | +--ro watchdog-disabled?    empty
    | +--ro keepalive-interval?   uint16
    | +--ro watchdog-status?      ipi-watchdog-types:watchdog_status_t
    | +--ro all-processes-status? ipi-watchdog-
types:watchdog_global_processes_status_t
  +--rw software-modules
    +--rw software-module* [name]
      +--rw name          -> ../config/name
      +--rw config
        | +--rw name?                ipi-watchdog-
types:watchdog_module_name_t
        | +--rw module-watchdog-status-disabled    empty
      +--ro state
        | +--ro name?                ipi-watchdog-
types:watchdog_module_name_t
        | +--ro module-watchdog-status-disabled    empty
      +--rw process
        +--ro state
          +--ro process-name?        ipi-watchdog-types:watchdog_module_name_t
          +--ro process-status?      ipi-watchdog-types:watchdog_process_status_t
          +--ro start-time?          yang:date-and-time
          +--ro down-reason?         cml-data-types:cml_line_t

rpcs:
  +---x clear-core-dump {feature-list:HAVE_PSERVD,feature-
list:HAVE_ZEBOS_CORE_ANALYSER}?
    +---w input
      +---w core-dump    string

notifications:
  +---n protocol-module-down {feature-list:HAVE_PSERVD}?
    | +--ro severity?          cml-data-types:cml_notif_severity_t
    | +--ro eventClass?       cml-data-types:cml_notif_class_t
    | +--ro name?              ipi-watchdog-types:watchdog_module_name_t
    | +--ro process-name?     ipi-watchdog-types:watchdog_module_name_t
    | +--ro down-reason?      cml-data-types:cml_line_t
  +---n protocol-module-restarted {feature-list:HAVE_PSERVD}?
    +--ro severity?          cml-data-types:cml_notif_severity_t
    +--ro eventClass?       cml-data-types:cml_notif_class_t
    +--ro name?              ipi-watchdog-types:watchdog_module_name_t
    +--ro process-name?     ipi-watchdog-types:watchdog_module_name_t
    +--ro start-time?       yang:date-and-time

```

module: ipi-xstp

```

+--rw xstp
  +--rw interfaces
    | +--rw interface* [name]
    |   +--rw name                               -> ../config/name
    |   +--rw config
    |   | +--rw name?                             -> /ipi-interface:interfaces/
interface/name
    |   | +--rw hello-time?                       uint8
    |   | +--rw port-configuration?              ipi-xstp-types:xstp_port_edge_t
    |   | +--rw enable-automatic-edge-detection? empty
    |   | +--rw bpdu-guard?                      ipi-xstp-types:xstp_bpdu_t
    |   | +--rw bpdu-filter?                    ipi-xstp-types:xstp_bpdu_t
    |   | +--rw enable-root-guard?              empty
    |   | +--rw link-type?                      ipi-xstp-types:xstp_link_type_t
    |   | +--rw enable-restricted-domain-role?  empty
    |   | +--rw enable-restricted-role?        empty
    |   | +--rw enable-restricted-tcn?         empty
    |   +--ro state
    |   | +--ro name?                            -> /ipi-interface:interfaces/
interface/name
    |   | +--ro hello-time?                      uint8
    |   | +--ro port-configuration?              ipi-xstp-types:xstp_port_edge_t
    |   | +--ro enable-automatic-edge-detection? empty
    |   | +--ro bpdu-guard?                     ipi-xstp-types:xstp_bpdu_t
    |   | +--ro bpdu-filter?                    ipi-xstp-types:xstp_bpdu_t
    |   | +--ro enable-root-guard?              empty
    |   | +--ro link-type?                      ipi-xstp-types:xstp_link_type_t
    |   | +--ro enable-restricted-domain-role?  empty
    |   | +--ro enable-restricted-role?        empty
    |   | +--ro enable-restricted-tcn?         empty
    |   +--rw mstp
    |   | +--rw mst-instances
    |   |   +--rw mst-instance* [instance-id]
    |   |     +--rw instance-id                   -> ../config/instance-id
    |   |     +--rw config
    |   |     | +--rw instance-id?                 -> /ipi-network-
instance:network-instances/network-instance/ipi-bridge:bridge/stp/mstp/mst-instances/
mst-instance/instance-id
    |   |     | +--rw enable-instance-restricted-role?  empty
    |   |     | +--rw enable-instance-restricted-tcn?  empty
    |   |     +--ro state
    |   |     | +--ro instance-id?                 -> /ipi-network-
instance:network-instances/network-instance/ipi-bridge:bridge/stp/mstp/mst-instances/
mst-instance/instance-id
    |   |     | +--ro enable-instance-restricted-role?  empty
    |   |     | +--ro enable-instance-restricted-tcn?  empty
    |   |     +--rw customer-spanning-tree {feature-list:HAVE_PROVIDER_BRIDGE}?

```



```

|         +---rw config
|         | +---rw bridge-priority?      uint16
|         | +---rw max-age?              uint8
|         | +---rw hello-time?          uint8
|         | +---rw forward-delay?       uint8
|         | +---rw transmit-hold-count?  uint8
|         +---ro state
|         | +---ro bridge-priority?      uint16
|         | +---ro max-age?              uint8
|         | +---ro hello-time?          uint8
|         | +---ro forward-delay?       uint8
|         | +---ro transmit-hold-count?  uint8
|         +---rw customer-edge
|         | +---rw config
|         | | +---rw port-priority?      uint8
|         | | +---rw path-cost?         uint32
|         | +---ro state
|         | | +---ro port-priority?      uint8
|         | | +---ro path-cost?         uint32
|         +---rw provider-edge
|         | +---rw vlans
|         | | +---rw vlan* [svlan-id]
|         | | | +---rw svlan-id      -> ../config/svlan-id
|         | | | +---rw config
|         | | | | +---rw svlan-id?      uint16
|         | | | | +---rw port-priority? uint8
|         | | | | +---rw path-cost?     uint32
|         | | | +---ro state
|         | | | | +---ro svlan-id?      uint16
|         | | | | +---ro port-priority? uint8
|         | | | | +---ro path-cost?     uint32
+---rw mstp
    +---rw debug
        +---rw config
        | +---rw options?   ipi-xstp-types:mstp_debug_t
        +---ro state
            +---ro options?           ipi-xstp-types:mstp_debug_t
            +---ro terminal-debug-status? ipi-xstp-types:mstp_debug_t

augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance/ipi-bridge:bridge:
+---rw stp
    +---rw config
    | +---rw ageing-time?          ipi-xstp-types:xstp_ageing_time_t
    | +---rw enable-cisco-interoperability? empty
    | +---rw forwarding-delay?     uint8
    | +---rw hello-time?          uint8
    | +---rw max-age?              uint8
    | +---rw max-hops?             uint8
    | +---rw bridge-priority?      uint32
    | +---rw transmit-hold-count?  uint8

```

```
+--ro state
| +--ro ageing-time?                ipi-xstp-types:xstp_ageing_time_t
| +--ro enable-cisco-interopability? empty
| +--ro forwarding-delay?          uint8
| +--ro hello-time?                uint8
| +--ro max-age?                    uint8
| +--ro max-hops?                  uint8
| +--ro bridge-priority?           uint32
| +--ro transmit-hold-count?       uint8
+--rw global
| +--rw config
| | +--rw enable-bpdu-filter?      empty
| | +--rw enable-bpdu-guard?       empty
| | +--rw enable-error-disable-timeout? empty
| | +--rw force-version?           uint8
| | +--rw path-cost-method?        ipi-xstp-types:xstp_path_cost_method_t
| +--ro state
| | +--ro enable-bpdu-filter?      empty
| | +--ro enable-bpdu-guard?       empty
| | +--ro enable-error-disable-timeout? empty
| | +--ro force-version?           uint8
| | +--ro path-cost-method?        ipi-xstp-types:xstp_path_cost_method_t
| +--rw bridge-admins
| | +--rw bridge-admin* [bridge-type disable-spanning-tree]
| |   +--rw bridge-type            -> ../config/bridge-type
| |   +--rw disable-spanning-tree  -> ../config/disable-spanning-tree
| |   +--rw config
| |     | +--rw bridge-forwarding?  ipi-xstp-types:xstp_bridge_forward_t
| |     | +--rw bridge-type?        ipi-xstp-types:xstp_bridge_type_t
| |     | +--rw disable-spanning-tree? empty
| |     +--ro state
| |       +--ro bridge-forwarding?  ipi-xstp-types:xstp_bridge_forward_t
| |       +--ro bridge-type?        ipi-xstp-types:xstp_bridge_type_t
| |       +--ro disable-spanning-tree? empty
| +--rw bridge-shutdowns
|   +--rw bridge-shutdown* [enable-shutdown]
|   +--rw enable-shutdown          -> ../config/enable-shutdown
|   +--rw config
|   | +--rw bridge-forwarding?      ipi-xstp-types:xstp_bridge_forward_t
|   | +--rw enable-shutdown?        empty
|   +--ro state
|     +--ro bridge-forwarding?      ipi-xstp-types:xstp_bridge_forward_t
|     +--ro enable-shutdown?        empty
+--rw mstp
  +--rw config
  | +--rw region-name?              string
  | +--rw revision-number?          uint16
  +--ro state
  | +--ro counters
  | | +--ro topology-changes-count?  uint32
```

```

| | +--ro total-topology-changes-count?  uint32
| | +--ro max-age-count?                  uint32
| +--ro region-name?                      string
| +--ro revision-number?                  uint16
| +--ro topology-change-detected?        boolean
| +--ro last-topology-change?             yang:date-and-time
| +--ro topology-change-initiator?       uint16
| +--ro topology-change-last-received-from? string
| +--ro cist-bridge-id?                   string
| +--ro cist-designated-root?            string
| +--ro cist-regional-root?              string
| +--ro cist-designated-bridge?          string
| +--ro cist-port-root-id?               uint16
| +--ro external-root-path-cost?         uint32
| +--ro internal-root-path-cost?         uint32
+--rw mst-instances
  +--rw mst-instance* [instance-id]
    | +--rw instance-id   -> ../config/instance-id
    | +--rw config
    | | +--rw instance-id?   ipi-xstp-types:mstp_instance_t
    | | +--rw bridge-priority? uint32
    | | +--rw vlan-id?       cml-data-types:cml_range_t
    | +--ro state
    | | +--ro instance-id?   ipi-xstp-
types:mstp_instance_t
    | | +--ro bridge-priority? uint32
    | | +--ro vlan-id?        cml-data-types:cml_range_t
    | | +--ro bridge-id?     string
    | | +--ro designated-root-priority? uint16
    | | +--ro designated-root-address? yang:mac-address
    | | +--ro internal-root-path-cost? uint32
    | | +--ro root-port-ifindex? uint32
    | | +--ro topology-change-detected? boolean
    | | +--ro topology-change-initiator? uint16
    | | +--ro topology-change-last-received-from? string
    | | +--ro last-topology-change? yang:date-and-time
    | | +--ro topology-changes? uint32
    +--rw interfaces
      +--rw interface* [name]
        | +--rw name   -> ../config/name
        | +--rw config
        | | +--rw name?   -> /ipi-interface:interfaces/interface/
name
        | | +--rw path-cost?   uint32
        | | +--rw port-priority? int16
        +--ro state
          +--ro counters
            | +--ro config-bpdu-sent?   uint32
            | +--ro config-bpdu-received? uint32
            | +--ro tcn-bpdu-sent?     uint32
            | +--ro tcn-bpdu-received? uint32

```

```

|           | +--ro similar-bpdu-count?      uint32
interface/name | +--ro name?                               -> /ipi-interface:interfaces/
|           | +--ro path-cost?              uint32
|           | +--ro port-priority?          int16
|           | +--ro port-id?               uint16
|           | +--ro internal-root-path-cost? uint32
|           | +--ro designated-root-priority? uint16
|           | +--ro designated-root-address? yang:mac-address
|           | +--ro designated-bridge-priority? uint16
|           | +--ro designated-bridge-address? yang:mac-address
|           | +--ro designated-port-priority? uint16
|           | +--ro designated-port-num?    uint16
|           | +--ro designated-cost?        uint16
|           | +--ro hello-time-remaining?   uint32
|           | +--ro forward-time-remaining? uint32
|           | +--ro message-age-time-remaining? uint32
|           | +--ro port-state?            ipi-xstp-
types:mstp_port_state_t
|           | +--ro port-role?             ipi-xstp-
types:mstp_port_role_t
+--rw te-mst-instance
  +--rw config
    | +--rw vlan-id*          uint16
    | +--rw disable-spanning-tree? empty
  +--ro state
    | +--ro vlan-id*          uint16
    | +--ro disable-spanning-tree? empty
    | +--ro bridge-id?        string
    | +--ro designated-root-priority? uint16
    | +--ro designated-root-address? yang:mac-address
    | +--ro internal-root-path-cost? uint32
    | +--ro root-port-ifindex? uint32
    | +--ro topology-change-detected? boolean
    | +--ro topology-change-initiator? uint16
    | +--ro topology-change-last-received-from? string
    | +--ro last-topology-change? yang:date-and-time
    | +--ro topology-changes? uint32
  +--rw interfaces
    +--rw interface* [name]
      +--rw name          -> ../config/name
      +--rw config
        | +--rw name?      -> /ipi-interface:interfaces/interface/name
        +--ro state
          +--ro counters
            | +--ro config-bpdu-sent?      uint32
            | +--ro config-bpdu-received?  uint32
            | +--ro tcn-bpdu-sent?         uint32
            | +--ro tcn-bpdu-received?     uint32
            | +--ro similar-bpdu-count?    uint32

```

```

interface/name          +---ro name?          -> /ipi-interface:interfaces/
    +---ro port-id?      uint16
    +---ro internal-root-path-cost?  uint32
    +---ro designated-root-priority?  uint16
    +---ro designated-root-address?   yang:mac-address
    +---ro designated-bridge-priority? uint16
    +---ro designated-bridge-address? yang:mac-address
    +---ro designated-port-priority?  uint16
    +---ro designated-port-num?       uint16
    +---ro designated-cost?           uint16
    +---ro hello-time-remaining?      uint32
    +---ro forward-time-remaining?    uint32
    +---ro message-age-time-remaining? uint32
    +---ro port-state?               ipi-xstp-
types:mstp_port_state_t
    +---ro port-role?               ipi-xstp-
types:mstp_port_role_t
    augment /ipi-network-instance:network-instances/ipi-network-instance:network-
instance/ipi-bridge:bridge/ipi-bridge:bridge-ports/ipi-bridge:interface:
    +---rw mstp-port
        +---rw port-bridge
            +---rw config
                | +---rw path-cost?      uint32
                | +---rw port-priority?  int16
            +---ro state
                +---ro counters
                    | +---ro config-bpdu-sent?      uint32
                    | +---ro config-bpdu-received?  uint32
                    | +---ro tcn-bpdu-sent?         uint32
                    | +---ro tcn-bpdu-received?     uint32
                    | +---ro source-mac-count?      uint32
                    | +---ro similar-bpdu-count?    uint32
                    | +---ro total-src-mac-count?    uint32
                +---ro path-cost?                  uint32
                +---ro port-priority?              int16
                +---ro link-type?                  ipi-xstp-
types:xstp_link_type_t
    +---ro bpdu-filter?                ipi-xstp-types:xstp_bpdu_t
    +---ro bpdu-guard?                 ipi-xstp-types:xstp_bpdu_t
    +---ro root-guard?                 empty
    +---ro cist-path-cost?              uint32
    +---ro cist-priority?               uint32
    +---ro cist-port-id?                uint16
    +---ro cist-port-number?            uint16
    +---ro cist-root?                   string
    +---ro cist-regional-root?          string
    +---ro cist-designated-bridge?      string
    +---ro cist-designated-root-path-cost?  uint32
    +---ro cist-designated-external-root-path-cost?  uint32
    +---ro cist-designated-internal-root-path-cost?  uint32

```

```

        +---ro cist-designated-port-id?                uint32
        +---ro cist-hello-time-remaining?             uint32
        +---ro cist-forward-time-remaining?           uint32
        +---ro cist-message-age-time-remaining?       uint32
        +---ro cist-topology-change-time-remaining?   uint32
        +---ro cist-port-state?                       string
        +---ro cist-port-role?                        ipi-xstp-
types:mstp_port_role_t
        +---ro cist-forward-transitions?              uint32
        +---ro service-vlan-id?                       uint16 {feature-
list:HAVE_PROVIDER_BRIDGE}?

rpcs:
  +---x mstp-terminal-debug-on {feature-list:HAVE_MSTPD}?
  | +---w input
  |   +---w terminal-debug-options    ipi-xstp-types:mstp_debug_t
  +---x mstp-terminal-debug-off {feature-list:HAVE_MSTPD}?
  | +---w input
  |   +---w terminal-debug-options    ipi-xstp-types:mstp_debug_t
  +---x clear-spanning-tree-detected-protocols-per-bridge {feature-list:HAVE_MSTPD}?
  | +---w input
  |   +---w bridge-id    string
  +---x clear-spanning-tree-detected-protocols-per-interface {feature-
list:HAVE_MSTPD}?
  | +---w input
  |   +---w interface-name    string
  +---x clear-spanning-tree-statistics-per-instance-and-bridge {feature-
list:HAVE_MSTPD,feature-list:HAVE_PROVIDER_BRIDGE_OR_HAVE_B_BEB}?
  | +---w input
  |   +---w bridge-id        string
  |   +---w mst-instance-id  ipi-xstp-types:mstp_instance_spbm_type_t
  +---x clear-spanning-tree-statistics-per-interface-vlan-and-bridge {feature-
list:HAVE_MSTPD,feature-list:HAVE_PROVIDER_BRIDGE_OR_HAVE_B_BEB}?
  | +---w input
  |   +---w bridge-id        string
  |   +---w interface-name    string
  |   +---w vlan-id          uint16
  +---x clear-spanning-tree-statistics-per-interface-and-bridge {feature-
list:HAVE_MSTPD}?
  | +---w input
  |   +---w bridge-id        string
  |   +---w interface-name    string
  +---x clear-spanning-tree-statistics-per-bridge {feature-list:HAVE_MSTPD}?
  | +---w input
  |   +---w bridge-id    string
  +---x clear-spanning-tree-statistics-per-vlan-and-bridge {feature-list:HAVE_MSTPD}?
  | +---w input
  |   +---w bridge-id    string
  |   +---w vlan-id      uint16
  +---x clear-spanning-tree-statistics-per-interface-instance-and-bridge {feature-
list:HAVE_MSTPD}?
  | +---w input

```

```
|    +---w bridge-id          string
|    +---w interface-name     string
|    +---w mst-instance-id    ipi-xstp-types:mstp_instance_spbm_type_t
+---x mstp-snmp-restart {feature-list:HAVE_SNMP}?
```

notifications:

```
+---n bridge-topology-change-notification
|  +--ro severity?           cml-data-types:cml_notif_severity_t
|  +--ro eventClass?        cml-data-types:cml_notif_class_t
|  +--ro message?           string
+---n bridge-new-root-notification
   +--ro severity?          cml-data-types:cml_notif_severity_t
   +--ro eventClass?        cml-data-types:cml_notif_class_t
   +--ro message?          string
```

